

Huawei Access Switch ALARM_3825 Minor Alarm SOP

Node: Huawei-Access-Mumbai-MH-60 | **Vendor:** Huawei | **Severity:** Minor | **Alarm Code:** ALARM_3825

Description

This SOP outlines the steps to diagnose and resolve the ALARM_3825 minor alarm on the Huawei Access Switch Node ID: Huawei-Access-Mumbai-MH-60.

Potential Root Causes

Cause	Probability
Physical Layer Issues	High
Fiber Optic Cable Problems	Medium
Optical Transceiver Issues	Low

Diagnostic Commands

```
display current-configuration interface GigabitEthernet 0/0/1
display interface GigabitEthernet 0/0/1
ping 10.1.1.1 source GigabitEthernet 0/0/1
show log | include ALARM_3825
```

Resolution Steps

- Step 1: {'Step': "Run the 'display current-configuration interface GigabitEthernet 0/0/1' command to verify the interface configuration.", 'Action': 'Check the interface configuration and correct any discrepancies.'}
- Step 2: {'Step': "Run the 'display interface GigabitEthernet 0/0/1' command to verify the interface status.", 'Action': 'Check the interface status and correct any issues.'}
- Step 3: {'Step': "Run the 'ping 10.1.1.1 source GigabitEthernet 0/0/1' command to verify connectivity.", 'Action': 'Verify that the interface has connectivity.'}
- Step 4: {'Step': 'Replace the fiber optic cable if it is damaged.', 'Action': 'Replace the fiber optic cable.'}
- Step 5: {'Step': 'Replace the optical transceiver if it is faulty.', 'Action': 'Replace the optical transceiver.'}

Post-Check Verification

```
display interface GigabitEthernet 0/0/1
```

```
ping 10.1.1.1 source GigabitEthernet 0/0/1  
show log | include ALARM_3825
```