

Huawei Provider Edge Router (PE) Alarm SOP: ALARM_8558

Node: Huawei-PE-Bangalore-KA-69 | **Vendor:** Huawei | **Severity:** Major | **Alarm Code:** ALARM_8558

Description

This SOP outlines the steps to diagnose and resolve the Huawei ALARM_8558 on the Provider Edge Router (PE) device Huawei-PE-Bangalore-KA-69.

Potential Root Causes

Cause	Probability
High CPU Utilization	High
Memory Leak	Medium
Interface Flapping	Low

Diagnostic Commands

```
huawei-pe-bangalore-ka-69# show cpu utilization
huawei-pe-bangalore-ka-69# show memory
huawei-pe-bangalore-ka-69# show interface status
```

Resolution Steps

- Step 1: {'Step': 'Step 1: Check CPU Utilization', 'Description': 'Check the CPU utilization on the device to identify if it is within the normal range.', 'Command': 'huawei-pe-bangalore-ka-69# show cpu utilization'}
- Step 2: {'Step': 'Step 2: Identify and Fix CPU-Intensive Processes', 'Description': "Use the 'show processes cpu' command to identify CPU-intensive processes and kill or restart them as needed.", 'Command': 'huawei-pe-bangalore-ka-69# show processes cpu'}
- Step 3: {'Step': 'Step 3: Clear Memory Leaks', 'Description': "Use the 'clear memory' command to clear any memory leaks and free up memory on the device.", 'Command': 'huawei-pe-bangalore-ka-69# clear memory'}
- Step 4: {'Step': 'Step 4: Disable Interface Flapping', 'Description': "Use the 'interface debounce' command to disable interface flapping and prevent further issues.", 'Command': 'huawei-pe-bangalore-ka-69# interface debounce'}

Post-Check Verification

```
huawei-pe-bangalore-ka-69# show cpu utilization
huawei-pe-bangalore-ka-69# show memory
```

```
huawei-pe-bangalore-ka-69# show interface status
```