

Nokia Core Router SOP for ALARM_3257: Critical Alarm

Node: Nokia-Core-Delhi-NCR-1 | **Vendor:** Nokia | **Severity:** Critical | **Alarm Code:** ALARM_3257

Description

This SOP outlines the procedures for diagnosing, resolving, and verifying the fix for the Critical Alarm ALARM_3257 on the Nokia Core Router Node ID: Nokia-Core-Delhi-NCR-1.

Potential Root Causes

Cause	Probability
High CPU Utilization due to Routing Information Protocol (RIP) Routing Table Overflow	High
Misconfigured Route Maps	Medium
Hardware Failure in the Core Router	Low

Diagnostic Commands

```
show rip routing-table | include
show ip route | include
show route-map | include
show platform hardware | include
```

Resolution Steps

- Step 1: {'Step': 'Step 1: Check RIP Routing Table Overflow', 'Description': 'Run the show rip routing-table command to verify the number of routes in the table. If the number exceeds the maximum limit, proceed to the next step.', 'Command': 'show rip routing-table'}
- Step 2: {'Step': 'Step 2: Verify Route Maps', 'Description': 'Run the show route-map command to verify the route maps configuration.', 'Command': 'show route-map'}
- Step 3: {'Step': 'Step 3: Perform a Hardware Failure Isolation', 'Description': 'Run the show platform hardware command to verify the hardware status of the router.', 'Command': 'show platform hardware'}
- Step 4: {'Step': 'Step 4: Clear the Routing Information Base (RIB)', 'Description': 'Run the clear ip bgp * command to clear the RIB.', 'Command': 'clear ip bgp *'}
- Step 5: {'Step': 'Step 5: Re-verify the Routing Table', 'Description': 'Run the show ip route command to verify the routing table after clearing the RIB.', 'Command': 'show ip route'}

Post-Check Verification

```
show rip routing-table | include  
show ip route | include  
show route-map | include
```