

SOP for Resolving Critical Alarm ALARM_6088 on Nokia Core Router Node ID: Nokia-Core-Delhi-NCR-2

Node: Nokia-Core-Delhi-NCR-2 | **Vendor:** Nokia | **Severity:** Critical | **Alarm Code:** ALARM_6088

Description

Alarm ALARM_6088 is triggered on Nokia Core Router Node ID: Nokia-Core-Delhi-NCR-2 indicating a critical issue. This SOP outlines the steps to diagnose, resolve, and verify the fix.

Potential Root Causes

Cause	Probability
High CPU Utilization on Route Processor	High
Memory Leak in Routing Engine	Medium
Misconfigured Routing Protocol	Low

Diagnostic Commands

```
show version
show clock
show cpu utilization
show memory statistics
show routing protocol statistics
```

Resolution Steps

- Step 1: {'Step': '1. Check CPU Utilization', 'Action': "Run command 'show cpu utilization' to check CPU utilization on Route Processor.", 'Command': 'show cpu utilization'}
- Step 2: {'Step': '2. Check Memory Statistics', 'Action': "Run command 'show memory statistics' to check memory statistics on Routing Engine.", 'Command': 'show memory statistics'}
- Step 3: {'Step': '3. Check Routing Protocol Configuration', 'Action': "Run command 'show routing protocol configuration' to check routing protocol configuration.", 'Command': 'show routing protocol configuration'}
- Step 4: {'Step': '4. Reload Route Processor', 'Action': 'Reload Route Processor to clear any stuck processes.', 'Command': 'reload'}
- Step 5: {'Step': '5. Verify Issue Resolved', 'Action': "Run command 'show cpu utilization' to verify that CPU utilization is within normal limits.", 'Command': 'show cpu utilization'}

Post-Check Verification

```
show cpu utilization
show memory statistics
show routing protocol statistics
```