

Nokia Core Router SOP for Alarm Code ALARM_4647

Node: Nokia-Core-Mumbai-MH-2 | **Vendor:** Nokia | **Severity:** Critical | **Alarm Code:** ALARM_4647

Description

This SOP outlines the procedures for diagnosing and resolving the ALARM_4647 (Critical) on Nokia Core Router Node ID: Nokia-Core-Mumbai-MH-2.

Potential Root Causes

Cause	Probability
Hardware failure in the Route Processor (RP)	High
Software bug or misconfiguration in the Routing Information Base (RIB)	Medium
High CPU utilization or memory issues on the RP	Low

Diagnostic Commands

```
show system alarm
show system resource usage
show routing information base (RIB) summary
show cpu utilization
show memory statistics
```

Resolution Steps

- Step 1: {'Step': 'Restart the Route Processor (RP)', 'Description': "Use the 'admin restart' command to restart the RP.", 'CLI_Command': 'admin restart'}
- Step 2: {'Step': 'Check and repair the RIB', 'Description': "Use the 'show routing information base (RIB) summary' command to identify any issues, then use the 'config routing information base (RIB) modify' command to repair any errors.", 'CLI_Commands': ['show routing information base (RIB) summary', 'config routing information base (RIB) modify']}
- Step 3: {'Step': 'Optimize RP resources', 'Description': "Use the 'show system resource usage' command to identify any resource bottlenecks, then use the 'config system resource optimize' command to optimize resources.", 'CLI_Commands': ['show system resource usage', 'config system resource optimize']}

Post-Check Verification

```
show system alarm
show system resource usage
```

```
show routing information base (RIB) summary
show cpu utilization
show memory statistics
```