

MCAL Integration Package



Document Information

History

Author	Date	Version	Remarks
	-		
			-
			-
			_
			-
			-
			-
			-
			-

Reference Documents

110.	No.	Source	Title	
------	-----	--------	-------	--





Caution



Contents

1	Introduction7	
2	First Steps9	
3	Workflow12	
	4 11. 0 3	Œ





Illustrations

-	
-	
-	
-	
-	
-	
-	
-	
-	
-	
-	
-	
Tables	
_	

.....



1 Introduction

MICROSAR MCAL Integration Package

3rd party MCAL

-

- 1. Single configuration tool usage
- 2. Mixed configuration tool usage
- 3. Split configuration tool usage

1.1 Responsibility

MCAL integration

1.2 Support requests

MCAL integration

-

VECTOR	>
--------	---

1.3 Mix between AUTOSAR specification versions

_

MCAL Integration

Package (mixed ASR)



2 First Steps

MCAL integration

2.1 Delivery structure

MCAL

integration

- > BSW\<MCAL_\u03b4C>:
- > BSWMD\<MCAL_\u00fcC>
- > DaVinciConfigurator\Generator\<MCAL_\u03c4C>
- > ThirdParty\<MCAL_µC>\Supply
 - _

 - >

1

Caution

ThirdParty\<MCAL_µC>\Supply



Note

Supply

ThirdParty\<MCAL_\u00fcC>\Supply
.\MC-ISAR_AS4XX_AURIX_TC27X_CA_PB_BASE_V100
.\MC-ISAR_AS4XX_AURIX_TC27X_CA_PB_MEM_V100
.\Tresos

- > ThirdParty\<MCAL_\u03c4C>\VectorIntegration
- 2.2 Starting up
- 2.2.1 MCAL delivered within Vector SIP



> Compiler_cfg.h MemMap.h

> BSWMD\<MCAL_µC>

>

2.2.3 MCAL Update needed



Practical Procedure

Script_MCAL_Prepare.bat --undo Script_MCAL_Prepare.bat --prepare



Caution

>

>

Script MCAL Prepare.bat

Script MCAL Prepare.bat

--prepare



3 Workflow

-



Note

 $Release Notes_3rd Party MCAL_Vector Integration.pdf$



Multimedia Link

3.1 Single configuration tool usage



Prerequisite	
Advantages	Disadvantages

3.2 Mixed configuration tool usage


>

>

>

one tool solution





Recommended/mandatory step Optional step


-



Prerequisite	
Advantages	Disadvantages

,,

Practical Procedure (startup) 1. 2. 3. 4. 5.



3.3 Split configuration tool usage



Prerequisite	
Advantages	Disadvantages



4 Configuration tools



Note

4.1 Vector DaVinci Configurator

4.2 EB tresos™

Tresos\bin


Studio_documentation_users_guide

4.2.1 Setting up a new Configuration Project

>

>






4.2.2 Project Details

- >
- >
- >
- >
- >






preferences.xdm

<d:var name="GenerationPath" value="output"/>


4.2.3 Selection of components


Dem Events EcuM run modes





4.2.4 Creation of importers and exporters





VECTO	OR >
4.2.5	Configure the MCAL components
4.2.6	Generation of the 3rd party MCAL
-	
4.3	Configuration hints for parallel usage of DaVinci Configurator and EB tresos™
EcuM/	Dem/DemConfigSet/DemEventParameter /EcuMConfiguration/EcuMCommonConfiguration/EcuMWakeupSource
	Dio Ports Mcu ConfigSets Mcu ClockReferences Fee Blocks
4.3.1	Vector DaVinci Configurator 5
-	




4.3.2 EB tresos™


>

>

DemEventParameter 0

Event ID Event Kind





**WDG Driver (Wdg) **Pwm (Pwm) **MCU Driver (Mcu) **Gpt (Gpt) **DemEventParameter

Name* DemEventParameter_0

General DemInitMonitorName DemDTCClassRef DemExtendedDataRef DemFreezeFrameClassR

DemEventID (1 -> 65535)* 65535

DemEventKind* DEM_EVENT_KIND_BSW

VECTOR

5 Known Issues

5.1 MCAL and SIP storage location using Vector Makesupport

D:\ -

5.2 Long path names



Caution

D:\<ECU-Acronym>

D:\BCM

5.3 Missing configuration items within imported configuration





Note

- 5.4 Configuration Export with EB tresos™ Version 13.0.0
- 5.5 Error messages regarding CommonPublishedInformation with EB tresos™

Invalid value for node "/AUTOSAR/TOP-LEVELPACKAGES/Wdg/ELEMENTS/Wdg/CommonPublishedInformation/VendorId
": Value "" is no number



6 Glossary and Abbreviations

6.1 Glossary

Term	Description

6.2 Abbreviations

Abbreviation	Description



7 Contact

>

>

>

>

>

>

www.vector.com