Voltra E5 Owner's Manual

1 Getting Started

This manual covers the Voltra E5 electric hatchback, model years 2026 and 2027.

1.1 Keys and Access

The E5 ships with two card keys and one key fob. Hold a card key against the B-pillar reader to unlock. The fob unlocks the car when you are within two metres and a door handle is touched. If the fob battery is flat, place the fob in the cup holder to start the car.

1.2 Driver Display

The 10.25-inch driver display shows speed, range and active warnings. Swipe the left steering-wheel pad to switch between the Range, Energy and Trip views.

1.3 Seat Adjustment

Front seats adjust electrically in eight directions. The driver seat stores three memory positions linked to each key.

2 Charging

The E5 accepts AC charging up to 11 kW and DC fast charging up to 150 kW.

2.1 Home Charging

With an 11 kW wall box a full charge from empty takes about 7.5 hours. On a standard household socket using the portable charger the same charge takes about 38 hours. Set the charging current limit in Settings > Charging if your home circuit is shared.

2.2 Public DC Fast Charging

Peak DC power is 150 kW. Charging from 10 to 80 percent takes about 28 minutes when the battery is at operating temperature. Use Battery Preconditioning before arriving at a fast charger in cold weather.

2.3 Scheduled Charging

Scheduled charging starts the session at a chosen time, for example to use off-peak electricity tariffs. A departure time can be set instead, and the car will finish charging and warm the cabin by then.

2.4 Charging Port Light

The ring around the charging port changes colour to show charging status.

Colour	Meaning
White	Port open, ready to connect
Pulsing green	Charging

Solid green	Charging complete
Amber	Charging fault, see warning code
Blue	Scheduled charging is waiting to start

3 Driving

3.1 Drive Modes

Eco limits power to 110 kW and softens accelerator response to extend range. Normal gives the full 160 kW. Sport sharpens steering weight and throttle response. Snow reduces torque at the front axle to limit wheel spin.

3.2 Regenerative Braking

Regeneration has four levels, 0 to 3. Level 3 enables one-pedal driving and can bring the car to a full stop. Regeneration is reduced automatically when the battery is full or very cold.

3.3 Towing

The E5 may tow a braked trailer of up to 1,200 kg or an unbraked trailer of up to 750 kg. Maximum vertical load on the tow ball is 75 kg. Expect range to fall by 30 to 40 percent while towing.

4 High-Voltage Battery

The 77 kWh lithium-ion battery sits under the cabin floor.

4.1 Battery Care

For daily use set the charge limit to 80 percent. Charge to 100 percent only before long trips. Avoid leaving the car below 10 percent for long periods.

4.2 Storage

If the car will be parked for more than a month, leave it at 50 to 60 percent charge and check the charge level every three months.

4.3 Warranty

Coverage: 8 years or 160,000 km, whichever comes first. The battery is covered against capacity falling below 70 percent of its original capacity during this period.

5 Maintenance

5.1 Service Schedule

Have the car serviced every 24 months or 30,000 km, whichever comes first. Each service includes a brake inspection, coolant check and software update.

5.2 Tyres

Recommended cold tyre pressure is 2.5 bar at the front and 2.7 bar at the rear. Rotate the tyres every

10,000 km. Replace a tyre when tread depth falls below 3 mm.

5.3 Brake Fluid

Replace the brake fluid every 2 years regardless of distance driven.

5.4 Cabin Air Filter

Replace the cabin air filter every 12 months. In dusty climates replace it every 6 months.

5.5 12V Battery

A conventional 12V battery powers locks, lights and the infotainment system. Its expected life is about 4 years. If it is flat the car cannot be unlocked with the card key; use the mechanical key hidden in the fob.

6 Warranty

Warranty starts on the date of first registration.

6.1 Basic Vehicle Warranty

Coverage: 3 years or 100,000 km, whichever comes first. Covers defects in materials and workmanship of the vehicle.

6.2 Drive Unit

Coverage: 6 years or 150,000 km, whichever comes first. Covers the electric motors, inverters and reduction gears.

6.3 Paint and Corrosion

Paint defects are covered for 3 years. Rust perforation of body panels from the inside out is covered for 12 years with no distance limit.

6.4 Exclusions

Warranty does not cover tyres, wiper blades, brake pads, damage from accidents, or damage caused by fitting non-approved accessories.

7 Warning Codes

Warning codes appear on the driver display and in the Voltra app.

7.1 Charging Codes

Code	Meaning	Action
E-201	Charging cable not locked	Reinsert the connector until it clicks
E-204	Charging port overheated	Stop charging and let the port cool for 30 minutes
E-207	Charger communication lost	Try another charger; if it repeats, contact service

E-210	Ground fault at the charger	Do not charge from this socket; have it inspected

7.2 Drivetrain Codes

Code	Meaning	Action
D-301	Motor temperature high	Drive gently; power is limited until it cools
D-305	Inverter fault	Stop safely and call roadside assistance
D-312	Gear selector fault	Park the car and contact service

7.3 Battery Codes

Code	Meaning	Action
B-401	Battery temperature high	Stop and let the battery cool before driving on
B-406	Cell imbalance detected	Charge to 100 percent once; if it repeats, contact service
B-415	Insulation fault	Stop safely, leave the vehicle and call roadside assistance