1
1 / 400 INDEX
1 / 400 INDEX
1 / 400 INDEX 2 / 402 INFORMATION 46 / 560 CONTROL LIGHTS 93 / 665 OUTPUT PLC (ST) 3 / 405 CONTROL PANEL DIMENSIONS 48 / 600 PORER SUPPLY PC-SYSTEM 95 / 666 OUTPUT PLC (ST) 4 / 407 CONTROL PANEL DIMENSIONS 48 / 601 PORER SUPPLY PC-SYSTEM 95 / 667 INPUT PLC (ST) 5 / 410 CONTROL BOX LIGHT 5 / 411 CONTROL BOX LIGHT 6 / 411 CONTROL BOX LIGHT 7 / 413 PLATE BOX LIGHT 7 / 413 PLATE BOX LIGHT 8 / 417 PLATE BOX LIGHT 9 / 417 PLATE BOX LIGHT 1 / 413 PLATE BOX LIGHT 1 / 413 PLATE BOX LIGHT 1 / 414 PLATE BOX LIGHT 1 / 415 PLATE BOX LIGHT 1 / 415 PLATE BOX LIGHT 1 / 416 PLATE BOX LIGHT 1 / 417 PLATE BOX LIGHT 1 / 418 PLATE BOX LIGHT 1 / 419 PLATE BOX LIGHT 1 / 419 PLATE BOX LIGHT 1 / 410 PLATE BOX LIGHT 1 / 420 CIRCUIT BREAKERS 5 / 613 INPUT PLC (FS) 1 / 410 PLATE BOX BOX LIGHT 1 / 421 CIRCUIT BREAKERS 5 / 613 INPUT PLC (FS) 1 / 421 CIRCUIT BREAKERS 5 / 613 INPUT PLC (FS) 1 / 422 PLATE BOX LIGHT 1 / 422 CIRCUIT BREAKERS 5 / 613 INPUT PLC (FS) 1 / 424 PLATE BOX LIGHT 1 / 429 PLATE BOX LIGHT 1 / 420 PLATE BOX LIGH
1 / 400
1 / 400 INDEX
1 / 400
1 / 400 INDEX 2 / 402 INFORMATION 47 / 568 CONTROL LIGHTS 3 / 405 CONTROL PANEL DIMENSIONS 48 / 600 POWER SUPPLY PC-SYSTEM 4 / 407 CONTROL PANEL DIMENSIONS 49 / 601 POWER SUPPLY PC-SYSTEM 5 / 410 CONTROL BOX LIGHT 50 / 605 ANALOG INPUT (FS) 6 / 411 POWER SUPPLY 3X400/230V 51 / 609 INPUT PLC (FS) 7 / 413 THREE-PHASE MOTIONS 52 / 610 INPUT PLC (FS) 8 / 417 PLATFORM PARK RAIL 53 / 611 INPUT PLC (FS) 8 / 417 PLATFORM PARK RAIL 53 / 611 INPUT PLC (FS) 10 / 421 CIRCUIT BREAKERS 55 / 613 INPUT PLC (FS) 11 / 422 CIRCUIT BREAKERS 55 / 613 INPUT PLC (FS) 11 / 422 CIRCUIT BREAKERS 56 / 614 INPUT PLC (FS) 12 / 423 LOW VOLTAGE 24V/DC 57 / 615 INPUT PLC (FS) 13 / 424 FUSE FAULT 58 / 616 INPUT PLC (FS) 14 / 428 HYDR. TENS. SOLENDID 59 / 617 INPUT PLC (FS) 15 / 450 RESET BUTTONS 60 / 618 INPUT PLC (FS) 16 / 455 READY 17 / 460 EMERGENCY DRIVE 62 / 620 OUTPUT PLC (FS) 18 / 461 CONTROLS PLATFORM PARK RAIL 64 / 622 INPUT PLC (FS) 19 / 464 CONTROLS PLATFORM PARK RAIL 64 / 622 INPUT PLC (FS) 20 / 470 SLOW 1 165 / 623 20 / 470 SLOW 1 165 / 623 20 / 470 SLOW 1 165 / 623 21 / 473 SLOW 2 PRESSURE TRANSDUCER HYDRAULIC TENSIONING 7 / 635 INPUT PLC (FS) 22 / 428 ROPE POSITION MONITORING 70 / 635 INPUT PLC (FS) 23 / 480 ROPE POSITION MONITORING 70 / 635 INPUT PLC (FS) 24 / 481 ROPE POSITION MONITORING 70 / 635 INPUT PLC (FS) 25 / 482 ROPE POSITION MONITORING 70 / 636 INPUT PLC (FS) 26 / 485 HIND MARNING 71 / 637 INPUT PLC (FS) 37 / 486 HIND MARNING 71 / 637 INPUT PLC (FS) 38 / 500 CONNECTIONS DRIVE STATION 75 / 641 INPUT PLC (FS) 39 / 493 CONNECTIONS DRIVE STATION 76 / 643 INPUT PLC (FS) 31 / 496 CONNECTIONS DRIVE STATION 76 / 643 INPUT PLC (FS) 35 / 507 SIGNAL BUTTONS 80 / 645 OUTPUT PLC (FS) 36 / 508 SIGNAL BUTTONS 80 / 645 OUTPUT PLC (FS) 37 / 486 HIND MARNING 71 / 637 INPUT PLC (FS) 38 / 500 CONNECTIONS DRIVE STATION 77 / 643 INPUT PLC (FS) 39 / 500 CONNECTIONS DRIVE STATION 77 / 648 OUTPUT PLC (FS) 31 / 496 CONNECTIONS DRIVE STATION 76 / 645 OUTPUT PLC (FS) 37 / 508 SIGNAL BUTTONS 80 / 645 OUTPUT PLC (FS) 38 / 500 SIGNAL BUTTONS 80 / 6
1 / 400 INDEX 2 / 402 INFORMATION 47 / 568 CONTROL LIGHT 3 / 405 CONTROL PANEL DIMENSIONS 48 / 600 POWER SUPPLY 4 / 407 CONTROL PANEL DIMENSIONS 49 / 601 POWER SUPPLY 5 / 410 CONTROL BOX LIGHT 50 / 605 ANALOG INPUT 6 / 411 POWER SUPPLY 3X400/230V 51 / 609 INPUT PLC (FS 7 / 413 THREE-PHASE MOTORS 52 / 610 INPUT PLC (FS 8 / 417 PLATFORM PARK RAIL 53 / 611 INPUT PLC (FS 9 / 420 POWER SUPPLY 24V/DC 54 / 612 INPUT PLC (FS 10 / 421 CIRCUIT BREAKERS 55 / 613 INPUT PLC (FS 11 / 422 CIRCUIT BREAKERS 55 / 613 INPUT PLC (FS 11 / 422 CIRCUIT BREAKERS 56 / 614 INPUT PLC (FS 12 / 423 LOW VOLTAGE 24V/DC 57 / 615 INPUT PLC (FS 13 / 424 FUSE FAULT 58 / 616 INPUT PLC (FS 14 / 429 HYDR. TENS. SOLENOID 59 / 617 INPUT PLC (FS 15 / 450 RESET BUTTONS 60 / 618 INPUT PLC (FS 16 / 455 READY 61 / 619 OUTPUT PLC (FS 20 / 470 SLOW 1 21 / 473 SLOW 1 22 / 479 PRESSURE TRANSDUCER HYDRAULIC TENSIONING? 633 621 INPUT PLC (FS 22 / 479 PRESSURE TRANSDUCER HYDRAULIC TENSIONING? 633 OUTPUT PLC (FS 22 / 479 PRESSURE TRANSDUCER HYDRAULIC TENSIONING? 633 OUTPUT PLC (FS 24 / 481 ROPE POSITION MONITORING 69 / 635 INPUT PLC (SS 25 / 482 ROPE POSITION MONITORING 77 / 637 INPUT PLC (SS 26 / 485 HIND HARNING 71 / 637 INPUT PLC (ST 27 / 486 HIND HARNING 72 / 638 INPUT PLC (ST 28 / 490 CONNECTIONS DRIVE STATION 73 / 639 INPUT PLC (ST 27 / 486 HIND HARNING 71 / 637 INPUT PLC (ST 28 / 490 CONNECTIONS DRIVE STATION 75 / 641 INPUT PLC (ST 31 / 496 CONNECTIONS DRIVE STATION 76 / 642 INPUT PLC (ST 32 / 500 CONNECTIONS DRIVE STATION 76 / 642 INPUT PLC (ST 33 / 504 CONNECTIONS DRIVE STATION 77 / 643 INPUT PLC (ST 34 / 505 INPUT PLC (ST 35 / 507 SIGNAL BUTTONS 83 / 649 OUTPUT PLC (ST 36 / 508 SIGNAL 81 / 647 OUTPUT PLC (ST 37 / 511 MAINTENANCE LOCK OUT 82 / 648 OUTPUT PLC (ST 38 / 500 STOP BUTTONS 83 / 649 OUTPUT PLC (ST 39 / 526 RELAY 86 / 652 OUTPUT PLC (ST 496 FLAY 86 / 652 OUTPUT PLC (ST 497 / 653 INPUT PLC (ST 497 / 654 OUTPUT PLC (ST 497 / 655 OUTPUT PLC (ST 497 / 655 OUTPUT PLC (ST 497 / 656 OUTPUT PLC (ST 497 / 657 OUTPUT PLC (ST 497 / 657 OUTPUT PLC (ST 497 /
1 / 400 INDEX 2 / 402 INFORMATION 47 / 588 3 / 405 CONTROL PANEL DIMENSIONS 48 / 600 4 / 407 CONTROL PANEL DIMENSIONS 49 / 601 5 / 410 CONTROL BOX LIGHT 50 / 605 6 / 411 POMER SUPPLY 3X400/230V 51 / 609 7 / 413 THREE-PHASE MOTORS 52 / 610 8 / 417 PLATFORM PARK RAIL 53 / 611 9 / 420 POMER SUPPLY 24V/DC 54 / 612 10 / 421 CIRCUIT BREAKERS 55 / 613 11 / 422 CIRCUIT BREAKERS 55 / 613 11 / 422 CIRCUIT BREAKERS 56 / 614 12 / 423 LOM VOLTAGE 24V/DC 57 / 615 13 / 424 FUSE FAULT 58 / 616 14 / 429 HYDR. TENS. SOLENOID 59 / 617 15 / 450 RESET BUTIONS 60 / 618 16 / 455 READY 61 / 619 17 / 460 EMERGENCY DRIVE 62 / 620 18 / 461 TYRE CONVEYOR 63 / 621 19 / 464 CONTROLS PLATFORM PARK RAIL 64 / 622 20 / 470 SLOW 1 65 / 623 21 / 473 SLOW 2 66 / 624 22 / 479 PRESSURE TRANSDUCER HYDRAULIC TENSIONIMO 68 / 633 23 / 480 ROPE POSITION MONITORING 69 / 633 24 / 481 ROPE POSITION MONITORING 69 / 633 25 / 482 ROPE POSITION MONITORING 70 / 636 26 / 485 WIND WARNING 71 / 637 27 / 486 WIND WARNING 72 / 638 28 / 490 CONNECTIONS DRIVE STATION 74 / 640 30 / 495 CONNECTIONS DRIVE STATION 75 / 641 31 / 496 CONNECTIONS DRIVE STATION 75 / 641 31 / 496 CONNECTIONS DRIVE STATION 75 / 641 31 / 496 CONNECTIONS DRIVE STATION 75 / 641 31 / 496 CONNECTIONS DRIVE STATION 75 / 641 31 / 496 CONNECTIONS DRIVE STATION 75 / 641 31 / 496 CONNECTIONS DRIVE STATION 75 / 641 31 / 496 CONNECTIONS DRIVE STATION 76 / 642 32 / 500 CONNECTIONS DRIVE STATION 77 / 633 33 / 504 CONNECTIONS DRIVE STATION 77 / 643 34 / 505 TELEPHONE 79 / 645 35 / 507 SIGNAL BUTTONS 80 / 646 36 / 508 SIGNAL 81 / 647 37 / 511 MAINTENANCE LOCK OUT 82 / 648 38 / 520 STOP BUTTONS 85 / 651 41 / 525 RELAY 87 / 653
1 / 400 INDEX 2 / 402 INFORMATION 3 / 405 CONTROL PANEL DIMENSIONS 4 / 407 CONTROL PANEL DIMENSIONS 5 / 410 CONTROL BOX LIGHT 6 / 411 POWER SUPPLY 3X400/230V 7 / 413 THREE-PHASE MOTORS 8 / 417 PLATFORM PARK RAIL 9 / 420 POWER SUPPLY 24V/DC 10 / 421 CIRCUIT BREAKERS 11 / 422 CIRCUIT BREAKERS 12 / 423 LOW VOLTAGE 24V/DC 13 / 424 FUSE FAULT 14 / 429 HYDR. TENS. SOLENOID 15 / 450 RESET BUTTONS 16 / 455 READY 17 / 460 EMERGENCY DRIVE 18 / 461 TYRE CONVEYOR 19 / 464 CONTROLS PLATFORM PARK RAIL 20 / 470 SLOW 1 21 / 473 SLOW 2 22 / 479 PRESSURE TRANSDUCER HYDRAULIC TENSIONI 23 / 480 ROPE POSITION MONITORING 24 / 481 ROPE POSITION MONITORING 24 / 481 ROPE POSITION MONITORING 25 / 482 ROPE POSITION MONITORING 26 / 485 WIND WARNING 27 / 486 WIND WARNING 28 / 490 CONNECTIONS DRIVE STATION 29 / 493 CONNECTIONS DRIVE STATION 30 / 495 CONNECTIONS DRIVE STATION 31 / 496 CONNECTIONS DRIVE STATION 32 / 500 CONNECTIONS DRIVE STATION 33 / 504 CONNECTIONS DRIVE STATION 34 / 505 TELEPHONE 35 / 507 SIGNAL BUTTONS 36 / 508 SIGNAL 37 / 511 MAINTENANCE LOCK OUT 38 / 520 STOP BUTTONS 39 / 522 EMERG. STOP BUTTONS 40 / 523 STOP EB BUTTONS 41 / 525 RELAY 42 / 526 RELAY
1 / 400 INDEX 2 / 402 INFORMATION 3 / 405 CONTROL PANEL DIMENSIONS 4 / 407 CONTROL PANEL DIMENSIONS 5 / 410 CONTROL BOX LIGHT 6 / 411 POWER SUPPLY 3X400/230V 7 / 413 THREE-PHASE MOTORS 8 / 417 PLATFORM PARK RAIL 9 / 420 POWER SUPPLY 24V/DC 10 / 421 CIRCUIT BREAKERS 11 / 422 CIRCUIT BREAKERS 12 / 423 LOW VOLTAGE 24V/DC 13 / 424 FUSE FAULT 14 / 429 HYDR. TENS. SOLENOID 15 / 450 RESET BUTTONS 16 / 455 READY 17 / 460 EMERGENCY DRIVE 18 / 461 TYRE CONVEYOR 19 / 464 CONTROLS PLATFORM PARK RAIL 20 / 470 SLOW 1 21 / 473 SLOW 2 22 / 479 PRESSURE TRANSDUCER HYDRAUL 23 / 480 ROPE POSITION MONITORING 24 / 481 ROPE POSITION MONITORING 25 / 482 ROPE POSITION MONITORING 26 / 485 WIND WARNING 27 / 486 WIND WARNING 28 / 490 CONNECTIONS DRIVE STATION 30 / 495 CONNECTIONS DRIVE STATION 31 / 496 CONNECTIONS DRIVE STATION 32 / 500 CONNECTIONS DRIVE STATION 33 / 504 CONNECTIONS DRIVE STATION 34 / 505 TELEPHONE 35 / 507 SIGNAL BUTTONS 36 / 508 SIGNAL 37 / 511 MAINTENANCE LOCK OUT 38 / 520 STOP BUTTONS 39 / 522 EMERG. STOP BUTTONS 40 / 523 STOP EB BUTTONS 41 / 525 RELAY
1 / 400 INDEX 2 / 402 INFORMATION 3 / 405 CONTROL PANE 4 / 407 CONTROL PANE 5 / 410 CONTROL BOX 6 / 411 POWER SUPPLY 7 / 413 THREE-PHASE 8 / 417 PLATFORM PAR 9 / 420 POWER SUPPLY 10 / 421 CIRCUIT BREA 11 / 422 CIRCUIT BREA 12 / 423 LOW VOLTAGE 13 / 424 FUSE FAULT 14 / 429 HYDR. TENS. 15 / 450 RESET BUTTON 16 / 455 READY 17 / 460 EMERGENCY DR 18 / 461 TYRE CONVEYO 19 / 464 CONTROLS PLA 20 / 470 SLOW 1 21 / 473 SLOW 2 22 / 479 PRESSURE TRA 23 / 480 ROPE POSITIO 24 / 481 ROPE POSITIO 25 / 482 ROPE POSITIO 26 / 485 WIND WARNING 27 / 486 WIND WARNING 28 / 490 CONNECTIONS 30 / 495 CONNECTIONS 30 / 495 CONNECTIONS 31 / 496 CONNECTIONS 32 / 500 CONNECTIONS 33 / 504 CONNECTIONS 34 / 505 TELEPHONE 35 / 507 SIGNAL BUTTO 36 / 508 SIGNAL 37 / 511 MAINTENANCE 38 / 520 STOP BUTTONS 39 / 522 EMERG. STOP 40 / 523 STOP EB BUTT 41 / 525 RELAY 42 / 526 RELAY
1 / 400 2 / 402 3 / 405 4 / 407 5 / 410 6 / 411 7 / 413 8 / 417 9 / 420 10 / 421 11 / 422 12 / 423 13 / 424 14 / 429 15 / 450 16 / 455 17 / 460 18 / 461 19 / 464 20 / 470 21 / 473 22 / 479 23 / 480 24 / 481 25 / 482 26 / 485 27 / 486 28 / 490 29 / 493 30 / 495 31 / 496 32 / 500 33 / 504 34 / 505 35 / 507 36 / 508 37 / 511 38 / 520 39 / 522 40 / 523 41 / 525 42 / 526
1 / 400 2 / 402 3 / 405 4 / 407 5 / 410 6 / 411 7 / 413 8 / 420 10 / 421 11 / 422 12 / 423 13 / 424 14 / 429 15 / 450 16 / 455 17 / 460 18 / 461 19 / 464 20 / 470 21 / 473 22 / 479 23 / 480 24 / 481 25 / 485 27 / 486 28 / 490 29 / 493 30 / 495 31 / 496 32 / 500 33 / 504 34 / 505 35 / 507 36 / 508 37 / 511 38 / 520 40 / 523 41 / 525 42 / 526
I











































































































































































































