Libero SoC License Installation Guide

Libero SoC v2026.1

Introduction (Ask a Question)

This guide provides a quick reference for acquiring and installing a license, enabling you to start developing with Microchip FPGA. To use the Libero® System-on-Chip (SoC) Design Suite, perform the following steps:

1. Download the Libero SoC Design Suite from the Microchip website: www.microchip.com/libero.
2. Run the installer and follow the on-screen instructions to complete the setup.
3. Obtain a valid Libero license.

© 2026 Microchip Technology Inc. and its subsidiaries

Table of Contents

Introduction....1

1. Libero License Installation Prerequisites....3
   1.1. Obtain a License....3

2. License Installation....5
   2.1. Installing a Node-Locked License....5

3. Installing a Floating License....6
   3.1. Installing a Floating License on a Windows Server....6
   3.2. Installing a Floating License on a Linux Server....6

4. Connecting the Client to the License Server....8
   4.1. Setting Up an Environment Variable on a Windows Client Machine....8
   4.2. Setting Up an Environment Variable on the UNIX or Linux Client Side....8
   4.3. Downloading and Installing IP MegaVault without an Internet Connection....8

5. Revision History....10

Microchip FPGA Support....11

Microchip Information....12
   Trademarks....12
   Legal Notice....12
   Microchip Devices Code Protection Feature....12

© 2026 Microchip Technology Inc. and its subsidiaries

1. Libero License Installation Prerequisites (Ask a Question)

This section describes the prerequisites for installing the Libero license.

1.1. Obtain a License (Ask a Question)

The Libero SoC Design Suite supports the following types of licenses:

- Node-locked license. This license is supported on Windows® operating systems only.
- Floating license. This license is supported on Windows, UNIX®, and Linux® operating systems.

Make sure to request or purchase the appropriate license for the Libero SoC Design Suite. To determine the best license for your needs, see the License Selector Guide.

1.1.1. Free License (Silver) (Ask a Question)

To obtain the free license (Silver), perform the following steps:

1. Sign in to microchipDIRECT.
2. Go to the License page at www.microchipdirect.com/fpga-software-products.
   The **FPGA Software and IP Core Products** page appears.
3. For a new license, select **Request Free License**.
4. To obtain either the Libero Silver Floating license or the Node-locked license, in the **Register** column, select **Register**.
5. At the next page, specify the DiskID or MACID, depending on the type of license you selected in the previous step, and then select **Register**.
   The requested software license is delivered through microchipDIRECT email.

> **Attention:** If you do not receive an email with your license in 15 to 30 minutes, log in again to the portal and download the license.

1.1.2. Paid License (Gold or Platinum) (Ask a Question)

To obtain the paid license (Gold or Platinum), perform the following steps:

1. Sign in to microchipDIRECT.
2. Go to the Libero software page at www.microchipdirect.com/fpga-software-products.
3. Choose the desired Libero SoC product license and complete the on-screen steps to order the license.
   When you complete your purchase, the requested software ID is delivered through microchipDIRECT email.

> **Attention:** If you do not receive an email with your license in 15 to 30 minutes, log in again to the portal and download the license.

After you receive the Software ID, perform the following steps to register the license:

4. Sign in to microchipDIRECT.
5. Go to the License page at www.microchipdirect.com/fpga-software-products.
6. Select **Registered Purchased Software ID** for a purchased license.
7. In the **Software ID** field, enter the Software ID, and then select **Submit**.
8. Specify the DiskID or MACID, depending on the license type, and select **Register**.

© 2026 Microchip Technology Inc. and its subsidiaries

When you complete your purchase, the system creates a license and delivers it through the microchipDIRECT email.

Attention: If you do not receive an email with your license in 15 to 30 minutes, log in again to the portal and download the license.

1.1.3. Paid IP License (Ask a Question)

To obtain a paid IP license, perform the following steps:

1. Sign in to microchipDIRECT.
2. Go to the IP page at www.microchipdirect.com/product/search/all/core.
3. Choose the desired IP product license and complete the remaining steps to order the license.

The requested software ID is delivered through microchipDIRECT email.

Attention: If you do not receive an email with your license in 15 to 30 minutes, log in again to the portal and download the license.

After you receive the Software ID, perform the following steps to register the license:

4. Sign in to microchipDIRECT.
5. Go to the License page at www.microchipdirect.com/fpga-software-products.
6. Select **Registered Purchased Software ID** for a purchased license.
7. In the **Software ID** field, enter the Software ID, and then select **Submit**.
8. Specify the DiskID or MACID, depending on the license type, and select **Register**.
   When you complete your purchase, the system creates a license and delivers it through the microchipDIRECT email.

   Attention: If you do not receive an email with your license in 15 to 30 minutes, log in again to the portal and download the license.

9. Copy the IP license file content and embed it in the original Libero license file on the similar Libero license option (Disk ID or MAC ID).

© 2026 Microchip Technology Inc. and its subsidiaries

2. License Installation (Ask a Question)

After completing the installation of the software and obtaining a paid or free Libero SoC Design Suite license, the license must be installed. This section describes the license installation for both node-locked and floating licenses.

2.1. Installing a Node-Locked License (Ask a Question)

The Libero SoC Design Suite node-locked license is supported only on Windows operating systems. The following steps describe how to install a node-locked license.

Attention: For UNIX and Linux installations, skip this step and go directly to the Installing a Floating License section.

1. Create a folder named FlexLM in a root directory (for example, `c:\FlexLM`), and then save the `License.dat` file in the created folder.

   Attention: The license file will be attached to the automatically generated email. Alternatively, you can download the license file from the License page at www.microchipdirect.com/fpga-software-products.

2. Open the **Start** menu, search for **Environment Variables**.
   The **Environment Variables** dialog appears.
3. In the dialog, under **User Variables**, perform the appropriate step:

   If `LM_LICENSE_FILE` appears in the dialog:

   a) Select the variable, and then select **Edit**.

   b) Append `<drive directory>\folder\License.dat` to the existing value, separating them with a semicolon.

   c) Select **OK** to save your edits and exit the dialog.

   If `LM_LICENSE_FILE` does not appear in the dialog:

   a) Select **New**.

   b) Set the **Variable Name** to `LM_LICENSE_FILE`.

   c) Set the **Variable Value** to `<drive directory>\Folder\License.dat`.

   d) Select **OK** to save your edits and exit the dialog.

The installation process is complete. You can start using the installed Libero SoC Design Suite tools.

4. Start Libero SoC Design Suite and verify its correct operation.

   Attention: In the unlikely event you encounter an issue, create a Microchip Support Case.

© 2026 Microchip Technology Inc. and its subsidiaries

3. Installing a Floating License (Ask a Question)

This section describes the steps for installing a floating license on servers running Windows or Linux operating systems.

3.1. Installing a Floating License on a Windows Server (Ask a Question)

To install a floating license on a server running the Windows operating system, perform the following steps:

1. Download the licensing daemons from the Microchip Libero page.
   a) Go to the **Download Software** section.
   b) Select the **Daemons** tab, and then select the Windows Daemons file you want to download.

   Tip: For convenience, select this link to download the Windows Daemon files.

2. Create a folder named FlexLM in a root directory. For example: `C:\FlexLM`.
3. Save the `License.dat` file in the folder you created in the previous step.
4. Save the downloaded daemon to `<directory_location>`.
5. Perform the following steps to edit the `License.dat` file:
   a) Update the **SERVER** line by replacing `<put.hostname.here>` with the actual hostname without the angle brackets.
   b) Modify the port number if necessary. The default port number is 1702.
   c) Update the **VENDOR** and **DAEMON** lines with the appropriate paths. For example, see the following paths.

   ```
   DAEMON actlmgrd C:\flexlm\actlmgrd
   DAEMON saltd C:\flexlm\saltd
   VENDOR snpslmd C:\flexlm\snpslmd
   ```

6. After making the necessary changes, save the file.
7. To start the License Manager, type the following command from the command prompt:

   ```
   C:\flexlm\lmgrd -c C:\flexlm\License.dat
   ```

8. To log the License Manager output, type the following command from the command prompt:

   ```
   C:\flexlm\lmgrd -c <path_to_License.dat>/License.dat -l /license.log
   ```

3.2. Installing a Floating License on a Linux Server (Ask a Question)

To install a floating license on a server running the Linux operating system, perform the following steps:

1. Download the licensing daemons from the Microchip Libero page.
   a) Go to the **Download Software** section.
   b) Select the **Daemons** tab, and then select the Unix/Linux Daemons file you want to download.

   Tip: For convenience, select this link to download the Linux/Unix Daemon files.

© 2026 Microchip Technology Inc. and its subsidiaries

2. Save the `License.dat` file on the server.
3. Select the downloaded daemon `<user_home>/FlexLM/`.
4. Perform the following steps to edit the `License.dat` file:
   a) Update the **SERVER** line by replacing `<put.hostname.here>` with the actual hostname, but without the angle brackets.
   b) Modify the port number if necessary (default is 1702).
   c) Update the **VENDOR** and **DAEMON** lines with the appropriate paths. For example, see the following paths.

```
VENDOR snpslmd /tools/Libero/snpslmd
DAEMON saltd /tools/Libero/saltd
DAEMON actlmgrd /tools/Libero/actlmgrd
```

5. To start the License Manager, type the following command from the command prompt:

```
<user_home>/FlexLM/lmgrd -c <path_to_License.dat>\License.dat
```

6. To attach a log file, type the following command in the terminal:

```
<user_home>/FlexLM/lmgrd -c <user_home>/FlexLM/License.dat -l <user_home>/FlexLM /
license.log
```


© 2026 Microchip Technology Inc. and its subsidiaries

4. Connecting the Client to the License Server (Ask a Question)

To use the licenses available on a license server, you must configure the Libero SoC Design Suite to connect to the license server. This configuration is necessary for Windows, UNIX, and Linux systems. If you use a node-locked license, this step is not required.

4.1. Setting Up an Environment Variable on a Windows Client Machine (Ask a Question)

To connect to the Windows server, perform the following steps:

1. Open the **Start** menu, search for **Environment Variables**.
   The **Environment Variables** dialog appears.
2. In the dialog, under **User variables**, perform the appropriate step:
   If `LM_LICENSE_FILE` appears in the dialog:
   a) Select the variable, and then select **Edit**.
   b) Append `port@hostname` to the existing value. For example, `1702@license_server`.
   c) Select **OK** to save your edits and exit the dialog.

   If `LM_LICENSE_FILE` does not appear in the dialog, perform the following steps:
   a) Select **New**.
   b) Set the **Variable Name** to `LM_LICENSE_FILE`.
   c) Set the **Variable Value** as `port@hostname`. For example: `1702@license_server`.
   d) Select **OK** to save your edits and exit the dialog.
3. To add or update the SNPSLMD_LICENSE_FILE, perform the following steps:
   If `SNPSLMD_LICENSE_FILE` exists:
   a) Append `port@hostname`. For example, `1702@license_server`.

   If `SNPSLMD_LICENSE_FILE` does not exist, perform the following steps:
   a) Create `SNPSLMD_LICENSE_FILE`.
   b) Set the value to `port@hostname`. For example, `1702@license_server`.

4.2. Setting Up an Environment Variable on the UNIX or Linux Client Side (Ask a Question)

Set the UNIX or Linux environment variables for correct operation of Libero SoC Design Suite. To perform this step, consider the appropriate example shown below.

- RHEL and CentOS:
  Set the following environment variables:

```
setenv LM_LICENSE_FILE 1702@sage
setenv SNPSLMD_LICENSE_FILE port@hostname (Ex: 1702@license_server)
setenv SYNPLCTYD_LICENSE_FILE port@hostname (Ex: 1702@license_server)
```

- Ubuntu:
  Set the following environment variables:

```
export LM_LICENSE_FILE port@hostname (Ex: 1702@license_server)
export SNPSLMD_LICENSE_FILE port@hostname (Ex: 1702@license_server)
export SYNPLCTYD_LICENSE_FILE port@hostname (Ex: 1702@license_server)
```

4.3. Downloading and Installing IP MegaVault without an Internet Connection (Ask a Question)

The MegaVault application includes a list of Microchip IP cores. When you install the application, you can add the IP cores to an existing vault or create a new vault on the local machine or server.

© 2026 Microchip Technology Inc. and its subsidiaries

Perform the following steps if the machine on which Libero is installed lacks Internet access or has security restrictions that prevent IP cores from being downloaded from the Libero Catalog:

1. Download and install the following MegaVault installer for the required Libero SoC versions.
   - MegaVault v12.0 and later
   - MegaVault v11.9 and earlier
2. Install the MegaVault application and change the Vault location as required.
3. Download individual IP cores (`.zip` files) into the Vault. To obtain specific cores and versions, download the `.cpz` file and import it into the Libero Vault. For a complete list of cores, see the following core indexes:
   - DirectCores
   - SgCores
   - Firmware cores
4. To import the downloaded cores into Libero SoC, perform the following steps:
   a) Launch the Libero SoC software.
   b) To open the **Catalog** window, on the **Windows** menu, go to **View** > **Catalog**.
   c) Select **Option**, and then select **Add Core to Vault**.
   d) Browse to the downloaded `.cpz` file, and then import it to the Vault location specified in your Libero software. The imported cores are added to the specified Vault location.

Attention: For further assistance, see the KB article to learn how to raise a Microchip support case, see How to submit a case.

© 2026 Microchip Technology Inc. and its subsidiaries

5. Revision History (Ask a Question)

The revision history describes the changes that were implemented in the document. The changes are listed by revision, starting with the most current publication.

Revision	Date	Description
G	06/2026	This document is released with Libero SoC Design Suite v2026.1 without changes from v2025.2.
F	12/2025	This document is released with Libero SoC Design Suite v2025.2 without changes from v2025.1.
E	05/2025	The following changes are made in this revision: • Reorganized the content of this guide. • Revised the content of this guide.
D	08/2024	The following changes are made in this revision: • Revised a note to describe how to allow the Synopsys tools to work beyond 50 miles and beyond the geographic locations, in section Installing a Node-Locked Disk ID License on Windows.
C	02/2024	The following changes are made in this revision: • In section Types of Licensing, revised the link to show the FPGA IP Search page. • In section Obtaining a License, changed the last step. • In section Ordering a License from microchipDIRECT, revised step 9. • In sections Performing a GUI Installation on Windows Operating Systems, Performing a GUI Installation on Linux Operating Systems, Performing a Console Installation (Linux Operating Systems), and Performing a Silent Installation, changed the step about verifying that the installation was successful. • Added the section Configuring Linux to Detect and Use FlashPro 6 Programmer Hardware. • Added the section Downloading IP Cores. • Added the section Can a Libero License be Hosted on a Virtual Machine?
B	09/2023	The following change is made in this revision: • Added the section Troubleshooting Linux Installations.
A	08/2023	Initial revision. This document supersedes the following documents and must be used instead of the ones listed below: • Libero SoC Linux Environment Setup User Guide (DS00003755) • Libero SoC Software Installation Licensing Setup User Guide (DS00003751) • Libero SoC Software Download and License Installation Quick Start Guide (DS50003162)

© 2026 Microchip Technology Inc. and its subsidiaries

Microchip FPGA Support

Microchip FPGA products group backs its products with various support services, including Customer Service, Customer Technical Support Center, a website, and worldwide sales offices. Customers are suggested to visit Microchip online resources prior to contacting support as it is very likely that their queries have been already answered.

Contact Technical Support Center through the website at www.microchip.com/support. Mention the FPGA Device Part number, select appropriate case category, and upload design files while creating a technical support case.

Contact Customer Service for non-technical product support, such as product pricing, product upgrades, update information, order status, and authorization.

- From North America, call **800.262.1060**
- From the rest of the world, call **650.318.4460**
- Fax, from anywhere in the world, **650.318.8044**

© 2026 Microchip Technology Inc. and its subsidiaries

Microchip Information

Trademarks

The “Microchip” name and logo, the “M” logo, and other names, logos, and brands are registered and unregistered trademarks of Microchip Technology Incorporated or its affiliates and/or subsidiaries in the United States and/or other countries (“Microchip Trademarks”). Information regarding Microchip Trademarks can be found at https://www.microchip.com/en-us/about/legal-information/microchip-trademarks.

Legal Notice

This publication and the information herein may be used only with Microchip products, including to design, test, and integrate Microchip products with your application. Use of this information in any other manner violates these terms. Information regarding device applications is provided only for your convenience and may be superseded by updates. It is your responsibility to ensure that your application meets with your specifications. Contact your local Microchip sales office for additional support or, obtain additional support at www.microchip.com/en-us/support/design-help/client-support-services.

THIS INFORMATION IS PROVIDED BY MICROCHIP “AS IS”. MICROCHIP MAKES NO REPRESENTATIONS OR WARRANTIES OF ANY KIND WHETHER EXPRESS OR IMPLIED, WRITTEN OR ORAL, STATUTORY OR OTHERWISE, RELATED TO THE INFORMATION INCLUDING BUT NOT LIMITED TO ANY IMPLIED WARRANTIES OF NON-INFRINGEMENT, MERCHANTABILITY, AND FITNESS FOR A PARTICULAR PURPOSE, OR WARRANTIES RELATED TO ITS CONDITION, QUALITY, OR PERFORMANCE.

IN NO EVENT WILL MICROCHIP BE LIABLE FOR ANY INDIRECT, SPECIAL, PUNITIVE, INCIDENTAL, OR CONSEQUENTIAL LOSS, DAMAGE, COST, OR EXPENSE OF ANY KIND WHATSOEVER RELATED TO THE INFORMATION OR ITS USE, HOWEVER CAUSED, EVEN IF MICROCHIP HAS BEEN ADVISED OF THE POSSIBILITY OR THE DAMAGES ARE FORESEEABLE. TO THE FULLEST EXTENT ALLOWED BY LAW, MICROCHIP’S TOTAL LIABILITY ON ALL CLAIMS IN ANY WAY RELATED TO THE INFORMATION OR ITS USE WILL NOT EXCEED THE AMOUNT OF FEES, IF ANY, THAT YOU HAVE PAID DIRECTLY TO MICROCHIP FOR THE INFORMATION.

Use of Microchip devices in life support and/or safety applications is entirely at the buyer’s risk, and the buyer agrees to defend, indemnify and hold harmless Microchip from any and all damages, claims, suits, or expenses resulting from such use. No licenses are conveyed, implicitly or otherwise, under any Microchip intellectual property rights unless otherwise stated.

Microchip Devices Code Protection Feature

Note the following details of the code protection feature on Microchip products:

- Microchip products meet the specifications contained in their particular Microchip Data Sheet.
- Microchip believes that its family of products is secure when used in the intended manner, within operating specifications, and under normal conditions.
- Microchip values and aggressively protects its intellectual property rights. Attempts to breach the code protection features of Microchip products are strictly prohibited and may violate the Digital Millennium Copyright Act.
- Neither Microchip nor any other semiconductor manufacturer can guarantee the security of its code. Code protection does not mean that we are guaranteeing the product is “unbreakable”. Code protection is constantly evolving. Microchip is committed to continuously improving the code protection features of our products.

© 2026 Microchip Technology Inc. and its subsidiaries