ErgoDesk Pro Standing Desk - Product Guide

Fictional sample document created for an open-source demo.

Overview

The ErgoDesk Pro is an electric sit-stand desk sold by Acme Supply Co. It uses two motors, one in each leg, to move the desktop smoothly.

Specifications

The height range is 62 cm to 127 cm, measured from the floor to the top of the desktop. The maximum load capacity is 120 kg, evenly distributed. Desktops are available in three sizes: 120 x 60 cm, 140 x 70 cm and 160 x 80 cm. The lifting speed is 38 mm per second.

The control panel has an up button, a down button, a memory button marked M and four preset buttons numbered 1 to 4.

Assembly

Assembly takes about 45 minutes. Two people are recommended because the frame is heavy. The only tool needed is a Phillips screwdriver; all other tools are included in the box.

Attach the legs to the crossbar first, then fix the frame to the underside of the desktop. Connect both motor cables and the control panel cable to the control box before plugging in the power cord.

Memory presets

To save a memory preset, move the desk to the height you want, press M, then press and hold a preset button from 1 to 4 for three seconds. The display blinks twice to confirm the preset was saved. To use a preset, press its number once and the desk moves to the saved height.

Troubleshooting

Error code E01 means motor overload. Remove some weight from the desktop, then reset the desk by holding the down button for 10 seconds until it beeps.

Error code E02 means the two legs are out of balance. Lower the desk fully and hold the down button for 10 seconds to recalibrate.

If the display stays blank, check that the power cord is firmly connected to the control box and to the wall outlet.

Care and cleaning

Clean the desktop with a soft damp cloth. Do not use solvents or abrasive cleaners, because they damage the surface finish.