
# Estimated engine load adjustment



< 29 >


#### **MOP**



### Torque Meter



## PMI System



**Engine** 

MAN Diesel & Turbo MAN PrimeServ Yang Yong Dong Operation 07.10.2015

## Estimated engine load adjustment



#### Adjusting estimated engine load on MOP

- Manually enter the lower calorific value and density@15°C. (See fuel oil analysis report.)
- B. Automatically 'Calculated Fuel Quality Offset' will take place.
- Manually adjust 'Applied Fuel Quality Offset' same as 'Calculated Fuel Quality Offset'.
- Measure engine load% with Torque meter (or PMI system).





Ε. Compare estimated engine load% on MOP with Torque meter (or PMI system).


Manually adjust 'Applied Fuel Quality Offset' to make the estimated engine load on MOP the same as the load measurement on Torque meter (or PMI system).

Repeat E and F until the difference between estimated engine load on MOP and PMI system is within 2%.

When est. engine load adjustment is done, Pcomp, Pi and Pmax may be adjusted.







<MOP/Engine/Process Information> <MOP/Engine/Process Adjustment>

MAN PrimeServ

Yang Yong Dong


Operation

07.10.2015

# **Engine:** Fuel Quality new version



< 31 >



MAN Diesel & Turbo MAN PrimeServ Yang Yong Dong Operation 07.10.2015