

SEL-451 Relay

Protection, Automation, and Control System

Instruction Manual

20190325

SEL SCHWEITZER ENGINEERING LABORATORIES, INC.[®]



©2004–2019 by Schweitzer Engineering Laboratories, Inc. All rights reserved.

All brand or product names appearing in this document are the trademark or registered trademark of their respective holders. No SEL trademarks may be used without written permission. SEL products appearing in this document may be covered by U.S. and Foreign patents.

Schweitzer Engineering Laboratories, Inc. reserves all rights and benefits afforded under federal and international copyright and patent laws in its products, including without limitation software, firmware, and documentation.

The information in this document is provided for informational use only and is subject to change without notice. Schweitzer Engineering Laboratories, Inc. has approved only the English language document.

This product is covered by the standard SEL 10-year warranty. For warranty details, visit selinc.com or contact your customer service representative.

PM451-01

Table of Contents

List of Tables	vii
List of Figures	xi
Preface.....	xxi

User's Guide

Section 1: Introduction and Specifications

Features.....	U.1.2
Models and Options.....	U.1.5
Applications.....	U.1.7
Specifications	U.1.12

Section 2: Installation

Shared Configuration Attributes.....	U.2.1
Plug-In Boards.....	U.2.13
Jumpers.....	U.2.18
Relay Placement	U.2.30
Connection.....	U.2.31
AC/DC Connection Diagrams	U.2.50

Section 3: PC Software

Installing the Computer Software.....	U.3.2
Communications Setup.....	U.3.4
Settings Database Management and Drivers	U.3.6
Create and Manage Relay Settings.....	U.3.10
Expression Builder	U.3.15
Analyze Events	U.3.16
HMI Meter and Control.....	U.3.21

Section 4: Basic Relay Operations

Inspecting a New Relay	U.4.1
Connecting and Applying Power.....	U.4.3
Establishing Communication.....	U.4.4
Changing the Default Passwords	U.4.6
Checking Relay Status.....	U.4.10
Making Simple Settings Changes.....	U.4.14
Examining Metering Quantities	U.4.34
Reading Oscillograms, Event Reports, and SER.....	U.4.43
Operating the Relay Inputs and Outputs	U.4.58
Configuring High-Accuracy Timekeeping	U.4.73
Readyng the Relay for Field Application.....	U.4.81

Section 5: Front-Panel Operations

Front-Panel Layout	U.5.2
Front-Panel Menus and Screens	U.5.14
Front-Panel Automatic Messages.....	U.5.36
Operation and Target LEDs.....	U.5.37
Front-Panel Operator Control Pushbuttons	U.5.42

Section 6: Testing and Troubleshooting

Testing Philosophy.....	U.6.1
Testing Features and Tools.....	U.6.4
Relay Test Connections.....	U.6.8
Test Methods.....	U.6.13
Checking Relay Operation.....	U.6.25
Relay Self-Tests	U.6.35
Relay Troubleshooting.....	U.6.38
Technical Support	U.6.41

Appendix A: Firmware and Manual Versions

Firmware.....	U.A.1
Instruction Manual.....	U.A.8

Applications Handbook

Section 1: Protection Application Examples

Overview.....	A.1.1
25 kV Overhead Distribution Line Example	A.1.1
Auto-Reclose Example	A.1.19
Auto-Reclose and Synchronism Check Example	A.1.25
Circuit Breaker Failure Application Examples.....	A.1.33

Section 2: Monitoring and Metering

Circuit Breaker Monitor.....	A.2.1
Station DC Battery System Monitor	A.2.16
Metering.....	A.2.22

Section 3: Analyzing Data

Data Processing.....	A.3.1
Triggering Data Captures and Event Reports	A.3.4
Duration of Data Captures and Event Reports.....	A.3.5
Oscillography	A.3.7
Event Reports, Event Summaries, and Event Histories	A.3.13
High-Impedance Fault Event Summaries and Histories	A.3.37
SER (Sequential Events Recorder)	A.3.42

Section 4: Time-Synchronized Measurements

Relay Configuration for High-Accuracy Timekeeping.....	A.4.1
Fault Analysis	A.4.6
Power Flow Analysis	A.4.7
State Estimation Verification	A.4.9

Section 5: Bay Control

Overview.....	A.5.1
Circuit Breaker Status Logic.....	A.5.3
Disconnect Logic	A.5.3
Bay Control Front-Panel Operations	A.5.13
ACSELERATOR QuickSet SEL-5030 Software Bay Control Screens	A.5.23
Bay Control Example Application.....	A.5.28
Predefined Bay Control One-Line Diagrams.....	A.5.35
Bay Character Set	A.5.49

Section 6: SEL Communications Processor Applications

SEL Communications Processors.....	A.6.1
SEL Communications Processor and Relay Architecture	A.6.3
SEL Communications Processor Example	A.6.5

Section 7: Direct Network Communications

Direct Network Communication	A.7.1
Serial Networking.....	A.7.2
Ethernet Card.....	A.7.4
Direct Networking Example.....	A.7.7

Reference Manual

Section 1: Protection Functions

Current and Voltage Source Selection	R.1.2
Frequency Estimation	R.1.14
Time-Error Calculation.....	R.1.15
Fault Location.....	R.1.17
High-Impedance Fault Detection	R.1.19
Ground Overcurrent High-Impedance Fault Detection	R.1.22
Open Phase Detection Logic	R.1.27
Pole Open Logic	R.1.27
Loss-of-Potential Logic	R.1.28
Fault Type Identification Selection Logic	R.1.33
Ground Overcurrent Elements Directional Control	R.1.33
Negative-Sequence/Phase Overcurrent Elements Directional Control	R.1.44
Directional Element Routing.....	R.1.45
Load-Encroachment Logic	R.1.46
Instantaneous/Definite-Time Line Overcurrent Elements.....	R.1.48
Inverse-Time Overcurrent Elements.....	R.1.55
Switch-On-to-Fault Logic.....	R.1.70
Communications-Assisted Tripping Logic.....	R.1.72
Directional Comparison Blocking Scheme	R.1.73
Permissive Overreaching Transfer Tripping Scheme	R.1.77
Directional Comparison Unblocking Scheme Logic.....	R.1.82
Trip Logic	R.1.86
Circuit Breaker Status Logic	R.1.91
Circuit Breaker Failure Protection.....	R.1.92

Section 2: Auto-Reclosing and Synchronism Check

Auto-Reclosing.....	R.2.2
One-Circuit-Breaker Auto-Reclosing.....	R.2.4
Two-Circuit-Breaker Auto-Reclosing	R.2.6
Auto-Reclose Logic Diagrams	R.2.18
Manual Closing	R.2.26
Voltage Checks for Auto-Reclosing and Manual Closing.....	R.2.29
Settings and Relay Word Bits for Auto-Reclosing and Manual Closing	R.2.31
Synchronism Check.....	R.2.35

Section 3: SELogic Control Equations

SELOGIC Control Equation History	R.3.1
Separation of Protection and Automation Areas	R.3.2
SELOGIC Control Equation Programming	R.3.3
SELOGIC Control Equation Setting Structure	R.3.6
Multiple Setting Groups	R.3.8
SELOGIC Control Equation Capacity	R.3.10
SELOGIC Control Equation Elements.....	R.3.11
SELOGIC Control Equation Operators.....	R.3.25
Effective Programming.....	R.3.36
SEL-311 and SEL-351 Series Users.....	R.3.38

Section 4: Communications Interfaces

Communications Interfaces	R.4.1
Serial Communication	R.4.2
Communications Card	R.4.4

Section 5: SEL Communications Protocols

Serial Port Hardware Protocol	R.5.1
Software Protocol Selections	R.5.2
Protocol Active When Setting PROTO := SEL	R.5.3
Virtual File Interface	R.5.11
SEL MIRRORED BITS Communications	R.5.15
SEL Distributed Port Switch Protocol (LMD).....	R.5.21
SEL-2600 Series RTD Module Operation	R.5.23

Section 6: DNP3 Communications

Introduction to DNP3.....	R.6.1
DNP3 (Serial) in the SEL-451	R.6.5
DNP3 (Serial) Documentation.....	R.6.12
DNP3 (Serial) Application Example	R.6.30
DNP LAN/WAN Communications.....	R.6.35
DNP LAN/WAN in the SEL-451.....	R.6.36
DNP LAN/WAN Documentation	R.6.45
DNP LAN/WAN Application Example	R.6.53

Section 7: Synchrophasors

Introduction.....	R.7.1
Synchrophasor Measurement.....	R.7.3
Settings for Synchrophasors	R.7.6
Synchrophasor Relay Word Bits	R.7.14
Synchrophasor Analog Quantities	R.7.14
View Synchrophasors by Using the MET PM Command	R.7.16
C37.118 Synchrophasor Protocol	R.7.18
SEL Fast Message Synchrophasor Protocol	R.7.24
Synchrophasor Protocols and SEL Fast Operate Commands	R.7.30

Section 8: IEC 61850 Communications

Features	R.8.1
Introduction to IEC 61850	R.8.2
IEC 61850 Operation	R.8.3
IEC 61850 Configuration.....	R.8.12
Logical Nodes	R.8.16
Protocol Implementation Conformance Statement: SEL-400 Series Devices.....	R.8.31
ACSI Conformance Statements	R.8.37

Section 9: ASCII Command Reference

Description of Commands	R.9.2
-------------------------------	-------

Section 10: Settings

Alias Settings	R.10.4
Global Settings.....	R.10.5
Breaker Monitor Settings.....	R.10.11
Group Settings	R.10.14
Protection Free-Form SELOGIC Control Equations	R.10.30
Automation Free-Form SELOGIC Control Equations	R.10.31
Output Settings	R.10.32
Front-Panel Settings.....	R.10.33
Report Settings.....	R.10.41
Port Settings	R.10.43

DNP3 Settings—Serial Port	R.10.47
Bay Settings (SEL-451-4 Relay)	R.10.49

Appendix A: Relay Word Bits

Alphabetic.....	.R.A.1
Row List	R.A.21

Appendix B: Analog Quantities

Quantities Listed Alphabetically	R.B.1
Quantities Listed by Function	R.B.9

Glossary

Index

SEL-451 Relay Command Summary

This page intentionally left blank

List of Tables

User's Guide

Table 1.1	Application Highlights	U.1.10
Table 2.1	Recommended Control Input Pickup Settings	U.2.6
Table 2.2	Required Settings for Use With AC Control Signals	U.2.7
Table 2.3	I/O Interface Boards Control Inputs.....	U.2.14
Table 2.4	I/O Interface Boards Control Outputs	U.2.15
Table 2.5	Main Board Jumpers	U.2.20
Table 2.6	Main Board Jumpers—JMP1, JMP2, and JMP3.....	U.2.21
Table 2.7	I/O Board Jumpers	U.2.28
Table 2.8	Jumper Positions for Breaker OPEN/CLOSE Indication.....	U.2.29
Table 2.9	Jumper Positions for Arc Suppression	U.2.29
Table 2.10	Front-Panel LED Option	U.2.29
Table 2.11	Fuse Requirements for the SEL-451 Power Supply.....	U.2.39
Table 3.1	System Requirements for ACCELERATOR QuickSet	U.3.2
Table 3.2	ACCELERATOR QuickSet HMI Tree View Functions.....	U.3.22
Table 4.1	Power Supply Voltage Inputs	U.4.3
Table 4.2	General Serial Port Settings	U.4.6
Table 4.3	SEL-451 Access Levels.....	U.4.7
Table 4.4	Access Level Commands and Passwords.....	U.4.7
Table 4.5	Settings Classes and Instances	U.4.15
Table 4.6	Actions at Settings Prompts	U.4.17
Table 4.7	Actions at Text-Edit Mode Prompts.....	U.4.19
Table 4.8	Control Inputs in the SEL-451	U.4.67
Table 4.9	SEL-451 Timekeeping Modes.....	U.4.74
Table 4.10	Date/Time Last Update Sources.....	U.4.78
Table 4.11	Communications Port Commands That Clear Relay Buffers	U.4.82
Table 5.1	Front-Panel Inactivity Time-Out Setting.....	U.5.4
Table 5.2	Metering Screens Enable Settings.....	U.5.5
Table 5.3	SER Point Settings	U.5.9
Table 5.4	Display Point Settings—Boolean.....	U.5.12
Table 5.5	Display Point Settings—Analog	U.5.12
Table 5.6	Display Point Settings—Boolean and Analog Examples	U.5.12
Table 5.7	Front-Panel Pushbutton Functions While Viewing SER Events	U.5.21
Table 5.8	Local Bit Control Settings.....	U.5.27
Table 5.9	Local Bit SELOGIC	U.5.27
Table 5.10	Settings Available From the Front Panel.....	U.5.29
Table 5.11	Front-Panel Target LEDs.....	U.5.38
Table 5.12	INST Target LED Trigger Elements-Factory Defaults	U.5.39
Table 5.13	Operator Control Pushbuttons and LEDs—Factory Defaults	U.5.42
Table 6.1	Acceptance Testing	U.6.2
Table 6.2	Commissioning Testing.....	U.6.2
Table 6.3	Maintenance Testing	U.6.3
Table 6.4	UUT Database Entries for SEL-5401 Relay Test System Software—5 A Relay	U.6.7
Table 6.5	UUT Database Entries for SEL-5401 Relay Test System Software—1 A Relay	U.6.8
Table 6.6	Phase Instantaneous Overcurrent Pickup	U.6.14
Table 6.7	Selectable Operating Quantity Time-Overcurrent Element (51S1) Test Settings	U.6.21
Table 6.8	Negative-Sequence Directional Element Settings AUTO Calculations.....	U.6.33
Table 6.9	Troubleshooting Procedures	U.6.39
Table A.1	Firmware Revision History	U.A.1
Table A.2	Ethernet Card Firmware Revision History	U.A.6
Table A.3	Compatible SEL-451 and Ethernet Card Firmware Versions	U.A.8
Table A.4	ACCELERATOR Architect CID File Compatibility	U.A.8
Table A.5	Instruction Manual Revision History	U.A.9

Applications Handbook

Table 1.1	System Data—25 kV Overhead Distribution Line	A.1.2
Table 1.2	Secondary Impedances	A.1.3
Table 1.3	LOP Enable Options	A.1.6
Table 1.4	Options for Enabling Pole-Open Logic	A.1.12
Table 1.5	Setting TULO Unlatch Trip Options	A.1.14
Table 1.6	SEL-451 Settings	A.1.15
Table 1.7	Desired Operating Modes for Auto-Reclose Example	A.1.19
Table 1.8	Relay Word Bits Used in the Auto-Reclose Example	A.1.20
Table 1.9	Determination of Operating Mode for the Auto-Reclose Example.....	A.1.21
Table 1.10	SEL-451 Settings	A.1.24
Table 1.11	SEL-451 Settings	A.1.31
Table 1.12	Secondary Quantities	A.1.36
Table 1.13	Relay Configuration (Group).....	A.1.41
Table 1.14	Secondary Quantities	A.1.42
Table 1.15	Relay Configuration (Group).....	A.1.49
Table 2.1	Circuit Breaker Monitor Configuration	A.2.2
Table 2.2	Circuit Breaker Maintenance Information—Example.....	A.2.4
Table 2.3	Contact Wear Monitor Settings—Circuit Breaker 1	A.2.4
Table 2.4	Circuit Breaker Monitor Initiate SELOGIC Control Equations	A.2.7
Table 2.5	Circuit Breaker Monitor Close SELOGIC Control Equations	A.2.8
Table 2.6	BRE Command.....	A.2.13
Table 2.7	DC1 Monitor Settings and Relay Word Bit Alarms	A.2.17
Table 2.8	Example DC Battery Voltage Conditions	A.2.18
Table 2.9	Example DC Battery Monitor Settings—125 Vdc for Vdc1 and 48 Vdc for Vdc2	A.2.19
Table 2.10	Example DC Battery Monitor Settings—AC Ripple Voltages	A.2.19
Table 2.11	Example DC Battery Monitor Settings—Ground Detection Factor (EGADVS := Y)....	A.2.20
Table 2.12	MET Command—Metering Only	A.2.23
Table 2.13	Instantaneous Metering Quantities—Voltages, Currents, Frequency	A.2.24
Table 2.14	Instantaneous Metering Quantities—Powers	A.2.25
Table 2.15	Instantaneous Metering Accuracy—Voltages, Currents, and Frequency	A.2.26
Table 2.16	Instantaneous Metering Accuracy—Power	A.2.26
Table 2.17	Maximum/Minimum Metering Quantities—Voltages, Currents, Frequency, and Powers....	A.2.27
Table 2.18	Demand and Peak Demand Metering Quantities—(LINE)	A.2.29
Table 2.19	Rolling Demand Calculations.....	A.2.30
Table 2.20	Demand Metering Settings	A.2.32
Table 2.21	Energy Metering Quantities—(LINE)	A.2.34
Table 3.1	Report Settings	A.3.6
Table 3.2	Event Report Nonvolatile Storage Capability.....	A.3.7
Table 3.3	EVE Command.....	A.3.15
Table 3.4	EVE Command Examples	A.3.16
Table 3.5	Event Report Metered Analog Quantities.....	A.3.18
Table 3.6	Event Types.....	A.3.33
Table 3.7	SUM Command	A.3.33
Table 3.8	HIS Command	A.3.35
Table 3.9	HIF Event Types	A.3.38
Table 3.10	HIF Event Phases.....	A.3.38
Table 3.11	HIF Downed Conductor	A.3.39
Table 3.12	SUM HIF Command	A.3.39
Table 3.13	HIS HIF Command.....	A.3.41
Table 3.14	SER Commands.....	A.3.43
Table 4.1	SEL-451 Voltage and Current Measurement	A.4.7
Table 5.1	Circuit Breaker and Disconnect Switch Definitions	A.5.15
Table 5.2	Circuit Breaker State Representations	A.5.16
Table 5.3	Disconnect Switch State Representations.....	A.5.16
Table 5.4	Application Example Bay Control Settings for Bus 1, Bus 2, and Transfer Bus Bay With Ground Switch Application	A.5.33

Table 5.5	Application Example Front-Panel Settings	A.5.34
Table 5.6	Application Example Output Settings, Output SELOGIC Control Equations	A.5.35
Table 5.7	Mimic 1 and Mimic 2 Apparatus Support.....	A.5.37
Table 5.8	Mimic 3 Apparatus Support	A.5.38
Table 5.9	Mimic 4 and Mimic 5 Apparatus Support.....	A.5.39
Table 5.10	Mimic 6 Apparatus Support	A.5.39
Table 5.11	Mimic 7 Apparatus Support	A.5.40
Table 5.12	Mimic 8 and Mimic 9 Apparatus Support.....	A.5.41
Table 5.13	Mimic 10 and Mimic 11 Apparatus Support.....	A.5.42
Table 5.14	Mimic 12, Mimic 13, and Mimic 14 Apparatus Support.....	A.5.43
Table 5.15	Mimic 15 and Mimic 16 Apparatus Support.....	A.5.44
Table 5.16	Mimic 17 and Mimic 18 Apparatus Support.....	A.5.45
Table 5.17	Mimic 19, Mimic 20, Mimic 21, and Mimic 22 Apparatus Support	A.5.47
Table 5.18	Mimic 23 Apparatus Support	A.5.48
Table 5.19	Mimic 24 and Mimic 25 Apparatus Support.....	A.5.49
Table 6.1	SEL Communications Processors Protocol Interfaces	A.6.3
Table 6.2	SEL Communications Processor Port 1 Settings	A.6.5
Table 6.3	SEL Communications Processor Data Collection Automessages.....	A.6.6
Table 6.4	SEL Communications Processor Port 1 Automatic Messaging Settings	A.6.6
Table 6.5	SEL Communications Processor Port 1 Region Map	A.6.7
Table 6.6	SEL Communications Processor METER Region Map	A.6.7
Table 6.7	SEL Communications Processor TARGET Region	A.6.9
Table 7.1	DNP3 Feature Summary	A.7.2
Table 7.2	Ethernet Connection Options	A.7.4
Table 7.3	Ethernet DNP3 Feature Summary	A.7.6
Table 7.4	SEL-451 Port 5 Direct Networking Settings.....	A.7.8

Reference Manual

Table 1.1	Available Current Source Selection Settings Combinations	R.1.4
Table 1.2	Available Current Source Selection Settings Combinations When ESS := Y, NUMBK := 1....	R.1.4
Table 1.3	Available Current Source Selection Settings Combinations When ESS := Y, NUMBK := 2....	R.1.5
Table 1.4	Available Voltage Source-Selection Setting Combinations	R.1.7
Table 1.5	ESS := N, Current and Voltage Source Selection.....	R.1.8
Table 1.6	ESS := 1, Current and Voltage Source Selection	R.1.8
Table 1.7	ESS := 2, Current and Voltage Source Selection	R.1.9
Table 1.8	ESS := 3, Current and Voltage Source Selection	R.1.10
Table 1.9	ESS := 4, Current and Voltage Source Selection	R.1.11
Table 1.10	ESS := Y, Tapped Line	R.1.12
Table 1.11	ESS := Y, Current Polarizing Source	R.1.13
Table 1.12	Frequency Estimation.....	R.1.14
Table 1.13	Frequency Estimation Analog Quantity	R.1.14
Table 1.14	Time-Error Calculation Inputs and Outputs	R.1.16
Table 1.15	Fault Location Triggering Elements.....	R.1.17
Table 1.16	Fault Type.....	R.1.18
Table 1.17	Fault Location Settings.....	R.1.18
Table 1.18	Fault Location Relay Word Bit	R.1.18
Table 1.19	High-Impedance Fault (HIF) Detection Settings	R.1.20
Table 1.20	HIF Relay Word Bits.....	R.1.21
Table 1.21	50G High-Z (HIZ) Fault Detection Settings	R.1.22
Table 1.22	Open Phase Detection Relay Word Bits.....	R.1.27
Table 1.23	Pole Open Logic Settings.....	R.1.27
Table 1.24	EPO Setting Selections.....	R.1.28
Table 1.25	Pole Open Logic Relay Word Bits	R.1.28
Table 1.26	LOP Logic Setting.....	R.1.29
Table 1.27	LOP Logic Relay Word Bits	R.1.29
Table 1.28	FIDS Relay Word Bits.....	R.1.33
Table 1.29	Directional Elements Supervising Ground Overcurrent Elements	R.1.33

Table 1.30	Ground Directional Element Settings.....	R.1.34
Table 1.31	Ground Directional Element Settings AUTO Calculations	R.1.34
Table 1.32	Ground Directional Element Enables	R.1.36
Table 1.33	Ground Directional Element Relay Word Bits	R.1.38
Table 1.34	Reference Table for Figure 1.28, Figure 1.29, and Figure 1.30	R.1.42
Table 1.35	Vector Definitions for Equation 1.1–Equation 1.11	R.1.42
Table 1.36	Phase and Negative-Sequence Directional Elements Relay Word Bits.....	R.1.44
Table 1.37	Level Directional Settings	R.1.45
Table 1.38	Load-Encroachment Logic Relay Settings	R.1.47
Table 1.39	Load-Encroachment Logic Relay Word Bits.....	R.1.47
Table 1.40	Phase Overcurrent Element Settings	R.1.48
Table 1.41	Negative-Sequence Overcurrent Element Settings.....	R.1.49
Table 1.42	Residual Ground Overcurrent Element Settings.....	R.1.49
Table 1.43	Phase Instantaneous and Definite-Time Line Overcurrent Relay Word Bits	R.1.50
Table 1.44	Negative-Sequence Instantaneous and Definite-Time Line Overcurrent Relay Word Bits....	R.1.50
Table 1.45	Residual Ground Instantaneous and Definite-Time Line Overcurrent Relay Word Bits	R.1.51
Table 1.46	Selectable Current Quantities	R.1.55
Table 1.47	Selectable Inverse-Time Overcurrent Settings	R.1.56
Table 1.48	Selectable Inverse-Time Overcurrent Relay Word Bits.....	R.1.57
Table 1.49	Equations Associated With U.S. Curves	R.1.58
Table 1.50	Equations Associated With IEC Curves	R.1.59
Table 1.51	SOTF Settings.....	R.1.71
Table 1.52	SOTF Relay Word Bits	R.1.71
Table 1.53	ECOMM Setting.....	R.1.72
Table 1.54	DCB Settings	R.1.75
Table 1.55	DCB Relay Word Bits	R.1.76
Table 1.56	POTT Settings.....	R.1.79
Table 1.57	POTT Relay Word Bits	R.1.79
Table 1.58	DCUB Settings	R.1.83
Table 1.59	DCUB Relay Word Bits.....	R.1.84
Table 1.60	Setting TULO Unlatch Trip Options	R.1.87
Table 1.61	Trip Logic Settings	R.1.87
Table 1.62	Trip Logic Relay Word Bits.....	R.1.88
Table 1.63	Circuit Breaker Status Logic Inputs	R.1.91
Table 1.64	Circuit Breaker Status Logic Relay Word Bits	R.1.91
Table 1.65	Circuit Breaker Failure Protection Logic Settings.....	R.1.97
Table 1.66	Circuit Breaker Failure Relay Word Bits.....	R.1.98
Table 2.1	Auto-Reclose Logical States for Circuit Breaker 1	R.2.4
Table 2.2	One-Circuit-Breaker Auto-Reclose Initial Settings.....	R.2.6
Table 2.3	One Circuit Breaker Modes of Operation.....	R.2.6
Table 2.4	Dynamic Leader/Follower Settings	R.2.11
Table 2.5	Leader/Follower Selection	R.2.12
Table 2.6	Example One: Reset and 79CY3 States	R.2.12
Table 2.7	Example One: Lockout State	R.2.13
Table 2.8	Example One: Reset State After Reclaim Time	R.2.13
Table 2.9	Leader/Follower Selection	R.2.13
Table 2.10	Example Two: Initial Reset State.....	R.2.14
Table 2.11	Example Two: Final Reset State.....	R.2.14
Table 2.12	Leader/Follower Selection	R.2.15
Table 2.13	Example Three: Reset State	R.2.15
Table 2.14	Example Three: Auto-Reclose Cycle State	R.2.15
Table 2.15	Example Three: Lockout State, BK1	R.2.16
Table 2.16	Leader/Follower Selection	R.2.16
Table 2.17	Two Circuit Breakers: Circuit Breaker BK1 Out of Service	R.2.17
Table 2.18	Two-Circuit-Breaker Auto-Reclose Initial Settings	R.2.17
Table 2.19	Circuit Breaker BK1 Modes of Operation.....	R.2.17
Table 2.20	Circuit Breaker BK2 Modes of Operation.....	R.2.18
Table 2.21	Auto-Reclosing and Manual Closing Settings	R.2.31

Table 2.22	Auto-Reclosing Logic Relay Word Bits.....	R.2.33
Table 2.23	Synchronism-Check Relay Word Bits.....	R.2.39
Table 3.1	Advanced SEL-451 SELOGIC Control Equation Features	R.3.1
Table 3.2	SEL-451 SELOGIC Control Equation Programming Summary	R.3.2
Table 3.3	Definitions for Active Setting Group Indication Relay Word Bits SG1 Through SG6	R.3.8
Table 3.4	Definitions for Active Setting Group Switching SELOGIC Control Equation Settings SS1 Through SS6	R.3.9
Table 3.5	Summary of SELOGIC Control Equation Elements	R.3.11
Table 3.6	First Execution Bit Operation on Power-Up	R.3.12
Table 3.7	First Execution Bit Operation on Automation Settings Change	R.3.12
Table 3.8	First Execution Bit Operation on Protection Settings Change, Group Switch, and Source Selection.....	R.3.12
Table 3.9	SELOGIC Control Equation Variable Quantities	R.3.12
Table 3.10	SELOGIC Control Equation Math Variable Quantities	R.3.13
Table 3.11	Latch Bit Quantities	R.3.14
Table 3.12	Latch Bit Parameters	R.3.14
Table 3.13	Conditioning Timer Quantities.....	R.3.17
Table 3.14	Conditioning Timer Parameters	R.3.17
Table 3.15	Sequencing Timer Quantities	R.3.21
Table 3.16	Sequencing Timer Parameters.....	R.3.21
Table 3.17	Counter Quantities.....	R.3.23
Table 3.18	Counter Parameters	R.3.23
Table 3.19	Operator Precedence From Highest to Lowest.....	R.3.26
Table 3.20	Boolean Operator Summary	R.3.27
Table 3.21	Parentheses Operation in Boolean Equation	R.3.27
Table 3.22	NOT Operator Truth Table	R.3.27
Table 3.23	AND Operator Truth Table	R.3.28
Table 3.24	OR Operator Truth Table.....	R.3.28
Table 3.25	Comparison Operations.....	R.3.30
Table 3.26	Math Operator Summary.....	R.3.31
Table 3.27	Math Error Examples	R.3.31
Table 3.28	SEL-351 Series Relays and SEL-451 SELOGIC Control Equation Programming Equivalent Functions.....	R.3.38
Table 3.29	SEL-351 Series Relays and SEL-451 SELOGIC Control Equation Boolean Operators....	R.3.38
Table 4.1	SEL-451 Communications Protocols	R.4.1
Table 4.2	EIA-232 Pin Assignments.....	R.4.3
Table 4.3	Ethernet Card Network Configuration Settings	R.4.5
Table 4.4	DEFRTR Address Setting Examples.....	R.4.6
Table 4.5	IP Network Address Resolution Settings	R.4.7
Table 4.6	Basic File Structure	R.4.8
Table 4.7	Ethernet Card FTP Settings.....	R.4.9
Table 4.8	Ethernet Card Telnet Settings.....	R.4.10
Table 4.9	Control Characters.....	R.4.11
Table 4.10	Ethernet Card Command Summary	R.4.11
Table 4.11	Ethernet Card Access Levels.....	R.4.11
Table 4.12	Access Level User Names and Passwords	R.4.12
Table 4.13	DATE Command	R.4.13
Table 4.14	HELP Command Options.....	R.4.16
Table 4.15	ID Command Internal Parameters Displayed.....	R.4.16
Table 4.16	PING Command Options	R.4.17
Table 4.17	TIME Command	R.4.18
Table 4.18	Ethernet Card Alarm Bit Assertion	R.4.19
Table 4.19	Ethernet Card Status Bit Assertion.....	R.4.19
Table 4.20	Communications Card Database Regions	R.4.21
Table 4.21	SEL-451 Communications Card Database Structure—LOCAL Region	R.4.22
Table 4.22	SEL-451 Communications Card Database Structure—METER Region	R.4.22
Table 4.23	SEL-451 Communications Card Database Structure—DEMAND Region	R.4.24
Table 4.24	SEL-451 Communications Card Database Structure—TARGET Region	R.4.25

Table 4.25	SEL-451 Communications Card Database Structure—HISTORY Region	R.4.25
Table 4.26	SEL-451 Communications Card Database Structure—BREAKER Region	R.4.26
Table 4.27	SEL-451 Communications Card Database Structure—STATUS Region.....	R.4.27
Table 4.28	SEL-451 Communications Card Database Structure—ANALOGS Region	R.4.28
Table 4.29	SEL-451 Communications Card Database Structure—STATE Region	R.4.28
Table 5.1	Hardware Handshaking	R.5.1
Table 5.2	Supported Serial Command Sets	R.5.2
Table 5.3	Selected ASCII Control Characters	R.5.4
Table 5.4	Compressed ASCII Commands	R.5.6
Table 5.5	Fast Commands and Response Descriptions	R.5.9
Table 5.6	Fast Operate Command Types	R.5.9
Table 5.7	Fast Message Command Function Codes Used With Fast SER (A546 Message) and Relay Response Descriptions	R.5.10
Table 5.8	Commands in Recommended Sequence for Automatic Configuration.....	R.5.10
Table 5.9	Virtual File Structure	R.5.11
Table 5.10	Settings Directory Files	R.5.13
Table 5.11	REPORTS Directory Files	R.5.13
Table 5.12	EVENTS Directory Files (for Event 10001)	R.5.14
Table 5.13	EVENTS Directory Files (for HIF Event 10001)	R.5.14
Table 5.14	Ethernet Card Subdirectory	R.5.15
Table 5.15	MIRRORED BITS Communications Features	R.5.15
Table 5.16	General Port Settings Used With MIRRORED BITS Communications	R.5.19
Table 5.17	MIRRORED BITS Communications Protocol Settings	R.5.20
Table 5.18	MIRRORED BITS Communications Message Transmission Period	R.5.21
Table 5.19	MIRRORED BITS Communications ID Settings for Three-Terminal Application	R.5.21
Table 5.20	SEL-2885 Initialization String [MODE PREFIX ADDR:SPEED].....	R.5.21
Table 5.21	RTD Status Bits	R.5.23
Table 5.22	MET T Command Status Messages	R.5.24
Table 6.1	DNP3 Implementation Levels	R.6.2
Table 6.2	Selected DNP3 Function Codes	R.6.3
Table 6.3	DNP Access Methods	R.6.4
Table 6.4	DNP Access Methods	R.6.5
Table 6.5	SEL-451 Event Buffer Capacity	R.6.7
Table 6.6	SEL-451 Port DNP Protocol Settings	R.6.8
Table 6.7	SEL-451 DNP Map Settings	R.6.10
Table 6.8	SEL-451 DNP3 Device Profile	R.6.12
Table 6.9	SEL-451 DNP Object List	R.6.13
Table 6.10	SEL-451 DNP3 Default Data Map	R.6.18
Table 6.11	SEL-451 Object 1, 2 Relay Word Bit Mapping	R.6.22
Table 6.12	Object 1, 2 Indices 1600—1615 Front-Panel Targets	R.6.25
Table 6.13	Object 30, 32, Index 176 Upper Byte—Event Cause	R.6.26
Table 6.14	Object 30, 32, Index 176 Lower Byte—Fault Type	R.6.26
Table 6.15	SEL-451 Object 12 Trip/Close Pair Operation	R.6.26
Table 6.16	SEL-451 Object 12 Code Selection Operation	R.6.27
Table 6.17	DNP3 Application Example Data Map	R.6.30
Table 6.18	SEL-451 Port 3 Example Settings	R.6.34
Table 6.19	DNP3 Over Ethernet Access Methods	R.6.36
Table 6.20	SEL-451 Ethernet Port DNP3 Protocol Settings	R.6.38
Table 6.21	SEL-451 DNP LAN/WAN Map Settings	R.6.42
Table 6.22	SEL-451 Binary Output CPId Values	R.6.44
Table 6.23	SEL-451 DNP LAN/WAN Device Profile	R.6.45
Table 6.24	SEL-451 DNP3 Object List	R.6.46
Table 6.25	SEL-451 DNP LAN/WAN Object 12 Control Point Operation	R.6.52
Table 6.26	DNP LAN/WAN Application Example Custom Data Map	R.6.53
Table 6.27	DNP LAN/WAN Application Example Protocol Settings	R.6.54
Table 6.28	DNP LAN/WAN Application Example Binary Input Map	R.6.56
Table 6.29	DNP LAN/WAN Application Example Binary Output Map	R.6.57
Table 6.30	DNP LAN/WAN Application Example Analog Input Map	R.6.57

Table 6.31	DNP LAN/WAN Application Example Analog Output Map	R.6.58
Table 7.1	PMU Settings in the SEL-451 for C37.118 Protocol in Global Settings	R.7.6
Table 7.2	Time and Date Management	R.7.7
Table 7.3	SEL-451 Serial Port Settings for Synchrophasors	R.7.7
Table 7.4	SEL-451 Ethernet Port Settings for Synchrophasors	R.7.8
Table 7.5	Synchrophasor Order in Data Stream (Voltages and Currents).....	R.7.10
Table 7.6	User-Defined Analog Values Selected by the NUMANA Setting	R.7.12
Table 7.7	User-Defined Digital Status Words Selected by the NUMDSW Setting	R.7.13
Table 7.8	PM Trigger Reason Bits—IEEE C37.118 Assignments	R.7.13
Table 7.9	Synchrophasor Trigger Relay Word Bits	R.7.14
Table 7.10	Time Synchronization Relay Word Bits.....	R.7.14
Table 7.11	Synchrophasor Analog Quantities.....	R.7.15
Table 7.12	Size of a C37.118 Synchrophasor Message	R.7.19
Table 7.13	Serial Port Bandwidth for Synchrophasors (in Bytes)	R.7.19
Table 7.14	Example Synchrophasor Global Settings.....	R.7.22
Table 7.15	Example Synchrophasor Protection Free-Form Logic Settings	R.7.23
Table 7.16	Example Synchrophasor Port Settings	R.7.23
Table 7.17	Fast Message Command Function Codes for Synchrophasor Fast Write	R.7.24
Table 7.18	PMU Settings in the SEL-451 for SEL Fast Message Protocol, in Global Settings	R.7.25
Table 7.19	SEL Fast Message Voltage and Current Selections Based on PHDATAV and PHDATAI.....	R.7.26
Table 7.20	SEL Fast Message Voltage and Current Synchrophasor Sources	R.7.26
Table 7.21	SEL Fast Message Current Channel <i>c</i> Definition	R.7.27
Table 7.22	Synchrophasor Voltage and Current Settings Conversion From Previous SEL-451 Firmware Version.....	R.7.27
Table 7.23	Synchrophasor Current Source Settings Conversion From Previous SEL-451 Firmware Version.....	R.7.27
Table 7.24	Size of an SEL Fast Message Synchrophasor Message	R.7.28
Table 7.25	Serial Port Bandwidth for Synchrophasors (in Bytes)	R.7.28
Table 8.1	IEC 61850 Document Set.....	R.8.2
Table 8.2	Example IEC 61850 Descriptor Components	R.8.4
Table 8.3	SEL-451 Logical Devices	R.8.4
Table 8.4	Buffered Report Control Block Client Access	R.8.6
Table 8.5	Unbuffered Report Control Block Client Access.....	R.8.7
Table 8.6	IEC 61850 Settings.....	R.8.12
Table 8.7	ICD Logical Nodes Summary	R.8.14
Table 8.8	Logical Device: PRO (Protection).....	R.8.16
Table 8.9	Logical Device: MET (Metering).....	R.8.19
Table 8.10	Logical Device: CON (Remote Control).....	R.8.20
Table 8.11	Logical Device: ANN (Annunciation)	R.8.21
Table 8.12	PICS for A-Profile Support	R.8.31
Table 8.13	PICS for T-Profile Support	R.8.31
Table 8.14	MMS Service Supported Conformance	R.8.32
Table 8.15	MMS Parameter	R.8.34
Table 8.16	AlternateAccessSelection Conformance Statement	R.8.35
Table 8.17	VariableAccessSpecification Conformance Statement	R.8.35
Table 8.18	VariableSpecification Conformance Statement.....	R.8.35
Table 8.19	Read Conformance Statement	R.8.35
Table 8.20	GetVariableAccessAttributes Conformance Statement.....	R.8.36
Table 8.21	DefineNamedVariableList Conformance Statement	R.8.36
Table 8.22	GetNamedVariableListAttributes Conformance Statement	R.8.36
Table 8.23	DeleteNamedVariableList Conformance Statement.....	R.8.36
Table 8.24	GOOSE Conformance.....	R.8.37
Table 8.25	ACSI Basic Conformance Statement	R.8.37
Table 8.26	ACSI Models Conformance Statement	R.8.38
Table 8.27	ACSI Services Conformance Statement.....	R.8.39
Table 9.1	2AC Command.....	R.9.2
Table 9.2	89CLOSE n Command.....	R.9.2
Table 9.3	89OPEN n Command.....	R.9.3

Table 9.4	AAC Command	R.9.3
Table 9.5	ACC Command.....	R.9.3
Table 9.6	BAC Command.....	R.9.3
Table 9.7	BNA Command	R.9.4
Table 9.8	BRE n Command.....	R.9.4
Table 9.9	BRE n C and BRE n R Commands	R.9.4
Table 9.10	BRE C A and BRE R A Commands.....	R.9.4
Table 9.11	BRE n H Command.....	R.9.5
Table 9.12	BRE n P Command.....	R.9.5
Table 9.13	CAL Command.....	R.9.5
Table 9.14	CAS Command.....	R.9.5
Table 9.15	CBR Command.....	R.9.6
Table 9.16	CBR TERSE Command	R.9.6
Table 9.17	CEV Command.....	R.9.7
Table 9.18	CEV ACK Command	R.9.7
Table 9.19	CEV C Command	R.9.7
Table 9.20	CEV L Command	R.9.7
Table 9.21	CEV Ly yy Command	R.9.8
Table 9.22	CEV N Command.....	R.9.8
Table 9.23	CEV NSET Command.....	R.9.8
Table 9.24	CEV NSUM Command	R.9.9
Table 9.25	CEV Sx Command	R.9.9
Table 9.26	CEV TERSE Command	R.9.9
Table 9.27	CEV Command Option Groups.....	R.9.10
Table 9.28	CHI Command.....	R.9.10
Table 9.29	CHI TERSE Command	R.9.11
Table 9.30	CHI HIF Command	R.9.11
Table 9.31	CHI HIF TERSE Command	R.9.11
Table 9.32	CLOSE n Command	R.9.12
Table 9.33	COM c Command.....	R.9.12
Table 9.34	COM c C and COM c R Command	R.9.13
Table 9.35	COM c L Command	R.9.13
Table 9.36	CON nn Command	R.9.14
Table 9.37	COPY Command.....	R.9.14
Table 9.38	CSE Command	R.9.15
Table 9.39	CSE TERSE Command	R.9.16
Table 9.40	CST Command	R.9.17
Table 9.41	CSU Command.....	R.9.17
Table 9.42	CSU ACK Command.....	R.9.17
Table 9.43	CSU MB Command.....	R.9.17
Table 9.44	CSU N Command	R.9.18
Table 9.45	CSU TERSE Command	R.9.18
Table 9.46	CSU HIF Command	R.9.18
Table 9.47	CSU HIF ACK Command	R.9.19
Table 9.48	CSU HIF NEXT Command.....	R.9.19
Table 9.49	CSU HIF NEXT Command.....	R.9.19
Table 9.50	DATE Command.....	R.9.19
Table 9.51	DNA Command	R.9.20
Table 9.52	DNP Command.....	R.9.20
Table 9.53	EVE Command.....	R.9.20
Table 9.54	EVE A Command	R.9.21
Table 9.55	EVE ACK Command.....	R.9.21
Table 9.56	EVE C Command	R.9.21
Table 9.57	EVE D Command	R.9.22
Table 9.58	EVE L Command	R.9.22
Table 9.59	EVE Ly yy Command.....	R.9.22
Table 9.60	EVE N Command	R.9.22
Table 9.61	EVE NSET Command.....	R.9.23

Table 9.62	EVE NSUM Command	R.9.23
Table 9.63	EVE Sx Command	R.9.23
Table 9.64	EVE Command Option Groups.....	R.9.24
Table 9.65	EVE Command Examples.....	R.9.24
Table 9.66	FILE Command.....	R.9.24
Table 9.67	GROUP Command.....	R.9.25
Table 9.68	HELP Command	R.9.25
Table 9.69	HIS Command.....	R.9.26
Table 9.70	HIS C and HIS R Commands.....	R.9.26
Table 9.71	HIS CA and HIS RA Commands.....	R.9.26
Table 9.72	HIS HIF Command	R.9.27
Table 9.73	HIS HIF C and HIS HIF R Commands.....	R.9.27
Table 9.74	HIS HIF CA and HIS HIF RA Commands	R.9.27
Table 9.75	HIZ Command.....	R.9.28
Table 9.76	HIZ C and HIZ R Commands	R.9.28
Table 9.77	HIZ CA and HIZ RA Commands	R.9.28
Table 9.78	HSG and HSG D Commands	R.9.29
Table 9.79	ID Command.....	R.9.29
Table 9.80	INI HIF Command	R.9.31
Table 9.81	IRIG Command	R.9.31
Table 9.82	LOG HIF Command.....	R.9.31
Table 9.83	LOOP Command.....	R.9.32
Table 9.84	LOOP DATA Command.....	R.9.33
Table 9.85	LOOP R Command	R.9.33
Table 9.86	MAP 1 Command.....	R.9.34
Table 9.87	MAP 1 Region Command	R.9.34
Table 9.88	MET Command.....	R.9.34
Table 9.89	MET AMV Command	R.9.35
Table 9.90	MET ANA Command	R.9.35
Table 9.91	MET BAT Command	R.9.36
Table 9.92	MET D Command	R.9.36
Table 9.93	MET E Command	R.9.36
Table 9.94	MET HIF Command	R.9.37
Table 9.95	MET M Command	R.9.37
Table 9.96	MET PM Command	R.9.37
Table 9.97	MET PMV Command	R.9.38
Table 9.98	MET RMS Command	R.9.39
Table 9.99	MET SYN Command	R.9.39
Table 9.100	MET T Command	R.9.39
Table 9.101	OAC Command	R.9.40
Table 9.102	OPEN n Command.....	R.9.40
Table 9.103	PAC Command	R.9.41
Table 9.104	PAS level new_password Command	R.9.41
Table 9.105	PAS level DISABLE Command.....	R.9.41
Table 9.106	PORT p Command	R.9.42
Table 9.107	PORT KILL n Command	R.9.42
Table 9.108	PUL OUTnnn Command	R.9.43
Table 9.109	QUI Command	R.9.43
Table 9.110	SER Command	R.9.44
Table 9.111	SER C and SER R Commands.....	R.9.44
Table 9.112	SER CA and SER RA Commands	R.9.45
Table 9.113	SER CV or SER RV Commands	R.9.45
Table 9.114	SER D Command	R.9.45
Table 9.115	SET Command Overview	R.9.46
Table 9.116	SET A Command	R.9.46
Table 9.117	SET B Command	R.9.47
Table 9.118	SET D Command	R.9.47
Table 9.119	SET F Command.....	R.9.47

Table 9.120	SET G Command.....	R.9.48
Table 9.121	SET L Command	R.9.48
Table 9.122	SET M Command	R.9.48
Table 9.123	SET O Command.....	R.9.48
Table 9.124	SET P Command	R.9.49
Table 9.125	SET R Command.....	R.9.49
Table 9.126	SET T Command	R.9.49
Table 9.127	SET TERSE Command Examples	R.9.50
Table 9.128	SHO Command Overview	R.9.50
Table 9.129	SHO A Command.....	R.9.51
Table 9.130	SHO B Command	R.9.51
Table 9.131	SHOW D Command	R.9.51
Table 9.132	SHO F Command	R.9.52
Table 9.133	SHO G Command.....	R.9.52
Table 9.134	SHO L Command	R.9.52
Table 9.135	SHO M Command	R.9.52
Table 9.136	SHO O Command.....	R.9.53
Table 9.137	SHO P Command	R.9.53
Table 9.138	SHO R Command	R.9.53
Table 9.139	SHO T Command	R.9.54
Table 9.140	SNS Command	R.9.54
Table 9.141	STA Command	R.9.54
Table 9.142	STA A Command.....	R.9.54
Table 9.143	STA C and STA R Command	R.9.55
Table 9.144	STA S Command	R.9.55
Table 9.145	STA SC and STA SR Command.....	R.9.55
Table 9.146	SUM Command.....	R.9.55
Table 9.147	SUM ACK Command.....	R.9.56
Table 9.148	SUM N Command	R.9.56
Table 9.149	SUM HIF Command	R.9.56
Table 9.150	SUM HIF ACK Command	R.9.57
Table 9.151	SUM HIF NEXT Command.....	R.9.57
Table 9.152	TAR Command	R.9.57
Table 9.153	TAR ALL Command	R.9.58
Table 9.154	TAR R Command	R.9.58
Table 9.155	TAR X Command	R.9.58
Table 9.156	TEC Command	R.9.59
Table 9.157	TEST DB Command	R.9.59
Table 9.158	TEST DB OFF Command	R.9.60
Table 9.159	TEST DNP Command	R.9.60
Table 9.160	TEST DNP Command	R.9.61
Table 9.161	TEST FM Command	R.9.61
Table 9.162	TEST FM DEM Command	R.9.62
Table 9.163	TEST FM OFF Command	R.9.62
Table 9.164	TEST FM PEAK Command.....	R.9.63
Table 9.165	TIME Command	R.9.63
Table 9.166	TIME Q Command	R.9.63
Table 9.167	TRI Command	R.9.64
Table 9.168	TRI HIF Command.....	R.9.64
Table 9.169	VER Command.....	R.9.64
Table 9.170	VIEW 1 Commands—Region	R.9.66
Table 9.171	VIEW 1 Commands—Register Item	R.9.66
Table 9.172	VIEW 1 Commands—Bit.....	R.9.67
Table 10.1	Default Alias Settings	R.10.5
Table 10.2	Global Settings Categories	R.10.5
Table 10.3	General Global Settings	R.10.6
Table 10.4	Global Enables.....	R.10.6
Table 10.5	Station DC1 Monitor (and Station DC2 Monitor).....	R.10.6

Table 10.6	Control Inputs (Global)	R.10.7
Table 10.7	Main Board Control Inputs	R.10.7
Table 10.8	Interface Board #1 Control Inputs	R.10.8
Table 10.9	Interface Board #2 Control Inputs	R.10.8
Table 10.10	Settings Group Selection	R.10.9
Table 10.11	Data Reset Control	R.10.9
Table 10.12	Frequency Estimation	R.10.9
Table 10.13	Time-Error Calculation	R.10.10
Table 10.14	Current and Voltage Source Selection	R.10.10
Table 10.15	Synchronized Phasor Measurement	R.10.10
Table 10.16	Time and Date Management	R.10.11
Table 10.17	Breaker Monitor Settings Categories	R.10.11
Table 10.18	Breaker Configuration	R.10.12
Table 10.19	Breaker 1 Inputs	R.10.12
Table 10.20	Breaker 2 Inputs	R.10.12
Table 10.21	Breaker 1 Monitor (and Breaker 2 Monitor)	R.10.12
Table 10.22	Breaker 1 Contact Wear (and Breaker 2 Contact Wear)	R.10.12
Table 10.23	Breaker 1 Electrical Operating Time (and Breaker 2 Electrical Operating Time)	R.10.12
Table 10.24	Breaker 1 Mechanical Operating Time (and Breaker 2 Mechanical Operating Time)	R.10.13
Table 10.25	Breaker 1 Pole Scatter and Pole Discrepancy (and Breaker 2 Pole Scatter and Pole Discrepancy)	R.10.13
Table 10.26	Breaker 1 Inactivity Time Elapsed (and Breaker 2 Inactivity Time Elapsed)	R.10.13
Table 10.27	Breaker 1 Motor Running Time (and Breaker 2 Motor Running Time)	R.10.13
Table 10.28	Breaker 1 Current Interrupted (and Breaker 2 Current Interrupted)	R.10.13
Table 10.29	Group Settings Categories	R.10.14
Table 10.30	Line Configuration	R.10.15
Table 10.31	Relay Configuration	R.10.15
Table 10.32	Switch-On-Fault Scheme	R.10.16
Table 10.33	Load Encroachment	R.10.16
Table 10.34	Phase Instantaneous Overcurrent Pickup	R.10.17
Table 10.35	Phase Definite-Time Overcurrent Time Delay	R.10.17
Table 10.36	Phase Instantaneous Definite-Time Overcurrent Torque Control	R.10.17
Table 10.37	Residual Ground Instantaneous Overcurrent Pickup	R.10.18
Table 10.38	Residual Ground Definite-Time Overcurrent Time Delay	R.10.18
Table 10.39	Residual Ground Instantaneous Definite-Time Overcurrent Torque Control	R.10.18
Table 10.40	Negative-Sequence Instantaneous Overcurrent Pickup	R.10.19
Table 10.41	Negative-Sequence Definite-Time Overcurrent Time Delay	R.10.19
Table 10.42	Negative-Sequence Instantaneous Definite-Time Overcurrent Torque Control	R.10.19
Table 10.43	Selectable Operating Quantity Inverse Time Overcurrent Element 1	R.10.19
Table 10.44	Selectable Operating Quantity Inverse Time Overcurrent Element 2	R.10.20
Table 10.45	Selectable Operating Quantity Inverse Time Overcurrent Element 3	R.10.20
Table 10.46	Selectable Operating Quantity Inverse Time Overcurrent Element 4	R.10.21
Table 10.47	Selectable Operating Quantity Inverse Time Overcurrent Element 5	R.10.21
Table 10.48	Selectable Operating Quantity Inverse Time Overcurrent Element 6	R.10.22
Table 10.49	Level Direction	R.10.22
Table 10.50	Directional Control Element	R.10.23
Table 10.51	Pole Open Detection	R.10.23
Table 10.52	POTT Trip Scheme	R.10.24
Table 10.53	DCUB Trip Scheme	R.10.24
Table 10.54	DCB Trip Scheme	R.10.24
Table 10.55	Breaker 1 Failure Logic (and Breaker 2 Failure Logic)	R.10.25
Table 10.56	Synchronism Check Element Reference	R.10.26
Table 10.57	Breaker 1 Synchronism Check	R.10.26
Table 10.58	Breaker 2 Synchronism Check	R.10.26
Table 10.59	Recloser and Manual Closing	R.10.27
Table 10.60	Three-Pole Reclose Settings	R.10.28
Table 10.61	Voltage Elements	R.10.29
Table 10.62	Demand Metering	R.10.29

Table 10.63	Trip Logic	R.10.29
Table 10.64	High-Impedance Fault (HIF) Detection.....	R.10.30
Table 10.65	50G High-Z (HIZ) Fault Detection.....	R.10.30
Table 10.66	Protection Free-Form SELOGIC Control Equations.....	R.10.30
Table 10.67	Protection Free-Form SELOGIC Control Equations.....	R.10.31
Table 10.68	Output Settings Categories	R.10.32
Table 10.69	Main Board	R.10.32
Table 10.70	Main Board	R.10.32
Table 10.71	Interface Board #1	R.10.32
Table 10.72	Interface Board #2	R.10.33
Table 10.73	Communications Card Outputs	R.10.33
Table 10.74	MIRRORED BITS Transmit Equations	R.10.33
Table 10.75	Front-Panel Settings Categories	R.10.33
Table 10.76	Front-Panel Settings.....	R.10.34
Table 10.77	Selectable Screens for the Front Panel	R.10.38
Table 10.78	Selectable Operator Pushbuttons	R.10.39
Table 10.79	Front-Panel Event Display.....	R.10.40
Table 10.80	Boolean Display Points and Aliases.....	R.10.40
Table 10.81	Analog Display Points and User Text and Formatting	R.10.40
Table 10.82	Local Control and Aliases	R.10.41
Table 10.83	Local Bit SELOGIC	R.10.41
Table 10.84	Report Settings Categories	R.10.41
Table 10.85	SER Chatter Criteria	R.10.41
Table 10.86	SER Points and Aliases	R.10.42
Table 10.87	Event Reporting	R.10.42
Table 10.88	Event Reporting Digital Elements	R.10.43
Table 10.89	HIF Event Reporting.....	R.10.43
Table 10.90	Port Settings Categories.....	R.10.43
Table 10.92	DNP3 Serial Port Protocol Settings	R.10.44
Table 10.93	SEL Protocol Settings.....	R.10.44
Table 10.94	DNP3 Serial Protocol Settings	R.10.44
Table 10.91	Protocol Selection	R.10.44
Table 10.95	MIRRORED BITS Protocol Settings.....	R.10.45
Table 10.96	RTD Protocol Settings	R.10.47
Table 10.97	Settings Categories	R.10.47
Table 10.98	DNP Reference Map Selection	R.10.47
Table 10.99	DNP3 Object Default Map Enables	R.10.47
Table 10.100	Binary Input Map.....	R.10.47
Table 10.101	Binary Output Map	R.10.48
Table 10.102	Counter Map,	R.10.48
Table 10.103	Analog Input Map,	R.10.48
Table 10.104	Analog Output Map	R.10.48
Table 10.105	Bay Control Settings Categories.....	R.10.49
Table 10.106	General One-Line Settings	R.10.49
Table 10.107	Busbar Information	R.10.49
Table 10.108	Breaker Information.....	R.10.49
Table 10.109	Disconnect Information	R.10.50
Table 10.110	One-Line Analog Display Points and User Text and Formatting	R.10.51
Table 10.111	Control Selection	R.10.51
Table A.1	Alphabetic List of Relay Word Bits	R.A.1
Table A.2	Relay Word Bits: Enable and Target LEDs	R.A.21
Table A.3	Relay Word Bits: Directional Elements.....	R.A.22
Table A.4	Relay Word Bits: Overcurrent Elements	R.A.23
Table A.5	Relay Word Bits: Synchronism-Check Elements	R.A.25
Table A.6	Relay Word Bits: Reclosing Elements.....	R.A.25
Table A.7	Relay Word Bits: Miscellaneous Elements.....	R.A.27
Table A.8	Relay Word Bits: Trip Logic Elements	R.A.28
Table A.9	Relay Word Bits: Pilot Tripping Elements	R.A.29

Table A.10	Relay Word Bits: Circuit Breaker 1 Failure Elements	R.A.30
Table A.11	Relay Word Bits: Circuit Breaker 2 Failure Elements	R.A.31
Table A.12	Relay Word Bits: Circuit Breaker Status and Open Phase Detector	R.A.32
Table A.13	Relay Word Bits: Circuit Breaker Monitor	R.A.34
Table A.14	Relay Word Bits: RTD Status.....	R.A.35
Table A.15	Relay Word Bits: DC Supply Monitor	R.A.35
Table A.16	Relay Word Bits: Metering Elements.....	R.A.36
Table A.17	Relay Word Bits: Open and Close Command.....	R.A.36
Table A.18	Relay Word Bits: Local Bits.....	R.A.36
Table A.19	Relay Word Bits: Remote Bits	R.A.37
Table A.20	Relay Word Bits: Active Protection Settings Group	R.A.38
Table A.21	Relay Word Bits: Input Elements	R.A.38
Table A.22	Relay Word Bits: Protection Variables	R.A.40
Table A.23	Relay Word Bits: Protection Latches	R.A.41
Table A.24	Relay Word Bits: Protection Conditioning Timers	R.A.42
Table A.25	Relay Word Bits: Protection Sequencing Timers	R.A.43
Table A.26	Relay Word Bits: Protection Counters	R.A.45
Table A.27	Relay Word Bits: Automation Variables	R.A.47
Table A.28	Relay Word Bits: Automation Latches.....	R.A.53
Table A.29	Relay Word Bits: Automation Sequencing Timers	R.A.54
Table A.30	Relay Word Bits: Automation Counters.....	R.A.56
Table A.31	Relay Word Bits: SELogic Control Equation Error and Status.....	R.A.58
Table A.32	Relay Word Bits: Relay Alarms	R.A.59
Table A.33	Relay Word Bits: Time and Date Elements.....	R.A.59
Table A.34	Relay Word Bits: Output Elements	R.A.60
Table A.35	Relay Word Bits: Pushbutton Elements	R.A.61
Table A.36	Relay Word Bits: Data Reset Bits	R.A.62
Table A.37	Relay Word Bits: Target Logic Bits	R.A.62
Table A.38	Relay Word Bits: MIRRORED BITS	R.A.63
Table A.39	Relay Word Bits: Test Bits	R.A.64
Table A.40	Relay Word Bits: Communications Card Input Points.....	R.A.64
Table A.41	Relay Word Bits: Communications Card Output Points	R.A.68
Table A.42	Relay Word Bits: Communications Card Status Points	R.A.69
Table A.43	Relay Word Bits: Fast SER Enable Bits.....	R.A.70
Table A.44	Relay Word Bits: Source Selection Elements	R.A.70
Table A.45	Synchrophasor Trigger SELogic Equations	R.A.70
Table A.46	DNP Event Mode Control	R.A.71
Table A.47	Time and Synchronization Control Bits.....	R.A.71
Table A.48	Time-Error Calculation	R.A.72
Table A.49	Relay Word Bits: Local Bit Supervision and Status.....	R.A.73
Table A.50	Relay Word Bits: Bay Control—Breaker Status	R.A.75
Table A.51	Relay Word Bits: Bay Control—Disconnect Status Indication and Alarms (Disconnects 1–5)	R.A.75
Table A.52	Relay Word Bits: Bay Control—Buszone Disconnect Contacts (Disconnects 1–5).....	R.A.76
Table A.53	Relay Word Bits: Bay Control—Disconnect Open/Close (Disconnects 1–5)	R.A.76
Table A.54	Pushbuttons, Pushbutton LEDs, Target LEDs for New HMI	R.A.79
Table A.55	50G High-Impedance Fault (50G HIF) Detection Elements	R.A.80
Table A.56	High-Impedance Fault (HIF) Detection Elements	R.A.80
Table A.57	Relay Word Bits: Bay Control—Disconnect Status Indication and Alarms (Disconnects 6–10).....	R.A.82
Table A.58	Relay Word Bits: Bay Control—Buszone Disconnect Contacts (Disconnects 6–10).....	R.A.83
Table A.59	Relay Word Bits: Bay Control—Disconnect Open/Close (Disconnects 6–10)	R.A.83
Table B.1	Analog Quantities Sorted Alphabetically.....	R.B.1
Table B.2	Analog Quantities Sorted By Function	R.B.9

This page intentionally left blank

List of Figures

User's Guide

Figure 1.1	SEL-451 Functional Overview.....	U.1.2
Figure 1.2	Protecting a Line Segment With MIRRORED BITS Communications on a Fiber Channel.....	U.1.7
Figure 1.3	Single Circuit Breaker Configuration (ESS := 1).....	U.1.7
Figure 1.4	Single Circuit Breaker Configuration With Line Breaker CTs (ESS := 2)	U.1.8
Figure 1.5	Double Circuit Breaker Configuration (ESS := 3)	U.1.8
Figure 1.6	Double Circuit Breaker Configuration With Bus Protection (ESS := 4).....	U.1.9
Figure 1.7	Tapped Line (ESS := Y)	U.1.9
Figure 1.8	Bus 1, Bus 2, and Transfer Bus Bay With Ground Option (MIMIC := 4).....	U.1.10
Figure 2.1	Horizontal Front-Panel Template (SEL-451).....	U.2.3
Figure 2.2	Vertical Front-Panel Template (SEL-451).....	U.2.3
Figure 2.3	Horizontal Front-Panel Template (SEL-451-4).....	U.2.4
Figure 2.4	Vertical Front-Panel Template (SEL-451-4)	U.2.4
Figure 2.5	Rear 3U Template, Fixed Terminal Block Analog Inputs	U.2.5
Figure 2.6	Rear 3U Template, Connectorized Analog Inputs	U.2.5
Figure 2.7	Standard Control Output Connection	U.2.8
Figure 2.8	Hybrid Control Output Connection	U.2.9
Figure 2.9	Fast Hybrid Control Output Connection, INT5 (INT8)	U.2.9
Figure 2.10	Fast Hybrid Control Output Connection, INT4	U.2.10
Figure 2.11	Fast Hybrid Control Output Typical Terminals, INT5 (INT8)	U.2.10
Figure 2.12	Preccharging Internal Capacitance of Fast Hybrid Output Contacts, INT5 (INT8)	U.2.11
Figure 2.13	INT1 I/O Interface Board	U.2.13
Figure 2.14	INT2 I/O Interface Board	U.2.13
Figure 2.15	INT3 I/O Interface Board	U.2.13
Figure 2.16	INT4 I/O Interface Board	U.2.13
Figure 2.17	INT5 I/O Interface Board	U.2.13
Figure 2.18	INT6 I/O Interface Board	U.2.14
Figure 2.19	INT7 I/O Interface Board	U.2.14
Figure 2.20	INT8 I/O Interface Board	U.2.14
Figure 2.21	Chassis Key Positions for I/O Interface Boards	U.2.16
Figure 2.22	Major Component Locations on the SEL-451 Main Board A (or B)	U.2.19
Figure 2.23	J18 Header—Password and Breaker Jumpers	U.2.20
Figure 2.24	Major Component Locations on the SEL-451 INT1 (or INT2) I/O Board	U.2.23
Figure 2.25	Major Component Locations on the SEL-451 INT3 I/O Board	U.2.24
Figure 2.26	Major Component Locations on the SEL-451 INT4 I/O Board	U.2.25
Figure 2.27	Major Component Locations on the SEL-451 INT5 (or INT8) I/O Board	U.2.26
Figure 2.28	Major Component Locations on the SEL-451 INT6 (or INT7) I/O Board	U.2.27
Figure 2.29	SEL-451 Chassis Dimensions	U.2.31
Figure 2.30	3U Rear Panel, Main Board A, SEL-451	U.2.32
Figure 2.31	3U Rear Panel, Main Board A, Connectorized SEL-451	U.2.32
Figure 2.32	4U Rear Panel, Main Board A, Without Optional I/O, SEL-451	U.2.33
Figure 2.33	4U Rear Panel, Main Board A, INT5 I/O Interface Board, SEL-451	U.2.33
Figure 2.34	4U Rear Panel, Main Board B, INT8 I/O Interface Board, SEL-451	U.2.33
Figure 2.35	5U Rear Panel, Main Board B, INT3 and INT1 I/O Interface Board, SEL-451	U.2.34
Figure 2.36	5U Rear Panel, Main Board A, INT4 and INT1 I/O Interface Board, SEL-451	U.2.34
Figure 2.37	5U Rear Panel, Main Board A, INT6 and INT4 I/O Interface Board, SEL-451	U.2.35
Figure 2.38	5U Rear Panel, Main Board B, INT2 and INT7 I/O Interface Board, SEL-451	U.2.35
Figure 2.39	Rear-Panel Symbols	U.2.36
Figure 2.40	Screw Terminal Connector Keying	U.2.37
Figure 2.41	Rear-Panel Receptacle Keying, SEL-451.....	U.2.38
Figure 2.42	PS30 Power Supply Fuse Location	U.2.41
Figure 2.43	Control Output OUT108	U.2.44

Figure 2.44	SEL-451 to Computer—D-Subminiature 9-Pin Connector.....	U.2.47
Figure 2.45	Example Ethernet Panel With Fiber-Optic Ports	U.2.48
Figure 2.46	Two 10/100BASE-T Port Configuration	U.2.49
Figure 2.47	100BASE-FX and 10/100BASE-T Port Configuration	U.2.49
Figure 2.48	Two 100BASE-FX Port Configuration.....	U.2.49
Figure 2.49	Typical External AC/DC Connections—Single Circuit Breaker.....	U.2.51
Figure 2.50	Typical External AC/DC Connections—Dual Circuit Breaker	U.2.52
Figure 2.51	SEL-451 Example Wiring Diagram Using the Auxiliary TRIP/CLOSE Pushbuttons....	U.2.53
Figure 3.1	SEL Software License Agreement (Sample).....	U.3.3
Figure 3.2	Windows Run Command Line to Load ACCELERATOR QuickSet	U.3.3
Figure 3.3	ACCELERATOR QuickSet Communication Parameters Dialog Box	U.3.4
Figure 3.4	ACCELERATOR QuickSet Network Parameters Dialog Box: FTP.....	U.3.5
Figure 3.5	ACCELERATOR QuickSet Network Parameters Dialog Box: Telnet.....	U.3.5
Figure 3.6	Database Manager Relay Database in ACCELERATOR QuickSet	U.3.6
Figure 3.7	Database Manager Copy/Move in ACCELERATOR QuickSet	U.3.8
Figure 3.8	ACCELERATOR QuickSet Driver Information in the FID String	U.3.9
Figure 3.9	HMI Driver Version Number in the HMI Window.....	U.3.9
Figure 3.10	Sample Settings in ACCELERATOR QuickSet.....	U.3.11
Figure 3.11	Selecting a Settings Driver in ACCELERATOR QuickSet	U.3.11
Figure 3.12	Opening Relay Settings in ACCELERATOR QuickSet.....	U.3.12
Figure 3.13	Reading Relay Settings in ACCELERATOR QuickSet	U.3.12
Figure 3.14	ACCELERATOR QuickSet Relay Editor.....	U.3.13
Figure 3.15	Setting the Relay Part Number in ACCELERATOR QuickSet	U.3.14
Figure 3.16	Location of Expression Builder Button	U.3.15
Figure 3.17	The ACCELERATOR QuickSet Expression Builder	U.3.16
Figure 3.18	Retrieving Relay Event History	U.3.17
Figure 3.19	ACCELERATOR QuickSet Event Waveform Window.....	U.3.18
Figure 3.20	Sample Event Oscillogram	U.3.18
Figure 3.21	Retrieving Event Report Waveforms	U.3.19
Figure 3.22	Sample Phasors Event Waveform Screen	U.3.19
Figure 3.23	Sample Harmonic Analysis Event Waveform Screen	U.3.20
Figure 3.24	Sample Event Report Summary Screen.....	U.3.20
Figure 3.25	Sample Event Waveform Settings Screen.....	U.3.21
Figure 3.26	ACCELERATOR QuickSet HMI Features.....	U.3.22
Figure 4.1	SEL-451 Serial Number Label	U.4.2
Figure 4.2	Power Connection Area of the Rear Panel	U.4.3
Figure 4.3	PORT F, LCD Display, and Navigation Pushbuttons	U.4.4
Figure 4.4	Report Header.....	U.4.6
Figure 4.5	Access Level Structure	U.4.7
Figure 4.6	Relay Status	U.4.11
Figure 4.7	ACCELERATOR QuickSet Communication Parameters and Password Entry.....	U.4.12
Figure 4.8	Retrieving Relay Status: ACCELERATOR QuickSet	U.4.12
Figure 4.9	Checking Relay Status: Front-Panel LCD	U.4.13
Figure 4.10	Relay Settings Structure Overview.....	U.4.15
Figure 4.11	Components of SET Commands	U.4.17
Figure 4.12	Initial Global Settings	U.4.18
Figure 4.13	Using Text-Edit Mode Line Editing to Set Display Points.....	U.4.22
Figure 4.14	Using Text-Edit Mode Line Editing to Delete a Display Point	U.4.23
Figure 4.15	Default Alias Settings	U.4.24
Figure 4.16	Using Text-Edit Mode Line Editing to Set Aliases	U.4.25
Figure 4.17	Using Text-Edit Mode Line Editing to Set Protection Logic	U.4.26
Figure 4.18	ACCELERATOR QuickSet Global Settings Window.....	U.4.28
Figure 4.19	Uploading Global Settings to the SEL-451	U.4.29
Figure 4.20	DATE and TIME Settings: Front-Panel LCD	U.4.30
Figure 4.21	SET/SHOW Menus.....	U.4.33
Figure 4.22	Setting ESS: Terminal.....	U.4.34
Figure 4.23	Setting CTRW and PTRY: Terminal.....	U.4.35
Figure 4.24	Test Connections Using Three Voltage Sources/Three Current Sources.....	U.4.36

Figure 4.25	Test Connections Using Two Current Sources for Three-Phase Faults and METER Test ...	U.4.37
Figure 4.26	Terminal Screen MET Metering Quantities	U.4.38
Figure 4.27	Global Alternate Source Selection Settings in ACSELERATOR QuickSet.....	U.4.39
Figure 4.28	Group 1 Terminal Configuration Settings: ACSELERATOR QuickSet.....	U.4.40
Figure 4.29	HMI Tree View: ACSELERATOR QuickSet	U.4.40
Figure 4.30	Phasor Metering Quantities: ACSELERATOR QuickSet HMI.....	U.4.41
Figure 4.31	Front-Panel Screens for METER	U.4.42
Figure 4.32	SEL-451-4 One-Line Diagram.....	U.4.43
Figure 4.33	ACSELERATOR QuickSet HMI Tree View	U.4.44
Figure 4.34	ACSELERATOR QuickSet HMI Control Window	U.4.45
Figure 4.35	Event Trigger Prompt: ACSELERATOR QuickSet.....	U.4.45
Figure 4.36	Relay Event History Dialog Box.....	U.4.46
Figure 4.37	Sample HIS Command Output: Terminal	U.4.47
Figure 4.38	EVENTS Folder Files	U.4.48
Figure 4.39	Relay Event History Dialog Box in ACSELERATOR QuickSet	U.4.50
Figure 4.40	ACSELERATOR QuickSet Event Waveform Window	U.4.50
Figure 4.41	Sample Event Oscillogram.....	U.4.51
Figure 4.42	Selecting SER Points and Aliases Settings: ACSELERATOR QuickSet.....	U.4.53
Figure 4.43	SER Points and Aliases Settings: ACSELERATOR QuickSet.....	U.4.54
Figure 4.44	Uploading Report Settings to the SEL-451	U.4.55
Figure 4.45	Retrieving SER Records With ACSELERATOR QuickSet.....	U.4.55
Figure 4.46	SER Records in the ACSELERATOR QuickSet HMI	U.4.56
Figure 4.47	Setting an SER Element: Terminal.....	U.4.57
Figure 4.48	Reports File Structure.....	U.4.58
Figure 4.49	Terminal Display for PULSE Command	U.4.59
Figure 4.50	Front-Panel Menus for Pulsing OUT104	U.4.60
Figure 4.51	Password Entry Screen.....	U.4.61
Figure 4.52	Using Text-Edit Mode Line Editing to Set Local Bit 3.....	U.4.62
Figure 4.53	Setting Control Output OUT105: Terminal	U.4.63
Figure 4.54	Front-Panel LOCAL CONTROL Screens.....	U.4.64
Figure 4.55	Assigning an Additional Close Output: ACSELERATOR QuickSet	U.4.66
Figure 4.56	Uploading Output Settings to the SEL-451.....	U.4.67
Figure 4.57	Setting 52AA1: Terminal	U.4.69
Figure 4.58	Accessing Control Inputs Settings in ACSELERATOR QuickSet	U.4.70
Figure 4.59	Control Input Pickup Level Settings in ACSELERATOR QuickSet	U.4.71
Figure 4.60	Control Input Pickup and Dropout Delay Settings in ACSELERATOR QuickSet	U.4.71
Figure 4.61	Setting 52AA1 in ACSELERATOR QuickSet	U.4.72
Figure 4.62	Uploading Global and Breaker Monitor Settings to the SEL-451	U.4.73
Figure 4.63	TIME BNC Connector, New Hardware	U.4.76
Figure 4.64	TIME BNC Connectors, Old Hardware	U.4.76
Figure 4.65	Retrofit Sticker	U.4.76
Figure 4.66	Confirming the High-Accuracy Timekeeping Relay Word Bits	U.4.76
Figure 4.67	Results of the TIME Q Command.....	U.4.77
Figure 4.68	Programming a PSV in ACSELERATOR QuickSet	U.4.80
Figure 4.69	Setting OUT108 in ACSELERATOR QuickSet	U.4.80
Figure 5.1	SEL-451 Front Panel (8 pushbutton model).....	U.5.2
Figure 5.2	SEL-451 Front Panel (12 pushbutton model).....	U.5.2
Figure 5.3	LCD Display and Navigation Pushbuttons	U.5.4
Figure 5.4	RELAY ELEMENTS Highlighted in MAIN MENU	U.5.5
Figure 5.5	Sample ROTATING DISPLAY	U.5.7
Figure 5.6	Sample Alarm Points Screen.....	U.5.8
Figure 5.7	Deasserted Alarm Point.....	U.5.10
Figure 5.8	Clear Alarm Point Confirmation Screen	U.5.10
Figure 5.9	No Alarm Points Screen.....	U.5.10
Figure 5.10	Alarm Points Data Loss Screen.....	U.5.10
Figure 5.11	Sample Display Points Screen.....	U.5.11
Figure 5.12	Fast Meter Display Points Sample Screen	U.5.14
Figure 5.13	Contrast Adjustment.....	U.5.15

Figure 5.14	Enter Password Screen	U.5.15
Figure 5.15	Invalid Password Screen	U.5.16
Figure 5.16	MAIN MENU	U.5.16
Figure 5.17	METER MENU Screens	U.5.17
Figure 5.18	METER SUBMENU	U.5.17
Figure 5.19	RMS, FUND, and DEMAND Metering Screens	U.5.18
Figure 5.20	ENERGY, MAX/MIN, and SYNCH CHECK Metering Screens	U.5.19
Figure 5.21	Events Menu Screen	U.5.20
Figure 5.22	EVENT SUMMARY Screens	U.5.20
Figure 5.23	SER Events Screen	U.5.21
Figure 5.24	No SER Events Screen	U.5.21
Figure 5.25	BREAKER MONITOR Report Screens	U.5.22
Figure 5.26	RELAY ELEMENTS Screen	U.5.22
Figure 5.27	ELEMENT SEARCH Screen	U.5.23
Figure 5.28	LOCAL CONTROL Initial Menu	U.5.24
Figure 5.29	BREAKER CONTROL Screens	U.5.25
Figure 5.30	LOCAL CONTROL Example Menus	U.5.26
Figure 5.31	Local Bit Supervision Logic	U.5.28
Figure 5.32	OUTPUT TESTING Screen	U.5.29
Figure 5.33	SET/SHOW Screens	U.5.30
Figure 5.34	Sample Settings Input Screens	U.5.31
Figure 5.35	Changing the ACTIVE GROUP	U.5.32
Figure 5.36	DATE/TIME Screen	U.5.32
Figure 5.37	Edit DATE and Edit TIME Screens	U.5.33
Figure 5.38	Relay STATUS Screens	U.5.33
Figure 5.39	VIEW CONFIGURATION Sample Screens	U.5.34
Figure 5.40	DISPLAY TEST Screens	U.5.35
Figure 5.41	RESET ACCESS LEVEL Screen	U.5.35
Figure 5.42	One-Line Diagram Screen	U.5.35
Figure 5.43	Sample Status Warning and Trip EVENT SUMMARY Screens	U.5.36
Figure 5.44	Sample Status Warning in the LCD Message Area	U.5.37
Figure 5.45	Factory Default Front-Panel Target Areas (16 or 24 LEDs)	U.5.38
Figure 5.46	INST Target LED Default Operation	U.5.40
Figure 5.47	Operator Control Pushbuttons and LEDs (8 or 12 Pushbuttons)	U.5.42
Figure 5.48	Factory Default Operator Control Pushbuttons	U.5.44
Figure 6.1	Low-Level Test Interface	U.6.7
Figure 6.2	Test Connections Using Three Voltage and Three Current Sources	U.6.9
Figure 6.3	Test Connections Using Two Current Sources for Phase-to-Phase, Phase-to-Ground, and Two-Phase-to-Ground Faults	U.6.10
Figure 6.4	Test Connections Using Two Current Sources for Three-Phase Faults	U.6.11
Figure 6.5	Test Connections Using a Single Current Source for a Phase-to-Ground Fault	U.6.12
Figure 6.6	Test Connections Using a Single Current Source for a Phase-to-Phase Fault	U.6.13
Figure 6.7	Sample Targets Display on a Serial Terminal	U.6.14
Figure 6.8	Viewing Relay Word Bits From the Front-Panel LCD	U.6.15
Figure 6.9	Setting Pushbutton LED Response: ACCELERATOR QuickSet	U.6.17
Figure 6.10	Uploading Front-Panel Settings to the SEL-451	U.6.17
Figure 6.11	Setting Main Board Outputs: ACCELERATOR QuickSet	U.6.19
Figure 6.12	Uploading Output Settings to the SEL-451	U.6.20
Figure 6.13	Checking the 51S1 Overcurrent Element: ACCELERATOR QuickSet	U.6.22
Figure 6.14	Setting SER Points and Aliases: ACCELERATOR QuickSet	U.6.23
Figure 6.15	Uploading Group 1 and Report Settings to SEL-451	U.6.24
Figure 6.16	HMI Tree View: ACCELERATOR QuickSet	U.6.24
Figure 6.17	SER Report: ACCELERATOR QuickSet HMI	U.6.25
Figure 6.18	Negative-Sequence Instantaneous Overcurrent Element Settings: ACCELERATOR QuickSet	U.6.27
Figure 6.19	Uploading Group 1 Settings to the SEL-451	U.6.28
Figure 6.20	ELEMENT SEARCH Screen	U.6.28
Figure 6.21	RELAY ELEMENTS Screen Containing Element 50Q1	U.6.28

Figure 6.22	Group 1 Relay Configuration Settings: ACSELERATOR QuickSet.....	U.6.31
Figure 6.23	Group 1 Line Configuration Settings: ACSELERATOR QuickSet.....	U.6.32
Figure 6.24	Directional Settings: ACSELERATOR QuickSet.....	U.6.33
Figure 6.25	Uploading Group 1 Settings to the SEL-451	U.6.34
Figure 6.26	RELAY ELEMENTS LCD Screen Containing Elements F32Q and R32Q	U.6.34
Figure 6.27	Relay Status: ACSELERATOR QuickSet HMI.....	U.6.37
Figure 6.28	Relay Status From a STATUS A Command on a Terminal	U.6.37
Figure 6.29	Compressed ASCII Status Message.....	U.6.38

Applications Handbook

Figure 1.1	25 kV Overhead Distribution Line.....	A.1.2
Figure 1.2	Circuit Breaker Arrangement at Station S.....	A.1.4
Figure 1.3	25 kV Example Power System.....	A.1.19
Figure 1.4	Timing of Auto-Reclose Shots for the Four Operating Modes	A.1.20
Figure 1.5	Circuit Breaker Secondary Connections at Station S.....	A.1.21
Figure 1.6	138 kV Power System	A.1.26
Figure 1.7	Potential Sources	A.1.29
Figure 1.8	Circuit Breaker Failure Timing Diagram	A.1.36
Figure 1.9	25 kV Power System for Circuit Breaker Failure Example 1	A.1.36
Figure 1.10	Timing Diagram for Setting BFPUI	A.1.37
Figure 1.11	Circuit Breaker Failure Trip and Circuit Breaker Trip DC Connections	A.1.41
Figure 1.12	138 kV Power System for Circuit Breaker Failure Example 2	A.1.42
Figure 1.13	Fault Current Distribution Through Faulted Line at Station S.....	A.1.43
Figure 1.14	Timing Diagram for Setting BFPUI	A.1.44
Figure 1.15	Timing Sequence for Circuit Breaker Failure Protection	A.1.45
Figure 1.16	Circuit Breaker Failure Seal-In Logic Using Protection Free-Form SELOGIC—Breaker 1	A.1.46
Figure 1.17	Circuit Breaker BK1 DC Connections (Two Trip Coils)	A.1.49
Figure 2.1	SEL-451 Intelligent Circuit Breaker Monitor	A.2.2
Figure 2.2	Circuit Breaker Maintenance Curve (Manufacturer's Data)	A.2.4
Figure 2.3	Circuit Breaker Contact Wear Curve With SEL-451 Settings	A.2.5
Figure 2.4	Trip Bus Sensing With Relay Input IN106	A.2.7
Figure 2.5	Mechanical Operating Time for Circuit Breaker 1.....	A.2.9
Figure 2.6	Electrical Operating Time for Circuit Breaker 1 A-Phase	A.2.10
Figure 2.7	Breaker Report	A.2.14
Figure 2.8	Breaker History Report	A.2.14
Figure 2.9	Circuit Breaker Preload Data	A.2.15
Figure 2.10	Compressed ASCII Circuit Breaker Report	A.2.16
Figure 2.11	Typical Station DC Battery System.....	A.2.17
Figure 2.12	Ground Detection Factor Areas.....	A.2.20
Figure 2.13	Battery Metering: Terminal	A.2.21
Figure 2.14	Complex Power (P/Q) Plane	A.2.25
Figure 2.15	Typical Current Measuring Accuracy	A.2.27
Figure 2.16	Thermal Demand Metering	A.2.30
Figure 2.17	Rolling Demand Metering	A.2.31
Figure 2.18	Demand Current Logic Outputs	A.2.32
Figure 3.1	SEL-451 Input Processing.....	A.3.3
Figure 3.2	Data Capture/Event Report Times	A.3.6
Figure 3.3	Sample SEL-451 Oscillogram.....	A.3.8
Figure 3.4	Sample COMTRADE .HDR Header File	A.3.9
Figure 3.5	Sample COMTRADE .CFG Configuration File Data.....	A.3.10
Figure 3.6	Sample HIF COMTRADE .HDR Header File	A.3.12
Figure 3.7	Sample HIF COMTRADE .CFG Configuration File Data	A.3.12
Figure 3.8	Sample Analog Section of the Event Report.....	A.3.17
Figure 3.9	Event Report Current Column Data and RMS Current Magnitude	A.3.20
Figure 3.10	Event Report Current Column Data and RMS Current Angle.....	A.3.21
Figure 3.11	Digital Section of the Event Report	A.3.25
Figure 3.12	Sample Digital Portion of the Event Report.....	A.3.26

Figure 3.13	Summary Section of the Event Report	A.3.27
Figure 3.14	Settings Section of the Event Report	A.3.28
Figure 3.15	Sample Compressed ASCII Event Report.....	A.3.31
Figure 3.16	Sample Event Summary Report.....	A.3.32
Figure 3.17	Sample Compressed ASCII Summary	A.3.34
Figure 3.18	Sample Event History	A.3.35
Figure 3.19	Sample Compressed ASCII History Report	A.3.36
Figure 3.20	Sample HIF Event Summary Report	A.3.37
Figure 3.21	Sample Compressed ASCII HIF Summary	A.3.40
Figure 3.22	Sample HIF Event History.....	A.3.40
Figure 3.23	Sample Compressed HIF History Report	A.3.41
Figure 3.24	Sample SER Report	A.3.42
Figure 3.25	Sample Compressed ASCII SER Report.....	A.3.44
Figure 4.1	High-Accuracy Timekeeping Connections.....	A.4.2
Figure 4.2	Selecting Protection Logic 1 Settings in ACCELERATOR	A.4.3
Figure 4.3	Setting PMV64 With the Expression Builder Dialog Box	A.4.4
Figure 4.4	Selecting Trip Logic and ER Trigger Settings in ACCELERATOR	A.4.5
Figure 4.5	Uploading Group Settings to the SEL-451	A.4.6
Figure 4.6	230 kV Transmission Line System.....	A.4.6
Figure 4.7	500 kV Three Bus Power System.....	A.4.7
Figure 4.8	Power Flow Solution	A.4.9
Figure 5.1	Disconnect Switch Close Logic.....	A.5.3
Figure 5.2	Disconnect Switch Open Logic	A.5.4
Figure 5.3	Disconnect Switch Status and Alarm Logic	A.5.7
Figure 5.4	Close Immobility Timer Logic	A.5.9
Figure 5.5	Open Immobility Timer Logic.....	A.5.9
Figure 5.6	Disconnect in Transition	A.5.12
Figure 5.7	SEL-451-4 Front-Panel Pushbuttons	A.5.13
Figure 5.8	SEL-451-4 Operator Control Pushbuttons.....	A.5.13
Figure 5.9	Bay Control One-Line Diagram	A.5.14
Figure 5.10	Screens for Circuit Breaker Selection.....	A.5.18
Figure 5.11	Screens for Disconnect Switch Selection	A.5.19
Figure 5.12	HMI Disconnect Operation Initiation.....	A.5.21
Figure 5.13	HMI Disconnect Operation in Progress.....	A.5.22
Figure 5.14	HMI Disconnect Operation Completed	A.5.23
Figure 5.15	Interactive Bay Control Setting Form.....	A.5.24
Figure 5.16	Disconnect 1 Settings	A.5.25
Figure 5.17	Breaker 1 Settings.....	A.5.25
Figure 5.18	Analog Quantity Setting Form.....	A.5.25
Figure 5.19	Analog Quantity Expression Builder.....	A.5.26
Figure 5.20	Analog Quantity Expression Builder for Fixed Element.....	A.5.26
Figure 5.21	Analog Quantity Expression Builder for Analog Element	A.5.26
Figure 5.22	Analog Quantity Setting Form—Fixed Element	A.5.26
Figure 5.23	Analog Quantity Setting Form—Analog Element	A.5.27
Figure 5.24	Interactive Bay Control Setting Form.....	A.5.27
Figure 5.25	Illustration of One-Line Diagram After Entering Example Settings.....	A.5.28
Figure 5.26	Illustration of Local and Remote Control Logic With Key Control	A.5.31
Figure 5.27	Illustration of One-Line Diagram With Labels.....	A.5.36
Figure 5.28	Bay With Ground SW (Option 1)	A.5.36
Figure 5.29	Bay Without Ground SW (Option 2)	A.5.37
Figure 5.30	Tie Breaker Bay (Option 3)	A.5.37
Figure 5.31	Bay With Ground SW (Option 4)	A.5.38
Figure 5.32	Bay Without Ground SW (Option 5)	A.5.38
Figure 5.33	Transfer Bay (Option 6).....	A.5.39
Figure 5.34	Tie-Breaker Bay (Option 7)	A.5.40
Figure 5.35	Bay With Ground SW (Option 8)	A.5.40
Figure 5.36	Bay Without Ground SW (Option 9)	A.5.41
Figure 5.37	Bay With Ground SW (Option 10).....	A.5.41

Figure 5.38	Bay Without Ground SW (Option 11)	A.5.42
Figure 5.39	Left Breaker Bay With Ground SW (Option 12)	A.5.42
Figure 5.40	Right Breaker Bay With Ground SW (Option 13).....	A.5.43
Figure 5.41	Middle Breaker Bay (Option 14)	A.5.43
Figure 5.42	Left Breaker Bay Without Ground SW (Option 15)	A.5.44
Figure 5.43	Right Breaker Bay Without Ground SW (Option 16).....	A.5.44
Figure 5.44	Bay With Ground SW (Option 17).....	A.5.45
Figure 5.45	Bay Without Ground SW (Option 18)	A.5.45
Figure 5.46	Left Breaker Bay With Ground SW (Option 19)	A.5.46
Figure 5.47	Left Breaker Bay Without Ground SW (Option 20)	A.5.46
Figure 5.48	Right Breaker Bay With Ground SW Option 21)	A.5.47
Figure 5.49	Right Breaker Bay Without Ground SW (Option 22).....	A.5.47
Figure 5.50	Source Transfer (Option 23).....	A.5.48
Figure 5.51	Bus Throw-Over Type 1 (Option 24)	A.5.48
Figure 5.52	Bus Throw-Over Type 2 (Option 25)	A.5.49
Figure 5.53	Bay Character Set.....	A.5.50
Figure 6.1	SEL Communications Processor Star Integration Network	A.6.1
Figure 6.2	Multitiered SEL Communications Processor Architecture	A.6.2
Figure 6.3	Enhancing Multidrop Networks With the SEL Communications Processor	A.6.4
Figure 6.4	Example SEL Relay and SEL Communications Processor Configuration	A.6.5
Figure 7.1	DNP3 Multidrop Network Topology	A.7.3
Figure 7.2	DNP3 Star Network Topology	A.7.3
Figure 7.3	DNP3 Network With Communications Processor	A.7.3
Figure 7.4	Example Direct Networking Topology	A.7.7
Figure 7.5	Telnet Connection Dialog Box	A.7.9
Figure 7.6	Example FTP Session.....	A.7.10
Figure 7.7	Partial Contents of SET_P5.TXT.....	A.7.11
Figure 7.8	Example Telnet Session	A.7.12

Reference Manual

Figure 1.1	Current and Voltage Source Connections for the SEL-451 Relay	R.1.2
Figure 1.2	Main and Alternate Line Current Source Assignments	R.1.3
Figure 1.3	Combined Currents for Line Current Source Assignment.....	R.1.3
Figure 1.4	Breaker Current Source Assignments	R.1.3
Figure 1.5	ESS := 1, Single Circuit Breaker Configuration	R.1.8
Figure 1.6	ESS := 2, Single Circuit Breaker Configuration	R.1.9
Figure 1.7	ESS := 3, Double Circuit Breaker Configuration.....	R.1.10
Figure 1.8	ESS := 4, Double Circuit Breaker Configuration.....	R.1.11
Figure 1.9	ESS := Y, Tapped Line	R.1.12
Figure 1.10	ESS := Y, Single Circuit Breaker With Current Polarizing Source.....	R.1.13
Figure 1.11	Frequency Estimation for Protection Functions	R.1.15
Figure 1.12	Sample TEC Command Response	R.1.16
Figure 1.13	Sample TEC <i>n</i> Command Response	R.1.17
Figure 1.14	Block Diagram of HIF detection	R.1.20
Figure 1.15	Sample HIZ Report	R.1.22
Figure 1.16	Ground Instantaneous Overcurrent Element 50GHIZ.....	R.1.23
Figure 1.17	Counter CPUDO for Assertion/Deassertion of Ground Fault Overcurrent Element 50GHIZ ..	R.1.23
Figure 1.18	Counter CHIZ for High-Impedance Ground Fault Detection	R.1.24
Figure 1.19	50G High-Impedance Fault (50G HIZ) Detection Logic	R.1.25
Figure 1.20	50G HIZ Counter CPUDO Logic.....	R.1.26
Figure 1.21	50G HIZ Counter CHIZ Logic	R.1.26
Figure 1.22	Pole-Open Logic Diagram	R.1.28
Figure 1.23	LOP Logic Process Overview	R.1.30
Figure 1.24	LOP Logic	R.1.32
Figure 1.25	32Q and 32QG Enable Logic Diagram	R.1.37
Figure 1.26	32V and 32I Enable Logic Diagram	R.1.37
Figure 1.27	Best Choice Ground Directional Logic	R.1.39

Figure 1.28	Negative-Sequence Voltage-Polarized Directional Element Logic	R.1.40
Figure 1.29	Zero-Sequence Voltage-Polarized Directional Element Logic	R.1.40
Figure 1.30	Zero-Sequence Current-Polarized Directional Element Logic.....	R.1.41
Figure 1.31	Ground Directional Element Output Logic Diagram	R.1.41
Figure 1.32	32P, Phase Directional Element Logic Diagram	R.1.45
Figure 1.33	32Q, Negative-Sequence Directional Element Logic Diagram	R.1.45
Figure 1.34	Load-Encroachment Logic Diagram	R.1.47
Figure 1.35	Load-Encroachment Characteristics.....	R.1.47
Figure 1.36	Phase Instantaneous/Definite-Time Overcurrent Elements (With Directional Control Option).....	R.1.52
Figure 1.37	Residual Ground Instantaneous/Definite-Time Overcurrent Elements (With Directional Control Option).....	R.1.53
Figure 1.38	Negative-Sequence Instantaneous/Definite-Time Overcurrent Elements (With Directional Control Option).....	R.1.54
Figure 1.39	U.S. Moderately Inverse Curve: U1	R.1.60
Figure 1.40	U.S. Inverse Curve: U2	R.1.61
Figure 1.41	U.S. Very Inverse Curve: U3	R.1.62
Figure 1.42	U.S. Extremely Inverse Curve: U4	R.1.63
Figure 1.43	U.S. Short-Time Inverse Curve: U5.....	R.1.64
Figure 1.44	IEC Standard Inverse Curve: C1.....	R.1.65
Figure 1.45	IEC Very Inverse Curve: C2	R.1.66
Figure 1.46	IEC Extremely Inverse Curve: C3	R.1.67
Figure 1.47	IEC Long-Time Inverse Curve: C4.....	R.1.68
Figure 1.48	IEC Short-Time Inverse Curve: C5	R.1.69
Figure 1.49	Selectable Inverse-Time Overcurrent Element Logic Diagram.....	R.1.70
Figure 1.50	SOTF Logic Diagram	R.1.72
Figure 1.51	Required Zone Directional Settings	R.1.73
Figure 1.52	DCB Logic Diagram.....	R.1.76
Figure 1.53	Permissive Trip Receiver Logic Diagram.....	R.1.80
Figure 1.54	POTT Logic Diagram	R.1.81
Figure 1.55	Permissive Trip Received Logic Diagram	R.1.84
Figure 1.56	DCUB Logic Diagram.....	R.1.85
Figure 1.57	Trip Logic Diagram	R.1.89
Figure 1.58	Two Circuit Breakers Trip Logic Diagram	R.1.90
Figure 1.59	Trip Unlatch Logic.....	R.1.90
Figure 1.60	Circuit Breaker One-Status Logic Diagram	R.1.92
Figure 1.61	Circuit Breaker Failure to Interrupt Fault Current Logic Diagram	R.1.93
Figure 1.62	No Current/Residual Current Circuit Breaker Failure Protection Logic Diagram	R.1.95
Figure 1.63	Circuit Breaker Failure Seal-In Logic Diagram	R.1.99
Figure 1.64	Raw Current Sample Logic Diagram	R.1.99
Figure 1.65	Failure to Interrupt Load Current Logic Diagram	R.1.100
Figure 1.66	Flashover Protection Logic Diagram.....	R.1.100
Figure 1.67	Circuit Breaker Failure Trip Logic Diagram	R.1.100
Figure 2.1	Auto-Reclose State Diagram for Circuit Breaker 1	R.2.4
Figure 2.2	Multiple Circuit Breaker Arrangement.....	R.2.9
Figure 2.3	Multiple Circuit Breaker Arrangement.....	R.2.12
Figure 2.4	Leader/Follower Selection by Relay Input	R.2.16
Figure 2.5	Circuit Breaker Pole-Open Logic Diagrams.....	R.2.18
Figure 2.6	Line-Open Logic Diagram When E79 := Y	R.2.18
Figure 2.7	Line-Open Logic Diagram When E79 := Y1	R.2.19
Figure 2.8	Qualified Auto-Reclose Initiation.....	R.2.19
Figure 2.9	One Circuit Breaker Three-Pole Cycle State (79CY3).....	R.2.20
Figure 2.10	Two Circuit Breakers Three-Pole Cycle State (79CY3) When E79 := Y	R.2.21
Figure 2.11	Two Circuit Breakers Three-Pole Cycle State (79CY3) When E79 := Y1	R.2.24
Figure 2.12	Manual Close Logic.....	R.2.28
Figure 2.13	Voltage Check Element Applications	R.2.30
Figure 2.14	Voltage Check Element Logic	R.2.31
Figure 2.15	Partial Breaker-and-a-Half or Partial Ring-Bus Breaker Arrangement.....	R.2.35

Figure 2.16	Voltage Angle Difference in a Paralleled System	R.2.36
Figure 2.17	Synchronism-Check Voltages for Two Circuit Breakers	R.2.37
Figure 2.18	Synchronism-Check Settings	R.2.38
Figure 2.19	Synchronism-Check Relay Word Bits.....	R.2.38
Figure 2.20	Example Synchronism-Check Voltage Connections to the SEL-451	R.2.40
Figure 2.21	Synchronism-Check Voltage Reference.....	R.2.41
Figure 2.22	Normalized Synchronism-Check Voltage Sources VS1 and VS2.....	R.2.42
Figure 2.23	Healthy Voltage Window and Indication.....	R.2.43
Figure 2.24	Synchronism-Check Enable Logic.....	R.2.44
Figure 2.25	“No Slip” System Synchronism-Check Element Output Response	R.2.46
Figure 2.26	“Slip—No Compensation” Synchronism-Check Element Output Response	R.2.47
Figure 2.27	“Slip—With Compensation” Synchronism-Check Element Output Response	R.2.49
Figure 2.28	Alternative Synchronism-Check Source 2 Example and Settings	R.2.51
Figure 3.1	Protection and Automation Separation	R.3.3
Figure 3.2	SELOGIC Control Equation Programming Areas	R.3.6
Figure 3.3	Conditioning Timer With Pickup and No Dropout Timing Diagram.....	R.3.18
Figure 3.4	Conditioning Timer With Pickup Not Satisfied Timing Diagram.....	R.3.18
Figure 3.5	Conditioning Timer With Dropout and No Pickup Timing Diagram.....	R.3.19
Figure 3.6	Conditioning Timer With Pickup and Dropout Timing Diagram	R.3.19
Figure 3.7	Conditioning Timer Timing Diagram for Example 3.7.....	R.3.20
Figure 3.8	Sequencing Timer Timing Diagram.....	R.3.22
Figure 3.9	R_TRIGGER Timing Diagram	R.3.29
Figure 3.10	F_TRIGGER Timing Diagram.....	R.3.30
Figure 4.1	SEL-451 3U Chassis Front-Panel Layout	R.4.2
Figure 4.2	SEL-451 3U Rear-Panel Layout.....	R.4.3
Figure 4.3	EIA-232 Connector Pin Numbers	R.4.3
Figure 4.4	MAP 1:METER Command Example.....	R.4.29
Figure 5.1	SEL-2600 Series RTD Module and the SEL-451	R.5.23
Figure 5.2	MET T Command Response	R.5.24
Figure 5.3	MET T Command Response for Status Problem	R.5.24
Figure 6.1	DNP Application Network Diagram	R.6.30
Figure 6.2	SEL-451 Example DNP Map Settings	R.6.33
Figure 6.3	DNP LAN/WAN Application Example Ethernet Network	R.6.53
Figure 6.4	Add Binary Inputs to SER Point List	R.6.56
Figure 7.1	High Accuracy Clock Controls Reference Signal (60 Hz System).	R.7.3
Figure 7.2	Waveform at Relay Terminals May Have a Phase Shift.....	R.7.3
Figure 7.3	Correction of Measured Phase Angle.....	R.7.4
Figure 7.4	Example Calculation of Real and Imaginary Components of Synchrophasor.....	R.7.4
Figure 7.5	Sample MET PM Command Response.....	R.7.17
Figure 8.1	SEL-451 Predefined Reports.....	R.8.6
Figure 8.2	SEL-451 Datasets	R.8.8
Figure 8.3	GOOSE Quality.....	R.8.9
Figure 9.1	Sample HIZ Report	R.9.28
Figure 9.2	Sample ID Command Response.....	R.9.30
Figure 9.3	Sample ID Command Response From Ethernet Card.....	R.9.30
Figure 9.4	Sample LOG HIF Command Response	R.9.32
Figure 9.5	Sample MET HIF Command Response	R.9.37
Figure 9.6	Sample VER Command Response.....	R.9.65
Figure 10.1	Changing a Default Name to an Alias.....	R.10.5
Figure 10.2	Extract From the Report Default Settings Showing SER Settings.....	R.10.42

This page intentionally left blank

Preface

This manual provides information and instructions for installing and operating the SEL-451 Relay. The three volumes that comprise this manual are for use by power engineers and others experienced in protective relaying applications. Included are detailed technical descriptions of the relay and application examples. While this manual gives reasonable examples and illustrations of relay uses, you must exercise sound judgment at all times when applying the SEL-451 in a power system. Throughout the manual, we provide margin notes next to the text explaining a feature to specify the availability of that feature in the SEL-451-1 and SEL-451-2 versions of the relay.

Manual Overview

The SEL-451 Relay Manual consists of three volumes:

- User's Guide
- Applications Handbook
- Reference Manual

In addition, the SEL-451 Relay Manual contains a comprehensive Index that encompasses the entire manual. The index appears at the end of each printed volume. In the electronic version of the manual, the index appears once; hyperlinks take you to material referenced in the index. Also included is a glossary that lists and defines technical terms used throughout the manual.

The SEL-451 Relay Manual is a comprehensive work covering all aspects of relay application and use. Read the sections that pertain to your application to gain valuable information about using the SEL-451. For example, to learn about relay protection functions, read the protection sections of this manual and skim the automation sections, then concentrate on the operation sections or on the automation sections of this manual as your job needs and responsibilities dictate. An overview of each manual section and section topics follows.

Preface. Describes manual organization and conventions used to present information (appears once in the electronic form of the manual; repeated in each printed volume).

User's Guide

Section 1: Introduction and Specifications. Introduces SEL-451 features; summarizes relay functions and applications; lists relay specifications, type tests, and ratings.

Section 2: Installation. Discusses the ordering configurations and interface features (control inputs, control outputs, and analog inputs, for example); provides information about how to design a new physical installation and secure the relay in a panel or rack; details how to set relay board jumpers and make proper rear-panel connections (including wiring to CTs, PTs, and a GPS receiver); explains basic connections for the relay communications ports and how to install optional communications cards (such as the SEL-2701 Ethernet Processor).

Applications Handbook

- Section 3: PC Software.** Explains how to use the ACCELERATOR QuickSet® SEL-5030 software program.
- Section 4: Basic Relay Operations.** Describes how to perform fundamental operations such as applying power and communicating with the relay, setting and viewing passwords, checking relay status, viewing metering data, reading event reports and SER (Sequential Events Recorder) records, operating relay control outputs and control inputs, and using relay features to make relay commissioning easier.
- Section 5: Front-Panel Operations.** Describes the LCD display messages and menu screens; shows you how to use front-panel pushbuttons and read targets; provides information about local substation control and how to make relay settings via the front panel.
- Section 6: Testing and Troubleshooting.** Describes techniques for testing, troubleshooting, and maintaining the SEL-451; includes the list of status notification messages and a troubleshooting chart.
- Appendix A: Firmware and Manual Versions.** Lists the current firmware versions and details differences between the current and previous versions.
- Section 1: Protection Application Examples.** Provides the following protection schemes with explanations and settings:
- 25 kV Overhead Distribution Line Example
 - Auto-Reclose Example
 - Auto-Reclose and Synchronism check Example
 - Circuit Breaker Failure Application Examples
- Section 2: Monitoring and Metering.** Describes how to use the circuit breaker monitors and the substation dc battery monitors; provides information on viewing fundamental and rms metering quantities for voltages and currents, as well as power and energy metering data.
- Section 3: Analyzing Data.** Explains how to obtain and interpret high-resolution raw data oscilloscopes, filtered event reports, event summaries, history reports, and SER reports; discusses how to enter SER trigger and alias settings.
- Section 4: Time-Synchronized Measurements.** Explains synchronized phasor measurements and estimation of power system states using the SEL-451 high-accuracy time-stamping capability; presents real-time load flow/power flow application ideas.
- Section 5: Bay Control.** Describes the features of the SEL-451-4 Bay Control Relay; presents circuit breaker and disconnect switch logic, one-line diagram display, settings example, and predefined bay configurations.
- Section 6: SEL Communications Processor Applications.** Provides examples of how to use the SEL-451 with the SEL-2032, SEL-2030, and SEL-2020 Communications Processors for total substation automation solutions.
- Section 7: Direct Network Communications.** Explains how to use DNP3 (serial and LAN/WAN) and other Ethernet protocols such as Telnet, FTP, and IEC 61850

Reference Manual

Section 1: Protection Functions. Describes the function of various relay protection elements; describes how the relay processes these elements; gives detailed specifics on protection scheme logic for POTT, DCB, and DCUB; provides trip logic diagrams, and current and voltage source selection details.

Section 2: Auto-Reclosing and Synchronism Check. Explains how to operate the SEL-451 two-circuit breaker multi-shot recloser; shows selection of the lead and follow circuit breakers; explains how to set and apply synchronism-check elements for automatic and manual closing.

Section 3: SELogic Control Equations. Describes multiple setting groups and SELOGIC control equations and how to apply these equations; discusses expanded SELOGIC control equation features such as PLC-style commands, math functions, counters, and conditioning timers; provides a tutorial for converting older format SELOGIC control equations to new free-form equations.

Section 4: Communications Interfaces. Explains the physical connection of the SEL-451 to various communications network topologies.

Section 5: SEL Communications Protocols. Describes the various SEL software protocols and how to apply these protocols to substation integration and automation; includes details about SEL ASCII, SEL Compressed ASCII, SEL Fast Meter, SEL Fast Operate, SEL Fast SER, and enhanced MIRRORED BITS® communications.

Section 6: DNP3 Communications. Describes the DNP 3.00 communications protocol and how to apply this protocol to substation integration and automation; provides an example for implementing DNP 3.00 in a substation.

Section 7: Synchrophasors. Describes the Phasor Measurement Unit (PMU) functions of the SEL-451; provides details on synchrophasor measurement; describes the IEEE C37.118 synchrophasor protocol settings; describes the SEL Fast Message synchrophasor protocol settings.

Section 8: IEC 61850 Communications. Describes the IEC 61850 protocol and how to apply this protocol to substation automation and integration. Includes IEC 61850 protocol compliance statements.

Section 9: ASCII Command Reference. Provides an alphabetical listing of all ASCII commands with examples for each ASCII command option.

Section 10: Settings. Provides a list of all SEL-451 settings and defaults. The organization of the settings is the same as for the settings organization in the relay and in the ACCELERATOR QuickSet software.

Appendix A: Relay Word Bits. Contains a summary of Relay Word bits.

Appendix B: Analog Quantities. Contains a summary of analog quantities.

CD-ROM

The CD-ROM contains the SEL-451 Relay manual in an electronic form that you can search easily.

Conventions

Typographic Conventions

There are three ways to communicate with the SEL-451:

- Using a command line interface in a PC terminal emulation window.
- Using the front-panel menus and pushbuttons.
- Using ACSELERATOR QuickSet® SEL-5030 Software

The instructions in this manual indicate these options with specific font and formatting attributes. The following table lists these conventions:

Example	Description
STATUS	Commands, command options, and command variables typed at a command line interface on a PC.
<i>n</i> SUM n	Variables determined based on an application (in bold if part of a command).
<Enter>	Single keystroke on a PC keyboard.
<Ctrl+D>	Multiple/combination keystroke on a PC keyboard.
Start > Settings	PC software dialog boxes and menu selections. The > character indicates submenus.
CLOSE	Relay front-panel pushbuttons.
ENABLE	Relay front- or rear-panel labels.
RELAY RESPONSE MAIN > METER	Relay front-panel LCD menus and relay responses visible on the PC screen. The > character indicates submenus.
U.3.1 A.3.1 R.3.1	Page numbers include a reference to the volume, section, and page number. U stands for User's Guide A stands for Applications Handbook R stands for Reference Manual.
SELOGIC control equations	SEL trademarks and registered trademarks contain the appropriate symbol on first reference in a section. In the SEL-451 Instruction Manual, certain SEL trademarks appear in small caps. These include SELOGIC control equations, MIRRORED BITS communications, and the ACSELERATOR QuickSet software program.
Modbus®	Registered trademarks of other companies include the registered trademark symbol with the first occurrence of the term in a section.

Examples

This instruction manual uses several example illustrations and instructions to explain how to effectively operate the SEL-451. These examples are for demonstration purposes only; the firmware identification information or settings values included in these examples may not necessarily match those in the current version of your SEL-451.

Notes

Margin notes serve two purposes in the SEL-451 Relay Manual. Notes present valuable or important points about relay features or functions. Use these notes as tips to easier and more efficient operation of the relay.

Commands

You can simplify the task of entering commands by shortening any ASCII command to the first three characters (upper- or lowercase); for example, **ACCESS** becomes **ACC**.

Always send a carriage return **<CR>** character, or a carriage return character followed by a line feed character **<CR><LF>**, to command the relay to process the ASCII command. Usually, most terminals and terminal programs interpret the **<Enter>** key as a **<CR>**. For example, to send the **ACCESS** command, type the following:

ACC <Enter>

Step-by-Step Procedures

The SEL-451 Relay Manual contains many step-by-step procedures. These procedures lead you easily and efficiently through complex tasks. Each procedure lists required equipment, as well as the basic knowledge you need to perform the steps in the procedure. Throughout the procedure, the documentation references other SEL-451 Relay Manual sections where you can find more information.

Read the entire procedure before performing the listed steps. Read each step again before you perform it. The format of a single step is the following:

- Synopsis of the step (if the step involves multiple actions)
- Tasks to perform the step (listed as a., b., c., etc. if the step involves multiple actions)
- Explanatory text or how the relay responds (if applicable)

The following text shows sample steps. Steps include explanations, text references, table references, and figure references to further illustrate the step.

- Step 1. Establish communication.
- a. Press **<Ctrl+T>** to use the serial communications terminal in ACSELERATOR.
 - b. Press **<Enter>** to see if the communications link is active between the software and the relay.
- You should see the Access Level 0 = prompt in the terminal window.
- Step 2. Confirm that you have loaded the correct passwords in ACSELERATOR.
- a. Click **Communication > Port Parameters**.
 - b. Confirm that you have entered the correct passwords in the **Level One Password** dialog box and the **Level Two Password** dialog box.
- Step 3. Click **Settings > Read** to read the present configuration in the SEL-451.
- The relay sends all configuration and settings data to ACSELERATOR.
- Step 4. Select settings by clicking the + mark next to the **Group** you want to program on the **Settings** tree view.
- This example uses Group 1, as shown in *Figure 1.2*.

Sample Step-by-Step Instructions

Numbers

This manual displays numbers as decimal values. Hexadecimal numbers include the letter h appended to the number. Alternatively, the prefix 0X can also indicate a hexadecimal number. For instance, 11 is the decimal number eleven, but 11h and 0X11 are hexadecimal representations of the decimal value seventeen.

Safety Information

This manual uses three kinds of hazard statements, formatted as follows:

CAUTION

Indicates a potentially hazardous situation that, if not avoided, may result in minor or moderate injury or equipment damage.

WARNING









Indicates a potentially hazardous situation that, if not avoided, **could** result in death or serious injury.

DANGER

Indicates an imminently hazardous situation that, if not avoided, **will** result in death or serious injury.

Logic Diagrams

Logic diagrams in this manual follow the conventions and definitions shown below.

NAME	SYMBOL	FUNCTION
COMPARATOR		Input A is compared to input B. Output C asserts if A is greater than B.
INPUT FLAG		Input A comes from other logic.
OR		Either input A or input B asserted cause output C to assert.
EXCLUSIVE OR		If either A or B is asserted, output C is asserted. If A and B are of the same state, C is deasserted.
NOR		If neither A nor B asserts, output C asserts.
AND		Input A and input B must assert to assert output C.
AND W/ INVERTED INPUT		If input A is asserted and input B is deasserted, output C asserts. Inverter "0" inverts any input or output on any gate.
NAND		If A and/or B are deasserted, output C is asserted.
TIME DELAYED PICK UP AND/OR TIME DELAYED DROP OUT		X is a time-delay-pickup value; Y is a time-delay-dropout value. B asserts time X after input A asserts; B will not assert if A does not remain asserted for time X. If X is zero, B will assert when A asserts. If Y is zero, B will deassert when A deasserts.
EDGE TRIGGER TIMER		Rising edge of A starts timers. Output B will assert time X after the rising edge of A. B will remain asserted for time Y. If Y is zero, B will assert for a single processing interval. Input A is ignored while the timers are running.
SET RESET FLIP FLOP		Input S asserts output Q until input R asserts. Output Q deasserts or resets when R asserts.
FALLING EDGE		B asserts at the falling edge of input A.

SEL-451 Cautions, Warnings, and Dangers

The following hazard statements appear in the body of this manual in English. See the following table for the English and French translation of these statements.

English	French
CAUTION Equipment components are sensitive to electrostatic discharge (ESD). Undetectable permanent damage can result if you do not use proper ESD procedures. Ground yourself, your work surface, and this equipment before removing any cover from this equipment. If your facility is not equipped to work with these components, contact SEL about returning this device and related SEL equipment for service.	ATTENTION Les composants de cet équipement sont sensibles aux décharges électrostatiques (DES). Des dommages permanents non-décelables peuvent résulter de l'absence de précautions contre les DES. Raccordez-vous correctement à la terre, ainsi que la surface de travail et l'appareil avant d'en retirer un panneau. Si vous n'êtes pas équipés pour travailler avec ce type de composants, contacter SEL afin de retourner l'appareil pour un service en usine.
CAUTION There is danger of explosion if the battery is incorrectly replaced. Replace only with Ray-O-Vac® no. BR2335 or equivalent recommended by manufacturer. Dispose of used batteries according to the manufacturer's instructions.	ATTENTION Il y a un danger d'explosion si la pile électrique n'est pas correctement remplacée. Utiliser exclusivement Ray-O-Vac® No. BR2335 ou un équivalent recommandé par le fabricant. Se débarrasser des piles usagées suivant les instructions du fabricant.
CAUTION Equipment damage can result from connecting ac circuits to Hybrid (high-current-interrupting) control outputs. Do not connect ac circuits to Hybrid control outputs. Use only dc circuits with Hybrid control outputs.	ATTENTION Des dommages à l'appareil pourraient survenir si un circuit CA était raccordé aux contacts de sortie à haut pouvoir de coupure de type "Hybrid." Ne pas raccorder de circuit CA aux contacts de sortie de type "Hybrid." Utiliser uniquement du CC avec les contacts de sortie de type "Hybrid."
CAUTION Substation battery systems that have either a high resistance to ground (greater than 10 kΩ) or are ungrounded when used in conjunction with many direct-coupled inputs can reflect a dc voltage offset between battery rails. Similar conditions can exist for battery monitoring systems that have high-resistance balancing circuits or floating grounds. For these applications, SEL provides optional ground-isolated (optoisolated) contact inputs. In addition, SEL has published an application advisory on this issue. Contact the factory for more information.	ATTENTION Les circuits de batterie de postes qui présentent une haute résistance à la terre (plus grande que 10 kΩ) ou sont isolés peuvent présenter un biais de tension CC entre les deux polarités de la batterie quand utilisés avec plusieurs entrées à couplage direct. Des conditions similaires peuvent exister pour des systèmes de surveillance de batterie qui utilisent des circuits d'équilibrage à haute résistance ou des masses flottantes. Pour ce type d'applications, SEL peut fournir en option des contacts d'entrée isolés (par couplage optoélectronique). De surcroît, SEL a publié des recommandations relativement à cette application. Contacter l'usine pour plus d'informations.
CAUTION If you are planning to install an INT4 I/O Interface Board in your relay (see Table 2.3 and Table 2.4 for board descriptions), first check the firmware version of the relay—see Firmware Version Number on page U.6.36 . If the firmware version is R111 or lower, you must first upgrade the relay firmware to the newest version and verify that the firmware upgrade was successful before installing the new board. Failure to install the new firmware first will cause the I/O Interface Board to fail, and it may require factory service. Complete firmware upgrade instructions are provided when new firmware is ordered.	ATTENTION Si vous avez l'intention d'installer une Carte d'Interface INT4 I/O dans votre relais (voit Table 2.3 et Table 2.4 pour la description de la carte), vérifiez en premier la version du logiciel du relais (voir l'indentification de la Version du logiciel [Firmware Version Number on page U.6.36]). Si la version est R111 ou antérieure, vous devez mettre à jour le logiciel du relais avec la version la plus récente et vérifier que la mise à jour a été correctement installée sur la nouvelle carte. Les instructions complètes de mise à jour sont fournies quand le nouveau logiciel est commandé.
CAUTION Field replacement of I/O boards INT1, INT2, INT5, INT6, INT7, or INT8 with INT4 can cause I/O contact failure. The INT4 board has a pickup and dropout delay setting range of 0-1 cycle. For all other I/O boards, pickup and dropout delay settings (IN201PU-IN224PU, IN201DO-IN224DO, IN301PU-IN324PU, and IN301DO-IN324DO) have a range of 0-5 cycles. Upon replacing any I/O board with an INT4 board, manually confirm reset of pickup and dropout delays to within the expected range of 0-1 cycle.	ATTENTION Le remplacement en chantier des cartes d'entrées/sorties INT1, INT2, INT5, INT6, INT7 ou INT8 par une carte INT4 peut causer la défaillance du contact d'entrée/sortie. La carte INT4 présente un intervalle d'ajustement pour les délais de montée et de retombée de 0 à 1 cycle. Pour toutes les autres cartes, l'intervalle de réglage du délai de montée et retombée (IN201PU-IN224PU, IN201DO-IN224DO, IN301PU-IN324PU, et IN301DO-IN324DO) est de 0 à 5 cycles. Quand une carte d'entrées/sorties est remplacée par une carte INT4, vérifier manuellement que les délais de montée et retombée sont dans l'intervalle de 0 à 1 cycle.

English	French
⚠ CAUTION Do not install a jumper on positions A or D of the main board J18 header. Relay misoperation can result if you install jumpers on positions J18A and J18D.	⚠ ATTENTION Ne pas installer de cavalier sur les positions A ou D sur le connecteur J18 de la carte principale. Une opération intempestive du relais pourrait résulter suite à l'installation d'un cavalier entre les positions J18A et J18D.
⚠ CAUTION Insufficiently rated insulation can deteriorate under abnormal operating conditions and cause equipment damage. For external circuits, use wiring of sufficiently rated insulation that will not break down under abnormal operating conditions.	⚠ ATTENTION Un niveau d'isolation insuffisant peut entraîner une détérioration sous des conditions anormales et causer des dommages à l'équipement. Pour les circuits externes, utiliser des conducteurs avec une isolation suffisante de façon à éviter les claquages durant les conditions anormales d'opération.
⚠ CAUTION Relay misoperation can result from applying other than specified secondary voltages and currents. Before making any secondary circuit connections, check the nominal voltage and nominal current specified on the rear-panel nameplate.	⚠ ATTENTION Une opération intempestive du relais peut résulter par le branchement de tensions et courants secondaires non conformes aux spécifications. Avant de brancher un circuit secondaire, vérifier la tension ou le courant nominal sur la plaque signalétique à l'arrière.
⚠ CAUTION Severe power and ground problems can occur on the communications ports of this equipment as a result of using non-SEL cables. Never use standard null-modem cables with this equipment.	⚠ ATTENTION Des problèmes graves d'alimentation et de terre peuvent survenir sur les ports de communication de cet appareil si des câbles d'origine autre que SEL sont utilisés. Ne jamais utiliser de câble de modem nul avec cet équipement.
⚠ CAUTION Do not connect power to the relay until you have completed these procedures and receive instruction to apply power. Equipment damage can result otherwise.	⚠ ATTENTION Ne pas mettre le relais sous tension avant d'avoir complété ces procédures et d'avoir reçu l'instruction de brancher l'alimentation. Des dommages à l'équipement pourraient survenir autrement.
⚠ CAUTION The outputs in the SEL-451-4 are not designed to break the coil current in the disconnect motor. An auxiliary contact with adequate current interrupting capacity must clear the coil current in the disconnect motor before the output on the SEL-451-4 opens. Failure to observe this safeguard could result in damage to the SEL-451-4 output contacts.	⚠ ATTENTION Les contacts de sortie du relais SEL-451-4 ne peuvent pas interrompre le courant de bobine du moteur de sectionneur. Un contact auxiliaire avec un pouvoir de coupe adéquat doit couper le courant de la bobine du moteur de sectionneur avant que le contact de sortie du SEL-451-4 ne s'ouvre. La non-conformité à cette règle de sécurité pourrait endommager les contacts de sortie du SEL-451-4.
⚠ CAUTION Use of controls or adjustments, or performance of procedures other than those specified herein, may result in hazardous radiation exposure.	⚠ ATTENTION L'utilisation de commandes ou de réglages, ou l'application de tests de fonctionnement différents de ceux décrits ci-après peuvent entraîner l'exposition à des radiations dangereuses.
⚠ WARNING Use of this equipment in a manner other than specified in this manual can impair operator safety safeguards provided by this equipment.	⚠ AVERTISSEMENT L'utilisation de cet appareil suivant des procédures différentes de celles indiquées dans ce manuel peut désarmer les dispositifs de protection d'opérateur normalement actifs sur cet équipement.
⚠ WARNING Have only qualified personnel service this equipment. If you are not qualified to service this equipment, you can injure yourself or others, or cause equipment damage.	⚠ AVERTISSEMENT Seules des personnes qualifiées peuvent travailler sur cet appareil. Si vous n'êtes pas qualifiés pour ce travail, vous pourriez vous blesser avec d'autres personnes ou endommager l'équipement.
⚠ WARNING This device is shipped with default passwords. Default passwords should be changed to private passwords at installation. Failure to change each default password to a private password may allow unauthorized access. SEL shall not be responsible for any damage resulting from unauthorized access.	⚠ AVERTISSEMENT Cet appareil est expédié avec des mots de passe par défaut. A l'installation, les mots de passe par défaut devront être changés pour des mots de passe confidentiels. Dans le cas contraire, un accès non-autorisé à l'équipement peut être possible. SEL décline toute responsabilité pour tout dommage résultant de cet accès non-autorisé.
⚠ WARNING Do not look into the fiber (laser) ports/connectors.	⚠ AVERTISSEMENT Ne pas regarder vers l'extrémité des ports ou connecteurs de fibres pour laser.

English	French
⚠WARNING Do not look into the end of an optical cable connected to an optical output.	⚠AVERTISSEMENT Ne pas regarder vers l'extrémité d'un câble optique raccordé à une sortie optique.
⚠WARNING Do not perform any procedures or adjustments that this instruction manual does not describe.	⚠AVERTISSEMENT Ne pas appliquer une procédure ou un ajustement qui n'est pas décrit explicitement dans ce manuel d'instruction.
⚠WARNING During installation, maintenance, or testing of the optical ports, use only test equipment qualified for Class 1 laser products.	⚠AVERTISSEMENT Durant l'installation, la maintenance ou le test des ports optiques, utilisez exclusivement des équipements de test homologués comme produits de type laser de Classe 1.
⚠DANGER Incorporated components, such as LEDs, transceivers, and laser emitters, are not user serviceable. Return units to SEL for repair or replacement.	⚠AVERTISSEMENT Les composants internes tels que les leds (diodes électroluminescentes), émetteurs-récepteurs ou émetteurs pour rayon laser ne peuvent pas être entretenus par l'usager. Retourner ces unités à SEL pour toute réparation ou remplacement.
⚠DANGER Disconnect or de-energize all external connections before opening this device. Contact with hazardous voltages and currents inside this device can cause electrical shock resulting in injury or death.	⚠DANGER Débrancher tous les raccordements externes avant d'ouvrir cet appareil. Tout contact avec des tensions ou courants internes à l'appareil peut causer un choc électrique pouvant entraîner des blessures ou la mort.
⚠DANGER Contact with instrument terminals can cause electrical shock that can result in injury or death.	⚠DANGER Tout contact avec les bornes de l'appareil peut causer un choc électrique pouvant entraîner des blessures ou la mort.

This page intentionally left blank

Section 1

Introduction and Specifications

The SEL-451 Relay is a distribution relay featuring auto-reclosing with synchronism check, circuit breaker monitoring and circuit breaker failure protection. The SEL-451 features extensive metering and data recording including high-resolution data capture and reporting.

The relay features expanded SELOGIC® control equation programming for easy and flexible implementation of custom protection and control schemes. The SEL-451 has separate protection and automation SELOGIC control equation programming areas with extensive protection programming capability and 1000 lines of automation programming capability. You can organize automation of SELOGIC control equation programming into 10 blocks of 100 program lines each.

The SEL-451 provides extensive communications interfaces from standard SEL ASCII and enhanced MIRRORED BITS® communications protocols to Ethernet connectivity with the optional Ethernet card. With the Ethernet card, you can employ the latest industry communications tools, including Telnet, FTP, IEC 61850, and DNP3 (Serial and LAN/WAN) protocols.

Purchase of an SEL-451 includes the ACCELERATOR Quickset® software program. ACCELERATOR Quickset assists you in setting, controlling, and acquiring data from the relays, both locally and remotely. ACCELERATOR Architect® is included with purchase of the optional Ethernet card with IEC 61850 protocol support. ACCELERATOR Architect enables you to view and configure IEC 61850 settings via a GUI interface, tightly integrated with ACCELERATOR Quickset.

Synchrophasor measurements are available when a high-accuracy time source is connected to the relay. The SEL-451 supports the IEEE C37.118, Standard for Synchrophasors for Power Systems.

The SEL-451-4 is an SEL-451 relay that features bay control functionality. The SEL-451-4 relay provides over 25 user-selectable predefined mimic displays. The mimic display selected is displayed on the front-panel screen in one-line diagram format. The number of disconnects and breakers that can be controlled by the SEL-451 are a function of the selected mimic display screen. A maximum of ten disconnects and two breakers can be supported in a single mimic display. Control of the breakers and disconnects is available through front-panel pushbuttons, ASCII interface, Fast Message, or SELOGIC equations. See [Section 5: Bay Control in the Applications Handbook](#) for bay control logic and disconnect/circuit breaker operations.

A simple and robust hardware design features efficient digital signal processing. Combined with extensive self-testing, these features provide relay reliability and enhance relay availability.

This section introduces the SEL-451 and provides information on the following topics:

- [Features on page U.1.2](#)
- [Models and Options on page U.1.5](#)
- [Applications on page U.1.7](#)
- [Specifications on page 1.12](#)

Features

The SEL-451 contains many protection, automation, and control features. [Figure 1.1](#) presents a simplified functional overview of the relay.




Figure 1.1 SEL-451 Functional Overview

SEL-451 features include the following:

Protection. Use multiple instantaneous and time-overcurrent elements with SELOGIC control equations to customize distribution protection. Best Choice Ground Directional Element™ logic optimizes directional element performance and eliminates the need for many directional settings. Built-in communications-assisted tripping logic simplifies communication scheme implementation.

Automation. Take advantage of enhanced automation features that include 32 programmable elements for local control, remote control, protection latching, and automation latching. Local metering on the large format front-panel Liquid Crystal Display (LCD) eliminates the need for separate panel meters. Use serial and Ethernet links to efficiently transmit key information, including metering data, protection element and control I/O status, Sequential Events Recorder (SER) reports, breaker monitor, relay summary event reports, and time

synchronization. Use expanded SELOGIC control equations with math and comparison functions in control applications. Incorporate up to 1000 lines of automation logic to speed and improve control actions.

High-Accuracy Time-Stamping. Time-tag binary COMTRADE event reports with real-time accuracy of better than 10 μ s. View system state information to an accuracy of better than 1/4 of an electrical degree.

Digital Relay-to-Relay Communications. Use Enhanced MIRRORED BITS communications to monitor internal element conditions between relays within a station, or between stations, using SEL fiber-optic transceivers. Send digital, analog, and virtual terminal data over the same MIRRORED BITS channel.

Ethernet Access. Access all relay functions with the optional Ethernet card. Interconnect with automation systems using IEC 61850 or DNP3 LAN/WAN protocols directly or DNP3 through an SEL-2032 Communications Processor. Use file transfer protocol (FTP) for high-speed data collection.

Primary Potential Redundancy. Multiple voltage inputs to the SEL-451 provide primary input redundancy. At loss-of-potential (LOP) detection, configure the relay to use inputs from an electrically equivalent source.

Dual CT Input. Apply with ring bus, breaker-and-a-half, or other two-breaker schemes. Combine currents within the relay from two sets of CTs for protection functions, but keep them separately available for monitoring and station integration applications.

Monitoring. Schedule breaker maintenance when accumulated breaker duty (independently monitored for each pole of two circuit breakers) indicates possible excess contact wear. Electrical and mechanical operating times are recorded for both the last operation and the average of operations since function reset. Alarm contacts provide notification of substation battery voltage problems (two independent battery monitors) even if voltage is low only during trip or close operations.

Reclosing. Incorporate programmable reclosing of one or two breakers into an integrated substation control system. Synchronism and voltage checks from multiple sources provide complete bay control.

Switch-onto-Fault. Relay switch-onto-fault (SOTF) logic permits specific protection elements to quickly trip after the circuit breaker closes, especially important when directional elements are being used with line-side PTs.

Breaker Failure. Use high-speed (less than one cycle) open-pole detection logic to reduce coordination times for critical breaker failure applications. Apply the SEL-451 to supply three-pole breaker failure for one or two breakers. Necessary logic for three-pole breaker failure retrip and initiation of transfer tripping is included.

Fault Locator. Efficiently dispatch line crews to quickly isolate line problems and restore service faster.

Oscillography and Event Reporting. Record voltages, currents, and internal logic points at up to 8 kHz sampling rate. Phasor and harmonic analysis features allow investigation of relay and system performance.

Rules-Based Settings Editor. Communicate with and set the relay using an ASCII terminal, or use the PC-based ACCELERATOR QuickSet to configure the SEL-451 and analyze fault records with relay element response. View real-time phasors.

Sequential Events Recorder (SER). Record the last 1000 entries, including setting changes, power-ups, and selectable logic elements.

Thermal Overload Modeling. Use the SEL-451 with the SEL-2600 Series RTD Module for dynamic overload protection using SELOGIC control equations. For more information, see [SEL Application Guide AG2003-06, Implementation of the SEL-49 Relay Line Thermal Protection Using the SEL-421 Relay SELogic Equations](#).

Increased Security. The SEL-451 divides control and settings into seven relay access levels; the relay has separate breaker, protection, automation, and output access levels, among others. Set unique passwords for each access level.

Comprehensive Metering. Improve feeder loading by using built-in, high-accuracy metering functions. Use watt and VAR measurements to optimize feeder operation. Minimize equipment needs with full metering capabilities, including: rms, maximum/minimum, demand/peak, energy, and instantaneous values. Synchrophasor data can be used for time-synchronized state measurements across the system.

Settings Reduction. Internal relay programming shows only the settings for the functions and elements you have enabled.

Bay Control. The SEL-451-4 provides bay control functionality with status indication and control of as many as ten disconnects. The relay features control for as many as two breakers and status indication of as many as three breakers. Numerous pre-defined user-selectable mimic displays are available; the selected mimic is displayed on the front-panel screen in one-line diagram format. The one-line diagram includes user-configurable labels for disconnect switches, breakers, bay name, and display for as many as six analog quantities. The SEL-451-4 features SELOGIC programmable local control supervision of breaker and disconnect switch operations. See [Section 5: Bay Control in the Applications Handbook](#) for more information.

Alias Settings. Use as many as 200 aliases to rename any digital or analog quantity in the relay. The aliases are now available for use in customized programming, making the initial programming and maintenance much easier.

Auxiliary TRIP/CLOSE Pushbuttons. The part number indicates whether the relay has auxiliary **TRIP** and **CLOSE** pushbuttons. These pushbuttons are shown in [Figure 5.2](#). These features are electrically isolated from the rest of the relay. They function independently from the relay and do not need relay power.

High-impedance Fault Detection. The part number indicates whether the relay supports high-impedance fault detection. The high-impedance fault (HIF) detection element operates for small current ground faults typically caused by downed conductors on ground surfaces such as earth, concrete or other poorly conductive materials. HIF event data are made available in standard COMTRADE format. The **HIS HIF** command gives a history of HIF events available in the relay.

NOTE: Refer to the SEL-451 Model Option Table for complete part number details. These tables are available on the SEL website or from the factory.

Models and Options

Consider the following options when ordering and configuring the SEL-451.

- Chassis size
 - 3U, 4U, and 5U
(U is one rack unit—1.75 inches or 44.45 mm)
- Main board I/O
 - Main board A:
Contact inputs: 5 independent and 2 common inputs (programmable pickup threshold);
Contact outputs: 2 standard Form A, 3 standard Form C, and 3 High-Current Interrupting Form A outputs
 - Main board B:
Contact inputs: 5 independent and 2 common inputs (level sensitive and optoisolated);
Contact outputs: 2 standard Form A, 3 standard Form C, and 3 High-Current Interrupting Form A outputs
- Additional I/O board (for 4U and 5U chassis)
 - INT1:
Contact inputs: 8 independent inputs (programmable pickup threshold);
Contact outputs: 13 standard Form A and 2 standard Form C outputs
 - INT2:
Contact inputs: 8 independent inputs (level sensitive and optoisolated);
Contact outputs: 13 standard Form A and 2 standard Form C outputs
 - INT3:
Contact inputs: 18 common (2 groups of 9) and 6 independent inputs (level sensitive and optoisolated);
Contact outputs: 4 high-current interrupting Form A outputs
 - INT4:
Contact inputs: 18 common (2 groups of 9) and 6 independent inputs (level sensitive and optoisolated);
Contact outputs: 6 Fast High-Current Interrupting Form A and 2 standard Form A outputs
 - INT5:
Contact inputs: 8 independent inputs (programmable pickup threshold);
Contact outputs: 8 Fast High-Current Interrupting Form A outputs

NOTE: The SEL-451-1 does not support Main Board B.

NOTE: The SEL-451-1 does not support I/O boards INT2, INT3, INT7, and INT8.

- INT6:
 - Contact inputs: 8 independent inputs (programmable pickup threshold);
 - Contact outputs: 13 High-Current Interrupting Form A and 2 standard Form C outputs
- INT7:
 - Contact inputs: 8 independent inputs (level sensitive and optoisolated);
 - Contact outputs: 13 High-Current Interrupting Form A and 2 standard Form C outputs
- INT8:
 - Contact inputs: 8 independent inputs (level sensitive and optoisolated);
 - Contact outputs: 8 Fast High-Current Interrupting Form A outputs
- Chassis orientation and type
 - Horizontal rack mount
 - Horizontal panel mount
 - Vertical rack mount
 - Vertical panel mount
- Power supply
 - 24/48 Vdc
 - 48/125 Vdc or 120 Vac
 - 125/250 Vdc or 120/230 Vac
- Secondary inputs
 - 1 A nominal or 5 A nominal CT inputs.
 - 300 V phase-to-neutral wye configuration PT inputs
- Communications card options
 - Ethernet card with combinations of 10/100BASE-T and 100BASE-FX media connections on each of two ports
- Communications protocols
 - Complete group of SEL protocols (SEL ASCII, SEL Compressed ASCII, SEL Settings File Transfer, SEL Fast Meter, SEL Fast Operate, SEL Fast SER, RTDs, Enhanced MIRRORED BITS Communications) and Synchrophasors (SEL Fast Message and IEEE C37.118 format).
 - Above protocols, plus DNP3.
 - Above protocols, plus IEC 61850.
- Connector type
 - Fixed PT and CT terminal block inputs
 - Plug-in/plug-out PT and shorting CT Connectorized® versions

NOTE: The Secondary inputs ordering option determines the availability of High Impedance Fault Detection.

Contact the SEL factory or your local Technical Service Center for particular part number and ordering information (see [Technical Support on page U.6.41](#)). You can also view the latest part number and ordering information on the SEL website at www.selinc.com.

Applications

Use the SEL-451 in a variety of distribution protection applications. For information on connecting the relay, see [Installation on page U.2.1](#). See the [Applications Handbook](#) for thorough discussions of protection and automation applications using the SEL-451.

The figures in this subsection illustrate common relay application configurations. [Figure 1.3](#), [Figure 1.4](#), [Figure 1.5](#), [Figure 1.6](#), and [Figure 1.7](#) demonstrate relay versatility with Global setting ESS (Current and Voltage Source Selection). These figures show the power and simplicity of the four preprogrammed ESS options. For more information on setting ESS, see [Current and Voltage Source Selection on page R.1.2](#).

The SEL-451 has two sets of three-phase analog current inputs, IW and IX, and two sets of three-phase analog voltage inputs, VY and VZ. The drawings that follow use a two-letter acronym to represent all three phases of a relay analog input. For example, IW represents IAW, IBW, and ICW for A-, B-, and C-phase current inputs on terminal W, respectively. The drawings list a separate phase designator if you need only one or two phases of the analog input set (VAZ for the A-phase voltage of the VZ input set, for example).




Figure 1.2 Protecting a Line Segment With MIRRORED BITS Communications on a Fiber Channel






Figure 1.3 Single Circuit Breaker Configuration (ESS := 1)




Analog Input	Function
IW	CB1 protection, line protection
IX	CB1 breaker failure
VY	Line protection
VAZ	Synchronism check

Figure 1.4 Single Circuit Breaker Configuration With Line Breaker CTs (ESS := 2)




Analog Input	Function
IW+IX	Line Protection
IW	CB1 protection
IX	CB2 protection
VY	Line protection
VAZ	Synchronism check Circuit Breaker 1
VBZ	Synchronism check Circuit Breaker 2

Figure 1.5 Double Circuit Breaker Configuration (ESS := 3)



Analog Input	Function
IW+IX	CB2 protection
IW	Line protection
IX	CB1 protection
VY	Line protection
VAZ	Synchronism check Circuit Breaker 1
VBZ	Synchronism check Circuit Breaker 2

Figure 1.6 Double Circuit Breaker Configuration With Bus Protection (ESS := 4)



Analog Input	Function
IW	Line protection
VY	Line protection
VAZ	Synchronism check Circuit Breaker 1
VBZ	Synchronism check Circuit Breaker 2

Figure 1.7 Tapped Line (ESS := Y)

Figure 1.8 illustrates a predefined bay control configuration available in the SEL-451-4. The SEL-451-4 supports over 25 different bay configurations. The bay configuration shown has control for five disconnect switches and control for one breaker. See *Section 5: Bay Control in the Applications Handbook* for an in-depth discussion of the SEL-451-4 Bay Control and application example.




Figure 1.8 Bus 1, Bus 2, and Transfer Bus Bay With Ground Option (MIMIC := 4)

Application Highlights

Apply the SEL-451 in power system protection and control situations. *Table 1.1* lists applications and key features of the relay.

Table 1.1 Application Highlights (Sheet 1 of 2)

Application	Key Features
Distribution Lines	Best Choice Ground Directional element Six selectable operating quantity time-overcurrent elements
Multiple-breaker tripping	Breaker failure protection
Reclosing and synchronism check	Up to 4 shots of auto-reclose Leader/follower breaker arrangements Two-circuit-breaker universal synchronism check and voltage checks
Long lines	Load-encroachment elements prevent unwanted trips on load Negative-sequence and residual overcurrent elements provide sensitive backup protection
Bus-tie or transfer circuit breakers	Multiple setting groups Match relay settings group to each line substitution Multiple CT inputs Eliminate current reversing switches Local or remote operator switches the setting groups
Subtransmission lines	Ground directional overcurrent protection Torque-controlled time-overcurrent elements
Lines with transformers	Negative-sequence overcurrent protection
Short transmission lines	Directional overcurrent elements and communications-assisted tripping schemes
Permissive Overreaching Transfer Tripping (POTT) schemes	Current reversal guard logic Open breaker echo keying logic Weak-infeed and zero-infeed logic Time-step backup protection

Table 1.1 Application Highlights (Sheet 2 of 2)

Application	Key Features
Directional Comparison Unblocking Tripping (DCUB) schemes	Includes all POTT logic All loss-of-channel logic is inside the relay Time-step backup protection
Permissive Under-reaching Transfer Tripping (PUTT) schemes	Supported by POTT logic Time-step backup protection
Directional Comparison Blocking Trip (DCB) schemes	Current reversal guard logic Carrier coordinating timers Carrier send and receive extend logic Time-step backup protection
SCADA applications Communications capability	Analog and digital data acquisition for station wide functions SEL ASCII Enhanced MIRRORED BITS communications SEL Fast Meter, SEL Fast Operate, SEL Fast SER SEL Compressed ASCII RTD Optional Serial DNP3 Optional protocols: Ethernet, IEC 61850, DNP3 (Ethernet) FTP, Telnet
Customized protection and automation schemes	Separate protection and automation SELOGIC control equation programming areas Use timers and counters in expanded SELOGIC control equations for complete flexibility
Synchrophasors	The SEL-451 can function as a phasor measurement unit (PMU) at the same time as it provides best-in-class protective relay functions. C37.118 message format allows up to eight current and four voltage synchronized measurements, up to 60 messages per second (on a 60 Hz nominal power system). Two choices of filter response, settable angle correction, and choice of numeric representation makes the data usable for a variety of synchrophasor applications. Selectable number of additional analog values (0 to 8) and digital status bits (0, 16, or 32) included in message. SEL Fast Operate commands are available on the synchrophasor communications ports, allowing control actions initiated by the synchrophasor processor. SEL Fast Message Synchrophasor format is also available, with up to four current and four voltage synchronized measurements.
Bay Control (SEL-451-4)	Over 25 preconfigured/user-selectable one-line diagrams with user-configurable labels for breakers, disconnect switches, and bay names. One-line diagrams support as many as ten disconnect switches (control and status indications), control for as many as two breakers, status indications of as many as three breakers, and display of as many as six user-selectable Analog Quantities.

Specifications

Important: Do not use the following specification information to order an SEL-451. Refer to the actual ordering information sheets.

General

AC Current Inputs (Secondary Circuits)

Note: Current transformers are Measurement Category II.

5 A nominal	15 A continuous, linear to 100 A symmetrical 500 A for 1 second 1250 A for 1 cycle
Burden:	0.27 VA at 5 A 2.51 VA at 15 A
1 A nominal	3 A continuous, linear to 20 A symmetrical 100 A for 1 second 250 A for 1 cycle

Burden:	0.13 VA at 1 A 1.31 VA at 3 A
---------	----------------------------------

AC Voltage Inputs

300 V _{L-N} continuous (connect any voltage up to 300 Vac)		
600 Vac for 10 seconds		
Burden:	0.03 VA at 67 V	
	0.06 VA at 120 V	
	0.8 VA at 300 V	

Power Supply

125/250 Vdc or 120/230 Vac

Range:	85–300 Vdc < 35 W or 85–264 Vac
VDC Input Ripple:	15% per IEC 60255-11:2008
Nominal Frequency:	50/60 Hz
Range:	30–120 Hz
Burden:	<120 VA

48/125 Vdc or 120 Vac

Range:	38–140 Vdc < 35W or 85–140 Vac
VDC Input Ripple:	15% per IEC 60255-11:2008
Nominal Frequency:	50/60 Hz
Range:	30–120 Hz
Burden:	<120 VA

24/48 Vdc

Range:	18–60 Vdc
VDC Input Ripple:	15% per IEC 60255-11:2008
Burden:	<35 W

Control Outputs

Standard

Make:	30 A
Carry:	6 A continuous carry at 70°C 4 A continuous carry at 85°C
1s Rating:	50 A
MOV Protection (maximum voltage):	250 Vac/330 Vdc
Pickup/Dropout Time:	6 ms, resistive load
Update Rate:	1/8 cycle
Break Capacity (10000 operations):	

48 Vdc	0.50 A	L/R = 40 ms
125 Vdc	0.30 A	L/R = 40 ms
250 Vdc	0.20 A	L/R = 40 ms

Cyclic Capacity (2.5 cycle/second):

48 Vdc	0.50 A	L/R = 40 ms
125 Vdc	0.30 A	L/R = 40 ms
250 Vdc	0.20 A	L/R = 40 ms

Note: EA certified relays do not have MOV protected standard output contacts.

Hybrid (high current interrupting)

Make:	30 A
Carry:	6 A continuous carry at 70°C 4 A continuous carry at 85°C
1s Rating:	50 A
MOV Protection (maximum voltage):	330 Vdc
Pickup/Dropout Time:	6 ms, resistive load

Break Capacity (10000 operations):

48 Vdc	10.0 A	L/R = 40 ms
125 Vdc	10.0 A	L/R = 40 ms
250 Vdc	10.0 A	L/R = 20 ms

Cyclic Capacity (4 cycles in 1 second, followed by 2 minutes idle for thermal dissipation):

48 Vdc	10.0 A	L/R = 40 ms
125 Vdc	10.0 A	L/R = 40 ms
250 Vdc	10.0 A	L/R = 20 ms

Note: Do not use hybrid control outputs to switch ac control signals. These outputs are polarity dependent.

Fast Hybrid (high-speed high current interrupting)

Make:	30 A
Carry:	6 A continuous carry at 70°C 4 A continuous carry at 85°C
1 s Rating:	50 A
MOV Protection (maximum voltage):	250 Vac/330 Vdc
Pickup Time:	10 µs, resistive load

Dropout Time: 8 ms, resistive load

Update Rate: 1/8 cycle

Break Capacity (10000 operations):

48 Vdc	10.0 A	L/R = 40 ms
125 Vdc	10.0 A	L/R = 40 ms
250 Vdc	10.0 A	L/R = 20 ms

Cyclic Capacity (4 cycles in 1 second, followed by 2 minutes idle for thermal dissipation):

48 Vdc	10.0 A	L/R = 40 ms
125 Vdc	10.0 A	L/R = 40 ms
250 Vdc	10.0 A	L/R = 20 ms

Note: Per IEC 60255-23:1994, using the simplified method of assessment.

Note: Make rating per IEEE C37.90-1989.

Auxiliary Trip/Close Pushbuttons (Select Models Only)

Resistive DC or AC Outputs with Arc Suppression Disabled:

Make:	30 A
Carry:	6 A continuous carry
1 s Rating:	50 A
MOV Protection:	250 Vac/330 Vdc/130 J
Breaking Capacity (1000 operations):	
48 V	0.50 A L/R = 40 ms
125 V	0.30 A L/R = 40 ms
250 V	0.20 A L/R = 40 ms

Note: Make per IEEE C37.90-1989.

High Interrupt DC Outputs with Arc Suppression Enabled:

Make:	30 A
Carry:	6 A continuous carry
1 s Rating:	50 A
MOV Protection:	330 Vdc/130 J
Breaking Capacity (10000 operations):	
48 V	10 A L/R = 40 ms
125 V	10 A L/R = 40 ms
250 V	10 A L/R = 20 ms

Note: Make per IEEE C37.90-1989.

Breaker Open/Closed LEDs:

250 Vdc:	on for 150–300 Vdc; 192–288 Vac
125 Vdc:	on for 80–150 Vdc; 96–144 Vac
48 Vdc:	on for 30–60 Vdc;
24 Vdc:	on for 15–30 Vdc

Note: With nominal control voltage applied, each LED draws 8 mA (max.). Jumpers may be set to 125 Vdc for 110 Vdc input and set to 250 Vdc for 220 Vdc input.**Control Inputs**

Direct Coupled (for use with dc signals)

Main Board A:	5 inputs with no shared terminals 2 inputs with shared terminals
INT1, INT5, and INT6 interface boards:	8 inputs with no shared terminals
Range:	15–265 Vdc, independently adjustable
Accuracy:	±5% plus ±3 Vdc
Maximum Voltage:	300 Vdc
Sampling Rate:	1/16 cycle
Typical Burden:	0.24 W at 125 Vdc
Optoisolated (use with ac or dc signals)	
Main Board B:	5 inputs with no shared terminals 2 inputs with shared terminals
INT2, INT7, and INT8 interface boards:	8 inputs with no shared terminals
INT3 and INT4 interface boards:	6 inputs with no shared terminals 18 inputs with shared terminals (2 groups of 9 inputs, with each group sharing one terminal)
Voltage Options:	24 V standard 48, 110, 125, 220, 250 V level sensitive

DC Thresholds (Dropout thresholds indicate level-sensitive option):

24 Vdc:	Pickup 15.0–30.0 Vdc
48 Vdc:	Pickup 38.4–60.0 Vdc; Dropout <28.8 Vdc
110 Vdc:	Pickup 88.0–132.0 Vdc; Dropout <66.0 Vdc
125 Vdc:	Pickup 105–150 Vdc; Dropout <75 Vdc
220 Vdc:	Pickup 176–264 Vdc; Dropout <132 Vdc
250 Vdc:	Pickup 200–300 Vdc; Dropout <150 Vdc

AC Thresholds (Ratings met only when recommended control input settings are used—see [Table 2.2 on page U.2.7.](#)):

24 Vac:	Pickup 12.8–30.0 Vac rms
48 Vac:	Pickup 32.8–60.0 Vac rms; Dropout <20.3 Vac rms
110 Vac:	Pickup 75.1–132.0 Vac rms; Dropout <46.6 Vac rms
125 Vac:	Pickup 89.6–150.0 Vac rms; Dropout <53.0 Vac rms
220 Vac:	Pickup 150–264 Vac rms; Dropout <93.2 Vac rms
250 Vac:	Pickup 170.6–300 Vac rms; Dropout <106 Vac rms
Current Drawn:	5 mA at nominal voltage 8 mA for 110 V option
Sampling Rate:	1/16 cycle

Frequency and Rotation

System Frequency:	50/60 Hz
Phase Rotation:	ABC or ACB
Frequency Tracking Range:	40–65 Hz

Communications Ports

EIA-232:	1 Front & 3 Rear
Serial Data Speed:	300–57600 bps
Communications Card Slot for optional Ethernet Processor	

Fiber Optic (Optional)

Ordering Options:	100BASE-FX
Mode:	Multi
Wavelength (nm):	1300
Source:	LED
Connector Type:	ST
Min. TX Pwr. (dBm):	-19
Max. TX Pwr. (dBm):	-14
RX Sens. (dBm):	-32
Sys. Gain (dB):	13

Time Inputs

IRIG Input-Serial Port 1

Input:	Demodulated IRIG-B
Nominal Voltage:	5 Vdc +10%
Maximum Voltage:	8 Vdc
Input Impedance:	333 ohms
Isolation:	500 Vdc

IRIG-B Input-BNC Connector

Input:	Demodulated IRIG-B
Nominal Voltage:	5 Vdc +10%
Maximum Voltage:	8 Vdc
Input Impedance:	2500 ohms

Operating Temperature

Without Ethernet:	-40° to +85°C (-40° to +185°F)
With Ethernet:	-40° to +70°C (-40° to +158°F)

Note: LCD contrast impaired for temperatures below -20° and above +70°C

Humidity

5% to 95% without condensation

Weight (Maximum)

3U Rack Unit:	17.5 lbs (8.0 kg)
4U Rack Unit:	21.5 lbs (9.8 kg)
5U Rack Unit:	25.5 lbs (11.6 kg)

Terminal Connections

Rear Screw-Terminal Tightening Torque, #8 Ring Lug

Minimum:	1.0 Nm (9 in-lb)
Maximum:	2.0 Nm (18 in-lb)

User terminals and stranded copper wire should have a minimum temperature rating of 105°C. Ring terminals are recommended.

Wire Sizes and Insulation

Wire sizes for grounding (earthing), current, voltage, and contact connections are dictated by the terminal blocks and expected load currents. You can use the following table as a guide in selecting wire sizes:

Connection Type	Minimum Wire Size	Maximum Wire Size
Grounding (Earthing) Connection	18 AWG (0.8 mm ²)	14 AWG (2.5 mm ²)
Current Connection	16 AWG (1.5 mm ²)	12 AWG (4 mm ²)
Potential (Voltage) Connection	18 AWG (0.8 mm ²)	14 AWG (2.5 mm ²)
Contact I/O	18 AWG (0.8 mm ²)	14 AWG (2.5 mm ²)
Other Connection	18 AWG (0.8 mm ²)	14 AWG (2.5 mm ²)

Use wire with 0.4 mm-thick insulation for high-voltage connections to allow for contact between adjacent wires. If possible, use 0.4 mm insulated wires for all connections.

Routine Dielectric Strength Tests (Performed on Each Manufactured Relay)

AC Current Inputs, optoisolated inputs, and output contacts:	2500 Vac for 10 s
Power Supply	3100 Vdc for 10 s

Type Tests

Electromagnetic Compatibility Emissions

Emissions:	IEC 60255-25:2000
------------	-------------------

Electromagnetic Compatibility Immunity

Conducted RF Immunity:	IEC 60255-22-6:2001 Severity Level: 10 Vrms IEC 61000-4-6:2008 Severity Level: 10 Vrms
Electrostatic Discharge Immunity:	IEC 60255-22-2:2008 Severity Level: 2, 4, 6, 8 kV contact; 2, 4, 8, 15 kV air IEC 61000-4-2:2008 Severity Level: 2, 4, 6, 8 kV contact; 2, 4, 8, 15 kV air IEEE C37.90.3-2001 Severity Level: 2, 4, 8 kV contact; 4, 8, 15 kV air
Fast Transient/Burst Immunity:	IEC 60255-22-4:2008 Severity Level: Calss A: 4 kV, 5 kHz; 2 kV, 5 kHz on communication ports IEC 61000-4-4:2011 Severity Level: 4 kV, 5 kHz
Magnetic Field Immunity:	IEC 61000-4-8:2009 Severity Level: 900 A/m for 3 seconds, 100 A/m for 1 minute IEC 61000-4-9:2001 Severity Level: 1000 A/m
Power Supply Immunity:	IEC 60255-11:2008 IEC 61000-4-11:2004 IEC 61000-4-29:2000
Radiated Digital Radio Telephone RF Immunity:	ENV 50204:1995 Severity Level: 10 V/m at 900 MHz and 1.89 GHz
Radiated Radio Frequency Immunity:	IEC 60255-22-3:2007 Severity Level: 10 V/m IEC 61000-4-3:2010 Severity Level: 10 V/m IEEE C37.90.2:2004 Severity Level: 35 V/m
Surge Immunity:	IEC 60255-22-5:2008 Severity Level: 1 kV Line-to-Line, 2 kV Line-to-Earth IEC 61000-4-5:2005 Severity Level: 1 kV Line-to-Line, 2 kV Line-to-Earth
Surge Withstand Capability Immunity:	IEC 60255-22-1:2007 Severity Level: 2.5 kV peak common mode, 1.0 kV peak differential mode IEEE C37.90.1:2002 Severity Level: 2.5 kV oscillatory, 4 kV fast transient waveform

Environmental

Cold:	IEC 60068-2-1:2007 Severity Level: 16 hours at -40°C
Damp Heat, Cyclic:	IEC 60068-2-30:2005 Severity Level: 25°C to 55°C, 6 cycles, Relative Humidity: 95%
Dry Heat:	IEC 60068-2-2:2007 Severity Level: 16 hours at +85°C

Vibration:	IEC 60255-21-1:1988 Severity Level: Class 1 Endurance, Class 2 Response
	IEC 60255-21-2:1988 Severity Level: Class 1-Shock withstand, Bump, and Class 2-Shock Response
	IEC 60255-21-3:1993 Severity Level: Class 2 (Quake Response)

Safety

Dielectric Strength:	IEC 60255-5:2000 Severity Level: 2500 Vac on contact inputs, contact outputs, and analog inputs. 3100 Vdc on power supply. Type Tested for 1 minute.
	IEEE C37.90:2005 Severity Level: 2500 Vac on contact inputs, contact outputs, and analog inputs. 3100 Vdc on power supply. Type Tested for 1 minute.
Impulse:	IEC 60255-5:2000 Severity Level: 0.5 Joule, 5 kV
	IEEE C37.90: 2005 Severity Level: 0.5 Joule, 5 kV
IP Code:	IEC 60529:2001 + CRGD:2003 Severity Level: IP30
Laser Safety:	ANSI Z136.1:2007, Class 1 IEC 60825-1:2007, Class 1

Safety Agency Certifications

Product Safety:	C22.2 No. 14 cUL Listed Protective Relay, Product Category NRGU7 UL 508 UL Listed Protective Relay, Product Category NRGU
-----------------	--

Certifications

ISO:	Relay is designed and manufactured using ISO 9001:2000 certified quality program.
Product Safety:	IEC 60255-6:1988

Reporting Functions

High-Resolution Data

Rate:	8000 samples/second 4000 samples/second 2000 samples/second 1000 samples/second
-------	--

Output Format:	Binary COMTRADE
----------------	-----------------

Note: Per IEEE Standard Common Format for Transient Data Exchange (COMTRADE) for Power Systems, IEEE C37.111-1999

Event Reports

Storage:	35 quarter-second events or 24 half-second events
Maximum Duration:	Record events as long as 5 seconds
Resolution:	8- or 4-samples/cycle

Event Summary

Storage:	100 summaries
----------	---------------

Breaker History

Storage:	128 histories
----------	---------------

Sequential Events Recorder

Storage:	1000 entries
Trigger elements:	250 relay elements

Processing Specifications

AC Voltage and Current Inputs

8000 samples per second, 3 dB low-pass analog filter cut-off frequency of 3000 Hz.

Digital Filtering

Full-cycle cosine and half-cycle Fourier filters after low-pass analog and digital filtering.

Protection and Control Processing

8 times per power system cycle

Synchrophasors

Maximum data rate in messages per second

IEEE C37.118 V7.3 protocol	60 (nominal 60 Hz system) 50 (nominal 50 Hz system)
SEL Fast Message protocol:	20 (nominal 60 Hz system) 10 (nominal 50 Hz system)

Control Points

32 remote bits
32 local control bits
32 latch bits in protection logic
32 latch bits in automation logic

Relay Element Pickup Ranges and Accuracies

Instantaneous/Definite-Time Overcurrent Elements

Phase, Residual Ground, and Negative-Sequence

Pickup Range

5 A Model:	OFF, 0.25–100.00 A secondary, 0.01 A steps
1 A Model:	OFF, 0.05–20.00 A secondary, 0.01 A steps

Accuracy (Steady State)

5 A Model:	±0.05 A plus ±3% of setting
1 A Model:	±0.01 A plus ±3% of setting

Transient Overreach: < 5% of pickup

Time Delay: 0.000–16000.000 cycles,
0.125 cycle steps

Timer Accuracy: ±0.125 cycle plus ±0.1% of setting

Maximum Operating Time: 1.5 cycles

Time-Overcurrent Elements

Pickup Range

5 A Model:	0.25–16.00 A secondary, 0.01 A steps
1 A Model:	0.05–3.20 A secondary, 0.01 A steps

Accuracy (Steady State)

5 A Model:	±0.05 A plus ±3% of setting
1 A Model:	±0.01 A plus ±3% of setting

Time Dial Range

US:	0.50–15.00, 0.01 steps
IEC:	0.05–1.00, 0.01 steps

Curve Timing Accuracy: ± 1.50 cycles plus $\pm 4\%$ of curve time
(for current between 2 and 30 multiples of pickup)

Reset: 1 power cycle or Electromechanical Reset Emulation time

Ground Directional Elements

Neg.-Seq. Directional Impedance Threshold (Z2F, Z2R)

5 A Model: -64 to 64Ω

1 A Model: -320 to 320Ω

Zero-Seq. Directional Impedance Threshold (ZOF, ZOR)

5 A Model: -64 to 64Ω

1 A Model: -320 to 320Ω

Supervisory Overcurrent Pickup 50FP, 50RP

5 A Model: 0.25 to 5.00 A 310 secondary
0.25 to 5.00 A 312 secondary

1 A Model: 0.05 to 1.00 A 310 secondary
0.05 to 1.00 A 312 secondary

Undervoltage and Overvoltage Elements

Pickup Ranges: Phase elements: 1–200 V secondary,
1 V steps

Phase-to-Phase Elements: 1.0–300.0 V secondary, 0.1 V steps

Accuracy (Steady State): ± 1 V plus $\pm 5\%$ of setting

Transient Overreach: $< 5\%$ of pickup

Optional RTD Elements

(Models Compatible With SEL-2600 Series RTD Module)

12 RTD Inputs via SEL-2600 Series RTD Module and SEL-2800 Fiber-Optic Transceiver

Monitor Ambient or Other Temperatures

PT 100, NI 100, NI 120, and CU 10 RTD-Types Supported, Field Selectable

Up to 500 m Fiber-Optic Cable to SEL-2600 Series RTD Module

Breaker Failure Instantaneous Overcurrent

Setting Range

5 A Model: 0.50–50.0 A, 0.01 A steps

1 A Model: 0.10–10.0 A, 0.01 A steps

Accuracy

5 A Model: ± 0.05 A plus $\pm 3\%$ of setting

1 A Model: ± 0.01 A plus $\pm 3\%$ of setting

Transient Overreach: $< 5\%$ of setting

Maximum Pickup Time: 1.5 cycles

Maximum Reset Time: 1 cycle

Timers Setting Range: 0–6000 cycles, 0.125 cycle steps
(All but BFIDOn, BFISPn)
0–1000 cycles, 0.125 cycle steps
(BFIDOn, BFISPn)

Time Delay Accuracy: 0.125 cycle plus $\pm 0.1\%$ of setting

Synchronization-Check Elements

Slip Frequency Pickup Range: 0.005–0.500 Hz, 0.001 Hz steps

Slip Frequency Pickup Accuracy: ± 0.0025 Hz plus $\pm 2\%$ of setting

Close Angle Range: 3 – 80° , 1° steps

Close Angle Accuracy: $\pm 3^\circ$

Load-Encroachment Detection

Setting Range

5 A Model: 0.05 – 64Ω secondary, 0.01 Ω steps

1 A Model: 0.25 – 320Ω secondary, 0.01 Ω steps

Forward Load Angle: -90° to $+90^\circ$

Reverse Load Angle: $+90^\circ$ to $+270^\circ$

Accuracy

Impedance Measurement:

$\pm 3\%$

Angle Measurement: $\pm 2^\circ$

Timer Specifications

Setting Ranges

Breaker Failure: 0–6000 cycles, 0.125 cycle steps
(All but BFIDOn, BFISPn)
0–1000 cycles, 0.125 cycle steps
(BFIDOn, BFISPn)

Communications-Assisted Tripping Schemes: 0.000–16000 cycles, 0.125 cycle steps

Pole Open Timer: 0.000–60 cycles, 0.125 cycle steps

Recloser: 1–999999 cycles, 1 cycle steps

Switch-On-Fault

CLOEND, 52AEND: OFF, 0.000–16000 cycles,
0.125 cycle steps

SOTFD: 0.500–16000 cycles, 0.125 cycle steps

Synchronism Check Timers

TCLSBK1,
TCLSBK2: 1.00–30.00 cycles, 0.25 cycle steps

Station DC Battery System Monitor Specifications

Operating Range: 0–350 Vdc

Input Sampling Rate: 2 kHz

Processing Rate: 1/8 cycle

Maximum Operating Time: ≤ 1.5 cycles

Setting Range

DC settings: 15–300 Vdc, 1 Vdc steps

AC ripple setting: 1–300 Vac, 1 Vac steps

Accuracy

Pickup Accuracy: $\pm 3\%$ plus ± 2 Vdc (all elements but DC1RP and DC2RP)

$\pm 10\%$ plus ± 2 Vac (DC1RP and DC2RP)

Metering Accuracy

All metering accuracy is at 20°C , and nominal frequency unless otherwise noted.

Currents

Phase Current Magnitude

5 A Model: $\pm 0.2\%$ plus ± 4 mA (2.5–15 A sec)

1 A Model: $\pm 0.2\%$ plus ± 0.8 mA (0.5–3 A sec)

Phase Current Angle

All Models $\pm 0.2^\circ$ in the current range $0.5 \cdot I_{\text{nom}}$ to $3.0 \cdot I_{\text{nom}}$

Sequence Currents Magnitude

- 5 A Model: $\pm 0.3\%$ plus ± 4 mA (2.5–15 A sec)
 1 A Model: $\pm 0.3\%$ plus ± 0.8 mA (0.5–3 A sec)

Sequence Current Angle

- All Models: $\pm 0.3^\circ$ in the current range $0.5 \cdot I_{nom}$ to $3.0 \cdot I_{nom}$

Voltages

- Phase and
Phase-to-Phase Voltage
Magnitude: $\pm 0.1\%$ (33.5–200 V_{L-N})

- Phase and
Phase-to-Phase Angle: $\pm 0.05^\circ$ (33.5–200 V_{L-N})

- Sequence Voltage
Magnitude: $\pm 0.15\%$ (33.5–200 V_{L-N})

- Sequence Voltage Angle: $\pm 0.1^\circ$ (33.5–200 V_{L-N})

Frequency (Input 40–65 Hz)

- Accuracy: ± 0.01 Hz

Power and Energy**Real Power, P (MW), Three Phase**

- At $0.1 \cdot I_{NOM}$
 Power factor unity: $\pm 0.4\%$
 Power factor 0.5 lag,
 0.5 lead: $\pm 0.7\%$

- At $1.0 \cdot I_{NOM}$
 Power factor unity: $\pm 0.4\%$
 Power factor 0.5 lag,
 0.5 lead: $\pm 0.4\%$

Reactive Power, Q (MVAR), Three Phase

- At $0.1 \cdot I_{nom}$
 Power factor 0.5 lag,
 0.5 lead: $\pm 0.5\%$

- At $1.0 \cdot I_{nom}$
 Power factor 0.5 lag,
 0.5 lead: $\pm 0.4\%$

Energy (MWh), Three Phase

- At $0.1 \cdot I_{nom}$
 Power factor unity: $\pm 0.5\%$
 Power factor 0.5 lag,
 0.5 lead: $\pm 0.7\%$

- At $1.0 \cdot I_{nom}$
 Power factor unity: $\pm 0.4\%$
 Power factor 0.5 lag,
 0.5 lead: $\pm 0.4\%$

Synchrophasors

See [Accuracy on page R.7.5](#) for test exclusions and details

TVE (total vector error): $\leq 1\%$

Frequency Range: ± 5 Hz of nominal (50 or 60 Hz)

Voltage Range: 30 V–150 V

Current Range: $(0.1\text{--}2) \cdot I_{nom}$ ($I_{nom} = 1A$ or $5A$)

Phase Angle Range: -179.99° to 180°

This page intentionally left blank

Section 2

Installation

The first steps in applying the SEL-451 Relay are installing and connecting the relay. This section describes common installation features and particular installation requirements for the many physical configurations of the SEL-451. You can order the relay in horizontal and vertical orientations, and in panel-mount and rack-mount versions. SEL also provides various expansion I/O (input/output) interface boards to tailor the relay to your specific needs.

To install and connect the relay safely and effectively, you must be familiar with relay configuration features and options and relay jumper configuration. You should carefully plan relay placement, cable connection, and relay communication. Consider the following when installing the SEL-451:

- [Shared Configuration Attributes on page U.2.1](#)
- [Plug-In Boards on page U.2.13](#)
- [Jumpers on page U.2.18](#)
- [Relay Placement on page U.2.30](#)
- [Connection on page U.2.31](#)
- [AC/DC Connection Diagrams on page U.2.50](#)

It is also very important to limit access to the SEL-451 settings and control functions by using passwords. For information on relay access levels and passwords, see [Changing the Default Passwords: Terminal on page U.4.9](#).

Shared Configuration Attributes

There are common or shared attributes among the many possible configurations of SEL-451 relays. This section discusses the main shared features of the relay.

Relay Sizes

SEL produces the SEL-451 in horizontal and vertical rack-mount versions and horizontal and vertical panel-mount versions. Relay sizes correspond to height in rack units, U, where U is approximately 1.75 inches or 44.45 mm. The SEL-451 is available in 3U, 4U, and 5U sizes.

Front-Panel Templates

Horizontal front-panel templates and vertical front-panel templates are the same for all 3U, 4U, and 5U versions of the relay. [Figure 2.1](#), [Figure 2.2](#), [Figure 2.3](#), and [Figure 2.4](#) illustrate examples of horizontal and vertical front-panel templates for different relay models.

The SEL-451 front panel has three pockets for slide-in labels: one pocket for the target LED label, and two pockets for the operator control labels.

[Figure 2.1](#) and [Figure 2.2](#) show the front-panel pocket areas and openings for

typical horizontal and vertical relay orientations; dashed lines denote the pocket areas. Refer to the instructions included in the Configurable Label kit for information on reconfiguring front-panel LED and pushbutton labels.

Rear Panels

Rear panels are identical for the horizontal and the vertical configurations of the relay. [Figure 2.5](#) is an example of a rear panel for a 3U relay with fixed terminal block analog inputs. [Figure 2.6](#) shows a rear panel for a 3U relay with Connectorized® analog inputs. See [Rear-Panel Layout on page U.2.32](#) for representative 3U, 4U, and 5U relay rear panels (large drawings are in [Figure 2.31](#), [Figure 2.32](#), [Figure 2.33](#), and [Figure 2.36](#)).

Connector Types

Screw Terminal Connectors-I/O and Monitor/Power

Connect to the relay I/O and Monitor/Power terminals on the rear panel through screw terminal connectors. You can remove the entire screw terminal connector from the back of the relay to disconnect relay I/O, dc battery monitor, and power without removing each wire connection. The screw terminal connectors are keyed (see [Figure 2.40](#)), so you can replace the screw terminal connector on the rear panel only at the location from which you removed the screw terminal connector. In addition, the receptacle key prevents you from inverting the screw terminal connector, making removal and replacement easier.

Secondary Circuit Connectors

Fixed Terminal Blocks

Connect PT and CT inputs to the fixed terminal blocks in the bottom row of the relay rear panel.

You cannot remove these terminal blocks from the relay rear panel. These terminals offer a secure high-reliability connection for PT and CT secondaries.

Connectorized

The Connectorized SEL-451 features receptacles that accept plug-in/plug-out connectors for terminating PT and CT inputs; this requires ordering a wiring harness (SEL-WA0421) with mating plugs and wire leads. [Figure 2.6](#) shows the relay 3U chassis with Connectorized CT and PT analog inputs (see [Connectorized on page U.2.42](#) for more information).




Figure 2.1 Horizontal Front-Panel Template (SEL-451)






Figure 2.2 Vertical Front-Panel Template (SEL-451)

U.2.4 Installation

Shared Configuration Attributes




i3937a




i3943a

Figure 2.3 Horizontal Front-Panel Template (SEL-451-4)

Figure 2.4 Vertical Front-Panel Template (SEL-451-4)

**Figure 2.5 Rear 3U Template, Fixed Terminal Block Analog Inputs**

(In a vertical-mount relay, the right rear side is at the top.)

**Figure 2.6 Rear 3U Template, Connectorized Analog Inputs**

(In a vertical-mount relay, the right rear side is at the top.)

13372f

Secondary Circuits

The SEL-451 is a very low burden load on the CT secondaries and PT secondaries. For both the CT and PT inputs, the frequency range is 40–65 Hz.

The relay accepts two sets of three-phase currents from power system CT inputs:

- IAW, IBW, and ICW
- IAX, IBX, and ICX

For 5 A relays, the rated nominal input current, I_{NOM} , is 5 A. For 1 A relays, the rated nominal input current, I_{NOM} , is 1 A.

Input current for both relay types can range to $20 \cdot I_{NOM}$. The CT burden for each relay is the following:

- 5 A relay: 0.27 VA @ 5A and 2.51 VA @ 15 A
- 1 A relay: 0.13 VA @ 1 A and 1.31 VA @ 3 A

See the [AC Current Inputs \(Secondary Circuits\) on page U.1.12](#) for complete CT input specifications.

The relay also accepts two sets of three-phase, four-wire (wye) potentials from power system PT secondaries:

- VAY, VBY, and VCY
- VAZ, VBZ, and VCZ

The nominal line-to-neutral input voltage for the PT inputs is 67 volts with a range of 0–300 volts. The PT burden is less than 0.5 VA at 67 volts, L-N. See [AC Voltage Inputs on page U.1.12](#) for complete PT input specifications.

Some applications do not use all three phases of a source; for example, voltage synchronization sources can be single phase. See [Section 1: Protection Application Examples in the Applications Handbook](#) for examples of connections to the potential inputs.

See [Secondary Circuit Connections on page U.2.41](#) for information on connecting power system secondary circuits to these inputs.

Control Inputs

Direct Coupled

NOTE: The SEL-451 Main Board A, and the INT1, INT5, and INT6 I/O interface boards, have polarity-sensitive inputs, and the terminals are identified with a polarity mark.

The SEL-451 Main Board A inputs, and the inputs on the optional I/O interface boards (INT1, INT5, or INT6 I/O boards—see [Models and Options on page U.1.5](#)), are direct-coupled, high-impedance control inputs. Use these inputs for monitoring on/off and logical change-of-state conditions of power system equipment. These high-isolation control inputs are polarity-sensitive circuits. You cannot damage these inputs with a reverse polarity connection, although the relay will not detect input changes with a reverse-polarity input. For more information on control input specifications, see [Control Inputs on page U.1.13](#).

Inputs can be independent or common. Independent inputs have two separate connections to a high-isolation ADC (analog to digital converter). There are no internal connections among independent inputs. Common inputs share one input leg in common; all input legs of common inputs are ground-isolated. Each pair of common inputs is isolated from all other pairs.

Nominal current draw for these inputs is very low (4 mA or less) with an input voltage range of 15 Vdc to 265 Vdc. You can adjust the level at which these inputs assert (and deassert) and can also debounce the control inputs. See [Global Settings on page R.10.5](#) for the default settings and more information.

To ensure secure performance of the control inputs, set the control input pickup level according to the battery voltage level. [Table 2.1](#) lists some of the common DC voltage levels and appropriate settings.

Table 2.1 Recommended Control Input Pickup Settings

Substation DC Voltage Level	Recommended Settings	
	Pickup: GINP ^a	Dropout: GINDF
24	18 Vdc	85%
48	36 Vdc	85%
110	88 Vdc	80%
125	100 Vdc	80%
220	176 Vdc	80%
250	200 Vdc	80%

^a Applies to IN1nnP, IN2nnP, IN3nnP when global setting EICIS := N.

The control input accuracy is ± 5 percent of the applied signal plus ± 3 Vdc. The maximum voltage input is 300 Vdc, and the relay samples the control inputs 16 times per cycle. See [Raw and Filtered Data on page A.3.2](#).

Optoisolated

The SEL-451 Main Board B inputs, and the inputs on the optional I/O interface boards (INT2, INT3, INT4, INT7, or INT8 I/O boards—see [Models and Options on page U.1.5](#)), are fixed pickup threshold, optoisolated, control inputs. The pickup voltage level is determined for each board at ordering time.

NOTE: The SEL-451 Main Board B, and the INT2, INT3, INT4, INT7 and INT8 I/O interface boards have optoisolated contact inputs that can be used in either polarity.

Use these inputs for monitoring change-of-state conditions of power system equipment. These high-isolation control inputs are ground-isolated circuits and are not polarity sensitive. In other words, the relay will detect input changes with voltage applied at either polarity.

Inputs can be independent or common. Independent inputs have two separate ground-isolated connections, with no internal connections among inputs. Common inputs share one input leg in common; all input legs of common inputs are ground isolated. Each group of common inputs is isolated from all other groups.

Nominal current drawn by these inputs is 8 mA or less with 6 voltage options covering a wide range of voltages, as listed in Control Inputs on page U.1.11. You can debounce the control input pickup delay and dropout delay separately for each input, or you can use a single debounce setting that applies to all the input pickup and dropout times—see [Global Settings on page R.10.5](#).

AC Control Signals

Optoisolated control inputs can be used with ac control signals, within the ratings shown in [Control Inputs on page U.1.13](#). Specific pickup and dropout time-delay settings are required to achieve the specified ac thresholds, as shown in [Table 2.2](#).

NOTE: Only the optoisolated control inputs can be used to detect ac control signals. Direct-coupled control inputs can only be used with dc control signals.

It is possible to mix ac and dc control signal detection on the same interface board with optoisolated contact inputs, provided that the two signal types are not present on the same set of combined inputs. Use standard debounce time settings (usually the same value in both the pickup and dropout settings) for the inputs being used with dc control voltages.

Table 2.2 Required Settings for Use With AC Control Signals^a

Global Settings	Description	Entry ^b	Relay Recognition Time for AC Control Signal state change
IN ^c nmmPU ^c	Pickup Delay	0.1250 cycles	0.625 cycles maximum (assertion)
IN ^c nmmDO ^c	Dropout Delay	1.0000 cycle	1.1875 cycles maximum (deassertion)

^a First set Global setting EICIS := Y to gain access to the individual input pickup and dropout timer settings.

^b These are the only setting values that SEL recommends for detecting ac control signals. Other values may result in inconsistent operation.

^c Where n is 1 for Main Board, 2 for Interface Board #1, and 3 for Interface Board #2; mm is number of available contact inputs depending on the type of board.

The recognition times listed in [Table 2.2](#) are only valid when:

- The ac signal applied is at the same frequency as the power system.
- The signal is within the ac threshold pickup ranges defined in [Optoisolated \(use with ac or dc signals\) on page U.1.13](#).
- The signal contains no dc offset.

The SEL-451 samples the optoisolated inputs 16 times per cycle—See [Raw and Filtered Data on page A.3.2](#).

Control Outputs

NOTE: EA certified relays do not have MOV protected standard output contacts.

I/O control outputs from the relay include Standard outputs, Hybrid (high-current-interrupting) outputs, and Fast Hybrid (fast high-current-interrupting) outputs. Fast Hybrid outputs are available only on the optional INT4, INT5, or INT8 I/O interface boards. An MOV (metal-oxide varistor) protects against excess voltage transients for each contact. Each output is individually isolated, except Form C outputs, which share a common connection between the NC (normally closed) and NO (normally open) contacts.

The relay updates control outputs eight times per cycle. Updating of relay control outputs does not occur when the relay is disabled. When the relay is reenabled, the control outputs assume the state that reflects the present protection processing.

Standard Control Outputs

NOTE: You can use ac or dc circuits with Standard control outputs.

The Standard control outputs are “dry” Form A contacts rated for tripping duty. Ratings for Standard outputs are 30 A make, 6 A continuous, and 0.5 A or less break (depending on circuit voltage). Standard contact outputs have a maximum voltage rating of 250 Vac/330 Vdc. Maximum break time is 6 ms (milliseconds) with a resistive load. The maximum pickup time for the Standard control outputs is 6 ms. [Figure 2.7](#) shows a representative connection for a Form A Standard control output on the main board I/O terminals.




Figure 2.7 Standard Control Output Connection

See [Control Outputs on page U.1.12](#) for complete standard control output specifications.

Hybrid (High-Current-Interrupting) Control Outputs

CAUTION
Equipment damage can result from connecting ac circuits to Hybrid (high-current-interrupting) control outputs. Do not connect ac circuits to Hybrid control outputs. Use only dc circuits with Hybrid control outputs.

The Hybrid (high-current-interrupting) control outputs are polarity dependent and are capable of interrupting high-current, inductive loads. Hybrid control outputs use an IGBT (Insulated Gate Bipolar Junction Transistor) in parallel with a mechanical contact to interrupt (break) highly inductive dc currents. The contacts can carry continuous current, while eliminating the need for heat sinking and providing security against voltage transients.

With any hybrid output, break time varies according to the L/R (circuit inductive/resistive) ratio. As the L/R ratio increases, the time needed to interrupt the circuit fully increases also. The reason for this increased interruption delay is that circuit current continues to flow through the output MOV after the output deasserts, until all of the inductive energy dissipates. Maximum dropout (break) time is 6 ms with a resistive load, the same as for the Standard control outputs. The other ratings of these control outputs are

similar to the Standard control outputs, except that the Hybrid outputs can break current as great as 10 A. Hybrid contact outputs have a maximum voltage rating of 330 Vdc.

The maximum pickup time for the Hybrid control outputs is 6 ms. *Figure 2.8* shows a representative connection for a Form A Hybrid control output on the main board I/O terminals.




Figure 2.8 Hybrid Control Output Connection

See [Section 1: Introduction and Specifications](#), for complete Hybrid control output specifications.

Fast Hybrid (Fast High-Current-Interrupting) Control Outputs

NOTE: You can use ac or dc circuits with Fast Hybrid (fast high-current-interrupting) outputs.

In addition to the Standard control outputs and the Hybrid control outputs, the INT4, INT5, and INT8 I/O interface boards offer Fast Hybrid (fast high-current-interrupting) control outputs. These control outputs have a resistive load pickup time of 10 µs (microseconds), which is much faster than the 6 ms pickup time of the Standard and Hybrid control outputs. The Fast Hybrid control outputs drop out at a maximum time of 8 ms. The maximum voltage rating is 250 Vac/330 Vdc. See [Control Outputs on page U.1.12](#), for complete Fast Hybrid control output specifications.

Figure 2.9 shows a representative connection for a Form A Fast Hybrid control output on the INT5 (INT8) I/O interface terminals.




Figure 2.9 Fast Hybrid Control Output Connection, INT5 (INT8)

Figure 2.10 shows a representative connection for a Form A Fast Hybrid control output on the INT4 I/O interface terminals. The HS marks are included to indicate that this is a high-speed control output.




Figure 2.10 Fast Hybrid Control Output Connection, INT4

The INT5 (INT8) Fast Hybrid control output uses three terminal positions, while the INT4 Fast Hybrid uses two. The third terminal of each INT5 (INT8) Fast Hybrid control output is connected to precharge resistors that can be used to mitigate transient inrush current conditions, as explained below. A similar technique can be used with INT4 board Fast Hybrid control outputs using external resistors.

Short transient inrush current can flow at the closing of an external switch in series with open Fast Hybrid contacts. This transient will not energize the circuits in typical relay-coil control applications (trip coils and close coils), and standard auxiliary relays will not pick up. However, an extremely sensitive digital input or light-duty, high-speed auxiliary relay can pick up for this condition. This false pick-up transient occurs when the capacitance of the Fast Hybrid output circuitry charges (creating a momentary short circuit that a fast, sensitive device sees as a contact closure). A third terminal (03 in [Figure 2.11](#)) provides an internal path for precharging the Fast Hybrid output circuit capacitance when the circuit is open.




Figure 2.11 Fast Hybrid Control Output Typical Terminals, INT5 (INT8)

[Figure 2.12](#) shows some possible connections for this third terminal that will eliminate the false pick-up transients when closing an external switch. In general, you must connect the third terminal to the dc rail (positive or negative) that is on the same side as the open external switch condition. If an open switch exists on either side of the output contact, then you can accommodate only one condition because two open switches (one on each side of the contact) defeat the precharge circuit.




Figure 2.12 Precharging Internal Capacitance of Fast Hybrid Output Contacts, INT5 (INT8)

For wiring convenience, on the INT5 (INT8) I/O Interface Board, the precharge resistors shown in [Figure 2.11](#) are built-in to the I/O board, and connected to a third terminal. On the INT4 I/O Interface Board, there are no built-in precharge resistors, and each Fast Hybrid control output has only two terminal connections.

Main Board I/O

The SEL-451 base model is a 3U chassis with I/O interface on the main board (the top board). See [Figure 2.30](#) and [Figure 2.31](#) for representative rear-panel views of the 3U chassis rear panel. There are two options for the main board depending on the type of contact inputs. The Main Board A I/O interface has direct coupled contact inputs. The Main Board B I/O interface has optoisolated contact inputs.

Every SEL-451 configuration includes the main board I/O and features these connections:

- Three Hybrid (high-current-interrupting) Form A outputs
- Two Standard Form A outputs
- Three Standard Form C outputs
- Seven high-isolation control inputs (five independent and two with a common leg)

TIME Inputs

The SEL-451 has a regular IRIG timekeeping mode, and a high-accuracy IRIG (HIRIG) timekeeping mode, as described in [Configuring High-Accuracy Timekeeping on page U.4.73](#).

The IRIG-B serial data format consists of a 1-second frame containing 100 pulses divided into fields. The relay decodes the second, minute, hour, and day fields and sets the internal time clock upon detecting valid time data in the IRIG time mode.

There are two IRIG-B inputs on the SEL-451 rear panel, but only one is capable of supporting the HIRIG mode. For input specifications, see [Time Inputs on page U.1.14](#).

IRIG-B Pins of Serial Port 1

This IRIG-B input is capable of regular IRIG mode timekeeping only. Timing accuracy for the IRIG time mode is 500 μ s.

IRIG-B BNC Connector

This IRIG-B input is capable of both modes of timekeeping. If the connected timekeeping source is qualified as high-accuracy (see [Table 4.9 on page U.4.74](#)), the relay enters the HIRIG mode, which has a timing accuracy of 1 μ s.

If both inputs are connected, the SEL-451 will use the IRIG-B BNC connector signal if a signal is detected.

SEL-451 Time Inputs Changed

If you are upgrading the firmware in an existing SEL-451 relay, you may need to remove or reconnect your time-source cables. Beginning with the release of SEL-451 firmware version R104, the rear-panel TIME inputs have been changed. There is no longer a 1k PPS time input—see [1k PPS Connection Not Required on page U.4.74](#) for details.

Battery-Backed Clock

If relay input power is lost or removed, a lithium battery powers the relay clock, providing date and time backup. The battery is a 3 V lithium coin cell, Ray-O-Vac® No. BR2335 or equivalent. If power is lost or disconnected, the battery discharges to power the clock. At room temperature (25°C), the battery will operate for approximately 10 years at rated load.

When the SEL-451 is operating with power from an external source, the self-discharge rate of the battery only is very small. Thus, battery life can extend well beyond the nominal 10-year period because the battery rarely discharges after the relay is installed. The battery cannot be recharged. [Figure 2.22](#) shows the clock battery location (at the front of the main board).

If the relay does not maintain the date and time after power loss, replace the battery (see [Replacing the Lithium Battery on page U.2.46](#)).

Communications Interfaces

The SEL-451 has several communications interfaces you can use to communicate with other IEDs (intelligent electronic devices) via EIA-232 ports: **PORT 1**, **PORT 2**, **PORT 3**, and **PORT F**. See [Section 4: Communications Interfaces in the Reference Manual](#) for more information and options for connecting your relay to the communications interfaces.

An optional communications card provides Ethernet capability for the SEL-451. A communications card gives the relay access to popular Ethernet networking standards including TCP/IP, FTP, Telnet, DNP3, and IEC 61850 over local area and wide area networks. The Ethernet card with IEC 61850 support is only available at purchase as a factory-installed option or as a factory-installed conversion to an existing relay. For information on DNP3 applications, see [Section 6: DNP3 Communications in the Reference Manual](#). For more information on IEC 61850 applications, see [Section 8: IEC 61850 Communications in the Reference Manual](#).

Other Shared Configuration Attributes

All versions of the SEL-451 also feature ground, power, and battery monitor connections, communications ports, and fiber ports. See [Connection on page U.2.31](#) for information on these relay interface features.

Plug-In Boards

NOTE: The SEL-451 does not support Main Board B I/O and INT2, INT3, INT7, and INT8 I/O interface boards.

NOTE: Ordering the 4U and 5U relay with partial or no extra I/O allows for future system expansion and future use of additional relay features.

The SEL-451 is available in many input/output configuration options. The relay base model is a 3U chassis with Main Board A or Main Board B I/O and screw terminal connector connections (see [Figure 2.5](#)). Other ordering options include versions of the relay in larger enclosures (4U or 5U) with all, partial, or no extra I/O boards installed.

Plug-in communications cards are also available for the SEL-451. The optional Ethernet card allows you to use TCP/IP, FTP, Telnet, DNP3 LAN/WAN and IEC 61850 applications on an Ethernet network. This card is only available at the time of purchase of a new SEL-451 as a factory-installed option.

I/O Interface Boards

You can choose among seven input/output interface boards for the I/O slots of the 4U and 5U chassis. These I/O interface boards are in addition to the main board I/O described in [Shared Configuration Attributes on page U.2.1](#). The I/O interface boards are INT1, INT2, INT3, INT4, INT5, INT6, INT7, and INT8. [Figure 2.13](#), [Figure 2.14](#), [Figure 2.15](#), [Figure 2.16](#), [Figure 2.17](#), [Figure 2.18](#), [Figure 2.19](#), and [Figure 2.20](#) show the rear screw terminal connectors associated with these interface boards.




Figure 2.13 INT1 I/O Interface Board




Figure 2.14 INT2 I/O Interface Board




Figure 2.15 INT3 I/O Interface Board




Figure 2.16 INT4 I/O Interface Board




Figure 2.17 INT5 I/O Interface Board




Figure 2.18 INT6 I/O Interface Board




Figure 2.19 INT7 I/O Interface Board




Figure 2.20 INT8 I/O Interface Board

The I/O interface boards carry jumpers that identify the board location (see [I/O Interface Board Jumpers on page U.2.22](#)).

I/O Interface Board Inputs

CAUTION

Substation battery systems that have either a high resistance to ground (greater than 10 kΩ) or are ungrounded when used in conjunction with many direct-coupled inputs can reflect a dc voltage offset between battery rails. Similar conditions can exist for battery monitoring systems that have high-resistance balancing circuits or floating grounds. For these applications, SEL provides optional ground-isolated (optoisolated) contact inputs. In addition, SEL has published an application advisory on this issue. Contact the factory for more information.

The INT1, INT3, INT5, and INT6 I/O interface boards have eight independent control inputs. All independent inputs are isolated from other inputs. These high-isolation control inputs are direct coupled and hence polarity-sensitive. You cannot damage these inputs with a reverse polarity connection; though, the relay will not detect input changes with a reverse-polarity input.

The INT3 and INT4 I/O interface board has two groups of nine (9) common contacts (18 total) and six (6) independent control inputs. The INT2, INT7 and INT8 I/O interface boards have eight independent control inputs. All independent inputs are isolated from other inputs. These control inputs are optoisolated and hence not polarity sensitive, i.e., the relay will detect input changes with voltage applied at either polarity, or ac signals (when properly configured). See [Optoisolated on page U.2.7](#).

Table 2.3 is a comparison of the I/O board input capacities; the table also shows the I/O inputs on Main Board A or Main Board B. See [Control Inputs on page U.1.13](#) for complete control input specifications.

Table 2.3 I/O Interface Boards Control Inputs (Sheet 1 of 2)

NOTE: The SEL-451-1 does not support Main Board B I/O and INT2, INT3, INT7, and INT8 I/O interface boards.

Board Number	Independent Contact Pairs	Common Contacts
INT1 ^a	8	
INT2 ^b	8	
INT3 ^b	6	Two sets of 9
INT4 ^b	6	Two sets of 9
INT5 ^a	8	
INT6 ^a	8	
INT7 ^b	8	
INT8 ^b	8	

Table 2.3 I/O Interface Boards Control Inputs (Sheet 2 of 2)

Board Number	Independent Contact Pairs	Common Contacts
Main Board A ^a	5	2
Main Board B ^b	5	2

^a Main board A, INT1, INT5, and INT6 control inputs are direct coupled, and are polarity sensitive.

^b Main board B, INT2, INT3, INT4, INT7, and INT8 control inputs are optoisolated, and are not polarity sensitive.

I/O Interface Board Outputs

The I/O interface boards vary by the type and amount of output capabilities. *Table 2.4* lists the outputs of the additional I/O interface boards; the table also shows the I/O outputs on the main board. Information about the Standard and Hybrid (high-current interrupting) control outputs is in *Control Outputs on page U.2.8*.

Table 2.4 I/O Interface Boards Control Outputs

NOTE: Form A control outputs cannot be jumpered to Form B.

NOTE: The SEL-451-1 does not support Main Board B I/O and INT2, INT3, INT7, and INT8 I/O interface boards.

Board Number	Standard		Fast Hybrid ^a	Hybrid ^b
	Form A	Form C	Form A	Form A
INT1	13	2		
INT2	13	2		
INT3				4
INT4	2		6	
INT5			8	
INT6		2		13
INT7		2		13
INT8			8	
Main Board A	2	3		3
Main Board B	2	3		3

^a High-Speed/High-Current Interrupting

^b High-Current Interrupting

Installing Optional I/O Interface Boards

WARNING

Have only qualified personnel service this equipment. If you are not qualified to service this equipment, you can injure yourself or others, or cause equipment damage.

DANGER

Disconnect or de-energize all external connections before opening this device. Contact with hazardous voltages and currents inside this device can cause electrical shock resulting in injury or death.

CAUTION

Equipment components are sensitive to electrostatic discharge (ESD). Undetectable permanent damage can result if you do not use proper ESD procedures. Ground yourself, your work surface, and this equipment before removing any cover from this equipment. If your facility is not equipped to work with these components, contact SEL about returning this device and related SEL equipment for service.

CAUTION

If you are planning to install an INT4 I/O Interface Board in your relay (see [Table 2.3](#) and [Table 2.4](#) for board descriptions), first check the firmware version of the relay—see [Firmware Version Number on page U.6.36](#). If the firmware version is R11 or lower, you must first upgrade the relay firmware to the newest version and verify that the firmware upgrade was successful before installing the new board. Failure to install the new firmware first will cause the I/O Interface Board to fail, and it may require factory service. Complete firmware upgrade instructions are provided when new firmware is ordered.

CAUTION

Field replacement of I/O boards INT1, INT2, INT5, INT6, INT7, or INT8 with INT4 can cause I/O contact failure. The INT4 board has a pickup and dropout delay setting range of 0-1 cycle. For all other I/O boards, pickup and dropout delay settings (IN201PU-IN224PU, IN201DO-IN224DO, IN301PU-IN324PU, and IN301DO-IN324DO) have a range of 0-5 cycles. Upon replacing any I/O board with an INT4 board, manually confirm reset of pickup and dropout delays to within the expected range of 0-1 cycle.

Perform the following steps to expand the capability of the SEL-451 with additional I/O interface boards:

- Step 1. Follow your company standard to remove the relay from service.
- Step 2. Disconnect power from the SEL-451.
- Step 3. Retain the **GND** connection, if possible, and ground the equipment to an ESD mat.
- Step 4. Remove the communications cable connected to the front-panel serial port, if applicable.
- Step 5. Loosen the four front-panel screws (they remain attached to the front panel), and remove the relay front panel.
- Step 6. Remove the 34-pin ribbon cable from the front panel by pushing the extraction ears away from the connector.
- Step 7. Disconnect the power, the interface board, and the analog input board cables from the main board.
- Step 8. Confirm proper installation of address jumpers on the interface board (see [Jumpers on page U.2.18](#)).
- Step 9. Confirm drawout tray keying.

The relay chassis and the drawout trays for the 200-addresses slot and the 300-addresses slot are keyed (see [Figure 2.21](#)).

The keys are two round plug-in/plug-out discs on the bottom of the drawout tray.

The 200-addresses slot keys go to the left, and the 300-addresses slot keys go to the right (when viewed from the top and front of the drawout tray).

- Step 10. Move a key on the bottom of the drawout tray to the correct position by prying the key from the tray and reinserting the key in the proper position.

Do this for both keys.




Figure 2.21 Chassis Key Positions for I/O Interface Boards

Step 11. Install the drawout tray with the I/O interface board, using the following precautions:

- a. Position the drawout tray edges into the left-side and right-side internally mounted slots.
- b. Slide the I/O interface board into the SEL-451 by pushing the front edge of the board drawout tray.
- c. Apply firm pressure to fully seat the I/O interface board.

If you encounter resistance, stop, and withdraw the board.

Inspect the drawout tray edge guide slots for damage.

If you see no damage, take all of the precautions outlined above and try again to insert the board.

Step 12. If this is a new I/O interface board installation, remove the **INTERFACE BOARD EXPANSION SLOT** self-sticking label from the rear panel.

Lift a corner of the label with a sharp tool and peel away the label from the rear panel.

Step 13. Confirm screw terminal connector keying.

SEL supplies three new screw terminal connectors with new I/O interface boards.

- a. Inspect the screw terminal connector receptacles on the rear of the I/O interface board.
- b. Refer to [Figure 2.41](#) for the corresponding key positions inside the receptacle.
- c. If the keys inside the I/O interface board receptacles are not in the positions indicated in [Figure 2.41](#), grasp the key edge with long-nosed pliers to remove the key and reinsert the key in the correct position.
- d. Break the webs of the screw terminal connectors in the position that matches the receptacle key (see [Figure 2.40](#)).

Step 14. Attach the screw terminal connector.

- a. Mount the screw terminal connectors to the rear panel of the SEL-451.

Refer to [Figure 2.13](#) and [Figure 2.17](#) for screw terminal connector placement.

- b. Tighten the screw terminal connector mounting screws to between 7 in-lb. and 12 in-lb. (0.8 Nm to 1.4 Nm).

Step 15. Reinstall the SEL-451 main board, and reconnect the power, the interface board, and the analog input board cables.

Step 16. Reconnect the cable removed in [Step 6](#) and reinstall the relay front-panel cover.

Step 17. Reconnect any serial cables that you removed from the **EIA-232 PORTS** in the disassembly process.

Step 18. Apply power.

Step 19. Enter Access Level 2 (see [Making Simple Settings Changes on page U.4.14](#)).

Step 20. Issue the **STA** command and answer **Y <Enter>** to accept the new hardware configuration (see *STATUS on page R.9.54*).

Step 21. Inspect the relay targets to confirm that the relay reads the added I/O interface board(s).

You can see the new control inputs in the target listings by using a terminal, the ACCELERATOR QuickSet® SEL-5030 software program, or the front panel.

Step 22. Use a communications terminal to issue the commands **TAR OUT201 <Enter>** (for the 200-addresses slot) or **TAR OUT301 <Enter>** (for the 300-addresses slot).

Alternatively, from the front panel **MAIN** menu, select **RELAY ELEMENTS**, and press the **Down Arrow** pushbutton to go to **ROW 105** (for the 200-addresses slot) or **ROW 108** (for the 300-addresses slot).

Step 23. Follow your company standard procedure to return the relay to service.

Communications Card

You can add communications protocols to the SEL-451 by purchasing the Ethernet card option. Factory-installed in the rear relay **PORT 5**, the Ethernet card provides Ethernet ports for industrial applications that processes data traffic between the SEL-451 and a LAN (local area network).

Jumpers

The SEL-451 contains jumpers that configure the relay for certain operating modes. The jumpers are located on the main board (the top board) and the I/O interface boards (one or two boards located immediately below the main board).

Main Board Jumpers

The jumpers on the main board of the SEL-451 perform these functions:

- Temporary/emergency password disable
- The “Breaker jumper” enables circuit breaker commands (**OPEN** and **CLOSE**), output **PULSE** commands, and the SEL-451-4 disconnect switch commands (**89OPEN** and **89CLOSE**).
- Rear serial port +5 Vdc source enable

Figure 2.22 shows the positions of the main board jumpers. The main board jumpers are in two locations. The password disable jumper and breaker jumper are at the front of the main board. The serial port jumpers are near the rear-panel serial ports; each serial port jumper is directly in front of the serial port that it controls.

Password and Circuit Breaker Jumpers

CAUTION

Do not install a jumper on positions A or D of the main board J18 header. Relay misoperation can result if you install jumpers on positions J18A and J18D.

You can access the password disable jumper and circuit breaker control jumper without removing the main board from the relay cabinet. Remove the SEL-451 front cover to view these jumpers (use appropriate ESD precautions). The password and circuit breaker jumpers are on jumper header J18 on the front of the main board, located immediately left of power connector J17 (see *Figure 2.22*).

The J18 header is denoted A, B, C, and D from right to left (position A is on the right). Position B is the password disable jumper. Position C is the breaker jumper. Positions A and D are not used. *Figure 2.23* shows the jumper header with the breaker jumper in the ON position and the password jumper in the OFF position. *Table 2.5* lists the J18 jumper positions and functions.




Figure 2.22 Major Component Locations on the SEL-451 Main Board A (or B)




Figure 2.23 J18 Header—Password and Breaker Jumpers

Table 2.5 Main Board Jumpers^a

Jumper	Jumper Location	Jumper Position	Function
J18A	Front	OFF	For SEL use only
J18B	Front	OFF	Enable password protection (normal and shipped position)
		ON	Disable password protection (temporary or emergency only)
J18C	Front	OFF	Disable circuit breaker commands (OPEN and CLOSE), output PULSE commands ^b , and SEL-451-4 disconnect switch commands (89OPEN and 89CLOSE) (shipped position)
		ON	Enable circuit breaker commands (OPEN and CLOSE), output PULSE commands ^b , and SEL-451-4 disconnect switch commands (89OPEN and 89CLOSE)
J18D	Front	OFF	For SEL use only

^a ON is the jumper shorting both pins of the jumper. Place the jumper over one pin only for OFF.

^b Also affects the availability of the Fast Operate Breaker Control messages, front-panel LOCAL CONTROL > BREAKER CONTROL screens, front-panel LOCAL CONTROL > OUTPUT TESTING screens, and disconnect and breaker control from the SEL-451-4 one-line diagram.

The password disable jumper, J18B, is for temporary or emergency suspension of the relay password protection mechanisms. Under no circumstance should you install J18B on a long-term basis. The SEL-451 ships with password disable jumper J18B OFF (passwords enabled).

For temporary unprotected access to a particular access level, use the **PAS n DISABLE** command (*n* is the access level: **n = 1, B, P, A, O, 2**). For more information on this command and setting passwords, see [Passwords on page U.4.9](#).

The breaker jumper, Jumper J18C, supervises the **CLOSE n** command, the **OPEN n** command, the **PULSE OUTnnn** command, and the SEL-451-4 **89OPEN n** and **89CLOSE n** commands. Additionally, it supervises the front-panel LOCAL CONTROL > BREAKER CONTROL and LOCAL CONTROL > OUTPUT TESTING screens, and disconnect or breaker control from the SEL-451-4 one-line diagrams. To use these functions, you must install jumper J18C.

The relay checks the status of the breaker jumper when you issue **CLOSE n**, **OPEN n**, **PULSE OUTnnn**, or the SEL-451-4 **89OPEN n** and **89CLOSE n** commands and when you use the front panel to close or open circuit breakers, control a local bit, pulse an output, or close or open disconnect switches in the SEL-451-4.

The SEL-451 ships with jumper J18C OFF. For commissioning and testing of the SEL-451 Contact Outputs, it may be convenient to set J18C ON, so that the **PULSE OUTnnn** commands can be used to check output wiring. J18C must also be set ON if SCADA Fast Operate is required for circuit breakers and SEL-451-4 disconnect switches control, or if the LOCAL CONTROL > BREAKER CONTROL screens or disconnect and breaker control from the SEL-451-4 one-line diagram is required.

Serial Port Jumpers

Place jumpers on the main board to connect +5 Vdc to Pin 1 of each of the three rear-panel EIA-232 serial ports. The maximum current available from this Pin 1 source is 0.5 A. The Pin 1 source is useful for powering an external modem. *Table 2.6* describes the JMP1, JMP2, and JMP3 positions. Refer to *Figure 2.22* for the locations of these jumpers. The SEL-451 ships with JMP1, JMP2, and JMP3 OFF (no +5 Vdc on Pin 1).

Table 2.6 Main Board Jumpers—JMP1, JMP2, and JMP3^a

Jumper	Jumper Location	Jumper Position	Function
JMP1	Rear	OFF	Serial PORT 3, Pin 1 = not connected
		ON	Serial PORT 3, Pin 1 = +5 Vdc
JMP2	Rear	OFF	Serial PORT 2, Pin 1 = not connected
		ON	Serial PORT 2, Pin 1 = +5 Vdc
JMP3	Rear	OFF	Serial PORT 1, Pin 1 = not connected
		ON	Serial PORT 1, Pin 1 = +5 Vdc

^a ON is the jumper shorting both pins of the jumper. Place the jumper over one pin only for OFF.

Changing Serial Port Jumpers

DANGER

Contact with instrument terminals can cause electrical shock that can result in injury or death.

WARNING

Have only qualified personnel service this equipment. If you are not qualified to service this equipment, you can injure yourself or others, or cause equipment damage.

CAUTION

Equipment components are sensitive to electrostatic discharge (ESD). Undetectable permanent damage can result if you do not use proper ESD procedures. Ground yourself, your work surface, and this equipment before removing any cover from this equipment. If your facility is not equipped to work with these components, contact SEL about returning this device and related SEL equipment for service.

You must remove the main board to access the serial port jumpers. Perform the following steps to change the JMP1, JMP2, and JMP3 jumpers in an SEL-451:

- Step 1. Follow your company standard to remove the relay from service.
- Step 2. Disconnect power from the SEL-451.
- Step 3. Retain the GND connection, if possible, and ground the equipment to an ESD mat.
- Step 4. Remove the communications cable connected to the front-panel serial port, if applicable.
- Step 5. Remove the rear-panel EIA-232 PORT mating connectors. Unscrew the keeper screws and disconnect any serial cables connected to the PORT 1, PORT 2, and PORT 3 rear-panel receptacles.
- Step 6. Loosen the four front-panel screws (they remain attached to the front panel), and remove the relay front panel.
- Step 7. Remove the 34-pin ribbon cable from the front panel by pushing the extraction ears away from the connector.
- Step 8. Disconnect the power, the interface board, and the analog input board cables from the main board.

Step 9. Remove the screw terminal connectors.

- a. Loosen the attachment screws at each end of the 100-addresses screw terminal connectors.
- b. Pull straight back to remove.

Step 10. Carefully pull out the drawout assembly containing the main board.

Step 11. Locate the jumper you want to change.

Jumpers JMP1, JMP2, and JMP3 are located at the rear of the main board, directly in front of **PORT 3**, **PORT 2**, and **PORT 1**, respectively (see *Figure 2.22*).

Step 12. Install or remove the jumper as needed (see *Table 2.6* for jumper position descriptions).

Step 13. Reinstall the SEL-451 main board, and reconnect the power, the interface board, and the analog input board cables.

Step 14. Reconnect the cable removed in *Step 7* and reinstall the relay front-panel cover.

Step 15. Reattach the rear-panel connections.

Step 16. Affix the screw terminal connectors to the appropriate 100-addresses locations on the rear panel.

Step 17. Reconnect any serial cables that you removed from the **EIA-232 PORTS** in the disassembly process.

Step 18. Follow your company standard procedure to return the relay to service.

I/O Interface Board Jumpers

Jumpers on the I/O interface boards identify the particular I/O board configuration and I/O board control address. Eight I/O interface boards are available: INT1, INT2, INT3, INT4, INT5, INT6, INT7, and INT8 (see *I/O Interface Boards on page U.2.13* for more information on these boards). The jumpers on these I/O interface boards are at the front of each board, as shown in *Figure 2.24*, *Figure 2.25*, *Figure 2.26*, *Figure 2.27*, and *Figure 2.28*.




Figure 2.24 Major Component Locations on the SEL-451 INT1 (or INT2) I/O Board

U.2.24 | Installation
Jumpers




Figure 2.25 Major Component Locations on the SEL-451 INT3 I/O Board




Figure 2.26 Major Component Locations on the SEL-451 INT4 I/O Board




Figure 2.27 Major Component Locations on the SEL-451 INT5 (or INT8) I/O Board




Figure 2.28 Major Component Locations on the SEL-451 INT6 (or INT7) I/O Board

To confirm the positions of your I/O board jumpers, remove the front panel and visually inspect the jumper placements. [Table 2.7](#) lists the four jumper positions for I/O interface boards. Refer to [Figure 2.24](#), [Figure 2.26](#), [Figure 2.27](#), and [Figure 2.28](#) for the locations of these jumpers.

The I/O board control address has a hundreds-series prefix attached to the control inputs and control outputs for that particular I/O board chassis slot. A 4U chassis has a 200-addresses slot for inputs IN201, IN202, etc., and outputs OUT201, OUT202, etc. A 5U chassis has a 200-addresses slot and a 300-addresses slot.

The drawout tray on which each I/O board is mounted is keyed. See [Installing Optional I/O Interface Boards on page U.2.16](#) for information on the key positions for the 200-addresses slot trays and the 300-addresses slot trays.

Table 2.7 I/O Board Jumpers

I/O Board Control Address	JMP1A/ JMP49A ^a	JMP1B/ JMP49B ^a	JMP2A/ JMP50A ^a	JMP2B/ JMP50B ^a
2XX	OFF	OFF	OFF	OFF
3XX	ON	OFF	ON	OFF

^a INT4 I/O Interface Board jumper numbering.

Changing I/O Interface Board Jumpers

Change the I/O interface board jumpers only when you move the slot position of an I/O board. You must remove the I/O interface boards to access the jumpers. Perform the following steps to change JMP1A, JMP1B, JMP2A, and JMP2B on an SEL-451 I/O interface board:

DANGER

Disconnect or de-energize all external connections before opening this device. Contact with hazardous voltages and currents inside this device can cause electrical shock resulting in injury or death.

WARNING

Have only qualified personnel service this equipment. If you are not qualified to service this equipment, you can injure yourself or others, or cause equipment damage.

CAUTION

Equipment components are sensitive to electrostatic discharge (ESD). Undetectable permanent damage can result if you do not use proper ESD procedures. Ground yourself, your work surface, and this equipment before removing any cover from this equipment. If your facility is not equipped to work with these components, contact SEL about returning this device and related SEL equipment for service.

- Step 1. Follow your company standard to remove the relay from service.
 - Step 2. Disconnect power from the SEL-451.
 - Step 3. Retain the GND connection, if possible, and ground the equipment to an ESD mat.
 - Step 4. Remove the communications cable connected to the front-panel serial port, if applicable.
 - Step 5. Loosen the four front-panel screws (they remain attached to the front panel), and remove the relay front panel.
 - Step 6. Remove the 34-pin ribbon cable from the front panel by pushing the extraction ears away from the connector.
 - Step 7. Disconnect the power, the interface board, and the analog input board cables from the main board.
 - Step 8. Pull out the drawout assembly containing the I/O interface board.
 - Step 9. Locate the jumper you want to change.
- Jumpers JMP1A, JMP1B, JMP2A, and JMP2B are located at the front of the I/O board to the left and right of the interface board connector (see [Figure 2.24](#), [Figure 2.27](#), and [Figure 2.28](#)).
- Step 10. Install or remove the jumper as needed (see [Table 2.7](#) for jumper position descriptions).
 - Step 11. Reinstall the interface board, and reconnect the power, the interface board, and the analog input board cables.
 - Step 12. Reconnect the cable removed in [Step 6](#) and reinstall the relay front-panel cover.

- Step 13. Replace any cables previously removed from serial ports.
- Step 14. Follow your company standard procedure to return the relay to service.
- Step 15. At relay power-up, confirm that the relay does not display a status warning about I/O board addresses. For information on this status warning, see [Relay Self-Tests on page U.6.35](#).

Auxiliary TRIP/CLOSE Pushbutton and Breaker Status LED Jumpers (select models only)

The jumpers listed in [Table 2.8](#) are used to select the proper control voltage for breaker open/closed indicating LEDs on the front panel of the relay.

[Figure 2.25](#) shows the jumper locations on the magnetics/auxiliary pushbutton board. The jumpers come preset from the factory with the voltage range set the same as the control input voltage, as determined by the part number at order time.

The voltage setting can be different for each LED. To access these jumpers, the relay front cover, top cover, main board, and any additional I/O board (if present) must first be removed. See instructions and precautions in the subsection [Changing Serial Port Jumpers on page U.2.21](#).

Table 2.8 Jumper Positions for Breaker OPEN/CLOSE Indication

	BREAKER OPEN LED			BREAKER CLOSED LED		
	JMP4	JMP5	JMP7	JMP3	JMP6	JMP8
24 V	Installed	Installed	Installed	Installed	Installed	Installed
48 V	Installed	Installed	Not Installed	Installed	Installed	Not Installed
110/125 V	Installed	Not Installed	Not Installed	Installed	Not Installed	Not Installed
220/250 V	Not Installed	Not Installed	Not Installed	Not Installed	Not Installed	Not Installed

[Table 2.9](#) shows how to enable or disable the arc suppression feature of the TRIP and CLOSE pushbuttons. If ac control power is used to operate the breaker, then the corresponding arc suppression jumper must be removed. If dc control power is used to operate the breaker, then the arc suppression is strongly recommended to break inductive loads. The arc suppression comes enabled from the factory. [Figure 2.25](#) shows the jumper locations on the magnetics/auxiliary pushbutton board.

NOTE: With arc suppression enabled, the corresponding output polarity marks must be followed when wiring the control.

Table 2.9 Jumper Positions for Arc Suppression

Option	TRIP pushbutton	CLOSE pushbutton
	JMP2	JMP1
Arc Suppression Enabled	Installed	Installed
Arc Suppression Disabled	Not Installed	Not Installed

Table 2.10 Front-Panel LED Option

JMP11, JMP12 ^a	LED Color
BRIDGE Pins 1 and 3 Pins 2 and 4	Red
BRIDGE Pins 3 and 5 Pins 4 and 6	Green

^a JMP11 Open; JMP12 Closed.

Relay Placement

Proper placement of the SEL-451 helps make certain that you receive years of trouble-free power system protection. Use the following guidelines for proper physical installation of the SEL-451.

Physical Location

You can mount the SEL-451 in a sheltered indoor environment (a building or an enclosed cabinet) that does not exceed the temperature and humidity ratings for the relay.

You can place the relay in extreme temperature and humidity locations. The temperature range over which the relay operates is -40° to $+185^{\circ}\text{F}$ (-40° to $+85^{\circ}\text{C}$, see *Operating Temperature on page U.1.14*). The relay operates in a humidity range from 5 percent to 95 percent, no condensation.

Rack Mounting

When mounting the SEL-451 in a rack, use the reversible front flanges to either semiflush-mount or projection mount the relay.

The semiflush mount gives a small panel protrusion from the relay rack rails of approximately 1.1 in. or 27.9 mm. The projection mount places the front panel approximately 3.5 in. or 88.9 mm in front of the relay rack rails.

See *Figure 2.29* for exact mounting dimensions for both the horizontal and vertical rack-mount relays. Use four screws of the appropriate size for your rack.




Figure 2.29 SEL-451 Chassis Dimensions

Panel Mounting

Place the panel-mount versions of the SEL-451 in a switchboard panel. See the drawings in [Figure 2.29](#) for panel cut and drill dimensions (these dimensions apply to both the horizontal and vertical panel-mount relay versions). Use the supplied mounting hardware to attach the relay.

Connection

CAUTION

Insufficiently rated insulation can deteriorate under abnormal operating conditions and cause equipment damage. For external circuits, use wiring of sufficiently rated insulation that will not break down under abnormal operating conditions.

The SEL-451 is available in many different configurations, depending on the number and type of control inputs, control outputs, and analog input termination you specified at ordering. This subsection presents a representative sample of relay rear-panel configurations and the connections to these rear panels. Only horizontal chassis are shown; rear panels of vertical chassis are identical to horizontal chassis rear panels for each of the 3U, 4U, and 5U sizes.

When connecting the SEL-451, refer to your company plan for wire routing and wire management. Be sure to use wire that is appropriate for your installation with an insulation rating of at least 90°C.

Rear-Panel Layout

NOTE: The SEL-451-1 does not support Main Board B I/O and INT2, INT3, INT7, and INT8 I/O interface boards.

Figure 2.30–Figure 2.38 show some of the available SEL-451 rear panels.

All relay versions have screw terminal connectors for I/O, power, and battery monitor. You can order the relay with fixed terminal blocks for the CT and PT connections, or you can order SEL Connectorized rear-panel configurations that feature plug-in/plug-out PT connectors and shorting CT connectors for relay analog inputs. *Figure 2.31* shows the Connectorized 3U horizontal configuration of the SEL-451. For clarity, the figures do not show a communications card installed in PORT 5.

The screw terminal connections for the INT1 (or INT2) and the INT6 (or INT7) I/O interface boards are the same. The INT5 (or INT8) I/O interface board has control output terminals grouped in threes, with the fourth terminal as a blank additional separator (terminals 4, 8, 12, 16, 20, 24, 28, and 32). The INT4 and INT5 (or INT8) I/O interface boards both contain fast hybrid control outputs, but use a different terminal layout—see *Control Outputs on page U.2.8* for details.

For more information on the main board control inputs and control outputs, see *Main Board I/O on page U.2.11*. For more information on the I/O interface board control inputs and control outputs, see *I/O Interface Board Jumpers on page U.2.22*.




Figure 2.30 3U Rear Panel, Main Board A, SEL-451




Figure 2.31 3U Rear Panel, Main Board A, Connectorized SEL-451




Figure 2.32 4U Rear Panel, Main Board A, Without Optional I/O, SEL-451




Figure 2.33 4U Rear Panel, Main Board A, INT5 I/O Interface Board, SEL-451




Figure 2.34 4U Rear Panel, Main Board B, INT8 I/O Interface Board, SEL-451




Figure 2.35 5U Rear Panel, Main Board B, INT3 and INT1 I/O Interface Board, SEL-451

(The INT3 board is the 200-addresses slot; the INT1 board is the 300-addresses slot.)






Figure 2.36 5U Rear Panel, Main Board A, INT4 and INT1 I/O Interface Board, SEL-451

(The INT4 board is the 200-addresses slot; the INT1 board is the 300-addresses slot.)



i3926a

Figure 2.37 5U Rear Panel, Main Board A, INT6 and INT4 I/O Interface Board, SEL-451




i3927a

Figure 2.38 5U Rear Panel, Main Board B, INT2 and INT7 I/O Interface Board, SEL-451

Rear-Panel Symbols

There are important safety symbols on the rear of the SEL-451 (see [Figure 2.39](#)). Observe proper safety precautions when you connect the relay at terminals marked by these symbols. In particular, the danger symbol located on the rear panel corresponds to the following: *Contact with instrument terminals can cause electrical shock that can result in injury or death.* Be careful to limit access to these terminals.

**Figure 2.39** Rear-Panel Symbols

Screw Terminal Connectors

Terminate connections to the SEL-451 screw terminal connectors with ring-type crimp lugs. Use a #8 ring lug with a maximum width of 0.360 in. (9.1 mm). The screws in the rear-panel screw terminal connectors are #8-32 binding head, slotted, nickel-plated brass screws. Tightening torque for the terminal connector screws is 9 in-lb. to 18 in-lb. (1.0 Nm to 2.0 Nm).

You can remove the screw terminal connectors from the rear of the SEL-451 by unscrewing the screws at each end of the connector block. Perform the following steps to remove a screw terminal connector:

- Step 1. Remove the connector by pulling the connector block straight out.
Note that the receptacle on the relay circuit board is keyed; you can insert each screw terminal connector in only one location on the rear panel.
- Step 2. To replace the screw terminal connector, confirm that you have the correct connector and push the connector firmly onto the circuit board receptacle.
- Step 3. Reattach the two screws at each end of the block.

Changing Screw Terminal Connector Keying

You can rotate a screw terminal connector so that the connector wire dress position is the reverse of the factory-installed position (for example, wires entering the relay panel from below instead of from above). In addition, you can move similar function screw terminal connectors to other locations on the rear panel. To move these connectors to other locations, you must change the screw terminal connector keying.

Inserts in the circuit board receptacles key the receptacles for only one screw terminal connector in one orientation. Each screw terminal connector has a missing web into which the key fits (see [Figure 2.40](#)).

If you want to move a screw terminal connector to another circuit board receptacle or reverse the connector orientation, you must rearrange the receptacle keys to match the screw terminal connector block. Use long-nosed pliers to move the keys.

[Figure 2.41](#) shows the factory default key positions.




Figure 2.40 Screw Terminal Connector Keying

Grounding

Connect the grounding terminal (#Z31) labeled **GND** on the rear panel to a rack frame ground or main station ground for proper safety and performance.

This protective earthing terminal is in the lower right side of the relay panel (see [Figure 2.30](#), [Figure 2.31](#), [Figure 2.32](#), [Figure 2.33](#), and [Figure 2.36](#)). The symbol that indicates the grounding terminal is shown in [Figure 2.39](#).

Use 10 AWG (6 mm^2) to 12 AWG (4 mm^2) or heavier wire less than 6.6 feet (2 m) in length for this connection. This terminal connects directly to the internal chassis ground of the SEL-451.




Figure 2.41 Rear-Panel Receptacle Keying, SEL-451

Power Connections

The terminals labeled **POWER** on the rear panel (#Z29 and #Z30) must connect to a power source that matches the power supply characteristics that your SEL-451 specifies on the rear-panel serial number label. (See [Power Supply](#)

([on page U.1.12](#), for complete power input specifications.) For the relay models that accept dc input, the serial number label specifies dc with the symbol shown in [Figure 2.39](#).

NOTE: The combined voltages applied to the **POWER** and **MONITOR** terminals must not exceed 600 V (rms or dc).

The **POWER** terminals are isolated from chassis ground. Use 16-14 AWG (1.5-2.1 mm²) size or heavier wire to connect to the **POWER** terminals. Connection to external power must comply with IEC 60947-1 and IEC 60947-3, and must be identified as the disconnect device for the equipment.

Place an external disconnect device, switch/fuse combination or circuit breaker, in the **POWER** leads for the SEL-451; this device must interrupt both the hot (**H/+**) and neutral (**N/-**) power leads. The current rating for the power disconnect circuit breaker or fuse must be 20 A maximum. Be sure to locate this device within 9.8 feet (3.0 m) of the relay.

Operational power is internally fused by power supply fuse F1. [Table 2.11](#) lists the SEL-451 power supply fuse requirements. Be sure to use fuses that comply with IEC 127-2.

You can order the SEL-451 with one of three operational power input ranges listed in [Table 2.11](#). Each of the three supply voltage ranges represents a power supply ordering option.

As noted in [Table 2.11](#), model numbers for the relay with these power supplies begin 04511n, where n is 2, 4, or 6, to indicate low, middle, and high voltage input power supplies, respectively.

Note that each power supply range covers two widely used nominal input voltages. The SEL-451 power supply operates from 30 Hz to 120 Hz when ac power is used for the **POWER** input.

Table 2.11 Fuse Requirements for the SEL-451 Power Supply

Nominal Power Supply Voltage Rating	Power Supply Voltage Range	Fuse F1	Fuse Description	Model Number
24/48 V	18–60 Vdc	T6.3AH250V	5x20 mm, time-lag, 6.3 A, high break capacity, 250 V	045112
48/125 V	38–140 Vdc or 85–140 Vac (30–120 Hz)	T3.15AH250V	5x20 mm, time-lag, 3.15 A, high break capacity, 250 V	045114
125/250 V	85–300 Vdc or 85–264 Vac (30–120 Hz)	T3.15AH250V	5x20 mm, time-lag, 3.15 A, high break capacity, 250 V	045116

The SEL-451 accepts dc power input for all three power supply models. The 48/125 Vdc supply also accepts 120 Vac; the 125/250 Vdc supply also accepts 120/240 Vac. When connecting a dc power source, you must connect the source with the proper polarity, as indicated by the + (terminal #Z29) and the - (terminal #Z30) symbols on the power terminals. When connecting to an ac power source, the + terminal #Z29 is hot (**H**), and the - terminal #Z30 is neutral (**N**).

Each model of the SEL-451 internal power supply exhibits low power consumption and a wide input voltage tolerance. For more information on the power supplies, see [Power Supply on page U.1.12](#).

Power Supply Fuse Replacement

You can replace a bad fuse in an SEL-451 power supply, or you can return the SEL-451 to SEL for fuse replacement. If you decide to replace the fuse, perform the following steps to replace the power supply fuse:

DANGER

Disconnect or de-energize all external connections before opening this device. Contact with hazardous voltages and currents inside this device can cause electrical shock resulting in injury or death.

WARNING

Have only qualified personnel service this equipment. If you are not qualified to service this equipment, you can injure yourself or others, or cause equipment damage.

CAUTION

Equipment components are sensitive to electrostatic discharge (ESD). Undetectable permanent damage can result if you do not use proper ESD procedures. Ground yourself, your work surface, and this equipment before removing any cover from this equipment. If your facility is not equipped to work with these components, contact SEL about returning this device and related SEL equipment for service.

- Step 1. Follow your company standard to remove the relay from service.
- Step 2. Disconnect power from the SEL-451.
- Step 3. Remove the relay from the rack or panel.
- Step 4. Retain the **GND** connection, if possible, and ground the equipment to an ESD mat.
- Step 5. Remove the communications cable connected to the front-panel serial port, if applicable.
- Step 6. Remove the rear-panel **EIA-232 PORT** mating connectors. Unscrew the keeper screws and disconnect any serial cables connected to the **PORT 1**, **PORT 2**, and **PORT 3** rear-panel receptacles.
- Step 7. Loosen the four front-panel screws (they remain attached to the front panel), and remove the relay front panel.
- Step 8. Remove the 34-pin ribbon cable from the front panel by pushing the extraction ears away from the connector.
- Step 9. Disconnect the power, the interface board, and the analog input board cables from the main board.
- Step 10. Remove the screw terminal connectors.
 - a. Loosen the attachment screws at each end of the 100-addresses, 200-addresses, and 300-addresses screw terminal connectors.
 - b. Pull straight back to remove.
- Step 11. Remove the top chassis plate by unscrewing seven screws from the chassis.
- Step 12. Pull out the drawout tray containing the main board.
- Step 13. Pull out the drawout tray containing the I/O interface board(s).
- Step 14. Locate the power supply. Fuse F1 is at the rear of the power supply circuit board (see *Figure 2.42*).
- Step 15. Examine the power supply for blackened parts or other damage. If you can see obvious damage, reinstall all boards and contact SEL to arrange return of the relay for repair.
- Step 16. Remove the spent fuse from the fuse clips.
- Step 17. Replace the fuse with an exact replacement (see *Table 2.11* for the proper fuse for your power supply).
- Step 18. Reinstall the interface board.
- Step 19. Reinstall the SEL-451 main board, and reconnect the power, the interface board, and the analog input board cables.
- Step 20. Replace the chassis top on the relay and secure it with seven screws.

Step 21. Reconnect the cable removed in [Step 8](#) and reinstall the relay front-panel cover.

Step 22. Reattach the rear-panel connections.

Affix the screw terminal connectors to the appropriate 100-addresses, 200-addresses, and 300-addresses locations on the rear panel.

Step 23. Reconnect any serial cables that you removed from the **EIA-232 PORTS** in the disassembly process.

Step 24. Follow your company standard procedure to return the relay to service.




Figure 2.42 PS30 Power Supply Fuse Location

Monitor Connections (DC Battery)

NOTE: The combined voltages applied to the **POWER** and **MONITOR** terminals must not exceed 600 V (rms or dc).

Secondary Circuit Connections

DANGER

Contact with instrument terminals can cause electrical shock that can result in injury or death.

The SEL-451 monitors two dc battery systems. For information on the battery monitoring function, see [Station DC Battery System Monitor on page A.2.16](#).

Connect the positive lead of Battery System 1 to Terminal #Z25 and the negative lead of Battery System 1 to Terminal #Z26. (Usually Battery System 1 is also connected to the rear-panel **POWER** input terminals.) For Battery System 2, connect the positive lead to Terminal #Z27, and the negative lead to Terminal #Z28.

The SEL-451 has two sets of three-phase current inputs and two sets of three-phase voltage inputs. [Shared Configuration Attributes on page U.2.1](#) describes these inputs in detail. The alert symbol and the word **DANGER** on the rear panel indicate that you should use all safety precautions when connecting secondary circuits to these terminals.

To verify these connections, use SEL-451 metering (see [Examining Metering Quantities on page U.4.34](#)). You can also review metering data in an event report that results when you issue the **TRIGGER** command (see [Triggering Data Captures and Event Reports on page A.3.4](#)).

Fixed Terminal Blocks

Connect the secondary circuits to the Z terminal blocks on the relay rear panel. Note the polarity dots above the odd-numbered terminals #Z01, #Z03, #Z05, #Z07, #Z09, and #Z11 for CT inputs. Similar polarity dots are above the odd-numbered terminals #Z13, #Z15, #Z17, #Z19, #Z21, and #Z23 for PT inputs.

Connectorized

CAUTION

Relay misoperation can result from applying other than specified secondary voltages and currents. Before making any secondary circuit connections, check the nominal voltage and nominal current specified on the rear-panel nameplate.

For the Connectorized SEL-451, order the wiring harness kit, SEL-WA0421. The wiring harness contains four prewired connectors for the relay current and voltage inputs.

You can order the wiring harness with various wire sizes and lengths. Contact your local Technical Service Center or the SEL factory for ordering information.

Perform the following steps to install the wiring harness:

- Step 1. Plug the CT shorting connectors into terminals #Z01 through #Z06 for the IW inputs, and #Z07 through #Z12 for the IX inputs, as appropriate.

Odd-numbered terminals are the polarity terminals.

- Step 2. Secure the connector to the relay chassis with the two screws located on each end of the connector.

When you remove the CT shorting connector, pull straight away from the relay rear panel.

As you remove the connector, internal mechanisms within the connector separately short each power system current transformer.

You can install these connectors in only one orientation.

- Step 3. Plug the PT voltage connectors into terminals #Z13 to #Z18 for the VY inputs, and #Z19 to #Z24 for the VZ inputs, as appropriate.

Odd numbered terminals are the polarity terminals. You can install these connectors in only one orientation.

Control Circuit Connections

You can configure the SEL-451 with many combinations of control inputs and control outputs. See [Main Board I/O on page U.2.11](#) and [I/O Interface Boards on page U.2.13](#) for information about I/O configurations. This subsection provides details about connecting these control inputs and outputs. Refer to [Figure 2.5](#), [Figure 2.13](#), and [Figure 2.17](#) for representative rear-panel screw terminal connector locations.

Control Inputs

NOTE: The combined voltages applied to the INnnn and OUTnnn terminals must not exceed 600 V (rms or dc).

[Table 2.3](#) lists the control inputs available with the SEL-451, and notes that some are Direct-Coupled, and some are Optoisolated.

Direct-Coupled

Direct-coupled control inputs are polarity sensitive. These inputs use direct-coupled circuitry, and have terminal markings to indicate polarity: a + mark appears for each input. Connect the positive sense of the control input to the + terminal. Although you cannot damage these inputs with a reverse polarity connection, a reverse polarity connection will cause the relay internal A/D converter to measure the input voltage incorrectly and the relay will no longer detect input changes (see [Control Inputs on page U.2.6](#)).

Note that the Main Board A I/O control inputs have one set of two inputs that share a common input leg. These inputs are IN106 and IN107 found on terminals #A30, #A31, and #A32.

Optoisolated

Optoisolated control inputs are not polarity sensitive. These inputs respond to voltage of either polarity, and can be used with ac control signals when properly configured.

Note that the Main Board B I/O control inputs have one set of two inputs that share a common input leg and INT3 and INT4 I/O interface boards have two sets of nine inputs that share a common leg (see [Figure 2.16](#)).

Assigning

To assign the functions of the control inputs, see [Operating the Relay Inputs and Outputs on page U.4.58](#), or [SET G on page R.9.47](#) for more details. You can also use ACCELERATOR QuickSet to set and verify operation of the inputs.

Control Outputs

The SEL-451 has three types of outputs:

- Standard outputs (example: main board OUT104)
- Hybrid (high-current-interrupting) outputs (example: main board OUT101)
- Fast Hybrid (fast high-current-interrupting) outputs (example: INT4 or INT5 or INT8 board OUT201, or OUT301)

See [Control Outputs on page U.2.8](#) for more information.

You can connect the Standard outputs and the Fast Hybrid (fast high-current-interrupting) outputs in either ac or dc circuits. Connect the Hybrid (high-current-interrupting) outputs to dc circuits only. The screw terminal connector legends alert you about this requirement by showing polarity marks on the Hybrid (high-current-interrupting) contacts.


Form A (SPST NO) contacts comprise the majority of the control outputs. Two pairs of Form C (DPST CO) contacts are on the main board, the INT1 (INT2) I/O interface board, and the INT6 (INT7) I/O interface board.

The INT4 and INT5 (INT8) I/O interface boards feature high-speed operation capability using Fast Hybrid control outputs. To limit the false pickup indications with digital inputs and light duty high-speed auxiliary relays, precharging resistors are available on the screw terminal connector for each pair of control output contacts for INT5 boards. See [Fast Hybrid \(Fast High-Current-Interrupting\) Control Outputs on page U.2.9](#) for further information, and [Figure 2.11](#) and [Figure 2.12](#) for resistor connection details.

Alarm Output

The SEL-451 monitors internal processes and hardware in continual self-tests. If the relay senses an out-of-tolerance condition, the relay declares a Status Warning or a Status Failure. The relay signals a Status Warning by pulsing the HALARM Relay Word bit (hardware alarm) to a logical 1 for five seconds. For a Status Failure, the relay latches the HALARM Relay Word bit at logical 1.

To provide remote alarm status indication, connect the b contact of OUT108 to your control system remote alarm input. [Figure 2.43](#) shows the configuration of the a and b contacts of control output OUT108.

**Figure 2.43 Control Output OUT108**

Program OUT108 to respond to NOT HALARM by entering the following SELOGIC control equation with a communications terminal, with ACCELERATOR QuickSet:

OUT108 := NOT HALARM

When the relay is operating normally, the NOT HALARM signal is at logical 1 and the b contacts of control output OUT108 are open.

When a status warning condition occurs, the relay pulses the NOT HALARM signal to logical 0 and the b contacts of OUT108 close momentarily to indicate an alarm condition.

For a status failure, the relay disables all control outputs and the OUT108 b contacts close to trigger an alarm. Also, when relay power is off, the OUT108 b contacts close to generate a power-off alarm. See *Relay Self-Tests on page U.6.35* for information on relay self-tests.

The relay pulses the SALARM Relay Word bit for software programmed conditions; these conditions include settings changes, access level changes, and alarming after three unsuccessful password entry attempts.

The SEL-451 also pulses the BADPASS Relay Word bit after three unsuccessful password entry attempts.

You can add the software alarm SALARM to the alarm output by entering the following SELOGIC control equation:

OUT108 := NOT (HALARM OR SALARM)

Tripping and Closing Outputs

To assign the control outputs for tripping and closing, see *Setting Outputs for Tripping and Closing on page U.4.64*. In addition, you can use the **SET O** command (see *SET on page R.9.45* for more details). You can also use the front panel to set and verify operation of the outputs (see *Set/Show on page U.5.29*).

Auxiliary TRIP/CLOSE Pushbuttons and OPEN/CLOSED LEDs (select models only)

Select relay models feature auxiliary **TRIP** and **CLOSE** pushbuttons and **OPEN** and **CLOSED** LED indicators. These features are electrically isolated from the rest of the relay. They function independently from the relay and do not need relay power.

The pushbuttons and LEDs can be hard-wired into a substation trip and close control circuit and operate the same as a separate installation of external trip/close switches and LED indicators. *Figure 2.50* shows example trip and close circuit connections for a control scheme configuration with a dc substation voltage source. The pushbutton switches come set from the factory for dc operation (arc suppression enabled). To use an ac trip or close potential, the arc suppression must be disabled for one or both pushbuttons (see *Table 2.9*). The voltage operating ranges of the LEDs are selected by jumpers (see *Table 2.8*).

⚠️ WARNING

SEL-451 features such as Hot Line Tag and Synchronism Check do not supervise the auxiliary close pushbutton.

Since the trip and close buttons are functionally separate from the relay, a manual trip or close cannot be distinguished from an external protection or automation-initiated operation. Unless provisions are made in the control wiring, the action of the close pushbutton is unsupervised.

TIME Input Connections

IRIG-B Input Connection

NOTE: The position of the IRIG-B BNC connector changed when SEL-451 firmware version R104 was released. See [1k PPS Connection Not Required on page U.4.74](#) for details.

The SEL-451 accepts a demodulated IRIG-B signal through two types of rear-panel connectors. These **IRIG-B** inputs are through the BNC connector labeled **TIME IRIG-B** or through Pin 4 (+) and Pin 6 (-) of the rear-panel 9-pin D-subminiature connector **PORT 1** (see [Communications Ports Connections on page U.2.47](#) for other DB-9 connector pinouts and additional details).

These inputs accept the dc shift time code generator output (demodulated) IRIG-B signal with positive edge on the time mark. For more information on IRIG-B and the SEL-451, see [TIME Inputs on page U.2.11](#).

The **PORT 1 IRIG-B** input circuit connects to a $330\ \Omega$ resistor in series with an optocoupler input diode. The optocoupler input diode forward voltage drop is about 1.5 V. Driver circuits should source approximately 10 mA through the circuit for the ON state. When you are using the **PORT 1** input, ensure that you connect Pins 4 and 6 with the proper polarity.

Where distance between the SEL-451 and the IRIG-B sending device exceeds the cable length recommended for conventional EIA-232 metallic conductor cables, you can use transceivers to provide isolation and to establish communication to remote locations.

Conventional fiber-optic and telephone modems do not support IRIG-B signal transmission. Use the SEL-2810 transceiver to provide long distance delivery of the IRIG-B signal to the SEL-451. The SEL-2810 includes a channel for the IRIG-B time code. These transceivers enable you to synchronize time precisely from IRIG-B time code generators (such as the SEL-2032 Communications Processor) over a fiber-optic communications link.

Use the IRIG-B BNC connector for synchrophasor and high-accuracy timekeeping applications—see [Configuring High-Accuracy Timekeeping on page U.4.73](#). Make the connection using a $50\ \Omega$ coaxial cable assembly with a male BNC connector.

Obsolete TIME Input Connection

Previous SEL-451 relays had a **TIME 1k PPS** input BNC connector. When relay firmware version R104 was released, the rear-panel **TIME** inputs were reconfigured. If you have upgraded the firmware in a previous SEL-451, see [Using New SEL-451 Firmware in an Existing Relay on page U.4.75](#) for retrofit information.

The previous **1k PPS** BNC connector is the new **IRIG-B** connector. The previous **IRIG-B** BNC connector is not used. See [1k PPS Connection Not Required on page U.4.74](#) for details.

Replacing the Lithium Battery

ΔDANGER

Disconnect or de-energize all external connections before opening this device. Contact with hazardous voltages and currents inside this device can cause electrical shock resulting in injury or death.

ΔWARNING

Have only qualified personnel service this equipment. If you are not qualified to service this equipment, you can injure yourself or others, or cause equipment damage.

ΔCAUTION

Equipment components are sensitive to electrostatic discharge (ESD). Undetectable permanent damage can result if you do not use proper ESD procedures. Ground yourself, your work surface, and this equipment before removing any cover from this equipment. If your facility is not equipped to work with these components, contact SEL about returning this device and related SEL equipment for service.

ΔCAUTION

There is danger of explosion if the battery is incorrectly replaced. Replace only with Ray-O-Vac® no. BR2335 or equivalent recommended by manufacturer. Dispose of used batteries according to the manufacturer's instructions.

- Step 1. Follow your company standard procedure to remove a relay from service.
- Step 2. Disconnect power from the SEL-451.
- Step 3. Remove the relay from the rack or panel.
- Step 4. Retain the **GND** connection, if possible, and ground the equipment to an ESD mat.
- Step 5. Remove the communications cable connected to the front-panel serial port, if applicable.
- Step 6. Remove the rear-panel **EIA-232 PORTS** mating connectors.
- Step 7. Unscrew the keeper screws and disconnect any serial cables connected to the **PORT 1**, **PORT 2**, and **PORT 3** rear-panel receptacles.
- Step 8. Loosen the four front-panel screws (they remain attached to the front panel), and remove the relay front panel.
- Step 9. Remove the 34-pin ribbon cable from the front panel by pushing the extraction ears away from the connector.
- Step 10. Disconnect the power, the interface board, and the analog input board cables from the main board.
- Step 11. Pull out the drawout tray containing the main board.
- Step 12. Locate the lithium battery.

The lithium battery is at the front of the main board (see [Figure 2.22](#)).

- Step 13. Remove the spent battery from beneath the clip of the battery holder.
 - Step 14. Replace the battery with an exact replacement.
- Use a 3 V lithium coin cell, Ray-O-Vac® No. BR2335 or equivalent. The positive side (+) of the battery faces up.
- Step 15. Reinstall the SEL-451 main board, and reconnect the power, the interface board, and the analog input board cables.
 - Step 16. Reconnect the cable removed in [Step 9](#) and reinstall the relay front-panel cover.
 - Step 17. Reconnect any serial cables that you removed from the **EIA-232 PORTS** in the disassembly process.

Step 18. Set the relay date and time via the communications ports or front panel (see [Making Simple Settings Changes on page U.4.14](#)).

Step 19. Follow your company standard procedure to return the relay to service.

Communications Ports Connections

The SEL-451 has three rear-panel EIA-232 serial communications ports labeled **PORT 1**, **PORT 2**, and **PORT 3** and one front-panel port, **PORT F**. For information on serial communications, see [Establishing Communication on page U.4.4](#), [Serial Communication on page R.4.2](#), and [Serial Port Hardware Protocol on page R.5.1](#).

In addition, the rear panel features a **PORT 5** for an optional communications card. For additional information about communications topologies and standard protocols that are available in the SEL-451, see [Network Connections on page U.2.48](#), [Section 6: SEL Communications Processor Applications in the Applications Handbook](#), [Section 7: Direct Network Communications in the Applications Handbook](#), [Section 6: DNP3 Communications in the Reference Manual](#), and [Section 8: IEC 61850 Communications in the Reference Manual](#).

Serial Ports

The SEL-451 serial communications ports use EIA-232 standard signal levels in a D-subminiature 9-pin connector. To establish communication between the relay and a DTE device (a computer terminal, for example) with a D-subminiature 9-pin connector, use an SEL Cable C234A (see [Making an EIA-232 Serial Port Connection on page U.4.5](#)).

Figure 2.44 shows the configuration of SEL Cable C234A that you can use for basic ASCII and binary communication with the relay. A properly configured ASCII terminal, terminal emulation program, or ACCELERATOR QuickSet along with the C234A cable provide communication with the relay in most cases. See [Section 4: Communications Interfaces in the Reference Manual](#) for a list of hardware interfaces to the SEL-451.

SEL-451 Relay		9-Pin DTE Device*	
Pin Func.	Pin #	Pin #	Pin Func.
RXD	2	3	TXD
TXD	3	2	RXD
GND	5	5	GND
CTS	8	8	CTS
		7	RTS
		1	DCD
		4	DTR
		6	DSR

*DTE = Data Terminal Equipment (Computer, Terminal, etc.)

Figure 2.44 SEL-451 to Computer-D-Subminiature 9-Pin Connector

Serial Cables

CAUTION

Severe power and ground problems can occur on the communications ports of this equipment as a result of using non-SEL cables. Never use standard null-modem cables with this equipment.

Using an improper cable can cause numerous problems or failure to operate, so you must be sure to specify the proper cable for application of your SEL-451. Several standard SEL communications cables are available for use with the relay. See [EIA-232 Communications Cables on page R.4.4](#) for information on recommended serial cables.

The following list provides additional rules and practices you should follow for successful communication using EIA-232 serial communications devices and cables:

- Route communications cables well away from power and control circuits. Switching spikes and surges in power and control circuits can cause noise in the communications circuits if power and control circuits are not adequately separated from communications cables.
- Keep the length of the communications cables as short as possible to minimize communications circuit interference and also to minimize the magnitude of hazardous ground potential differences that can develop during abnormal power system conditions.
- Ensure that EIA-232 communications cable lengths never exceed 50 feet, and always use shielded cables for communications circuit lengths greater than 10 feet.
- Modems provide communication over long distances and give isolation from ground potential differences that are present between device locations (examples are the SEL-28XX-series transceivers).
- Lower data speed communication is less susceptible to interference and will transmit greater distances over the same medium than higher data speeds. Use the lowest data speed that provides an adequate data transfer rate.

Network Connections

The optional Ethernet card for the SEL-451 can use either the connection on Port A or Port B to operate on a network. These ports work together to provide a primary and backup interface, as described in [Network Port Fail-Over Operation on page R.4.6](#). The following list describes the Ethernet card port options.

- 10/100BASE-T. 10 Mbps or 100 Mbps communications using CAT 5 cable (category 5 twisted-pair) and an RJ-45 connector
- 100BASE-FX. 100 Mbps communications over multimode fiber-optic cable using an ST connector




Figure 2.45 Example Ethernet Panel With Fiber-Optic Ports

Ethernet Card Rear-Panel Layout

Rear-panel layouts for the three Ethernet card port configurations are shown in [Figure 2.46](#)–[Figure 2.48](#).

CAUTION

Use of controls or adjustments, or performance of procedures other than those specified herein, may result in hazardous radiation exposure.

WARNING

Do not look into the fiber (laser) ports/connectors.

WARNING

Do not look into the end of an optical cable connected to an optical output.

WARNING

Do not perform any procedures or adjustments that this instruction manual does not describe.

WARNING

During installation, maintenance, or testing of the optical ports, use only test equipment qualified for Class 1 laser products.

WARNING

Incorporated components, such as LEDs, transceivers, and laser emitters, are not user serviceable. Return units to SEL for repair or replacement.




Figure 2.46 Two 10/100BASE-T Port Configuration




Figure 2.47 100BASE-FX and 10/100BASE-T Port Configuration




Figure 2.48 Two 100BASE-FX Port Configuration

Twisted-Pair Networks

NOTE: Use caution with UTP cables as these cables do not provide adequate immunity to interference in electrically noisy environments unless additional shielding measures are employed.

NOTE: Many computers and most newer Ethernet switches support autocrossover, so nearly any Cat 5 Ethernet cable with RJ45 connectors, such as an SEL-C627 cable, will work. When the computer does not support autocrossover, use a crossover cable between the computer and relay, such as an SEL-C628 cable. For fiber-optic Ethernet ports, use an SEL-C808 cable (62.5 µm fiber-optic cable with LC connectors).

While Unshielded Twisted Pair (UTP) cables dominate office Ethernet networks, Shielded Twisted Pair (STP) cables are often used in industrial applications. The SEL-451 Ethernet card is compatible with standard UTP cables for Ethernet networks as well as STP cables for Ethernet networks.

Typically UTP cables are installed in relatively low-noise environments including offices, homes, and schools. Where noise levels are high, you must either use STP cable or shield UTP using grounded ferrous raceways such as steel conduit.

Several types of STP bulk cable and patch cables are available for use in Ethernet networks. If noise in your environment is severe, you should consider using fiber-optic cables. We strongly advise against using twisted-pair cables for segments that leave or enter the control house.

If you use twisted-pair cables, you should use care to isolate these cables from sources of noise to the maximum extent possible. Do not install twisted-pair cables in trenches, raceways, or wireways with unshielded power, instrumentation, or control cables. Do not install twisted-pair cables in parallel with power, instrumentation, or control wiring within panels, rather make them perpendicular to the other wiring.

You must use a cable and connector rated as Category 5 (CAT 5) to operate the twisted-pair interface (10/100BASE-T) at 100 Mbps. Because lower categories are becoming rare and because you may upgrade a 10 Mbps network to 100 Mbps, we recommend using all CAT 5 components.

Some industrial Ethernet network devices use 9-pin connectors for STP cables. The Ethernet card RJ-45 connectors are grounded so you can ground the shielded cable using a standard, externally shielded jack with cables terminating at the Ethernet card.

AC/DC Connection Diagrams

You can apply the SEL-451 in many power system protection schemes. *Figure 2.49* shows one particular application scheme with connections that represent typical interfaces to the relay for a single circuit breaker connection. *Figure 2.50* depicts typical connections for a dual circuit breaker protection scheme.




Figure 2.49 Typical External AC/DC Connections—Single Circuit Breaker

U.2.52 | Installation
AC/DC Connection Diagrams




Figure 2.50 Typical External AC/DC Connections—Dual Circuit Breaker




Figure 2.51 SEL-451 Example Wiring Diagram Using the Auxiliary TRIP/CLOSE Pushbuttons

This page intentionally left blank

Section 3

PC Software

This section provides information on the following topics:

- [*Installing the Computer Software on page U.3.2*](#)
- [*Communications Setup on page U.3.4*](#)
- [*Settings Database Management and Drivers on page U.3.6*](#)
- [*Create and Manage Relay Settings on page U.3.10*](#)
- [*Expression Builder on page U.3.15*](#)
- [*Analyze Events on page U.3.16*](#)
- [*HMI Meter and Control on page U.3.21*](#)

The SEL-451 Relay includes ACSELERATOR QuickSet® SEL-5030 software, a powerful relay settings, analysis, and measurement tool to aid you in applying and using the relay. ACSELERATOR QuickSet reduces engineering costs for relay settings, logic programming, and system analysis.

ACSELERATOR QuickSet also makes it easier for you to do the following:

- Create and Manage Relay Settings
 - Create settings for one or more SEL-451 relays
 - Store and retrieve settings with an IBM-compatible personal computer (PC)
 - Upload and download relay settings files to and from SEL-451 relays
- Analyze Events
 - Use the integrated waveform and harmonic analysis tools
- Monitor real-time and relay-stored power system data
 - Use the human machine interface (HMI) to view metering, Relay Word bits, and circuit breaker monitor data
- Control the relay
 - Command relay operation through use of a graphical user interface (GUI) environment
 - Execute relay serial port commands in terminal mode
- Configure the serial port and passwords

SEL provides ACSELERATOR QuickSet for easier, more efficient configuration of relay settings, metering, and control. ACSELERATOR QuickSet gives you the advantages of rules-based settings checks, SELOGIC® control equation Expression Builder, operator control and metering HMI, and event analysis.

However, you do not have to use ACCELERATOR QuickSet to configure the SEL-451; you can continue to use an ASCII terminal or a computer running terminal emulation software to access all relay settings and metering.

Installing the Computer Software

Load ACCELERATOR QuickSet on an IBM-compatible PC. If you encounter any difficulties installing ACCELERATOR QuickSet, contact your Technical Service Center or the SEL factory for assistance. See *Technical Support on page U.6.41* for contact information.

System Requirements

To successfully install and use ACCELERATOR QuickSet, your PC must have the minimum resources listed in *Table 3.1*.

Table 3.1 System Requirements for ACCELERATOR QuickSet

Item	Description
Processor	Pentium® class, ≥ 90 MHz
Operating System / RAM	Microsoft® Windows® 98/ME/XP—64 MB RAM Microsoft Windows 2000—64 MB RAM Microsoft Windows NT®—32 MB RAM (64 MB recommended)
Hard drive	At least 100 MB available storage space
Communications Port	One EIA-232 serial port or one Ethernet port
Drives	CD-ROM for software installation
Monitor	SVGA 800 x 600 pixel resolution or greater (1024 x 768 pixel resolution recommended)
Pointing Device	Mouse or other pointing device

Installation

You can load ACCELERATOR QuickSet automatically if your computer autorun feature is enabled; this is Method A.

If autorun is not enabled on your computer, use the Windows **Run** command to load ACCELERATOR QuickSet; this is Method B.

Method A

Load ACCELERATOR QuickSet automatically:

- Step 1. Turn on your PC and run the Windows operating environment.
- Step 2. Close all other applications on your PC.
- Step 3. Place the ACCELERATOR QuickSet CD-ROM in the PC CD-ROM drive.

The setup software runs automatically and the **SEL Software License Agreement** appears, as in *Figure 3.1*.



Figure 3.1 SEL Software License Agreement (Sample)

Method B

Load ACSELERATOR QuickSet with the Windows **Run** Command:

- Step 1. If the **Setup** program does not start automatically, click **Start > Run** to load ACSELERATOR QuickSet.
- Step 2. Type the command shown in [Figure 3.2](#), being certain to use the correct drive letter for the CD-ROM drive in your PC (the CD-ROM drive in the [Figure 3.2](#) example is drive **D:**).
- Step 3. The SEL **Software License Agreement** appears ([Figure 3.1](#)).



Figure 3.2 Windows Run Command Line to Load ACSELERATOR QuickSet

- Step 4. Complete the software loading process.
- Step 5. Read the **Software License Agreement** and follow the loading instructions as these instructions appear on the PC screen.

Starting ACSELERATOR QuickSet

You can use the Windows **Start** menu to open ACSELERATOR QuickSet:

- Step 1. If you installed ACSELERATOR QuickSet to the **Program Manager** group, click **Start > Programs**.
- Step 2. Click **SEL Applications > ACSELERATOR QuickSet**.
- Step 3. If you used a custom program group, click **Start** and click ACSELERATOR QuickSet in the custom group.

You can also create a shortcut on the Windows Desktop (see your Windows documentation for instructions on creating a shortcut). Double-click the shortcut icon to start ACSELERATOR QuickSet from the shortcut.

Communications Setup

ACSELERATOR QuickSet uses the relay communications ports to communicate with the SEL-451. Configure the ACSELERATOR QuickSet **Communication Parameters** menu settings to communicate effectively with the relay.

You can also use a basic terminal emulation window any time you run ACSELERATOR QuickSet. Use the **Communication** menu to view and clear a **Connection Log**. For a step-by-step procedure using ACSELERATOR QuickSet to communicate with the relay, see *Checking Relay Status: ACSELERATOR QuickSet on page U.4.11*.

Communication Parameters

Use the **Communication Parameters** dialog box to configure relay communications settings. Select the **Communication > Parameters** from the top ACSELERATOR QuickSet toolbar to open this dialog box.

Figure 3.3 shows the ACSELERATOR QuickSet **Communication Parameters** dialog box.




Figure 3.3 ACSELERATOR QuickSet Communication Parameters Dialog Box

Serial Setup

You can use serial communication via **PORT 1**, **PORT 2**, **PORT 3**, and **PORT F** (front panel). *Figure 3.3* shows the default serial port parameters (**9600, 8, N, 1**). Enter your relay **Level One** and **Level Two** passwords in the respective text boxes. (For complete information on passwords, see *Changing the Default Passwords: Terminal on page U.4.9*.)

If you choose a device from the **Device** text box that is a telephone modem, enter the dial-up telephone number in the **Phone Number** text box.

FTP Setup

Click the **Use Network** check box to access the **Network Parameters**. *Figure 3.4* shows the **Network Parameters** dialog box. For **FTP** (File Transfer Protocol) use **Telnet Port number 23**.




Figure 3.4 AcSELERATOR QuickSet Network Parameters Dialog Box: FTP

When you connect to a relay to use FTP, you must specify the access level and password.

Enter the access level command (ACC, 2AC, for example) in the **User ID** text box and the corresponding access level password in the **Password** text box to control the relay at a specific access level (see [Changing the Default Passwords: Terminal on page U.4.9](#)).

Telnet Setup

Click the **Telnet** option button in the **Network Parameters** dialog box (see [Figure 3.5](#)) to connect to a relay for a **Telnet** session. The **Telnet** session uses the relay passwords in the **Communication Parameters** dialog box ([Figure 3.3](#)).

The default **Telnet Port Number** for accessing the relay is **T1PNUM := 23**. The default **Telnet Port Number** for communicating directly with an installed Ethernet card is **T2PNUM := 1024**.

See [Section 7: Direct Network Communications in the Applications Handbook](#) for information on changing the **Telnet Port Number**.




Figure 3.5 AcSELERATOR QuickSet Network Parameters Dialog Box: Telnet

Terminal Mode

The terminal emulation window is an ASCII interface between you and the relay. This is a basic terminal emulation with no file transfer capabilities. Many third-party terminal emulation programs are available with file transfer encoding schemes.

Click **Communication > Terminal** to start the terminal emulation window. Another convenient method to start the terminal is to type **<Ctrl+T>**.

Terminal Logging

When you check the **Terminal Logging** item in the **Communication** menu, ACSELERATOR QuickSet records communications events and errors in a log.

Click **Communication > Connection Log** to view the log.

Clear the log by selecting **Communication > Clear Connection Log**.

Settings Database Management and Drivers

Database Manager

ACSELERATOR QuickSet uses a relay database to save relay settings.

ACSELERATOR QuickSet contains sets of all settings files for each relay that you specify in the **Database Manager**. See [Virtual File Interface on page R.5.11](#) for a list of the settings files in the SEL-451.

Choose appropriate storage backup methods and a secure location for storing your relay database files. Use the **File > Active Database** menu to retrieve a relay database from computer memory.

Relay Database

The default relay database file already configured in ACSELERATOR QuickSet is **Relay.rdb**. This database may contain example settings files for the SEL products with which you can use ACSELERATOR QuickSet.

Perform the following steps to access and/or modify the database:

Step 1. Open the **Database Manager**.

- Click **File > Database Manager** in the ACSELERATOR QuickSet top toolbar.

A dialog box similar to [Figure 3.6](#) appears.




Figure 3.6 Database Manager Relay Database in ACSELERATOR QuickSet

- Step 2. Enter descriptions for the database and for each relay in the database in the **Database Description** and **Relay Description** dialog boxes.

Type in the **Relay Description** dialog box special operating characteristics that describe the relay settings. These can include the protection scheme settings and communications settings.

Perform the following steps to create a new collection of relay settings:

- Step 1. Highlight one of the relays listed in **Relays in Database** and click **Copy**.

ACSELERATOR QuickSet prompts you to provide a new name.

- Step 2. Enter a new description in **Relay Description**.

Copy/Move Relays Between Databases

You can create multiple relay databases with the **Database Manager**; these databases are useful for grouping similar protection schemes or geographic areas.

Perform the following steps to copy or move a relay between databases:

- Step 1. Select the **Copy / Move Relays Between Databases** tab to access the dialog box shown in [Figure 3.7](#).

- Step 2. Click **Open B** to open a relay database.

- Step 3. Select or type a filename and click **Open**; for example, **Relay2.rdb** is the B relay database in [Figure 3.7](#).

- Step 4. Highlight a relay in the **Database A** list, select **Copy** or **Move**, and click the > button to create a new relay in **Database B**.

➢ **Copy** creates an identical relay that appears in both databases.

➢ **Move** removes the relay from one database and places the relay in another database.

- Step 5. Reverse this process to copy or move relays from **Database B** to **Database A**.




Figure 3.7 Database Manager Copy/Move in ACSELERATOR QuickSet

Create a New Database

Perform the following steps to create and copy an existing database of relays to a new database:

- Step 1. Select the **File > Database Manager** to access the **Database Manager** dialog box.
- Step 2. Select the **Copy / Move Relays Between Databases** tab in the **Database Manager** dialog box.
ACSELERATOR QuickSet opens the last active database and assigns it as **Database A** (see [Figure 3.7](#)).
- Step 3. Click the **Open B** button.
ACSELERATOR QuickSet prompts you for a file location.
- Step 4. Type a new database name, click the **Open** button, and answer **Yes**.
The program creates a new empty database.
- Step 5. Load relays into the new database as in [Copy/Move Relays Between Databases on page U.3.7](#).

Drivers

Relay settings folders in ACSELERATOR QuickSet are closely associated with the ACSELERATOR QuickSet relay driver that you used to create the settings. The relay settings and the ACSELERATOR QuickSet drivers must match.

Perform the following steps to ensure that the relay settings and ACSELERATOR QuickSet drivers match:

- Step 1. Use any of the following methods to view the relay FID information:
 - Enter the **STATUS** command.
 - Click the **Status** button in the HMI tree view. See [Checking Relay Status on page U.4.10](#) for more information on viewing relay status.
 - At a terminal (<Ctrl+T> from ACSELERATOR QuickSet), type **ID <Enter>**.

Step 2. View the ACSELERATOR QuickSet settings driver information at the bottom of the **Relay Editor** window (see [Figure 3.14](#)).

Step 3. Compare the ACSELERATOR QuickSet driver number and the relay FID number. The ACSELERATOR QuickSet driver Z-number and the corresponding part of the relay FID must match.

The first portion of the Z-number is the ACSELERATOR QuickSet settings driver version number (see [Figure 3.8](#)).




Figure 3.8 AcSELERATOR QuickSet Driver Information in the FID String

ACSELERATOR QuickSet reads the latter portion of the Z-number (ZXXX001, for example) to determine the correct HMI to display when you select the **HMI Meter and Control** menu. View the bottom of the HMI window to check the HMI driver number (see [Figure 3.9](#)).




Figure 3.9 HMI Driver Version Number in the HMI Window

As SEL develops new drivers, you can update your existing ACSELERATOR QuickSet software with specific relay drivers for each SEL product that uses ACSELERATOR QuickSet. Contact your local Technical Service Center or the SEL factory for the latest ACSELERATOR QuickSet drivers.

Create and Manage Relay Settings

ACSELERATOR QuickSet gives you the ability to create settings for one or more SEL-451 relays. You can store existing relay settings downloaded from SEL-451 relays with ACSELERATOR QuickSet, creating a library of relay settings (see [Database Manager on page U.3.6](#)). You can then modify and upload these settings from your settings library to an SEL-451.

ACSELERATOR QuickSet makes setting the relay easy and efficient. For an example of setting the SEL-451 with ACSELERATOR QuickSet, see [Making Initial Global Settings: ACSELERATOR QuickSet on page U.4.26](#).

Collected Settings

ACSELERATOR QuickSet arranges relay settings in easy-to-understand categories (for an explanation of settings organization, see [Making Simple Settings Changes on page U.4.14](#)). These categories of collected settings help you quickly set the relay.

[Figure 3.10](#) is an example of relay settings categories in the **Relay Editor Settings** tree view. (Use the procedures described in [Settings Menu on page U.3.11](#) to view the tree views in [Figure 3.10](#).)

ACSELERATOR QuickSet shows all of the settings categories in the settings tree view. When you enable and disable settings categories, the tree view remains constant, but when you click the tree view to access the settings in a disabled category, the disabled settings are dimmed.

For example, select the **Group 1 > Set 1 > Relay Configuration > Negative-Seq Inst O/C** branch of the **Settings** tree view and choose **N** for **E50Q**.

Observe that the **Negative-Sequence Overcurrent Elements** settings are dim.

If you select **1** for **E50Q**, then only the level 1 overcurrent element settings are active and the remainder of the **Negative-Sequence Overcurrent Element** settings are dim.

[Figure 3.10](#) illustrates this feature of ACSELERATOR QuickSet.




Figure 3.10 Sample Settings in ACSELERATOR QuickSet

Settings Menu

The **Settings** menu on the top ACSELERATOR QuickSet toolbar is the starting point for all settings entries. The menu items on the **Settings** menu are **New**, **Open**, **Read**, and **Convert**. All of these menu items open the **Relay Editor** (see [Relay Editor on page U.3.12](#)).

New

Selecting the **New** menu item creates new relay settings files. ACSELERATOR QuickSet makes the new settings files from the relay drivers that you specify in the **Settings Editor Selection** dialog box (see [Figure 3.11](#)).

ACSELERATOR QuickSet uses the Z-number in the relay FID string to create a particular version of relay settings (see [Drivers on page U.3.8](#)).




Figure 3.11 Selecting a Settings Driver in ACSELERATOR QuickSet

After selecting the relay model and settings driver, ACSELERATOR QuickSet presents the **Relay Part Number** dialog box. Use this dialog box to configure the **Relay Editor** to produce settings for a relay with options determined by the part number (see [Relay Part Number on page U.3.14](#)).

Open

The **Open** menu item opens an existing relay from the active database folder (see [Figure 3.12](#)). ACSELERATOR QuickSet prompts you for a folder containing relay settings to load into the **Relay Editor**.




Figure 3.12 Opening Relay Settings in ACSELERATOR QuickSet

Read

When you select the **Read** menu item, ACSELERATOR QuickSet reads the relay settings from a connected relay. As ACSELERATOR QuickSet reads the relay, and a dialog box similar to [Figure 3.13](#) appears.

ACSELERATOR QuickSet uses serial protocols at a serial port or FTP from an Ethernet port to read settings from SEL devices.



Figure 3.13 Reading Relay Settings in ACSELERATOR QuickSet

Convert

Use the **Convert** menu item to convert from one settings version to another. Typically this utility is used to upgrade an existing settings file to a newer version because the relays are using a newer version number. ACSELERATOR QuickSet provides a **Convert Settings** report that shows missed, changed, and invalid settings created as a result of the conversion. Review this report to determine whether changes are required.

Relay Editor

Use the **Relay Editor** to enter relay settings. [Figure 3.14](#) illustrates the important features of the editor. These features include the ACSELERATOR QuickSet settings driver version number (the first three digits of the Z-number) in the lower left corner of the **Relay Editor**.




Figure 3.14 ACSELERATOR QuickSet Relay Editor

Entering Settings

Click the + marks and the buttons in the **Settings Tree View** to expand and select the settings class, instance, and category that you want to change.

Use **<Tab>** or click in a dialog box to edit a setting.

The right-click mouse button performs two special functions when you are editing settings: **Previous Value** and **Default Value**. To restore the previous value for a setting, right-click the setting and select **Previous Value**. Right-click the setting dialog box and select **Default Value** if you want to restore the factory default setting value.

If you enter a setting that is out of range or has an error, ACSELERATOR QuickSet shows the error at the bottom of the **Relay Editor**. Double-click the error listing to go to the setting to enter a valid input.

Relay Part Number

The relay part number determines the settings that ACCELERATOR QuickSet displays and the functions that the software controls. When configuring ACCELERATOR QuickSet to control a particular relay, you should confirm that the ACCELERATOR QuickSet part number matches the relay part number so that you can access all of the settings you need for your relay.

Configuring the Part Number

Perform the following steps to configure the part number:

- Step 1. Select the **Settings** menu on the ACCELERATOR QuickSet top toolbar and click **New**, **Open**, **Read**, or **Convert** to start the **Relay Editor** (see [Settings Menu on page U.3.11](#)).
- Step 2. Once in the **Relay Editor**, click the **Options** menu on the **Relay Editor** toolbar.
- Step 3. Click **Part Number**.

The **Relay Part Number** dialog box appears, as shown in [Figure 3.15](#).

- Step 4. Use the arrows inside the text boxes to match corresponding portions of the **Relay Part Number** dialog box to your relay.




Figure 3.15 Setting the Relay Part Number in ACCELERATOR QuickSet

Expression Builder

SELOGIC control equations are a powerful means for customizing relay performance. Creating these equations can be difficult because of the large number of relay elements (Relay Word bits) and analog quantities in the relay.

ACSELERATOR QuickSet simplifies this process with the **Expression Builder**, a rules-based editor for programming SELOGIC control equations. The **Expression Builder** organizes relay elements, analog quantities, and SELOGIC control equation variables and focuses your equation decision-making. The **Expression Builder** checks basic rules and flags mistakes in SELOGIC control equation settings.

Access the Expression Builder

Settings dialog boxes (see [Figure 3.16](#)) in the **Relay Editor** window show the following (ellipsis) button:



Click this button of a SELOGIC equation to use the Expression Builder.



Figure 3.16 Location of Expression Builder Button

Expression Builder Organization

The **Expression Builder** dialog box is organized into two main parts representing the left side (LVALUE) and right side (RVALUE) of the SELOGIC control equation. (The LVALUE is fixed for all settings except Protection Free-Form SELOGIC and Automation Free Form SELOGIC settings; see [Fixed SELOGIC Control Equations on page R.3.4](#).)

[Figure 3.17](#) shows the two sides of the **Expression Builder**, with the SELOGIC control equation that you are constructing at the top of the dialog box. Note the dark vertical line and the equals sign (:=) separating the equation left and right sides.




Figure 3.17 The ACSELERATOR QuickSet Expression Builder

Using the Expression Builder

For Protection Free-Form SELOGIC and Automation Free Form SELOGIC, select the type of result (LVALUE) for the SELOGIC control equation to use the **Expression Builder**. ACSELERATOR QuickSet shows these possibilities in the file box directly underneath the left side of the equation. The program shows the relay elements for each type of SELOGIC control equation (Boolean Variables, Math Variables, etc.).

On the right side of the equation (RVALUE), you can select broad categories of relay elements, analog quantities, counters, timers, latches, Boolean variables, and math variables. Select a category in the RVALUE tree view, and the **Expression Builder** displays all elements for that category in the list box at the bottom right side.

Directly underneath the right side of the equation, you can choose operations to include in the RVALUE. These operations include basic logic functions, rising and falling edge triggers, expression compares, and math functions.

For more information on programming SELOGIC control equations, see [Section 3: SELOGIC Control Equations in the Reference Manual](#).

Analyze Events

ACSELERATOR QuickSet has integrated analysis tools that help you retrieve information about protection system operations quickly and easily. Use the protection system event information that the SEL-451 stores to evaluate the performance of a protection system.

Event Waveforms

The SEL-451 records power system events for all trip situations and for other operating conditions that you program with SELOGIC control equations (see [SELOGIC Control Equation ER on page A.3.4](#)).

The relay provides two types of event data captures: high-resolution oscillography that uses raw sample per second data and event report oscillography that uses filtered sample per cycle data. See [Triggering Data Captures and Event Reports on page A.3.4](#) and [Generating an Event on page U.4.43](#) for information on recording events.

Use ACSELERATOR QuickSet to view high resolution and event report oscillograms, phasor diagrams, harmonic analyses, and settings.

Read History

You can retrieve event files stored in the relay and transfer these files to your PC. For information on the types of event files and data capture, see [Triggering Data Captures and Event Reports on page A.3.4](#).

To download event files from the relay, open the ACCELERATOR QuickSet **Analysis** menu at the top ACCELERATOR QuickSet toolbar and click **View Event History**. The **Event History** dialog box appears ([Figure 3.18](#)).




Figure 3.18 Retrieving Relay Event History

Get Event

Perform the following steps to view events:

- Step 1. Highlight the event you want to view and click the **Get Selected Event** button.

The **Event Type** dialog box lists high resolution data files as Binary COMTRADE, and event report files (from Compressed ASCII format) as CEV 4 samples/cyc or CEV 8 samples/cyc.

- Step 2. When downloading is complete, ACCELERATOR QuickSet asks whether you want to save the file on your PC.
- Step 3. Once the file is saved, select the **Analysis** menu and click **View Event Files**.

Open the event file you want to see.

NOTE: If your PC is loaded with SEL-5601 Analytic Assistant software (purchased separately), ACSELERATOR QuickSet automatically uses SEL-5601 to provide event analysis functionality. Some of the screen captures and related information may differ from the examples shown in this manual.

- Step 4. ACSELERATOR QuickSet displays the **Event Waveform** dialog box and the event oscilloscope (see *Figure 3.19* and *Figure 3.20*).

You can see high-accuracy time-stamp information on the event oscilloscope.

When viewing the event oscilloscope, use keyboard function keys to measure the time of oscilloscope occurrences. These function keys and related functions help in event analysis

<F2>: go to trigger

<F3>: Cursor 1

<F4>: Cursor 2

The display shows the time difference between the <F3> and <F4> cursors.

- Step 5. Click the **Pref** button at the bottom of the oscilloscope and select **Time** (under **Time Units, Starting/Ending Row**).

- Step 6. Click **OK**.

- Step 7. Click on any point in a graph to observe the **Event Time** in microseconds of that data point at the bottom of the oscilloscope.



Figure 3.19 AcSELERATOR QuickSet Event Waveform Window




Figure 3.20 Sample Event Oscilloscope

You can also view other event displays:

- Step 8. From the **Event Waveform** dialog box, select the **View** menu.

NOTE: The Phasors display is designed for 4- or 8-sample per cycle event reports. A warning message is displayed if you are viewing a COMTRADE file that cannot be properly represented in the phasor display.

Step 9. Click **Phasors**, as shown in *Figure 3.21*, to view a sample-by-sample phasor display.

A phasor display similar to *Figure 3.22* appears.




Figure 3.21 Retrieving Event Report Waveforms




Figure 3.22 Sample Phasors Event Waveform Screen

ACCELERATOR QuickSet also presents a harmonic analysis of power system data for raw data binary COMTRADE event captures (see *Get Event on page U.3.17*).

Step 1. From the **Event Waveform View** menu, click **Harmonic Analysis**.

A window similar to *Figure 3.23* appears. The data used in *Figure 3.23* is unrelated to *Figure 3.22*.




Figure 3.23 Sample Harmonic Analysis Event Waveform Screen

- Step 2. On the left side of the **Harmonic Analysis** screen, choose the relay voltage and current channels to monitor for harmonic content.
- You can view both a spectral analysis plot and a harmonic analysis bar chart.
- Step 3. Click the arrows of the **Data Scroll** box or the **# Cycles** box to change the data analysis range.
- Step 4. Click **Summary Data** on the **Event Waveform View** menu to see event summary information and to confirm that you are viewing the correct event.

Figure 3.24 shows a sample ACSELERATOR QuickSet **Event Report Summary** screen.




Figure 3.24 Sample Event Report Summary Screen

- Step 5. Click **Settings** on the **Event Waveform View** menu to view the relay settings that were active at the time of the event.

Figure 3.25 shows a sample CEV-type event **Settings** screen.




Figure 3.25 Sample Event Waveform Settings Screen

Open File

Computer-stored data captures are available as COMTRADE files (*.DAT) or compressed event report files (*.CEV).

Perform the following steps to open these files:

Step 1. Open the ACSELERATOR QuickSet Analysis menu and click **View Event Files** to view the waveforms in an event file stored on your computer.

The **Event Waveform** dialog box (similar to [Figure 3.19](#)) and an oscillographic event screen (similar to [Figure 3.20](#)) appear.

Step 2. At the **Event Waveform** dialog box, you can select the **Summary Data** display, the **Graph** display, **Graph Preferences**, the **Phasors** display, the **Harmonic Analysis** display, and the **Settings** display from the **Event Waveform** window (see [Read History on page U.3.17](#)).

HMI Meter and Control

Use the ACSELERATOR QuickSet HMI feature to view real-time relay information in a graphical format. Use the virtual relay front panel to read metering and targets and to operate the relay.

Open the ACSELERATOR QuickSet HMI

On the HMI menu, click **Meter and Control**.

ACSELERATOR QuickSet opens the HMI window and downloads the interface data. See the detailed examples in [View Metering: ACSELERATOR QuickSet on page U.4.38](#) for step-by-step instructions.

ACSELERATOR QuickSet HMI Features

You can use ACSELERATOR QuickSet to access many types of relay information and relay controls.

- Step 1. Click the HMI menu at the top ACSELERATOR QuickSet toolbar and then click **Meter and Control** to access the ACSELERATOR QuickSet HMI.

Figure 3.26 shows the HMI tree view.

Table 3.2 lists the functions in the HMI tree view and a brief explanation of each function.

In the ACSELERATOR QuickSet HMI, an LED representation shows that a color is asserted or “on.”

The flashing LED representation in the lower left of each HMI screen indicates an active data update via the communications channel.

- Step 2. Click the button marked **Disable Update** to suspend HMI use of the communications channel.




Figure 3.26 ACSELERATOR QuickSet HMI Features

Table 3.2 ACSELERATOR QuickSet HMI Tree View Functions

Function	Description
Device Overview	View general metering, selected targets, control input, control outputs, and the virtual front panel.
Phasors	A graphical and textual representation of phase and sequence voltage and current phasors.
Instantaneous	A table of instantaneous voltages, currents, powers, frequency, and dc monitor voltages.
Synchrophasor	A table showing synchrophasor data, if enabled.
Demand/Peak	A table showing demand and peak demand values. Reset buttons are in this display.
Max/Min	A table showing maximum/minimum metering quantities. A reset button is in this display.
Energy	A table showing energy import/export. A reset button is in this display.
Targets	View selected Relay Word bits in a row/column format.
Status	A list of relay status conditions.
SER	Sequential Events Recorder data listed oldest to newest, top to bottom. Set the range of SER records with the dialog boxes at the bottom of the display.
Breaker Monitor Data	A table showing the latest circuit breaker monitor data.
Control Window	Metering and records reset buttons, trip and close control, output pulsing, target reset, time and date set, group switch, and remote bit control.

Section 4

Basic Relay Operations

The SEL-451 Relay is a powerful tool for power system protection and control. Understanding basic relay operation principles and methods will help you use the relay effectively. This section presents the fundamental knowledge you need to operate the SEL-451, organized by task. These tasks help you become familiar with the relay and include the following:

- *Inspecting a New Relay on page U.4.1*
- *Connecting and Applying Power on page U.4.3*
- *Establishing Communication on page U.4.4*
- *Changing the Default Passwords on page U.4.6*
- *Checking Relay Status on page U.4.10*
- *Making Simple Settings Changes on page U.4.14*
- *Examining Metering Quantities on page U.4.34*
- *Reading Oscillograms, Event Reports, and SER on page U.4.43*
- *Operating the Relay Inputs and Outputs on page U.4.58*
- *Configuring High-Accuracy Timekeeping on page U.4.73*
- *Readyng the Relay for Field Application on page U.4.81*

Perform these tasks to gain a good understanding of relay operation, be able to confirm that the relay is properly connected, and be more effective when using the relay.

Inspecting a New Relay

CAUTION

Do not connect power to the relay until you have completed these procedures and receive instruction to apply power. Equipment damage can result otherwise.

The following items are included in your shipment from SEL:

- SEL-451 Relay
- Printed volume of the entire SEL-451 User's Guide
- CD-ROM containing the electronic version of the entire SEL-451 Relay Manual and the Customer Label Templates
- CD-ROM containing the ACCELERATOR QuickSet® SEL-5030 Software program
- Configurable Front-Panel Label Kit
- SEL Contact Card

If any item is missing or damaged, please contact your distributor or SEL immediately.

Initial Inspection

Perform the following initial inspection when the relay arrives:

- Step 1. Remove the protective wrapping from the SEL-451.
- Step 2. Observe the outside of the front cover and the rear panel.
- Step 3. Check that no significant scratches or dents are evident on any outer surface.
- Step 4. Confirm that all terminal strips on the rear panel are secure.

Cleaning

Perform the following steps and use care when cleaning the SEL-451:

- Step 1. Use a mild soap or detergent solution and a damp cloth to clean the relay chassis.

Be careful cleaning the front and rear panels because a permanent plastic sheet covers each panel; do not use abrasive materials, polishing compounds, or harsh chemical solvents (such as xylene or acetone) on any relay surface.
- Step 2. Allow the relay to air dry, or wipe dry with a soft dry cloth.

Verify Relay Configuration

When you first inspect the relay, confirm that the relay power supply voltage and nominal ac signal magnitudes are appropriate for your application.

Examine the serial number label on the relay rear panel; *Figure 4.1* shows a sample rear-panel serial number label.




Figure 4.1 SEL-451 Serial Number Label

NOTE: Do not use this page for ordering a relay. For ordering information, refer to the SEL-451 Model Option Table available at www.selinc.com, or contact your SEL Sales Representatives.

Figure 4.1 shows a serial number label for an SEL-451 with additional I/O in a SU horizontal chassis. This example serial number label is for a 5 A-per-phase secondary current transformer input relay. For information on CT and PT inputs, see *Secondary Circuits on page U.2.5*.

The power supply specification in *Figure 4.1* indicates that this relay is equipped with a power supply that accepts a nominal 48/125 Vdc input. This power supply also accepts a 120 Vac input. Other power supply options include nominal 24/48 Vdc and 125/250 Vdc power supplies. The 125/250 Vdc power supply also accepts a 120/230 Vac input. Refer to the serial number label affixed to the back of your relay to determine the power supply voltage you should apply to the relay power supply input terminals. As this label indicates, the voltage source should be capable of providing at least 35 W for dc inputs and 120 VA for ac inputs. See *Power Supply on page U.1.12* for more information on power supply specifications.

The serial number label does not list power system phase rotation and frequency ratings, because you can use relay settings to configure these parameters. The factory defaults are ABC phase rotation and 60 Hz nominal frequency. See [Making Settings Changes: Initial Global Settings](#) on page U.4.17 for details on setting these parameters.

Logic Input Ratings

The serial number label in [Figure 4.1](#) only lists control input voltages for I/O Interface Boards that have 24 optoisolated inputs, which is determined at ordering time. In the sample shown, only position (slot) B contains an INT4 I/O Interface board, so only one input rating appears. The other types of control inputs (Direct Coupled) have settable pickup voltages, and do not appear on the serial number label. See [Control Input Assignment](#) on page U.4.67 for more information.

Connecting and Applying Power

Connect external power to the SEL-451 to perform the initial checkout and familiarization procedures in this section. For complete information on power connections, see [Power Connections](#) on page U.2.38.

[Figure 4.2](#) shows the portion of the relay rear panel where you connect the power input.




Figure 4.2 Power Connection Area of the Rear Panel

You can order the SEL-451 with one of three power supplies with nominal operating voltages: 24/48 Vdc, 48/125 Vdc, and 125/250 Vdc. The two higher voltage supplies, 48/125 Vdc and 125/250 Vdc, use ac input or dc input. The relay serial number label on the back of the relay lists voltage ranges that encompass the nominal voltages.

[Table 4.1](#) shows the nominal voltage inputs and power supply voltage ranges for dc input, and ac inputs if applicable.

Table 4.1 Power Supply Voltage Inputs

Nominal DC Voltage Input	DC Input Range	AC Input Range (30–120 Hz)
24/48 Vdc	18–60 Vdc <35 W	N/A
48/125 Vdc	38–140 Vdc <35 W	120 Vac <120 VA
125/250 Vdc	85–300 Vdc <35 W	120/230 Vac <120 VA

Observe the following precautions when connecting power to the SEL-451:

DANGER

Contact with instrument terminals can cause electrical shock that can result in injury or death.

- Step 1. Always attach a safety ground as the first connection you make to the SEL-451.
- Step 2. Connect the grounding terminal (#Z31) labeled **GND** on the rear panel to a rack frame ground or main station ground for proper safety and performance.
- Step 3. Use 16 AWG (1.5 mm²) wire (or heavier) to connect to the **POWER** terminals, observing the following:
 - When you use a dc power source, you must connect the source with the proper polarity, as indicated by the + (Terminal #Z29) and - (Terminal #Z30) symbols on the power terminals.
 - You can use ac input for the 48/125 Vdc power supply and the 125/250 Vdc power supply.
 - The relay operates from 30 to 120 Hz (nominal 50/60 Hz) when alternating current supplies the **POWER** input.

Upon connecting power, you will see information on the front-panel LCD (liquid crystal display) and the **ENABLED** LED (light-emitting diode) will illuminate.

For complete information on the SEL-451 front panel, see [Front-Panel Operations on page U.5.1](#).

Establishing Communication

Once you have applied the correct power input successfully, you are ready to operate the relay. Use the relay front panel and the communications ports to communicate with the relay.

Front-panel control of relay functions involves use of a menu system that you access through the LCD and the six navigational pushbuttons shown in [Figure 4.3](#). For complete instructions on using the front-panel menu system, see [Navigating the Menus on page U.5.4](#).




Figure 4.3 PORT F, LCD Display, and Navigation Pushbuttons

Fast and efficient communication with the relay is available through communications ports such as **PORT F**, also shown in [Figure 4.3](#). A design philosophy for all SEL relays is that an ASCII or open terminal is all that you

need to communicate with the relay. Many off-the-shelf computer programs provide terminal emulation. These programs are inexpensive and widely available.

Use the cable connections appropriate for your terminal configuration. See [Section 4: Communications Interfaces in the Reference Manual](#) for more information on communications ports.

All ASCII commands you send to the relay must terminate with a carriage return or carriage return/line feed; the terminal emulation program appends the necessary carriage return when you press <Enter>.

You can truncate commands to the first three characters: **EVENT 1 <Enter>** becomes **EVE 1 <Enter>**. Use upper- and lower-case characters without distinction, except in passwords, which are case sensitive. For a list of ASCII commands see [Section 9: ASCII Command Reference in the Reference Manual](#).

Help

When you are using a terminal, you can access built-in relay help for each ASCII command. Relay help is access-level sensitive; you see only the ASCII commands for the present access level when you type **HELP <Enter>**. For in-depth information on a particular ASCII command, enter the command name after typing **HELP**. For example, for help on the **EVENT** ASCII command, type **HELP EVE <Enter>**.

When you are using ACCELERATOR QuickSet, press <F1> to get help, or select the **Help** menu from the ACCELERATOR QuickSet toolbars. The help information in ACCELERATOR QuickSet gives detailed information and sample screens in a GUI format.

Making an EIA-232 Serial Port Connection

The following steps use any popular computer terminal emulation software and SEL serial cables to connect to the SEL-451.

Use an SEL Cable C234A to connect a 9-pin computer serial port to the SEL-451. Use an SEL Cable C227A to connect a 25-pin computer serial port to the relay. See [Section 4: Communications Interfaces in the Reference Manual](#) for further information on serial communications connections. These and other cables are available from SEL. Contact the factory or your local distributor for more information.

- Step 1. Connect the computer and the SEL-451 using the serial communications cable.

Use the 9-pin serial port labeled **PORT F** on the relay front panel.

- Step 2. Apply power to both the computer and to the relay.
- Step 3. Start the computer terminal emulation program.
- Step 4. Set your computer terminal emulation program serial communications parameters.

The default SEL-451 communications port settings are listed in [Table 4.2](#).

Also set the terminal program to emulate either VT100 or VT52 terminals. These terminal emulations work best with SEL relays.

Table 4.2 General Serial Port Settings

Name	Description	Default
PROTO	Protocol (SEL, DNP ^a , MBA, MBB, RTD, PMU)	SEL
SPEED	Data speed (300 to 57600, SYNC ^b)	9600
DATABIT	Data bits (7, 8 bits)	8
PARITY	Parity (Odd, Even, None)	N
STOPBIT	Stop bits (1, 2, bits)	1
RTSCTS	Enable Hardware Handshaking (Y, N)	N

^a DNP protocol is an ordering option.

^b SYNC setting only available when PROTO := MBA or MBB

Step 5. To check the communications link, press <Enter> to confirm that you can communicate with the relay.

You will see the Access Level 0 = prompt at the left side of your computer screen (column 1).

If you do not see the prompt, check the cable connections and confirm the settings for the default communications parameters of *Table 4.2* in your terminal emulation program.

Step 6. Type QUIT <Enter> to view the relay report header.

You will see a computer screen display similar to *Figure 4.4*. (Text that you type is emphasized in bold letters.)

If you see jumbled characters, change the terminal emulation type in the computer terminal program.

```
=QUIT <Enter>
Relay 1                               Date: 04/16/2004 Time: 00:01:05.209
Station A                             Serial Number: 2001001234
=
```

Figure 4.4 Report Header

When you communicate with the relay at the Access Level 0 = prompt, you are in security Access Level 0. You cannot control relay functions at this level.

Higher access levels are password protected and allow increased control over relay operation. For more information on access levels and password protection, see *Changing the Default Passwords: Terminal* on page U.4.9.

Changing the Default Passwords

NOTE: Perform the password-change steps described in *Changing the Default Passwords: Terminal* on page U.4.9.


It is extremely important that you change the factory default passwords programmed in the SEL-451. Setting unique passwords for the relay access levels increases the security of your substation and the power system.

This subsection begins with information on the access level/password system in the SEL-451 and includes an example of changing the default passwords.

Access Levels

Access levels control whether you can perform different operations within the SEL-451. These security levels are labeled 0, 1, B, P, A, O, 2, and C.

Figure 4.5 presents an overview of the general access level structure in the relay.

**Figure 4.5 Access Level Structure**

Access Level 0 is the least secure and most limited access level, and Access Level 2 is the most secure level at which you have total relay functionality (Level C is reserved for SEL factory operations. Only go to level C to change the level C password or under the direction of an SEL employee). For example, from Access Level 1, you can view settings but you cannot change settings unless you are at a higher access level.

[Table 4.3](#) lists access levels and operator functions for the SEL-451.

Table 4.3 SEL-451 Access Levels

Access Level	Prompt	Allowed Operations
0	=	Log in to Access Level 1; some test diagnostics.
1	=>	View data and status information.
B	==>	Access Level 1 functions plus breaker control and data.
P	P=>	Access Level B functions plus protection settings.
A	A=>	Access Level B functions plus automation settings.
O	O=>	Access Level B functions plus output settings.
2	=>>	Perform all relay access level functions.
C	==>>	SEL calibration specific functions. For a list of commands available, contact SEL.

The SEL-451 performs command interpretation and execution according to your validated access level. Each access level has a password that the relay must verify before you can control the relay at that level. [Table 4.4](#) lists the access level commands with corresponding passwords.

Table 4.4 Access Level Commands and Passwords

Access Level	Command	Factory Default Password
0	QUIT	(None)
1	ACCESS	OTTER
B	BACCESS	EDITH
P	PACCESS	AMPERE
A	AACCESS	VOLTA
O	OACCESS	WATT
2	2ACCESS	TAIL
C	CAL	Sel-1

Communications Ports Access Levels

WARNING

This device is shipped with default passwords. Default passwords should be changed to private passwords at installation. Failure to change each default password to a private password may allow unauthorized access. SEL shall not be responsible for any damage resulting from unauthorized access.

Entrance to the higher security levels is sequential. You must first enter a correct password to move from Access Level 0 to Access Level 1.

To enter Access Levels B, P, A, O, and 2, you must enter a correct password from Access Level 1. For example, to go to the O (Output) Access Level from Access Level 1, type **OAC <Enter>**. At the **Password: ?** prompt, type your Access Level O password.

To enter level C, you must enter a correct password from Access Level 2.

Use the relay **QUIT** command from any access level to return the relay to Access Level 0. To reestablish control at a previous access level from Access Level 1, you must use the access level commands and passwords to log in to that previous access level.

When a connection with the SEL-451 times out, the relay reduces the access level to Access Level 0 for that communications port connection.

The MAXACC port setting can be used to limit the maximum access level permitted on a port. This can be useful to restrict what remote users can do.

Front-Panel Access Levels

The lowest access level for the front panel is Access Level 1. To enter Access Levels B, P, A, O, and 2, you must enter a correct password from Access Level 1.

The front-panel LCD displays a password prompt when you attempt to control the relay at any access level higher than Access Level 1. (For more information on entering passwords from the front panel, see *Password on page U.5.15*.)

The front-panel **MAIN MENU** item **RESET ACCESS LEVEL** returns the relay to Access Level 1. In addition, when the front-panel inactivity timer times out (indicated by the **ROTATING DISPLAY** on the front-panel LCD), the relay returns the front-panel access level to Access Level 1.

ACCESS Command

NOTE: You can shorten relay commands to the first three letters of the full command. See [Section 9: ASCII Command Reference in the Reference Manual](#) for more information.

Enter the **ACCESS (ACC)** command to change to Access Level 1. Passwords are case sensitive; you must enter a password exactly as set.

If you enter the password correctly, the SEL-451 moves to Access Level 1 and the Access Level 1 => prompt appears. If you are at a higher access level (B, P, A, O, and 2), you can reduce the access level to Access Level 1 by entering the **ACC** command. The relay performs no password validation to reduce the present access level.

Higher Access Level Commands

Enter the commands in [Table 4.4](#) to enter access levels above Access Level 1. For example, enter the **2ACCESS (2AC)** command to change to Access Level 2.

If you are presently at Access Level 1, B, P, A, or O, typing **2AC <Enter>** causes the SEL-451 to prompt you to type the Access Level 2 password. If the present level is Access Level 0, the SEL-451 responds with **Invalid Access Level**. The relay asserts alarm Relay Word bit SALARM when entering Access Level B, P, A, O, and 2 from a lower access level.

If you are unable to enter the correct password after the third failed attempt, the SEL-451 asserts the BADPASS and SALARM Relay Word bits for one second and displays on a communications terminal screen the following error message:

WARNING: ACCESS BY UNAUTHORIZED PERSONS STRICTLY PROHIBITED

In addition, you cannot make further access level entry attempts for 30 seconds. The relay terminates the communications connection after the third failed attempt when you use Ethernet via an Ethernet card, DNP3 (Distributed Network Protocol version 3.0), and MIRRORED BITS® communications virtual terminal mode. For more information on these protocols, see *Section 5: SEL Communications Protocols in the Reference Manual* and *Section 6: DNP3 Communications in the Reference Manual*.

If your connection to the SEL-451 has an inactivity time-out (in the **SET P** port settings), the SEL-451 automatically closes the communications connection and changes to Access Level 0 when the time-out occurs.

Passwords

⚠ WARNING

This device is shipped with default passwords. Default passwords should be changed to private passwords at installation. Failure to change each default password to a private password may allow unauthorized access. SEL shall not be responsible for any damage resulting from unauthorized access.

Valid passwords are character sequences of as many as twelve characters. Valid password characters are any printable ASCII character. HMI password entry is limited to upper- and lower-case letters, numbers, underscore, and period, so you must limit your password to these characters if you need to do privileged operations from the front panel. Passwords are case-sensitive.

It is important that you change all of the passwords from their default values. This will protect you from unauthorized access.

Use strong passwords. Strong passwords contain a mix of the valid password characters in a combination that does not spell common words in any portion of the password.

Changing the Default Passwords: Terminal

- Step 1. Confirm that the relay is operating (see *Connecting and Applying Power on page U.4.3*).
- Step 2. Establish communication with the SEL-451. (See *Making an EIA-232 Serial Port Connection on page U.4.5* to learn how to use a terminal to communicate with the relay.)
- Step 3. Enter Access Level C (Level 2 is sufficient except when changing the Level C password.).
 - a. Using a communications terminal, type **ACC <Enter>**.
 - b. Type the Access Level 1 password **OTTER** and press **<Enter>**.
You will see the Access Level 1 => prompt.
 - c. Type **2AC <Enter>**.
 - d. At the password prompt, type **TAIL <Enter>**.
You will see the Access Level 2 =>> prompt.

NOTE: Passwords are case sensitive; you must enter passwords exactly as set.

- e. Type **CAL <Enter>**.
- f. At the password prompt type **Sel-1 <Enter>**.

You will see the Access Level C ==> prompt.

Step 4. To set a new password for Access Level 2, type the following:

PAS 2 nE2Pw <Enter>

(**nE2Pw** becomes the new strong password)

The relay will return the word **Set** and the Access Level 2 ==> prompt.

Step 5. Set new passwords for each access level.

In a similar manner as the previous step, create new strong passwords for each access level.

Step 6. Commit these passwords to memory, permanently record your new passwords, and store this permanent record in a secure location.

To eliminate password verification for an access level, enter **DISABLE** in place of the new password. This action will disable the password of that level; therefore, the relay does not check for a password upon entering that access level.

Using **DISABLE** is not recommended. Always set a unique, strong password in the relay for each access level. Failure to do this can severely jeopardize the security of your substation and the power system.

After you enter a new password, the relay pulses the Relay Word bit **SALARM** for one second and responds **Set**. The relay responds with the message **Password Disabled** if you used the **DISABLE** parameter.

If you forget a password, or encounter difficulty changing the default passwords in [Changing the Default Passwords: Terminal on page U.4.9](#), you can temporarily disable password verification. See [Jumpers on page U.2.18](#) for information on the password disable jumper J18B.

Checking Relay Status

With continual self-testing, the SEL-451 monitors the internal operation of all circuits to verify optimal performance of relay functions. If an internal circuit, protection algorithm, or automation algorithm enters an out-of-tolerance operating range, the relay reports a status warning. In the unlikely event that an internal failure occurs, the relay reports a status failure. For more information on relay status, see [Relay Self-Tests on page U.6.35](#).

You can check relay status through a communications port by using a terminal, terminal emulation computer program, or ACCELERATOR QuickSet. In addition, you can use the relay front panel to view status information.

Checking Relay Status: Terminal


The procedure in the following steps assumes that you have successfully established communication with the relay (see [Making an EIA-232 Serial Port Connection on page U.4.5](#)). In addition, you must be familiar with relay access levels and passwords (see [Changing the Default Passwords: Terminal on page U.4.9](#) to change the default access level passwords).

Step 1. Enter Access Level 1.

- Using a communications terminal, type **ACC <Enter>**.
- Type the Access Level 1 password and press **<Enter>**.

You will see the Access Level 1 => prompt.

Step 2. Type **STA <Enter>**. The relay returns a status terminal screen similar to that in [Figure 4.6](#).



```

=>STA <Enter>
Relay 1
Station A
Date: mm/dd/yyyy Time:07:02:50.776
Serial Number: 000000000
FID=SEL-451-1-Rxxx-V0-Zxxxxx-Dyyyymmdd
CID=0x9aed
Failures
No Failures
Warnings
No Warnings
SELogic Relay Programming Environment Errors
No Errors
Relay Enabled
=>

```

Figure 4.6 Relay Status

Step 3. Type **STA A <Enter>** to view all relay status entries.

For more information on relay status report items, see [STATUS on page R.9.54](#).

Checking Relay Status: ACSELERATOR QuickSet

You can use ACSELERATOR QuickSet to check relay status. Use the **HMI > Meter Control** menu to view status conditions.

The procedure in the following steps assumes that you have successfully established communication with the relay (see [Making an EIA-232 Serial Port Connection on page U.4.5](#)). In addition, you must be familiar with relay access levels and passwords (see [Changing the Default Passwords: Terminal on page U.4.9](#) to change the default access level passwords). You should also be familiar with ACSELERATOR QuickSet (see [Section 3: PC Software](#)).

Step 1. Configure the communications port.

- Start ACSELERATOR QuickSet.
- On the top toolbar, click **Communication > Parameters**.

You will see the **Communication Parameters** dialog box similar to [Figure 4.7](#).

NOTE: The DTR parameter has no effect on communications with the SEL-451 relay.




Figure 4.7 ACSELERATOR QuickSet Communication Parameters and Password Entry

- Select the **Data Speed**, **Data Bits**, **Stop Bits**, **Parity**, and **RTS/CTS** that match the relay settings.

The defaults are **9600**, **8**, **1**, **None**, and **Off**, respectively.

- Click **OK** to update the ACSELERATOR QuickSet communications parameters and connect to the relay.
- Confirm that the **Communications Status** bar at the bottom of the ACSELERATOR QuickSet window says **Connected**.

Step 2. Confirm that you have loaded the correct passwords in ACSELERATOR QuickSet.

- Enter your Access Level 1 password in the **Level One Password** text box, and your Access Level 2 password in the **Level Two Password** text box.
- Click **OK** to accept changes and close the dialog box.

Step 3. Click **Meter and Control** in the top toolbar **HMI** menu to start the ACSELERATOR QuickSet operator interface.

Step 4. Click the **Status** button of the HMI tree view (see [Figure 4.8](#)).

ACSELERATOR QuickSet displays the relay status with a display similar to that in [Figure 4.6](#).




Figure 4.8 Retrieving Relay Status: ACSELERATOR QuickSet

Checking Relay Status: Front Panel

Use the front-panel display and navigation pushbuttons to check SEL-451 status. See [Section 5: Front-Panel Operations](#) for information on using the relay front panel.

- Step 1. Apply power to the relay, and note that the LCD shows a sequence of screens called the ROTATING DISPLAY.

(If you do not operate the front panel for a certain period, the relay will enter front-panel time-out mode and you will see the sequential screens of the ROTATING DISPLAY.)

- Step 2. Press the ENT pushbutton to display the MAIN MENU of [Figure 4.9](#).




Figure 4.9 Checking Relay Status: Front-Panel LCD

- Step 3. View the relay status:

- Press the Up Arrow and Down Arrow navigation pushbuttons to highlight the RELAY STATUS action item (see [Figure 4.9](#)).
- Press the ENT pushbutton.

You will see the RELAY STATUS screen (the second screen of [Figure 4.9](#)).

- Step 4. Press the ESC key to return to the MAIN MENU.

- Step 5. Press ESC again to return to the ROTATING DISPLAY.

For more information on the front-panel screen presentations and the items in the STATUS screens, see [Relay Status on page U.5.33](#).

Making Simple Settings Changes

The SEL-451 settings structure makes setting the relay easy and efficient. Settings are grouped logically, and you do not see relay elements that are not used in your selected protection scheme.

For example, if you select only three levels of a particular type of overcurrent protection, the corresponding Level 4 overcurrent element settings do not appear on the communications terminal screen. Hiding unused elements and settings that you have not enabled greatly simplifies the task of setting the SEL-451.


ACSELERATOR QuickSet uses a similar method to focus your attention on the active settings. Unused relay elements and inactive settings are dimmed (grayed) in the ACSELERATOR QuickSet menus. See [Section 3: PC Software](#) for more information on ACSELERATOR QuickSet.

Settings Structure

The SEL-451 settings structure assigns each relay setting to a specific location based on the setting type. A top-down organization allocates relay settings into these layers:

- Class
- Instance
- Category
- Setting

Examine [Figure 4.10](#) to understand the settings structure in the SEL-451. The top layer of the settings structure contains classes and instances. Class is the primary sort level; all classes have at least one instance, and some classes have multiple instances. Settings classes and related instances for the SEL-451 are listed in [Table 4.5](#).


Figure 4.10 Relay Settings Structure Overview
Table 4.5 Settings Classes and Instances (Sheet 1 of 2)

Class	Description	Instance	Description	ASCII Command	Access Level
Global	Relay-wide applications settings	Global		SET G	P, A, O, 2
Group	Individual scheme settings	Group 1 • • • Group 6	Group 1 settings • • • Group 6 settings	SET 1, SET S 1 • • • SET 6, SET S 6	P, 2
Breaker Monitor	Circuit breaker monitoring settings	Breaker Monitor		SET M	P, 2

Table 4.5 Settings Classes and Instances (Sheet 2 of 2)

Class	Description	Instance	Description	ASCII Command	Access Level
Port	Communications port settings	PORT F PORT 1 • • • PORT 3 PORT 5	Front-panel port PORT 1 settings • • • PORT 3 settings Communications card settings	SET P F SET P 1 • • • SET P 3 SET P 5	P, A, O, 2
Report	Event report and SER ^a settings	Report		SET R	P, A, O, 2
Front Panel	Front-panel HMI settings	Front Panel		SET F	P, A, O, 2
Protection SELOGIC® control equations	Protection-related SELOGIC control equations	Group 1 • • • Group 6	Group 1 protection SELOGIC control equations • • • Group 6 protection SELOGIC control equations	SET L 1 • • • SET L 6	P, 2
Automation SELOGIC control equations	Automation-related SELOGIC control equations	Block 1 • • • Block 10	Block 1 automation SELOGIC control equations • • • Block 10 automation SELOGIC control equations	SET A 1 • • • SET A 10	A, 2
DNP	Direct Network Protocol data remapping	DNP		SET D	P, A, O, 2
Output SELOGIC control equations	Relay control output settings and MIRRORED BITS communication transmit equations	Output		SET O	O, 2
Bay ^b	Bay control settings	Bay		SET B	P, 2
Alias	Set aliases	Analog or digital quantities		SET T	P, A, O, 2

^a SER is the Sequential Events Recorder; see [SER \(Sequential Events Recorder\) on page A.3.42](#).

^b Bay control settings available in the SEL-451-4 relay.

Note that some settings classes have only one instance and you do not specify the instance designator when accessing these classes. An example is the Global settings class. You can view or modify Global settings with a communications terminal by entering **SET G** as shown in the ASCII Command column of [Table 4.5](#). The relay presents the Global settings categories at the **SET G** command; no instance numbers follow **SET G**. Conversely, the Port settings command has five instances (PORT F, PORT 1, PORT 2, PORT 3, and PORT 5). To access the PORT 1 settings, type **SET P 1 <Enter>**. If you do not specify which port to set, the relay defaults to the active port (the port you are presently using).

The Group settings can have the optional one-letter acronym **S** attached to the command; you can enter **SET 1** or **SET S 1** for Group 1 settings, **SET 2** or **SET S 2** for Group 2 settings, etc. If you do not specify which group to set, the

relay defaults to the present active group. If Group 6 is the active group, and you type **SET <Enter>**, for example, you will see the settings prompts for the Group 6 settings.

Settings: Terminal

When you change settings (with any **SET** command) from a terminal, the relay shows the setting category, prompt, present value, and action prompt.

Figure 4.11 shows two settings examples: multiple-line settings (SID and RID) and an in-line setting (NUMBK) for relay Global settings from Access Level P (protection). The relay prompts you for input by presenting an action prompt. You have many options for navigating the settings at the ? action prompt.

Table 4.6 lists the operations possible from a settings action prompt.




Figure 4.11 Components of SET Commands

Table 4.6 Actions at Settings Prompts

Action	Relay Response
<Enter>	Accept setting and move to the next setting; if at the last setting, exit settings.
[value] <Enter>	Enter the given <i>value</i> and move to the next setting if valid; if at the last setting, exit settings.
^ <Enter>	Move to the previous setting; if at the top of settings, stay at the present setting.
< <Enter>	Move to the top of the previous settings category; if at the top of settings, stay at the present setting.
> <Enter>	Move to the top of the next settings category; if in the last category, exit settings.
END <Enter>	Go to the end of the present settings session. Prepare to exit settings via the Save settings (Y,N) ? prompt.
<Ctrl+X>	Abort the editing session without saving changes.

When you exit settings entry from the **SET** commands, the relay responds, Save settings (Y,N) ?. If you answer **Y <Enter>**, the relay writes the new settings to nonvolatile storage. If you answer **N <Enter>**, the relay discards any settings changes you have made.

Making Settings Changes: Initial Global Settings

You must configure the SEL-451 for specific conditions found in the power system where you are connecting the relay. In particular, you must set the nominal frequency and phase rotation.

The procedure in the following steps assumes that you have successfully established communication with the relay; see [Making an EIA-232 Serial Port Connection on page U.4.5](#) for a step-by-step procedure. In addition, you must

be familiar with relay access levels and passwords. See [Changing the Default Passwords: Terminal on page U.4.9](#) to change the default access level passwords.

This example jumps to a Global setting that is not at the beginning of the Global settings list. Thus, you enter **SET G**, the setting name, and <Enter>. To start at the beginning of the Global settings, simply type **SET G <Enter>** without a settings name.

Step 1. Prepare to control the relay at Access Level 2.

- a. Using a communications terminal, type **ACC <Enter>**.
- b. Type the Access Level 1 password and press <Enter>. You will see the Access Level 2 => prompt.
- c. Type the **2AC <Enter>** command.
- d. Type the correct password to go to Access Level 2. You will see the Access Level 2 =>> prompt.

Step 2. Type **SET G NFREQ <Enter>** (this sets the nominal system frequency using the **NFREQ** setting, which has options of 50 Hz and 60 Hz).

The relay responds with a terminal screen display similar to the beginning of [Figure 4.12](#).

```
=>>SET G NFREQ <Enter>
Global
General Global Settings
Nominal System Frequency (50,60 Hz)          NFREQ   := 60      ? <Enter>
System Phase Rotation (ABC,ACB)                PHROT   := ABC     ? <Enter>
Date Format (MDY,YMD,DMY)                      DATE_F  := MDY     ? YMD <Enter>
Fault Condition Equation (SELogic Equation)
FAULT := 51S1 OR 51S2 OR 50P1
? END <Enter>
.
.
.

Save settings (Y,N) ? Y <Enter>
Saving Settings, Please Wait.....
Settings Saved
=>>
```

Figure 4.12 Initial Global Settings

Step 3. Accept the default settings.

- a. For a 60 Hz system, simply press <Enter> to accept the **NFREQ** existing value of 60 (Hz). The relay presents the next setting, which is the **PHROT** (phase rotation) setting.
- b. Type <Enter> to accept the **ABC** phase rotation default.

Step 4. Set the date format:

The SEL-451 reports dates in three formats: MDY, YMD, and DMY (where M = month, D = date, and Y = year).

- a. For this procedure type **YMD <Enter>**.

At each setting in turn, the relay presents the settings prompt, name, present value, and action prompt.

Note that SELOGIC control equation settings, such as **FAULT** in [Figure 4.12](#), can appear on multiple lines.

- b. If you make a mistake or want to go backward through the settings, type the ^ character (on most computer keyboards, this is a shifted numeral 6) and <Enter>.

Refer to [Table 4.6](#) for this and other navigational aids.

Step 5. End the settings session.

- a. Type END <Enter> at the FAULT action prompt.

(The FAULT SELLOGIC control equation remains unchanged.)

The relay next scrolls a readback of all the Global settings, eventually displaying the following prompt:

Save settings (Y,N) ? prompt

(In [Figure 4.12](#), a vertical ellipsis represents the relay information during readback.)

- b. Examine the settings readback to verify your new settings.
- c. Answer Y <Enter> to save your new settings.

The TERSE Option

You can avoid viewing the entire class settings summary the relay displays when you type END <Enter> midway through a settings class or instance.

On slow data speed links, waiting for the complete settings readback can clog your automation control system or take too much of your time for a few settings changes. Eliminate the settings readback by appending TERSE to the SET command.

Text-Edit Mode Line Editing

Some SEL-451 settings present multiple input lines to your terminal; you use basic line text editing commands to construct the setting. For display, the relay references each line of the setting by line number, not by the setting name. See [Making Text-Edit Mode Settings Changes on page U.4.20](#) for an example of a text-edit mode setting.

While in the text-edit mode, you see a prompt consisting of the line number and the present setting for that line. You can keep the setting, enter a new setting, or delete the setting. [Table 4.7](#) lists the commands for text-edit mode.

Table 4.7 Actions at Text-Edit Mode Prompts (Sheet 1 of 2)

Action	Relay Response
<Enter>	Accept the setting and move to the next line; if at the last line or at a blank line, exit settings.
>n <Enter>	Move to line n. If this is beyond the end of the list, move to a blank line following the last line.
^ <Enter>	Move to the previous line; if at the first line, stay at the present line.
< <Enter>	Move to the first line.
> <Enter>	Move to a blank line following the last line.
LIST <Enter>	List all settings and return to the present action prompt.
DELETE [n] <Enter>	Delete the present line and subsequent lines for a total of n lines; n = 1 if not provided. Lines after deletion shift upward by the number of lines deleted.

Table 4.7 Actions at Text-Edit Mode Prompts (Sheet 2 of 2)

Action	Relay Response
INSERT <Enter>	Insert a blank line at the present location; the present line and subsequent lines shift downward.
END <Enter>	Go to the end of the present settings session. Prepare to exit settings via the Save settings (Y, N) ? prompt.
<Ctrl+X>	Abort editing session without saving changes.

Use commas to separate the items in a text-edit mode setting when you are entering multiple items per line. After you enter each line, the relay checks the validity of the setting. If the entered setting is invalid, the relay responds with an error message and prompts you again for the setting.

Making Text-Edit Mode Settings Changes

The procedure in the following steps familiarizes you with basic text-edit mode line editing. You set Display Point 1 through Display Point 3 to show the status of Circuit Breaker 1, Circuit Breaker 2, and the operational state (on or off) of the transformer cooling fans near the circuit breaker bay where you have installed the SEL-451. See [Display Points on page U.5.11](#) for information on programming display points.

For this example, use inputs IN101, IN102, and IN105. You can use other inputs for your particular application. See [Control Inputs on page U.2.6](#) for more information on control inputs.

This procedure assumes that you have successfully established communication with the relay (see [Making an EIA-232 Serial Port Connection on page U.4.5](#)). In addition, you must be familiar with relay access levels and passwords (see [Changing the Default Passwords: Terminal on page U.4.9](#)) to change the default access level passwords.

Step 1. Prepare to control the relay at Access Level 2.

- Using a communications terminal, type **ACC <Enter>**.
- Type the Access Level 1 password and press **<Enter>**.
You will see the Access Level 1 => prompt.
- Type the **2AC <Enter>** command.
- Type the correct password to go to Access Level 2.
You will see the Access Level 2 ==> prompt.

Step 2. Access the display point settings.

- Type **SET F <Enter>** to modify the front-panel settings.
- Advance through the front-panel settings (repeatedly type **>** and then **<Enter>**) until you reach the **Display Points and Aliases** category.

[Figure 4.13](#) shows a representative terminal screen. The relay displays the first line that you can edit. For the case of display points, the line number is the display point number.

- Step 3. At the Line 1 settings ? prompt, type the following to create Display Point 1:

IN101,CB1,CLOSED,OPEN <Enter>

The relay verifies that this is a valid entry, then responds with the next line prompt 2: followed by the settings ? prompt (see *Figure 4.14*).

- Step 4. At the Line 2 settings ? prompt, type the following to create Display Point 2:

IN102,CB2,CLOSED,OPEN <Enter>

The relay verifies that this is a valid entry, then responds with the next line prompt 3: followed by the settings ? prompt (see *Figure 4.14*).

- Step 5. At the **Display Points and Aliases** prompt, use the text-edit mode line editing commands to list the active display points. Type the following:

LIST <Enter>

After showing the active display points, the relay returns to line 3: followed by the settings ? prompt.

- Step 6. Type the following to create Display Point 3:

IN105,“5 MVA XFMR Fans”,ON,OFF <Enter>

The relay verifies that this is a valid entry, then responds with the next line prompt 4: followed by the settings ? prompt (see *Figure 4.13*).

- Step 7. Type **END <Enter>** to end the editing session.

The relay scrolls a readback of all the Front-Panel settings, eventually displaying the Save settings (Y,N) ? prompt. (A vertical ellipsis in *Figure 4.13* represents the readback.)

At the end of the readback information, just before the Save settings (Y,N) ? prompt, you can verify the new display point information.

- Step 8. Answer **Y <Enter>** to save the new settings.

NOTE: Use quotation marks when entering alias strings that contain spaces or punctuation marks, as shown in the IN105 sample, step 6.

```

Display Points and Aliases
(Boolean) : RWB Name, "Alias", "Set String", "Clear String", "Text Size"
(Analog) : Analog Quantity Name, "User Text and Formatting", "Text Size"

1:
? IN101,CB1,CLOSED,OPEN <Enter>
2:
? IN102,CB2,CLOSED,OPEN <Enter>
3:
? LIST <Enter>

1: IN101,"CB1","CLOSED","OPEN",S
2: IN102,"CB2","CLOSED","OPEN",S

3:
? IN105,"5 MVA XFMR Fans",ON,OFF <Enter>
4:
? END <Enter>

.
.

Display Points and Aliases
(Boolean) : RWB Name, "Alias", "Set String", "Clear String", "Text Size"
(Analog) : Analog Quantity Name, "User Text and Formatting", "Text Size"

1: IN101,"CB1","CLOSED","OPEN",S
2: IN102,"CB2","CLOSED","OPEN",S
3: IN105,"5 MVA XFMR Fans","ON","OFF",S

.
.

Save settings (Y,N) ? Y <Enter>
Saving Settings, Please Wait.....
Settings Saved
=>

```

Figure 4.13 Using Text-Edit Mode Line Editing to Set Display Points

This procedure proposes connecting the transformer bank fan sensor to relay input IN105. In the **SET G (GLOBAL)** command, verify that the assertion level (setting IN105P) and the debounce time (setting IN105PU and IN105DO) are correct for your fan-running sensor. To access separate input parameters, you must first enable independent control input settings with setting EICIS. To change the input conditioning, enter these settings:

EICIS := **Y** Independent Control Input Settings (Y, N)
IN105P := **80** Input IN105 Pickup Level (15–265 Vdc)
IN105PU := **0.3750** Input IN105 Pickup Delay (0.0000–5 cyc)
IN105DO := **0.3750** Input IN105 Dropout Delay (0.0000–5 cyc)

Use the appropriate interface hardware to connect the fan-running sensor to IN105. Choose any relay input that conforms to your requirements. See [Control Inputs on page U.2.6](#) for more information on SEL-451 control inputs.

Deleting a Display Point

This example shows how you can delete a previously used display point. In the **SET F** command, at the Display Points and Aliases prompt, use the text-edit mode line editing commands to set and delete the display points. This procedure shows two previously programmed display points that indicate on the front-panel LCD the status of Circuit Breaker 1 and Circuit Breaker 2. Relay control inputs IN101 and IN102 are the Relay Word bits for the Circuit Breaker 1 and Circuit Breaker 2 display points, respectively (see [Making Text-Edit Mode Settings Changes on page U.4.20](#)). You can use other inputs for your particular application. See [Control Inputs on page U.2.6](#) for more information on control inputs.

The procedure in the following steps assumes that you have successfully established communication with the relay (see [Making an EIA-232 Serial Port Connection on page U.4.5](#)). In addition, you must be familiar with relay access levels and passwords (see [Changing the Default Passwords: Terminal on page U.4.9](#)).

Step 1. Prepare to control the relay at Access Level 2.

- a. Using a communications terminal, type **ACC <Enter>**.
- b. Type the Access Level 1 password and press **<Enter>**.
You will see the Access Level 1 => prompt.
- c. Type the **2AC <Enter>** command.
- d. Type the correct password to go to Access Level 2.
You will see the Access Level 2 =>> prompt.

Step 2. Access the Display Points and Aliases prompt.

- a. Enter the **SET F** command.
- b. Advance through the front-panel settings (repeatedly type **>** and then **<Enter>**) until you reach the **Display Points and Aliases** category.

Figure 4.14 shows a representative terminal screen. The relay displays the first line that you can edit. For display points, the line number is the display point number.

```

Display Points and Aliases
(Boolean) : RWB Name, "Alias", "Set String", "Clear String", "Text Size"
(Analog) : Analog Quantity Name, "User Text and Formatting", "Text Size"

1: IN101,"CB1","CLOSED","OPEN",S
? LIST <Enter>

1: IN101,"CB1","CLOSED","OPEN",S
2: IN102,"CB2","CLOSED","OPEN",S
3: IN105,"5 MVA XFMR Fans","ON","OFF",S

1: IN101,"CB1","CLOSED","OPEN",S
? <Enter>
2: IN102,"CB2","CLOSED","OPEN",S
? DELETE <Enter>
2: IN105,"5 MVA XFMR Fans","ON","OFF",S
? LIST <Enter>

1: IN101,"CB1","CLOSED","OPEN",S
2: IN105,"5 MVA XFMR Fans","ON","OFF",S

2: IN105,"5 MVA XFMR Fans","ON","OFF",S
? END <Enter>

.
.

Display Points and Aliases
(Boolean) : RWB Name, "Alias", "Set String", "Clear String", "Text Size"
(Analog) : Analog Quantity Name, "User Text and Formatting", "Text Size"

1: IN101,"CB1","CLOSED","OPEN",S
2: IN105,"5 MVA XFMR Fans","ON","OFF",S

.
.

Save settings (Y,N) ? Y <Enter>
Saving Settings, Please Wait.....
Settings Saved
=>>

```

Figure 4.14 Using Text-Edit Mode Line Editing to Delete a Display Point

- Step 3. List the present display points.
- Type **LIST <Enter>** at the **Control Points and Aliases** prompt.
 - After showing the active display points, the relay returns to line 1: followed by the settings ? prompt.
- Step 4. Type **<Enter>** once to proceed to the line 2 present value and settings ? prompt.
- Step 5. Type **DELETE <Enter>** to delete Display Point 2.
- Step 6. Type **LIST <Enter>** to examine the remaining display points.
Former **Display Point 2** is eliminated, and **Display Point 3** moves up to position 2.
The relay returns to line 2: followed by the settings ? prompt.
- Step 7. Type **END <Enter>** to end the settings process.
The relay next scrolls a readback of all the Front-Panel settings, eventually displaying the **Save settings (Y,N) ?** prompt. (In *Figure 4.14*, a vertical ellipsis represents this scrolling readback.)
At the end of the readback information, just before the **Save settings (Y,N) ?** prompt, you can verify the new display point information.
- Step 8. Answer **Y <Enter>** to save your new settings.

Alias Settings

Rename, or assign up to 200 alias names to any Relay Word bit or analog quantity in the relay. This is very useful when programming using SELOGIC® control equations or analyzing SER and event report data. Assigning alias names is also a text-edit type entry, with the same syntax as the display point entries.

Use the **SHO T** command to view the default settings, as shown in *Figure 4.15*.

```
=>>SHO T <Enter>
Alias
Relay Aliases
(RW Bit or Analog Qty. 7 Character Alias [0-9 A-Z _])
1: EN,"RLY_EN"
=>>
```

Figure 4.15 Default Alias Settings

Making Text-Edit Mode Alias Changes

Assign the alias name THETA to math variable PMV01 and the alias TAN to math variable PMV02. These variables are then used in calculating the tangent of theta, using their alias names in the equation.

- Step 1. Prepare to control the relay at Access Level 2.
- Type **ACC <Enter>** at a communications terminal.
 - Type the Access Level 1 password and press **<Enter>**. You will see the => prompt.

- c. Type **2AC <Enter>**.
- d. Type the correct password to go to Access Level 2.
You will see the =>> prompt.

Step 2. Type **SET T <Enter>** to access the alias settings.

Figure 4.16 shows a representative computer terminal screen.

Step 3. Type **> <Enter>** for the relay to display the first line that you can edit.

Step 4. Type **PMV01,THETA <Enter>** at the Line 2 ? settings prompt to set the alias for PMV01.

The relay verifies that this is a valid entry, then responds with the next line prompt 3: followed by the ? settings prompt.

Step 5. Type **PMV02,TAN <Enter>** at the Line 3 ? settings prompt to set the alias for PMV02.

The relay verifies that this is a valid entry, then responds with the next line prompt 4: followed by the ? settings prompt.

Step 6. Type **END <Enter>** to end the settings session.

The relay scrolls a readback of all the front-panel settings, eventually displaying the Save settings (Y, N) ? prompt. At the end of the readback information, just before the Save settings (Y, N) ? prompt, you can verify the new display point information.

Step 7. Type **Y <Enter>** to save the new settings.

```
=>>SET T <Enter>
Alias
Relay Aliases
(RW Bit or Analog Qty. 7 Character Alias [0-9 A-Z _])
1: EN,"RLY_EN"
? <Enter>
2:
? PMV01,THETA <Enter>
3:
? PMV02,TAN <Enter>
4:
? END <Enter>
Alias
Relay Aliases
(RW Bit or Analog Qty. 7 Character Alias [0-9 A-Z _])
1: EN,"RLY_EN"
2: PMV01,"THETA"
3: PMV02,"TAN"
Save settings (Y,N) ?Y <Enter>
Saving Settings, Please Wait.....
Settings Saved
=>>
```

Figure 4.16 Using Text-Edit Mode Line Editing to Set Aliases

Use the alias names, instead of the Relay Word bits, in SELOGIC control equation programming. *Figure 4.17* shows an example of an alias used in protection logic programming.

```
=>>SET L <Enter>
Protection 1
1: PLT01S := PB1_PUL AND NOT PLT01 #GROUND ENABLED
? > <Enter>
15:
? THETA:=I01FA <Enter>
16:
? TAN:=SIN(THETA)/COS(THETA) <Enter>
17:
? END <Enter>
Protection 1
.
.
.

Save settings (Y,N) ?Y <Enter>
Saving Settings, Please Wait.....
Settings Saved

=>>
```

Figure 4.17 Using Text-Edit Mode Line Editing to Set Protection Logic

Settings: ACSELERATOR QuickSet

You can use ACSELERATOR QuickSet to develop settings for the SEL-451 offline. ACSELERATOR QuickSet automatically checks interrelated settings and alerts you to out-of-range settings. Upload the off-line ACSELERATOR QuickSet settings to the relay via the communications ports. See [Checking Relay Status: ACSELERATOR QuickSet on page U.4.11](#) for an introductory tutorial on using ACSELERATOR QuickSet.

You can also use ACSELERATOR QuickSet as a terminal program to interact in real time with the relay. For an introduction to ACSELERATOR QuickSet and all of features of this software, see [Section 3: PC Software](#).

Making Initial Global Settings: ACSELERATOR QuickSet

ACSELERATOR QuickSet makes setting the relay an easy task. The purpose of the procedure in the following steps is to familiarize you with reading, modifying, and sending settings with ACSELERATOR QuickSet.

This example assumes that you have successfully established communication with the relay (see [Making an EIA-232 Serial Port Connection on page U.4.5](#)). In addition, you must be familiar with relay access levels and passwords (see [Changing the Default Passwords: Terminal on page U.4.9](#) to change the default access level passwords). You should also be familiar with ACSELERATOR QuickSet; see [Section 3: PC Software](#) and [Checking Relay Status: ACSELERATOR QuickSet on page U.4.11](#).

Step 1. Configure the communications port.

- a. Start ACSELERATOR QuickSet.
- b. On the top toolbar, open the **Communication** menu, and then click **Parameters**.

You will see the **Parameters** dialog box similar to [Figure 4.7](#).

- c. Select the **Data Speed**, **Data Bits**, **Stop Bits**, **Parity**, and **RTS/CTS** that match the relay settings. The defaults are **9600, 8, 1, None, Off**, respectively.
- d. Click **OK** to update the ACSELERATOR QuickSet communications parameters.
- e. Type **<Ctrl+T>** to open the ACSELERATOR QuickSet terminal window.

- f. Type <Enter> to see whether the communications link is active between ACSELERATOR QuickSet and the relay.

You will see the Access Level 0 = prompt in the terminal window.

- g. Exit the terminal window.

Step 2. Confirm the correct ACSELERATOR QuickSet passwords.

- a. Reopen the **Communication** menu and click **Parameters**.
- b. Enter your Access Level 1 password in the **Level One Password** text box, and your Access Level 2 password in the **Level Two Password** text box.
- c. Click **OK** to accept changes and close the dialog box.

Step 3. On the **Settings** menu, click **Read** to read the present configuration in the SEL-451.

The relay sends all configuration and settings data to ACSELERATOR QuickSet.

Step 4. Select **Global** settings.

- a. Click the plus mark (+) next to the **Global** branch of the left-hand ACSELERATOR QuickSet tree structure shown in *Figure 4.18*.
- b. Click **General Global Settings**.

You will see the **Global Settings/Enables** window (see *Figure 4.18*).

Step 5. Change settings.

- a. Click the button for the correct option for NFREQ and PHROT to specify your system frequency and phase rotation.

When you tab or click to the next field, the relay validates the new setting.

- b. The right-click mouse button performs two special functions when you are editing settings: **Previous Value** and **Default Value**.
 - Right-click in the setting dialog box and select **Previous Value** if you want to revert to the setting value before you made a change.
 - Right-click in the setting dialog box and select **Default Value** if you want to restore the factory default setting value.




Figure 4.18 ACSELERATOR QuickSet Global Settings Window

Step 6. Save the new settings in ACSELERATOR QuickSet.

- On the **Relay Editor File** menu, click **Save**.
- Specify a **Relay Name**.
- Click **OK**.

Step 7. Upload the new settings to the SEL-451.

- On the **File** menu, click **Send**.
ACSELERATOR QuickSet prompts you for the settings class or instance you want to send to the relay, as shown in the first dialog box of [Figure 4.19](#).
- Click the check box for **Global**.
- Click **OK**.
ACSELERATOR QuickSet responds with the second dialog box of [Figure 4.19](#).
If you see no error message, the new settings are loaded in the relay.



Figure 4.19 Uploading Global Settings to the SEL-451

Settings: Front Panel

You can use the relay front panel to enter some of the relay settings. The SEL-451 presents the settings in order from class to instance (if applicable) to category to the particular setting, in a manner similar to setting the relay using a terminal.

Use the LCD and the adjacent navigation pushbuttons to enter each character of the setting in sequence. This can be a laborious process for some settings (e.g., long SELOGIC control equations). However, if you need to make a quick correction or have no faster means to make settings, settings functions are available at the front panel. For more information on making settings changes from the front panel, see [Set>Show on page U.5.29](#).

Entering DATE and TIME from the Front Panel

The purpose of the procedure in the following steps is to familiarize you with entering data from the SEL-451 front panel. Refer to [Connecting and Applying Power on page U.4.3](#) before performing this example.

- Step 1. Prepare to use the front panel by applying power to the relay.

Note that the relay front-panel display shows a sequence of LCD screens called the ROTATING DISPLAY. (If you do not operate the front panel for a certain period, the relay will enter front-panel time-out mode and you will see the sequential screens of the ROTATING DISPLAY.)

- Step 2. Press the ENT pushbutton to display the MAIN MENU of [Figure 4.20](#).

- Step 3. View the settings screens.

- a. Press the Up Arrow and Down Arrow navigation pushbuttons to highlight the SET/SHOW action item (see [Figure 4.20](#)).
- b. Press the ENT pushbutton.

You will see the SET/SHOW submenu (the second screen in [Figure 4.20](#)).

Step 4. View the date/time screen.

- Press the **Up Arrow** and **Down Arrow** navigation pushbuttons to highlight the **DATE/TIME** action item (*Figure 4.20*, second screen).
- Press the **ENT** pushbutton.

The relay next displays the **DATE/TIME** submenu (the third screen of *Figure 4.20*).




Figure 4.20 DATE and TIME Settings: Front-Panel LCD

Step 5. Set the date.

- Press the **ENT** pushbutton.

The relay shows the last screen of *Figure 4.20*, the DATE edit screen.

- Use the **Up Arrow** and **Down Arrow** navigation pushbuttons to increase and decrease the date position numbers.

Step to the next or previous position by using the **Left Arrow** and **Right Arrow** pushbuttons.

- c. When finished adjusting the new date, press ENT.

The relay returns the display to the DATE/TIME submenu. Note that the relay reports the TIME SOURCE as FP DATE (front-panel date).

Step 6. Press ESC repeatedly to normalize the front-panel display.

Changing a Relay Setting From the Front Panel

The purpose of the procedure in the following steps is to provide additional practice at entering relay settings from the front panel. In this example, you change the PORT F front-panel communications port settings.

Step 1. View the MAIN MENU.

- a. If you have been using the front panel (as in the previous example), press the ESC key repeatedly until you see the MAIN MENU.
- b. If the relay is displaying the ROTATING DISPLAY, press the ENT pushbutton to display the MAIN MENU.

The first screen of [Figure 4.21](#) shows the MAIN MENU at the beginning of the front-panel settings process.

Step 2. View the settings screens.

- a. Press the Up Arrow and Down Arrow navigation pushbuttons to highlight the SET/SHOW action item (see [Figure 4.21](#)).
- b. Press the ENT pushbutton. You will see the SET/SHOW submenu (the second screen in [Figure 4.21](#)).

Step 3. Select PORT F.

- a. Highlight PORT and press the ENT pushbutton.
The relay displays the PORT instances (the third screen of [Figure 4.21](#)).
- b. Choose the port you want to configure by using the Up Arrow and Down Arrow navigation pushbuttons to move the screen arrow.

For this example, select PORT F and press ENT.

Step 4. View the **Communications Settings** category screen.

- a. The relay shows the fourth screen of [Figure 4.21](#), the PORT F category screen. Use the Up Arrow and Down Arrow navigation pushbuttons to select the settings category.
- b. For this example, highlight **Communications Settings** and press ENT.

The relay displays the fifth screen of [Figure 4.21](#), the Communications Settings screen.

Step 5. Change settings.

- a. Highlight the SPEED setting.
- b. Press ENT.

(The relay possibly requires a password here; see [Passwords on page U.4.9](#) and [Section 5: Front-Panel Operations](#).)

The LCD displays the SPEED selection submenu that has all the possible choices for serial data speeds.

The highlight in the sixth screen of *Figure 4.21* indicates the default setting of 9600 (bps).

- c. Use the Up Arrow and Down Arrow navigation pushbuttons to select a different speed.
- d. Once you have selected a data speed, press the ENT pushbutton.

NOTE: Once you have changed communications parameters, you must change the corresponding parameters in your terminal emulation program to communicate with the relay via a communications port.

Step 6. End the settings session.

- a. The relay returns to the previous category settings list screen. Press ESC to return to the categories screen where you see the Save Settings item at the bottom of the screen.
- b. Use the Up Arrow and Down Arrow pushbuttons to highlight Save Settings and press ENT.
- c. Highlight YES, and then press ENT.

The relay validates the setting and returns to the PORT screen (the third screen of *Figure 4.21*).

Step 7. Press ESC repeatedly to return to the MAIN MENU.




Figure 4.21 SET/SHOW Menus

Examining Metering Quantities

The SEL-451 features high-accuracy power system metering. You can view fundamental and rms quantities by using a communications terminal, ACCELERATOR QuickSet, or the front panel. For more information on SEL-451 metering, see [Metering on page A.2.22](#).

View Metering: Terminal

The procedure in the following steps shows how to use a terminal or terminal emulation computer program to view power system metering. In this example, you connect specific voltages and currents for a 5 A, 60 Hz relay. Scale these quantities appropriately for your particular relay. For more information on testing the relay and making test connections, see [Section 6: Testing and Troubleshooting](#).

NOTE: If the relay is in service, disable any output circuits (such as trip and close) to avoid an unintended relay operation caused by test signals.

This example assumes that you have successfully established communication with the relay (see [Making an EIA-232 Serial Port Connection on page U.4.5](#)). In addition, you must be familiar with relay access levels and passwords (see [Changing the Default Passwords: Terminal on page U.4.9](#) to change the default access level passwords).

Step 1. Prepare to control the relay at Access Level 2.

- a. Using a communications terminal, type **ACC <Enter>**.
- b. Type the Access Level 1 password and press **<Enter>**.
You will see the Access Level 1 => prompt.
- c. Type the **2AC <Enter>** command.
- d. Type the correct password to go to Access Level 2.
You will see the Access Level 2 =>> prompt.

Step 2. Set the relay to a nominal operation mode.

- a. Use a terminal to perform the initial global settings relay setup in [Making Settings Changes: Initial Global Settings on page U.4.17](#).
- b. Set the relay for 60-Hz operation, ABC phase rotation.

Step 3. Set the relay for a basic voltage and current configuration (see [Figure 4.22](#)). Use the terminal to set global settings ESS := 1.

- a. Type **SET G ESS TERSE <Enter>**.
- b. Type **1 <Enter>** if the ESS setting is not 1 (See [Default Applications on page R.1.7](#)).
- c. Type **END <Enter>** to finish this settings session.
- d. Answer **Y <Enter>** to the save settings prompt.

```
=>>SET G ESS TERSE <Enter>
Global
Current and Voltage Source Selection
Current and Voltage Source Selection (Y,N,1,2,3,4)      ESS    := N    ? 1<Enter>
Line Current Source (IW,COMB)                            LINEI  := IW  ? END <Enter>
Save settings (Y,N) ? Y <Enter>
Saving Settings, Please Wait.....
Settings Saved
=>>
```

Figure 4.22 Setting ESS: Terminal

Step 4. Set CT and PT ratios. Use the terminal to set Group 1 setting CTRW := 200 (the current transformer W-input ratio), and PTRY := 2000 (the potential transformer Y-input ratio).

- a. Type **SET CTRW TERSE <Enter>**.
- b. If the CTRW setting is not 200, type **200 <Enter>**.
- c. Proceed as shown in *Figure 4.23* to PTRY and change PTRY to 2000, if needed.
- d. Type **END <Enter>** to finish this settings session.
- e. Answer **Y <Enter>** to the save settings prompt.

```
=>>SET CTRW TERSE <Enter>
Group 1

Line Configuration

Current Transformer Ratio - Input W (1-50000)      CTRW    := 120    ?200
Current Transformer Ratio - Input X (1-50000)      CTRX    := 120    ?
Potential Transformer Ratio - Input Y (1-10000)    PTRY    := 180    ?2000
PT Nominal Voltage (L-L) - Input Y (60-300 V,sec) VNOMY   := 115    ?END

Save settings (Y,N) ? Y<Enter>
Saving Settings, Please Wait.....
Settings Saved

=>>
```

Figure 4.23 Setting CTRW and PTRY: Terminal

Step 5. Turn the relay power off.

Step 6. Connect analog inputs.

- a. If three voltage sources and three current sources are available, connect the sources to the relay as shown in *Figure 4.24*.

If three voltage sources and two current sources are available, use the connection diagram of *Figure 4.25*.

- b. Apply 67 V per phase (line-to-neutral) in ABC phase rotation.
- c. Apply 2.0 A per phase, in phase with the applied phase voltages.




Figure 4.24 Test Connections Using Three Voltage Sources/Three Current Sources




Figure 4.25 Test Connections Using Two Current Sources for Three-Phase Faults and METER Test

Step 7. Turn the relay power on.

Step 8. View metering.

- Type ACC <Enter> to log-in to relay Access Level 1.
- Type your password and press <Enter>.
- Type MET <Enter>.

The relay displays the fundamental frequency (50 Hz or 60 Hz) metering information in a manner similar to that in [Figure 4.26](#).

```
=>>MET <Enter>

Relay 1                               Date: 02/26/2004 Time: 01:35:05.221
Station A                             Serial Number: 0000000000

Phase Currents
    IA      IB      IC
I MAG (A)   398.882  399.041  398.784
I ANG (DEG) -1.18    -120.97   119.21

Phase Voltages
    VA      VB      VC
V MAG (kV) 133.994  133.986  133.953
V ANG (DEG) -0.17   -120.02   120.18

Phase-Phase Voltages
    VAB     VBC     VCA
VAB          231.903  231.815  232.450
VBC          29.91   -89.92   150.01
VCA

Sequence Currents (A)
    I1      I2      I3
MAG        398.901  2.159   2.588
ANG (DEG) -0.98   -62.68   -115.80

Sequence Voltages (kV)
    V1      V2      V0
V1          133.977  0.692   0.713
V2          0.00    -53.25   -120.79
V0

A       B       C       3P
P (MW)  53.44   53.46   53.41   160.31
Q (MVAR) 0.95   0.89   0.91   2.75
S (MVA)  53.45   53.47   53.42   160.33
POWER FACTOR 1.00   1.00   1.00   1.00
LAG           LAG     LAG     LAG

FREQ (Hz) 60.00   VDC1(V) 125.00   VDC2(V) 48.00

=>
```

Figure 4.26 Terminal Screen MET Metering Quantities

The metering quantities of [View Metering: Terminal on page U.4.34](#) are the fundamental line quantities. Other variants of the MET command give different relay metering quantities. For example, you can see the line rms (harmonics-included) quantities by issuing the MET RMS command. See [Metering on page A.2.22](#) and [METER on page R.9.34](#) for more information on the MET command.

View Metering: ACSELERATOR QuickSet

Use the procedures in the following steps to examine the SEL-451 metering with the ACSELERATOR QuickSet HMI.

This example assumes that you have successfully established communication with the relay (see [Making an EIA-232 Serial Port Connection on page U.4.5](#)). In addition, you must be familiar with relay access levels and passwords (see [Changing the Default Passwords: Terminal on page U.4.9](#) to change the default access level passwords). You should also be familiar with ACSELERATOR QuickSet (see [Checking Relay Status: ACSELERATOR QuickSet on page U.4.11](#) and [Section 3: PC Software](#)).

- Step 1. Configure the communications port.
 - a. Start ACSELERATOR QuickSet.
 - b. On the top toolbar, open the **Communication** menu, and then click **Parameters**. You will see the **Communication Parameters** dialog box similar to [Figure 4.7](#).
 - c. Select the **Data Speed**, **Data Bits**, **Stop Bits**, **Parity**, and **RTS/CTS** that match the relay settings. The defaults are **9600, 8, 1, None, Off**, respectively.
 - d. Click **OK** to update the ACSELERATOR QuickSet communications parameters.
 - e. Confirm that the **Communications Status** bar at the bottom of the ACSELERATOR QuickSet window says **Connected**.

Step 2. Confirm the correct ACSELERATOR QuickSet passwords.

- a. Reopen the **Communication** menu and click **Parameters**.
- b. Enter your Access Level 1 password in the **Level One Password** text box, and your Access Level 2 password in the **Level Two Password** text box.
- c. Click **OK** to accept changes and close the dialog box.

Step 3. Set the relay to a nominal operation mode. Perform the initial global settings relay setup of [Making Initial Global Settings: ACSELERATOR QuickSet on page U.4.26](#) to set the relay for 60-Hz operation, ABC phase rotation.

Step 4. Set a basic voltage and current configuration.

- a. In the ACSELERATOR QuickSet **Settings** tree view, double-click the **Global** entry of the **Settings** tree view to expand the **Global** branch (see [Figure 4.27](#)).
- b. Click the **Current and Voltage Source Selection** branch.

You will see the **Current and Voltage Source Selection** dialog box of [Figure 4.27](#).

- c. Click the down button to select **1** for **ESS Current and Voltage Source Selection**.




Figure 4.27 Global Alternate Source Selection Settings in ACSELERATOR QuickSet

Step 5. Set PT and CT ratios.

- a. In the ACCELERATOR QuickSet **Settings** tree view, click the + mark next to **Group 1** to expand this branch (see *Figure 4.28*).
- b. Click the plus (+) mark next to **Set 1**.
- c. Click **Line Configuration**.
- You will see the **Line Configuration** window similar to *Figure 4.28*.
- d. Enter setting **CTRW Current Transformer Ratio - Input W** as **200**, and the **PTRY Potential Transformer Ratio - Input Y** as **2000**
- e. Save the settings and send the **Group 1** settings if you change the settings (see *Step 6* and *Step 7*).




Figure 4.28 Group 1 Terminal Configuration Settings: ACCELERATOR QuickSet

Step 6. Start the ACCELERATOR QuickSet operator interface.

Step 7. In the top toolbar HMI menu, click **Meter and Control**.

Step 8. Click the **Phasors** button of the HMI tree view (see *Figure 4.29*) to view phasors.

ACCELERATOR QuickSet displays fundamental line metering quantities with a display similar to *Figure 4.30*. (The test setup is adjusted for an approximately 30-degree lagging current.)




Figure 4.29 HMI Tree View: ACCELERATOR QuickSet




Figure 4.30 Phasor Metering Quantities: ACCELERATOR QuickSet HMI

Step 9. Click the **Instantaneous** button of the HMI tree view to see metering information similar to *Figure 4.30*.

View Metering: Front Panel

You can use the front-panel display and navigation pushbuttons to view the metering quantities of the SEL-451 (see *Meter on page U.5.16* for more information on viewing metering on the relay front panel). The screens in this procedure are for one circuit breaker, and this example assumes that you have not enabled the demand metering and synchronism check features.

Step 1. Prepare to use the front panel by applying power to the relay.

Note that the LCD shows a sequence of screens called the ROTATING DISPLAY. (If you do not operate the front panel for a certain period, the relay will enter front-panel time-out mode and you will see the sequential screens of the ROTATING DISPLAY.)

Step 2. Press the ENT pushbutton to display the MAIN MENU at the top of *Figure 4.31*.

Step 3. View the metering selection screen.

- Highlight the METER action item (see the first screen of *Figure 4.31*).
- Press the ENT pushbutton.

The relay displays the METER submenu (the second screen in *Figure 4.31*).

Step 4. View the metering screens.

- Press the Up Arrow and Down Arrow navigation pushbuttons to highlight the FUNDAMENTAL METER action item (see *Figure 4.31*, middle screen).
- Press the ENT pushbutton.

The relay displays the first FUNDAMENTAL METER screen (the third screen of *Figure 4.31*).

- c. Use the **Up Arrow** and **Down Arrow** navigation pushbuttons to move among the fundamental line quantities metering screens.

Step 5. Press the **ESC** pushbutton repeatedly to return to the **MAIN MENU**.




Figure 4.31 Front-Panel Screens for METER

Figure 4.32 illustrates how the SEL-451-4 provides front-panel metering information as well as bay label information in the pre-defined one-line diagram. Depending on the one-line diagram selected, up to six Analog Quantities can be displayed on the front panel. User-configurable labels are also available in the one-line diagram. See *Section 10: Settings in the Reference Manual* for configurable labels and Analog Quantity settings.




Figure 4.32 SEL-451-4 One-Line Diagram

Reading Oscillograms, Event Reports, and SER

The SEL-451 has great capabilities for storing and reporting power system events. These include high-resolution oscillography with sampling as high as 8 kHz, event reports that encompass important variables in the power system, and the SER that reports changing power system conditions and relay operating states.

You can view oscillograms taken from high-resolution raw data or from filtered event report data. Each type of presentation gives you a unique view of the power system. High-resolution oscillograms are useful for viewing system transients and dc artifacts outside the relay filter system; event report oscillograms give you a picture of the quantities that the relay used in the protection algorithms.

The examples listed in this subsection give step-by-step procedures to acquaint you with these features. [Section 3: Analyzing Data in the Applications Handbook](#) gives a complete discussion of these relay features.

Generating an Event

To view high-resolution raw data oscillograms and event reports, you must generate a relay event. High-resolution oscillography and event reports use the same event triggering methods. The relay uses three sources to initiate a data capture: Relay Word bit TRIP asserts, SELOGIC control equation ER (event report trigger), and the **TRI** command. (Factory default setup no longer includes the **PUL** command as an event report trigger. You can add the **PUL** command by entering the Relay Word bit TESTPUL in the ER SELOGIC control equation; see [Test Commands on page U.6.5](#).)

Triggering an Event

You can use an event trigger to initiate capturing power system data. The procedure in the following steps shows how to use the ACCELERATOR QuickSet HMI to generate the **TRI** command, which triggers an event capture. In this example, the relay uses default parameters to record the event. These parameters are at a sampling rate (SRATE) of 2000 samples per second (2 kHz), a pretrigger or prefault recording length (PRE) of 0.1 seconds, and an event report length (LER) of 0.5 seconds. See [Duration of Data Captures and Event Reports on page A.3.5](#) for complete information on changing these default settings to match your application.

This example assumes that you have successfully established communication with the relay (see [Making an EIA-232 Serial Port Connection on page U.4.5](#)). In addition, you must be familiar with relay access levels and passwords (see

Changing the Default Passwords: Terminal on page U.4.9 to change the default access level passwords). You should also be familiar with ACSELERATOR QuickSet (see *Checking Relay Status: ACSELERATOR QuickSet on page U.4.11* and *Section 3: PC Software*). In addition, you should perform *View Metering: Terminal on page U.4.34* to connect secondary test voltages and currents, and to set the relay to meter these quantities correctly.

- Step 1. Connect voltage and current sources to the relay secondary voltage and secondary current inputs (use the connections of *View Metering: Terminal on page U.4.34* and *Figure 4.24* or *Figure 4.25*).
- Step 2. Apply power to the relay and establish communication.
 - a. Start ACSELERATOR QuickSet.
 - b. On the top toolbar, open the **Communication** menu, and click **Parameters**. You will see the **Communication Parameters** dialog box similar to *Figure 4.7*.
 - c. Select the **Data Speed**, **Data Bits**, **Stop Bits**, **Parity**, and **RTS/CTS** that match the relay settings. The defaults are **9600, 8, 1, None, Off**, respectively.
 - d. Click **OK** to update the ACSELERATOR QuickSet communications parameters.
 - e. Confirm that the **Communications Status** bar at the bottom of the ACSELERATOR QuickSet window says **Connected**.
- Step 3. Confirm the correct ACSELERATOR QuickSet software passwords.
 - a. Reopen the **Communication** menu and click **Parameters**.
 - b. Enter your Access Level 1 password in the **Level One Password** text box, and your Access Level 2 password in the **Level Two Password** text box.
 - c. Click **OK** to accept changes and close the dialog box.

NOTE: The **Trigger New Event** button in the Event History dialog box may also be used. See *Figure 4.36*.

- Step 4. In the top toolbar HMI menu, click **Meter and Control** to start the ACSELERATOR QuickSet operator interface.

- Step 5. Click the **Control Window** button of the HMI tree view (see *Figure 4.33*).

ACSELERATOR QuickSet displays the **Control Window** similar to that in *Figure 4.34*.




Figure 4.33 ACSELERATOR QuickSet HMI Tree View




Figure 4.34 ACSELERATOR QuickSet HMI Control Window

Step 6. Trigger an Event.

- Click the **Event Trigger** box to trigger an event.
ACSELERATOR QuickSet displays a prompt in a dialog box similar to that in [Figure 4.35](#).
- Click **Yes** to trigger an event.



Figure 4.35 Event Trigger Prompt: ACSELERATOR QuickSet

Reading the Event History

The SEL-451 has two convenient methods for checking whether you successfully captured power system data. You can view the event history data with ACSELERATOR QuickSet, or you can examine internal relay file folders for the recorded data.

Reading the Event History: ACSELERATOR QuickSet

The procedure in the following steps shows how to use the ACSELERATOR QuickSet HMI to gather relay event history information. See [Event History on page A.3.34](#) for more information on event history.

This example assumes that you have successfully established communication with the relay (see [Making an EIA-232 Serial Port Connection on page U.4.5](#)). In addition, you must be familiar with relay access levels and passwords (see [Changing the Default Passwords: Terminal on page U.4.9](#) to change the default access level passwords). You should also be familiar with ACSELERATOR QuickSet (see [Checking Relay Status: ACSELERATOR QuickSet on page U.4.11](#) and [Section 3: PC Software](#)).

Step 1. Configure the communications port.

- Start ACCELERATOR QuickSet.
- On the top toolbar, open the **Communication** menu, and then click **Parameters**.

You will see the **Communication Parameters** dialog box similar to [Figure 4.7](#).

- Select the **Data Speed**, **Data Bits**, **Stop Bits**, **Parity**, and **RTS/CTS** that match the relay settings. The defaults are **9600, 8, 1, None, Off**, respectively.
- Click **OK** to update the ACCELERATOR QuickSet communications parameters.
- Confirm that the **Communications Status** bar at the bottom of the ACCELERATOR QuickSet window says **Connected**.

Step 2. Confirm that you have loaded the correct passwords in ACCELERATOR QuickSet.

- Enter your Access Level 1 password in the **Level One Password** text box, and your Access Level 2 password in the **Level Two Password** text box.
- Click **OK** to accept changes and close the dialog box.

Step 3. To view the event history report, open the ACCELERATOR QuickSet **Analysis** menu and click **View Event History**.

You will see the **Relay Event History** dialog box similar to that in [Figure 4.36](#).




Figure 4.36 Relay Event History Dialog Box

Reading the Event History: Terminal

The procedure in the following steps shows how to use the SEL-451 file structure to confirm that you captured power system data with an event trigger. This example assumes that you have successfully established communication with the relay (see [Making an EIA-232 Serial Port Connection on page U.4.5](#)). In addition, you must be familiar with relay access levels and passwords (see [Changing the Default Passwords: Terminal on page U.4.9](#) to change the default access level passwords).

Step 1. Prepare to monitor the relay at Access Level 1.

- Using a communications terminal, type **ACC <Enter>**.
- Type the Access Level 1 password and press **<Enter>**.

You will see the Access Level 1 => prompt.

Step 2. Type **HIS <Enter>** to examine the event history

You will see a screen display similar to [Figure 4.37](#).

```
=>HIS<Enter>
Relay 1                               Date: 03/03/2004 Time: 17:27:44.140
Station A                             Serial Number: 0000000000

#      DATE        TIME     EVENT   LOCAT   CURR GRP TARGETS
10024 03/03/2004 08:33:29.201 TRIP    $$$$.$$    0  1
10023 03/02/2004 15:41:35.777 ER      $$$$.$$    0  1
10022 03/02/2004 15:41:35.227 ER      $$$$.$$    0  1
10021 03/02/2004 15:41:34.577 ER      $$$$.$$    0  1
10020 03/02/2004 15:41:34.152 ER      $$$$.$$    0  1
10019 03/02/2004 15:41:32.702 ER      $$$$.$$    0  1
10018 02/24/2004 15:22:19.496 TRIG   $$$$.$$    1  3
10017 02/24/2004 15:22:17.705 TRIG   $$$$.$$    1  3
10016 02/23/2004 17:42:56.581 TRIG   $$$$.$$    1  3
10015 02/20/2004 19:23:41.369 BCG    0.02   3442  3
10014 02/20/2004 17:14:40.056 CA T    7.28    2449  3  TIME AFAULT CFAULT

=>>
```

Figure 4.37 Sample HIS Command Output: Terminal

For more information on the event history, see [Event History on page A.3.34](#).

Viewing High-Resolution Oscilloscopes

Once you have successfully generated an event, you can view high-resolution oscilloscopes and event report oscilloscopes about this event. When gathered from a field-installed relay, this information helps you assess power system operating conditions. In addition, when you first install the relay, this reporting information helps you confirm that you have connected the relay correctly.

The SEL-451 outputs high-resolution oscillography data in the binary COMTRADE file format (*IEEE/ANSI standard C37.111-1999*). File transfer is the only mechanism for retrieving high-resolution COMTRADE data from the relay.

The SEL-5601 Analytic Assistant is a program you can use to view COMTRADE data. Many third-party software suppliers can provide you with programs to display and manipulate COMTRADE files.

Retrieving High-Resolution COMTRADE Data: Terminal

The relay recorded the event triggered in [Triggering an Event on page U.4.43](#). The procedure in the following steps shows you how to retrieve the high-resolution raw oscillography data for this event.

Perform the steps listed in [Triggering an Event on page U.4.43](#) before executing the instructions in this example. For this procedure, you must use a communications terminal emulation computer program capable of file transfers (this function is not available in ACCELERATOR QuickSet).

If you need help finding a terminal emulation program, contact the SEL factory or your local Technical Service Center.

- Step 1. Prepare to monitor the relay at Access Level 1.
 - a. Using a communications terminal, type **ACC <Enter>**.
 - b. Type the Access Level 1 password and press **<Enter>**. You will see the Access Level 1 => prompt.

- Step 2. Type **FILE DIR EVENTS <Enter>** to view the contents of the SEL-451 events file directory.

The relay lists file names for recently recorded events in a manner similar to that shown in *Figure 4.38*.

The relay shows three high-resolution oscillography files with the file extensions .HDR, .CFG, and .DAT for each event.

This procedure uses HR_10014 as the number of the event that you recently triggered; use the event number corresponding to your triggered event.

```
->FILE DIR EVENTS
C4_10014.TXT      R  02/20/2004 17:14:40
C8_10014.TXT      R  02/20/2004 17:14:40
CHISTORY.TXT      R
E4_10014.TXT      R  02/20/2004 17:14:40
E8_10014.TXT      R  02/20/2004 17:14:40
HISTORY.TXT       R
HR_10014.CFG      R  02/20/2004 17:14:40
HR_10014.DAT      R  02/20/2004 17:14:40
HR_10014.HDR      R  02/20/2004 17:14:40
=>
```

Figure 4.38 EVENTS Folder Files

- Step 3. Type **FILE READ EVENTS HR_10014.* <Enter>** to ready the relay to transfer the HR_10014.HDR, HR_10014.CFG, and HR_10014.DAT files to your computer.

- Step 4. Download the files. Perform the steps necessary for your terminal emulation program to receive a file.

Typically, these are the file transfer steps:

- Specify the destination file location in your computer file storage system and file name.
- Select the transfer type as **Y-Modem** (if this transfer type is not already enabled).
- Click **Receive**.

You will usually see a confirmation message when the file transfer is complete.

When these files have transferred successfully, you have the entire COMTRADE file for the high-resolution raw data capture.

- Step 5. Use the SEL-5601 Analytic Assistant, ACSELERATOR QuickSet, or other COMTRADE-capable programs to play back high-resolution raw data oscillograms of the high-resolution raw data capture files you just transferred.

Retrieving High Resolution COMTRADE Data: ACCELERATOR QuickSet

The procedure in the following steps shows how to use ACCELERATOR QuickSet to view the event that you triggered in [Triggering an Event on page U.4.43](#). You can use this procedure to view other events stored in the SEL-451.

This example assumes that you have successfully established communication with the relay (see [Making an EIA-232 Serial Port Connection on page U.4.5](#)). In addition, you must be familiar with relay access levels and passwords (see [Changing the Default Passwords: Terminal on page U.4.9](#) to change the default access level passwords). You should also be familiar with ACCELERATOR QuickSet (see [Checking Relay Status: ACCELERATOR QuickSet on page U.4.11](#) and [Section 3: PC Software](#)).

Step 1. Configure the communications port.

- a. Start ACCELERATOR QuickSet.
- b. On the top toolbar, open the **Communication** menu, and then click **Parameters**. You will see the **Communication Parameters** dialog box similar to [Figure 4.7](#).
- c. Select the **Data Speed**, **Data Bits**, **Stop Bits**, **Parity**, and **RTS/CTS** that match the relay settings. The defaults are **9600, 8, 1, None, Off**, respectively.
- d. Click **OK** to update the ACCELERATOR QuickSet communications parameters.
- e. Confirm that the **Communications Status** bar at the bottom of the ACCELERATOR QuickSet window says **Connected**.

Step 2. Confirm the correct ACCELERATOR QuickSet passwords.

- a. Reopen the **Communication** menu and click **Parameters**.
- b. Enter your Access Level 1 password in the **Level One Password** text box, and your Access Level 2 password in the **Level Two Password** text box.
- c. Click **OK** to accept changes and close the dialog box.

Step 3. Open the ACCELERATOR QuickSet **Analysis** menu and click **View Event History** to view the Event History.

You will see the **Event History** dialog box similar to that shown in [Figure 4.39](#).




Figure 4.39 Relay Event History Dialog Box in ACSELERATOR QuickSet


Step 4. Get the event.

- a. Select Binary COMTRADE in the **Event Type** dialog box.
- b. Highlight the event you want to view and click the **Get Selected Event** button.
- c. After getting the event ACSELERATOR QuickSet prompts you to save the event file (.DAT) in a directory.
- d. Click Analysis > View Event Files and select the saved event file (.DAT).
- e. Press Open.

ACSELERATOR QuickSet then presents the window similar to that in [Figure 4.40](#) and the sample event oscilloscope of [Figure 4.41](#).



Figure 4.40 ACSELERATOR QuickSet Event Waveform Window

**Figure 4.41 Sample Event Oscillogram**

You can also examine a phasors display, an event harmonic analysis display, and the event summary from the **Event Waveform View** menu. See [Analyze Events on page U.3.16](#) and [Section 3: Analyzing Data in the Applications Handbook](#) for more information.

Viewing Event Report Data

Examine relay event reports to inspect the operating quantities the SEL-451 used at each triggered event. Unlike the raw data samples/second high-resolution oscillography files, these reports contain the filtered samples/cycle data the relay uses to make protection decisions. Event reports are useful for determining why the relay operated for a particular set of power system conditions. For more information on event reports, see [Event Report on page A.3.14](#).

Retrieving Event Report Data Files: Terminal

The relay recorded the event triggered in [Triggering an Event on page U.4.43](#). The procedure in the following steps shows you how to retrieve the event report data files for this event. Perform the steps listed in [Triggering an Event on page U.4.43](#) before executing the instructions in this example. For this procedure, you must use a terminal program capable of Ymodem protocol file transfer.

Step 1. Prepare to monitor the relay at Access Level 1.

- Using a communications terminal, type **ACC <Enter>**.
 - Type the Access Level 1 password and press **<Enter>**.
- You will see the Access Level 1 => prompt.

Step 2. Type **FILE DIR EVENTS <Enter>** to view the events file directory.

The relay lists file names for recently recorded events in a manner similar to that shown in [Figure 4.38](#).

In the figure, the relay shows two event report files: E4_10014.TXT and E8_10014.TXT, and two Compressed ASCII event report files: C4_10014.TXT and C8_10014.TXT.

Step 3. Type **FILE READ EVENTS C8_10014.TXT <Enter>** to transfer the Compressed ASCII event report file to your computer.

Step 4. Download the file. Perform the steps necessary for your terminal emulation program to receive a file.

Typically, these are the file transfer steps:

- Specify the destination file location in your computer file storage system and file name.
- Select the transfer type as **Y-Modem** (if not already enabled).
- Click **Receive**.

You will usually see a confirmation message when the file transfer is complete.

Step 5. When this file has transferred successfully, use the SEL-5601 Analytic Assistant to play back the event report oscilloscopes of the 8-samples/cycle event report file you just transferred.

Use the ASCII command **CEVENT** to retrieve event report files in Compressed ASCII format. See [SEL Compressed ASCII Commands on page R.5.4](#) and [CEVENT on page R.9.6](#) for more information.

Viewing SER Records

The relay SER records relay operating changes and relay element states. In response to an element change of state, the SER logs the element, the element state, and a time stamp. Program the relay elements that the relay stores in the SER records, thus capturing significant system events such as an input/output change of state, element pickup/dropout, recloser state changes, etc.

The SEL-451 stores the latest 1000 entries to a nonvolatile record. Use the relay communications ports or ACCELERATOR QuickSet to view the SER records. For more information on the SER, see [Section 3: Analyzing Data in the Applications Handbook](#).

The latest 200 SER events are viewable from the front panel. For more information, see [Section 5: Front-Panel Operations](#).

Setting the SER and Examining an SER Record: ACCELERATOR QuickSet

The procedure in the following steps shows you how to use ACCELERATOR QuickSet to program relay elements into the SER. Also, use these procedures to review SER records with ACCELERATOR QuickSet.

This example assumes that you have successfully established communication with the relay (see [Making an EIA-232 Serial Port Connection on page U.4.5](#)). In addition, you must be familiar with relay access levels and passwords (see [Changing the Default Passwords: Terminal on page U.4.9](#) to change the default access level passwords). You should also be familiar with ACCELERATOR QuickSet (see [Section 3: PC Software](#)).

Step 1. Configure the communications port.

- a. Start ACCELERATOR QuickSet.
- b. On the top toolbar, open the **Communication** menu, and then click **Parameters**.

You will see the **Communication Parameters** dialog box similar to [Figure 4.7](#).

- c. Select the **Data Speed**, **Data Bits**, **Stop Bits**, **Parity**, and **RTS/CTS** that match the relay settings.
The defaults are **9600, 8, 1, None, Off**, respectively.
- d. Click **OK** to update the ACCELERATOR QuickSet communications parameters.
- e. Confirm that the **Communications Status** bar at the bottom of the ACCELERATOR QuickSet window says **Connected**.

Step 2. Confirm the correct ACCELERATOR QuickSet passwords.

- a. Reopen the **Communication** menu and click **Parameters**.
- b. Enter your Access Level 1 password in the **Level One Password** text box, and your Access Level 2 password in the **Level Two Password** text box.
- c. Click **OK** to accept changes and close the dialog box.

Step 3. Download the present configuration in the SEL-451 by clicking **Settings > Read**.

The relay sends all configuration and settings data to ACCELERATOR QuickSet.

Step 4. Click the **Report** branch of the ACCELERATOR QuickSet **Settings** tree view structure (see *Figure 4.42*) to view the SER settings entry screen.

You will see the **SER Points and Aliases** window similar to *Figure 4.43*.




Figure 4.42 Selecting SER Points and Aliases Settings: ACCELERATOR QuickSet




Figure 4.43 SER Points and Aliases Settings: ACSELERATOR QuickSet

Step 5. Enter SER trigger settings.

- For this example, open the entry form by clicking in the icon beside the **SITM4 SER Points and Aliases, Point 4** entry field. We will change this SER point from reporting the status of the Circuit Breaker 2 Close Output (factory default setting) to reporting the operation of the Target Reset pushbutton.
- Click the icon beside the **Relay Word Bit** entry field.
- Select Target Logic Bits, and then double-click on TRGTR to copy the TRGTR name into the **Relay Word Bit** field. This also copies TRGTR to the **Reporting Name** (or alias) field.
- Type **Target Reset PB** in the **Reporting Name** field.
- Type **TEST** in the **Set State Name** field.
- Type **OFF** in the **Clear State Name** field.
- Click **OK**.

Step 6. Click **File > Save** to save the new settings in ACSELERATOR QuickSet.

Step 7. Upload the new settings to the SEL-451.

- Click **File > Send**.

ACSELERATOR QuickSet prompts you for the settings class you want to send to the relay, as shown in the first dialog box of [Figure 4.44](#).

- Click the **Report** check box.
- Click **OK**.

ACSELERATOR QuickSet responds with the second dialog box of [Figure 4.44](#).

If you see no error message, the new settings are loaded in the relay.




Figure 4.44 Uploading Report Settings to the SEL-451

Step 8. Press and release the front-panel **TARGET RESET** pushbutton to generate an SER record.

Step 9. View the SER report.

- Start the ACSELERATOR QuickSet operator interface.
- In the top toolbar Tools menu, click **Meter and Control**.
- Click the **SER** button of the HMI tree view (see [Figure 4.45](#)).

ACSELERATOR QuickSet displays the SER records with a display similar to [Figure 4.46](#).




Figure 4.45 Retrieving SER Records With ACSELERATOR QuickSet




Figure 4.46 SER Records in the ACSELERATOR QuickSet HMI

The relay lists the SER records in chronological order from top to bottom as shown in *Figure 4.46*. In addition, the relay numbers each record with the most recent record as number 1; new events are usually more important for determining the effects of recently occurring power system events.

For each application of power to the relay, the SER reports a “Power-up” indication and the active settings group (**Group 1** in *Figure 4.46*). A properly operating relay immediately goes to the enabled state, an event that causes the SER to report another SER record. The SER reports the **TARGET RESET** button when you press the pushbutton. For more information on the Sequential Events Recorder, see *SER (Sequential Events Recorder) on page A.3.42*.

Setting the SER and Examining the SER Record: Terminal

The procedure in the following steps shows how to use a terminal connected to an SEL-451 communications port to set an element in the SER. Use text edit mode line editing to enter the SER settings (see *Text-Edit Mode Line Editing on page U.4.19*). Also included is a procedure for viewing the SER report with a terminal. For more information on the SER, see *SER (Sequential Events Recorder) on page A.3.42*.

This example assumes that you have successfully established communication with the relay (see *Making an EIA-232 Serial Port Connection on page U.4.5*). In addition, you must be familiar with relay access levels and passwords (see *Changing the Default Passwords: Terminal on page U.4.9* to change the default access level passwords).

Step 1. Prepare to control the relay at Access Level 2.

- Using a communications terminal, type **ACC <Enter>**.
- Type the Access Level 1 password and press **<Enter>**. You will see the Access Level 1 => prompt.
- Type the **2AC <Enter>** command.
- Type the correct password to go to Access Level 2. You will see the Access Level 2 =>> prompt.

Step 2. Enter SER trigger data.

- Type **SET R TERSE <Enter>** to access the **Report** settings (see *Figure 4.47*).

- b. Press <Enter> to move past the **SER Chatter Criteria** setting.
- c. At the **SER Points and Aliases** prompt line, type the following:
TRGTR,“TARGET RESET PB”,TEST,OFF,N
<Enter>. At the next line, type **END <Enter>**.
- d. The relay prompts you to save the new setting; type **Y** <Enter>.

```
=>>SET R TERSE <Enter>
Report
SER Chatter Criteria
Automatic Removal of Chattering SER Points (Y,N)   ESERDEL := N ? <Enter>

SER Points
(Relay Word Bit, Reporting Name, Set State Name, Clear State Name, HMI Alarm)

1:
? TRGTR,“TARGET RESET PB”,TEST,OFF,N
2:
? END <Enter>

Save settings (Y,N) ? Y <Enter>
Saving Settings, Please Wait.....
Settings Saved
=>>
```

Figure 4.47 Setting an SER Element: Terminal

- Step 3. Press and release the front-panel **TARGET RESET** pushbutton to generate an SER record.
- Step 4. Type **SER <Enter>** (at the Access Level 1 prompt or higher) to view the SER report.

The relay presents a screen similar to the SER display of [Figure 4.46](#).

Downloading an SER Report File

The procedure in the following steps shows you how to retrieve the SER report stored in the relay as a file. For this procedure, you must use a terminal emulation program with file transfer capability. For more information on the SER, see [SER \(Sequential Events Recorder\) on page A.3.42](#).

- Step 1. Prepare to monitor the relay at Access Level 1.
 - a. Using a communications terminal, type **ACC <Enter>**.
 - b. Type the Access Level 1 password and press <Enter>. You will see the Access Level 1 => prompt.
- Step 2. Type **FILE DIR REPORTS <Enter>** to view the events file directory.
The terminal lists the file names for standard reports as shown in [Figure 4.48](#).
- Step 3. Prepare the relay to download the SER report.
 - a. Type **FILE READ REPORTS SER.TXT <Enter>**.
 - b. If you want the Compressed ASCII file, type the following:
FILE READ REPORTS CSER.TXT <Enter>

```
=>FILE DIR REPORTS <Enter>
BRE_1.TXT          R
BRE_2.TXT          R
BRE_S1.TXT         R
BRE_S2.TXT         R
CBRE_.TXT          R
CHISTORY.TXT       R
CSER.TXT           R
HISTORY.TXT        R
SER.TXT            R
=>
```

Figure 4.48 Reports File Structure

- Step 4. Download the SER report. Perform the steps necessary for your terminal emulation program to receive a file.

Typically, these are the file transfer steps:

- Specify the destination file location in your computer file storage system and file name.
- Select the transfer type as **Y-Modem** (if not already enabled).
- Click **Receive**.

You will usually see a confirmation message when the file transfer is complete.

- Step 5. When the SER.TXT file has transferred successfully, use a word-processing program to view the contents of the file.

You will see the SER records in a format similar to [Figure 4.46](#).

The CSER.TXT file viewed with a word-processing program is similar to the example in CSER, SER (Sequential Events Recorder), in [CSER on page A.3.44](#).

Operating the Relay Inputs and Outputs

The SEL-451 gives you great ability to perform control actions at bay and substation locations via the relay control outputs. The control outputs close and open circuit breakers, switch disconnects, and operate auxiliary station equipment such as fans and lights. The relay reads data from the power system and interfaces with external signals (contact closures and data) through the control inputs. This subsection is an introduction to operating the SEL-451 control outputs and control inputs. For more information on connecting and applying the control outputs and control inputs, see [Section 2: Installation](#).

Control Output

The SEL-451 features Standard, Hybrid (High-Current Interrupting), and Fast Hybrid (Fast High-Current Interrupting) control outputs that you can use to control circuit breakers and other devices in an equipment bay or substation control house. See [Control Outputs on page U.2.8](#) for more information on control outputs.

Pulsing a Control Output: Terminal

When first connecting the relay, or at any time that you want to test relay control outputs, perform the following procedure. The procedure in the following steps shows how to use a communications terminal to pulse the

control output contacts. Perform the steps in this example to become familiar with relay control and serial communication. For more information on the **PULSE** command, see *PULSE on page R.9.43*.

This example assumes that you have successfully established communication with the relay; see *Making an EIA-232 Serial Port Connection on page U.4.5* for a step-by-step procedure. In addition, you must be familiar with relay access levels and passwords (see *Changing the Default Passwords: Terminal on page U.4.9* to change the default access level passwords).

NOTE: To pulse an output, the circuit breaker control enable jumper, J18C, must be installed on the main board.

Step 1. Prepare to control the relay at Access Level B.

- a. Using a communications terminal, type **ACC <Enter>**.
- b. Type the Access Level 1 password and press **<Enter>**.
You will see the Access Level 1 => prompt.
- c. Type the **BAC <Enter>** command.
- d. Type the correct password to go to Access Level B.

You will see the Access Level 1 => prompt.

Step 2. Attach an indicating device (ohmmeter with a beep sounder or a test set) to the terminals for control output OUT104.

This output is a Standard control output and is not polarity sensitive.

For more information on connecting control outputs, see *Control Outputs on page U.2.8*.

Step 3. Perform the pulse operation.

- a. Type **PULSE OUT104 <Enter>**.
The relay confirms your request to pulse an output with a prompt such as that shown in *Figure 4.49*.
- b. Type **Y <Enter>** at the prompt.
You will see or hear the indicating device turn on for a second and then turn off.

```
-->PULSE OUT104 <Enter>
Pulse contact OUT104 for 1 seconds(Y/N) ? Y <Enter>
-->
```

Figure 4.49 Terminal Display for PULSE Command

You can also pulse an output for longer than the default 1-second period. If you enter a number after the **PULSE** command, that number specifies the duration in seconds for the pulse. For example, if you enter **PULSE OUT104 3 <Enter>**, the relay pulses OUT104 for 3 seconds.

Pulsing a Control Output: Front Panel

The procedure in the following steps shows you how to use the front-panel display and navigation pushbuttons to check for proper operation of the SEL-451 control outputs. See [Section 5: Front-Panel Operations](#) for information on using the relay front panel.

- Step 1. Attach an indicating device (an ohmmeter with a beep sounder or a test set) to the terminals for control output OUT104.

This output is a Standard control output and is not polarity sensitive.

For more information on connecting control outputs, see [Control Outputs on page U.2.8](#).

- Step 2. View the front-panel display.

After applying power to the relay, note that the LCD shows a sequence of screens called the ROTATING DISPLAY.

(Also, if you do not operate the front panel for a certain period, the relay will enter front-panel time-out mode and you will see the sequential screens of the ROTATING DISPLAY.)

- Step 3. Press the ENT pushbutton to view the MAIN MENU, similar to that at the top of [Figure 4.50](#).




Figure 4.50 Front-Panel Menus for Pulsing OUT104

- Step 4. View the local control screen.

- Press the Up Arrow and Down Arrow navigation pushbuttons to highlight the LOCAL CONTROL action item (see [Figure 4.50](#)).

- b. Press the **ENT** pushbutton.

You will see the LOCAL CONTROL submenu (the middle screen in *Figure 4.50*).

Step 5. View the output testing screen.

- Press the **Up Arrow** and **Down Arrow** navigation pushbuttons to highlight the --OUTPUT TESTING-- action item (see *Figure 4.50*, middle screen).
- Press the **ENT** pushbutton.

The relay next displays the OUTPUT TESTING submenu (the last screen of *Figure 4.50*).

Step 6. Command the relay to pulse the control output.

- Press the **Up Arrow** and **Down Arrow** navigation pushbuttons to highlight OUT104 (see *Figure 4.50*, last screen).
- Press the **Right Arrow** navigation pushbutton to highlight YES under PULSE OUTPUT?
- Press the **ENT** pushbutton.

The relay detects your request for a function at an access level for which you do not yet have authorization. Whenever this condition occurs, the relay displays the password access screen of *Figure 4.51*.




Figure 4.51 Password Entry Screen

Step 7. Input a password and pulse the output.

- Enter a valid Access Level B, P, A, O, or 2 password.
(The front panel is always at Access Level 1, so you do not enter the Access Level 1 password.)

Enter a valid password by using the navigation pushbuttons to select, in sequence, the alphanumeric characters that correspond to your password.

- Press the **ENT** pushbutton at each password character.
(If you make a mistake, highlight the BACKSPACE option and press **ENT** to reenter a character or characters.)
- After entering all password characters, press the **Up Arrow** or **Down Arrow** pushbuttons to highlight **ACCEPT**, and press **ENT**.

The relay pulses the output, and you will see the indicating device turn on for a second and then turn off.

Controlling a Relay Control Output With a Local Bit: Terminal

In this example, you set Local Bit 3 to start the transformer cooling fans near the breaker bay where you have installed the SEL-451. Thus, you can use the LCD screen and navigation pushbuttons to toggle relay Local Bit 3 to control the state of the cooling fans. Relay Word bit LB_SP03 provides supervision for local bit 3. Relay Word bit LB_SP03 must be asserted for successful Local Bit 3 operations. For more information on local bits, see [Local Control Bits on page U.5.25](#).

The procedure in the following steps proposes connecting the transformer bank fan control to relay output OUT105. You can choose any relay output that conforms to your requirements. See [Control Outputs on page U.2.8](#) for more information on SEL-451 control outputs.

This example assumes that you have successfully established communication with the relay (see [Making an EIA-232 Serial Port Connection on page U.4.5](#)). In addition, you must be familiar with relay access levels and passwords (see [Changing the Default Passwords: Terminal on page U.4.9](#) to change the default access level passwords).

Step 1. Prepare to control the relay at Access Level 2.

- a. Using a communications terminal, type **ACC <Enter>**.
- b. Type the Access Level 1 password and press **<Enter>**.
You will see the Access Level 1 => prompt.
- c. Type the **2AC <Enter>** command.
- d. Type the correct password to go to Access Level 2.
You will see the Access Level 1 =>> prompt.

Step 2. Access the local control settings.

- a. Type **SET F <Enter>** command.
- b. Repeatedly type **>** and then **<Enter>** to advance through the front-panel settings until you reach the **Display Points and Aliases** category.
- c. Press **<Enter>** to access the **Control Points and Aliases Category**.

Figure 4.52 shows a representative terminal screen.

```

Control Points and Aliases
(Local Bit, Local Name, Local Set State, Local Clear State, Pulse Enable)

1:
? LIST <Enter>

1:
? LB03,"5 MVA XFMR Fans",ON,OFF,N <Enter>
2:
? END <Enter>

.

.

Control Points and Aliases
(Local Bit, Local Name, Local Set State, Local Clear State, Pulse Enable)

1: LB03,"5 MVA XMFR Fans","ON","OFF",N
Save settings (Y,N) ? Y <Enter>
Saving Settings, Please Wait.....
Settings Saved
=>>

```

Figure 4.52 Using Text-Edit Mode Line Editing to Set Local Bit 3

- Step 3. Type **LIST <Enter>** at the **Local Control and Aliases** prompt to list the active control points.

This example assumes that you are using no local bits, so the relay returns you to line 1: followed by the settings ? prompt.

- Step 4. Type **LB03,“5 MVA XFMR Fans”,ON,OFF,N <Enter>** at the line 1 prompt:

1: LB03,“5 MVA XFMR Fans”,ON,OFF,N <Enter>

The relay checks that this is a valid entry and responds with the next line prompt 2: followed by the settings ? prompt.

- Step 5. End the settings session.

- a. Type **END <Enter>**.

The relay scrolls a readback of all the front-panel settings, eventually displaying the **Save settings (Y,N) ?** prompt. (In *Figure 4.52* a vertical ellipsis represents the readback.)

At the end of the readback information, just before the **Save settings (Y,N) ?** prompt, you can see the new local bit information.

- b. Answer **Y <Enter>** to save your new settings.

- Step 6. Set OUT105 to respond to Local Bit 3.

- Type **SET O OUT105 <Enter>** (see *Figure 4.53*).
- At the ? prompt, type **LB03 <Enter>**.
- At the next ? prompt, type **END <Enter>**.
- When prompted to save settings, answer **Y <Enter>**.

```
=>>SET O OUT105 <Enter>
Output
Main Board
OUT105 := NA
? LB03 <Enter>
OUT106 := NA
? END <Enter>
Output
Main Board
OUT101 := T3P1 #BREAKER 1 TRIP
OUT102 := T3P1 #EXTRA BREAKER 1 TRIP
OUT103 := BK1CL #BREAKER 1 CLOSE
OUT104 := NA
OUT105 := LB03
OUT106 := NA
OUT107 := NA
OUT108 := NOT (HALARM OR SALARM)

Save settings (Y,N) ? Y <Enter>
Saving Settings, Please Wait.....
Settings Saved
=>>
```

Figure 4.53 Setting Control Output OUT105: Terminal

- Step 7. Test the connection and programming.

- Use the appropriate interface hardware to connect the fan control start circuit to OUT105.
- At the relay front-panel **MAIN MENU**, select **LOCAL CONTROL** and press the **ENT** pushbutton (see *Figure 4.54*).

c. Select 5 MVA XFMR Fans on the LOCAL CONTROL screen as shown in [Figure 4.54](#).

d. Press ENT to see the last screen of [Figure 4.54](#).

e. Highlight 1 ON and press ENT.

The graphical local control handle moves to the 1 position. At this time, the transformer fans will begin running.




Figure 4.54 Front-Panel LOCAL CONTROL Screens

Setting Outputs for Tripping and Closing

To actuate power system circuit breakers, you must configure the SEL-451 control outputs to operate the trip bus and close bus. The relay uses internal logic and SELOGIC control equations to activate the control outputs.

Trip Output Signals

The SEL-451 is capable of three-pole tripping. There are many Relay Word bits (e.g., T3P1, T3P2, and 3PT) that you can program to drive control outputs to trip circuit breakers. See [Section 1: Protection Functions in the Reference Manual](#) for complete information on tripping equations and settings. For target illumination at tripping, see [Section 5: Front-Panel Operations](#).

Close Output Signals

The SEL-451 features an automatic recloser for single circuit breaker and two circuit breaker applications. The relay provides as many as four auto-reclose shots. See [Section 2: Auto-Reclosing and Synchronism Check in the Reference Manual](#) for more information.

Close the circuit breakers using Relay Word bits BK1CLS and BK2CLS for Circuit Breaker 1 and Circuit Breaker 2, respectively.

Assigning Control Outputs for Tripping and Closing

The procedure in the following steps shows a method for setting the relay to operate the trip bus and the close bus at a typical substation. Relay factory defaults assign control outputs OUT101 and OUT102 to the trip bus and OUT103 to the close bus for a three-pole tripping circuit breaker. This procedure assigns an additional close output at OUT106.

This example assumes that you have successfully established communication with the relay (see [Making an EIA-232 Serial Port Connection on page U.4.5](#)). In addition, you must be familiar with relay access levels and passwords (see [Changing the Default Passwords: Terminal on page U.4.9](#) to change the default access level passwords). You should also be familiar with ACSELERATOR QuickSet (see [Section 3: PC Software](#)).

Step 1. Configure the communications port.

- Start ACSELERATOR QuickSet.
- On the top toolbar, open the **Communication** menu, and then click **Parameters**.

You will see the **Communication Parameters** dialog box similar to [Figure 4.7](#).

- Select the **Data Speed**, **Data Bits**, **Stop Bits**, **Parity**, and **RTS/CTS** that match the relay settings.
The defaults are **9600, 8, 1, None, Off**, respectively.
- Click **OK** to update the ACSELERATOR QuickSet communications parameters.
- Confirm that the **Communications Status** bar at the bottom of the ACSELERATOR QuickSet window says **Connected**.

Step 2. Confirm the correct ACSELERATOR QuickSet passwords.

- Reopen the **Communication** menu and click **Parameters**.
- Enter your Access Level 1 password in the **Level One Password** text box, and your Access Level 2 password in the **Level Two Password** text box.
- Click **OK** to accept changes and close the dialog box.

Step 3. Click **Settings > Read**.

The relay sends all configuration and settings data to ACSELERATOR QuickSet.

Step 4. Access the **Main Board** output settings.

- Expand the **Outputs** branch of the **Settings** tree view.
- Click **Main Board** (see [Figure 4.55](#)).




Figure 4.55 Assigning an Additional Close Output: ACSELERATOR QuickSet

Step 5. Assign a control output for the close bus.

- In the **Main Board Outputs** dialog box, click the **OUT106** text box and type the following:

BK1CL #ADDITIONAL BREAKER 1 CLOSE

(The # indicates that a comment follows.)

- Click or tab to another text box.

ACSELERATOR QuickSet checks that your entry is valid.

Step 6. Click **File > Save** to save the new settings in ACSELERATOR QuickSet.

Step 7. Upload the new settings to the SEL-451.

- Click **File > Send**.


ACSELERATOR QuickSet prompts you for the settings class or instance you want to send to the relay.

- Click the check box for **Outputs** as shown in the first dialog box of [Figure 4.56](#).

- Click **OK**.

ACSELERATOR QuickSet responds with the second dialog box of [Figure 4.56](#).

If you see no error message, the new settings are loaded in the relay.

**Figure 4.56 Uploading Output Settings to the SEL-451**

Control Input Assignment

The SEL-451 relay has control inputs on the main board (IN101–IN107), and on one or two optional I/O interface boards (IN201–IN2xx, IN301–IN3xx), if so equipped. See [Control Inputs on page U.2.6](#) for detailed information.

There are two types of input circuitry: Direct Coupled and Optoisolated. [Table 4.8](#) lists the main differences between the two types of control inputs.

Table 4.8 Control Inputs in the SEL-451

	Direct-Coupled	Optoisolated
Pickup characteristics:	Pickup voltage can be selected via Global settings. Can have different pickup voltages on each input.	Pickup voltage is determined by hardware: one of six voltage levels determined at time of factory order. All pickup voltages are the same on each I/O interface board.
Polarity-sensitive:	Yes (will not respond to reverse polarity signals). A + polarity mark is printed over the positive terminals.	No (will respond to signals of either polarity). No polarity mark. AC signal detection is possible. ^a
Where found:	<ul style="list-style-type: none"> ► SEL-451 Main Board A (IN101–IN107) ► INT1, INT5, and INT6 I/O Interface Boards (IN201–IN208; IN301–IN308) 	<ul style="list-style-type: none"> ► SEL-451 Main Board B (IN101–IN107) ► INT2, INT7, and INT8 I/O Interface Boards (IN201–IN208; IN301–IN308) ► INT4 I/O Interface Board (IN201–IN224; IN301–IN324)

^a With appropriate debounce settings—see [Table 2.2](#).

The default value for Global setting EICIS (Enable Independent Control Input Settings) is N, which hides all individual control input settings, and only presents some overall settings that will apply to all control inputs. Set EICIS := Y to gain full access to the individual control input settings. For information on the Global settings related to control inputs, see [Table 9.5 on page R.9.3](#), and [Table 9.7 on page R.9.4](#) through [Table 9.12 on page R.9.5](#).

The following exercises use Direct-Coupled control inputs on Main Board A.

Setting a Control Input: Circuit Breaker Auxiliary Contacts (52A): Terminal

This is a step-by-step procedure to configure a control input that reflects the state of the circuit breaker auxiliary (52A) NO (normally open) contact. A common relay input is from circuit breaker auxiliary contacts; the relay monitors the 52A contacts to detect the closed/open status of the circuit breaker. Perform the following steps to connect three-pole circuit breaker auxiliary contacts to the SEL-451. This example is for a 125 Vdc system; the open state of the auxiliary contacts is 0 Vdc (circuit breaker open), and the closed state of the auxiliary contacts is approximately 125 Vdc (circuit breaker closed). The voltage drop in the connecting wires from the auxiliary contacts through the station battery to the relay gives a slightly lower voltage than the station battery at the relay control input terminals. Make the control input pickup, dropout, and debounce timer settings as explained in [Control Inputs on page U.2.6](#).

This example assumes that you have successfully established communication with the relay (see [Making an EIA-232 Serial Port Connection on page U.4.5](#)). In addition, you must be familiar with relay access levels and passwords (see [Changing the Default Passwords: Terminal on page U.4.9](#) to change the default access level passwords).

Step 1. Prepare to control the relay at Access Level 2.

- a. Using a communications terminal, type **ACC <Enter>**.
- b. Type the Access Level 1 password and press **<Enter>**.
You will see the => action prompt.
- c. Type the **2AC <Enter>** command.
- d. Type the correct password to go to Access Level 2.
You will see the Access Level 2 =>> prompt.

Step 2. Configure the relay to read the circuit breaker auxiliary contact.

- a. Type **SET M <Enter>** (see [Figure 4.57](#)).
These settings are the breaker monitor settings.
- b. Type **<Enter>** to bypass the Breaker 1 Monitoring enable, and **<Enter>** again to bypass the Breaker 2 Monitoring enable (NUMBK := 2 in this example).
The relay displays the 52AA1 SELOGIC control equation action prompt.
- c. Type **IN101 <Enter>** at the ? prompt to specify input IN101 as the control input that represents the close/open state of Circuit Breaker 1.
The relay next displays the 52AA2 SELOGIC control equation action prompt.
- d. Type **IN102 <Enter>** at the ? prompt to specify input IN102 as the control input that represents the close/open state of Circuit Breaker 2.

Step 3. End the settings process. The relay next scrolls a readback of all the Global settings, eventually displaying the **Save settings (Y,N) ?** prompt.

- a. In the readback information, just before the **Save settings (Y,N) ?** prompt, confirm the new control input information.
- b. Answer **Y <Enter>** to save your new settings.

```
=>>SET M <Enter>
Breaker Monitor
Breaker Configuration
Breaker 1 Monitoring (Y,N) EB1MON := N ? <Enter>
Breaker 2 Monitoring (Y,N) EB2MON := N ? <Enter>
Breaker 1 Inputs
N/O Contact Input -BK1 (SELLogic Equation)
52AA1 := NA
? IN101 <Enter>
Breaker 2 Inputs
N/O Contact Input -BK2 (SELLogic Equation)
52AA2 := NA
? IN102 <Enter>
Breaker Monitor
Breaker Configuration
EB1MON := N EB2MON := N
Breaker 1 Inputs
52AA1 := IN101
Breaker 2 Inputs
52AA2 := IN102
Save settings (Y,N) ? Y <Enter>
Saving Settings, Please Wait.....
Settings Saved
=>>
```

Figure 4.57 Setting 52AA1: Terminal

Setting a Control Input for Circuit Breaker Auxiliary Contacts (52A): ACSELERATOR QuickSet

The procedure in the following steps shows how to program the SEL-451 control input IN101 to read the state of circuit breaker auxiliary contacts. This example uses a single three-pole tripping breaker. Modify the procedure listed here for your application.

This example assumes that you have successfully established communication with the relay (see [Making an EIA-232 Serial Port Connection on page U.4.5](#)). In addition, you must be familiar with relay access levels and passwords (see [Changing the Default Passwords: Terminal on page U.4.9](#) to change the default access level passwords). You should also be familiar with ACSELERATOR QuickSet (see [Section 3: PC Software](#)).

- Step 1. Configure the communications port.
 - a. Start ACSELERATOR QuickSet.
 - b. On the top toolbar, open the **Communication** menu, and then click **Parameters**. You will see the **Communication Parameters** dialog box similar to [Figure 4.7](#).
 - c. Select the **Data Speed**, **Data Bits**, **Stop Bits**, **Parity**, and **RTS/CTS** that match the relay settings. The defaults are **9600, 8, 1, None, Off**, respectively.
 - d. Click **OK** to update the ACSELERATOR QuickSet communications parameters.
 - e. Confirm that the **Communications Status** bar at the bottom of the ACSELERATOR QuickSet window says **Connected**.

Step 2. Confirm the correct ACSELERATOR QuickSet passwords.

- Reopen the **Communication** menu and click **Parameters**.
- Enter your Access Level 1 password in the **Level One Password** text box, and your Access Level 2 password in the **Level Two Password** text box.
- Click **OK** to accept changes and close the dialog box.

Step 3. On the **Settings** menu, click **Read**.

The relay sends all configuration and settings data to ACSELERATOR QuickSet.

Step 4. Access the **Control Input** settings.

- Click the + mark next to the **Global** branch of the **Settings** tree view.
- Click the + mark next to the **Control Inputs** branch of the **Settings** tree view, and click the **Control Inputs** branch (see *Figure 4.58*).

Step 5. Set EICIS Independent Control Input Settings to Y.




Figure 4.58 Accessing Control Inputs Settings in ACSELERATOR QuickSet

Step 6. Access the **Control Inputs** settings.

- Expand the **Main Board** branch by clicking the + button next to **Main Board**.
- Click **Mainboard Pickup Levels**. You will see the input window similar to that in *Figure 4.59*.
- Click **Mainboard Pickup** and **Dropout Delay**. You will see the input window similar to that in *Figure 4.60*.




Figure 4.59 Control Input Pickup Level Settings in ACSELERATOR QuickSet

Step 7. Set the control input IN101 pickup threshold.

For this example, a 125 Vdc station battery is providing the control voltage. Referring to [Table 2.1 on page U.2.6](#), the appropriate pickup voltage settings is 100 Vdc. Click the mouse cursor (or press <Tab>) to highlight **IN101P Main Board Input 101 Assertion Level**.

- Delete the present setting by pressing <Delete>.
- Type **100**, and then click or <Tab> to another value.

The relay checks the new value and enters the value in the ACSELERATOR QuickSet database.




Figure 4.60 Control Input Pickup and Dropout Delay Settings in ACSELERATOR QuickSet

Step 8. Set the control input IN101 debounce time.

For this example, assume that the auxiliary contacts are slow and noisy; you must provide a slightly longer debounce time for these contacts.

- a. Double-click the mouse cursor (or press <Tab>) to highlight **IN101PU Input IN101 pickup delay**.
- b. Delete the present setting by pressing <Delete>.
- c. Type **0.25 <Enter>**.
- d. Similarly change the **IN101DO Input IN101 Dropout Delay** to **0.25**.

The relay checks the new value and enters the value in the ACSELERATOR QuickSet database.

Step 9. Configure the relay to read the circuit breaker auxiliary contact.

- a. Expand the **Breaker Monitor** branch of the **Settings** tree view by clicking the + button (see *Figure 4.61*).
- b. In the tree view, click **Breaker 1** to select circuit breaker monitor settings for Circuit Breaker 1.
- c. Set the 52AA1 SELOGIC control equation by clicking in the text box labeled **N/O Contact Input -BK1**.
- d. Type **IN101**, and then click or <Tab> to another field to specify input IN101 as the control input that represents the close/open state of Circuit Breaker 1.




Figure 4.61 Setting 52AA1 in ACSELERATOR QuickSet

Step 10. Click **File > Save** to save the new settings in ACSELERATOR QuickSet.

Step 11. Upload the new settings to the SEL-451.

- a. Click **File > Send**.

ACSELERATOR QuickSet prompts you for the settings class or instance you want to send to the relay

- b. Click the **Global** check box and the **Breaker Monitor** check box, as shown in the first dialog box of *Figure 4.62*.
- c. Click **OK**.
- d. ACCELERATOR QuickSet responds with the second dialog box of *Figure 4.62*.

If you see no error message, the new settings are loaded in the relay.



Figure 4.62 Uploading Global and Breaker Monitor Settings to the SEL-451

Configuring High-Accuracy Timekeeping

The SEL-451 features high-accuracy timekeeping when supplied with an IRIG-B signal. When the supplied clock signal is sufficiently accurate, the SEL-451 can act as a Phasor Measurement Unit (PMU) and transmit synchrophasor data representative of the power system at fixed time periods to an external data processor. The relay can also record COMTRADE event report data using the high-accuracy time stamp. See *Synchrophasors on page R.7.1*, *Oscillography on page A.3.7*, and *Time-Synchronized Measurements on page A.4.1* for details on these applications.

IRIG-B

The SEL-451 has two input connectors that accept IRIG-B (Inter-Range Instrumentation Group-B) demodulated time-code format: the IRIG-B pins of Serial Port 1, and the IRIG-B BNC connector—see *TIME Input Connections on page U.2.45*.

The IRIG-B BNC connector can be used for high-accuracy timekeeping purposes, with up to 1 μ s accuracy with an appropriate time source. Either input can be used for general-purpose timekeeping, and the relay will have up to 500 μ s accuracy. See *Table 4.9* for SEL-451 timekeeping mode details.

NOTE: The SEL-2407 Satellite-Synchronized Clock meets both the SEL-451 accuracy and IEEE C37.118 requirements for a high-accuracy time source.

Table 4.9 SEL-451 Timekeeping Modes

Item	Internal clock	IRIG	HIRIG (or High-Accuracy IRIG)
Best accuracy (condition)	Depends on last method of setting, or synchronization ^a	500 µs (when time source jitter is less than 3 ms)	1 µs (when time source jitter is less than 500 ns, and time-error is less than 1 µs) ^b
IRIG-B Connection Required	None	BNC connector (preferred), or Serial Port 1	BNC connector
Relay Word bits	TIRIG = logical 0 TSOK = logical 0	TIRIG = logical 1 TSOK = logical 0	TIRIG = logical 1 TSOK = logical 1

^a The SEL-451 internal clock can be synchronized via DNP3, Ethernet port, SEL-2030 Communications Processor, or MIRRORED BITS communications.

^b The time source must include the IEEE C37.118 IRIG-B control bit assignments to provide the Time Error estimate for the clock.

NOTE: If the time-code signal connected to the BNC connector degrades in quality, the SEL-451 will not switch-over to the IRIG-B pins of serial port 1. The SEL-451 will only switch to Serial Port 1 if the signal on the BNC connector completely fails (e.g. the cable is un-plugged).

Only one IRIG-B time source can be used by the SEL-451, and the signal connected to the IRIG-B BNC connector (shown in Figure 4.61) takes priority over the Serial Port 1 IRIG-B pins. If a signal is detected on the IRIG-B BNC input, the IRIG-B pins of Serial Port 1 will be ignored.

The SEL-451 determines the suitability of the IRIG-B signal connected to the BNC connector for high-accuracy timekeeping by applying two tests:

- Measuring whether the jitter between positive-transitions (rising edges) of the clock signal is less than 500 ns.
- Decoding the time-error information contained in the IRIG-B control field and determining that Analog Quantity TQUAL is less than 10^{-6} seconds (1 µs).

The SEL-451 will assert Relay Word bit TSOK only when these two tests are met, indicating HIRIG mode. The TQUAL Analog Quantity can be viewed with the **MET PM** command, and is shown beside the label

Time Quality Maximum time synchronization error:. See [Figure 7.5 on page R.7.17](#) for a sample.

The IRIG-B control field is defined in the IEEE C37.118 standard. The SEL-451 places the raw time quality information in Relay Word bits TQUAL1, TQUAL2, TQUAL4, and TQUAL8; and the decoded maximum clock error in Analog Quantity TQUAL, in seconds.

If the clock signal is determined to be of low quality, with more than 500 ns of jitter, the SEL-451 will not assert the TIRIG Relay Word bit.

1k PPS Connection Not Required

SEL-451 Relays Changed

Previous versions of the SEL-451 Relay required a 1k PPS clock signal in addition to the IRIG-B signal to allow HIRIG mode (high-accuracy IRIG timekeeping). The previous SEL-451 hardware included two BNC connectors for timekeeping: 1k PPS and IRIG-B (see [Figure 4.64](#)). On newer SEL-451 relays, there is only one BNC connector, IRIG-B, as shown in [Figure 4.63](#).

Starting with SEL-451 firmware version R104, HIRIG mode is available if a sufficiently accurate IRIG-B time source is connected to the IRIG-B BNC connector (see [Table 4.9](#)). A 1k PPS time source *cannot be used*.

Firmware version R104 redefines the meaning of the BNC connectors on the rear panel of the SEL-451. Pay close attention to the following instructions if you are upgrading your SEL-451 firmware.

Using New SEL-451 Firmware in an Existing Relay

In new SEL-451 relays, the IRIG-B BNC connector is in the same location as the 1k PPS BNC connector on previous relays. If you upgrade a previously installed SEL-451 relay to firmware version R104 or later, you will be provided with a retrofit kit that includes a new rear-panel label for the TIME inputs (see [Figure 4.65](#)). Follow the instructions included in the firmware upgrade package, and be sure to remove any 1k PPS time source cables that were previously connected.

Additionally, if the IRIG-B signal was previously supplied to the SEL-451 via Serial Port 1, and HIRIG mode operation is desired, connect the IRIG-B source to the IRIG-B BNC connector instead.

Time and Date Management Settings Not Required

SEL-451 Relays Changed

Previous firmware versions (R103 and earlier) of the SEL-451 relay provided Global Settings ETPPS and ETIRIG to enable or disable the 1k PPS and IRIG-B time sources. Beginning in firmware version R104, these settings are no longer part of Global Settings, because there is no 1k PPS input connector. Relay Word bit TPPS has also been removed from the relay.

Connecting High-Accuracy Timekeeping

The procedure in the following steps assumes that you have a modern high-accuracy GPS receiver with a BNC connector output for an IRIG-B signal. Use a communications terminal to send commands and receive data from the relay (see [Making an EIA-232 Serial Port Connection on page U.4.5](#)).

This example assumes that you have successfully established communication with the relay (see [Making an EIA-232 Serial Port Connection on page U.4.5](#)). In addition, you must be familiar with relay access levels and passwords (see [Changing the Default Passwords: Terminal on page U.4.9](#) to change the default access level passwords).

- Step 1. Confirm that the relay is operating (see [Connecting and Applying Power on page U.4.3](#)).
- Step 2. Prepare to control the relay at Access Level 2.
 - a. Using a communications terminal, type **ACC <Enter>**.
 - b. Type the Access Level 1 password and press **<Enter>**. You will see the Access Level 1 => prompt.
- Step 3. Connect the cable.

Attach the IRIG-B signal with a BNC-to-BNC coaxial jumper cable from the GPS receiver IRIG-B output to the SEL-451 **TIME IRIG-B** BNC connector (see [Figure 4.63](#)).

NOTE: Consult the specific GPS Clock (IRIG-B time source) instruction manual for the IRIG-B cable requirements, termination resistor requirements, antenna installation, and clock configuration details.



Figure 4.63 TIME BNC Connector, New Hardware




Figure 4.64 TIME BNC Connectors, Old Hardware




Figure 4.65 Retrofit Sticker

Step 4. Confirm/Enable automatic detection of high-accuracy timekeeping.

- Wait at least 20 seconds for the SEL-451 to acquire the clock signal, and then, at a communications terminal, type **TAR TIRIG <Enter>**

The relay will return one row from the Relay Word, as shown in [Figure 4.66](#). Only the state of the TIRIG and TSOK Relay Word bits are discussed in the troubleshooting steps below. The other Relay Word bits of interest to this discussion are TUPDH, which indicates that the SEL-451 internal clock is presently being updated by the HIRIG source, and TSYNCA, which acts as an alarm bit that asserts when the SEL-451 is not synchronized to either an internal or an external source. TSYNCA will only assert briefly when the HIRIG time source is connected or disconnected.

=>TAR TIRIG <Enter>

*	*	TIRIG	TUPDH	TSYNCA	TSOK	PMDOK	FREQOK
0	0	1	1	0	1	1	0
=>							

Figure 4.66 Confirming the High-Accuracy Timekeeping Relay Word Bits

- The TIRIG and TSOK Relay Word bits should be asserted (logical 1), indicating that the relay is in the High-Accuracy IRIG timekeeping mode (HIRIG).

If TSOK is not asserted, but TIRIG is asserted, the relay is in regular IRIG timekeeping mode. Here is a list of possible reasons for not entering HIRIG mode:

- The IRIG-B clock does not use the IEEE C37.118 Control Bit assignments, or the IRIG-B signal is not of sufficient accuracy.
- The termination resistor, required by some IRIG clocks, is not installed.
- If the time-source clock is reporting that its time error is greater than 1 μ s.
- The IRIG-B clock source is connected via Serial Port 1 instead of the IRIG-B BNC connector.
- The IRIG-B clock source is connected to the unlabeled BNC connector on older relay hardware (the previous location of the IRIG-B BNC connector).

NOTE: If the firmware in an already installed SEL-451 is upgraded to version R104 or later, and the previous IRIG-B BNC cable is not moved to the new location (see [Figure 4.63](#)), the SEL-451 cannot enter High-Accuracy mode.

If neither TSOK nor TIRIG are asserted, the relay is not in an IRIG time-source mode. Here is a list of possible reasons for not entering IRIG mode:

- The IRIG-B clock signal is not of sufficient accuracy or is improperly configured.
- The termination resistor, required by some IRIG clocks, is not installed.
- The time source clock is not connected to an antenna.
- An IRIG-B clock source is connected both to serial port 1 and the unlabeled BNC connector on older relay hardware (the previous location of the IRIG-B BNC connector).
- A 1k PPS cable is still connected to the relay.

Step 5. Type **TIME Q <Enter>** to confirm that the relay is operating in the high-accuracy IRIG (HIRIG) mode.

The relay displays information similar to [Figure 4.67](#).

The Time Source will be HIRIG, indicating that the relay internal clock is locked to the high-accuracy IRIG input signal.

```
=>TIME Q <Enter>
Relay 1                               Date: 10/06/2004  Time: 15:44:30.840
Station A                             Serial Number: 0000000000
Time Source: HIRIG
Last Update Source: HIRIG
IRIG Time Mark Period: 1000.000000 ms
Internal Clock Period: 24.999995 ns
=>
```

Figure 4.67 Results of the TIME Q Command

TIME Q Descriptions

The **TIME Q** command provides details about relay timekeeping (see [Figure 4.67](#)). The SEL-451 internal clock is initially calibrated at the SEL factory. An external IRIG source is required to eliminate clock drift. For high-accuracy timekeeping functions such as synchrophasor measurement, the connected clock must support IEEE C37.118 IRIG-B Control Bit assignments. The Time Source field provides the present high-accuracy timing

input source; entries for this line are HIRIG and OTHER. The Last Update Source reports the source from which the relay referenced the last time value measurement. Entries for this line can be high-priority or low-priority sources. *Table 4.10* lists the possible Last Update Source values for the SEL-451.

Table 4.10 Date/Time Last Update Sources

Time Input Source Mode (QQQQQ)	Priority	Time Source	Front Panel Editing?
HIRIG	High	Time/date from the high-accuracy IRIG-B input.	No
IRIG	High	Time/date from the IRIG-B format time base signal	No
COMM CARD	Low	Time/date signal from the communications card	Date and Time
DNP	Low	Time/date from the DNP communications port	Date and Time
MIRRORED BITS	Low	Time/date from the MIRRORED BIT port	Date and Time
ASCII TIME	Low	Time from the relay serial ports	Time only
ASCII DATE	Low	Date from the relay serial ports	Date only
NONV CLK	Low	Time/date from the nonvolatile memory clock	Date and Time
FRONT PANEL TIME	Low	Time from the front-panel TIME entry screen	Time only
FRONT PANEL DATE	Low	Time from the front-panel DATE entry screen	Date only

The IRIG Time Mark Period value indicates the instantaneous period in which the relay measures the time-source inputs. The relay displays the time mark periods showing the present time precision derived from the applied time-source signals.

The **TIME Q** command is also helpful for troubleshooting IRIG problems. If the IRIG Time Mark Period value changes significantly between successive **TIME Q** commands, there may be too much noise in the signal for the relay timekeeping function.

Adaptive Internal Clock Period Adjustment

The Internal Clock Period is the internal relay timekeeping period. The relay adjusts this master internal clock when you apply HIRIG mode timekeeping, adapting the internal relay clock for your installation temperature conditions. If you lose the HIRIG timing lock, the relay internal clock operates at this precisely adapted clock period until HIRIG mode is restored. Time tags for event reports during a loss of HIRIG mode timekeeping remain very accurate. Lower accuracy time sources do not adaptively adjust the internal relay clock period.

Monitoring High-Accuracy Time Source Status

The purpose of the procedure in the following steps is to show one method for deriving the TIME Q Time Source information from Relay Word bits TSOK and TIRIG. The TSOK Relay Word bit is at logical 1 when the relay is in HIRIG time mode. For this application example, use a PSV (Protection SELOGIC Variable) to monitor time keeping status.

PSV01 asserts when the relay is synchronized to the HIRIG source. A departure from this condition asserts the relay alarm output (OUT108 for this application example).

This example assumes that you have successfully established communication with the relay (see [Making an EIA-232 Serial Port Connection on page U.4.5](#)). In addition, you must be familiar with relay access levels and passwords (see [Changing the Default Passwords: Terminal on page U.4.9](#) to change the default access level passwords). Also, you should be familiar with ACSELERATOR QuickSet (see [Section 3: PC Software](#)).

Step 1. Configure the communications port.

- a. Start ACSELERATOR QuickSet.
- b. On the top toolbar, open the **Communication** menu, and then click **Port Parameters**.

You will see the **Port Parameters** dialog box similar to [Figure 4.7](#).

- c. Select the **Data Speed**, **Data Bits**, **Stop Bits**, **Parity**, and **RTS/CTS** that match the relay settings.
The defaults are **9600**, **8**, **1**, **None**, and **Off**, respectively.
- d. Click **OK** to update the ACSELERATOR QuickSet communications parameters.
- e. Confirm that the **Communications Status** bar at the bottom of the ACSELERATOR QuickSet window says **Connected**.

Step 2. Confirm the correct ACSELERATOR QuickSet passwords.

- a. Reopen the **Communication** menu and click **Port Parameters**.
- b. Enter your Access Level 1 password in the **Level One Password** text box, and your Access Level 2 password in the **Level Two Password** text box.
- c. Click **OK** to accept changes and close the dialog box.

Step 3. Read the present configuration in the SEL-451. Click **Settings > Read**.

The relay sends all configuration and settings data to ACSELERATOR QuickSet.

Step 4. Access the protection free-form SELOGIC settings.

- a. Click the + mark next to **Group 1** in the **Settings** tree view.
- b. Click the **Protection Logic 1** settings (see [Figure 4.68](#)).

Step 5. Enter the two lines of SELOGIC control equation programming in the **Protection Free-Form Logic Settings** shown in [Figure 4.68](#).

Comments begin with the # character (see [Fixed SELOGIC Control Equations on page R.3.4](#)).




Figure 4.68 Programming a PSV in ACSELERATOR QuickSet

Step 6. Configure a control output to alarm a loss of HIRIG mode.

- In the **Settings** tree view, double-click **Outputs** and then click **Main Board** (see *Figure 4.69*).
- In the **OUT108 Main Board Outputs** text box, enter the OR NOT PSV01 condition to the preexisting OUT108 := NOT (SALARM OR HALARM) equation, as shown in *Figure 4.69*.




Figure 4.69 Setting OUT108 in ACSELERATOR QuickSet

Step 7. Click **File > Save** to save the new settings in ACSELERATOR QuickSet.

Step 8. Upload the new settings to the SEL-451.

- Click File > Send.**

ACSELERATOR QuickSet prompts you for the settings class or instance you want to send to the relay.

- Click the check box for **Group 1** check box and the **Output** check box, as shown in the first dialog box of *Figure 4.56*.**

- c. Click **OK**.

ACSELERATOR QuickSet responds with a display similar to the second dialog box of [Figure 4.56](#).

If you see no error message, the new settings are loaded in the relay.

To confirm that you have prepared an out-of synchronization/loss of HIRIG mode alarm, disconnect the IRIG-B input. The relay alarm will activate.

Readyng the Relay for Field Application

Before applying the SEL-451 in your power system, set the relay for your particular field application. Be sure to modify the relay factory default settings for your power system conditions to enable relay features to help you protect and control your system.

This procedure is a guide to help you ready the relay for field application. If you are unfamiliar with the steps in this procedure, see the many relay usage examples presented in this section. This is a suggested procedure; modify the procedure as necessary to conform to your standard company practices.

- Step 1. Open the appropriate low-voltage breaker(s) and remove fuses to verify removal of control power and ac signals from the SEL-451.
- Step 2. Isolate the relay TRIP control output.
- Step 3. Perform point-to-point continuity checks on the circuits associated with the SEL-451 to verify the accuracy and correctness of the ac and dc connections.
- Step 4. Apply power to the relay (see [Connecting and Applying Power on page U.4.3](#)).
The green **ENABLED** LED on the front panel will illuminate.
- Step 5. Use an SEL Cable C234A to connect a serial terminal to the relay.
- Step 6. Start the terminal (usually a PC with terminal emulation software).
- Step 7. Establish communication with the relay at Access Level 0.
- Step 8. Proceed to Access Level 2 (see [Changing the Default Passwords on page U.4.6](#)).
- Step 9. Change the default passwords (see [Changing the Default Passwords on page U.4.6](#)).
- Step 10. Set the DATE and TIME (see [Making Simple Settings Changes on page U.4.14](#)).
- Step 11. Use test sources to verify relay ac connections (see [Examining Metering Quantities on page U.4.34](#)).
- Step 12. Verify control input connections (see [Operating the Relay Inputs and Outputs on page U.4.58](#) and [Control Inputs on page U.2.6](#)).

- Step 13. Verify control output connections (see *Operating the Relay Inputs and Outputs on page U.4.58* and *Control Outputs on page U.2.8*).
- Step 14. Perform protection element tests (see *Checking Relay Operation on page U.6.25*).
- Step 15. Set the relay (see *Making Simple Settings Changes on page U.4.14*, *Section 1: Protection Application Examples in the Applications Handbook*, and *Section 1: Protection Functions in the Reference Manual*).
- Step 16. Connect the relay for tripping/closing duty (see *AC/DC Connection Diagrams on page U.2.50*).
- Step 17. From Access Level 2, use a communications terminal to issue the commands to clear the relay data buffers (listed in *Table 4.11*).

Table 4.11 Communications Port Commands That Clear Relay Buffers

Communications Port Command	Task Performed
MET RD	Reset demand meter data
MET RP	Reset peak demand meter data
MET RE	Reset energy meter data
MET RM	Reset maximum/minimum meter data
HIS CA	Reset event report and history buffers
SER CA	Reset Sequential Events Recorder data

Step 18. Connect the secondary voltage and current inputs (see *User's Guide Section 2: Installation*).

Step 19. Use the **MET** command or the ACSELERATOR QuickSet HMI to view relay metering to confirm secondary connections (see *Examining Metering Quantities on page U.4.34*).

Section 5

Front-Panel Operations

The SEL-451 Relay front panel makes power system data collection and system control quick and efficient. Using the front panel, you can analyze power system operating information, view and change relay settings, and perform relay control functions. The relay features a straightforward menu-driven control structure presented on the front-panel liquid crystal display (LCD). Front-panel targets and other LED indicators give a quick look at SEL-451 operation status. You can perform often-used control actions rapidly by using the large direct-action pushbuttons. All of these features help you operate the relay from the front panel and include:


- Reading metering
- Inspecting targets
- Accessing settings
- Controlling relay operations

This section includes the following:

- *Front-Panel Layout on page U.5.2*
- *Front-Panel Menus and Screens on page U.5.14*
- *Front-Panel Automatic Messages on page U.5.36*
- *Operation and Target LEDs on page U.5.37*
- *Front-Panel Operator Control Pushbuttons on page U.5.42*

Front-Panel Layout


The front panel for the horizontal 3U (3 rack unit) SEL-451 configuration is shown in [Figure 5.1](#) (other configurations are similar).



i3741a

Figure 5.1 SEL-451 Front Panel (8 pushbutton model)

The front panel for the horizontal 5U (5-rack unit) SEL-451 configured with auxiliary TRIP/CLOSE pushbuttons is shown in [Figure 5.2](#).



i4055c

Figure 5.2 SEL-451 Front Panel (12 pushbutton model)

A 128 x 128 pixel LCD (liquid crystal display) shows relay operating data including event summaries, metering, settings, and relay self-test information.

Six navigation pushbuttons adjacent to the LCD window control the relay menus and information screens. Sequentially rotating display screens relate important power system metering parameters; you can easily change this ROTATING DISPLAY to suit your particular on-site monitoring needs. Use a

simple and efficient menu structure to operate the relay from the front panel. With these menus you can quickly access SEL-451 metering, control, and settings.

Front-panel LEDs (light emitting diodes) indicate the relay operating status. You can confirm that the SEL-451 is operational by viewing the **ENABLED** LED. The relay illuminates the **TRIP** LED target to indicate a tripping incident. The relay is factory programmed for particular relay elements to illuminate the other target LEDs. You can program these target LEDs to show the results of the most recent relay trip event. The asserted and deasserted colors for the LEDs are programmable.

Select SEL-451 models feature auxiliary **TRIP/CLOSE** pushbuttons. These pushbuttons are electrically isolated from the rest of the relay. See [Auxiliary TRIP/CLOSE Pushbutton and Breaker Status LED Jumpers \(select models only\) on page U.2.29](#) for more information about this feature.

The SEL-451 front panel features large operator control pushbutton switches with annunciator LEDs that facilitate local control. Factory default settings associate specific relay functions with these direct-action pushbuttons and LEDs. Using SELOGIC® control equations or front-panel settings **PBn_HMI**, you can readily change the default direct-action pushbutton functions and LED indications to fit your specific control and operational needs. Change the pushbutton and pushbutton LED labels with the slide-in labels adjacent to the pushbuttons. The asserted and deasserted colors for the LEDs are programmable in 12-pushbutton models.

The SEL-451 front panel includes an EIA-232 serial port (labeled **PORT F**) for connecting a communications terminal or using the ACCELERATOR QuickSet® SEL-5030 Software program. Use the common EIA-232 open ASCII communications protocol to communicate with the relay via front-panel **PORT F**. Other communications protocols available with the front-panel port are MIRRORED BITS® communications, and DNP3. For more information on communications protocols and **PORT F**, see [Communications Ports Connections on page U.2.47](#) and [Serial Communication on page R.4.2](#).

Front-Panel LCD

The LCD is the prominent feature of the SEL-451 front panel. [Figure 5.3](#) shows the areas contained in the LCD:

- Title area
- Main area
- Message area
- Scroll bars

The scroll bars are present only when a display has multiple screens.




Figure 5.3 LCD Display and Navigation Pushbuttons

Front-Panel Inactivity Time Out

An LCD backlight illuminates the screen when you press any front-panel pushbutton. This backlight extinguishes after a front-panel inactivity time out. You can control the duration of the time out with relay setting FP_TO, listed in [Table 5.1](#).

To set FP_TO, use the **SET F** (set front panel) settings from any communications port or use the Front Panel branch of the ACCELERATOR QuickSet **Settings** tree view. The maximum backlight time is one hour. Obtain this 60-minute maximum backlight time by setting FP_TO to 60 or to OFF. When the front-panel times out, the relay displays an automatic ROTATING DISPLAY, described later in this section under [Screen Scrolling on page U.5.5](#).

Table 5.1 Front-Panel Inactivity Time-Out Setting

Name	Description	Range	Default
FP_TO	Front-panel display time-out	OFF, 1–60 minutes	15 minutes

Navigating the Menus

The SEL-451 front panel presents a menu system for accessing metering, settings, and control functions. Use the LCD and the six pushbuttons adjacent to the display (see [Figure 5.3](#)) to navigate these front-panel menus.

The navigation pushbutton names and functions are the following:

- **ESC**—Escape pushbutton
- **ENT**—Enter pushbutton
- **Left Arrow, Right Arrow, Up Arrow, and Down Arrow**—Navigation pushbuttons

Menus show lists of items that display information or control the relay. A rectangular box around an action or choice indicates the menu item you have selected. This rectangular box is the menu item highlight.

[Figure 5.4](#) shows an example of the highlighted item RELAY ELEMENTS in the MAIN MENU. When you highlight a menu item, pressing the **ENT** pushbutton selects the highlighted item.

NOTE: ONE LINE DIAGRAM selection is available with the SEL-451-4 relay.




Figure 5.4 RELAY ELEMENTS Highlighted in MAIN MENU

The **Up Arrow** pushbutton and **Down Arrow** pushbutton scroll the highlight box to the previous or next menu selection, respectively. When there is more than one screen of menu items, pressing **Up Arrow** while at the first menu item causes the display to show the previous set of full-screen menu items, with the last menu item highlighted. Pressing **Down Arrow** while at the bottom menu item causes the display to show the next set of full-screen menu items, with the first menu item highlighted.

Pressing the **ESC** pushbutton reverts the LCD display to the previous screen. Pressing **ESC** repeatedly returns you to the **MAIN MENU**. If a status warning, alarm condition, or event condition is active (not acknowledged or reset), the relay displays the full-screen status warning, alarm screen, or trip event screen in place of the **MAIN MENU**.

Screen Scrolling

The SEL-451 has two screen scrolling modes: autoscrolling mode and manual-scrolling mode. After front-panel time out, the LCD presents each of the display screens in this sequence:

- One-line diagram (SEL-451-4)
- Any active (filled) alarm points screens
- Any active (filled) display points screens
- Enabled metering screens

The relay displays enabled metering screens in the order listed in [Table 5.2](#). (see [Figure 5.19](#) for samples of the metering screens.) This sequence comprises the **ROTATING DISPLAY**.

Table 5.2 Metering Screens Enable Settings (Sheet 1 of 2)

Name	Description	Range	Default
RMS_V	RMS Line Voltage Screen	Y, N	N
RMS_I	RMS Line Current Screen ^a	Y, N	Y
RMS_VPP	RMS Line Voltage Phase-to-Phase Screen	Y, N	N
RMS_W	RMS Active Power Screen	Y, N	N
FUNDVAR	Fundamental Reactive Power Screen	Y, N	N
RMS_VA	RMS Apparent Power Screen	Y, N	N
RMS_PF	RMS Power Factor Screen	Y, N	N
RMS_BK1	RMS Breaker 1 Currents Screen	Y, N	N
RMS_BK2	RMS Breaker 2 Currents Screen	Y, N	N
STA_BAT	Station Battery Screen	Y, N	N

NOTE: The initial display can present only the RMS_I line current screen. This can occur when you have not enabled any of the metering screens, alarm points, and display points.


Table 5.2 Metering Screens Enable Settings (Sheet 2 of 2)

Name	Description	Range	Default
FUND_VI	Fundamental Voltage and Current Screen ^a	Y, N	Y
FUNDSEQ	Fundamental Sequence Quantities Screen	Y, N	N
FUND_BK	Fundamental Breaker Currents Screen	Y, N	N
ONELINE ^b	One Line Bay Control Diagram	Y, N	Y

^a The default displays are RMS_I and FUND_VI.

^b ONELINE setting available with SEL-451-4 relay and is the first screen in the rotating display.

Use the front-panel settings (the **SET F** command from a communications port or the Front Panel settings in ACCELERATOR QuickSet) to access the metering screen enables. Entering a **Y** (Yes) for a metering screen enable setting causes the corresponding metering screen to appear in the ROTATING DISPLAY. Entering an **N** (No) hides the metering screen from presentation in the ROTATING DISPLAY. [Figure 5.5](#) shows a sample ROTATING DISPLAY consisting of an example alarm points screen, an example display points screen, and the two factory-default metering screens, RMS_I and FUND_VI (the screen values in [Figure 5.5](#) are representative values).

**Figure 5.5 Sample ROTATING DISPLAY**

The active alarm points are the first screens in the ROTATING DISPLAY (see [Alarm Points on page U.5.8](#)). Each alarm points screen shows as many as eleven alarm conditions. The SEL-451 can present a maximum of six alarm points screens.

The active display points are the next screens in the ROTATING DISPLAY after alarm points (see [Display Points on page U.5.11](#)). Each display points screen shows as many as eleven enabled display points. (With 96 display points, the SEL-451 can present a maximum of nine display points screens.) If a display point does not have text to display, the screen space for that display point is maintained.

Autoscrolling Mode

Autoscrolling mode shows each screen for a user-settable period of time. Front Panel setting SCROLD defines the period of time each screen is shown. When you first apply power to the relay, the LCD shows the autoscrolling ROTATING DISPLAY. With SCROLD := OFF the screen remains on the first screen in the rotating display order, automatic rotation of additional screens is disabled.

The autoscrolling ROTATING DISPLAY also appears after a front-panel inactivity time out (see [Front-Panel Inactivity Time Out on page U.5.4](#)). The relay retrieves data prior to displaying each new screen. The relay does not update screen information during the display interval. At any time during autoscrolling mode, pressing ENT takes you to the MAIN MENU. Pressing any of the four navigation pushbuttons switches the display to manual-scrolling mode.

Manual-Scrolling Mode

In the manual-scrolling mode you can use the directional navigation arrow pushbuttons to select the next or previous screen. Pressing the Down Arrow or Right Arrow pushbuttons switches the display to the next screen; pressing the Up Arrow or Left Arrow pushbuttons switches the display to the previous screen.

In manual-scrolling mode, the display shows arrows at the top and bottom of the vertical scroll bar. The screen arrows indicate that you can navigate between the different screens at will. The relay retrieves data prior to displaying each new screen. Unlike the autoscrolling mode, the relay continues to update screen information while you view it in the manual-scrolling mode. To return to autoscrolling mode, press ESC or wait for a front-panel time out.

Alarm Points

You can display messages on the SEL-451 front-panel LCD that indicate alarm conditions in the power system. The relay uses alarm points to place these messages on the LCD.

[Figure 5.6](#) shows a sample alarm points screen. The relay is capable of displaying as many as 66 alarm points. The relay automatically displays new alarm points while in manual-scrolling mode and in autoscrolling mode. While you navigate the HMI menu structure, the relay does not automatically display the alarm points. Instead, ALARM EVENT displays in the footer. When you escape the HMI menu structure, the relay will display the alarm points screen.




Figure 5.6 Sample Alarm Points Screen

The alarm point setting is an element of the SER settings. To enable an alarm point, enable the HMI alarm parameter of the SER Point Settings listed in [Table 5.3](#). The format for entering the SER point data is the following comma-delimited string:

Relay Word Bit, Reporting Name, Set State Name, Clear State Name, HMI Alarm

Names can contain any valid ASCII character. Enclose the name within double quotation marks. See [Example 5.1](#) for particular information on the format for entering SER point data.

Table 5.3 SER Point Settings

Description	Range
Relay Word Bit	Any valid relay element
Reporting Name	20-character maximum ASCII string
SET State Name (logical 1)	20-character maximum ASCII string
CLR State Name (logical 0)	20-character maximum ASCII string
HMI Alarm	Y,N

If you enter a Relay Word bit that does not match a valid relay element, the relay displays: Unknown relay word reference. If you enter an alias or name that is too long, the relay displays: Alias label too long.

The relay displays alarm points in a similar fashion as the SER. As many as 19 characters of the given alias are displayed, with a character reserved for the “*.” The asterisk denotes if the element is asserted. Initially, an alarm point must be asserted in order to be displayed; after the corresponding element deasserts, the asterisk is removed, but the alias is not. The relay displays alarm points in reverse chronological order, just as in the SER, with the most recently asserted alarm displayed on the top. Deasserted alarms may be removed from the display with user acknowledgement, as shown in [Example 5.1](#).

EXAMPLE 5.1 Creating an Alarm Point

Alarm points screens provide operator feedback about the status of system conditions. An alarm points screen contains 11 alarm points; this example demonstrates a method to set the alarm point message that is shown in [Figure 5.6](#). This example is based on the Relay Word bit IN101 asserting when circuit breaker 1 is in an alarm condition.

In the Report settings (**SET R**), enter the following after the SER Points line 1 prompt:

1: IN101,"Circuit BK1 SF6 Gas","Alarm","Normal","Y"

The circuit breaker alarm condition is indicated by the set state, "Alarm" and the circuit breaker normal condition is indicated by the clear state "Normal." The HMI Alarm parameter is set to "Y" in order to enable alarm points screen display of this element.

While in the scrolling mode, the assertion of IN101 will cause [Figure 5.6](#) to be automatically displayed. Upon the deassertion of IN101, the asterisk will disappear, as in [Figure 5.7](#).




Figure 5.7 Deasserted Alarm Point

Pressing the ENT pushbutton will allow the user to acknowledge and clear deasserted alarms. Before clearing, you will be prompted to confirm that this is the intended action, as shown in [Figure 5.8](#).




Figure 5.8 Clear Alarm Point Confirmation Screen

In the case that all alarms are deasserted, pressing the ENT pushbutton will allow the user to acknowledge and clear all alarms. After clearing, a screen showing the results of the action will be shown, as in [Figure 5.9](#).




Figure 5.9 No Alarm Points Screen

Alarm points are not updated for a particular element if it has been deleted from the SER due to chatter criteria (see [Automatic Deletion and Reinsertion on page A.3.45](#)). Upon reinsertion, the element state will be updated on the alarm point display. If the relay enters a period of SER data loss, the status of alarm points cannot be determined. The screen shown in [Figure 5.10](#) will appear until you exit the data loss condition, at which point the alarm point elements will be polled and displayed if asserted. Subsequent alarm point assertions will be displayed above the data loss message.




Figure 5.10 Alarm Points Data Loss Screen

Display Points

You can display messages on the SEL-451 front-panel LCD that indicate conditions in the power system. The relay uses display points to place these messages on the LCD.

Figure 5.11 shows a sample display points screen. Display points can show the status of Relay Word bits or display the value of analog quantities. The relay has 96 possible display points; *Table 5.4* and *Table 5.5* list the display points settings. The relay updates the display points data once per second if you are viewing the display points in manual-scrolling mode; in autoscrolling mode the relay updates the display points information each time the screen appears in the ROTATING DISPLAY sequence.




Figure 5.11 Sample Display Points Screen

To enable a display point, enter the display point settings listed in *Table 5.4* or *Table 5.5*. All display points occupy one, and only one, line on the display at all times. The height of the line is determined by the “Text Size” setting parameter. Display points of single-line height span one screen in total width. Display points of double-line height span two screens in total width. You can use multiple display points to simulate multiple lines.

Use the following syntax to display the given Relay Word bit exactly as seen in the navigational menu (name and value).

DPxx := Name

Use the following syntax to display the given Relay Word bit as seen in the navigational menu, replacing the name of the value with the given alias string. The text size determines if the display will be in single font or double font. If the text size is empty, the display will be in single font.

DPxx := Name, "Alias", "Text Size"

Use the following syntax to display the given Relay Word bit with the given alias. If the Relay Word bit is asserted (logical 1), the LCD displays the set string in the place of the value. If the Relay Word bit is deasserted (logical 0), the LCD displays the clear string in the place of the value. One or all of Alias, Set String, or Clear String can be empty. If Alias is empty, then the LCD displays only the Set or Clear Strings. If either Set String or Clear String is empty, then an empty line is displayed when the bit matches that state. The text size determines if the display will be in single font or double font. If the text size is empty, the display will be in single font.

DPxx := Name, "Alias", "Set String", "Clear String", "Text Size"

Use the following syntax to display the given analog quantity with the given text and formatting. Formatting must be in the form {Width.Decimal,Scale} with the value of Name, scaled by “Scale,” formatted with total width “Width” and “Decimal” decimal places. The width value includes the decimal point and sign character, if applicable. The “scale” value is optional; if omitted, the scale factor is processed as 1. If the numeric value is smaller than the field size requested, the field is padded with spaces to the left of the number. If the

numeric value will not fit within the field width given, "\$" characters are displayed. The text size determines if the display will be in single font or double font. If the text size is empty, the display will be in single font.

DPxx := Name, "Text1 {Width.Decimal,Scale} Text2", "Text Size"

Table 5.4 Display Point Settings—Boolean

Description	Range
Relay Word Bit Name	Reference Manual, Appendix A: Relay Word Bits
Alias	ASCII string
Set String	ASCII string
Clear String	ASCII string
Text Size	S, D

Table 5.5 Display Point Settings—Analog

Description	Range
Analog Quantity Name	Reference Manual, Appendix B: Analog Quantities
"User Text and Formatting"	ASCII string
Text Size	S, D

Table 5.6 Display Point Settings—Boolean and Analog Examples

Example Display Point Setting Value	Example Display
IN101	12345678901234567890 IN101=1 IN101=0
MWHAIN,"{7.2}"	1234.56
50P1,Overcurrent,,	Overcurrent=1 Overcurrent=0
PSV01,Control,On,Off	Control=On Control=Off
PSV02,Breaker,Tripped,	Breaker=Tripped <i>Empty Line</i>
50P1,,Overcurrent	<i>Empty Line</i> Overcurrent
MWHAIN,"A Ph Import={7.2}"	A Ph Import=1234.56
MWHAIN," A Ph Import={7.3}"	A Ph Import=\$\$.###
MWHAIN,"A Ph Imp {4}MWh"	A Ph Imp 1234MWh
PAD,"{7.2}"	1234.56
PAD,"A Ph Dem Pwr={4.1}"	A Ph Dem Pwr=1234.5
ICD,"C Demand={5}"	C Demand= 1230
ICD,"C Demand={4.2,0.001} kA"	C Demand=1.23 kA
MWHAOUT,"A Phase Out={3, 1000}"	A Phase Out=1234
MWHAOUT," A Phase Out={3, 1000} kWh"	A Phase Out=\$\$ kWh
1,"Fixed Text"	Fixed Text
0,"Fixed Text"	Fixed Text
1,	<i>Empty Line</i>
0,	<i>Empty Line</i>
	<i>Display Point is hidden</i>

If you enter a Relay Word bit or Analog Quantity that does not match a valid relay element, the relay displays: Invalid element. If you enter a display point that exceeds the allowable length, the relay displays: Too many characters. If you enter an invalid scale factor, invalid width, too many parameters, or omit necessary quotation marks or brackets, the relay displays an error message. If a display point was used previously and you want to remove the display point, you can delete the display point. In the Front Panel settings (**SET F**), at the Display Points and Aliases prompt, use the text-edit mode line editing commands to set the display points (see [Text-Edit Mode Line Editing on page U.4.19](#) for information on text-edit mode line editing). To delete Display Point 1, type **DELETE <Enter>** at the Front Panel settings Line 1 prompt.

EXAMPLE 5.2 Creating a Display Point

Display points screens provide operator feedback about the readiness of equipment connected to the SEL-451. A display points screen contains 11 display points; this example demonstrates a method to set the display point messages that are shown in [Figure 5.11](#). The SEL-451 in this example has an additional I/O interface board.

This example is based on a three-pole circuit breaker with breaker input settings entered as shown in [Setting a Control Input for Circuit Breaker Auxiliary Contacts \(52A\): ACSELERATOR QuickSet on page U.4.69](#). The Relay Word bit 52AA1 will assert when Circuit Breaker 1 is in the closed position.

IN109 will assert when circuit breaker 1 is in an alarm condition. B2IAFIM is the filtered instantaneous magnitude for the A-Phase current through Circuit Breaker 2.

In the Front Panel settings (**SET F**), enter the following after the Display Points and Aliases line 1 prompt:

- 1: 1,"Circuit Breaker 1"
- 2: 52AA1," --Closed--"," --Open--"
- 3: 0
- 4: 0,"Circuit BK1 SF6 Gas"
- 5: IN109," --Alarm--"," --Normal--"
- 6: 1
- 7: 1,"Circuit Breaker 2"
- 8: B2IAFIM," A PH={6.1,1} A pri"
- 9: IN109,, "SF6 ALARM", D

Fixed text is set by assigning an alias to a "1" or "0." Blank lines are set by assigning a blank alias to a "1" or "0." The circuit breaker closed condition is indicated by the set state, " --Closed--" where leading spaces are added to center the set state message. Add a clear state named " --Open--" to show that the circuit breaker is open. The circuit breaker alarm condition is indicated by the set state, " --Alarm--" where leading spaces are added to center the set state message. Add a clear state named " --Normal--" to show that the circuit breaker is not in alarm. User text " A PH=" and "A pri" allows for customized display of the Circuit Breaker 2 A-Phase current, which has been formatted to display numerically as XXXX.X. Double font display is used to give greater visibility to the SF6 Alarm. A horizontal scroll appears while in manual-scrolling mode regardless of whether or not the display point label width requires two full screens to display.

EXAMPLE 5.3 Monitoring Test Modes With Display Points

This example uses the Relay Word bit TESTFM (Fast Meter test running) to activate a front-panel display point that alerts an on-site operator that the relay is in Fast Meter test mode.

In the Front Panel settings (**SET F**), enter the following after the line 10 prompt:

10: TESTFM,,“FAST METER TEST!!!!”

The LCD displays the screen shown in [Figure 5.12](#) as a part of the ROTATING DISPLAY if the Fast Meter test is running. (Instruct the operator to view the relay front panel for messages or warnings as the last item on a “Leaving the Substation” checklist.)

Again, this display point application example does not require a clear state, so the clear state is blank. If the Fast Meter test is not running and no other display points are active, the relay shows a blank screen in the ROTATING DISPLAY.




Figure 5.12 Fast Meter Display Points Sample Screen

Front-Panel Menus and Screens

Operate the SEL-451 front panel through a sequence of menus that you view on the front-panel display. The **MAIN MENU** is the introductory menu for other front-panel menus (see [Figure 5.4](#)). These additional menus allow you on-site access to metering, control, and settings for configuring the SEL-451 to your specific application needs. Use the following menus and screens to set the relay, perform local control actions, and read metering:

- Support Screens
 - Contrast
 - Password
- MAIN MENU
 - METER
 - EVENTS
 - BREAKER MONITOR
 - RELAY ELEMENTS
 - LOCAL CONTROL
 - SET/SHOW
 - RELAY STATUS
 - VIEW CONFIGURATION
 - DISPLAY TEST
 - RESET ACCESS LEVEL
 - ONE LINE DIAGRAM (available with the SEL-451-4)

Support Screens

The relay displays special screens over the top of the menu or screen that you are using to control the relay or view data. These screens are the contrast adjustment screen and the **PASSWORD REQUIRED** screen.

Contrast

You can adjust the LCD screen contrast to suit your viewing angle and lighting conditions. To change screen contrast, press and hold the **ESC** pushbutton for one second. The relay displays a contrast adjustment box superimposed over the display.

Figure 5.13 shows the contrast adjustment box with the **MAIN MENU** screen in the background. Pressing the **Right Arrow** pushbutton increases the contrast. Pressing the **Left Arrow** pushbutton decreases the screen contrast. When finished adjusting the screen contrast, press the **ENT** pushbutton.




Figure 5.13 Contrast Adjustment

Password

WARNING

This device is shipped with default passwords. Default passwords should be changed to private passwords at installation. Failure to change each default password to a private password may allow unauthorized access. SEL shall not be responsible for any damage resulting from unauthorized access.

The SEL-451 uses passwords to control access to settings and control menus. The relay has six access-level passwords. See *Changing the Default Passwords on page U.4.6* for more information on access levels and setting passwords. The SEL-451 front panel is at Access Level 1 upon initial power-up and after front-panel time out.

Password validation occurs only when you request a menu function that is at a higher access level than the presently authorized level. At this point, the relay displays a password entry screen, shown in *Figure 5.14*. This screen has a blank password field and an area containing alphabetic, numeric, and special password characters with a movable highlight box.




Figure 5.14 Enter Password Screen

Enter the password by pressing the navigation pushbuttons to move the highlight box through the alphanumeric field. When at the desired character, press **ENT**. The relay enters the selected character in the password field and moves the dark box cursor one space to the right. You can backspace at any time by highlighting the **BACKSPACE** character and then pressing **ENT**. When finished, enter the password by highlighting the **ACCEPT** option and then pressing **ENT**.

If you entered a valid password for an access level greater than or equal to the required access level, the relay authorizes front-panel access to the combination of access levels (new level and all lower levels) for which the

password is valid. The relay replaces the password screen with the menu screen that was active before the password validation routine. When you enter Access Levels B, P, A, O, and 2, the Relay Word bit SALARM pulses for one second.

If you did not enter a valid password, the relay displays the error screen shown in [Figure 5.15](#). Entering a valid password for an access level below the required access level also causes the relay to generate the error screen. In both password failure cases, the relay does not change the front-panel access level (it does not reset to Access Level 1 if at a higher access level). The relay displays the **PASSWORD INVALID** screen for five seconds. If you do not want to wait for the relay to remove the message, press any of the six navigational pushbuttons during the five-second error message to return to the previous screen in which you were working.




Figure 5.15 Invalid Password Screen

Main Menu

The **MAIN MENU** is the starting point for all other front-panel menus. The relay **MAIN MENU** is shown in [Figure 5.16](#). When the front-panel LCD is in the **ROTATING DISPLAY**, press the **ENT** pushbutton to show the **MAIN MENU**.

NOTE: ONE LINE DIAGRAM selection is available with the SEL-451-4.





Figure 5.16 MAIN MENU

Meter

The SEL-451 displays metering screens on the LCD. Highlight **METER** on the **MAIN MENU** screen to select these screens. The **METER MENU**, shown in [Figure 5.17](#), allows you to choose the following metering screens corresponding to the relay metering modes:

- RMS METER
- FUNDAMENTAL METER
- DEMAND METER (if enabled)
- ENERGY METER
- MAX/MIN
- SYNCHRONISM CHECK (if enabled)


**Figure 5.17 METER MENU Screens**

NOTE: Global settings ESS (Enable Source Selection) and NUMBK (Number of Circuit Breakers) affect how the SEL-451 determines the line current and the voltage source for protection functions (directional elements, load encroachment, and loss-of-potential).

Combinations of relay Global settings ESS and NUMBK give you metering data for Line, Circuit Breaker 1, and Circuit Breaker 2 when you view RMS METER, FUNDAMENTAL METER, and MAX/MIN metering screens. The relay shows the METER SUBMENU of [Figure 5.18](#) so you can choose the line or circuit breaker data that you want to display.

For example, if you have two sources feeding a transmission line through two circuit breakers and you set ESS := 3, NUMBK := 2, then the SEL-451 measures BREAKER 1 currents, BREAKER 2 currents, and combined (Circuit Breakers 1 and 2) currents for LINE. The relay displays the METER SUBMENU screen when you make this settings configuration.

Other combinations of settings ESS and NUMBK do not require separate circuit breaker metering screens; for these configurations, the relay does not present the METER SUBMENU screen. See [Current and Voltage Source Selection on page R.1.2](#) and [Global Settings on page R.10.5](#) for information on configuring global settings ESS, NUMBK, LINEI, BK1I, and BK2I.

**Figure 5.18 METER SUBMENU**

The relay presents the meter screens in the order shown in each column of [Figure 5.19](#) and [Figure 5.20](#). Once you have selected the type of metering data to display (RMS METER, FUNDAMENTAL METER, DEMAND METER, ENERGY METER, MAX/MIN, or SYNCHRONISM CHECK), you can scroll through the particular display column by pressing the Down Arrow pushbutton. Return to a previously viewed screen in each column by pressing the Up Arrow pushbutton. Press ESC to revert the LCD screen to the METER SUBMENU and METER MENU screens.

The metering screens show reset options for the MAX/MIN, ENERGY METER, PEAK DEMAND METER, and DEMAND METER metering quantities at the end of each screen column. Use the Left Arrow and Right Arrow pushbuttons to select a NO or YES response to the reset prompt, and then press ENT to reset the metering quantity.

The primary voltage quantities (kV) in any screens in [Figure 5.19](#) will be displayed with three digits to the right of the decimal point when all voltages on a particular screen are less than 10.0 kV.




Figure 5.19 RMS, FUND, and DEMAND Metering Screens



Figure 5.20 ENERGY, MAX/MIN, and SYNCH CHECK Metering Screens

Events

The SEL-451 front panel features summary event reporting, which simplifies post-fault analysis. These summary event reports include all trip events, event and data capture triggering (via the ER SELOGIC control equation), and manual triggers. The relay displays event reports based on the Relay Word bit elements in the ER (event report trigger) SELOGIC control equation. See [Event Report on page A.3.14](#) for more information on event reports.

The front-panel event buffer size is 100 summaries. The relay numbers summary events in order from 10000 through 42767 and displays the most recent summaries on the LCD.

You can view summary event reports from the relay front-panel display by selecting EVENTS from the MAIN MENU. The relay presents the Events Menu as shown in [Figure 5.21](#). Select Event Summary from the Events Menu to view event summary data. [Figure 5.22](#) shows sample Event Summary screens for a phase-to-phase-to-ground fault. Use the Right Arrow and Left Arrow pushbuttons to show each of the summary screens for the event. Event reports can also be viewed via a front-panel automatic message ([Front-Panel Automatic Messages on page U.5.36](#)) or programmable front-panel operator control pushbutton ([Front-Panel Operator Control Pushbuttons on page U.5.42](#)).




Figure 5.21 Events Menu Screen

The horizontal scroll bar indicates that you can view other event 10002 screens. Use the Up Arrow and Down Arrow pushbuttons to move among the events in the summary buffer. Press ESC to return to the Events Menu and ESC again to return to the MAIN MENU.





Figure 5.22 EVENT SUMMARY Screens


SER

The Sequential Events Recorder records state changes of user-programmable Relay Word bits. State changes are time-tagged for future analysis of relay operations during an event. See [SER \(Sequential Events Recorder\) on page A.3.42](#) for more information on SER events. To view SER events from the front panel, select EVENTS from the MAIN MENU and SER Events from the Events Menu as shown in [Figure 5.21](#). SER events are also viewable using programmable front-panel operator-control pushbuttons; see [Front-Panel Operator Control Pushbuttons on page U.5.42](#).

[Figure 5.23](#) illustrates the SER Events display screen. Data reported in this screen for each event are the SER number, SER Point Alias Name, Asserted or Deasserted state, and the Date and Time of the event. When in the SER Events screen, three SER records are displayed. Using the navigation pushbuttons, the most recent 200 SER events are viewable on the front-panel display. The topmost event is the most recent event and the bottommost event is the oldest. The upper right of the screen displays the number of the SER events currently being viewed. If a new event occurs while viewing the SER events, the display does not update with the new event automatically. To include the new SER event in the display, exit the SER screen by pressing ESC and re-enter the SER Events screen by pressing ENT with the SER Events selection highlighted. This rebuilds the SER Events display and contains the latest SER events triggered.

**Figure 5.23 SER Events Screen**

If no SER events are available, [Figure 5.24](#) is displayed.

**Figure 5.24 No SER Events Screen**

While viewing the SER events, front-panel pushbuttons provide navigation and control functions as indicated in [Table 5.7](#).

Table 5.7 Front-Panel Pushbutton Functions While Viewing SER Events

Pushbutton	Description
Up Arrow, Down Arrow	Navigates one screen at a time up or down. Each screen contains three SER events. Accelerated scrolling is obtained when the pushbutton remains pressed (see accelerated scrolling behavior below).
Left Arrow, Right Arrow	Navigates between SER events to allow adjacent SER events to be displayed on one screen. For example, if events 1, 2, and 3 are displayed, press the Right Arrow once to display events 2, 3, and 4 in the same screen. No accelerated scrolling is provided with the Left Arrow and Right Arrow pushbuttons.
ESC	Returns to the Events Menu
ENT	Does nothing

Hold down either the **Up Arrow** or **Down Arrow** to achieve accelerated scrolling. Holding down the **Up Arrow** or **Down Arrow** navigates one screen at a time for the first five screens, and then increases to five screens at a time if the button remains pressed. Accelerated scrolling stops at the newest or oldest SER event record available, depending on the direction of the scrolling.

When the upper limit of the SER events is reached, press the **Down Arrow** one more time and the report will wrap around to display the screen containing the first SER event. Similarly, when the lower limit of the SER events is reached, press the **Up Arrow** one more time and the report will wrap around to display the screen containing the last SER event.

Breaker Monitor

The SEL-451 features an advanced circuit breaker monitor. Select **BREAKER MONITOR** screens from the **MAIN MENU** to view circuit breaker monitor alarm data on the front-panel display.

Figure 5.25 shows sample breaker monitor display screens. The BKR n ALARM COUNTER screen displays the number of times the circuit breaker exceeded certain alarm thresholds (see *Circuit Breaker Monitor on page A.2.1*).

If you have two circuit breakers and have set NUMBK := 2, the alarm submenu in *Figure 5.25* appears first. Use the navigation pushbuttons to choose either Circuit Breaker 1 or Circuit Breaker 2. Press ENT to view the selected circuit breaker monitor information. An example of the Circuit Breaker 1 ALARM COUNTER screen is shown on the right side of *Figure 5.25*.




Figure 5.25 BREAKER MONITOR Report Screens

Relay Elements (Relay Word Bits)

You can view the RELAY ELEMENTS screen to check the state of the Relay Word bits in the SEL-451. The relay has two unique manual-scrolling features for viewing these elements:

- Accelerated navigation
- Search

These Relay Word bit scrolling features make selecting elements from among the many relay targets easy and efficient. *Figure 5.26* shows an example of the RELAY ELEMENTS screen. If an alias exists for an element, the alias name is displayed instead of the element name. The asterisk (*) in *Figure 5.26* indicates that this Relay Word bit position is reserved for future use.




Figure 5.26 RELAY ELEMENTS Screen

When you move item by item through the Relay Word bit table, pressing the Up Arrow or Down Arrow pushbuttons shows each previous or next screen in turn.

Accelerated navigation occurs when you press and hold the **Up Arrow** or **Down Arrow** pushbuttons. Holding the **Up Arrow** or **Down Arrow** pushbutton repeats the regular pushbutton action at 2 rows every second for the first 10 rows.

Continue pressing the **Up Arrow** or **Down Arrow** pushbutton to cause the relay screen scrolling to accelerate to 20 rows per second. When you are scrolling up in accelerated scrolling, scrolling will stop at the first relay elements screen. When you are scrolling down, scrolling will stop at the last screen.




Figure 5.27 ELEMENT SEARCH Screen

Search mode allows you to find a specific relay target element quickly.

Figure 5.27 shows the menu screen that the relay displays when you select the **SEARCH** option of the **RELAY ELEMENTS** initial menu.

When you first enter this search menu, the block cursor is at the beginning of the element name field and the highlight box in the alphanumeric field is around the letter **A**. Use the navigation pushbuttons to move through the alphanumeric characters. If the highlight is on one of the characters, pressing **ENT** enters the character at the block cursor location in the element name field. Next, the block cursor moves automatically to the character placeholder to the right. If the block cursor was already at the first character position on the left, the block cursor remains at the end of the name field. To backspace the cursor in the element name field, move the highlight to **BACKSPACE** and press **ENT**. When you have finished entering an element name, move the highlight to **ACCEPT** and press **ENT**. At any time, pressing **ESC** returns the display to the **RELAY ELEMENTS** screen.

If the highlight is on **ACCEPT**, the relay finds the matching relay element when you press **ENT**. The relay first searches for alias names, seeking an exact match. If the relay does not find an exact alias name match, it searches for an exact primitive name match. If there is no exact primitive name match, the relay initiates a partial alias name string search, followed by a partial primitive name string search. If the relay finds no match, the screen displays an error message and stays in the **ELEMENT SEARCH** screen. If the relay finds a match, the screen displays the element row containing the matching element.

Local Control

The SEL-451 provides great flexibility in power system control through the **LOCAL CONTROL** menus. You can use the front-panel **LOCAL CONTROL** menus to perform these relay functions:

- Trip and close circuit breakers (password required)
- Assert, deassert, and pulse relay control outputs to command station control actions
- Test relay outputs (password required)

In the first **LOCAL CONTROL** submenu of *Figure 5.28*, you can choose **BREAKER CONTROL**, **LOCAL BITS CONTROL**, or **OUTPUT TESTING**. You must install the circuit breaker control enable jumper to enable circuit breaker control and output testing capability (see *Operating the Relay Inputs and Outputs on*

page U.4.58 and Password and Circuit Breaker Jumpers on page U.2.18). The submenu will not display the --BREAKER CONTROL-- option and the --OUTPUT TESTING-- option if the breaker jumper is not installed. (The relay checks the status of the breaker jumper whenever you activate the front-panel settings and at power-up.) If the breaker jumper is not installed, and there are no local bits enabled, the relay displays an information message when you attempt to enter LOCAL CONTROL and the screen returns to the MAIN MENU after a short delay.

Local bit names that you have programmed (see *Example 5.4*) appear in the local control bit names field between --BREAKER CONTROL-- and --OUTPUT TESTING--, as shown in *Figure 5.28*. Use the **Up Arrow** and **Down Arrow** pushbuttons to highlight the local control action you want to perform. Pressing **ENT** takes you to the specific LOCAL CONTROL screen.




Figure 5.28 LOCAL CONTROL Initial Menu

BREAKER CONTROL

The BREAKER CONTROL option presents a circuit breaker selection submenu if NUMBK := 2. Use the navigation pushbuttons and **ENT** to select the circuit breaker you want to control.

Figure 5.29 shows the BREAKER CONTROL submenu and sample circuit breaker control screens for BREAKER 1. Use the **Up Arrow** and **Down Arrow** pushbuttons to highlight the TRIP BREAKER 1 or CLOSE BREAKER 1 control actions.

When you highlight the trip option and press **ENT**, the relay displays the confirmation message OPEN COMMAND ISSUED and trips Circuit Breaker 1 (Relay Word bit OC1 pulses). The BREAKER 1 STATUS changes to OPEN.

When you highlight the close option and press **ENT**, the relay displays the confirmation message CLOSE COMMAND ISSUED and closes Circuit Breaker 1 (Relay Word bit CC1 pulses). The BREAKER 1 STATUS changes to CLOSED.




Figure 5.29 BREAKER CONTROL Screens

Local Control Bits

The relay provides 32 local control bits with SELOGIC control equation supervision. These local bits replace substation control handles to perform switching functions such as bus transfer switching. The SEL-451 saves the states of the local bits in nonvolatile memory and restores the local bit states at relay power-up.

NOTE: The default settings for LB_SPnn are "1". The default settings satisfy the local bit supervision logic so that local bit operations can take place.

Local control bit supervision is available through a SELOGIC control equation provided in the Front Panel settings (LB_SPnn). For local bit operations to take place, the corresponding LB_SPnn must be asserted. [Table 5.9](#) defines the local bit SELOGIC settings available in the Front Panel settings class.

[Figure 5.31](#) illustrates the logic that supervises all local bit operations (Set, Clear, Pulse).

NOTE: The default settings for LB_DPnn are LBnn. The default settings cause the local bit switch to move to the corresponding state of the local bit (asserted = 1, deasserted = 0).

The SELOGIC control equation local bit status (LB_DPnn) is provided to return the status of a device that is being controlled by the local bit. The LB_DPnn Relay Word bit drives the state of the graphical switch on the display, i.e., with LB_DPnn deasserted, the switch points to 0.

Any unused local control bits default to the clear (logical 0) state. Also, any reconfigured local bit retains the existing bit state after you change the bit setting. Deleting a local bit sets that bit to the clear (logical 0) state.

In the top part of [Figure 5.30](#), the custom labeled functions are those controlled by local control bit operation.

- Enable Bus Switching
- North Bus MOD
- South bus MOD
- Bus Tie Interlock
- Alternate Settings 3

In addition, [Figure 5.30](#) gives an example of a custom-labeled function, Bus Tie Interlock. The LCD shows a graphic representation of a substation control handle. The LB_DPnn SELOGIC control equation determines the state of the switch position on the LCD. If the LB_DPnn Relay Word bit is deasserted, the graphic control handle points to 0; if the LB_DPnn Relay Word bit is asserted, the switch points to 1.

You can program names or aliases for the local bit clear and set states; these appear next to logical 0 and logical 1, respectively, in the lower portion of the sample Bus Tie Interlock screens of [Figure 5.30](#). Use the Up Arrow and Down Arrow pushbuttons to highlight the set (1) or clear (0) control actions. Highlighting the set option (shown in [Figure 5.30](#) as Closed (OK to TIE)) and pressing ENT changes the local control bit and performs the required control action. If the LB_DPnn Relay Word bit asserts, the graphical switch moves to 1 to indicate the asserted local bit status.




Figure 5.30 LOCAL CONTROL Example Menus

To enable a local bit, enter the local bit settings in [Table 5.8](#) ($n = 1\text{--}32$). The format for entering the local bit data is the comma-delimited string:

local bit,control function name,alias for the set state,alias for the clear state,pulse enable

Names or aliases can contain any printable ASCII character except double quotation marks. Use double quotation marks to enclose the name or alias. See [Example 5.4](#) for particular information on enabling a local control bit.

Table 5.8 Local Bit Control Settings^a

Description	Range	Default
Local Bit n	1–32	1
Local Bit n Name	20-character maximum ASCII string	(blank)
Local Bit n Set Alias (1 state)	20-character maximum ASCII string	(blank)
Local Bit n Clear Alias (0 state)	20-character maximum ASCII string	(blank)
Pulse Local Bit n	Y, N	N

^a $n = 1\text{--}32$

The pulse state enable setting at the end of the setting string is optional. If your application requires a pulsed or momentary output, you can activate an output pulse by setting the option at the end of the local bit command string to Y (for Yes). The default for the pulse state is N (for No); if you do not specify Y, the local bit defaults at N and gives a continuous set or clear switch level.

If you enter an invalid setting, the relay displays an error message prompting you to correct your input. If you do not enter a valid local bit number, the relay displays A local bit element must be entered. If you enter a local bit number and that local bit is already in use, the relay displays The local bit element is already in use. Likewise, if you do not enter valid local bit name, set alias, and clear alias, the relay returns an error message. If an alias is too long, the relay displays Too many characters.


Table 5.9 Local Bit SELOGIC^a

Description	Range	Default
Local Bit Supervision n	SELogic Equation, NA	1
Local Bit Status Display n	SELogic Equation, NA	L Bn

^a $n = 1\text{--}32$, only available if the corresponding local bit is defined.

Local Bit Supervision SELOGIC control equation provides supervision of Local Bit Set, Clear, and Pulse operations

Local Bit Status Display SELOGIC control equation returns the status of the local bit switch state.



*SELOGIC Control Equation

Figure 5.31 Local Bit Supervision Logic

EXAMPLE 5.4 Enabling Local Bit Control

This application example demonstrates a method to create one of the control points in the LOCAL CONTROL screens of [Figure 5.30](#) to control the interlock on a power bus tie circuit breaker. Perform the following actions to create a local control bit:

- Eliminate previous usage of the local bit and condition the state of the local bit
- Set the local bit
- Assign the local bit to a relay output

If you are using a previously used local bit, delete all references to the local bit from the SELOGIC control equations already programmed in the relay. A good safety practice would be to disconnect any relay output that was programmed to that local bit.

To change the local bit state, select the bit and set it to the state you want. In addition, you can delete the local bit, which changes the state of this local bit to logical 0 when you save the settings. To delete, use the front-panel settings. When using a communications port and terminal, use the text-edit mode line setting editing commands at the Local Bits and Aliases prompt to go to the line that lists Local Bit 9. (See [Text-Edit Mode Line Editing on page U.4.19](#) for information on text-edit mode line editing.) To delete Local Bit 9, type **DELETE <Enter>** after the line that displays Local Bit 9 information. For example, if a previously programmed Local Bit 9 appears in the **SET F** line numbered listings on Line 1, then typing **DELETE <Enter>** at Line 1 deletes Local Bit 9.

Next, set the local bit. In the Front Panel settings (**SET F**), enter the following:

1: **LB09, "Bus Tie Interlock", "Closed (OK to TIE)", "Open (No TIE)"**, N

This sets Local Bit 9 to "Bus Tie Interlock" with the set state as "Closed (OK to TIE)" and the clear state as "Open (No TIE)."

Assign the local bit to a relay output. In the Output settings (**SET O**), set the SELOGIC control equation, OUT201, to respond to Local Bit 9.

OUT201:= LB09

Use the appropriate interface hardware to connect the circuit breaker interlock to OUT201.

OUTPUT TESTING

NOTE: The circuit breaker control enable jumper J18C must be installed to perform output testing (see [Main Board Jumpers on page U.2.18](#)).

You can check for proper operation of the SEL-451 control outputs by using the OUTPUT TESTING submenu of the LOCAL CONTROL menu. A menu screen similar to [Figure 5.32](#) displays a list of the control outputs available in your relay configuration. For more information on output testing, see [Control Output on page U.4.58](#).




Figure 5.32 OUTPUT TESTING Screen

Set>Show

NOTE: You cannot use the front-panel SET/SHOW menus to change front-panel settings. To change front-panel settings, use a communications port interface and the **SET F** command or use the AcCELERATOR QuickSet Front Panel settings.

You can use the SET/SHOW menus to examine or modify SEL-451 port settings, global settings, active group settings, and date/time. From the front panel you can change only the settings classes and settings listed in [Table 5.10](#).

Table 5.10 Settings Available From the Front Panel

Class/Setting	Description
PORT	Relay communications port settings
GLOBAL	Global relay settings
GROUP	Relay group settings
ACTIVE GROUP	Active settings group number 1–6
DATE/TIME	Date and time settings

[Figure 5.33](#) shows how to enter the setting CTRW (Terminal W CT ratio) from the front panel. At the MAIN MENU, select the SET/SHOW item and press ENT. The LCD screen displays the SET/SHOW screen of [Figure 5.33](#). Use the navigation pushbuttons to select the relay settings class (PORT, GROUP, and GLOBAL) or to change the ACTIVE GROUP or the DATE/TIME. Select the GROUP class.

NOTE: Port 5 settings are not available through the front panel on SEL-451 model relays with an SEL-2701/SEL-2702 Ethernet card.

Next, select the particular instance of the settings class. For the PORT settings class, the instances are PORT 1, PORT 2, PORT 3, and PORT F. For the GROUP class, the instances are the numbered groups from 1 through 6 and M, the breaker monitor (see the GROUP screen in [Figure 5.33](#)). The class GLOBAL, the setting ACTIVE GROUP = n (where n is a number from 1 to 6), and the settings for DATE/TIME have no settings instance screens. In the GROUP screen, move the highlight box to 3 and press ENT.

Proceed to selecting the settings category. The GROUP submenu in [Figure 5.33](#) is an example of settings Group 3 categories. Once you have highlighted the settings category, pressing ENT causes the relay to display the particular settings in that category. The LINE CONFIGURATION screen in [Figure 5.33](#) shows the settings that you can set in the line configuration settings category.

To edit or examine a setting, use the Up Arrow and Down Arrow pushbuttons to highlight that setting, then press ENT. The relay displays a settings entry screen with the existing setting value (see the SET CTRW screen in [Figure 5.33](#)). If the prompt for the selected setting does not fit on the line, the relay scrolls the setting prompt across the screen.

Enter the setting name using a method similar to the method described in [Relay Elements \(Relay Word Bits\) on page U.5.22](#). Place characters in the element name field (with the block cursor) using the navigation pushbuttons.

If the data you entered is valid (within settings range checks), the front-panel display returns to the settings category screen that shows each setting and corresponding present value (see the LINE CONFIGURATION screen of

([Figure 5.33](#)). If the data you entered are invalid, the relay displays an error message screen, then returns to the particular settings entry screen so you can attempt a valid settings entry (see the `CTRW` screen of [Figure 5.33](#)).

When finished entering the new settings data, press **ESC**. The relay prompts you with a Save Settings screen. Using the navigation pushbuttons, answer YES to make the settings change(s), or NO to abort the settings change(s).




Figure 5.33 SET/SHOW Screens

The SEL-451 displays different settings entry screens depending on the settings type. For the CTRW setting in [Figure 5.33](#), the relay requires basic alphanumeric input. Other settings can have other data input requirements. The front-panel settings input data types are the following:

- Basic alphanumeric
- Character or string or SELOGIC control equations
- Setting options

For alphanumeric settings, the relay presents the character or string input screen. Some settings have specific options; use the setting options screens to select these options. [Figure 5.34](#) shows examples of the settings input screens.




Figure 5.34 Sample Settings Input Screens

ACTIVE GROUP

Perform the following steps to change the active setting group:

- Step 1. Select the ACTIVE GROUP option of the SET/SHOW submenu screen (shown in [Figure 5.33](#)) to change the settings group.

The relay performs a password validation test at this point to confirm that you have Breaker Access Level authorization or above.

- Step 2. If access is allowed, and all the results of SELOGIC control equations SS1–SS6 are not logical 1 (asserted), then the relay displays the EDIT ACTIVE GROUP screen in [Figure 5.35](#).

The relay shows the active group and underlines the group number after NEW GROUP =.

- Step 3. Use the Up Arrow and Down Arrow pushbuttons to increase or decrease the NEW GROUP number.

- Step 4. Once you have selected the new active group, press ENT to change the relay settings to this new settings group.




Figure 5.35 Changing the ACTIVE GROUP

DATE/TIME

Another submenu item of the SET/SHOW first screen (*Figure 5.33*) is the DATE/TIME screen shown in *Figure 5.36*. The SEL-451 generates date and time information internally, or you can use external high-accuracy time modes with time sources such as a GPS receiver.

Figure 5.36 is the relay date/time screen when a high accuracy source is in use. Possible time sources, qqqqq, are listed in *Table 4.10*. If you use a high-accuracy time source, edits are disabled, the DATE/TIME display does not show the highlight, and the screen does not show the help message on the bottom line.





Figure 5.36 DATE/TIME Screen

When operating from a non-high-accuracy time source, you can use the front-panel DATE and TIME entry screens to set the date and time.

Figure 5.37 shows an example of these edit screens. Use the Left Arrow and Right Arrow navigation pushbuttons to move the underscore cursor; use the Up Arrow and Down Arrow navigation pushbuttons to increment or decrement each date and time digit as appropriate to set the date and time. For a description of the LAST UPDATE SOURCE field, see *Configuring High-Accuracy Timekeeping on page U.4.73*.

**Figure 5.37** Edit DATE and Edit TIME Screens


To enable a high-accuracy external time source, connect an IRIG-B clock to the relay. For a discussion of the IRIG timing modes in the SEL-451 see [Configuring High-Accuracy Timekeeping on page U.4.73](#). See [TIME Input Connections on page U.2.45](#) for more information on connecting time source inputs.

Relay Status

The SEL-451 performs continuous hardware and software self-checking. If any vital system in the relay approaches a failure condition, the relay issues a status warning. If the relay detects a failure, the relay displays the status failure RELAY STATUS screen immediately on the LCD.

For both warning and failure conditions, the relay shows the error message for the system or function that caused the warning or failure condition. You can access the RELAY STATUS screen via the MAIN MENU. The RELAY STATUS screen shows the firmware identification number (FID), serial number, whether the relay is enabled, and any status warnings.

[Figure 5.38](#) shows examples of a normal RELAY STATUS screen, a status warning RELAY STATUS screen, and a status failure RELAY STATUS screen. For more information on status warning and status failure messages, see [Relay Self-Tests on page U.6.35](#).

**Figure 5.38** Relay STATUS Screens

View Configuration

You can use the front panel to view detailed information about the configuration of the firmware and hardware components in the SEL-451 Relay. In the MAIN MENU, highlight the VIEW CONFIGURATION option by using the navigation pushbuttons. The relay presents five screens in the order shown in [Figure 5.39](#). Use the navigation pushbuttons to scroll through these screens. When finished viewing these screens, press **ESC** to return to the MAIN MENU.




Figure 5.39 VIEW CONFIGURATION Sample Screens

Display Test

You can use the DISPLAY TEST option of the MAIN MENU to confirm operation of all of the LCD pixels. The LCD screen alternates the on/off state of the display pixels once every time you press ENT. [Figure 5.40](#) shows the resulting two screens. The DISPLAY TEST option also illuminates all of the front-panel LEDs. To exit the test mode, press ESC.

NOTE: The LCD DISPLAY TEST does NOT reset the front-panel LED targets.




Figure 5.40 DISPLAY TEST Screens

Reset Access Level

The SEL-451 uses various passwords to control access to front-panel functions. As you progress through these menus, the relay detects the existing password level and prompts you for valid passwords before allowing you access to levels greater than Access Level 1 (see [Password on page U.5.15](#) in this section). When you want to return the front-panel to the lowest access level (Access Level 1), highlight RESET ACCESS LEVEL item on the MAIN MENU. Pressing ENT momentarily displays the screen of [Figure 5.41](#) and places the front panel at Access Level 1.

The relay automatically resets the access level to Access Level 1 upon front-panel timeout (setting FP_TO is not set to OFF). Use this feature to reduce the front-panel access level before the timeout occurs.




Figure 5.41 RESET ACCESS LEVEL Screen

One Line Diagram (Applicable to the SEL-451-4)

This option from the Front Panel MAIN MENU displays the one-line diagram that has been selected in the Bay settings class. From this screen, disconnect switch open and close operations, as well as breaker open and close operations can be performed. This screen also displays labels for the different apparatus in the bay configuration and Analog Quantity metering values. The one-line diagram, display labels, and Analog Quantities are settable in the Bay class settings; see [Bay Settings \(SEL-451-4 Relay\) on page R.10.49](#) for these settings. See [Figure 5.42](#) for an illustration of the one-line diagram.

For navigation and control operations in the one-line diagram screen, see [Section 5: Bay Control in the Applications Handbook](#).




Figure 5.42 One-Line Diagram Screen

Front-Panel Automatic Messages

The SEL-451 automatically displays alert messages. Any message generated due to an alert condition takes precedence over the normal ROTATING DISPLAY and the MAIN MENU. Alert conditions include these significant events:

- Alarm Point asserts
- Event reports and trips (user-defined)
- Status warnings
- Status failures

In order to display event reports automatically from the ROTATING DISPLAY, you must set front-panel setting DISP_ER to Y. Front-panel setting TYPE_ER allows the user to define which types of event reports will be automatically displayed from the normal ROTATING DISPLAY; ALL will display all event types described in [Table 3.6 on page A.3.33](#) and TRIP will display only the event types that include the assertion of the TRIP Relay Word bit.

For alarm point assertions, qualified event reports (including trip events) and status warnings, the relay displays the corresponding full-screen automatic message, only if the front-panel display is in the time-out or standby condition (the relay is scrolling through the default display points/enabled metering screens of the ROTATING DISPLAY or is displaying the MAIN MENU). When a status warning, alarm, or event is triggered, the relay full-screen presentation is similar to the screens of [Figure 5.43](#).




Figure 5.43 Sample Status Warning and Trip EVENT SUMMARY Screens

If you are on site using the SEL-451 front panel in menus and screens other than the MAIN MENU and a status warning occurs, alarm point assertions, or an event report triggers, the relay shows automatic messages at the bottom of the active screen in the message area.

For example, the message area shows RELAY STATUS WARNING for a status warning. [Figure 5.44](#) is an example of a status warning notification that appears in the message area of a LOCAL CONTROL (local bit) screen. If an alarm point asserts while you are using a front-panel screen, the message area notification reads: ALARM EVENT. If a trip event occurs while you are using a front-panel screen, the message area notification reads RELAY EVENT. When you repeatedly press ESC (as if returning to the MAIN MENU) during this warning or trip alert situation, the relay displays the corresponding full-screen automatic message concerning the warning or trip in place of the MAIN MENU. If the front-panel display is at the MAIN MENU and a status warning occurs, the full-screen warning replaces the MAIN MENU. After you view the warning, alarm, or trip screen, pressing ESC returns the LCD to the MAIN MENU.




Figure 5.44 Sample Status Warning in the LCD Message Area

For a status failure, the relay immediately displays the full-screen status alert regardless of the present front-panel operating state. The relay displays no further LCD screens until the status failure clears. Should an unlikely status failure event occur, contact your local Technical Service Center or an SEL factory representative (see [Technical Support on page U.6.41](#)).

Operation and Target LEDs

The SEL-451 gives you at-a-glance confirmation of relay conditions via operation and target LEDs. These LEDs are located in the middle of the relay front panel. The SEL-451 provides either 16 or 24 LEDs depending on ordering option.

You can reprogram all of these indicators except the **ENABLED** and **TRIP** LEDs to reflect other operating conditions than the factory default programming described in this subsection. Settings Tn_LED are SELOGIC control equations that, when asserted during a relay trip event, light the corresponding LED. Parameter n is a number from 1 through 24 that indicates each LED. LED positions are described in parenthesis next to each LED in [Figure 5.45](#).

Program settings $TnLEDL := Y$ to latch the LEDs during trip events; when you set $TnLEDL := N$, the trip latch supervision has no effect and the LED follows the state of the Tn_LED SELOGIC control equation. The relay reports these targets in event reports; set the alias name listed in the report (as many as eight characters) with settings $TnLEDA$. The asserted and deasserted colors for the LED are determined with settings $TnLEDC$. Options include red, green, amber, or off.

After setting the target LEDs, issue the **TAR R** command to reset the target LEDs. For a concise listing of the default programming on the front-panel LEDs, see [Front-Panel Settings on page R.10.33](#).

Use the slide-in labels to mark the LEDs with custom names. Included on the SEL-451 Product Literature CD are Customer Label Templates to print labels for the slide-in label carrier.




Figure 5.45 Factory Default Front-Panel Target Areas (16 or 24 LEDs)

Figure 5.45 shows the arrangement of the operation and target LEDs region into several areas described in *Table 5.11*.

Table 5.11 Front-Panel Target LEDs

Label	Function
ENABLED, TRIP	Operational
INST, TIME, COMM, SOTF, NEG-SEQ	Trip Type
79 RESET, 79 CYCLE, 79 LOCKOUT	Recloser Status
A FAULT, B FAULT, C FAULT, GROUND	Phase(s) or Ground
LOP, VAY ON, VBY ON, VCY ON, VAZ ON ^a , VBZ ON ^a , VCZ ON ^a	Voltage Status
BKR FAIL ^a , BKR MAINT ^a , EXT TRIP ^a , 51 TIMING ^a	Miscellaneous Status
IRIG LOCKED ^a	Clock Status

^a Only available in 24 LED models.

Operational

The **ENABLED** LED indicates that the relay is active. Trip events illuminate the **TRIP** LED. The prominent location of the **TRIP** LED in the top target area helps you recognize a trip event quickly. Program settings EN_LEDc and TR_LEDc to determine the color of the respective LED. Options include red or green.

TARGET RESET and Lamp Test

For a trip event, the relay latches the trip-involved target LEDs (except for the **ENABLED** LED and the Recloser Status area LEDs). Press the **TARGET RESET** pushbutton to reset the latched target LEDs. When a new trip event occurs and you have not reset the previously latched trip targets, the relay clears the latched targets and displays the new trip targets.

Pressing the **TARGET RESET** pushbutton illuminates all the LEDs. Upon releasing the **TARGET RESET** pushbutton, two possible trip situations can exist: the conditions that caused the relay to trip have cleared or the trip conditions remain present at the relay inputs. If the trip conditions have cleared, the latched target LEDs turn off. If the trip event conditions remain, the relay re-

illuminates the corresponding target LEDs. The **TARGET RESET** pushbutton also removes the trip automatic message displayed on the LCD menu screens if the trip conditions have cleared.

Lamp Test Function With TARGET RESET

The **TARGET RESET** pushbutton also provides a front-panel lamp test. Pressing **TARGET RESET** illuminates all the front-panel LEDs, and these LEDs remain illuminated for as long as you press **TARGET RESET**. The target LEDs return to a normal operational state after you release the **TARGET RESET** pushbutton.

Lamp Test Function With LCD DISPLAY TEST Menu

The LCD menus provide a front-panel **DISPLAY TEST** mode. This menu-activated lamp test, from the **DISPLAY TEST** menu, does not reset the target LEDs (see [Display Test on page U.5.34](#)).

Other Target Reset Options

You can reset the target LEDs with the ASCII command **TAR R**; see [TARGET on page R.9.57](#) for more information.

The **TAR R** command and the **TARGET RESET** pushbutton also control the TRGTR Relay Word bit, which can be used for other functions, as shown in [Figure 1.67 on page R.1.100](#). TRGTR is the factory default setting for the unlatch trip SELOGIC control equation, ULTR, in group settings. See [Table 1.61 on page R.1.87](#).

You can reset the targets from the ACCELERATOR QuickSet Control branch of the HMI tree view. Programming specific conditions in the SELOGIC control equation RSTTRGT is another method to reset the relay targets. Access RSTTRGT in the relay **Global** settings (**Data Reset Control**); to use RSTTRGT, you must enable data reset control with global setting EDRSTC := Y.

Trip Type

The SEL-451 indicates essential information about the most recent relay trip event with the LEDs of the Trip Type area. These trip types are **INST**, **TIME**, **COMM**, **SOTF**, and **NEG-SEQ**. For information on setting the corresponding trip logic, see [Trip Logic on page R.1.86](#).

The **INST** target LED illuminates if elements 51S1 or 51S2 or 50P1 pick up and a relay trip occurs within three cycles. [Table 5.12](#) lists the elements that activate the **INST** LED in the factory default settings. [Figure 5.46](#) shows the operation of the **INST** target LED as defined by the factory settings. This logic can be changed to suit your application.

Table 5.12 INST Target LED Trigger Elements-Factory Defaults

Element	Description
51S1	Inverse-time Overcurrent Element 1 pickup
51S2	Inverse-time Overcurrent Element 1 pickup
50P1	Level 1 Phase Overcurrent Element
PSV01	Indicates overcurrent pickup
PCT01Q	Indicates overcurrent pickup for at least 3 cycles




Figure 5.46 INST Target LED Default Operation

TIME

The **TIME** target LED indicates that a timed relay element caused a relay trip. The elements that activate the **TIME** LED in the factory default settings are 51S1T (Inverse-Time Overcurrent Element 1 timed out) or 51S2T (Inverse-Time Overcurrent Element 2 timed out).

COMM

The **COMM** LED illuminates, indicating that tripping resulted from a communications-assisted trip. The relay lights the **COMM** target when there is a relay tripping condition and the Relay Word bit COMPRM (communications-assisted trip permission) asserts.

SOTF

The **SOTF** target LED indicates that the switch-onto-fault protection logic operated. The relay illuminates the **SOTF** target when there is a relay tripping condition and the Relay Word bit SOTFT (switch-onto-fault trip) asserts.

NEG-SEQ

This LED is not programmed in the SEL-451 factory default settings.

Recloser Status

The **79 RESET**, **79 CYCLE**, and the **79 LOCKOUT** target LEDs show the operating status of the SEL-451 reclosing function. The **79 RESET** LED indicates that the relay recloser is in the reset or ready-to-reclose state for Circuit Breaker 1 (Relay Word bit BK1RS is asserted).

The **79 CYCLE** target illuminates when the relay is in the auto-reclose cycle state.

The **79 LOCKOUT** target illuminates when the relay has completed the reclose attempts unsuccessfully (a drive-to-lockout condition), or when other programmed lockout conditions exist (Relay Word bit BK1L0 is asserted).

See [Section 2: Auto-Reclosing and Synchronization Check in the Reference Manual](#) for complete information on the SEL-451 recloser function.

Phase(s) or Ground

The phase(s) or ground targets illuminate according to the SEL-451 targeting logic. This logic accurately classifies which phase, phases, and/or ground were involved in a trip event. The Target Logic Relay Word bits PHASE_A, PHASE_B, PHASE_C, and GROUND are included in the factory default settings for T9_LED through T12_LED.

The **A FAULT** target LED lights for faults on the power system A-phase. Single-phase-to-ground faults from A-phase to ground illuminate both the **A FAULT** and **GROUND** targets. A phase-to-phase fault between A-phase and B-phase illuminates the **A FAULT** target and the **B FAULT** target.

The relay displays faults involving other phase combinations similarly. If the phase-to-phase fault includes ground, the relay also lights the **GROUND** target. The relay lights the **A FAULT**, **B FAULT**, and **C FAULT** target LEDs for a three-phase fault.

Voltage Status

The **LOP**, **VAY ON**, **VBY ON**, **VCY ON**, **VAZ ON**, **VBZ ON**, and **VCZ ON** target LEDs illuminate in the SEL-451 for voltage status conditions.

The **LOP** LED illuminates when the relay detects a loss-of-potential condition (Relay Word bit LOP is asserted). See [Loss-of-Potential Logic on page R.1.28](#) for complete details.

The **VAY ON**, **VBY ON**, **VCY ON**, **VAZ ON**, **VBZ ON**, and **VCZ ON** LEDs illuminate when the phase filtered instantaneous voltages are greater than 55 V. See [Table 10.75 on page R.10.33](#) for setting default values. The default setting of 55 V is 82 percent of the line-to-neutral nominal voltage of 67 V to coincide with the nominal line-to-line voltage setting of 115 V (VNOMY and VNOMZ - PT nominal voltage).

Miscellaneous Status

The **BKR FAIL**, **BKR MAINT**, **EXT TRIP**, and **51 TIMING** target LEDs illuminate in the SEL-451 for miscellaneous status conditions.

The **BKR FAIL** LED illuminates when the relay detects a breaker failure trip for Circuit Breaker 1 (Relay Word bit BFTRIP1 is asserted). See [Circuit Breaker Failure Protection Trip Logic on page A.1.40](#) for complete details.

The **BKR MAINT** LED illuminates when the relay detects breaker maintenance is needed for Circuit Breaker 1 (Relay Word bit B1BCWAL is asserted). See [Circuit Breaker Contact Wear Monitor on page A.2.2](#) for complete details.

The **EXT TRIP** LED is not programmed in the SEL-451 factory default settings.

The **51 TIMING** LED illuminates when the relay detects an inverse-time overcurrent element is timing on its curve (Relay Word bit 51S1, 51S2, 51S3, 51S4, 51S5, or 51S6 is asserted). See [Inverse-Time Overcurrent Elements on page R.1.55](#) for complete details.

Clock Status

The **IRIG LOCKED** target LED illuminates in the SEL-451 when the relay detects synchronization to an external clock with less than 500 ns of jitter (Relay Word bit TIRIG is asserted). See [IRIG-B on page U.4.73](#) for complete details.

Front-Panel Operator Control Pushbuttons

The SEL-451 front panel features large operator control pushbuttons coupled with amber annunciator LEDs for local control. [Figure 5.47](#) shows this region of the relay front panel with factory default configurable front-panel label text. The SEL-451 provides either 8 or 12 pushbuttons depending on ordering option.




Figure 5.47 Operator Control Pushbuttons and LEDs (8 or 12 Pushbuttons)

Factory default programming associates specific relay functions with the eight pushbuttons and LEDs, as listed in [Table 5.13](#). For a concise listing of the default programming for the front-panel pushbuttons and LEDs, see [Front-Panel Settings on page R.10.33](#).

Table 5.13 Operator Control Pushbuttons and LEDs—Factory Defaults

LABEL	Function
GROUND ENABLED	Enable ground-overcurrent tripping
RECLOSE ENABLED	Enable automatic reclosing
REMOTE ENABLED	Enable remote control
ALT SETTINGS	Switch between setting group 1 and setting group 2 ^a . The LED is illuminated when group 1 is not the active setting group.
HOT LINE TAG	Enable Hot Line Tag
DISPLAY POINTS ^b	Display Display Points HMI screen
SER EVENTS ^b	Display SER HMI Screen
EVENT SUMMARY ^b	Display Event Summaries HMI screen
AUX n ^c	Programmable
BREAKER CLOSED/CLOSED ^d	Close Circuit Breaker 1
BREAKER OPEN/TRIP ^d	Open Circuit Breaker 1

^a With factory settings, the ALT SETTINGS pushbutton must be pressed and held for three seconds before the SEL-451 will change setting groups.

^b Available on 12-pushbutton models.

^c n is the number of AUX buttons available depending on ordering option.

^d Not available on model with auxiliary TRIP/CLOSE pushbuttons.

Press the operator control pushbuttons momentarily to toggle on and off the functions listed adjacent to each LED/pushbutton combination. The **CLOSE** and **TRIP** pushbuttons momentarily assert the close and trip relay outputs after a short delay.

The operator control pushbuttons and LEDs are programmable. [Figure 5.48](#) describes the factory defaults for the operator controls. [Figure 5.8 on page A.5.13](#) describes the factory defaults for the SEL-451-4 operator controls.


There are two ways to program the operator control pushbuttons. The first is through front-panel settings **PBn_HMI**. These settings allow any of the operator control pushbuttons to be programmed to display a particular HMI screen category. The HMI screen categories available are Alarm Points, Display Points, Event Summaries, SER, and Bay Control one-line diagram (available in the SEL-451-4). Front-panel setting **NUM_ER** allows the user to define the number of event summaries that are displayed via the operator control pushbutton; it has no effect on the event summaries automatically displayed or the event summaries available through the main menu. Each HMI screen category can be assigned to a single pushbutton. Attempting to program more than one pushbutton to a single HMI screen category will result in an error. After assigning a pushbutton to an HMI screen category, pressing the pushbutton will jump to the first available HMI screen in that particular category. If more than one screen is available, a navigation scroll bar will be displayed. Pressing the navigation arrows will scroll through the available screens. Subsequent pressing of the operator control pushbutton will advance through the available screens, behaving the same as the **Right Arrow** or the **Down Arrow** pushbutton. Pressing the **ESC** pushbutton will return the user to the **ROTATING DISPLAY**. The second way to program the operator control pushbutton is through SELOGIC control equations, using the pushbutton output as a programming element.

Using SELOGIC control equations, you can readily change the default pushbutton and LED functions. Use the slide-in labels to mark the pushbuttons and pushbutton LEDs with custom names to reflect any programming changes that you make. The labels are keyed; you can insert each Operator Control Label in only one position on the front of the relay. Included on the SEL-451 Relay Product Literature CD are word processor templates for printing slide-in labels. See the instructions included in the Configurable Label kit for more information on changing the slide-in labels.

The SEL-451 has two types of outputs for each of the front-panel pushbuttons. Relay Word bits represent the pushbutton presses. One set of Relay Word bits follows the pushbutton and another set pulses for one processing interval when the button is pressed. Relay Word bits PB1 through PB12 are the “follow” outputs of operator control pushbuttons. Relay Word bits PB1_PUL through PB12PUL are the pulsed outputs.

Annunciator LEDs for each operator control pushbutton are PB1_LED through PB12LED. The factory defaults programmed for these LEDs are protection latches (PLT01, for example), settings groups, Relay Word bits (NOT SG1), and the status of the circuit breaker auxiliary contacts (52ACL1). The asserted and deasserted colors for the LED are determined with settings **PBnCOL**. Options include red, green, amber, or off.

You can change the LED indications to fit your specific control and operational requirements. This programmability allows great flexibility and provides operator confidence and safety, especially in indicating the status of functions that are controlled both locally and remotely.

Front-Panel Operator Control Pushbuttons**Figure 5.48** Factory Default Operator Control Pushbuttons

Section 6

Testing and Troubleshooting

This section contains guidelines for determining and establishing test routines for the SEL-451 Relay. Follow the standard practices of your company in choosing testing philosophies, methods, and tools. The relay incorporates self-tests to help you diagnose potential difficulties should these occur. The subsection [Relay Troubleshooting on page U.6.38](#) contains a quick-reference table for common relay operation problems.

Topics, tests, and troubleshooting procedures presented in this section include the following:

- [Testing Philosophy on page U.6.1](#)
- [Testing Features and Tools on page U.6.4](#)
- [Relay Test Connections on page U.6.8](#)
- [Test Methods on page U.6.13](#)
- [Checking Relay Operation on page U.6.25](#)
- [Relay Self-Tests on page U.6.35](#)
- [Relay Troubleshooting on page U.6.38](#)
- [Technical Support on page U.6.41](#)

The SEL-451 is factory calibrated; this section contains no calibration information. If you suspect that the relay is out of calibration, contact your Technical Service Center or the SEL factory.

Testing Philosophy

Protective relay testing generally consists of three categories: acceptance testing, commissioning testing, and maintenance testing. The categories differ in testing complexity and according to when these activities take place in the life of the relay.

Each testing category includes particular details as to when to perform the test, the testing goals at that time, and the relay functions that you need to test. This information is a guide to testing the SEL-451; be sure to follow the practices of your company for relay testing.

Acceptance Testing

SEL performs detailed acceptance testing on all new relay models and versions. We are certain that your SEL-451 meets published specifications. Even so, you can perform acceptance testing on a new relay model to become familiar with the relay operating theory and settings; this familiarity helps you apply the relay accurately and correctly. A summary of acceptance testing guidelines is presented in [Table 6.1](#).

Table 6.1 Acceptance Testing

Details	Description
Time	Test when qualifying a relay model for use on the utility system.
Goals	a) Confirm that the relay meets published critical performance specifications such as operating speed and element accuracy. b) Confirm that the relay meets the requirements of the intended application. c) Gain familiarity with relay settings and capabilities.
Test	Test all protection elements and logic functions critical to your intended application.

Commissioning Testing

SEL performs a complete functional check and calibration of each SEL-451 before shipment so that your relay operates correctly and accurately. You should perform commissioning tests to verify proper connection of the relay to the power system and all auxiliary equipment. Check control signal inputs and outputs. Check breaker auxiliary inputs, SCADA control inputs, and monitoring outputs. Use an ac connection test to verify that the relay current and voltage inputs are the proper magnitude and phase rotation.

Brief fault tests confirm that the relay settings and protection scheme logic are correct. You do not need to test every relay element, timer, and function in these tests.

At commissioning, use the relay **METER** command to verify the ac current and voltage magnitude and phase rotation (see *Examining Metering Quantities on page U.4.34*).

Use the **PUL** command to pulse relay control output operation. Use the **TAR** command to view relay targets and verify that control inputs are operational. Use **TEST FM**, **TEST DNP**, and **TEST DB** to check SCADA interfaces. (See *TEST DB on page R.9.59* for information on these relay commands.)

Table 6.2 lists guidelines for commissioning testing. For further discussion of these tests, see *Checking Relay Operation on page U.6.25*.

Table 6.2 Commissioning Testing

Details	Description
Time	Test when installing a new protection system.
Goals	a) Validate all system ac and dc connections. b) Confirm that the relay functions as intended using your settings. c) Check that all auxiliary equipment operates as intended. d) Check SCADA interface.
Tests	Test all connected/monitored inputs and outputs, and the polarity and phase rotation of ac connections. Make simple checks of protection elements. Test communications interfaces.

Maintenance Testing

The SEL-451 uses extensive self-testing routines and features detailed metering and event reporting functions. These features reduce your dependence on routine maintenance testing. When you want to perform maintenance testing, follow the recommendations in *Table 6.3*.

Table 6.3 Maintenance Testing

Details	Description
Time	Test at scheduled intervals or when there is an indication of a problem with the relay or power system.
Goals	a) Confirm that the relay is measuring ac quantities accurately. b) Check that scheme logic and protection elements function correctly. c) Verify that auxiliary equipment functions correctly.
Tests	Test all relay features/power system components that did not operate during an actual fault within the past maintenance interval.

You can use the SEL-451 reporting features as maintenance tools. Periodically compare the relay **METER** command output to other meter readings on a line to verify that the relay measures currents and voltages correctly and accurately. Use the circuit breaker monitor, for example, to detect slow breaker auxiliary contact operations and increasing or varying breaker pole operating times. For details on these features, see *Circuit Breaker Monitor on page A.2.1*.

Each occurrence of a fault tests the protection system and relay application. Review relay event reports in detail after each fault to determine the areas needing your attention. Use the event report current, voltage, and relay element data to determine that the relay protection elements and communications channels operate properly. Inspect event report input and output data to determine whether the relay asserts outputs at the correct times and whether auxiliary equipment operates properly.

At each maintenance interval, the only items to be tested are those that have not operated (via fault conditions and otherwise) during the maintenance interval. The basis for this testing philosophy is simple: you do not need to perform further maintenance testing for a correctly set and connected relay that measures the power system properly and for which no relay self-test has failed.

The SEL-451 is based on microprocessor technology; the relay internal processing characteristics do not change over time. For example, if time-overcurrent element operating times change, these changes occur because of alterations to relay settings and/or differences in the signals applied to the relay. You do not need to verify relay element operating characteristics as a part of maintenance checks.

SEL recommends that you limit maintenance tests on SEL relays according to the guidelines listed in *Table 6.3*. You will spend less time checking relay operations that function correctly. You can use the time you save to analyze event data and thoroughly test systems needing more attention.

Testing Features and Tools

The SEL-451 provides the following features to assist you during relay testing:

- Metering
- High-resolution oscillography
- Event reports
- Event summary reports
- SER (Sequential Events Recorder) reports

Certain relay commands are useful in confirming relay operation. The following commands, for example, aid you in testing the relay:

- **TAR**
- **PUL**
- **TEST DB**
- **TEST FM**
- **TEST DNP**

In addition, the SEL-451 incorporates a low-level test interface where you can interrupt the connection between the relay input transformers and the input processing module. Use the low-level test interface to apply reduced-scale test quantities from the SEL-4000 Relay Test System; you do not need to use large power amplifiers to perform relay testing.

Test Features

Metering

The metering data show the ac currents and voltages (magnitude and phase angle) connected to the relay in primary values. In addition, metering shows many other quantities including the power system frequency (FREQ) and the voltage input to the station dc battery monitors (Vdc1 and Vdc2). Compare these quantities against quantities from other devices of known accuracy. The metering data are available at the serial ports, from the ACCELERATOR QuickSet® SEL-5030 Software HMI, and at the front-panel LCD METER menu. See [MET on page R.9.34](#), [Meter on page U.5.16](#), [HMI Meter and Control on page U.3.21](#), and [Examining Metering Quantities on page U.4.34](#) for more information.

High-Resolution Oscillography

NOTE: Control Inputs are sampled 16 times per cycle, and the raw binary data (prior to debounce timer conditioning) is available in high-resolution oscillography (see [Figure 3.1 on page A.3.3](#)). The COMTRADE data labels for raw control input data are IN101-IN107, and optionally IN201-IN2nn, IN301-IN3nn, where nn = 01-08 or 01-24.

The SEL-451 takes an unfiltered data snapshot of the power system at each event trigger or trip. The relay samples power system data at high sample rates from 1 kHz to 8 kHz. You can use the SEL-5601 Analytic Assistant or other COMTRADE viewing program to export and view these raw data in a binary COMTRADE file format. Use high-resolution oscillography to capture fast power system transients or to examine low frequency anomalies in the power system. See [Raw Data Oscillography on page A.3.8](#) for more information.

Event Reports

NOTE: Control Inputs are sampled 16 times per cycle, and then conditioned by a debounce timer. The resulting Relay Word bits are updated 8 times per cycle and are available in standard event report files—see [Figure 3.1 on page A.3.3](#).

The relay also generates a filtered-quantities event report in response to faults or disturbances. Each event report contains information on current and voltage, relay element states, control inputs, and control outputs. If you are unsure of the relay response or your test method, the event report provides you with information on the operating quantities that the relay used at the event trigger. The relay provides oscillographic displays of the filtered event report data, which give you a visual tool for testing relay operating quantities. You can use the serial ports and ACSELERATOR QuickSet to view event reports. See [Event Reports, Event Summaries, and Event Histories on page A.3.13](#) for a complete discussion of event reports.

Event Summary Reports

The relay generates an event summary for each event report; use these event summaries to quickly verify proper relay operation. With event summaries, you can quickly compare the reported fault current and voltage magnitudes and angles against the reported fault location and fault type. If you question the relay response or your test method, you can obtain the full event report and the high-resolution oscillographic report for a more detailed analysis. See [Event Summary on page A.3.31](#) for more information on the event summary.

SER Reports

The relay provides an SER report that time tags changes in relay elements, control inputs, and control outputs. Use the SER for convenient verification of the pickup and dropout of any relay element. For a complete discussion of the SER, see [SER \(Sequential Events Recorder\) on page A.3.42](#).

Test Commands

TAR Command

Use the **TAR** command to view the state of relay control inputs, relay outputs, and relay elements individually during a test. You can see relay targets at the serial ports, and from the front-panel LCD (see [TARGET on page R.9.57](#) and [Operation and Target LEDs on page U.5.37](#)).

PUL Command

Use the **PUL** command to test the control output circuits. The specified output closes if open, or opens if closed. You can use the **PUL** command at the serial ports, in the ACSELERATOR QuickSet HMI, and from the front-panel LCD (see [PULSE on page R.9.43](#), [HMI Meter and Control on page U.3.21](#), and [Operation and Target LEDs on page U.5.37](#)).

TEST DB Command

Use the **TEST DB** command for testing the communications card relay database. The **TEST DB** command can be used to override any value in the relay database. Since the relay database provides data to the Ethernet card interfaces, the **TEST DB** command can also be used to test the data read operations of the DNP3 LAN/WAN or IEC 61850 protocols on an installed Ethernet card. Use the **MAP 1** command and the **VIEW1** command to inspect the relay database (see [MAP on page R.9.33](#)). You must be familiar with the relay database structure to use the **TEST DB** command effectively; see [Communications Card Database on page R.4.21](#) for more information.

TEST DNP Command

Use the **TEST DNP** command to test the serial DNP3 interface. Values you enter in the DNP3 map are “override values.” Use the **TEST DNP** command to write override values in the serial DNP3 map. The **TEST DNP** command does not affect data on the DNP3 LAN/WAN interface. For more information on serial DNP3 and the SEL-451, see [DNP3 Communications on page R.6.1](#).

TEST FM Command

Use the **TEST FM** command to override normal Fast Meter quantities for testing purposes. You can only override “reported” Fast Meter values (per-phase voltages and currents). You cannot directly test Fast Meter values that the relay derives from the reported values (power, sequence components, and so on). For more information on Fast Meter and the SEL-451, see [SEL Communications Protocols on page R.5.1](#).

Low-Level Test Interface

The SEL-451 has a low-level test interface between the calibrated input module and the processing module. You can check the relay in two ways: by using secondary injection testing, or by applying low-magnitude ac voltage signals to the low-level test interface.

Connection

CAUTION


Equipment components are sensitive to electrostatic discharge (ESD). Undetectable permanent damage can result if you do not use proper ESD procedures. Ground yourself, your work surface, and this equipment before removing any cover from this equipment. If your facility is not equipped to work with these components, contact SEL about returning this device and related SEL equipment for service.

The top circuit board is the relay main board and the bottom circuit board is the input module board. At the right side of the relay main board (the top board) is the processing module. The input to the processing module is multipin connector J20, the analog or low-level test interface connection. Receptacle J20 is on the right side of the main board; for a locating diagram, see [Figure 2.22](#).

[Figure 6.1](#) shows the low-level interface connections. Note the nominal voltage levels, current levels, and scaling factors listed in [Figure 6.1](#) that you can apply to the relay. Never apply voltage signals greater than 6.6 Vp-p sinusoidal signal (2.33 Vrms) to the low-level test interface.

To use the low-level test interface, perform the following steps:

- Step 1. Remove any cables connected to serial ports on the front panel.
- Step 2. Loosen the four front-panel screws (they remain attached to the front panel), and remove the relay front panel.
- Step 3. Remove the 34-pin ribbon cable from the front panel by pushing the extraction ears away from the connector.
- Step 4. Remove the ribbon cable from the main board J20 receptacle.
- Step 5. Substitute a test cable with the signals specified in [Figure 6.1](#).
- Step 6. Reconnect the cables removed in [Step 4](#) and replace the relay front-panel cover.
- Step 7. Replace any cables previously connected to serial ports on the front panel.



Input Module Output (J3): 66.6 mV At Nominal Current (1 A or 5 A).
446 mV at Nominal Voltage (67 V_{LN}).

Processing Module Input (J20): 6.6 Vp-p Maximum.
U.S. Patent 5,479,315.

Figure 6.1 Low-Level Test Interface

Main Board Processing Module Tests

Use signals from the SEL-4000 Low-Level Relay Test System to test the relay processing module. Apply appropriate signals to the low-level test interface J20 from the SEL-4000 Relay Test System (see [Figure 6.1](#)). These signals simulate power system conditions, taking into account PT ratio and CT ratio scaling. Use relay metering to determine whether the applied test voltages and currents produce correct relay operating quantities.

The UUT Database entries for the SEL-451 in the SEL-5401 Relay Test System Software are shown in [Table 6.4](#) and [Table 6.5](#).

Table 6.4 UUT Database Entries for SEL-5401 Relay Test System Software—5 A Relay

	Label	Scale Factor	Unit
1	IAW	75	A
2	IBW	75	A
3	ICW	75	A
4	IAX	75	A
5	IBX	75	A
6	ICX	75	A
7	VAY	150	V
8	VBY	150	V
9	VCY	150	V
10	VAZ	150	V
11	VBZ	150	V
12	VCZ	150	V

Table 6.5 UUT Database Entries for SEL-5401 Relay Test System Software-1 A Relay

	Label	Scale Factor	Unit
1	IAW	15	A
2	IBW	15	A
3	ICW	15	A
4	IAX	15	A
5	IBX	15	A
6	ICX	15	A
7	VAY	150	V
8	VBY	150	V
9	VCY	150	V
10	VAZ	150	V
11	VBZ	150	V
12	VCZ	150	V

Relay Test Connections

NOTE: The procedures specified in this subsection are for initial relay testing only. Follow your company policy for connecting the relay to the power system.

The SEL-451 is a flexible tool that you can use to implement many protection and control schemes. Although you can connect the relay to the power system in many ways, connecting basic bench test sources helps you model and understand more complex relay field connection schemes.

Test Setup

Test Source Connections

For each relay element test, you must apply ac voltage and current signals to the relay. The text and figures in this subsection describe the test source connections you need for relay protection element checks. You can use these connections to test protective elements and simulate all fault types.

Connections for Three Voltage Sources and Three Current Sources

Figure 6.2 shows the connections to use when you have three voltage sources and three current sources available.




Figure 6.2 Test Connections Using Three Voltage and Three Current Sources

Connections for Three Voltage Sources and Two Current Sources

Figure 6.3 and *Figure 6.4* show connections to use when you have three voltage sources and two current sources. You can use the connections shown in *Figure 6.3* to simulate phase-to-phase, phase-to-ground, and two-phase-to-ground faults. Use the connections shown in *Figure 6.4* to simulate three-phase faults.




Figure 6.3 Test Connections Using Two Current Sources for Phase-to-Phase, Phase-to-Ground, and Two-Phase-to-Ground Faults




Figure 6.4 Test Connections Using Two Current Sources for Three-Phase Faults

Connections for Three Voltage Sources and One Current Source

Figure 6.5 and *Figure 6.6* show connections to use when you have three voltage sources and a single current source. You can use the connections shown in *Figure 6.5* to simulate phase-to-ground faults. Use the connections shown in *Figure 6.6* to simulate phase-to-phase faults.

U.6.12 | Testing and Troubleshooting
Relay Test Connections




Figure 6.5 Test Connections Using a Single Current Source for a Phase-to-Ground Fault




Figure 6.6 Test Connections Using a Single Current Source for a Phase-to-Phase Fault

Test Methods

Use the following methods to conveniently test the pickup and dropout of relay elements and other relay functions:

- Target indications (element pickup/dropout)
- Control output closures
- SER reports

The tests and procedures in the following subsections are for 5 A relays. Scale values appropriately for 1 A relays.

Once you have completed a test, return the relay settings that you modified for the test to default or operational values.

Testing With Targets

Use the communications port **TAR** command or the front panel to display the state of relay elements, control inputs, and control outputs. Viewing a change in relay element (Relay Word bit) status is a good way to verify the pickup settings you have entered for protection elements.

View Relay Elements With a Serial Terminal

The procedure in the following steps shows you how to view a change in state for the 50P1 Phase Instantaneous Overcurrent element from a

communications port. Use the factory defaults for the pickup level (see *Table 6.6*). For more information on the 50P elements, see *Instantaneous/Definite-Time Line Overcurrent Elements on page R.1.48*.

Table 6.6 Phase Instantaneous Overcurrent Pickup

Setting	Description	Default (5A)
50P1P	Level 1 Pickup (OFF, 0.25–100 amps secondary)	15.00

For this procedure, you must have a serial terminal or computer with terminal emulation software and a variable current source for relay testing.

This example assumes that you have successfully established communication with the relay (see *Making an EIA-232 Serial Port Connection on page U.4.5*). In addition, you must be familiar with relay access levels and passwords (see *Changing the Default Passwords on page U.4.6* to change the default access level passwords and enter higher relay access levels).

- Step 1. Type ACC <Enter> at a communications terminal.
- Step 2. Type the Access Level 1 password and press <Enter>. You will see the Access Level 1 => prompt.
- Step 3. Connect a test source to the relay.
 - a. Set the current output of a test source to zero output level.
 - b. Connect a single-phase current output of the test source to the IAW analog input (see *Figure 6.5* and *Section 2: Installation*).
- Step 4. Type TAR 50P1 <Enter> to view the initial element status.

The relay returns a target terminal screen similar to *Figure 6.7*.

```
=>TAR 50P1 <Enter>
50P1 50P2 50P3 50P4 67P1 67P2 67P3 67P4
0 0 0 0 0 0 0 0
=>
```

Figure 6.7 Sample Targets Display on a Serial Terminal

- Step 5. View the element status change.
 - a. Type TAR 50P1 1000 <Enter> (this command causes the relay to repeat the TAR 50P1 command 1000 times).
 - b. Increase the current source to produce a current magnitude greater than 15.00 A secondary in the relay. You will see the 50P1 element status change to 1 when the input current exceeds the 50P1P setting threshold.
 - c. Type <Ctrl+X> to stop the relay from presenting the target display before completion of the 1000 target repeats.

View Relay Elements With the Front-Panel LCD

You can use the front-panel display and navigation pushbuttons to check Relay Word bit elements. See *Section 5: Front-Panel Operations* for more information on using the relay front panel.

This procedure uses the 50P1 Phase Instantaneous Overcurrent element. Use the factory defaults for the pickup level ([Table 6.6](#)). For more information on the 50P elements, see [Instantaneous/Definite-Time Line Overcurrent Elements on page R.1.48](#).

- Step 1. Display the MAIN MENU.
- Step 2. If the relay LCD is in the ROTATING DISPLAY, press the ENT pushbutton to display the MAIN MENU similar to that in [Figure 6.8](#).
- Step 3. Press the Down Arrow navigation pushbutton to highlight the RELAY ELEMENTS action item (see the first screen of [Figure 6.8](#)).
- Step 4. Press the ENT pushbutton.

You will see a RELAY ELEMENTS screen (the second screen of [Figure 6.8](#)).




Figure 6.8 Viewing Relay Word Bits From the Front-Panel LCD

- Step 5. Display the 50P1 Relay Word bit on the front-panel LCD screen.
- Press ENT to go to the ELEMENT SEARCH submenu of [Figure 6.8](#).
 - Use the navigation keys to highlight 5 and then press ENT to enter the character 5 in the text input field.
 - Enter the 0, P, and 1 characters in the same manner.
 - Highlight ACCEPT and press ENT.

The relay displays the LCD screen containing the 50P1 element, as shown in the last screen of [Figure 6.8](#).

- Step 6. Connect a test source to the relay.
- Set the current output of a test source to zero output level.
 - Connect a single-phase current output of the test source to the IAW analog input (see [Figure 6.5](#) and [Secondary Circuits on page U.2.5](#)).
- Step 7. View the target status change.
- Increase the current source to produce a current magnitude greater than 15.00 A secondary in the relay.
 - Observe the 50P1 target on the front-panel display.
- You will see the 50P1 element status change to 1 when the input current exceeds the 50P1P setting threshold.
- Step 8. Press ESC to return to the MAIN MENU.

View Relay Elements With a Front-Panel LED

The procedure in the following steps shows you how to use a front-panel LED to view a change-in-state for the 50P1 Phase Instantaneous Overcurrent element. Use the factory defaults for the pickup level (see [Table 6.6](#)). For more information on the 50P elements, see [Instantaneous/Definite-Time Line Overcurrent Elements on page R.1.48](#).

In this example, use ACCELERATOR QuickSet to configure the relay. You must have a computer that is communicating with the SEL-451 and running the ACCELERATOR QuickSet (see [Making Settings Changes: Initial Global Settings on page U.4.17](#)). In addition, you need a variable current source suitable for relay testing.

- Step 1. Prepare to control the relay with ACCELERATOR QuickSet by establishing communication, checking passwords, and reading relay settings (see [Making Settings Changes: Initial Global Settings on page U.4.17](#)).
- Step 2. Set a pushbutton LED SELOGIC control equation.
- Expand the **Front Panel** branch of the **Settings** tree view and click **Pushbuttons** (see [Figure 6.9](#)).
ACCELERATOR QuickSet displays the **Pushbuttons** dialog box similar to [Figure 6.9](#).
 - Click in the **PB6_LED** text box and type **50P1**.
 - Tab or click to any other text box.
ACCELERATOR QuickSet checks the validity of the setting.




Figure 6.9 Setting Pushbutton LED Response: ACSELERATOR QuickSet

Step 3. Click **File > Save** to save the new settings in ACSELERATOR QuickSet.

Step 4. Upload the new settings to the SEL-451.

a. Click **File > Send**.

ACSELERATOR QuickSet prompts you for the settings class you want to send to the relay, as shown in the **Group Select** dialog box of [Figure 6.10](#).

- Click the check box for **Front Panel**.
- Click **OK**.

The relay responds with the **Transfer Status** dialog box of [Figure 6.10](#).

If you see no error message, the new settings are loaded in the relay.



Figure 6.10 Uploading Front-Panel Settings to the SEL-451

Step 5. Connect a test source to the relay.

- a. Set the current output of a test source to zero output level.
- b. Connect a single-phase current output of the test source to the IAW analog input (see *Figure 6.5* and *Secondary Circuits on page U.2.5*).

Step 6. View the target status change.

- a. Increase the current source to produce a current magnitude greater than 15.00 A secondary in the relay.
- b. Observe the LED next to the AUX pushbutton (PB6) on the SEL-451 front panel.

You will see the LED light when the input current exceeds the 50P1P setting threshold.

Testing With Control Outputs

You can set the relay to operate a control output to test a single element. Set the SELOGIC control equation for a particular output (OUT101 through OUT108, for example) to respond to the Relay Word bit for the element under test. See *Operating the Relay Inputs and Outputs on page U.4.58* for configuring control inputs and control outputs. *Appendix A: Relay Word Bits in the Reference Manual* lists the names of the relay element logic outputs.

Testing the 50P1 Element With a Control Output

This procedure shows how to set control output OUT105 to test the 50P1 Phase Instantaneous Overcurrent element. Use the factory defaults for the pickup level (see *Table 6.6*). For more information on the 50P elements, see *Instantaneous/Definite-Time Line Overcurrent Elements on page R.1.48*.


For this test, you must have a computer with ACCELERATOR QuickSet for the SEL-451, a variable current source for relay testing, and a control output closure indicating device such as a test set or a VOM (volt ohmmeter).

In this example, use ACCELERATOR QuickSet to configure the relay. You must have a computer that is communicating with the SEL-451 and running ACCELERATOR QuickSet (see *Making Settings Changes: Initial Global Settings on page U.4.17*).

Step 1. Prepare to control the relay with ACCELERATOR QuickSet by establishing communication, checking passwords, and reading relay settings (see *Making Settings Changes: Initial Global Settings on page U.4.17*).

Step 2. Click the **Outputs > Main Board** branch of the ACCELERATOR QuickSet **Settings** tree structure to view output settings (shown in *Figure 6.11*).

The **Main Board Outputs** dialog box appears.

**Figure 6.11 Setting Main Board Outputs: ACCELERATOR QuickSet**

Step 3. Set OUT105 to respond to the 50P1 element pickup.

- Move the cursor to the OUT105 Main Board Output105 (SELOGIC) text box and double-click the left (regular) mouse button.
- Delete the NA default setting.
- Type **50P1**.
- Press **<Tab>** or click in any other text box.
- The relay checks the validity of the setting you entered.

An invalid setting (you could have mistyped the element name) causes the OUT105 text box to turn red.

If the setting is valid, the text box displays the new setting on a white background.

Step 4. Click **File > Save** to save the new settings in ACCELERATOR QuickSet.

Step 5. Upload the new settings to the SEL-451.

- Click **File > Send**.

ACCELERATOR QuickSet prompts you for the settings class you want to send to the relay, as shown in the **Group Select** dialog box in [Figure 6.12](#).

- Click the **Output** check box.
- Click **OK**.

The relay responds with the **Transfer Status** dialog box in [Figure 6.12](#).

If you see no error message, the new settings are loaded in the relay.




Figure 6.12 Uploading Output Settings to the SEL-451

- Step 6. Connect an indicating device to OUT105 on the relay rear panel.
A VOM multi-tester on a low resistance scale can indicate an OUT105 control output closure.
- Step 7. Connect a test source to the relay.
 - a. Set the current output of a test source to zero output level.
 - b. Connect a single-phase current output of the test source to the IAW analog input (see *Figure 6.5* and *Secondary Circuits on page U.2.5*).
- Step 8. Increase the current source to produce a current magnitude greater than 15.00 A secondary in the relay (to test the element).
When the 50P1 element picks up, the relay changes the 50P1 Relay Word bit to logical 1 and closes the output contacts of control output OUT105.
The indicating device operates.

Testing With SER

You can set the relay to generate a report from the SER to test relay elements; include the element that you want to test in the **SER Points and Aliases** list. Set aliases for the element name, set state, and clear state in the SEL-451 SER to simplify reading the SER report. See *SER (Sequential Events Recorder) on page A.3.42* for complete information on the SER.

Testing the 51S1 Element Using the SER

The SER gives exact time data for testing time-overcurrent element timeouts. Subtract the 51S1T assertion time from the 51S1 assertion time to check the operation time for this element. Use the factory defaults for the operating quantity, pickup level, curve, time dial, electromechanical reset, and torque control (*Table 6.7*).

The procedure in the following steps shows how to set the SER trigger lists to capture the selectable operating quantity time-overcurrent element 51S1 operating times. The procedure also shows how to set the torque control supervision for the 51S1 element.

Table 6.7 Selectable Operating Quantity Time-Overcurrent Element (51S1) Test Settings

Setting	Description	5A
51S1O	51S1 Operating Quantity (IA _n , IB _n , IC _n , IMAX _n , IA _{nR} , IB _{nR} , IC _{nR} , IMAX _{nR} , I1L, 3I2L, 3I0n) ^a	3I0L
51S1P	51S1 Overcurrent Pickup (0.25–16 amps, secondary)	0.75
51S1C	51S1 Inv-Time Overcurrent Curve (U1–U5, C1–C5)	U3
51S1TD	51S1 Inv-Time Overcurrent Time Dial (0.50–15.00)	1.00
51S1RS	51S1 Inv-Time Overcurrent EM Reset (Y, N)	N
51S1TC	51S1 Torque Control (SELOGIC control equation)	1

^a n is L, 1, and 2 for Line, Circuit Breaker 1, and Circuit Breaker 2, respectively. R suffix selects rms filtered magnitudes.

The relay uses [Equation 6.1](#) and [Equation 6.2](#) to determine the operating time for the 51S1 element. For a current input 50 percent greater than the default pickup, the test value, I_{TEST}, is:

$$\begin{aligned} I_{TEST} &= M \cdot (51S1P) \\ &= 1.5 \cdot (0.75 \text{ A}) \\ &= 1.125 \text{ A} \end{aligned} \quad \text{Equation 6.1}$$

where M is the pickup multiple and 51S1P is the element pickup value (see [Table 6.7](#)).

The operating time (t_p) for a time dial (TD) equal to 1 for the U3 (Very Inverse) Curve is:

$$\begin{aligned} t_p &= TD \cdot \left(0.0963 + \frac{3.88}{M^2 - 1} \right) \\ &= 1 \cdot 0.0963 + \frac{3.88}{1.5^2 - 1} \\ &= 3.2 \text{ seconds} \end{aligned} \quad \text{Equation 6.2}$$

For more information on the 51S elements, see [Inverse-Time Overcurrent Elements on page R.1.55](#).

In this example, use ACCELERATOR QuickSet to configure the relay. You must have a computer that is communicating with the SEL-451 and running the ACCELERATOR QuickSet (see [Making Settings Changes: Initial Global Settings on page U.4.17](#)). You also need a variable current source for relay testing.

- Step 1. Prepare to control the relay with ACCELERATOR QuickSet by establishing communication, checking passwords, and reading relay settings (see [Making Settings Changes: Initial Global Settings on page U.4.17](#)).
- Step 2. Set the selectable operating quantity time-overcurrent element for test operation.
 - a. Open the **Group 1 > Set 1 > Relay Configuration > Time Overcurrent** branch of the **Settings** tree view (see [Figure 6.13](#)).
 - b. Verify that enable setting E51S (Selectable Inverse Time Overcurrent Element) is set to 1, or greater.

- c. In the **Time Overcurrent** dialog box, change setting **51S1O Operating Quantity** to **3I0L**.
- d. Change the remaining element configurations to match [Table 6.7](#).

For more information on using ACSELERATOR QuickSet to change settings, see [Making Initial Global Settings: ACSELERATOR QuickSet](#) on page U.4.26.)




Figure 6.13 Checking the 51S1 Overcurrent Element: ACSELERATOR QuickSet

Step 3. View the SER settings.

- a. Click the + mark next to the **Report** branch of the ACSELERATOR QuickSet **Settings** tree view structure shown in [Figure 6.14](#).
- b. Click on the **SER Points and Aliases** branch.




Figure 6.14 Setting SER Points and Aliases: ACSELERATOR QuickSet

Step 4. Enter SER element names and aliases.

- Use the scroll bar on the right-hand side of the window to find **SITM26 SER Points and Aliases, Point 26** entry field, and then click the [...] icon beside the entry box.
- If the **Relay Word bit** field does not contain **51S1T** (the factory default setting), click the [...] icon beside the **Relay Word bit** entry field.
- Select Overcurrent Element Bits.
- Double-click on 51S1T to copy the name into the Relay Word Bit field.
- Type **GROUND O/C 1 LINE 1** in the **Reporting Name** field.
- Type **51S1 TIMEOUT** in the **Set State Name** field.
- Type **51S1 DROPOUT** in the **Clear State Name** field.
- Click on the OK button.
- Repeat Steps *Step a–Step h* for **SITM28 SER Points and Aliases, Point 28**, with setting values **51S1**, **GROUND O/C 1 LINE 1**, **51S1 PICKED UP**, **51S1 RESET**. *Figure 6.14* shows the entry field for SITM28 just before pressing the OK button.

You can enter as many as 250 relay elements in the **SER Points and Aliases** list (see [SER \(Sequential Events Recorder\) on page A.3.42](#)).

Step 5. Click **File > Save** to save the new settings in ACSELERATOR QuickSet.

Step 6. Upload the new settings to the SEL-451.

- Click **File > Send**.
- ACSELERATOR QuickSet prompts you for the settings class you want to send to the relay, as shown in the **Group Select** dialog box of *Figure 6.15*.
- Click the check box for **Group 1** and for **Report**.
- Click **OK**.

ACSELERATOR QuickSet responds with a **Transfer Status** dialog box as in [Figure 6.15](#).

If you see no error message, the new settings are loaded in the relay.




Figure 6.15 Uploading Group 1 and Report Settings to SEL-451

Step 7. Connect a test source to the relay.

- Set the current output of a test source to zero output level.
- Connect a single-phase current output of the test source to the IAW analog input (see [Figure 6.5](#) and [Secondary Circuits on page U.2.5](#)).

Step 8. Test the element.

- Increase the current source to produce a current magnitude of 1.125 A secondary in the relay.
- Keep the current source at this level past the expected element timeout (longer than 3.2 seconds).
- Return the current source to zero after the element time out.

Step 9. Select the HMI menu (top toolbar) and then click **Meter and Control** to start the ACSELERATOR QuickSet HMI interface.

Step 10. View the SER report.

Step 11. Click the **SER** button of the HMI tree view (see [Figure 6.16](#)).

ACSELERATOR QuickSet displays the **SER** report similar to [Figure 6.17](#).

The time difference between SER entries **51S1 PICKED UP** and **51S1 TIMOUT** is approximately 3.2 seconds.




Figure 6.16 HMI Tree View: ACSELERATOR QuickSet

SER				
Relay 1 Station A			Date: 03/15/2001 Time: 00:32:29.718	Serial Number: 0001001234
#	DATE	TIME	ELEMENT	STATE
6	03/15/2001	00:00:00.004	Power-up	Group 1
5	03/15/2001	00:00:00.222	Relay	Enabled
4	03/15/2001	00:30:00.021	GROUND O/C 1 LINE 1 51S1 PICKED UP	
3	03/15/2001	00:30:03.221	GROUND O/C 1 LINE 1 51S1 TIMEOUT	
2	03/15/2001	00:32:00.114	GROUND O/C 1 LINE 1 51S1 RESET	
1	03/15/2001	00:32:00.114	GROUND O/C 1 LINE 1 51S1 DROPOUT	

SER TO

Figure 6.17 SER Report: ACCELERATOR QuickSet HMI

Checking Relay Operation

The SEL-451 comes to you with all functions fully checked and calibrated so that the relay operates correctly and accurately. You can perform tests on the relay to verify proper relay operation, but you do not need to test every relay element, timer, and function in this evaluation. The following checks are valuable for confirming proper SEL-451 connections and operation:

- AC connection check (metering)
- Commissioning tests
- Functional tests
- Element verification

An ac connection check uses relay metering to verify that the relay current and voltage inputs are the proper magnitude and phase rotation (see [Examining Metering Quantities on page U.4.34](#)).

Commissioning tests help you verify that you have properly connected the relay to the power system and all auxiliary equipment. These tests confirm proper connection of control inputs and control outputs as well (see [Operating the Relay Inputs and Outputs on page U.4.58](#)).

Brief functional tests and element verification confirm correct internal relay processing.

Selected Element Tests

Testing Overcurrent Elements

This subsection discusses tests of the following relay elements:

- Overcurrent element: Negative-sequence instantaneous, 50Q1
- Directional element: Negative-sequence portion, F32Q/R32Q, of the phase directional element, F32P/R32P

Overcurrent elements operate by detecting power system sequence quantities and asserting when these quantities exceed a preset threshold.

Apply current to the analog current inputs and compare relay operation to the element pickup settings to test the instantaneous and definite-time overcurrent elements. Be sure to apply the test current to the proper input set (IW or IX), according to the Global Current and Voltage Source Selection settings (ESS and ALINEI, for example) to accept the input. See [Current and Voltage Source Selection on page R.1.2](#) for more information.

Phase Overcurrent Elements

The SEL-451 phase overcurrent elements compare the phase current applied to the secondary current inputs with the phase overcurrent element pickup setting. The relay asserts the phase overcurrent elements when any of the three phase currents exceeds the corresponding element pickup setting.

Negative-Sequence Overcurrent Elements

The SEL-451 negative-sequence overcurrent elements compare a negative-sequence calculation of the three-phase secondary inputs with the corresponding negative-sequence overcurrent element pickup setting. The relay makes this negative-sequence calculation (assuming ABC rotation):

$$3I_2 = \text{A-phase} + \text{B-phase (shifted by } -120^\circ) + \text{C-phase (shifted by } 120^\circ)$$

The relay asserts negative-sequence overcurrent elements when the $3I_2$ calculation exceeds the corresponding negative-sequence current pickup setting. If balanced currents are applied to the relay, the relay reads $3I_2 \approx 0$ (load conditions) and does not pick up the negative-sequence overcurrent elements.

For testing, apply current to a single phase of the relay, causing the negative-sequence overcurrent elements to operate. For example, assume 1 A of current on A-phase and zero current input on the B-phase and C-phase:

$$3I_2 = 1 \text{ A} + 0 \text{ (shifted } -120^\circ) + 0 \text{ (shifted } 120^\circ) = 1 \text{ A} \text{ (a simulated ground fault condition)}$$

Ground Overcurrent Elements

The SEL-451 ground overcurrent elements compare a residual ground calculation of the three-phase inputs with the residual overcurrent setting. The relay makes this residual current calculation:

$$3I_0 = \text{A-phase} + \text{B-phase} + \text{C-phase}$$

The relay asserts ground overcurrent elements when the $3I_0$ calculation exceeds the ground current element pickup setting. If balanced currents are applied to the relay, the relay reads $3I_0 = 0$ (load conditions) because the currents cancel in the calculation; the relay does not pick up the ground overcurrent elements.

For testing, apply current to a single phase of the relay, causing the residual overcurrent elements to operate. For example, assume 1 A of current on A-phase and zero current input on B-phase and C-phase:

$$3I_0 = 1 \text{ A} + 0 + 0 = 1 \text{ A} \text{ (a simulated ground fault condition)}$$

Checking the Negative-Sequence Instantaneous Overcurrent Element, 50Q1

NOTE: As you perform this test, other protection elements can assert. This causes the relay to assert other targets and possibly close control outputs. Be sure to isolate the relay from the power system to avoid unexpected system effects.

The procedure in the following steps tests the 50Q1 negative-sequence overcurrent element. Use a similar procedure to test other overcurrent elements.

This example assumes that you have successfully established communication with the relay (see [Making an EIA-232 Serial Port Connection on page U.4.5](#)). In addition, you must be familiar with relay access levels and passwords (see

[Changing the Default Passwords on page U.4.6](#) to change the default access level passwords and enter higher relay access levels). You should be familiar with ACSELERATOR QuickSet (see [Section 3: PC Software](#)).

Step 1. Configure the relay.

- Start ACSELERATOR QuickSet and read the present configuration in the SEL-451.
- Click **Settings > Read**.
The relay sends all settings and configuration data to ACSELERATOR QuickSet.
- Expand **Group 1, Set 1**, and the **Relay Configuration** branch of the **Settings** tree view.
- Click the **Negative-Seq Inst O/C** button of the **Settings** tree view as shown in [Figure 6.18](#).

Step 2. Set the instantaneous overcurrent element pickup value.

- Click the arrow in the **Instantaneous and Definite Time Overcurrent Element Levels E50Q** dialog box and select **1**.
- For this test, set the **50Q1P** level to **1.00**.




Figure 6.18 Negative-Sequence Instantaneous Overcurrent Element Settings: ACSELERATOR QuickSet

Step 3. Upload the new setting to the SEL-451.

- Click **File > Send**.

ACSELERATOR QuickSet prompts you for the settings class you want to send to the relay, as shown in the **Group Select** dialog box in [Figure 6.19](#).

- Click the check box for **Group 1**.

- Click **OK**.

The relay responds with the **Transfer Status** dialog box similar to [Figure 6.19](#).

If you see no error message, the new settings are loaded in the relay.



Figure 6.19 Uploading Group 1 Settings to the SEL-451

- Step 4. Display the 50Q1 Relay Word bit on the front-panel LCD screen.

- Access the front-panel LCD MAIN MENU.
- Highlight RELAY ELEMENTS and press ENT.
- Press ENT to go to the ELEMENT SEARCH submenu of [Figure 6.20](#).
- Use the navigation keys to highlight 5 and then press ENT to enter characters in the text input field.
- Enter the **0**, **Q**, and **1** characters in turn.
- Highlight ACCEPT and press ENT.

The relay displays the screen containing the 50Q1 element, as shown in [Figure 6.21](#).




Figure 6.20 ELEMENT SEARCH Screen

RELAY ELEMENTS		
ROW 26	ROW 27	
67Q4 =0	*	=0
67Q3 =0	*	=0
67Q2 =0	*	=0
67Q1 =0	*	=0
50Q4 =0	67Q4T =0	
50Q3 =0	67Q3T =0	
50Q2 =0	67Q2T =0	
50Q1 =0	67Q1T =0	
SEARCH		
PRESS ↶ TO SEARCH		

Figure 6.21 RELAY ELEMENTS Screen Containing Element 50Q1

Step 5. Connect a test source to the relay.

- a. Set the current output of a test source to zero output level.
- b. Connect a single-phase current output of the test source to the IAW analog input (see [Figure 6.5](#) and [Secondary Circuits on page U.2.5](#)).

Step 6. Increase the current source to produce a current magnitude greater than 1.00 A secondary in the relay.

You will see that the 50Q1 element state changes on the LCD screen from 50Q1 = 0 to 50Q1 = 1.

Negative-Sequence Directional Element for Phase Faults

The SEL-451 features a phase directional element (represented by Relay Word bits F32P/R32P) to control the phase directional elements. The negative-sequence directional element, F32Q/R32Q, is a part of the phase directional element, F32P/R32P. Whenever the negative-sequence directional element asserts, the phase directional element asserts.

The relay also contains a ground directional element, F32G/R32G, for directional control of the residual ground overcurrent elements. For more information on directional elements, see [Ground Overcurrent Elements Directional Control on page R.1.33](#), and [Section 1: Protection Application Examples in the Applications Handbook](#).

The SEL-451 calculates the negative-sequence impedance Z_2 from the magnitudes and angles of the negative-sequence voltage and current. [Table 6.3](#) defines this function (the ‘c’ in Z_{2c} indicates “calculated”).

$$\begin{aligned} Z_{2c} &= \frac{\operatorname{Re}[V_2 \cdot (1 \angle Z1ANG \cdot I_2)^*]}{|I_2|^2} \\ &= \frac{|V_2|}{|I_2|} \cdot \cos(\angle V_2 - \angle Z1ANG - \angle I_2) \end{aligned} \quad \text{Equation 6.3}$$

where:

V_2 = the negative-sequence voltage

I_2 = the negative-sequence current

$Z1ANG$ = the positive-sequence line impedance angle

Re = the real part of the term in brackets, for example,
 $(\operatorname{Re}[A + jB] = A)$

* = the complex conjugate of the expression in parentheses,
 $(A + jB)^* = (A - jB)$

The result of [Equation 6.3](#) is an impedance magnitude that varies with the magnitude and angle of the applied current. Normally, a forward fault results in a negative Z_{2c} relay calculation.

Test Current

Solve [Equation 6.3](#) to find the test current values that you need to apply to the relay to test the element. For the negative sequence current I_2 , the result is

$$|I_2| = \frac{|V_2|}{Z_{2c}} \quad \text{Equation 6.4}$$

when:

$$\angle I_2 = \angle V_2 - \angle Z1ANG \quad \text{Equation 6.5}$$

Multiply the quantities in [Equation 6.4](#) by three to obtain $3I_2$, the negative-sequence current that the relay processes. With a fixed applied negative-sequence voltage V_A , the relay negative sequence voltage is $3V_2$. Set $Z_{2c} = Z_{2F}$ to find the test current magnitude at the point where the impedance calculation equals the forward fault impedance threshold. [Equation 6.4](#) becomes:

$$|I_{TEST}| = |3I_2| = \frac{|3V_2|}{Z_{2c}} = \frac{|3V_2|}{Z_{2F}} \quad \text{Equation 6.6}$$

when:

$$\angle I_{TEST} = \angle 3I_2 = \angle 3V_2 - \angle Z1ANG \quad \text{Equation 6.7}$$

For a reverse fault impedance threshold, where $Z_{2c} = Z_{2R}$, [Equation 6.4](#) becomes:

$$|I_{TEST}| = |3I_2| = \frac{|3V_2|}{Z_{2c}} = \frac{|3V_2|}{Z_{2R}} \quad \text{Equation 6.8}$$

when the angle calculation is the same as [Equation 6.7](#).

For more information on the directional elements, see [Ground Overcurrent Elements Directional Control on page R.1.33](#). For settings and application information, see [Section 1: Protection Application Examples in the Applications Handbook](#).

Checking the Negative-Sequence Directional Element (Phase Faults)

NOTE: As you perform this test, other protection elements can assert. This causes the relay to assert other targets and possibly close control outputs. Be sure to isolate the relay from the power system to avoid unexpected system effects.

This test confirms operation of the F32Q and the R32Q negative-sequence directional elements. This test procedure is for a 5 A relay; scale values appropriately for a 1 A relay.

This example assumes that you have successfully established communication with the relay (see [Making an EIA-232 Serial Port Connection on page U.4.5](#)). In addition, you must be familiar with relay access levels and passwords (see [Changing the Default Passwords on page U.4.6](#) to change the default access level passwords and enter higher relay access levels). You should be familiar with ACSELERATOR QuickSet (see [Section 3: PC Software](#)).

Step 1. Configure the relay.

- Open ACSELERATOR QuickSet and read the present configuration in the SEL-451.
- Click **Settings > Read**.
The relay sends all settings and configuration data to ACSELERATOR QuickSet.
- Expand the **Group 1, Set 1**, and click the **Relay Configuration** branch of the **Settings** tree view as shown in [Figure 6.22](#).
- Confirm that **ELOP** is set to N.




Figure 6.22 Group 1 Relay Configuration Settings: ACSELERATOR QuickSet

Step 2. Set test values in the relay.

- Select the **Line Configuration** branch as shown in [Figure 6.23](#).
- Change the settings of **Z1MAG** to **7.80** and **Z1ANG** to **84.00**.
- Click the + mark next to the **Relay Configuration** branch to expand that **Settings** branch.
- Select the **Directional** button.

You will see the **Directional** dialog box similar to [Figure 6.24](#).

- Set E32 Directional Element Control to AUTO, and set ORDER := Q.
- Confirm the following settings: **50FP** is **0.60**, **50RP** is **0.40**, **Z2F** is **3.90**, **Z2R** is **4.00**, **a2** is **0.10**, and **k2** is **0.2**.

The dialog box is dim since there are no settings to change.

The relay calculates these settings automatically because **E32** is set to **AUTO**.

- If you need to change these settings, set **E32** to **Y**.

[Table 6.8](#) shows the calculations.

See [Ground Overcurrent Elements Directional Control on page R.1.33](#) for details on these relay calculations.

U.6.32 | Testing and Troubleshooting
Checking Relay Operation




Figure 6.23 Group 1 Line Configuration Settings: AcSELerator QuickSet




Figure 6.24 Directional Settings: ACSELERATOR QuickSet

Table 6.8 Negative-Sequence Directional Element Settings AUTO Calculations

Setting	Calculation
50FP	$0.12 \cdot I_{NOM}$
50RP	$0.08 \cdot I_{NOM}$
Z2F	$0.5 \cdot Z1MAG$
Z2R	$Z2F + 1 / (2 \cdot I_{NOM})$
a2	0.1
k2	0.2

Step 3. Upload the new settings to the SEL-451.

- Click **File > Send**.

ACSELERATOR QuickSet prompts you for the settings class you want to send to the relay, as shown in the **Group Select** dialog box in [Figure 6.25](#).

- Click the check box for **Group 1**.
- Click **OK**.
- ACSELERATOR QuickSet responds with a **Transfer Status** dialog box as in [Figure 6.25](#).

If you see no error message, the new settings are loaded in the relay.




Figure 6.25 Uploading Group 1 Settings to the SEL-451

Step 4. Display the F32Q and R32Q Relay Word bits on the front-panel LCD screen.

- Access the front-panel LCD MAIN MENU.
- Highlight RELAY ELEMENTS and press ENT.

You will see a RELAY ELEMENTS screen with SEARCH highlighted at the bottom of the screen.

- Press ENT to go to the ELEMENT SEARCH submenu of *Figure 6.20*.
- Enter characters in the text input field using the navigation keys.
- Highlight F and press ENT to enter the F character.
- Enter the 3, 2, and Q characters in like manner.
- Highlight ACCEPT and press ENT.

The relay displays the screen containing the F32Q and R32Q elements, as shown in *Figure 6.26*.




Figure 6.26 RELAY ELEMENTS LCD Screen Containing Elements F32Q and R32Q

Step 5. Calculate impedance thresholds.

- For this test, apply an A-phase voltage of $V_A = 3V_2 = 18.0 \angle 180^\circ V$ secondary.
- Use *Equation 6.8* to find the current that is equal to the reverse impedance threshold Z2R:

$$|I_{TEST}| = |3I_2| = \frac{|3V_2|}{Z2R} = \frac{|18.0 \angle 180^\circ V|}{4.00} = 4.50 \text{ A}$$

Step 6. Use *Equation 6.6* to find the current that is equal to the forward impedance threshold Z2F:

$$|I_{TEST}| = |3I_2| = \frac{|3V_2|}{Z2RF} = \frac{|18.0 \angle 180^\circ V|}{3.90} = 4.62 \text{ A}$$

Step 7. Use [Equation 6.7](#) to determine the applied current angle ($\angle I_{TEST}$):

$$\angle I_{TEST} = \angle 3I_2 = \angle 3V_2 - \angle Z1ANG = 180^\circ - 84^\circ = 96^\circ$$

Step 8. Apply a test current to confirm operation of R32Q and F32Q.

- a. Connect a single current test source as shown in [Figure 6.5](#).
- b. Apply an A-phase voltage of $V_A = 18.0 \angle 180^\circ$ V secondary.
- c. Set the current source for $I_A = 0.0 \angle 96^\circ$ A.
- d. Slowly increase the magnitude of I_A to apply the source test current.
- e. Observe the RELAY ELEMENT LCD screen.

Relay Word bit R32Q asserts when $|I_A| = 0.4$ A, indicating that the relay negative-sequence current is greater than the 50RP pickup threshold.

R32Q deasserts when $|I_A| = 4.5$ A, indicating that the relay negative-sequence calculation Z2c is now less than the Z2 reverse threshold Z2R (see [Reverse Threshold on page R.1.43](#) and [Forward Threshold on page R.1.42](#).)

- f. Continue to increase the current source while you observe the RELAY ELEMENT LCD screen.
- Relay Word bit F32Q asserts when $|I_A| = 4.62$ A, indicating that the relay negative-sequence calculation Z2c is less than the Z2 forward threshold Z2F.

Relay Self-Tests

The SEL-451 continuously runs many self-tests to detect out-of-tolerance conditions. These tests run at the same time as relay protection and automation logic, but do not degrade SEL-451 performance.

Status Warning and Status Failure

The relay reports out-of-tolerance conditions as a status warning or a status failure. For conditions that do not compromise relay protection, yet are beyond expected limits, the relay issues a status warning and continues to operate. A severe out-of-tolerance condition causes the relay to declare a status failure and enter a protection-disabled state. During a protection-disabled state, the relay suspends protection element processing and trip/close logic processing and deenergizes all control outputs. When disabled, the **ENABLED** front-panel LED is not illuminated.

The relay signals a status warning by pulsing the HALARM Relay Word bit (hardware alarm) to logical 1 for five seconds. For a Status Failure, the relay latches the HALARM Relay Word bit at logical 1. SEL-451 relays will restart on certain diagnostic failures. When this occurs, the relay will log a Diagnostic Restart in the SER, and the HALARM Relay Word bit will assert for five seconds. See [Appendix A: Firmware and Manual Versions](#) for affected firmware revisions. To provide remote status indication, connect the b contact of OUT108 to your control system remote alarm input and program

the output SELOGIC control equation to respond to NOT (SALARM OR HALARM). See [Alarm Output on page U.2.43](#) on connecting this alarm output for the SEL-451.

If you repeatedly receive status warnings, check the relay operating conditions as soon as possible. Take preventive action early during the development of potential problems to avoid system failures. For any status failure, contact your Technical Service Center or the SEL factory immediately (see [Technical Support on page U.6.41](#)).

The relay generates an automatic status report at the serial ports for a self-test status failure if you set Port setting AUTO := Y. The relay issues a status message with a format identical to the **STATUS** command output (see [Status](#)), except that the power supply information from the **STA A** response is included after the SELOGIC control equation error messages.

The relay also displays status warning and status failure automatic messages on the front-panel LCD. Use the serial port **STATUS** and **CSTATUS** commands, the ACCELERATOR QuickSet HMI **Status** button, and the front-panel **RELAY STATUS** menu to display status warnings and status failures. See [STATUS on page R.9.54](#), [Checking Relay Status on page U.4.10](#), and [Relay Status on page U.5.33](#) for more information on automatic status notifications and on viewing relay status.


Status

[Figure 6.27](#) is a sample **STATUS** screen from the Status option of the ACCELERATOR QuickSet HMI > **Meter and Control** tree view (the terminal **STATUS** report is similar). [Figure 6.28](#) is the **STATUS A** report showing all status information on a terminal.

Firmware Version Number

At the top of each status report the relay displays the present firmware version number that identifies the software program that controls relay functions. The firmware version is the four-place designator immediately following the relay model number (the first characters in the firmware identification or FID string). The first character in the four-place firmware version number is R (representing Release).

[Figure 6.27](#) and [Figure 6.28](#) show the location of the FID sting, with a blank or generic response. To see the actual FID string for the firmware version described in this manual, see [Appendix A: Firmware and Manual Versions](#) for firmware version information.

**Figure 6.27 Relay Status: ACCELERATOR QuickSet HMI**

```
=>>STA A <Enter>
Relay 1 Date: 03/15/2004 Time: 04:48:49.938
Station A Serial Number: 0000000000
FID=SEL-451-1-Rxxx-V0-Zxxxxxx-Dyyyymmdd CID=0xxxxx
Failures
No Failures
Warnings
No Warnings
Channel Offsets (mV) W=Warn F=Fail
CH1 CH2 CH3 CH4 CH5 CH6 CH7 CH8 CH9 CH10 CH11 CH12 MOF
0 0 0 0 0 0 0 0 0 0 0 0 0 0
Power Supply Voltages (V) W=Warn F=Fail
3.3V_PS 5V_PS NSV_PS 15V_PS N15V_PS
3.28 4.91 -4.93 14.70 -14.79
Temperature
23.7 degrees Celsius
Communication Interfaces
Active High Accuracy Time Synchronization Source: IRIG-B
IRIG-B Source PRESENT
SELogic Relay Programming Environment Errors
No Errors
Relay Enabled
=>
```

Figure 6.28 Relay Status From a STATUS A Command on a Terminal

CSTATUS

The relay also reports status information in the Compressed ASCII format when you issue the **CST** command. The Compressed ASCII status message is shown in [Figure 6.29](#).

```

"RID","SID","FID","yyyy",
"relay_name","station_name","FID=SEL-xxx-x-Rxxx-Vx-Zxxxxxx-Dxxxxxxxxx","yyyy"
"MONTH","DAY","YEAR","HOUR","MIN","SEC","MSEC","yyyy"
(Month),(Day),(Year),(Hour),(Min),(Sec),(MSec),"yyyy"
"CPU_RAM","CPU_Prog","SELBOOT","CPU_Settings","DSP_RAM","DSP","DSP_Checksum","DSP_TIMEOUT","CPU_CARD_RAM","CPU_DSP_RAM","FRONT
_PANEL","CAL_BOARDA","CAL_BOARDB","Comm_Card_Change","Comm_Card","Comm_Card_Code","QUART","Analog_Conv","IO_1","IO_2","I
O_3","IO_4","yyyy"
(Ok or F),(Ok or W or F),(Ok or W
or F),(Ok or W or F),(Ok or W),(ccrdh),(Ok or F),(Ok or F),(Ok or F),(Ok or F),(Ok or F),"yyyy"
"Atod_Offset","Master_Offset","3.3V_PS","5V_PS","N5V_PS","15V_PS","N15V_PS","Temp_Status","Temp","FPGA","ADC_FPGA","yyyy"
(Ok or W),(Ok or W or F),(Ok or W or F),(Temp
value),(Ok or Fail),(Ok or Fail),"yyyy"
"Fast_Fiber_Port","MBA","MBB","Active_Time_Source","SELLogic_Math","FM_Test","CCrd_Test","DNP_Test","Event_Playback_Mode","Re
lay_Status","Port_F_Transp","Port_1_Transp","Port_2_Transp","Port_3_Transp","Port_4_Transp","Port_5_Transp","yyyy"
(Ok_or_F),(Inac or Ok or F),(Inac or Ok or F),(HIRIG or IRIG or " "), (Ok or F), (Enabled or Disabled),(Enabled or
Disabled),(Enabled or Disabled),(Enabled or Disabled),(Enabled or Disabled),(F, 0 - 5),(F, 0 - 5),(F, 0 - 5),(F, 0 -
5),(F, 0 - 5),(F, 0 - 5),"yyyy"

```

Figure 6.29 Compressed ASCII Status Message

Definitions for the items and fields in the Compressed ASCII configuration are listed below:

- yyyy is the checksum
- x is text in the FID (Firmware ID) string
- ccrd is the communications card hex code
- (description) is text that the relay supplies
- (Ok or W or F) is normal, warning, or failure, respectively

Relay Troubleshooting

Inspection Procedure

Complete the following inspection procedure before disturbing the system. After you finish the inspection, proceed to [Troubleshooting Procedures](#).

- Step 1. Confirm that the power is on. Do not turn the relay off.
- Step 2. Measure and record the control power voltage at the relay **POWER** terminals marked + and - on the rear-panel terminal strip.
- Step 3. Measure and record the voltages at all control inputs.
- Step 4. Measure and record the state of all control outputs.
- Step 5. Inspect the serial communications ports cabling to be sure that a communications device is connected to at least one communications port.

Troubleshooting Procedures

Troubleshooting procedures for common problems are listed in [Table 6.9](#). The table lists each symptom, possible causes, and corresponding diagnoses/solutions. Related SEL-451 commands are listed in bold capitals. See [Section 9: ASCII Command Reference in the Reference Manual](#) for details on SEL-451 commands and [Section 10: Settings in the Reference Manual](#) for details on relay settings.

Table 6.9 Troubleshooting Procedures (Sheet 1 of 3)

Possible Cause	Diagnosis/Solution
Dark Front Panel	
Power is off.	Verify that substation battery power is operational.
Input power is not present.	Verify that power is present at the rear-panel terminal strip.
Blown power supply fuse.	Replace the fuse (see Power Supply Fuse Replacement on page U.2.40).
Poor contrast adjustment.	Press and hold ESC for two seconds. Press Up Arrow and Down Arrow pushbuttons to adjust contrast.
Status Failure Notice on Front Panel	
Self-test failure.	Contact the SEL factory or your Technical Service Center. The OUT108 relay control output b contacts will be closed if you programmed NOT HALARM to OUT108 (see Alarm Output on page U.2.43).
Alarm Output Asserts	
Power is off.	Restore power.
Blown power supply fuse.	Replace the fuse (see Power Supply Fuse Replacement on page U.2.40).
Power supply failure.	LCD displays STATUS FAILURE screen. Contact the SEL factory or your Technical Service Center.
Main board or interface board failure.	LCD displays STATUS FAILURE screen. Contact the SEL factory or your Technical Service Center.
Other self-test failure.	LCD displays STATUS FAILURE screen. Contact the SEL factory or your Technical Service Center.
System Does Not Respond to Commands	
NOTE: If Port setting PROTO := PMU, that serial port will not respond to ASCII commands. Additionally, a PROTO := PMU port will not respond to any messages when Global setting EPMU := N.	
No communication.	Confirm cable connections and types. If correct, type < Ctrl+X > < Enter >. This resets the terminal program.
Communications device is not connected to the system.	Connect a communications device.
Incorrect data speed (baud rate) or other communications parameters.	Configure your terminal port parameters to the particular relay port settings. Use the front panel to check port settings (see Set/Show on page U.5.29).
Incorrect communications cables.	Use SEL communications cables, or cables you build according to SEL specifications (see Communications Ports Connections on page U.2.47).
Communications cabling error.	Check cable connections.
Handshake line conflict; system is attempting to transmit information, but cannot do so.	Check communications cabling. Use SEL communications cables, or cables you build according to SEL specifications (see Communications Ports Connections on page U.2.47).
System is in the XOFF state, halting communications.	Type < Ctrl+Q > to put the system in the XON state.
Terminal Displays Meaningless Characters	
Data speed (baud rate) is set incorrectly.	Check the terminal parameters configuration (see Communications Ports Connections on page U.2.47).
Terminal emulation is not optimal.	Try other terminal types, including VT-100 and VT-52 terminal emulations.

Table 6.9 Troubleshooting Procedures (Sheet 2 of 3)

Possible Cause	Diagnosis/Solution
System Does Not Respond to Faults	
Relay is set improperly.	Review the relay settings (see Section 1: Protection Application Examples in the Applications Handbook).
Improper test settings.	Restore operating settings.
PT or CT connection wiring error.	Confirm PT and CT wiring.
Input voltages and currents phasing, and rotation errors.	Use relay metering. Use the TRI event trigger command and examine the generated event report (see Examining Metering Quantities on page U.4.34).
The analog input (flat multipin ribbon) cable between the input module board and the main board is loose or defective.	Reseat both ends of the analog input cable, observing proper ESD precautions (see Installing Optional I/O Interface Boards on page U.2.16).
Check the relay self-test status.	Take preventive action as directed by relay Status Warning and Status Failure information (see Relay Self-Tests on page U.6.35 and Checking Relay Status on page U.4.10).
Tripping Output Relay Remains Closed Following a Fault	
Auxiliary contact control inputs are improperly wired.	Check circuit breaker auxiliary contacts wiring.
Control output relay contacts have burned closed.	Remove relay power. Remove the control output connection. Check continuity; a contacts will be open and b contacts will be closed. Contact the SEL factory or your Technical Service Center if continuity checks fail.
I/O interface board failure.	LCD displays STATUS FAILURE screen. Contact the SEL factory or your Technical Service Center.
Power Supply Voltage Status Warning	
Power supply voltage(s) are out-of-tolerance.	Log the Status Warning. If repeated warnings occur, take preventive action.
A/D converter failure.	LCD displays STATUS FAILURE screen. Contact the SEL factory or your Technical Service Center.
Power Supply Voltage Status Failure	
Power supply voltage(s) are out-of-tolerance.	LCD displays STATUS FAILURE screen. Contact the SEL factory or your Technical Service Center.
A/D converter failure.	LCD displays STATUS FAILURE screen. Contact the SEL factory or your Technical Service Center.
A/D OFFSET WARN Status Warning	
Loose ribbon cable between the input module board and the main board.	Reseat both ends of the analog input cable.
A/D converter drift.	Log the Status Warning. If repeated warnings occur, contact the SEL factory or your Technical Service Center.
Master offset drift.	LCD displays STATUS FAILURE screen. Contact the SEL factory or your Technical Service Center.

Table 6.9 Troubleshooting Procedures (Sheet 3 of 3)

Possible Cause	Diagnosis/Solution
Time/Date Errors	
External IRIG time source error.	Check IRIG-B time source or cables. Check TIME Q command or HMI SET SHOW Date/Time screen
1k PPS cable still connected.	Remove 1k PPS cable (see <i>Configuring High-Accuracy Timekeeping on page U.4.73</i>)
IRIG-B connected to incorrect BNC input.	Ensure that the correct BNC connector is being used. See <i>Figure 4.63 on page U.4.76</i> .
A low-priority time source error.	Check last update source (TIME Q command or HMI SET SHOW Date/Time screen). See <i>Table 4.10 on page U.4.78</i> .
Lithium clock battery failure.	Verify that the battery has failed before replacing the battery—it should last for 10 years if the relay is energized. See <i>Battery-Backed Clock on page U.2.12</i> .

Technical Support

We appreciate your interest in SEL products and services. If you have any questions or comments, please contact us at:

Schweitzer Engineering Laboratories, Inc.
 2350 NE Hopkins Court
 Pullman, WA 99163-5603 USA
 Phone: +1.509.338.3838
 Fax: +1.509.332.7990
 Internet: selinc.com/support
 Email: info@selinc.com

This page intentionally left blank

Appendix A

Firmware and Manual Versions

Firmware

To find the firmware revision number in your relay, view the status report using the serial port **STATUS** command. The status report displays the Firmware Identification (FID) label:

FID=SEL-451-1-Rxxx-Vx-Zxxxxxx-Dxxxxxxxx

You can also view the FID label from the front panel. From the ROTATING DISPLAY front-panel screen, press the **ENT** pushbutton to advance to the MAIN MENU screen. Use the **Down Arrow** pushbutton to highlight the RELAY STATUS option, and press the **ENT** pushbutton. The FID label displays on the screen:

SEL-451-1-Rxxx-Vx-Zxxxxxx-Dxxxxxxxx

In the FID label, the firmware revision number follows the R and the release date follows the D.

For example,

FID=SEL-451-1-R106-V0-Z002002-D20051107

is firmware revision number 106, release date November 7, 2005.

Table A.1 lists the firmware versions, a description of modifications, and the instruction manual date code that corresponds to firmware versions. The most recent firmware version is listed first.

Table A.1 Firmware Revision History (Sheet 1 of 6)

Firmware Identification (FID) Number	Summary of Revisions	Manual Date Code
SEL-451-2-R126-V0-Z100011-D20121207 SEL-451-4-R126-V0-Z100011-D20121207	<ul style="list-style-type: none">► Added recloser setting 3PRHI. Default is 15 cycles to maintain same behavior as previous versions.► Added the MET HIF, LOG HIF, HSG, and HSG D commands to help with high-impedance fault indications.► Updated the tuning method for the HIF algorithm.► Improved DNP Multidrop (EIA-485) communications to operate at baud rates higher than 9600.	20121207
SEL-451-2-R125-V0-Z014011-D20110906 SEL-451-4-R125-V0-Z014011-D20110906	<ul style="list-style-type: none">► Ethernet card firmware (see <i>Table A.2</i>) and manual update only (see <i>Table A.5</i>).	20111215
SEL-451-2-R125-V0-Z014011-D20110906 SEL-451-4-R125-V0-Z014011-D20110906	<ul style="list-style-type: none">► Added Relay Word bit CCOK to indicate that communications card (SEL-2702) is alive and operational.► Corrected problem writing high-impedance fault (HIF) data to nonvolatile memory.	20110906
SEL-451-2-R124-V0-Z011011-D20100723 SEL-451-4-R124-V0-Z011011-D20100723	<ul style="list-style-type: none">► Ethernet card update only (see <i>Table A.2</i>).	20101109

Table A.1 Firmware Revision History (Sheet 2 of 6)

Firmware Identification (FID) Number	Summary of Revisions	Manual Date Code
SEL-451-2-R124-V0-Z011011-D20100723 SEL-451-4-R124-V0-Z011011-D20100723	► Corrected issue with DNP3 Cold Restart operation.	20100723
SEL-451-2-R123-V0-Z011011-D20090930 SEL-451-4-R123-V0-Z011011-D20090930	► Corrected issue with upgrades from R119 and lower firmware revisions.	20090930
SEL-451-2-R122-V0-Z011011-D20090526 SEL-451-4-R122-V0-Z011011-D20090526	► Manual update only (see Table A.5).	20090715
SEL-451-2-R122-V0-Z011011-D20090526 SEL-451-4-R122-V0-Z011011-D20090526	► Improved loss-of-potential handling during the transition of a breaker from opened to closed. ► Corrected handling of DNP fault summary records when EVELOCK = 0. ► Added MET PM HIS command.	20090526
SEL-451-2-R121-V0-Z011011-D20090309 SEL-451-4-R121-V0-Z011011-D20090309	► Corrected issue with settings corruption during upgrade to R120. ► Corrected issue with the HMI display of analog quantities in display points and bay mimic screens.	20090309
SEL-451-2-R120-V0-Z011011-D20090213 SEL-451-4-R120-V0-Z011011-D20090213 SEL-451-1-R202-V0-Z004004-D20090213	► Added EPORT port setting so user can disable ports. ► Added MAXACC port setting so user can restrict maximum privileges on a port. ► Extended password length from 6 to 12 characters. ► Increased the number of disconnects available in the mimic display from 5 to 10. ► Increased the number of bay display names available in the mimic display from 2 to 9. ► Increased the number of busbar sections available in the mimic display from 3 to 9.	20090213
SEL-451-2-R119-V0-Z010010-D20070730 SEL-451-4-R119-V0-Z010010-D20070730 SEL-451-1-R201-V0-Z004004-D20070220	► Ethernet card firmware (see Table A.2) and manual update only (see Table A.5).	20081022
SEL-451-2-R119-V0-Z010010-D20070730 SEL-451-4-R119-V0-Z010010-D20070730 SEL-451-1-R201-V0-Z004004-D20070220	► Ethernet card firmware (see Table A.2) and manual update only (see Table A.5).	20080110
SEL-451-2-R119-V0-Z010010-D20070730 SEL-451-4-R119-V0-Z010010-D20070730 SEL-451-1-R201-V0-Z004004-D20070220	► Ethernet card firmware (see Table A.2) and manual update only (see Table A.5).	20070914
SEL-451-2-R119-V0-Z010010-D20070730 SEL-451-4-R119-V0-Z010010-D20070730 SEL-451-2-R118-V0-Z009009-D20070717 SEL-451-4-R118-V0-Z009009-D20070717	► Added support for high-impedance fault detection (HIF) and ground overcurrent high-impedance fault detection (50G HIZ). ► Added support for additional user-selectable bay types. ► Updated how SER points are reported through DNP after initial DNP setup.	20070730 20070717

Table A.1 Firmware Revision History (Sheet 3 of 6)

Firmware Identification (FID) Number	Summary of Revisions	Manual Date Code
SEL-451-2-R117-V0-Z008008-D20070223 SEL-451-4-R117-V0-Z008008-D20070223	<ul style="list-style-type: none"> ➤ Added support for synchrophasors over Ethernet. ➤ Added TLED_17 through TLED_24 and PB9_LED through PB12_LED to the Fast Message response. ➤ Corrected intermittent pickup of RTDCOMF bit when connected to an SEL-2600. ➤ Expanded diagnostics coverage to include additional failure modes that will result in a relay restart. ➤ Modified frequency and rate-of-change of frequency (DFDT) measurements included in the synchrophasor data packet. These quantities are now calculated using synchrophasor data. ➤ Added a new global setting (IRIGC) that selects specify if the IRIG signal uses the C37.118 control bits. ➤ Added Ethernet card information in the ID command. ➤ Added two Bay Control one-line diagrams for bus throw-over schemes (SEL-451-4 Relay only). 	20070223
SEL-451-1-R201-V0-Z004004-D20070220	<ul style="list-style-type: none"> ➤ Further enhancements to diagnostics. Expanded coverage to include additional failure modes that will result in a relay restart. 	20070223
SEL-451-2-R116-V0-Z007007-D20061215 SEL-451-4-R116-V0-Z007007-D20061215	<p>Note: This firmware version was not production released. See R117, above.</p> <ul style="list-style-type: none"> ➤ Added support for expanded HMI features: auxiliary TRIP/CLOSE pushbuttons, 12 operator control pushbuttons, 24 target LEDs, double-height display points, and tri-colored LEDs. ➤ Added Alias Settings class. ➤ Added new DNP setting MAPSEL and implemented extended binary input map. ➤ Implemented DNP single-event mode. ➤ Increased number of SELOGIC conditional timers from 16 to 32. ➤ Decreased LOP latching delay from 60 cycles to 15 cycles. ➤ Added Fast Message commands to read database regions. ➤ Added 3I01 and 3I02 to Selectable Operating Quantity Inverse-Time Overcurrent Elements (51S). ➤ Restrained DNP power factor binary inputs from updating if voltage falls below 10 percent of nominal or Open Phase Detection Logic asserts. ➤ Modified HMI password entry so that characters are not echoed to the screen. ➤ Added Recloser Open Interval Supervision settings 3POISC and 3POISD. 	20061215
SEL-451-2-R115-V0-Z006006-D20060814 SEL-451-4-R115-V0-Z006006-D20060814	<ul style="list-style-type: none"> ➤ Modified diagnostic failure mode management. Certain diagnostic test errors will result in a relay restart. Relay will log Diagnostic Restart in the SER if this event occurs. 	20060814
SEL-451-1-R200-V0-Z004004-D20060814		
SEL-451-2-R114-V0-Z006006-D20060808 SEL-451-4-R114-V0-Z006006-D20060808 Note: This version was not released from the factory.	<ul style="list-style-type: none"> ➤ Enhanced rms metering to properly measure analog quantities with greater than 50% harmonic content. ➤ Fixed incorrect metering condition following a pulse of the Alternate Voltage Source (ALTV) or Alternate Current Source (ALTI) SELOGIC equations. 	20060808
SEL-451-2-R113-V0-Z006006-D20060727 SEL-451-4-R113-V0-Z006006-D20060727	<ul style="list-style-type: none"> ➤ Corrected problem reading settings with the ACCELERATOR QuickSet® software from the SEL-451-2 Ethernet port using FTP protocol. 	20060727

Table A.1 Firmware Revision History (Sheet 4 of 6)

Firmware Identification (FID) Number	Summary of Revisions	Manual Date Code
SEL-451-2-R112-V0-Z006006-D20060710 SEL-451-4-R112-V0-Z006006-D20060710	<ul style="list-style-type: none"> ► Improvement to dropout time of breaker failure overcurrent fault detector under extreme subsidence current conditions. ► Improvement to automatic removal of chattering SER points where the status of the chattering element is reported after it is reinserted in the SER record. 	20060710
SEL-451-2-R111-V0-Z006006-D20060630 SEL-451-4-R111-V0-Z006006-D20060630 Firmware version R110 and newer are not applicable to the SEL-451-1.	<ul style="list-style-type: none"> ► Added IEC 61850 support for optional Ethernet card. ► Corrected IG magnitude and angle calculations in the CEV summary report. 	20060703
SEL-451-2-R110-V0-Z005005-D20060504 SEL-451-4-R110-V0-Z005005-D20060504 Firmware version R110 is not applicable to the SEL-451-1.	<ul style="list-style-type: none"> ► Added support for the SEL-451-4 Bay Control. ► Added SER events on the front-panel screen. ► Included SER and Bay Screen in the direct menu pushbuttons. ► Added OFF as a setting option to SCROLD to disable the rotating display. ► Added programmable supervision and position status feedback to the standard Local Bits. ► Added phase-to-phase voltage analog quantities for VY and VZ. ► Fixed the CEV command event summary where the IG currents quantity was calculated incorrectly. 	20060504
SEL-451-1-R109-V0-Z004004-D20060413 SEL-451-2-R109-V0-Z004004-D20060413	<p>Note: This firmware version requires the use of R109 or later firmware on any installed SEL-2701 Ethernet Card.</p> <ul style="list-style-type: none"> ► Improved accuracy of time-tagged DNP LAN/WAN binary inputs. 	20060413
SEL-451-1-R107-V0-Z004004-D20060126 SEL-451-2-R107-V0-Z004004-D20060126	<ul style="list-style-type: none"> ► Added support for the SEL-451-2. ► Added support for Main Board B and interface boards INT2, INT7, and INT8 which are optoisolated versions of Main Board A and interface boards INT1, INT5, and INT6. ► Updated to the released (non-draft) version of C37.118 IEEE Synchrophasor Standard. ► Added alarm points and SER settings parameter HMI Alarm in order to enable automatic HMI display of alarm points. ► Added analog display points. ► Expanded to 96 display points and changed format to display on a single line. ► Changed Global setting class for contact inputs to support Main Board A and Main Board B and interface boards INT1, INT2, INT4, INT5, INT6, INT7, and INT8. ► Added setting SCROLD for changing the ROTATING DISPLAY update rate. ► Added settings PB1_HMI through PB8_HMI for assigning alarm point, display point, or event summary screens to the selectable operator pushbuttons. ► Added settings DISP_ER and TYPE_ER for enabling and configuring automatic HMI display of event summary screens. ► Added setting NUM_ER to specify the number of event summary screens viewed through the operator pushbutton. ► Added 15 messages per second option for Global setting MRATE. ► Corrected the voltage check element logic which is using incorrect input voltages. ► Improved performance of phase directional element logic. ► Corrected transition from ROTATING DISPLAY to manual mode when using navigational arrows. 	20060126

Table A.1 Firmware Revision History (Sheet 5 of 6)

Firmware Identification (FID) Number	Summary of Revisions	Manual Date Code
SEL-451-1-R106-V0-Z003003-D20051107	<p>Note: This firmware version requires the use of R108 or later firmware on any installed SEL-2701 Ethernet card.</p> <ul style="list-style-type: none"> ➤ Added DNP3 LAN/WAN support when using the SEL-2701 Ethernet Card. ➤ The STATUS A command now includes information on how many Telnet sessions are active. ➤ Added second file transfer session to allow access to SEL-2701 settings files (SET_DNPn.TXT) via FTP. ➤ Fixed the Trip Unlatch logic to ignore 52AA2 logic when NUMBK = 1. ➤ SET_DNPn.TXT files from the SEL-2701 are now available in the relay file system and can be accessed via FTP or the ASCII FILE command. ➤ Added time-stamped SER data from the relay into TARGET region of the SEL-2701 DNP3 database. ➤ Improved the tripping speed for internal faults under weak infeed applications when loss-of-potential logic is enabled. ➤ Fixed IRIG/HIRIG time synchronization problem to properly lock onto the incoming time signal after a year rollover. ➤ Fixed the event summary report to correctly display the breaker position. ➤ Enhanced the LOP logic to accommodate a corner case scenario. If SPO bit is set to three-pole tripping and 52AA<i>n</i> status shows breaker is open, even though it is closed (due to removing dc or setting mistake) and phase current is below the open pole detection, then LOP will assert. ➤ Enhanced the PORT 5 command to allow transparent access to the SEL-2701 user interface from the host relay. 	20051107
SEL-451-1-R105-V0-Z002002-D20050428	Internal changes only. This firmware includes all of the enhancements listed under R104, below.	20050428
SEL-451-1-R104-V0-Z002002-D20050407	<p>Note: This firmware version was not production released. See R105, above.</p> <ul style="list-style-type: none"> ➤ Added support for IEEE C37.118, Standard for Synchrophasors for Power Systems. ➤ Added PMU (Phasor Measurement Unit) to the serial port settings protocol (PROTO) options for dedicated synchrophasor communications. ➤ Removed port settings PMADDR and PMDATA. Similar functionality is now provided through Global settings, Synchrophasor category. ➤ Changed the TIME input processing to provide high-accuracy timekeeping with a GPS-synchronized IRIG-B signal applied to the IRIG-B BNC connector. ➤ Removed 1k PPS BNC input. ➤ Renamed high-accuracy timekeeping mode HIRIG (previously called PPS mode). ➤ Added timekeeping-related analog quantities for time quality (TQUAL) and UTC Offset (TUTC). ➤ Added Synchrophasor data to the analog quantities available for use in SELOGIC®. ➤ Added a rate-of-change-of-frequency calculation analog quantity, DFDT. ➤ Added time-error calculation logic, and analog quantities TE and TECORR. 	20050407

Table A.1 Firmware Revision History (Sheet 6 of 6)

Firmware Identification (FID) Number	Summary of Revisions	Manual Date Code
	<ul style="list-style-type: none"> ► Added TEC (Time-Error Calculation) command for viewing the time-error, or pre-loading a correction value. ► Added support for INT4 I/O Interface Board with 24 optoisolated control inputs and 8 control outputs. ► Added Relay Word bits for Synchrophasor (PMU) Triggers, Time and Synchronization Control, Time-Error Calculation, and INT4 I/O Interface board support. ► Changed Global settings class to support new Synchrophasor settings, Time-Error Calculation settings, and settings for INT4 I/O Interface Board support. ► Changed factory Global settings SS1, SS2, and TGR so the ALT SETTINGS operator control will function properly. ► Removed Time and Date Management settings from Global settings class. ► Added SER CV and SER RV commands for clearing viewed SER data. ► Added analog quantities for angles $I\phi WA$, $I\phi XA$, $V\phi YA$, $V\phi ZA$ ($\phi = A, B, \text{ or } C$) to complement the corresponding magnitude analog quantities (IAWM, etc.). ► Added analog quantities CTRW, CTRX, PTRY, PTRZ, based on the active group settings of the same name. ► Updated Human Machine Interface (HMI) screens to display 3 digits to the right of the decimal for primary voltage quantities less than 10 kV. ► Removed unused Relay Word bits B1PDAL, B1PSAL, B2PDAL, B2PSAL, RT3P1, RT3P2. ► Changed frequency tracking logic so it will operate independently of circuit breaker status. 	
SEL-451-1-R103-V0-Z001001-D20041201	<ul style="list-style-type: none"> ► Added Security Enhancements when used with the SEL-2701 Ethernet Processor. ► Modified scaling algorithm that could cause erroneous drift in the metered quantities over time. ► Corrected issue where the synchronism check element may report incorrect values for slip frequency. ► Corrected issue in DNP implementation that can cause communications to lock up. 	20041201
SEL-451-1-R102-V0-Z001001-D20040602	<ul style="list-style-type: none"> ► Initial version. 	20040603

Table A.2 lists the Ethernet card firmware versions, a description of modifications, and the instruction manual date code that corresponds to firmware versions. The most recent firmware version is listed first.

Table A.2 Ethernet Card Firmware Revision History (Sheet 1 of 2)

Firmware Identification (FID) Number	Summary of Revisions	Manual Date Code
SEL-2702-R115-V0-Z002002-D20190325 SLBT-2701-R103-V0-Z000000-D20080820	<ul style="list-style-type: none"> ► Resolved an issue where certain Ethernet traffic could cause the relay to safely restart. 	20190325
SEL-2702-R114-V0-Z002002-D20190308 SLBT-2701-R103-V0-Z000000-D20080820	Note: This firmware did not production release.	—
SEL-2702-R113-V0-Z002002-D20111215 SLBT-2701-R103-V0-Z000000-D20080820	<ul style="list-style-type: none"> ► Added support for database references in IEC 61850 configuration files. 	20111215

Table A.2 Ethernet Card Firmware Revision History (Sheet 2 of 2)

Firmware Identification (FID) Number	Summary of Revisions	Manual Date Code
SEL-2702-R112-V0-Z002002-D20110715 SLBT-2701-R103-V0-Z000000-D20080820	► Improved port failover performance of 100BASE-FX fiber channel.	20110906
SEL-2702-R111-V0-Z002001-D20101109 SLBT-2701-R103-V0-Z000000-D20080820	► Added support for multicast synchrophasors.	20101109
SEL-2702-R110-V0-Z001001-D20090205 SLBT-2701-R103-V0-Z000000-D20080820	► Improved security (see www.selinc.com/privacy.htm for details).	20090205
SEL-2702-R109-V0-Z001001-D20081022 SLBT-2701-R103-V0-Z000000-D20080820	► Updated IEC 61850 firmware to streamline MMS processing and improve TCP/IP connections. ► Improved security (see www.selinc.com/privacy.htm for details). ► Corrected issue that could cause the Ethernet card to fail under heavy DNP traffic.	20081022
SEL-2702-R107-V0-Z001001-D20080107 SLBT-2701-R102-V0-Z000000-D20051107	► Enhanced IEC 61850 with KEMA certification updates. ► Added indication of ICD/CID file parse failure to the SEL-2702 user interface (ID , STA , GOO commands).	20080110
SEL-2702-R106-V0-Z001001-D20070914 SLBT-2701-R102-V0-Z000000-D20051107	► Added additional improvements to IEC 61850 control operation priorities when using IEC 61850 GOOSE messaging. ► Corrected issue where communications card MAC address is deleted when upgrading from SEL-2701 firmware version R105 to an SEL-2702.	20070914
SEL-2702-R104-V0-Z001001-D20070717 SLBT-2701-R102-V0-Z000000-D20051107	► Made improvements to IEC 61850 control operation priorities when using IEC 61850 GOOSE messaging. ► Allocated additional memory for read/write of large IEC 61850 messages. ► Fixed ability to pulse Breaker and Latch control bits using DNP LAN/WAN when DNPMAP=AUTO.	20070717
SEL-2702-R103-V0-Z001001-D20070223 SLBT-2701-R102-V0-Z000000-D20051107	► Added support for synchrophasors over Ethernet.	20070223
SEL-2702-R101-V0-Z000000-D20060808 SLBT-2701-R102-V0-Z000000-D20051107	► Added support for pulse operations on DNP LAN/WAN control points, both paired and unpaired. ► Added ability to sense local operations and update IEC 61850 origination category.	20060808
SEL-2702-R100-V0-Z000000-D20060703 SLBT-2701-R102-V0-Z000000-D20051107	► Initial version.	20060703

The optional Ethernet card (SEL-2701 or SEL-2702) must be paired with a compatible SEL-451 version. You may need to upgrade your SEL-451 firmware to access features in new versions of the Ethernet cards. *Table A.1* includes notes on SEL-451 modifications that support new features of the Ethernet cards.

To find the firmware revision number in your Ethernet card, first connect to the SEL-451 with the **ACC** command. View the FIDs with the **VERSION** command. Look for the Ethernet card Firmware Identification (FID) label in the response under Communications Card:

FID=SEL-2701-Rxxx-Vx-Zxxxxxx-Dxxxxxxxx

In the FID label, the 4 digits after “SEL” indicate which Ethernet card is installed. The firmware revision number follows the R and the release date follows the D.

For example,

SEL-2701-R108-V0-Z002001-D20051205

is for an SEL-2701 Ethernet card, firmware revision number 108, release date December 5, 2005.

Table A.3 lists current Ethernet card firmware versions with compatible SEL-451 versions.

Table A.3 Compatible SEL-451 and Ethernet Card Firmware Versions

SEL-451 Firmware	Ethernet Card	Ethernet Card Firmware
R117 or higher	SEL-2702	R103 or higher
R110–R116	SEL-2702	R100–R101
R106–R109; R200 or higher	SEL-2701	R108 or higher
R105 or earlier	SEL-2701	R105 or earlier

Newer Ethernet card firmware (R106 and higher) uses a different software library from earlier versions and is unable to process version 001 CID files. ACCELERATOR Architect® generates CID files from ICD files, so the ICD file version number and CID file version number are the same. If downloaded to the Ethernet port, an incompatible CID file will generate file parse errors during processing and disable the IEC 61850 protocol.

If you perform an Ethernet port firmware upgrade that spans different file version compatibilities, the relay may not be able to process the stored CID file. See the *Ethernet Port Firmware Upgrade Instructions* in the *SEL-400 Series Upgrade Instructions* for CID file conversion procedures.

See *Table A.4* for compatibilities between ACCELERATOR Architect, ICD/CID file, and Ethernet card firmware versions.

Table A.4 ACCELERATOR Architect CID File Compatibility

ACCELERATOR Architect Software Version	ACCELERATOR Architect ICD/CID File Version	Ethernet Card Firmware
All versions	Ver 001	R100–R106
R.1.1.69.0 or higher	Ver 002 (all)	R107 or higher

Instruction Manual

The date code at the bottom of each page of this manual reflects the creation or revision date.

Table A.5 lists the instruction manual release dates and a description of modifications. The most recent instruction manual revisions are listed at the top.

Table A.5 Instruction Manual Revision History (Sheet 1 of 13)

Revision Date	Summary of Revisions
20190325	<p>User's Guide Appendix A ► Updated for Ethernet firmware version R115-V0.</p>
20121207	<p>User's Guide Section 1 ► Updated <i>Specifications</i>. Section 5 ► Removed out-of-step reference. Applications Handbook Section 2 ► Updated <i>Figure 2.11: Typical Station DC Battery System</i>. Section 5 ► Added <i>Bay Character Set</i> section and <i>Figure 5.53: Bay Character Set</i>. Reference Manual Section 1 ► Updated tuning process description for <i>High-Impedance Fault Detection Logic</i>. ► Added note that the voltage is required for fault identification logic. ► Updated <i>Figure 1.42: U.S. Extremely Inverse Curve: U4</i>. ► Added <i>Open Phase Detection Logic</i>. Section 7 ► Changed header from 16 bytes to 18 bytes. Section 9 ► Added <i>HSG and HSG D</i> command description. Appendix B ► Added footnote clarifying the accuracy of time of day in ms analog (TODMS).</p>
20111215	<p>User's Guide Section 1 ► Updated <i>Specifications</i>. Section 2 ► Updated <i>Table 2.1: Recommended Control Inputs Pickup Settings</i>. ► Updated <i>Physical Location</i>. ► Updated <i>Figure 2.29: SEL-451 Chassis Dimensions</i>. Section 4 ► Updated <i>Table 4.8: Control Inputs in the SEL-451</i>. Appendix A ► Updated for Ethernet card firmware version R113. Applications Handbook Section 2 ► Updated <i>Mechanical Operating Time</i>. ► Updated <i>Circuit Breaker Report</i>. Reference Manual Section 1 ► Updated <i>Voltage Source Switching and Uses</i>. ► Updated <i>High-Impedance Fault Detection</i>. ► Updated <i>Table 1.20 HIF Relay Word Bits</i>. ► Updated <i>Figure 1.50: SOTF Logic Diagram</i>. Section 6 ► Updated <i>Table 6.24: SEL-451 DNP3 Object List</i>.</p>
20110906	<p>User's Guide Appendix A ► Updated for firmware version R125. ► Updated for Ethernet card firmware version R112.</p>

Table A.5 Instruction Manual Revision History (Sheet 2 of 13)

Revision Date	Summary of Revisions
20101109	<p>User's Guide Appendix A</p> <ul style="list-style-type: none"> ➤ Updated for Ethernet card firmware version R111.
20100723	<p>User's Guide Appendix A</p> <ul style="list-style-type: none"> ➤ Updated for firmware version R124.
20090930	<p>User's Guide Appendix A</p> <ul style="list-style-type: none"> ➤ Updated for firmware version R123.
20090715	<p>Reference Manual Section 2</p> <ul style="list-style-type: none"> ➤ Added information about reclose cycle operations.
20090526	<p>User's Guide Appendix A</p> <ul style="list-style-type: none"> ➤ Updated for firmware version R122.
20090309	<p>User's Guide Appendix A</p> <ul style="list-style-type: none"> ➤ Updated for firmware version R121.
20090213	<p>User's Guide Section 4</p> <ul style="list-style-type: none"> ➤ Updated <i>Changing the Default Passwords</i> to reflect Access Level C addition. ➤ Updated <i>Figure 4.5: Access Level Structure</i>. ➤ Updated <i>Table 4.3: SEL-451 Access Levels</i> and <i>Table 4.4: SEL-451 Access Level Commands and Passwords</i>. ➤ Updated <i>Communications Ports Access Levels</i> to reflect new Access Level C port settings. ➤ Updated steps under <i>Passwords</i>. <p>Appendix A</p> <ul style="list-style-type: none"> ➤ Updated for firmware version R120. ➤ Updated for Ethernet card firmware version R110. ➤ Updated <i>Table A.3: Compatible SEL-451 and Ethernet Card Firmware Versions</i>. <p>Reference Manual Section 6</p> <ul style="list-style-type: none"> ➤ Updated <i>Table 6.10: SEL-451 DNP3 Default Data Map</i>, <i>Table 6.15: SEL-451 Object 12 Trip/Close Pair Operation</i>, <i>Table 6.16: SEL-451 Object 12 Code Selection Operation</i>, <i>Table 6.17: DNP3 Application Example Data Map</i>, <i>Table 6.22: SEL-451 Binary Output CPId Values</i>, and <i>Table 6.25: SEL-451 DNP LAN/WAN Object 12 Control Point Operation</i>. <p>Section 9</p> <ul style="list-style-type: none"> ➤ Added CAL command. ➤ Modified <i>Password</i> to reflect the extended password length from 6 to 12 characters. ➤ Updated <i>Table 9.2: 89CLOSE n Command</i> and <i>Table 9.3: 89OPEN n Command</i>. <p>Section 10</p> <ul style="list-style-type: none"> ➤ Updated <i>Table 10.91: Protocol Selection</i>, <i>Table 10.106: General One-Line Settings</i>, <i>Table 10.107: Busbar Information</i>, and <i>Table 10.109: Disconnect Information</i>. <p>Appendix A</p> <ul style="list-style-type: none"> ➤ Updated <i>Table A.1: Alphabetic List of Relay Word Bits</i>. ➤ Added <i>Table A.57: Relay Word Bits: Bay Control–Disconnect Status Indication and Alarms (Disconnects 6–10)</i>, <i>Table A.58: Relay Word Bits: Bay Control–Buszone Disconnect Contacts (Disconnects 6–10)</i>, and <i>Table A.59: Relay Word Bits: Bay Control–Disconnect Open/Close (Disconnects 6–10)</i>.

Table A.5 Instruction Manual Revision History (Sheet 3 of 13)

Revision Date	Summary of Revisions
20081022	<p>User's Guide</p> <p>Appendix A</p> <ul style="list-style-type: none"> ➤ Updated for Ethernet card firmware version R109 and SELBOOT firmware version R103.
20080110	<p>User's Guide</p> <p>Appendix A</p> <ul style="list-style-type: none"> ➤ Updated for Ethernet card firmware version R107. ➤ Added <i>Table A.4: ACCELERATOR Architect CID File Compatibility</i>. <p>Reference Manual</p> <p>Section 4</p> <ul style="list-style-type: none"> ➤ Added descriptions of ID, STA, and GOO commands ICD/CID file parse failure indication. <p>Section 8</p> <ul style="list-style-type: none"> ➤ Added and edited tables to document new ICD file versions supported by ACCELERATOR Architect version R.1.1.69.0. ➤ Added <i>Table 8.7: ICD Logical Nodes Summary</i>. ➤ Updated <i>Table 8.8: Logical Device: PRO (Protection) through Table 8.11: Logical Device: ANN (Annunciation)</i>.
20070914	<p>User's Guide</p> <p>Appendix A</p> <ul style="list-style-type: none"> ➤ Updated for Ethernet card firmware version R106. <p>Reference Manual</p> <p>Added details and examples to indicate how to get SOE-quality timestamped data over a DNP LAN/WAN connection in the following sections.</p> <p>Section 4</p> <ul style="list-style-type: none"> ➤ Updated titles in <i>Table 4.19–Table 4.27</i>. <p>Section 6</p> <ul style="list-style-type: none"> ➤ Updated <i>Table 6.21</i>, <i>Table 6.26</i>, and <i>Table 6.28</i>. ➤ Added <i>Figure 6.4</i>.
20070730	<p>User's Guide</p> <p>Appendix A</p> <ul style="list-style-type: none"> ➤ Updated for firmware version R119. <p>Section 1</p> <ul style="list-style-type: none"> ➤ Added <i>High-Impedance Fault Detection to Features</i>. ➤ Added secondary inputs note regarding high-impedance fault detection support in <i>Models and Options</i>. <p>Applications Handbook</p> <p>Section 3</p> <ul style="list-style-type: none"> ➤ Added <i>High-Impedance Fault Event Oscillography to Oscillography</i>. ➤ Added <i>High-Impedance Fault Event Summaries and Histories</i>. <p>Reference Manual</p> <p>Section 1</p> <ul style="list-style-type: none"> ➤ Added <i>High-Impedance Fault Detection</i>. <p>Section 5</p> <ul style="list-style-type: none"> ➤ Added high-impedance fault event oscillography to EVENTS directory in <i>Table 5.9</i>. ➤ Added high-impedance fault event oscillography description to <i>EVENTS Directory</i>. ➤ Added <i>Table 5.13</i>.

Table A.5 Instruction Manual Revision History (Sheet 4 of 13)

Revision Date	Summary of Revisions
	<p>Section 9</p> <ul style="list-style-type: none"> ➤ Added CSU HIF, HIS HIF, HIZ,INI HIF, SUM HIF, and TRI HIF commands as well as related parameters. ➤ Added Table 9.43, Table 9.44, Table 9.45, Table 9.46, Table 9.69, Table 9.70, Table 9.71, Table 9.72, Table 9.73, Table 9.74, Table 9.76, Table 9.144, Table 9.145, Table 9.146, Table 9.162, and Table 9.163. ➤ Added Figure 9.1. <p>Section 10</p> <ul style="list-style-type: none"> ➤ Added Group settings High-Impedance Fault Detection and 50G High-Z (HIZ) Fault Detection to Table 10.29. ➤ Added High Impedance Fault (HIF) Detection and 50G High-Z (HIZ) Fault Detection to Table 10.29. ➤ Added EHIF setting to Table 10.31. ➤ Added Table 10.64 and Table 10.65. ➤ Added HIF Event Reporting to Table 10.84. ➤ Added Table 10.89. <p>Appendix A</p> <ul style="list-style-type: none"> ➤ Added 3PH_A-3PH_EVE, 50GHIZ, 50GHIZA, CHIZ0, CPUDO0, DDNA-DDNG, DIA_DIS- DL2CLRG, DUPA-DVG_DIS, FRZCLRA-FRZCLRG, HIA1_A-HIZRST, ITUNE_A-ITUNE_G, LRA-LR3, NTUNE_A-NTUNE_G to Table A.1. ➤ Added new Table A.55 and Table A.56.
20070717	<p>User's Guide</p> <p>Appendix A</p> <ul style="list-style-type: none"> ➤ Updated for firmware version R118. ➤ Updated for Ethernet card firmware version R104. <p>Applications Handbook</p> <p>Section 5</p> <ul style="list-style-type: none"> ➤ Added statement to indicate support for additional user-selectable bay types made available at selinc.com. ➤ Updated MIMIC setting range in Table 5.4 to reflect support for additional user-selectable bay types. <p>Reference Manual</p> <p>Section 10</p> <ul style="list-style-type: none"> ➤ Update MIMIC setting range in Table 10.106 to reflect support for additional user-selectable bay types.
20070223	<p>User's Guide</p> <p>Appendix A</p> <ul style="list-style-type: none"> ➤ Updated for firmware version R117 (SEL-451-2, -4) and R201 (SEL-451-1). <p>Reference Manual</p> <p>Section 1</p> <ul style="list-style-type: none"> ➤ Added <i>Frequency Estimation Provided by Synchrophasor</i>. <p>Section 4</p> <ul style="list-style-type: none"> ➤ Added the Ethernet card as one of the available communications interfaces for the Phasor Measurement Protocol. <p>Section 7</p> <ul style="list-style-type: none"> ➤ Added Table 7.2 for the Time and Date Management setting IRIGC. ➤ Added Table 7.4: <i>Ethernet Port Settings for Synchrophasors</i>. ➤ Changed FREQ to FREQ_PM (frequency measurement using phasor measurement quantities) in Table 7.9. ➤ Added synchrophasor protocol availability when EPMIP := Y. ➤ Revised example logic settings in Table 7.15. <p>Section 10</p> <ul style="list-style-type: none"> ➤ Added Table 10.16 for the Time and Date Management setting IRIGC.

Table A.5 Instruction Manual Revision History (Sheet 5 of 13)

Revision Date	Summary of Revisions
	<p>Applications Handbook</p> <p>Section 5</p> <ul style="list-style-type: none"> ► Added <i>Bus Throw-Over</i>. <p>Section 6</p> <ul style="list-style-type: none"> ► Added LED and pushbutton statuses from expanded HMI to <i>Table 6.7</i>. <p>Section 7</p> <ul style="list-style-type: none"> ► Added synchrophasor to list of available protocols.
20061215	<p>Note: This version was not released from the factory. The 20070223 version contains the following changes.</p> <p>User's Guide</p> <p>Section 1</p> <ul style="list-style-type: none"> ► Added Alias Settings and Auxiliary TRIP/CLOSE Pushbuttons to <i>Features</i>. ► Added INT3 board to <i>Models and Options</i>. ► Added INT3 and Auxiliary TRIP/CLOSE Pushbuttons to <i>Specifications</i>. <p>Section 2</p> <ul style="list-style-type: none"> ► Added INT3 to <i>Optoisolated and Control Inputs</i>. ► Added new <i>Figure 2.15</i>. ► Added INT3 to <i>Table 2.3</i> and <i>Table 2.4</i>. ► Added new <i>Figure 2.25</i>. ► Added Auxiliary TRIP/CLOSE Pushbutton and Breaker Status LED Jumpers with <i>Table 2.8</i>, <i>Table 2.9</i>, and <i>Table 2.10</i>. ► Updated <i>Figure 2.29</i> to include optional pushbutton. ► Added Auxiliary TRIP/CLOSE to <i>Control Outputs</i>. ► Added <i>Figure 2.54</i>. ► Added INT3 to <i>I/O Interface Board Jumpers</i>. <p>Section 4</p> <ul style="list-style-type: none"> ► Added Alias setting to <i>Table 4.5</i>. ► Updated Display Points Text Size parameter in <i>Figure 4.14</i> and <i>Figure 4.15</i>. ► Added Alias Settings. ► Added new <i>Figure 4.16</i>, <i>Figure 4.17</i>, and <i>Figure 4.18</i>. <p>Section 5</p> <ul style="list-style-type: none"> ► Added new <i>Figure 5.2</i>. ► Updated <i>Front-Panel Layout</i> for HMI changes: expanded pushbuttons, expanded target LEDs, tri-color LEDs, and auxiliary TRIP/CLOSE pushbuttons. ► Updated <i>Figure 5.5</i> to include double-height Display Points. ► Updated <i>Display Points</i> to include Text Size parameter. ► Updated <i>Figure 5.11</i> to include double-height Display Points. ► Updated <i>Example 5.2</i> to include double-height Display Points. ► Updated <i>Relay Elements (Relay Word Bits)</i> for Alias impact. ► Updated <i>Operation and Target LEDs</i> for HMI changes: expanded target LEDs and tri-color LEDs. ► Updated <i>Figure 5.45</i> for expanded target LEDs. ► Added <i>Table 5.11</i>. ► Updated <i>Voltage Status</i> for expanded target LEDs. ► Added <i>Miscellaneous Status and Clock Status</i> for expanded target LEDs. ► Updated <i>Figure 5.47</i>, <i>Table 5.13</i>, and <i>Figure 5.48</i> for 12 pushbuttons. <p>Section 6</p> <ul style="list-style-type: none"> ► Updated <i>Figure 6.8</i> for Alias impact. ► Updated <i>Table 6.7</i> for 3IOn. <p>Appendix A</p> <ul style="list-style-type: none"> ► Updated for firmware version R116.

Table A.5 Instruction Manual Revision History (Sheet 6 of 13)

Revision Date	Summary of Revisions
	<p>Applications Guide</p> <p>Section 1</p> <ul style="list-style-type: none"> ➤ Updated 25 kV Overhead Distribution Line Example for 3I0n 51S quantity. ➤ Updated Table 1.6 for 3I0n 51S quantity. <p>Section 3</p> <ul style="list-style-type: none"> ➤ Added INT3 to <i>Data Processing</i>. ➤ Added Alias Names to <i>Event Report, Event Summaries, and Event Histories</i>. ➤ Updated Digital Section of the Event Report for Alias impact. ➤ Updated Settings Section of the Event Report for Alias impact. ➤ Updated Figure 3.12 and Figure 3.13 to include Alias settings. <p>Section 5</p> <ul style="list-style-type: none"> ➤ Updated Figure 5.7 for 12 pushbuttons. <p>Section 6</p> <ul style="list-style-type: none"> ➤ Updated Table 6.3 to include new database region 20 messages. <p>Reference Manual</p> <p>Section 1</p> <ul style="list-style-type: none"> ➤ Updated Figure 1.16 to decrease LOP latching delay from 60 cycles to 15 cycles. ➤ Updated Table 1.43, Table 1.44, and Figure 1.41 for 3I0n 51S quantity. <p>Section 2</p> <ul style="list-style-type: none"> ➤ Updated E79 := Y1, Figure 2.11, Table 2.21, and Table 2.22 for new settings 3POISC and 3POISD. <p>Section 3</p> <ul style="list-style-type: none"> ➤ Updated Table 3.2 and Table 3.13 to include 32 conditioning timers. ➤ Added Alias and Example 3.10. ➤ Updated Table 3.28 to include 32 conditioning timers. <p>Section 5</p> <ul style="list-style-type: none"> ➤ Updated Table 5.10 to include Alias settings. <p>Section 6</p> <ul style="list-style-type: none"> ➤ Updated Table 6.6 for new settings EVELOCK, MINDIST, and MAXDIST. ➤ Updated Table 6.7 for new setting MAPSEL. ➤ Edited Default Data Map to explain new reference maps. ➤ Updated Table 6.10 to include two reference maps and new index 182. ➤ Updated Reading Relay Even Data for new single-event mode. ➤ Corrected Bit values in Table 6.14. ➤ Updated Figure 6.2 for new setting MAPSEL. ➤ Updated Table 6.18 for new settings EVELOCK, MINDIST, and MAXDIST. <p>Section 9</p> <ul style="list-style-type: none"> ➤ Added SET T and SHO T to <i>Description of Commands</i>. ➤ Added Aliases to TAR command.

Table A.5 Instruction Manual Revision History (Sheet 7 of 13)

Revision Date	Summary of Revisions
	<p>Section 10</p> <ul style="list-style-type: none"> ► Added Alias Settings and <i>Table 10.1</i> and <i>Figure 10.1</i>. ► Updated <i>Table 10.11</i> for RSTDNPE. ► Updated <i>Table 10.42</i> through <i>Table 10.47</i> for 3IOn 51S quantity. ► Updated <i>Table 10.58</i> for new BK1MCL default setting. ► Updated <i>Table 10.59</i> for new settings 3POISC and 3POISD. ► Updated <i>Table 10.62</i> for new BK1MTR default settings. ► Updated <i>Table 10.73</i> for HMI changes: tri-color LEDs, expanded pushbuttons, and expanded target LEDs. ► Updated <i>Table 10.75</i> for expanded pushbuttons. ► Updated <i>Table 10.77</i> and <i>Table 10.78</i> for Text Size parameter. ► Updated <i>Table 10.90</i> for new settings EVELOCK, MINDIST, and MAXDIST. ► Added <i>Table 10.94</i>. <p>Appendix A</p> <ul style="list-style-type: none"> ► Updated <i>Table A.1</i> to increment certain Relay Word bit rows, and added EVELOCK, 3POISC, PB9_PUL–PB12PUL, PCT17Q–PCT32Q, PB_CLSE, PB_TRIP, RSTDNPE, and TLED_17–TLED_24. ► Added 3POISC to <i>Table A.6</i>. ► Added PCT17Q–PCT32Q to <i>Table A.24</i>. ► Added RSTDNPE to <i>Table A.36</i>. ► Added new <i>Table A.46</i> and <i>Table A.52</i>. <p>Appendix B</p> <ul style="list-style-type: none"> ► Added PCT17DO–PCT32DO and PCT17PU–PCT32PU to <i>Table B.1</i> and <i>Table B.2</i>.
20060814	<p>User's Guide</p> <p>Section 6</p> <ul style="list-style-type: none"> ► In <i>Status Warning</i> and <i>Status Failure</i> added information about the relay restarting on certain diagnostic failures. <p>Appendix A</p> <ul style="list-style-type: none"> ► Updated for firmware version R115 (SEL-451-2, -4) and R200 (SEL-451-1). <p>Applications Handbook</p> <p>Section 3</p> <ul style="list-style-type: none"> ► Added diagnostic restart to the list of conditions captured by the SER.
20060808	<p>Note: This version was not released from the factory. The 20060814 version contains the following changes.</p> <p>User's Guide</p> <p>Section 2</p> <ul style="list-style-type: none"> ► Updated Ethernet card rear-panel layouts. <p>Appendix A</p> <ul style="list-style-type: none"> ► Updated for firmware revision R114. ► Updated for SEL-2702 firmware revision R101. <p>Reference Manual</p> <p>Section 6</p> <ul style="list-style-type: none"> ► Documented additional support for paired control outputs (BO). <p>Section 8</p> <ul style="list-style-type: none"> ► Clarified multiple client access for Unbuffered Reports. ► Added Protocol Implementation Conformance Statement (PICS).
20060727	<p>User's Guide</p> <p>Appendix A</p> <ul style="list-style-type: none"> ► Updated for firmware revision R113.
20060710	<p>User's Guide</p> <p>Appendix A</p> <ul style="list-style-type: none"> ► Updated for firmware revision R112.

Table A.5 Instruction Manual Revision History (Sheet 8 of 13)

Revision Date	Summary of Revisions
20060703	<p>User's Guide</p> <p>Section 2</p> <ul style="list-style-type: none"> ➤ Included network port configurations and safety warnings in <i>Network Connections</i>. <p>Appendix A</p> <ul style="list-style-type: none"> ➤ Updated for firmware revision R111. <p>Applications Handbook</p> <p>Section 7</p> <ul style="list-style-type: none"> ➤ Revised FTP File Structure description in <i>FTP</i>. ➤ Specified CID file location in <i>FTP</i>. <p>Reference Manual</p> <p>Section 4</p> <ul style="list-style-type: none"> ➤ Added Ethernet card commands to <i>Ethernet Card Commands</i>. ➤ Added “keep alive” settings ETCPKA, KAIDLE, KAINTV, and KACNT to <i>Ethernet Network Operation Settings</i>. ➤ Revised FTP File Structure description in <i>File Structure</i>. <p>Section 6</p> <ul style="list-style-type: none"> ➤ Increased CCINs from 32 to 128 (DNP LAN/WAN map) and adjusted indices as necessary. <p>Section 8</p> <ul style="list-style-type: none"> ➤ Added new <i>IEC 61850</i> section (replaced the <i>UCA2</i> section). <p>Section 9</p> <ul style="list-style-type: none"> ➤ Added information about new ID command response for an Ethernet card with IEC 61850 support. <p>Appendix A</p> <ul style="list-style-type: none"> ➤ Increased CCINs from 32 to 128 (Relay Word bits) and adjusted row numbers for those and all subsequent rows. <p>Glossary</p> <ul style="list-style-type: none"> ➤ Added IEC 61850 entries. <p>Miscellaneous</p> <ul style="list-style-type: none"> ➤ Removed <i>GOMSFE</i> appendix. ➤ Removed references to UCA2 and GOMSFE. ➤ Modified GOOSE references to describe IEC 61850 GOOSE.
20060504	<p>Preface</p> <ul style="list-style-type: none"> ➤ Added description of <i>Section 5: Bay Control</i> in the <i>Applications Handbook</i>. <p>User's Guide</p> <p>Section 1</p> <ul style="list-style-type: none"> ➤ Added description of the SEL-451-4. ➤ Added text to include the SEL-451-4 Bay Control as an SEL-451 feature. ➤ Added <i>Figure 1.8</i>. ➤ Updated <i>Table 1.1</i> to include SEL-451-4 in application highlights. <p>Section 2</p> <ul style="list-style-type: none"> ➤ Edited <i>Jumpers</i> to include breaker jumper supervision of disconnect switch control operations. <p>Section 4</p> <ul style="list-style-type: none"> ➤ Updated <i>Table 4.5</i> to include Bay control settings class. ➤ Added SEL-451-4 Bay Control metering screen example. ➤ Added note to indicate that the latest 200 SER events are viewable on the front panel. ➤ Edited <i>Operating the Relay Inputs and Outputs</i> to include Local Bit supervision.

Table A.5 Instruction Manual Revision History (Sheet 9 of 13)

Revision Date	Summary of Revisions
	<p>Section 5</p> <ul style="list-style-type: none"> ➤ Updated <i>Table 5.2</i> to include ONELINE in Metering Screen Enable Settings. ➤ Edited <i>Front Panel Layout</i> to include OFF as a SCROLLED setting option. ➤ Added <i>Figure 5.20</i>. ➤ Added description of SER event viewing on the front panel. ➤ Added Local Control bit supervision and display logic. ➤ Added <i>Table 5.9</i>. ➤ Added <i>Figure 5.30</i>. ➤ Added description of the ONE LINE DIAGRAM selection in the front panel Main Menu. ➤ Added <i>Figure 5.41</i>. ➤ Edited <i>Front-Panel Operator Control Pushbuttons</i> to include SER and BC as direct-operate pushbuttons options. ➤ Edited <i>Front-Panel Menus and Screens</i> to indicate what Relay Word bits are affected by front-panel breaker operations. <p>Appendix A</p> <ul style="list-style-type: none"> ➤ Updated for firmware version R110. <p>Applications Handbook</p> <p>Section 3</p> <ul style="list-style-type: none"> ➤ Added note to indicate the latest 200 SER Events are viewable on the front panel. <p>Section 5</p> <ul style="list-style-type: none"> ➤ Added new <i>Section 5: Bay Control</i>. <p>Section 6</p> <ul style="list-style-type: none"> ➤ Edited <i>SEL Communications Processor Example</i> to include Fast Operate control of disconnect switches in the SEL-451-4 using the communications processor. <p>Reference Manual</p> <p>Section 1</p> <ul style="list-style-type: none"> ➤ Added <i>Circuit Breaker Status Logic</i>. <p>Section 6</p> <ul style="list-style-type: none"> ➤ Updated <i>Table 6.11</i> to include SEL-451-4 Relay Word bits. ➤ Updated <i>Table 6.10</i>, <i>Table 6.15</i>, <i>Table 6.16</i>, <i>Table 6.22</i>, and <i>Table 6.25</i> for SEL-451-4 DNP objects. <p>Section 9</p> <ul style="list-style-type: none"> ➤ Added 89CLOSE and 89OPEN commands. ➤ Added instance of Bay class settings for the SET and SHO commands. <p>Section 10</p> <ul style="list-style-type: none"> ➤ Updated <i>Table 10.62</i> to indicate SEL-451 default settings. ➤ Added <i>Table 10.63</i> to indicate SEL-451-4 default settings. ➤ Updated <i>Table 10.71</i> to add Local Bits SELOGIC. ➤ Updated <i>Table 10.72</i> to indicate SEL-451 and SEL-451-4 PBn_LED default settings. ➤ Updated <i>Table 10.73</i> to add OFF as a SCROLLED setting option, add ONELINE setting, and indicate SEL-451-4 default settings. ➤ Updated <i>Table 10.74</i>. ➤ Added Bay settings class (SEL-451-4) <p>Appendix A</p> <ul style="list-style-type: none"> ➤ Updated <i>Table A.1</i> (Local Bit supervision Relay Word bits, Local Bit display Relay Word bits, and SEL-451-4 Relay Word bits). ➤ Added <i>Table A.48–Table A.52</i> (Local Bit supervision Relay Word bits, Local Bit display Relay Word bits, and SEL-451-4 Relay Word bits). <p>Appendix B</p> <ul style="list-style-type: none"> ➤ Updated <i>Table B.1</i> with VY and VZ phase-to-phase filtered instantaneous voltage magnitude and angle. ➤ Updated <i>Table B.2</i> with VY and VZ phase-to-phase filtered instantaneous voltage magnitude and angle.

Table A.5 Instruction Manual Revision History (Sheet 10 of 13)

Revision Date	Summary of Revisions
	<p>Command Summary</p> <ul style="list-style-type: none"> ► Added 89CLOSE and 89OPEN commands. ► Added Bay settings class to <i>Table 1.2</i>.
20060413	<p>User's Guide</p> <p>Appendix A</p> <ul style="list-style-type: none"> ► Updated for firmware version R109.
20060126	<p>Preface</p> <ul style="list-style-type: none"> ► Moved cautions, warnings, and dangers in English and French from reverse of front cover to the <i>Preface</i>. <p>User's Guide</p> <p>Section 1</p> <ul style="list-style-type: none"> ► Added information about Main Board A and Main Board B and interface boards INT2, INT7, and INT8. <p>Section 2</p> <ul style="list-style-type: none"> ► Corrected <i>Figure 2.5</i> to remove positive polarity mark. ► Updated <i>Table 2.4</i>. ► Added Main Board B and interface boards INT2, INT7, and INT8. ► Added rear-panel drawings: 4U Rear Panel, Main Board B, INT8 I/O Interface Board; 5U Rear Panel, Main Board A, INT6 and INT4 I/O Interface Board; 5U Rear Panel, Main Board B, INT2 and INT7 I/O Interface Board. <p>Section 3</p> <ul style="list-style-type: none"> ► Updated <i>Figure 3.15: Setting the Relay Part Number in ACCELERATOR QuickSet</i>. <p>Section 4</p> <ul style="list-style-type: none"> ► Corrected the IRIG-B jitter tolerance level. ► Modified <i>Figure 4.44</i> to reflect new SER setting parameter HMI Alarm. ► Updated <i>Table 4.8</i> with the information for Main Board A and Main Board B and interface board INT2, INT7, and INT8. ► Updated <i>Figure 4.56</i> to reflect changes to Control Inputs settings and added <i>Figure 4.57</i> to reflect changes to Main Board Control Inputs settings. <p>Section 5</p> <ul style="list-style-type: none"> ► Updated figures throughout to correct Enter pushbutton graphic. ► Updated figures throughout to correct footer capitalization errors. ► Added alarm points screen to <i>Figure 5.4</i>. ► Added <i>Alarm Points</i>. ► Modified <i>Display Points</i> to allow for analog quantity display points. ► Added note clarifying the line current and voltage source for protection functions. ► Modified <i>Events</i> to explain event summary access options. ► Modified <i>Front-Panel Automatic Messages</i> to include alarm points. ► Added alarm points screen to <i>Figure 5.37</i>. ► Added application references for TRGTR Relay Word bit and group setting ULTR. ► Modified <i>Front-Panel Operator Control Pushbuttons</i> section to include alarm points, display points, and event summary viewing options. <p>Section 6</p> <ul style="list-style-type: none"> ► Modified <i>Figure 6.9</i> to update for new front-panel settings categories. ► Modified <i>Figure 6.14</i> to reflect new SER setting parameter HMI Alarm. <p>Appendix A</p> <ul style="list-style-type: none"> ► Updated for firmware version R107. <p>Applications Handbook</p> <p>Section 3</p> <ul style="list-style-type: none"> ► Modified <i>Setting SER Points and Aliases</i> to reflect new SER setting parameter HMI Alarm. ► Updated <i>Figure 3.1</i> to include Main Board A and Main Board B and Interface Boards INT1, INT2, INT4, INT5, INT6, INT7, and INT8. ► Added IN101 through IN208 analog channels in <i>Figure 3.5</i>.

Table A.5 Instruction Manual Revision History (Sheet 11 of 13)

Revision Date	Summary of Revisions
	<p>Reference Manual</p> <p>Section 2</p> <ul style="list-style-type: none"> ► Corrected <i>Figure 2.20</i> and <i>Figure 2.21</i>. <p>Section 7</p> <ul style="list-style-type: none"> ► Added footnote to <i>Table 7.9</i>. ► Added a row (15 option to the range of MRATE in the Global setting class) to <i>Table 7.11</i>. <p>Section 10</p> <ul style="list-style-type: none"> ► Updated <i>Table 10.5</i>, <i>Table 10.6</i>, <i>Table 10.7</i>, and <i>Table 10.8</i> for the changes in the Control Inputs, Main Board Control Inputs, Interface Board #1 Control Inputs, and Interface Board #2 Control Inputs settings. ► Added 15 option to the range of MRATE setting in <i>Table 10.16</i>. ► Added new front-panel settings categories to <i>Table 10.69</i>. ► Added new setting SCROLDD to <i>Table 10.71</i>. ► Added new front-panel settings <i>Table 10.74</i> and <i>Table 10.75</i>. ► Split Display Points and Aliases table into two separate tables, <i>Table 10.74</i> and <i>Table 10.75</i>, for Boolean and Analog Display Points. ► Updated <i>Table 10.79</i>.
20051107	Revised entire manual to include new DNP3 LAN/WAN functionality (firmware version R106).
20050428	<p>User's Guide</p> <p>Appendix A</p> <ul style="list-style-type: none"> ► Updated for firmware version R105.
20050407	<p>General</p> <ul style="list-style-type: none"> ► Added <i>Glossary</i> entries for C37.118, Fast Message, IEEE, RTD, Time Error, Time Quality, and TVE. ► Updated PPS entry in <i>Glossary</i>. <p>User's Guide</p> <p>Section 1</p> <ul style="list-style-type: none"> ► Updated <i>Specifications</i>. <p>Section 2</p> <ul style="list-style-type: none"> ► Added INT4 I/O Interface Board information, including instructions for using the optoisolated control inputs to detect ac control signals. ► Updated rear-panel figures and related text to show new TIME input configuration. <p>Section 3</p> <ul style="list-style-type: none"> ► Updated ACCELERATOR® SEL-5030 screen captures and related text. <p>Section 4</p> <ul style="list-style-type: none"> ► Updated ACCELERATOR SEL-5030 screen captures and related text. ► Updated serial number label in <i>Figure 4.1</i> and related text. ► Added INT4 I/O Interface Board control inputs information and <i>Table 4.8</i>. ► Updated <i>Configuring High-Accuracy Timekeeping</i>. <p>Section 5</p> <ul style="list-style-type: none"> ► Added footnote to <i>Table 5.13</i> related to ALT SETTINGS operator control. <p>Section 6</p> <ul style="list-style-type: none"> ► Added Time/Date Errors to Troubleshooting Procedures, <i>Table 6.9</i>. <p>Appendix A</p> <ul style="list-style-type: none"> ► Updated for firmware version R104. <p>Applications Handbook</p> <p>Section 1</p> <ul style="list-style-type: none"> ► Updated <i>Circuit Breaker Failure Protection—Example 2</i>.

Table A.5 Instruction Manual Revision History (Sheet 12 of 13)

Revision Date	Summary of Revisions
	<p>Section 2</p> <ul style="list-style-type: none"> ➤ Updated <i>Table 2.15</i>. ➤ Updated <i>Time-Synchronized Metering</i>. <p>Section 3</p> <ul style="list-style-type: none"> ➤ Updated <i>Figure 3.1</i> and related text. <p>Section 4</p> <ul style="list-style-type: none"> ➤ Updated <i>Relay Configuration for High-Accuracy Timekeeping</i>. ➤ Updated <i>State Estimation Verification</i>. <p>Section 5</p> <ul style="list-style-type: none"> ➤ Updated <i>Table 6.7</i>. <p>Reference Manual</p> <p>Section 1</p> <ul style="list-style-type: none"> ➤ Updated <i>Current and Voltage Source Selection</i>, including new <i>Figure 1.1</i> through <i>Figure 1.4</i>, and new <i>Table 1.1</i> through <i>Table 1.3</i>. ➤ Updated <i>Frequency Estimation</i>, and added rate-of-change-of-frequency, DFDT, to <i>Table 1.13</i> and <i>Figure 1.12</i>. ➤ Added <i>Time-Error Calculation</i>. ➤ Updated <i>Circuit Breaker Failure Initiation Dropout and Seal-In</i>. <p>Section 2</p> <ul style="list-style-type: none"> ➤ Corrected error in <i>Figure 2.14</i>. <p>Section 3</p> <ul style="list-style-type: none"> ➤ Added <i>Multiple Setting Groups</i> to describe this feature already in the SEL-451. <p>Section 4</p> <ul style="list-style-type: none"> ➤ Updated <i>Table 4.1</i> and <i>Figure 4.2</i>. <p>Section 5</p> <ul style="list-style-type: none"> ➤ Updated <i>Table 5.2</i>. ➤ Added <i>Automatic Messages</i> and <i>Timeout</i> to describe these features already in the SEL-451. ➤ Removed Fast Message Synchrophasor information—now covered in <i>Section 7</i>. <p>Section 6</p> <ul style="list-style-type: none"> ➤ Updated <i>Table 6.10</i> to include analog quantity information, and the new TECORR value (Object 40, 41; Index 1). ➤ Updated <i>DNP3 (Serial) Application Example</i> to show DNP Map settings entry, including custom scaling. <p>Section 7</p> <ul style="list-style-type: none"> ➤ Added new <i>Section 7: Synchrophasors</i>. Includes information on both IEEE C37.118 and SEL Fast Message synchrophasor protocols. <p>Section 9</p> <ul style="list-style-type: none"> ➤ Updated MET PM command description. ➤ Added SER CV, SER RV, and TEC commands. <p>Section 10</p> <ul style="list-style-type: none"> ➤ Removed Global settings for Time and Date Management. ➤ Added Global settings for INT4 I/O Interface Board (<i>Table 10.6</i>, <i>Table 10.9</i> and <i>Table 10.11</i>), Time-Error Calculation (<i>Table 10.13</i>), and Synchrophasors (<i>Table 10.4</i> and <i>Table 10.15</i>). ➤ Added PMU protocol option to Port settings (<i>Table 10.91</i>). ➤ Removed Port settings PMADDR and PMDATA. <p>Appendix A</p> <ul style="list-style-type: none"> ➤ Updated tables with new Relay Word bits, and new row numbers for Relay Word bits above row 100. ➤ Removed unused Relay Word bits B1PDAL, B1PSAL, B2PDAL, B2PSAL, RT3P1, RT3P2.

Table A.5 Instruction Manual Revision History (Sheet 13 of 13)

Revision Date	Summary of Revisions
	Appendix B <ul style="list-style-type: none"> ➤ Added instantaneous current and voltage angle quantities $I\phi WA$, $I\phi XA$, $V\phi YA$, $V\phi ZA$ ($\phi = A$, B, or C) ➤ Added new analog quantities DFDT, TUTC, TQUAL, TECORR, TE, CTRW, CTRX, PTRY, PTRZ, and 66 synchrophasor measurement quantities.
20041201	User's Guide Section 1 <ul style="list-style-type: none"> ➤ Updated <i>Metering Accuracy Currents and Voltages</i> specifications. Appendix A <ul style="list-style-type: none"> ➤ Updated for firmware version R103.
20040603	<ul style="list-style-type: none"> ➤ Initial version.

This page intentionally left blank

Glossary

“a” Contact	A breaker auxiliary contact (ANSI Standard Device Number 52A) that closes when the breaker is closed and opens when the breaker is open.
“a” Output	A relay control output that closes when the output relay asserts.
“b” Contact	A breaker auxiliary contact (ANSI Standard Device Number 52B) that opens when the breaker is closed and closes when the breaker is open.
“b” Output	A relay control output that opens when the output relay asserts.
“c” Contact	A breaker auxiliary contact that can be set to serve either as an “a” contact or as a “b” contact.
“c” Output	An output with both an “a” output and “b” output sharing a common post.
3U, 4U, 5U	The designation of the vertical height of a device in rack units. One rack unit, U, is approximately 1.75 inches or 44.45 mm.
A	Abbreviation for amps or amperes; unit of electrical current flow.
ABS Operator	An operator in math SELOGIC® control equations that provides absolute value.
AC Ripple	The peak-to-peak ac component of a signal or waveform. In the station dc battery system, monitoring ac ripple provides an indication of whether the substation battery charger has failed.
Acceptance Testing	Testing that confirms that the relay meets published critical performance specifications and requirements of the intended application. Such testing involves testing protection elements and logic functions when qualifying a relay model for use on the utility system.
Access Level	A relay command level with a specified set of relay information and commands. Except for Access Level 0, you must have the correct password to enter an access level.
Access Level 0	The least secure and most limited access level. No password protects this level. From this level, you must enter a password to go to a higher level.
Access Level 1	A relay command level you use to monitor (view) relay information. The default access level for the relay front panel.
Access Level 2	The most secure access level where you have total relay functionality and control of all settings types.
Access Level A	A relay command level you use to access all Access Level 1 and Access Level B (Breaker) functions plus Automation, Alias, Global, Front Panel, Report, Port, and DNP settings.

Access Level B	A relay command level you use for Access Level 1 functions plus circuit breaker control and data.
Access Level O	A relay command level you use to access all Access Level 1 and Access Level B (Breaker) functions plus Output, Alias, Global, Front Panel, Report, Port, and DNP settings.
Access Level P	A relay command level you use to access all Access Level 1 and Access Level B (Breaker) functions plus Protection, SELOGIC, Alias, Global, Group, Breaker Monitor, Front Panel, Report, Port, and DNP settings.
ACSELERATOR Architect® SEL-5032 Software	ACSELERATOR Architect is an add-on to the ACSELERATOR Suite that utilizes the IEC 61850 Substation Configuration Language to configure SEL IEDs.
ACSELERATOR QuickSet® SEL-5030 Software	A Windows®-based program that simplifies settings and provides analysis support.
ACSI	Abstract Communications Service Interface for the IEC 61850 protocol. Defines a set of objects, a set of services to manipulate and access those objects, and a base set of data types for describing objects.
Active Settings Group	The settings group that the SEL-451 is presently using from among six settings groups available in the relay.
Admittance	The reciprocal of impedance; I/V.
Advanced Settings	Settings for customizing protection functions; these settings are hidden unless you set EADVS := Y and EGADVS := Y.
Analog Quantities	Variables represented by such fluctuating measurable quantities as temperature, frequency, current, and voltage.
AND Operator	Logical AND. An operator in Boolean SELOGIC control equations that requires fulfillment of conditions on both sides of the operator before the equation is true.
ANSI Standard Device Numbers	A list of standard numbers used to represent electrical protection and control relays. The standard device numbers used in this instruction manual include the following:
	<ul style="list-style-type: none"> 21 Distance element 25 Synchronism-check element 27 Undervoltage Element 32 Directional Elements 50 Overcurrent Element 51 Inverse-Time Overcurrent Element 52 AC Circuit Breaker 59 Overvoltage Element 67 Definite Time Overcurrent 79 Recloser 86 Breaker Failure Lockout 89 Disconnect

These numbers are frequently used within a suffix letter to further designate their application. The suffix letters used in this instruction manual include the following:

- P Phase Element
- G Residual/Ground Element
- N Neutral/Ground Element
- Q Negative-Sequence (3I2) Element

Anti-Aliasing Filter

A low pass filter that blocks frequencies too high for the given sampling rate to accurately reproduce.

Apparent Power, S

Complex power expressed in units of volt-amps (VA), kilovolt-amps (kVA), or megavolt-amps (MVA). Accounts for both real (P) and reactive (Q) power dissipated in a circuit: $S = P + jQ$. This is power at the fundamental frequency only; no harmonics are included in this quantity.

Arcing Resistance

The resistance in the arc resulting from a power line fault.

ASCII

Abbreviation for American Standard Code for Information Interchange. Defines a standard set of text characters. The SEL-451 uses ASCII text characters to communicate using front-panel and rear-panel EIA-232 serial ports on the relay and through virtual serial ports.

ASCII Terminal

A terminal without built-in logic or local processing capability that can only send and receive information.

Assert

To activate. To fulfill the logic or electrical requirements needed to operate a device. To set a logic condition to the true state (logical 1) of that condition. To apply a closed contact to an SEL-451 input. To close a normally open output contact. To open a normally closed output contact.

**AT Modem Command Set
Dialing String Standard**

The command language standard that Hayes Microcomputer Products, Inc. developed to control auto-dial modems from an ASCII terminal (usually EIA-232 connected) or a PC (personal computer) containing software allowing emulation of such a terminal.

Autoconfiguration

The ability to determine relay type, model number, metering capability, port ID, baud rate, passwords, relay elements, and other information that an IED (an SEL communications processor) needs to automatically communicate with relays.

Automatic Messages

Messages including status failure and status warning messages that the relay generates at the serial ports and displays automatically on the front-panel LCD.

Automatic Reclose

Automatic closing of a circuit breaker after a breaker trip by a protective relay.

Automation Variables

Variables that you include in automation SELOGIC control equations.

**Auto-Reclose-
Drive-to-Lockout**

A logical condition that drives the auto-reclose function out of service with respect to a specific circuit breaker.

Autotransformer

A transformer with at least two common windings.

AX-S4 MMS

“Access for MMS” is an IEC 61850, UCA2, and MMS client application produced by SISCO, Inc., for real-time data integration in Microsoft Windows-based systems supporting OPC and DDE. Included with AX-S4

	MMS is the interactive MMS Object Explorer for browser-like access to IEC 61850 / UCA2 and MMS device objects.
Bandpass Filter	A filter that passes frequencies within a certain range and blocks all frequencies outside this range.
Best Choice Ground Directional Supervision™ logic	An SEL logic that determines the directional element that the relay uses for ground faults.
Bit Label	The identifier for a particular bit.
Bit Value	Logical 0 or logical 1.
Block Trip Extension	Continuing the blocking signal at the receiving relay by delaying the dropout of Relay Word bit BT.
Blocking Signal Extension	The blocking signal for the DCB (directional comparison blocking) trip scheme is extended by a time delay on dropout timer to prevent unwanted tripping following current reversals.
Bolted Fault	A fault with essentially zero impedance or resistance between the shorted conductors.
Boolean Logic Statements	Statements consisting of variables that behave according to Boolean logic operators such as AND, NOT, and OR.
Breaker Auxiliary Contact	An electrical contact associated with a circuit breaker that opens or closes to indicate the breaker position. A form-a breaker auxiliary contact (ANSI Standard Device Number 52A) closes when the breaker is closed and opens when the breaker is open. A form-b breaker auxiliary contact (ANSI Standard Device Number 52B) opens when the breaker is closed and closes when the breaker is open.
Breaker-and-a-half Configuration	A switching station arrangement of three circuit breakers per two circuits; the two circuits share one of the circuit breakers.
Buffered Report	IEC 61850 IEDs can issue buffered reports of internal events (caused by trigger options data-change, quality-change, and data-update). These event reports can be sent immediately or buffered (to some practical limit) for transmission, such that values of data are not lost due to transport flow control constraints or loss of connection. Buffered reporting provides sequence-of-events (SOE) functionality.
C37.118	C37.118 IEEE Standard for Synchrophasors for Power Systems
Category	A collection of similar relay settings.
CCVT	Coupling-capacitor voltage transformer that uses a capacitive voltage divider to reduce transmission voltage to a level safe for metering and relaying devices. See CVT.
Checksum	A method for checking the accuracy of data transmission involving summation of a group of digits and comparison of this sum to a previously calculated value.
CID	Checksum identification of the firmware.

CID File	IEC 61850 Configured IED Description file. XML file that contains the configuration for a specific IED.
Circuit Breaker Failure Logic	This logic within the SEL-451 detects and warns of failure or incomplete operation of a circuit breaker in clearing a fault or in performing a trip or close sequence.
Circuit Breaker History Report	A concise circuit breaker event history that contains as many as 128 events. This breaker history report includes circuit breaker mechanical operation times, electrical operation times, interrupted currents, and dc battery monitor voltages.
Circuit Breaker Report	A full report of breaker parameters for the most recent operation. These parameters include interrupted currents, number of operations, and mechanical and electrical operating times among many parameters.
Class	The first level of the relay settings structure including Global, Group, Breaker Monitor, Port, Report, Front Panel, DNP settings, Protection SELOGIC control equations, Automation SELOGIC control equations, and Output SELOGIC control equations.
Cold Start	Beginning a system from power up without carryover of previous system activities.
Commissioning Testing	Testing that serves to validate all system ac and dc connections and confirm that the relay, auxiliary equipment, and SCADA interface all function as intended with your settings. Perform such testing when installing a new protection system.
Common Data Class	IEC 61850 grouping of data objects that model substation functions. Common Data Classes include Status information, Measured information, Controllable status, Controllable analog, Status settings, Analog settings, and Description information.
Common Inputs	Relay control inputs that share a common terminal.
Common Time Delay	Both ground and phase distance protection follow a common time delay on pickup.
Common Zone Timing	Both ground and phase distance protection follow a common time delay on pickup.
Communications Protocol	A language for communication between devices.
Communications-Assisted Tripping	Circuit breaker tripping resulting from the transmission of a control signal over a communications medium.
Comparison	Boolean SELOGIC control equation operation that compares two numerical values. Compares floating-point values such as currents, total counts, and other measured and calculated quantities.
COMTRADE	Abbreviation for Common Format for Transient Data Exchange. The SEL-451 supports the IEEE Standard Common Format for Transient Data Exchange (COMTRADE) for Power Systems, IEEE C37.111–1999.
Conditioning Timers	Timers for conditioning Boolean values. Conditioning timers either stretch incoming pulses or allow you to require that an input take a state for a certain period before reacting to the new state.

Contact Input	See Control input.
Contact Output	See Control output.
Coordination Timer	A timer that delays an overreaching element so that a downstream device has time to operate.
Control Input	Relay inputs for monitoring the state of external circuits. Connect auxiliary relay and circuit breaker contacts to the control inputs.
Control Output	Relay outputs that affect the state of other equipment. Connect control outputs to circuit breaker trip and close coils, breaker failure auxiliary relays, communications-assisted tripping circuits, and SCADA systems.
COS Operator	Operator in math SELOGIC control equations that provides the cosine function.
Counter	Variable or device such as a register or storage location that either records or represents the number of times an event occurs.
Cross-country fault	A cross-country fault consists of simultaneous separate single phase-to-ground faults on parallel lines.
CT	Current transformer.
CT Subsidence Current	Subsidence current appears as a small exponentially decaying dc current with a long time constant. This current results from the energy trapped in the CT magnetizing branch after the circuit breaker opens to clear a fault or interrupt load.
CTR	Current transformer ratio.
Current Reversal Guard Logic	Under this logic, the relay does not key the transmitter and ignores reception of a permissive signal from the remote terminal when a reverse-looking element detects an external fault.
Current Transformer Saturation	The point of maximum current input to a current transformer; any change of input beyond the saturation point fails to produce any appreciable change in output.
CVT	Capacitive voltage transformer that uses a capacitive voltage divider to reduce transmission voltage to a level safe for metering and relaying devices. See CCVT.
Data Attribute	In the IEC 61850 protocol, the name, format, range of possible values, and representation of values being communicated.
Data Bit	A single unit of information that can assume a value of either logical 0 or logical 1 and can convey control, address, information, or frame check sequence data.
Data Class	In the IEC 61850 protocol, an aggregation of classes or data attributes.
Data Label	The identifier for a particular data item.
Data Object	In the IEC 61850 protocol, part of a logical node representing specific information (status or measurement, for example). From an object-oriented point of view, a data object is an instance of a data class.

DC Offset	A dc component of fault current that results from the physical phenomenon preventing an instantaneous change of current in an inductive circuit.
DCB (Directional Comparison Blocking)	A communications-assisted protection scheme. A fault occurring behind a sending relay causes the sending relay to transmit a blocking signal to a remote relay; the blocking signal interrupts the tripping circuit of the remote relay and prevents tripping of the protected line.
DCE Devices	Data communication equipment devices (modems).
DCUB (Directional Comparison Unblocking)	A communications-assisted tripping scheme with logic added to a POTT scheme that allows high-speed tripping of overreaching elements for a brief time during a loss of channel. The logic then blocks trip permission until the communications channel guard returns for a set time.
Deadband	The range of variation an analog quantity can traverse before causing a response.
Deassert	To deactivate. To remove the logic or electrical requirements needed to operate a device. To clear a logic condition to its false state (logical 0). To open the circuit or open the contacts across an SEL-451 input. To open a normally open output contact. To close a normally closed output contact.
Debounce Time	The time that masks the period when relay contacts continue to move after closing; debounce time covers this indeterminate state.
Default Data Map	The default map of objects and indices that the SEL-451 uses in DNP protocol.
Delta	A phase-to-phase series connection of circuit elements, particularly voltage transformers or loads.
Demand Meter	A measuring function that calculates a rolling average or thermal average of instantaneous measurements over time.
Direct Tripping	Local or remote protection elements provide tripping without any additional supervision.
Directional Start	A blocking signal provided by reverse reaching elements to a remote terminal used in DCB communications-assisted tripping schemes. If the fault is internal (on the protected line), the directional start elements do not see the fault and do not send a blocking signal. If the fault is external (not on the protected line), the directional start elements start sending the block signal.
Directional Supervision	The relay uses directional elements to determine whether protective elements operate based on the direction of a fault relative to the relay.
Disabling Time Delay	A DCUB scheme timer (UBDURD) that prevents high-speed tripping following a loss-of-channel condition.
DMTC Period	The time of the demand meter time constant in demand metering.
DNP (Distributed Network Protocol)	Manufacturer-developed, hardware-independent communications protocol.
Dropout Time	The time measured from the removal of an input signal until the output signal deasserts. You can set the time, in the case of a logic variable timer, or the

dropout time can be a result of the characteristics of an element algorithm, as in the case of an overcurrent element dropout time.

DTE Devices

Data terminal equipment (computers, terminals, printers, relays, etc.).

DTT (Direct Transfer Trip)

A communications-assisted tripping scheme. A relay at one end of a line sends a tripping signal to the relay at the opposite end of the line.

Dumb Terminal

See ASCII terminal.

DUTT (Direct Underreaching Transfer Trip)

A communications-assisted tripping scheme. Detection of a Zone 1 fault at either end of a line causes tripping of the local circuit breaker as well as simultaneous transmission of a tripping signal to the relay at the opposite end of the line. The scheme is said to be underreaching because the Zone 1 relays at both ends of the line reach only 80 percent (typically) of the entire line length.

Echo

The action of a local relay returning (echoing) the remote terminal permissive signal to the remote terminal when the local breaker is open or a weak infeed condition exists.

Echo Block Time Delay

A time delay that blocks the echo logic after dropout of local permissive elements.

Echo Duration Time Delay

A time delay that limits the duration of the echoed permissive signal.

ECTT (Echo Conversion to Trip)

An element that allows a weak terminal, after satisfaction of specific conditions, to trip by converting an echoed permissive signal to a trip signal.

EEPROM

Electrically Erasable Programmable Read-Only Memory. Nonvolatile memory where relay settings, event reports, SER records, and other nonvolatile data are stored.

EHV

Extra high voltage. Voltages greater than 230 kV.

EIA-232

Electrical definition for point-to-point serial data communications interfaces, based on the standard EIA/TIA-232. Formerly known as RS-232.

EIA-485

Electrical standard for multidrop serial data communications interfaces, based on the standard EIA/TIA-485. Formerly known as RS-485.

Electrical Operating Time

Time between trip or close initiation and an open phase status change.

Electromechanical Reset

Setting of the relay to match the reset characteristics of an electromechanical overcurrent relay.

End-Zone Fault

A fault at the farthest end of a zone that a relay is required to protect.

Energy Metering

Energy metering provides a look at imported power, exported power, and net usage over time; measured in MWh (megawatt hours).

Equalize Mode

A procedure where substation batteries are overcharged intentionally for a preselected time in order to bring all cells to a uniform output.

ESD (Electrostatic Discharge)

The sudden transfer of charge between objects at different potentials caused by direct contact or induced by an electrostatic field.

Ethernet	A network physical and data link layer defined by IEEE 802.2 and IEEE 802.3.
Event History	A quick look at recent relay activity that includes a standard report header; event number, date, time, and type; fault location; maximum fault phase current; active group at the trigger instant; and targets.
Event Report	A text-based collection of data stored by the relay in response to a triggering condition, such as a fault or ASCII TRI command. The data show relay measurements before and after the trigger, in addition to the states of protection elements, relay inputs, and relay outputs each processing interval. After an electrical system fault, use event reports to analyze relay and system performance.
Event Summary	A shortened version of stored event reports. An event summary includes items such as event date and time, event type, fault location, time source, recloser shot counter, prefault and fault voltages, currents, and sequence current, and MIRRORED BITS communications channel status (if enabled). The relay sends an event report summary (if auto messaging is enabled) to the relay serial port a few seconds after an event.
EXP Operator	Math SELOGIC control equation operator that provides exponentiation.
F_TRIGGER	Falling-edge trigger. Boolean SELOGIC control equation operator that triggers an operation upon logic detection of a falling edge.
Fail-Safe	Refers to an output that is open during normal relay operation and closed when relay power is removed or if the relay fails. Configure alarm outputs for fail-safe operation.
Falling Edge	Transition from logical 1 to logical 0.
Fast Hybrid Control Output	A control output similar to, but faster than, the hybrid control output. The fast hybrid output uses an insulated gate bipolar junction transistor (IGBT) to interrupt (break) high inductive dc currents and to very rapidly make and hold the current until a metallic contact operates, at which time the IGBT turns off and the metallic contact holds the current. Unlike the hybrid control output, this output is not polarity sensitive; reversed polarity causes no misoperations.
Fast Meter	SEL binary serial port command used to collect metering data with SEL relays.
Fast Operate	SEL binary serial port command used to perform control with SEL relays.
Fast Message	SEL binary serial port protocol used for Fast SER, Fast Message Synchrophasors, and RTD communications.
Fault Type Identification Selection	Logic the relay uses to identify balanced and unbalanced faults (FIDS).
FID	Relay firmware identification string. Lists the relay model, firmware version and date code, and other information that uniquely identifies the firmware installed in a particular relay.
Firmware	The nonvolatile program stored in the relay that defines relay operation.
Flash Memory	A type of nonvolatile relay memory used for storing large blocks of nonvolatile data.

Flashover	A disruptive discharge over the surface of a solid dielectric in a gas or liquid.
Float High	The highest charging voltage supplied by a battery charger.
Float Low	The lowest charging voltage supplied by a battery charger.
Free-Form Logic	Custom logic creation and execution order.
Free-Form SELOGIC Control Equations	Free-form relay programming that includes mathematical operations, custom logic execution order, extended relay customization, and automated operation.
FTP	File transfer protocol.
Function	In IEC 61850, task(s) performed by the substation automation system, i.e., by application functions. Generally, functions exchange data with other functions. Details are dependent on the functions involved. Functions are performed by IEDs (physical devices). A function may be split into parts residing in different IEDs but communicating with each other (distributed function) and with parts of other functions. These communicating parts are called logical nodes.
Function Code	A code that defines how you manipulate an object in DNP3 protocol.
Functional Component	Logical Node dedicated to a particular function including status, control, and descriptive tags.
Fundamental Frequency	The component of the measured electrical signal with a frequency equal to the normal electrical system frequency, usually 50 Hz or 60 Hz. Generally used to differentiate between the normal system frequency and any harmonic frequencies present.
Global Settings	General settings including those for relay and station identifiers, number of breakers, date format, phase rotation, nominal system frequency, enables, station dc monitoring, control inputs, settings group selection, data reset controls, frequency tracking, time and date management, and current and voltage source selection.
GOMSFE	Generic Object Model for Substation and Feeder Equipment; a system for presenting and exchanging IED data.
GOOSE	IEC 61850 Generic Object Oriented Substation Event. GOOSE objects can quickly and conveniently transfer status, controls, and measured values among peers on an IEC 61850 network.
GPS	Global Positioning System. Source of position and high-accuracy time information.
Ground Directional Element Priority	The order the relay uses to select directional elements to provide ground directional decisions; relay setting ORDER.
Ground Distance Element	A mho or quadrilateral distance element the relay uses to detect faults involving ground along a transmission line.
Ground Fault Loop Impedance	The impedance in a fault-caused electric circuit connecting two or more points through ground conduction paths.
Ground Overcurrent Elements	Elements that operate by comparing a residual ground calculation of the three-phase inputs with the residual overcurrent threshold setting. The relay asserts

Ground Return Resistance	ground overcurrent elements when a relay residual current calculation exceeds ground current setting thresholds.
Guard-Present Delay	Fault resistance that can consist of ground path resistance typically in tower footing resistance and tree resistance.
GUI	A timer that determines the minimum time before the relay reinstates permissive tripping following a loss-of-channel condition in the DCUB communications-assisted tripping scheme; relay setting GARD1D.
Hexadecimal Address	Graphical user interface.
High-Resolution Data Capture	A register address consisting of a numeral with an “h” suffix or a “0x” prefix.
HMI	Reporting of 3 kHz low-pass analog filtered data from the power system at each event trigger or trip at high sample rates of 8000 samples/second, 4000 samples/second, 2000 samples/second, and 1000 samples/second.
Homogeneous System	Human machine interface.
HV	A power system with nearly the same angle (<5 ° difference) for the impedance angles of the local source, the protected line, and the remote source.
Hybrid Control Output	High voltage. System voltage greater than or equal to 100 kV and less than 230 kV.
IA, IB, IC	Contacts that use an insulated gate bipolar junction transistor (IGBT) in parallel with a mechanical contact to interrupt (break) high inductive dc currents. The contacts can carry continuous current, while eliminating the need for heat sinking and providing security against voltage transients. These contacts are polarity dependent and cannot be used to switch ac control signals.
ICD File	Measured A-phase, B-phase, and C-phase currents.
IEC 61850	IEC 61850 IED Capability Description file. XML file that describes IED capabilities, including information on logical node and GOOSE support.
IED	Internationally standardized method of communications and integration conceived with the goal of supporting systems of multivendor IEDs networked together to perform protection, monitoring, automation, metering, and control.
IEEE	Intelligent electronic device.
IG	Institute of Electrical and Electronics Engineers, Inc.
IGBT	Residual current, calculated from the sum of the phase currents. In normal, balanced operation, this current is very small or zero.
Infinite Bus	Insulated gate bipolar junction transistor.
Input Conditioning	A constant-voltage bus.
	The establishment of debounce time and assertion level.

Instance	A subdivision of a relay settings class. Group settings have several subdivisions (Group 1–Group 6), while the Global settings class has one instance.
Instantaneous Meter	Type of meter data presented by the SEL-451 that includes the present values measured at the relay ac inputs. The word “Instantaneous” is used to differentiate these values from the measurements presented by the demand, thermal, energy, and other meter types.
IP Address	An identifier for a computer or device on a TCP/IP network. Networks using the TCP/IP protocol route messages based on the IP address of the destination. The format of an IP address is a 32-bit numeric address written as four numbers separated by periods. Each number can be zero to 255. For example, 1.160.10.240 could be an IP address.
IRIG-B	A time code input that the relay can use to set the internal relay clock.
Jitter	Time, amplitude, frequency, or phase-related abrupt, spurious variations in duration, magnitude, or frequency.
L/R	Circuit inductive/resistive ratio.
Latch Bits	Nonvolatile storage locations for binary information.
LED	Light-emitting diode. Used as indicators on the relay front panel.
Left-Side Value	LVALUE. Result storage location of a SELOGIC control equation.
Line Impedance	The phasor sum of resistance and reactance in the form of positive-sequence, negative-sequence, and zero-sequence impedances of the protected line.
LMD	SEL distributed port switch protocol.
LN Operator	Math SELOGIC control equation operator that provides natural logarithm.
Load Encroachment	The load-encroachment feature allows setting of phase overcurrent elements independent of load levels.
Local Bits	The Relay Word bit outputs of local control switches that you access through the SEL-451 front panel. Local control switches replace traditional panel-mounted control switches.
Lockout Relay	An auxiliary relay that prevents operation of associated devices until it is reset either electrically or by hand.
Logical 0	A false logic condition, dropped out element, or deasserted control input or control output.
Logical 1	A true logic condition, picked up element, or asserted control input or control output.
Logical Node	In IEC 61850, the smallest part of a function that exchanges data. A logical node (LN) is an object defined by its data and methods. Each logical node represents a group of data (controls, status, measurements, etc.) associated with a particular function.

Loss of Channel	Loss of guard and no permissive signal from communications gear in a DCUB (directional comparison unblocking scheme) for either two or three terminal lines.
Loss of Guard	No guard signal from communications gear.
Loss of Potential	Loss of one or more phase voltage inputs to the relay secondary inputs.
Low-Level Test Interface	An interface that provides a means for interrupting the connection between the relay input transformers and the input processing module and allows inserting reduced-scale test quantities for relay testing.
MAC Address	The Media Access Control (hardware) address of a device connected to a shared network medium, most often used with Ethernet networks.
Maintenance Testing	Testing that confirms that the relay is measuring ac quantities accurately and verifies correct functioning of auxiliary equipment, scheme logic, and protection elements.
Math Operations	Calculations for automation or extended protection functions.
Math Operators	Operators that you use in the construction of math SELOGIC control equations to manipulate numerical values and provide a numerical base-10 result.
Maximum Dropout Time	The maximum time interval following a change of input conditions between the deassertion of the input and the deassertion of the output.
Maximum/Minimum Meter	Type of meter data presented by the SEL-451 that includes a record of the maximum and minimum of each value, along with the date and time that each maximum and minimum occurred.
Mechanical Operating Time	Time between trip initiation or close initiation and the change in status of an associated circuit breaker auxiliary 52A normally open contacts.
MIRRORED BITS® Communications	Patented relay-to-relay communications technique that sends internal logic status, encoded in a digital message, from one relay to the other. Eliminates the need for some communications hardware.
MMS	Manufacturing Messaging Specification, a data exchange protocol used by IEC 61850.
MOD	Motor-operated disconnect.
Model	Model of device (or component of a device) including the data, control access, and other features in UCA protocol.
Motor Running Time	The circuit breaker motor running time. Depending on your particular circuit breaker, you can use the motor running time to monitor the charge time of the circuit breaker springs or the running time of the compressor motor.
MOV	Metal-oxide varistor.
Negation Operator	A SELOGIC control equation math operator that changes the sign of the argument. The argument of the negation operation is multiplied by -1.
Negative-Sequence	A configuration of three-phase currents and voltages. The currents and voltages have equal magnitude and a phase displacement of 120°, and have clockwise phase rotation with current and voltage maxima that occur

	differently from that for positive-sequence configuration. If positive-sequence maxima occur as ABC, negative-sequence maxima occur as ACB.
Negative-Sequence Current Supervision Pickup	An element allowed to operate only when a negative-sequence current exceeds a threshold.
Negative-Sequence Directional Element	An element that provides directivity by the sign, plus or minus, of the measured negative-sequence impedance.
Negative-Sequence Impedance	Impedance of a device or circuit that results in current flow with a balanced negative-sequence set of voltage sources.
Negative-Sequence Overcurrent Elements	Elements that operate by comparing a negative-sequence calculation of the three-phase secondary inputs with negative-sequence overcurrent setting thresholds. The relay asserts these elements when a relay negative-sequence calculation exceeds negative-sequence current setting thresholds.
Negative-Sequence Voltage-Polarized Directional Element	These directional elements are 32QG and 32Q. 32QG supervises the ground distance elements and residual directional overcurrent elements; 32Q supervises the phase distance elements.
NEMA	National Electrical Manufacturers' Association.
Neutral Impedance	An impedance from neutral to ground on a device such as a generator or transformer.
No Current/Residual Current Circuit Breaker Failure Protection Logic	Logic for detecting and initiating circuit breaker failure protection with a logic transition, or when a weak source drives the fault or a high-resistance ground fault occurs.
Nondirectional Start	A blocking signal provided by nondirectional overcurrent elements to a remote terminal used in DCB communications-assisted tripping schemes. The nondirectional start elements start sending the block signal.
Nonhomogeneous System	A power system with a large angle difference ($>5^\circ$ difference) for the impedance angles of the local source, the protected line, and the remote source.
Nonvolatile Memory	Relay memory that persists over time to maintain the contained data even when the relay is deenergized.
NOT Operator	A logical operator that produces the inverse value.
OR Operator	Logical OR. A Boolean SELOGIC control equation operator that compares two Boolean values and yields either a logical 1 if either compared Boolean value is logical 1 or a logical 0 if both compared Boolean values are logical 0.
OSI	Open Systems Interconnect. A model for describing communications protocols. Also an ISO suite of protocols designed to this model.
Override Values	Test values you enter in Fast Meter, DNP, and communications card database storage.
Parentheses Operator	Math operator. Use paired parentheses to control the execution of operations in a SELOGIC control equation.
PC	Personal computer.

Peak Demand Metering	Maximum demand and a time stamp for phase currents, negative-sequence and zero-sequence currents, and powers. The SEL-451 stores peak demand values and the date and time these occurred to nonvolatile storage once per day, overwriting the previously stored value if the new value is larger. Should the relay lose control power, the relay restores the peak demand information saved at 23:50 hours on the previous day.
Phase Overcurrent Element	Elements that operate by comparing the phase current applied to the secondary current inputs with the phase overcurrent setting. The relay asserts these elements when any combination of the phase currents exceeds phase current setting thresholds.
Phase Rotation	The sequence of voltage or current phasors in a multiphase electrical system. In an ABC phase rotation system, the B-phase voltage lags the A-phase voltage by 120°, and the C-phase voltage lags B-phase voltage by 120°. In an ACB phase rotation system, the C-phase voltage lags the A-phase voltage by 120°, and the B-phase voltage lags the C-phase voltage by 120°.
Phase Selection	Ability of the relay to determine the faulted phase or phases.
Pickup Time	The time measured from the application of an input signal until the output signal asserts. You can set the time, as in the case of a logic variable timer, or the pickup time can be a result of the characteristics of an element algorithm, as in the case of an overcurrent element pickup time.
Pinout	The definition or assignment of each electrical connection at an interface. Typically refers to a cable, connector, or jumper.
Polarizing Memory	A circuit that provides a polarizing source for a period after the polarizing quantity has changed or gone to zero.
Pole-Open Logic	Logic that determines the conditions that the relay uses to indicate an open circuit breaker pole.
Port Settings	Communications port settings such as Data Bits, Speed, and Stop Bits.
Positive-Sequence	A configuration of three-phase currents and voltages. The currents and voltages have equal magnitude and a phase displacement of 120°. With conventional rotation in the counter-clockwise direction, the positive-sequence current and voltage maxima occur in ABC order.
Positive-Sequence Current Restraint Factor, a2	This factor compensates for highly unbalanced systems with many untransposed lines and helps prevent misoperation during current transformer saturation. The a2 factor is the ratio of the magnitude of negative-sequence current to the magnitude of positive-sequence current (I_2/I_1).
Positive-Sequence Current Supervision Pickup	An element that operates only when a positive-sequence current exceeds a threshold.
Positive-Sequence Impedance	Impedance of a device or circuit that results in current flow with a balanced positive-sequence set of voltage sources.
POTT (Permissive Overreaching Transfer Trip)	A communications-assisted line protection scheme. At least two overreaching protective relays must receive a permissive signal from the other terminal(s) before all relays trip and isolate the protected line.

Power Factor	The cosine of the angle by which phase current lags or leads phase voltage in an ac electrical circuit. Power factor equals 1.0 for power flowing to a pure resistive load.
PPS	Pulse per second from a GPS receiver. Previous SEL-451 relays had a TIME 1k PPS input.
Protection and Automation Separation	Segregation of protection and automation processing and settings.
Protection Settings Group	Individual scheme settings for as many as six different schemes (or instances).
Protection-Disabled State	Suspension of relay protection element and trip/close logic processing and deenergization of all control outputs.
PT	Potential transformer. Also referred to as a voltage transformer or VT.
PTR	Potential transformer ratio.
Qualifier Code	Specifies type of range for DNP3 objects. With the help of qualifier codes, DNP master devices can compose the shortest, most concise messages.
R_TRIGGER	Rising-edge trigger. Boolean SELOGIC control equation operator that triggers an operation upon logic detection of a rising edge.
RAM	Random Access Memory. Volatile memory where the relay stores intermediate calculation results, Relay Word bits, and other data.
Real Power	Power that produces actual work. The portion of apparent power that is real, not imaginary.
Reclose	The act of automatically closing breaker contacts after a protective relay trip has opened the circuit breaker contacts and interrupted current through the breaker.
Relay Word Bit	A single relay element or logic result. A Relay Word bit can equal either logical 1 or logical 0. Logical 1 represents a true logic condition, picked up element, or asserted control input or control output. Logical 0 represents a false logic condition, dropped out element, or deasserted control input or control output. Use Relay Word bits in SELOGIC control equations.
Remapping	The process of selecting data from the default map and configuring new indices to form a smaller data set optimized to your application.
Remote Bit	A Relay Word bit with a state that is controlled by serial port commands, including the CONTROL command, a binary Fast Operate command, DNP binary output operation, or an IEC 61850 control operation.
Report Settings	Event report and Sequential Events Recorder settings.
Residual Current	The sum of the measured phase currents. In normal, balanced operation, this current is very small or zero.
Residual Directional Overcurrent Element	A residual overcurrent element allowed to operate in only the forward or reverse direction.
Residual Overcurrent Protection	Overcurrent protection that operates at conditions exceeding a threshold of system unbalance ($3I_0 = I_A + I_B + I_C$).

Retrip	A subsequent act of attempting to open the contacts of a circuit breaker after the failure of an initial attempt to open these contacts.
Reverse Fault	A fault operation behind a relay terminal.
Rising Edge	Transition from logical 0 to logical 1, or the beginning of an operation.
RMS	Root-mean-square. This is the effective value of the current and voltage measured by the relay, accounting for the fundamental frequency and higher-order harmonics in the signal.
Rolling Demand	A sliding time-window arithmetic average in demand metering.
RTD	Resistance Temperature Detector
RTU	Remote Terminal Unit.
RXD	Received data.
SCADA	Supervisory control and data acquisition.
SCD File	IEC 61850 Substation Configuration Description file. XML file that contains information on all IEDs within a substation, communications configuration data, and a substation description.
SCL	IEC 61850 Substation Configuration Language. An XML-based configuration language that supports the exchange of database configuration data among different software tools that can be from different manufacturers. There are four types of SCL files used within IEC 61850: CID, ICD, SCD, and SSD.
Self-Description	A feature of GOMSFE in the UCA2 protocol. A master device can request a description of all of the GOMSFE models and data within the IED.
Self-Test	A function that verifies the correct operation of a critical device subsystem and indicates detection of an out-of-tolerance condition. The SEL-451 has self-tests that validate the relay power supply, microprocessor, memory, and other critical systems.
SELOGIC Expression Builder	A rules-based editor within the ACCELERATOR QuickSet SEL-5030 Software program for programming SELOGIC control equations.
SELOGIC Math Variables	Math calculation result storage locations.
SELOGIC Control Equation	A relay setting that allows you to control a relay function (such as a control output) using a logical combination of relay element outputs and fixed logic outputs.
Sequencing Timers	Timers designed for sequencing automated operations.
Sequential Events Recorder	A relay function that stores a record of the date and time of each assertion and deassertion of every Relay Word bit in a list that you set in the relay. SER provides a useful way to determine the order and timing of events of a relay operation.
SER	Sequential Events Recorder or the relay serial port command to request a report of the latest 1000 sequential events.

Settle/Settling Time	Time required for an input signal to result in an unvarying output signal within a specified range.
Shot Counter	A counter that records the number of times a recloser attempts to close a circuit breaker.
Shunt Admittance	The admittance resulting from the presence of a device in parallel across other devices or apparatus that diverts some current away from these devices or apparatus.
Shunt Capacitance	The capacitance between a network connection and any existing ground.
Shunt Current	The current that a parallel-connected high-resistance or high-impedance device diverts away from devices or apparatus.
SIN Operator	Operator in math SELOGIC control equations that provides the sine function.
SIR	Source-to-line impedance ratio.
SOTF (Switch-On-to-Fault Protection Logic)	Logic that provides tripping if a circuit breaker closes into a zero voltage bolted fault, such as would happen if protective grounds remained on the line following maintenance.
Source Impedance	The impedance of an energy source at the input terminals of a device or network.
SQRT Operator	Math SELOGIC control equation operator that provides square root.
SSD File	IEC 61850 System Specification Description file. XML file that describes the single-line diagram of the substation and the required logical nodes.
Status Failure	A severe out-of-tolerance internal operating condition. The relay issues a status failure message and enters a protection-disabled state.
Status Warning	Out-of-tolerance internal operating conditions that do not compromise relay protection, yet are beyond expected limits. The relay issues a status warning message and continues to operate.
Strong Password	A mix of valid password characters in a six-character combination that does not spell common words in any portion of the password. Valid password characters are numbers, upper- and lower-case alphabetic characters, “.” (period), and “-” (hyphen).
Subnet Mask	The subnet mask divides the local node IP address into two parts, a network number and a node address on that network. A subnet mask is four bytes of information and is expressed in the same format as an IP address.
Subsidence Current	See CT subsidence current.
Synch Reference	A phasor the relay uses as a polarizing quantity for synchronism check calculations.
Synchronism Check	Verification by the relay that system components operate within a preset frequency difference and within a preset phase angle displacement between voltages.

Synchronized Phasor	A phasor calculated from data samples using an absolute time signal as the reference for the sampling process. The phasors from remote sites have a defined common phase relationship. Also known as Synchrophasor.
Telnet	An Internet protocol for exchanging terminal data that connects a computer to a network server and allows control of that server and communication with other servers on the network.
Terminal Emulation Software	Software that can be used to send and receive ASCII text messages and files via a computer serial port.
Thermal Demand	Thermal demand is a continuous exponentially increasing or decreasing accumulation of metered quantities; used in demand metering.
Thermal Withstand Capability	The capability of equipment to withstand a predetermined temperature value for a specified time.
Three-Phase Fault	A fault involving all three phases of a three-phase power system.
Three-Pole Trip	A circuit breaker operation that occurs when the circuit breaker opens all three poles at the same time.
Time Delay on Pickup	The time interval between initiation of a signal at one point and detection of the same signal at another point.
Time Dial	A control that governs the time scale of the time-overcurrent characteristic of a relay. Use the time-dial setting to vary relay operating time.
Time-Delayed Tripping	Tripping that occurs after expiration of a pre-determined time.
Time Error	A measurement of how much time an ac powered clock would be ahead or behind a reference clock, as determined from system frequency measurements.
Time-Overcurrent Element	An element that operates according to an inverse relationship between input current and time, with higher current causing faster relay operation.
Time Quality	An indication from a GPS clock receiver that specifies the maximum error in the time information. Defined in IEEE C37.118.
Torque Control	A method of using one relay element to supervise the operation of another.
Total Clearing Time	The time interval from the beginning of a fault condition to final interruption of the circuit.
Tower Footing Resistance	The resistance between true ground and the grounding system of a tower.
Transformer Impedance	The resistive and reactive parameters of a transformer looking in to the transformer primary or secondary windings. Use industry accepted open-circuit and short-circuit tests to determine these transformer equivalent circuit parameters.
Tree Resistance	Resistance resulting from a tree in contact with a power line.
TVF	Total Vector Error. A measurement of accuracy for phasor quantities that combines magnitude and angle errors into one quantity. Defined in IEEE C37.118.

TXD	Transmitted data.
Unbalanced Fault	All faults that do not include all three phases of a system.
Unbuffered Report	IEC 61850 IEDs can issue immediate unbuffered reports of internal events (caused by trigger options data-change, quality-change, and data-update) on a “best efforts” basis. If no association exists, or if the transport data flow is not fast enough to support it, events may be lost.
Unconditional Tripping	Protection element tripping that occurs apart from conditions such as those involving communication, switch-onto-fault logic, etc.
Untransposed Line	A transmission line with phase conductors that are not regularly transposed. The result is an imbalance in the mutual impedances between phases.
User ST	Region in GOOSE for user-specified applications.
VA, VB, VC	Measured A-phase-to-neutral, B-phase-to-neutral, and C-phase-to-neutral voltages.
VAB, VBC, VCA	Measured or calculated phase-to-phase voltages.
VG	Residual voltage calculated from the sum of the three phase-to-neutral voltages, if connected.
Virtual Terminal Connection	A mechanism that uses a virtual serial port to provide the equivalent functions of a dedicated serial port and a terminal.
Volatile Storage	A storage device that cannot retain data following removal of relay power.
VT	Voltage transformer. Also referred to as a potential transformer or PT.
Warm Start	The reset of a running system without removing and restoring power.
Weak Infeed Logic	Logic that permits rapid tripping for internal faults when a line terminal has insufficient fault current to operate protective elements.
Wye	A phase-to-neutral connection of circuit elements, particularly voltage transformers or loads. To form a wye connection using transformers, connect the nonpolarity side of each of three voltage transformer secondaries in common (the neutral), and take phase to neutral voltages from each of the remaining three leads. When properly phased, these leads represent the A-phase-, B-phase-, and C-phase-to-neutral voltages. This connection is frequently called ‘four-wire wye,’ alluding to the three phase leads plus the neutral lead.
XML	Extensible Markup Language. This specification developed by the W3C (World Wide Web Consortium) is a pared-down version of SGML designed especially for web documents. It allows designers to create their own customized tags, enabling the definition, transmission, validation, and interpretation of data among applications and organizations.
Zero-Sequence	A configuration of three-phase currents and voltages with currents and voltages that occur simultaneously, are always in phase, and have equal magnitude ($3I_0 = I_A + I_B + I_C$).
Zero-Sequence Impedance	Impedance of a device or circuit resulting in current flow when a single voltage source is applied to all phases.

Zero-Sequence Mutual Coupling

Zero-sequence current in an unbalanced circuit in close proximity to a second circuit induces voltage into the second circuit. When not controlled by protection system design and relay settings, this situation can cause improper operation of relays in both systems.

Zero-Sequence Overcurrent Element

Overcurrent protection that operates at conditions exceeding a threshold of system unbalance.

Zero-Sequence Voltage-Polarized Directional Element

An element that provides directionality by the sign, plus or minus, of the measured zero-sequence impedance.

Z-Number

That portion of the relay FID string that identifies the proper ACSELERATOR QuickSet software relay driver version and HMI driver version when creating or editing relay settings files.

This page intentionally left blank

Index

Page numbers appearing in bold mark the location of the topic's primary discussion.

U=User's Guide; A=Applications Handbook; R=Reference Manual

Symbols

- *¹, largest current [A.3.18](#), [A.3.22](#)
- >, trigger row [A.3.18](#), [A.3.22](#)

A

- METER Command
 - See also Meter
- Acceptance Testing [U.6.1](#)
 - See also Testing
- ACCESS Command [U.4.8](#), [R.9.3](#)
- Access Control
 - for FTP [R.4.9](#)
 - See also TCP/IP
- Access Levels [U.4.6–U.4.9](#), [R.4.11](#)
 - 1, B, P, A, O, 2 levels [U.4.7](#)
 - communications ports [U.4.8](#)
 - front panel [U.4.8](#)
- Accuracy
 - energy metering [A.2.34](#)
 - instantaneous metering [A.2.25](#)
 - maximum/minimum metering [A.2.28](#)
 - synchrophasor (PMU) [U.1.17](#)
- ACSELERATOR QuickSet Software [U.3.1–U.3.22](#)
 - bay control screens [A.5.23–A.5.27](#)
 - communications setup [U.3.4–U.3.6](#)
 - FTP [U.3.4](#)
 - serial [U.3.4](#)
 - Telnet [U.3.5](#)
 - terminal [U.3.5](#)
 - COMTRADE [U.3.16](#), [U.4.49](#)
 - control window [U.3.22](#), [U.4.44–U.4.45](#)
 - database manager [U.3.6–U.3.8](#)
 - device overview screen [U.3.22](#)
 - drivers [U.3.8–U.3.9](#)
 - event reports [U.3.16–U.3.21](#), [U.4.43](#)
 - event phasor display [U.3.19](#), [U.4.41](#)
 - event settings screen [U.3.21](#)
 - expression builder [U.3.15–U.3.16](#)
 - harmonic analysis [U.3.20](#)
 - HMI [U.3.21](#)
 - HMI phasors screen [U.3.22](#), [U.4.41](#)
 - installation [U.3.2–U.3.3](#)

- metering [U.3.22](#), [U.4.38](#)
- Relay Editor [U.3.12](#), [U.4.26](#)
- relay part number [U.3.14](#)
- setting the relay [U.3.10–U.3.14](#)
- summary event screen [U.3.20](#)
- system requirements [U.3.2](#)

Alarm

- dc battery system monitor [A.2.21](#)
- HALARM [U.6.35](#)
- relay output [U.2.43](#)
- SALARM [U.2.44](#)
- ALARM Bit [R.4.12](#)
- Alarm Points [U.5.8–U.5.10](#), [R.10.42](#)
 - creating, application example [U.5.9](#)
- Alias Settings [U.4.24](#)

Analog Quantities

- in display points [U.5.12](#), [R.10.40](#)
- in SELOGIC control equations [R.3.11](#)
- list sorted alphabetically [R.B.1](#)
- list sorted by function [R.B.9](#)

Anonymous User

- for FTP [R.4.9](#)

ASCII

- ASCII text files [R.4.9](#)
- compressed ASCII files [R.4.9](#)

ASCII Commands

- See also Commands

Automessages

- [U.5.36](#), [A.6.6](#), [R.5.8](#)
- See also SEL Binary Protocols
- See also Status Warning

Auto-Reclose

- [R.2.1–R.2.26](#)
- application example [A.1.19](#), [A.1.26](#)
- logic diagrams [R.2.18–R.2.26](#)
- one circuit breaker [R.2.4](#)
 - application example [A.1.19](#)
- Relay Word bits [R.2.33](#)
- settings [R.2.31](#), [R.10.27–R.10.29](#)
- states [R.2.2–R.2.4](#)
 - auto-reclose cycle [R.2.3](#)
 - lockout [R.2.3](#)
 - reset [R.2.2](#)
 - start [R.2.2](#)
 - state diagram [R.2.4](#)
- two circuit breakers [R.2.6](#)
 - application example [A.1.26](#)

B

- Battery Monitor
 - See DC Battery System Monitor
- Bay Control [A.5.1–A.5.48](#)
 - ACSELERATOR QuickSet [A.5.23–A.5.27](#)
 - circuit breaker status logic [A.5.3](#)
 - disconnect logic [A.5.3–A.5.12](#)
 - close and open control [A.5.3–A.5.6](#)
 - close and open immobility timer [A.5.9–A.5.10](#)
 - close, open, and undetermined states [A.5.11–A.5.12](#)
 - status and alarm [A.5.6–A.5.9](#)
 - example application [A.5.28–A.5.35](#)
 - front-panel operations [A.5.13](#)
 - circuit breaker and disconnect [A.5.17–A.5.23](#)
 - one-line diagrams [A.5.14–A.5.23](#)
 - circuit breaker and disconnect symbols [A.5.15–A.5.17](#)
 - labels [A.5.14](#)
 - predefined [A.5.35–A.5.49](#)
 - breaker-and-a-half [A.5.42–A.5.44](#)
 - Bus 1, Bus 2, transfer bus [A.5.38–A.5.40](#)
 - double bus double breaker [A.5.46–A.5.47](#)
 - main bus and auxiliary [A.5.36–A.5.38](#)
 - main bus and transfer bus [A.5.40–A.5.42](#)
 - ring bus [A.5.45](#)
 - source transfer bus [A.5.48–A.5.49](#)
 - pushbutton navigation [A.5.15](#)
 - Boolean Equations [R.3.4](#)
 - See also SELOGIC Control Equations
 - Breaker Bit [A.6.11](#)
 - BREAKER Command [A.2.13](#), [R.9.4–R.9.5](#)
 - BREAKER CONTROL
 - front panel [U.5.24–U.5.25](#)
 - Breaker History Report
 - See Circuit Breaker, history report

- Breaker Monitor
See Circuit Breaker, monitor
- Breaker Report
See Circuit Breaker, breaker report
- Breaker Status Logic
See Circuit Breaker, status logic
- C**
- C37.118
See Synchrophasors, protocols
- Cable
See Communications
- CEVENT Command [A.3.28–A.3.31, R.9.6–R.9.10](#)
See also Event Report
- CHISTORY Command [A.3.36, R.9.10–R.9.11](#)
See also Event History
- Circuit Breaker
auxiliary contacts (52A)
application example [U.4.69–U.4.73](#)
breaker report [A.2.13](#)
Compressed ASCII CBR [A.2.15](#)
contact wear curve [A.2.5–A.2.6](#)
choose midpoint [A.2.5](#)
creating [A.2.5](#)
 I^2t [A.2.6](#)
maximum interrupted current limit [A.2.5](#)
mechanical circuit breaker service life [A.2.5](#)
contact wear monitor [A.2.2–A.2.8](#)
loading maintenance data [A.2.3](#)
preload contact wear [A.2.6](#)
history report [A.2.14](#)
maintenance curve [A.2.4](#)
monitor [A.2.1](#)
application example [A.2.3–A.2.12](#)
electrical operating time [A.2.10](#)
application example [A.2.11](#)
enabling [A.2.2–A.2.3](#)
external trip initiation [A.2.7](#)
inactivity time [A.2.11](#)
application example [A.2.12](#)
kA interrupt monitor [A.2.8](#)
mechanical operating time [A.2.9](#)
application example [A.2.9](#)
motor running time [A.2.12](#)
application example [A.2.12](#)
settings [R.10.11](#)
status logic [R.1.91–R.1.92](#)
- Circuit Breaker Failure [R.1.92–R.1.100](#)
application example [A.1.33–A.1.50](#)
- failure to interrupt fault current [A.1.34–A.1.36](#)
failure to interrupt load current [R.1.95–R.1.96](#)
flashover [R.1.96](#)
logic diagrams [R.1.99–R.1.100](#)
no current/residual current [R.1.94](#)
application example [A.1.39](#)
retrip [R.1.93](#)
types [R.1.92](#)
- Cleaning [U.4.2](#)
- Close
CLOSE n Command [R.9.11–R.9.12](#)
manual [R.2.26](#)
output [U.4.64–U.4.67](#)
- Commands [R.9.1](#)
89CLOSE [R.9.2](#)
89OPEN [R.9.2](#)
ACCESS [R.9.3](#)
ASCII [R.9.1–R.9.67](#)
BREAKER [A.2.13, R.9.4–R.9.5](#)
CBREAKER [A.2.15](#)
CEVENT [A.3.28–A.3.31, R.9.6–R.9.10](#)
CHISTORY [A.3.36, R.9.10–R.9.11](#)
CLOSE n [R.9.11–R.9.12](#)
COM [R.9.12–R.9.13](#)
CSER [A.3.44, R.9.15–R.9.16](#)
CSTATUS [U.6.37, R.9.16](#)
CSUMMARY [A.3.33–A.3.34, R.9.17–R.9.18](#)
EVENT [A.3.14–A.3.16, R.9.20–R.9.24](#)
FILE [R.9.24–R.9.25](#)
HELP [R.9.25](#)
HISTORY [A.3.35–A.3.36, R.9.25–R.9.26](#)
ID [R.9.29](#)
METER [A.2.22, R.9.34–R.9.39](#)
OPEN n [R.9.40–R.9.41](#)
PASSWORD [R.9.41–R.9.42](#)
PULSE [U.6.5, R.9.43](#)
QUIT [R.9.43](#)
SER [U.4.57, A.3.42–A.3.43, R.9.43–R.9.45](#)
SET [R.9.45–R.9.50](#)
SHOW [R.9.50](#)
STATUS [U.6.36–U.6.37, R.9.54–R.9.55](#)
SUMMARY [A.3.33, R.9.55–R.9.56](#)
TARGET [U.6.5, R.9.57–R.9.58](#)
TEC [R.1.15–R.1.17](#)
TEST DB [U.6.5, R.9.59–R.9.60](#)
TEST DNP [U.6.6, R.9.60–R.9.61](#)
TEST FM [U.6.6, R.9.61–R.9.63](#)
TIME Q [U.4.77–U.4.78, R.9.63](#)
TRIGGER [U.4.43, A.3.5, R.9.64](#)
- VERSION [R.9.64–R.9.65](#)
- Commissioning
procedure [U.4.81–U.4.82](#)
- Commissioning Testing [U.6.2](#)
See also Testing
- Communications
ACSELERATOR QuickSet software
FTP [U.3.4](#)
ACSELERATOR QuickSet software
serial [U.3.4](#)
Telnet [U.3.5](#)
terminal [U.3.5](#)
ASCII commands
See ASCII commands;
Commands [R.9.1](#)
cable [U.2.47, U.4.5, R.4.4](#)
DNP3
See DNP3
- EIA-232 [R.4.2](#)
hardware flow control [R.5.1](#)
pin functions [R.4.3](#)
- EIA-485 [R.4.4, R.5.21](#)
- IEC 61850
See IEC 61850
- interfaces [U.2.12, R.4.1](#)
- LMD
See Distributed Port Switch
- MIRRORED BITS communications
See MIRRORED BITS
Communications
- protocol [R.4.1](#)
serial [U.2.47–U.2.48, R.4.2–R.4.4](#)
application example [U.4.5–U.4.6](#)
transparent mode [R.9.42](#)
virtual serial ports [R.5.3](#)
- Communications Card [A.7.1](#)
application example [A.7.7–A.7.12](#)
database [R.4.21](#)
Ethernet [A.7.4, R.4.4](#)
Ethernet Card [A.6.4](#)
Ethernet card [R.4.4](#)
SEL-2702 [A.7.4, R.4.8](#)
- Communications Processor [A.6.1](#)
application example [A.6.5](#)
- Communications-Assisted Tripping [R.1.72–R.1.85](#)
DCB [R.1.73–R.1.76](#)
DCUB [R.1.82–R.1.85](#)
POTT [R.1.77–R.1.81](#)
- Compressed ASCII [R.5.5](#)
See also ASCII Commands
- COMTRADE [A.3.8–A.3.11, A.4.6](#)
See also Event
.CFG file [A.3.9–A.3.10](#)
.DAT file [A.3.11](#)

- .HDR file A.3.8
- Configuration
 - serial number label U.4.2–U.4.3
- Connection U.2.31–U.2.48
 - 1k PPS (obsolete) U.2.12, U.2.45, U.4.75
 - ac/dc diagram U.2.50–U.2.52
 - alarm output U.2.43
 - battery monitors U.2.41
 - close output U.2.44, U.4.64
 - communications ports U.2.47
 - Connectorized U.2.2, U.2.32, U.2.42
 - control inputs U.2.42
 - control outputs U.2.43
 - grounding U.2.37
 - IRIG-B U.2.12, U.2.45, U.4.73
 - power U.2.38, U.4.3
 - screw terminal connectors U.2.36
 - secondary circuits U.2.41–U.2.42
 - serial port U.2.47
 - terminal blocks U.2.41
 - test connections U.6.8–U.6.13
 - trip output U.2.44
 - wire insulation U.2.31
 - wire size U.2.37, U.4.4
- Connectorized U.2.2, U.2.42
 - SEL-WA0421 U.2.2, U.2.42
 - wiring harness U.2.2, U.2.42
- Connectors U.2.2
 - Connectorized U.2.2
 - screw terminal connectors U.2.2
 - terminal blocks U.2.2
- Contact Card
 - See SEL Contact Card
- Contact Inputs
 - See Control Inputs
- Contact Outputs
 - See Control Outputs
- Contact Wear Curve
 - See Circuit Breaker, contact wear curve
- Contact Wear Monitor
 - See Circuit Breaker, contact wear monitor
- Contrast, LCD U.5.15
- Control Inputs U.2.6, U.2.14, U.2.42
 - ac voltages U.2.7
 - breaker auxiliary contacts (52A)
 - application example
 - ACCELERATOR QuickSet software U.4.69–U.4.73
 - terminal U.4.68–U.4.69
 - common U.2.6–U.2.7
 - connecting U.2.42
 - debounce U.2.6–U.2.7, U.4.67
 - direct coupled U.2.6
 - dropout factor, GINDF U.2.6
 - I/O, Main Board A and Main Board B U.2.11
 - independent U.2.6–U.2.7
 - INT1, INT2, INT4, INT5, INT6, INT7, and INT8 U.2.14
 - optoisolated U.2.7, U.2.15
 - pickup adjust U.2.6, U.4.67
 - range U.2.6–U.2.7
 - recommended settings U.2.6
 - sample rate U.2.6, U.2.8
 - time
 - COMTRADE report A.3.26
 - event report A.3.26
- Control Outputs U.2.8–U.2.11, U.2.15, U.2.43–U.2.44
 - alarm U.2.43
 - application example U.4.59, A.1.14
 - close outputs U.4.64–U.4.67
 - connecting U.2.43
 - fast hybrid (fast high-current interrupting) U.2.9–U.2.11
 - diagrams U.2.9
 - precharging U.1.12
 - ratings U.2.9
 - Form A U.2.8–U.2.9, U.2.11, U.2.43
 - Form C U.2.8, U.2.11, U.2.43
 - hybrid (high-current interrupting) U.2.8
 - diagram U.2.9
 - ratings U.1.12
 - INT1, INT2, INT4, INT5, INT6, INT7, and INT8 U.2.15
 - local bit control
 - application example U.4.62–U.4.64
 - main board U.2.11, U.2.15
 - MOV U.2.8
 - plug-in boards U.2.13
 - pulsing
 - application example
 - front panel U.4.60–U.4.61
 - terminal U.4.58–U.4.59
 - sample rate U.2.8
 - standard U.2.8
 - diagram U.2.8
 - ratings U.1.12
 - trip outputs U.4.64–U.4.67
- Counters
 - See SELOGIC Control Equations
- CSER Command A.3.44, R.9.15–R.9.16
 - See also SER (Sequential Events Recorder)
- CST Command U.6.37, R.9.16
- CSUMMARY Command A.3.33–A.3.34, R.9.17–R.9.18
 - See also Event Summary
- Current and Voltage Source Selection U.1.7, R.1.2–R.1.14
 - application example A.1.4
 - connections R.1.2
 - ESS := N (single circuit breaker) R.1.4, R.1.8
 - ESS := 1 (single circuit breaker) R.1.4, R.1.8
 - ESS := 2 (single circuit breaker) R.1.4, R.1.9
 - ESS := 3 (double circuit breaker) R.1.4, R.1.10
 - ESS := 4 (double circuit breaker) R.1.4, R.1.10–R.1.11
 - ESS := Y R.1.4–R.1.5, R.1.11–R.1.13
 - current polarizing source R.1.12–R.1.13
 - voltage source switching R.1.6–R.1.7

D

- Data
 - filtered data A.3.2
 - high-resolution raw data A.3.2
- Database
 - See ACCELERATOR QuickSet Software; Communications Card
- Date
 - See Ethernet Card Commands
- DC Battery System Monitor A.2.16–A.2.21
 - ac ripple, definition A.2.16
 - ac ripple, measuring A.2.19
 - alarm A.2.21
 - application example A.2.18–A.2.20
 - dc ground detection A.2.19
 - equalize mode voltage level A.2.18
 - float high voltage level A.2.18
 - float low voltage level A.2.18
 - metering A.2.21
 - open-circuit voltage level A.2.18
 - reset metering A.2.21
 - thresholds, warn and fail A.2.17
 - trip/close voltage level A.2.18
 - Vdc1 A.2.17
 - Vdc2 A.2.17
- DCB R.1.73–R.1.76
 - blocking signal extension R.1.75
 - coordination timers R.1.74
 - logic diagram R.1.76
 - starting elements R.1.74
 - stopping elements R.1.75

DCUB [R.1.82–R.1.85](#)
 logic diagrams [R.1.84–R.1.85](#)
 loss-of-guard, LOG [R.1.82](#)
 permissive trip blocking, UBB
[R.1.82](#)
 POTT scheme similarities [R.1.82](#)
 three-terminal lines [R.1.82–R.1.83](#)
 timers [R.1.83](#)

Debounce
 See also Control Inputs

Demand Metering [A.2.29–A.2.33](#)
 See also Meter
 reset [A.2.33](#)

DIAGNOSTICS.TXT [R.4.8](#)

Dimensions [U.2.31](#)
 rack units, defined [U.2.1](#)

Directional Comparison Blocking
 See DCB

Directional Comparison Unblocking
 See DCUB

Directional Control [R.1.45](#)

Directional Elements
 See Ground Directional Elements;
 Phase and Negative-Sequence
 Directional Elements

Directional Overcurrent Elements
 See Overcurrent Elements

Disconnect Logic
 See Bay Control, disconnect logic

Display
 See LCD, Front Panel

Display Points [U.5.8](#)
 creating, application examples
[U.5.13–U.5.14](#)
 deleting, application example
[U.4.22–U.4.24](#)

Distributed Port Switch [R.4.1, R.5.21](#)

DNP3 [A.6.3, A.7.2–A.7.3, R.4.1, R.6.1–R.6.11](#)
 access method [R.6.4–R.6.5](#)
 application example [R.6.30–R.6.35](#)
 conformance testing [R.6.4](#)
 Device Profile document [R.6.12](#)
 event data [R.6.3](#)
 objects [R.6.2, R.6.13–R.6.17](#)
 polling
 See DNP3, access method
 settings [R.6.8](#)
 testing [R.6.11](#)
 User's Group [R.6.1](#)

E

Earthing
 See Grounding

EIA-232
 See Communications

EIA-485
 See Communications

Energy Metering [A.2.33–A.2.34](#)
 See also Meter
 accuracy [A.2.34](#)
 reset [A.2.34](#)

EPMU, setting
 See Synchrophasors

ESS, setting
 See Current and Voltage Source Selection

Ethernet
 See also Communications Card

Ethernet Card
 See Communications Card

Ethernet Card Commands [R.4.10–R.4.18](#)
 2ACCESS [R.4.12–R.4.13](#)
 ACCESS [R.4.13](#)
 DATE [R.4.13](#)
 DNPMAP [R.4.13](#)
 HELP [R.4.16](#)
 ID [R.4.16](#)
 MEMORY [R.4.17](#)
 PING [R.4.17](#)
 QUIT [R.4.12, R.4.17](#)
 STATUS [R.4.18](#)
 summary [R.4.11](#)
 syntax [R.4.10](#)
 TIME [R.4.18](#)

Ethernet Card Settings
 FTP [R.4.7](#)
 Telnet [R.4.9](#)

EVE Command [A.3.14–A.3.16, R.9.20–R.9.24](#)
 See also Event

Event
 data capture initiate [A.3.4–A.3.5](#)
 data capture time [A.3.5](#)
 duration [A.3.5](#)
 effective sample rate, SRATE [A.3.5](#)
 ER equation [A.3.4–A.3.5](#)
 application example [A.3.4](#)
 EVE command [A.3.14–A.3.16, R.9.20–R.9.24](#)
 initiate, TRI command [U.4.43, A.3.5, R.9.64](#)
 application example
 ACSELERATOR QuickSet software [U.4.43](#)
 length, LER [A.3.5](#)
 prefault, PRE [A.3.5](#)
 PUL does not initiate [A.3.4](#)
 storage capability [A.3.7](#)

TRIP initiate [A.3.4](#)

Event History [A.3.34–A.3.36](#)
 See also Event

ACSELERATOR QuickSet software
[U.3.17, A.3.36](#)

blank row [A.3.35](#)

CHISTORY command [A.3.36, R.9.10](#)

contents [A.3.34](#)

event types [A.3.33, A.3.35](#)

HIS command [A.3.35, R.9.25–R.9.26](#)

retrieving history [U.3.17, U.4.45–U.4.47](#)
 application example
 ACSELERATOR QuickSet software
[U.4.45–U.4.46](#)
 front-panel [U.5.19](#)
 terminal [U.4.46](#)
 terminal [A.3.35–A.3.36](#)

Event Report [A.3.14–A.3.31](#)
 See also Event
 *, largest current [A.3.18, A.3.22](#)
 >, trigger row [A.3.18, A.3.22](#)
 ACSELERATOR QuickSet software
[U.3.16](#)

analog section [A.3.16–A.3.22](#)

Compressed ASCII CEVENT
[A.3.28–A.3.31](#)
 sample [A.3.29–A.3.31](#)

COMTRADE (Raw and Filtered Data) [A.3.2](#)

currents and voltages [A.3.18](#)

digital section [A.3.22–A.3.26](#)
 label header [A.3.23](#)
 reading, application example
[A.3.26](#)
 selecting elements [A.3.26](#)

header [A.3.16](#)

phasor calculation
 application example [A.3.18–A.3.22](#)

retrieving event data [U.3.17](#)
 application example
 ACSELERATOR QuickSet software
[U.4.49–U.4.51](#)
 high-resolution
 (COMTRADE) [U.3.17, U.4.47–U.4.51](#)
 terminal [U.4.51, R.9.6, R.9.20](#)

settings section [A.3.27](#)

summary section [A.3.27](#)

terminal [A.3.16, A.3.31](#)

trigger [U.4.43](#)

Event Summary [A.3.31–A.3.34](#)
 See also Event

- ACSELERATOR QuickSet software [A.3.33](#)
 contents [A.3.32](#)
 CSUMMARY command [A.3.33–A.3.34, R.9.17–R.9.18](#)
 event types [A.3.32](#)
 SUM command [A.3.33, R.9.55–R.9.56](#)
 terminal [A.3.33](#)
- Expression Builder [U.3.15, A.4.3](#)
 See also ACSELERATOR QuickSet Software
- F**
- Factory Assistance [U.6.41](#)
 Fast Message
 See SEL Binary Protocols
 Fast Meter
 See SEL Binary Protocols
 Fast Operate
 See SEL Binary Protocols
 Fast SER
 See SEL Binary Protocols
FAULT
 metering suspend [A.2.29](#)
Fault Locator [R.1.17–R.1.18](#)
Fault Type Identification Selection [R.1.33](#)
Fiber Optic [R.4.4](#)
FIDS
 See Fault Type Identification Selection
File
 See FTP; FILE Command
FILE Command [R.9.24–R.9.25](#)
 application example [U.4.47, U.4.57](#)
Firmware Version
 of SEL-2701 [R.4.16](#)
Frequency Estimation [R.1.14](#)
Front Panel
 access level [U.5.15](#)
 alarm points [U.5.8–U.5.10](#)
 automatic messages [U.5.36–U.5.37](#)
 bay control operations [A.5.17–A.5.23](#)
 display points [U.5.11–U.5.14, R.10.40](#)
 labels [U.5.37, U.5.42](#)
 layout [U.2.3, U.5.2](#)
 LCD [U.5.2–U.5.4](#)
 contrast [U.5.15](#)
 pushbuttons
 See Pushbuttons
 ROTATING DISPLAY [U.5.5, U.5.8](#)
 screen scrolling [U.5.5–U.5.8](#)
 serial port [U.5.3](#)
- set relay, application example [U.5.29–U.5.30](#)
 setting screen types [U.5.31](#)
 targets [U.5.3, U.5.37](#)
- Front-Panel Menus** [U.5.14–U.5.35](#)
 BREAKER MONITOR [U.5.21](#)
 DISPLAY TEST [U.5.34](#)
 EDIT ACTIVE GROUP [U.5.31](#)
 EVENTS [U.5.19–U.5.20](#)
 LOCAL CONTROL [U.5.23–U.5.29](#)
 BREAKER CONTROL [U.5.24](#)
 OUTPUT TESTING [U.5.28](#)
 MAIN MENU [U.5.16](#)
 METER [U.5.16–U.5.19](#)
 RELAY ELEMENTS [U.5.22–U.5.23](#)
 RELAY STATUS [U.5.33](#)
 RESET ACCESS LEVEL [U.5.35](#)
 SER [U.5.20–U.5.21](#)
 SET/SHOW [U.5.29–U.5.33](#)
 DATE/TIME [U.5.32](#)
 VIEW CONFIGURATION [U.5.33](#)
- FTP** [A.6.3, A.7.4](#)
- Fuse** [U.2.39–U.2.41](#)
 replacement [U.2.40–U.2.41](#)
 size [U.2.39](#)
- G**
- GOOSE**
 See IEC 61850
- GPS Receiver**
 See Time Synchronization
- Ground Directional Elements** [R.1.33–R.1.44](#)
 32I, zero-sequence current polarized [R.1.33](#)
 32QG, negative-sequence polarized [R.1.33](#)
 32V, zero-sequence voltage polarized [R.1.33](#)
 application example [A.1.11](#)
 automatic settings calculation [R.1.34](#)
 Best Choice Ground Directional logic [R.1.39](#)
 logic flow chart [R.1.39](#)
 calculations [R.1.42–R.1.44](#)
 logic diagrams [R.1.37, R.1.40–R.1.41](#)
 ORDER [R.1.36](#)
- Grounding** [U.2.37](#)
- H**
- Help**
 ACSELERATOR QuickSet software [U.4.5](#)
 terminal [U.4.5](#)
- HIRIG** [U.4.74, A.4.1](#)
- HIS Command** [A.3.35, R.9.25–R.9.26](#)
 See also Event History
- History Report**
 See also Event History
 circuit breaker [A.2.14](#)
 See also Circuit Breaker, history report
 event [A.3.34](#)
- I**
- I** [U.2.16](#)
- I/O**
 See Input/Output
- I²t**
 application example [A.2.6](#)
 fault current arcing time [A.2.3](#)
- ID Command** [R.9.29](#)
 codes [R.9.29](#)
 sample response [R.9.30](#)
- IEC 61850** [A.7.5, R.8.1](#)
 ACSELERATOR Architect [R.8.12](#)
 ACSI Conformance [R.8.37–R.8.41](#)
 GOOSE [R.8.10](#)
 Logical Nodes [R.8.16](#)
 Object Models [R.8.3](#)
 Reports [R.8.11](#)
 SCL Files [R.8.5](#)
 Settings [R.8.12](#)
- Input Processing** [A.3.1–A.3.2](#)
- Input/Output**
 communications card [U.2.18](#)
 See also Communications Card
 INT1 [U.2.13–U.2.18](#)
 INT2 [U.2.13–U.2.18](#)
 INT4 [U.2.13–U.2.18](#)
 INT5 [U.2.13–U.2.18](#)
 INT6 [U.2.13–U.2.18](#)
 INT7 [U.2.13](#)
 INT8 [U.2.13–U.2.18](#)
 interface board inputs [U.2.14](#)
 interface board installation [U.2.16–U.2.18](#)
 interface board jumpers [U.2.22–U.2.29](#)
 See also Jumpers
 interface board outputs [U.2.15](#)
 jumpers [U.2.22](#)
 See also Jumpers
 main board [U.2.11](#)
- Installation** [U.2.30–U.2.48](#)
 dimensions [U.2.31](#)
 panel mounting [U.2.31](#)
 physical location [U.2.30](#)
 rack mounting [U.2.30](#)

- Instantaneous Metering [A.2.23–A.2.27](#)
 See also Meter
- Instantaneous Overcurrent Elements
 See Overcurrent Elements
- Interface Boards INT1, INT2, INT4, INT5, INT6, INT7, and INT8 [U.2.13–U.2.18](#)
 inputs [U.2.14](#)
 installation [U.2.13–U.2.18](#)
 outputs [U.2.15](#)
- Inverse Time-Overcurrent Elements
 See Overcurrent Elements
- IRIG-B [U.2.11, U.2.45, U.4.73, A.4.1](#)
 See also Time Synchronization
- J**
- Jumpers [U.2.18–U.2.29](#)
 interface boards [U.2.22–U.2.29](#)
 main board [U.2.18–U.2.22](#)
 breaker jumper [U.2.18, U.2.20](#)
 password jumper [U.2.18, U.2.20](#)
 serial port [U.2.21–U.2.22](#)
- L**
- Labels
 See Front Panel, labels
- Latch Bits [R.3.14](#)
- LCD, Front Panel [U.5.3–U.5.4](#)
 autoscrolling mode [U.5.8](#)
 contrast [U.5.15](#)
 manual-scrolling mode [U.5.8](#)
- LEDs
 front panel [U.5.37–U.5.40, U.5.42](#)
 labels [U.5.37, U.5.43](#)
 targets [U.5.37–U.5.40](#)
- LMD
 See Distributed Port Switch
- Load Encroachment [R.1.46–R.1.47](#)
 application example [A.1.7–A.1.8](#)
- Local Bits [U.5.25–U.5.28](#)
 See also Local Control
 application example [U.5.28](#)
 delete a local bit [U.5.28](#)
 enter a local bit [U.5.27](#)
 names [U.5.24, U.5.27](#)
 states [U.5.26](#)
- Local Control [U.5.23–U.5.29](#)
 See also Breaker Control
 application examples [U.4.58–U.4.64](#)
 graphic display [U.5.26](#)
 local bits [U.5.25–U.5.28](#)
 output testing [U.5.28–U.5.29](#)
- LOP
 See Loss-of-Potential
- Loss-of-Potential [R.1.28–R.1.32](#)
 application example [A.1.6](#)
 logic diagram [R.1.32](#)
 logic flow chart [R.1.30](#)
- Low-Level Test Interface [U.6.6–U.6.8](#)
- Lugs, Crimp [U.2.36](#)
- M**
- Maintenance Curve
 See Circuit Breaker, maintenance curve
- Maintenance Data
 See also Circuit Breaker, contact wear monitor
 load circuit breaker [A.2.3](#)
- Maintenance Testing [U.6.2–U.6.3](#)
 See also Testing
- Manual Trip
 See Trip Logic
- Maximum/Minimum Metering [A.2.27–A.2.29](#)
 See also Meter
 accuracy [A.2.28](#)
 reset [A.2.28](#)
- Menus
 See Front-Panel Menus;
 ACSELERATOR QuickSet Software
- Meter [A.2.22](#)
 accuracy [A.2.25, A.2.28, A.2.34](#)
 current [A.2.23](#)
 dc battery monitor [A.2.21](#)
 demand [A.2.29–A.2.33](#)
 rolling [A.2.30–A.2.31](#)
 thermal [A.2.30](#)
 energy [A.2.33–A.2.34](#)
 error coefficients [A.2.25–A.2.26](#)
 frequency [A.2.23](#)
 fundamental [A.2.23](#)
 instantaneous [A.2.23–A.2.27](#)
 maximum/minimum [A.2.27–A.2.29](#)
 power [A.2.24](#)
 rms [A.2.23](#)
 synchrophasors [R.7.16](#)
 view metering [U.4.34–U.4.42](#)
 application example
 ACSELERATOR QuickSet software [U.4.38–U.4.41](#)
 front panel [U.4.41–U.4.42](#)
 terminal [U.4.34–U.4.38](#)
 voltage [A.2.23](#)
- METER Command [R.9.34–R.9.39](#)
 See also Meter
 automation math variables [R.9.34](#)
 MIRRORED BITS analog values [R.9.35](#)
 Phasor Measurement Unit [R.7.16](#)
- protection math variables [R.9.38](#)
 RTD temperature [R.9.39](#)
 synchronism check [R.9.39](#)
- METER.TXT [R.4.9](#)
- MIRRORED BITS Communications [R.4.2, R.5.15–R.5.21](#)
 Pulsar modem [R.5.19](#)
 virtual terminal [R.9.42](#)
- Modbus Plus [A.6.3](#)
- Modbus RTU [A.6.3](#)
- Monitor, Circuit Breaker
 See Circuit Breaker, monitor
- MOV
 control outputs [U.2.8](#)
- Multidrop Network [A.6.4](#)
- O**
- One-Line Diagrams
 See Bay Control, one-line diagrams
- OPEN n Command [R.9.40–R.9.41](#)
- Open Phase Detection Logic [R.1.27](#)
- Operator Control LEDs [U.5.42](#)
 See also LEDs
 factory defaults [U.5.43](#)
- Operator Control Pushbuttons [U.5.42](#)
 factory defaults [U.5.42](#)
- Oscillography [U.4.43–U.4.51, A.3.7–A.3.11](#)
 See also Event
 COMTRADE [A.3.7](#)
 event report [A.3.7, A.3.11](#)
 retrieving [U.3.17–U.3.18, U.4.47](#)
 application example
 ACSELERATOR QuickSet software [U.4.49–U.4.51](#)
 terminal [U.4.47–U.4.48](#)
- Output SELOGIC Control Equations [R.3.3, R.10.32](#)
- Output Testing
 front panel [U.5.28–U.5.29](#)
- Outputs
 See Control Outputs
- Overcurrent Elements [R.1.48–R.1.58](#)
 application example [A.1.8](#)
 definite-time
 negative-sequence [R.1.49](#)
 phase [R.1.48](#)
 residual ground [R.1.49](#)
 direction [R.1.48, R.1.55](#)
 instantaneous
 negative-sequence [R.1.49–R.1.50](#)
 phase [R.1.48, R.1.50](#)
 residual ground [R.1.49, R.1.51](#)
 inverse time [R.1.55–R.1.70](#)

- curves R.1.60–R.1.69
 equations R.1.58
 selectable operating quantity **R.1.55**
 logic diagrams R.1.52–R.1.54, **R.1.70**
 selectable operating quantity **R.1.55**
 current selections R.1.55
 time-current characteristics R.1.58–
R.1.69
 torque control R.1.48, R.1.55
- P**
- Panel Mount **U.2.31**
 dimensions U.2.31
- Password **U.4.7, U.4.9–U.4.10**
 defaults U.4.7
 changing, application example
U.4.9–U.4.10
 front-panel screen **U.5.15**
 jumper **U.2.20**
 See also Jumpers
 unauthorized **U.4.9**
- Passwords **R.4.11**
- PC Software
 See ACSELERATOR QuickSet Software
- Permissive Overreaching Transfer Trip
 See POTT
- Phase and Negative-Sequence Directional Elements **R.1.44–R.1.45**
 32P, phase R.1.44
 32Q, negative-sequence voltage polarized R.1.33, R.1.44
 logic diagrams R.1.45
 ZLOAD effect R.1.44
- Phase Instantaneous Definite-Time Overcurrent Elements
 See Overcurrent Elements
- Phasors
 calculate from event report
 application example A.3.18–
A.3.22
 hand calculation method A.3.18–
A.3.22
 polar calculator method A.3.22
- Plug-In Boards **U.2.13**
 See also Input/Output
 communications card U.2.18
 interface boards **U.2.13–U.2.18**
- PMU, phasor measurement unit **R.7.1**
 See also Synchrophasors
- Pole-Open Logic **R.1.27**
 application example A.1.12
- POTT **R.1.77**
 current reversal guard R.1.77
- echo **R.1.77–R.1.78**
 logic diagrams R.1.80
 three-terminal lines R.1.79
 weak infeed R.1.78–R.1.79
- Power Flow
 analysis **A.4.7–A.4.9**
 power flow convention **A.2.24**
- Power Supply
 connections **U.2.38, U.4.3**
 types **U.4.3**
 voltage ranges **U.2.39, U.4.3**
- PPS **U.2.12, U.4.75**
 See also Time Synchronization
 1k PPS (obsolete) **U.2.12, U.4.75**
- Protection and Automation Separation **R.3.3**
 See also SELOGIC Control Equations
- Pulsar Modem
 See MIRRORED BITS Communications
- PULSE Command **U.6.5, R.9.43**
 application example
 front panel **U.4.60–U.4.61**
 terminal **U.4.58–U.4.59**
 include TESTPUL in ER A.3.5
 no event data A.3.4
- Pushbuttons
 factory defaults **U.5.42**
 front panel **U.5.3**
 labels **U.5.43**
 LEDs
 See Operator Control LEDs
 navigation **U.5.4–U.5.5**
 operator control **U.5.42**
 programming **U.5.43**
- Q**
- QUIT Command **R.9.43**
- R**
- Rack Mount **U.2.30–U.2.31**
 dimensions U.2.31
- Rear Panel
 alert symbols U.2.35
 layout **U.2.5, U.2.32–U.2.34**
 template **U.2.5**
- Recloser
 See Auto-Reclose
- RELAY TRIP EVENT
 front panel **U.5.36**
- Relay Word Bits
 in display points **U.5.12, R.10.40**
 in SELOGIC control equations
R.3.11
 list sorted alphabetically **R.A.1**
- listed by row, sorted by function
R.A.21–R.A.70
- Remote Bit **A.6.11, R.3.15, R.9.14**
- Remote Terminal Unit (RTU) **R.6.1**
- Reset
 See also ACSELERATOR QuickSet, control window
 battery monitor metering **A.2.21**
 demand metering **A.2.33**
 energy metering **A.2.34**
 maximum/minimum metering
A.2.28
 targets **U.5.38–U.5.39**
- Rolling Demand Metering **A.2.30–A.2.31**
 See also Demand Metering
- S**
- Schweitzer Engineering Laboratories
 contact information **U.6.41**
- Screw Terminal Connectors **U.2.2, U.2.36–U.2.38**
 keying **U.2.36–U.2.37**
 receptacle keying **U.2.38**
 removal and insertion **U.2.36**
 tightening torque **U.2.36**
- Scrolling
 See Front Panel, screen scrolling
- Secondary Connections **U.2.5–U.2.6, U.2.41–U.2.42**
 ac/dc connection diagrams **U.2.50**
 levels **U.2.5**
- Security
 access levels **R.4.11**
 passwords **R.4.11**
- SEL Binary Protocols **R.4.1**
 Fast Message Synchrophasor **R.7.24**
 Fast Meter **A.6.6, R.5.8, R.9.4, R.9.20, R.9.61–R.9.63**
 Fast Operate **A.6.11, R.5.8, R.7.30**
 Fast SER **R.5.8, R.9.54**
 RTD **R.5.23**
- SEL Contact Card **U.4.1**
- SEL-2020/2030/2032
 See Communications Processor
- SEL-2030
 database regions **R.4.9**
- SEL-2407
 See Time Synchronization
- SEL-3306
 See Synchrophasors
- SEL-451 Relay
 features **U.1.1–U.1.4**
 models **U.1.5**
 options **U.1.5**

SEL-5030 ACSELERATOR QuickSet Software
 See ACSELERATOR QuickSet Software

Self-Tests [U.4.10](#), [U.6.35](#)–[U.6.38](#)
 See also Testing; Troubleshooting

SELOGIC Control Equations
 analog quantities [R.3.11](#)
 automation [R.3.6](#)
 Boolean equations [R.3.4](#)–[R.3.5](#), [R.3.26](#)–[R.3.30](#)
 capacity [R.3.10](#)
 comments [R.3.5](#), [R.3.36](#)
 conditioning timers [R.3.17](#)
 convert [R.3.38](#)
 counters [R.3.23](#)
 fixed result [R.3.4](#)
 free-form [R.3.4](#)
LVALUE [R.3.5](#)
 math equations [R.3.4](#)–[R.3.5](#), [R.3.30](#)–[R.3.35](#)
 math error [R.3.31](#)
 math variables [R.3.13](#)
 output [R.3.7](#)
 PMU trigger [R.7.13](#)
 protection [R.3.6](#), [R.10.30](#)
 Relay Word bits [R.3.11](#)
 sequencing timers [R.3.20](#)
 variables [R.3.12](#)

Sequential Events Recorder
 See SER (Sequential Events Recorder)

SER (Sequential Events Recorder) [U.4.52](#), [A.3.42](#)–[A.3.45](#)
 ACSELERATOR QuickSet software [A.3.43](#)
 automatic deletion [A.3.45](#)
 chattering elements [A.3.45](#)
 contents [A.3.42](#)
 CSER command [A.3.44](#), [R.9.15](#)–[R.9.16](#)
 file download [U.4.57](#)
 front-panel alarm points [U.5.8](#)–[U.5.10](#), [A.3.44](#), [R.10.42](#)
 SER command [U.4.57](#), [A.3.43](#), [R.9.43](#)–[R.9.45](#)
 set points and aliases [U.4.52](#)–[U.4.57](#), [A.3.44](#)
 application example
 ACSELERATOR QuickSet software [U.4.52](#)–[U.4.55](#)
 terminal [U.4.56](#)–[U.4.57](#)
 terminal [A.3.43](#)
 view SER report
 application example
 ACSELERATOR QuickSet software [U.4.55](#)–[U.4.56](#)
 front panel [U.5.20](#)–[U.5.21](#)

terminal [U.4.57](#)

SER Command [R.9.43](#)–[R.9.45](#)

Serial Number Label [U.4.2](#)–[U.4.3](#)

Serial Port [R.4.2](#)
 See also Communications cable
 See Communications
EIA-232
 See Communications
EIA-485
 See Communications
 front panel [U.5.3](#)
 jumper [U.2.21](#)–[U.2.22](#)
 See also Jumpers

SET Command [U.4.15](#), [R.9.45](#)–[R.9.50](#)

Setting [U.4.14](#)–[U.4.33](#), [R.9.50](#)
 See also Commands, SET
 See also Commands, SHOW
 ACSELERATOR QuickSet software [U.3.10](#)
 application example [U.4.26](#)–[U.4.29](#)
 application example [A.1.4](#)
 ASCII commands [U.4.16](#)
 class [U.4.14](#)–[U.4.15](#)
 date [U.5.32](#), [R.9.19](#)
 from front panel [U.4.29](#)–[U.4.33](#), [U.5.29](#)–[U.5.33](#)
 application example [U.4.29](#)–[U.4.33](#)
 instance [U.4.14](#)–[U.4.15](#)

SER [U.4.52](#)
 See also SER (Sequential Events Recorder)
 structure [U.4.15](#)

terminal [U.4.17](#)–[U.4.24](#)
 application example [U.4.17](#)–[U.4.19](#), [U.4.22](#)–[U.4.24](#)

TERSE [U.4.19](#)
 text-edit mode [U.4.19](#)–[U.4.24](#)
 time [U.5.32](#), [R.9.63](#)

Setting Groups
 multiple setting [R.3.8](#)
 nonvolatile [R.3.9](#)

Settings
 data access [R.4.7](#)

SOTF
 See Switch-On-O-Fault

Specifications [U.1.12](#)–[U.1.17](#)

Star Network Topology [A.6.1](#), [A.6.3](#)

State Estimation [A.4.9](#)
 State Measurement [A.4.9](#)

Station DC Battery System Monitor [A.2.16](#)
 See also DC Battery System Monitor

Status [U.6.36](#)
 check relay status [U.4.10](#)–[U.4.13](#)
 application example
 ACSELERATOR QuickSet software [U.4.11](#)
 front panel [U.4.13](#)
 terminal [U.4.11](#)
 CST command [U.6.37](#), [R.9.17](#)
 STATUS command [R.9.54](#)–[R.9.55](#)

Status Failure [U.6.35](#), [U.6.37](#)
 front panel [U.5.37](#)

Status Warning [U.6.35](#), [U.6.37](#)
 front panel [U.5.36](#)

Substation Automation [R.3.2](#)
 See also SELOGIC Control Equations

SUM Command [A.3.33](#), [R.9.55](#)–[R.9.56](#)
 See also Event Summary

Switch-On-O-Fault [R.1.70](#)–[R.1.72](#)
 application example [A.1.6](#)–[A.1.7](#)
 close signal monitor, CLSMON [A.1.7](#), [R.1.71](#)
 duration [A.1.7](#), [R.1.71](#)
 end [A.1.6](#), [R.1.71](#)
 initiation [A.1.7](#), [R.1.70](#)
 logic diagram [R.1.72](#)
 trip [A.1.6](#)
 validation [R.1.70](#)

Synchronism Check [R.2.35](#)–[R.2.52](#)
 alternate source 2 [R.2.50](#)–[R.2.52](#)
 angle checks [R.2.44](#)
 application example [A.1.30](#)
 block synchronism check [R.2.43](#)
 circuit breaker closing [R.2.39](#)
 enable logic [R.2.43](#)
 healthy voltage window [R.2.42](#)
 input angle compensation [R.2.40](#)–[R.2.43](#)
 input voltage magnitude compensation [R.2.40](#)–[R.2.42](#)
 no slip [R.2.45](#)–[R.2.46](#)
 PT connections [R.2.40](#)
 Relay Word bits [R.2.38](#)–[R.2.39](#)
 settings [R.2.37](#)–[R.2.38](#)
 single-phase voltage inputs [R.2.36](#)–[R.2.37](#)
 slip, no compensate [R.2.46](#)–[R.2.48](#)
 slip, with compensate [R.2.48](#)–[R.2.50](#)

Synchrophasors [R.7.1](#)–[R.7.30](#)
 Fast Operate [R.7.30](#)
 MET PM Command [R.7.16](#)
 protocols
 C37.118 [R.7.18](#)
 Fast Message [R.7.24](#)
 Relay Word bits [R.7.14](#)

- See also Time-Synchronized Measurements
 SEL-3306 R.7.2
 setting example R.7.20
 settings R.7.6, R.7.25
 Time-Synchronized Metering A.2.34
- Time-Synchronized Measurements
 See also Synchrophasors
- System Integration A.6.1
- T**
- TARGET Command U.6.5, R.9.57–R.9.58
- Targets U.5.37–U.5.40
 operational U.5.38
 phases/ground U.5.40
 recloser status U.5.40
 regions U.5.38
 reset U.5.38–U.5.39
 trip type U.5.39
- TCP/IP
 FTP
 access control R.4.9
 anonymous user R.4.9
 downloading settings R.4.8
 file structure R.4.8–R.4.9
 security R.4.12
 SEL-2701 related settings R.4.7–R.4.9
 simultaneous users R.4.7
- Telnet
 security R.4.12
 SEL-2701 related settings R.4.9–R.4.10
 transmission control characters R.4.10
 user interface access R.4.9
- Telnet A.7.5
- TEST DB Command U.6.5, R.6.44, R.9.59–R.9.60
- TEST DNP Command U.6.6, R.9.60–R.9.61
- TEST FM Command U.6.6, R.9.61–R.9.63
- Testing U.6.1
 acceptance testing U.6.1
 ASCII commands U.6.5–U.6.6
 commissioning testing U.6.2
 directional elements U.6.29
 application example U.6.30
 element tests U.6.25
 features U.6.4
 low-level test interface U.6.6, U.6.8
 maintenance testing U.6.2–U.6.3
 methods U.6.13–U.6.25
 application example
- control outputs U.6.18–U.6.20
 front panel U.6.16
 SER U.6.20–U.6.25
 targets, LCD U.6.14–U.6.16
 targets, LED U.6.16, U.6.18
 targets, terminal U.6.13–U.6.14
 overcurrent elements U.6.25–U.6.29
 application example U.6.26–U.6.29
 self-tests U.6.35
 test connections U.6.8–U.6.13
- Thermal Demand Metering A.2.30
 See also Demand Metering
- Time U.4.73–U.4.81
 See also Synchrophasors
 high-accuracy U.4.73–U.4.81
 application example U.4.75–U.4.81
 Relay Word bits U.4.74, U.4.76
 See Ethernet Card Commands
- Time Synchronization
 See also Time Inputs
- TIME Command R.9.63
- Time Inputs U.2.11, U.2.45
 See also IRIG-B
 connecting U.4.75
 IRIG-B U.2.11
- TIME Q Command U.4.77–U.4.78, R.9.63
- Time Synchronization U.4.73
 See also Time Inputs U.4.73
 DNP3 R.6.7
 GPS R.7.1
 IRIG-B U.4.73, A.6.2, A.6.5
 SEL-2407 R.7.1
- Timeout
 front panel U.5.4
 serial port R.5.8
- Time-Overcurrent Curves R.1.58–R.1.69
 See also Overcurrent Elements
- Time-Overcurrent Elements
 See Overcurrent Elements
- Timers
 See SELOGIC Control Equations
- Time-Synchronized Measurements A.4.1
 See also Synchrophasors R.7.1
 power flow analysis A.4.7–A.4.9
 state estimation A.4.9
 time trigger A.4.2–A.4.6
 application example A.4.2–A.4.6
- Trigger
 data capture A.3.4
- event A.3.4
 PMU R.7.13
 TRIGGER Command R.9.64
- Trip
 output U.2.44, U.4.64
 Relay Word bit, TRIP A.3.4
- Trip Bus
 capture external/internal trips A.2.7
- Trip Logic R.1.86
 application example A.1.13
 logic diagrams R.1.89–R.1.90
 manual trip R.1.87
 trip equations A.1.13, R.1.86
 TR R.1.86
 TRCOMM R.1.86
 TRSOTF R.1.86
 trip Relay Word bits R.1.88
 trip timers A.1.14, R.1.87
 trip unlatch options A.1.13, R.1.86
 TULO A.1.13, R.1.87
 ULTR A.1.13, R.1.87
- Troubleshooting U.6.38–U.6.40
- U**
- UCA2 R.8.2
 GOOSE R.8.4
- User Interface
 Ethernet Card command entry R.4.10
 Telnet access R.4.9
- V**
- VERSION Command R.9.64–R.9.65
 driver number U.3.8
 firmware number U.6.36
 release numbers R.9.64
 sample response R.9.65
- Virtual Devices R.4.9
- Virtual File Interface R.5.11–R.5.14
- Voltage Checks
 auto-reclose R.2.29
 synchronism check R.2.42
- W**
- Wire
 grounding size U.2.37
 insulation U.2.31
 power connection size U.2.39, U.4.4

This page intentionally left blank

SEL-451 Relay Command Summary

Command ^{a, b}	Description
2ACCESS	Go to Access Level 2 (complete relay monitoring and control)
89CLOSE <i>n</i>	Close disconnect switch <i>n</i> in SEL-451-4 (<i>n</i> = disconnect switches 1–10)
89OPEN <i>n</i>	Open disconnect switch <i>n</i> in SEL-451-4 (<i>n</i> = disconnect switches 1–10)
AACCESS	Go to Access Level A (automation control)
ACCESS	Go to Access Level 1 (monitor relay)
BACCESS	Go to Access Level B (monitor relay and control circuit breakers)
BNAME	ASCII names of all relay status bits (Fast Meter)
BREAKER <i>n</i>	Display the circuit breaker report and breaker history; preload and reset breaker monitor data (<i>n</i> = 1 is BK1; <i>n</i> = 2 is BK2)
CASCII	Generate the Compressed ASCII response configuration message
CBREAKER	BREAKER command for the Compressed ASCII response
CEVENT	EVENT command for the Compressed ASCII response
CHISTORY	HISTORY command for the Compressed ASCII response
CLOSE <i>n</i>	Close the circuit breaker (<i>n</i> = 1 is BK1; <i>n</i> = 2 is BK2)
COMM <i>c</i>	Display relay-to-relay MIRRORED BITS® communications data (<i>c</i> = A is channel A; <i>c</i> = B is channel B; <i>c</i> = M is either enabled single channel)
CONTROL <i>nn</i>	Set, clear, or pulse an internal remote bit (<i>nn</i> is the remote bit number from 01–32)
COPY <i>m n</i>	Copy settings between instances in the same class (<i>m</i> and <i>n</i> are instance numbers; for example: <i>m</i> = 1 is Group 1; <i>n</i> = 2 is Group 2)
CSER	SER command for the Compressed ASCII response
CSTATUS	STATUS command for the Compressed ASCII response
CSUMMARY	SUMMARY command for the Compressed ASCII response
DATE	Display and set the date
DNAME X	ASCII names of all relay digital I/O (Fast Meter)
DNP	Access or modify serial port DNP3 settings (similar to SHOW D and SET D)
EVENT	Display and acknowledge event reports
FILE	Transfer data between the relay and external software
GROUP	Display the active group number or select the active group
HELP	Display available commands or command help at each access level
HISTORY	View event summaries/histories; clear event data
HIZ	Displays a report of ground overcurrent high-impedance fault (50G HIZ) detection activity.
ID	Display the firmware id, user id, device code, part number, and configuration information
INI HIF	Restarts the 24-hour tuning process used in high-impedance fault detection.
IRIG	Update the internal clock/calendar from the IRIG-B input
LOG HIF	Displays the progress of the HIF detection in the percentage to their final pickup.
LOOPBACK	Connect MIRRORED BITS data from transmit to receive on the same port
MAP 1	Analyze the communications card database
METER	Display metering data and internal relay operating variables
OACCESS	Go to Access Level O (output control)

Command ^{a, b}	Description
OPEN <i>n</i>	Open the circuit breaker (<i>n</i> = 1 is BK1; <i>n</i> = 2 is BK2)
PACCESS	Go to Access Level P (protection control)
PASSWORD	Change relay passwords
PORT	Connect to a remote relay via MIRRORED BITS virtual terminal (for port number <i>p</i> = 1–3, and F), or the Ethernet card (port <i>p</i> = 5)
PULSE OUT<i>nnn</i>	Pulse a relay control output (OUT <i>nnn</i> is a control output number)
QUIT	Reduce access level to Access Level 0 (exit relay control)
SER	View Sequential Events Recorder reports
SET^c	Enter relay settings
SHOW^c	Display relay settings
SNS	Display Sequential Events Recorder settings name strings (Fast SER)
STATUS	Report or clear relay status and SELOGIC® control equation errors
SUMMARY	View summary event reports
TARGET	Display relay elements for a row in the Relay Word table
TEC	Display time-error estimate; display or modify time-error correction value.
TEST DB	Display or place values in the communications card database (Useful for Ethernet protocol read tests)
TEST DNP	Display or place values in the serial port DNP3 object map
TEST FM	Display or place values in metering database (Fast Meter)
TIME	Display and set the internal clock
TRIGGER	Initiate a data capture and record an event report
VERSION	Display the relay hardware and software configurations
VIEW 1	View data from the communications card database

^a See [Section 9: ASCII Command Reference in the Reference Manual](#)

^b For help on a specific command, type HELP [command] <Enter> at an ASCII terminal communicating with the relay.

^c See the table below for SET/SHOW options.

SET/SHOW Command Options

Option	Setting Type	Description
[S] <i>n</i>	Group Settings 1–6	Particular application settings
A <i>n</i>	Automation Logic Block 1–10	Automation SELOGIC control equations
B	Bay	Bay Control Settings (SEL-451-4)
D	DNP3	Direct Network Protocol remapping (serial port only)
F	Front Panel	Front-panel HMI settings
G	Global 1–6	Relay-wide settings
L <i>n</i>	Protection Logic Group 1–6	Protection SELOGIC control equations
M	Breaker Monitor	Circuit breaker monitor settings
O	Outputs	Output SELOGIC control equations
P <i>n</i>	Port 1–3, F, 5	Communications port settings
R	Report	Event report and SER settings
T	Alias	Alias names for analog quantities and Relay Word bits

SEL-451 Relay Command Summary

Command ^{a, b}	Description
2ACCESS	Go to Access Level 2 (complete relay monitoring and control)
89CLOSE <i>n</i>	Close disconnect switch <i>n</i> in SEL-451-4 (<i>n</i> = disconnect switches 1–10)
89OPEN <i>n</i>	Open disconnect switch <i>n</i> in SEL-451-4 (<i>n</i> = disconnect switches 1–10)
AACCESS	Go to Access Level A (automation control)
ACCESS	Go to Access Level 1 (monitor relay)
BACCESS	Go to Access Level B (monitor relay and control circuit breakers)
BNAME	ASCII names of all relay status bits (Fast Meter)
BREAKER <i>n</i>	Display the circuit breaker report and breaker history; preload and reset breaker monitor data (<i>n</i> = 1 is BK1; <i>n</i> = 2 is BK2)
CASCII	Generate the Compressed ASCII response configuration message
CBREAKER	BREAKER command for the Compressed ASCII response
CEVENT	EVENT command for the Compressed ASCII response
CHISTORY	HISTORY command for the Compressed ASCII response
CLOSE <i>n</i>	Close the circuit breaker (<i>n</i> = 1 is BK1; <i>n</i> = 2 is BK2)
COMM <i>c</i>	Display relay-to-relay MIRRORED BITS® communications data (<i>c</i> = A is channel A; <i>c</i> = B is channel B; <i>c</i> = M is either enabled single channel)
CONTROL <i>nn</i>	Set, clear, or pulse an internal remote bit (<i>nn</i> is the remote bit number from 01–32)
COPY <i>m n</i>	Copy settings between instances in the same class (<i>m</i> and <i>n</i> are instance numbers; for example: <i>m</i> = 1 is Group 1; <i>n</i> = 2 is Group 2)
CSER	SER command for the Compressed ASCII response
CSTATUS	STATUS command for the Compressed ASCII response
CSUMMARY	SUMMARY command for the Compressed ASCII response
DATE	Display and set the date
DNAME X	ASCII names of all relay digital I/O (Fast Meter)
DNP	Access or modify serial port DNP3 settings (similar to SHOW D and SET D)
EVENT	Display and acknowledge event reports
FILE	Transfer data between the relay and external software
GROUP	Display the active group number or select the active group
HELP	Display available commands or command help at each access level
HISTORY	View event summaries/histories; clear event data
HIZ	Displays a report of ground overcurrent high-impedance fault (50G HIZ) detection activity.
ID	Display the firmware id, user id, device code, part number, and configuration information
INI HIF	Restarts the 24-hour tuning process used in high-impedance fault detection.
IRIG	Update the internal clock/calendar from the IRIG-B input
LOG HIF	Displays the progress of the HIF detection in the percentage to their final pickup.
LOOPBACK	Connect MIRRORED BITS data from transmit to receive on the same port
MAP 1	Analyze the communications card database
METER	Display metering data and internal relay operating variables
OACCESS	Go to Access Level O (output control)

Command ^{a, b}	Description
OPEN <i>n</i>	Open the circuit breaker (<i>n</i> = 1 is BK1; <i>n</i> = 2 is BK2)
PACCESS	Go to Access Level P (protection control)
PASSWORD	Change relay passwords
PORT	Connect to a remote relay via MIRRORED BITS virtual terminal (for port number <i>p</i> = 1–3, and F), or the Ethernet card (port <i>p</i> = 5)
PULSE OUT<i>nnn</i>	Pulse a relay control output (OUT <i>nnn</i> is a control output number)
QUIT	Reduce access level to Access Level 0 (exit relay control)
SER	View Sequential Events Recorder reports
SET^c	Enter relay settings
SHOW^c	Display relay settings
SNS	Display Sequential Events Recorder settings name strings (Fast SER)
STATUS	Report or clear relay status and SELOGIC® control equation errors
SUMMARY	View summary event reports
TARGET	Display relay elements for a row in the Relay Word table
TEC	Display time-error estimate; display or modify time-error correction value.
TEST DB	Display or place values in the communications card database (Useful for Ethernet protocol read tests)
TEST DNP	Display or place values in the serial port DNP3 object map
TEST FM	Display or place values in metering database (Fast Meter)
TIME	Display and set the internal clock
TRIGGER	Initiate a data capture and record an event report
VERSION	Display the relay hardware and software configurations
VIEW 1	View data from the communications card database

^a See [Section 9: ASCII Command Reference in the Reference Manual](#)

^b For help on a specific command, type HELP [command] <Enter> at an ASCII terminal communicating with the relay.

^c See the table below for SET/SHOW options.

SET/SHOW Command Options

Option	Setting Type	Description
[S] <i>n</i>	Group Settings 1–6	Particular application settings
A <i>n</i>	Automation Logic Block 1–10	Automation SELOGIC control equations
B	Bay	Bay Control Settings (SEL-451-4)
D	DNP3	Direct Network Protocol remapping (serial port only)
F	Front Panel	Front-panel HMI settings
G	Global 1–6	Relay-wide settings
L <i>n</i>	Protection Logic Group 1–6	Protection SELOGIC control equations
M	Breaker Monitor	Circuit breaker monitor settings
O	Outputs	Output SELOGIC control equations
P <i>n</i>	Port 1–3, F, 5	Communications port settings
R	Report	Event report and SER settings
T	Alias	Alias names for analog quantities and Relay Word bits