SEL-487E-5

Transformer Protection Relay With Sampled Values or TiDL Technology

Instruction Manual

20250214

SEL SCHWEITZER ENGINEERING LABORATORIES

© 2018–2025 by Schweitzer Engineering Laboratories, Inc.

Content subject to change without notice. Unless otherwise agreed in writing, all SEL product sales are subject to SEL's terms and conditions located here: https://selinc.com/company/termsandconditions/.
Part Number: PM487E-05

Table of Contents

List of Tables v

List of Figures xi

Preface xix

Differentiating Between Relay Versions xix
Overview xx
Safety Information xxiii
General Information xxvi

Section 1: Introduction and Specifications

Features 1.3
Models and Options 1.8
Applications 1.10
Product Characteristics 1.22
Specifications 1.24

Section 2: Installation

Shared Configuration Attributes 2.1
Plug-In Boards 2.12
Jumpers 2.14
Relay Placement 2.23
Connection 2.25
Merging Unit AC/DC Connections 2.38

Section 3: Testing

Low-Level Test Interface 3.1
Relay Test Connections 3.4
Checking Relay Operation 3.5
Commissioning Testing 3.31
Technical Support 3.32
SEL-487E Relay Commissioning Test Worksheet 3.33

Section 4: Front-Panel Operations

Front-Panel LCD Default Displays 4.1
Front-Panel Menus and Screens 4.4
Target LEDs 4.14
Front-Panel Operator Control Pushbuttons 4.16
One-Line Diagrams 4.20

Section 5: Protection Functions

Analog Channel Statuses 5.2
Sampled Values Alarm Logic (SEL-487E-5 SV Subscriber) 5.4
TiDL Alarm Logic (SEL-487E-5 TiDL Relay) 5.4
Application Setting SVBLK and Relay Word Bit SVBK_EX 5.5
Selective Protection Disabling 5.5
Differential Zone and Restricted Earth Fault Element Blocking Logic 5.6
Potential Transformer (PT) Ratio Settings With LEA Inputs 5.7
Inverting Polarity of Current and Voltage Inputs 5.12
Voltage Source Selection 5.13
Differential Elements (87) 5.13
CT Sizing 5.49
CT Ratio Selection for a Multiwinding Transformer 5.50
Delta-Connected CTs 5.51

REF Element 5.52
Combined Terminals 5.59
Overcurrent Elements 5.60
Selectable Time-Overcurrent Element (51) 5.68
Terminal Harmonic Blocking 5.75
Line Protection Elements 5.75
Fault Identification Logic 5.96
Directional Control for Ground-Overcurrent Elements 5.99
Best Choice Function Block 5.108
Directional Control for Phase and Negative-Sequence Overcurrent Elements 5.109
Unbalance Current Elements 5.117
Open-Phase Detection Logic 5.119
Breaker Failure Elements 5.120
Volts/Hertz Elements 5.124
Synchronism Check 5.131
Over- and Undervoltage Elements 5.152
Frequency Estimation 5.154
Over- and Underfrequency Elements 5.157
Total Harmonic Distortion 5.158
IEC Thermal Elements 5.159
Over- and Underpower Element 5.164
Trip Logic 5.169
Close Logic 5.171
Autoreclosing 5.172
Loss-of-Potential (LOP) Logic 5.178
Circuit Breaker Status 5.182

Section 6: Protection Application Examples

Transformer Winding and CT Connection Compensation Settings Examples 6.1
References 6.25

Section 7: Metering, Monitoring, and Reporting

Metering 7.1
Circuit Breaker Monitor 7.14
Station DC Battery System Monitor 7.15
Thermal Monitor 7.15
Through-Fault Monitor 7.35
Analog Signal Profiling 7.40
Reporting 7.41

Section 8: Settings

Alias Settings 8.1
Global Settings 8.2
Monitor Settings 8.8
Group Settings 8.12
Protection Logic: Default Settings 8.29
Automation Freeform SELOGIC Control Equations 8.29
Output Settings 8.29
Front-Panel Settings 8.30
Report Settings 8.33
Port Settings 8.33
DNP3 Settings—Custom Maps 8.33
Notes Settings 8.33
Bay Settings 8.33

Section 9: ASCII Command Reference

Description of Commands 9.1

Section 10: Communications Interfaces

Virtual File Interface 10.1
Communications Database 10.1
DNP3 Communication 10.10
IEC 61850 Communication 10.27
Synchrophasors 10.69

Section 11: Relay Word Bits

Alphabetical List 11.1
Row List 11.93

Section 12: Analog Quantities

Appendix A: Firmware, ICD File, and Manual Versions

Firmware A.1
SELBOOT A.10
ICD File A.10
Instruction Manual A.17

SEL-487E-5 Relay Command Summary

This page intentionally left blank

List of Tables

Table 1.1 Interface Board Information 1.8
Table 1.2 Supported 1 A/5 A Terminals Combinations 1.10
Table 1.3 SEL-487E-5 SV Subscriber Relay IEC 61850 Subscriptions, Transformer With Grounding Bank 1.12
Table 1.4 SEL-487E-5 SV Subscriber Relay IEC 61850 Publications, Transformer With Grounding Bank 1.12
Table 1.5 Transformer With Grounding-Bank Subscribed Analog Applications 1.12
Table 1.6 SEL-487E-5 TiDL System Mapping, Transformer With Grounding Bank 1.13
Table 1.7 SEL-487E-5 SV Subscriber Relay IEC 61850 Subscriptions, Autotransformer 1.15
Table 1.8 SEL-487E-5 SV Subscriber Relay IEC 61850 Publications, Autotransformer 1.16
Table 1.9 Autotransformer Subscribed Analog Applications 1.16
Table 1.10 SEL-487E-5 TiDL System Mapping, Autotransformer 1.17
Table 1.11 Application Highlights 1.21
Table 1.12 SEL-487E Relay Characteristics 1.22
Table 2.1 Required Settings for Use With AC Control Signals 2.8
Table 2.2 I/O Interface Boards Control Inputs 2.14
Table 2.3 I/O Interface Boards Control Outputs 2.14
Table 2.4 Main Board Jumpers 2.15
Table 2.5 Serial Port Jumpers 2.17
Table 2.6 I/O Board Jumpers 2.23
Table 2.7 Fuse Requirements for the Power Supply 2.30
Table 2.8 CFG CTNOM Options for Determining Nominal Current for Terminals S, T, and U 2.32
Table 2.9 CFG CTNOM Options for Determining Nominal Current for Terminals W, X, and Y 2.32
Table 3.1 UUT Database Entries for SEL-5401 Relay Test System Software (Analog Input Board Y)—5 A Relay 3.2
Table 3.2 UUT Database Entries for SEL-5401 Relay Test System Software (Analog Input Board Z)—5 A Relay 3.2
Table 3.3 UUT Database Entries for SEL-5401 Relay Test System Software (Analog Input Board Y)—1 A Relay 3.3
Table 3.4 UUT Database Entries for SEL-5401 Relay Test System Software (Analog Input Board Z)—1 A Relay 3.3
Table 3.5 Settings to Test the V/Hz Elements 3.7
Table 3.6 Voltage Values 3.10
Table 3.7 Time Overcurrent Element Settings 3.12
Table 3.8 Unrestrained Phase-Differential Element Settings 3.17
Table 3.9 Differential Element Settings 3.20
Table 3.10 Calculate the Current Values in Amperes (Case 1) 3.22
Table 3.11 Calculate the Current Values in Amperes (Case 2, Stage 1) 3.23
Table 3.12 Calculate the Current Values in Amperes (Case 2, Stage 2) 3.24
Table 3.13 Current Values in Amperes (Case 3) 3.24
Table 3.14 Settings for the Negative-Sequence Test 3.26
Table 3.15 Currents for Negative-Sequence Differential Test 3.26
Table 3.16 Settings to Test the Negative-Sequence Directional Element for Terminal T 3.28
Table 4.1 Metering Screens Enable Settings 4.1
Table 4.2 RMS Values 4.2
Table 4.3 Fundamental Values 4.2
Table 4.4 Energy Quantities 4.3
Table 4.5 Differential Quantities 4.3
Table 4.6 Meter Availability Conditions 4.5
Table 4.7 Event Types 4.12
Table 4.8 LED Settings 4.15
Table 4.9 Pushbutton LED Settings 4.17
Table 5.1 Inverting Polarity Setting 5.12

Table 5.2 Voltage Source Selection Setting Combinations 5.13
Table 5.3 Complete List of Compensation Matrices 5.34
Table 5.4 Relationships Among Input Currents and REF Elements 5.52
Table 5.5 U.S. Operate and Reset Curve Equations 5.69
Table 5.6 IEC Operate and Reset Curve Equations 5.69
Table 5.7 Fundamental or RMS Operating Quantities 5.73
Table 5.8 Line-to-Terminal Setting Integration 5.77
Table 5.9 Terminal-to-Line Relay Word Bit Integration 5.78
Table 5.10 Delta-Wye Faulted Loop Mapping 5.84
Table 5.11 Fault Identification Logic Relay Word Bits 5.97
Table 5.12 Overcurrent Element the Relay Considers When Determining the Faulted Phase(s) 5.98
Table 5.13 Availability of Directional Elements 5.99
Table 5.14 Enable Logic Checks for Negative-Sequence Element 5.100
Table 5.15 Enable Logic Checks for Zero-Sequence Element 5.102
Table 5.16 Directional Element Summary and Example Settings (Terminal S) 5.113
Table 5.17 Directional Element Summary 5.113
Table 5.18 Active V/Hz Elements as a Function of the 24CCS Setting 5.129
Table 5.19 Synchronism-Check Relay Word Bits 5.134
Table 5.20 Active Polarizing Voltage 5.149
Table 5.21 Fundamental or RMS Operating Quantities 5.152
Table 5.22 Frequency Measurement and Frequency Tracking Ranges 5.155
Table 5.23 Frequency Estimation Outputs 5.155
Table 5.24 Summary of the Valpha and 81UVSP Calculations 5.157
Table 5.25 Power Element Operating Quantities (Secondary Values) 5.165
Table 5.26 Autoreclose Logical States for Circuit Breaker m 5.174
Table 5.27 IEC Autoreclose Logical States for Circuit Breaker m 5.175
Table 6.1 TmCTC Setting: Corresponding Phase and Direction of Correction 6.2
Table 6.2 (A, B, C) to (H1, H2, H3) Phase-to-Bushing Connections 6.7
Table 6.3 (A, C, B) to (H1, H2, H3) Phase-to-Bushing Connections 6.8
Table 6.4 Quick Settings Guide for Common Transformer Configurations and Standard Connections 6.25
Table 7.1 MET Command 7.1
Table 7.2 Valid Reference Quantities 7.2
Table 7.3 Quantities in the Fundamental Meter Report 7.3
Table 7.4 Meter Report Settings Summary 7.3
Table 7.5 Quantities in the RMS Meter Report 7.8
Table 7.6 Quantities in the MET SEC Report 7.9
Table 7.7 Quantities in the Demand Metering Report 7.10
Table 7.8 Demand Metering Operating Quantities 7.10
Table 7.9 Quantities in the MET DIF Z1 Report 7.12
Table 7.10 Quantities in the MET DIF Z2 Report 7.13
Table 7.11 Default Transformer Constants 7.17
Table 7.12 T1CS2S and T1CS23 Evaluation 7.25
Table 7.13 Default Transformer Constants 7.30
Table 7.14 Using the THE Command to Access Data Reports 7.35
Table 7.15 Through-Fault Events Report Messages 7.40
Table 7.16 Event Report Nonvolatile Storage Capability When ERDIG = S 7.42
Table 7.17 Event Report Nonvolatile Storage Capability When ERDIG = A 7.42
Table 7.18 Event Report Analog Quantities 7.44
Table 7.19 Differential Report Analog Quantities 7.46
Table 7.20 Event Types 7.49
Table 8.1 Default Alias Settings 8.1
Table 8.2 Global Setting Categories 8.2
Table 8.3 General Global Settings 8.2
Table 8.4 Global Enables 8.2
Table 8.5 Control Inputs (Global) 8.3
Table 8.6 Interface Board #1 Control Inputs 8.3
Table 8.7 Interface Board #n Control Inputs 8.3

Table 8.8 Settings Group Selection 8.3
Table 8.9 Frequency Source Selection 8.4
Table 8.10 Synchronized Phasor Configuration Settings 8.4
Table 8.11 Phasors Included in the Data q 8.5
Table 8.12 Phasor Aliases in Data Configuration q 8.5
Table 8.13 Number of Digital Status Words to Include in Stream q 8.6
Table 8.14 Synchrophasor Digitals in Data Configuration q 8.6
Table 8.15 Synchronized Phasor Configuration Settings Part 2 ....8.6
Table 8.16 Synchronized Phasor Recorder Settings 8.7
Table 8.17 Synchronized Phasor Real-Time Control 8.7
Table 8.18 Time and Date Management 8.7
Table 8.19 Data Reset Control 8.7
Table 8.20 Access Control 8.7
Table 8.21 DNP 8.8
Table 8.22 SV and TiDL Application Settings 8.8
Table 8.23 Monitor Setting Categories 8.8
Table 8.24 Enables 8.8
Table 8.25 Station DC Monitor 8.9
Table 8.26 Breaker Monitor Settings 8.9
Table 8.27 Through-Fault Monitoring 8.10
Table 8.28 Thermal Model Configuration 8.10
Table 8.29 Thermal Probe Selection 8.10
Table 8.30 Cooling Stage Constants for Transformers 8.10
Table 8.31 Default Transformer Constants (When EDFTC = Y) 8.11
Table 8.32 Thermal Loss-of-Life 8.11
Table 8.33 Thermal Alarm Limits 8.11
Table 8.34 IEC Thermal (49) Elements 8.11
Table 8.35 Thermal Ambient Compensation 8.12
Table 8.36 Group Setting Categories 8.12
Table 8.37 Relay Configuration 8.13
Table 8.38 CT Data 8.14
Table 8.39 Potential Transformer Data 8.15
Table 8.40 Voltage Reference Terminal Selection 8.15
Table 8.41 Differential Element Zone 1 (87T) 8.15
Table 8.42 Differential Element Zone 2 (87B) 8.16
Table 8.43 Restricted Earth Fault Element 8.16
Table 8.44 Line 1 Elements 8.17
Table 8.45 Line Configuration 8.17
Table 8.46 Mho Phase Distance Element Reach 8.17
Table 8.47 Quad Phase Distance Element Reach 8.18
Table 8.48 Phase Distance Fault Detectors 8.19
Table 8.49 Mho Ground Distance Element Reach 8.19
Table 8.50 Quad Ground Distance Element Reach 8.19
Table 8.51 Zero-Sequence Compensation Factor 8.20
Table 8.52 Ground Distance Fault Detectors 8.20
Table 8.53 Zone/Level Direction 8.20
Table 8.54 Distance Element Common Time Delay 8.20
Table 8.55 Line Directional Control Settings 8.21
Table 8.56 Out-of-Step Blocking 8.21
Table 8.57 Pole-Open Detection 8.22
Table 8.58 Switch-Onto-Fault Scheme 8.22
Table 8.59 Load Encroachment 8.22
Table 8.60 Line Harmonic Blocking 8.22
Table 8.61 Terminal m Overcurrent and Directional Elements 8.22
Table 8.62 Terminal m Phase Overcurrent Element Level a 8.23
Table 8.63 Terminal m Negative-Sequence Overcurrent Element Levels 8.24
Table 8.64 Terminal m Zero-Sequence Overcurrent Element Levels 8.24
Table 8.65 Terminal m Harmonic Blocking 8.24

Table 8.66 Inverse-Time Overcurrent Elements....8.24
Table 8.67 Terminal Current Unbalance Elements....8.24
Table 8.68 Volts-Per-Hertz Elements....8.25
Table 8.69 Volts-Per-Hertz Level 2 Definite Time....8.25
Table 8.70 Volts-Per-Hertz Level 2, User-Defined Curve h....8.25
Table 8.71 Synchronism-Check (25) Elements....8.25
Table 8.72 Undervoltage (27) Elements....8.26
Table 8.73 Overvoltage (59) Elements....8.26
Table 8.74 Frequency (81) Elements....8.26
Table 8.75 Breaker Failure Logic....8.26
Table 8.76 Overpower (32) Elements....8.27
Table 8.77 Underpower (32) Elements....8.27
Table 8.78 Demand Metering Elements....8.27
Table 8.79 Trip Logic....8.28
Table 8.80 Close Logic....8.28
Table 8.81 Reclosing Logic....8.28
Table 8.82 Main Board Defaults....8.30
Table 8.83 Front-Panel Settings Defaults....8.30
Table 8.84 MIRRORED BITS Protocol Defaults....8.33
Table 8.85 Bay Settings....8.33
Table 9.1 SEL-487E List of Commands....9.2
Table 9.2 EVE DIF Command....9.4
Table 9.3 MET Command....9.5
Table 9.4 MET DIF Command....9.5
Table 9.5 MET DIF A Command....9.5
Table 9.6 MET E Command....9.6
Table 9.7 MET RMS Command....9.6
Table 9.8 MET SEC Command....9.6
Table 9.9 SET Command Overview....9.6
Table 9.10 SHO Command Overview....9.7
Table 9.11 TFE Command....9.8
Table 9.12 THE Command....9.9
Table 10.1 REPORTS Directory Files....10.1
Table 10.2 SEL-487E Database Regions....10.2
Table 10.3 SEL-487E Database Structure—LOCAL Region....10.2
Table 10.4 SEL-487E Database Structure—METER Region....10.2
Table 10.5 SEL-487E DNP LAN/WAN Database Structure—DEMAND Region....10.5
Table 10.6 SEL-487E Database Structure—TARGET Region....10.6
Table 10.7 SEL-487E Database Structure—HISTORY Region....10.6
Table 10.8 SEL-487E Database Structure—BREAKER Region....10.6
Table 10.9 SEL-487E Database Structure—STATUS Region....10.7
Table 10.10 SEL-487E Database Structure—ANALOGS Region....10.8
Table 10.11 SEL-487E Fast Operate Control Bits....10.10
Table 10.12 SEL-487E Binary Input Reference Data Map....10.11
Table 10.13 SEL-487E Binary Output Reference Data Map....10.11
Table 10.14 SEL-487E Binary Counter Reference Data Map....10.12
Table 10.15 SEL-487E Analog Input Reference Data Map....10.13
Table 10.16 SEL-487E Analog Output Reference Data Map....10.18
Table 10.17 SEL-487E Object 12 Control Point Operations....10.19
Table 10.18 Object 30, 32, FTYPE Upper Byte-Event Cause....10.21
Table 10.19 SEL-487E DNP3 Default Binary Input Data Map....10.21
Table 10.20 SEL-487E DNP3 Default Binary Output Data Map....10.23
Table 10.21 SEL-487E DNP3 Default Binary Counter Data Map....10.24
Table 10.22 SEL-487E Default Analog Input Map....10.25
Table 10.23 SEL-487E DNP3 Default Analog Output Data Map....10.27
Table 10.24 Logical Device: PRO (Protection)....10.27
Table 10.25 Logical Device: MET (Metering)....10.55
Table 10.26 Logical Device: MU01 (SV Merging Unit)....10.67

Table 10.27 FLTYPE—Fault Type 10.68
Table 10.28 FLTCAUS—Fault Cause 10.68
Table 10.29 Voltage Synchrophasor Names 10.69
Table 10.30 Current Synchrophasor Names 10.69
Table 10.31 Synchrophasor Order in Data Stream (Voltages and Currents) 10.70
Table 11.1 Alphabetical List of Relay Word Bits 11.1
Table 11.2 Row List of Relay Word Bits 11.93
Table 12.1 Analog Quantities Sorted Alphabetically 12.1
Table 12.2 Analog Quantities Sorted by Function 12.11
Table A.1 Firmware Revision History A.2
Table A.2 SELBOOT Revision History A.10
Table A.3 SEL-487E-5 SV Publisher ICD File Revision History A.11
Table A.4 SEL-487E-5 SV Subscriber ICD File Revision History A.12
Table A.5 SEL-487E-5 TiDL ICD File Revision History A.15
Table A.6 Instruction Manual Revision History A.17

This page intentionally left blank

List of Figures

Figure 1.1 SEL-487E-5 SV Publisher Functional Overview 1.3
Figure 1.2 SEL-487E-5 SV Subscriber or TiDL Relay Functional Overview 1.4
Figure 1.3 Wye-Delta Transformer With Grounding Bank (SV Subscriber) 1.11
Figure 1.4 Wye-Delta Transformer With Grounding Bank (TiDL) 1.13
Figure 1.5 Wye-Delta Transformer With Grounding Bank (Conventional) 1.14
Figure 1.6 Autotransformer Application (SV Subscriber) 1.15
Figure 1.7 Autotransformer Application (TiDL) 1.17
Figure 1.8 Distance Protection for Transformer (TiDL) 1.19
Figure 1.9 Six Terminal Feeder Protection (TiDL) 1.19
Figure 1.10 Consolidated Protection and Control (TiDL) 1.20
Figure 1.11 Consolidated Protection and Control (SV) 1.21
Figure 2.1 Horizontal Front-Panel Template (a); Vertical Front-Panel Template (b) 2.2
Figure 2.2 Rear Panel With Fixed Terminal Blocks (8U) and INT4 I/O Boards 2.4
Figure 2.3 Rear Panel Connectorized (7U) With INT2 I/O Boards 2.5
Figure 2.4 Rear Panel Connectorized With LEA Voltage Inputs (6U) With INT8 I/O Board 2.5
Figure 2.5 SV Subscriber Relay Rear Panel (4U) With INT4 I/O Board 2.6
Figure 2.6 TiDL Relay Rear Panel (4U) With INT4 I/O Board 2.6
Figure 2.7 Standard Control Output Connection 2.9
Figure 2.8 Hybrid Control Output Connection 2.9
Figure 2.9 INT4 High-Speed Control Output Connection 2.10
Figure 2.10 High-Speed Control Output Typical Terminals, INT8 ....2.11
Figure 2.11 Precharging Internal Capacitance of High-Speed Output Contacts, INT8 ....2.11
Figure 2.12 INT2 I/O Interface Board (Standard) 2.13
Figure 2.13 INT4 I/O Interface Board (High-Speed, High-Current) 2.13
Figure 2.14 INTD I/O Interface Board (Standard) 2.13
Figure 2.15 INT7 I/O Interface Board (High-Current) 2.13
Figure 2.16 INT8 I/O Interface Board (High-Speed, High-Current) 2.13
Figure 2.17 Jumper Location on the Main Board 2.15
Figure 2.18 Major Component Locations on the SEL-487E Main Board 2.16
Figure 2.19 Main Components of the EIA-232 Board, Showing the Location of Serial Port Jumpers JMP1 and JMP2 ....2.17
Figure 2.20 Major Jumper and Connector Locations on the INT2 I/O Board 2.19
Figure 2.21 Major Jumper and Connector Locations on the INT4 I/O Board 2.20
Figure 2.22 Major Jumper and Connector Locations on the INT8 I/O Board 2.21
Figure 2.23 Major Jumper and Connector Locations on the INT7 I/O Board 2.22
Figure 2.24 SEL-487E 4U Chassis Dimensions 2.24
Figure 2.25 SEL-487E 6U, 7U, and 8U Chassis Dimensions 2.25
Figure 2.26 Rear-Panel Symbols 2.26
Figure 2.27 Screw-Terminal Connector Keying 2.27
Figure 2.28 Rear-Panel Receptacle Keying 2.28
Figure 2.29 Power Connection Area of the Rear Panel 2.29
Figure 2.30 Control Output OUT215 ....2.33
Figure 2.31 SEL-487E to Computer—D-Subminiature 9-Pin Connector 2.35
Figure 2.32 Four 100BASE-FX Port Configuration 2.37
Figure 2.33 Four 10/100BASE-T Port Configuration 2.37
Figure 2.34 100BASE-FX and 10/100BASE-T Port Configuration 2.37
Figure 2.35 Two 100/1000BASE and Three 100BASE SFP Ports 2.37
Figure 2.36 Autotransformer Application 2.39
Figure 2.37 Typical External DC Connections 2.40
Figure 2.38 Wiring Connections for Open-Delta Connected PTs 2.41
Figure 3.1 Low-Level Test Interface J24 ....3.2

Figure 3.2 Low-Level Test Interface J14 ..... 3.2
Figure 3.3 Test Network Topology 3.4
Figure 3.4 Test Connections for Balanced Load With Three-Phase Current Sources 3.5
Figure 3.5 Voltage Test Connections 3.5
Figure 3.6 User-Defined V/Hz Curve 1 ..... 3.6
Figure 3.7 Group Settings for the V/Hz Test 3.7
Figure 3.8 Logic Settings for the V/Hz Test 3.8
Figure 3.9 Front-Panel Settings for the V/Hz Test 3.9
Figure 3.10 SER Settings for the V/Hz Test 3.9
Figure 3.11 Element Assert and Operate Times (105%) 3.10
Figure 3.12 Element Assert and Operate Times (107%) 3.11
Figure 3.13 C1 Curve 3.11
Figure 3.14 Group Settings for the 51 Tests 3.13
Figure 3.15 Setting the SER 3.14
Figure 3.16 Clearing the SER 3.14
Figure 3.17 SER Results 3.14
Figure 3.18 RB01 Asserted 3.14
Figure 3.19 Test 2 SER Results 3.15
Figure 3.20 RB02 Asserted 3.15
Figure 3.21 Test 3 SER Results 3.15
Figure 3.22 REF Characteristic and Test Setup 3.16
Figure 3.23 Group Settings 3.17
Figure 3.24 Differential Element Comparator 3.19
Figure 3.25 Differential Element Characteristic 3.19
Figure 3.26 Group Settings for the Differential Test 3.20
Figure 3.27 Values for Case 1 ..... 3.22
Figure 3.28 Values for Case 2 ..... 3.23
Figure 3.29 Enable Overcurrent Element for Terminal T 3.25
Figure 3.30 Enter Overcurrent Element in the SER 3.25
Figure 3.31 Group Settings for the Directional Test 3.29
Figure 3.32 Front-Panel Settings 3.30
Figure 3.33 RELAY ELEMENTS LCD Screen Containing Elements TF32Q and TR32Q 3.30
Figure 3.34 Connections for Directional Element Test 3.31
Figure 4.1 Sample ROTATING DISPLAY 4.3
Figure 4.2 METER Menus 4.5
Figure 4.3 Line Voltages, Single Terminal, and Combined Terminal Options 4.6
Figure 4.4 RMS Meter Screens 4.7
Figure 4.5 RMS Combined Terminals 4.7
Figure 4.6 Fundamental Single Terminal Screens 4.8
Figure 4.7 Demand Meter Screens 4.10
Figure 4.8 Energy Meter Screens 4.11
Figure 4.9 Differential Meter Screen 4.11
Figure 4.10 EVENT SUMMARY Screen 4.12
Figure 4.11 BREAKER MONITOR Report Screens 4.13
Figure 4.12 VIEW CONFIGURATION Sample Screens 4.14
Figure 4.13 Factory-Default Front-Panel Target LEDs 4.15
Figure 4.14 Operator Control Pushbuttons and LEDs 4.17
Figure 4.15 Factory-Default Operator Control Pushbuttons 4.19
Figure 5.1 IAS Channel Status Processing (Similar for Other Terminals) 5.2
Figure 5.2 Voltage Terminal Status Logic 5.3
Figure 5.3 Current Terminal Status Logic for Terminal S (Similar for Other Current Terminals) 5.3
Figure 5.4 Current Channel Freeze Logic for Channel S (Similar for Other Current Channels) 5.3
Figure 5.5 General Sampled Values Alarm Logic (SVSALM) 5.4
Figure 5.6 General TiDL Alarm Logic 5.5
Figure 5.7 Extended Application Blocking Logic (SVBK_EX) 5.5
Figure 5.8 Selective Protection Disabling Overview 5.6

Figure 5.9 Zone 1 Differential Blocking Logic 5.7
Figure 5.10 Blocking Logic for Restricted Earth Fault Element 5.7
Figure 5.11 Low-Energy Analog (LEA) Voltage Sensor 5.8
Figure 5.12 Zone 1 Terminal Selection and Matrix Compensation....5.15
Figure 5.13 Zone 2 Terminal Selection and Polarity Compensation....5.16
Figure 5.14 Filtered Differential-Element Characteristic 5.17
Figure 5.15 A-Phase Internal and External Fault Detection Logic and Harmonic Filtering 5.18
Figure 5.16 A-Phase Harmonic Logic 5.20
Figure 5.17 Dwell-Time Intervals in the Inrush Currents....5.22
Figure 5.18 Sufficient Operate Current Check 5.22
Figure 5.19 Waveshape Dwell-Time Inrush Detection Logic for Three-Legged, Three-Phase Transformers 5.22
Figure 5.20 Waveshape Dwell-Time Inrush Detection Logic for A-Phase....5.23
Figure 5.21 Waveshape Blocking Logic....5.24
Figure 5.22 Differential Currents for an Internal Fault During Inrush Conditions....5.24
Figure 5.23 Fault Current During Energization (Black) Compared With Positive (Red) and Negative (Blue) Thresholds 5.25
Figure 5.24 A-Phase Bipolar Low-Set Signature Detection Logic....5.25
Figure 5.25 A-Phase Bipolar Low-Set Logic....5.26
Figure 5.26 A-Phase Unblocking Logic 5.26
Figure 5.27 A-Phase Bipolar High-Set Signature Detection Logic 5.27
Figure 5.28 A-Phase Bipolar High-Set Logic....5.27
Figure 5.29 Zone 1 A-Phase Percentage-Restrained Differential Element....5.29
Figure 5.30 Two-Winding Transformer....5.37
Figure 5.31 Differential Operations 5.41
Figure 5.32 Negative-Sequence Percentage-Restrained Differential Element 5.42
Figure 5.33 Negative-Sequence Differential-Element Blocking Logic....5.42
Figure 5.34 A-Phase Unrestrained Differential Element 5.44
Figure 5.35 Worst-Case Inrush Current for Setting U87P....5.46
Figure 5.36 Combined Differential Tripping....5.47
Figure 5.37 Zone 2 A-Phase Percentage-Restrained Differential Element....5.48
Figure 5.38 Common CT Between Differential Zones....5.49
Figure 5.39 REF Directional Element....5.52
Figure 5.40 REF 1 Element Enable Logic 5.53
Figure 5.41 Algorithm That Performs the Directional Calculations....5.54
Figure 5.42 REF Negative-Sequence Summation Logic 5.54
Figure 5.43 REF Element Trip Output....5.55
Figure 5.44 Internal Fault With LV Breaker Open....5.55
Figure 5.45 Programmable 51 REF Element 5.56
Figure 5.46 REF Neutral Element....5.56
Figure 5.47 Single-Wye Winding REF Application....5.58
Figure 5.48 Autotransformer REF Application 5.58
Figure 5.49 Autotransformer With Two-HV CT REF Application....5.59
Figure 5.50 Three-Winding Transformer With Two REF Elements 5.59
Figure 5.51 Two CTs on HV Side 5.60
Figure 5.52 Equivalent Single CT on HV Side....5.60
Figure 5.53 Phase Instantaneous Overcurrent Element 5.61
Figure 5.54 Negative-Sequence Instantaneous Overcurrent Element....5.62
Figure 5.55 Zero-Sequence Instantaneous Overcurrent Element 5.62
Figure 5.56 Three Settings Possibilities....5.63
Figure 5.57 ECTTERM and EPTTERM Settings....5.63
Figure 5.58 E50 and E51 Enables....5.64
Figure 5.59 Enable Overcurrent and Directional Elements for Terminal S....5.64
Figure 5.60 Negative-Sequence Definite-Time Overcurrent Settings 5.64
Figure 5.61 Voltage Reference Terminal Selection Setting....5.65
Figure 5.62 Enable Overcurrent and Directional Elements for Terminal T 5.65

Figure 5.63 Disable Definite-Time Overcurrent Elements 5.65
Figure 5.64 Terminal T Directional 51 Element Settings 5.66
Figure 5.65 Enable Overcurrent and Directional Elements for Terminal U 5.66
Figure 5.66 Terminal U Directional 50 Element Setting 5.67
Figure 5.67 U.S. Curves: U1, U2, U3, and U4 ....5.70
Figure 5.68 U.S. Curve U5 and IEC Curves C1, C2, and C3 ....5.71
Figure 5.69 IEC Curves C4 and C5 ....5.72
Figure 5.70 Time-Overcurrent Element 5.72
Figure 5.71 Phase Inrush Detection Logic for Terminal m 5.75
Figure 5.72 Source Assignment for Single Current Terminal 5.76
Figure 5.73 Source Assignment for Combined Current Terminal 5.77
Figure 5.74 Pole-Open Diagram 5.79
Figure 5.75 Zone 1 CVT Transient Detection Logic 5.80
Figure 5.76 OOS Characteristics 5.81
Figure 5.77 OOS Positive-Sequence Measurements 5.82
Figure 5.78 OOS Blocking Logic 5.83
Figure 5.79 OOS Override Logic 5.83
Figure 5.80 Mho Phase Distance Element Characteristic 5.85
Figure 5.81 Mho Phase Distance Element Logic 5.85
Figure 5.82 Quadrilateral Phase Distance Element Characteristic (TANGP = 0) 5.87
Figure 5.83 Quadrilateral Phase Distance Element Characteristic (TANGP = —10 degrees) 5.87
Figure 5.84 Quadrilateral Phase Distance Element Logic 5.88
Figure 5.85 Mho Ground Distance Element Logic 5.89
Figure 5.86 Quadrilateral Ground Distance Element Logic 5.92
Figure 5.87 Zone 1–4 Distance Element Logic 5.93
Figure 5.88 Common Zone Timers 5.93
Figure 5.89 SOTF Logic 5.94
Figure 5.90 Load-Encroachment Logic 5.95
Figure 5.91 Load-Encroachment Characteristics 5.95
Figure 5.92 A-Phase Line Inrush and Overexcitation Detection Logic 5.96
Figure 5.93 Sector Determination Block Diagram 5.97
Figure 5.94 Block Diagram Showing Determination of the Particular Phase(s) Involved in the Fault 5.98
Figure 5.95 Block Diagram of the Directional Elements 5.99
Figure 5.96 Internal Enables for Negative-Sequence (m32QE) and Zero-Sequence (m32QGE) Directional Elements 5.101
Figure 5.97 Internal Enable (m32VE) for Zero-Sequence Directional Element 5.102
Figure 5.98 Negative-Sequence Directional Calculation Logic (Ground Elements) 5.103
Figure 5.99 Negative-Sequence Directional Element Characteristic 5.103
Figure 5.100 Close-In, Single-Phase Fault F1 and Fault F2 ....5.103
Figure 5.101 Phasor Relationships for an A-Phase-to-Ground Fault 5.104
Figure 5.102 Phasor Relationships for a Reverse A-Phase-to-Ground Fault 5.105
Figure 5.103 Zero-Sequence Directional Element Characteristic 5.106
Figure 5.104 Zero-Sequence Directional Calculation Logic 5.107
Figure 5.105 Single Negative-Sequence and Zero-Sequence Directional Element Output 5.108
Figure 5.106 Negative-Sequence Directional Element 5.109
Figure 5.107 Positive-Sequence Directional Element 5.110
Figure 5.108 Positive-Sequence Memory Voltage 5.110
Figure 5.109 Phase Directional Element 5.112
Figure 5.110 CTPm Changes the Polarity of the CTs for the Directional Elements 5.114
Figure 5.111 Unbalance Logic for Terminal m, A-Phase 5.118
Figure 5.112 Unbalance Blocking Logic for Terminal m 5.118
Figure 5.113 A-Phase Open-Phase Detection Logic 5.119
Figure 5.114 Breaker Failure Logic for Terminal m When BF_SCHM = Y 5.120
Figure 5.115 Breaker Failure Logic for Terminal m When BF_SCHM = Y1 ....5.121
Figure 5.116 Alternate Breaker Failure Logic for Terminal k 5.122

Figure 5.117 Current Redistribution in a Dual-Breaker Configuration 5.122
Figure 5.118 Levels 1 and 2 V/Hz 5.125
Figure 5.119 Two-Level, Definite-Time V/Hz Logic 5.126
Figure 5.120 Logic for the User-Defined Curves 5.127
Figure 5.121 V/Hz Curve From Manufacturer 5.127
Figure 5.122 Three- and Sixteen-Point Curves 5.128
Figure 5.123 Partial Breaker-and-a-Half or Partial Ring-Bus Breaker Arrangement 5.131
Figure 5.124 Synchronism-Check Voltages for Two Circuit Breakers 5.132
Figure 5.125 Synchronism-Check Settings 5.133
Figure 5.126 Synchronism-Check Relay Word Bits 5.134
Figure 5.127 Example Synchronism-Check Voltage Connections to the SEL-487E-5 ....5.136
Figure 5.128 Synchronism-Check Voltage Reference 5.137
Figure 5.129 Normalized Synchronism-Check Voltage Sources V_{SS} and V_{ST} 5.138
Figure 5.130 Healthy Voltage Window and Indication 5.139
Figure 5.131 Synchronism-Check Voltage Difference Logic 5.139
Figure 5.132 Synchronism-Check Enable Logic 5.140
Figure 5.133 Breaker S Slip-Frequency Check Logic 5.141
Figure 5.134 Static (Not Slipping) Synchronism-Check Elements 5.141
Figure 5.135 Slipping Synchronism-Check Elements 5.142
Figure 5.136 “No-Slip” System Synchronism-Check Element Output Response 5.143
Figure 5.137 “Slip—No Compensation” Synchronism-Check Element Output Response 5.144
Figure 5.138 “Slip—With Compensation” Synchronism-Check Element Output Response 5.146
Figure 5.139 Alternative Synchronism-Check Source T Example and Settings 5.148
Figure 5.140 Alternative Synchronism-Check Polarizing Voltage Selection Logic 5.149
Figure 5.141 Alternative Synchronism-Check Polarizing Voltage Example System 5.151
Figure 5.142 Undervoltage Elements 5.152
Figure 5.143 Overvoltage Elements 5.152
Figure 5.144 SEL-487E Alpha Quantity Calculation 5.155
Figure 5.145 Undervoltage Supervision Logic 5.156
Figure 5.146 Frequency Element Logic 5.158
Figure 5.147 Thermal Alarming and Tripping Logic 5.161
Figure 5.148 Primary Plant Connections 5.164
Figure 5.149 Complex Power Measurement Conventions 5.164
Figure 5.150 Selection of Operating Quantities 5.165
Figure 5.151 Overpower Element Logic 5.165
Figure 5.152 Load Flow Towards Load 5.166
Figure 5.153 Reverse Load Flow 5.166
Figure 5.154 Reactive Power Characteristic 5.167
Figure 5.155 Underpower Element Logic 5.167
Figure 5.156 Transformer Trip Logic 5.169
Figure 5.157 Circuit Breaker Trip Logic 5.170
Figure 5.158 TRIP Logic 5.170
Figure 5.159 Close Logic for Breaker m 5.171
Figure 5.160 Autoreclose State Diagram for Circuit Breaker m 5.174
Figure 5.161 IEC Autoreclose Logical States for Circuit Breaker m 5.174
Figure 5.162 Circuit Breaker Pole-Open Logic 5.176
Figure 5.163 Three-Pole Reclose Enable Logic 5.176
Figure 5.164 Three-Pole Cycle State for Breaker m 5.177
Figure 5.165 Logic that Calculates the Change in Current 5.179
Figure 5.166 LOP Logic for Potential Transformer V 5.180
Figure 5.167 Logic to Detect Abnormal Voltage Condition 5.182
Figure 5.168 Circuit Breaker Status 5.182
Figure 6.1 Transformer Nameplate 6.3
Figure 6.2 Three-Line Diagram Showing System Phase-to-Transformer Bushing, CT, and CT-to-Relay Connections 6.4
Figure 6.3 Primary Current Phasors 6.4

Figure 6.4 Current at the Relay Terminals 6.5
Figure 6.5 Standard System Phase-to-Transformer Bushing Connections 6.6
Figure 6.6 X- and H-Side Current Phasors for Figure 6.5 ....6.6
Figure 6.7 Non-Standard System Phase-to-Transformer Bushing Connections 6.7
Figure 6.8 X- and H-Side Current Phasors for Figure 6.7 ....6.7
Figure 6.9 Combination of Standard and Non-Standard Phase-to-Bushing Connection Diagram 6.8
Figure 6.10 X- and H-Side Current Phasors for Figure 6.9 ....6.9
Figure 6.11 Standard CT Connections 6.9
Figure 6.12 Primary System Current and Current as Seen by the Relay 6.10
Figure 6.13 Current Flow With Reversed X-Side CT Polarity 6.10
Figure 6.14 Current Flow With Reversed X-Side CT Polarity and Reversed Connections 6.11
Figure 6.15 Results of Reversed X-Side CT Polarity and Reversed Connections 6.11
Figure 6.16 Delta-Wye Transformer With Standard Phase-to-Bushing Connections 6.13
Figure 6.17 Differential Current Measured by the Relay 6.13
Figure 6.18 Delta-Wye Transformer With Non-Standard Phase-to-Bushing Connections for Example 6.2 ....6.14
Figure 6.19 IAS and IAT for Example 6.2 ....6.15
Figure 6.20 Wye-Delta Transformer With Non-Standard CT Connections on X-Side 6.16
Figure 6.21 System Currents on H-Side (Wye) and X-Side (Delta) of the Transformer 6.16
Figure 6.22 Comparison of Standard and Non-CT Connections on X-Side of Transformer 6.17
Figure 6.23 Autotransformer With Standard Phase-to-Bushing Connections 6.18
Figure 6.24 Primary Currents and Secondary Currents as Measured by the Relay 6.19
Figure 6.25 Delta-Delta Transformer With Standard Phase-to-Bushing Connections 6.19
Figure 6.26 X- and H-Side Current Phasors for Figure 6.25 ....6.20
Figure 6.27 Differential Current Measured by the Relay 6.20
Figure 6.28 Delta-Wye Transformer With Standard Phase-to-Bushing Connections With an ACB Phase Rotation 6.21
Figure 6.29 X- and H-Side Current Phasors for Figure 6.28 ....6.22
Figure 6.30 System Phase Rotation 6.22
Figure 6.31 Primary Currents and Secondary Currents as Measured by the Relay 6.22
Figure 6.32 Common Transformer Connections 6.24
Figure 7.1 Fundamental Quantities Report With VREFS = OFF and EPTTERM = OFF 7.4
Figure 7.2 Fundamental Quantities Report With VREFS = OFF and EPTTERM = V, Z 7.5
Figure 7.3 Fundamental Quantities With EPCAL = OFF 7.6
Figure 7.4 Fundamental Quantities Report 7.7
Figure 7.5 Complex Power (P/Q) Plane 7.8
Figure 7.6 RMS Report for Terminal S 7.9
Figure 7.7 MET SEC Report for Terminal T 7.10
Figure 7.8 Demand Report With Four Elements Enabled 7.11
Figure 7.9 Synchrophasor Report 7.11
Figure 7.10 Zone 1 Differential-Element Report 7.13
Figure 7.11 Zone 2 Differential-Element Report 7.13
Figure 7.12 Expanded Differential-Element Report 7.14
Figure 7.13 Top-Oil and Hot-Spot Temperatures 7.16
Figure 7.14 Cooling System Efficiency Logic 7.19
Figure 7.15 Oil Temperature Logic 7.28
Figure 7.16 Hot-Spot Logic 7.28
Figure 7.17 Aging Acceleration Factors Logic 7.28
Figure 7.18 Daily Rate of Loss-of-Life Logic 7.29
Figure 7.19 Total Loss-of-Life Logic 7.29
Figure 7.20 Thermal Condition (TEC) Logic for Transformer 1 ....7.30
Figure 7.21 Example System Block Diagram 7.31
Figure 7.22 Transformer Bank Subjected to Through Fault 7.36
Figure 7.23 Category IV Transformers Through-Fault Protection Curves 7.36
Figure 7.24 Through-Fault Diagram 7.38
Figure 7.25 Result of the TFE Command 7.39

Figure 7.26 Preload the Values of the Accumulated Data 7.40
Figure 7.27 Compressed ASCII Data Display 7.41
Figure 7.28 Profile Data in Excel Spreadsheet 7.41
Figure 7.29 Profile Data Reset 7.41
Figure 7.30 Analog Section of the Event Report 7.44
Figure 7.31 Differential Report 7.45
Figure 7.32 Digital Section of the Event Report 7.47
Figure 7.33 Sample Digital Portion of the Event Report 7.47
Figure 7.34 Summary Section of the Event Report 7.48
Figure 7.35 Sample Event Summary Report 7.48
Figure 10.1 MAP 1:METER Command Example 10.8

This page intentionally left blank

Preface

This manual provides information and instructions for installing and operating the relay. The manual is for use by power engineers and others experienced in protective relaying applications. Included are detailed technical descriptions of the relay and application examples. While this manual gives reasonable examples and illustrations of relay uses, you must exercise sound judgment at all times when applying the relay in a power system.

Differentiating Between Relay Versions

Unless otherwise indicated, the functionality of the SEL-487E discussed in this manual is common in both the traditional hardwired models (SEL-487E-3, -4, -5) and the model that exclusively supports digital secondary system (DSS) technology (SEL-487E-5). Should there be differences or logic that is specific to one version of the SEL-487E-5, the section indicates it is only for the specific version identified (for example, *Sampled Values Alarm Logic (SEL-487E-5 SV Subscriber) on page 5.4* is specific logic for the SV subscriber version of the SEL-487E-5).

The SEL-487E-5 supports DSS and can be ordered as either a Sampled Values (SV) subscriber relay, SV publisher relay, or an SEL TiDL relay. The supported DSS technology of the relay is locked at the time of order, and you cannot change the relay to support a DSS technology other than the one it was explicitly manufactured for; you can only use the SV subscriber relay version in networks that conform to IEC 61850-9-2LE, and you can only use the TiDL relay in an SEL TiDL system where it communicates with SEL TiDL Merging Units (TMUs). SV publisher relays can also be used as traditional hardwire relays if SV functionality is not required.

The following table highlights the currently available relays for order and their corresponding instruction manuals.

SEL-487E Relay Versions (Sheet 1 of 2)

Relay Model	High-Level Overview	Instruction Manual
SEL-487E-3, -4 Traditional Relay SEL-487E-5 SV Publisher (for traditional applications)		See the *SEL-487E-3, -4 Instruction Manual* Use this manual for the SEL-487E-5 SV Publisher
SEL-487E-3, -4 TiDL Relay With Axion[a]		See the *SEL-487E-3, -4 Instruction Manual*

SEL-487E Relay Versions (Sheet 2 of 2)

Relay Model	High-Level Overview	Instruction Manual
SEL-487E-5 SV Subscriber or SEL-487E-5 SV Publisher		Use this manual
SEL-487E-5 TiDL Relay With the SEL-TMU		Use this manual

[a] TiDL (EtherCAT) technology is no longer offered in the SEL-487E-3, -4. TiDL (T-Protocol) is available in the SEL-487E-5.

Overview

The SEL-487E-5 Instruction Manual consists of two volumes:

- SEL-487E-5 Instruction Manual
- SEL-400 Series Relays Instruction Manual

The SEL-487E-5 manual set is a comprehensive work covering all aspects of relay application and use. Read the sections that pertain to your application to gain valuable information about using the SEL-487E-5. An overview of each manual section and section topics follows.

SEL-487E Instruction Manual

Preface. Describes manual organization and conventions used to present information, as well as safety information.

Section 1: Introduction and Specifications. Introduces SEL-487E-5 features, summarizes relay functions and applications, and lists relay specifications, type tests, and ratings.

Section 2: Installation. Discusses the ordering configurations and interface features (control inputs, control outputs, and analog inputs, for example). Provides information about how to design a new physical installation and secure the relay in a panel or rack. Details how to set relay board jumpers and make proper rear-panel connections (including connecting to merging units and a GPS receiver). Explains basic connections for the relay communications ports.

Section 3: Testing. Describes techniques for testing the relay.

Section 4: Front-Panel Operations. Describes the LCD display messages and menu screens that are unique to the SEL-487E.

Section 5: Protection Functions. Describes the function of various relay protection elements. Describes how the relay processes these elements. Gives detailed specifics on protection scheme logic for the differential elements. Provides trip logic diagrams, and current and voltage source selection details.

Section 6: Protection Application Examples. Provides examples of configuring the SEL-487E-5 for some common applications.

Section 7: Metering, Monitoring, and Reporting. Describes SEL-487E specific metering, monitoring, and reporting features.

Section 8: Settings. Provides a list of all relay settings and defaults. The settings list is organized in the same order as in the relay and in the SEL Grid Configurator Software.

Section 9: ASCII Command Reference. Provides an alphabetical listing of all ASCII commands with examples for each ASCII command option.

Section 10: Communications Interfaces. Describes the SEL-487E specific communications characteristics.

Section 11: Relay Word Bits. Contains a summary of Relay Word bits.

Section 12: Analog Quantities. Contains a summary of analog quantities.

Appendix A: Firmware, ICD File, and Manual Versions. Lists the current firmware and manual versions and details differences between the current and previous versions.

SEL-400 Series Relays Instruction Manual

Preface. Describes manual organization and conventions used to present information, as well as safety information.

Section 1: Introduction. Introduces SEL-400 series relay common features.

Section 2: PC Software. Explains how to use SEL Grid Configurator and ACSELERATOR QuickSet SEL-5030 Software.

Section 3: Basic Relay Operations. Describes how to perform fundamental operations such as applying power and communicating with the relay, setting and viewing passwords, checking relay status, viewing metering data, reading event reports and Sequential Events Recorder (SER) records, operating relay control outputs and control inputs, and using relay features to make relay commissioning easier.

Section 4: Front-Panel Operations. Describes the LCD messages and menu screens. Shows you how to use front-panel pushbuttons and read targets. Provides information about local substation control and how to make relay settings via the front panel.

Section 5: Control. Describes various control features of the relay, including circuit breaker operation, disconnect operation, remote bits, and one-line diagrams.

Section 6: Autoreclosing. Explains how to operate the two-circuit breaker multishot recloser. Describes how to set the relay for single-pole reclosing, three-pole reclosing, or both. Shows selection of the lead and follow circuit breakers.

Section 7: Metering. Provides information on viewing current, voltage, power, and energy quantities. Describes how to view other common internal operating quantities.

Section 8: Monitoring. Describes how to use the circuit breaker monitors and the substation dc battery monitors.

Section 9: Reporting. Explains how to obtain and interpret high-resolution raw data oscillograms, filtered event reports, event summaries, history reports, and SER reports. Discusses how to enter SER trigger settings.

Section 10: Testing, Troubleshooting, and Maintenance. Describes techniques for testing, troubleshooting, and maintaining the relay. Includes the list of status notification messages and a troubleshooting chart.

Section 11: Time and Date Management. Explains timekeeping principles, synchronized phasor measurements, and estimation of power system states using the high-accuracy time-stamping capability. Presents real-time load flow/power flow application ideas.

Section 12: Settings. Provides a list of all common SEL-400 Series Relay settings and defaults.

Section 13: SELOGIC Control Equation Programming. Describes multiple setting groups and SELOGIC control equations and how to apply these equations. Discusses expanded SELOGIC control equation features such as PLC-style commands, math functions, counters, and conditioning timers. Provides a tutorial for converting older format SELOGIC control equations to new freeform equations.

Section 14: ASCII Command Reference. Provides an alphabetical listing of all ASCII commands with examples for each ASCII command option.

Section 15: Communications Interfaces. Explains the physical connection of the relay to various communications network topologies. Describes the various software protocols and how to apply these protocols to substation integration and automation. Includes details about Ethernet IP protocols, SEL ASCII, SEL Compressed ASCII, SEL Fast Meter, SEL Fast Operate, SEL Fast SER, and enhanced MIRRORED BITS communications.

Section 16: DNP3 Communication. Describes the DNP3 communications protocol and how to apply this protocol to substation integration and automation. Provides a Job Done example for implementing DNP3 in a substation.

Section 17: IEC 61850 Communication. Describes the IEC 61850 protocol and how to apply this protocol to substation automation and integration. Includes IEC 61850 protocol compliance statements.

Section 18: Synchrophasors. Describes the phasor measurement unit (PMU) functions of the relay. Provides details on synchrophasor measurement and real-time control. Describes the IEEE C37.118 synchrophasor protocol settings. Describes the SEL Fast Message synchrophasor protocol settings.

Section 19: Digital Secondary Systems. Describes the basic concepts of digital secondary systems (DSS). This includes both the Time-Domain Link (TiDL) system and UCA 61850-9-2LE Sampled Values.

Appendix A: Manual Versions. Lists the current manual version and details differences between the current and previous versions.

Appendix B: Firmware Upgrade Instructions. Describes the procedure to update the firmware stored in Flash memory.

Appendix C: Cybersecurity Features. Describes the various features of the relay that impact cybersecurity.

Glossary. Defines various technical terms used in the SEL-400 Series Relays instruction manuals.

Safety Information

Dangers, Warnings, and Cautions

This manual uses three kinds of hazard statements, defined as follows:

⚠DANGER
Indicates an imminently hazardous situation that, if not avoided, **will** result in death or serious injury.

⚠WARNING
Indicates a potentially hazardous situation that, if not avoided, **could** result in death or serious injury.

⚠CAUTION
Indicates a potentially hazardous situation that, if not avoided, **may** result in minor or moderate injury or equipment damage.

Safety Symbols

The following symbols are often marked on SEL products.

	⚠CAUTION Refer to accompanying documents.	**⚠ATTENTION** Se reporter à la documentation.
	Earth (ground)	Terre
	Protective earth (ground)	Terre de protection
	Direct current	Courant continu
	Alternating current	Courant alternatif
	Both direct and alternating current	Courant continu et alternatif
	Instruction manual	Manuel d'instructions

Safety Marks

The following statements apply to this device.

General Safety Marks

⚠CAUTION There is danger of explosion if the battery is incorrectly replaced. Replace only with Rayovac no. BR2335 or equivalent recommended by manufacturer. See Owner's Manual for safety instructions. The battery used in this device may present a fire or chemical burn hazard if mistreated. Do not recharge, disassemble, heat above 100°C, or incinerate. Dispose of used batteries according to the manufacturer's instructions. Keep battery out of reach of children.	⚠ATTENTION Une pile remplacée incorrectement pose des risques d'explosion. Remplacez seulement avec un Rayovac no BR2335 ou un produit équivalent recommandé par le fabricant. Voir le guide d'utilisateur pour les instructions de sécurité. La pile utilisée dans cet appareil peut présenter un risque d'incendie ou de brûlure chimique si vous en faites mauvais usage. Ne pas recharger, démonter, chauffer à plus de 100°C ou incinérer. Éliminez les vieilles piles suivant les instructions du fabricant. Gardez la pile hors de la portée des enfants.
⚠CAUTION To ensure proper safety and operation, the equipment ratings, installation instructions, and operating instructions must be checked before commissioning or maintenance of the equipment. The integrity of any protective conductor connection must be checked before carrying out any other actions. It is the responsibility of the user to ensure that the equipment is installed, operated, and used for its intended function in the manner specified in this manual. If misused, any safety protection provided by the equipment may be impaired.	⚠ATTENTION Pour assurer la sécurité et le bon fonctionnement, il faut vérifier les classements d'équipement ainsi que les instructions d'installation et d'opération avant la mise en service ou l'entretien de l'équipement. Il faut vérifier l'intégrité de toute connexion de conducteur de protection avant de réaliser d'autres actions. L'utilisateur est responsable d'assurer l'installation, l'opération et l'utilisation de l'équipement pour la fonction prévue et de la manière indiquée dans ce manuel. Une mauvaise utilisation pourrait diminuer toute protection de sécurité fournie par l'équipement.
For use in Pollution Degree 2 environment.	Pour l'utilisation dans un environnement de Degré de Pollution 2.

Other Safety Marks (Sheet 1 of 3)

⚠DANGER Disconnect or de-energize all external connections before opening this device. Contact with hazardous voltages and currents inside this device can cause electrical shock resulting in injury or death.	⚠DANGER Débrancher tous les raccordements externes avant d'ouvrir cet appareil. Tout contact avec des tensions ou courants internes à l'appareil peut causer un choc électrique pouvant entraîner des blessures ou la mort.
⚠DANGER Contact with instrument terminals can cause electrical shock that can result in injury or death.	⚠DANGER Tout contact avec les bornes de l'appareil peut causer un choc électrique pouvant entraîner des blessures ou la mort.
⚠WARNING Use of this equipment in a manner other than specified in this manual can impair operator safety safeguards provided by this equipment.	⚠AVERTISSEMENT L'utilisation de cet appareil suivant des procédures différentes de celles indiquées dans ce manuel peut désarmer les dispositifs de protection d'opérateur normalement actifs sur cet équipement.
⚠WARNING Have only qualified personnel service this equipment. If you are not qualified to service this equipment, you can injure yourself or others, or cause equipment damage.	⚠AVERTISSEMENT Seules des personnes qualifiées peuvent travailler sur cet appareil. Si vous n'êtes pas qualifiés pour ce travail, vous pourriez vous blesser avec d'autres personnes ou endommager l'équipement.
⚠WARNING This device is shipped with default passwords. Default passwords should be changed to private passwords at installation. Failure to change each default password to a private password may allow unauthorized access. SEL shall not be responsible for any damage resulting from unauthorized access.	⚠AVERTISSEMENT Cet appareil est expédié avec des mots de passe par défaut. A l'installation, les mots de passe par défaut devront être changés pour des mots de passe confidentiels. Dans le cas contraire, un accés non-autorisé á l'équipement peut être possible. SEL décline toute responsabilité pour tout dommage résultant de cet accés non-autorisé.
⚠WARNING Do not look into the fiber ports/connectors.	⚠AVERTISSEMENT Ne pas regarder vers les ports ou connecteurs de fibres optiques.
⚠WARNING Do not look into the end of an optical cable connected to an optical output.	⚠AVERTISSEMENT Ne pas regarder vers l'extrémité d'un câble optique raccordé à une sortie optique.
⚠WARNING Do not perform any procedures or adjustments that this instruction manual does not describe.	⚠AVERTISSEMENT Ne pas appliquer une procédure ou un ajustement qui n'est pas décrit explicitement dans ce manuel d'instruction.
⚠WARNING During installation, maintenance, or testing of the optical ports, use only test equipment qualified for Class 1 laser products.	⚠AVERTISSEMENT Durant l'installation, la maintenance ou le test des ports optiques, utilisez exclusivement des équipements de test homologués comme produits de type laser de Classe 1.

Other Safety Marks (Sheet 2 of 3)

⚠WARNING Incorporated components, such as LEDs and transceivers are not user serviceable. Return units to SEL for repair or replacement.	**⚠AVERTISSEMENT** Les composants internes tels que les leds (diodes électroluminescentes) et émetteurs-récepteurs ne peuvent pas être entretenus par l'usager. Retourner les unités à SEL pour réparation ou remplacement.
⚠CAUTION Equipment components are sensitive to electrostatic discharge (ESD). Undetectable permanent damage can result if you do not use proper ESD procedures. Ground yourself, your work surface, and this equipment before removing any cover from this equipment. If your facility is not equipped to work with these components, contact SEL about returning this device and related SEL equipment for service.	**⚠ATTENTION** Les composants de cet équipement sont sensibles aux décharges électrostatiques (DES). Des dommages permanents non-décelables peuvent résulter de l'absence de précautions contre les DES. Raccordez-vous correctement à la terre, ainsi que la surface de travail et l'appareil avant d'en retirer un panneau. Si vous n'êtes pas équipés pour travailler avec ce type de composants, contacter SEL afin de retourner l'appareil pour un service en usine.
⚠CAUTION Equipment damage can result from connecting ac circuits to Hybrid (high-current interrupting) control outputs. Do not connect ac circuits to Hybrid control outputs. Use only dc circuits with Hybrid control outputs.	**⚠ATTENTION** Des dommages à l'appareil pourraient survenir si un circuit CA était raccordé aux contacts de sortie à haut pouvoir de coupure de type "Hybrid." Ne pas raccorder de circuit CA aux contacts de sortie de type "Hybrid." Utiliser uniquement du CC avec les contacts de sortie de type "Hybrid."
⚠CAUTION Substation battery systems that have either a high resistance to ground (greater than 10 kΩ) or are ungrounded when used in conjunction with many direct-coupled inputs can reflect a dc voltage offset between battery rails. Similar conditions can exist for battery monitoring systems that have high-resistance balancing circuits or floating grounds. For these applications, SEL provides optional ground-isolated (optoisolated) contact inputs. In addition, SEL has published an application advisory on this issue. Contact the factory for more information.	**⚠ATTENTION** Les circuits de batterie de postes qui présentent une haute résistance à la terre (plus grande que 10 kΩ) ou sont isolés peuvent présenter un biais de tension CC entre les deux polarités de la batterie quand utilisés avec plusieurs entrées à couplage direct. Des conditions similaires peuvent exister pour des systèmes de surveillance de batterie qui utilisent des circuits d'équilibrage à haute résistance ou des masses flottantes. Pour ce type d'applications, SEL peut fournir en option des contacts d'entrée isolés (par couplage optoélectronique). De surcroît, SEL a publié des recommandations relativement à cette application. Contacter l'usine pour plus d'informations.
⚠CAUTION If you are planning to install an INT4 I/O interface board in your relay, first check the firmware version of the relay. If the firmware version is R111 or lower, you must first upgrade the relay firmware to the newest version and verify that the firmware upgrade was successful before installing the new board. Failure to install the new firmware first will cause the I/O interface board to fail, and it may require factory service. Complete firmware upgrade instructions are provided when new firmware is ordered.	**⚠ATTENTION** Si vous avez l'intention d'installer une Carte d'Interface INT4 I/O dans votre relais, vérifiez en premier la version du logiciel du relais. Si la version est R111 ou antérieure, vous devez mettre à jour le logiciel du relais avec la version la plus récente et vérifier que la mise à jour a été correctement installée sur la nouvelle carte. Les instructions complètes de mise à jour sont fournies quand le nouveau logiciel est commandé.
⚠CAUTION Field replacement of I/O boards INT1, INT2, INT5, INT6, INT7, or INT8 with INT4 can cause I/O contact failure. The INT4 board has a pickup and dropout delay setting range of 0–1 cycle. For all other I/O boards, pickup and dropout delay settings (IN201PU–IN224PU, IN201DO–IN224DO, IN301PU–IN324PU, and IN301DO–IN324DO) have a range of 0–5 cycles. Upon replacing any I/O board with an INT4 board, manually confirm reset of pickup and dropout delays to within the expected range of 0–1 cycle.	**⚠ATTENTION** Le remplacement en chantier des cartes d'entrées/sorties INT1, INT2, INT5, INT6, INT7 ou INT8 par une carte INT4 peut causer la défaillance du contact d'entrée/sortie. La carte INT4 présente un intervalle d'ajustement pour les délais de montée et de retombée de 0 à 1 cycle. Pour toutes les autres cartes, l'intervalle de réglage du délai de montée et retombée (IN201PU–IN224PU, IN201DO– IN224DO, IN301PU–IN324PU, et IN301DO–IN324DO) est de 0 à 5 cycles. Quand une carte d'entrées/sorties est remplacée par une carte INT4, vérifier manuellement que les délais de montée et retombée sont dans l'intervalle de 0 à 1 cycle.
⚠CAUTION Do not install a jumper on positions A or D of the main board J21 header. Relay misoperation can result if you install jumpers on positions J21A and J21D.	**⚠ATTENTION** Ne pas installer de cavalier sur les positions A ou D sur le connecteur J21 de la carte principale. Une opération intempestive du relais pourrait résulter suite à l'installation d'un cavalier entre les positions J21A et J21D.
⚠CAUTION Insufficiently rated insulation can deteriorate under abnormal operating conditions and cause equipment damage. For external circuits, use wiring of sufficiently rated insulation that will not break down under abnormal operating conditions.	**⚠ATTENTION** Un niveau d'isolation insuffisant peut entraîner une détérioration sous des conditions anormales et causer des dommages à l'équipement. Pour les circuits externes, utiliser des conducteurs avec une isolation suffisante de façon à éviter les claquages durant les conditions anormales d'opération.
⚠CAUTION Relay misoperation can result from applying other than specified secondary voltages and currents. Before making any secondary circuit connections, check the nominal voltage and nominal current specified on the rear-panel nameplate.	**⚠ATTENTION** Une opération intempestive du relais peut résulter par le branchement de tensions et courants secondaires non conformes aux spécifications. Avant de brancher un circuit secondaire, vérifier la tension ou le courant nominal sur la plaque signalétique à l'arrière.

Other Safety Marks (Sheet 3 of 3)

⚠CAUTION Severe power and ground problems can occur on the communications ports of this equipment as a result of using non-SEL cables. Never use standard null-modem cables with this equipment.	⚠ATTENTION Des problèmes graves d'alimentation et de terre peuvent survenir sur les ports de communication de cet appareil si des câbles d'origine autre que SEL sont utilisés. Ne jamais utiliser de câble de modem nul avec cet équipement.
⚠CAUTION Do not connect power to the relay until you have completed these procedures and receive instruction to apply power. Equipment damage can result otherwise.	⚠ATTENTION Ne pas mettre le relais sous tension avant d'avoir complété ces procédures et d'avoir reçu l'instruction de brancher l'alimentation. Des dommages à l'équipement pourraient survenir autrement.
⚠CAUTION Use of controls or adjustments, or performance of procedures other than those specified herein, may result in hazardous radiation exposure.	⚠ATTENTION L'utilisation de commandes ou de réglages, ou l'application de tests de fonctionnement différents de ceux décrits ci-après peuvent entraîner l'exposition à des radiations dangereuses.

General Information

The SEL-487E Instruction Manual uses certain conventions that identify particular terms and help you find information. To benefit fully from reading this manual, take a moment to familiarize yourself with these conventions.

Typographic Conventions

There are three ways to communicate with the SEL-487E-5:

- Using a command line interface on a PC terminal emulation window, such as Microsoft HyperTerminal
- Using the front-panel menus and pushbuttons
- Using QuickSet or SEL Grid Configurator

The instructions in this manual indicate these options with specific font and formatting attributes. The following table lists these conventions:

Example	Description
STATUS	Commands, command options, and command variables typed at a command line interface on a PC.
n **SUM *n***	Variables determined based on an application (in bold if part of a command).
<Enter>	Single keystroke on a PC keyboard.
<Ctrl+D>	Multiple/combination keystroke on a PC keyboard.
Start > Settings	PC software dialog boxes and menu selections. The > character indicates submenus.
ENABLE	Relay front- or rear-panel labels and pushbuttons.
`MAIN > METER`	Relay front-panel LCD menus and relay responses visible on the PC screen. The > character indicates submenus.

Logic Diagrams

Logic diagrams in this manual follow the conventions and definitions shown below.

NAME	SYMBOL	FUNCTION
Comparator	A, B, +, −, C	Input A is compared to Input B. Output C asserts if Input A is greater than Input B.
Input Flag	A	Input A comes from other logic.
OR	A, B, C	If either Input A or Input B asserts, Output C asserts.
Exclusive OR	A, B, C	If either Input A or Input B asserts, Output C asserts. If Input A and Input B are of the same state, Output C deasserts.
NOR	A, B, C	If neither Input A nor Input B asserts, Output C asserts.
AND	A, B, C	If Input A and Input B assert, Output C asserts.
AND w/ Inverted Input	A, B, C	If Input A asserts and Input B deasserts, Output C asserts. Inverter "O" inverts any input or output on any gate.
NAND	A, B, C	If Input A and/or Input B deassert, Output C asserts.
Time-Delayed Pick Up and/or Time-Delayed Drop Out	A, X, Y, B	X is a time-delay-pickup value; Y is a time-delay-dropout value. Output B asserts Time X after Input A asserts; Output B does not assert if Input A does not remain asserted for Time X. If Time X is zero, Output B asserts when Input A asserts. If Time Y is zero, Input B deasserts when Input A deasserts.
Edge Trigger Timer	A, X, Y, B	Rising edge of Input A starts timers. Output B asserts Time X after the rising edge of Input A. Output B remains asserted for Time Y. If Time Y is zero, Output B asserts for a single processing interval. Input A is ignored while the timers are running.
Set-Reset/Flip-Flop	S, Q, R	Input S asserts Output Q until Input R asserts. Output Q deasserts or resets when Input R asserts.
Falling Edge	A ⌉ B	Output B asserts at the falling edge of Input A.
Rising Edge	A ⌈ B	Output B asserts at the rising edge of Input A.

Trademarks

All brand or product names appearing in this document are the trademark or registered trademark of their respective holders. No SEL trademarks may be used without written permission.

SEL trademarks appearing in this manual are shown in the following table.

ACSELERATOR Architect®	SEL-2240 Axion®
ACSELERATOR QuickSet®	SELBOOT®
Best Choice Ground Directional Element®	SELOGIC®
MIRRORED BITS®	SYNCHROWAVE®

EtherCAT is registered trademark and patented technology, licensed by Beckhoff Automation GmbH, Germany.

Technical Support

We appreciate your interest in SEL products and services. If you have questions or comments, please contact us at:

Schweitzer Engineering Laboratories, Inc.
2350 NE Hopkins Court
Pullman, WA 99163-5603 U.S.A.
Tel: +1.509.338.3838
Fax: +1.509.332.7990
Internet: selinc.com/support
Email: info@selinc.com

SECTION 1

Introduction and Specifications

The SEL-487E-5 provides a suite of current and voltage elements for the comprehensive protection of power transformers. In total, the relay consists of 24 analog channels, divided into three groups of analog inputs. The first group consists of 15 channels for phase current inputs that are divided into five groups of three-phase inputs. The second group consists of either three channels for single-phase current inputs or a sixth three-phase current input. The third group consists of six channels for two three-phase voltage inputs.

There are three versions of the SEL-487E-5 available: a Sampled Values (SV) publisher, an SV subscriber, or an SEL Time-Domain Link (TiDL) relay.

The SEL-487E-5 SV Publisher and SV Subscriber profiles are compliant with UCA International Users Group's "Implementation Guideline for Digital Interface to Instrument Transformers Using IEC 61850-9-2," also known as UCA 61850-9-2LE or 9-2LE. The SV subscriber supports subscriptions for as many as seven SV merging units. See *Section 2: Installation* for more details about SV applications.

The SEL-487E-5 TiDL relay is designed exclusively for SEL TiDL systems. SEL TiDL relays communicate with as many as eight SEL TiDL Merging Units (TMUs) over direct, point-to-point fiber-optic connections. See *Section 2: Installation* for more details about TiDL applications.

In addition to transformer protection, the relay is suited for other current differential protection such as busbar protection for as many as six terminals with mismatched CT ratios as high as 35:1. When installed as busbar protection, use the relay as a PMU and a station-wide digital fault recorder to collect data from each of the six terminals.

As main protection for power transformers, current-operated protection includes two adaptive-slope phase percentage restraint differential elements, an unrestraint differential element, a negative-sequence percentage restraint differential element, programmable restricted earth fault (REF) elements, breaker failure protection for each terminal, and several voltage-polarized directional and nondirectional phase, negative-sequence and zero-sequence definite-time and inverse-time overcurrent elements. Available as an ordering option, the SEL-487E provides four zones of phase and ground distance protection as transformer backup or line distance protection.

Select secondary current inputs from a combination of 1 A and 5 A on a per-terminal basis for the phase input terminals (Terminal S through Terminal X), or a combination of 1 A and 5 A on a per-phase basis on the neutral terminals (Terminal Y).

Voltage-operated transformer protection includes under- and overfrequency elements, under- and overpower elements, several phase, positive-sequence, negative-sequence and zero-sequence voltage elements, and two levels of volts-per-hertz protection.

System measurement, monitoring, and reports include an IEEE C57.91-1995 thermal element, IEEE C37.118-2005-compliant synchrophasor measurements, an IEEE C57.109-1993 through-fault current monitor, breaker wear monitoring for each individual pole, battery voltage monitoring, sequential event reporting (SER), and 8 kHz COMTRADE event reports. Collect data from as many as 12 temperature measuring elements when used with the SEL-2600 RTD Module.

For customized protection and automation functions, use the SELOGIC control equations with extensive programming capabilities. Because protection and automation programming require different execution times, the relay provides separate programming areas for protection and automation programming. You can organize automation SELOGIC control equation programming into 10 blocks of 100 program lines each for a total of 1000 lines of automation programming. Use as many as 250 lines in the separate protection programming area to program custom protection functions.

Communications interfaces include standard SEL ASCII and enhanced MIRRORED BITS communications protocols. Establish Ethernet connectivity with the Ethernet card to employ common industry communications tools including Telnet, FTP, DNP3 LAN/WAN, and IEC 61850 Edition 2.1 protocols.

Purchase of an SEL-487E-5 includes the SEL Grid Configurator. SEL Grid Configurator is SEL's relay configuration software package. SEL Grid Configurator assists you in setting, controlling, and acquiring data from the relay. For the SEL TiDL relays, use SEL Grid Configurator to configure and then commission your TiDL system. ACSELERATOR Architect SEL-5032 Software is included as well. Architect enables you to view and configure IEC 61850 GOOSE and MMS settings via a graphical user interface (GUI). In SV relays, you can set your SV mapping settings in Architect or SEL Grid Configurator.

This section introduces the SEL-487E and provides information on the following topics:

- *Features on page 1.3*
- *Models and Options on page 1.8*
- *Applications on page 1.10*
- *Product Characteristics on page 1.22*
- *Specifications on page 1.14*

Features

The SEL-487E contains many protection, automation, and control features. *Figure 1.2* presents a simplified functional overview of the relay.

Figure 1.1 SEL-487E-5 SV Publisher Functional Overview

ANSI NUMBERS/ACRONYMS AND FUNCTIONS	
16 SEC	Access Security (Serial, Ethernet)
21*	Phase and Ground Distance
24	Volts/Hertz
25	Synchronism Check
27	Undervoltage
32	Directional Power
46	Current Unbalance
49	IEEE C59.71 and IEC 60255-Compliant Thermal Model
50BF	Dual Breaker Failure Overcurrent
50N	Neutral Overcurrent
50	Overcurrent (Phase, Zero-Sequence, and Negative-Sequence)
51N	Neutral Time-Overcurrent
51	Time-Overcurrent (Phase, Zero-Sequence, and Negative-Sequence)
59	Overvoltage
67	Directional Overcurrent (Phase, Zero-Sequence, and Negative-Sequence)
68*	Out-of-Step Block
79*	Autoreclosing
81	Over- and Underfrequency
85 RIO	SEL MIRRORED BITS Communications
87T	Transformer Differential (Unrestrained, Restrained, Neg. Seq.)
87B*	Bus Differential (Restrained)

ADDITIONAL FUNCTIONS	
BRM	Breaker Wear Monitor
DFR	Event Reports
ENV	SEL-2600 RTD Module*
HBL	Harmonic Blocking
HMI	Operator Interface
LDP	Load Data Profiling
LGC	SELOGIC Control Equations
MET	High-Accuracy Metering
PMU	Synchrophasors
REF	Restricted Earth Fault
RTU	Remote Terminal Unit
SER	Sequential Events Recorder
SBM	Station Battery Monitor
SIP	Software-Invertible Polarities
TRM	Transformer Monitor

[1] Copper or Fiber Optic * Optional Feature

ANSI NUMBERS/ACRONYMS AND FUNCTIONS	
16 SEC	Access Security (Serial, Ethernet)
21*	Phase and Ground Distance
24	Volts/Hertz
25	Synchronism Check
27	Undervoltage
32	Directional Power
46	Current Unbalance
49	IEEE C59.71 and IEC 60255-Compliant Thermal Model
50BF	Dual Breaker Failure Overcurrent
50N	Neutral Overcurrent
50	Overcurrent (Phase, Zero-Sequence, and Negative-Sequence)
51N	Neutral Time-Overcurrent
51	Time-Overcurrent (Phase, Zero-Sequence, and Negative-Sequence)
59	Overvoltage
67	Directional Overcurrent (Phase, Zero-Sequence, and Negative-Sequence)
68*	Out-of-Step Block
79*	Autoreclosing
81	Over- and Underfrequency
85 RIO	SEL Mirrored Bits Communications
87T	Transformer Differential (Unrestrained, Restrained, Neg. Seq.)
87B*	Bus Differential (Restrained)

ADDITIONAL FUNCTIONS	
BRM	Breaker Wear Monitor
DFR	Event Reports
ENV	SEL-2600 RTD Module*
HBL	Harmonic Blocking
HMI	Operator Interface
LDP	Load Data Profiling
LGC	SELogic Control Equations
MET	High-Accuracy Metering
PMU	Synchrophasors
REF	Restricted Earth Fault
RTU	Remote Terminal Unit
SBM	Station Battery Monitor
SER	Sequential Events Recorder
SIP	Software-Invertible Polarities
TRM	Transformer Monitor

* Optional Feature
Note: Both copper and fiber-optic Ethernet ports are available.

Five-port Ethernet card ordering option depicted.

Figure 1.2 SEL-487E-5 SV Subscriber or TiDL Relay Functional Overview

The SEL-487E features include the following:

IEC 61850 Operating Modes. The relay supports IEC 61850 standard operating modes such as Test, Blocked, On, and Off, in addition to the separate IEC 61850 simulation mode.

Digital Current Summation. The relay can combine incoming current data digitally for mapped terminal inputs to simplify external wiring.

IEC 61850 SV Publications (SEL-487E-5 SV Publisher Only). The SEL-487E-5 SV Publisher supports as many as seven SV publications compliant with UCA 9-2LE guidelines. Per the guideline, each publication includes one Application Data Service Unit (ASDU) with four current and four voltage channels. The supported publication rate is 4.8 kHz for a 60 Hz power system and 4 kHz for a 50 Hz power system.

IEC 61850 SV Subscription (SEL-487E-5 SV Subscriber Only). The SEL-487E-5 SV Subscriber supports as many as seven SV subscriptions. SV message subscription complies with UCA 9-2LE guidelines. The SEL-487E only accepts 9-2LE-compliant SV messages with 1 ASDU. Each subscription includes four current and four voltage channels. The supported SV subscription message rate is 4.8 kHz for a 60 Hz power system and 4 kHz for a 50 Hz power system.

SEL TiDL Technology (SEL-487E-5 TiDL Relay Only). The SEL-487E-5 TiDL relay supports communicating with as many as eight SEL-TMUs over direct, point-to-point fiber-optic connections.

Selective Protection Disabling. The SEL-487E-5 provides selective disabling of protection functions through hard-coded logic or available torque-control equations due to loss of communication between your merging unit and relay that results in the loss of relevant analog data.

Restraint Differential Element. The SEL-487E provides two independent restraint differential zones. Zone 1 has additional features for transformer protection, such as inrush detection and a negative sequence differential. Innovative algorithms switch the relay within 2 milliseconds to a high-security mode during through-fault conditions for maximum security. While in the high-security mode, the algorithm does not block the differential elements, thus avoiding unnecessary time delays for clearing faults evolving from external-to-internal faults.

Unrestrained Differential Element. This element operates independent of the harmonic content of the differential current, providing fast, unrestraint tripping for high-current transformer faults, such as bushing faults. The unrestrained differential element compliments the phase-differential elements, particularly during inrush conditions when harmonics in the differential current may cause the restraint differential elements to operate slower. Waveshape-based inrush detection addresses inrush conditions that contain low second- and fourth-harmonic content.

Negative-Sequence Differential Element. Use the negative-sequence differential element to provide greater sensitivity for turn-to-turn faults during heavy load conditions, when phase-current differential elements are less sensitive.

REF Element. Provides fast, sensitive protection for ground faults close to the neutral for grounded wye-transformer windings.

CT Ratio Mismatch. Mismatched CTs of ratios as high as 35:1 can be installed. For example, one set of CTs in a breaker-and-a-half installation can have CT ratios of 4000/5 and the other set of CTs can have CT ratios of 120/5.

1 A/5 A CT Ratio Combination. Set each three-phase terminal input for either 1 A or 5 A secondary current SV subscriptions. For the REF CTs, set each single phase input for either 1 A or 5 A secondary SV subscriptions.

Distance Element. The SEL-487E protects transformers and transmission lines with four zones of phase distance and ground distance elements by using mho or quadrilatrial characteristics. Security of the distance element is enhanced with line harmonic blocking, out-of-step blocking logic, capacitively coupled voltage transformer (CCVT) transient overreach logic, and load encroachment logic.

Out-of-Step Blocking. Select out-of-step blocking of distance elements on unstable power swings.

Second-Harmonic Blocking for Feeder Protection. Order the second-harmonic blocking option to secure feeder protection elements during inrush conditions. This option provides second-harmonic calculations for each individual terminal in addition to transformer differential harmonic blocking elements.

Breaker Failure Protection. The SEL-487E provides breaker failure protection for each of the six current terminals, initiated by either phase current, zero-sequence current, or a combination of phase current and zero-sequence current. To reduce breaker failure coordination time, advanced open-phase detection ensures current-element reset in less than one cycle.

Nondirectional Overcurrent Elements. Compliment the differential elements with a large number of instantaneous, definite-time, and adaptive inverse-time phase overcurrent elements; instantaneous, definite-time, and inverse-time residual (zero-sequence) overcurrent elements; instantaneous, definite-time, and inverse-time negative-sequence overcurrent elements, as well as combined overcurrent elements (inverse-time for phase and ground) for applications such as stations with breaker-and-a-half layouts.

Directional Overcurrent Elements. Convert any nondirectional overcurrent element to a directional overcurrent with a range of voltage-polarized directional elements.

Voltage Elements. The SEL-487E provides phase overvoltage and undervoltage elements, phase-to-phase overvoltage and undervoltage elements, as well as positive-sequence, negative-sequence, and zero-sequence voltage elements for each of the two sets of voltage inputs.

Synchronism Check. The SEL-487E includes synchronism-check elements for as many as six breakers. The synchronism-check function incorporates slip frequency, maximum angle difference, maximum voltage difference, breaker close time, and allows different sources of synchronizing voltage.

Frequency Elements. Any of the six levels of frequency elements can operate as either an underfrequency element, or as an overfrequency element. The frequency elements are suited for applications such as underfrequency load shedding and restoration control systems.

Volts-per-Hertz Elements. Combining the voltage elements with the frequency elements, the SEL-487E offers two levels of volts-per-hertz elements; one level for an unloaded transformer, and the other level for a loaded transformer.

Reclosing. Incorporate programmable reclosing of six independent breakers into an integrated substation control system.

Power Elements. Set the per-phase power elements to detect real and reactive power flow for applications such as reverse power protection/control and overpower and/or underpower protection/control.

Monitoring Elements. Use the SEL-487E to monitor a variety of items in the substation. To monitor the transformer insulation health, use the thermal element based on IEEE Std C57.91-1995, Guide for Loading Mineral-Oil-Immersed Power Transformer; monitor the ac ripple and battery ground faults with the built-in battery monitor; calculate the percentage breaker wear and record the number of operations to optimize breaker maintenance with the breaker wear monitor. Monitor the transformer through-fault current on a per-phase basis to determine the impact of through faults on the transformer windings.

Fault Identification Logic. Determines which phase(s) was involved in a fault for which the transformer tripped on a per-terminal basis. Faulted phase identification is based on current inputs from wye-connected CTs.

Synchrophasor. The relay provides IEEE C37.118-compliant synchrophasors for all 24 channels. The relay supports five independent synchrophasor data streams that can be channeled through both serial and Ethernet ports. The relay supports message rates as high as 60 messages per second and three different filters. The relay can record synchrophasor data for as many as 120 seconds. The relay can process synchrophasor data from a remote source for real-time control.

Parallel Redundancy Protocol (PRP). Provide seamless recovery from any single Ethernet network failure with this protocol, in accordance with IEC 62439-3. You can connect all PRP compatible devices in two independent networks and duplicate the traffic on both. The station bus and process bus Ethernet networks support PRP.[1]

High-Availability Seamless Redundancy (HSR) Protocol. Provide seamless recovery from any single Ethernet network failure with this protocol, in accordance with IEC 62439-3. You can connect all HSR compatible devices in a ring, fully duplicate the traffic, and send the traffic in both clockwise and counterclockwise directions around the ring. The station bus and process bus Ethernet networks support HSR.[1]

Expanded SELOGIC Control Equations. Modify and set custom relay applications with PLC-style (programmable logic controller, IEC 61131-3) SELOGIC control equation programming that includes math and comparison functions. Use counters and multifunction timers for greater application flexibility, i.e., perform advanced PLC functions within the relay. The SEL-487E has separate protection and automation SELOGIC control equation programming areas. These programming areas provide ample protection programming capability and 10 blocks of 100-line automation programming capability (1000 lines).

Alias Settings. Use as many as 200 aliases to rename any digital or analog quantity in the relay. These aliases are then available for use in customized programming, making the initial programming and maintenance much easier.

Metering. View primary or secondary rms or fundamental metering information for phase currents and angles of all terminals, phase voltages, and angles, as well as the per-unit operating and restraint values from all differential elements.

Control. Open and close breakers and disconnects from the front panel with the bay control function. Obtain custom-build screens to match your transformer layout.

Oscillography and Event Reporting. Record raw and/or filtered currents, voltages, and digital information (8 kHz, COMTRADE format) that you select. Investigate relay internal logic points and power system performance with event report phasor analysis.

Sequential Events Recorder (SER). Record 1000 system entries from 250 monitoring points, including settings changes, power ups, and Relay Word bit elements that you select. Set element names to easily understood aliases.

[1] Only the five-port Ethernet card ordering option supports PRP on both the station bus and the process bus. HSR is only supported on the five-port Ethernet card.

Digital Relay-to-Relay Communication. Use MIRRORED BITS communications to monitor internal element conditions between relays within a substation and between substations by using communication channels (SEL fiber-optic transceivers to send a direct transfer trip, for example).

Ethernet Communications Capability. Implement control and data gathering capabilities via substation LANs and company WANs with the Ethernet card. Employ the FTP protocol for system data acquisition. Use Telnet for remote terminal interface. Use DNP3 and IEC 61850 for SCADA. Employ SNTP or Precision Time Protocol (PTP) for time synchronization.

Rules-Based Settings Editor. Communicate with and set the relay by using an ASCII terminal, or use the PC-based SEL Grid Configurator to configure the SEL-487E-5.

IEC 60255-Compliant Thermal Model. Use the relay to provide a configurable thermal model for the protection of a wide variety of devices.

Models and Options

Consider the following options when ordering and configuring the SEL-487E.

- DSS connector type
  - IEC 61850-9-2LE-compliant SV publisher
  - IEC 61850-9-2LE-compliant SV subscriber
  - SEL TiDL relay with T-Protocol
- Chassis size
  - U is one rack unit—1.75 in or 44.45 mm
    - SEL-487E-5 SV Subscriber or TiDL relay supports 4U only
    - SEL-487E-5 SV Publisher supports 6U, 7U, and 8U

Table 1.1 Interface Board Information

Board Name	Inputs	Description	Outputs	Description
INT2	8	Optoisolated, independent, level-sensitive	13	Standard Form A
			2	Standard Form C
INT4	18	Two sets of 9 common optoisolated, level-sensitive	6	High-speed, high-current interrupting, Form A
	6	Optoisolated, independent, level-sensitive	2	Standard Form A
INT7	8	Optoisolated, independent, level-sensitive	13	High-current interrupting, Form A
			2	Standard Form C
INT8	8	Optoisolated, independent, level-sensitive	8	High-speed, high-current interrupting, Form A
INTD	18	Two sets of 9 common optoisolated, level-sensitive	8	Standard Form A
	6	Optoisolated, independent, level-sensitive		

- Voltage ranges for the inputs on the main board as well as for the inputs on the four interface boards
  - 24 Vdc
  - 48 Vdc
  - 110 Vdc
  - 125 Vdc

- 220 Vdc
- 250 Vdc

- Connector type
  - Screw-terminal block inputs
  - Connectorized
- Conformal coat
  - Conformal coating provides an additional barrier to harsh environments, such as high humidity and airborne contaminants. See selinc.com/conformalcoating/ for more information.
- Power supply
  - 24–48 Vdc
  - 48–125 Vdc or 110–120 Vac
  - 125–250 Vdc or 110–240 Vac
- Voltage channel options
  - 300 V phase-to-neutral wye configuration PT inputs
  - Two three-phase, 8 Vac, C37.92-compliant LEA inputs
- Ethernet card options
  - Four-port Ethernet card with port combinations of:
    - Four copper (10BASE-T/100BASE-TX)
    - Four fiber (100BASE-FX)
    - Two copper (10BASE-T/100BASE-TX) and two fiber (100BASE-FX)
  - Five-port Ethernet card with small form-factor pluggable (SFP) ports (100BASE-FX and 1000BASE-X)[2]

NOTE: The SEL-487E-5 can be ordered with either SV publication or SV subscription.

- Communications protocols
  - Complete group of SEL protocols (SEL ASCII, SEL Compressed ASCII, SEL Settings File Transfer, SEL Fast Meter, SEL Fast Operate, SEL Fast SER, resistance temperature detectors (RTDs), Enhanced MIRRORED BITS Communications), DNP3, and Synchrophasors (SEL Fast Message and IEEE C37.118 format)
  - Above protocols plus IEC 61850 Edition 2.1

Contact the SEL factory or your local Technical Service Center for particular part number and ordering information (see *Technical Support on page 3.32*). You can also view the latest part number and ordering information on the SEL website at selinc.com.

Current Channel Options

For SV subscriber or TiDL devices, the relay ships with all current channels set for 5 A CTs by default. Set the subscribed secondary nominal current for any one of the five terminals (S, T, U, W, X) to either 1 A or 5 A (all three phases 1 A or 5 A) by using the CFG **CTNOM** command. Neutral terminals (three inputs of Terminal Y) can have each of the individual inputs set to use either 1 A or 5 A nominal current. For example, select 5 A secondary currents for the three phases of Terminal S, 5 A secondary currents for the three phases of Terminal T, 1 A

[2] All ports support 100 Mbps speeds. **PORT 5A** and **PORT 5B** also support 1 Gbps speeds.

secondary currents for the three phases of Terminal U, 5 A secondary current for REF 1 (first neutral current input), and 1 A secondary current for REF 2 (second neutral current input).

NOTE: In the R400 firmware, the **CFG CTNOM** command defaults all relay settings. Starting in the R401 firmware, **CFG CTNOM** only defaults the global and group protection settings on a nominal secondary current configuration change.

Although each three-phase terminal (S, T, U, W, and X) can be either 1 A or 5 A, and the Y-terminals either 1 A or 5 A on a per-phase basis, all SEL-487E-5 models, including SV publishers, support the combinations shown in *Table 1.2*.

Table 1.2 Supported 1 A/5 A Terminals Combinations

Terminals S, T, U	Terminals W, X, IY1, IY2, IY3
Terminal S = 5 A Terminal T = 5 A Terminal U = 5 A	Terminal W = 5 A Terminal X = 5 A Terminal IY1, IY2, IY3 = 5 A, 5 A, 5 A
Terminal S = 5 A Terminal T = 5 A Terminal U = 1 A	Terminal W = 5 A Terminal X = 5 A Terminal IY1, IY2, IY3 = 5 A, 5 A, 1 A
Terminal S = 5 A Terminal T = 1 A Terminal U = 1 A	Terminal W = 5 A Terminal X = 5 A Terminal IY1, IY2, IY3 = 5 A, 1 A, 1 A
Terminal S = 1 A Terminal T = 1 A Terminal U = 1 A	Terminal W = 5 A Terminal X = 5 A Terminal IY1, IY2, IY3 = 1 A, 1 A, 1 A Terminal W = 1A Terminal X = 1A Terminal IY1, IY2, IY3 = 5 A, 5 A, 5 A Terminal W = 1 A Terminal X = 1 A Terminal IY1, IY2, IY3 = 5 A, 5 A, 1 A Terminal W = 1 A Terminal X = 1 A Terminal IY1, IY2, IY3 = 5 A, 1 A, 1 A Terminal W = 1 A Terminal X = 1 A Terminal IY1, IY2, IY3 = 1 A, 1 A, 1 A

Applications

Use the SEL-487E for as many as six restraint windings for transformers at power plants, transmission stations, distribution stations, and industrial plants. For information on connecting the relay, see *Section 2: Installation*.

The SEL-487E has five sets of three-phase analog current inputs (IS, IT, IU, IW, and IX), three neutral analog current inputs (IY1, IY2, and IY3), and two sets of three-phase analog voltage inputs (VY and VZ). For applications that do not require REF protection, neutral analog current inputs (IY1, IY2, and IY3) can be used as a sixth set of three-phase analog current inputs (IAY, IBY, ICY). The drawings that follow use a two-letter acronym to represent all three phases of a relay analog input. For example, IW represents IAW, IBW, and ICW for A-, B-, and C-Phase current inputs on Terminal W, respectively. The drawings list a separate phase designator if you need only one or two phases of the analog input set (VAZ for the A-Phase voltage of the VZ input set, for example).

Transformer With Grounding Bank

NOTE: Use caution if summing current data external to the SEL-487E. For percent restraint differential applications external current summation could cause an unexpected reduction in restraint current if misapplied.

Figure 1.3, *Figure 1.4*, and *Figure 1.5* show a wye-delta transformer with a grounding bank on the delta side. This installation calls for REF protection on both the grounded wye winding and the grounding bank. Current channel IY of the SEL-487E includes three independent REF elements.

For the SV version of this application, as shown in *Figure 1.3*, the SEL-487E-5 SV Subscriber subscribes to a total of four IEC 61850 9-2 SV streams from two different merging units. The SV publishers and subscriber for this application are connected through a process bus network switch. The same network switch is being used to communicate GOOSE messages and time synchronize the system by using a PTP time source. SV and GOOSE mapping between SEL-401 Merging Units and the SEL-487E-5 SV Subscriber Relay is described in *Table 1.3*–*Table 1.5*.

In *Figure 1.3*, SEL-401 Merging Unit #1 has both Relay Word bits VB001 and VB002 set to trip Breaker S, while VB003 is set to close Breaker S. SEL-401 Merging Unit #2 has both VB001 and VB002 set to trip Breaker T, while VB003 is set to close Breaker T. The SEL-487E uses VB001 and VB002 to monitor the status of Breaker S and Breaker T, respectively. Refer to *Table 1.5* for details on possible applications that use subscribed analog data.

Figure 1.3 Wye-Delta Transformer With Grounding Bank (SV Subscriber)

Table 1.3 SEL-487E-5 SV Subscriber Relay IEC 61850 Subscriptions, Transformer With Grounding Bank

Merging Unit Publications	SEL-487E Subscriptions
SEL-401 #1	
IAW, IBW, ICW	IAS, IBS, ICS
IAX, IBX[a], ICX[a]	IY1
52AA1	VB001
SEL-401 #2	
IAX, IBX, ICX	IAT, IBT, ICT
IAW, IBW[a], ICW[a]	IY2
52AA2	VB002

[a] No physical connection. Published data do not contain valid analog measurements.

Table 1.4 SEL-487E-5 SV Subscriber Relay IEC 61850 Publications, Transformer With Grounding Bank

Merging Unit Subscriptions	SEL-487E Publications
SEL-401 #1	
VB001, VB002, VB003	TRPXFMR, TRIPS, CLS
SEL-401 #2	
VB001, VB002, VB003	TRPXFMR, TRIPT, CLT

Table 1.5 Transformer With Grounding-Bank Subscribed Analog Applications

Subscribed Analog Input	SV Subscriber Protection
IS, IT	Transformer differential
IS, IT	Overcurrent protection
IY	REF

In the TiDL version of this application, as shown in *Figure 1.4*, the SEL-487E-5 TiDL Relay is connected to two SEL-TMU. The SEL-TMU inputs and outputs are mapped locally within the relay, as shown in *Table 1.6*.

Figure 1.4 Wye-Delta Transformer With Grounding Bank (TiDL)

Table 1.6 SEL-487E-5 TiDL System Mapping, Transformer With Grounding Bank (Sheet 1 of 2)

SEL-TMU Input	Signal/Control	SEL-487E-5 Local I/O Mapping
SEL-TMU #1		
I1	Breaker S Current IA	IAS
I2	Breaker S Current IB	IBS
I3	Breaker S Current IC	ICS
I4	Transformer Ground Current	IY1
V1	None	None
V2	None	None
V3	None	None
V4	None	None
IN01	52AAS	IN301
OUT01	BKS Close	OUT301
OUT05	BKS Trip	OUT302
SEL-TMU #2		
I1	Breaker T Current IA	IAT
I2	Breaker T Current IB	IBT
I3	Breaker T Current IC	ICT
I4	Grounding Transformer Ground Current	IY2
V1	None	None
V2	None	None
V3	None	None
V4	None	None
IN01	52AAT	IN302

Table 1.6 SEL-487E-5 TiDL System Mapping, Transformer With Grounding Bank (Sheet 2 of 2)

SEL-TMU Input	Signal/Control	SEL-487E-5 Local I/O Mapping
OUT01	BKT Close	OUT303
OUT05	BKT Trip	OUT304

The SEL-487E-5 can also be used as a conventional relay when ordered as a SV publisher, as shown in *Figure 1.5*.

Figure 1.5 Wye-Delta Transformer With Grounding Bank (Conventional)

Autotransformer

Figure 1.6 and *Figure 1.7* show the SEL-487E-5 applied to an autotransformer with both HV and LV busbars configured as breaker-and-a-half busbars.

As shown in *Figure 1.6*, the SEL-487E-5 SV Subscriber subscribes to a total of five IEC 61850 9-2 SV streams from three different merging units. The SV publishers and subscriber for this application are connected through a process bus network switch. The same network switch is being used to communicate GOOSE messaging and to time-synchronize the system by using a PTP time source. SV and GOOSE mapping between SEL-401 Merging Units and the SEL-487E-5 SV Subscriber Relay is described in *Table 1.7–Table 1.9*.

In *Figure 1.6*, SEL-401 Merging Unit #1 has Relay Word bits VB002 and VB003 set to trip Breakers S and T respectively, while SEL-401 Merging Unit #3 has VB002 and VB003 set to trip Breakers U and W. Both merging units are set so that VB001 trips all four breakers. Relay Word bits VB004 and VB005 are set to close Breakers S and T for Merging Unit #1 and Breakers U and W for Merging Unit #3. The SEL-487E uses VB001–VB004 to monitor the status of Breakers S, T, U, and W, respectively. Refer to *Table 1.9* for details on possible applications that use subscribed analog data.

Figure 1.6 Autotransformer Application (SV Subscriber)

Table 1.7 SEL-487E-5 SV Subscriber Relay IEC 61850 Subscriptions, Autotransformer (Sheet 1 of 2)

Merging Unit Publications	SEL-487E Subscriptions
SEL-401 #1	
IAW, IBW, ICW VAY, VBY, VCY	IAS, IBS, ICS VAV, VBV, VCV
IAX, IBX, ICX	IAT, IBT, ICT
52AA1, 52AA2	VB001, VB002
SEL-401 #2	
IAW, IBW[a], ICW[a]	IY1

Table 1.7 SEL-487E-5 SV Subscriber Relay IEC 61850 Subscriptions, Autotransformer (Sheet 2 of 2)

Merging Unit Publications	SEL-487E Subscriptions
SEL-401 #3	
IAW, IBW, ICW VAY, VBY, VCY	IAU, IBU, ICU VAZ, VBZ, VCZ
IAX, IBX, ICX	IAW, IBW, ICW
52AA1, 52AA2	VB003, VB004

[a] No physical connection. Published data do not contain valid analog measurements.

Table 1.8 SEL-487E-5 SV Subscriber Relay IEC 61850 Publications, Autotransformer

Merging Unit Subscriptions	SEL-487E Publications
SEL-401 #1	
VB001, VB002, VB003, VB004, VB005	TRPXFMR, TRIPS, TRIPT, CLS, CLT
SEL-401 #3	
VB001, VB002, VB003, VB004, VB005	TRPXFMR, TRIPU, TRIPW, CLU, CLW

Table 1.9 Autotransformer Subscribed Analog Applications

Subscribed Analog Input	SV Subscriber Protection
IS, IT, IU, IW	Transformer differential
IS, IT	Combined overcurrent
IU, IW	Combined overcurrent
IY	REF
VV, VZ	Volts/hertz, undervoltage, power metering, directional overcurrent, underfrequency, overpower

In the TiDL version of the application, as shown in *Figure 1.7*, the SEL-487E is connected to three SEL-TMU. The SEL-TMU inputs and outputs are mapped locally within the relay, as shown in *Table 1.10*.

Figure 1.7 Autotransformer Application (TiDL)

Table 1.10 SEL-487E-5 TiDL System Mapping, Autotransformer (Sheet 1 of 2)

SEL-TMU Input	Signal/Control	SEL-487E-5 Local I/O Mapping
SEL-TMU #1		
I1	Breaker S Current IA	IAS
I2	Breaker S Current IB	IBS
I3	Breaker S Current IC	ICS
I4	None	None
I5	Breaker T Current IA	IAT
I6	Breaker T Current IB	IBT
I7	Breaker T Current IC	ICT
I8	None	None
IN01	52AAS	IN301
IN02	52AAT	IN302
OUT01	BKS Close	OUT301
OUT02	BKT Close	OUT302
OUT05	BKS Trip	OUT303
OUT06	BKT Trip	OUT304

Table 1.10 SEL-487E-5 TiDL System Mapping, Autotransformer (Sheet 2 of 2)

SEL-TMU Input	Signal/Control	SEL-487E-5 Local I/O Mapping
SEL-TMU #2		
I1	Autotransformer Neutral Current	IY1
I2	None	None
I3	None	None
I4	None	None
V1	HV Bus Voltage VA	VAV
V2	HV Bus Voltage VB	VBV
V3	HV Bus Voltage VC	VCV
V4	None	None
SEL-TMU #3		
I1	Breaker U Current IA	IAU
I2	Breaker U Current IB	IBU
I3	Breaker U Current IC	ICU
I4	None	None
V1	None	None
V2	None	None
V3	None	None
V4	None	None
IN01	52AAU	IN303
OUT01	BKU Close	OUT305
OUT05	BKU Trip	OUT306
SEL-TMU #4		
I1	Breaker W Current IA	IAW
I2	Breaker W Current IB	IBW
I3	Breaker W Current IC	ICW
I4	None	None
V1	LV Bus Voltage VA	VAZ
V2	LV Bus Voltage VB	VBZ
V3	LV Bus Voltage VC	VCZ
V4	None	None
IN01	52AAW	IN304
OUT01	BKW Close	OUT307
OUT05	BKW Trip	OUT308

Distance Protection for Transformers

Figure 1.8 shows an application where the SEL-487E-5 is applied to provide backup distance protection for a power transformer. The distance protection requires the current and voltage transformer inputs to be on the same side of the power transformer. For the application shown, the CT and PT from the HV side are used by the distance element. In this example, the Zone 1 distance element is set to reach 70 percent of the transformer impedance and the Zone 2 element is set to reach 120 percent of the transformer impedance.

Figure 1.8 shows a TiDL system that can be used for this application; however, an IEC 61850 9-2 or conventional configuration is also supported.

Figure 1.8 Distance Protection for Transformer (TiDL)

Six Terminal Feeder Protection

Use the six three-phase current terminals on the SEL-487E to provide comprehensive feeder protection and control including overcurrent, reclosing, directional overcurrent, and breaker failure protection for six feeders. A single SEL-487E can provide full feeder functionality of six single function feeder relays thereby reducing the device count within the system. *Figure 1.9* shows a TiDL system that can be used for this application; however, an IEC 61850 9-2 or conventional configuration is also supported.

Figure 1.9 Six Terminal Feeder Protection (TiDL)

Consolidated Protection

Figure 1.10 shows as small distribution substation where all protection functions have been consolidated to a single SEL-487E. For this application, the relay provides protection to each of the three feeders and provides a differential zone for transformer protection, a second differential zone for busbar protection, and a distance element to protect the incoming transmission line. All lines and feeders

have independent instances of reclosing enabled in addition to positive-, negative-, and zero-sequence directional and inverse-time overcurrent elements. The CT polarity of each protection element shown can be inverted independently, which allows for greater flexibility when configuring consolidation protection applications.

In this example, the CT connection supplying current from the high side of the transformer should be inverted for the distance element but is in the correct orientation for the transformer differential element. Setting the current transformer polarity for Line 1 to negative, CTPL1 = N, inverts the current observed by the distance element without impacting the transformer differential element. *Figure 1.10* shows a TiDL system for this application, and *Figure 1.11* shows an IEC 61850 9-2 system. This application also can be configured as a conventional hardwired system by using the SEL-487E-5 SV Publisher model.

Figure 1.10 Consolidated Protection and Control (TiDL)

Figure 1.11 Consolidated Protection and Control (SV)

Application Highlights

Table 1.11 lists applications and key features of the relay.

Table 1.11 Application Highlights (Sheet 1 of 2)

Application	Key Features
Installation at power plants, transmission stations, and distribution stations	➤ Unique combination of protection including V/Hz, control, and monitoring makes the relay ideal for most transformer applications. ➤ Patented adaptive-slope differential characteristic provides fast tripping time.
Impedance-grounded systems	Three independent REF elements provide sensitive ground fault protection.
Wye-delta transformers	The standard matrix settings compensate for all 30-degree transformer winding phase shifts.
Unit transformers, cogeneration	➤ Two separate V/Hz settings; one setting for a loaded transformer and one setting for an unloaded transformer. ➤ Use the built-in synchrophasors to synchronize the generator with the power system. ➤ Reverse power elements control power flow.
1 A CT secondary (HV REF) 5 A CT secondary (LV REF) or vice versa	Provides a choice of 1 A or 5 A CT secondary currents among the phases of Terminal Y, or vice versa.
Large CT ratio mismatch among windings	The SEL-487E accepts a ratio mismatch of 35:1 among CTs; i.e., CT ratios of 3500/5 and 100/5.
Backup protection feeder overcurrent protection	Numerous voltage-polarized directional and nondirectional phase, negative-sequence, and zero-sequence 50 and 51 elements.
Optimize circuit breaker maintenance	Use the per-phase circuit breaker monitoring to calculate the circuit breaker contact wear.
Balance transformer insulation life aging with temporary overloading	Calculate the accelerated aging factor for the insulation with the IEEE C57.91-1995 transformer thermal model.

Table 1.11 Application Highlights (Sheet 2 of 2)

Application	Key Features
Collect through-fault data and the calculated damage on the transformer windings	Based on IEEE C57.109-1993, the through-fault monitor calculates mechanical and electrical damage to the transformer resulting from through faults.
Synchrophasors	➤ The SEL-487E can function as a PMU at the same time as it provides best-in-class protective relay functions. ➤ IEEE C37.118 message format allows as many as 24 current and 8 voltage synchronized measurements, and as many as 60 messages per second (on a 60 Hz nominal power system). Five unique data streams, three choices of filter response, settable angle correction, and a choice of numeric representation makes the data usable for a variety of synchrophasor applications. ➤ SEL Fast Operate commands are available on the synchrophasor communications ports, allowing control actions initiated by the synchrophasor processor. ➤ Records as much as 120 seconds of IEEE C37.118 synchrophasor data based on a trigger. Recorded files follow the IEEE C37.232 file naming convention. ➤ SEL Fast Message Synchrophasor format is also available as legacy, with as many as four current and four voltage synchronized measurements.
IEC 61850 Sampled Values[a]	➤ Complies with UCA International Users Group's "Implementation Guideline for Digital Interface to Instrument Transformers Using IEC 61850-9-2" ➤ Supports one Application Data Service Unit (ASDU). ➤ SEL-487E-5 Publisher: supports as many as seven SV publications. ➤ SEL-487E-5 Subscriber: support as many as seven SV subscriptions.
TiDL[a]	➤ Allows you to communicate with as many as eight SEL-TMU over a direct, point-to-point fiber-optic connection via T-Protocol.

[a] For SV applications, operating times are delayed by the configured channel delay, CH_DLY. See SV Network Delays on page 17.33 in the SEL-400 Series Relays Instruction Manual for more details. For TiDL applications, the operating times are delayed by a fixed 1 ms. Use caution when setting relay coordination to account for this added delay.

Product Characteristics

Each SEL-400 series relay shares common features, but has unique characteristics. *Table 1.12* summarizes the unique characteristics for the SEL-487E.

Table 1.12 SEL-487E Relay Characteristics (Sheet 1 of 2)

Characteristic	Value
Standard Processing Rate	8 times per cycle
Battery Monitor	One
Autorecloser	Three-pole
MBG Protocol	Not supported
SELOGIC	
Protection Free-Form	250 lines
Automation Free-Form	10 blocks of 100 lines each
SELOGIC Variables	96 protection 256 automation
SELOGIC Math Variables	64 protection 256 automation
Conditioning Timers	32 protection 48 automation

Table 1.12 SEL-487E Relay Characteristics (Sheet 2 of 2)

Characteristic	Value
Sequencing Timers	32 protection 48 automation
Counters	32 protection 32 automation
Latch Bits	32 protection 80 automation
Control	
Remote Bits	96
Local Bits	96
Breakers	Six: S, T, U, W, X, Y Three-pole only
Disconnects	20
Bay Control	Supported
Metering	
Maximum/Minimum Metering	Not supported
Energy Metering	Supported
Demand Metering	Supported

Specifications

Note: For SV subscriber applications, operating times are delayed by the configured channel delay, CH_DLY. See *SV Network Delays on page 17.33 in the SEL-400 Series Relays Instruction Manual* for more details. For TiDL applications, the operating times are delayed by a fixed 1 ms. Use caution when setting relay coordination to account for this added delay.

Note: The metering and protection element accuracies specified for the SEL-487E-5 SV Subscriber Relay are valid only when using SEL merging units. For SV applications, third-party SV publisher devices are supported, but hardware accuracies and analog filtering need to be considered to determine the effect on SEL-487E-5 SV Subscriber performance.

Compliance

Designed and manufactured under an ISO 9001 certified quality management system

FCC Compliance Statement

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference in which case the user will be required to correct the interference at his own expense.

UL Listed to U.S. and Canadian safety standards (File E212775; NRGU, NRGU7)

CE Mark

RCM Mark

General

AC Analog Inputs

Sampling Rate:	8 kHz

AC Current Inputs (Secondary Circuits)

Note: Current transformers are Measurement Category II.

Input Current

5 A Nominal:	S, T, U, W, X, and Y terminals
1 A Nominal:	S. T, U, W, X, and Y terminals
1 A/5 A Nominal:	Y terminal only (REF)

Current Rating (With DC Offset at X/R = 10, 1.5 cycles)

5 A Nominal:	91.0 A
1 A Nominal:	18.2 A

Continuous Thermal Rating

5 A Nominal:	15 A 20 A (+55°C)
1 A Nominal:	3 A 4 A (+55°C)

Saturation Current (Linear) Rating

5 A Nominal:	100 A
1 A Nominal:	20 A

One-Second Thermal Rating

5 A Nominal:	500 A
1 A Nominal:	100 A

One-Cycle Thermal Rating

5 A Nominal:	1250 A-peak
1 A Nominal:	250 A-peak

Burden Rating

5 A Nominal:	≤0.5 VA at 5 A
1 A Nominal:	≤0.1 VA at 1 A

A/D Current Limit

Note: Signal clipping may occur beyond this limit.

5 A Nominal:	247.5 A
1 A Nominal:	49.5 A

AC Voltage Inputs

Three-phase, four-wire (wye) connections are supported.

Rated Voltage Range:	55–250 V_{LN}
Operational Voltage Range:	0–300 V_{LN}
Ten-Second Thermal Rating:	600 Vac
Burden:	≤0.1 VA @ 125 V

LEA Voltage Inputs

Rated Voltage Range:	4 V_{L-N}
Operational Voltage Range:	0–8 V_{L-N}
Ten-Second Thermal Rating:	300 Vac
Input Impedance:	1 MΩ

Frequency and Rotation

System Frequency:	50/60 Hz
Phase Rotation:	ABC or ACB
Nominal Frequency Rating:	50 ±5 Hz 60 ±5 Hz
Frequency Tracking (Requires PTs):	Tracks between 40.0–65.0 Hz Below 40 Hz = 40 Hz Above 65.0 Hz = 65 Hz
Default Slew Rate:	15 Hz per s

Power Supply

24–48 Vdc

Rated Voltage:	24–48 Vdc
Operational Voltage Range:	18–60 Vdc
Vdc Input Ripple:	15% per IEC 60255-26:2013
Interruption:	20 ms at 24 Vdc, 100 ms at 48 Vdc per IEC 60255-26:2013
Burden	
SV Relay:	<35 W
TiDL Relay:	<40 W

48–125 Vdc or 110–120 Vac

Rated Voltage:	48–125 Vdc, 110–120 Vac
Operational Voltage Range:	38–140 Vdc 85–140 Vac
Rated Frequency:	50/60 Hz
Operational Frequency Range:	30–120 Hz
Vdc Input Ripple:	15% per IEC 60255-26:2013
Interruption:	14 ms @ 48 Vdc, 160 ms @ 125 Vdc per IEC 60255-26:2013
Burden	
SV Relay:	<35 W, <90 VA
TiDL Relay:	<40 W, <90 VA

125–250 Vdc or 110–240 Vac

Rated Voltage:	125–250 Vdc, 110–240 Vac
Operational Voltage Range:	85–300 Vdc 85–264 Vac

Rated Frequency:	50/60 Hz
Operational Frequency Range:	30–120 Hz
Vdc Input Ripple:	15% per IEC 60255-26:2013
Interruption:	46 ms @ 125 Vdc, 250 ms @ 250 Vdc per IEC 60255-26:2013
Burden	
SV Relay:	<35 W, <90 VA
TiDL Relay:	<40 W, <90 VA

Control Outputs

Note: IEEE C37.90-2005 and IEC 60255-27:2013

Update Rate:	1/8 cycle
Make (Short Duration Contact Current):	30 Adc 1,000 operations at 250 Vdc 2,000 operations at 125 Vdc
Limiting Making Capacity:	1000 W at 250 Vdc (L/R = 40 ms)
Mechanical Endurance:	10,000 operations

Standard

Rated Voltage:	24–250 Vdc 110–240 Vrms
Operational Voltage Range:	0–300 Vdc 0–264 Vrms
Operating Time:	Pickup ≤6 ms (resistive load) Dropout ≤6 ms (resistive load)
Short-Time Thermal Withstand:	50 A for 1 s
Continuous Contact Current:	6 A at 70°C 4 A at 85°C
Contact Protection:	MOV protection across open contacts 264 Vrms continuous voltage 300 Vdc continuous voltage
Limiting Breaking Capacity/Electrical Endurance:	10,000 operations 10 operations in 4 seconds, followed by 2 minutes idle

Rated Voltage	Resistive Break	Inductive Break L/R = 40 ms (DC) PF = 0.4 (AC)
24 Vdc	0.75 Adc	0.75 Adc
48 Vdc	0.63 Adc	0.63 Adc
125 Vdc	0.30 Adc	0.30 Adc
250 Vdc	0.20 Adc	0.20 Adc
110 Vrms	0.30 Arms	0.30 Arms
240 Vrms	0.20 Arms	0.20 Arms

Fast Hybrid (High-Speed High-Current Interrupting)

Rated Voltage:	48–250 Vdc
Operational Voltage Range:	0–300 Vdc
Operating Time:	Pickup ≤10 µs (resistive load) Dropout ≤8 ms (resistive load)
Short Time Thermal Withstand:	50 Adc for 1 s
Continuous Contact Current:	6 Adc at 70°C 4 Adc at 85°C
Contact Protection:	MOV protection across open contacts 300 Vdc continuous voltage
Limiting Breaking Capacity/Electrical Endurance:	10,000 operations 4 operations in 1 second, followed by 2 minutes idle

Rated Voltage	Resistive Break	Inductive Break
24 Vdc	10 Adc	10 Adc (L/R = 40 ms)
48 Vdc	10 Adc	10 Adc (L/R = 40 ms)
125 Vdc	10 Adc	10 Adc (L/R = 40 ms)
250 Vdc	10 Adc	10 Adc (L/R = 20 ms)

Note: Do not use hybrid control outputs to switch ac control signals.

Control Inputs

Optoisolated (Use With AC or DC Signals)

INT2, INT7, and INT8 Interface Boards:	8 inputs with no shared terminals
INT4 and INTD Interface Boards:	6 inputs with no shared terminals 18 inputs with shared terminals (2 groups of 9 inputs with each group sharing one terminal)
Voltage Options:	24, 48, 110, 125, 220, 250 V
Current Drawn:	<5 mA at nominal voltage <8 mA for 110 V option

DC Thresholds (Dropout Thresholds Indicate Level-Sensitive Option)

24 Vdc:	Pickup 19.2–30.0 Vdc Dropout: <14.4 Vdc
48 Vdc:	Pickup 38.4–60.0 Vdc; Dropout <28.8 Vdc
110 Vdc:	Pickup 88.0–132.0 Vdc; Dropout <66.0 Vdc
125 Vdc:	Pickup 105–150 Vdc; Dropout <75 Vdc
220 Vdc:	Pickup 176–264 Vdc; Dropout <132 Vdc
250 Vdc:	Pickup 200–300 Vdc; Dropout <150 Vdc

AC Thresholds (Ratings Met Only When Recommended Control Input Settings Are Used—see *Table 2.1*.)

24 Vac:	Pickup 16.4–30.0 Vac rms Dropout: <10.1 Vac rms
48 Vac:	Pickup 32.8–60.0 Vac rms; Dropout <20.3 Vac rms
110 Vac:	Pickup 75.1–132.0 Vac rms; Dropout <46.6 Vac rms
125 Vac:	Pickup 89.6–150.0 Vac rms; Dropout <53.0 Vac rms
220 Vac:	Pickup 150.3–264 Vac rms; Dropout <93.2 Vac rms
250 Vac:	Pickup 170.6–300 Vac rms; Dropout <106 Vac rms
Sampling Rate:	2 kHz

Communications Ports

EIA-232:	1 Front and 3 Rear
Serial Data Speed:	300–57600 bps

Ethernet Card Slot for Four-Port Ethernet Card

Ordering Option:	10/100BASE-T
Connector Type:	RJ45
Ordering Option:	100BASE-FX fiber-optic Ethernet
Mode:	Multi
Wavelength (nm):	1300
Source:	LED
Connector Type:	LC
Min. TX Pwr. (dBm):	–19

Max. TX Pwr. (dBm): –14

RX Sens. (dBm): –32

Sys. Gain (dB): 13

Ethernet Card Slot for the Five-Port Ethernet Card

Ordering Option: 100BASE-FX fiber-optic Ethernet SFP transceiver

Part Number: 8103-01 or 8109-01

Mode: Multi

Wavelength (nm): 1310

Source: LED

Connector Type: LC

Min. TX Pwr. (dBm): –24

Max. TX Pwr. (dBm): –14

Min. RX Sens. (dBm): –31

Max. RX Sens. (dBm): –12

Approximate Range: 2 km

Transceiver Internal Temperature Accuracy: ±3.0°C

Transmitter Average Optical Power Accuracy: ±3.0 dB

Received Average Optical Input Power Accuracy: ±3.0 dB

Ordering Option: 1000BASE-LX fiber-optic Ethernet SFP transceiver

Part Number: 8130-01, 8130-02, 8130-03, or 8130-04

Mode: Single

Wavelength (nm): 1310

Source: LED

Connector Type: LC

	Part Number			
	8130-01	8130-02	8130-03	8130-04
Min. TX Pwr. (dBm)	–9.5	–6	–5	–2
Max. TX Pwr. (dBm)	–3	–1	0	3
Min. RX Sens. (dBm)	–21	–22	–24	–24
Max. RX Sens. (dBm)	–3	–3	–3	–3
Approximate Range (km)	10	20	30	40

Transceiver Internal Temperature Accuracy: ±3.0°C

Transmitter Average Optical Power Accuracy: ±3.0 dB

Received Average Optical Input Power Accuracy: ±3.0 dB

Ordering Option: 1000BASE-XD fiber-optic Ethernet SFP transceiver

Part Number: 8130-05

Mode: Single

Wavelength (nm): 1550

Source: LED

Connector Type: LC

Min. TX Pwr. (dBm): –5

Max. TX Pwr. (dBm): 0

Min. RX Sens. (dBm): –24

Max. RX Sens. (dBm): –3

Approximate Range: 50 km

Transceiver Internal Temperature Accuracy: ±3.0°C

Transmitter Average Optical Power Accuracy: ±3.0 dB

Received Average Optical Input Power Accuracy: ±3.0 dB

Ordering Option: 1000BASE-ZX fiber-optic Ethernet SFP transceiver

Part Number: 8130-06, 8130-08, or 8130-10

Mode: Single

Wavelength (nm): 1550

Source: LED

Connector Type: LC

	Part Number		
	8130-06	8130-08	8130-10
Min. TX Pwr. (dBm)	0	1	5
Max. TX Pwr. (dBm)	5	5	8
Min. RX Sens. (dBm)	–24	–36	–36
Max. RX Sens. (dBm)	–3	–10	–10
Approximate Range (km)	80	160	200

Transceiver Internal Temperature Accuracy: ±3.0°C

Transmitter Average Optical Power Accuracy: ±3.0 dB

Received Average Optical Input Power Accuracy: ±3.0 dB

Ordering Option: 1000BASE-SX fiber-optic Ethernet SFP transceiver

Part Number: 8131-01

Mode: Multi

Wavelength (nm): 850

Source: LED

Connector Type: LC

Min. TX Pwr. (dBm): –9

Max. TX Pwr. (dBm): –2.5

Min. RX Sens. (dBm): –18

Max. RX Sens. (dBm): 0

Approximate Range: 300 m for 62.5/125 µm; 550 m for 50/125 µm

Transceiver Internal Temperature Accuracy: ±3.0°C

Transmitter Average Optical Power Accuracy: ±3.0 dB

Received Average Optical Input Power Accuracy: ±3.0 dB

Optional TiDL Communication Ports

Number of Ports: 8

Protocol: T-Protocol

Supported SFP Transceivers: 8103-01 or 8109-01

Note: For SFP Transceiver specification, see *Ethernet Card Slot for the Five-Port Ethernet Card on page 1.26*.

Time Inputs

IRIG Time Input—Serial PORT 1

Input:	Demodulated IRIG-B
Rated I/O Voltage:	5 Vdc
Operational Voltage Range:	0–8 Vdc
Logic High Threshold:	≥2.8 Vdc
Logic Low Threshold:	≤0.8 Vdc
Input Impedance:	2.5 kΩ

IRIG-B Input—BNC Connector

Input:	Demodulated IRIG-B
Rated I/O Voltage:	5 Vdc
Operational Voltage Range:	0–8 Vdc
Logic High Threshold:	≥2.2 Vdc
Logic Low Threshold:	≤0.8 Vdc
Input Impedance:	50 Ω or >1 kΩ
Dielectric Test Voltage:	0.5 kVac

PTP

Input:	IEEE 1588 PTPv2
Profiles:	Default, IEEE C37.238-2011 (Power Profile), IEC/IEEE 61850-9-3-2016 (Power Utility Automation Profile)
Synchronization Accuracy:	±100 ns @ 1-second synchronization intervals when communicating directly with master clock

Operating Temperature

–40° to +85°C (–40° to +185°F)

Note: LCD contrast impaired for temperatures below –20° and above +70°C.

Humidity

5% to 95% without condensation

Weight (Maximum)

SV Publisher

6U Rack Unit:	15.9 kg (35 lb)
7U Rack Unit:	17.6 kg (39 lb)
8U Rack Unit:	20.4 kg (45 lb)

SV Subscriber

4U Rack Unit:	6.57 kg (14.47 lb)

TiDL Relay

4U Rack Unit:	6.74 kg (14.87 lb)

Terminal Connections

Rear Screw-Terminal Tightening Torque, #8 Ring Lug

Minimum:	1.0 Nm (9 in-lb)
Maximum:	2.0 Nm (18 in-lb)

User terminals and stranded copper wire should have a minimum temperature rating of 105°C. Ring terminals are recommended.

Wire Sizes and Insulation

Wire sizes for grounding (earthing) and contact connections are dictated by the terminal blocks and expected load currents. You can use the following table as a guide in selecting wire sizes:

Connection Type	Min. Wire Size	Max. Wire Size
Grounding (Earthing) Connection	14 AWG (2.5 mm^2)	N/A
Contact I/O	18 AWG (0.8 mm^2)	10 AWG (5.3 mm^2)
Other Connection	18 AWG (0.8 mm^2)	10 AWG (5.3 mm^2)

Type Tests

Installation Requirements

Overvoltage Category:	2
Pollution Degree:	2

Safety

Product Standards:	IEC 60255-27:2013 IEEE C37.90-2005 21 CFR 1040.10
Dielectric Strength:	IEC 60255-27:2013, Section 10.6.4.3 2.5 kVac, 50/60 Hz for 1 min: Analog Inputs, Contact Outputs, Digital Inputs 3.6 kVdc for 1 min: Power Supply, Battery Monitors 2.5 kVdc for 1 min: IRIG-B 1.1 kVdc for 1 min: Ethernet
Impulse Withstand:	IEC 60255-27:2013, Section 10.6.4.2 IEEE C37.90-2005 Common Mode: ±1.0 kV: Ethernet ±2.5 kV: IRIG-B ±5.0 kV: All other ports Differential Mode: 0 kV: Analog Inputs, Ethernet, IRIG-B, Digital Inputs ±5.0 kV: Standard Contact Outputs, Power Supply Battery Monitors +5.0 kV: Hybrid Contact Outputs
Insulation Resistance:	IEC 60255-27:2013, Section 10.6.4.4 >100 MΩ @ 500 Vdc
Protective Bonding:	IEC 60255-27:2013, Section 10.6.4.5.2 <0.1 Ω @ 12 Vdc, 30 A for 1 min
Ingress Protection:	IEC 60529:2001 + CRGD:2003 IEC 60255-27:2013 IP30 for front and rear panel IP10 for rear terminals with installation of ring lug IP40 for front panel with installation of serial port cover IP52 for front panel with installation of dust protection accessory
Max Temperature of Parts and Materials:	IEC 60255-27:2013, Section 7.3
Flammability of Insulating Materials:	IEC 60255-27:2013, Section 7.6 Compliant

Electromagnetic (EMC) Immunity

Product Standards:	IEC 60255-26:2013 IEC 60255-27:2013 IEEE C37.90-2005
Surge Withstand Capability (SWC):	IEC 61000-4-18:2006 + A:2010 IEEE C37.90.1-2012 Slow Damped Oscillatory, Common and Differential Mode: ±1.0 kV ±2.5 kV Fast Transient, Common and Differential Mode: ±4.0 kV
Electrostatic Discharge (ESD):	IEC 61000-4-2:2008 IEEE C37.90.3-2001 Contact: ±8 kV Air Discharge: ±15 kV

Radiated RF Immunity:	IEEE C37.90.2-2004 IEC 61000-4-3:2006 + A1:2007 + A2:2010 20 V/m (>35 V/m, 80% AM, 1 kHz) Sweep: 80 MHz to 1 GHz Spot: 80, 160, 450, 900 MHz 10 V/m (>15 V/m, 80% AM, 1 kHz) Sweep: 80 MHz to 1 GHz Sweep: 1.4 GHz to 2.7 GHz Spot: 80, 160, 380, 450, 900, 1850, 2150 MHz
Electrical Fast Transient Burst (EFTB):	IEC 61000-4-4:2012 Zone A: ±2 kV: Communication ports ±4 kV: All other ports
Surge Immunity:	IEC 61000-4-5:2005 Zone A: ±2 kV_{L-L} ±4 kV_{L-E} ±4 kV: Communication Ports **Note:** Cables connected to IRIG-B ports shall be less than 10 m in length for Zone A compliance. Zone B: ±2 kV: Communication Ports
Conducted Immunity:	IEC 61000-4-6:2013 20 V/m; (>35 V/m, 80% AM, 1 kHz) Sweep: 150 kHz–80 MHz Spot: 27, 68 MHz
Power Frequency Immunity (DC Inputs):	IEC 61000-4-16:2015 Zone A: Differential: 150 V_{RMS} Common Mode: 300 V_{RMS}
Power Frequency Magnetic Field:	IEC 61000-4-8:2009 Level 5: 100 A/m; ≥60 Seconds; 50/60 Hz 1000 A/m 1 to 3 Seconds; 50/60 Hz **Note:** 50G1P ≥0.05 (ESS = N, 1, 2) 50G1P ≥0.1 (ESS = 3, 4)
Power Supply Immunity:	IEC 61000-4-11:2004 IEC 61000-4-17:1999/A1:2001/A2:2008 IEC 61000-4-29:2000 AC Dips & Interruptions Ripple on DC Power Input DC Dips & Interruptions Gradual Shutdown/Startup (DC only) Discharge of Capacitors Slow Ramp Down/Up Reverse Polarity (DC only)
Damped Oscillatory Magnetic Field:	IEC 61000-4-10:2016 Level 5: 100 A/m

EMC Compatibility

Product Standards:	IEC 60255-26:2013
Emissions:	IEC 60255-26:2013, Section 7.1 Class A 47 CFR Part 15B Class A Canada ICES-001 (A) / NMB-001 (A)

Environmental

Product Standards:	IEC 60255-27:2013
Cold, Operational:	IEC 60068-2-1:2007 Test Ad: 16 hours at –40°C
Cold, Storage:	IEC 60068-2-1:2007 Test Ad: 16 hours at –40°C
Dry Heat, Operational:	IEC 60068-2-2:2007 Test Bd: 16 hours at +85°C
Dry Heat, Storage:	IEC 60068-2-2:2007 Test Bd: 16 hours at +85°C
Damp Heat, Cyclic:	IEC 60068-2-30:2005 Test Db: +25 °C to +55 °C, 6 cycles (12 + 12-hour cycle), 95% RH
Damp Heat, Steady State:	IEC 60068-2-78:2013 Severity: 93% RH, +40 °C, 10 days
Vibration Resistance:	EC 60255-21-1:1988 Class 2 Endurance, Class 2 Response
Shock Resistance:	IEC 60255-21-2:1988 Class 1 Shock Withstand, Class 1 Bump Withstand, Class 2 Shock Response
Seismic:	IEC 60255-21-3:1993 Class 2 Quake Response

Reporting Functions

High-Resolution Data

Rate:	8000 samples/second 4000 samples/second 2000 samples/second 1000 samples/second
Output Format:	Binary COMTRADE

Note: Per IEEE C37.111-1999 and IEEE C37.111-2013, *Common Format for Transient Data Exchange (COMTRADE) for Power Systems*.

Event Reports

Length:	0.25–24 seconds (based on LER and SRATE settings)
Volatile Memory:	3 s of back-to-back event reports sampled at 8 kHz
Nonvolatile Memory:	At least 4 event reports of a 3 s duration sampled at 8 kHz
Resolution:	4 and 8 samples/cycle

Event Summary

Storage:	100 summaries

Breaker History

Storage:	128 histories

Sequential Events Recorder

Storage:	1000 entries
Trigger Elements:	250 relay elements
Resolution:	0.5 ms for contact inputs 1/8 cycle for all elements

Processing Specifications

AC Voltage and Current Inputs

8000 samples per second
Full-cycle cosine filtering

Subscribed AC Input Current (Nominal Secondary)

5 A Nominal:	S, T, U, W, X, and Y terminals
1 A Nominal:	S. T, U, W, X, and Y terminals
1 A/5 A Nominal:	Y terminal only (REF)

Protection and Control Processing

8 times per power system cycle

Control Points

96 remote bits
96 local control bits
32 latch bits in protection logic
80 latch bits in automation logic

Relay Element Pickup Ranges and Accuracies

Differential Elements (General)

Number of Zones:	2 (A, B, and C elements)
Number of Terminals:	6
TAP Setting Range:	(0.1–32.0) • I_{NOM} A secondary
TAP Limit:	$TAP_{MAX}/TAP_{MIN} \leq 35$
Time-Delay Accuracy:	±0.1% plus ±0.125 cycle

Differential Elements (Restraint)

Pickup Range:	0.1–4.0 per unit
Pickup Accuracy:	1 A nominal: ±5% of setting plus ±0.02 A 5 A nominal: ±5% of setting plus ±0.10 A
Pickup Time (If E87UNB = N):	1.25 minimum cycle 1.38 typical cycle 1.5 maximum cycle
Pickup Time (If E87UNB = Y):	0.5 minimum cycle 0.75 typical cycle 1.5 maximum cycle
Slope 1	
Setting Range:	5% to 100%
Slope 2	
Setting Range:	5% to 100%

Differential Elements (Unrestraint)

Pickup Range:	(1.0–20.0) • TAP
Pickup Accuracy:	±5% of setting plus ±0.02 • I_{NOM} A
Pickup Time (Filtered Unrestraint):	0.7 minimum cycle 0.85 typical cycle 1.2 maximum cycle
Pickup Time (Raw Unrestraint):	0.25 minimum cycle 0.5 typical cycle 1.0 maximum cycle

Note: The raw unrestraint pickup is set to U87P • √2 • 2.

Harmonic Elements (2nd, 4th, 5th)

Pickup Range:	OFF, 5–100% of fundamental
Pickup Accuracy:	1 A nominal ±5% of setting plus ±0.02 A 5 A nominal ±5% of setting plus ±0.10 A
Time-Delay Accuracy:	±0.1% plus ±0.125 cycle (differential element) ±0.1% plus ±0.25 cycle (distance element)

Negative-Sequence Differential Element

Pickup Range:	0.05–1 per unit
Slope Range:	5% to 100%
Pickup Accuracy:	±5% of setting plus ±0.02 • I_{NOM} A
Maximum Pickup/Dropout Time:	4 cycles
Winding Coverage:	2%

Incremental Restraint and Operating Threshold Current Supervision

Setting Range:	0.1–10.0 per unit
Accuracy:	±5% of setting plus ±0.02 • I_{NOM}

Open-Phase Detection Logic

3 elements per terminal (S, T, U, W, X, Y)

Pickup Range	
1 A Nominal:	0.04–1.00 A
5 A Nominal:	0.2–5.00 A
Maximum Pickup/Dropout Time:	0.625 cycle

Restricted Earth Fault (REF)

Elements

Three Independent Elements:	REF1, REF2, REF3

REF1F, REF1R (Element 1, forward and reverse)
REF2F, REF2R (Element 2, forward and reverse)
REF3F, REF3R (Element 3, forward and reverse)

Operating Quantity

Select:	IY1, IY2, IY3

Restraint Quantity

Select:	3I0S, 3I0T, 3I0U, 3I0W, and 3I0X
Pickup Range:	0.05–5 per unit 0.02–0.05 positive-sequence ratio factor (I0/I1)
Pickup Accuracy	
1 A Nominal:	±0.01 A
5 A Nominal:	±0.05 A
Maximum Pickup/Dropout Time:	2.75 cycles

Mho Phase Distance Elements

Zones 1–4 Impedance Reach

Setting Range	
5 A Model:	OFF, 0.05 to 64 Ω secondary, 0.01 Ω steps
1 A Model:	OFF, 0.25 to 320 Ω secondary, 0.01 Ω steps
Sensitivity	
5 A Model:	0.5 A_{P-P} secondary
1 A Model:	0.1 A_{P-P} secondary (Minimum sensitivity is controlled by the pickup of the supervising phase-to-phase overcurrent elements for each zone.)
Accuracy (Steady State):	± 3% of setting at line angle for SIR (source-to-line impedance ratio) < 30 ± 5% of setting at line angle for 30 ≤ SIR ≤ 60
Zone 1 Transient Overreach:	< 5% of setting plus steady-state accuracy
Maximum Operating Time:	1.75 cycles at 90% of reach and SIR = 1

Quadrilateral Phase Distance Elements

Zones 1–4 Impedance Reach

Quadrilateral Reactance Reach	
5 A Model:	OFF, 0.05 to 64 Ω secondary, 0.01 Ω steps
1 A Model:	OFF, 0.25 to 320 Ω secondary, 0.01 Ω steps
Quadrilateral Resistance Reach	
Zones 1, 2, and 3	
5 A Model:	OFF, 0.05 to 50 Ω secondary, 0.01 Ω steps
1 A Model:	OFF, 0.25 to 250 Ω secondary, 0.01 Ω steps
Zones 4	
5 A Model:	OFF, 0.05 to 150 Ω secondary, 0.01 Ω steps
1 A Model:	OFF, 0.25 to 750 Ω secondary, 0.01 Ω steps
Sensitivity	
5 A Model:	0.5 A secondary
1 A Model:	0.1 A secondary
Accuracy (Steady State):	±3% of setting at line angle for SIR < 30 ±5% of setting at line angle for 30 ≤ SIR ≤ 60
Transient Overreach:	<5% of setting *plus* steady-state accuracy
Maximum Operating Time:	1.75 cycles at 90% of reach and SIR = 1

Mho Ground Distance Elements

Zones 1–4 Impedance Reach

Mho Element Reach

5 A Model:	OFF, 0.05 to 64 Ω secondary, 0.01 Ω steps
1 A Model:	OFF, 0.25 to 320 Ω secondary, 0.01 Ω steps

Sensitivity

5 A Model:	0.5 A secondary
1 A Model:	0.1 A secondary (Minimum sensitivity is controlled by the pickup of the supervising phase and residual overcurrent elements for each zone.)
Accuracy (Steady State):	±3% of setting at line angle for SIR < 30 ±5% of setting at line angle for 30 ≤ SIR ≤ 60
Zone 1 Transient Overreach:	<5% of setting *plus* steady-state accuracy
Maximum Operating Time:	1.75 cycles at 90% of reach and SIR = 1

Quadrilateral Ground Distance Elements

Zones 1–4 Impedance Reach

Quadrilateral Reactance Reach

5 A Model:	OFF, 0.05 to 64 Ω secondary, 0.01 Ω steps
1 A Model:	OFF, 0.25 to 320 Ω secondary, 0.01 Ω steps

Quadrilateral Resistance Reach

Zones 1, 2, and 3

5 A Model:	OFF, 0.05 to 50 Ω secondary, 0.01 Ω steps
1 A Model:	OFF, 0.25 to 250 Ω secondary, 0.01 Ω steps

Zones 4

5 A Model:	OFF, 0.05 to 150 Ω secondary, 0.01 Ω steps
1 A Model:	OFF, 0.25 to 750 Ω secondary, 0.01 Ω steps

Sensitivity

5 A Model:	0.5 A secondary
1 A Model:	0.1 A secondary (Minimum sensitivity is controlled by the pickup of the supervising phase and residual overcurrent elements for each zone.)
Accuracy (Steady State):	±3% of setting at line angle for SIR < 30 ±5% of setting at line angle for 30 ≤ SIR ≤ 60
Transient Overreach:	<5% of setting plus steady-state accuracy
Maximum Operating Time:	1.75 cycles at 90% of reach and SIR = 1

Out-of-Step Elements

Blinders (R1) Parallel to the Line Angle

5 A Model:	0.05 to 140 Ω secondary –0.05 to –140 Ω secondary
1 A Model:	0.25 to 700 Ω secondary –0.25 to –700 Ω secondary

Blinders (X1) Perpendicular to Line Angle

5 A Model:	0.05 to 140 Ω secondary –0.05 to –140 Ω secondary
1 A Model:	0.25 to 700 Ω secondary –0.25 to –700 Ω secondary

Accuracy (Steady State)

5 A Model:	±5% of setting plus ±0.01 A for SIR (source to line impedance ratio) < 30 ±10% of setting plus ±0.01 A for 30 ≤ SIR ≤ 60
1 A Model:	±5% of setting plus ±0.05 A for SIR (source to line impedance ratio) < 30 ±10% of setting plus ±0.05 A for 30 ≤ SIR ≤ 60

Negative-Sequence Supervision

Setting Range

5 A Model:	0.5–100.0 A, 0.01 A steps
1 A Model:	0.1–20.0 A, 0.01 A steps

Accuracy (Steady State)

5 A Model:	±3% of setting plus ±0.05 A
1 A Model:	±3% of setting plus ±0.01 A
Transient Overreach:	<5% of setting

Instantaneous/Definite-Time Overcurrent Elements (50)

Phase- and Negative-Sequence, Ground-Residual Elements

Pickup Range

5 A Nominal:	0.25–100.00 A secondary, 0.01-A steps
1 A Nominal:	0.05–20.00 A secondary, 0.01-A steps

Accuracy (Steady State)

5 A Nominal:	±3% of setting plus ±0.05 A
1 A Nominal:	±3% of setting plus ±0.01 A

Transient Overreach (Phase and Ground Residual)

5 A Nominal:	±5% of setting plus ±0.10 A
1 A Nominal:	±5% of setting plus ±0.02 A

Transient Overreach (Negative Sequence)

5 A Nominal:	±6% of setting plus ±0.10 A
1 A Nominal:	±6% of setting plus ±0.02 A
Time-Delay Range:	0.00–16000.00 cycles, 0.125 cycle steps
Timer Accuracy:	±0.1% of setting plus ±0.25 cycle
Maximum Pickup/Dropout Time:	1.5 cycles

Adaptive Time-Overcurrent Elements (51)

Pickup Range (Adaptive Within the Range)

5 A Nominal:	0.25–16.00 A secondary, 0.01 A steps
1 A Nominal:	0.05–3.20 A secondary, 0.01 A steps

Accuracy (Steady State)

5 A Nominal:	±3% of setting plus ±0.05 A
1 A Nominal:	±3% of setting plus ±0.01 A

Transient Overreach

5 A Nominal:	±5% of setting plus ±0.10 A
1 A Nominal:	±5% of setting plus ±0.02 A

Time-Dial Range (Adaptive Within the Range)

U.S.:	0.50–15.00, 0.01 steps
IEC:	0.05–1.00, 0.01 steps
Curve Timing Accuracy:	±1.50 cycles plus ±4% of curve time (for current between 2 and 30 multiples of pickup)

Curves operate on definite time for current greater than 30 multiples of pickup.

Reset:	1 power cycle or Electromechanical Reset Emulation time

Combined Time-Overcurrent Elements (51)

Pickup Range	
5 A Nominal:	0.25–16.00 A secondary, 0.01 A steps
1 A Nominal:	0.05–3.20 A secondary, 0.01 A steps
Accuracy (Steady State)	
5 A Nominal:	±3% of setting plus ±0.05 A
1 A Nominal:	±3% of setting plus ±0.01 A
Transient Overreach	
5 A Nominal:	±5% of setting plus ±0.10 A
1 A Nominal:	±5% of setting plus ±0.02 A
Time-Dial Range	
U.S.:	0.50–15.00, 0.01 steps
IEC:	0.05–1.00, 0.01 steps
Curve Timing Accuracy:	±1.50 cycles plus ±4% of curve time (for current between 2 and 30 multiples of pickup)
Curves operate on definite time for current greater than 30 multiples of pickup.	
Reset:	1 power cycle or electromechanical reset emulation time

Phase Directional Elements (67)

Number:	6 (1 each for S, T, U, W, X, Y)
Polarization:	Positive-sequence memory voltage Negative-sequence voltage
Time-Delay Range:	0.000–16,000 cycles, 0.125 cycle increment
Time-Delay Accuracy:	±0.1% of setting plus ±0.25 cycle

Phase-to-Phase Directional Elements

Number:	6 (1 each for S, T, U, W, X, Y)
Polarization Quantity:	Negative-sequence voltage
Operate Quantity:	Negative-sequence current ($3I_2$)
Sensitivity:	0.05 • I_{NOM} A of secondary $3I_2$
Accuracy:	±0.05 Ω secondary
Transient Overreach:	+5% of set reach
Max. Delay:	1.75 cycles
Time-Delay Range:	0.000–16,000 cycles, 0.125-cycle increment
Time-Delay Accuracy:	±0.1% of setting plus ±0.25 cycle

Ground Directional Elements

Number:	6 (1 each for S, T, U, W, X, Y)
Outputs:	Forward and reverse
Polarization Quantity:	Zero-sequence voltage
Operate Quantity:	Zero-sequence current 3I0, where 3I0 = IA + IB + IC
Sensitivity:	0.05 • I_{NOM} A of secondary 3I0
Accuracy:	±0.05 Ω secondary
Transient Overreach:	+5% of set reach
Max. Delay:	1.75 cycles

Undervoltage and Overvoltage Elements

Pickup Ranges

Phase Elements:	2–300 V_{L-N} in 0.01-V steps
Phase-to-Phase Elements:	4–520 V_{L-L} in 0.01-V steps
Sequence Elements:	2–300 V_{L-N} in 0.01-V steps

Pickup Accuracy (Steady State)

Phase Elements:	±3% of setting plus ±0.5 V
Phase-to-Phase Elements (Wye):	±3% of setting plus ±0.5 V
Phase-to-Phase Elements (Delta):	±3% of setting plus ±1 V
Sequence Elements:	±5% of setting plus ±1 V

Pickup Accuracy (Transient Overreach)

Phase Elements:	±5%
Phase-to-Phase Elements (Wye):	±5%
Phase-to-Phase Elements (Delta):	±5%
Sequence Elements:	±5%

Maximum Pickup/Dropout Time

Phase Elements:	1.5 cycles
Phase-to-Phase Elements (Wye):	1.5 cycles
Sequence Elements:	1.5 cycles

Under- and Overfrequency Elements

Pickup Range:	40.01–69.99 Hz, 0.01-Hz steps
Accuracy, Steady State Plus Transient:	±0.005 Hz for frequencies between 40.00 and 70.00 Hz
Maximum Pickup/Dropout Time:	3.0 cycles
Time-Delay Range:	0.04–300.00 s, 0.001-s increment
Time-Delay Accuracy:	±0.1% of setting plus ±0.0042 s
Pickup Range, Undervoltage Blocking:	20.00–200.00 V_{L-N} (Wye) or V_{L-L} (Open-Delta)
Pickup Accuracy, Undervoltage Blocking:	±2% of setting plus ±0.5 V

Volts/Hertz Elements (24)

Definite-Time Element

Pickup Range:	100% to 200% steady state
Pickup Accuracy, Steady-State:	±1% of setting
Maximum Pickup/Dropout Time:	1.5 cycles
Time-Delay Range:	0.0–400.00 s
Time-Delay Accuracy:	±0.1% of setting plus ±4.2 ms at 60 Hz
Reset Time-Delay Range:	0.00–400.00 s

User-Definable Curve Element

Pickup Range:	100% to 200%
Pickup Accuracy:	±1% of setting
Reset Time-Delay Range:	0.00–400.00 s

Breaker Failure Instantaneous Overcurrent

Setting Range	
5 A Nominal:	0.50–50 A, 0.01-A steps
1 A Nominal:	0.10–10.0 A, 0.01-A steps
Accuracy	
5 A Nominal:	±3% of setting plus ±0.05 A
1 A Nominal:	±3% of setting plus ±0.01 A
Transient Overreach	
5 A Nominal:	±5% of setting plus ±0.1 A
1 A Nominal:	±5% of setting plus ±0.02 A
Maximum Pickup Time:	1.5 cycles

Maximum Dropout Time:	Less than 1 cycle
Maximum Reset Time:	Less than 1 cycle
Timers	
Setting Range:	0–6000 cycles, 0.125-cycle steps
Time-Delay Accuracy:	±0.1% of setting plus ±0.125 cycle

Directional Overpower/Underpower Element

Operating Quantities:	OFF, 3P*m*F, 3Q*m*F,3P*qp*F, 3Q*qp*F (*m* = S, T, U, W, X, Y *qp* = ST, TU, UW, WX)
Pickup Range:	–20000.00 VA (secondary) to 20000.00 VA (secondary, 0.01 steps) Pickup range cannot fall within $\pm I_{NOM}$
Pickup Accuracy:	±3% of setting plus ±5 VA, power factor >±0.5 at nominal frequency
Time-Delay Range:	0.000–16,000 cycles, 0.25-cycle increment
Time-Delay Accuracy:	±0.1% of setting plus ±0.25 cycle

Bay Control

Breakers:	6 maximum
Disconnects (Isolators):	20 maximum
Timers	
Setting Range:	1–99999 cycles, 1-cycle steps
Time-Delay Accuracy:	±0.1% of setting plus ±0.25 cycle

Station DC Battery System Monitor Specifications

Rated Voltage:	24–250 Vdc
Operational Voltage Range:	0–300 Vdc
Sampling Rate:	2 kHz
Processing Rate:	1/8 cycle
Operating Time:	Less than 1.5 cycles (all elements except ac ripple) Less than 1.5 seconds (ac ripple element)

Setting Range

15–300 Vdc, 1 Vdc steps (all elements except ac ripple)

1–300 Vac, 1 Vac steps (ac ripple element)

Accuracy

Pickup Accuracy:	±3% of setting plus ±2 Vdc (all elements except ac ripple) ±10% of setting plus ±2 Vac (ac ripple element)

Metering Accuracy

All metering accuracies are based on an ambient temperature of 20°C and nominal frequency.

Currents

Phase Current Magnitude

5 A Model:	±0.2% plus ±4 mA (0.25–15 A secondary)
1 A Model:	±0.2% plus ±0.8 mA (0.05–3.0 A secondary)

Phase Current Angle

All Models:	±0.2° in the current range (0.5–3.0) • I_{NOM}

Sequence Current Magnitude

5 A Model:	±0.3% plus ±4 mA (0.25–15 A secondary)
1 A Model:	±0.3% plus ±0.8 mA (0.05–3 A secondary)

Sequence Current Angle

All Models:	±0.3° in the current range (0.5–3.0) • I_{NOM}

Voltages

300 V Maximum Inputs

Phase and Phase-to-Phase Voltage Magnitude:	±2.5% plus ±1 V (5–33.5 V) ±0.1% (33.5–300 V)
Phase and Phase-to-Phase Angle:	±1.0° (5–33.5 V) ±0.5° (33.5–300 V)
Sequence Voltage Magnitude (V1, V2, 3V0):	±2.5% plus ±1 V (5–33.5 V) ±0.1% (33.5–300 V)
Sequence Voltage Angle (V1, V2, 3V0):	±1.0° (5–33.5 V) ±0.5° (33.5–300 V)

8 V LEA Maximum Inputs

Phase and Phase-to-Phase Voltage Magnitude:	±0.3% (0.2–0.6 V) ±0.1% (0.6–8.0 V)
Phase and Phase-to-Phase Angle:	±0.5° (0.2–8.00 V)
Sequence Voltage Magnitude (V1, V2, 3V0):	±0.3%, (0.2–0.6 V) ±0.1% (0.6–8.0 V)
Sequence Voltage Angle (V1, V2, 3V0):	±0.5° (0.2–8.00 V)

Power

MW (P), Per Phase (Wye), 3ϕ (Wye or Delta) Per Terminal

±1% (0.1–1.2) • I_{NOM}, 33.5–300 Vac, PF = 1, 0.5 lead, lag (1ϕ)
±0.7% (0.1–1.2) • I_{NOM}, 33.5–300 Vac, PF = 1, 0.5 lead, lag (3ϕ)

MVAr (Q), Per Phase (Wye), 3ϕ (Wye or Delta) Per Terminal

±1% (0.1–1.2) • I_{NOM}, 33.5–300 Vac, PF = 0, 0.5 lead, lag (1ϕ)
±0.7% (0.1–1.2) • I_{NOM}, 33.5–300 Vac, PF = 0, 0.5 lead, lag (3ϕ)

MVA (S), Per Phase (Wye), 3ϕ (Wye or Delta) Per Terminal

±1% (0.1–1.2) • I_{NOM}, 33.5–300 Vac, PF = 1, 0.5 lead, lag (1ϕ)
±0.7% (0.1–1.2) • I_{NOM}, 33.5–300 Vac, PF = 1, 0.5 lead, lag (3ϕ)

PF, Per Phase (Wye), 3ϕ (Wye or Delta) Per Terminal

±1% (0.1–1.2) • I_{NOM}, 33.5–300 Vac, PF = 1, 0.5 lead, lag (1ϕ)
±0.7% (0.1–1.2) • I_{NOM}, 33.5–300 Vac, PF = 1, 0.5 lead, lag (3ϕ)

Energy

MWh (P), Per Phase (Wye), 3ϕ (Wye or Delta)

±1% (0.1–1.2) • I_{NOM}, 33.5–300 Vac, PF = 1, 0.5 lead, lag (1ϕ)
±0.7% (0.1–1.2) • I_{NOM}, 33.5–300 Vac, PF = 1, 0.5 lead, lag (3ϕ)

MVARh (Q), Per Phase (Wye), 3ϕ (Wye or Delta)

±1% (0.1–1.2) • I_{NOM}, 33.5–300 Vac, PF = 0, 0.5 lead, lag (1ϕ)
±0.7% (0.1–1.2) • I_{NOM}, 33.5–300 Vac, PF = 0, 0.5 lead, lag (3ϕ)

Demand/Peak Demand Metering

Time Constants:	5, 10, 15, 30, and 60 minutes
IA, IB, and IC per Terminal:	±0.2% plus ±0.0008 • I_{NOM}, (0.1–1.2) • I_{NOM}
3I2 per Terminal 3I0 (IG) per Terminal (Wye-Connected Only):	±0.3% plus ±0.0008 • I_{NOM}, (0.1–20) • I_{NOM}

Optional RTD Elements (Models Compatible With SEL-2600 Series RTD Module)

12 RTD inputs via SEL-2600 Series RTD Module and SEL-2800 Fiber-Optic Transceiver

Monitor Ambient or Other Temperatures

PT 100, NI 100, NI 120, and CU 10 RTD-Types Supported, Field Selectable

As long as 500 m Fiber-Optic Cable to SEL-2600 Series RTD Module

Synchrophasor

Number of Synchrophasor Data Streams:	5
Number of Synchrophasors for Each Stream:	24 Phase Synchrophasors (6 Voltage and 18 Currents) 8 Positive-Sequence Synchrophasors (2 Voltage and 6 Currents)
Number of User Analogs for Each Stream:	16
Number of User Digitals for Each Stream:	64
Synchrophasor Protocol:	IEEE C37.118-2005, SEL Fast Message (Legacy)
Synchrophasor Data Rate:	As many as 60 messages per second
Synchrophasor Accuracy	
Voltage Accuracy:	±1% Total Vector Error (TVE) Range 30–150 V, f_{NOM} ±5 Hz
Current Accuracy:	±1% Total Vector Error (TVE) Range (0.1–2.0) • I_{NOM} A, f_{NOM} ±5 Hz
Current Accuracy:	±1% Total Vector Error (TVE) Range (0.1–2.0) • I_{NOM} A, f_{NOM} ±5 Hz
Synchrophasor Data Recording:	Records as much as 120 s IEEE C37.232-2011, File Naming Convention

Breaker Monitoring

Running Total of Interrupted Current (kA) per Pole:	±5% plus ±0.02 • I_{NOM}
Percent kA Interrupted for Trip Operations:	±5%
Percent Breaker Wear per Pole:	±5%
Compressor/Motor Start and Run Time:	±1 s
Time Since Last Operation:	±1 day

This page intentionally left blank

SECTION 2

Installation

The first steps in applying the SEL-487E-5 are installing and connecting the relay. This section describes common installation features and particular installation requirements for the many physical configurations of the SEL-487E. You can order the relay in horizontal and vertical orientations, and in panel-mount and rack-mount versions. SEL also provides various expansion I/O interface boards to tailor the relay to your specific needs.

To install and connect the relay safely and effectively, you must be familiar with relay configuration features and options and relay jumper configuration. You should carefully plan relay placement, cable connection, and relay communication. Consider the following when installing the SEL-487E:

- *Shared Configuration Attributes on page 2.1*
- *Plug-In Boards on page 2.12*
- *Jumpers on page 2.14*
- *Relay Placement on page 2.23*
- *Connection on page 2.25*
- *Merging Unit AC/DC Connections on page 2.38*

It is also very important to limit access to the SEL-487E settings and control functions by using passwords. For information on relay access levels and passwords, see *Changing the Default Passwords in the Terminal on page 3.11 in the SEL-400 Series Relays Instruction Manual*.

For more introductory information on using the relay, see *Section 2: PC Software* and *Section 3: Basic Relay Operations in the SEL-400 Series Relays Instruction Manual*.

Shared Configuration Attributes

There are common or shared attributes among the many possible configurations of SEL-487E relays. This section discusses the main shared features of the relay.

Relay Sizes

The SEL-487E-5 is available in 6U, 7U, and 8U sizes when ordered as an Sampled Values (SV) publisher. Relay sizes correspond to height in rack units, U, where U is approximately 44.45 mm (1.75 in). All relay sizes are available in a horizontal configuration as a rack-mount or panel-mount relay. The 6U size is available with one I/O board. The 7U version can support as many as two I/O boards, and the 8U version can support as many as three I/O boards.

The relay is also available in a 4U chassis when ordered as an SV subscriber or an SEL Time-Domain Link (TiDL) relay. The 4U chassis is available in a horizontal or vertical configuration as a rack-mount or panel-mount relay.

Front-Panel Templates

The horizontal front-panel template for the SEL-487E-5 shown in *Figure 2.1(a)* is the same for the 4U, 6U, 7U, and 8U horizontal versions of the relay. The vertical front-panel template for the 4U version is shown in *Figure 2.1(b)*.

The SEL-487E front panel has several pockets for slide-in labels: one pocket for the target LED label, and two to three pockets for the operator control labels. *Figure 2.1* shows the front-panel pocket areas and openings for typical horizontal and vertical relay orientations; dashed lines denote the pocket areas. Refer to the instructions included in the Configurable Label kit for information on reconfiguring front-panel LED and pushbutton labels.

Figure 2.1 Horizontal Front-Panel Template (a); Vertical Front-Panel Template (b)

Rear Panels

Rear panels are identical for the horizontal and the vertical configurations of the relay. See *Figure 2.2–Figure 2.6* for representative 4U, 6U, 7U, and 8U relay rear panels.

Connector Types

Screw-Terminal Connectors—I/O and MONITOR/POWER

Connect to the relay I/O and **MONITOR/POWER** terminals on the rear panel through screw-terminal connectors. You can remove the entire screw-terminal connector from the back of the relay to disconnect relay I/O, dc battery monitor, and power without removing each wire connection. The screw-terminal connectors are keyed (see *Figure 2.27*), so you can replace the screw-terminal connector on the rear panel only at the location from which you removed the screw-terminal connector. In addition, the receptacle key prevents you from inverting the screw-terminal connector, making removal and replacement easier.

Secondary Circuit Connectors

Fixed Terminal Blocks

Connect PT and CT inputs to the fixed terminal blocks in the bottom row of the relay rear panel. You cannot remove these terminal blocks from the relay rear panel. These terminals offer a secure high-reliability connection for PT and CT secondaries.

Connectorized

The Connectorized SEL-487E features receptacles that accept plug-in/plug-out connectors for terminating CT and PT inputs. This requires ordering a Connectorized wiring harness kit (SEL-WA0487E) with mating plugs and wire leads. *Figure 2.3* shows the relay with Connectorized CT and PT analog inputs (see *Connectorized on page 2.31* for more information). Euro connectors are also available for low-energy analog (LEA) voltage inputs, as shown in *Figure 2.4*.

Figure 2.2 Rear Panel With Fixed Terminal Blocks (8U) and INT4 I/O Boards

Figure 2.3 Rear Panel Connectorized (7U) With INT2 I/O Boards

Figure 2.4 Rear Panel Connectorized With LEA Voltage Inputs (6U) With INT8 I/O Board

Five-port Ethernet card ordering option depicted.

Figure 2.5 SV Subscriber Relay Rear Panel (4U) With INT4 I/O Board

Four-port Ethernet card ordering option depicted.

Figure 2.6 TiDL Relay Rear Panel (4U) With INT4 I/O Board

Secondary Circuits

SV Subscriber Relays and TiDL Relays

SEL-487E-5 relays that subscribe to data (through SV or TiDL communications) do not contain secondary circuits on the relay. The relay uses a merging unit to supply the voltages and currents through a networked connection (for the SV subscriber) or a direct point-to-point (for the TiDL relay). Both the SV subscriber version and the TiDL relay version must be configured to match the nominal secondary current of the mapped current inputs of the connected merging units. The SV subscriber and TiDL relay both, by default, assume 5 A as the nominal current selection for all terminals. For 1 A scaling or available terminal combinations of 1 A and 5 A nominal inputs, use the **CFG CTNOM** command (see *Table 14.28 in the SEL-400 Series Relays Instruction Manual* for more information).

SV Publisher Relays

The SEL-487E-5 SV Publisher presents a low burden load on the CT secondaries and PT secondaries. The relay accepts the following five sets of three-phase CT inputs:

- IAS, IBS, and ICS
- IAT, IBT, and ICT
- IAU, IBU, and ICU
- IAW, IBW, and ICW
- IAX, IBX, and ICX

⚠WARNING
Before working on a CT circuit, first apply a short to the secondary winding of the CT.

The relay also accepts the following three single-phase CT inputs, primarily for restricted earth fault protection: IY1, IY2, and IY3. When IY1, IY2, and IY3 are ordered with matching rated nominal current inputs, you can use Terminal Y as a sixth set of three-phase CT inputs: IAY, IBY, and ICY.

For 5 A relays, the rated nominal input current, I_{NOM}, is 5 A. For 1 A relays, the rated nominal input current, I_{NOM}, is 1 A. Continuous input current for both relay types is 3 • I_{NOM} (or 4 • I_{NOM} as high as 55°C). See *AC Current Inputs (Secondary Circuits) on page 1.24* for complete CT input specifications.

The relay also accepts the following two sets of three-phase potentials from power system PT, LEA, or CCVT (capacitor-coupled voltage transformer) secondaries.

- VAV, VBV, and VCV
- VAZ, VBZ, and VCZ

The nominal line-to-neutral input voltage for the PT inputs is 67 V with a range of 0–300 V. PT connections can be four-wire (wye) or open-delta connections. For LEA inputs, the nominal input is 4 V with a range of 0–8 V.

See *Secondary Circuit Connections on page 2.30* for information on connecting power system secondary circuits to these inputs.

Control Inputs

Optoisolated

The SEL-487E inputs on the optional I/O interface boards (INT2, INT4, INTD, INT7, or INT8 I/O boards—see *Models and Options on page 1.8*), are fixed pickup threshold, optoisolated, control inputs. The pickup voltage level is determined for each board at ordering time.

Inputs can be independent or common. Independent inputs have two separate ground-isolated connections, with no internal connections among inputs. Common inputs share one input leg in common; all input legs of common inputs are ground-isolated. Each group of common inputs is isolated from all other groups.

Nominal current drawn by these inputs is 8 mA or less with six voltage options covering a wide range of voltages, as listed in *Control Inputs on page 1.25*. You can debounce the control input pickup delay and dropout delay separately for each input, or you can use a single debounce setting that applies to all the contact input pickup and dropout times (see *Global Settings on page 8.2*).

AC Control Signals

Optoisolated control inputs can be used with ac control signals, within the ratings shown in *Control Inputs on page 1.25*. Specific pickup and dropout time-delay settings are required to achieve the specified ac thresholds, as shown in *Table 2.1*.

It is possible to mix ac and dc control signal detection on the same interface board with optoisolated contact inputs, provided that the two signal types are not present on the same set of combined inputs. Use standard debounce time settings (usually the same value in both the pickup and dropout settings) for the inputs being used with dc control voltages.

Table 2.1 Required Settings for Use With AC Control Signals

Global Settings[a]	Prompt	Entry[b]	Relay Recognition Time for AC Control Signal state change
IN*nmm*PU[c]	Pickup Delay	0.1250 cycles	0.625 cycles maximum (assertion)
IN*nmm*DO[c]	Dropout Delay	1.0000 cycle	1.1875 cycles maximum (deassertion)

[a] First set Global setting EICIS := Y to gain access to the individual input pickup and dropout timer settings.
[b] These are the only setting values that SEL recommends for detecting ac control signals. Other values may result in inconsistent operation.
[c] Where n is 2 for Interface Board 1, 3 for Interface Board 2, and 4 for Interface Board 3. mm = number of available contact inputs depending on the type of board.

The recognition times listed in *Table 2.1* are only valid when:

- The ac signal applied is at the same frequency as the power system.
- The signal is within the ac threshold pickup ranges defined in *Optoisolated (Use With AC or DC Signals) on page 1.25*.
- The signal contains no dc offset.

The SEL-487E samples the optoisolated inputs at 2 kHz (see *Data Processing on page 9.1 in the SEL-400 Series Relays Instruction Manual*).

Control Outputs

I/O control outputs from the relay include standard outputs, hybrid (high-current interrupting) outputs, and high-speed, high-current interrupting outputs. High-speed, high-current interrupting outputs are available on the optional INT4 and INT8 I/O interface boards. A metal oxide varistor (MOV) protects against excess voltage transients for each contact. Each output is individually isolated, except Form C outputs, which share a common connection between the NC (normally closed) and NO (normally open) contacts.

The relay updates control outputs eight times per cycle. Updating of relay control outputs does not occur when the relay is disabled. When the relay is reenabled, the control outputs assume the state that reflects the present protection processing.

For the SEL-487E-5 TiDL relay, the control outputs of the connected SEL-TMUs map to local I/O of the relay (in the 300, 400, and 500 level of I/O) based on your configured TiDL topology in Grid Configurator. Because any control output on the SEL-TMU can be shared across the connected SEL TiDL relays, the SEL-TMU provides the state (asserted/deasserted) of each output to all connected SEL TiDL relays. The SEL TiDL relays then map the SEL-TMU output states to local output states based on the configured TiDL topology.

Standard Control Outputs

NOTE: You can use ac or dc circuits with standard control outputs.

The standard control outputs are "dry" Form A contacts rated for tripping duty. Ratings for standard outputs are 30 A make, 6 A continuous, and 0.75 A or less break (depending on circuit voltage). Standard contact outputs have a maximum voltage rating of 250 Vac/330 Vdc. Maximum break time is 6 ms (milliseconds) with a resistive load. The maximum pickup time for the standard control outputs is 6 ms (see *Figure 2.7*).

Figure 2.7 Standard Control Output Connection

See *Control Outputs on page 1.25* for complete standard control output specifications.

Hybrid (High-Current Interrupting) Control Outputs

⚠CAUTION
Equipment damage can result from connecting ac circuits to Hybrid (high-current interrupting) control outputs. Do not connect ac circuits to Hybrid control outputs. Use only dc circuits with Hybrid control outputs.

The hybrid (high-current interrupting) control outputs are polarity-dependent and are capable of interrupting high-current, inductive loads. Hybrid control outputs use an insulated-gate bipolar junction transistor (IGBT) in parallel with a mechanical contact to interrupt (break) highly inductive dc currents. The contacts can carry continuous current, while eliminating the need for heat sinking and providing security against voltage transients.

With any hybrid output, break time varies according to the circuit inductive/resistive (L/R) ratio. As the L/R ratio increases, the time needed to interrupt the circuit fully increases also. The reason for this increased interruption delay is that circuit current continues to flow through the output MOV after the output deasserts, until all of the inductive energy dissipates. Maximum dropout (break) time is 6 ms with a resistive load, the same as for the standard control outputs. The other ratings of these control outputs are similar to the standard control outputs, except that the hybrid outputs can break current as great as 10 A. Hybrid contact outputs have a maximum voltage rating of 330 Vdc.

The maximum pickup time for the hybrid control outputs is 6 ms. *Figure 2.8* shows a representative connection for a Form A hybrid control output.

Figure 2.8 Hybrid Control Output Connection

See *Section 1: Introduction and Specifications*, for complete hybrid control output specifications.

Short transient inrush current can flow at the closing of an external switch in series with open high-current interrupting contacts. This transient will not energize the circuits in typical relay-coil control applications (trip coils and close coils), and standard auxiliary relays will not pick up. However, an extremely sensitive digital input or light-duty, high-speed auxiliary relay can pick up for this condition. This false pickup transient occurs when the capacitance of the high-speed, high-current interrupting output circuitry charges (creating a momentary short circuit that a fast, sensitive device sees as a contact closure). When using I/O boards other than INT8, avoid possible false pickups of the output contact by connecting an external resistor across the output contact (see the high-speed, high-current interrupting, and the high-speed, high-current output discussions for more details).

High-Speed, High-Current Interrupting Control Outputs

NOTE: You can use only dc circuits with high-speed, high-current interrupting outputs.

In addition to the standard control outputs and the hybrid control outputs, the INT4 and INT8 I/O interface boards offer high-speed high-current interrupting control outputs. A metal-oxide varistor (MOV) protects against excess voltage transients for each contact. These control outputs have a resistive load contact closing time of 10 µs, which is much faster than the 6 ms contact closing time of the standard and hybrid control outputs. The high-speed contact outputs open at a maximum time of 8 ms. The maximum voltage rating is 330 Vdc. See *Control Outputs on page 2.8* for more information.

Figure 2.9 shows a representative connection for a Form A high-speed contact output on the INT4 I/O interface terminals. The HS marks are included to indicate that this is a high-speed control output.

Figure 2.9 INT4 High-Speed Control Output Connection

Figure 2.10 shows a representative connection for a Form A fast hybrid control output on the INT8 I/O interface terminals.

The INT8 high-speed contact output uses three terminal positions, while the INT4 high-speed contact output uses two. The third terminal of each INT8 high-speed control output is connected to precharge resistors that can be used to mitigate transient inrush current conditions, as explained below. A similar technique can be used with INT4 board high-speed control outputs using external resistors. Short transient inrush current can flow at the closing of an external switch in series with open high-speed contacts. This transient will not energize the circuits in typical relay-coil control applications (trip coils and close coils), and standard auxiliary relays will not pick up. However, an extremely sensitive digital input or light-duty, high-speed auxiliary relay can pick up for this condition. This false pickup transient occurs when the capacitance of the high-speed output circuitry charges (creating a momentary short circuit that a fast, sensitive device sees as a contact closure). A third terminal (03 in *Figure 2.10*) provides an internal path for precharging the high-speed output circuit capacitance when the circuit is open.

Figure 2.10 High-Speed Control Output Typical Terminals, INT8

Figure 2.11 shows some possible connections for this third terminal that will eliminate the false pickup transients when closing an external switch. In general, you must connect the third terminal to the dc rail (positive or negative) that is on the same side as the open external switch condition. If an open switch exists on either side of the output contact, then you can accommodate only one condition because two open switches (one on each side of the contact) defeat the precharge circuit.

Figure 2.11 Precharging Internal Capacitance of High-Speed Output Contacts, INT8

For wiring convenience, on the INT8 I/O interface board, the precharge resistors shown in *Figure 2.11* are built into the I/O board, and connected to a third terminal. On the INT4 I/O interface board, there are no built-in precharge resistors, and each high-speed control output has only two terminal connections.

IRIG-B Inputs

The SEL-487E has a regular IRIG-B timekeeping mode, and a high-accuracy IRIG-B (HIRIG) timekeeping mode. The IRIG-B serial data format consists of a 1-second frame containing 100 pulses divided into fields, from which the relay decodes the second, minute, hour, and day fields and sets the internal time clock upon detecting valid time data in the IRIG time mode. There are two IRIG-B inputs on the SEL-487E rear panel, capable of supporting the HIRIG mode.

IRIG-B Pins of Serial PORT 1

This IRIG-B input is capable of both modes of timekeeping. If the connected timekeeping source is qualified as high-accuracy, the relay enters the HIRIG mode, which has a timing accuracy of 1 µs.

IRIG-B BNC Connector

This IRIG-B input is capable of both modes of timekeeping. If the connected timekeeping source is qualified as high-accuracy, the relay enters the HIRIG mode, which has a timing accuracy of 1 µs. If IRIG-B is present on both Serial Port 1 and the BNC connector, the relay uses the IRIG-B signal from the BNC connection (if a signal is available).

Battery-Backed Clock

If relay input power is lost or removed, a lithium battery powers the relay clock, providing date and time backup. The battery is a 3 V lithium coin cell, Rayovac No. BR2335 or equivalent. If power is lost or disconnected, the battery discharges to power the clock. At room temperature (25°C), the battery will operate for approximately 10 years at rated load.

When the SEL-487E is operating with power from an external source, the self-discharge rate of the battery only is very small. Thus, battery life can extend well beyond the nominal 10-year period because the battery rarely discharges after the relay is installed. The battery cannot be recharged. *Figure 2.18* shows the clock battery location (at the front of the main board).

If the relay does not maintain the date and time after power loss, replace the battery (see *Replacing the Lithium Battery on page 10.27 in the SEL-400 Series Relays Instruction Manual*).

Communications Interfaces

The SEL-487E has several communications interfaces you can use to communicate with other IEDs via EIA-232 ports: **PORT 1**, **PORT 2**, **PORT 3**, and **PORT F**. See *Section 10: Communications Interfaces* for more information and options for connecting your relay to the communications interfaces.

The Ethernet card gives the relay access to popular Ethernet networking standards including TCP/IP, FTP, Telnet, DNP3, IEEE C37.118 Synchrophasors, and IEC 61850 over local area and wide area networks. For information on DNP3 applications, see *Section 16: DNP3 Communication in the SEL-400 Series Relays Instruction Manual*. For more information on IEC 61850 applications, see *Section 17: IEC 61850 Communication in the SEL-400 Series Relays Instruction Manual*.

Plug-In Boards

NOTE: Ordering relays with partial I/O allows for future system expansion and future use of additional relay features.

The relay is available in many input/output configuration options. SV subscriber and TiDL models use a 4U chassis with one I/O board (there are no I/O on the main board) and screw-terminal connector connections (see *Figure 2.2*). SV publisher models can be ordered with larger enclosures (6U, 7U, and 8U) with all, partial, or no extra I/O boards installed.

I/O Interface Boards

You can choose among five input/output interface boards for the I/O slots of the 4U, 6U, 7U, and 8U chassis. The I/O interface boards are INT2, INT4, INTD, INT7, and INT8. *Figure 2.12–Figure 2.16* show the rear screw-terminal connectors associated with these interface boards.

Figure 2.12 INT2 I/O Interface Board (Standard)

Figure 2.13 INT4 I/O Interface Board (High-Speed, High-Current)

Figure 2.14 INTD I/O Interface Board (Standard)

Figure 2.15 INT7 I/O Interface Board (High-Current)

Figure 2.16 INT8 I/O Interface Board (High-Speed, High-Current)

The I/O interface boards carry jumpers that identify the board location (see *Jumpers on page 2.14*).

I/O Interface Board Inputs

⚠CAUTION
Substation battery systems that have either a high resistance to ground (greater than 10 kΩ) or are ungrounded when used in conjunction with many direct-coupled inputs can reflect a dc voltage offset between battery rails. Similar conditions can exist for battery monitoring systems that have high-resistance balancing circuits or floating grounds. For these applications, SEL provides optional ground-isolated (optoisolated) contact inputs. In addition, SEL has published an application advisory on this issue. Contact the factory for more information.

The INT4 and INTD I/O interface board has two groups of 9 common contacts (18 total) and 6 independent control inputs. The INT2, INT7, and INT8 I/O interface boards have eight independent control inputs. All independent inputs are isolated from other inputs. These control inputs are optoisolated and hence are not polarity-sensitive, i.e., the relay will detect input changes with voltage applied at either polarity, or ac signals when properly configured, (see *Optoisolated on page 2.32*).

Table 2.2 is a comparison of the I/O board input capacities; the table also shows the absence of I/O inputs on the Main Board. See *Control Inputs on page 1.25* for complete control input specifications.

Table 2.2 I/O Interface Boards Control Inputs

Board	Independent Contact Pairs	Common Contacts
INT2, INT7, and INT8	8	0
INT4 and INTD	6	Two sets of 9

I/O Interface Board Outputs

NOTE: Form A control outputs cannot be jumpered to Form B.

The I/O interface boards vary by the type and amount of output capabilities. *Table 2.3* lists the outputs of the I/O interface boards. Information about the standard and hybrid (high-current interrupting) control outputs is in *Control Outputs on page 2.33*.

Table 2.3 I/O Interface Boards Control Outputs

Board	Standard		High-Speed, High-Current Interrupting	Hybrid[a]
	Form A	Form C	Form A	Form A
INT2	13	2	0	0
INT4	2	0	6	0
INTD	8	0	0	0
INT7	0	2	0	13
INT8	0	0	8	0
Main Board	0	0	0	0

[a] High-Current Interrupting.

Ethernet Card

Factory-installed in the rear relay PORT 5, the Ethernet card provides Ethernet ports for industrial applications that process data traffic between the relay and a LAN.

Jumpers

The SEL-487E contains jumpers that configure the relay for certain operating modes. The jumpers are located on the main board (the top board) and the I/O interface boards (one or two boards located immediately below the main board).

Main Board Jumpers

The jumpers on the main board of the SEL-487E perform these functions:

- Temporary/emergency password disable
- Circuit breaker and disconnect control enable

Figure 2.18 shows the positions of the main board jumpers. The main board jumpers are in two locations. The password disable jumper and circuit breaker control jumper are at the front of the main board. The serial port jumpers are on the EIA-232 card.

Password and Circuit Breaker Jumpers

You can access the password disable jumper and circuit breaker control jumper without removing the main board from the relay cabinet. Remove the SEL-487E front cover to view these jumpers (use appropriate ESD precautions). The password and circuit breaker jumpers are located on the front of the main board, immediately left of the power connector (see *Figure 2.17*).

⚠CAUTION
Do not install a jumper on positions A or D of the main board J18 header. Relay misoperation can result if you install jumpers on positions J18A and J18D.

There are four jumpers, denoted **D**, **BREAKER**, **PASSWORD**, and **A** from left to right (position **D** is on the left). Position **PASSWORD** is the password disable jumper; position **BREAKER** is the circuit breaker control enable jumper. Positions **D** and **A** are for SEL use. *Figure 2.17* shows the jumper header with the circuit breaker/control jumper in the **ON** position and the password jumper in the **OFF** position; these are the normal jumper positions for an in-service relay. *Table 2.4* lists the jumper positions and functions.

Figure 2.17 Jumper Location on the Main Board

Table 2.4 Main Board Jumpers

Jumper	Jumper Location	Jumper Position[a]	Function
A	Front	OFF	For SEL use only
PASSWORD	Front	OFF	Enable password protection (normal and shipped position)
		ON	Disable password protection (temporary or emergency only)
BREAKER	Front	OFF	Disable circuit breaker commands (**OPEN** and **CLOSE**) and output **PULSE** commands[b] (shipped position)
		ON	Enable circuit breaker commands (**OPEN** and **CLOSE**) and output **PULSE** commands[b]
D	Front	OFF	For SEL use only

[a] ON is the jumper shorting both pins of the jumper. Place the jumper over one pin only for OFF.

[b] Also affects the availability of the Fast Operate Breaker Control Messages and the front-panel `LOCAL CONTROL > BREAKER CONTROL`, and front-panel `LOCAL CONTROL > OUTPUT TESTING` screens.

The password disable jumper, **PASSWORD**, is for temporary or emergency suspension of the relay password protection mechanisms. Under no circumstance should you install **PASSWORD** on a long-term basis. The SEL-487E ships with the **PASSWORD** jumper in the **OFF** position (passwords enabled).

The circuit breaker control enable jumper, **BREAKER**, supervises the **CLOSE *n*** command, the **OPEN *n*** command, the **PULSE OUT*nnn*** command, and front-panel local bit control. To use these functions, you must install the **BREAKER**

jumper. The relay checks the status of the BREAKER jumper when you issue the **CLOSE *n***, **OPEN *n***, or **PULSE OUT*nnn*** command, and when you use the front panel to close or open circuit breakers, control a local bit, or pulse an output. The SEL-487E ships with the BREAKER jumper in the OFF position. For commissioning and testing of the SEL-487E contact outputs, it may be convenient to set the BREAKER jumper to ON, so that the **PULSE OUT*nnn*** commands can be used to check output wiring. The BREAKER jumper must also be set to ON if SCADA control of the circuit breaker via Fast Operate is required, or if the LOCAL CONTROL > BREAKER CONTROL screens are going to be used.

Figure 2.18 Major Component Locations on the SEL-487E Main Board

Serial Port Jumpers

Place jumpers on the EIA-232 board to connect +5 Vdc to Pin 1 of each of the three rear-panel EIA-232 serial ports. The maximum current available from this Pin 1 source is 0.5 A. The Pin 1 source is useful for powering an external modem. *Table 2.5* describes the JMP1 and JMP2 positions. Refer to *Figure 2.18* for the locations of these jumpers. The SEL-487E ships with the JMP1A, JMP2A, and JMP2B jumpers in the OFF position (no +5 Vdc on Pin 1).

Table 2.5 Serial Port Jumpers

Jumper	Jumper Location	Jumper Position[a]	Function
JMP1	A	OFF	Serial PORT 1, Pin 1 = not connected
		ON	Serial PORT 1, Pin 1 = +5 Vdc
	B	—	Not used
JMP2	A	OFF	Serial PORT 2, Pin 1 = not connected
		ON	Serial PORT 2, Pin 1 = +5 Vdc
	B	OFF	Serial PORT 3, Pin 1 = not connected
		ON	Serial PORT 3, Pin 1 = +5 Vdc

[a] ON is the jumper shorting both pins of the jumper. Place the jumper over one pin only for OFF.

Figure 2.19 Main Components of the EIA-232 Board, Showing the Location of Serial Port Jumpers JMP1 and JMP2

Changing Serial Port Jumpers

⚠DANGER
Contact with instrument terminals can cause electrical shock that can result in injury or death.

⚠WARNING
Have only qualified personnel service this equipment. If you are not qualified to service this equipment, you can injure yourself or others, or cause equipment damage.

⚠CAUTION
Equipment components are sensitive ESD. Undetectable permanent damage can result if you do not use proper ESD procedures. Ground yourself, your work surface, and this equipment before removing any cover from this equipment. If your facility is not equipped to work with these components, contact SEL about returning this device and related SEL equipment for service.

You must remove the EIA-232 board to access the serial port jumpers. Perform the following steps to change the **JMP1A**, **JMP2A**, and **JMP2B** jumpers in an SEL-487E:

Step 1. Follow your company standard to remove the merging unit from service.

Step 2. Disconnect power from the merging unit.

Step 3. Retain the **GND** connection, if possible, and ground the equipment to an ESD mat.

Step 4. Unscrew the keeper screws and disconnect any serial cables connected to the **PORT 1**, **PORT 2**, and **PORT 3** rear-panel receptacles. Disconnect the IRIG-B cable from the BNC connector.

Step 5. Loosen the screws retaining the serial port plug-in card and remove the card.

Step 6. Locate the jumper you want to change (see *Figure 2.19*).

Step 7. Install or remove the jumper as needed (see *Table 2.5* for jumper position descriptions).

Step 8. Reinstall the relay EIA-232 board and tighten the keeper screws.

Step 9. Reconnect any serial cables that you removed from the EIA-232 ports in the disassembly process.

Step 10. Follow your company standard procedure to return the merging unit to service.

I/O Interface Board Jumpers

Jumpers on the I/O interface boards identify the particular I/O board configuration and I/O board control address. The jumpers on these I/O interface boards are at the front of each board.

Figure 2.20 Major Jumper and Connector Locations on the INT2 I/O Board

Figure 2.21 Major Jumper and Connector Locations on the INT4 I/O Board

Figure 2.22 Major Jumper and Connector Locations on the INT8 I/O Board

Figure 2.23 Major Jumper and Connector Locations on the INT7 I/O Board

To confirm the positions of your I/O board jumpers, remove the front panel and visually inspect the jumper placements. *Table 2.6* lists the four jumper positions for I/O interface boards. Refer to *Figure 2.20* and *Figure 2.21* for the locations of these jumpers.

The I/O board control address has a hundreds-series prefix attached to the control inputs and control outputs for that particular I/O board chassis slot. A 4U or 6U chassis has a 200-addresses slot for inputs IN201, IN202, etc., and outputs

OUT201, OUT202, etc. A 7U chassis has a 200-addresses slot and a 300-addresses slot. A 8U chassis has a 200-addresses slot, a 300-addresses slot, and a 400-addresses slot.

The drawout tray on which each I/O board is mounted is keyed. See *Installing Optional I/O Interface Boards on page 10.30 in the SEL-400 Series Relays Instruction Manual* for information on the key positions for the 200-addresses slot trays, 300-addresses slot trays, and 400-addresses slot trays.

Table 2.6 I/O Board Jumpers

I/O Board Control Address	JMP1A/ JMP49A[a]	JMP1B/ JMP49B[a]	JMP2A/ JMP50A[a]	JMP2B/ JMP50B[a]
2XX	OFF	OFF	OFF	OFF
3XX	ON	OFF	ON	OFF
4XX	OFF	ON	OFF	ON

[a] INT4 and INTD I/O interface board jumper numbering.

Relay Placement

Proper placement of the SEL-487E helps make certain that you receive years of trouble-free power system protection. Use the following guidelines for proper physical installation of the SEL-487E.

Physical Location

You can mount the SEL-487E in a sheltered indoor environment (a building or an enclosed cabinet) that does not exceed the temperature and humidity ratings for the relay.

The relay is rated at Installation/Overvoltage Category II and Pollution Degree 2. This rating allows mounting the relay indoors or in an outdoor (extended) enclosure where the relay is protected against exposure to direct sunlight, precipitation, and full wind pressure, but neither temperature nor humidity are controlled.

You can place the relay in extreme temperature and humidity locations. The temperature range over which the relay operates is –40° to +185°F (–40° to +85°C, see *Operating Temperature on page 1.27*). The relay operates in a humidity range from 5 to 95 percent, no condensation, and is rated for installation at a maximum altitude of 2000 m (6560 ft) above mean sea level.

Rack Mounting

When mounting the SEL-487E in a rack, use the reversible front flanges to either semiflush-mount or projection-mount the relay. The semiflush mount gives a small panel protrusion from the relay rack rails of approximately 1.1 in or 27.9 mm. The projection mount places the front panel approximately 3.5 in or 88.9 mm in front of the relay rack rails.

See *Figure 2.24* for exact mounting dimensions for both the horizontal and vertical rack-mount 4U relays. See *Figure 2.25* for exact mounting dimensions for 6U, 7U, or 8U relays. Use four screws of the appropriate size for your rack.

Figure 2.24 SEL-487E 4U Chassis Dimensions

DIMENSION	ONE I/O BOARD (6U)	TWO I/O BOARD (7U)	THREE I/O BOARD (8U)
A	10.47 [265.9]	12.22 [310.4]	13.97 [354.8]
B	7.50 [190.5]	9.25 [235.0]	11.00 [279.4]
C	11.90 [302.3]	13.65 [346.7]	15.40 [391.2]
D	10.35 [262.9]	12.10 [307.3]	13.85 [351.8]
E	3.00 [76.2]	2.25 [57.2]	3.00 [76.2]

*ADD 0.30 [7.6] FOR CONNECTORIZED RELAYS

Figure 2.25 SEL-487E 6U, 7U, and 8U Chassis Dimensions

Panel Mounting

Place the panel-mount versions of the SEL-487E in a switchboard panel. See the drawings in *Figure 2.24* for panel cut and drill dimensions (these dimensions apply to both the horizontal and vertical panel-mount relay versions). Use the supplied mounting hardware to attach the relay.

Connection

⚠CAUTION
Insufficiently rated insulation can deteriorate under abnormal operating conditions and cause equipment damage. For external circuits, use wiring of sufficiently rated insulation that will not break down under abnormal operating conditions.

The SEL-487E-5 is available as an SV subscriber or publisher, or as a TiDL relay. This section presents a representative sample of relay rear-panel configurations and the connections to these rear panels. Only horizontal chassis are shown; rear panels of vertical chassis are identical to horizontal chassis rear panels for the 4U chassis size.

When connecting the SEL-487E, refer to your company plan for wire routing and wire management. Be sure to use wire that is appropriate for your installation with an insulation rating of at least 90°C.

Rear-Panel Layout

Figure 2.2–Figure 2.6 show some of the available SEL-487E rear panels.

All relay versions have screw-terminal connectors for I/O, power, and battery monitor. You can order the relay with fixed terminal blocks for the CT and PT connections, or you can order SEL Connectorized rear-panel configurations that feature plug-in/plug-out PT connectors and shorting CT connectors for relay analog inputs.

The screw-terminal connections for the INT2 and the INT7 I/O interface boards are the same. The INT8 I/O interface board has control output terminals grouped in threes, with the fourth terminal as a blank additional separator (Terminals 4, 8, 12, 16, 20, 24, 28, and 32). The INT4 and INT8 I/O interface boards both contain fast hybrid control outputs, but use a different terminal layout—see *Control Outputs on page 2.8* for details.

Rear-Panel Symbols

There are important safety symbols on the rear of the SEL-487E (see *Figure 2.26*). Observe proper safety precautions when you connect the relay at terminals marked by these symbols. In particular, the danger symbol located on the rear panel corresponds to the following: Contact with instrument terminals can cause electrical shock that can result in injury or death. Be careful to limit access to these terminals.

Danger (Caution, risk of danger) Symbol | Grounding Terminal Symbol | AC/DC Input Symbol | DC Input Symbol

Figure 2.26 Rear-Panel Symbols

Screw-Terminal Connectors

Terminate connections to the SEL-487E screw-terminal connectors with ring-type crimp lugs. Use a #8 ring lug with a maximum width of 9.1 mm (0.360 in). The screws in the rear-panel screw-terminal connectors are #8-32 binding head, slotted, nickel-plated brass screws. Tightening torque for the terminal connector screws is 1.0 Nm to 2.0 Nm (9 in-lb to 18 in-lb).

You can remove the screw-terminal connectors from the rear of the SEL-487E by unscrewing the screws at each end of the connector block. Perform the following steps to remove a screw-terminal connector:

Step 1. Remove the connector by pulling the connector block straight out.

Note that the receptacle on the relay circuit board is keyed; you can insert each screw-terminal connector in only one location on the rear panel.

Step 2. To replace the screw-terminal connector, confirm that you have the correct connector and push the connector firmly onto the circuit board receptacle.

Step 3. Reattach the two screws at each end of the block.

Changing Screw-Terminal Connector Keying

You can rotate a screw-terminal connector so that the connector wire dress position is the reverse of the factory-installed position (for example, wires entering the relay panel from below instead of from above). In addition, you can move

similar function screw-terminal connectors to other locations on the rear panel. To move these connectors to other locations, you must change the screw-terminal connector keying.

Inserts in the circuit board receptacles key the receptacles for only one screw-terminal connector in one orientation. Each screw-terminal connector has a missing web into which the key fits (see *Figure 2.27*).

If you want to move a screw-terminal connector to another circuit board receptacle or reverse the connector orientation, you must rearrange the receptacle keys to match the screw-terminal connector block. Use long-nosed pliers to move the keys.

Figure 2.28 shows the factory-default key positions.

Figure 2.27 Screw-Terminal Connector Keying

Figure 2.28 Rear-Panel Receptacle Keying

Grounding

Connect the grounding terminal (#Z31) labeled GND on the rear panel to a rack frame ground or main station ground for proper safety and performance.

This protective earthing terminal is in the lower right side of the relay panel (see *Figure 2.2–Figure 2.6*). The symbol that indicates the grounding terminal is shown in *Figure 2.26*.

Use 2.5 mm^2 (14 AWG) or larger wire less than 2 m (6.6 ft) in length for this connection. This terminal connects directly to the internal chassis ground of the SEL-487E.

Power Connections

The terminals labeled POWER on the rear panel (#Z29 and #Z30) must connect to a power source that matches the power supply characteristics that your SEL-487E specifies on the rear-panel serial number label. (See *Power Supply on page 1.24*, for complete power input specifications.) For the relay models that accept dc input, the serial number label specifies dc with the symbol shown in *Figure 2.26*.

Figure 2.29 Power Connection Area of the Rear Panel

NOTE: The combined voltages applied to the POWER and MONITOR terminals must not exceed 600 V (rms or dc).

The POWER terminals are isolated from chassis ground. Use 0.8 mm^2 (18 AWG) or larger size wire to connect to the POWER terminals. Connection to external power must comply with IEC 60947-1 and IEC 60947-3 and must be identified as the disconnect device for the equipment.

Place an external disconnect device, switch/fuse combination, or circuit breaker in the POWER leads for the SEL-487E; this device must interrupt both the hot (H/+) and neutral (N/−) power leads. The current rating for the power disconnect circuit breaker or fuse must be 20 A maximum. Be sure to locate this device within 3.0 m (9.8 ft) of the relay.

Operational power is internally fused by power supply fuse F1. *Table 2.7* lists the SEL-487E power supply fuse requirements. Be sure to use fuses that comply with IEC 127-2.

You can order the SEL-487E with one of three operational power input ranges listed in *Table 2.7*. Each of the three supply voltage ranges represents a power supply ordering option. As noted in *Table 2.7*, model numbers for the relay with these power supplies begin with 0487E5XXXX*n*, where *n* is 2, 4, or 6, to indicate low, middle, and high-voltage input power supplies, respectively. Note that each power supply range covers two widely used nominal input voltages. The SEL-487E power supply operates from 30 Hz to 120 Hz when ac power is used for the POWER input.

Table 2.7 Fuse Requirements for the Power Supply

Rated Voltage	Operational Voltage Range	Fuse F1	Fuse Description
24-48 Vdc	18-60 Vdc	T5.0AH250V	5x20 mm, time-lag, 5.0 A, high break capacity, 250 V
48–125 V or 110–120 Vac	38–140 Vdc or 85–140 Vac (30–120 Hz)	T3.15AH250V	5x20 mm, time-lag, 3.15 A, high break capacity, 250 V
125–250 V or 110–240 Vac	85–300 Vdc or 85–264 Vac (30–120 Hz)		

The SEL-487E accepts dc power input for all three power supply models. The 48–125 Vdc supply also accepts 110–120 Vac; the 125–250 Vdc supply also accepts 110–240 Vac. When connecting a dc power source, you must connect the source with the proper polarity, as indicated by the **+** (Terminal #**Z29**) and **–** (Terminal #**Z30**) symbols on the power terminals. When connecting to an ac power source, the **+** Terminal #**Z29** is hot (**H**), and the **–** Terminal #**Z30** is neutral (**N**).

Each model of the SEL-487E internal power supply exhibits low power consumption and a wide input voltage tolerance. For more information on the power supplies, see *Power Supply on page 1.24*.

Monitor Connections (DC Battery)

The SEL-487E monitors one dc battery system. For information on the battery monitoring function, see *Station DC Battery System Monitor Specifications on page 1.32*.

NOTE: The combined voltages applied to the **POWER** and **MONITOR** terminals must not exceed 600 V (rms or dc).

Connect the positive lead of Battery System 1 to Terminal #**Z25** and the negative lead of Battery System 1 to Terminal #**Z26**.

Secondary Circuit Connections

SV Subscriber and Publishers

The SEL-487E-5 SV Subscriber does not have secondary circuit connections but rather relies on the Ethernet ports connected to an Ethernet network to subscribe to published voltage and current signals by a merging unit.

⚠CAUTION
Relay misoperation can result from applying anything other than specified secondary voltages and currents. Before making any secondary circuit connections, check the nominal voltage and nominal current specified on the rear-panel nameplate.

⚠DANGER
Contact with instrument terminals can cause electrical shock that can result in injury or death.

The SEL-487E-5 SV Publisher has six sets of three-phase current inputs and two sets of three-phase voltage inputs. *Secondary Circuits on page 2.6* describes these inputs in detail. The alert symbol and the word **DANGER** on the rear panel indicate that you should use all safety precautions when connecting secondary circuits to these terminals.

To verify these connections, use SEL-487E metering (see *Examining Metering Quantities on page 3.34 in the SEL-400 Series Relays Instruction Manual*). You can also review metering data in an event report that results when you issue the **TRIGGER** command (see *Triggering Data Captures and Event Reports on page 9.7 in the SEL-400 Series Relays Instruction Manual*).

TiDL Relays

The SEL-487E-5 TiDL relay does not have secondary circuit connections but rather relies on direct, point-to-point fiber-optic cable connections with SEL-TMUs. For supported fiber-optic cable types and connectors, see *Specifications on page 1.24*.

Fixed Terminal Blocks

Connect the secondary circuits to the Y and Z terminal blocks on the relay rear panel of the SEL-487E-5 SV Publisher. Note the polarity dots above the odd-numbered terminals for CT inputs. Similar polarity dots are above the odd-numbered terminals for PT inputs.

Connectorized

For the Connectorized SEL-487E-5 SV Publisher, order the wiring harness kit, SEL-WA0487E. The wiring harness contains eight prewired connectors for the relay current and voltage inputs.

You can order the wiring harness with various wire sizes and lengths. Contact your local Technical Service Center or the SEL factory for ordering information.

Perform the following steps to install the wiring harness:

Step 1. Plug the CT shorting connectors into terminals #Y01 through #Y18 and #Z01 through #Z18 as appropriate.

Odd-numbered terminals are the polarity terminals.

Step 2. Secure the connector to the relay chassis with the two screws located on each end of the connector.

When you remove the CT shorting connector, pull straight away from the relay rear panel.

As you remove the connector, internal mechanisms within the connector separately short each power system current transformer.

You can install these connectors in only one orientation.

Step 3. Plug the PT voltage connectors into terminals #Y19 to #Y24 for the W inputs, and #Z19 to #Z24 for the VZ inputs, as appropriate.

Odd-numbered terminals are the polarity terminals. You can install these connectors in only one orientation.

SEL-487E-5 Nominal Secondary Current Configuration

NOTE: In the R400 firmware, the **CFG CTNOM** command defaults all relay settings. Starting in the R401 firmware, **CFG CTNOM** only defaults the global and group protection settings on a nominal secondary current configuration change.

When configured as a SV subscriber or TiDL device, the relay receives currents from a merging unit. You must set the nominal current inputs of the relay to either 1 A or 5 A. In the SEL-487E, not all terminals require the same nominal current configuration. There are two parameters to enter for the **CFG CTNOM** command in the SEL-487E-5: the first determines the nominal currents for Terminals S, T, and U, and the second determines the nominal currents for Terminals W, X, and Y. *Table 2.8* and *Table 2.9* show the **CFG CTNOM** command parameter options. For example, to set all current terminals to 5 A nominal, issue **CFG CTNOM 1 1**. Here, the first *1* corresponds to the 5,5,5 option for Terminals S, T, and U, respectively. The second *1* corresponds to the 5,5,5 option

for Terminals W, X, and Y, respectively. To set Terminals S, T, and U to 1 A nominal and W, X, and Y to 5 A nominal, issue **CFG CTNOM 4 1**. Here, the *4* corresponds to the 1,1,1 option for Terminals S, T, and U given in *Table 2.8*. The *1* corresponds to the 5,5,5 option for Terminals W, X, and Y given in *Table 2.9*. Other combinations are specified similarly.

The SV subscriber or TiDL relays, by default, assumes 5 A as the nominal current selection (see *Table 14.28 in the SEL-400 Series Relays Instruction Manual* for more information). SV publisher relays can be ordered with any CTNOM configuration shown in *Table 2.8* and *Table 2.9*.

Table 2.8 CFG CTNOM Options for Determining Nominal Current for Terminals S, T, and U

Option Number	Terminal S Nominal Current (A)	Terminal T Nominal Current (A)	Terminal U Nominal Current (A)
1	5	5	5
2	5	5	1
3	5	1	1
4	1	1	1

Table 2.9 CFG CTNOM Options for Determining Nominal Current for Terminals W, X, and Y

Option Number	Terminal W Nominal Current (A)	Terminal X Nominal Current (A)	Terminal Y (Y1,Y2,Y3) Nominal Current (A)
1	5	5	5,5,5
2	5	5	5,5,1
3	5	5	5,1,1
4	5	5	1,1,1
5	1	1	5,5,5
6	1	1	5,5,1
7	1	1	5,1,1
8	1	1	1,1,1

Control Circuit Connections

You can configure the SEL-487E with many combinations of control inputs and control outputs. See and *I/O Interface Boards on page 2.13* for information about I/O configurations. This section provides details about connecting these control inputs and outputs. Refer to *Figure 2.2* for representative rear-panel screw-terminal connector locations.

Control Inputs

Optoisolated

NOTE: The combined voltages applied to the INnnn and OUTnnn terminals must not exceed 600 V (rms or dc).

Optoisolated control inputs are not polarity-sensitive. These inputs respond to voltage of either polarity and can be used with ac control signals when properly configured.

Note that INT4 and INTD I/O interface board have two sets of nine inputs that share a common leg (see *Figure 2.13*).

Assigning

To assign the functions of the control inputs, see *Operating the Relay Inputs and Outputs on page 3.55 in the SEL-400 Series Relays Instruction Manual* for more details. You can also use ACSELERATOR QuickSet SEL-5030 Software to set and verify operation of the inputs.

Control Outputs

The SEL-487E has three types of outputs:

- Standard outputs
- Hybrid (high-current interrupting) outputs
- High-speed, high-current interrupting outputs

See *Control Outputs on page 2.33* for more information.

You can connect the standard outputs in either ac or dc circuits. Connect the high-speed, high-current interrupting and hybrid (high-current interrupting) outputs to dc circuits only. The screw-terminal connector legends alert you about this requirement by showing polarity marks on the hybrid contacts and HS marks on the high-speed, high-current interrupting contacts.

Alarm Output

The relay monitors internal processes and hardware in continual self-tests. Also see *Relay Self-Tests on page 10.19 in the SEL-400 Series Relays Instruction Manual*. If the relay senses an out-of-tolerance condition, the relay declares a Status Warning or a Status Failure. The relay signals a Status Warning by pulsing the HALARM Relay Word bit (hardware alarm) to a logical 1 for five seconds. For a Status Failure, the relay latches the HALARM Relay Word bit at logical 1.

To provide remote alarm status indication, connect the b contact of an output contact to your control system remote alarm input. *Figure 2.30* shows the configuration of the a and b contacts of control output OUT215, using INT2 as an example.

Figure 2.30 Control Output OUT215

Program OUT215 to respond to NOT HALARM by entering the following SELOGIC control equation with a communications terminal, with QuickSet.

OUT215 := **NOT HALARM**

When the relay is operating normally, the NOT HALARM signal is at logical 1 and the b contacts of control output OUT215 are open.

When a status warning condition occurs, the relay pulses the NOT HALARM signal to logical 0 and the b contacts of OUT215 close momentarily to indicate an alarm condition.

For a status failure, the relay disables all control outputs and the OUT215 b contacts close to trigger an alarm. Also, when relay power is off, the OUT215 b contacts close to generate a power-off alarm. See *Relay Self-Tests on page 10.19 in the SEL-400 Series Relays Instruction Manual* for information on relay self-tests.

The relay pulses the SALARM Relay Word bit for software programmed conditions; these conditions include settings changes, access level changes, alarming after three unsuccessful password entry attempts, and Ethernet firmware upgrade attempts.

The relay also pulses the BADPASS Relay Word bit after three unsuccessful password entry attempts.

You can add the software alarm SALARM to the alarm output by entering the following SELOGIC control equation.

OUT215 := **NOT (HALARM OR SALARM)**

Tripping and Closing Outputs

To assign the control outputs for tripping and closing, see *Setting Outputs for Tripping and Closing on page 3.61 in the SEL-400 Series Relays Instruction Manual*. In addition, you can use the **SET O** command (see *Output Settings on page 8.29* for more details). You can also use the front panel to set and verify operation of the outputs (see *Set/Show on page 4.26 in the SEL-400 Series Relays Instruction Manual*).

IRIG-B Input Connections

The SEL-487E accepts a demodulated IRIG-B signal through two types of rear-panel connectors. These IRIG-B inputs are the BNC connector labeled IRIG-B and Pin 4 (+) and Pin 6 (–) of the DB-9 rear-panel serial port labeled PORT 1. When you use the PORT 1 input, ensure that you connect Pins 4 and 6 with the proper polarity. See *Communications Ports Connections on page 2.35* for other DB-9 connector pinouts and additional details.

These inputs accept the dc shift time code generator output (demodulated) IRIG-B signal with positive edge on the time mark. For more information on IRIG-B and the SEL-487E, see *IRIG-B Inputs on page 2.11*.

The PORT 1 IRIG-B input connects to a 2.5-kΩ grounded resistor and goes through a single logic signal buffer. The PORT 1 IRIG-B is equipped with robust ESD and overvoltage protection but is not optically isolated. When you are using the PORT 1 input, ensure that you connect Pin 4 (+) and Pin 6 (–) with the proper polarity.

The IRIG network should be properly terminated with an external termination resistor (SEL 240-1802, BNC Tee, and SEL 240-1800, BNC terminator, 50 ohm) placed on the unit that is farthest from the source. This termination provides impedance matching of the cable for the best possible signal-to-noise ratio.

Where distance between the SEL-487E and the IRIG-B sending device exceeds the cable length recommended for conventional EIA-232 metallic conductor cables, you can use transceivers to provide isolation and to establish communication to remote locations.

Conventional fiber-optic and telephone modems do not support IRIG-B signal transmission. The SEL-2810 Fiber-Optic Transceiver/Modem includes a channel for the IRIG-B time code. These transceivers enable you to synchronize time precisely from IRIG-B time code generators (such as the SEL-2032 Communications Processor) over a fiber-optic communications link.

Communications Ports Connections

The SEL-487E has three rear-panel EIA-232 serial communications ports labeled **PORT 1**, **PORT 2**, and **PORT 3** and one front-panel port, **PORT F**. For information on serial communication, see *Establishing Communication on page 3.3*, *Serial Communication on page 15.2*, and *Serial Port Hardware Protocol on page 15.4 in the SEL-400 Series Relays Instruction Manual*.

In addition, the rear-panel features a **PORT 5** for an Ethernet card. For additional information about communications topologies and standard protocols that are available in the SEL-487E, see *Section 15: Communications Interfaces*, *Section 16: DNP3 Communication*, and *Section 17: IEC 61850 Communication in the SEL-400 Series Relays Instruction Manual* and *Section 10: Communications Interfaces* in this manual.

Serial Ports

The SEL-487E serial communications ports use EIA-232 standard signal levels in a D-subminiature 9-pin (DB-9) connector. To establish communication between the relay and a DTE device (a computer terminal, for example) with a DB-9 connector, use an SEL-C234A cable. Alternatively, you can use a SEL-C662 cable to connect to a USB port.

Figure 2.31 shows the configuration of SEL-C234A cable that you can use for basic ASCII and binary communication with the relay. A properly configured ASCII terminal, terminal emulation program, or SEL Grid Configurator along with the SEL-C234A cable provide communication with the relay in most cases.

Figure 2.31 SEL-487E to Computer—D-Subminiature 9-Pin Connector

Serial Cables

⚠CAUTION
Severe power and ground problems can occur on the communications ports of this equipment as a result of using non-SEL cables. Never use standard null-modem cables with this equipment.

Using an improper cable can cause numerous problems or failure to operate, so you must be sure to specify the proper cable for application of your SEL-487E. Several standard SEL communications cables are available for use with the relay.

The following list provides additional rules and practices you should follow for successful communication through use of EIA-232 serial communications devices and cables:

- Route communications cables well away from power and control circuits. Switching spikes and surges in power and control circuits can cause noise in the communications circuits if power and control circuits are not adequately separated from communications cables.
- Keep the length of the communications cables as short as possible to minimize communications circuit interference and also to minimize the magnitude of hazardous ground potential differences that can develop during abnormal power system conditions.
- Ensure that EIA-232 communications cable lengths never exceed 50 feet, and always use shielded cables for communications circuit lengths greater than 10 feet.
- Modems provide communication over long distances and give isolation from ground potential differences that are present between device locations (examples are the SEL-2800 series transceivers).
- Lower data speed communication is less susceptible to interference and will transmit greater distances over the same medium than higher data speeds. Use the lowest data speed that provides an adequate data transfer rate.

Ethernet Network Connections

⚠CAUTION
Use of controls or adjustments, or performance of procedures other than those specified herein, may result in hazardous radiation exposure.

⚠WARNING
Do not look into the fiber ports/connectors.

NOTE: The five-port Ethernet card uses SFP ports for its fiber-optic connections. SFP transceivers are not included with the card and must be ordered separately. See Table 15.7 in the SEL-400 Series Relays Instruction Manual or selinc.com/products/sfp/ for a list of compatible SFP transceivers.

The Ethernet card for the SEL-487E is available with either four or five Ethernet ports. These ports can work together to provide a primary and backup interface. Other operating modes are also available. The following list describes the Ethernet card port options.

- **10/100BASE-T.** 10 Mbps or 100 Mbps communication through the use of Cat 5 cable (category 5 twisted-pair) and an RJ45 connector (four-port Ethernet card only)
- **100BASE-FX.** 100 Mbps communication over multimode fiber-optic cable through the use of an LC connector
- **1000BASE-X.** 1 Gbps communication over fiber-optic cable through the use of an LC connector (**PORT 5A** and **PORT 5B** on the five-port Ethernet card only)

For SV applications, your process bus and stations bus port designations depend on certain settings and which Ethernet card is installed. For more information, see *Section 17: IEC 61850 Communication in the SEL-400 Series Relays Instruction Manual*.

Ethernet Card Rear-Panel Layout

⚠WARNING
Do not perform any procedures or adjustments that this instruction manual does not describe.

⚠WARNING
During installation, maintenance, or testing of the optical ports, use only test equipment qualified for Class 1 laser products.

⚠WARNING
Incorporated components, such as LEDs and transceivers are not user serviceable. Return units to SEL for repair or replacement.

Rear-panel layouts for the Ethernet card port configurations are shown in *Figure 2.32–Figure 2.35*.

Figure 2.32 Four 100BASE-FX Port Configuration

Figure 2.33 Four 10/100BASE-T Port Configuration

Figure 2.34 100BASE-FX and 10/100BASE-T Port Configuration

Figure 2.35 Two 100/1000BASE and Three 100BASE SFP Ports

Twisted-Pair Networks

NOTE: Use caution with UTP cables as these cables do not provide adequate immunity to interference in electrically noisy environments unless additional shielding measures are employed.

While Unshielded Twisted Pair (UTP) cables dominate office Ethernet networks, Shielded Twisted Pair (STP) cables are often used in industrial applications. The four-port Ethernet card is compatible with standard UTP cables for Ethernet networks as well as STP cables for Ethernet networks.

Typically UTP cables are installed in relatively low-noise environments including offices, homes, and schools. Where noise levels are high, you must either use STP cable or shield UTP by using grounded ferrous raceways such as a steel conduit.

Several types of STP bulk cable and patch cables are available for use in Ethernet networks. If noise in your environment is severe, you should consider using fiber-optic cables. SEL strongly advises against using twisted-pair cables for segments that leave or enter the control house.

If you use twisted-pair cables, you should use care to isolate these cables from sources of noise to the maximum extent possible. Do not install twisted-pair cables in trenches, raceways, or wireways with unshielded power, instrumentation, or control cables. Do not install twisted-pair cables in parallel with power, instrumentation, or control wiring within panels, rather make them perpendicular to the other wiring.

You must use a cable and connector rated as Category 5 (Cat 5) to operate the twisted-pair interface (10/100BASE-T) at 100 Mbps. Because lower categories are becoming rare and because you may upgrade a 10 Mbps network to 100 Mbps, SEL recommends using all Cat 5 or better components.

Some industrial Ethernet network devices use 9-pin connectors for STP cables. The Ethernet card RJ45 connectors are grounded so you can ground the shielded cable by using a standard, externally shielded jack with cables terminating at the Ethernet card.

Merging Unit AC/DC Connections

See *AC/DC Connection Diagrams in Section 2: Installation in the SEL-421-7, SEL-401*, or *SEL-TMU Instruction Manuals* for typical power system connections to the merging unit for a variety of schemes. See *Applications on page 1.10* for a variety of schemes and corresponding example SV networks or TiDL systems.

You can apply the SEL-487E-5 SV Publisher in many power system protection schemes. *Figure 2.36* shows an autotransformer with both HV and LV sides configured as breaker-and-a-half. This figure does not show any PT or dc connections. For more applications examples, *Figure 2.37* shows typical dc connections for the SEL-487E.

Figure 2.36 Autotransformer Application

① Figure 2.36.

Figure 2.37 Typical External DC Connections

Figure 2.38 shows the connections for an open-delta connected PT when wired to the V-PT inputs. Connect the A-Phase and C-Phase polarity wires from the PT secondary to the SEL-487E A-Phase (Y19) and C-Phase (Y23) terminals with polarity marks. Connect the common point from the PT to the SEL-487E

B-phase (Y21) terminal with polarity mark. Connect jumpers between terminals Y20, Y22, and Y24, and also connect this wire to Y21. *Figure 2.38* shows the ground connection on the common point; be sure to follow the wiring standards of your company when grounding the PTs. However, be sure to apply only one ground to the PTs.

Figure 2.38 Wiring Connections for Open-Delta Connected PTs

This page intentionally left blank

SECTION 3

Testing

This section provides guidelines for determining and establishing test routines for the SEL-487E-5 relay. Follow the standard practices of your company in choosing testing philosophies, methods, and tools. *Section 10: Testing, Troubleshooting, and Maintenance in the SEL-400 Series Relays Instruction Manual* provides additional information related to testing.

Topics presented in this section include the following:

- *Low-Level Test Interface on page 3.1*
- *Relay Test Connections on page 3.4*
- *SEL-487E-5 SV Publisher Connections on page 3.4*
- *Checking Relay Operation on page 3.5*
- *Commissioning Testing on page 3.31*
- *Technical Support on page 3.32*
- *SEL-487E Relay Commissioning Test Worksheet on page 3.33*

Low-Level Test Interface

You can test the SV publisher relay in two ways: by using secondary injection testing or by applying low-magnitude ac voltage signals to the low-level test interface. This section describes the low-level test interface between the calibrated input module and the separately calibrated processing module.

Access the test interface by removing the relay front panel. At the right side of the relay main board is the processing module. Inputs to the processing module are multipin connectors J14 and J24, the analog or low-level test interface connections. Receptacle J24 is on the right side of the main board, with J14 located 5 cm (2 in) behind J24; see *Figure 2.18* for a locating diagram.

⚠CAUTION
The relay contains devices sensitive to Electrostatic Discharge (ESD). Undetectable permanent damage can result if you do not use proper ESD procedures. Ground yourself, your work surface, and this equipment before removing any cover from this equipment. If your facility is not equipped to work with these components, contact SEL about returning this device and related SEL equipment for service.

NOTE: The relay front, I/O, and CAL boards are not hot-swappable. Remove all power from the relay before altering ribbon cable connections.

Figure 3.1 shows the J24 low-level interface connections and signal scaling factors. The J14 interface has the same scaling factors as the front interface, but with the channel allocation shown in *Figure 3.2*. Remove the ribbon cable between the two modules to access the outputs of the input module and the inputs to the processing module (relay main board). You can test the relay processing module using signals from a low-level test source, such as the SEL-RTS Low-Level Relay Test System. Never apply voltage signals greater than 6.6 V peak-to-peak to the low-level test interface.

Figure 3.1 Low-Level Test Interface J24

Figure 3.2 Low-Level Test Interface J14

Use signals from the Low-Level Relay Test System to test the relay processing module. These signals simulate power system conditions, taking into account PT ratio and CT ratio scaling. Use relay metering to determine whether the applied test voltages and currents produce correct relay operating quantities. The UUT Database entries for the SEL-487E in the SEL-5401 Relay Test System Software are shown in *Table 3.1–Table 3.4*.

Table 3.1 UUT Database Entries for SEL-5401 Relay Test System Software (Analog Input Board Y)—5 A Relay

Channel	Label	Scale Factor	Unit
1	IAS	75	A
2	IBS	75	A
3	ICS	75	A
4	IAT	75	A
5	IBT	75	A
6	ICT	75	A
7	IAU	75	A
8	IBU	75	A
9	ICU	75	A
10	VAV	150	V
11	VBV	150	V
12	VCV	150	V

Table 3.2 UUT Database Entries for SEL-5401 Relay Test System Software (Analog Input Board Z)—5 A Relay (Sheet 1 of 2)

Channel	Label	Scale Factor	Unit
1	IAW	75	A
2	IBW	75	A
3	ICW	75	A

Table 3.2 UUT Database Entries for SEL-5401 Relay Test System Software (Analog Input Board Z)—5 A Relay (Sheet 2 of 2)

Channel	Label	Scale Factor	Unit
4	IAX	75	A
5	IBX	75	A
6	ICX	75	A
7	IY1	75	A
8	IY2	75	A
9	IY3	75	A
10	VAZ	150	V
11	VBZ	150	V
12	VCZ	150	V

Table 3.3 UUT Database Entries for SEL-5401 Relay Test System Software (Analog Input Board Y)—1 A Relay

Channel	Label	Scale Factor	Unit
1	IAS	15	A
2	IBS	15	A
3	ICS	15	A
4	IAT	15	A
5	IBT	15	A
6	ICT	15	A
7	IAU	15	A
8	IBU	15	A
9	ICU	15	A
10	VAV	150	V
11	VBV	150	V
12	VCV	150	V

Table 3.4 UUT Database Entries for SEL-5401 Relay Test System Software (Analog Input Board Z)—1 A Relay

Channel	Label	Scale Factor	Unit
1	IAW	15	A
2	IBW	15	A
3	ICW	15	A
4	IAX	15	A
5	IBX	15	A
6	ICX	15	A
7	IY1	15	A
8	IY2	15	A
9	IY3	15	A
10	VAZ	150	V
11	VBZ	150	V
12	VCZ	150	V

Relay Test Connections

The SEL-487E is a flexible tool that you can use to implement many protection and control schemes. Although you can configure many topologies in the substation, connecting basic bench test sources helps you model and understand more complex schemes.

For each relay element test, you must apply ac voltage and current signals to the SEL-487E. The text and figures in this section describe the test source connections you need for relay protection element checks. You can use these connections to test protective elements and simulate all fault types.

If testing an SV subscriber or TiDL relay, create a simple connection between your merging unit and the SEL-487E-5, as shown in *Figure 3.3*. *Figure 3.3* shows the SV subscriber and merging unit connections and mapping for the examples provided in this section. See *IEC 61850-9-2 Sampled Values (SV) on page 19.23* in the *SEL-400 Series Relays Instruction Manual* for guidance on how to configure a Sampled Values (SV) network. See *Time-Domain Link (TiDL) on page 19.1* in the *SEL-400 Series Relays Instruction Manual* for guidance on configuring and commissioning an SEL Time-Domain Link (TiDL) system. Use the **CFG CTNOM** command (See *Secondary Circuit Connections on page 2.30*) to match the SEL-487E-5 CT nominal current with the nominal currents of the associate merging units.

NOTE: In the R400 firmware, the **CFG CTNOM** command defaults all relay settings. Starting in the R401 firmware, **CFG CTNOM** only defaults the global and group protection settings on a nominal secondary current configuration change.

① SV configurations require time synchronization; for more information, see IEC 61850-9-2 Sampled Values (SV) on page 19.23 in the SEL-400 Series Relays Instruction Manual.

② See the merging unit instruction manual for connection details.

Figure 3.3 Test Network Topology

SEL-487E-5 SV Publisher Connections

Figure 3.4 shows the test set and relay connections for three-phase current injection.

NOTE: The procedures specified in this section are for initial relay testing only. Follow your company policy for connecting the relay to the power system.

⚠WARNING
Before working on a CT circuit, first apply a short to the secondary winding of the CT.

Figure 3.4 Test Connections for Balanced Load With Three-Phase Current Sources

Figure 3.5 shows the test set and relay connections for three-phase voltage injection.

Figure 3.5 Voltage Test Connections

Checking Relay Operation

This section discusses tests of selected functions in the SEL-487E-5 SV Publisher when used as a continentally hardwired relay. The same procedures can be used when testing an SV subscriber or TiDL relay. These test are designed to show a method of testing a function in an easy way while at the same time familiarizing you with other functions such as programming logic functions, SER and the front panel. Each test starts with the default settings to avoid unexpected results from previous programming when testing other functions. This section provides tests for the following relay elements:

- Volts/Hertz Elements
- TOC (IDMT) Overcurrent Elements
- Restricted Earth Fault (REF) Elements
- Unrestrained Phase-Differential Element

- Restrained Phase-Differential Elements
- Negative-Sequence Differential Elements
- Negative-Sequence Directional Elements—Phase Elements

The paragraphs below describe when each type of test is performed, the goals of testing at that time, and the relay functions that you need to test at each point. This information is intended as a guideline for testing SEL relays.

Volts/Hertz

Although the V/Hz element offers definite-time and user-defined elements, this test shows how to test the user-defined function. For this test, you program a SELOGIC variable to assert LEDs on the front panel to indicate the status of the V/Hz element. You also program the SER to record the status of the V/Hz element, and then use these recorded values to calculate the element operating time(s).

Figure 3.6(a) shows a curve with four points defined, and *Figure 3.6(b)* shows an intermediate point Pt (107,?) between Point 24U101 and Point 24U102.

Figure 3.6 User-Defined V/Hz Curve 1

Because the relay linearly interpolates these data points, use *Equation 3.1* to calculate the operating time for a V/Hz value of 107 percent.

$$t = \left[\frac{t1 - t2}{P1 - P2}\right] \bullet Pt + \left[\frac{t1 \bullet P2 - t2 \bullet P1}{P2 - P1}\right]$$

Equation 3.1

where:

t1 = the operate time value of 24U101 (20)
P1 = the percentage V/Hz value of 24U101 (105)
t2 = the operate time value of 24U102 (10)
P2 = the percentage V/Hz value of 24U102 (110)
Pt = the percentage V/Hz value of 107 percent

$$t = \left[\frac{20 - 10}{105 - 110}\right] \bullet 107 + \left[\frac{20 \bullet 110 - 10 \bullet 105}{110 - 105}\right]$$

$$t = 16 \text{ seconds}$$

Equation 3.2

Table 3.5 Settings to Test the V/Hz Elements

Setting	Setting Category	Comments
EPTTERM = V	Group (SET)	Enable PT V; makes E24 settings available
E24 = Y	Group	Enable the V/Hz elements
24TC = 0	Group	Disable the definite-time V/Hz elements
24CCS = UI	Group	Select User-defined curve
24U1TC = 1	Group	Enable the logic for user-defined curves
24U1NP = 4	Group	Specify a curve with 4 points
24U101 = 105,20	Group	Coordinates for Point 1
24U102 = 110,10	Group	Coordinates for Point 2
24U103 = 115,5	Group	Coordinates for Point 3
24U104 = 120,2	Group	Coordinates for Point 4
PSV01 = 24RPU > 105	Protection Logic (SET L)	PSV01 asserts when V/Hz exceeds 105 percent
PSV02 = 24RPU > 107	Protection Logic	PSV02 asserts when V/Hz exceeds 107 percent
PB1_LED = PSV01	Front panel (SET F)	Pushbutton LED 1 reports the status of PSV01
PB1_COL = AG	Front panel	LED is amber when PSV01 asserts, and green when PSV01 deasserts
PB2_LED = PSV02	Front panel	Pushbutton LED 2 reports the status of PSV02
PB2_COL = AG	Front panel	LED is amber when PSV02 asserts, and green when PSV02 deasserts
PSV01,“V/Hz picked up”	Report (SER) (SET R)	Reports and time-stamps when PSV01 asserts
24U1T,“V/Hz timed out”	Report (SER)	Reports and time-stamps when V/Hz elements times out

Figure 3.7 shows the group settings (Group 1) for this test.

```
=>>SET <Enter>
Group 1

Relay Configuration

Enable Current Terminals (OFF or combo of S,T,U,W,X)
ECTTERM := "S,T"  ? <Enter>
Enable Voltage Terminals (OFF or combo of V,Z)       EPTTERM := OFF    ?V <Enter>
Enable Diff Elem. Prot. Terms (OFF or combo of S,T)
E87     := OFF    ? <Enter>
Enable Restricted Earth Fault Element (N,1-3)        EREF    := N      ? <Enter>
Enable Def. Time Dir. O/C Ele. (OFF or combo of S,T)
E50     := OFF    ? <Enter>
Enable Inverse Time Overcurrent Elements (N, 1-10)   E51     := N      ? <Enter>
Enable Current Unb. Elements (OFF or combo of S,T)   E46     := OFF    ? <Enter>
Enable Over Voltage Elements (N,1-5)                 E59     := N      ? <Enter>
Enable Under Voltage Elements (N,1-5)                E27     := N      ? <Enter>
Enable Frequency Elements (N,1-6)                    E81     := N      ? <Enter>
Enable Volts per Hertz Element (Y,N)                 E24     := N      ?Y <Enter>
Enable Synch. Check (OFF or combo of S,T)            E25     := OFF    ? <Enter>
Enable Bkr Fail. Prot. (OFF or combo of S,T)         EBFL    := OFF    ? <Enter>
Enable Power Calc. Term (OFF or combo of S,T)        EPCAL   := OFF    ? <Enter>
Enable Demand Metering (N, 1-10)                     EDEM    := N      ? <Enter>

Current Transformer Data

Current Trans. Ratio Terminal S (1-50000)            CTRS    := 100    ?> <Enter>

Potential Transformer Data

Potential Trans. Ratio Terminal V (1.0-10000.0)      PTRV   := 2000.0   ?> <Enter>

Current Transformer Data

Current Trans. Ratio Terminal S (1-50000)            CTRS    := 100    ?> <Enter>

Potential Transformer Data

Potential Trans. Ratio Terminal V (1.0-10000.0)      PTRV   := 2000.0   ?> <Enter>
```

Figure 3.7 Group Settings for the V/Hz Test

```
Voltage Reference Terminal Selection

Voltage Reference For Terminal S (OFF,V)            VREFS   := OFF    ?> <Enter>

Volts per Hertz Element

Level 1 Volts/Hertz P/U (100-200%)                  24D1P   := 110    ? <Enter>
Level 1 Time Delay (0.04 - 400 sec)                 24D1D   := 10.00  ? <Enter>
Volts/Hertz Torque control (SELOGIC Eqn)
24TC := 1
?  0 <Enter>
Level 2 composite Curve (OFF,DD,U1,U2)              24CCS   := OFF    ?U1 <Enter>

Volts per Hertz Level 2, User Defined Curve 1

User Defined Curve 1 Torque Control (SELOGIC Eqn)
24U1TC := 1 <Enter>
?
Number of Point on User 1 Curve (3-20)              24U1NP  := 3      ?4 <Enter>
User Def. Curve 1, Point 1 (100 - 200%, 0.04 - 400 sec)
24U101 := 200, 400.00
?  105,20 <Enter>
User Def. Curve 1, Point 2 (100 - 200%, 0.04 - 400 sec)
24U102 := 200, 400.00
?  110,10 <Enter>
User Def. Curve 1, Point 3 (100 - 200%, 0.04 - 400 sec)
24U103 := 200, 400.00
?  115,5 <Enter>
User Def. Curve 1, Point 4 (100 - 200%, 0.04 - 400 sec)
24U104 := 200, 400.00
?  120,2 <Enter>
User Def. Curve 1 Reset Time (0.01 - 400 sec)       24U1CR  := 0.01   ? <Enter>

Trip Logic

Trip Transformer (SELOGIC Eqn)
TRXFMR := 87R OR REFF1
?  END <Enter>

Save settings (Y,N)  ?Y <Enter>
Saving Settings, Please Wait...........
Settings Saved

=>>
```

Figure 3.7 Group Settings for the V/Hz Test (Continued)

Figure 3.8 shows the Protection Logic setting for the test. Protection SELOGIC variable PSV01 asserts when the analog output (24RPU, see *Volts/Hertz Settings on page 5.122*) exceeds 105 percent, and PSV02 asserts when 24RPU exceeds 107 percent. Protection math variables PMV01 and PMV02 are included for easy monitoring of the values 24RPU and VPMAXVF.

```
=>>SET L TE <Enter>
Protection 1

1: # BREAKER S OPEN AND CLOSE CMD
?  >
21:
?  PSV01:=24RPU > 105 <Enter>
22:
?  PSV02:=24RPU > 107 <Enter>
23:
?  PMV01:=24RPU <Enter>
24:
?  PMV02:=VPMAXVF <Enter>
25:
?  END <Enter>

Save settings (Y,N)  ?Y <Enter>
Saving Settings, Please Wait...........
Settings Saved

=>>
```

Figure 3.8 Logic Settings for the V/Hz Test

Program the front-panel pushbutton LEDs to indicate the status of PSV01 and PSV02. Set the LED to show amber when PSV01 (PB1_LED) and PSV02 (PB2_LED) are asserted, and to show green when PSV01 and PSV02 are deasserted. *Figure 3.9* shows the front-panel LED programming.

```
=>>SET F TE <Enter>
Front Panel

Front Panel Settings

Front Panel Display Time-Out (OFF,1-60 mins)         FP_TO   := 15     ?
Enable LED Asserted Color (R,G)                      EN_LEDC := G      ?
Trip LED Asserted Color (R,G)                        TR_LEDC := R      ?
Pushbutton LED 1 (SELogic Equation)
PB1_LED := NA
?  PSV01 <Enter>
PB1_LED Assert & Deassert Color (Enter 2: R,G,A,O)   PB1_COL := AO     ?AG <Enter>
Pushbutton LED 2 (SELogic Equation)
PB2_LED := NA
?  PSV02 <Enter>
PB2_LED Assert & Deassert Color (Enter 2: R,G,A,O)   PB2_COL := AO     ?AG <Enter>
Pushbutton LED 3 (SELogic Equation)
PB3_LED := NA
?  END <Enter>

Save settings (Y,N)  ?Y <Enter>
Saving Settings, Please Wait...........
Settings Saved

=>>
```

Figure 3.9 Front-Panel Settings for the V/Hz Test

Use the Sequential Event Recorder (SER) to record the exact time when PSV01 and PSV02 assert, and when the output from the V/Hz element (24U1T) asserts. Calculate the operating time of the V/Hz element by finding the difference between these two times. *Figure 3.10* shows the SER programming.

```
=>>SET R TE <Enter>
Report

SER Chatter Criteria

Automatic Removal of Chattering SER Points (Y,N)    ESERDEL := N     ? <Enter>

SER Points
(Relay Word Bit, Reporting Name, Set State Name, Clear State Name, HMI Alarm)

1:
? PSV01,"V/Hz picked up 105" <Enter>
2:
? PSV02,"V/Hz picked up 107" <Enter>
3:
?  24U1T,"V/Hz timed out" <Enter>
4:
? END <Enter>

Save settings (Y,N)  ?Y <Enter>
Saving Settings, Please Wait...........
Settings Saved

=>>
```

Figure 3.10 SER Settings for the V/Hz Test

This concludes the settings and programming. At this point, pushbutton PB1_LED and PB2_LED must both show green. Refer to *Figure 5.124* to see the logic that determines 24RPU. Notice that it compares the maximum phase-to-phase voltage with the nominal phase-to-phase voltage. To monitor 24RPU and VPMAXVF, perform a **MET PMV** command while running the test conditions below.

Step 1. Connect an injection set as shown in *Figure 3.5* to the PT V terminals.

Step 2. Calculate the line-to-line voltage for the nominal line-to-neutral voltage of 63.5 V ($63.5 \cdot (\sqrt{3}) = 110$). Next, calculate 105% and 107% of 110 V to determine the magnitude of VPMAXVF that will cause PSV01 and PSV02 to assert. Start off by injecting the voltage values shown in the Initial Voltage (105%) column in *Table 3.6*.

Step 3. Slowly increase the A-Phase voltage until PB1_LED changes from green to amber. Record this voltage value in *Table 3.6*. Perform a **MET PMV** command and record the values of PMV01 and PMV02 in the table.

Step 4. Turn off the injection set.

Step 5. Clear the SER by typing **SER C <Enter>**. Enter **Y <Enter>** at the prompt: `Are you sure (Y/N)?`

Table 3.6 Voltage Values

Initial Voltage (105%)	Recorded Voltage	Initial Voltage (107%)	Recorded Voltage
VA = 68 ∠0°	VA = PMV01 = % PMV02 = V	VA = 71∠0°	VA = PMV01 = % PMV02 = V
VB = 63.5∠–120°	VB = 63.5∠–120°	VB = 63.5∠–120°	VB = 63.5∠–120°
VC = 63.5∠120°	VC = 63.5∠120°	VC = 63.5∠120°	VC = 63.5∠120°

Step 6. Inject the relay with the recorded voltages for at least 22 seconds (verify that PB1_LED is amber, and PB2_LED is green).

Step 7. Stop the injection and turn the test set off. Type **SER <Enter>** to see the element assert and operate times, as shown in *Figure 3.11*.

```
=>>SER <Enter>

Relay 1                                    Date: 06/03/2015  Time: 04:40:38.976
Station A                                  Serial Number: 1151000001

FID=SEL-487E-3-R310-V0-Z104101-D20140515

#      DATE        TIME           ELEMENT              STATE
2    06/03/2015  04:40:36.8201   V/Hz picked up 105   Asserted
1    06/03/2015  04:40:56.7316   V/Hz timed out       Asserted

=>>
```

Figure 3.11 Element Assert and Operate Times (105%)

Because we are testing point (105,20), we expect the V/Hz element to assert after 20 seconds. Calculate the trip time as follows:

Trip time = 56.7316 – 36.8201 = 19.91 seconds.

This result is within the tolerance range of the V/Hz element.

Step 8. With the test set connected, repeat *Step 1* through *Step 5*, noting the voltage when PB2_LED changes from green to amber in *Step 3* (PB1_LED also changes from green to amber).

Step 9. Inject the relay with the recorded voltages for at least 18 seconds (verify that both PB1_LED and PB2_LED are amber).

Step 10. Stop the injection and turn the test set off. Type **SER <Enter>** to see the element assert and operate times, as shown in *Figure 3.12*.

```
=>>SER <Enter>

Relay 1                                    Date: 06/03/2015  Time: 12:01:00.135
Station A                                  Serial Number: 1151000001

FID=SEL-487E-3-R310-V0-Z104101-D20140515

#      DATE        TIME           ELEMENT              STATE
3    06/03/2015  12:00:42.3249   V/Hz picked up 105   Asserted
2    06/03/2015  12:00:42.3334   V/Hz picked up 107   Asserted
1    06/03/2015  12:00:58.2694   V/Hz timed out       Asserted

=>>
```

Figure 3.12 Element Assert and Operate Times (107%)

Because we are testing point (107,16), we expect the V/Hz element to assert after 16 seconds. Calculate the trip time as follows:

Trip time = 12:00:58.2694 – 12:00:42.3334 = 15.936 seconds

This result is within the tolerance range of the V/Hz element. This concludes the V/Hz tests for this example; use similar tests to test more points on the curve.

Adaptive Inverse-Time Overcurrent

This example tests the Element 01 set to the C1 curve (see *Figure 3.13*), using the A-Phase current from Terminal S. Use the same procedure to test all inverse-time overcurrent elements for each terminal.

Figure 3.13 C1 Curve

For this test, you use remote bits to dynamically change the relay time dial setting. You also program the SER to record the status of the 51 element, and then use these recorded values to calculate the element operating time.

Be sure to enable each overcurrent element in two places: the ECTTERM and E51 settings. Enable the terminal by including the particular terminal in the ECTTERM setting, then select the number of 51 elements with the E51 setting.

Because the inverse-time overcurrent elements are adaptive, test three time-dial values, select arbitrary values of TD = 0.3 and TD = 0.6, and a third value of TD = 1.4. Setting TD = 1.4 exceeds the limit of the time dial range, causing the relay to clamp the time dial setting to the upper limit of the range. Use two remote bits (RB01 and RB02) to change the time setting from the default value of 0.3 to 0.6 and to 1.4.

Step 1. Use *Equation 3.3* to determine the expected operate time of the overcurrent element. *Table 3.7* shows the pickup and time dial settings for the three tests.

$$Tp = TD \bullet \left[\frac{0.14}{M^{0.02} - 1} \right]$$

Equation 3.3

In all cases, inject a current of 10 A into the relay. With a pickup setting of 1.5 and current of 10 A, M = 6.667 (M = IMAXSF/51P01).

Table 3.7 Time Overcurrent Element Settings

Setting	Setting Category	Comment
E51 = 1	Group	Enable one 51 element
51P01 = 1.5	Group	Pickup (plug) setting
51TD01 = 0.3 + (RB01 • 0.3) + (RB02 • 0.8)	Group	Time-dial (multiplier) setting, resulting in trip times of 1.086, 2.172, and 3.620 seconds, respectively

Step 2. Use the Group setting **SET** command to enable one 51 element, and apply the pickup and time dial settings as shown in *Table 3.7*. Save the settings, as shown in *Figure 3.14*.

```
=>>SET <Enter>
Group 1

Relay Configuration

Enable Current Terminals (OFF or combo of S,T,U,W,X)
ECTTERM := "S,T"  ? <Enter>
Enable Voltage Terminals (OFF or combo of V,Z)       EPTTERM := OFF    ? <Enter>
Enable Diff Elem. Prot. Terms (OFF or combo of S,T)
E87     := OFF    ?
Enable Restricted Earth Fault Element (N,1-3)        EREF    := N      ? <Enter>
Enable Def. Time Dir. O/C Ele. (OFF or combo of S,T)
E50     := OFF    ?
Enable Inverse Time Overcurrent Elements (N, 1-10)   E51     := N      ?1 <Enter>
Enable Current Unb. Elements (OFF or combo of S,T)   E46     := OFF    ? <Enter>
Enable Bkr Fail. Prot. (OFF or combo of S,T)         EBFL    := OFF    ? <Enter>
Enable Demand Metering (N, 1-10)                     EDEM    := N      ? <Enter>

Current Transformer Data

Current Trans. Ratio Terminal S (1-50000)            CTRS    := 100    ?> <Enter>

Inverse Time Overcurrent Element 01

Inv.Time O/C 1 Operate Quantity                      51001   := IMAXSF ? <Enter>
Inv.Time O/C 1 Pickup Value (SEL Math Eqn.)
51P01 := 1.000000
?  1.5 <Enter>
Inv.Time O/C 1 Curve Selection (U1-U5, C1-C5)        51C01   := U1     ?C1 <Enter>
Inv.Time O/C 1 Time Dial (SEL Math Eqn)
51TD01 := 1.000000
?  0.3+(RB01*0.3)+(RB02*0.8) <Enter>
Inv.Time O/C 1 EM Reset (Y, N)                       51RS01  := N      ?
Inv.Time O/C 1 Torque control (SELogic Eqn)
51TC01 := 1
? <Enter>

Trip Logic

Trip Transformer (SELogic Eqn)
TRXFMR := 87R OR REFF1
?  END <Enter>
Group 1

.
.
.

CFD     := 4.00
Save settings (Y,N)  ?Y <Enter>
Saving Settings, Please Wait...........
Settings Saved

=>>
```

Figure 3.14 Group Settings for the 51 Tests

Step 3. Set the SER to check the operate time of the element, as shown in *Figure 3.15*. When using the TERSE option (**SET TE**), there is no read back, so that the setting change is much faster.

```
=>>SET R TE <Enter>
Report

SER Chatter Criteria

Automatic Removal of Chattering SER Points (Y,N)     ESERDEL := N      ? <Enter>

SER Points
(Relay Word Bit, Reporting Name, Set State Name, Clear State Name, HMI Alarm)

1:
?  51SO1 "51 Asserted"<Enter>
2:
?  51TO1 "51 Timed out"<Enter>
3:
?  END <Enter>

Save settings (Y,N)  ?Y <Enter>
Saving Settings, Please Wait...........
Settings Saved

=>>
```

Figure 3.15 Setting the SER

Step 4. Use the **SER C** command to clear the SER before starting the test, as shown in *Figure 3.16*.

```
=>>SER C <Enter>

Clear the sequential events recorder for this port.
Are you sure (Y/N)?Y <Enter>

SER records for this port are cleared
```

Figure 3.16 Clearing the SER

Step 5. Inject 10 A into the relay for at least two seconds, then stop the injection and turn the injection set off. Issue the **SER** command to see the results of the test, as shown in *Figure 3.17*. Use the bold SER entries to calculate the operating time: 39.4516 – 38.3598 = 1.092 seconds. This value compares favorably with the expected value of 1.086 seconds.

```
=>>SER <Enter>

Relay 1                                    Date: 01/07/2015  Time: 04:52:44.740
Station A                                  Serial Number: 1151000001

FID=SEL-487E-3-R310-V0-Z104101-D20140515

#      DATE        TIME           ELEMENT              STATE
4    01/07/2015  04:52:38.3598   51 ASSERTED          Asserted
3    01/07/2015  04:52:39.4516   51 TIMED OUT         Asserted
2    01/07/2015  04:52:41.7520   51 TIMED OUT         Deasserted
1    01/07/2015  04:52:41.7520   51 ASSERTED          Deasserted

=>>
```

Figure 3.17 SER Results

Step 6. To dynamically change the time dial (time multiplier) setting from 0.3 to 0.6, assert RB01. *Figure 3.18* shows how to assert RB01 by means of the **CON** (control) command.

```
=>>CON 01 S <Enter>
Remote Bit Operated
```

Figure 3.18 RB01 Asserted

Step 7. Inject 10 A into the relay for at least three seconds, then stop the injection and turn the injection set off. Issue the **SER** command to see the results of the test, as shown in *Figure 3.19*. Use the bold SER entries to calculate the operating time: 35.0417 – 32.8581 = 2.184 seconds. This value compares favorably with the expected value of 2.172 seconds.

```
=>>SER <Enter>

Relay 1                                    Date: 01/07/2015 Time: 04:56:30.007
Station A                                  Serial Number: 1151000001

FID=SEL-487E-3-R310-V0-Z104101-D20140515

#      DATE        TIME           ELEMENT              STATE
8    01/07/2015  04:52:38.3598   51 ASSERTED          Asserted
7    01/07/2015  04:52:39.4516   51 TIMED OUT         Asserted
6    01/07/2015  04:52:41.7520   51 TIMED OUT         Deasserted
5    01/07/2015  04:52:41.7520   51 ASSERTED          Deasserted
4    01/07/2015  04:55:32.8581   51 ASSERTED          Asserted
3    01/07/2015  04:55:35.0417   51 TIMED OUT         Asserted
2    01/07/2015  04:55:37.3755   51 TIMED OUT         Deasserted
1    01/07/2015  04:55:37.3755   51 ASSERTED          Deasserted

=>>
```

Figure 3.19 Test 2 SER Results

Step 8. To dynamically change the time-dial (time multiplier) settings from 0.6 to 1.4, assert RB02, as shown in *Figure 3.20*.

```
=>>CON 02 S <Enter>
Remote Bit Operated
```

Figure 3.20 RB02 Asserted

Step 9. Inject 10 A into the relay for at least five seconds, then stop the injection and turn the injection set off. Issue the **SER** command to see the results of the test, as shown in *Figure 3.21*. Use the bold SER entries to calculate the operating time: 6.8780 – 3.2357 = 3.642 seconds. This value compares favorably with the expected value of 3.62 seconds.

```
=>>SER <Enter>

Relay 1                                    Date: 01/07/2015 Time: 04:58:20.106
Station A                                  Serial Number: 1151000001

FID=SEL-487E-3-R310-V0-Z104101-D20140515

#      DATE        TIME           ELEMENT              STATE
12   01/07/2015  04:52:38.3598   51 ASSERTED          Asserted
11   01/07/2015  04:52:39.4516   51 TIMED OUT         Asserted
10   01/07/2015  04:52:41.7520   51 TIMED OUT         Deasserted
9    01/07/2015  04:52:41.7520   51 ASSERTED          Deasserted
8    01/07/2015  04:55:32.8581   51 ASSERTED          Asserted
7    01/07/2015  04:55:35.0417   51 TIMED OUT         Asserted
6    01/07/2015  04:55:37.3755   51 TIMED OUT         Deasserted
5    01/07/2015  04:55:37.3755   51 ASSERTED          Deasserted
4    01/07/2015  04:58:03.2357   51 ASSERTED          Asserted
3    01/07/2015  04:58:06.8780   51 TIMED OUT         Asserted
2    01/07/2015  04:58:09.1242   51 TIMED OUT         Deasserted
1    01/07/2015  04:58:09.1242   51 ASSERTED          Deasserted

=>>
```

Figure 3.21 Test 3 SER Results

Restricted Earth Fault (REF) Test

The REF is a directional element, comparing the angle between the neutral current and the residual current from one or more windings. *Figure 3.22(a)* shows the element characteristic, an internal fault being the shaded area.

Figure 3.22 REF Characteristic and Test Setup

Figure 3.22(b) shows the test setup for the REF test. For this example, we test one REF element, configured between the W-Terminal currents and the IY1 neutral current.

Step 1. Apply the following settings.

SET

ECTTERM = W

EREF = 1

REFRF1 = W

REF50G1 = 0.05

TCREF1 = 1

CTRW = 100

CTRY1 = 50

CTCONW = Y

Step 2. Wire the relay as shown in *Figure 3.22*, i.e., connect the three elements of the W-Terminal in series, and connect to a current source. Connect the Y-Terminal to a separate phase of the current source (or a different current source).

Inject the following signals:

I1 = 1.0∠0°

I2 = 1.5∠180°

Because the two currents are opposite in phase, the element should not operate. To verify this, enter the **TAR REFF1** command. Both Relay Word bits REFF1 and REFR1 are in this row. With the currents applied as above, the element should calculate a reverse fault, asserting Relay Word bit REFR1.

Change the angle of I2 to any value within ±75 degrees of I1 (I2 = 1.5∠60°, for example) to move the fault to within the internal fault area, causing the REF element to operate. To verify this, again enter the **TAR REFF1** command. This time, Relay Word bit REFF1 (forward fault) must be asserted and Relay Word bit REFR1 deasserted.

U87P Unrestrained Phase-Differential Element

In this test, you test the filtered unrestrained differential element operation by injecting current in Terminal S. *Table 3.8* shows the setting for this test.

Table 3.8 Unrestrained Phase-Differential Element Settings

Setting	Setting Category	Comment
E87U = F	Group	Enable unrestrained differential element
E87 = S, T	Group	Enable Terminals S and T in the differential calculations
CTRS = 100	Group	Terminal S CT ratio (default setting)
CTRT = 100	Group	Terminal T CT ratio (default setting)
E87TS = 1	Group	Include Terminal S in the Differential Element (default setting)
E87TT = 1	Group	Include Terminal T in the Differential Element (default setting)
MVA = 100	Group	Transformer MVA rating
VTERMS = 275	Group	Terminal S rated voltage (default setting)
VTERMT = 132	Group	Terminal T rated voltage
U87P = 4	Group	Unrestrained Element Current pickup

Figure 3.23 shows the setting change in the Group category, using the **TE**(ERSE) option.

```
=>>SET U87P TE <Enter>
Group 1

Differential Element Configuration and Data

Unrestrained Element Current PU (1.00-20)          U87P    := 8.00   ?4 <Enter>
Incr. Operate Current Threshold p.u. (0.10-10)     DIOPR   := 1.20   ?END <Enter>

Save settings (Y,N)  ?Y <Enter>
Saving Settings, Please Wait...........
Settings Saved

=>>
```

Figure 3.23 Group Settings

Use the **TAR 87U 999** (the 999 repeats the display 999 times on the screen) command to view the line in the relay that shows the status of the elements, as shown below.

```
=>>TAR 87U 999 <Enter>

87UA    87UB    87UC    87U     87T_SF  87T_SFA 87T_SFB 87T_SFC
0       0       0       0       0       0       0       0
0       0       0       0       0       0       0       0
0       0       0       0       0       0       0       0
0       0       0       0       0       0       0       0
```

Step 1. Calculate the required current to pick up the unrestrained differential element (setting 4 per unit).

$$IAS = 4 \bullet TAPS$$

Equation 3.4

$$IAS = 4 \bullet 2.1\ pu$$

Equation 3.5

$$IAS = 8.4\ A$$

Equation 3.6

⚠DANGER
The continuous rating of the current inputs is 3 • I_{NOM}. For this example, you may want to choose low values of U87P and TAPn to limit the required test current to a safe value.

Step 2. Start by injecting 7 A three-phase current, and enter **TAR 87U 999**. Slowly increase the current until the unrestrained differential elements assert, as shown below.

87UA	87UB	87UC	87U	87T_SF	87T_SFA	87T_SFB	87T_SFC
0	0	0	0	0	0	0	0
0	0	0	0	0	0	0	0
0	0	0	0	0	0	0	0
0	0	0	0	0	0	0	0

87RA, 87RB, and 87RC Restrained Differential Elements

This section provides tests to show the operation of the restraint differential element under the following system conditions (for ease of testing consider only two terminals [Terminal S and Terminal T]):

- Internal fault
- External fault with heavy CT saturation
- Evolving fault, causing the relay to trip on Slope 2

In general, the relay uses *Equation 3.7* and *Equation 3.8* to calculate the operational operating current (IOP_{OP}) and the restraint current (IRT).

$$IOP_{OP} = \left|\overrightarrow{IAS} + \overrightarrow{IAT}\right|$$

Equation 3.7

$$IRT = |IAS| + |IAT|$$

Equation 3.8

Equation 3.7 calculates the absolute value of the vector sum of $\overrightarrow{IAS}$ and $\overrightarrow{IAT}$, and *Equation 3.8* calculates the sum of the absolute values of $\overrightarrow{IAS}$ and $\overrightarrow{IAT}$.

Equation 3.9 is the third equation that the differential element uses to make a trip/no trip decision.

$$IOP(IRT) = \frac{SLP}{100} \bullet IRT$$

Equation 3.9

Equation 3.9 provides the reference value (from the slope setting) for various restraint values, as shown in *Figure 3.24*.

Figure 3.24 Differential Element Comparator

Each processing interval, the relay calculates IRT (*Equation 3.8*), uses this calculated IRT value to calculate IOP(IRT) (*Equation 3.9*), and compares this calculated IOP(IRT) value with the result of *Equation 3.7* (IOP_{OP}).

Figure 3.25 shows the characteristic of the differential element, together with IOP_{OP}. In *Figure 3.25*, the shaded area (area below the SLP line) is the non-operating or restraint area, and the area above the SLP line is the operating or tripping area.

Figure 3.25 Differential Element Characteristic

To simplify *Equation 3.7*, consider a fixed angular relationship of 180 degrees between $\overline{IAS}$ and $\overline{IAT}$, i.e., $\overline{IAS} = IAS\angle 0°$ and $\overline{IAT} = IAT\angle 180°$. With this relationship, both IAS and IAT are real numbers, and *Equation 3.7* becomes:

$$IOP_{OP} = IAS - IAT$$

Equation 3.10

or

$$IAS = IOP_{OP} + IAT$$

Equation 3.11

Also, from *Equation 3.8*,

$$IAS = IRT - IAT$$

Equation 3.12

Combine *Equation 3.11* and *Equation 3.12* to solve for IAT as follows:

$$IAT = \frac{IRT - IOP_{OP}}{2}$$

Equation 3.13

With this value, use *Equation 3.12* to calculate IAS as follows:

$$IAS = \frac{IRT + IOP_{OP}}{2}$$

Equation 3.14

Testing

Connect a three-phase test set to the SEL-487E as shown in *Figure 3.4*. Change the following settings, as shown in *Table 3.9* and *Figure 3.26*.

Table 3.9 Differential Element Settings

Setting	Setting Category	Comment
VTERMT = 132	Group	Rated line-to-line voltage for Terminal S
E87 = S,T	Group	Include Terminals S and T for the differential element
E87TS = 1	Group	Terminal S is permanently included in the differential element
E87TT = 1	Group	Terminal T is permanently included in the differential element
O87P = 0.3	Group	Restraint differential element pickup
SLP1 = 30	Group	Set Slope 1 to 30 percent
SLP2 = 60	Group	Set Slope 2 to 60 percent
MVA = 100	Group	Transformer maximum capacity

```
=>>SET TE <Enter>
Group 1

Relay Configuration

Enable Current Terminals (OFF or combo of S,T,U,W,X)
ECTTERM := "S,T"  ? <Enter>
Enable Voltage Terminals (OFF or combo of V,Z)       EPTTERM := OFF    ? <Enter>
Enable Diff Elem. Prot. Terms (OFF or combo of S,T)
E87     := OFF    ?S, T <Enter>
Enable Restricted Earth Fault Element (N,1-3)        EREF    := N      ? <Enter>
Enable Def. Time Dir. O/C Ele. (OFF or combo of S,T)
E50     := OFF    ? <Enter>
Enable Inverse Time Overcurrent Elements (N, 1-10)   E51     := N      ? <Enter>
Enable Current Unb. Elements (OFF or combo of S,T)   E46     := OFF    ? <Enter>
Enable Bkr Fail. Prot. (OFF or combo of S,T)         EBFL    := OFF    ? <Enter>
Enable Demand Metering (N, 1-10)                     EDEM    := N      ? <Enter>

Current Transformer Data

Current Trans. Ratio Terminal S (1-50000)            CTRS    := 100    ? <Enter>
Current Trans. Connection Terminal S (Y,D)           CTCONS  := Y      ? <Enter>
Current Trans. Ratio Terminal T (1-50000)            CTRT    := 100    ? <Enter>
Current Trans. Connection Terminal T (Y,D)           CTCONT  := Y      ? <Enter>
```

Figure 3.26 Group Settings for the Differential Test

```
Differential Element Configuration and Data

Term S included in 87 Element (SELOGIC Eqn)
E87TS := 0
?  1 <Enter>
Term T included in 87 Element (SELOGIC Eqn)
E87TT := 0
?  1 <Enter>
Internal CT Conn. Compensation Enabled (Y,N)         ICOM    := Y      ? <Enter>
Terminal S CT Conn. Compensation (0 - 12)            TSCTC   := 12     ? <Enter>
Terminal T CT Conn. Compensation (0 - 12)            TTCTC   := 12     ? <Enter>
Transformer Max. Power Capacity (OFF, 1 - 5000MVA)   MVA     := OFF    ?100 <Enter>
Terminal S Line-to-Line Voltage  (1.00-1000 kV)      VTERMS  := 275.00 ? <Enter>
Terminal T Line-to-Line Voltage  (1.00-1000 kV)      VTERMT  := 275.00 ?132 <Enter>
Terminal S Current Tap  (0.50-175 A,sec)             TAPS    := 2.10   ? <Enter>
Terminal T Current Tap  (0.50-175 A,sec)             TAPT    := 4.37   ? <Enter>
Differential Element Oper. Current PU (0.10-4)       O87P    := 1.00   ?0.3 <Enter>
Slope 1 Percentage (5.00-100%)                       SLP1    := 35.00  ?30 <Enter>
Slope 2 Percentage (5.00-100%)                       SLP2    := 75.00  ?60 <Enter>
Unrestrained Element Current PU (1.00-20)            U87P    := 8.00   ? <Enter>
Incr. Operate Current Threshold p.u. (0.10-10)       DIOPR   := 1.20   ? <Enter>
Incr. Restraint Current Threshold p.u. (0.10-10)     DIRTR   := 1.20   ? <Enter>
Enable Harmonic Blocking Diff. Element (Y,N)         E87HB   := N      ? <Enter>
Enable Harmonic Restraint Diff. Element (Y,N)        E87HR   := Y      ? <Enter>
Second-Harmonic Percentage (OFF, 5-100%)             PCT2    := 15     ? <Enter>
Fourth-Harmonic Percentage (OFF, 5-100%)             PCT4    := 15     ? <Enter>
Fifth-Harmonic Percentage (OFF, 5-100%)              PCT5    := 35     ? <Enter>
Fifth-Harmonic Alarm Threshold p.u. (OFF, 0.2-3.2)   TH5P    := OFF    ? <Enter>
Enable Wave-Shape Blocking Diff. Element (Y,N)       E87T_WS := N      ? <Enter>
Neg. Seq. Differential Op current (0.05-1)           87QP    := 0.30   ? <Enter>
Neg. Seq. Differential Slope (5 - 100%)              SLPQ1   := 25     ?END <Enter>

Save settings (Y,N)  ?Y <Enter>
Saving Settings, Please Wait...........
Settings Saved

=>>
```

Figure 3.26 Group Settings for the Differential Test (Continued)

Step 1. With arbitrary values IRT = 3 per unit, SLP1 = 30, and SLP2 = 60 percent, use *Equation 3.9* to calculate IOP(IRT) values for Slope 1 and Slope 2:

$$\mathrm{IOP(IRT)} = \frac{30}{100} \bullet 3 = 0.9 \text{ pu (Slope 1)}$$

Equation 3.15

$$\mathrm{IOP(IRT)} = \frac{60}{100} \bullet 3 = 1.8 \text{ pu (Slope 2)}$$

Equation 3.16

Case 1: Internal Fault

Select an IOP_{OP} value greater than 1.8 to ensure that the relay will operate, such as 3 per unit. *Figure 3.27* shows the selected point P(3,3), which is well within the tripping area (shaded area).

Figure 3.27 Values for Case 1

For this test, you need to inject current into Terminal S only, i.e., I*n*T (*n* = A, B, C) = 0, and I*n*S = 3 per unit. Convert per-unit values (pu) to ampere values, by multiplying the per-unit values with the TAPS value (2.1), as shown in *Table 3.10*.

Table 3.10 Calculate the Current Values in Amperes (Case 1)

Current (per unit)	Current (Amperes)
IAS = 3∠0°pu • 2.1	IAS = 6.3∠0°A
IBS = 3∠–120°pu • 2.1	IBS = 6.3∠–120°A
ICS = 3∠120°pu • 2.1	ICS = 6.3∠120°A

Step 1. Inject balanced 6.3 A into Terminal S for 100 ms, then stop.

Step 2. Verify that LEDs 3, 4, and 5 are illuminated.

Step 3. Press the TARGET RESET button to reset the LEDs.

Case 2: External Fault With Heavy CT Saturation

This test simulates an external fault that eventually results in extreme CT saturation that would have caused the relay to trip if the relay were still operating on Slope 1. However, because the relay switched to Slope 2, the relay does not operate for this fault for less than one second. This test will be run in two stages, the first stage simulating an external fault without CT saturation and the second stage introducing heavy CT saturation.

Step 1. For Stage 1, select a large IRT value that will simulate an external fault without CT saturation (IOP_{OP} is zero); a good value for IRT is 3 pu. *Figure 3.28* shows the selected point P1(3,0).

Figure 3.28 Values for Case 2

Step 2. Calculate IAS and IAT for the point P1(3,0):

$$IAS = \frac{IRT + IOP_{OP}}{2} = \frac{3 + 0}{2} = 1.5$$

Equation 3.17

$$IAT = \frac{IRT - IOP_{OP}}{2} = \frac{3 - 0}{2} = 1.5$$

Equation 3.18

Convert per-unit values (pu) to ampere values by multiplying the per-unit values with the TAP values, as shown in *Table 3.11*.

Table 3.11 Calculate the Current Values in Amperes (Case 2, Stage 1)

Current (per unit)	Current (Amperes)
IAS = 1.5∠0°pu • 2.1	IAS = 3.15∠0°A
IBS = 1.5∠–120°pu • 2.1	IBS = 3.15∠–120°A
ICS = 1.5∠120°pu • 2.1	ICS = 3.15∠120°A
IAT = 1.5∠180°pu • 4.37	IAT = 6.56∠180°A
IBT = 1.5∠60°pu • 4.37	IBT = 6.56∠60°A
ICT = 1.5∠–60°pu • 4.37	ICT = 6.56∠–60°A

Step 3. For Stage 2, select an IOP_{OP} value between 0.9 pu and 1.8 pu that will simulate CT saturation. Accounting for the group settings of the relay, a good choice for IOP_{OP} would be 1.2 pu. *Figure 3.28* shows the selected point P2(3,1.2) and the area between the two slopes (shaded area).

Step 4. Calculate IAS and IAT for the point P2(3,1.2):

$$IAS = \frac{IRT + IOP_{OP}}{2} = \frac{3 + 1.2}{2} = 2.1$$

Equation 3.19

$$IAT = \frac{IRT - IOP_{OP}}{2} = \frac{3 - 1.2}{2} = 0.9$$

Equation 3.20

As before, convert the pu values to ampere values by multiplying by the appropriate TAP values, as shown in *Table 3.12*.

Table 3.12 Calculate the Current Values in Amperes (Case 2, Stage 2)

Current (per unit)	Current (Amperes)
IAS = 2.1∠0°pu • 2.1	IAS = 4.41∠0°A
IBS = 2.1∠–120°pu • 2.1	IBS = 4.41∠–120°A
ICS = 2.1∠120°pu • 2.1	ICS = 4.41∠120°A
IAT = 0.9∠180°pu • 4.37	IAT = 3.93∠180°A
IBT = 0.9∠60°pu • 4.37	IBT = 3.93∠60°A
ICT = 0.9∠–60°pu • 4.37	ICT = 3.93∠–60°A

Step 5. Inject the currents for Stage 1 shown in *Table 3.11* into Terminal S and Terminal T for 1.8 cycles, and then inject the currents for Stage 2 shown in *Table 3.12* into Terminal S and Terminal T for 800 ms.

Step 6. Verify that LEDs 3, 4, and 5 are NOT illuminated, i.e., the relay did not trip.

Case 3: Evolving Fault, Causing the Relay to Trip on Slope 2

This test is for a fault that starts out as an external fault (causing the relay to switch to Slope 2), but then evolves into an in-zone fault. The worst case for this fault is when there is only one source, i.e., when the fault moves to an internal fault, the side where the external fault was, does not contribute any fault current.

This test is in two stages: Stage 1 for the external fault (no saturation) and Stage 2 for the evolved fault.

Table 3.13 Current Values in Amperes (Case 3)

Current (Amperes) Stage 1	Current (Amperes) Stage 2
IAS = 4.2∠0°A	IAS = 4.2∠0°A
IBS = 4.2∠–120°A	IBS = 4.2∠–120°A
ICS = 4.2∠120°A	ICS = 4.2∠120°A
IAT = 8.74∠180°A	IAT = 0
IBT = 8.74∠60°A	IBT = 0
ICT = 8.74∠–60°A	ICT = 0

Step 1. Enable an overcurrent element for Terminal T, and set the pickup value to 0.5 A, as shown in *Figure 3.29*.

```
=>>SET E50 TE <Enter>
Group 1

Relay Configuration

Enable Def. Time Dir. O/C Ele. (OFF or combo of S,T)
E50     := OFF    ?T <Enter>
Enable Inverse Time Overcurrent Elements (N, 1-10)   E51     := N      ?1 <Enter>
Enable Current Unb. Elements (OFF or combo of S,T)   E46     := OFF    ?> <Enter>

Current Transformer Data

Current Trans. Ratio Terminal S (1-50000)            CTRS    := 100    ? <Enter>
Current Trans. Connection Terminal S (Y,D)           CTCONS  := Y      ? <Enter>
Current Trans. Ratio Terminal T (1-50000)            CTRT    := 100    ? <Enter>
Current Trans. Connection Terminal T (Y,D)           CTCONT  := Y      ? <Enter>

Terminal T
Overcurrent Elements Terminal T

Type of O/C Elements Enabled Term. T (Combo of P,Q,G)
E50T    := "P"    ? <Enter>
Enable Directional elements Terminal T (Y,N)         E67T    := N      ? <Enter>

Terminal T Phase Overcurrent Element Level 1

Phase Inst O/C pickup Level 1 (OFF,0.25-100)         50TP1P  := OFF    ?0.5 <Enter>
Phase Inst O/C Level 1 Torque Ctrl (SELogic Eqn)
67TP1TC := TF32P
?  END <Enter>


Save settings (Y,N)  ?Y <Enter>
Saving Settings, Please Wait...........
Settings Saved

=>>
```

Figure 3.29 Enable Overcurrent Element for Terminal T

Step 2. Enter the setting in *Figure 3.30* to include the overcurrent element in the SER.

```
=>>SET R TE <Enter>
Report

SER Chatter Criteria

Automatic Removal of Chattering SER Points (Y,N)     ESERDEL := N      ?

SER Points
(Relay Word Bit, Reporting Name, Set State Name, Clear State Name, HMI Alarm)

1:
?  50TP1 <Enter>
2:
?  TRPXFMR <Enter>
3:
?  END <Enter>

Save settings (Y,N)  ?Y <Enter>
Saving Settings, Please Wait...........
Settings Saved

=>>
```

Figure 3.30 Enter Overcurrent Element in the SER

Step 3. Inject the current shown in the Stage 1 column of *Table 3.13* into Terminal S and Terminal T for 200 ms, then inject the Stage 2 currents for 200 ms.

Step 4. Issue the **SER** command and calculate the time difference between the deassertion of 50TP1 and the assertion of TRPXFMR. This must be less than two cycles.

Negative-Sequence Differential Element

Use the settings shown in *Table 3.14* for the negative-sequence differential element test.

Table 3.14 Settings for the Negative-Sequence Test

Settings	Setting Group	Comment
E87Q = Y	Group	Enable negative-sequence differential element
MVA = 100	Group	Transformer rating
VTERMS = 275	Group	HV rated voltage
VTERMT = 132	Group	LV rated voltage
E87 = S, T	Group	Enable Terminals S and T in the differential element
E87TS = 1	Group	
E87TT = 1	Group	

Be sure that the compensation settings (TSCTC = TTCTC = 0) and the negative-sequence elements (87QP = 0.3, SLPQ1 = 25) are at default settings.

Step 1. Inject the currents shown in *Table 3.15* in the relay.

Table 3.15 Currents for Negative-Sequence Differential Test

Terminal S	Terminal T
IAS = 0.55 A	IAT = 0
IBS = 0	IBT = 0
ICS = 0	ICT = 0

Step 2. Issue the **TAR 87Q 9999** command as shown below.

```
=>>TAR 87Q 9999 <Enter>

87Q     87PQ    *       *       *       *       *       *
0       0       0       0       0       0       0       0
0       0       0       0       0       0       0       0
0       0       0       0       0       0       0       0
0       0       0       0       0       0       0       0
0       0       0       0       0       0       0       0
0       0       0       0       0       0       0       0
```

Step 3. Slowly increase IAS current in 10 mA steps. 87Q asserts (87Q = 1) when IAS is approximately 0.63 A.

At threshold:

$$\begin{aligned} 3I2S = IAS &= 87QP \bullet TAPS \\ &= 0.3 \bullet 2.1 \\ &= 0.63 \end{aligned}$$

Negative-Sequence Directional Element for Phase Faults

Use the phase directional element (represented by Relay Word bits *k*F32P/*k*R32P, *k* = S, T, U, W, X) to convert non-directional phase overcurrent elements to directional phase overcurrent elements. The negative-sequence directional element, *k*F32Q/*k*R32Q, is a part of the phase directional element, and provides directional

control for all shunt faults except for bolted, three-phase faults. Because the negative-sequence element is part of the phase element, the phase directional element asserts whenever the negative-sequence directional element asserts.

The SEL-487E calculates the negative-sequence impedance Z2 from the magnitudes and angles of the negative-sequence voltage and current. *Equation 3.21* defines this function (the "c" in Z2c indicates "calculated").

$$Z2c = \frac{Re[V_2 \bullet (1\angle Z1ANG \bullet I_2)^*]}{|I_2|^2}$$
$$= \frac{|V_2|}{|I_2|} \bullet (\cos\angle V_2 - \angle Z1ANG - \angle$$

Equation 3.21

where:

V_2 = the negative-sequence voltage
I_2 = the negative-sequence current
Z1ANG = the positive-sequence line impedance angle
Re = the real part of the term in brackets, for example, (Re[A + jB] = A)
* = the complex conjugate of the expression in parentheses, (A + jB)* = (A – jB)

The result of *Equation 3.21* is an impedance magnitude that varies with the magnitude and angle of the applied current. Normally, a forward fault results in a negative Z2c relay calculation.

Test Current

Solve *Equation 3.22* to find the test current values that you need to apply to the relay to test the element. For the negative-sequence current I_2, the result is

$$|I_2| = \frac{|V_2|}{Z2c}$$

Equation 3.22

when:

$$\angle I_2 = \angle V_2 - \angle Z1ANG$$

Equation 3.23

Multiply the quantities in *Equation 3.22* by three to obtain $3I_2$, the negative-sequence current that the relay processes. With a fixed applied negative-sequence voltage VA, the relay negative-sequence voltage is 3V2. Set Z2c = Z2FT to find the test current magnitude at the point where the impedance calculation equals the forward fault impedance threshold as follows:

$$|I_{TEST}| = |3I_2| = \frac{|3V_2|}{Z2c} = \frac{|3V_2|}{Z2FT}$$

Equation 3.24

when:

$$\angle I_{TEST} = \angle 3I_2 = \angle 3V_2 - \angle Z1ANG$$

Equation 3.25

Use *Equation 3.26* for a reverse fault impedance threshold, where Z2c = Z2R:

$$\left|I_{TEST}\right| = \left|3I_2\right| = \frac{\left|3V_2\right|}{Z2c} = \frac{\left|3V_2\right|}{Z2R}$$

Equation 3.26

when the angle calculation is the same as *Equation 3.25*.

Checking the Negative-Sequence Directional Element (Phase Faults Clear of Ground)

NOTE: As you perform this test, other protection elements can assert. This causes the relay to assert other targets and possibly close control outputs. Be sure to isolate the relay from the power system to avoid unexpected system effects.

This test confirms operation of the TF32Q and the TR32Q negative-sequence directional element for Terminal T, using a 5 A relay; scale values appropriately for a 1 A relay. This example assumes that you have successfully established communication with the relay, and that you are familiar with relay access levels and passwords. *Table 3.16* shows the settings necessary for the test.

Table 3.16 Settings to Test the Negative-Sequence Directional Element for Terminal T

Settings	Description	Category
EPTTERM = V	Enables the PT inputs (V or Z)	Group
E50 = T	Enables the directional element for Terminal T	Group
VREFT = V	Declares which PT to use (V or Z)	Group
E50T = Q	Specifies which overcurrent elements to enable for Terminal T (P, Q, G)	Group
E67T = Y	Enables the directional logic for Terminal T	Group
Z1ANGT = 84 degrees	Positive-sequence line impedance angle	Group
EADVST = Y	Enable advanced settings Terminal T	Group
50FPT = 0.6 A	Forward directional overcurrent pickup	Group
50RPT = 0.4 A	Reverse directional overcurrent pickup	Group
Z2FT = 3.9 Ω	Forward directional Z2 Threshold	Group
Z2RT = 4.4 Ω	Reverse directional Z2 Threshold	Group
A2T = 0.10	Positive-sequence Restraint Factor	Group

Step 1. Configure the relay.

Set the Group settings for Terminal T (see *Figure 3.31*).

```
=>>SET <Enter>
Group 1

Relay Configuration

Enable Current Terminals (OFF or combo of S,T,U,W,X)
ECTTERM := "S,T"  ? <Enter>
Enable Voltage Terminals (OFF or combo of V,Z)       EPTTERM := OFF    ?V <Enter>
Enable Diff Elem. Prot. Terms (OFF or combo of S,T)
E87     := OFF    ? <Enter>
Enable Restricted Earth Fault Element (N,1-3)        EREF    := N      ? <Enter>
Enable Def. Time Dir. O/C Ele. (OFF or combo of S,T)
E50     := OFF    ?T <Enter>
Enable Inverse Time Overcurrent Elements (N, 1-10)   E51     := N      ? <Enter>
Enable Current Unb. Elements (OFF or combo of S,T)   E46     := OFF    ? <Enter>
Enable Over Voltage Elements (N,1-5)                 E59     := N      ? <Enter>
Enable Under Voltage Elements (N,1-5)                E27     := N      ? <Enter>
Enable Frequency Elements (N,1-6)                    E81     := N      ? <Enter>
Enable Volts per Hertz Element (Y,N)                 E24     := N      ? <Enter>
Enable Bkr Fail. Prot. (OFF or combo of S,T)         EBFL    := OFF    ? <Enter>
Enable Power Calc. Term (OFF or combo of S,T)        EPCAL   := OFF    ? <Enter>
Enable Demand Metering (N, 1-10)                     EDEM    := N      ? <Enter>

Current Transformer Data

Current Trans. Ratio Terminal S (1-50000)            CTRS    := 100    ? <Enter>
Current Trans. Connection Terminal S (Y,D)           CTCONS  := Y      ? <Enter>
Current Trans. Ratio Terminal T (1-50000)            CTRT    := 100    ? <Enter>
Current Trans. Connection Terminal T (Y,D)           CTCONT  := Y      ? <Enter>

Potential Transformer Data

Potential Trans. Ratio Terminal V (1.0-10000.0)      PTRV    := 2000.0  ? <Enter>
Potential Trans. Connection Terminal V (Y,D)         PTCONV  := Y       ? <Enter>
PT Nominal Voltage (L-L) Term. V (30-300 V,sec)      VNOMV   := 110     ? <Enter>

Voltage Reference Terminal Selection

Voltage Reference For Terminal S (OFF,V)             VREFS   := OFF     ? <Enter>
Voltage Reference For Terminal T (OFF,V)             VREFT   := OFF     ?V <Enter>

Terminal T
Overcurrent Elements Terminal T

Type of O/C Elements Enabled Term. T (Combo of P,Q,G)
E50T    := "P"    ?
Enable Directional elements Terminal T (Y,N)         E67T    := N      ?Y <Enter>
Current Transformer Polarity Terminal T (P,N)        CTPT    := P      ? <Enter>
Pos.-Seq. Line Impedance Angle (5.00-90 deg)         Z1ANGT  := 89.00  ?84 <Enter>
Enable Advanced Setting Terminal T (Y,N)             EADVST  := N      ?Y <Enter>
Forward Dir. O/C Pickup (0.25-5 A,sec)               50FPT   := 0.25   ?0.6 <Enter>
Reverse Dir. O/C Pickup (0.25-5 A,sec)               50RPT   := 0.25   ?0.4 <Enter>
Fwd Dir Z2 Threshold (-64.00-64 ohms,sec)            Z2FT    := -0.10  ?3.9 <Enter>
Rev Dir Z2 Threshold (-64.00-64 ohms,sec)            Z2RT    := 0.10   ?4.4 <Enter>
Pos.-Seq. Restraint Factor, I2/I1 (0.02-0.50)        A2T     := 0.10   ?

Terminal T Phase Overcurrent Element Level 1

Phase Inst O/C pickup level 1 (OFF,0.25-100)         50TP1P  := 0.50   ?END <Enter>

Save settings (Y,N)  ?Y <Enter>
Saving Settings, Please Wait...........
Settings Saved

=>>
```

Figure 3.31 Group Settings for the Directional Test

Step 2. Set test values in the relay.

Step 3. Set the front-panel LED to show the directional element word bits, as in *Figure 3.32*. With these settings, the LEDs are green when TF32Q and TR32Q are deasserted, and red when TF32Q and TR32Q are asserted.

```
=>>SET F PB8_LED TE <Enter>
Front Panel

Front Panel Settings

Pushbutton LED 8 (SELOGIC Equation)
PB8_LED := NA
?  TF32Q <Enter>
PB8_LED Assert & Deassert Color (Enter 2: R,G,A,O)   PB8_COL := AO     ?RG
Pushbutton LED 9 (SELOGIC Equation)
PB9_LED := NA
?  TR32Q <Enter>
PB9_LED Assert & Deassert Color (Enter 2: R,G,A,O)   PB9_COL := AO     ?RG
Pushbutton LED 10 (SELOGIC Equation)
PB10LED := NA
?  END <Enter>

Save settings (Y,N)  ?Y <Enter>
Saving Settings, Please Wait...........
Settings Saved

=>>
```

Figure 3.32 Front-Panel Settings

Step 4. Display the F32Q and R32Q Relay Word bits on the front-panel LCD screen.

a. Access the front-panel LCD MAIN MENU.

b. Highlight RELAY ELEMENTS and press **ENT**.

You will see a RELAY ELEMENTS screen with SEARCH highlighted at the bottom of the screen.

c. Press **ENT** to go to the ELEMENT SEARCH submenu.

d. Enter characters in the text input field using the navigation keys.

e. Highlight T and press **ENT** to enter the T character.

f. Highlight F and press **ENT** to enter the F character.

g. Enter the 3, 2, and Q characters in like manner.

h. Highlight ACCEPT and press **ENT**.

The relay displays the screen containing the TF32Q and TR32Q elements, as shown in *Figure 3.33*.

Figure 3.33 RELAY ELEMENTS LCD Screen Containing Elements TF32Q and TR32Q

Step 5. Calculate impedance thresholds.

a. For this test, apply an A-Phase voltage of VAV = 3V2 = 18.0 ∠180° V secondary.

b. Use *Equation 3.27* to find the current that is equal to the reverse impedance threshold Z2R.

$$\left|I_{TEST}\right| = \left|3I_2\right| = \frac{\left|3V_2\right|}{Z2RT} = \frac{\left|18.0\angle 180°V\right|}{4.4} = 4.1\ A$$

Equation 3.27

Step 6. Use *Equation 3.28* to find the current that is equal to the forward impedance threshold Z2F:

$$|I_{TEST}| = |3I_2| = \frac{|3V_2|}{Z2RFT} = \frac{|18.0\angle 180°V|}{3.90} = 4.62\ A$$

Equation 3.28

Step 7. Use *Equation 3.29* to determine the applied current angle ($\angle I_{TEST}$):

$$\angle I_{TEST} = \angle 3I_2 = \angle 3V_2 - \angle Z1ANG = 180° - 84° = 96°$$

Equation 3.29

Step 8. Apply a test current to confirm operation of TR32Q and TF32Q.

a. Connect a test source as shown in *Figure 3.34*.

b. Apply an A-Phase voltage of VA = 18.0∠180° V secondary.

Figure 3.34 Connections for Directional Element Test

c. Set the current source for IA = 0.0∠96° A.

d. Slowly increase the magnitude of IAT to apply the source test current.

e. Observe the `RELAY ELEMENT` LCD screen. Relay Word bit TR32Q asserts when |IA| = 0.4 A, indicating that the relay negative-sequence current is greater than the 50RPT pickup threshold. TR32Q deasserts when |IA| = 4.1 A, indicating that the relay negative-sequence calculation Z2c is now less than the Z2 reverse threshold Z2RT.

f. Continue to increase the current source while you observe the `RELAY ELEMENT` LCD screen. Relay Word bit TF32Q asserts when |IA| = 4.62 A, indicating that the relay negative-sequence calculation Z2c is less than the Z2 forward threshold Z2FT.

Commissioning Testing

When: When installing a new protection system.

Goal:

- Ensure that all SV and GOOSE publishing and subscribing is correct.
- Ensure that all system ac and dc connections are correct.
- Ensure that the relay functions as intended by using your settings.
- Ensure that all auxiliary equipment operates as intended.

⚠WARNING
Before working on a CT circuit, first apply a short to the secondary winding of the CT.

What to test: SV and GOOSE network; all connected or monitored inputs and outputs; polarity and phase rotation of ac current connections; simple check of protection elements.

SEL performs a complete functional check and calibration of each relay before it is shipped. This helps ensure that you receive a relay that operates correctly and accurately. Commissioning tests should verify that the relay is properly connected to the power system and all auxiliary equipment. Verify control signal inputs and outputs. Check breaker auxiliary inputs, SCADA control inputs, and monitoring outputs. Use an ac connection check to verify that the relay current inputs are of the proper magnitude and phase rotation.

Brief fault tests ensure that the relay settings are correct. It is not necessary to test every relay element, timer, and function in these tests.

Use the *SEL-487E Relay Commissioning Test Worksheet on page 3.33* to verify correct CT connections and settings when placing the relay in service. The worksheet shows how using software commands or the front-panel display can replace the need for the traditional phase angle meter and ammeter.

At commissioning time, use the relay **METER DIF** command to record the measured operate and restraint values for through-load currents. Use the **PULSE** command to verify relay output contact operation.

TEST SV

NOTE: The **TEST SV** command is not supported in the SEL-487E-5 SV Publisher.

NOTE: In the R400 firmware, the **CFG CTNOM** command sets all relay settings back to their factory-default values. Starting in the R401 firmware, **CFG CTNOM** only defaults the global and group protection settings on a nominal secondary current configuration change.

SEL SV publishers provide a **TEST SV** command that is useful when first commissioning a SV network. When the **TEST SV** command is executed, the publishers publish predefined values for all configured published streams on the SV network with the test flag asserted. The SEL-487E-5 SV Subscriber Relay disregards the messages until the **TEST SV** command is also issued at the relay (See *TEST SV on page 14.69 in the SEL-400 Series Relays Instruction Manual*). Once you have issued the **TEST SV** command, the relay starts accepting SV packets with the test flag asserted. No relay elements operate on the test signals because of the test flag assertion, but metering functionality still operates. The **TEST SV** command is useful for verifying proper publishing and subscriptions of the SV streams and aids in the commissioning of your SV network. In the SEL-487E, use the **CFG CTNOM** command (See *CFG CTNOM on page 14.10 in the SEL-400 Series Relays Instruction Manual*) to match the nominal secondary current of the SEL-487E-5 SV Subscriber Relay to the nominal CT rating of the publisher unit.

Technical Support

We appreciate your interest in SEL products and services. If you have questions or comments, please contact us at:

Schweitzer Engineering Laboratories, Inc.
2350 NE Hopkins Court
Pullman, WA 99163-5603 U.S.A.
Tel: +1.509.338.3838
Fax: +1.509.332.7990
Internet: selinc.com/support
Email: info@selinc.com

SEL-487E Relay Commissioning Test Worksheet

System Information

System Settings

RID (Relay identification) =	
TID (Terminal identification) =	
MVA (Maximum transformer Rating) =	

	Winding S		Winding T		Winding U		Winding W		Winding X	
Current transformer connection:	CTCONS =		CTCONT =		CTCONU =		CTCONW =		CTCONX =	
Current transformer ratio:	CTRS =		CTRT =		CTRU =		CTRW =		CTRX =	
Connection compensation:	TSCTC =		TTCTC =		TUCTC =		TWCTC =		TXCTC =	
Nominal line-to-line voltage (kV):	VTERMS =		VTERMT =		VTERMU =		VTERMW =		VTERMX =	
TAP calculation:	TAPS =		TAPT =		TAPU =		TAPW =		TAPX =	

Differential Settings

087P =		SLP1 =		SLP2 =		U87P =	

Metered Load (Data taken from substation panel meters, not the SEL-487E)

± Readings from meters	Winding S		Winding T		Winding U		Winding W		Winding X	
Megawatts:	MWS =		MWT =		MWU =		MWW =		MWX =	
Megavars:	MVARS =		MVART=		MVARU=		MVARW=		MVARX =	
MVA calculation:	MVAS =		MVAT =		MVAU =		MVAW =		MVAX =	

MVA calculation:

$$\mathrm{MVAn} = \sqrt{\mathrm{MWn}^2 + \mathrm{MVARn}^2}$$

Calculated Relay Load

	Winding S		Winding T		Winding U		Winding W		Winding X	
Primary Amperes calculation:	ISpri =		ITpri =		IUpri =		IWpri =		IXpri =	
Secondary Amperes calculation:	ISsec =		ITsec =		IUsec =		IWsec =		IXsec =	

Primary Amperes calculation:

$$\text{Inpri} = \frac{\text{MVAn} \bullet 1000}{\sqrt{3} \bullet \text{VTERMn}}$$

Secondary Amperes calculation:

$$\text{CTCONn} = \text{Y, In sec} = \frac{\text{Inpri}}{\text{CTRn}}$$

$$\text{CTCONn} = \text{D, In sec} = \frac{\text{Inpri} \bullet \sqrt{3}}{\text{CTRn}}$$

Connection Check

System load conditions should be higher than 0.1 A secondary. 0.5 A secondary is recommended for the best results.

Differential Connection (issue MET DIF <Enter> to serial port or front panel)

Operate Current:	IOPA =		IOPB =		IOPC =	
Restraint Current:	IRTA =		IRTB =		IRTC =	
Mismatch Calculation:	MMA =		MMB =		MMC =	

Check individual current magnitudes, phase angles, and operate and restraint currents in an event report if mismatch is not less than 0.10.

Mismatch Calculation:

$$\text{MMn} = \frac{\text{IOPn}}{\text{IRTn}}$$

Magnitude, Angle, and Phase Rotation Check

Issue **MET SEC <Enter>** to the serial port or front panel.

	Winding S		Winding T		Winding U		Winding W		Winding X	
A-Phase Secondary Amperes:	IAWS =		IAWT =		IAWU =		IAWW =		IAWX =	
A-Phase Angle:										
B-Phase Secondary Amperes:	IBWS =		IBWT =		IBWU =		IBWW =		IBWX =	
B-Phase Angle:										
C-Phase Secondary Amperes:	ICWS =		ICWT =		ICWU =		ICWW =		ICWX =	
C-Phase Angle:										

1. Calculated relay amperes match MET SEC amperes?
2. Phase rotation is as expected for each winding?
3. Do angular relationships among windings correspond to expected results? (Remember that secondary current values for load current flowing out of a winding will be 180° out-of-phase with the reference phase position for that winding. The reason is that CT polarity marks normally face away from the transformer on all windings.)

This page intentionally left blank

SECTION 4

Front-Panel Operations

The SEL-487E-5 relay front panel makes power system data collection and system control quick and efficient. Using the front panel, you can examine power system operating information, view and change port, group, and global settings, and perform relay control functions. The relay features a straightforward menu-driven control structure presented on the front-panel LCD. Front-panel targets and other LED indicators give a quick look at SEL-487E operation status. You can perform often-used control actions rapidly by using the large direct-action pushbuttons. All of these features help you operate the relay from the front panel, and they include the following:

- Reading metering
- Inspecting targets
- Accessing settings
- Controlling relay operations

General front-panel operations are described in *Section 4: Front-Panel Operations in the SEL-400 Series Relays Instruction Manual*. This section provides additional information that is unique to the SEL-487E. This section includes the following:

- *Front-Panel LCD Default Displays on page 4.1*
- *Front-Panel Menus and Screens on page 4.4*
- *Target LEDs on page 4.14*
- *Front-Panel Operator Control Pushbuttons on page 4.16*
- *One-Line Diagrams on page 4.20*

Front-Panel LCD Default Displays

The SEL-487E has two screen scrolling modes: autoscrolling and manual scrolling. After front-panel time-out, the relay enters the autoscrolling mode, and the LCD presents each of the display screens in this sequence:

- Any active (filled) alarm points screens
- Any active (filled) display points screens
- Enabled metering screens
- One-line diagrams

Table 4.1 shows the high-voltage and low-voltage side screen selection, and *Table 4.2* through *Table 4.5* show the meter screen available for display on the front panel in the autoscrolling mode.

Table 4.1 Metering Screens Enable Settings

Screen	Description
ONELINE	Bay Control screen

Table 4.2 RMS Values

Screen	Description
Individual Terminals (Values)	
RMS_VLL	Line-to-line rms voltage
RMSW*m*VI[a]	Terminal *m* rms current and voltage screens
Combined Terminals	
STRMSVI	Combined Terminals S and T current and voltage screens
TURMSVI	Combined Terminals T and U current and voltage screens
UWRMSVI	Combined Terminals U and W current and voltage screens
WXRMSVI	Combined Terminals W and X current and voltage screens

[a] m = S, T, U, W, X, Y.

Table 4.3 Fundamental Values

Screen	Description
Individual Terminals (Values)	
FUN_VLL	Fundamental Line-to-Line Voltage, Frequency, and VDC screen
FUNW*m*VI[a]	Terminal *m* Fundamental Phase current and voltage screen
FUNW*m*SQ[a]	Terminal *m* Fundamental Sequence voltage and current screens
FUNW*m*PQ[a]	Terminal *m* Fundamental real (P) and reactive (Q) screen
FUNW*m*VA[a]	Terminal *m* Fundamental Apparent Power and pf screen
Combined Terminals	
STFUNVI	Combined Terminals S and T current and voltage screen
TUFUNVI	Combined Terminals T and U current and voltage screen
UWFUNVI	Combined Terminals U and W current and voltage screen
WXFUNVI	Combined Terminals W and X current and voltage screen
STFUNSQ	Combined Terminals S and T Fundamental Sequence voltage and current screen
TUFUNSQ	Combined Terminals T and U Fundamental Sequence voltage and current screen
UWFUNSQ	Combined Terminals U and W Fundamental Sequence voltage and current screen
WXFUNSQ	Combined Terminals W and X Fundamental Sequence voltage and current screen
STFUNPQ	Combined Terminals S and T real (P) and reactive (Q) screen
TUFUNPQ	Combined Terminals T and U real (P) and reactive (Q) screen
UWFUNPQ	Combined Terminals U and W real (P) and reactive (Q) screen
WXFUNPQ	Combined Terminals W and X real (P) and reactive (Q) screen
STFUNVA	Combined Terminals S and T Apparent Power and Power Factor Screen
TUFUNVA	Combined Terminals T and U Apparent Power and Power Factor Screen
UWFUNVA	Combined Terminals U and W Apparent Power and Power Factor Screen
WXFUNVA	Combined Terminals W and X Apparent Power and Power Factor Screen

[a] m = S, T, U, W, X, Y.

Table 4.4 Energy Quantities

Screen	Description
ENRMET*m*[a]	Terminal *m* energy screen
STENERM	Combined Terminals S and T energy screen
TUENERM	Combined Terminals T and U energy screen
UWENERM	Combined Terminals U and W energy screen
WXENERM	Combined Terminals W and X energy screen

[a] m = S, T, U, W, X, Y.

Table 4.5 Differential Quantities

Screen	Description
DIFFMET	Differential quantities screen

Use the front-panel settings (the **SET F RDD** command from a communications port or the **Front Panel** settings in SEL Grid Configurator) to access the metering screen enables. Enter each of the desired screens on a separate line. The relay will display the screens in the sequence that you enter. *Figure 4.1* shows a sample `ROTATING DISPLAY` consisting of an example alarm points screen (see *Alarm Points on page 4.7 in the SEL-400 Series Relays Instruction Manual*), an example display points screen (see *Display Points on page 4.10 in the SEL-400 Series Relays Instruction Manual*), and the metering screen RMSWSVI (see *Table 4.2*).

Figure 4.1 Sample ROTATING DISPLAY

Front-Panel Menus and Screens

Operate the SEL-487E front panel through a sequence of menus that you view on the front-panel display. The MAIN MENU is the introductory menu for other front-panel menus. These additional menus allow you on-site access to metering, control, and settings for configuring the SEL-487E to your specific application needs. Use the following menus and screens to set the relay, perform local control actions, and read metering:

- Support Screens
  - Contrast
  - Password
- MAIN MENU
  - METER
  - EVENTS
  - BREAKER MONITOR
  - RELAY ELEMENTS
  - LOCAL CONTROL
  - SET/SHOW
  - RELAY STATUS
  - VIEW CONFIGURATION
  - DISPLAY TEST
  - RESET ACCESS LEVEL
  - ONELINE DIAGRAM

See *Section 4: Front-Panel Operations in the SEL-400 Series Relays Instruction Manual* for information on most of these screens. The following screen descriptions are unique to the SEL-487E.

Meter

The SEL-487E displays metering screens on the LCD. Highlight METER on the MAIN MENU screen to select these screens. The METER MENU, shown in *Figure 4.2*, allows you to choose the following metering screens corresponding to the relay metering modes:

- RMS METER
- FUNDAMENTAL METER
- DEMAND METER
- ENERGY METER
- DIFFERENTIAL METER

Figure 4.2 METER Menus

Figure 4.2 shows the five categories of meter screens available in the SEL-487E, as well as the prerequisite(s) for each screen. *Table 4.6* summarizes these prerequisite(s) and also states how the VREF*m*, ALTV*m*, PTCON*k* (*k* = V, Z), and CTCON*m* (*m* = S, T, U, W, X, Y) settings influence the displays. *Table 4.6* also shows the sequence in which the screens appear on the front panel.

Table 4.6 Meter Availability Conditions

Meter[a]	Prerequisite
RMS Meter[b]	Neither ECTTERM nor EPTTERM is set to OFF.
Fundamental Meter[b, c]	Neither ECTTERM nor EPTTERM is set to OFF.
Demand Meter	EDEM ≠ OFF
Energy Meter	VREF*m* ≠ OFF and EPCAL ≠ OFF
Differential Meter	E87 ≠ OFF and E87Z2 ≠ OFF

[a] Power screens (apparent, real, and reactive) are displayed only for those terminals that specified a PT in the VREFm settings (where m = S, T, U, W, X, Y).

[b] If ALTVm is true, screens will display the opposite voltage reference of that selected by VREFm (where m = S, T, U, W, X, Y).

[c] If PTCONk = D (delta-connected PTs), 3V0 is not displayed (where k = V, Z). If CTCONm = D (delta-connected CTs), 3I0 is not displayed (where m = S, T, U, W, X, Y).

When metering combined quantities, the individual terminals must have the same reference voltage. For example, for Terminal ST, ALTVS and ALTVT must be equal and VREFS and VREFT must be set to the same reference voltage.

RMS Meter

To view the rms meter values, select METER from the main menu and press **ENT**, then press **ENT** with RMS METER highlighted, as shown in *Figure 4.3(a)*. *Figure 4.3(b)* shows the screen with the LINE VOLTAGES, SINGLE TERMINAL, and COMBINED TERMINAL options. With the LINE VOLTAGES highlighted, press **ENT** to see the line-to-line voltages of the enabled PTs, as shown in *Figure 4.3(c)*. In this example, both PT V and PT Z are enabled (included in the EPTTERM Group setting), and values from both PTs are available. If no PTs are enabled (EPTTERM = OFF), then this screen is not displayed.

Figure 4.3 Line Voltages, Single Terminal, and Combined Terminal Options

With the `SINGLE TERMINAL` highlighted, press **ENT** to go to screen *(a)* in *Figure 4.4*, showing the single terminals. Only terminals that are included in the ECTTERM Group setting appear on this screen. In this example, all five terminals are included in the ECTTERM setting (ECTTERM = S, T, U, W, X, Y). With `TERMINAL S` highlighted, press **ENT** to move to the `RMS METER: TERMINAL S` and `VOLTAGE` screen (screen *(b)*) in *Figure 4.4*. If no voltages are enabled, then only current values are shown.

Figure 4.4 RMS Meter Screens

In screen *(b),* <VREFS> displays the value of the PT specified by Group setting VREFS (V or Z) for Terminal S. If ALTVS is asserted, <VREFS> displays the value of the alternate PT (V or Z). For example, if VREFS = V and ALTVS = 0, <VREFS> displays the value of PT V. If VREFS = V and ALTVS = 1, <VREFS> displays the value of PT Z. If no PT is specified for Terminal S (VREFS = OFF), then the voltage is not displayed. Terminal T through Terminal X have similar screens.

Combined terminal screens are similar to the terminal specific screens, as shown in *Figure 4.5* (combined Terminal ST). Valid combinations are ST, TU, UW, and WX, and the content of *Table 4.6* also applies to the combined terminals.

Figure 4.5 RMS Combined Terminals

Fundamental Meter

The fundamental voltage and single terminal screens provides similar information as shown in *Figure 4.3* and *Figure 4.4*. However, the fundamental meter also includes active, reactive, and apparent power screens, as well as sequence component screens, as shown in *Figure 4.6*. *Figure 4.6(a)* shows the fundamental metering screen for Terminal S. Notice that the fundamental meter includes the angular relationships, using the positive-sequence voltage of Terminal V as reference (VREFS = V and ALTVS = NA in this example). Press the **Down Arrow** to move to the Terminal S sequence screen. This screen shows the positive, negative, and zero-sequence voltage and currents for Terminal S. Zero-sequence values are not shown when the CTs or PTs are connected in delta. Press the **Down Arrow** repeatedly to move through the remaining enabled terminal, until screen *(c)*. Screens *(c)* and *(d)* shows the fundamental real, reactive and apparent power, and the power factors.

Figure 4.6 Fundamental Single Terminal Screens

Screens for the combined terminal are the fundamental meter combined terminal screens, including positive-, negative-, and zero-sequence screens.

Demand Meter

Following the fundamental meter screens are the demand meter screens. In the SEL-487E, the demand meter operate quantities are not fixed. Instead of fixed operating quantities, select a suitable operating quantity (see *Section 12: Analog Quantities*) for each of the 10 demand elements (see *Demand Meter on page 7.10* for more information).

Because you can select the number of demand elements, there will be either one or two sets of demand meter screens. If you select five or less demand elements, then there is only one screen; for more than five demand elements, there are two screens. *Figure 4.7* shows the four demand screens. Screen *(a)* and screen *(b)* show the selected demand element operating quantities (screen *(b)* is shown only if more than five operating quantities are selected). Also, each operating quantity can be either a rolling or a thermal calculation. This selection is shown by `ROLL PK` or `THERM PK` following the operating quantity in screen *(a)* and screen *(b)*. Screen *(c)* and screen *(d)* show reset options for demand and maximum demand quantities. Use the **Left Arrow** and **Right Arrow** pushbuttons to select a `NO` or `YES` response to the reset prompt, and then press **ENT** to reset the all of the metering quantities.

Figure 4.7 Demand Meter Screens

Energy Meter

Energy metering is the final front-panel display screen. *Figure 4.8(a)* shows the screen for a single terminal, *Figure 4.8(b)* the screen for a combined terminal, and *Figure 4.8(c)* the energy reset screen. Use the **Left Arrow** and **Right Arrow** pushbuttons to select a `NO` or `YES` response to the reset prompt, and then press **ENT** to reset all of the metering quantities.

Figure 4.8 Energy Meter Screens

Differential Meter

The SEL-487E provides a differential metering screen for two possible zones. Differential operate and restraint current are metered for each enabled zone, as shown in *Figure 4.9*.

Figure 4.9 Differential Meter Screen

Events

The SEL-487E front panel features summary event reporting, which simplifies post-fault analysis. These summary event reports include the items shown in *Table 4.7*.

Table 4.7 Event Types

Event	Description
87 Z1	Zone 1 differential element involved, indicated by the rising edge of 87R
87 Z2	Zone 2 differential element involved, indicated by the rising edge of 87R2
REF	Restricted earth fault element involved, indicated by the rising edge of REF
TRIP	Rising edge of Relay Word bit TRIP
ER (event report trigger)	Rising edge of ER (SELOGIC control equation)
TRIG	Execution of the **TRIGGER** (**TRI**) command (manually triggered)

(a) (b) (c) (d)

Figure 4.10 EVENT SUMMARY Screen

To assist with fault analysis, the SEL-487E displays the targets that asserted during the event on the front panel. Use the **Right Arrow** pushbutton to move from screen *(a)* to screen *(b)* in *Figure 4.10*. There are 24 alias items (ALIAS 01 through ALIAS 24), one for each of the front-panel LEDs. Use the **SET T** command to enter alias settings for Relay Word bits TLED_1 through TLED_24. If no alias is defined for a particular TLED_*x* (*x* = 1 through 24), then the TLED_*x* Relay Word bit name is displayed. Also, if the particular TLED_*x* target is not set to be a tripping target, (i.e., T*x*LEDL setting is N), then it is not displayed. *Figure 4.10(d)* shows the differential quantities for the event.

Breaker Monitor

The SEL-487E features an advanced circuit breaker monitor. Select `BREAKER MONITOR` screens from the `MAIN MENU` to view circuit breaker monitor alarm data on the front-panel display. *Figure 4.11* shows the case where Monitor setting EBMON = S T U, i.e., three breakers are enabled. (If only one breaker is enabled [e.g., EBMON = S], then *Figure 4.110(b)* is not shown, and *Figure 4.11(c)* appears directly). Use the navigation pushbuttons to choose between `BREAKER S`, `BREAKER T`, or `BREAKER U`. Press **ENT** to view the selected circuit breaker monitor information, as shown in *Figure 4.11(c)*. The `BKR n ALARM COUNTER` screen displays the number of times the circuit breaker exceeded certain alarm thresholds (see *Circuit Breaker Monitor on page 7.14*).

Figure 4.11 BREAKER MONITOR Report Screens

Figure 4.11(d) shows the screen when no breaker monitors are enabled (EBMON = OFF).

View Configuration

You can use the front panel to view detailed information about the configuration of the firmware and hardware components in the SEL-487E. In the `MAIN MENU`, highlight the `VIEW CONFIGURATION` option by using the navigation pushbuttons and press **ENT**. The relay presents seven screens in the order shown in *Figure 4.12*. Use the navigation pushbuttons to scroll through these screens. When finished viewing these screens, press **ESC** to return to the `MAIN MENU`.

Figure 4.12 VIEW CONFIGURATION Sample Screens

Target LEDs

The SEL-487E gives you at-a-glance confirmation of relay conditions via 24 color-programmable operation and target LEDs, located in the middle of the relay front panel, as shown in *Figure 4.13*. To provide clear visual indication, choose between red and green for the **ENABLED** and **TRIP** LED colors. For the remaining LEDs, choose among red, green, or amber.

Figure 4.13 Factory-Default Front-Panel Target LEDs

A description of the general operation and configuration of these LEDs is provided in *Section 4: Front-Panel Operations in the SEL-400 Series Relays Instruction Manual*. Please note that the SEL-487E has alternative behavior on the T*n*_LED bits: they latch independent of the trip condition.

Table 4.8 shows the LED labels (top to bottom in *Figure 4.13*) and the actual settings. These settings are based on a two-winding transformer with directional overcurrent elements and REF protection enabled. All voltage elements are with reference to PT V.

Table 4.8 LED Settings (Sheet 1 of 2)

LED Label	Settings	Comment
TRIP S	TRIPS	Trip logic asserted, Terminal S
TRIP T	TRIPT	Trip logic asserted, Terminal T
A PH DIFF	87RA OR 87UA	Restraint or unrestraint differential element A
B PH DIFF	87RB OR 87UB	Restraint or unrestraint differential element B
C PH DIFF	87RC OR 87UC	Restraint or unrestraint differential element C
REF	REF51T1	REF Element 1 TOC element timed out
S BRKR FAIL	FBFS	Breaker failure, Terminal S
T BRKR FAIL	FBFT	Breaker failure, Terminal T
OVER CURRENT	50TP1 OR 67TPT1 OR 51T01	Overcurrent
VOLTS/HZ	24D1T OR 24D2T OR 24U1T OR 24U2T	Volts/hertz
U/O VOLTAGE	271P1T OR 591P1T	Voltage Element 1 under- or overvoltage function asserted
U/O FREQUENCY	81D1T	Frequency Element 1 under- or overpower function asserted
DIRECTIONAL POWER	32OPT01 OR 32UPT01	Power Element 1 under- or overvoltage function asserted
COMMS ALARM	NA	Communications Alarm. NA by default. Select Relay Word bits associated with your communications scheme.
HARM BLOCK	87ABK5 OR 87BBK5 OR 87CBK5 OR 87XBK2	Harmonic-block or harmonic-restraint differential element A, B, or C
VAV ON	VAVFM > 55	A-Phase from PT V present

Table 4.8 LED Settings (Sheet 2 of 2)

LED Label	Settings	Comment
VBV ON	VBVFM > 55	B-Phase from PT V present
VCV ON	VCVFM > 55	C-Phase from PT V present
THRU-FAULT ALARM	TFLTALA OR TFLTALB OR TFLTALC	Through-fault element asserted, phase A, B, or C
LOP V	LOPV or LOPZ	Loss-of-potential (LOP), PT V or PT Z
INSULATION ALARM	FAA1	Thermal Element 1 aging acceleration factor asserted
IRIG OK	TIRIG	
EXTERNAL FAULT	CON	External fault detected; relay in high-security mode
FREQ OK	FREQOK	Frequency OK

You can reprogram all of these indicators except the ENABLED and TRIP LEDs to reflect other operating conditions than the factory-default programming described in this section. Settings T*n*_LED are SELOGIC control equations that, when asserted during a relay trip event, light the corresponding LED. Parameter *n* is a number from 1 through 24 that indicates each LED.

Program settings T*n*LEDL := Y to latch the LEDs when the T*n*_LED SELOGIC control equation is true, regardless of the status of TRIP. The LEDs will reset with a subsequent TRIP or a TARGET RESET via the front panel or the **TAR R** command. When you set T*n*LEDL := N, the trip latch supervision has no effect and the LED follows the state of the T*n*_LED SELOGIC control equation. The relay reports these targets in event report summaries. The asserted and deasserted colors for the LED are determined with settings T*n*LEDC. Options include red, green, amber, or off.

After setting the target LEDs, issue the **TAR R** command or press the TARGET RESET button on the front panel to reset the target LEDs.

Use the slide-in labels to mark the LEDs with custom names. Download the word processor configurable label templates for printing slide-in labels from selinc.com.

Front-Panel Operator Control Pushbuttons

The SEL-487E front panel features large operator control pushbuttons coupled with color-programmable annunciator LEDs for local control. *Figure 4.14* shows this region of the relay front panel with factory-default configurable front-panel label text.

Figure 4.14 Operator Control Pushbuttons and LEDs

Table 4.9 shows the LED labels and the actual settings. These settings are based on a two-winding transformer with directional overcurrent elements and REF protection enabled.

Table 4.9 Pushbutton LED Settings

LED Number	LED Label	Settings	Assert and Deassert Color
1	Trip Breaker S01	NOT 52CLS	GO
2	Trip Breaker T01	NOT 52CLT	GO
3	Enable Directional Overcurrent	PLT03	AO
4	Reset Breaker Wear Levels	RST_BKS OR RST_BKT	AO
5	Blank	NA	AO
6	Blank	NA	AO
7	Close Breaker S01	52CLS	RO
8	Close Breaker T01	52CLT	RO
9	Enable Adaptive Overcurrent	PLT09	AO
10	Event Summary	NA	AO
11	Blank	NA	AO
12	Blank	NA	AO

Press the operator control pushbuttons momentarily to toggle on and off the functions listed adjacent to each LED/pushbutton combination.

There are two ways to program the operator control pushbuttons. The first is through front-panel settings PB*nn*_HMI (*nn* = 1–12). These settings allow any of the operator control pushbuttons to be programmed to display a particular HMI screen category. The HMI screen categories available are Alarm Points, Display Points, Event Summaries, SER, and Bay Control. Front-panel setting NUM_ER allows the user to define the number of event summaries that are displayed via

the operator control pushbutton; it has no effect on the event summaries automatically displayed or the event summaries available through the main menu. Each HMI screen category can be assigned to a single pushbutton.

Attempting to program more than one pushbutton to a single HMI screen category will result in an error. After assigning a pushbutton to an HMI screen category, pressing the pushbutton will jump to the first available HMI screen in that particular category. If more than one screen is available, a navigation scroll bar will be displayed. Pressing the navigation arrows will scroll through the available screens. Subsequent pressing of the operator control pushbutton will advance through the available screens, behaving the same as the **Right Arrow** or **Down Arrow** pushbutton. Pressing the **ESC** pushbutton will return the user to the `ROTATING DISPLAY`. The second way to program the operator control pushbutton is through SELOGIC control equations, using the pushbutton output as a programming element.

Using SELOGIC control equations, you can readily change the default LED functions. Use the slide-in labels to mark the pushbuttons and pushbutton LEDs with custom names to reflect any programming changes that you make. The labels are keyed; you can insert each Operator Control Label in only one position on the front of the relay. Download the word processor configurable label templates for printing slide-in labels from selinc.com. See the instructions included in the Configurable Label kit for more information on changing the slide-in labels.

The SEL-487E has two types of outputs for each of the front-panel pushbuttons. Relay Word bits represent the pushbutton presses. One set of Relay Word bits follows the pushbutton and another set pulses for one processing interval when the button is pressed. Relay Word bits PB1–PB12 are the “follow” outputs of operator control pushbuttons. Relay Word bits PB1_PUL–PB12PUL are the pulsed outputs.

Annunciator LEDs for each operator control pushbutton are PB1_LED–PB12LED. The asserted and deasserted colors for the LED are determined with settings PB*nn*COL. Options include red, green, amber, or off. You can change the LED indications to fit your specific control and operational requirements. This programmability allows great flexibility and provides operator confidence and safety, especially in indicating the status of functions that are controlled both locally and remotely.

SELOGIC Factory Setting	Operator Control Pushbutton	LED	Description
PB1_LED = NOT 52CLS		TRIP BREAKER S01	Press and hold this operator control pushbutton for one second to close OUT201 to trip Circuit Breaker S. The corresponding **TRIP BREAKER S01** LED is illuminated green, indicating that Circuit Breaker S is open based on the status of 52CLS. 52CLS is driven by the 52A_S SELOGIC equation, which is set to IN201 by default. Therefore, if IN201 is not connected, IN201 = 0, 52CLS = 0, and the LED will stay illuminated. If the LED is off, IN201 is asserted.
PB2_LED = NOT 52CLT		TRIP BREAKER T01	Press and hold this operator control pushbutton for one second to close OUT202 to trip Circuit Breaker T. The corresponding **TRIP BREAKER T01** LED is illuminated green, indicating that Circuit Breaker T is open based on the status of 52CLT. 52CLT is driven by the 52A_T SELOGIC equation, which is set to IN202 by default. Therefore, if IN202 is not connected, IN202 = 0, 52CLT = 0, and the LED will stay illuminated. If the LED is off, IN202 is asserted.
PB3_LED = PLT03		ENABLE DIRECTIONAL OVER CURRENT	Press this operator control pushbutton to supervise the phase instantaneous overcurrent Level 1, 2, and 3 torque-control elements 67*m*P1TC, 67*m*P2TC, and 67*m*P3TC (*m* = S, T, U, W, X, or Y). Default Protection Logic settings are programmed to latch Relay Word bit PLT03 with the pulse of this pushbutton. Pressing PB3 again while PLT03 is asserted will reset the latch. The **ENABLE DIRECTIONAL OVERCURRENT** LED is illuminated amber indicating that PLT03 is asserted. Note: By default, E50 = OFF and 50*m*P1P = OFF. These settings must also be enabled to run the 67*m*P1TC element.
PB4_LED = RST_BKS OR RST_BKT		RESET BREAKER WEAR LEVELS	Press this operator control pushbutton to reset (clear) the circuit breaker monitoring data for Breaker *m* (*m* = S, T, U, W, X, or Y). By default, Breaker S and T are enabled (BK_SEL = S, T). However, the breaker monitor is disabled by default (EBMON = N), so you must set EBMON to enable the breaker reset logic. Default Protection Logic settings are programmed to latch Relay Word bit PLT04 with the pulse of this pushbutton. Any condition that results in a true result in the RST_BKS or RST_BKT SELOGIC equation will reset the latch. Because RST_BKS and RST_BKT are set to PLT04 by default, the latch is reset one processing interval after it is set. However, RST_BKS and RST_BKT remain true for a few seconds until the reset logic clears. The **RESET BREAKER WEAR LEVELS** LED is illuinated amber until the reset logic clears. The LED will not illuminate if EBMON = OFF. Note: By default, E50 = OFF and 50*m*P1P = OFF. These settings must also be enabled to run the 67*m*P1TC element.
PB5_LED = NA PB6_LED = NA			
PB7_LED = 52CLS		CLOSE BREAKER S01	Press and hold this operator control pushbutton for one second to close OUT203 to close Circuit Breaker S. The corresponding **CLOSE BREAKER S01** LED is illuminated red, indicating that Circuit Breaker S is closed based on the status of 52CLS. 52CLS is driven by the 52A_S SELOGIC equation, which is set to IN201 by default. Therefore, if IN201 is not connected, IN201 = 0, 52CLS = 0, and the LED will not illuminate. If the LED is on, IN201 is asserted.
PB8_LED = 52CLT		CLOSE BREAKER T01	Press and hold this operator control pushbutton for one second to close OUT204 to close Circuit Breaker T. The corresponding **CLOSE BREAKER T01** LED is illuminated red, indicating that Circuit Breaker T is closed based on the status of 52CLT. 52CLT is driven by the 52A_T SELOGIC equation, which is set to IN202 by default. Therefore, if IN202 is not connected, IN202 = 0, 52CLT = 0, and the LED will not illuminate. If the LED is on, IN202 is asserted.
PB9_LED = PLT09		ENABLE ADAPTIVE OVER CURRENT	Press this operator control pushbutton to enable the inverse-time overcurrent torque-control elements 51TC*xx* (*xx* = 01–20). Default Protection Logic settings are programmed to latch Relay Word bit PLT09 with the pulse of this pushbutton. Pressing PB9 again while PLT09 is asserted will reset the latch. The **ENABLE ADAPTIVE OVERCURRENT** LED is illuminated amber indicating that PLT09 is asserted. Note: By default, E51 = OFF. This setting must also be enabled to run the 51TC*xx* elements.
PB10LED = NA		EVENT SUMMARY	Press this operator control pushbutton to display the Event Summaries HMI screen. The corresponding LED is not programmed to illuminate when the pushbutton is pressed. If there are no event summaries, the front panel will display the message, "NO EVENT SUMMARIES EXIST."
PB11LED = NA PB12LED = NA			

Figure 4.15 Factory-Default Operator Control Pushbuttons

One-Line Diagrams

One-line diagrams are fully explained in *Section 5: Control in the SEL-400 Series Relays Instruction Manual*. The SEL-487E supports a three-part one-line diagram: a HV portion selected with the HVMIMIC setting, a transformer section selected with a T_MIMIC setting, and a LV portion selected with the LVMIMIC setting.

By using QuickSet, you can include the bay control screens in the rotating display. Select ONELINE (found under Front Panel settings), selectable screens.

SECTION 5

Protection Functions

NOTE: For SV applications, operating times are delayed by the configured channel delay, CH_DLY. See SV Network Delays on page 17.33 in the SEL-400 Series Relays Instruction Manual for more details. For TiDL applications, the operating times are delayed by a fixed 1 ms. Use caution when setting relay coordination to account for this added delay.

This section provides a detailed explanation of the SEL-487E-5 Relay protection functions. Each subsection provides an explanation of the function, along with a list of the corresponding settings and Relay Word bits. Logic diagrams and other figures are included.

Functions discussed in this section are listed below.

- *Analog Channel Statuses on page 5.2*
- *Sampled Values Alarm Logic (SEL-487E-5 SV Subscriber) on page 5.4*
- *Application Setting SVBLK and Relay Word Bit SVBK_EX on page 5.5*
- *Differential Zone and Restricted Earth Fault Element Blocking Logic on page 5.6*
- *Potential Transformer (PT) Ratio Settings With LEA Inputs on page 5.7*
- *Inverting Polarity of Current and Voltage Inputs on page 5.12*
- *Voltage Source Selection on page 5.13*
- *Differential Elements (87) on page 5.13*
- *CT Sizing on page 5.49*
- *CT Ratio Selection for a Multiwinding Transformer on page 5.50*
- *Delta-Connected CTs on page 5.51*
- *REF Element on page 5.52*
- *Combined Terminals on page 5.59*
- *Overcurrent Elements on page 5.60*
- *Selectable Time-Overcurrent Element (51) on page 5.68*
- *Terminal Harmonic Blocking on page 5.75*
- *Line Protection Elements on page 5.75*
- *Fault Identification Logic on page 5.96*
- *Directional Control for Ground-Overcurrent Elements on page 5.99*
- *Best Choice Function Block on page 5.108*
- *Directional Control for Phase and Negative-Sequence Overcurrent Elements on page 5.109*
- *Unbalance Current Elements on page 5.117*
- *Open-Phase Detection Logic on page 5.119*
- *Breaker Failure Elements on page 5.120*
- *Volts/Hertz Elements on page 5.124*
- *Synchronism Check on page 5.131*
- *Over- and Undervoltage Elements on page 5.152*
- *Frequency Estimation on page 5.154*
- *Over- and Underfrequency Elements on page 5.157*

➤ *Total Harmonic Distortion on page 5.158*
➤ *IEC Thermal Elements on page 5.159*
➤ *Over- and Underpower Element on page 5.164*
➤ *Trip Logic on page 5.169*
➤ *Close Logic on page 5.171*
➤ *Autoreclosing on page 5.172*
➤ *Loss-of-Potential (LOP) Logic on page 5.178*
➤ *Circuit Breaker Status on page 5.182*

Analog Channel Statuses

The SEL-487E-5 SV Subscriber or TiDL relay provides Relay Word bits for monitoring the status of analog channel data received over a DSS connection. Relay Word bits IASMAP, IBSMAP, and ICSMAP assert to indicate that the relay is configured to receive data for the Terminal S current channels (similar for Terminals T, U, W, X, and Y). Relay Word bits VAVMAP, VBVMAP, VCVMAP, VAZMAP, VBZMAP, and VCZMAP assert to indicate that the relay is configured to receive data for the respective voltage channels from a merging unit. For example, IASMAP = 1 and VAVMAP = 1 if IAS and VAV are configured to receive data over a DSS connection. Otherwise, these Relay Word bits evaluate to zero.

The relay declares each analog channel to be either OK or Blocked depending on the following criteria (*Figure 5.1* illustrates the processing of IASOK and IASBK as an example):

- If an analog channel is mapped (such as IASMAP = 1) and no more than three samples (for SV subscriber relays) or seven samples (for TiDL relays) are unusable or lost, the corresponding OK Relay Word bit asserts (such as IASOK = 1).
- If an analog channel is mapped (such as IASMAP = 1) and more than three samples (for SV subscriber relays) or seven samples (for TiDL relays) are unusable or lost, the corresponding Blocked Relay Word bit asserts (such as IASBK = 1).
- The Blocked Relay Word bit has a 1.5-cycle dropout timer when the channel data becomes good and usable again to account for proper filtering of the incoming signal.
- If an analog channel is not mapped (such as IASMAP = 0), neither the OK nor the Blocked Relay Word bit asserts.
- A data loss condition occurs when a relay can no longer interpolate between data points to account for missed data. In the SV relay, the loss of more than three consecutive samples results in a data loss condition. In the TiDL relay, the loss of more than seven consecutive samples results in a data loss condition.

Figure 5.1 IAS Channel Status Processing (Similar for Other Terminals)

IASOK, IBSOK, ICSOK, and similar Relay Word bits for the T, U,W, X, and Y terminals, assert to indicate good data for the respective current channels. Relay Word bits VAVOK, VBVOK, VCVOK, VAZOK, VBZOK, and VCZOK assert to indicate good data for the respective voltage channels. You can use these Relay Word bits to monitor the health of the DSS.

The SEL-487E-5 generates per-terminal status indications based on the OK and Blocked Relay Word bits for the individual voltage and current channels, as shown in *Figure 5.2* and *Figure 5.3*. If all three individual phases of a three-phase voltage or current terminal are healthy, the OK Relay Word bit for that terminal asserts. Otherwise, the terminal OK bit is deasserted. If any of the three individual phases are unhealthy (Blocked), the Blocked Relay Word bit for that terminal asserts.

Figure 5.2 Voltage Terminal Status Logic

Figure 5.3 Current Terminal Status Logic for Terminal S (Similar for Other Current Terminals)

Figure 5.4 illustrates the freeze logic of analog current channels.

The freeze dropout delay setting, SVFZDO, allows users to reset the freeze logic for a permanent communications outage. If SVFZDO is set to the default value of OFF, the output of the timer is forced to always be deasserted and the freeze Relay Word bits follow the blocking Relay Word bits.

When SVFZDO is set to 0, the freeze Relay Word bit is permanently blocked. Changing SVFZDO to a value other than OFF or 0 specifies the time to deassert the freeze Relay Word bit for a permanent loss of data.

Figure 5.4 Current Channel Freeze Logic for Channel S (Similar for Other Current Channels)

Sampled Values Alarm Logic (SEL-487E-5 SV Subscriber)

NOTE: This functionality is only for the SV subscriber relay and not for the TiDL relay.

While the SV analog channel status Relay Word bits allow the user to monitor the health of individual analog channels and maintain protection element security, the general SV alarm logic alerts the user to potential communication and time source problems. *Figure 5.5* illustrates the SV alarm logic, which generates Relay Word bit SVSALM, which asserts under the following conditions:

- After a falling edge of Relay Word bit SVCC (SV coupled-clocks mode), SVSALM asserts until a subsequent rising edge of SVCC. SVCC = 0 indicates that the SEL-487E-5 SV Subscriber Relay is not operating in coupled-clocks mode, and is instead operating in freewheeling mode. This indicates a potential problem with the time source that serves the relay or the merging unit.
- The relay is in coupled-clocks mode (SVCC = 1), and the total network delay associated with any configured SV data stream is excessive (among Streams 1 through 7, for as many as seven streams). The measured total network delay includes the network path delay and the merging unit processing delay. The measured total network delay for each stream is compared against the CH_DLY relay setting. SVSALM assertion through this logic path indicates potential communication network issues or excessive merging unit processing delays.
- Any configured SV stream is declared invalid (SVS*mm*OK = 0, *mm* = 01–07). Problems such as packet corruption and packet loss can cause an SV subscription to be discarded by the SEL-487E-5 SV Subscriber Relay. These may indicate communication network problems.

Note that if the relay has been in freewheeling mode since turning on, the SVSALM logic will not assert through the upper latch shown in *Figure 5.5*. SVSALM will only assert if the relay begins in coupled-clocks mode and subsequently falls out of coupled-clocks mode and into freewheeling mode. If SVSALM asserts in the SEL-487E-5 SV Subscriber Relay, be sure to check your communication network and time sources for potential problems.

Figure 5.5 General Sampled Values Alarm Logic (SVSALM)

TiDL Alarm Logic (SEL-487E-5 TiDL Relay)

NOTE: This functionality is only for the TiDL relay and not for the SV subscriber relay.

While the analog channel status Relay Word bits allow the user to monitor the health of data mapped to analog terminals of the relay, the general TiDL alarm logic alerts the user to any communications issue with a connected and commissioned SEL-TMU. *Figure 5.6* illustrates the TiDL alarm logic, which generates

Relay Word bit TIDLALM. TIDLALM asserts under the condition that the SEL TiDL relay has identified a communication issue with at least one of its commissioned SEL-TMU.

Figure 5.6 General TiDL Alarm Logic

Application Setting SVBLK and Relay Word Bit SVBK_EX

In both the SEL-487E-5 SV Subscriber Relay and SEL-487E-5 TiDL Relay, use Global application SELOGIC setting SVBLK to specify the general conditions under which DSS data are unsuitable for use. You are free to specify this equation in any way, but SEL recommends that you use the analog channel status blocking Relay Word bits in this equation. For an application that uses Current Terminals S and T for transformer differential protection, Terminal U for feeder overcurrent protection, and Terminal V for undervoltage protection, a reasonable setting for SVBLK would be SVBLK := ISBK OR ITBK OR IUBK OR VVBK (see *Analog Channel Statuses on page 5.2*). *Figure 5.7* shows the extended blocking logic.

Figure 5.7 Extended Application Blocking Logic (SVBK_EX)

Selective Protection Disabling

The term “selective protection disabling” is used in some protection functions to discuss the application of the analog channel status block or freeze Relay Word bits in blocking or freezing certain protection elements and their outputs as a result of a loss of communications with a merging unit.

The goal of selective protection disabling is to maximize the availability of protection functions that are not impacted by the loss of data that are not required by that protection function.

A transformer current differential scheme is an example of using selective protection disabling where the bus voltage is provided by a merging unit that is not providing differential current measurements. *Figure 5.8* shows a simplified typical transformer differential scheme with bus voltages and transformer different current all provided by independent merging units. In this example application, a loss of communications with either merging unit that is measuring bus voltage only blocks protection elements relying on those voltage measurements and allows for the continued operation of the transformer current differential elements.

Figure 5.8 Selective Protection Disabling Overview

To perform selective protection disabling, some relay protection elements (such as loss of potential, breaker failure, etc.) are hard-coded to include block and freeze Relay Word bits as needed. Set other elements that provide torque-control equations (such as 32U, 51, 67G/Q, etc.) to include the block or freeze Relay Word bits in their torque-control equations. Some torque-control equations are set by default to include blocking bits, primarily when negative-sequence or zero-sequence quantities are used as the operating quantities. You can customize these torque-control equations and use the idea of torque controlling with these bits in your custom SELOGIC freeform logic to perform selective protection disabling within your custom logic.

Differential Zone and Restricted Earth Fault Element Blocking Logic

When using DSS data for differential protection, any loss of data on a current terminal within the differential zone will create false operating current, compromising the security of the differential element. To keep the differential element secure during such a scenario, the SEL-487E-5 includes dedicated logic to block the differential zone, as shown in *Figure 5.9*. Loss of data for currents within the differential zone will block the differential zone from operating, subject to the following two conditions:

- Loss of more than three packets (for SV subscriber relays) or seven packets (for TiDL relays) associated with the current terminal, resulting in the assertion of the terminal blocking bit (i.e., ISBK has asserted for Terminal S)
- The current terminal is included in the differential zone, according to settings E87 for Zone 1 or E87Z2 for Zone 2.

If the above criteria are met for any of the six current terminals in the Zone 1 differential, Relay Word bit 87BK asserts. 87BK is incorporated into the Zone 1 differential element to prevent the element from asserting for false operating current (see *Zone 1 Differential Elements (87T) on page 5.19* for details). Similar logic exists for the Zone 2 differential (see *Zone 2 Differential Elements (87B) on page 5.47* for details).

Figure 5.9 Zone 1 Differential Blocking Logic

The SEL-487E Restricted Earth Fault (REF) element discriminates between internal and external faults by calculating the relative phase angle between the measured transformer neutral (operating) current and a derived line zero-sequence (reference) current. If either the operating or reference current data are compromised because of a loss of DSS data, the security of the REF element could be compromised. The SEL-487E-5 uses dedicated logic to secure the REF elements during data loss, as shown in *Figure 5.10*. Similar to differential zone blocking, a loss of the data used to calculate zero-sequence reference current or neutral operating current will block the REF element from operating.

REF*n*BK is included by default in the REF torque-control SELOGIC equation (see *REF Element on page 5.52* for details). You can add additional logical conditions to the torque-control equations as well, but SEL recommends that you keep the REF blocking bit in this equation to keep the element secure.

Figure 5.10 Blocking Logic for Restricted Earth Fault Element

Potential Transformer (PT) Ratio Settings With LEA Inputs

PT Ratio Setting Adjustments

The SEL-487E can be ordered with different secondary input voltage configurations. Low-Energy Analog (LEA) voltage inputs are suitable for C37.92-compliant high-impedance sensors, such as capacitive voltage dividers and resistive voltage dividers (see *Figure 5.11*).

Figure 5.11 Low-Energy Analog (LEA) Voltage Sensor

Derive PT Ratio Settings for 8 Vac LEA Voltage Inputs

Refer to *Figure 5.11*.

V_{pri} / V_{sec} = true ratio of voltage divider when connected to the VV-terminal or VZ-terminal (8 Vac LEA) voltage inputs.

The SEL-487E sees 8 Vac on the VV-terminal or VZ-terminal (8 Vac LEA) voltage inputs as 300 Vac. To realize accurate primary voltage metering, the corresponding potential transformer ratio settings (PTRV or PTRZ), are set as follows:

$$\text{PTRV or PTRZ} = V_{pri} / V_{sec} \bullet (8/300)$$

For example, if an LEA sensor has a PTR of 1400:1,

$$\text{PTRV or PTRZ} = 1400 \bullet (8/300) = 37.3$$

$$\text{PT Ratio} = 37.3$$

Voltage-Related Settings and LEA Inputs (Group Settings)

Study *Figure 5.11* in preparation for *Example 5.1*.

When the V-terminal voltage inputs are 8 Vac LEA inputs, any voltage-related setting tied to the V-terminal voltage inputs is adjusted by a factor of 300/8.

Example 5.1 Voltage Setting Conversion to 300 V Base (Sheet 1 of 2)

A voltage divider (10000 ratio) is connected between a 12.47 kV system (7.2 kV line-to-neutral) and the LEA inputs.

7200 V / 10000V = 0.72 V
(actual voltage divider output to the 8 Vac LEA inputs; 8 V base)

0.72 V • (300/8) = 27 V
(the relay thinks it is looking at 27 V on a 300 V base, not 0.72 V on an 8 V base)

Example 5.1 Voltage Setting Conversion to 300 V Base (Sheet 2 of 2)

27 V is the nominal adjusted secondary voltage—adjusted by the 300/8 factor from an 8 V base to a 300 V base. For this same example, if a 0.8 V output of the 8 Vac LEA (8 V base) is deemed an overvoltage condition, then an overvoltage element pickup setting (e.g., 59P1P1) could be set at 59P1P1 := 0.8 V • (300/8) = 30 V (300 V base).

LEA Ratio Correction Factors

In the SEL-487E with LEA voltage inputs, RCF values for V terminals (Global settings VAVRCF, VBVRCF, and VCVRCF) are applied to respective voltage inputs VAV, VBV, and VCV, and the RCF values for VZ terminals (Global settings VAZRCF, VBZRCF, and VCZRCF) are applied to respective voltage inputs VAZ, VBZ, and VCZ. The resultant secondary voltages from these voltage inputs are normalized by the RCF values. These normalized secondary voltages are used throughout the SEL-487E.

Voltage Ratio Correction Factors for V- and Z-Terminal Voltage Inputs (Global Settings)

Use the VAVRCF, VBVRCF, and VCVRCF ratio correction factor Global settings for the V-terminal voltage inputs (VAV, VBV, and VCV, respectively) when they are ordered as LEA voltage inputs (see *Figure 5.11*). Use the VAZRCF, VBZRCF, and VCZRCF ratio correction factor Global settings for VZ-terminal voltage inputs (VAZ, VBZ, and VCZ, respectively) when they are ordered as LEA voltage inputs (see *Figure 5.11*). Ratio correction factor (RCF) settings compensate for irregularities (on a per-phase basis) of voltage dividers connected between the primary voltage system and the LEA inputs. The derivation of the RCF value for a voltage divider for a particular phase is defined as follows:

$$\begin{aligned} RCF &= \frac{\text{true ratio}}{\text{marked ratio}} \\ &= \frac{(V_{pri}/V_{sec})}{PTR_{LEA}} \\ &= \frac{V_{pri}}{V_{sec} \bullet PTR_{LEA}} \end{aligned}$$

Equation 5.1

where:

V_{pri} = test voltage applied to the primary side of the voltage divider

V_{sec} = resultant voltage measured on the secondary side of the voltage divider

true ratio = V_{pri} / V_{sec}

marked ratio = PTR_{LEA}

= effective nominal potential transformer (PT) ratio of the voltage divider connected between the primary voltage system and the LEA input.

The marked ratio of the voltage divider (PTR_{LEA}) is always provided by the manufacturer and often the per-phase RCF values are also provided.

If the voltage divider is perfect, then,

$V_{pri} / V_{sec} = PTR_{LEA}$ and RCF = 1.000

Therefore, the measured voltage divider performance equals the marked ratio of the voltage divider, as given by the manufacturer. But such perfect conditions are usually not the case.

If the voltage divider is putting out more voltage (V_{sec}) than nominally expected for an applied voltage input (V_{pri}), then,

$V_{pri} / V_{sec} < PTR_{LEA}$ and RCF < 1.000

An example of an RCF value less than 1.000 is found in *Example 5.2*. In this example, setting VBVRCF := 0.883 brings down the too-high voltage on voltage input VBV (0.82 V is brought down to nominal 0.72 V).

If the voltage divider is putting out less voltage (V_{sec}) than nominally expected for an applied voltage input (V_{pri}), then,

$V_{pri} / V_{sec} > PTR_{LEA}$ and RCF > 1.000

Example 5.2 Normalizing Voltages With Ratio Correction Factors

A voltage divider is connected to the 8 Vac LEA voltage inputs (see *Figure 5.11*). The RCF values per phase for the voltage divider are as follows:

VAVRCF := **1.078** (voltage input VAV)

VBVRCF := **0.883** (voltage input VBV)

VCVRCF := **1.112** (voltage input VCV)

The marked ratio of the voltage divider is as follows:

PTRLEA = 10000

What are the true ratios of each phase of the voltage divider?

true ratio (for a given phase) = V_{pri} / V_{sec}

V_{pri} and V_{sec} are measured in manufacturer tests to derive RCF values as shown in *Equation 5.1* and accompanying explanation. From *Equation 5.1* we obtain the following:

$RCF \bullet PTR_{LEA} = V_{pri} / V_{sec}$ = true ratio

1.078 • 10000 = 10780 (true ratio for voltage input VAV)

0.883 • 10000 = 8830 (true ratio for voltage input VBV)

1.112 • 10000 = 11120 (true ratio for voltage input VCV)

Note that these true ratios vary from 8830 to 11120, while the marked ratio of the voltage divider is 10000.

Consider what is happening in *Example 5.2*. First, assume the primary voltage (V_{pri}) is the same magnitude for each phase. When this primary voltage is run through the respective true ratios, the secondary voltage outputs vary widely. Presuming primary voltage of 12.47 kV (7.2 kV line-to-neutral), the resultant secondary voltages are listed as follows:

7200 V / 10780 = 0.67 V (true secondary voltage to voltage input VAV)

7200 V / 8830 = 0.82 V (true secondary voltage to voltage input VBV)

7200 V / 11120 = 0.65 V (true secondary voltage to voltage input VCV)

Note that the true secondary voltages to voltage inputs VAV and VCV are running low (below normalized secondary voltage 0.72 V = 7200 V / 10000), while the voltage to voltage input VBV is running high (above normalized secondary voltage 0.72 V). But the RCF values adjust these true secondary voltages to normalized secondary voltages:

0.67 V • 1.078 = 0.72 V (normalized voltage from voltage input VAV)

0.82 V • 0.883 = 0.72 V (normalized voltage from voltage input VBV)

0.65 V • 1.112 = 0.72 V (normalized voltage from voltage input VCV)

Again, the normalized secondary voltage (0.72 V) is the same for all three phases in this example, because the primary voltage is assumed to be the same magnitude for each phase (7200 V). These normalized secondary voltages are used throughout the SEL-487E. The true secondary voltages cannot be seen (via the SEL-487E) unless the RCF values are set to unity (RCF = 1.000).

Group setting PTRV is the potential transformer ratio from the primary system to the SEL-487E VV-Terminal voltage inputs. Group setting PTRZ is the potential transformer ratio from the primary system to the SEL-487E VZ-terminal voltage inputs. To make these settings for traditional 300 Vac voltage inputs is straightforward.

For example, on a 12.47 kV phase-to-phase primary system with wye-connected 7200:120 V PTs, the correct PTRV or PTRZ setting is 7200 / 120 = 60.00.

RCF Impact on COMTRADE Files

Relay event recordings in the COMTRADE format apply the RCF as a multiplier to the incoming low-level analog signal. The maximum range of the LEA input is 8 V_{rms}, which is scaled in relay firmware to represent 300 V_{rms} secondary voltage at the relay.

The COMTRADE recordings used by the relay have a maximum limit of 350 V_{rms} (495 V_{pk}). Because the RCF is a multiplier applied to the LEA input measurement, the RCF is present in the voltage values shown in the COMTRADE file, and a large RCF could have the effect of driving the COMTRADE voltage values to their maximum value even though the applied LEA input is below this level.

If voltage waveform clipping in the COMTRADE event report is apparent to the relay at nominal LEA voltage inputs, check the affected phase ratio correction factor. If the LEA scaling factor multiplied by the RCF and the LEA voltage input exceeds 350 V_{rms}, the COMTRADE waveform will be clipped.

Example 5.3

LEA voltage input (V_{LEA}) = 6 V_{rms}

LEA Scaling Factor (K_{LEA}) = 300/8

Phase RCF (RCF) = 1.5

Maximum COMTRADE Voltage (V_{max}) = 350 V_{rms}

$V_{LEA} \bullet K_{LEA} \bullet RCF < V_{max}$

$6 \bullet 300/8 \bullet 1.5 = 337.5\ V_{rms}$

This value will display in COMTRADE correctly.

Example 5.4

LEA voltage input (V_{LEA}) = 7 V_{rms}

LEA Scaling Factor (K_{LEA}) = 300/8

Phase RCF (RCF) = 1.5

Maximum COMTRADE Voltage (V_{max}) = 350 V_{rms}

$V_{LEA} \bullet K_{LEA} \bullet RCF < V_{max}$

$7 \bullet 300/8 \bullet 1.5 = 393.75\ V_{rms}$

This value will appear as a clipped waveform in the COMTRADE event file. Relay metering and protection will continue to work properly. Only the COMTRADE file is affected.

Note that the RCF is typically used on a per-phase basis to fine tune the relay measurement systems to small variations in secondary voltage from the voltage sensor. RCF correction values outside of the range of 0.800 to 1.200 are not typical. If the RCF does exceed these ranges on all three voltage phases, consider changing the PTR for the voltage input to compensate for high or low RCF values. If abnormally high RCF factors are present on only one or two voltage phase inputs, check the LEA sensor wiring and functionality as this may indicate a problem with the field device.

LEA ratio correction factor (RCF) settings are only available if the LEA option is supported by the relay part number.

Inverting Polarity of Current and Voltage Inputs

The relay can change the polarity of the mapped CT and PT inputs. This ability allows the user to change CT and PT polarity digitally to correct for incorrect wiring to the input on the back of a publisher or to change a zone of protection based on the subscribed to data. You can change the polarity on a per-terminal or per-phase basis, but you must practice extreme caution when using this function. The change of polarity applies directly to the mapped terminal and is carried throughout all calculations, metering, and protection logic.

The EINVPOL setting is always hidden on the front-panel HMI.

Table 5.1 Inverting Polarity Setting

Setting	Prompt	Range	Default Value
EINVPOL	Enable Invert Polarity (Off or combo of terminals)	OFF, Combo of S[p][a], T[p], U[p], W[p], X[p], Y[3][b], V[p] and Z[p]	OFF

[a] Where [p] = A, B, C. Entering a terminal without specifying a phase designation applies the setting to all phases of that terminal. For example, EINVPOL := SA,SB,X inverts the polarity of the A- and B-Phases for Terminal S and all phases for Terminal X.

[b] Where [3] = 1, 2, 3. For example, EINVPOL := Y1, Y3 inverts the polarity of the Y1 and Y3 terminals.

If redundant entries of terminals are used, such as W, WA or X, XC, the relay displays the following error message: `Redundant entries for terminal [m]`.

Inverse Polarity in Event Reports

In COMTRADE event reports, terminals that have EINVPOL enabled do not show the polarity as inverted. The COMTRADE must display the values as they are applied to the relay. This also ensures that when you use an event playback, the setting is applied to the signals coming into the relay and recreates the event properly.

Compressed event reports (CEV), show the polarity as inverted. The CEV displays the analogs as the relay uses them in processed logic; therefore, the inverted polarity is shown.

Voltage Source Selection

The SEL-487E has two sets of three-phase voltage inputs on Terminals V and Z. Group setting VREF*m* (*m* = S, T, U, W, X, Y) associates a voltage reference (V or Z) to each current terminal for applications that require both voltage and current measurements (metering, distance, directional, etc.). The Group setting SELOGIC control equation ALTV*m* allows immediate switching to an alternative voltage source. Reasons for switching from one three-phase voltage to another may be for loss-of-potential or bus switching rearrangement. *Table 5.2* summarizes how VREF*m* and ALTV*m* determine a voltage reference for each current terminal.

Table 5.2 Voltage Source Selection Setting Combinations[a]

VREFm (Voltage Reference)	ALTVm (Alternate Voltage Source)	Voltage Source
V	0	VAV, VBV, VCV
V	1	VAZ, VBZ, VCZ
Z	0	VAZ, VBZ, VCZ
Z	1	VAV, VBV, VCV
OFF	NA	NA

[a] m = S, T, U, W, X, Y

Voltage source selection for frequency estimation can be set independently from the voltage source selection used for each current terminal. See *Frequency Estimation on page 5.154* for more information.

Differential Elements (87)

Differential Protection Overview

The SEL-487E provides two zones of differential protection. Zone 1 differential elements have additional features included to accommodate transformer differential protection, whereas Zone 2 differential elements are designed for simpler applications, such as busbar protection. Zone 1 differential elements are found in all SEL-487E models, and Zone 2 elements are available as an ordering option.

Differential-Element Speed and Security Features

Each zone supports flexible compensation for every terminal, simplifying complex transformer settings and allowing shared CTs between transformer and bus differential zones. The differential elements use an adaptive-slope percentage differential characteristic. The advanced adaptive-slope algorithm includes filtered differential elements, as well as instantaneous differential elements, allowing the SEL-487E to operate substantially faster than relays that use legacy differential characteristics. An external/internal fault detection supervision adds security during external faults with CT saturation. Features found in both Zone 1 and Zone 2 differential elements include:

- Compensation calculations
- Adaptive-slope phase percentage-restrained characteristic
- Internal external fault detection logic

The SEL-487E offers three different types of Zone 1 differential protection elements:

- Phase percentage-restrained differential elements (87R)
- A negative-sequence percentage-restrained differential element (87Q)
- Unrestrained phase differential elements (87U)

When configured for transformer protection, Zone 1 differential elements can be secured using the following features:

- Harmonic- and waveshape-based inrush detection
- Fifth-harmonic overexcitation detection

Zone 2 provides an adaptive-slope phase percentage-restrained differential element for applications that do not have an in-zone transformer, such as bus bar protection.

Compensation Calculations

The filtered and unfiltered (raw) currents for each terminal current are normalized to per unit, compensating for both magnitude and angle differences. Only the current inputs from those terminals that you select via Group setting E87T*m* or E87T*m*2 are included within the Zone 1 or Zone 2 differential elements, respectively. These settings are useful when removing or adding terminals into the protection zone following changes in bus configuration.

The TAP values are used to convert the terminal currents bounding the differential zones to a common per-unit system. When a transformer is included within the Zone 1 differential, the relay uses the transformer MVA, line-to-line voltages, and CT information you have entered and calculates the TAP values automatically. You can also configure the TAP value manually for Zone 1. The TAP value for the Zone 2 differential is calculated automatically based on the CT ratio for each terminal. See *Equation 5.8* and *Equation 5.21* for considerations when determining an appropriate TAP value.

After dividing each input current with the applicable TAP value, the relay compensates each current channel to normalize the phase angle differences between the terminals. The Group setting T*m*CTC uses 3x3 matrix compensation for Zone 1 differential elements to provide round-the-clock angle compensation for each current input. In this way, you can connect all CTs in wye regardless of

transformer winding configurations. Zone 2 uses Group setting T*m*CTP2 to specify the CT polarity for each current input. Current inputs with a negative CT polarity are rotated 180 degrees, as shown in *Figure 5.13*.

The Zone 1 filtered differential elements (i.e., the phase-restrained differential elements, the negative-sequence differential element, and the filtered unrestrained differential elements) use filtered quantities, as indicated in *Figure 5.12*. Zone 1 internal and external fault detection logic, waveshape-based logic, and the raw unrestrained differential elements use unfiltered analog quantities. Zone 2 differential elements have a similar analog quantity chain as Zone 1 for both the filtered and unfiltered elements, as shown in *Figure 5.13*.

Figure 5.12 Zone 1 Terminal Selection and Matrix Compensation

Figure 5.13 Zone 2 Terminal Selection and Polarity Compensation

Adaptive-Slope Phase Percentage-Restrained Characteristic

To provide increased security and sensitivity for the phase percentage-restrained differential elements, the relay employs an adaptive-slope characteristic that uses a more secure slope when there is danger of CT saturation during an external fault and a more sensitive slope for all other operating conditions. The relay forms filtered and unfiltered phase-restrained differential elements by using operate and restraint quantities from the appropriate analog quantities (see *Figure 5.12* and *Figure 5.13*). *Figure 5.14* illustrates the characteristic of the A-Phase filtered differential element as a straight line through the origin defined by *Equation 5.2*. The Zone 2 filtered differential element uses the same operating characteristic as Zone 1.

NOTE: Factor k is 0.5 in the SEL-387 and SEL-587 relays. Take this into consideration when calculating the slope setting. Also see SLP1, SLP2 (Restraint Slope Percentage) on page 5.37.

$$\text{IOPA} = k \bullet \text{SLP}c \bullet \text{IRTA}$$

Equation 5.2

where:

IOPA = filtered operating current

IRTA = filtered restraint current

c = 1 or 2 (1 if in normal mode, 2 if in high-security mode)

SLP1 = initial slope, beginning at origin

SLP2 = second slope, also starts at the origin

k = 1

Figure 5.14 Filtered Differential-Element Characteristic

NOTE: The relay does not block for external faults but changes to high security.

For operating quantities (IOPA) exceeding the threshold level O87P and falling in the operate region of *Figure 5.14*, the filtered differential element issues an output. There are two slope settings: Slope 1 (SLP1) and Slope 2 (SLP2). Slope 1 is effective during normal operating conditions, and Slope 2 is effective when the fault detection logic detects an external fault condition.

Internal and External Fault Detection Logic

Internal Fault Detection Logic

Figure 5.15 shows the Zone 1 logic that uses unfiltered (raw) quantities to detect an A-Phase internal fault (IFTLA) and external fault (CONA). Other phases and Zone 2 elements have similar logic. Functions unique to Zone 1, such as harmonic blocking, are indicated accordingly. Elements in the fault detection logic use unfiltered, compensated per-unit currents to calculate a raw restraint quantity, IRTRA, and a raw operating quantity, IOPRA, according to *Equation 5.3* and *Equation 5.4*.

$$\text{IOPRA} = |\Sigma \text{IA}m\text{MC}|$$

Equation 5.3

$$\text{IRTRA} = \Sigma|\text{IA}m\text{MC}|$$

Equation 5.4

where:

IAmMC = A-Phase unfiltered, compensated per-unit current (m = S, T, U, W, X, Y)

Figure 5.15 A-Phase Internal and External Fault Detection Logic and Harmonic Filtering

The internal and external fault detection logic uses the principle that operating and restraint currents increase simultaneously for internal faults, but that only the restraint current increases for external faults (if there is no CT saturation). By comparing the change in operating current (ΔIOPRAP) to the change in restraint current (ΔIRTRAP), the relay distinguishes between external and internal faults. In particular, if ΔIRTRAP asserts, and ΔIOPRAP remains deasserted for 0.1 cycles, then the relay declares the fault as external and asserts Relay Word bit CONA. Conversely, if both ΔIRTRAP and ΔIOPRAP assert, the relay does not assert CONA, ruling out an external fault condition.

Two further measurements (moving window fault detection and instantaneous fault detection) ensure that the relay identifies an internal fault correctly. The output from the unfiltered phase percentage-restrained differential element forms the input into both fault detection modules. The raw operate quantity, IOPRA, must exceed the O87P setting before these modules are processed.

The moving window fault detection logic declares an internal fault when differential current still exists on a consecutive measurement one-half cycle after the unfiltered phase percentage-restrained differential element asserts. Relay Word bit WFLTA asserts when the moving window fault detector logic declares an internal fault.

As shown in *Figure 5.29*, IFLTA contributes to the A-Phase percentage-restrained differential elements (87AHB, 87AHR). Note that even though the expected behavior of IFLTA causes the 87AHB and 87AHR Relay Word bits to deassert momentarily, it does not affect the protection speed. Once a Relay Word bit assigned to the trip equation asserts, the trip result is sealed in and does not reset. The two-cycle window is sufficient time for the relay to detect the fault, issue a trip, and seal in the trip signal. To prevent a chattering Relay Word bit from filling up the SER, set Enable SER Delete (ESERDEL) to **Y** for automatic removal of chattering SER points. For more information on ESERDEL, see *Setting SER Points on page 9.31 in the SEL-400 Series Relays Instruction Manual*. Alternatively, include the 87AHB, 87BHB, 87CHB, 87AHR, 87BHR, and 87CHR Relay Word bits in the event report digitals list and omit them from the SER.

If surge (lightning) arresters are installed within the differential zone, a path to ground exists when these devices conduct, resulting in operating current in the differential elements. The instantaneous fault detection logic qualifies the operating current for a power system quarter cycle to differentiate between operating current resulting from surge arrester conduction and operating current because of internal faults. Relay Word bit GFLTA asserts when the instantaneous fault detection logic detects an internal fault.

External Fault Detection Logic

Relay Word bit CONA changes the operating mode of the relay to high-security mode, primarily to avoid misoperation resulting from CT saturation for external faults. High security causes the following in the relay:

- Slope *k* selection changes from Slope 1 to Slope 2 for both the unfiltered and filtered phase percentage-restrained differential elements (see *Figure 5.15* and *Figure 5.29*).
- Delay time of the adaptive security timer increases (see *Figure 5.29*).

While the high-security mode provides satisfactory security for through faults, this mode can cause the relay to operate slower for evolving faults (where the fault starts as an external fault and then develops into an internal fault).

To avoid this delayed tripping, the relay uses two timers (minimum external fault reset timer and external fault reset timer) and CT unsaturate logic to switch the relay back to normal operating mode as soon as possible. The minimum external fault reset timer resets after three cycles, ensuring that the relay stays in the high-security mode for at least three cycles after it detects an external fault. The external fault reset timer resets after 60 cycles, or when the Reset CONA signal asserts. Finally, when there is no danger of CT saturation following the external fault, Relay Word bit CTUA asserts and resets the internal fault detector logic to normal mode (see *Figure 5.15*), which resets the slope latch and causes the unfiltered phase-restrained differential elements to use the Slope 1 value. However, the filtered phase-restrained differential element resets the slope latch and returns to using the Slope 1 value only when CONA resets (see *Figure 5.29*).

Zone 1 Differential Elements (87T)

Zone 1 differential elements provide overall transformer or bus protection for all fault types, fault levels, and operating conditions. The SEL-487E offers three different types of Zone 1 differential protection elements:

- Phase percentage-restrained differential elements (87R)
- A negative-sequence percentage-restrained differential element (87Q)
- Unrestrained phase differential elements (87U)

The negative-sequence differential element provides sensitive protection for low-magnitude faults, such as turn-to-turn faults. The sensitivity of the phase-percentage differential element is tied to the transformer loading, making turn-to-turn faults particularly difficult to detect. The negative-sequence differential element is unaffected by load and, therefore, very sensitive to the small unbalance caused by turn-to-turn faults regardless of operating conditions. The negative-sequence differential element requires appropriate blocking during energization or overexcitation conditions. The relay provides the option to block the element through the use of either harmonic- or waveshape-based inrush detection methods and provides the option to cancel the inrush blocking action upon assertion of the waveshape-based unblocking logic.

The unrestrained differential elements are intended to operate very quickly for faults with high differential current, occurring above the worst-case inrush current magnitude. The SEL-487E provides three different types of unrestrained differential elements. The first is a filtered unrestrained element that operates on filtered differential currents. The second is a raw unrestrained element that operates on raw (unfiltered) differential current and can operate substantially faster than the filtered unrestrained element. The third is a waveshape-based bipolar differential overcurrent element that is significantly more sensitive than the other two elements because it differentiates between inrush current and internal fault current. The SEL-487E allows you to enable any combination of these three unrestrained differential elements.

To add security during transformer inrush conditions, the relay provides harmonic blocking, harmonic restraint, or both. Second and fourth harmonics provide security during energization, and fifth-harmonic blocking provides security for overexcitation conditions. In the event of low harmonic content during energization, which can occur with new transformer core materials, the waveshape-based inrush detection logic provides security during energization where the traditional harmonic-blocking and restraint methods may fail. An optional unblocking logic, which uses a waveshape-based bipolar differential overcurrent element, quickly and securely detects internal faults and cancels the inrush blocking action, improving element operating times, especially for faults occurring during energization.

Inrush and Overexcitation Blocking Logic

Harmonic Logic

NOTE: For more information regarding inrush currents, refer to the technical paper, Transformer Modeling as Applied to Differential Protection by Stanley E. Zocholl, Armando Guzmán, and Daqing Hou (available at selinc.com).

The second- and fourth-harmonic content present in the differential current is used to block the differential (harmonic-blocking method) or to boost the restraining signal (harmonic-restraint method) during inrush conditions to prevent misoperation, and the fifth-harmonic differential current is used to prevent misoperation during transformer overexcitation. *Figure 5.15* shows the filter function block where the relay calculates the various harmonic magnitudes of the differential current.

Figure 5.16 illustrates the logic for the A-Phase harmonic-based inrush and overexcitation functions.

where:
kh2 = the second-harmonic setting 100/PCT2
kh4 = the fourth-harmonic setting 100/PCT4
kh5 = the fifth-harmonic setting 100/PCT5

Figure 5.16 A-Phase Harmonic Logic

In *Figure 5.16*, the relay scales the magnitudes of the harmonic quantities (IAM2, IAM4, and IAM5) by the per-unit value of their respective harmonic percentage settings (PCT2, PCT4, and PCT5). The scaled second- and fourth-harmonic magnitudes (IAMkh2 and IAMkh4, respectively) are used by the harmonic-restrained differential element (see *Equation 5.8* and *Figure 5.29*). For the harmonic-blocking functions, the relay compares each scaled harmonic magnitude against the fundamental operate current, IOPA (*Figure 5.29*), and asserts the appropriate binary signals (second-, fourth-, or fifth-harmonic pickup) when the harmonic content exceeds the settings.

When either (or both) the A-Phase second- or fourth-harmonic content exceeds the setting, Relay Word bit 87ABK2 asserts. The harmonic-blocked differential elements and the negative-sequence differential element operate in a cross-blocking mode and, therefore, use output 87XBK2, which is the OR combination of the second- or fourth-harmonic blocking bits from all three phases (see *Figure 5.29* and *Figure 5.33*). When the A-Phase fifth-harmonic content exceeds the fundamental operate current, Relay Word bit 87ABK5 asserts and prevents the A-Phase percentage-restrained elements from misoperating during an overexcitation condition (see *Figure 5.29*). The fifth-harmonic cross-blocking Relay Word bit, 87XBK5, is used to properly block the negative-sequence differential element during overexcitation (see *Figure 5.33*).

An overexcitation alarm function compares the fifth harmonic against a fifth-harmonic alarm threshold (TH5P) and uses an adjustable timer (TH5D). This threshold and timer may be useful for transformer applications in or near generating stations.

The SEL-487E CEV reports include I*p*H2, I*p*H4 and I*p*H5 (*p* = A, B, C) harmonic analog quantities. These quantities are the percentage of operating current for the second, fourth, and fifth harmonic. They provide a convenient way of comparing harmonic operate currents to their harmonic thresholds (PCT2, PCT4, and PCT5).

$$I_pH2 = (I_pM2 / IOP_p) \cdot 100$$

$$I_pH4 = (I_pM4 / IOP_p) \cdot 100$$

$$I_pH5 = (I_pM5 / IOP_p) \cdot 100$$

Waveshape-Based Inrush Detection Logic

Although inrush currents are typically rich in even-numbered harmonics (the second harmonic in particular) some power transformers, especially new designs with the core material improved for lower losses, produce low levels of these harmonics. These low harmonic levels can challenge the effectiveness of traditional harmonic-blocking and harmonic-restraint schemes.

The waveshape-based inrush detection element addresses inrush conditions that contain low second and fourth-harmonic content by using a dwell-time algorithm. The magnetizing currents of a three-phase, three-legged transformer exhibit intervals where the currents are both small and flat (see *Figure 5.17*), called dwell-times, which coincide with one another in each phase. The dwell-time algorithm uses this small and flat interval to detect transformer inrush and supervise the percentage-restrained differential elements. For three-phase transformers built from single-phase units or four- or five-legged cores, the dwell times still exist in each phase but do not necessarily coincide. Thus the dwell-time algorithm requires information about the transformer construction, established via the 87CORE setting before it can activate the appropriate logic.

Figure 5.17 Dwell-Time Intervals in the Inrush Currents

Dwell-Time Algorithm for Three-Legged, Three-Phase Transformers

Setting 87CORE = T enables the dwell-time algorithm for three-legged, three-phase transformers.

The dwell-time logic first performs a supervisory check whereby it confirms that there is sufficient differential current to activate the dwell-time algorithm. If either the filtered A-Phase operate current or the negative-sequence operate current is above half of their respective pickup thresholds, 87T_MA asserts to indicate sufficient operate current magnitude, as shown in *Figure 5.18*. If any phase has sufficient operate current, the three-legged operate current magnitude check, 87T_M, asserts. Assertion of 87T_M is a required condition for operation of the three-legged dwell-time logic, as shown in *Figure 5.19*.

Figure 5.18 Sufficient Operate Current Check

Figure 5.19 Waveshape Dwell-Time Inrush Detection Logic for Three-Legged, Three-Phase Transformers

The three-legged dwell-time algorithm executes on a sample-by-sample basis and works as follows:

- The relay adds the absolute values of the raw (unfiltered) differential current in all three phases (IOPRAR, IOPRBR, and IOPRCR) (see *Figure 5.15*) to form a portion of the dwell-time identifier signal. During inrush conditions, this signal is low for the duration of the dwell-time periods because all three differential currents exhibit their dwell periods at the same time.
- To provide resiliency against gradual CT saturation that may occur during inrush, the relay forms a second measure of the dwell-time pattern by summing the absolute values of the derivatives of the raw differential currents. Because all three inrush currents are coincidentally flat during the dwell-time periods, this signal is low during the dwell-time periods of the inrush currents.
- The two portions of the dwell-time identifier signal are multiplied by a scaling factor and added together. The resulting signal is low during the dwell-time periods, high during internal faults, and resilient to gradual CT saturation during inrush.
- The relay creates an adaptive threshold by taking a fraction of the three-phase sum of the filtered operating currents (IOPA, IOPB, and IOPC) (see *Figure 5.29*). A comparator checks if the level of the dwell-time identifier signal is below the adaptive threshold for the duration of the pickup time (PU). If so, 87T_S asserts, indicating that the relay has identified an inrush condition through the use of waveshape recognition. The dropout time (DO) is set for one power system cycle and is necessary to keep 87T_S continually asserted until the dwell-time of the next subsequent cycle, maintaining reliable inrush detection.

Dwell-Time Algorithm for Single-Phase Units, or Four- or Five-Legged Three-Phase Transformers

When a three-phase transformer is constructed with single-phase transformers or with a four- or five-legged core, the individual phase dwell-time intervals are not aligned in time. In a transformer built with single-phase units or with a four- or five-legged core, the flux in each core can be independent, meaning the three cores go in and out of saturation independently. Therefore, one instance of the dwell-time algorithm is required for each phase of the transformer.

Setting 87CORE = S segregates the inrush detection dwell-time logic into individual phases, such as in the A-Phase logic shown in *Figure 5.20*. The logic is identical to the three-legged core logic shown in *Figure 5.19*, except that it only uses a single-phase current rather than a three-phase sum.

Figure 5.20 Waveshape Dwell-Time Inrush Detection Logic for A-Phase

NOTE: For a more detailed discussion and analysis of the waveshape inrush detection method, refer to the technical paper, Low Second-Harmonic Content in Transformer Inrush Currents – Analysis and Practical Solutions for Protection Security by Steven Hodder, Bogdan Kasztenny, Normann Fischer, and Yu Xia (available at selinc.com).

Figure 5.21 shows the waveshape-based inrush-blocking logic used by the differential elements. If the logic identifies magnetizing inrush current through use of waveshape recognition, the 87WB Relay Word bit asserts. The logic uses phase-specific Relay Word bits (87WBA, 87WBB, and 87WBC) to block the percentage-restrained differential elements, as shown in *Figure 5.29*. The negative-sequence differential element is blocked by the 87WB Relay Word bit, as shown in *Figure 5.33*.

Figure 5.21 Waveshape Blocking Logic

Waveshape-Based Bipolar Unblocking Logic

A waveshape-based bipolar differential overcurrent element allows for improvements in the operation of the restrained and unrestrained differential elements. *Figure 5.22* shows the differential currents for an internal transformer fault that develops during transformer energization. The first part of the figure shows the unipolar characteristic of the differential currents during an inrush condition. When the internal fault occurs on one phase, the resulting waveform has a bipolar characteristic as shown in blue.

Figure 5.22 Differential Currents for an Internal Fault During Inrush Conditions

Figure 5.23 shows the differential current of the faulted phase of *Figure 5.22* superimposed on two thresholds. Note that during inrush conditions (the first 72 milliseconds), the current is negative and it repeatedly crosses the negative threshold (the dashed blue line in *Figure 5.23*). The current during this time does not cross the symmetrically placed positive threshold (the dashed red line). When the internal fault occurs, the current crosses the negative threshold and then crosses the positive threshold shortly afterwards. Using this information, we create a pair of bipolar differential overcurrent elements: a low-set element that we can use to unblock the inrush-blocking functions of the relay and a high-set element that we can use for unrestrained differential protection. Because the elements work on a bipolar principle, we set the thresholds relatively sensitively and still ensure security during inrush conditions.

Figure 5.23 Fault Current During Energization (Black) Compared With Positive (Red) and Negative (Blue) Thresholds

As shown in *Figure 5.24*, the A-Phase, low-set bipolar differential overcurrent element compares the unfiltered (raw) operate current, IOPRAR (see *Figure 5.15*), against positive (+L) and negative (–L) thresholds. The B- and C-Phase logic is similar. If the current exceeds the positive threshold for a short duration (PKPBP timer), a window equal to the DPOBP timer opens to wait for the current to decrease below the negative threshold. If it does, the relay declares the current to be symmetrical and not an inrush current. Mirrored logic covers the negative polarity. The magenta trace in *Figure 5.23* is the output of the bipolar low-set overcurrent element, shown in *Figure 5.24* as 87T_B1A.

Figure 5.24 A-Phase Bipolar Low-Set Signature Detection Logic

Prior to using the low-set bipolar overcurrent element as an unblocking function, the relay performs additional security checks, as shown in *Figure 5.25*, to ensure that the bipolar logic is asserting properly. The first is a sudden change detection logic, which confirms that the bipolar nature of the differential current is caused by an internal short circuit rather than by gradual CT saturation occurring during inrush conditions. The sudden change detection logic monitors the absolute value of the per-cycle difference of the operate current and checks that this difference is significant (above the +L threshold). The output of the comparator passes through a pickup timer (PKPS) for security, and a dropout timer (DPOS) ensures that the sudden change detection logic coordinates with the input from the unsupervised bipolar low-set logic, 87T_B1A.

To distinguish between a sudden change in current due to transformer energization or an internal short circuit, a second security check is performed using filtered restraint current. An internal short circuit during normal operating conditions has a measurable amount of restraint current prior to the fault,

whereas there is zero restraint current prior to energization. The pickup timer (PKPR) and dropout timer (DPOR) ensure sufficient time has passed since energization so that a sudden change in current can be properly identified.

The third security check (shown in *Figure 5.25*) ensures that the bipolar logic does not assert because of CT saturation when an external fault condition is detected (CONA must be deasserted, see *Figure 5.15*). However, if the CT is deemed to be in an unsaturated state following the external fault, as indicated by CTUA asserting, the bipolar logic can assert. When the bipolar low-set logic, 87T_B1A, asserts, along with the security checks, the bipolar low-set element, 87BPLA, asserts. The B- and C-Phase supervised low-set logic is similar to the A-Phase logic.

Figure 5.25 A-Phase Bipolar Low-Set Logic

The unblocking logic makes direct use of the bipolar low-set element, as shown in *Figure 5.26*. When you enable the unblocking logic via the E87UNB setting, the unblocking Relay Word bit, 87UNBLA, asserts for one cycle following the assertion of the bipolar low-set element, 87BPLA. The B- and C-Phase unblocking logic is similar to the A-Phase logic.

Figure 5.26 A-Phase Unblocking Logic

When the unblocking logic asserts, the following changes occur to the phase-restrained differential elements, as shown in *Figure 5.29*:

- The second- and fourth-harmonic cross blocking, 87XBK2, and waveshape-based inrush blocking, 87WBA, are canceled in the harmonic-blocked differential element.
- The waveshape-based inrush blocking, 87WBA, is canceled in the harmonic-restrained differential element.
- The second- and fourth-harmonic magnitudes are removed from the restraint current, IRTHRA, of the harmonic-restrained differential element.
- The fifth-harmonic integrity timer used by the phase-restrained elements is bypassed (although direct assertions of the 87ABK5 Relay Word bit still block the elements).
- The delay time of the adaptive security timer decreases.

The following changes are made to the negative-sequence differential element when the unblocking logic asserts, as shown in *Figure 5.32* and *Figure 5.33*:

- The second- and fourth-harmonic cross blocking, 87XBK2, and waveshape-based inrush blocking, 87WB, are canceled.
- The negative-sequence differential element delay timer, 87QD, is bypassed.

A high-set version of the bipolar differential overcurrent element is available for use as an unrestrained differential element and is identical to the low-set version except that it uses a threshold that is a multiple of the low-set threshold, as shown in *Figure 5.27* and *Figure 5.28*.

Figure 5.27 A-Phase Bipolar High-Set Signature Detection Logic

Figure 5.28 A-Phase Bipolar High-Set Logic

As shown in *Figure 5.34*, unrestrained differential element can use the bipolar high-set element, 87BPHA, for unrestrained tripping.

Using Harmonic and Waveshape Logic in the Differential Elements

The enable settings options for the various percentage-restrained differential elements (E87HB, E87HR, and E87Q) allow for each element to provide inrush security by using only the harmonic-based method (setting option Y), by using either the harmonic- or waveshape-based blocking methods for the harmonic-blocked differential element and negative-sequence differential element (setting option E), or by adding waveshape-based blocking to the harmonic-restrained differential element (setting option W). As shown in *Figure 5.29* and *Figure 5.33*, the appropriate inrush-blocking methods are activated or deactivated depending on the enable settings option. Note that for the harmonic-restrained differential element, setting option **W** enables the waveshape-based blocking method (87WBA) but does not remove the harmonic boost to the restraining current from the scaled second- and fourth-harmonic magnitudes (IAMkh2 and IAMkh4, respectively). Consider using the **E** and **W** settings option to provide the benefit of both the harmonic- and waveshape-based inrush-blocking methods.

NOTE: Consider enabling all of the harmonic and waveshape functions through the **E** and **W** settings options for the settings E87HB, E87HR, and E87Q as well as setting E87UNBL = Y to gain the best security and speed performance from the differential elements.

The waveshape-based unblocking logic is separate from the inrush-blocking logic and is enabled in all the percentage-restrained differential elements (87HB, 87HR, and 87Q) when setting E87UNBL = Y (see *Waveshape-Based Bipolar Unblocking Logic on page 5.24*). Should the unblocking logic assert, indicating that the logic detected an internal fault, the relay cancels the inrush security checks and modifies the security timers in the differential elements (see

Figure 5.29, *Figure 5.32*, and *Figure 5.33*), allowing for improved element operating times. Consider enabling the unblocking logic to gain speed improvements for all internal fault types and conditions.

Phase Percentage-Restrained Differential Element (87R)

Because of differing harmonic philosophies, the SEL-487E includes harmonic-blocking and harmonic-restraint functions to avoid relay misoperation during inrush current conditions. The harmonic-blocking functions always operate in cross-blocking mode, whereby the relay blocks all phases when the harmonic magnitude of any phase exceeds the harmonic setting. By contrast, the harmonic-restraint functions always operate in independent blocking mode, i.e., there is no cross blocking between phases.

NOTE: The SEL-487E restraint quantity IRTp calculation differs from the SEL-587 and SEL-387 by a factor of 2.

NOTE: The 87R element currents are in per unit of the TAPm values (see Figure 5.12).

Figure 5.29 shows the Zone 1 A-Phase percentage-restrained differential element. Using the compensated output quantities from the digital band-pass filter (full-cycle cosine filter), the relay calculates an operating quantity, IOPA (*Equation 5.5*), and a restraint quantity, IRTA (*Equation 5.6*), both of which are used by the harmonic-blocked differential element and the harmonic-restrained differential element.

$$\mathrm{IOPA} = |\Sigma \mathrm{IA}m\mathrm{CFC}|$$

Equation 5.5

$$\mathrm{IRTA} = \Sigma|\mathrm{IA}m\mathrm{CFC}|$$

Equation 5.6

where:

IA*m*CFC = A-Phase filtered, compensated per-unit current (*m* = S, T, U, W, X, Y) (see *Figure 5.12*)

Figure 5.29 Zone 1 A-Phase Percentage-Restrained Differential Element

As shown in *Figure 5.29*, the harmonic-blocked and harmonic-restrained differential elements are run independently of one another. Enable whichever element is best suited for your application by using the E87HB (harmonic-blocked element) or E87HR (harmonic-restrained element) enable settings. Because the two elements are complimentary, consider enabling both elements to allow them to run in parallel. The harmonic-blocked element is generally faster, but because of cross blocking, it has reduced dependability when energizing a faulted transformer. The harmonic-restraint element is generally slower because of the additional restraint, but it has improved dependability when energizing a faulted transformer. Also, because the harmonics are summed, harmonic restraint is more secure during inrush conditions.

From *Figure 5.29*, the relay calculates the filtered operate (IOPA) and restraint (IRTA) quantities from the filtered, compensated terminal currents (see *Figure 5.12*). After selecting the appropriate slope (SLP2 if CONA is asserted or SLP1 if CONA is deasserted), the relay calculates the biased restraint current, IRTFKA, for use by the harmonic-blocked element and then adds the scaled second- and fourth-harmonic quantities (IAMkh2 and IAMkh4, respectively, see *Figure 5.16*) to IRTFKA to form IRTHRA for use by the harmonic-restrained element.

Both of the differential elements are supervised by the IO87PA Relay Word bit, which asserts when the fault detection logic detects an internal fault, IFLTA, (see *Figure 5.15*) and IOPA exceeds the O87P pickup value. The harmonic-blocked and harmonic-restrained differential elements each have a preliminary Relay Word bit (87HBPA and 87HRPA, respectively) that asserts when the minimum operate current check is satisfied (IO87PA is asserted) and the operate current is greater than the appropriate biased restraint current (indicating that the operating condition lies within the operate region of the percentage-restrained characteristic). You can use these 87HBPA and 87HRPA Relay Word bits for testing and troubleshooting purposes.

For the harmonic-blocked differential element, the remaining checks are tied to the AND gate that is controlling the 87AHB Relay Word bit, and they pertain to inrush and overexcitation security. The inrush security checks are enabled or disabled via the E87HB setting option. If you have selected harmonic-based inrush security by setting E87HB = Y or E, an assertion of the second- and fourth-harmonic cross-blocking logic, 87XBK2, (see *Figure 5.16*) blocks the differential element. If you have also enabled waveshape-based inrush security by setting E87HB = E, an assertion of the waveshape inrush-blocking logic, 87WBA, (see *Figure 5.21*) blocks the differential element. If you have enabled the unblocking logic and 87UNBLA asserts (see *Figure 5.26*), indicating detection of an internal fault, the relay cancels the inrush blocking of both the harmonic- and waveshape-based methods. If the fifth-harmonic overexcitation logic, 87ABK5, asserts (see *Figure 5.5*), the differential element will be blocked.

For the harmonic-restrained differential element, the relay makes similar inrush and overexcitation security checks prior to asserting the 87AHR Relay Word bit. If you have selected harmonic-based inrush security by setting E87HR = Y, the differential element is secured against inrush by the harmonic-boosted restraint signal, IRTHRA. If you have selected waveshape-based inrush security by setting E87HR = W, an assertion of the waveshape inrush-blocking logic, 87WBA, blocks the differential element, and the element will also use the harmonic-boosted restraint current, IRTHRA, to provide additional inrush security. If you have enabled the unblocking logic and 87UNBLA asserts, indicating detection of an internal fault, the relay removes harmonic content from the IRTHRA signal and cancels the inrush blocking of the waveshape-based method. If the fifth-harmonic overexcitation logic, 87ABK5, asserts, the differential element will be blocked.

The harmonic integrity timers in *Figure 5.29* prevent differential element misoperation if the harmonic content momentarily drops below the harmonic threshold setting. If the timer input asserts continuously for at least 1.5 cycles, the relay activates the dropout timer and keeps the timer output asserted for an additional 1 cycle. However, this 1 cycle does not need to be continuous. For example, if 87XBK2 has been asserted for 1.5 cycles, drops out for 0.125 cycles, and then asserts again, the dropout timer value changes from 1 cycle to 0.875 cycles.

When either the harmonic-blocked (87AHB) or harmonic-restrained (87AHR) outputs asserts, the adaptive security timer is loaded with the pickup timer value t, which depends on the state of the 87UNBLA and CONA Relay Word bits at the moment the timer output asserts (P87A), as shown in *Figure 5.29*. When the adaptive security timer pickup time expires, the A-Phase restrained differential element, 87RA, asserts along with the overall phase-restrained differential element, 87R. The B- and C-Phase percentage-restrained differential element logic is similar to the A-Phase logic. The 87R Relay Word bit is an input to the overall transformer differential tripping logic, 87T, as shown in *Figure 5.36*.

Note that even if you have disabled one of the phase differential-element outputs (87AHB or 87AHR Relay Word bits) by setting E87HB = N or E87HR = N, the analog quantities and Relay Word bits for that differential element are still active, allowing you to analyze or evaluate the element performance in an event report or with the SER even though the element is not enabled for tripping.

Relay Word bit 87BK secures the differential element when DSS current data are lost (see *Differential Zone and Restricted Earth Fault Element Blocking Logic on page 5.6* for more details). The 87RA, 87RB, 87RC, and 87R elements are blocked if data are lost for any of the current terminals included in the differential zone. If data are lost for current terminals not included in the differential zone, the 87R element is unaffected. Note that harmonic-blocked outputs (87AHB, 87BHB, and 87CHB) and harmonic-restrained outputs (87AHR, 87BHR, and 87CHR) are not secure during current data loss, and should not be used directly in the trip equation. When current data are restored, the differential element remains blocked via 87BK for an additional 1.5 cycles to allow the full-cycle cosine filter to stabilize before resuming protection.

When analyzing relay performance associated with a fault or disturbance, it is important to check the analog channel status and terminal status Relay Word bits. If these Relay Word bits indicate that communications were compromised during the event, use caution when analyzing the behavior of the logical outputs processed prior to (87RA, 87RB, 87RC, and 87R). The final logical outputs will reliably maintain security during such events, but the intermediate Relay Word bits might not.

Setting Descriptions

E87 (Enable Differential-Element Protection Terminals)

The SEL-487E has five sets of three-phase current inputs, Terminals S–X. Terminal Y can be configured as a sixth three-phase input or as three single-phase inputs for REF applications. Terminals listed in the ECCTERM group setting can be used for three-phase applications. Depending on the application, you may not need all of these inputs for differential protection. All terminals not included in the differential element are available for other protection such as standalone overcurrent protection. The E87 setting specifies which of the terminals the relay is to include in the differential calculation.

E87Tm (Terminals Included in the 87 Element)

Use this SELOGIC control equation to specify operational conditions to include/exclude those terminals specified with the E87 setting in the differential calculations. For example, assume you have a three-winding autotransformer and the 22 kV tertiary delta of the autotransformer is a standby supply for a small 22 kV network. Further assume that the tertiary delta winding connects to the 22 kV busbar through a circuit breaker (CBD) that is normally open, and will only be closed under emergency conditions. You assign Terminal S (HV), Terminal T (LV), and Terminal U (tertiary delta) as the terminals for the differential element. Because the default settings are set to 1, Terminals S and T are already part of the differential element, i.e.:

E87TS = 1

E87TT = 1

Terminal U is only part of the differential element if CBD is closed. Wire a 52A contact to input IN201, and set the SELOGIC control equations for Terminal U as follows:

E87TU = IN201

With this setting, Terminal U is part of the differential element only when CBD is closed.

ICOM (Internal CT Connection Compensation)

This Yes/No setting defines whether the input currents need any correction, either to accommodate phase shifts in the transformer or CTs or to remove zero-sequence components from the secondary currents. If this setting is Yes (Y), the relay permits you (see *TmCTC, TmANG, TmZSR (Internal CT Connection Compensation) on page 5.32*) to define the amount of shift needed to properly align the secondary currents for the differential calculation.

TmCTC, TmANG, TmZSR (Internal CT Connection Compensation)

These settings define the amount of compensation the relay applies to each set of winding currents to properly account for phase shifts in transformer winding connections and CT connections. For example, this correction is needed if both wye and delta power transformer windings are present, but all of the CTs are connected in wye. The effect of the compensation is to create phase shift and to remove zero-sequence current components.

The general expression for current compensation is as follows:

$$\begin{bmatrix} \mathrm{IA}m\mathrm{CFC} \\ \mathrm{IB}m\mathrm{CFC} \\ \mathrm{IC}m\mathrm{CFC} \end{bmatrix} = \begin{bmatrix} \mathrm{X}\ \mathrm{X}\ \mathrm{X} \\ \mathrm{X}\ \mathrm{X}\ \mathrm{X} \\ \mathrm{X}\ \mathrm{X}\ \mathrm{X} \end{bmatrix} \bullet \begin{bmatrix} \mathrm{IA}m\mathrm{CF} \\ \mathrm{IB}m\mathrm{CF} \\ \mathrm{IC}m\mathrm{CF} \end{bmatrix}$$

where:

IA*m*CF, etc. = the three-phase currents entering Terminal *m* of the relay

IA*m*CFC, etc. = the corresponding phase currents after compensation

$$\begin{bmatrix} \mathrm{X}\ \mathrm{X}\ \mathrm{X} \\ \mathrm{X}\ \mathrm{X}\ \mathrm{X} \\ \mathrm{X}\ \mathrm{X}\ \mathrm{X} \end{bmatrix} = [\mathrm{CTC}(m)]$$

= a three-by-three compensation matrix (m = 0, 1, 2, …, 11, 12)

Setting T*m*CTC specifies which compensation matrix the differential element is to use. The traditional setting values are 0–12. These values physically represent the number of increments of 30 degrees that a *balanced set of currents with ABC phase rotation* will be rotated in a *counterclockwise* direction when multiplied by Matrix CTC(*m*). For example, setting TSCTC = 1 rotates the Terminal S set of currents counterclockwise by 30 degrees. If a *balanced set of currents with ACB phase rotation* undergoes the same exercise, the rotations by the CTC(*m*) matrices are in the clockwise direction.

The 0 setting value creates no changes at all in the currents but multiplies them by an identity matrix. Thus, for T*m*CTC = 0, we obtain the following:

$$\mathrm{CTC}(0) = \begin{bmatrix} 1 & 0 & 0 \\ 0 & 1 & 0 \\ 0 & 0 & 1 \end{bmatrix}$$

that is,

IA*m*CFC = IA*m*CF
IB*m*CFC = IB*m*CF
IC*m*CFC = IC*m*CF

Assuming ABC phase rotation, the CTC(1) setting performs a 30-degree compensation in the counterclockwise direction, as would a delta CT connection of type DAB (Dy1). The name for this connection comes from the fact that the polarity end of the A-Phase CT connects to the nonpolarity end of the B-Phase CT, and so on, in forming the delta. Therefore, the DAB (Dy1) connection results from the following relationships:

$$\mathrm{IA}m\mathrm{CFC} = \frac{(\mathrm{IA}m\mathrm{CF} - \mathrm{IB}m\mathrm{CF})}{\sqrt{3}}$$

$$\mathrm{IB}m\mathrm{CFC} = \frac{(\mathrm{IB}m\mathrm{CF} - \mathrm{IC}m\mathrm{CF})}{\sqrt{3}}$$

$$\mathrm{IC}m\mathrm{CFC} = \frac{(\mathrm{IC}m\mathrm{CF} - \mathrm{IA}m\mathrm{CF})}{\sqrt{3}}$$

Setting T*m*CTC = 1 realizes the above-mentioned relationships, and the relay uses the following CTC(1) matrix to compensate the currents:

$$[\mathrm{CTC}(1)] = \frac{1}{\sqrt{3}} \bullet \begin{bmatrix} 1 & -1 & 0 \\ 0 & 1 & -1 \\ -1 & 0 & 1 \end{bmatrix}$$

Similarly, assuming ABC phase rotation, a setting of T*m*CTC = 11 performs a 330-degree compensation (11 • 30 degrees) in the counterclockwise direction, or a 30-degree compensation in the clockwise direction, as would a delta CT connection of type DAC (Dy11). The name for this connection comes from the fact that the polarity end of the A-Phase CT connects to the nonpolarity end of the C-phase CT, and so on, in forming the delta. Thus, for T*m*CTC = 11, the relay uses the following CTC(11) matrix:

$$[\mathrm{CTC}(11)] = \frac{1}{\sqrt{3}} \bullet \begin{bmatrix} 1 & 0 & -1 \\ -1 & 1 & 0 \\ 0 & -1 & 1 \end{bmatrix}$$

that is,

$$\mathrm{IA}m\mathrm{CFC} = \frac{(\mathrm{IA}m\mathrm{CF} - \mathrm{IC}m\mathrm{CF})}{\sqrt{3}}$$

$$\mathrm{IB}m\mathrm{CFC} = \frac{(\mathrm{IB}m\mathrm{CF} - \mathrm{IA}m\mathrm{CF})}{\sqrt{3}}$$

$$\mathrm{IC}m\mathrm{CFC} = \frac{(\mathrm{IC}m\mathrm{CF} - \mathrm{IB}m\mathrm{CF})}{\sqrt{3}}$$

The compensation matrix CTC(12) is similar to CTC(0), in that it produces no phase shift (or, more correctly, 360 degrees of shift) in a balanced set of phasors. The difference between these two matrices is that CTC(12) removes the zero-sequence components from the winding currents while CTC(0) retains the zero-sequence components. All other even matrices and matrix CTC(13) allow the user to retain or remove zero-sequence components, depending on the T*m*ZSR user setting, as shown in *Table 5.3*.

$$[\mathrm{CTC}(12)] = \frac{1}{3} \bullet \begin{bmatrix} 2 & -1 & -1 \\ -1 & 2 & -1 \\ -1 & -1 & 2 \end{bmatrix}$$

that is,

$$\mathrm{IA}m\mathrm{CFC} = \frac{(2 \bullet \mathrm{IA}m\mathrm{CF} - \mathrm{IB}m\mathrm{CF} - \mathrm{IC}m\mathrm{CF})}{3}$$

$$\mathrm{IB}m\mathrm{CFC} = \frac{(-\mathrm{IA}m\mathrm{CF} + 2 \bullet \mathrm{IB}m\mathrm{CF} - \mathrm{IC}m\mathrm{CF})}{3}$$

$$\mathrm{IC}m\mathrm{CFC} = \frac{(-\mathrm{IA}m\mathrm{CF} - \mathrm{IB}m\mathrm{CF} + 2 \bullet \mathrm{IC}m\mathrm{CF})}{3}$$

The effect of each compensation on balanced three-phase currents is to rotate the currents *m* • 30 degrees without a magnitude change. *Table 5.3* shows the complete list of compensation matrices.

Table 5.3 Complete List of Compensation Matrices (Sheet 1 of 2)

TmCTC	Degrees Compensated		TmZSR = N	TmZSR = Y
0	ABC, 0*30° cw	0°	$\begin{bmatrix} 1 & 0 & 0 \\ 0 & 1 & 0 \\ 0 & 0 & 1 \end{bmatrix}$	N/A
	ACB, 0*30° ccw	0°		
1	ABC, 1*30° cw	30°	N/A	$\frac{1}{\sqrt{3}} \begin{bmatrix} 1 & -1 & 0 \\ 0 & 1 & -1 \\ -1 & 0 & 1 \end{bmatrix}$
	ACB, 1*30° ccw	330°		
2	ABC, 2*30° cw	60°	$\begin{bmatrix} 0 & -1 & 0 \\ 0 & 0 & -1 \\ -1 & 0 & 0 \end{bmatrix}$	$\frac{1}{3} \begin{bmatrix} 1 & -2 & 1 \\ 1 & 1 & -2 \\ -2 & 1 & 1 \end{bmatrix}$
	ACB, 2*30° ccw	300°		
3	ABC, 3*30° cw	90°	N/A	$\frac{1}{\sqrt{3}} \begin{bmatrix} 0 & -1 & 1 \\ 1 & 0 & -1 \\ -1 & 1 & 0 \end{bmatrix}$
	ACB, 3*30° ccw	270°		
4	ABC, 4*30° cw	120°	$\begin{bmatrix} 0 & 0 & 1 \\ 1 & 0 & 0 \\ 0 & 1 & 0 \end{bmatrix}$	$\frac{1}{3} \begin{bmatrix} -1 & -1 & 2 \\ 2 & -1 & -1 \\ -1 & 2 & -1 \end{bmatrix}$
	ACB, 4*30° ccw	240°		
5	ABC, 5*30° cw	150°	N/A	$\frac{1}{\sqrt{3}} \begin{bmatrix} -1 & 0 & 1 \\ 1 & -1 & 0 \\ 0 & 1 & -1 \end{bmatrix}$
	ACB, 5*30° ccw	210°		

Table 5.3 Complete List of Compensation Matrices (Sheet 2 of 2)

TmCTC	Degrees Compensated		TmZSR = N	TmZSR = Y
6	ABC, 6*30° cw	180°	$\begin{bmatrix} -1 & 0 & 0 \\ 0 & -1 & 0 \\ 0 & 0 & -1 \end{bmatrix}$	$\frac{1}{3}\begin{bmatrix} -2 & 1 & 1 \\ 1 & -2 & 1 \\ 1 & 1 & -2 \end{bmatrix}$
	ACB, 6*30° ccw	180°		
7	ABC, 7*30° cw	210°	N/A	$\frac{1}{\sqrt{3}}\begin{bmatrix} -1 & 1 & 0 \\ 0 & -1 & 1 \\ 1 & 0 & -1 \end{bmatrix}$
	ACB, 7*30° ccw	150°		
8	ABC, 8*30° cw	240°	$\begin{bmatrix} 0 & 1 & 0 \\ 0 & 0 & 1 \\ 1 & 0 & 0 \end{bmatrix}$	$\frac{1}{3}\begin{bmatrix} -1 & 2 & -1 \\ -1 & -1 & 2 \\ 2 & -1 & -1 \end{bmatrix}$
	ACB, 8*30° ccw	120°		
9	ABC, 9*30° cw	270°	N/A	$\frac{1}{\sqrt{3}}\begin{bmatrix} 0 & 1 & -1 \\ -1 & 0 & 1 \\ 1 & -1 & 0 \end{bmatrix}$
	ACB, 9*30° ccw	90°		
10	ABC, 10*30° cw	300°	$\begin{bmatrix} 0 & 0 & -1 \\ -1 & 0 & 0 \\ 0 & -1 & 0 \end{bmatrix}$	$\frac{1}{3}\begin{bmatrix} 1 & 1 & -2 \\ -2 & 1 & 1 \\ 1 & -2 & 1 \end{bmatrix}$
	ACB, 10*30° ccw	60°		
11	ABC, 11*30° cw	330°	N/A	$\frac{1}{\sqrt{3}}\begin{bmatrix} 1 & 0 & -1 \\ -1 & 1 & 0 \\ 0 & -1 & 1 \end{bmatrix}$
	ACB, 11*30° ccw	30°		
12	ABC, 0*30° cw	0°	N/A	$\frac{1}{3}\begin{bmatrix} 2 & -1 & -1 \\ -1 & 2 & -1 \\ -1 & -1 & 2 \end{bmatrix}$
	ACB, 0*30° ccw	0°		

If T*m*CTC = 13 and T*m*ANG is equal to a multiple of 30 degrees, the resulting compensation matrix is identical to that shown in *Table 5.3*. The compensation matrix for CTC(13) is defined by *Equation 5.7* for all other angles. When T*m*ZSR = Y, *k* is set to 0 and *Equation 5.7* is used to remove the zero-sequence components, similar to Matrices 1, 11, and 12 that were previously discussed. When T*m*ZSR = N, *k* is set to 0.5, retaining the zero-sequence components.

$$[\mathrm{CT}(13)] = \frac{2}{3}\begin{pmatrix} k + \cos(\mathrm{T}m\mathrm{ANG}) & k + \cos(\mathrm{T}m\mathrm{ANG} + 120°) & k + \cos(\mathrm{T}m\mathrm{ANG} - 120°) \\ k + \cos(\mathrm{T}m\mathrm{ANG} - 120°) & k + \cos(\mathrm{T}m\mathrm{ANG}) & k + \cos(\mathrm{T}m\mathrm{ANG} + 120°) \\ k + \cos(\mathrm{T}m\mathrm{ANG} + 120°) & k + \cos(\mathrm{T}m\mathrm{ANG} - 120°) & k + \cos(\mathrm{T}m\mathrm{ANG}) \end{pmatrix}$$

Equation 5.7

where:

k = 0 if T*m*ZSR = Y

k = 0.5 if T*m*ZSR = N

The T*m*ANG setting specifies the phase rotation produced by the compensation matrix CTC(13) and has a range of –179.99 to 180.00 degrees. For example, setting TSCTC = 13 and TSANG = 15 degrees rotates a balanced set of Terminal S currents counterclockwise by 15 degrees, assuming an ABC phase rotation. In an ACB system, the rotation is in the clockwise direction.

For further information, see *Section 6: Protection Application Examples* for detailed settings guidelines for transformer winding and CT connection and compensation settings.

MVA (Transformer Capacity, Three-Phase MVA)

Use the expected transformer rating, such as the forced oil and air cooled (FOA) rating or a higher emergency rating, when setting the transformer capacity.

VTERMm (Terminal Line-to-Line Voltage)

Enter the nominal line-to-line transformer terminal voltages. If the transformer differential zone includes a load tap-changer, assume that the tap-changer is in the neutral position. The setting units are kilovolts.

TAPm (Terminal m Current Tap)

The TAP*m* values are used to convert the terminal currents bounding the differential zone to a common per-unit system. Upon your entry of an MVA setting (i.e., MVA is not set to "OFF"), the relay uses the MVA, winding voltage, CT ratio, and CT connection settings you have entered and calculates the TAP*m* values automatically, according to *Equation 5.8*. You can also enter tap values directly. Set MVA = OFF, and enter the TAPS–TAPY values directly, along with the other pertinent settings.

NOTE: MVA is typically set to the maximum rated transformer MVA. Refer to the technical paper, "Application Considerations for Protecting Transformers With Dual Breaker Terminals" by Shahab Uddin, Abu Bapary, Michael Thompson, Ryan McDaniel, and Kunal Salunkhe (available at selinc.com) for additional considerations in selecting an appropriate MVA for TAP scaling.

$$\mathrm{TAP}m = \frac{\mathrm{MVA} \bullet 1000}{\sqrt{3} \bullet \mathrm{VTERM}m \bullet \mathrm{CTR}m} \bullet \mathrm{C}$$

Equation 5.8

where:

TAP*m* = TAP value for each winding to convert from ampere to per unit (*m* = S, T, U, W, X, Y)

MVA = Transformer MVA (MVA)

VTERM*m* = Terminal line-to-line voltage of the winding (kV)

CTR*m* = CT ratio of the specific winding

C = 1 if CTCON*m* = Y (wye- or star-connected CTs)

C = √3 if CTCON*m* = D (delta-connected CTs)

The relay calculates TAP with the following limitations:

1. The TAP settings are within the range 0.1 • I_{NOM} and 35 • I_{NOM} (I_{NOM} = 1 A or 5 A).
2. The ratio of the highest (TAP*m* / I_{NOMm}) to the lowest (TAP*m* / I_{NOMm}) is less than or equal to 35.

O87P (Restrained Element Operating Current Pickup)

O87P is set in per unit of the TAP_{MIN} value. Set the operating current pickup at a minimum for increased sensitivity but high enough to avoid operation because of steady-state CT error and transformer excitation current. To ensure proper relay operation, be sure to select a setting value that satisfies the following equation:

$$\mathrm{O87P} \geq \frac{0.02 \bullet I_{NOM}}{TAP_{MIN}}$$

Equation 5.9

SLP1, SLP2 (Restraint Slope Percentage)

Use restraint slope percentage settings to discriminate between internal and external faults. Set SLP1 and SLP2 to accommodate differential current resulting from power transformer tap-changer, CT saturation, CT errors, and relay error.

We derive the Slope 1 setting (SLP1) as follows:

Assume the CT error, ε, is equal to ±10 percent. In per unit:

$\varepsilon = 0.1$

Assume the voltage ratio variation of the power transformer load tap-changer (LTC), *a*, is from 90 percent to 110 percent. In per unit:

$a = 0.1$

In a through-current situation, the worst-case theoretical differential current occurs when all of the input currents are measured with maximum positive CT error, and all of the output currents are measured with maximum negative CT error while also being offset by maximum LTC variation. Therefore, the greatest differential current one can expect for through-current conditions is as follows:

$$Id\max = \left[(1+\varepsilon) \bullet \frac{\Sigma ITn}{"IN"}\right] - \left[\frac{(1-\varepsilon)}{1+a} \bullet \frac{\Sigma ITn}{"OUT"}\right]$$

Equation 5.10

where the summation terms are the total input and output power transformer secondary currents after tap compensation. Per-unit current entering the transformer equals the per-unit current exiting the transformer, so the summation terms cancel, and we can express the maximum differential current (*Id*max) as a percentage of winding current:

$$\begin{aligned} Id\max &= (1+\varepsilon) - \frac{(1-\varepsilon)}{(1+a)} \\ &= \frac{(2 \bullet \varepsilon) + \mathrm{a} + (\varepsilon \bullet a)}{(1+a)} \bullet 100 \\ &= 28.18\% \end{aligned}$$

Equation 5.11

In addition to the error we just calculated, we must consider additional errors from transformer excitation current (≅2 percent) and relay measurement error (<5 percent). The maximum total error is 35 percent.

In the following text, we briefly discuss the correlation between the percentage error and the relay slope setting (also see *87RA, 87RB, and 87RC Restrained Differential Elements on page 3.18*). For this discussion, consider a two-winding transformer, with I1 flowing toward the transformer and I2 flowing away from the transformer (see *Figure 5.30*).

Figure 5.30 Two-Winding Transformer

In general, Slope 1 of the differential element characteristic in SEL percentage differential elements is a straight line through the origin, as *Equation 5.12* represents.

$$\mathrm{IOP(IRT)} = k \bullet \mathrm{SLP1} \bullet \mathrm{IRT}$$

Equation 5.12

where:

k = design constant (k = 1)
SLP1 = Slope 1
IRT = restraint current

The relay uses *Equation 5.13* to calculate the differential current (Idiff), and it uses *Equation 5.14* to calculate the restraint current (IRT).

$$\mathrm{Idiff} = \left|\overline{\mathrm{I1}} + \overline{\mathrm{I2}}\right|$$

Equation 5.13

$$\mathrm{IRT} = \left|\overline{\mathrm{I1}}\right| + \left|\overline{\mathrm{I2}}\right|$$

Equation 5.14

where I1 and I2 are per-unit vector quantities.

To calculate I1 and I2, evaluate the IN (I1) and OUT (I2) values of *Equation 5.10* separately.

$$\mathrm{I1} = (1 + \varepsilon) = 1.1 \text{ pu}$$

and

$$\mathrm{I2} = \frac{(1 - \varepsilon)}{(1 + \mathrm{a})} = 0.818 \text{ pu}$$

Use *Equation 5.13* to calculate Idiff.

$$\mathrm{Idiff} = \left|\overline{\mathrm{I1}} + \overline{\mathrm{I2}}\right|$$

$$\mathrm{Idiff} = |1.1 - 0.818| = 0.282 \text{ pu (or 28.18 percent as before)}$$

Use *Equation 5.14* to calculate the restraint current.

$$\mathrm{IRT} = \left|\overline{\mathrm{I1}}\right| + \left|\overline{\mathrm{I2}}\right|$$

$$\mathrm{IRT} = |1.1| + |0.818| = 1.918 \text{ pu}$$

The maximum differential error is 0.282 pu, and the restraint current is 1.918 pu. Evaluate *Equation 5.12* with SLP1 = 0.35 (35%) and k = 1. Remember that k is not a setting, it is a design constant.

$$\mathrm{IOP(IRT)} = k \bullet \mathrm{SLP1} \bullet \mathrm{IRT}$$
$$\mathrm{IOP(IRT)} = 1 \bullet 0.35 \bullet 1.918$$
$$\mathrm{IOP(IRT)} = 0.67 \text{ pu}$$

The value of 0.67 pu is much greater than 0.282, and is an extremely conservative setting. For the SEL-487E, reducing the SLP1 setting by half still provides an adequate margin for an anticipated maximum differential error of 0.282 pu, as calculated above.

$$\mathrm{IOP(IRT)} = 1 \bullet 0.18 \bullet 1.918$$
$$\mathrm{IOP(IRT)} = 0.345 \text{ pu}$$

During external faults, the relay changes to high-security mode and switches from Slope 1 to Slope 2 to avoid relay misoperation resulting from CT saturation. In contrast to small CT errors for load current, CT errors during external faults can be quite large. Although CT saturation resulting from high-current magnitude is less likely to occur with low-impedance relays, the dc component of the primary current can still cause severe CT saturation. During CT saturation, current resulting from CT errors appears as differential current and can cause relay misoperation.

To avoid relay misoperation, set Slope 2 as high as possible. Normally, a high Slope 2 setting causes slow tripping for evolving faults (external-to-internal faults). However, because the differential element in the SEL-487E requires less than 1.5 cycles to return to normal mode for an evolving fault, a Slope 2 setting as high as 90 percent is acceptable.

Differential-Element Settings in SEL-487E, SEL-387, and SEL-587

NOTE: The SEL-487E uses the total value of the restraint current, which is accounted for with the design constant k = 1. The SEL-387 and SEL-587 relays use half the restraint current (IRT/2), which is accounted for with a design constant of k = 0.5. For more information, refer to the technical paper, Percentage Restrained Differential, Percentage of What? by Michael J. Thompson (available at selinc.com).

The SEL-487E restraint quantity IRT*n* calculation differs from the SEL-587 and SEL-387 by a factor of 2. To achieve the same characteristics for the differential elements in the SEL-487E, SEL-387, and SEL-587, this factor of 2 has to be accounted for. The relationships between differential element settings for the three relays are shown next.

Convert SEL-387 and SEL-587 Relay Settings to the SEL-487E Relay

$O87P_{487E} = O87P_{387/587}$

$SLP1_{487E} = 1/2 \bullet SLP1_{387/587}$

$SLP2_{487E} = 1/2 \bullet SLP2_{387/587}$

$U87P_{487E} = U87P_{387/587}$

Convert SEL-487E Relay Settings to the SEL-387 and SEL-587 Relays

$O87P_{387/587} = O87P_{487E}$

$SLP1_{387/587} = 2 \bullet SLP1_{487E}$

$SLP2_{387/587} = 2 \bullet SLP2_{487E}$

$U87P_{387/587} = U87P_{487E}$

DIOPR and DIRTR (Incremental Operate and Restraint Threshold)

The relationship between the change in operating current and the change in restraint current determines the relay mode of operation. A change in restraint current without a change in operating current causes the relay to change to high-security mode, while a change in both restraint current and operating current causes the relay to trip. In setting the incremental quantities (DIOPR and DIRTR), we must consider the effect of load current on relay operation.

For low DIRTR settings, the relay enters the high-security mode for small changes in load current. Although the relay detects evolving faults (external to internal) in a short time, there is a time delay (less than one cycle) when the relay changes to internal fault detection. We should, therefore, select a step value that indicates an external fault rather than an increase in load current.

In general, we want to enter the high-security mode of operation when there is a danger of CT saturation for external faults. DIOPR and DIRTR default settings of 1.2 per unit provide satisfactory results in most applications.

E87HB (Enable Harmonic-Blocked Differential Element)

Choose among harmonic blocking, harmonic restraint, or both to obtain relay stability during transformer inrush conditions (see *Figure 5.29*). Setting E87HB enables the harmonic-blocked differential element, and the setting options control the method of inrush security. Set E87HB = Y to provide inrush blocking from only the harmonic-based method. Set E87HB = E to provide inrush blocking from either the harmonic- or waveshape-based methods.

Note that the harmonic-blocked element always operates in cross-blocking mode when using the harmonic-based inrush-blocking method.

E87HR (Enable Harmonic-Restrained Differential Element)

Choose among harmonic blocking, harmonic restraint, or both to obtain relay stability during transformer inrush conditions (see *Figure 5.29*). Setting E87HR enables the harmonic-restrained differential element, and the setting option controls the method of inrush security. Set E87HR = Y to provide inrush security that uses only the harmonic-based method. Set E87HR = W to provide additional inrush security with the waveshape-based inrush-blocking method.

Note that the harmonic-restrained element always operates in an independent-blocking mode, i.e., no cross blocking between phases.

At least one of E87HB or E87HR must be enabled (both settings cannot be set to N). Because the two elements are complimentary, it is possible to enable both elements and allow them to run in parallel.

E87UNB (Enable Waveshape-Unblocking Logic)

The waveshape-unblocking logic provides sensitive detection of internal faults and cancels the inrush-blocking functions used by the phase-restrained and negative-sequence differential elements, improving element operation times for internal faults. Enable the unblocking logic by setting E87UNB = Y.

PCT2, PCT4, PCT5 (Second-, Fourth-, and Fifth-Harmonic Percentage of Fundamental)

NOTE: The larger the PCT2, PCT4, or PCT5 setting, the smaller the effect of the setting.

The SEL-487E measures the amount of second-, fourth-, and fifth-harmonic current flowing in the transformer (see *Figure 5.16*). Set PCT2 and PCT4 based on the amount of harmonic content, in percentage of fundamental, the transformer produces during energization to provide security for inrush conditions. Set PCT5 based on the amount of harmonic content, in percentage of fundamental, that is expected during overexcitation conditions and is above the rated transformer excitation current. These settings are only used by the phase-restrained and negative-sequence differential elements.

To disable a harmonic function, set that setting to OFF.

TH5P, TH5D (Fifth-Harmonic Alarm Threshold and Delay)

When the volts/hertz function is unavailable, use the fifth-harmonic measurement to assert an alarm output during startup. This alarm indicates current in excess of the rated transformer excitation current. At full load, a TH5P setting of 0.1 corresponds to 10 percent of the fundamental current. Use Timer TH5D to prevent the relay from indicating transient presence of fifth-harmonic currents. You might consider triggering an event report if transformer excitation current exceeds the fifth-harmonic threshold.

NOTE: Beginning with firmware version R316, the E87T_WS setting is no longer used. During the firmware upgrade process, the relay automatically sets the new waveshape settings options appropriately based on the E87T_WS setting status to yield similar behavior (see SEL Application Guide "Enhancements to the SEL-487E Differential Elements," [AG2018-05] for more information). The E87T_WS is retained for firmware upgrade settings comparison purposes, but it no longer has any active function.

There are two criteria for setting TH5P:

- $TH5P \bullet TAP_{MIN} \geq 0.05 \bullet I_{NOM}$
- $TH5P \bullet TAP_{MAX} \leq 35 \bullet I_{NOM}$

where TAP_{MIN} and TAP_{MAX} are the least and greatest, respectively, of the tap settings.

To disable a harmonic function, set that setting to OFF.

87CORE (Transformer Core Type, Three-Legged or Individual Cores)

NOTE: Firmware versions prior to R316 used 87T_TYP (rather than 87CORE) as the setting name. During the firmware upgrade process, the relay automatically maps the 87T_TYP setting into the new 87CORE setting (see SEL Application Guide "Enhancements to the SEL-487E Differential Elements," [AG2018-05] for more information). The 87T_TYP setting is retained for settings comparisons, but it no longer has any active function.

The waveshape-based dwell-time algorithm for inrush detection has to be adjusted based on the transformer core type. 87CORE defaults to T for three-legged, three-phase transformers. The setting 87CORE = S is for transformers made with single-phase units or with a four- or five-legged core.

Negative-Sequence Percentage-Restrained Differential Element (87Q)

NOTE: For SV applications, operating times are delayed by the configured channel delay, CH_DLY. See SV Network Delays on page 17.33 in the SEL-400 Series Relays Instruction Manual for more details. For TiDL applications, the operating times are delayed by a fixed 1 ms. Use caution when setting relay coordination to account for this added delay.

During heavy load conditions, the resulting increase in restraint current renders the phase-differential element less sensitive, particularly from detecting transformer winding interturn faults. Because negative-sequence currents are unaffected by load in a balanced system, the negative-sequence percentage differential element provides sensitive protection for winding interturn faults.

Figure 5.31 shows the trajectory of a fault that shorts out 2 percent of the A-Phase winding of a three-phase transformer. In the phase-differential operation portion of *Figure 5.31*, the transformer is fully loaded, and the phase-differential relay operates when the operate current reaches around 0.43 per unit. *Figure 5.31* also shows the negative-sequence differential element response for the same fault. Because balanced load does not affect negative-sequence current, the negative-sequence element operates when the operate current reaches 0.3 per unit.

Figure 5.31 Differential Operations

The relay uses filtered compensated currents (see *Figure 5.12*) and *Equation 5.15* to calculate the negative-sequence currents for each terminal included in the differential element (ABC phase rotation) when you have enabled the element through the E87Q setting. The element calculates the negative-sequence operating and restraint current as shown in *Equation 5.16* and *Equation 5.17*, respectively.

NOTE: The 87Q element currents are set in per unit of the TAPm values (see Figure 5.12).

$$3I2mC = \begin{bmatrix} 1 & a^2 & a \end{bmatrix} \bullet \begin{bmatrix} IAmCFC \\ IBmCFC \\ ICmCFC \end{bmatrix}$$

Equation 5.15

where:

$$a = e^{j120}$$
$$a^2 = e^{j240}$$

$$IOP87Q = |\Sigma 3I2mC|$$

Equation 5.16

$$IRT87Q = \max(|3I2mC|)$$

Equation 5.17

NOTE: CON is the OR combination of CONA, CONB, CONC (see Figure 5.15).

Figure 5.32 shows the logic that forms the negative-sequence differential element. In the figure, the relay calculates the operating current in a similar manner to that of the phase-restrained differential element. However, the restraint current is the maximum of the negative-sequence currents among the terminals that are part of the differential calculations. After evaluating the operating and restraint currents in the differential element, the relay verifies that the fault is indeed internal (CON is deasserted) and that the negative-sequence differential element blocking logic (87QB) is deasserted (see *Figure 5.33*).

Figure 5.32 Negative-Sequence Percentage-Restrained Differential Element

Figure 5.33 Negative-Sequence Differential-Element Blocking Logic

The negative-sequence differential element blocking logic illustrated in *Figure 5.33* secures the element during inrush or overexcitation conditions. Enable or disable the inrush security checks via the negative-sequence differential element enable setting (E87Q). If you have selected harmonic-based inrush security by setting E87Q = Y or E, an assertion of the second- and fourth-harmonic cross-blocking logic, 87XBK2, (see *Figure 5.16*) asserts 87QB and blocks the element. If you have also enabled waveshape-based inrush security by setting E87Q = E, an assertion of the waveshape inrush-blocking logic, 87WB, (see *Figure 5.21*) asserts 87QB and blocks the element. If you have enabled the unblocking logic and 87UNBL asserts (see *Figure 5.26*), indicating detection of an internal fault, the relay cancels the inrush blocking of both the harmonic- and wavehsape-based methods. If the fifth-harmonic overexcitation cross-blocking logic (87XBK5) asserts, 87QB asserts and blocks the element.

As shown in *Figure 5.32*, if you have enabled the unblocking logic and 87UNBL asserts, the relay bypasses the 87QD timer, allowing the negative-sequence differential element to operate faster.

Relay Word bit 87BK secures the negative-sequence differential element when DSS current data are lost (see *Differential Zone and Restricted Earth Fault Element Blocking Logic on page 5.6* for more details). The 87Q element is blocked if data are lost for any of the current terminals included in the differential zone. If data are lost for current terminals not included in the differential zone, the 87Q element is unaffected. When current data are restored, the differential element remains blocked via 87BK for an additional 1.5 cycles to allow the full-cycle cosine filter to stabilize before resuming protection.

The 87Q Relay Word bit is an input to the overall transformer differential tripping logic, 87T, as shown in *Figure 5.36*.

E87Q Enable Negative-Sequence Differential Element

The E87Q setting enables the negative-sequence differential element, and the setting option controls the method of inrush security. Set E87Q = Y to provide inrush blocking that uses only the harmonic-based method. Set E87Q = E to provide inrush blocking from either the harmonic- or waveshape-based methods.

87QP Negative-Sequence Differential-Element Operating Current Pickup

Set the negative-sequence differential element to improve sensitivity to internal transformer winding turn-to-turn faults during heavy load conditions. 87QP is the negative-sequence pickup threshold of the element and is set in per unit of the TAP*m* values.

If 87QP is set lower than the default value, perform an analysis to determine how much negative-sequence operating current is present because of CT measurement errors. This analysis assures the security of the 87Q element.

SLPQ1 Negative-Sequence Differential Slope

The SLPQ1 setting defines the slope of the negative-sequence differential element. Unlike the phase-restrained differential elements, there is only one slope to set because the negative-sequence element is blocked if an external fault is detected (when the CON Relay Word bit asserts).

87QD Negative-Sequence Differential-Element Delay

The output of the negative-sequence differential element can be delayed for added security. Set the negative-sequence differential element delay to the recommended delay of 10 cycles.

Unrestrained Phase-Differential Element (87U)

NOTE: The 87U element currents are in per unit of the TAPm values (see Figure 5.12).

The relay provides three types of unrestrained differential elements intended to rapidly detect very high-magnitude currents that clearly indicate an internal fault. *Figure 5.34* illustrates the logic for the A-Phase unrestrained differential element. B- and C-Phase logics have similar logic to A-Phase.

Figure 5.34 A-Phase Unrestrained Differential Element

As shown in *Figure 5.34*, the filtered unrestrained element (87UFA) is a traditional unrestrained differential element and operates when the filtered operating current, IOPA, (see *Figure 5.29*) exceeds the U87P setting value. The raw unrestrained element (87URA) operates when the raw (unfiltered) incremental change in operating current, ΔIOPRA, (see *Figure 5.15*) exceeds the threshold *k* • U87P and there is no external fault detected, as evidenced by CONA being deasserted (see *Figure 5.15*) or the CT is deemed to be in an unsaturated state following an external fault, as indicated by CTUA asserting. The *k* value is an internal setting equal to $\sqrt{2} \bullet 2$ that secures 87URA against unfiltered inrush currents (see *U87P (Unrestrained Element Current Pickup) on page 5.45* for more information). Because 87URA operates on raw currents, it can operate substantially faster compared to 87UFA. The waveshape-based bipolar high-set differential overcurrent element, 87BPHA, (see *Figure 5.27*) serves as an input to the unrestrained differential-element logic. Because 87BPHA can differentiate between inrush and internal fault current, it is more sensitive than 87UFA and 87URA.

The A-Phase unrestrained differential element (87UA) will operate from any combination of these three unrestrained elements, depending on the E87U combo setting.

- When the E87U combo setting includes F, the unrestrained element operates on filtered operate current.
- When the E87U combo setting includes R, the unrestrained element operates on raw operate current.
- When the E87U combo setting includes W, the unrestrained element operates on the output of the waveshape-based bipolar high-set logic.

Note that even if a particular unrestrained element is not set to assert the 87U Relay Word bit via the E87U setting, the Relay Word bits for the individual unrestrained elements (87UFA, 87URA, and 87BPHA in *Figure 5.34*) are still active and available for evaluation and analysis purposes.

Relay Word bit 87BK secures the unrestrained differential element when DSS current data are lost (see *Differential Zone and Restricted Earth Fault Element Blocking Logic on page 5.6* for more details). The unrestrained element is blocked if

data are lost for any of the current terminals included in the differential zone. If data are lost for current terminals not included in the differential zone, the unrestrained element is unaffected. Note that this security is applied to the per-phase logic outputs (87UA, 87UB, and 87UC), as well as to the overall output (87U). Be advised that Relay Word bits 87UFA, 87URA, and 87BPHA (and their B-Phase and C-Phase equivalents) are not secure under data loss conditions and should not be included directly in the TRIP equation. When current data are restored, the differential element remains blocked via 87BK for an additional 1.5 cycles, to allow the full-cycle cosine filter to stabilize before resuming protection.

Relay Word bit 87U is the OR combination of the outputs from the A-, B-, and C-Phase unrestrained differential elements. The 87U Relay Word bit is an input to the overall transformer differential tripping logic, 87T, as shown in *Figure 5.36*.

E87U Enable Unrestrained Differential Element

The E87U combination setting enables the unrestrained differential element and controls for which types of unrestrained elements it will operate. When the E87U setting includes F, the unrestrained element operates on the filtered unrestrained element. When the E87U setting includes R, the unrestrained element operates on the raw unrestrained element. When the E87U setting includes W, the unrestrained element operates on the waveshape-based bipolar high-set differential overcurrent element.

The unrestrained element can be set to trip for any combination of these three elements.

U87P (Unrestrained Element Current Pickup)

NOTE: If you apply the SEL-487E with a dual breaker terminal, it is possible that spurious differential current that occurs from CT saturation during an external fault is the limiting factor in setting U87P. In this case, take the maximum bus fault in per-unit of the TAPm value and multiply by your estimate for CT saturation (e.g., 50%), setting U87P to the result after rounding up to the nearest integer value.

The purpose of the instantaneous unrestrained current element is to react quickly to very high-magnitude currents that clearly indicate an internal fault. The unrestrained differential elements only respond to the differential operating current. They are unaffected by the SLP1, SLP2, PCT2, PCT4, PCT5 settings, so there is no harmonic blocking/restraint for this element during inrush conditions. Thus, you must set the element pickup level high enough (set in per unit of the TAP*m* values) that the element does not react to through faults or transformer inrush currents. In cases where the maximum through-fault current is limited by the impedance of the transformer, inrush current is usually the governing limit. The 87UFA Relay Word bit is the output of the comparison of U87P (a pickup threshold) against a full-cycle cosine-filtered quantity, IOPA. For this reason, you can set U87P below the peak inrush current. See *Equation 5.18* for information on how to determine the value of U87P.

Figure 5.35 is an oscillographic capture of the worst-case inrush currents during energization of a 120 MVA 275/33 kV YDAC (Yd1) transformer (50 Hz nominal), as measured by the SEL-487E. The transformer was energized via the wye-side breaker with the delta-side breaker open. Relay Terminal S measured the wye-side (star-side) currents. The A-Phase experienced the largest inrush current, with a peak value exceeding 5 pu, as recorded by the raw (unfiltered) IAS_PU trace in *Figure 5.35*. Terminal S winding compensation was set with TSCTC = 11 to properly compensate for the phase shift across the transformer. The IASMC trace records the raw, compensated current while the IASCFC trace is the filtered, compensated current (see *Figure 5.12* for the filtered and unfiltered compensated current definitions). Because the inrush current represents a single-feed condition, the magnitude of IOPA is equal to the magnitude of the filtered, compensated Terminal S current, IASCFC. U87P needs to properly coordinate with the magnitude of the IOPA under the worst-case inrush current.

Figure 5.35 Worst-Case Inrush Current for Setting U87P

Notice the effect that the cosine filter has on the inrush current, as recorded by the IASCFC and IOPA values in *Figure 5.35*. The peak current of the compensated Terminal S current, IASMC, is 4 pu, but the cosine filter removes the dc component and the harmonics and produces an output IASCFC. The IOPA signal is the magnitude of the operating current (see *Figure 5.29*), so it is reduced by a factor of √2 compared to the IASCFC peak value. Therefore, we recommend a setting rule for U87P as given by *Equation 5.18*.

$$\text{U87P} = \frac{1.2 \bullet \text{IPKIR}}{\sqrt{2} \bullet 2}$$

Equation 5.18

where:

IPKIR is the worst-case peak inrush current

The 1.2 factor in *Equation 5.18* is added for security. For the waveforms captured in *Figure 5.35*, the worst-case inrush current captured by IAS_PU is around 5.2 pu. We use this for the value of IPKIR in *Equation 5.18*, and we solve for a value of U87P = 2.21 pu, as shown in *Figure 5.35*. This provides an adequate margin when comparing against the IOPA waveform and secures the filtered unrestrained element for the worst-case inrush current.

Note that the raw unrestrained differential element, 87URA, (see *Figure 5.34*) boosts the U87P setting by the factor *k* (equal to √2 • 2) to provide coordination with the inrush waveform measured by the raw, compensated Terminal S current in *Figure 5.35*, IASMC. Thus, given a setting value of U87P = 2.21 pu, the raw unrestrained element threshold shown in *Figure 5.34* is 6.24 pu and secures the raw unrestrained element for the worst-case inrush current shown in *Figure 5.35*.

Combined Differential Element (87T)

The relay combines the outputs of the phase-restrained differential elements, the negative-sequence differential element, and the unrestrained differential elements into an overall transformer differential short-circuit trip logic, given by 87T, as shown in *Figure 5.36*. The 87WS Relay Word bit is preserved for legacy users of the waveshape logic and is the combination of the phase-restrained and unrestrained differential elements.

Figure 5.36 Combined Differential Tripping

You can apply the 87T Relay Word bit to the transformer trip equation, TRXFMR.

Note that the 87R, 87Q, and 87U elements are kept secure when DSS current data are lost (see *Differential Zone and Restricted Earth Fault Element Blocking Logic on page 5.6*). Consequently, Relay Word bit 87T is safe to include in the trip equation.

Zone 2 Differential Elements (87B)

The SEL-487E provides a second adaptive-slope phase percentage-restrained differential element for applications that do not have an in-zone transformer, such as bus bar protection. For these applications inrush and overexcitation detection is not needed. A negative-sequence percentage-restrained differential element is also not needed because this element is primarily used to detect transformer turn-to-turn faults. Zone 2 differential elements allow users to select the CT polarity on each terminal included in the differential zone. Inverted CT polarity is useful in applications where the same current terminal is shared by both Zone 1 and Zone 2 differential elements.

Phase Percentage-Restrained Differential Element

Figure 5.37 shows the Zone 2 A-Phase percentage-restrained differential element. Using the compensated output quantities from the digital band-pass filter (full-cycle cosine filter), the relay calculates an operating quantity, IOPA2 (*Equation 5.19*), and a restraint quantity, IRTA2 (*Equation 5.20*).

$$\mathrm{IOPA2} = |\Sigma \mathrm{IA}m\mathrm{CFC2}|$$

Equation 5.19

$$\mathrm{IRTA2} = \Sigma|\mathrm{IA}m\mathrm{CFC2}|$$

Equation 5.20

where:

IA*m*CFC2 = A-Phase filtered, compensated per-unit current (*m* = S, T, U, W, X, Y) (see *Figure 5.13*)

Figure 5.37 Zone 2 A-Phase Percentage-Restrained Differential Element

From *Figure 5.37*, the relay calculates the filtered operate (IOPA2) and restraint (IRTA2) quantities from the filtered, compensated terminal currents (see *Figure 5.13*). After selecting the appropriate slope (SLP22 if CONA2 is asserted or SLP12 if CONA2 is deasserted), the relay calculates the biased restraint current, IRTFKA2.

The differential element is supervised by the IO87PA2 Relay Word bit, which asserts when the fault detection logic detects an internal fault, IFLTA2, (see *Figure 5.15*) and IOPA2 exceeds the O87P2 pickup value. The differential element asserts when the minimum operate current check is satisfied (IO87PA2 is asserted) and the operate current is greater than the appropriate biased restraint current (indicating that the operating condition lies within the operate region of the percentage-restrained characteristic).

The adaptive security timer is loaded with the pickup timer value *t*, which depends on the state of the CONA2 Relay Word bits at the moment the differential output asserts (P87A2), as shown in *Figure 5.37*. When the adaptive security timer pickup time expires, the A-Phase restrained Zone 2 differential element, 87RA2, asserts along with the overall phase-restrained Zone 2 differential element, 87R2. The B- and C-Phase percentage-restrained differential element logic is similar to the A-Phase logic.

Relay Word bit 87BK2 secures the differential element when DSS current data are lost (see *Differential Zone and Restricted Earth Fault Element Blocking Logic on page 5.6* for more details). The 87RA2, 87RB2, 87RC2, and 87R2 elements are blocked if data are lost for any of the current terminals included in the differential zone. If data are lost for current terminals not included in the differential zone, the 87R2 element is unaffected.

E87Z2, E87Tm2, O87P2, SLP12, SLP22, DIOPR2, DIRTR2

These settings are similar to the Zone 1 differential element setting. See *Phase Percentage-Restrained Differential Element (87R) on page 5.28* for a detailed description of each setting.

TmCTP2 (Terminal m Current Transformer Polarity)

When a negative CT polarity is entered for the T*m*CTP2 setting, the relay applies 180 degrees of compensation to the specified terminal current. This compensation is only available in the Zone 2 differential element and does not impact any other element within the relay. This is useful in applications where a common CT is used for the Zone 1 and Zone 2 differential elements, as shown in *Figure 5.38*.

Figure 5.38 Common CT Between Differential Zones

TAPm2 (Terminal m Current Tap)

The relay uses the highest CT ratio (CTR_{MAX}) of the installed CT ratios as a reference value to normalize the input currents.

Using *Equation 5.21*, the relay calculates a normalization factor value (TAP) for each terminal:

$$TAP m2 = \frac{CTR_{MAX}}{CTR_m}$$

Equation 5.21

where:

TAP*m2* = TAP value for each terminal (*m* = S, T, U, W, X, Y)

CTR_{MAX} = Highest CT ratio of the terminals used in the Zone 2 differential

CTR_m = CT ratio of Terminal *m*

CT Sizing

It is vital that you select adequate CTs for a transformer differential application. Use the following procedure (based on ANSI/IEEE Std C37.110-1996): IEEE Guide for the Application of Current Transformers Used for Protective Relaying Purposes.

Sizing a CT to avoid saturation for the maximum asymmetrical fault current is ideal but not always possible. Such sizing requires CTs with C-voltage ratings greater than (1 + X/R) times the burden voltage for the maximum symmetrical fault current, where X/R is the reactance-to-resistance ratio of the primary system.

CT Ratio Selection for a Multiwinding Transformer

Step 1. Determine the secondary side burdens in ohms for all CTs connected to a merging unit.

Step 2. Select the CT ratio for the highest-rated winding (CTRS, for example) by considering the maximum continuous secondary current, I_{HS}, based on the highest MVA rating of the transformer.

For wye-connected CTs, the relay current, I_{REL}, equals I_{HS}. For delta-connected CTs, I_{REL} equals $\sqrt{3} \cdot I_{HS}$. Select the nearest standard ratio such that I_{REL} is between $0.1 \cdot I_{NOM}$ and $1.0 \cdot I_{NOM}$ A secondary, where I_{NOM} is the merging unit nominal secondary current, 1 A or 5 A.

Step 3. Select the remaining CT ratios (CTRT–CTRY) by considering the maximum continuous secondary current, I_{LS}, for each winding.

Typically, the CT ratio is based on the rated maximum MVA of the particular winding. If the MVA rating is much smaller than the rating of the largest winding (typically the case for the tertiary delta winding), you can violate the tap ratio limit for the SEL-487E (see *Step 4* and *Step 5*). As before, for wye-connected CTs, I_{REL} equals I_{LS}. For delta-connected CTs, I_{REL} equals $\sqrt{3} \cdot I_{LS}$. Select the nearest standard ratio such that I_{REL} is between $0.1 \cdot I_{NOM}$ and $1.0 \cdot I_{NOM}$ A secondary.

Step 4. The SEL-487E calculates settings TAPS–TAPY if the ratio TAP_{MAX}/TAP_{MIN} is less than or equal to 35.

When the relay calculates the tap settings, it reduces CT mismatch to less than 1 percent. Allowable tap settings are in the range $(0.1–35) \cdot I_{NOM}$.

Step 5. If the ratio TAP_{MAX}/TAP_{MIN} is greater than 35, select a different CT ratio to meet the above conditions.

You can often do this by selecting a higher CT ratio for the smallest rated winding, but you may need to apply auxiliary CTs to achieve the required ratio. Repeat *Step 2–Step 5*.

Step 6. Calculate the maximum symmetrical fault current for an external fault, and verify that the CT secondary currents do not exceed your utility standard maximum allowed CT current, typically $20 \cdot I_{NOM}$.

If necessary, reselect the CT ratios and repeat *Step 2–Step 6*.

Step 7. For each CT, multiply the burdens you calculated in Step 1 by the magnitude, in secondary amperes, of the maximum symmetrical fault current you expect for an external fault.

Select a nominal accuracy class voltage for each CT that is greater than twice the calculated voltage. If necessary, select a higher CT ratio to meet this requirement, then repeat *Step 2–Step 7*. This selection criterion helps reduce the likelihood of CT saturation for a fully offset fault current signal.

Note that the effective C-voltage rating of a CT is lower than the nameplate rating if you use a tap other than the maximum. Derate the CT C-voltage rating by a factor of ratio used/ratio maximum.

Delta-Connected CTs

NOTE: SV publications are not supported for measurements that use delta-connected CTs or PTs. Any SV stream that includes data from a delta-connected CT or PT is marked as questionable/inaccurate.

Connecting CTs in delta affects different metering and elements in different ways. In general, delta-connected CTs remove zero-sequence quantities and cause a phase shift and a √3 increase in magnitude (with respect to the balanced quantities used in the delta connection). Removing the zero-sequence quantities impacts all ground elements, a phase shift impacts all calculations based on quantities from delta-connected CTs, and the increase in magnitude affects all elements that operate on current magnitude.

Directional and Distance Element

Delta-connected CTs remove zero-sequence quantities, so directional and distance elements are not available for those mapped terminals with delta-connected CTs. For example, if the CTs mapped to Terminal S are delta-connected, then directional elements are not available for Terminal S. If the CTs of the remaining terminals are wye-connected, then directional elements are available for the remaining terminals.

Combined Terminals, Thermal Element, and Through-Fault Element

⚠WARNING
Be sure to connect both sets of CTs in the same delta configuration (AB, BC, CA, for example). When you connect the two sets of CTs in different delta configurations (AB, BC, CA, and AC, BA, CB), the phase difference results in incorrect combined current values.

Delta-connected CTs cause a phase shift, so currents from the combined windings (ST, TU, UW, WX) are not available when CTs from one of the two terminals are delta connected. Currents from the combined terminals are available if CTs from both terminals are delta-connected. However, be sure to connect both sets of CTs in the same delta configuration because the relay does not check for this condition.

Power Calculations

To account for the inherent phase shift associated with delta-connected CTs, the setting CTCOMP*m* (*m* = S, T, U, W, X, Y) is available for any terminal used in power calculations with a delta-connected CT (CTCON*m* = D). Specifying either a DAB or DAC connection ensures proper compensation when calculating power for over- and underpower elements and power metering.

Combined Terminals, Thermal Element, Through-Fault Element, and Event Reporting

Because of the √3 increase in magnitude resulting from the delta-connected CTs, elements that operate on primary current values use the incorrect current values. To correct this, the relay divides the secondary currents by √3 before multiplying by the CT ratio to convert to primary currents.

For the event report, the relay also divides the secondary currents by √3 before multiplying by the CT ratio to convert to primary currents.

In the COMTRADE report, the relay divides the CT ratio in the .cfg file by √3 to compensate for the delta connection. This compensation applies to primary values only. Changing the CT ratio instead of the stored data do not change the secondary current values, so you can inject the secondary values into the relay without any change.

In summary, the relay compensates for delta-connected CTs when reporting or using primary values. No secondary currents are compensated; the relay processes secondary currents at the values the relay terminals measure.

REF Element

REF protection comes from a zero-sequence directional element that provides sensitive detection of ground faults near the neutral of a grounded wye-connected transformer winding. To provide REF protection, the element compares the direction of a reference current, derived from the line-end CTs, with the operating current, obtained from the neutral CT. *Figure 5.39* shows the characteristic of the REF element, with the shaded area indicating the tripping area.

Figure 5.39 REF Directional Element

Because the REF element employs a neutral CT at one end of the winding and a set of three CTs at the line end of the winding, REF protection can detect only ground faults within that particular wye-connected winding. The element is restricted in the sense that protection is limited to ground faults within a zone defined by neutral and line CT placement.

The REF element uses comparison of zero-sequence currents, so the line-end CTs must be connected in wye for the element to function. Delta-connected CTs cancel out all zero-sequence components of the currents, eliminating one of the quantities the REF element needs for comparison.

The SEL-487E-5 maps subscribed analogs to Terminal Y on a per-phase basis for REF applications. *Table 5.4* shows the relationships among the input currents of the Y Terminal and the REF elements. These relationships are not settable; they are fixed and must be observed when you use the REF function. For example, if you select REF 1 for your application, be sure to wire the input current from the neutral CT to IY1.

Table 5.4 Relationships Among Input Currents and REF Elements

Input Current	REF Element
IY1	REF Element 1
IY2	REF Element 2
IY3	REF Element 3

Figure 5.40 shows the REF 1 element logic diagram (REF 2 and REF 3 have similar diagrams) that produces the REF enable output and the two bypass outputs IOPNRF1 and IRFFR1P. Note that some of the signal labels below are not Relay Word bits, but are included with this diagram for ease of discussion.

[1] Signals are labeled in this figure for ease of discussion. These are not Relay Word bits.
[2] PU and DO times are 20% larger for 50 Hz systems.

① See Figure 5.41.

Figure 5.40 REF 1 Element Enable Logic

Comparator C1 compares the normalized neutral current against the REF50G1 Group setting. The REF nondirectional operate, IOPNRF1, is asserted by comparator C1. Comparator C2 compares 80 percent of the REF50G1 setting value against the magnitude of the reference current. The 0.8 multiplier ensures that the nondirectional output (NDREF1) does not assert for an external fault (see *Figure 5.44*).

During an internal fault, both the neutral current and zero-sequence reference current exceed the REF50G1 setting. Two likely conditions where this is not true would be for a settings error or an open circuit. REFOCT1 is used to secure the REF enable declaration under these conditions.

REFOCT1, together with Comparator C2 and the torque-control equation TCREF1, enable the REF 1 element. The REF enable supervises the directional calculations (see *Figure 5.41*).

Figure 5.41 shows the logic that performs the directional calculations. After closing the appropriate cells of Switch S1, the relay converts the currents to primary values by multiplying each current times the appropriate CT ratio. The relay then sums these currents vectorially to produce the reference current in vector form. To bring this value to the same base as the neutral CT, the algorithm divides the reference current by the product of the CT ratio and the neutral CT nominal current. These calculations produce IREFR1, the reference current in vector form. For the operating current, the algorithm normalizes IY1CF to produce IOPR1, the operating current in vector form.

① See Figure 5.40.

Figure 5.41 Algorithm That Performs the Directional Calculations

To determine the direction, the algorithm calculates the real part of the product of the reference quantity and the conjugate of the operating quantity. This calculation yields the signed torque quantity REFTQ1 (this calculation is equivalent to |IOPR1| times |IREFR1| times the cosine of the angle between them). REFTQ1 is positive if the angle is within ±90 degrees, indicating a forward or internal fault. Conversely, REFTQ1 is negative if the angle is greater than +90 or less than –90 degrees, indicating a reverse or external fault. The switching logic shown in *Figure 5.42* is nearly identical to that previously discussed in *Figure 5.41*. Instead of switching zero-sequence current, this logic switches negative-sequence current. Once the appropriate terminals are switched in, the currents are scaled to primary, summed, and then normalized to produce a per-unit reference quantity. The negative-sequence reference quantity, IQFR1, is used in *Figure 5.44* to further secure the REF element.

Figure 5.42 REF Negative-Sequence Summation Logic

Figure 5.43 shows the logic that compares REFTQ1 to a positive threshold (THRES1P) and a negative threshold (THRES1N). These thresholds are designed to restrict the operating angle (80 degrees) to secure the element under a wide variety of conditions. The threshold reference values are equal and opposite to one another.

[1] Signals are labeled in this figure for ease of discussion. These are not Relay Word bits.

Figure 5.43 REF Element Trip Output

REF schemes are generally susceptible to CT saturation resulting from external LLG faults. To address this, the REF is blocked if the negative-sequence current is greater than the pickup REF50G1 and more than 10 times greater than either IOPFR1 or IRFFR1.

LLG or the reverse faults indication supervises the forward REF elements via REFBLK1. A 60 cycle security dropout timer is used for both the forward and reverse REF elements to ensure the supervision is secure in the event of severe CT saturation.

A reverse REF fault is declared by asserting REFR1 if the reverse threshold THRES1N is exceeded by REFTQ1 and a forward or LLG fault is not detected. A forward fault is declared by asserting REFF1 when the element is enabled (see *Figure 5.62*) and is not blocked by REFBLK1. REFBLK asserts for any fault declared reverse, as determined by the angle of REFTQ1. This gives the forward operating region the characteristic shown in *Figure 5.39*, which is a torque angle within approximately ±100 degrees of the reference current.

Figure 5.44 shows the need for the bypass logic (C1) in *Figure 5.40*. For the directional element to produce a meaningful result, both operating and restraint quantities must be present. If Fault F1 occurs with the LV breaker open, no current flows through the LV CT, and there is no reference quantity present.

Figure 5.44 Internal Fault With LV Breaker Open

In *Figure 5.43*, the top AND gate has three inputs, namely IOPNRF1 and IRFFR1P (see *Figure 5.40*), and a SELOGIC control equation TCREF1. IOPNRF1 and negated IRFFR1P identify the condition in *Figure 5.44* in which current flows in the neutral but no current flows in the line. Use TCREF1 to further qualify the bypass condition by checking, for example, the status of the LV breaker. Therefore, when Fault F1 occurs, NDREF1 asserts and clears the fault.

For fast tripping, include REFF1, the output of the REF element, into one or more of the trip equations (Group settings TR*k*) as appropriate. If you want additional security, use the programmable 51 element in *Figure 5.45* to delay tripping. In *Figure 5.45*, the overcurrent element uses the neutral current (IY1FM) as an input quantity. To avoid inadvertent tripping for external faults, use REFF1 (see *Figure 5.43*) in the torque-control equation (RF51TC1) of the overcurrent element.

Figure 5.45 Programmable 51 REF Element

REF511P in *Figure 5.45* shows that the inverse-time overcurrent element has picked up. REF51T1 indicates that the element has timed out and REF51R1 is used to indicate that the element has been reset.

Neutral Element

For applications such as frame leakage protection or sustained ground fault protection, the REF element includes a definite-time overcurrent (50) element. *Figure 5.46* shows the REF 50 element, with neutral current IY1FM as an input quantity. If IY1FM exceeds the REF50P1 setting, REF501 asserts and starts the REF Definite-Time Timer. If IY1FM exceeds the REF50P1 setting for a period exceeding the REF50D1 timer setting, REF50T1 asserts. Disable this element by setting REF50P1 = OFF.

Figure 5.46 REF Neutral Element

Applications and Setting Descriptions

REF Directional Element Enable (EREF)

Use the EREF setting to enable the number of REF elements appropriate for the application. Setting EREF = N disables all REF elements, but not the neutral element. There are no neutral input current/REF element assignment settings: the relationships are fixed as in *Table 5.4*.

Therefore, when you set EREF = 1, the REF element evaluates only an input mapped to Terminal IY1; the element ignores inputs mapped to IY2 and IY3.

Restraint (Reference) Quantity (REFRFa)

Setting REFRF*a* (*a* = 1–3) identifies the terminal or combination of terminals the REF element must include when it calculates the reference current (closing the cells of Switch S in *Figure 5.40* and *Figure 5.41*). Available terminals are those enabled by the ECTTERM setting.

Residual Current Sensitivity Threshold (REF50Ga)

You can set the residual current sensitivity threshold to as low as 0.05 times nominal current (0.25 A for 5 A nominal CT current), the minimum residual current sensitivity of the relay. However, the minimum acceptable value of REF50G*a* must be greater than any natural 3I0 unbalance resulting from load conditions.

REF Torque Control (TCREFa)

SELOGIC control equation TCREF*a* provides a method to externally control the enabling of the directional calculations (see *Figure 5.40*).

REF Neutral Element Instantaneous Overcurrent Pickup (REF50Pa)

REF50P*a* is the instantaneous overcurrent pickup setting for the neutral element (see *Figure 5.46*).

REF Neutral Element Overcurrent Time Delay (REF50Da)

REF50D*a* is the time-delay setting for the instantaneous overcurrent element of the neutral element (see *Figure 5.46*).

REF TOC (51) Pickup (REF51Pa)

REF51P*a* is the time-overcurrent pickup setting for the programmable 51 element (see *Figure 5.45*).

REF TOC (51) Curve (REF51Ca)

REF51C*a* is the time-overcurrent curve selection setting for the programmable 51 element (see *Figure 5.45*).

REF TOC (51) Time Dial (RF51TDa)

RF51TD*a* is the time-dial (time multiplier) setting for the programmable 51 element (see *Figure 5.45*).

REF TOC (51) Electromechanical Reset (RF51RSa)

RF51RS*a* is the time-dial (time multiplier) electromechanical reset setting for the programmable 51 element (see *Figure 5.45*).

REF TOC (51) Torque Control (RF51TCa)

RF51TC*a* is the torque-control setting for the programmable 51 element (see *Figure 5.45*).

Selection of the Restraint Quantity

The operating quantity/reference quantity relationship is according to software assignment (instead of a fixed relationship), so you can apply the REF elements to any primary plant configuration with the correct CT arrangement. In general, identify all lines that are electrically connected to the grounded winding that you want to protect with the REF element. Then enter those terminals at the REFRF*a* setting. Following are examples of a few applications, assuming that both differential and REF elements protect the transformer in each example.

Figure 5.47 shows an ungrounded HV winding and a grounded-wye LV winding. Because we need two terminals for the differential protection, set ECTTERM = S, T, and assign Terminal S to the HV side and Terminal T to the LV side. Set EREF = 1 to enable one REF element (this setting dictates that we connect the neutral CT to Terminal IY1). Although Terminals S and T are enabled, only Terminal T electrically connects to the winding earmarked for REF protection. Therefore, set REFRF1 = T.

ECTTERM	S, T
EREF	1
REFRF1	T

Figure 5.47 Single-Wye Winding REF Application

Figure 5.48 shows an autotransformer. Because we need two terminals for the differential protection, set ECTTERM = S, T, and assign Terminal S to the HV side and Terminal T to the LV side. Set EREF = 1 to enable one REF element (this setting dictates that we use IY1). In this case, both Terminal S and Terminal T connect electrically to the winding earmarked for REF protection. Therefore, set REFRF1 = S, T.

ECTTERM	S, T
EREF	1
REFRF1	S, T

Figure 5.48 Autotransformer REF Application

Figure 5.49 also shows an autotransformer, but in this application, the HV side has two CTs (breaker-and-a-half application). Because we need three terminals for the differential protection, set ECTTERM = S, T, U, and assign Terminals S and T to the HV side and Terminal U to the LV side. Set EREF = 1 to enable one REF element (this setting dictates that we use IY1). In this case, Terminal S, Terminal T, and Terminal U connect electrically to the winding earmarked for REF protection. Therefore, set REFRF1 = S, T, U.

Figure 5.49 Autotransformer With Two-HV CT REF Application

Figure 5.50 shows a three-winding wye-wye transformer with tertiary delta. Assume that no load connects to the delta, so that the differential calculations exclude the delta. Because we need two terminals for the differential protection, set ECTTERM = S, T, and assign Terminals S to the HV side and Terminal T to the MV side. In contrast to an autotransformer, the HV and MV windings of this transformer are not connected electrically, and we need a separate REF for each winding. Set EREF = 2 to enable two REF elements (this setting dictates that we use IY1 and IY2). On the assumption that we assign REF 1 to the HV side, set REFRF1 = S, and set REFRF2 = T for the MV side.

Figure 5.50 Three-Winding Transformer With Two REF Elements

Combined Terminals

Figure 5.51 shows a breaker-and-a-half layout on the transformer HV side and a single busbar on the LV side. On the HV side, the HV current flows through both CTS and CTT, but the total current flows through CTU and the LV side. Current distribution through CTS and CTT is a function of system conditions, so the

proper coordination with CTU involves using the sum of CTS and CTT. *Figure 5.52* shows the result of the combined current values in the SEL-487E. The relay adds the currents from CTS and CTT to form the equivalent of a single CT.

Be aware that the relay combines the current values only if the corresponding terminal current settings for the CT winding connection type are identical (CTCON*m* and CTCOMP*m*) and the terminals have the same nominal current rating (i.e., 5 A or 1 A). For example, Terminals S and T could not be combined if CTCONS = Y and CTCONT = D.

Furthermore, when combined current terminals are used for applications that require a voltage measurement, the voltage reference terminal and alternative voltage source settings (VREF*m* and ALTV*m*) must be identical between the two combined terminal settings.

You can configure the overcurrent, time-overcurrent, power, distance, and directional overcurrent elements to use predefined combinations of secondary currents, namely the ST, TU, UW, and WX terminal combinations.

Figure 5.51 Two CTs on HV Side

Figure 5.52 Equivalent Single CT on HV Side

Overcurrent Elements

NOTE: For SV applications, operating times are delayed by the configured channel delay, CH_DLY. See SV Network Delays on page 17.33 in the SEL-400 Series Relays Instruction Manual for more details. For TiDL applications, the operating times are delayed by a fixed 1 ms. Use caution when setting relay coordination to account for this added delay.

The SEL-487E provides three levels of phase, negative-sequence, and zero-sequence instantaneous overcurrent elements (50) for each of the six terminals (S, T, U, W, X, Y), combined terminals (ST, TU, UW, WX), and 20 configurable time-overcurrent (51) elements. These overcurrent elements are nondirectional, but you can make any of the 50 or 51 elements directional with a choice of phase and sequence-based directional elements (see *Directional and Distance Element on page 5.51*).

Loss of DSS current data can potentially compromise the security of the 67G and 67Q elements. To secure the 67G and 67Q elements under these conditions, include analog channel status Relay Word bits in the torque-control equations for these elements (see *Analog Channel Statuses on page 5.2* and *Application Setting SVBLK and Relay Word Bit SVBK_EX on page 5.5*).

Phase Instantaneous Overcurrent Elements

Figure 5.53 shows the logic for the phase instantaneous overcurrent element. At the top of the logic are four settings that enable the overcurrent element. All four settings must evaluate to a logical 1 to enable the overcurrent element. To enable the Level 1 instantaneous overcurrent element for Terminal S, apply the following settings: ECTTERM = S, … , E50 = S, … , E50S = P, and 50SP1P = 4 (any setting within the range other than OFF).

Figure 5.53 Phase Instantaneous Overcurrent Element

Setting 50SP1P also provides the reference value against which three comparators test the three phase currents (IA*q*FM, IB*q*FM, IC*q*FM). If the element is enabled, and any phase current exceeds the 50SP1P setting value, then Relay Word bit 50SP1 asserts.

Use the torque-control setting 67*m*P*a*TC to combine the 50 element with other functions such as the directional element, or to add a time delay. For a time delay (Terminal S, Level 1), set 67SP1TC = 1 (or any other appropriate condition such as the directional element or a breaker auxiliary contact status), and set 67SP1D to the desired time delay. If the element is enabled, and any phase current exceeds the 50SP1P setting value, then Relay Word bits 50SP1 and 67SP1 assert instantaneously, and Relay Word bit 67SP1T asserts when the Phase 50 timer times out.

Negative-Sequence Instantaneous Overcurrent Elements

Figure 5.54 shows the logic for the negative-sequence instantaneous overcurrent element. This element operates similar to the phase instantaneous overcurrent element, except that the element uses negative-sequence values instead of phase values.

Figure 5.54 Negative-Sequence Instantaneous Overcurrent Element

Zero-Sequence Instantaneous Overcurrent Elements

Figure 5.55 shows the logic for the zero-sequence instantaneous overcurrent element. This element operates similar to the phase instantaneous overcurrent element, except that the element uses zero-sequence values instead of phase values.

Figure 5.55 Zero-Sequence Instantaneous Overcurrent Element

Setting Descriptions

E50 (Definite-Time Overcurrent and Directional Element Enable)

Setting E50 is a composite setting that identifies the following three protection options for each terminal:

- Terminals that require only definite-time overcurrent elements
- Terminals that require only directional elements
- Terminals that require both definite-time overcurrent elements and directional elements

For example, at a particular substation you want the following protection:

- Terminal S: negative-sequence definite-time overcurrent only
- Terminal T: only directional control (directional elements for time overcurrent [51] protection)

- Terminal U: both definite-time overcurrent protection (Level 1) and directional control
- Terminals W, X, and Y: not used

Figure 5.56 shows the flow diagram for setting the three protection options (gray blocks are not used).

Figure 5.56 Three Settings Possibilities

In general, regardless of the function you want (overcurrent or directional), always enter the E50 and E50*m* settings. In this example, include Terminals S, T, and U in the Group setting ECTTERM to enable these terminals for processing, as shown in *Figure 5.57*. Also select the PT for the directional element polarizing (EPTTERM setting). The voltage reference terminal selection setting, VREF*n* (*n* = S, T, U, W, X, Y), also needs to be set to the PT to enable the directional elements E67*m*.

Figure 5.57 ECTTERM and EPTTERM Settings

After enabling the CTs for processing, enter Terminals S, T, and U in the Group setting E50 (see *Figure 5.58*). *Figure 5.58* also shows the selection of the 51 element that must have directional control. The 51 elements are not terminal-specific, so setting the terminal CT/51 elements correlation occurs later.

Figure 5.58 E50 and E51 Enables

Use the E50*m* setting to specify the type of overcurrent elements you want to use, both for overcurrent elements and for directional elements. Because Terminal S requires negative-sequence definite-time overcurrent only, set E50S = Q.

Figure 5.59 Enable Overcurrent and Directional Elements for Terminal S

Figure 5.60 shows the negative-sequence definite-time overcurrent settings. The setting 50SQ1P is the Level 1 negative-sequence overcurrent element pickup value (arbitrarily set at 12). The setting 67SQ1TC is the torque-control setting for the negative-sequence overcurrent element (refer to *Figure 5.54* for the logic diagram). In this example, set 67SQ1TC = NOT SVBLK to secure the element if DSS data are lost. The last setting is 67SQ1D, the negative-sequence overcurrent element time delay, set in *Figure 5.60* to an arbitrary value of 20 cycles.

Figure 5.60 Negative-Sequence Definite-Time Overcurrent Settings

This concludes the negative-sequence definite-time overcurrent settings for Terminal S.

Terminal T protection calls for a directional element 51. To enable the T-terminal directional element, the voltage reference terminal selection setting, VREFT, must be set to a voltage. In this example, V is the only voltage terminal available in EPTTERM, so VREFT = V as shown in *Figure 5.61*. *Figure 5.62* shows the settings to enable the directional element (E50T = P, G, Q), and *Figure 5.63* shows the settings to disable the definite-time overcurrent Level 1 elements (50TP1P = OFF) for Terminal T.

Figure 5.61 Voltage Reference Terminal Selection Setting

Figure 5.62 Enable Overcurrent and Directional Elements for Terminal T

Figure 5.63 Disable Definite-Time Overcurrent Elements

Enable the directional elements by setting E67T = Y. This makes the CTPT, Z1ANGT, Z0ANGT (E50T includes both P and G) and EADVST settings available. With 50TP1P = OFF, the phase overcurrent elements are disabled, so that only the directional elements are active for Terminal T.

Figure 5.64 shows the settings for the Terminal T directional 51 element. For this example, do not use adaptive settings for the pickup and time-dial settings. Set the operating quantity (51O01 = IMAXTF), the pickup setting (51P01), Curve type (51C01), time dial (51TD01), and the type of reset (51RS01).

Use setting 51TC01 to add directional control to the 51 element. Setting 51TC01 = TF32G (negative- and zero-sequence direction) OR TF32P (phase direction) causes the 51 element to be active only for forward faults.

Figure 5.64 Terminal T Directional 51 Element Settings

This concludes the directional 51 settings for Terminal T.

Terminal T protection calls for one level of directional definite-time overcurrent protection. Similar to *Figure 5.61*, VREFU must be set to an enabled voltage terminal to enable the E67U directional element. *Figure 5.65* shows the settings to enable the directional element (E50U = P, Q, G and E67U = Y).

Figure 5.65 Enable Overcurrent and Directional Elements for Terminal U

With the directional elements enabled, set the 50 elements settings, as shown in *Figure 5.66*. To make the 50 elements directional, enter the forward directional Relay Word bits (UF32P and UF32G) in the 67UP1TC torque equation.

Figure 5.66 Terminal U Directional 50 Element Setting

Only one level of overcurrent protection is necessary, so leave 50UP2P = OFF. This concludes the directional 50 settings for Terminal U.

E50m (50 Function Enable)

After identifying the terminal(s) that requires definite-time overcurrent/directional protection with the E50 setting, select the specific instantaneous overcurrent element(s)/directional type for each terminal(s) by using the E50*m* setting. Choose from among phase (P), negative-sequence (Q), zero-sequence (G), or any combination of P, Q, and G.

50mPaP (Phase Element Pickup)

Setting 50*m*P*a*P is the current pickup setting in secondary amperes for the phase instantaneous overcurrent element. For a 5 A relay, the range is 0.25–100.00 A, secondary. The range for a 1 A relay is 0.05–20.00 A, secondary.

67mPaTC (Phase Element Torque Control)

NOTE: This setting does not affect the 50mPa outputs (see Figure 5.53).

Use the torque-control setting to specify conditions under which the output 67*m*P*a*T must be active. The default setting is *m*F32P, so that the 67*m*P*a*T function can only assert if the phase directional element declares a fault in the forward direction. With the torque equation set to 1 (67SP1TC = 1, Terminal S, Level 1), the output 67*m*P*a*T is nondirectional and active constantly.

67mPaD (Phase Element Time Delay)

NOTE: This setting is active only if 67mPaTC asserts.

Set the duration of the phase element time delay with this setting.

50mQaP (Negative-Sequence Element Pickup)

Setting 50*m*Q*a*P is the current pickup setting in secondary amperes for the negative-sequence instantaneous overcurrent element. For a 5 A relay, the range is 0.25–100.00 A, secondary. The range for a 1 A relay is 0.05–20.00 A, secondary.

67mQaTC (Negative-Sequence Element Torque Control)

NOTE: This setting does not affect the 50mQa outputs (see Figure 5.54).

Use the torque-control setting to specify conditions under which the output 67*m*Q*a*T must be active. The default setting is *m*F32Q, so that the 67*m*Q*a*T function can only assert if the negative-sequence directional element declares a fault in the forward direction. With the torque equation set to 1 (67SQ1TC = 1, Terminal S, Level 1), the output 67*m*Q*a*T is nondirectional and active constantly.

67mQaD (Negative-Sequence Element Time Delay)

NOTE: This setting is active only if 67mQaTC asserts.

Set the duration of the negative-sequence element time delay with this setting.

50mGaP (Zero-Sequence Element Pickup)

50*m*G*a*P is the current pickup setting in secondary amperes for the zero-sequence instantaneous overcurrent element (shown is the range for a 5 A relay; the range is 0.05 to 20 for a 1 A relay).

67mGaTC (Zero-Sequence Element Torque Control)

NOTE: This setting does not affect the 50mGa outputs (see Figure 5.55).

Use the torque-control setting to specify conditions under which the output 67*m*G*a*T must be active. The default setting is *m*F32G, so that the 67*m*G*a*T function can only assert if the zero-sequence directional element declares a fault in the forward direction. With the torque equation set to 1 (67SG1TC = 1, Terminal S, Level 1), the output 67*m*G*a*T is nondirectional and active constantly.

67mGaD (Zero-Sequence Element Time Delay)

NOTE: This setting is active only if 67mGaTC asserts.

Set the duration of the zero-sequence element time delay with this setting.

Selectable Time-Overcurrent Element (51)

NOTE: For SV applications, operating times are delayed by the configured channel delay, CH_DLY. See SV Network Delays on page 17.33 in the SEL-400 Series Relays Instruction Manual for more details. For TiDL applications, the operating times are delayed by a fixed 1 ms. Use caution when setting relay coordination to account for this added delay.

Instead of having dedicated inverse-time overcurrent elements (also known as Inverse Definite Minimum Time or IDMT) for each terminal, the SEL-487E offers the flexibility of 20 unassigned time-overcurrent elements, each with the choice of five U.S. and five IEC operating curves. Unassigned means that the 51 elements are not assigned to a specific transformer terminal, but they are available for assignment, as the application requires (see *Table 5.7*).

Be sure to include the terminals selected as 51 element input quantities in the ECTTERM setting. For example, if IMAXSF (see *Table 5.7*) is the input for element 51O01 and if IMAXTF is the input for element 51O02, then set ECTTERM = S, T. To provide selective protection disabling of the 51 elements under data loss conditions, include the analog channel status Relay Word bits in the torque-control equations for these elements (see *Analog Channel Statuses on page 5.2*).

Inverse-time overcurrent elements are not enabled by default. Enable the inverse-time overcurrent elements by setting E51 = *xx* (*xx* = 01–20). After you enable these elements, the inverse-time overcurrent elements up to and including the number *xx* you entered are active. For example, if you want to use six inverse-time overcurrent elements for your application, set E51 = 6. Inverse-time overcurrent elements 1–6 become active.

Table 5.5 shows the five U.S. characteristics, and *Table 5.6* shows the five IEC characteristics. Each table shows the five operating time equations, together with the five electromechanical reset characteristic equations.

Table 5.5 U.S. Operate and Reset Curve Equations

Curve Type	Operating Time	Reset Time
U1 (Moderately Inverse)	$T_P = TD \bullet \left(0.0226 + \frac{0.0104}{M^{0.02} - 1}\right)$	$T_R = TD \bullet \left(\frac{1.08}{1 - M^2}\right)$
U2 (Inverse)	$T_P = TD \bullet \left(0.180 + \frac{5.95}{M^2 - 1}\right)$	$T_R = TD \bullet \left(\frac{5.95}{1 - M^2}\right)$
U3 (Very Inverse)	$T_P = TD \bullet \left(0.0963 + \frac{3.88}{M^2 - 1}\right)$	$T_R = TD \bullet \left(\frac{3.88}{1 - M^2}\right)$
U4 (Extremely Inverse)	$T_P = TD \bullet \left(0.02434 + \frac{5.64}{M^2 - 1}\right)$	$T_R = TD \bullet \left(\frac{5.64}{1 - M^2}\right)$
U5 (Short-Time Inverse)	$T_P = TD \bullet \left(0.00262 + \frac{0.00342}{M^{0.02} - 1}\right)$	$T_R = TD \bullet \left(\frac{0.323}{1 - M^2}\right)$

Table 5.6 IEC Operate and Reset Curve Equations

Curve Type	Operating Time	Reset Time
C1 (Standard Inverse)	$T_P = TD \bullet \left(\frac{0.14}{M^{0.02} - 1}\right)$	$T_R = TD \bullet \left(\frac{13.5}{1 - M^2}\right)$
C2 (Very Inverse)	$T_P = TD \bullet \left(\frac{13.5}{M - 1}\right)$	$T_R = TD \bullet \left(\frac{47.3}{1 - M^2}\right)$
C3 (Extremely Inverse)	$T_P = TD \bullet \left(\frac{80}{M^2 - 1}\right)$	$T_R = TD \bullet \left(\frac{80}{1 - M^2}\right)$
C4 (Long-Time Inverse)	$T_P = TD \bullet \left(\frac{120}{M - 1}\right)$	$T_R = TD \bullet \left(\frac{120}{1 - M}\right)$
C5 (Short-Time Inverse)	$T_P = TD \bullet \left(\frac{0.05}{M^{0.04} - 1}\right)$	$T_R = TD \bullet \left(\frac{4.85}{1 - M^2}\right)$

where:

T_P = Operate time
T_R = Reset time
TD = Time dial (multiplier)
M = Multiple of pickup current ($I_{measured}/I_{pickup}$)

Figure 5.67–Figure 5.69 show the five U.S. curves and the five IEC curves.

Figure 5.67 U.S. Curves: U1, U2, U3, and U4

Figure 5.68 U.S. Curve U5 and IEC Curves C1, C2, and C3

Figure 5.69 IEC Curves C4 and C5

Figure 5.70 uses Element 01 as an example to show the logic for the 51 element. All five inputs are Group settings. Essentially, the logic compares the magnitude of an operating quantity (51O01) to pickup setting 51P01.

Figure 5.70 Time-Overcurrent Element

Operating Quantity

The 51 elements are unassigned, so you can select the operating quantity from many phase and sequence quantities, either fundamental or root-mean-square (rms), as *Table 5.7* shows.

NOTE: Secure negative-sequence and zero-sequence overcurrent elements in DSS applications by including (NOT SVBLK) in the torque-control equation. Phase overcurrent elements are inherently secure during DSS data loss.

Table 5.7 Fundamental or RMS Operating Quantities[a]

	Fundamental Quantities	RMS Quantities
Phase	I*pm*FM, IMAX*m*F	I*pm*RMS, IMAX*m*R
Combined	I*pqp*FM, IMAX*qp*F	I*pqp*RMS, IMAX*qp*R
Sequence	I1*m*M, 3I2*m*M, 3I0*m*M, I1*qp*M, 3I2*qp*M, 3I0*qp*M	

[a] Where:
p = A, B, C.
m = S, T, U, W, X, Y.
qp = ST, TU, UW, WX.

Pickup and Time-Dial Settings

NOTE: The 51 elements can combine terminals with mismatched CT ratios. In such a case, use the larger of the two CT ratios when selecting your multiple of pickup setting.

Pickup setting 51P01, operating on the ratio of the measured current to the pickup setting (multiple of pickup setting), moves the characteristic horizontally to vary the pickup current; time-dial (multiplier) setting 51TD01 moves the curve vertically to vary the operating time for a given multiple of pickup.

Both pickup (51P01) and time-dial (51TD01) settings are math variables instead of fixed settings. SEL math variables, unlike fixed settings that cannot be dynamically changed, allow for the adaptive changing of pickup and time-dial settings without the need for changing relay setting groups.

However, if your installation does not require adaptive pickup and/or time-dial settings changes, use the time-overcurrent element as a conventional 51 element. For a conventional element, simply enter the pickup and time-dial settings as numbers, such as:

51P01 := **1.5**
51TD01 := **1**

Setting Range Assignment and Limit Checks

Because the relay accepts both 1 A and 5 A secondary CTs, the relay assigns the element pickup setting range only after you select the operating quantity. For example, if the relay is set so that Terminal S is a 5 A CT, then the relay assigns the range 0.25 to 16.00 as the pickup range of all 51 elements that use any of the Terminal S quantities.

Example 5.5

Single Terminal S—5 A CT secondary

Terminal S has a 5 A nominal CT input, so the range is 0.25 (lower limit) to 16.0 (upper limit).

Example 5.6

Single Terminal T—1 A CT secondary

Terminal T has a 1 A nominal CT input, so the range is 0.05 (lower limit) to 3.2 (upper limit).

Upper and Lower Range Limits

When you use SEL math variables, the selected analog value can exceed the upper value of the pickup range, or it can fall below the lower value of the pickup range. When this happens, the relay assigns the appropriate threshold value to the element and continues to calculate the trip time. For the 51P*nn* pickup settings, the upper threshold is 3.2 for 1 A relays and 16 for 5 A relays. The lower threshold is 0.05 for 1 A relays and 0.25 for 5 A relays. For the 51TD*nn* time-dial settings, the U.S. curve thresholds are 0.5 and 15, and the IEC thresholds are 0.05 and 1.0. In addition, the relay also asserts the appropriate Relay Word bits: 51MM01 (pickup value out of bounds) and/or 51TM01 (time-dial value out of bounds).

Example 5.7

For example, you want a 1 A relay to pick up at 1.5 A when IN101 asserts and to pick up at 2 A when IN102 asserts (IN101 deasserted). Program the following:

51P01 := IN101 • 1.5 + IN102 • 2

With IN101 asserted (logical 1), and IN102 deasserted (logical 0), the 51P01 setting is:

(1 • 1.5) + (0 • 2) = 1.5 + 0 = 1.5

When IN102 asserts (IN101 deasserted), the 51P01 setting is:

(0 • 1.5) + (1 • 2) = 0 + 2 = 2

If, however, IN102 asserts while IN101 is still asserted, the 51P01 setting is:

(1 • 1.5) + (1 • 2) = 1.5 + 2 = 3.5

Because 3.5 exceeds the upper range value of 3.2, the relay clamps the setting at 3.2 and asserts Relay Word bit 51MM01.

Torque Control

SELOGIC control equation 51TC01 allows you to state the conditions when the element must run. When 51TC01 asserts (logical 1), Switch S1 in *Figure 5.70* closes and the relay evaluates input 51O01. For example, if the element should only measure when the HV circuit breaker (Terminal S, for example) is closed, enter the following:

51TC01 := **52CLS**

With this setting, Switch S1 closes only when 52CLS is a logical 1. If the element must measure all the time, enter the following:

51TC01 := **1**

EM Reset

Setting 51RS01 defines whether the curve resets slowly like an electromechanical disk or after one power system cycle when current drops below pickup. If you set 51RS01 = Y, then the relay resets according to the Reset Timer equations for that particular curve (see *Table 5.5* or *Table 5.6*). If you set 51RS01 = N, then the relay resets after one power system cycle when current drops below pickup.

Terminal Harmonic Blocking

When a distribution feeder is supplying a transformer, magnetizing inrush currents may cause overcurrent elements to operate when the line is energized. Second-harmonic blocking logic can prevent this by blocking such elements until inrush currents have subsided. As shown in *Figure 5.71*, this logic uses the ratio of the second-harmonic content of each phase to the fundamental current of the same phase to calculate the percent of the second-harmonic content. An independent instance of second-harmonic blocking logic is available on all SEL-487E current terminals.

Figure 5.71 Phase Inrush Detection Logic for Terminal m

In addition to inrush, CT saturation during faults can cause the relay to measure second-harmonic current. The second-harmonic blocking element may also assert briefly when the fundamental frequency current changes. Either condition might delay the supervised element. Set an unsupervised element higher than the expected inrush current to provide fast protection during large faults.

Instead of the relay providing this function in fixed logic, the Relay Word bits shown in *Figure 5.71* are available for you to apply as necessary for your protection application. For example, enter these Relay Words bits in the torque-control equation of the 50 or 51 elements to block these elements during transformer inrush conditions. To block the element in the presence of excessive second-harmonic content, a typical torque-control setting for Element 1 of the 51 protection element would be as follows:

51O01 := IMAXSF

51TC01 := NOT H2BKS

Line Protection Elements

The SEL-487E line protection includes mho or quadrilateral distance elements with integrated capacitor voltage transformer (CVT) transient detection, out-of-step blocking, and adaptive memory voltage logic. The relay supports as many as four phase and ground distance protection zones, each of which can be set in either the forward or reverse direction. Switch-onto-fault, load-encroachment, and harmonic-blocking logic are also included to supervise transmission, distribution, or transformer distance protection applications.

To simplify the setting process while maximizing flexibility, the settings are arranged in a multitier structure. Settings in Tiers 1–4 should be entered in the order shown. The following is a list of these settings along with their descriptions. All distance element settings and integrated security functions should be set after the Tier 4 settings.

Tier 1 settings—ECTTERM, EPTTERM, ELINE, VREF*m,* and ALTV*m* (*m* = S, T, U, W, X, Y).

Tier 2 settings—LINEIL1

Tier 3 settings—ELOADL1, ESOTFL1, EHBL1, EADVSL1, E21PL1, E21GL1

Tier 4 settings—E21MPL1, E21XPL1, E21MGL1, E21XGL1

Enable Line Protection Elements (ELINE). Line protection elements require an enabled current and voltage terminal, as selected by the ECTTERM and EPTTERM Group settings, respectively. For applications that require both voltage and current measurements (metering, distance, directional, etc.), the VREF*m* and ALTV*m* Group settings associate a voltage reference to each enabled current terminal.

The SEL-487E distance elements are designed to protect multiple lines or transformers simultaneously. The enable setting, ELINE, selects how many instances are active. The number of supported instances is determined by the relay ordering options.

Line Current Source (LINEIL1). The terminal selected by the LINEIL1 setting determines which terminal current is used in line protection elements, including mho or quadrilateral distance elements, load encroachment, switch-onto-fault, and line current harmonic-blocking logic.

Six sets of three-phase current terminals (S, T, U, W, X, or Y) and four sets of three-phase derived combination terminals (ST, TU, UW, or WX) are available for line protection in the SEL-487E. Use the VREF*m* and ALTV*m* Group settings to assign these current terminals to a voltage terminal (V or Z). You can use any current terminal that is assigned a voltage reference for distance protection by using the LINEIL1 Group setting. *Figure 5.72* and *Figure 5.73* show the source assignments for typical single and combined terminal applications, respectively.

Whenever combination terminals are used, the same voltage channel is used as the reference for both terminals. The VREF*m* setting associated with a combined terminal is the first terminal listed in the terminal name. For example, the combined Terminal TU is assigned a reference voltage by using the VREFT Group setting. See *Combined Terminals on page 5.59* for further considerations when using combined terminals.

Figure 5.72 Source Assignment for Single Current Terminal

Figure 5.73 Source Assignment for Combined Current Terminal

Enable Load Encroachment, Switch-Onto-Fault, and Harmonic Blocking (ELOADL1, ESOTFL1, EHBL1). These security functions all operate using the current source specified by the LINEIL1 Group setting and the voltage source specified by the associated voltage reference setting (VREF*m*). You can enable these functions independently of distance elements. To secure distance applications, harmonic-blocking outputs are used in the default torque-control equations for both the distance and directional elements; load encroachment outputs are used in the default phase distance element torque-control equations.

Phase and Ground Distance Characteristics (E21PL1, E21GL1). These settings determine which characteristic is active for distance protection. Use the E21PL1 setting to select either the mho or the quadrilateral characteristic for phase distance protection. Similarly, use the E21GL1 setting to select either the mho or the quadrilateral characteristic for ground distance protection.

Enable Distance Element Zones (E21MPL1, E21XPL1, E21MGL1, E21XGL1). You can enable as many as four zones for phase distance protection that use either the mho or the quadrilateral characteristics by using the E21MPL1 and E21XPL1 settings, respectively. You can also enable four zones for ground distance protection that use either mho or quadrilateral characteristics by using the E21MGL1 and E21XGL1 settings, respectively.

Directional Control

The SEL-487E automatically integrates an existing directional element associated with the terminal selected by the LINEIL1 Group setting.

When you enter directional control settings for distance protection applications, the relay automatically populates the directional control Group settings for the terminal that is selected by the LINEIL1 Group setting. *Table 5.8* shows a complete list of all automatically populated terminal settings.

Table 5.8 Line-to-Terminal Setting Integration (Sheet 1 of 2)

Line 1 Setting	Populated Terminal m Setting[a]	Description
CTPL1[b]	CTP*m*	Current transformer polarity
50FPL1	50FP*m*	Forward direction O/C pickup
50RPL1	50RP*m*	Reverse direction O/C pickup
Z2FL1	Z2F*m*	Forward direction Z2 threshold
Z2RL1	Z2R*m*	Reverse direction Z2 threshold
A2L1	A2*m*	Positive-sequence restraint factor, I2/I1
ORDERL1	ORDER*m*	Ground directional element priority
K2L1	K2*m*	Zero-sequence restraint factor, I2/I0
Z0FL1	Z0F*m*	Forward direction Z0 threshold

Table 5.8 Line-to-Terminal Setting Integration (Sheet 2 of 2)

Line 1 Setting	Populated Terminal m Setting[a]	Description
Z0RL1	Z0R*m*	Reverse direction Z0 threshold
A0L1	A0*m*	Positive-sequence restraint factor, I0/I1
DIRBKL1	DIRBK*m*	Block phase and ground directional elements (SELOGIC control equation)

[a] m is the terminal selected by the LINEIL1 Group setting. Note that m is represented by a number in combination terminals, where 1 = ST, 2 = TU, 3 = UW, and 4 = WX.

[b] When the CTPL1 Group setting is set to N, line current analog quantities are inverted. This functions independently from the inverting logic associated with the Global setting EINVPOL.

To simplify integration and troubleshooting, the outputs of the directional element selected by the LINEIL1 Group setting have been assigned to similarly named Relay Word bits by using the terminal designation L1. These Relay Word bits are used throughout line protection for directional supervision.

Table 5.9 Terminal-to-Line Relay Word Bit Integration

Terminal m Output[a]	Derived Line Relay Word Bit	Description
*m*50QF	L150QF	Negative-sequence current above forward threshold, Line 1
*m*50QR	L150QR	Negative-sequence current above reverse threshold, Line 1
*m*50GF	L150GF	Zero-sequence current above forward threshold, Line 1
*m*50GR	L150GR	Zero-sequence current above reverse threshold, Line 1
*m*F32G	L1F32G	Forward ground directional element asserted, Line 1
*m*R32G	L1R32G	Reverse ground directional element asserted, Line 1
*m*F32V	L1F32V	Forward zero-sequence ground directional element asserted, Line 1
*m*R32V	L1R32V	Reverse zero-sequence ground directional element asserted, Line 1
*m*F32QG	L1F32QG	Forward negative-sequence ground directional element asserted, Line 1
*m*R32QG	L1R32QG	Reverse negative-sequence phase directional element asserted, Line 1
*m*32QGE	L132QGE	Negative-sequence ground directional element enabled, Line 1
*m*32VE	L132VE	Zero-sequence voltage directional element enabled, Line 1
*m*F32P	L1F32P	Forward phase directional element asserted, Line 1
*m*R32P	L1R32P	Reverse phase directional element asserted, Line 1
*m*32QE	L132QE	Negative-sequence phase directional element enabled, Line 1
*m*F32Q	L1F32Q	Forward negative-sequence phase directional element asserted, Line 1
*m*R32Q	L1R32Q	Reverse negative-sequence phase directional element asserted, Line 1
ILOPk[b]	ILOPL1	Internal loss of potential, Line 1
VPOLk[b]	VPOLL1	Polarizing voltage available, Line 1

[a] m is the current terminal selected by the LINEIL1 Group setting. Note that m is represented by a number in combination terminals, where 1 = ST, 2 = TU, 3 = UW, and 4 = WX.

[b] Group settings VREFm and ALTVm associate a voltage reference k to each current Terminal m (where m = S, T, U, W, X, Y and k = V, Z).

For more information on the SEL-487E directional elements, see *Directional Control for Ground-Overcurrent Elements on page 5.99* and *Directional Control for Phase and Negative-Sequence Overcurrent Elements on page 5.109*.

Polarizing Quantity for Mho Distance Element Calculations

The relay uses positive-sequence voltage as the polarizing quantity for mho distance element calculations. Memory voltage polarization ensures proper operation during zero-voltage three-phase faults and provides expansion of the mho

characteristic back to the source impedance, improving fault-resistance coverage. However, longer memory may impair distance element security when a power system disturbance causes a fast frequency excursion. For this reason, the polarization memory is adaptive.

The relay normally uses positive-sequence voltage with no memory, which works satisfactorily for all faults other than zero-voltage three-phase faults. When the relay determines that the positive-sequence voltage magnitude is lower than a threshold, it automatically switches to a long memory polarizing quantity. When the Group setting ESCMPL1 := Y, the relay uses the medium length memory and automatically switches to the long memory polarizing quantity when the relay detects voltage inversion or the positive-sequence voltage magnitude is lower than a threshold.

Series-Compensation Line Logic

In applications where there is a series capacitor on an adjacent line, for any SEL-487E on noncompensated lines, set ESCMPL1 := Y. This allows an instantaneous distance element to be set to the desired sensitivity yet still be secure during the voltage reversal that will occur when a neighboring compensated line experiences a fault. The SEL-487E does not provide protection logic to account for series capacitor reactance (XC) on series-compensated lines. For more information on setting the relay for series-compensated lines, see SEL Application Guide AG2000-11, “Applying the SEL-321 Relay on Series-Compensated Systems.”

Distance Element Pole-Open Logic

The SEL-487E pole-open logic detects any-pole-open and three-pole-open conditions, as shown in *Figure 5.74*. If the breaker status is measured as open and any phase current drops less than the user-defined threshold, the L1PO output asserts, indicating an any-pole-open condition. When all three poles are open, L13PO asserts. L13PO deasserts 3PODL1 cycles after any of the poles close. If any pole is declared to be open, all distance elements are blocked from operation.

Figure 5.74 Pole-Open Diagram

The breaker status used in *Figure 5.74* is determined using the SELOGIC control equations corresponding to the terminal selected by the LINEIL1 Group setting. If a combination terminal is selected by LINEIL1, the 52A_*m* SELOGIC control equation for both terminals must evaluate to 0 before L1POA can assert.

CVT Transient Detection

The SEL-487E detects CVT transients that can cause Zone 1 instantaneous distance elements to overreach during external faults. If CVT transient blocking is enabled and the relay detects a high source-to-impedance ratio (SIR), the relay delays asserting the Zone 1 element for as long as 1.5 cycles to allow the CVT transients to stabilize.

You do not need to enter settings. The relay adapts automatically to different system SIR conditions by monitoring the measured voltage and current.

If the distance calculation does not change significantly (i.e., is smooth), the SEL-487E unblocks the CVT transient blocking that results from low voltage and low current during close-in faults that are driven by a source with a high SIR. Therefore, Zone 1 distance elements operate without significant delay for close-in faults.

Consider using CVT transient detection logic when you have both of the following conditions:

- The SIR is greater than or equal to five
- The CVTs have active ferroresonance-suppression circuits (AFSC)

The following conditions can aggravate CVT transients:

- The CVT secondary has a mostly inductive burden
- A low C value CVT, as defined by the manufacturer

Figure 5.75 Zone 1 CVT Transient Detection Logic

SIR is defined as follows:

$$SIR = \frac{Z_{1S}}{Z_R}$$

where:

Z_{1S} = positive-sequence source impedance
Z_R = distance element reach

Out-of-Step Blocking Logic

You can enable out-of-step (OOS) blocking logic on each zone by listing the zone in the EOOSL1 enable setting. The OOS logic determines whether a power swing is stable. You can set this relay logic to block distance protection when the measured positive-sequence impedance (Z1) remains between the inner and outer zone longer than the OOS blocking delay (OSBDL1 setting). All resistive reach settings are configured parallel to the line angle. All reactance reach settings are set perpendicular to the line angle.

Figure 5.76 OOS Characteristics

If a three-phase fault occurs during a power swing that has operated the OOS logic, the logic also overrides OOS blocking; a set of internally derived inner blinders encompasses the protected line and detects internal three-phase faults.

The following rules apply when you set the OOS logic:

- Settings X1TIL1, X1TOL1, R1RIL1, and R1ROL1 must be set to a positive value.
- Settings X1BIL1, X1BOL1, R1LIL1, and R1LOL1 must be set to a negative value.
- Setting R1RIL1 must be set less than R1ROL1.
- Setting R1LIL1 must be set greater than R1LOL1.
- Setting X1TIL1 must be set less than X1TOL1.
- Setting X1BIL1 must be set greater than X1BOL1.
- The minimum separation between settings R1RIL1 and R1ROL1 is $0.25/I_{NOM}$.
- The minimum separation between settings R1LIL1 and R1LOL1 is $0.25/I_{NOM}$.
- The minimum separation between settings X1TIL1 and X1TOL1 is $0.25/I_{NOM}$.
- The minimum separation between settings X1BIL1 and X1BOL1 is $0.25/I_{NOM}$.

Figure 5.77 OOS Positive-Sequence Measurements

The UBOSDL1 timer length is the expected duration of the power swing within the three-phase unblocking zone. The relay bases the calculation on the actual time required for the swing to traverse from the outer zone to the inner zone before entering the three-phase unblocking zone. If the swing remains inside the three-phase unblocking zone for a period greater than UBOSDL1, an unblock signal asserts. You can increase the adaptive UBOSDL1 timer calculation in multiples of setting, UBOSFL1. If UBOSFL1 is a multiplier of one, the relay calculates the expected time to traverse across the inner blinders based on the rate at which the swing moved from the outer zone to the inner zone. Similarly, if UBOSFL1 is a multiplier of four, the relay multiplies UBOSDL1 by four.

The SEL-487E automatically resets the OOS blocking logic if this logic asserts for more than two seconds while the positive-sequence impedance locus is within the outer zone. During an unstable power swing, the relay also resets the OOS blocking logic each time the swing impedance exits the outer zone. You can latch the OOS blocking function during an unstable power swing to continue blocking the distance elements if the power swing impedance locus moves outside of the outer zone and before it comes back inside the outer zone on its next swing cycle. If latched, the OOS blocking logic resets one second after the power system stops the out-of-step logic. Latching the OOS blocking logic gives you an advantage in that the relay can successfully block uncontrolled distance element operations if a fault occurs when the unstable swing impedance is outside of the outer zone.

Relay elements detect internal faults that occur during a power swing and take the appropriate action (unblock). Set the Group setting OSBLTL1 = Y to enable the latching OOS blocking logic.

Figure 5.78 OOS Blocking Logic

The OOS logic detects all power swings that enter the OOS characteristics. If either negative-sequence directional element, 67QF*n*L1 or 67QR*n*L1, picks up (i.e., an unbalanced fault has occurred) during a power swing, the logic overrides OOS blocking. The negative-sequence current level detector, 50QU*n*L1, determines the sensitivity of the 67QF*n*L1 or 67QR*n*L1 elements. These outputs are used with the OOS blocking logic output OSB*n*L1 to supervise both the quadrilateral and the mho distance elements.

Figure 5.79 OOS Override Logic

Transformer Distance Protection

Distance elements are often used as backup protection to transformer differential elements because they maintain coordination with nearby devices and can be set sensitively and securely for heavy load conditions. Configure distance elements in the SEL-487E to protect transformer windings via the Group setting EXFMRL1.

The inherent phase shift associated with most transformer constructions can challenge traditional fault selection logic. In addition to phase shifts, delta windings remove zero-sequence content from the measured currents, further challenging fault type identification and ground loop (AG, BG, CG) current supervision. To overcome these challenges, zones that are listed in the Group setting EXFMRL1 have zero-sequence current and fault identification supervision bypassed.

Identifying which loop should assert for a given fault type varies with transformer construction. For phase-to-phase and three-phase faults, the faulted loop with the greatest fault current measures the expected apparent impedance,

$m \bullet ZT_1$, where $m \bullet ZT_1$ equals a percentage of the transformer positive-sequence impedance relative to the fault location (m). This is true for any transformer construction.

For ground faults where the transformer constructions includes both a delta-connected and wye-connected windings, the faulted loop with the greatest current magnitude measures an apparent impedance of ($m \bullet ZT_1 + Z_{error}$), where Z_{error} is a function of the zero-sequence network impedance. Z_{error} causes distance elements to underreach for ground faults, causing apparent impedances to appear further away than expected. For example, when measuring delta-side currents in radial systems, $Z_{error} = 0.5 \bullet ZT_0$ for wye-side ground faults, where ZT_0 is the transformer zero-sequence impedance. For non-radial systems, consider additional sources of error, such as remote source impedance, when evaluating the effective reach for ground fault protection.

Table 5.10 shows the relationship between a fault on the far side of a delta-wye transformer and the corresponding loop in the relay that measures the expected apparent impedance to the fault.

Table 5.10 Delta-Wye Faulted Loop Mapping

Far-Side Fault Type	Corresponding Loop on Relay Side	Measured Impedance
Three-phase	Any loop	$m \bullet ZT_1$
Phase-to-phase	Ground loop with largest fault current	$m \bullet ZT_1$
Ground	Phase-to-phase loop with largest fault current	$m \bullet ZT_1 + Z_{error}$

Set the reach for phase-to-phase instantaneous elements for a three-phase fault on the far side of the transformer to maintain security because phase-to-phase loops operate for both ground and three-phase faults on the far side of the transformer. Because the effective reach for ground faults on the far side of the transformer is reduced, consider other backup protection functions such as REF or neutral overcurrent elements for ground fault transformer protection. The resistive reach for quadrilateral elements should not exceed the reactive reach to maintain security with the active, non-faulted loops.

Mho Phase Distance Elements

NOTE: See the SEL-421 instruction manual for protection application examples that use distance elements for distribution or transmission line protection.

The SEL-487E has four independent zones of mho phase distance protection. The mho phase distance protection operates for phase-to-phase, phase-to-phase-to-ground, and three-phase faults. Set the reach and direction for each zone independently. *Figure 5.80* illustrates how the reach (Z*n*MPL1), positive-sequence line impedance angle (Z1ANGL1), and direction (DIR*n*L1) settings are used to form the mho operating characteristics. The mho phase distance elements use positive-sequence voltage polarization for increased reliability and also generate a dynamic expanding mho characteristic that provides additional fault resistance coverage. For more information on dynamic expanding mho characteristics, refer to the technical paper "Understanding the Dynamic Mho Distance Characteristic" by Donald D. Fentie.

Figure 5.80 Mho Phase Distance Element Characteristic

Settable zone overcurrent supervision settings are available for phase distance elements (Z50P*n*L1, where *n* = 1–4). These advanced settings (EADVSL1 = Y) apply to both the mho and the quadrilateral distance elements and are useful in applications with series compensation. For more information on setting relays to protect series-compensated lines, see SEL Application Guide AG2000-11, "Applying the SEL-321 Relay on Series-Compensated Systems."

Figure 5.81 shows the A-B-phase mho distance element logic. The other fault calculations (B-C and C-A) have similar logic.

Figure 5.81 Mho Phase Distance Element Logic

Each zone of the mho phase distance element has an individual torque-control setting, Z*n*MPTC1 (*n* = 1–4). The mho phase distance elements are blocked from operation when the respective zone Z*n*MPTC1 input evaluates to a logical 0. Load-encroachment and harmonic-blocking outputs are included in the default settings of Z*n*MPTC1 to secure the mho distance element during conditions of high load, transformer energization, or transformer overexcitation.

Quadrilateral Phase Distance Elements

The SEL-487E has four independent zones of quadrilateral phase distance protection. All zones are independently set and configured to be in the forward or reverse direction by the DIR*n*L1 setting. *Figure 5.82* and *Figure 5.83* illustrate how the reactance reach (XP*n*L1), resistive reach (RP*n*L1, *n* = 1–4), and positive-sequence line impedance angle (Z1ANGL1) settings are used to form the quadrilateral phase operating characteristics.

For forward-looking zones, there is no setting for the left resistive blinder. The value is fixed at the negative value of the lowest forward-looking resistive RP*n*L1 setting. For example, if DIR1L1 = F, RP1L1 = 3.8 Ω, and if RP1L1 is the minimum of RP1L1–RP4L1, the left blinder setting becomes –3.8 Ω.

For reverse-looking zones, there is no setting for the right resistive blinder. The value is fixed at the positive value of the lowest reverse-looking resistive RP*n*L1 setting. For example, if DIR1L1 = R, DIR2L1 = R, RP2L1 = 3.2 Ω, and if RP2L1 is the minimum of RP1L1–RP4L1, the right blinder setting becomes 3.2 Ω.

The resistive reach of the RP*n*L1 quadrilateral phase distance element setting is reduced to RP*n*L1C based on the ratio of I2/I1 by using the following equation when L132QE is not asserted.

$$\mathrm{RP}n\mathrm{L1C} := \mathrm{RP}n\mathrm{L1} \bullet \left(0.25 + 0.75 \bullet \left(\frac{3\mathrm{I2L1M}}{3 \bullet \mathrm{I1L1M}}\right)\right)$$

Equation 5.22

NOTE: The reactance element is fixed to use loop current for polarization (ESPQDL1 = Y) whenever distance elements are configured for transformer applications (EXFMRL1 != N).

The resistance element uses the loop current for polarization while the reactance element can use either the loop current or the negative-sequence current for polarization. Using the negative-sequence current for polarizing the reactance element provides adaptation to prevent overreach for remote faults while also providing increased fault resistance coverage. When you set the reactance element to use self-polarization (i.e., polarized with the loop current) via the ESPQDL1 setting, the reactance blinders become fixed on the impedance plane without any adaptation to load conditions. The resistance blinders are always polarized with the loop current.

Each quadrilateral phase distance element is supervised by the corresponding Relay Word bit (ENX2AB1, ENX2BC1, or ENX2CA1) during unbalanced fault conditions (32QE = 1). This supervisory condition secures the reactance element in the quadrilateral phase distance element against unusual, unbalanced load conditions where the currents are unbalanced but not the voltages.

TANGPL1, the tilt angle setting, tilts the reactance values but does not affect the resistance values. *Figure 5.82* shows the quadrilateral-phase characteristic with TANGPL1 = 0.

Figure 5.83 shows the quadrilateral phase distance element characteristic with TANGPL1 = –10 degrees. The pivot point of the tilt is the line impedance and not the reactance axis. There is only one TANGPL1 setting, and it applies to all zones of the quadrilateral phase distance element. TANGPL1 is used to correct for negative-sequence network nonhomogeneity when using the sequence current to polarize the quadrilateral element. If the self-polarized elements are enabled, the TANGPL1 setting is hidden and forced to a default of –15 degrees to secure the element against the inherent overreaching nature caused by self-polarization. If the advanced setting is enabled (EADVSL1 = Y), this setting becomes settable. For more information on setting the tilt angle setting or the adaptive behavior for the quadrilateral distance elements, refer to the technical paper “Adaptive Phase and Ground Quadrilateral Distance Elements” by Fernando Calero, Armando Guzmán, and Gabriel Benmouyal, available at selinc.com.

NOTE: A tilt angle that is negative tilts the reactance in the clockwise direction. Some relay manufacturers use a positive value for this behavior.

Figure 5.82 Quadrilateral Phase Distance Element Characteristic (TANGP = 0)

Figure 5.83 Quadrilateral Phase Distance Element Characteristic (TANGP = –10 degrees)

Settable zone overcurrent supervision settings are available for phase distance elements (Z50P*n*L1, where *n* =1–4). These advanced settings (EADVSL1 = Y) apply to both the mho and the quadrilateral distance elements and are useful in

applications with series compensation. For more information on setting relays to protect series-compensated lines, see SEL Application Guide AG2000-11, "Applying the SEL-321 Relay on Series-Compensated Systems."

Each zone of the quadrilateral phase distance element has an individual torque-control setting, Z*n*XPTC1 (*n* = 1–4). The quadrilateral phase distance elements are blocked from operation when the respective zone Z*n*XPTC1 input evaluates to a logical 0. Load-encroachment and harmonic-blocking outputs are included in the default settings of Z*n*XPTC1 to secure the quadrilateral distance element during conditions of high load, transformer energization, or transformer overexcitation.

Figure 5.84 Quadrilateral Phase Distance Element Logic

Mho Ground Distance Elements

The SEL-487E has four independent zones of mho ground distance protection. The reach for each zone is set independently and configured for either forward or reverse directions by the DIR*n*L1 setting (*n* = 1, 2, 3, 4). The mho ground distance elements use positive-sequence voltage polarization for security and generate a dynamic expanding mho characteristic by using a similar characteristic, as shown in *Figure 5.80*. Use the k0M*n*L1 and k0A*n*L1 settings to configure the

magnitude and angle of the zero-sequence compensation factors for ground distance elements on a per-zone basis. If you set k0M*n*L1 to AUTO, the relay automatically calculates the values of k0*n*L1 based on the following equation:

$$\overline{k0nL1} = \frac{\overline{Z_{0L1}} - \overline{Z_{1L1}}}{3 \bullet \overline{Z_{1L1}}}$$

Equation 5.23

NOTE: INOML1 is the CT nominal current value associated with the current terminal selected by Group setting LINEIL1. This is used in mho, load-encroachment, and line harmonic-blocking logic.

where:

Z_{1L1} = positive-sequence transmission line impedance

Z_{0L1} = zero-sequence transmission line impedance

The mho ground distance protection operates for single phase-to-ground faults for line applications. Zones listed in the EXFMRL1 Group setting can also operate for phase-to-phase faults when protecting transformer windings. See *Transformer Distance Protection on page 5.83* for more information on setting the SEL-487E distance elements in transformer applications.

Settable zone overcurrent supervision settings are available for ground distance elements (Z50G*n*L1, where *n* =1–4). These advanced settings (EADVSL1 = Y) apply to both th mho and the quadrilateral distance elements and are useful in applications with series compensation. For more information on setting relays to protect series-compensated lines, see SEL Application Guide AG2000-11, "Applying the SEL-321 Relay on Series-Compensated Systems."

Figure 5.85 Mho Ground Distance Element Logic

Each zone of the mho ground distance element has an individual torque-control setting, Z*n*MGTC1 (*n* = 1–4). The mho ground distance elements are blocked from operation when the respective zone Z*n*MGTC1 input evaluates to a logical 0. Harmonic-blocking outputs are included in the default settings of Z*n*MGTC1 to secure the mho ground distance element during conditions of transformer energization or transformer overexcitation.

Quadrilateral Ground Distance Elements

The SEL-487E has four independent zones of quadrilateral ground distance protection. The reach for each zone is set independently and configured for either forward or reverse directions by the DIR*n*L1 setting (*n* = 1, 2, 3, 4). Similar to the phase distance quadrilateral element in *Figure 5.82* and *Figure 5.83*, the reactance reach (XG*n*L1), resistive reach (RG*n*L1, *n* = 1–4), and positive-sequence line impedance angle (Z1ANGL1) settings are used to form the quadrilateral ground operating characteristics. Notice that for forward elements, the right resistive blinders are parallel to the line impedance, and not parallel to the to the reactance axis.

For forward-looking zones, there is no setting for the left resistive blinder. The value is fixed at the negative value of the lowest forward-looking resistive RG*n*L1 setting. For example, if DIR1L1 = F, RG1L1 = 3.8 Ω, and if RG1L1 is the minimum of RG1L1–RG4L1, the left blinder setting becomes –3.8 Ω.

For reverse-looking zones, there is no setting for the right resistive blinder. The value is fixed at the positive value of the lowest reverse-looking resistive RG*n*L1 setting. For example, if DIR1L1 = R, DIR2L1 = R, RG2L1 = 3.2 Ω, and if RG2L1 is the minimum of RG1L1–RG4L1, the right blinder setting becomes 3.2 Ω.

Use the k0M*n*L1 and k0A*n*L1 settings to configure the magnitude and angle of the zero-sequence compensation factors for ground distance elements on a per-zone basis (*n* = 1, 2, 3, 4). If you set k0M*n*L1 to AUTO, the relay automatically calculates the values of k0*n* as shown in *Equation 5.23*.

The user can choose either loop, negative-sequence, or zero-sequence current as the polarizing quantity for the ground reactance element based on the Group settings ESPQDL1 and XGPOLL1. Using negative-sequence or zero-sequence current for polarizing the reactance element provides adaptation to prevent overreach for remote faults while also providing increased fault resistance coverage.

NOTE: The reactance element is fixed to use loop current for polarization (ESPQDL1 = Y) whenever distance elements are configured for transformer applications (EXFMRL1 != N).

When setting the reactance element to use self-polarization (i.e., polarized with the loop current) via the ESPQDL1 setting, the reactance blinders become fixed on the impedance plane without any adaptation to the load conditions. The resistance blinders are always polarized with the loop current. The single setting ESPQDL1 applies to both the quadrilateral phase and quadrilateral ground elements.

Each quadrilateral ground distance element is supervised by the corresponding Relay Word bit (ENX2AG1, ENX2BG1, or ENX2CG1) during unbalanced fault conditions (L132QE = 1). This supervisory condition secures the reactance element in the quadrilateral ground distance element against unusual, unbalanced load conditions where the currents are unbalanced but not the voltages.

NOTE: A tilt angle that is negative tilts the reactance in the clockwise direction. Some relay manufacturers use a positive value for this behavior.

TANGGL1, the tilt angle setting, tilts the reactance values but does not affect the resistance values. Similar to the quadrilateral phase distance element, *Figure 5.86* shows the quadrilateral characteristic with TANGGL1 = 0 for the quadrilateral ground distance element. For more information on setting the tilt angle setting for

the quadrilateral distance elements, see the technical paper "Adaptive Phase and Ground Quadrilateral Distance Elements" by Fernando Calero, Armando Guzmán, and Gabriel Benmouyal, available at selinc.com.

The quadrilateral ground distance protection operates for single phase-to-ground faults for line applications. Zones listed in the EXFMRL1 Group setting can also operate for phase-to-phase faults when protecting transformer windings. See *Transformer Distance Protection on page 5.83* for more information on setting the SEL-487E distance elements in transformer applications.

Settable zone overcurrent supervision settings are available for ground distance elements (Z50G*n*L1, where *n* =1–4). These advanced settings (EADVSL1 = Y) apply to both the mho and the quadrilateral distance elements and are useful in applications with series compensation. For more information on setting relays to protect series-compensated lines, see SEL Application Guide AG2000-11, "Applying the SEL-321 Relay on Series-Compensated Systems."

Each zone of the quadrilateral ground distance element has an individual torque-control setting, Z*n*XGTC1 (*n* = 1–4). The quadrilateral ground distance elements are blocked from operation when the respective zone Z*n*XGTC1 input evaluates to a logical 0. Harmonic-blocking outputs are included in the default settings of Z*n*XGTC1 to secure the quadrilateral ground distance element during conditions of transformer energization or transformer overexcitation.

Figure 5.86 Quadrilateral Ground Distance Element Logic

Zone Time Delay

The SEL-487E supports a common timing delay philosophy for zone timing. All phase and ground distance elements are combined into a common Relay Word bit per zone, Z*n*PL1 and Z*n*GL1, respectively, as shown in *Figure 5.87*.

With common timing the phase and ground distance elements both drive a common zone timer, Z*n*DL1, as shown in *Figure 5.88*.

Figure 5.87 Zone 1–4 Distance Element Logic

If the timer input drops out while timing, the relay suspends the common zone timer for two cycles. This feature prevents resetting the timer when a fault evolves (e.g., the fault changes from single phase-to-ground to phase-to-phase-to-ground). If the two-cycle timer expires, the relay blocks the suspend-timing logic. When the zone timer is set to OFF, the output from the timer is blocked.

Figure 5.88 Common Zone Timers

Use the Z*n*L1T (Zone *n* Distance Protection) Relay Word bits to select common zone timing in SELOGIC trip equations.

The following example uses common timing for Zone 2 distance protection:

TRS := Z1L1 OR Z2TL1

Switch-Onto-Fault Logic

The switch-onto-fault (SOTF) logic permits specified protection elements to trip for a settable time after the circuit breaker closes. Specify these elements in the SELOGIC control equation TRSOTF1 (switch-onto-fault trip). The SOTF logic works in two stages: validating a possible SOTF condition (which asserts SOTFEL1) and initiating (enabling) the SOTF protection duration.

The relay validates an SOTF condition by sensing the following:

- **Upon circuit breaker opening:** Detection of a pole-open condition (L13PO) when the 52ENDL1 (52A Pole Open Qualifying Time Delay) setting is set to a value other than OFF.
- **Upon circuit breaker closing:** Detection of a pole-open condition (L13PO) when the CLENDL1 (Close Enable Time Delay) setting is set to a value other than OFF.

Select either or both methods for the validating procedure.

The relay initiates SOTF protection at these corresponding instances:

- **Circuit breaker opening:** 52ENDL1 timer times out
- **Circuit breaker closing:** CLENDL1 timer times out and the SELOGIC control equation CLMONL1 asserts

Circuit Breaker Opened SOTF Logic

Set ESOTFL1 to Y and set 52ENDL1 to a value other than OFF to enable the circuit breaker opened SOTF logic. When the circuit breaker opens, the 52ENDL1 timer operates when three poles open (L13PO asserts). When the three-pole-open condition lasts longer than the 52ENDL1 timer, the relay asserts the SOTFEL1 (SOTF Enable) Relay Word bit.

When the circuit breaker closes, the L13PO Relay Word bit deasserts after the 3PODL1 dropout time. When 3PO deasserts, the relay continues to assert the SOTFEL1 Relay Word bit for SOTFDL1 dropout time or until the logic detects a healthy voltage condition.

Circuit Breaker Closed SOTF Logic

You can detect a circuit breaker close bus assertion by monitoring the dc close bus. Connect a control input on the SEL-487E to the dc close bus. The control input energizes whenever a manual close or automatic reclosure occurs. Set the CLMONL1 (Close Signal Monitor) SELOGIC control equation to monitor the control input (e.g., CLMONL1 := IN102) and consequently detect close bus assertion.

Set ESOTFL1 to Y and set CLENDL1 to a value other than OFF to enable the circuit breaker closed SOTF logic. The CLENDL1 timer operates when three poles open (L13PO asserts). If the three-pole-open condition continues longer than the CLENDL1 time and the close bus asserts (the CLMONL1 SELOGIC control equation equals logical 1), the SOTFEL1 Relay Word bit asserts and remains asserted for the SOTFDL1 dropout time or until the logic detects a healthy voltage condition.

Figure 5.89 SOTF Logic

When the SOTFL1 Relay Word bit is added to a trip equation, the elements included in the TRSOTF1 SELOGIC control equation will initiate a trip instantaneously if they assert during the SOTFD time.

Load-Encroachment Logic

The load-encroachment logic prevents the load from causing the phase protection to operate. You can set the phase distance and phase overcurrent elements independent of the load. Two independent positive-sequence impedance characteristics monitor the positive-sequence load impedance (Z1L1) for both exported and imported load. *Figure 5.90* illustrates the load-encroachment logic.

The logic operates only if the positive-sequence current (I1L1) is greater than the positive-sequence threshold (10 percent of the nominal terminal current). The ZLOUTL1 Relay Word bit indicates that load is flowing out with respect to the relay (an export condition). The ZLINL1 Relay Word bit indicates that load is flowing in with respect to the relay (an import condition). *Figure 5.91* illustrates load-encroachment settings and corresponding characteristics in the positive-sequence impedance plane. Either Relay Word bit, ZLOUTL1 or ZLINL1, asserts if the relay measures a positive-sequence impedance that lies within the corresponding shaded region. The ZLOADL1 Relay Word bit is the OR combination of ZLOUTL1 and ZLINL1. Apply the ZLOADL1 Relay Word Bit in the phase distance or overcurrent torque-control setting to prevent the operation of these elements for loads within the defined enchroachment zone.

Figure 5.90 Load-Encroachment Logic

Figure 5.91 Load-Encroachment Characteristics

Line Current Transformer Inrush and Overexcitation Blocking Logic

The relay calculates the amount of second-, fourth-, and fifth-harmonic current present in the relay line current from a nearby transformer. For detecting an inrush condition, the relay calculates the second- and fourth-harmonic current content of each phase and compares the result to the fundamental current of that phase. If the second- or fourth-harmonic current content of that phase exceeds a user-defined threshold, the output from the second- and fourth-harmonic logic asserts.

For detecting an overexcitation condition, the relay calculates the fifth-harmonic current content of each phase individually and compares this result to the fundamental current of that phase. If the fifth-harmonic current content of any phase exceeds a user-defined threshold, the output from the overexcitation element asserts.

To enable the element, set EHBL1 = Y, then set the harmonic contents with the individual harmonic settings (PCT2L1 [second harmonic], PCT4L1 [fourth harmonic], and PCT5L1 [fifth harmonic]). Apply the harmonic blocking Relay Word Bits H2BKL1 and H5BKL1 in the distance element torque-control settings to prevent operation of these elements for transformer energization events.

Figure 5.92 A-Phase Line Inrush and Overexcitation Detection Logic

Fault Identification Logic

The purpose of the Fault Identification Logic is to determine, on a per-terminal basis, which phase(s) was involved in a fault. The logic determines the faulted phase by using current inputs from wye-connected CTs.

The logic does not determine the faulted phase for the following cases:

- Delta-connected CTs
- Where only zero-sequence current flows through the relay terminal (no negative-sequence current and no positive-sequence current)

This logic identifies a sector in which a faulted phase(s) can appear by comparing the angle between the negative- and zero-sequence currents I2*n* and I0*n* (*n* = S, T, U, W, X, Y, L1). *Table 5.11* shows the Relay Word bits for the three sectors and the phases associated with each sector.

Table 5.11 Fault Identification Logic Relay Word Bits

Relay Word Bit	Sector	Description
FIDEN		Fault Identification logic enabled—asserts when the relay has internally enabled the sector calculations
FSA	Sector A	A-Phase-to-ground fault or B-Phase to C-Phase-to-ground fault selected
FSB	Sector B	B-Phase-to-ground fault or C-Phase to A-Phase-to-ground fault selected
FSC	Sector C	C-Phase-to-ground fault or A-Phase to B-Phase-to-ground fault selected

Figure 5.93 shows a block diagram of the sector determination in which a faulted phase(s) can appear.

Figure 5.93 Sector Determination Block Diagram

In line applications (n = L1), if the angle between the negative- and zero-sequence currents cannot be accurately determined, the fault identification logic uses single-phase undervoltage elements for faulted-phase identification.

When any of the terminal-specific trip equations asserts (TRIPm), the relay uses the output from *Figure 5.93* to determine which particular phase(s) is involved in the fault for that particular terminal (m = S, T, U, W, X, Y). *Figure 5.94* shows the block diagram for this step. Note that this logic and the remainder of the logic discussed in this section is specific to Terminal S, T, U, W, X, and Y fault identification and does not apply for line applications (L1).

NOTE: Please note that the logic resets Relay Word bits PHA_m, PHB_m, PHC_m, and GROUNDm only at the beginning of the algorithm. If any of these Relay Word bits assert, they remain asserted until a subsequent fault on the same terminal occurs. For example, if the relay determines that a fault occurred on A-Phase of Terminal T, then PHA_T asserts and remains asserted until a subsequent fault occurs on Terminal T. Also, only the Relay Word bits of the faulted terminal are cleared; if Relay Word bits on other terminals are asserted, they remain asserted until a fault on that particular terminal occurs.

① See Table 5.12.

Figure 5.94 Block Diagram Showing Determination of the Particular Phase(s) Involved in the Fault

The steps for determining the faulted phase(s) for Terminal S are as follows:

- TRIPS asserts
- The relay clears Relay Word bits PHA_S, PHB_S, PHC_S, and GROUNDS
- The relay verifies that an overcurrent element listed in *Table 5.12* from Terminal S asserted
- The relay uses the sector outputs to determine the faulted phase(s)

Table 5.12 shows the overcurrent elements that the relay considers when determining the faulted phase(s). If any one of these elements is asserted, the relay determines the faulted phase.

NOTE: Be certain to include the output(s) of the 51 element (51Sxx, xx = 01–20) in both the trip equations of the two terminals of the combined overcurrent element. For example, for 51O06 = IATUFM, include 51T06 in TRT and TRU.

Table 5.12 Overcurrent Element the Relay Considers When Determining the Faulted Phase(s)

Element	Description
50*m*P*a*, 50*m*Q*a*, 50*m*G*a* (*a* = 1, 2, 3)	Instantaneous overcurrent elements
51S01–51S20	Time-overcurrent elements

Whereas the instantaneous overcurrent elements (50) are terminal specific, the Time-Overcurrent (51) elements can be assigned to any of the six terminals. The logic automatically associates the 51 element with the correct terminal by inspecting the operating quantity. For example, if 51 Element 05 was assigned Operating Quantity 51O05 = IAUFM, then the relay associates Terminal U with 51S05. When TRIPU and 51S05 assert, the relay determines the faulted phase for Terminal U.

For combined terminal operating quantities such as IATUFM, the relay associates both Terminal T and Terminal U with the 51 element. For example, if you assign 51 Element 06 Operating Quantity 51O06 = IATUFM, then the relay associates both Terminal T and Terminal U with 51 Element 06.

Directional Control for Ground-Overcurrent Elements

For each terminal, the SEL-487E offers a choice of two independent voltage-polarized directional elements (negative-sequence and zero-sequence) to supervise the ground-overcurrent elements. In addition, you can also use the REF elements if you prefer current polarization instead of voltage polarization. You can use either negative-sequence (Q) or zero-sequence polarization (V), or a combination of the two (QV or VQ). When using the combination setting, select your polarization preference with the ORDER setting. *Table 5.13* shows the two directional elements, their availability as a function of the PT connections, and the effect of the ORDER setting in terms of the preferred directional element. Be aware that directional elements are not available for PTs or CTs connected in delta (PTCON*k* = D or CTCON*m* = D, see *Delta-Connected CTs on page 5.51*).

Table 5.13 Availability of Directional Elements

ORDER Settings	Corresponding Ground Directional Element	CT Connection PTCONk =[a]	PT Connection PTCONk =[a]	Polarization Preference	
				First Choice	Second Choice
Q	Negative-sequence	Y	Y	—	—
QV	Negative- and zero-sequence	Y	Y	Q (*m*32QGE)[b]	V (*m*32VE)[b]
V	Zero-sequence	Y	Y	V (*m*32VE)[b]	—
VQ	Negative- and zero-sequence	Y	Y	V (*m*32VE)[b]	Q (*m*32QGE)[b]

[a] k = V, Z.
[b] m = S, T, U, W, X, Y, 1, 2, 3, 4 (combined terminals: 1 = ST, 2 = TU, 3 = UW, 4 = WX).

Figure 5.95 shows a block diagram of the directional elements. Note that the order in which the ORDER setting lists directional elements (Q and V) determines the priority in which these elements operate, as selected by the Best Choice Ground Directional Element logic. See the discussion on setting ORDER under *Directional Control Settings on page 5.113*.

Figure 5.95 Block Diagram of the Directional Elements

Following is a discussion of each of the function blocks in *Figure 5.95*.

Negative-Sequence Internal Enable Function Block

Figure 5.96 shows the enable logic for the negative-sequence directional element. This logic checks the validity of the settings in *Table 5.14*, checks for a loss-of-potential condition, and compares the negative-sequence current, 3I2*q*FM (*q* = S, T, U, W, X, Y, ST, TU, UW, WX), against the following four values:

- 50FP*m*—the forward current threshold
- 50RP*m*—the reverse current threshold
- a2*m* • 3I1*q*FM—the positive-sequence current (adjusted by a2, the positive-sequence restraint factor)
- k2*m* • 3I0*q*FM—the zero-sequence current (adjusted by k2, the zero-sequence restraint factor)

NOTE: Figure 5.96 has internal enables 32QE and 32QGE, which the directional element logic uses to control negative-sequence and zero-sequence overcurrent elements.

Table 5.14 Enable Logic Checks for Negative-Sequence Element

Setting	Value Required for Valid Setting
E50*m*[a]	Q (enable negative-sequence overcurrent element)
VREF*n*[b]	V or Z (voltage terminals)
ORDER*m*[a]	Includes Q (negative sequence)
E50[c]	Terminal Name (S, T, U, W, X, Y, ST, TU, UW, or WX)
E67*m*[a]	Y
E50*m*[a]	Includes G (enable zero-sequence overcurrent element)

[a] m = S, T, U, W, X, Y, 1, 2, 3, 4 (combined terminals: 1 = ST, 2 = TU, 3 = UW, 4 = WX).
[b] n = S, T, U, W, X, Y.
[c] Combination terminals are only available for channels with the same nominal current rating, same CT connection (CTCON), and same voltage reference (VREF).

Note:
S_1 = 1 if (VREFn = V AND ALTVn = 0) OR (VREFn = Z AND ALTVn = 1)
S_1 = 2 if (VREFn = Z AND ALTVn = 0) OR (VREFn = V AND ALTVn = 1)

$a2 = \frac{I2}{I1}$

$k2 = \frac{I2}{I0}$

Where:
n = S, T, U, W, X, Y
m = S, T, U, W, X, Y, 1, 2, 3, 4
q = S, T, U, W, X, Y, ST, TU, UW, WX
For combined current applications (m = 1–4), the InBK bit is derived from the logical OR of the terminal specific blocking bits:

Figure 5.96 Internal Enables for Negative-Sequence (m32QE) and Zero-Sequence (m32QGE) Directional Elements

When a loss-of-potential (LOP) condition occurs (Relay Word bit ILOPV or ILOPZ asserts), all the internal enables are disabled. Also, the directional element blocking SELOGIC equation (DIRBLKm) is set to 87XBK2 OR 87XBK5 by default and blocks the element when the second-harmonic or fifth-harmonic elements pick up, avoiding relay misoperations during transformer inrush conditions (see *Directional Control Settings on page 5.113* for the restraint factors).

Zero-Sequence Internal Enable Functional Block

Figure 5.97 shows the enable logic for the zero-sequence directional element. This logic checks the validity of the settings in *Table 5.15*, selects the appropriate voltage source, verifies 3V0 voltage supervision threshold is met (32GVSm), checks for a LOP condition, and compares the zero-sequence current, 3I0qFM (q = S, T, U, W, X, Y, ST, TU, UW, WX), against the following three values:

- 50FPm—the forward current threshold
- 50RPm—the reverse current threshold
- a0m • 3I1qFM—the positive-sequence current (adjusted by a0, the positive-sequence restraint factor)

Table 5.15 Enable Logic Checks for Zero-Sequence Element

Setting	Value Required for Valid Setting
E50*m*[a]	G (enable zero-sequence overcurrent element)
VREF*n*[b]	V or Z (voltage terminals)
ORDER*m*[a]	Includes V (zero-sequence)
E50[c]	Terminal Name (S, T, U, W, X, Y, ST, TU, UW, or WX)
E67*m*[a]	Y

[a] m = S, T, U, W, X, Y, 1, 2, 3, 4 (combined terminals: 1 = ST, 2 = TU, 3 = UW, 4 = WX).
[b] n = S, T, U, W, X, Y.
[c] Combination terminals are only available for channels with the same nominal current rating, same CT connection (CTCON), and same voltage reference (VREF).

Figure 5.97 Internal Enable (m32VE) for Zero-Sequence Directional Element

Negative-Sequence Directional Calculation Block

Figure 5.98 shows the negative-sequence directional element logic. For each terminal, Group setting VREF*n* determines which loss-of-potential (ILOPV or ILOPZ) value, voltage blocking bit (VVBK or VZBK), and negative-sequence voltage (3V2VCF or 3V2ZCF) value the algorithm uses in the directional calculations. The directional calculations produce a signed impedance Z2*m* (see *Equation 5.24*) that the logic compares against Z2FTH*m*, the forward threshold, and Z2RTH*m*, the reverse threshold (see *Equation 5.25–Equation 5.28* for the threshold calculations). Inputs *m*50QF and *m*50QR are from the internal enable logic (see *Figure 5.96*). At the bottom, inputs ORDER and *m*32VE form the Best Choice Ground Directional Element logic selection.

Figure 5.98 Negative-Sequence Directional Calculation Logic (Ground Elements)

Figure 5.99 shows the characteristic of the negative-sequence directional element, consisting of a forward threshold and a reverse threshold.

Figure 5.99 Negative-Sequence Directional Element Characteristic

Figure 5.100 shows a system with Fault F1 and Fault F2. These faults are two separate, close-in, A-Phase faults. Fault F1 is in the forward direction with respect to Relay R, and Fault F2 is in the reverse direction with respect to Relay R. For the purpose of the following discussion, assume that both faults are at the line angle.

Figure 5.100 Close-In, Single-Phase Fault F1 and Fault F2

Figure 5.101 shows the phasor relationships for Fault F1 at the line angle Z1ANG. Using A-Phase as reference, we see that the fault current lags the A-Phase voltage by the line angle Z1ANG. All three sequence components of the

current are in phase with the A-Phase fault current. However, the negative-sequence voltage and the zero-sequence voltages are 180 degrees out-of-phase with the A-Phase voltage.

Figure 5.101 Phasor Relationships for an A-Phase-to-Ground Fault

For each phase, the negative-sequence directional element uses *Equation 5.24* to determine the signed quantity Z2*m*.

$$Z2m = \frac{\mathrm{Re}[3V2kCF \bullet (3I2qCF \bullet 1\angle Z1ANGm)^*]}{3I2qFM^2}$$

Equation 5.24

where:

3V2*k*CF = negative-sequence voltage in phasor form
3I2*q*CF = negative-sequence current in phasor form
1∠Z1ANG*m* = the line angle in degrees
3I2*q*FM = magnitude of the negative-sequence current (scalar)
* = complex conjugate
Re = real part of
m = S, T, U, W, X, Y, 1, 2, 3, 4
q = S, T, U, W, X, Y, ST, TU, UW, WX
k = V, Z

If we assume 3V2VCF = 100∠180°, 3I2SCF = 10∠–80°, 3I2SFM = 10, and Z1ANGS = 1∠80°, the directional calculation for Terminal S is as follows:

$$Z2S = \frac{\mathrm{Re}[100\angle 180° \bullet (10\angle -80° \bullet 1\angle 80°)^*]}{(10)^2}$$

$$Z2S = \frac{\mathrm{Re}[100\angle 180° \bullet 10\angle 0°]}{100}$$

$$Z2S = \frac{\mathrm{Re}[1000\angle 180°]}{100}$$

$$Z2S = \frac{\mathrm{Re}[-1000 + j0]}{100}$$

$$Z2S = -10\Omega$$

Therefore, for a fault in the forward direction, Z2S has a negative value.

Figure 5.102 shows the phasor relationships for a reverse Fault 2 at the line angle Z1ANG.

Figure 5.102 Phasor Relationships for a Reverse A-Phase-to-Ground Fault

If we assume 3V2VCF = 100∠180°, 3I2SCF = 10∠100°, 3I2SFM = 10, and Z1ANGS = 1∠80°, the calculation for Terminal S is as follows:

$$Z2S = \frac{Re[100\angle 180° \bullet (10\angle 100° \bullet 1\angle 80°)^*]}{(10)^2}$$

$$Z2S = \frac{Re[100\angle 180° \bullet 10\angle 180°]}{100}$$

$$Z2S = \frac{Re[1000\angle 0°]}{100}$$

$$Z2S = (10\Omega)$$

Therefore, for a fault in the reverse direction, Z2S has a positive value.

To form the distinct shape of the thresholds, the element computes the forward threshold (Z2FTH*m*) and the reverse threshold (Z2RTH*m*) as described below.

Negative-Sequence Directional Element Forward Threshold Calculation

If Z2F*m* Setting ≤ 0, Forward Threshold (Z2FTH*m*) =

$$0.75 \bullet Z2Fm - 0.25 \bullet \left|\frac{3V2kCF}{3I2qCF}\right|$$

Equation 5.25

If Z2F*m* Setting > 0, Forward Threshold (Z2FTH*m*) =

$$1.25 \bullet Z2Fm - 0.25 \bullet \left|\frac{3V2kCF}{3I2qCF}\right|$$

Equation 5.26

Negative-Sequence Directional Element Reverse Threshold Calculation

If Z2R*m* Setting ≥ 0, Reverse Threshold (Z2RTH*m*) =

$$0.75 \bullet Z2Rm + 0.25 \bullet \left|\frac{3V2kCF}{3I2qCF}\right|$$

Equation 5.27

If Z2R*m* Setting < 0, Reverse Threshold (Z2RTH*m*) =

$$1.25 \bullet Z2Rm + 0.25 \bullet \left|\frac{3V2kCF}{3I2qCF}\right|$$

Equation 5.28

Zero-Sequence Directional Calculation Block

Figure 5.103 shows the characteristic of the zero-sequence directional element, consisting of a forward threshold and a reverse threshold. When setting the element, be sure to not overlap the two thresholds, because the area between the two thresholds provides security against relay errors.

Figure 5.103 Zero-Sequence Directional Element Characteristic

For each phase, the zero-sequence directional element uses *Equation 5.29* to determine the signed quantity Z0*m*.

$$Z0m = \frac{\mathrm{Re}[3V0k\mathrm{CF} \bullet (3I0q\mathrm{CF} \bullet 1\angle Z0\mathrm{ANG}m)^*]}{3I0q\mathrm{FM}^2}$$

Equation 5.29

where:

3V0*k*CF = zero-sequence voltage in phasor form
3I0*q*CF = zero-sequence current in phasor form
1∠Z0ANG*m* = the line angle in degrees
3I0*q*FM = magnitude of the zero-sequence current (scalar)
* = complex conjugate
Re = real part of

Zero-Sequence Directional Element Forward Threshold Calculation

Calculations for the zero-sequence directional element are identical to those for the negative-sequence directional element, except that the zero-sequence directional element calculations use zero-sequence quantities instead of negative-sequence quantities. The zero-sequence directional element uses *Equation 5.30*–*Equation 5.33*.

If Z0F*m* Setting ≤ 0, Forward Threshold (Z0FTH*k*) =

$$0.75 \bullet Z0Fm - 0.25 \bullet \left|\frac{3V0k\mathrm{CF}}{3I0q\mathrm{CF}}\right|$$

Equation 5.30

If Z0F*m* Setting > 0, Forward Threshold (Z0FTH*m*) =

$$1.25 \bullet Z0Fm - 0.25 \bullet \left|\frac{3V0k\mathrm{CF}}{3I0q\mathrm{CF}}\right|$$

Equation 5.31

Zero-Sequence Directional Element Reverse Threshold Calculation

If Z0R*m* Setting ≥ 0, Reverse Threshold (Z0RTH*m*) =

$$0.75 \bullet \text{Z0R}m + 0.25 \bullet \left|\frac{3\text{V0}k\text{CF}}{3\text{I0}q\text{CF}}\right|$$

Equation 5.32

If Z0R*m* Setting < 0, Reverse Threshold (Z0RTH*m*) =

$$1.25 \bullet \text{Z0R}m + 0.25 \bullet \left|\frac{3\text{V0}k\text{CF}}{3\text{I0}q\text{CF}}\right|$$

Equation 5.33

Figure 5.104 shows the zero-sequence directional element logic. For each terminal, Group setting VREF*n* determines which ILOP*k* value or VkBK value and 3V0*k*CF value the algorithm uses in the calculations. Inputs ORDER and *m*32QGE form the Best Choice Ground Directional Element logic selection. After calculating the signed impedance Z0*m*, the logic compares Z0*m* against Z0FTH*m*, the forward threshold, and Z0RTH*k*, the reverse threshold (see *Equation 5.30–Equation 5.33* for the threshold calculations).

Figure 5.104 Zero-Sequence Directional Calculation Logic

Figure 5.105 combines the logic from *Figure 5.98* and *Figure 5.104* to provide a single directional quantity for the negative-sequence and the zero-sequence directional elements.

Figure 5.105 Single Negative-Sequence and Zero-Sequence Directional Element Output

Best Choice Function Block

The Best Choice Ground Directional Element logic determines which directional element should operate. This directional element then controls ground-overcurrent elements set for directional control. Although the best choice function is a separate function, the function logic is integrated into both the negative-sequence and zero-sequence directional element. In *Figure 5.98* and *Figure 5.104*, the two AND gates at the bottom of the figures (Gate 1 and Gate 2) form the best choice function. For the best choice function, the algorithm evaluates the value in the first position of the ORDER setting. In *Figure 5.104*, for example, the ORDER setting for the input into Gate 1 is ORDER*m* = V (or VQ). Because the algorithm only evaluates the first position of the ORDER setting, V and VQ produce the same result. If the ORDER*m* setting is set to V or VQ, then the input into Gate 1 asserts permanently to a logical 1 (before the inverter). If the ORDER*m* setting is set to Q or QV, then the input into Gate 1 asserts permanently to a logical 0.

For example, if you want the Terminal S zero-sequence directional element to take preference over the Terminal S negative-sequence directional element, set the ORDER setting as follows: ORDERS = V (or VQ). This setting asserts the input into Gate 1 permanently to a logical 1, but the inverter at the input of Gate 1 changes the value to a permanent logical 0. This zero input turns Gate 1 permanently off, so that the output from Gate 1 is a permanent logical 0. This logical 0 after the inverter asserts the bottom input into Gate 3 permanently, requiring only *m*32VE to assert (see *Figure 5.104*) to enable the Z0*m* calculations.

Consider now the effect of the ORDER setting ORDER = V (or VQ) 1 on the negative-sequence directional logic (see *Figure 5.98*). There are three possible scenarios:

- *m*32VE asserts, but not *m*32QGE
- *m*32QGE asserts, but not *m*32VE
- both *m*32QGE and *m*32VE assert

In general, with the ORDER setting ORDER = V (or VQ), the top input into Gate 1 is a permanent logical 0, but the input turns into a permanent logical 1 through means of the inverter at the input. Also, the bottom input into Gate 2 is a permanent logical 1 because of setting ORDER = V (or VQ).

When *m*32VE asserts (but not *m*32QGE), Gate 2 turns on. Then Gate 1 turns Gate 3 off. When Gate 3 turns off, the Z2*m* calculations cannot be enabled even if *m*32QGE asserts, so Z0*m* takes preference.

When *m*32QGE asserts (but not *m*32VE), Gate 3 asserts (Gate 1 is still turned off), and the Z2*m* calculations begin. Therefore, if you select a combined setting (VQ), and the first choice does not assert, the directional calculations still begin if the second choice asserts.

It is when both *m*32QGE and *m*32VE assert that the relay calls upon best choice logic to select the appropriate value. As before, when *m*32VE asserts, Gate 2 turns on. Then Gate 1 turns Gate 3 off. When Gate 3 turns off, the Z2*m* calculations cannot be enabled, and Z0*m* takes preference.

Directional Control for Phase and Negative-Sequence Overcurrent Elements

Whereas the previous section describes directional elements for faults that involve ground, this section describes directional elements for faults clear of ground. Because negative-sequence quantities are present in all faults except for three-phase faults, a typical use for negative-sequence elements is as a control for both negative- and positive-sequence overcurrent elements. However, phase overcurrent elements also require positive-sequence directional elements because no negative-sequence quantities exist during three-phase faults.

Negative-Sequence Directional Element

Figure 5.106 shows the negative-sequence directional element, which uses the result of *Equation 5.24* (Z2*m*). This element differs from the negative-sequence element used for ground-fault overcurrent elements by not having zero-sequence directional elements.

Note:
S_1 = 1 if (VREF*n* = V AND ALTV*n* = 0) OR (VREF*n* = Z AND ALTV*n* = 1)
S_1 = 2 if (VREF*n* = Z AND ALTV*n* = 0) OR (VREF*n* = V AND ALTV*n* = 1)

Figure 5.106 Negative-Sequence Directional Element

Phase Directional Element

In general, voltage-polarized elements work well for all types of shunt faults, except for close-in, three-phase faults. Because the voltage goes to zero for these faults, directional elements can lose the reference value and misoperate. To maintain polarizing voltage for close-in, three-phase faults, the SEL-487E uses posi-

tive-sequence polarized memory voltage. The complete phase directional element consists of a number of calculations and logic such as that in *Figure 5.107–Figure 5.108*.

Using the positive-sequence voltage as reference, the element declares a forward direction if the angle between the positive-sequence voltage and the positive-sequence current is between 300 degrees and 120 degrees.

Figure 5.107 shows the logic that calculates the positive-sequence forward (Z1F*m*) and reverse (Z1R*m*) directions. If the positive-sequence voltage is greater than 1 V, and if the positive-sequence current is greater than 10 percent of the nominal current (100 mA for a 1 A CT or 500 mA for a 5 A CT), calculation of Z1*m* begins.

Figure 5.107 Positive-Sequence Directional Element

As for the negative-sequence directional element, the relay calculates a signed quantity to determine the forward and reverse directions. For the positive-sequence directional element, the relay uses positive-sequence phase-to-phase current values and positive-sequence phase-to-phase memory voltage values.

Figure 5.108 shows the algorithm that calculates the positive-sequence memory voltage. This algorithm uses the positive-sequence voltage as a function of the VREF*n* setting. Output VPOL*k* asserts if the absolute value of VA1*kmem* exceeds 1 V.

Figure 5.108 Positive-Sequence Memory Voltage

Equation 5.34–Equation 5.36 shows the calculation to determine positive-sequence element direction. In contrast to the similar calculation for the negative-sequence element, a positive result indicates a forward direction. A negative result indicates a reverse direction.

$$\mathrm{MABD}m = \mathrm{Re}[e^{j.\mathrm{Z1ANG}m} \bullet (-1)^{g}\mathrm{IAB}q\mathrm{CF} \bullet (\mathrm{VAB}kmem^{*})]$$

Equation 5.34

$$\mathrm{MBCD}m = \mathrm{Re}[e^{j.\mathrm{Z1ANG}m} \bullet (-1)^{g}\mathrm{IBC}q\mathrm{CF} \bullet (\mathrm{VBC}kmem^{*})]$$

Equation 5.35

$$\mathrm{MCAD}m = \mathrm{Re}[e^{j.\mathrm{Z1ANG}m} \bullet (-1)^{g}\mathrm{ICA}q\mathrm{CF} \bullet (\mathrm{VCA}kmem^{*})]$$

Equation 5.36

where:

Re = real part of
Z1ANG*m* = positive-sequence line angle
g = 1 if CTP*m* = N
g = 2 if CTP*m* = P
CTP*m* = CT polarity of Terminal *m*
* = complex conjugate
m = S, T, U, W, X, Y, 1, 2, 3, 4
q = S, T, U, W, X, Y, ST, TU, UW, WX
n = S, T, U, W, X, Y

Figure 5.109 shows the logic that produces the forward phase declaration (*m*F32P) and the reverse phase declaration (*m*R32P). For the forward direction, the following conditions must be met:

- Magnitudes MABD*m* MBCD*m*, and MCAD*m* must all be greater than 10 percent of the nominal current,
- The directional element function must be enabled (E67*m* = Y),
- VREF*n* cannot be set to OFF,
- There must be sufficient polarizing voltage and no loss of potential,
- Either the forward positive-sequence load direction (Z1F*m*, see *Figure 5.107*) must assert, or
- Either the positive-sequence current must be below 10 percent of nominal, or the positive-sequence voltage must be below 1 V.

For the reverse direction, the following conditions must be met:

- MABD*m*, MBCD*m*, and MCAD*m* must all be below –10 percent of the nominal current,
- The directional element function must be enabled (E67*m* = Y),
- VREF*n* cannot be set to OFF,
- There must be sufficient polarizing voltage and no loss of potential,
- Either the reverse positive-sequence load direction (Z1R*m*, see *Figure 5.107*) must assert, or
- Either the positive-sequence current must be below 10 percent of nominal, or the positive-sequence voltage must be below 1 V.

Figure 5.109 Phase Directional Element

Table 5.16 shows examples of torque-control equation settings for each overcurrent element (P, Q, G) of Terminal S.

Many utilities prefer to use the current from the transformer neutral as the polarizing quantity. By using the reverse output from the REF elements, you can also use current polarizing as a method of directional control. Be aware that the Best Choice function does not include the REF elements, so include the REF element in specifying the directional control conditions. The last row in *Table 5.16* shows an example that uses the reverse output from REF Element 1 as current polarizing and that includes the REF element in the Best Choice function.

Table 5.16 Directional Element Summary and Example Settings (Terminal S)

E50S Setting	Selected O/C Element	Torque-Control Setting for Selected O/C Element	Comment
P	50SP1	67SP1TC = SF32P	Include SF32P for bolted, three-phase faults.
Q	50SQ1	67SQ1TC = SF32G AND NOT ISBK	No need to include SF32P (no negative-sequence current for three-phase faults), and SF32G includes negative- and zero-sequence directional elements (see *Figure 5.105*). *AND NOT ISBK* in the torque-control equation secures the 50SQ1 element during DSS data loss.
G	50SG1	67SG1TC = SF32G AND NOT ISBK	No need to include SF32P (no negative-sequence current for three-phase faults), and SF32G includes negative- and zero-sequence directional elements (see *Figure 5.105*). *AND NOT ISBK* in the torque-control equation secures the 50SG1 element during DSS data loss
G	50SG1	67SG1TC = (REFR1 OR SF32G) AND NOT ISBK	Relay Word bit REFR1 asserts when the REF element detects a fault external to the REF zone. See *REF Element on page 5.52* for more information. *AND NOT ISBK* in the torque-control equation secures 50SG1 element during DSS data loss

Directional Control Settings

Setting E50 is a composite setting that determines definite-time overcurrent and directional element settings. *Table 5.17* summarizes the interaction between the E50, E50*m*, E67*m*, and the 67*m*P*a*TC settings.

Table 5.17 Directional Element Summary

Setting	Range	Purpose
E50[a]	S, T, U, W, X, Y, ST, TU, UW, WX	Select terminals that require: 1. definite-time overcurrent elements 2. directional elements (at this point, there is no distinction between selecting overcurrent elements and selecting directional elements).
E50*m*[b]	P, Q, G	After selecting the terminal(s) (E50), select the overcurrent elements directional elements from among phase (P), negative-sequence (Q) and zero-sequence (G) if required for each terminal. If overcurrent elements are not required, leave E50*m* = OFF.
E67*m*[b]	Y, N	After selecting the terminal(s) (E50) and the type of directional elements (E50*k*), enable the directional elements for the terminals. For example, if you set E50 = S, E50S = P, and E67S = N, then Terminal S has phase overcurrent elements only, (i.e., no directional elements). Setting E67S = Y enables the directional elements for Terminal S.
67*m*P*a*TC[b,c]	SELOGIC Control Equation	State the directional conditions for the phase overcurrent elements (see *Table 5.16*).
67*m*Q*a*TC[b,c]	SELOGIC Control Equation	State the directional conditions for the negative-sequence overcurrent elements (see *Table 5.16*).
67*m*G*a*TC[b,c]	SELOGIC Control Equation	State the directional conditions for the zero-sequence overcurrent elements (see *Table 5.16*).

[a] Combination terminals are only available for channels with the same nominal current rating, same CT connection (CTCON), and same voltage reference (VREF).
[b] m = S, T, U, W, X, Y, 1, 2, 3, 4 (combined terminals: 1 = ST, 2 = TU, 3 = UW, 4 = WX).
[c] a = 1–3.

E67m (Enable Directional Elements)

For each terminal, enable the directional control for overcurrent elements by setting directional control enable setting E67*m*. Setting E67*m* = Y enables the directional element for that terminal; disable the directional element for that terminal by setting E67*m* = N.

CTPm (CT Polarity)

Use the CTP*m* setting, available only if E67*m* =Y, to select the CT polarity for the directional element of each terminal. You cannot select the polarity of the individual phases; the setting applies to all three phases. In *Figure 5.110*, CTS and

CTT are installed and connected in the conventional way to provide CT information with the correct polarity for the differential element. However, if you want to use CTT for directional control in the same direction as, for example, CTU, then the polarity of CTT is incorrect.

Figure 5.110 CTPm Changes the Polarity of the CTs for the Directional Elements

NOTE: The CTPm setting has no effect on the CT polarity of any other element; the setting applies only to the directional element.

By your setting CTPT = N, the relay internally changes the polarity of CTT for the directional element and interprets the polarity of CTT as if it is the same as the polarity of CTU.

Z1ANGm (Positive-Sequence Line Impedance Angle)

For each terminal, set the positive-sequence line angle in degrees. This setting is only available if setting E67*m* = Y.

Z0ANGm (Zero-Sequence Line Impedance Angle)

For each terminal, set the zero-sequence line angle in degrees. This setting is only available if setting E67*m* = Y and if setting E50*m* includes G.

EADVSm (Enable Advanced Settings)

Enable the advanced settings by setting EADVS*m* = Y. This setting is only available if setting E67*m* = Y. Advanced settings include the following:

- 50FP*m*
- 50RP*m*

50FPm (Forward Direction Overcurrent Pickup)

Setting 50FP*m* is the Forward Direction Overcurrent Pickup value that the negative-sequence current, 3I2*q*FM (*q* = S, T, U, W, X, Y, ST, TU, UW, WX), must exceed, and it is one of the conditions that must be true to assert *m*32QGE (see *Figure 5.96*). This setting is only available if setting E67*m* = Y. If setting EADVS*m* = N, then the relay internally sets 50FP*m* to 0.12 • $I_{NOM}m$.

50RPm (Reverse Direction Overcurrent Pickup)

Setting 50RP*m* is the Reverse Direction Overcurrent Pickup value that the negative-sequence current (3I2*q*FM) must exceed, and it is one of the conditions that must be true to assert *m*32QGE (see *Figure 5.96*). This setting is only available if setting E67*m* = Y. If setting EADVS*m* = N, then the relay internally sets 50RP*m* to 0.08 • $I_{NOM}m$.

Z2Fm (Forward Direction Z2 Threshold)

Use Z2F to calculate the Forward Threshold for the negative-sequence voltage-polarized directional elements. This setting is only available if setting E67*m* = Y. If setting EADVS*m* = N, then the relay internally sets Z2F*m* to –0.5 / $I_{NOM}m$.

Z2Rm (Reverse Direction Z2 Threshold)

Use Z2R to calculate the reverse threshold for the negative-sequence voltage-polarized directional elements. This setting is only available if setting E67*m* = Y. If setting EADVS*m* = N, then the relay internally sets Z2R*m* to 0.5 / $I_{NOM}m$. When setting the element, be sure to set Z2R greater in value than setting Z2F by at least Z2F*m* + 0.5 / $I_{NOM}m$ secondary.

a2m (Positive-Sequence Restraint Factor—m32QE)

The a2 factor is the ratio of the negative-sequence current and the positive-sequence current (I2/I1). This factor increases the security of negative-sequence voltage-polarized directional elements by preventing these elements from operating for negative-sequence current (system unbalance). Negative-sequence current circulates because of line asymmetries, CT saturation during three-phase faults, etc. (see *Figure 5.96*). This setting is only available if setting E67*m* = Y. If setting EADVS*m* = N, then the relay internally sets a2*m* to 0.1.

ORDERm (Ground Directional Element Priority)

This setting is hidden when E67*m* = N or if E50*m* does not include G. Also, if the advanced settings EADVS*m* = N, then this setting is set to QV.

Setting ORDER can be set to negative-sequence (Q), zero-sequence control (V), or the combination of the two (i.e., QV or VQ). The order in which you enter the directional elements in setting ORDER determines the priority in which these elements operate to provide Best Choice Ground Directional Element logic control.

For example, if setting:

ORDER = QV

then the first listed directional element (Q = negative-sequence voltage-polarized directional element) is the first priority directional element to provide directional control for the neutral-ground and residual-ground overcurrent elements.

If the negative-sequence voltage-polarized directional element is inoperable (it does not have sufficient operating quantity, as indicated by its internal enable, 32QGE, not being asserted), then the second listed directional element (V = zero-sequence voltage-polarized directional element) provides directional control for the neutral-ground and residual-ground overcurrent elements.

If the zero-sequence voltage-polarized directional element is inoperable (it does not have sufficient operating quantity, as indicated by its internal enable, 32VE, not being asserted), then no directional control is available.

In another example, if setting:

ORDER = V

then the zero-sequence voltage-polarized directional element (V = zero-sequence voltage-polarized directional element) provides directional control for the neutral-ground and residual-ground overcurrent elements at all times (assuming it has sufficient operating quantity). If there is insufficient operating quantity during an event (the internal enable 32VE is not asserted), then no directional control is available.

k2m (Zero-Sequence Current Restraint Factor, I2/I0)

Note the internal enable logic outputs in *Figure 5.96*.

- *m*32QE, the internal enable for the negative-sequence voltage-polarized directional element that controls the negative-sequence and phase overcurrent elements
- *m*32QGE, the internal enable for the negative-sequence voltage-polarized directional element that controls the zero-sequence overcurrent elements

For the 32QGE internal enable to be on, the negative-sequence current magnitude (3I2*q*FM) must be greater than the zero-sequence current (3I0*q*FM) magnitude multiplied by k2:

$$|I2| > k2 \bullet |I0|$$

This check ensures that the relay uses the most robust analog quantities in making directional decisions for the neutral-ground and residual-ground overcurrent elements. The zero-sequence current (3I0*q*FM), to which we refer in the previous application of the k2 factor, is from the residual current, which we derived from phase currents IA, IB, and IC.

The k2 factor increases the security of the zero-sequence voltage-polarized directional elements. It keeps the elements from operating for zero-sequence current (system unbalance), which circulates because of line asymmetries, CT saturation during three-phase faults, etc. (see *Figure 5.96*). This setting is only available if setting E67*m* = Y. If setting EADVS*k* = N, the relay internally sets a2*m* to 0.1.

Z0Fm (Forward Directional Z0 Threshold)

This setting is only available if setting E67*m* = Y and if setting E50*m* includes G. If setting EADVS*m* = N, then the relay internally sets Z0F*m* to –0.5 / I_{NOM}*m* (I_{NOM} = 1 for a 1 A relay and 5 for a 5 A relay). When setting Z0F*m* and Z0R*m*, be sure that Z0R is greater in value than setting Z0F by at least 0.1 Ω secondary.

Z0Rm (Reverse Directional Z0 Threshold)

This setting is only available if setting E67*m* = Y and if setting E50*m* includes G. If setting EADVS*m* = N, then the relay internally sets Z0R*m* to 0.5 / I_{NOM}*m* (I_{NOM} = 1 for a 1 A relay and 5 for a 5 A relay). When setting Z0F*m* and Z0R*m*, be sure that Z0R is greater in value than setting Z0F by at least 0.1 Ω secondary.

a0m (Positive-Sequence Current Restraint Factor, I0/I1)

This setting is only available if setting E67*m* = Y and if setting E50*m* includes G. The a0 factor increases the security of the zero-sequence voltage-polarized directional element. This factor keeps the elements from operating for zero-sequence current (system unbalance), which circulates because of line asymmetries, CT saturation during three-phase faults, etc.

The zero-sequence current (I0), to which we referred in the application of the a0 factor, is from the residual current (IG), which we derived from phase currents IA, IB, and IC: 3I0 = IG = IA + IB + IC.

32GVSm (Zero-Sequence Directional Voltage Supervision)

This setting is only available if E67*m* = Y, E50*m* includes G, ORDER*m* contains V, and EADVS*m* = Y. This setting specifies the amount of zero-sequence voltage required to enable the zero-sequence directional element for Terminal *m*. If EADVS*m* = N, the relay internally sets 32GVS*m* to 2V.

DIRBLKm (Directional Element Blocking)

Customize a SELOGIC equation to determine when to block the phase and ground directional element for Terminal *m* (*m* = S, T, U, W, X, Y, 1, 2, 3, 4). The DIRBLK*m* setting is hidden for the following conditions:

- The definite-time overcurrent element E50 = OFF or does not include *m*
- E50*m* does not include negative-sequence or ground elements (Q or G)
- E67*m* = N. (To enable E67*m*, you must set CTCON*n* = Y [*n* = S, T, U, W, X, Y] and PTCON*k* = Y [*k* = V, Z], and EPTTERM, E50, and VREF*n* cannot be set to OFF.)

Unbalance Current Elements

Use the current unbalance logic to detect unbalance among the three-phase current magnitudes during normal system operating conditions. For each terminal in the E46 setting, the relay uses *Equation 5.37* to calculate the average current.

$$I_{AVEm} = \frac{(IAmFM + IBmFM + ICmFM)}{3}$$

Equation 5.37

where:

m = S, T, U, W, X, Y

Figure 5.111 shows the logic that uses the result of *Equation 5.37* (I_{AVEm}) to calculate the unbalance for the A-Phase. Calculations begin only if the E46 setting includes the terminal and if the average current is larger than five percent of the nominal current. After calculating the percentage difference between the individual phase current and the terminal average current, the logic compares this result to the value of setting 46*m*PU. If the result exceeds the setting value, 46*m* asserts.

Figure 5.111 Unbalance Logic for Terminal m, A-Phase

Figure 5.112 shows the logic that prevents assertion of the unbalance element during fault conditions and after closure of a terminal circuit breaker.

Figure 5.112 Unbalance Blocking Logic for Terminal m

The current unbalance logic does not operate if any of the following conditions are true:

- The maximum terminal current is greater than 2 • I_{NOM}, indicating a system fault.
- The Relay Word bit FAULT asserts.
- The circuit breaker has been closed (open-phase detection elements have deasserted).

After the circuit breaker closes (and current flows), all three open-phase detection elements (OPHA*m*, OPHB*m*, and OPHC*m*) deassert. When the first open-phase detection element deasserts, the Close Timer starts and asserts for a time period equal to the 46*m*CD time setting, during which time Gate 2 is turned off. If one of the phases fails to close, AND Gate 2 is not turned off, and, provided I_{MAX} is above five percent I_{NOM}, but below 2 • I_{NOM}, Gate 3 turns on. When Gate 3 turns on, Relay Word bit 46*m*P asserts and the Unbalance Timer starts timing. If Gate 3 is turned on for a period equal to the 46*m*BD setting, then Relay Word bit 46*m*T asserts.

Unbalance Current Settings

46mPU (Current Unbalance Pickup)

Set the percentage unbalance among the three phases of a particular terminal.

46mCD (Close Delay)

Set the time for the current to settle after closing the circuit breaker. During this time, Gate 2 in *Figure 5.112* is turned off; the unbalance function is inoperative.

46mBD (Current Unbalance Delay)

The unbalance timer starts timing when the unbalance among the three phases exceeds the 46*m* setting. Use setting 46*m*BD to specify how long unbalance must persist before the elements provide an output.

Open-Phase Detection Logic

Subsidence current results from energy trapped in a CT magnetizing branch after a circuit breaker opens to clear a fault or interrupt load. This current exponentially decays and delays the resetting of instantaneous overcurrent elements used for breaker failure protection. Breaker failure protection requires fast open-phase detection to ensure fast resetting of instantaneous overcurrent elements. *Figure 5.113* shows open-phase logic that asserts SEL-487E open-phase detection elements OPH*pm* (*p* = A, B, C; *m* = S, T, U, W, X, Y) in less than one cycle, even during subsidence current conditions.

Figure 5.113 A-Phase Open-Phase Detection Logic

The relay declares an open phase when the logic does not detect a zero crossing or current value within 0.625 cycles since the previous measurement. OPH*m*, the output of the logic, asserts when all three phases of a particular terminal assert.

If the SEL-487E-5 loses current data because of DSS communication problems, there is the potential for spurious assertions of the open-phase Relay Word bits. To prevent this, the SEL-487E-5 uses terminal specific freeze Relay Word bits I*m*FZ (*m* = S, T, U, W, X, Y) to maintain the status of the open-phase logic (see *Analog Channel Statuses on page 5.2*). While Relay Word bits I*m*FZ are asserted, indicating a loss of line-current data on Terminal *m*, Relay Word bits OPHA*m*, OPHB*m*, and OPHC*m* hold their previous states despite the loss of line-current data and are thus effectively frozen. The duration of the freeze period is limited by the Global setting SVFZDO (see *Analog Channel Statuses on page 5.2*). When DSS communication issues related to current Terminal *m* are resolved, I*m*FZ deasserts and the open-phase logic operates normally.

Breaker Failure Elements

There are six breaker failure elements in the relay, one for each of the six current terminals. Use the EBFL Group setting to enable the appropriate windings necessary for your particular application. *Figure 5.114*, *Figure 5.115*, and *Figure 5.116* show the breaker failure logic. In *Figure 5.114*, three comparators test the three-phase currents against the 50FPU*m* settings, and one comparator tests the neutral current against the INFPU*m* setting. SELOGIC setting ENINBF*m* allows the neutral breaker failure function to be conditional if system unbalance conditions could cause inadvertent initiation of the neutral element, such as might occur in single-pole tripping systems. When any phase current exceeds the 50FPU*m* setting, or the neutral current exceeds the INFPU*m* setting, the appropriate Relay Word bit asserts (IA*m*BF, IB*m*BF, IC*m*BF, and/or IN*m*BF). Each phase current comparator is supervised by the associated open-phase detectors OPH*pm*, (*p* = A, B, C; *m* = S, T, U, W, X, Y). The neutral current comparator is supervised by the all three poles open detector (OPH*m*). The open-phase detectors provide subcycle resetting of all input currents, even when subsidence current is present.

① Figure 5.115

Figure 5.114 Breaker Failure Logic for Terminal m When BF_SCHM = Y

Input BFI*m* is a SELOGIC control equation that provides the breaker failure initiate signal. When BFI*m* asserts, both the breaker failure timer and the retrip timer start timing as shown in *Figure 5.114*. When the retrip timer expires, RTm asserts, and when the breaker failure timer expires, BFIT*m* asserts. If 50F*m* is

asserted when BFIT*m* asserts, the breaker failure output, FBF*m*, asserts. Note that BFI*m* must be present for the entire duration of the breaker failure timer setting. If BFI*m* is not present constantly, the timers reset when BFI*m* falls away (see alternative initiate logic in *Figure 5.116*).

① Figure 5.114

Figure 5.115 Breaker Failure Logic for Terminal m When BF_SCHM = Y1

The logic shown in *Figure 5.115* is enabled when the breaker failure scheme setting is set to Y1 (BF_SCHM = Y1). The logic enabled with option Y1 is similar to that shown in *Figure 5.114*, but the current check (50F*m*) is now part of the breaker failure initiate timer (BFPU*m*) and retrip time delay (RTPU*m*) in addition to the external breaker failure initiate setting (EXBF*m*).

EXBF*m* (SELOGIC control equation) is the input for the case when breaker failure initiates from a protection function alone with no current supervision, such as when the Buchholz relay operates on an unloaded transformer. Because a Buchholz relay assertion can be present even after the breakers are open, increase security by using the non/low-current SELOGIC control equation, EXBFSP*m*. When EXBF*m* asserts, both the external breaker failure timer and the retrip timer start timing. When the retrip timer expires, RT*m* asserts, and when the external breaker failure timer expires, the breaker failure output, FBF*m*, asserts.

Figure 5.116 shows an alternate breaker failure initiate logic. This logic is applied when the protection philosophy dictates that both current and breaker-failure initiate signals may not be coincident. Referring to *Figure 5.116*, the alternate breaker failure logic creates a time window following the reset of a breaker failure initiate (ATBFI*m*). If the current detector asserts during this time window, the breaker failure operation will still occur.

To use the alternate initiate logic, connect the breaker failure initiate signal to ATBFI*m* (instead of to BFI*n* in *Figure 5.114*). Then connect the output of the alternate initiate logic (ABFIT*m*) to BFI*m* (*Figure 5.114*).

Figure 5.116 Alternate Breaker Failure Logic for Terminal k

The timers in this logic accommodate possible intermittent behavior of either the breaker failure initiate signal or the current detector signal, as described in the following sections.

1. Substitution of the current detector signal using the BFIDO*m* timer

   Use this option in dual-breaker applications when current is not immediately present. This can happen in a dual-breaker application, as shown in *Figure 5.117*. In this scenario, Breaker T has failed but most of the fault current is initially flowing through Breaker S. Once Breaker S opens, the fault current is redistributed through Breaker T. The dropout timer (BFIDO*m*) is used to prevent a delayed breaker failure operation under this scenario (because of insufficient current through Breaker T). Set the dropout time longer than the expected operate time of Breaker S. On the rising edge of ATBFI*m*, the lower input of AND Gate 2 is asserted for the duration of BFIDO*k*. After time-out, the current detector takes over this roll.

Figure 5.117 Current Redistribution in a Dual-Breaker Configuration

2. Seal-in of the breaker-failure initiation signal

   Use this option when it is possible for the breaker-failure-initiate signal to reset prior to time-out of the breaker failure timer (BFPU*m*). The logic requires that both the breaker-failure initiate and current detector signals are initially present for period longer than the breaker failure seal-in (BFISP*m*) time delay. Once this timer expires, the scheme seals-in until the current detector resets. To use this option, set EBFIS*m* to Y. It is important to set BFISP*m* long enough to avoid seal-in from any possible spurious protection assertion.

When the SEL-487E-5 loses breaker current data because of DSS communications problems, there is the potential for spurious deassertion of the breaker failure overcurrent Relay Word bits. This could compromise the dependability of the breaker failure logic. To safeguard against this scenario, the breaker failure overcurrent Relay Word bits freeze and maintain their previous status as long as Relay Word bits I*m*FZ (*m* = S, T, U, W, X, Y) are asserted (see *Analog Channel*

Statuses on page 5.2). As long as the breaker freeze Relay Word bits are asserted (I*m*FZ), the corresponding breaker failure Relay Word bits (50F*m*) freeze and maintain their previous states. The duration of the freeze period is determined by the Global setting SVFZDO (see *Analog Channel Statuses on page 5.2*). When DSS communication issues are resolved, I*m*FZ deasserts and the breaker failure logic operates normally.

Breaker Failure Settings

EBFL (Enable Breaker Fail)

Set EBFL to enable breaker failure protection for the specific terminals in your application. The EBFL setting considers for selection only terminals that you include in the ECTTERM setting.

BF_SCHM (Breaker Failure Scheme)

Set BF_SCHM to Y or Y1 for your preferred breaker failure scheme for your application. See *Figure 5.114* and *Figure 5.115* for further details. If EBFL = OFF, BK_SCHM is hidden.

EXBFm (Enable External Breaker Fail)

EXBF*m* (SELOGIC control equation) is the input for the case when breaker failure results from a protection function with no current supervision, such as when the Buchholz relay operates on an unloaded transformer. Use the setting to specify conditions under which the external breaker input must be active. There is a setting for each of the enabled terminals. If you set EXBF*m* = 1, the input is asserted permanently.

EXBFSPm (External Breaker Failure Supervision)

Select a signal that indicates that the breaker is still closed. This is typically the 52CL*m* Relay Word bit.

EBFPUm (External Breaker Failure Initiation Pickup)

For each enabled terminal, select a time in cycles that you want the external breaker failure element to wait before asserting.

50FPUm (Fault Current Pickup)

The setting 50FPU*m* is the current pickup setting in amperes secondary for the breaker failure overcurrent element of each enabled terminal.

BFPUm (Breaker Failure Initiation Pickup Delay)

For each enabled terminal, select a time in cycles that you want the breaker failure timer to wait before asserting.

RTPUm (Retrip Delay)

For each enabled terminal, select a time in cycles that you want the retrip timer to wait before asserting.

BFIm (Breaker Fail Initiate)

Use the BFI*m* setting (SELOGIC control equation) to specify conditions under which the breaker failure initiate input must be active. There is a setting for each of the enabled terminals. If you set BFI*m* = 1, the input is asserted permanently.

ATBFIm (Alternative Breaker Fail Initiate)

Use the ATBFI*m* setting (SELOGIC control equation) to specify conditions under which the alternative breaker failure initiate input must be active. When using the ATBFI*m* setting, be sure to set ABFIT*m* = BFI*m*. There is a setting for each of the enabled terminals. If you set ABFIT*m* = 1, the input is asserted permanently.

ENINBFm (Enable Neutral Breaker Fail)

Use the ENINBF*m* setting (SELOGIC control equation) to specify conditions under which the neutral breaker input must be active. There is a setting for each of the enabled terminals. If you set ENINBF*m* = 1, the input is asserted permanently.

INFPUm (Neutral Current Pickup)

INFPU*m* is the current pickup setting in secondary amperes for the neutral breaker failure overcurrent element of each enabled terminal. The range is 0.10 to 10 for a 1 A relay.

EBFISm (Breaker Fail Initiate Seal-In)

Enable the breaker failure seal-in timer circuit by setting EBFIS*m* = Y (see *Figure 5.116*).

BFISPm (Breaker Fail Initiate Seal-In Delay)

Select a time in cycles that you want the breaker failure seal-in timer to wait before asserting (see *Figure 5.116*).

BFIDOm (Alternative Breaker Failure Timer)

Select a time in cycles that you want the alternative breaker failure timer to wait before asserting (see *Figure 5.116*).

Volts/Hertz Elements

Overexcitation occurs when system conditions cause the magnetic core of a transformer to saturate. These system conditions are an overvoltage condition, an underfrequency condition, (or a combination of the two conditions). The volts/hertz function in the SEL-487E combines these two system conditions into one element by calculating the ratio of normalized voltage to normalized frequency (V/Hz). This ratio is proportional to the flux in the transformer core, and therefore, also proportional to any over- or underexcitation of the transformer core. Because transformer core saturation is different for loaded and unloaded trans-

formers, the volts/hertz element provides two levels of definite-time V/Hz protection. In addition, the element also provides two user-defined curves so that you can form an inverse type of V/Hz characteristic.

Definite-Time Elements

NOTE: For SV applications, operating times are delayed by the configured channel delay, CH_DLY. See SV Network Delays on page 17.33 in the SEL-400 Series Relays Instruction Manual for more details. For TiDL applications, the operating times are delayed by a fixed 1 ms. Use caution when setting relay coordination to account for this added delay.

Figure 5.118(a) shows the definite-time characteristic when only Level 1 is active, and *Figure 5.118(b)* shows the characteristic when Level 2 is active.

Figure 5.118 Levels 1 and 2 V/Hz

Figure 5.119 shows the definite-time V/Hz logic. To enable the Level 1 element, set Group setting E24 = Y (24CCS is at the default setting = OFF). With the Level 1 element active, only the top part of the logic (up to the V/Hz timer) is active.

After selecting the appropriate voltage (V if 24VSRC = V or Z if 24VSRC = Z), the logic normalizes the measured voltage (maximum of the secondary line-to-line voltages) and the measured frequency to the VNOM*k* and NFREQ values. To form the V/Hz per-unit value, the logic divides the normalized voltage by the normalized frequency and multiplies the result by 100 to calculate a percentage to form analog quantity 24RPU.

In Comparator C1, the logic compares 24RPU against the 24D1P setting value. If 24RPU exceeds the 24D1P setting value, and if SELOGIC control equation 24TC is asserted, then Gate 1 turns on and the V/Hz conditional timer starts timing. If Gate 1 remains turned on until expiration of the 24D1D time setting, then Relay Word bit 24D1T asserts.

Note that Level 2 of the definite-time element uses stair counters instead of conditional timers to avoid resetting the conditional timer when 24RPU momentarily dips below the threshold setting. The Level 2 logic uses a stair counter that operates as follows:

- If the input is high (true), the counter is incremented by 1 until the counter reaches its upper value limit where the counter is stopped (similar to a limiter).
- If the input is low (false), the counter is decremented by 1 until the counter reaches a value of 0, at which point the counter value remains at 0 if the input remains low.

The stair counter has the advantage over the conventional timer because if the signal goes low for one processing interval, the stair counter does not reset to zero immediately but only decrements the value by a single count and then increases again if the input signal goes high.

To enable Level 2, set 24CCS = DD. Setting 24CCS to DD asserts one input of both Gate 2 and Gate 3. In Comparator 2, the logic compares 24RPU against the 24D2P1 setting value, and in Comparator 3, the logic compares 24RPU against the 24D2P2 setting value. If SELOGIC control equation 24TC is asserted, Gate 2 turns on when 24RPU exceeds the 24D2P1 setting value, and Gate 3 turns on when 24RPU exceeds the 24D2P2 setting value. In turn, Counter 1 starts when Gate 2 turns on and Counter 2 starts when Gate 3 turns on.

Each counter has two outputs. When either counter reaches a count that equals the timer setting (24D2D1 or 24D2D2), Relay Word bit 24D2T asserts (because these are counters, the time will be longer if 24RPU fell below the threshold setting). When both counters are reset (count = 0), Relay Word bit 24D2R asserts.

Figure 5.119 Two-Level, Definite-Time V/Hz Logic

User-Defined Curves

Figure 5.120 shows the logic for the user-defined curves. Use setting 24CCS to select either User-Defined Element 1 (24CCS = U1), or both User-Defined Element 1 and User-Defined Element 2 (24CCS = U2). Each element has a separate torque-control setting (24U1TC and 24U2TC), and 24RPU is the analog quantity the V/Hz logic calculated in *Figure 5.119*.

These user-defined curves consist of as many as 20 points (24U101–24U120 and 24U201–24U220) to form characteristics suitable for most applications. For each point, enter the V/Hz value and the time associated with that particular V/Hz value. Because the relay calculates the time after linear interpolation of the V/Hz values, enter as many points as possible for accurate time results.

Figure 5.120 Logic for the User-Defined Curves

NOTE: The SEL Grid Configurator settings interface and the relay terminal prompt display the user-defined curve settings in different ways. From a terminal emulation program, 24U101 is entered as a comma-separated value. In this example, point 24U101 = 110,33. From SEL Grid Configurator, two settings are provided: 24U111 and 24U121. The first setting, 24U111, is Curve 1, Point 1 volts/hertz in units of percentage. In this example, 24U111 = 110. The second setting, 24U121, is Curve 1, Point 1 time in units of seconds. **24U101**, the name of the setting stored in the relay, is made up of these two SEL Grid Configurator settings: 24U111 and 24U121.

For example, assume that you obtain the V/Hz characteristic in *Figure 5.121* from a transformer manufacturer. To program this characteristic, you need to enter any number of points between 3 and 20. *Figure 5.121* shows three such points:

- Point 24U101: V/Hz = 110 (percentage) and the operate time = 33 (seconds)
- Point 24U102: V/Hz = 150 (percentage) and the operate time = 22 (seconds)
- Point 24U103: V/Hz = 200 (percentage) and the operate time = 14 (seconds)

Figure 5.121 V/Hz Curve From Manufacturer

Figure 5.122(a) shows a programmed curve from entry of only three points. Clearly, this programmed curve is much different from the original curve, and the time calculations will be inaccurate. *Figure 5.122(b)* shows a programmed curve, obtained after entry of 16 points, superimposed on the original curve. With more points, the programmed curve closely follows the original curve, and the time calculations are accurate.

Figure 5.122 Three- and Sixteen-Point Curves

Each element has two output Relay Word bits. When the element times out, Relay Word bits 24U1T (Element 1) and 24U2T (Element 2) assert. When the elements are reset, Relay Word bits 24U1R (Element 1) and 24U2R (Element 2) assert.

Volts/Hertz Settings

24VSRC (Voltage Source for V/Hz Calculation)

⚠WARNING
Make sure the estimated frequency is from the same terminal as the 24VSRC setting. See Frequency Estimation on page 5.154 for details.

After enabling the V/Hz elements (E24 = Y), select the voltage terminal for calculating V/Hz with the 24VSRC setting. If you have enabled only one voltage terminal (by using EPTTERM) then 24VSRC is forced to that terminal.

24D1P (Level 1 Overexcitation Pickup)

Set the Level 1 percentage overexcitation with the 24D1P setting. If you want to use the Level 1 element only, leave the 24CCS setting at the default value (24CCS = OFF).

24D1D (Level 1 Time Delay)

When the system V/Hz exceeds the 24D1P setting value, and if SELOGIC control equation 24TC is asserted, the V/Hz conditional timer starts timing. Set the delay (in seconds) for which the timer must run before the 24D1D setting asserts the output.

24TC (Definite-Time V/Hz Torque Control)

Use the torque-control setting to specify conditions under which the definite-time V/Hz elements must be active. This setting controls all levels of the definite-time elements. The default setting is 1, so that one input into Gates 1–3 in *Figure 5.119* is asserted permanently.

24CCS (Level 2 Composite Curve)

This setting selects which of the V/Hz elements are active, as *Table 5.18* shows.

Table 5.18 Active V/Hz Elements as a Function of the 24CCS Setting

Setting	Active V/Hz Element			
24CCS[a]	Level 1 DD	Level 2 DD	Level 1 UD	Level 2 UD
OFF	Yes	No	No	No
DD	Yes	Yes	No	No
U1	Yes	No	Yes	No
U2	Yes	No	Yes	Yes

[a] Where:
DD = Definite-time element.
UD = User-defined element.

Although the Level 1 DD element is active by default, you can deactivate this element with the 24TC setting.

24D2P1 (Level 2 Overexcitation Pickup)

To enable the Level 2 percentage overexcitation pickup setting, set E24 = Y and 24CSS = DD. With 24CSS = DD, both Level 1 and Level 2 definite-time V/Hz elements are active.

24D2D1 (Level 2 Time Delay)

When the system V/Hz exceeds the 24D2P1 setting value, and if SELOGIC control equation 24TC is asserted, Stair Counter 1 (*Figure 5.119*) starts timing. Set the delay (in seconds) for which the timer must run before the 24D2D1 setting asserts the output. Although the counter counts in discrete steps, for time calibration the counter is the same as for a conditional timer.

24D2P2 (Level 2 Overexcitation Pickup)

To enable the Level 2 percentage overexcitation pickup setting, set E24 = Y and 24CCS = DD. With 24CCS = DD, both Level 1 and Level 2 definite-time V/Hz elements are active.

24D2D2 (Level 2 Time Delay)

When the system V/Hz exceeds the 24D2P2 setting value, and if SELOGIC control equation 24TC is asserted, Stair Counter 2 starts timing. Set the delay (in seconds) for which the timer must run before asserting the output with the 24D2D2 setting. Although the counter counts in discrete steps, time calibration for the counter is the same as for a conditional timer.

24U1TC (User-Defined Curve 1 Torque Control)

Use the torque-control setting to specify conditions under which the user-defined V/Hz Curve 1 must be active.

24U1NP (Number of Points for User-Defined Curve 1)

Form user-defined curves by entering as many as 20 points that the relay interpolates to form a particular V/Hz characteristic. Use setting 24U1NP to specify the number of points for Curve 1 (see *Figure 5.121* and *Figure 5.122*).

24U1xx (Data Points for User-Defined Curve 1)

Enter each data point (01–20) here to form the user-defined curve. Data points must be entered in order of increasing V/Hz values. The data point format when using a terminal settings interface is <volts/hertz>(comma)<time> (i.e., 115,30).

The units are volts/hertz in percent and time in seconds.

24U1CR (User-Defined Curve 1 Reset Time)

Specify the Curve 1 reset time with the 24U1CR setting. This setting is only an absolute value if the element has timed out (if 24U1T has asserted). If there is interruption of the Curve 1 timing, then the reset time is proportional to the elapsed time. For example, assume there is an overexcitation condition on the system and Curve 1 starts timing. At the 60 percent mark, the system overexcitation condition disappears, and Curve 1 stops timing. Because the timing interruption was at the 60 percent mark, the reset time is also 60 percent of the 24U1CR setting.

24U2TC (User-Defined Curve 2 Torque Control)

Use the torque-control setting to specify conditions under which the user-defined V/Hz Curve 2 must be active.

24U2NP (Number of Points for User-Defined Curve 2)

Form user-defined curves by entering as many as 20 points that the relay interpolates to form a particular V/Hz characteristic. Use setting 24U2NP to specify the number of points for Curve 2 (see *Figure 5.121* and *Figure 5.122*).

24U2xx (Data Points for User-Defined Curve 2)

Enter the data point here to form the user-defined curve. Data points must be entered in order of increasing V/Hz values. The data point format is <volts/hertz>(comma)<time> (i.e., 115,30).

The units are volts/hertz in percent and time in seconds.

24U2CR (User-Defined Curve 2 Reset Time)

Specify the Curve 2 reset time with the 24U2CR setting. This setting is only an absolute value if the element has timed out (if 24U2T has asserted). If there is interruption of the Curve 2 timing, then the reset time is proportional to the elapsed time. For example, assume there is an overexcitation condition on the system and Curve 2 starts timing. At the 60 percent mark, the system overexcitation condition disappears and Curve 2 stops timing. Because the timing interruption was at the 60 percent mark, the reset time is also 60 percent of the 24U2CR setting.

Synchronism Check

NOTE: For SV applications, operating times are delayed by the configured channel delay, CH_DLY. See SV Network Delays on page 17.33 in the SEL-400 Series Relays Instruction Manual for more details. For TiDL applications, the operating times are delayed by a fixed 1 ms. Use caution when setting relay coordination to account for this added delay.

Synchronism-check elements prevent circuit breakers from closing if the corresponding phases across the open circuit breaker are excessively out-of-phase, magnitude, or frequency. The SEL-487E synchronism-check elements selectively close circuit breaker poles under the following criteria:

The systems on both sides of the open circuit breaker are in phase (within a settable voltage angle difference), and one of the following is true:

- The voltages on both sides of the open circuit breaker are healthy (within a settable voltage magnitude window).
- The difference between the voltages on both sides of the open circuit breaker is less than a set limit.
- The voltages on both sides are healthy and the difference voltage is less than a set limit.

You can use synchronism-check elements to program the relay to supervise circuit breaker closing; include the synchronism-check element outputs in the close SELOGIC control equations. These element outputs are Relay Word bits 25W1BK*m*, 25W2BK*m*, 25A1BK*m*, and 25A2BK*m* (*m* = S, T, U, W, X, or Y) (see *Synchronism-Check Logic Outputs on page 5.134* and *Angle Checks and Synchronism-Check Element Outputs on page 5.140*).

Examples best demonstrate the synchronism-check capability in the SEL-487E. This section presents typical synchronism-check systems.

Generalized System

The generalized system single-line drawing in *Figure 5.123* shows a partial circuit breaker-and-a-half or ring-bus substation arrangement. Assuming that both Circuit Breakers BKS and BKT are open, the system is split into three sections: Bus S, Bus T, and Line.

Figure 5.123 Partial Breaker-and-a-Half or Partial Ring-Bus Breaker Arrangement

Paralleled and Asynchronous Systems

Figure 5.123 shows remote sources for each section. Often, a portion of the power system is paralleled beyond the open Circuit Breakers BKS and BKT; the remote sources are really the same aggregate source. If the aggregate source is much closer to one side of the open circuit breaker than the other, there is a

noticeable voltage angle difference across the system (it is not simply zero degrees). The corresponding angular separation results from load flow and the impedance of the parallel system.

You must conduct a load flow study to determine the maximum angle across the circuit breaker and consider this angle difference when setting the synchronism-check element for a paralleled system. For example, if the expected load angle because of load flow is 10 degrees, do not set the voltage angle difference setting to less than 15–20 degrees. A paralleled system does not imply a zero-degree voltage angle difference at every measuring point.

Single-Phase Voltage Inputs

Figure 5.124 shows single-phase voltage transformers on Bus S and Bus T. Use these single-phase voltage sources to perform a synchronism check across the two circuit breakers.

Figure 5.124 Synchronism-Check Voltages for Two Circuit Breakers

Synchronism check occurs on a single-phase voltage basis—see the single-phase PTs shown on each bus in *Figure 5.124*. The assumption is that if the monitored single-phase voltage inputs are in phase (within a settable voltage angle difference), and they meet the criteria of being healthy (within a settable voltage magnitude window) and/or the voltage difference is less than a set limit, the other phase-to-neutral voltages are likewise in phase and share the same voltage magnitude relationship. The line voltage source is three-phase, but you only need a single-phase bus voltage to perform a synchronism check across the corresponding circuit breaker. The relay uses the three-phase voltage from the load for other functions such as metering.

Setting 25_SCHM := Y

If setting 25_SCHM = Y, the synchronizing logic verifies that both the reference voltage and synchronizing voltage are healthy (within a settable voltage magnitude window) before enabling the synchronism-check logic.

Setting 25_SCHM := Y1

If setting 25_SCHM = Y1, the synchronizing logic verifies that the difference voltage between the reference and synchronizing voltages is less than the 25VDIF setting before enabling the synchronism-check logic.

Setting 25_SCHM := Y2

If setting 25_SCHM = Y2, the synchronizing logic verifies that both the reference and synchronizing voltages are healthy and that the difference between them is less than the 25VDIF setting before enabling the synchronism-check logic. It combines the logic that is used when 25_SCHM is set to Y or Y1.

Synchronism-Check Settings Example

E25 (Enable Synchronism Check)

Select the terminals that will be available for synchronism check. The E25 setting is hidden if the CT or PT terminals are not enabled (i.e., the setting ECTTERM = OFF or EPTTERM = OFF). The available terminals are limited to the terminals selected in the ECTTERM setting.

This example uses a two-circuit breaker arrangement (Breakers S and T) (see *Figure 5.124*). Set the synchronism-check enable settings:

E25 := **S, T** Enable Synchronism Check for Breaker S and Breaker T

Figure 5.125 shows the correspondence between the synchronism-check settings and the two-circuit breaker application example. The following sections explain these settings and include an explanation of Alternative Synchronism-Check Voltage Source T settings (see *Figure 5.139*).

Figure 5.125 Synchronism-Check Settings

Synchronism Check (25) Voltage Reference and Breaker m Synchronism Source Voltage

When the E25 synchronism-check setting is enabled for Terminal *m*, the relay checks if SYNCP (the polarizing reference voltage), and SYNCS*m* (the synchronizing source voltage), are within the voltage threshold window and the block

synchronism-check equation (BSYNBK*m*) is not asserted. Note that SYNCP and SYNCS*m* must be unique per breaker when each of these settings are enabled. The available voltage inputs are limited to the terminals enabled by the EPT-TERM setting.

Synchronism-Check Logic Outputs

Figure 5.126 shows the correspondence between synchronism-check logic outputs (Relay Word bits) and the two-circuit breaker arrangement. These Relay Word bits assert to logical 1 (e.g., 59VP equals logical 1) if true and deassert to logical 0 if false. *Table 5.19* lists these Relay Word bits.

Figure 5.126 Synchronism-Check Relay Word Bits

NOTE: The polarizing voltage, VP, is often referred to as the synchronism-check voltage reference throughout the examples below. It is the user-selectable voltage associated with the Synchronism Check (25) Reference setting, SYNCP.

NOTE: f_{Sm} is the frequency of the synchronizing voltage associated with Breaker m, where m = S, T, U, W, X, or Y.

NOTE: If the Maximum Slip Frequency setting 25SFBKm = OFF, then the Relay Word bit SFBKm = 0.

Table 5.19 Synchronism-Check Relay Word Bits[a] (Sheet 1 of 2)

Relay Word Bit	Description
59VP	Polarizing voltage (V_P) within healthy voltage window.
59VP*m*	Breaker *m* polarizing voltage within healthy voltage window.
59VS*m*	Breaker *m* synchronizing voltage (V_{Sm}) within healthy voltage window.
ALTS*m*	Breaker *m* alternative synchronizing voltage source selected.
ALTP*m*1	Breaker *m* Alternative Reference Source Selection Logic 1 (SELOGIC control equation).
ALTP*m*2	Breaker *m* Alternative Reference Source Selection Logic 2 (SELOGIC control equation).
BSYNBK*m*	Breaker *m* synchronism check blocked.
25ENBK*m*	Breaker *m* synchronism-check element enabled.
59VDIF*m*	The difference between the polarizing voltage magnitude, VPFM, and the Breaker *m* synchronizing voltage magnitude, 25VS*m*FM, is less than the limit set by 25VDIF (see *Figure 5.131*).

Table 5.19 Synchronism-Check Relay Word Bits[a] (Sheet 2 of 2)

Relay Word Bit	Description
SFZBK*m*	Breaker *m* slip frequency less than 0.005 Hz ("no-slip" condition).
SFBK*m*	0.005 Hz ≤ Breaker *m* slip frequency < maximum slip frequency (25SFBK*m*).
25A1*m*	Breaker *m* voltage with uncompensated sync angle within ± Sync Angle 1 (ANG1BK*m*) window and SFZBK*m* is asserted (no slip).
25A2*m*	Breaker *m* voltage with uncompensated sync angle within ± Sync Angle 2 (ANG2BK*m*) window and SFZBK*m* is asserted (no slip).
25C1*m*	Breaker *m* voltage with slip-compensated sync angle is within zero degrees to ANG1BK*m* when FAST*m* is asserted. When SLOW*m* is asserted, it is within zero degrees to –ANG1BK*m* (zero-degree close attempt). 25C1*m* is supervised with NOT SFZBK*m* and maximum allowed slip-frequency setting 25SFBK*m* (SFBK*m* asserted).
25WC1*m*	Breaker *m* voltage with slip-compensated sync angle is within zero degrees to ANG1BK*m* when FAST*m* is asserted. When SLOW*m* is asserted, it is within zero degrees to –ANG1BK*m* (zero-degree close attempt).
25C2*m*	Breaker *m* voltage with slip-compensated sync angle is within zero degrees to ANG2BK*m* when FAST*m* is asserted. When SLOW*m* is asserted, it is within zero degrees to –ANG2BK*m* (zero-degree close attempt). 25C2*m* is supervised with NOT SFZBK*m* and maximum allowed slip-frequency setting 25SFBK*m* (SFBK*m* asserted).
25WC2*m*	Breaker *m* voltage with slip-compensated sync angle is within zero degrees to ANG2BK*m* when FAST*m* is asserted. When SLOW*m* is asserted, it is within zero degrees to –ANG2BK*m* (zero-degree close attempt).
25W1BK*m*	Breaker *m* voltage is within the uncompensated and unsupervised Synchronism Angle 1 window.
25W2BK*m*	Breaker *m* voltage is within the uncompensated and unsupervised Synchronism Angle 2 window.
25A1BK*m*	Breaker *m* voltage is within either the uncompensated or slip-compensated Angle 1 window (25A1*m* OR 25C1*m*)
25A2BK*m*	Breaker *m* voltage is within either the uncompensated or slip-compensated Angle 2 window (25A2*m* OR 25C2*m*)
FAST*m*	The frequency of the voltage associated with Breaker *m* is greater than the frequency of the reference (polarizing) voltage ($f_{Sm} > f_P$)
SLOW*m*	The frequency of the voltage associated with Breaker *m* is less than the frequency of the reference (polarizing) voltage ($f_{Sm} < f_P$)

[a] m = S, T, U, W, X, or Y.

NOTE: The term uncompensated refers to the synchronism-check logic and associated Relay Word bits that do not take into consideration the breaker closing time setting (TCLSBKm) or the slip frequency (25SLIPm). If the polarizing voltage and synchronizing voltage for the breaker are not slipping (i.e., when SFZBKm = 1 or when the setting 25SFBKm = OFF), the uncompensated synchronism-check logic allows closing permission without considering the setting TCLSBKm or the analog quantity 25SLIPm. When the setting 25SFBKm = OFF, the setting TCLSBKm is disabled. The Relay Word bits associated with compensated synchronism check allow closing permission considering the breaker closing time and slip frequency.

If the synchronism-check element is not enabled for a particular circuit breaker, the following Relay Word bits are forced to the conditions below. In this example, the synchronism-check element is only enabled for Terminals S and T. Therefore, Terminals U, W, X, and Y are not enabled.

E25 = S, T

25ENBK [U, W, X, and Y] = 0

SFZBK [U, W, X, and Y] = 0

SFBK [U, W, X, and Y] = 0

Also, in this example, the analog quantities 25ANG [U, W, X, and Y] = 0, 25ANGC [U, W, X, and Y] = 0, and 25SLIP [U, W, X, and Y] = 10,000 because synchronism check is not enabled for Terminals U, W, X, and Y.

PT Connections

Figure 5.127 is an example of connecting PTs to a merging unit (or merging units) and shows how those PT inputs are mapped internally within the SEL-487E for a two-circuit breaker application. The Bus S and Bus T single-phase voltages are mapped to relay voltage inputs VAZ and VBZ, respectively. They could just as easily have been connected to any of the other voltage inputs. The voltage connected to voltage input VAZ (setting SYNCSS := VAZ; see *Figure 5.127*) is not necessarily from A-Phase on Bus S. Likewise, the voltage mapped to a merging unit voltage input that maps within the relay to VBZ (setting SYNCST := VBZ; see *Figure 5.127*) is not necessarily from B-Phase on Bus T. The connection can be from any phase-to-neutral or phase-to-phase voltage. Settings in the SEL-487E compensate for any steady-state magnitude or angle difference with respect to a synchronism-check voltage reference, as discussed next in this example.

Three-phase line voltages are mapped to relay voltage inputs VAV, VBV, and VCV (these voltage inputs are also used for LOP and directionality). Only one of these single-phase voltage inputs is designated for use in synchronism check. In this example, this voltage input is also designated the synchronism-check voltage reference (setting SYNCP := VAV; see *Figure 5.127*). As the synchronism-check voltage reference, the relay makes all steady-state magnitude and angle adjustments for the Bus S and Bus T synchronism-check voltages (mapped to voltage inputs VAZ and VBZ, respectively, as discussed in the preceding paragraph) with respect to this designated reference line voltage, VAV, as discussed later in this example.

Merging Unit Publications	SEL-487E Subscriptions
VAY, VBY, VCY	VAV, VBV, VCV
VAZ, VBZ, VCZ	VAZ, VBZ

Figure 5.127 Example Synchronism-Check Voltage Connections to the SEL-487E-5

For a single-circuit breaker application, map the three-phase voltage source to voltage inputs VAV, VBV, and VCV. If a single-phase voltage source is available on the other side of the circuit breaker for synchronism check, map the source to voltage input VAZ, VBZ, or VCZ.

Voltage Magnitude and Angle Compensation

The *Figure 5.127* example continues in *Figure 5.128*. The *Figure 5.128* example demonstrates possible voltage mapping connections (presuming ABC phase rotation). The synchronism-check voltage reference (V_P) is from the A-Phase voltage (V_A) of the line (setting SYNCP := VAV). You can map the voltage synchronizing source, SYNCSS, as a phase-to-phase voltage V_{BC} originating from Bus S, and map the voltage synchronizing source, SYNCST, as a phase-to-neutral voltage V_C from Bus T. Thus, Bus S voltage V_{BC} lags synchronism-check voltage reference V_P by 90 degrees, and Bus T voltage V_C lags the synchronism-check voltage reference V_P by 240 degrees (same as –120 degrees). To compensate for these steady-state angle differences, set KSSA for Bus S and KSTA for Bus T as follows.

KSSA := **90** Synchronism Source S Angle Shift (–179.99 to 180 degrees)

KSTA := **–120** Synchronism Source T Angle Shift (–179.99 to 180 degrees)

Figure 5.128 Synchronism-Check Voltage Reference

For a given secondary base voltage, phase-to-phase voltages are a factor of 1.73 ($\sqrt{3}$) times the magnitude of the phase-to-neutral voltages. In reverse, phase-to-neutral voltages are a factor of 0.58 ($1/\sqrt{3}$) times the magnitude of the phase-to-phase voltages. Therefore, you must compensate the Bus S voltage V_{BC} magnitude with setting KSSM to reference it to the synchronism-check voltage reference V_P magnitude.

KSSM := **0.58** Synchronism Source S Ratio Factor (0.10–3.00)

You do not need special magnitude compensation for the Bus T voltage V_C to reference Synchronism Source T to the synchronism-check voltage reference V_P magnitude; these are both phase-to-neutral voltages with the same nominal rating (for example, 67 V secondary).

KSTM := **1.00** Synchronism Source T Ratio Factor (0.10–3.00)

As another example of synchronism-source magnitude adjustment flexibility, suppose Bus S voltage V_{BC} is 201 V secondary (phase-to-phase), and the synchronism-check voltage reference V_P is 67 V secondary (phase-to-neutral). Then, the magnitude compensation setting would be as in *Equation 5.38*.

$$\text{KSSM} = \frac{67\ \text{V}}{201\ \text{V}} := 0.33$$

Equation 5.38

Normalized Synchronism-Check Voltage Sources VSS and VST

The *Figure 5.128* example continues in *Figure 5.129*. *Figure 5.129* graphically illustrates how the introduced settings adjust the Bus S and Bus T synchronism-check input voltages in angle and magnitude to reference to the synchronism-check voltage reference, V_P. The resultant Bus S and Bus T voltages are the normalized synchronism-check voltage sources V_{SS} and V_{ST}, respectively.

Voltages V_P, V_{SS}, and V_{ST} are used in the logic of this section to check for healthy voltage and determine voltage phase angle for synchronism-check element operation. Analog quantities 25VPFM and 25VPFA are available to monitor the polarizing voltage magnitude and angle. Similarly, the analog quantities 25VS*m*FM and 25VS*m*FA are available to monitor the normalized synchronizing voltage magnitude and angle for Breaker *m*.

Figure 5.129 Normalized Synchronism-Check Voltage Sources V_{SS} and V_{ST}

Voltage Checks and Blocking Logic

Two conditions can cause the synchronism-check function in the SEL-487E to abort. These conditions are out-of-range synchronism-check input voltages and block synchronism-check configurations that you specify in SELOGIC control equations.

Voltage Magnitude Checks (Applicable When 25_SCHM = Y or Y2)

For synchronism check to proceed for a given circuit breaker (BKS or BKT) when 25_SCHM = Y or Y2, the voltage magnitudes of the synchronism-check voltage reference, V_P, and the corresponding normalized synchronism-check voltage source on the other side of the circuit breaker (normalized voltage V_{SS} for Circuit Breaker BKS and normalized voltage V_{ST} for Circuit Breaker BKT) must lie within a healthy voltage window, bounded by voltage threshold settings 25VH and 25VL (see *Figure 5.130*).

The relay asserts Relay Word bits 59VP, 59VSS, and 59VST to indicate healthy synchronism-check voltages V_P, V_{SS}, and V_{ST} (see *Figure 5.130*). If either of the voltage pairs (V_P and V_{SS} or V_P and V_{ST}) does not meet this healthy voltage criterion, synchronism check cannot proceed for the circuit breaker associated with the corresponding voltage pair.

Figure 5.130 Healthy Voltage Window and Indication

Voltage Difference Checks (Applicable When 25_SCHM = Y1 or Y2)

NOTE: Analog quantities 25VPFM and 25VPFA are forced to zero when EISYNC := Y; analog quantities 25VPmFM and 25VPmFA are forced to zero when EISYNC := N.

For synchronism check to proceed for a given circuit breaker (BK*m*) when 25_SCHM = Y1 or Y2, the absolute value of the difference between the synchronism-check reference voltage, 25VPFM, and the corresponding normalized synchronism-check voltage source on the other side of the circuit breaker, 25VS*m*FM (*m* = S, T, U, W, X, Y), must be less than the 25VDIF setting (see *Figure 5.131*). The logic includes a 5 V secondary check to ensure the relay does not operate on erroneous signals.

[1]25VPFM is replaced with 25VP*m*FM when EISYNC = Y

Figure 5.131 Synchronism-Check Voltage Difference Logic

Block Synchronism Check

If the block synchronism check BSYNBK*m* SELOGIC control equation (where *m* = S, T, U, W, X, or Y asserts, synchronism check cannot proceed for the corresponding circuit breaker. Following is an example for Circuit Breaker BK*m*:

BSYNBKm := **52CLm** Block Synchronism Check—BK*m* (SELOGIC Equation)

If Circuit Breaker BK*m* is closed, the indication back to the relay shows 52CL*m* equals logical 1. Thus, BSYNBK*m* equals logical 1, and synchronism check is blocked for Circuit Breaker BK*m*. There is no need to qualify or continue with the synchronism check for circuit breaker closing; the circuit breaker is already closed.

Synchronism-Check Enable Logic

The relay combines the voltage check elements and block synchronism check condition to create a synchronism-check enable condition for each circuit breaker, as shown in *Figure 5.132*. The 25_SCHM setting determines which enable logic is active.

Figure 5.132 Synchronism-Check Enable Logic

Angle Checks and Synchronism-Check Element Outputs

After the relay determines that it is appropriate to enable synchronism-check logic as defined in *Figure 5.132*, the relay must check voltage phase angles across the circuit breakers before a final synchronism-check element output can be available for supervising circuit breaker closing.

The following discussion/examples use Circuit Breaker BKS. Synchronism-check element output operation for Circuit Breaker BKT, U, W, X, or Y is similar (replace BKT, U, W, X, or Y for BKS in associated settings and Relay Word bits).

Angle Difference Settings ANG1BKS and ANG2BKS

NOTE: For SV applications, operating times are delayed by the configured channel delay, CH_DLY. See SV Network Delays on page 17.33 in the SEL-400 Series Relays Instruction Manual for more details. For TiDL applications, the operating times are delayed by a fixed 1 ms. Use caution when setting relay coordination to account for this added delay.

Each circuit breaker has two angle difference windows. For Circuit Breaker BKS, the maximum angle difference settings are ANG1BKS and ANG2BKS.

Slip-Frequency Element

[1]Each breaker is assigned a polarizing voltage (VP*m*) and normalized when EISYNC = Y. See ① for details.

① Independent Synchronism-Check Polarizing Voltage Selection Settings on page 5.149

Figure 5.133 Breaker S Slip-Frequency Check Logic

"No-Slip" and "Slipping" Synchronism-Check Elements

Figure 5.134 and *Figure 5.135* show the logic for static and slipping synchronism-check elements. The following examples compare the operation of these two elements under different system conditions.

[1]Each breaker is assigned a polarizing voltage (VP*m*) and normalized when EISYNC = Y. See ① for details.

① Independent Synchronism-Check Polarizing Voltage Selection Settings on page 5.149

Figure 5.134 Static (Not Slipping) Synchronism-Check Elements

① Independent Synchronism-Check Polarizing Voltage Selection Settings on page 5.149

Figure 5.135 Slipping Synchronism-Check Elements

"No-Slip" Synchronism Check

Refer to the paralleled system beyond the open circuit breaker in *Figure 5.124*. For such a system, there is essentially no slip across the open circuit breaker (the monitored voltage phasors on each side are not moving with respect to one another). In a "no-slip" system, any voltage angle difference across the open circuit breaker remains relatively constant.

The four drawings shown in *Figure 5.136* are separate, independent cases for a "no- slip" paralleled system. If the phase angle between the synchronism-check voltage reference V_P and the normalized synchronism-check voltage source V_{SS} is less than angle setting ANG1BKS, synchronism-check element output 25A1S asserts to logical 1. The relay declares that the per-phase voltages across Circuit Breaker BKS are in synchronism. Otherwise, if the phase angle is greater than or equal to angle setting ANG1BKS, element output 25A1S deasserts to logical 0; the relay declares that the per-phase voltages across Circuit Breaker BKS are out-of-synchronism.

The out-of-synchronism phase angles in *Figure 5.136* appear dramatic for a "no-slip" paralleled system. This is for illustrative purposes; these angles are not usually this large in actual systems.

Figure 5.136 "No-Slip" System Synchronism-Check Element Output Response

Slip Frequency and SFZBKS

Relay Word bit SFZBKS (BKS Slip Frequency less than 0.005 Hz) also asserts to logical 1, indicating a "no-slip" condition across Circuit Breaker BKS. In other words, the slip frequency is less than 0.005 Hz ($|f_{SS}–f_P| < 0.005$ Hz).

Synchronism-Check Element Output Effects

Note that during a "no-slip" condition, FASTS, SLOWS, and SFBKS are all deasserted, forcing 25C1S to logical 0.

"Slip—No Compensation" Synchronism Check

The four cases [*(a)*, *(b)*, *(c)*, and *(d)*] shown in *Figure 5.137* are "slip—no compensation" cases for asynchronous systems (not paralleled). The cases progress in time from top to bottom. The normalized synchronism-check voltage source V_{SS} slips with respect to synchronism-check voltage reference V_P. The indication

of the rotation arrow on phasor V_{SS} (and the time progression from top to bottom) shows that the system corresponding to V_{SS} has a higher system frequency f_{SS} than the system corresponding reference V_P with system frequency f_P. The slip frequency across Circuit Breaker BKS is $f_{SS}–f_P$.

Figure 5.137 "Slip—No Compensation" Synchronism-Check Element Output Response

Positive Slip Frequency

If the slip frequency is positive, V_{SS} is slipping ahead of reference V_P (the system corresponding to V_{SS} has a higher system frequency than the system corresponding to V_P; $f_{SS} > f_P$). Positive slip frequency is the counter-clockwise rotation of V_{SS} with respect to reference V_P, as shown in *Figure 5.137*. Relay Word bit FASTS asserts to logical 1 (and Relay Word bit SLOWS deasserts to logical 0) to indicate this condition.

Negative-Slip Frequency

If the slip frequency is negative, V_{SS} is slipping behind reference V_P (the system corresponding to V_{SS} has a lower system frequency than the system corresponding to V_P; $f_{SS} < f_P$). For such a case, V_{SS} rotates clockwise with respect to reference V_P. Relay Word bit SLOWS asserts to logical 1 (and Relay Word bit FASTS deasserts to logical 0) to indicate this condition.

"No-Slip" Condition

If the absolute value of the slip is less than 0.005 Hz ($|f_{SS}–f_P| < 0.005$ Hz; a "no-slip" condition), both Relay Word bits FASTS and SLOWS deassert to logical 0 and Relay Word bit SFZBKS asserts to logical 1. A "no-slip" condition is confirmed when FASTS and SLOWS are deasserted and SFZBKS is asserted.

Synchronism-Check Element Output Effects

Compare the corresponding "slip—no compensation" cases in *Figure 5.137* to the previous "no-slip" cases in *Figure 5.136*.

With setting 25SFBKS := OFF, the relay does not compensate for the further angular travel of V_{SS} (with respect to reference V_P) during the Circuit Breaker BKS close time setting TCLSBKS. The relay measures the phase angle directly with no compensation between reference V_P and V_{SS} for synchronism-check element output 25WC1S. SFKBS is deasserted when 25SFBKS := OFF, forcing 25C1S to logical 0.

The relay always measures the phase angle directly (without compensation) between reference V_P and V_{SS} for element output 25A1S. Setting 25SFBKS, time setting TCLSBKS, and whether system conditions are "no-slip" (*Figure 5.136*) have no effect on element output 25A1S.

"Slip—With Compensation" Synchronism Check

Figure 5.138 is derived from *Figure 5.137*, but with the maximum slip-frequency setting 25SFBKS set to some value other than OFF; thus, the relay compensates for circuit breaker closing time with setting TCLSBKS. This results in a compensated normalized synchronism-check voltage source V'_{SS}.

Figure 5.138 "Slip–With Compensation" Synchronism-Check Element Output Response

NOTE: For SV applications, operating times are delayed by the configured channel delay, CH_DLY. See SV Network Delays on page 17.33 in the SEL-400 Series Relays Instruction Manual for more details. For TiDL applications, the operating times are delayed by a fixed 1 ms. Use caution when setting relay coordination to account for this added delay.

Element 25C1S follows V'_{SS}. With setting 25SFBKS (maximum slip frequency) set to other than OFF, the relay calculates V'_{SS} derived from V_{SS}. Phasor V'_{SS} leads V_{SS} by an angle described by *Equation 5.39*.

$$\text{angle} = \frac{(f_{SS} - f_P)\text{slip cycle}}{s \bullet \frac{60\ \text{cyc}}{s}} \bullet \frac{360°}{\text{slip cycle}} \bullet \text{TCLSBKS (cyc)}$$

Equation 5.39

From *Equation 5.39*, note that the angle between V_{SS} and V'_{SS} increases for a greater slip between V_{SS} and V_P (f_{SS}–f_P), a greater Circuit Breaker BKS close time setting TCLSBKS, or both in combination. For any case [*(a)*, *(b)*, *(c)*, or *(d)*] in *Figure 5.138*, the location of V'_{SS} is the location of V_{SS} a period later (this period is setting TCLSBKS, Circuit Breaker BKS Close Time). Consider, for

example, issuing a close command to Circuit Breaker BKS. If case *(b)* in *Figure 5.138* represents the time at which the close command occurs, then V_{SS} is the normalized synchronism-check voltage source position at the instant the close is issued and V'_{SS} is the position of V_{SS} when Circuit Breaker BKS actually closes.

Slip Frequency

If the slip frequency exceeds setting 25SFBKS, synchronism check stops because element output 25C1S deasserts to logical 0 for an out-of-range slip frequency condition, regardless of other synchronism-check conditions such as healthy voltage magnitudes.

Synchronism-Check Element Output Effects

A contradiction seems to result from analysis of case *(a)* in *Figure 5.138*; it appears that element output 25C1S should assert to logical 1 because V'_{SS} is within angle setting ANG1BKS. Note in this case, however, that V'_{SS} is approaching synchronism-check reference V_P. This is where element output 25C1S behaves differently than element output 25A1S, for setting 25SFBKS set to some value other than OFF. As V'_{SS} approaches V_P, 25C1S remains deasserted (equals logical 0) until the phase angle difference between reference V_P and V'_{SS} equals zero degrees.

At this zero degrees difference between V_P and V'_{SS}, element output 25CS1 asserts to logical 1. We know the systems will truly be in synchronism (0 degrees between reference V_P and V_{SS}) a period later (this period is setting TCLSBKS, Circuit Breaker BKS Close Time). Thus, if a close command occurs right at the instant that element output 25C1S asserts to logical 1, then there will be a zero-degree phase angle difference across Circuit Breaker BKS when Circuit Breaker BKS actually closes. Closing Circuit Breaker BKS at a phase angle difference of 0 degrees between reference V_P and V'_{SS} minimizes system shock when you bring two asynchronous systems together.

Element output 25C1S remains asserted to logical 1 as V'_{SS} moves away from reference V_P. When the phase angle difference between reference V_P and V'_{SS} is again greater than an angle setting ANG1BKS, element output 25C1S deasserts to logical 0.

With the slip frequency greater than 0.005 Hz and 25SFBKS set to other than OFF, element output 25A1S remains deasserted.

Alternative Synchronism-Check Source ALTSm Settings

You can program alternative input sources for the synchronism-check function in the SEL-487E. Alternative inputs give you additional flexibility to synchronize other portions of your power system.

The SELOGIC control equation ALTS*m* determines when the relay uses alternative Synchronism-Check Voltage Source *m* in place of regular Synchronism-Check Voltage Source *m*. When ALTS*m* is logical 1, the relay substitutes alternative Synchronism-Check Voltage Source *m* (ASYNCS*m*) and corresponding settings AKS*m*M and AKS*m*A for the regular Synchronism-Check Voltage Source *m* values SYNCS*m*, KS*m*M, and KS*m*A. The result is a normalized synchronism-check voltage source V_{Sm} derived from the alternative source.

Example 5.8 Setting Alternative Synchronism-Check Source T

Figure 5.139 shows an extra circuit breaker (BKU) and a generator position added to the existing example system of *Figure 5.124*. You can monitor the voltage at the generator position by mapping a single-phase voltage to remaining voltage input VCZ (see *Figure 5.127*). Make setting ASYNCST := VCZ to designate this relay voltage input as the alternative synchronism-check voltage source.

ASYNCST := **VCZ** Alternative Synchronism Source T (VAV, VBV, VCV, VAZ, VBZ, VCZ)

For this new synchronism source voltage connection, adjust the source-to-reference magnitude ratio with setting AKSTM and the source-to-reference angle compensation with setting AKSTA, considering the settings for Voltage Magnitude and Angle Compensation.

Figure 5.139 Alternative Synchronism-Check Source T Example and Settings

For example, in *Figure 5.139*, the Bus T voltage is the preferred Synchronism-Check Voltage Source T for synchronism check across Circuit Breaker BKT. However, if Circuit Breaker BKU is open and the generator switch is closed, the preferred Synchronism-Check Voltage Source T transfers to the Alternative Synchronism-Check Voltage Source T the voltage from the generator position.

Example 5.8 Setting Alternative Synchronism-Check Source T (Continued)

For circuit breaker status, make the following 52A auxiliary contact connections from the circuit breaker and switch to control inputs on the SEL-487E:

- Circuit Breaker BKU to IN203
- Generator switch to IN202

These input connections are for this application example only; use relay inputs that are appropriate for your system.

Set the ALTST SELOGIC control equation to assert when Circuit Breaker BKT is open and the generator switch is closed.

ALTST := **IN202 AND NOT IN203** Alternative Synchronism Source T (SELOGIC equation)

Independent Synchronism-Check Polarizing Voltage Selection Settings

You can program independent and alternative polarizing voltages for each available breaker synchronism-check element via the enable independent synchronism check setting, EISYNC.

Setting EISYNC := Y enables dynamic reconfiguration of the polarizing sources based on changes in substation topology. With EISYNC := Y, each breaker has its own unique polarizing voltage with two alternative polarizing sources. See *Example 5.9* for a description of a practical application that uses these settings. When EISYNC := N, breakers use the same polarizing voltage (VP), and there are no alternative polarizing sources available, as described earlier in this section.

The user-programmable ALTP*m*1 and ALTP*m*2 logic settings are available while EISYNC := Y, and when combined, they determine the active polarizing voltage for Breaker *m* (*m* = S, T, U, W, X, or Y), as shown in *Figure 5.140*. The impact of the logic is then summarized in *Table 5.20*.

Figure 5.140 Alternative Synchronism-Check Polarizing Voltage Selection Logic

Table 5.20 shows that when ALTP*m*1 := 0, the status of ALTP*m*2 does not impact the selected polarizing voltage.

Table 5.20 Active Polarizing Voltage

ALTPm1	ALTPm2	Polarizing Voltage for Breaker m
0	0	SYNCP*m*
0	1	SYNCP*m*
1	0	ASYNP*m*1
1	1	ASYNP*m*2

Use the ALTP*m*1 and ALTP*m*2 settings to determine the alternative polarizing voltages and use the ALTS*m* setting to determine the alternative synchronizing voltage. See *Alternative Synchronism-Check Source ALTSm Settings on page 5.147* for additional information on alternative synchronizing voltages.

When compensating synchronism-check voltages, create an equivalent voltage base for secondary voltage magnitudes and account for any phase shifts between voltage inputs on a per-breaker basis. Typically, the polarizing voltage source of one of the breakers is used as the voltage and phase angle reference to which all other synchronism-check voltages are to be compensated. When configuring alternative sources for both polarizing and synchronizing quantities, the primary and alternative voltages need to be compensated to the same equivalent base.

Group settings KP*m*M and KP*m*A are provided when EISYNC := Y to compensate the magnitude and angle of the primary polarizing voltage input identified by the SYNCP*m* setting. The AKP*m*1M and AKP*m*1A settings compensate the magnitude and angle of the first alternative polarizing voltage input, as identified by the ASYNP*m*1 setting. The AKP*m*2M and AKP*m*2A settings compensate the magnitude and angle of the second alternative polarizing voltage input, as identified by the ASYNP*m*2 setting. These compensation settings are similar to KS*m*M and KS*m*A, which were previously discussed in *Alternative Synchronism-Check Source ALTSm Settings on page 5.147*,

The active polarizing voltage for Breaker *m* is compensated by the associated compensating factors and then assigned to the 25VP*m*FM and 25VP*m*FA analog quantities. The 25VP*m*FM quantity is compared to the synchronizing source voltage, 25VS*m*FM, and the voltage-difference setting, 25VDIF, to ensure an acceptable voltage difference between the polarizing and source voltages, as shown in *Figure 5.131*.

Whenever a synchronizing or polarizing voltage quantity changes through either the ALTS*m* or the ALTP*m*1 and ALTP*m*2 settings, the synchronism-check enable bit is reset, and there is a 6-cycle stability counter that must be satisfied prior to re-enabling the Breaker *m* synchronism-check logic (25ENBK*m* = 1). See *Figure 5.132*.

Example 5.9 Synchronism-Check Application/Settings Example (EISYNC = Y)

Figure 5.141 shows a line switch added to the existing example system of *Figure 5.139*.

The bus voltages are available to the relay unconditionally, and the line voltage measurement (VAV) is only available to the relay if the line disconnect switch, 89L1, is closed. Similarly, the generator voltage measurement (VBZ) is only available to the relay if the Line 2 disconnect switch, 89L2, is closed. Assume the normally open 89L1A and 89L2A contacts are mapped to relay digital inputs IN201 and IN202, respectively.

Consider the settings for the Breaker S synchronism-check element. The Bus S voltage (VAZ) acts as the synchronizing quantity for Breaker S, and no alternative value is needed. The synchronizing-voltage settings for Breaker S are SYNCSS := VAZ and ALTSS := NA.

Example 5.9 Synchronism-Check Application/Settings Example (EISYNC = Y) (Continued)

VAV is the preferred polarizing quantity for Breaker S. If disconnect switch 89L1 is open and this voltage is unavailable, the relay instead uses VBZ from the generator as a first alternative polarizing source for Breaker S. If disconnect switches 89L1 and 89L2 are both open, the relay uses the Bus T voltage (VCZ) as a second alternative polarizing source for Breaker S. The polarizing voltage settings for Breaker S are SYNCPS := VAV, ASYNPS1 := VBZ, ASYNPS2 := VCZ, ALTPS1 := NOT IN201, and ALTPS2 := NOT IN202.

Consider the settings for the Breaker T synchronism-check element. VAV is the preferred polarizing quantity for Breaker T. If disconnect switch 89L1 is open and this voltage is unavailable, the relay instead uses VAZ (from Bus S) as an alternative polarizing source for Breaker T. The polarizing voltage settings for Breaker T are SYNCPT := VAV, ASYNPT1 := VAZ, ALTPT1 := NOT IN201, ALTPT2 := NA.

VBZ is the preferred synchronizing quantity for Breaker T. If disconnect switch 89L2 is open and this voltage is unavailable, the relay instead uses VCZ (from Bus T) as an alternative synchronizing source for Breaker T. The synchronizing voltage settings for Breaker T are SYNCST := VBZ, ASYNCST := VCZ, and ALTST := NOT IN202.

As a final application note for EISYNC = Y, be sure to use the angle-correction factors to compensate for use of voltages from different phases (e.g., A, B, or C) and to compensate for differently connected potential transformers (e.g., delta or wye).

Breaker S

Polarizing	Synchronizing
SYNCPS := VAV	SYNCSS := VAZ
ASYNPS1 := VBZ	ALTSS := NA
ALTPS1 := NOT IN201	
ASYNPS2 := VCZ	
ALTPS2 := NOT IN202	

Breaker T

Polarizing	Synchronizing
SYNCPT := VAV	SYNCST := VBZ
ASYNPT1 := VAZ	ASYNCST := VCZ
ALTPT1 := NOT IN201	ALTST := NOT IN202
ALTPT2 := NA	

Figure 5.141 Alternative Synchronism-Check Polarizing Voltage Example System

Over- and Undervoltage Elements

The SEL-487E offers as many as five undervoltage and five overvoltage elements. Each of these 10 elements has two levels, for a total of 20 under- and overvoltage elements. *Figure 5.142* shows the undervoltage elements, and *Figure 5.143* shows the overvoltage elements.

Table 5.21 Fundamental or RMS Operating Quantities[a]

Parameter	Fundamental Quantities	RMS Quantities
Phase and Phase-to-Phase	V*pk*FM, V*ppk*FM, VNMIN*k*F, VNMAX*k*F, VPMIN*k*F, VPMAX*k*F	V*pk*RMS, V*ppk*RMS, VNMIN*k*R, VNMAX*k*R, VPMIN*k*R, VPMAX*k*R
Sequence	V1*k*M, 3V2*k*M[b], 3V0*k*M[b]	

[a] where:
p = A, B, C
pp = AB, BC, CA
k = V, Z

[b] Not available for undervoltage elements.

NOTE: For SV applications, operating times are delayed by the configured channel delay, CH_DLY. See SV Network Delays on page 17.33 in the SEL-400 Series Relays Instruction Manual for more details. For TiDL applications, the operating times are delayed by a fixed 1 ms. Use caution when setting relay coordination to account for this added delay.

Figure 5.142 Undervoltage Elements

Although each under- and overvoltage element offers two levels, only Level 1 has a timer. If your application requires a time delay for the Level 2 elements, use a programmable timer to delay the output.

Figure 5.143 Overvoltage Elements

Select any one of the voltage elements from *Table 5.21* as an input quantity. You can select the same quantity for the undervoltage element as for an overvoltage element. Be sure that the PT terminal is enabled with the Group EPTTERM setting. For example, if EPTTERM = V, then only voltage values from the V PT are available for selection.

Over- and Undervoltage Settings

E59 (Enable Overvoltage Elements)

Select the number of overvoltage elements (1–5) you require for your application. This setting is not available if EPTTERM = OFF.

E27 (Enable Undervoltage Elements)

Select the number of undervoltage elements (1–5) you require for your application. This setting is not available if EPTTERM = OFF.

27On (Undervoltage Element Operating Quantity)

Select the operating quantity you want for each voltage terminal from *Table 5.21*. Only voltage quantities from enabled voltage terminals are available.

27PnP1 (Undervoltage Level 1 Pickup)

Set pickup values for the voltage values below which you want the Level 1 undervoltage elements to assert.

27PnP2 (Undervoltage Level 2 Pickup)

Set pickup values for the voltage values below which you want the Level 2 undervoltage elements to assert.

27TC (Undervoltage Torque Control)

Use the torque-control setting to specify conditions under which the undervoltage elements must be active. There is only one setting for both Level 1 and Level 2 elements. With the default setting equal to 1, both levels are active permanently.

To provide selective protection disabling of the 27 elements under data loss conditions, include the analog channel status Relay Word bits in the torque-control equations for these elements (see *Analog Channel Statuses on page 5.2* and *Application Setting SVBLK and Relay Word Bit SVBK_EX on page 5.5*).

27PnD1 (Undervoltage Level 1 Time Delay)

When the system voltage falls below the undervoltage setting value, the undervoltage timer starts timing. Set the delay (in cycles) for which the timer must run before the 27P*n*D1 setting asserts the output.

59On (Overvoltage Element Operating Quantity)

Select from *Table 5.21* the operating quantity you want for each voltage terminal. Only voltage quantities from enabled voltage terminals are available.

59PnP1 (Overvoltage Level 1 Pickup)

Set pickup values for the voltage values above which you want the Level 1 overvoltage elements to assert.

59PnP2 (Overvoltage Level 2 Pickup)

Set pickup values for the voltage value above which you want the Level 2 overvoltage elements to assert.

59TCn (Overvoltage Torque Control)

Use the torque-control setting to specify conditions under which the overvoltage elements must be active. There is only one setting for both Level 1 and Level 2 elements. With the default setting equal to 1, both levels are active permanently.

To provide selective protection disabling of the 59 elements (particularly those operating on zero- or negative-sequence voltages) under data loss conditions, include the analog channel status Relay Word bits in the torque-control equations for these elements. By default, no selective protection disabling is provided in the torque-control equations (see *Analog Channel Statuses on page 5.2* and *Application Setting SVBLK and Relay Word Bit SVBK_EX on page 5.5*).

59PnD1 (Overvoltage Level 1 Time Delay)

When the system voltage exceeds the overvoltage setting value, the overvoltage timer starts timing. Set the delay (in cycles) for which the timer must run before the 59P*n*D1 setting asserts the output.

Frequency Estimation

The relay uses filtered analog values related to the system frequency to calculate internal quantities such as phasor magnitudes and phase angles. When the system frequency changes, the relay measures these frequency changes and adapts the processing rate of the protection functions accordingly. Adapting the processing rate is called frequency tracking.

Note that frequency measurement is not the same as frequency tracking. The relay first measures the frequency and then tracks the frequency by changing the processing rate.

The relay measures the frequency over the 20–80 Hz range (protection frequency, see FREQP in *Table 5.23*), but only tracks the frequency over the 40–65 Hz range (see FREQ in *Table 5.23*). If the system frequency is outside the 40–65 Hz range, the relay does not track the frequency. Instead, it clamps the frequency to either limit. For frequencies below 40 Hz, the relay clamps the frequency at 40 Hz. For frequencies above 65 Hz, the relay clamps the frequency at 65 Hz.

NOTE: The SEL-487E-5 freezes its frequency measurement and tracking for 4 cycles upon a transition of VYOK or VZOK. This adds security to the frequency measurement and tracking during DSS data loss conditions.

To measure the frequency, the relay calculates the alpha component quantity and then estimates the frequency based on the zero-crossings of the alpha component. Relay Word bit FREQOK asserts when the relay measures the frequency over the range 20–80 Hz. If the frequency is below 40 Hz or above 65 Hz, FREQ reports the clamped values of either 40 Hz or 65 Hz. In this case, the relay no longer tracks the frequency. Instead, it uses either 40 Hz or 65 Hz to calculate the internal quantities.

If the frequency is in the 20–80 Hz range, but outside the 40–65 Hz range (for example, 70 Hz), FREQP shows the frequency the relay measures and FREQ shows the clamped frequency. In this case, FREQP = 70 Hz and FREQ = 65 Hz. *Table 5.22* summarizes the frequency measurement and frequency tracking ranges.

If the frequency is below 20 Hz or above 80 Hz, the relay no longer measures the frequency. Relay Word bit FREQFZ asserts and Relay Word bit FREQOK deasserts to indicate this condition. FREQ and FREQP are no longer valid, but they display the frequency at the time that the relay stopped measuring the frequency.

Table 5.22 Frequency Measurement and Frequency Tracking Ranges

Frequency Range (Hz)	Measures Frequency	Tracks Frequency	FREQOK	FREQFZ
40–65	Y	Y	1	0
20–39.99	Y	N	1	0
65.01–80	Y	N	1	0
Below 20 or above 80	N	N	0	1

The relay has six voltage inputs (VAV, VBV, VCV, VAZ, VBZ, and VCZ) that can be used as sources for estimating the frequency. Assign any of the six voltage inputs to VF01, VF02, and VF03. Note that assigning **ZERO** will set that input to zero. The relay also provides an alternative frequency source selection where you can assign any of the six voltage inputs to VF11, VF12, and VF13. The relay uses VF01, VF02, and VF03 as sources if the SELOGIC evaluation of EAFSRC is 0. The relay uses VF11, VF12, and VF13 as sources if EAFSRC is 1. The relay calculates the alpha quantity, Valpha, as shown in *Figure 5.144* using the mapped sources. Note that the alpha quantity is based on the instantaneous secondary voltage samples from the mapped resources and is an instantaneous quantity.

Figure 5.144 SEL-487E Alpha Quantity Calculation

Table 5.23 Frequency Estimation Outputs

Name	Description	Type
FREQ	Measured system frequency (Hz) (40–65 Hz)	Analog Quantity
FREQP	Measured frequency (Hz) (20–80 Hz)	Analog Quantity
FREQOK	Measured frequency is valid	Relay Word bit
FREQFZ	Measured frequency is frozen	Relay Word bit

Undervoltage Supervision Logic

Relay Word bit 27B81, the output of the logic in *Figure 5.145*, supervises the frequency elements for system undervoltage conditions. In the logic, the comparator compares the absolute value of the alpha component voltage (Valpha) against the 81UVSP setting value. *Equation 5.40* shows the equation for calculating Valpha.

$$\text{Valpha} = \text{VF01} - \left[\frac{\text{VF02}}{2} + \frac{\text{VF03}}{2}\right]$$

Equation 5.40

Generally, settings VF01, VF02, VF03 correlate to VA, VB, and VC.

Equation 5.41 shows the relationship between the peak amplitude of Valpha and the rms value of the system voltage phasors for three-phase voltage inputs.

$$\text{Valpha} = \sqrt{2} \bullet 1.5 \bullet \text{Vrms}$$

Equation 5.41

where Vrms is the root-mean-square value of the voltage phasor.

Relay Word bit 27B81 asserts if Valpha falls below the 81UVSP setting value for longer than a cycle.

Figure 5.145 Undervoltage Supervision Logic

Calculate the 81UVSP Setting Value

Because the relay accepts voltage input from the PTs in any combination, Valpha can have different values, depending on the voltage inputs. In general, the following examples use the average (60 percent) of the 50–70 percent undervoltage range that the IEEE C37.117 Guide recommends. Also, the calculations are based on an rms phase-to-neutral value of 67 V for the PT inputs, although the 81UVSP setting is a peak value and not an rms value.

Case 1: Three-Phase PT Inputs

In this case, VF01 = VA, VF02 = VB, and VF03 = VC (with default settings). Use *Equation 5.41* to calculate the nominal value of Valpha as follows:

$$\text{Valpha} = \sqrt{2} \bullet 1.5 \bullet 67 \text{ V}$$

Equation 5.42

$$\text{Valpha} = 142.13 \text{ V}$$

Equation 5.43

Set 81UVSP to 60 percent of this value:

$$\text{81UVSP} = 0.6 \bullet 142.13 \text{ V}$$

Equation 5.44

$$\text{81UVSP} = 85.28 \text{ V}$$

Equation 5.45

Case 2: Single-Phase PT Input, Connected to the A-Phase Input

In this case, VF01 = VA, VF02 = ZERO, and VF03 = ZERO.

$$\text{Valpha} = \sqrt{2} \bullet 67 \text{ V}$$

Equation 5.46

$$\text{Valpha} = 94.75\ \text{V}$$

Equation 5.47

Set 81UVSP to 60 percent of this value:

$$81\text{UVSP} = 0.6 \bullet 94.75\ \text{V}$$

Equation 5.48

$$81\text{UVSP} = 56.85\ \text{V}$$

Equation 5.49

Case 3: Single-Phase PT Input, Connected to the B- or C-Phase Input

In this case, VF01 = ZERO, VF02 = VB, and VF03 = ZERO.

$$\text{Valpha} = \sqrt{2} \bullet \frac{67}{2}\text{V}$$

Equation 5.50

$$\text{Valpha} = 47.37\ \text{V}$$

Equation 5.51

Set 81UVSP to 60 percent of this value:

$$81\text{UVSP} = 0.6 \bullet 47.37\ \text{V}$$

Equation 5.52

$$81\text{UVSP} = 28.43\ \text{V}$$

Equation 5.53

Table 5.24 summarizes the results of the three cases.

Table 5.24 Summary of the Valpha and 81UVSP Calculations

Case	PT Connections	VA	VB	VC	Valpha	0.6 • Valpha
Case 1	Three-phase	67 ∠0°	67 ∠–120°	67 ∠120°	142.13	85.28
Case 2	Single-phase, VA	67 ∠0°	0	0	94.75	56.85
Case 3	Single-phase, VB/VC	0	67 ∠–120°	0	47.38	28.43

Over- and Underfrequency Elements

Use the relay frequency elements for such abnormal frequency protection as underfrequency load shedding.

Figure 5.146 shows the logic for the six levels of over- and underfrequency elements in the relay.

Each frequency element can operate as an overfrequency or as an underfrequency element, depending on its pickup setting. If the element pickup setting (81D*n*P, *n* = 1–6) is less than the nominal system frequency setting, NFREQ, the element operates as an underfrequency element, picking up if measured frequency is less than the set point. If the pickup setting is greater than NFREQ, the element operates as an overfrequency element, picking up if measured frequency is greater than the set point.

Figure 5.146 Frequency Element Logic

Note that Relay Word bit 27B81 controls all six frequency elements. This undervoltage supervision control prevents erroneous frequency element operations during system faults or during DSS data loss.

Over- and Underfrequency Element Settings

E81 (Enable 81 Elements)

Set E81 to enable as many as six over- and underfrequency elements. When E81 = N, the relay disables the frequency elements and hides corresponding settings; you do not need to enter these hidden settings.

81UVSP (81 Element Undervoltage Supervision)

This setting applies to all six frequency elements. If the instantaneous alpha voltage falls below the 81UVSP setting, all frequency elements are disabled.

81DnP (Level n Pickup)

Set the value at which you want the frequency element for each of six levels to assert. For a value of 81D*n*P less than the nominal system frequency NFREQ (50 or 60 Hz), the element operates as an underfrequency element. For a value greater than NFREQ, the element operates as an overfrequency element. Note that *n* can be one of six levels, 1–6.

81DnD (Level n Time Delay)

Select a time in seconds that you want frequency elements to wait before asserting.

Total Harmonic Distortion

The SEL-487E provides a total harmonic distortion (THD) calculation for voltage inputs by using the equation shown in *Equation 5.54*.

$$\mathrm{THD} = \sqrt{\left(\frac{\mathrm{RMS}}{\mathrm{FUN}}\right)^2 - 1}$$

Equation 5.54

The THD analog quantity outputs, V*p*VTHD and V*p*ZTHD (*p* = A, B, or C), are updated every processing interval. The inputs to the THD calculation are the instantaneous rms voltage and filtered fundamental voltage magnitude.

NOTE: The –3dB point of the anti-aliasing filter is 640 Hz. Higher frequency content is attenuated from the rms calculation accordingly. See Data Processing on page 9.1 in the SEL-400 Series Relay Instruction Manual for more information.

While an rms quantity is used, the calculation takes into account interharmonic components. Interharmonic components can be caused by fluctuating system voltage, etc. You should take the expected system voltage fluctuation and any standing interharmonic components into consideration when using the THD analog quantities.

IEC Thermal Elements

Thermal Element

The relay implements three independent thermal elements that conform to the IEC 60255-149 standard. Use these elements to activate a control action or issue an alarm or trip when your equipment overheats as a result of adverse operating conditions.

The relay computes the instantaneous thermal level, H, of the equipment. The thermal level is a ratio between the estimated actual temperature of the equipment and the steady-state temperature of the equipment when the equipment is operating at a maximum current value.

The relay computes the accumulated thermal level by using the following equations:

If IEQ ≥ IEQPU:

$$THRL_t = THRL_{t-1} \bullet \left(\frac{TCONH}{TCONH + \Delta t}\right) + \left(\frac{IEQ_t}{IMC}\right)^2 \bullet \left(\frac{\Delta t}{TCONH + \Delta t}\right) \bullet FAMB$$

Equation 5.55

If IEQ < IEQPU

$$THRL_t = THRL_{t-1} \bullet \left(\frac{TCONC}{TCONC + \Delta t}\right)$$

Equation 5.56

where:

$THRL_t$ = The accumulated thermal level at time *t*

$THRL_{t-1}$ = The accumulated thermal level from the previous processing interval

Δt = The processing interval for the element, which is once every power system cycle (i.e., 50 or 60 Hz)

IEQ = The equivalent heating current at time t, given in per unit

IEQPU = The equivalent heating current pick up threshold, given in per unit

IMC = The maximum continuous current, given in per unit

TCONH = User-selectable equipment hot time constant that models the thermal characteristics of the equipment when it is energized. The setting is entered in minutes. The setting is converted to cycles before it is used in *Equation 5.56*.

TCONC = User-selectable equipment cold time constant that models the thermal characteristics of the equipment when it is de-energized. The setting is entered in minutes. The setting is converted to cycles before it is used in *Equation 5.56*.

FAMB = The ambient temperature factor

The relay calculates the equivalent heating current, IEQ, according to the following:

$$IEQ = \frac{THRO}{INOM}$$

Equation 5.57

where:

THRO = User-selectable thermal model operating current

INOM = Nominal current rating of the input associated with THRO operating current (i.e., 1 or 5 A). For combination terminals (ST, TU, UW, or WX), the INOM of the terminal with the greatest CT ratio is used.

Additionally, the relay calculates the maximum continuous current (IMC), according to the following:

$$IMC = KCONS \bullet IBAS$$

Equation 5.58

where:

KCONS = User-selectable basic current correction factor

IBAS = User-selectable basic current values in per unit

Lastly, the relay computes the ambient temperature factor, FAMB, according to the following:

NOTE: FAMB freezes on the last calculated value if the relay loses resistance temperature detector (RTD) connectivity (MAMB_OK = 0).

$$FAMB = \frac{TMAX - 40°C}{TMAX - MAMBT}$$

Equation 5.59

where:

TMAX = User-selectable maximum operating temperature of the equipment

MAMBT = Ambient temperature measurement from the user-selectable temperature probe

Thermal Element Logic

Figure 5.147 shows the thermal alarming and tripping logic for each of the three thermal elements (n = 1, 2, and 3).

Figure 5.147 Thermal Alarming and Tripping Logic

When considering settings levels for the thermal elements alarming and tripping functions, note from *Equation 5.60* that the relay calculates the instantaneous thermal level, H, as follows:

$$H = \left(\frac{IEQ_t}{IMC}\right)^2 \bullet FAMB$$

Equation 5.60

From this equation, the per-unit thermal level the relay computes depends on the per-unit current flowing through the equipment (IEQ) and the KCONS and IBAS settings (these two settings make up the IMC value). Given this information, one can set the thermal level alarm and tripping thresholds when considering the various operating current levels and temperature the equipment will be subjected to.

If the instantaneous thermal level H is greater than the thermal level trip limit (THLT*n)* and the accumulated tripping element has not yet asserted (THRLT*n*), the relay calculates the remaining time before the thermal element trips, as shown in *Equation 5.61*. The relay also calculates how much of the thermal capacity of the equipment is currently being used, as shown in *Equation 5.62*.

$$THTRIP n = TCONH n \bullet \ln\left(\frac{H n - THRL n}{H n - \left(\frac{THLT n}{100}\right)}\right)$$

Equation 5.61

$$THTCU n = 100 \bullet \left(\frac{THRL n}{\left(\frac{THLT n}{100}\right)}\right)$$

Equation 5.62

Thermal levels (THRL*n)*, thermal element remaining time before trip (THTRIP*n)*, and thermal element capacity used (THTCU*n*) are all available as analog quantities. Additionally, the three thermal level alarming Relay Word bits, (THRLA*n*), as well as the three thermal level tripping Relay Word bits, THRLT*n*, are available.

Settings Description

Enable IEC Thermal Element (ETHRIEC)

Enable 1, 2, or 3 independent thermal elements.

Label	Prompt	Range	Default
ETHRIEC	Enable IEC Thermal (N, 1–3)	N, 1–3	N

Thermal Model Operating Quantity (THROn)

The thermal model must use a current that includes all of the additional heating effects of the current passing through the equipment. For this reason, the operating current choices are the three individual phase RMS currents from a user-selectable terminal or the IMAXWR current, which is the maximum RMS current seen among the three phase currents.

Label	Prompt	Range	Default
THRO*n*[a]	Thermal Model *n* Operating Quantity	IA*m*RMS, IB*m*RMS, IC*m*RMS[b]	THRO1 = IASRMS THRO2 = IBSRMS THRO3 = ICSRMS

[a] n = 1–3.
[b] m = S, T, U, W, X, Y, ST, TU, UW, or WX.

Basic Current Value in Per Unit (IBASn)

This setting accounts for the specified limiting value of the current for which the relay is required not to operate at when considering steady-state conditions. The product of the Basic Current Value, IBAS*n* (*n* = 1–3), and the Basic Current Correction Factor, KCONS*n* (described below), is the Maximum Continuous Current, IMC, used by the relay in computing the thermal level.

Label	Prompt	Range	Default
IBAS*n*[a]	Basic Current Value in PU *n* (0.1–3.0)	0.1–3	1.1

[a] n = 1–3.

Equivalent Heating Current Pickup Value in Per Unit (IEQPUn)

The equivalent heating current pickup value is used by the relay to switch between the hot and cold time constant thermal equations. This setting defines what the equipment considers to be insignificant operating current that results in negligible heating effects. Typically this value is very close to zero, corresponding to when the equipment is de-energized.

Label	Prompt	Range	Default
IEQPU*n*[a]	Eq. Heating Current PickUp Value in PU *n* (0.05–1)	0.05–1	0.05

[a] n = 1–3.

Basic Current Correction Factor (KCONSn)

This setting dictates the maximum continuous load current of the equipment. The product of the Basic Current Value, IBAS*n*, and the Basic Current Correction Factor, KCONS*n*, is the Maximum Continuous Current, IMC, used by the relay in computing the thermal level.

Label	Prompt	Range	Default
KCONS*n*[a]	Basic Current Correction Factor n (0.50-1.5)	0.05–1	1

[a] n = 1–3.

Heating Thermal Time Constant (TCONHn)

This setting defines the thermal characteristic of the equipment when the equipment is energized, that is when the current is above the IEQPU value.

Label	Prompt	Range	Default
TCONH*n*[a]	Heating Thermal Time Constant *n* (1–500 min)	1–500 min	60

[a] n = 1–3.

Cooling Thermal Time Constant (TCONCn)

This setting defines the thermal characteristic of the equipment when the equipment is de-energized, that is when the current is below the IEQPU value.

Label	Prompt	Range	Default
TCONC*n*[a]	Cooling Thermal Time Constant *n* (1-500 min)	1–500 min	60

[a] n = 1–3.

Thermal Level Alarm Limit (THLAn)

This setting specifies the per-unit thermal level when the relay will assert the thermal alarm Relay Word bit.

Label	Prompt	Range	Default
THLA*n*[a]	Thermal Level Alarm Limit *n* (1–100%)	1.0%–100%	50

[a] n = 1–3.

Thermal Level Trip Limit (THLTn)

This setting specifies the per-unit thermal level when the relay will assert the thermal trip Relay Word bit.

Label	Prompt	Range	Default
THLT*n*[a]	Thermal Level Trip Limit *n* (1–100%)	1.0%–150%	80

[a] n = 1–3.

Maximum Temperature of the Equipment (TMAXn)

This setting specifies the maximum operating temperature of the protected equipment. This setting is used to calculate FAMB*n* (see *Equation 5.59*).

Label	Prompt	Range	Default
TMAX*n*[a, b]	Maximum Temperature of the Equipment *n* (80°–300°C)	80°–300°C	155

[a] n = 1–3.
[b] Hide setting if AMB_M = NA.

Over- and Underpower Element

The SEL-487E offers 10 overpower elements and 10 underpower elements. Use Group setting E32 to enable the number of power elements you want. Typical applications of power elements are the following:

- Overpower and/or underpower protection/control
- Reverse power protection/control
- VAR control for capacitor banks

The SEL-487E uses the IEEE convention for power measurement, as *Figure 5.148* and *Figure 5.149* illustrate.

Figure 5.148 Primary Plant Connections

Figure 5.149 Complex Power Measurement Conventions

Figure 5.150 shows an installation with the direction of real power as indicated. CT S and CT T are the HV and LV CTs, connected in the conventional way to supply the differential elements with the correct polarity CT inputs. In this installation, be sure to specify operating quantities from CT S to comply with the IEEE convention.

Figure 5.150 Selection of Operating Quantities

Input quantities for the 10 power elements are not fixed; make your selection from the three-phase power elements in *Table 5.25*. All analog quantities in *Table 5.25* are fundamental secondary values and include power quantities for single terminals as well as combined terminals.

Table 5.25 Power Element Operating Quantities (Secondary Values)

Analog Quantity	Description
3P*m*F[a]	Fundamental three-phase active power, Terminal *m*
3Q*m*F	Fundamental three-phase reactive power, Terminal *m*
3P*qp*F[b]	Fundamental three-phase active power, Combined Terminals *qp*
3Q*qp*F	Fundamental three-phase reactive power, Combined Terminals *qp*

[a] m = S, T, U, W, X, Y.
[b] qp = ST, TU, UW, WX.

Figure 5.151 shows the logic for the overpower element, and *Figure 5.155* shows the logic for the underpower element. There are six conditions that must be met to enable both over- or underpower logic:

- ECTTERM and EPTTERM must not be set to OFF.
- Power calculations (EPCAL) must be enabled.
- The current terminal for each operating quantity must be referenced to a voltage terminal by using VREF*m* and ALTV*m*.
- Over- and underpower elements must be specified (E32).
- An operating quantity (32OPO*nn*) must be specified.
- SELOGIC control equation E32OP*nn* must be asserted.

Figure 5.151 Overpower Element Logic

Input 32OPO*nn* is the power quantity (see *Table 5.25*) that the logic compares against the 32OPP*nn* setting. In general, the output of a comparator asserts to logical 1 when the (+) quantity exceeds the (–) quantity. Switch S selects the appropriate comparator as a function of the 32OPP*nn* setting. For example, if 32OPP*nn* < 0 (negative value), then Switch S is in position 1 and Comparator 2 is in use. In this case, the output of Comparator 2 asserts to logical 1 when the 32OPP*nn* setting value exceeds the 32OPO*nn* analog quantity.

Conversely, if 32OPP*nn* > 0 (positive value), then Switch S is in position 2, and Comparator 1 is in use. In this case, the output of Comparator 1 asserts to logical 1 when the 32OPO*nn* analog quantity exceeds the 32OPP*nn* setting value.

As an example, assume that you want to assert an output when the fundamental three-phase active power of Terminal S exceeds 54 VA secondary in the direction of the load flow. From *Table 5.25*, select 3PSF (fundamental three-phase active power) as the operating quantity. Using the first power element, set 32OPO01 = 3PSF. From *Figure 5.149*, the direction of the load flow is positive in the first and fourth quadrants. Therefore, set the threshold to a positive value (32OPP01 = +54). If you want to control the load in the reverse direction, then set 32OPP01 = –54. *Figure 5.152* shows a case where the control direction is towards the load, and *Figure 5.153* shows a case where the control direction is away from the load.

Figure 5.152 Load Flow Towards Load

Figure 5.153 Reverse Load Flow

Use SELOGIC control equation E32OP*nn* to state the conditions when the power elements must be active. Output 32OP*nn* is the instantaneous output when the AND gate turns on, and 32OPT*nn* is the time-delayed output.

The sign of the pickup setting also determines the directional control for the reactive power element. In *Figure 5.154*, the top shaded area shows a case where the direction of the fundamental three-phase reactive power (3QPSF) is towards the load. The bottom shaded area shows a case where the flow is in the reverse direction.

Figure 5.154 Reactive Power Characteristic

Figure 5.155 shows the logic for the underpower element. This element is the same as the overpower element.

Figure 5.155 Underpower Element Logic

Over- and Underpower Element Settings

E32 (Enable Over/Underpower)

Set E32 to the number of power elements for the specific terminals in your application. The E32 setting considers for selection only terminals that you include in the ECTTERM and the EPCAL settings.

32OPOnn (Overpower Operating Quantities)

Select the analog quantity (see *Table 5.25*) for each of the enabled (E32 setting) power elements. The 32OPO*nn* setting considers for selection only terminals that you include in the ECTTERM setting and the EPCAL setting.

32OPPnn (Overpower Pickup)

The 32OPP*nn* setting is the overpower pickup and directional control setting for each of the enabled overpower elements in secondary VA. In general, a setting with a positive sign controls power in the direction of the load (see *Figure 5.148* and *Figure 5.149*), and a setting with a negative sign controls power in the reverse direction (see *Figure 5.153* and *Figure 5.154*). Analog quantities in *Table 5.25* are in secondary quantities, so you do not need any conversions.

32OPDnn (Overpower Delay)

For each enabled overpower element, select a time in cycles that you want the element(s) to wait before asserting.

E32OPnn (Torque Control)

Use the torque-control setting to specify conditions under which the overpower elements must be active. With the default setting of NA, the element is switched off.

32UPOnn (Underpower Operating Quantities)

Select the analog quantity (see *Table 5.25*) for each of the enabled (set in the E32 setting) power elements. The 32UPO*nn* setting considers for selection only terminals that you include in the ECTTERM setting and the EPCAL setting.

32UPPnn (Underpower Pickup)

The 32UPP*nn* setting is the underpower pickup and directional control setting for each of the enabled overpower elements in secondary VA. In general, a setting with a positive sign controls power in the direction of the load (see *Figure 5.148* and *Figure 5.149*), and a setting with a negative sign controls power in the reverse direction (see *Figure 5.153* and *Figure 5.154*). Analog quantities in *Table 5.25* are in secondary quantities, so you do not need any conversions.

32UPDnn (Underpower Delay)

For each enabled underpower element, select a time in cycles that you want the element(s) to wait before asserting.

E32UPnn (Torque Control)

Use the torque-control setting to specify conditions under which the underpower elements must be active. With the default setting of NA, the element is switched off.

To provide selective protection disabling of the 32U elements under DSS data loss conditions, include the analog channel status Relay Word bits in the torque-control equations for these elements (see *Analog Channel Statuses on page 5.2* and *Application Setting SVBLK and Relay Word Bit SVBK_EX on page 5.5*).

Trip Logic

To provide settings for selective tripping between unit faults and system faults, the SEL-487E includes seven instances of trip logic. Use the logic in *Figure 5.156* for transformer (unit) faults and the logic in *Figure 5.157* (one for each of the six breakers) for system faults. Although you set the input quantities separately for each of the seven instances of trip logic, there exists only one Minimum Trip Duration timer and only one reset setting (RSTTRGT).

In *Figure 5.156*, the Transformer Trip timer starts when SELOGIC control equation TRXFMR asserts for one processing interval. Assertion of this equation immediately asserts Output TRPXFMR. Output TRPXFMR remains asserted for the Minimum Trip Duration timer (TDURD) setting regardless of the status of Input TRXFMR. When Output TRPXFMR asserts, the logic seals TRPXFMR in through the AND gate under the following conditions:

- SELOGIC control equation RSTTRGT is deasserted (Global setting)
- The target reset (TRGTR) input is deasserted
- The unlatch input (ULTXFMR) is deasserted
- The ECTTERM setting includes the terminal name

Relay Word bit TRGTR asserts for one processing interval when either you press the front-panel **TARGET RESET** pushbutton or you issue the ASCII **TAR R** command.

Once latched, TRPXFMR remains asserted until any (or all) of the following happens:

- SELOGIC control equation RSTTRGT asserts
- The target reset (TRGTR) input asserts
- The unlatch input (ULTXFMR) asserts

Figure 5.156 Transformer Trip Logic

Figure 5.157 shows the trip logic for each of the six circuit breakers. The logic itself is identical, but there are trip (TR*m*) and trip unlatch (ULTR*m*) equations for each of the six circuit breakers.

Figure 5.157 Circuit Breaker Trip Logic

Figure 5.158 TRIP Logic

Trip-Logic Settings

TRXFMR (Trip Transformer)

Specify the conditions under which all the circuit breakers must trip with the TRXFMR setting. Default settings are the differential and restricted earth fault trip outputs.

For the SEL-487E-5, the TRXFMR equation is disabled by default when the relay is in SEL test mode via the **TEST SV** command (SVSTST = 1).

ULTXFMR (Unlatch Trip Transformer)

Specify the conditions to unlatch the transformer trip output command (TRPXFMR). The default setting is Relay Word bit TRGTR.

TRm (Trip Terminal)

Specify the conditions under which each of the enabled circuit breakers must trip with the TR*m* setting. Default settings are the phase and negative-sequence overcurrent elements.

For the SEL-487E-5, the TR*m* equations are disabled by default when the relay is in SEL test mode via the **TEST SV** command (SVSTST = 1).

ULTRm (Unlatch Trip Terminal)

NOTE: Changing setting groups when the trip duration timer is running extends the duration by 3.5–4 cycles. The timer does not reset during this delay.

Specify the conditions to unlatch each of the enabled circuit breaker trip outputs with the ULTR*m* setting. The default setting is Relay Word bit TRGTR.

TDURD (Minimum Trip Duration Timer)

There is only one minimum trip duration timer for all six terminals. Set this delay (in cycles) slightly longer than the trip time of the slowest circuit breaker.

Close Logic

The SEL-487E close logic shown *Figure 5.159* offers two ways to close each of the six circuit breakers:

- Conditions mapped to CL*m,* where *m* = S, T, U, W, X, Y
- Automatic reclosing

Set the CL*m* SELOGIC control equation to include an OR-combination of all Relay Word bits for which you want the relay to close the breaker. Include the CC*m* bits for breaker control by using the **CLOSE *m*** command or for SCADA operations. The relay closes output contact(s) when the CLS*m* bit appears in an output contact SELOGIC control equation.

Figure 5.159 Close Logic for Breaker m

Once the CLS*m* bit is asserted, it is sealed-in until any of the following conditions are true:

- Unlatch close SELOGIC control equation setting ULCL*m* asserts to logical 1.
- Close failure delay timer (CFD) expires.

The close failure timer is unaffected by a setting group change. The timer starts timing in the present setting group, continues to run for the intermediate time between setting groups, and completes timing in the new setting group.

Close Logic Settings

CLm (Close SELOGIC Control Equation)

Specify the conditions under which the circuit breaker must close with the CL*m* setting. The default setting is LB10 OR CC*m*, which allows close operations from the front panel or the use of the **CLOSE *m*** command. This settings category is hidden when ECTTERM = OFF.

ULCLm (Unlatch Close SELOGIC Control Equation)

Specify the conditions to unlatch the close output command (CLS*m*) and reset the close failure timer. The close output command and close failure timer will reset on the rising edge of the unlatch. Default settings are the 52A breaker auxiliary contacts that assert when the breakers close. ULCL*m* must be deasserted before CLS*m* can assert.

CFD (Close Failure Delay)

Set the close failure delay (setting CFD) equal to the highest breaker close time with additional safety margins.

Autoreclosing

This section describes the operation of autoreclose logic in SEL-487E. The relay autoreclose function provides complete control for single circuit breaker three-pole reclosing schemes for as many as six independent breakers. Three-pole breaker operations can be set for as many as four three-pole reclose shots.

Autoreclosing States

The autoreclose logic for any circuit breaker can be in one of the following four states (see *Figure 5.160*):

- Start (79STRT*m*)
- Reset (79RS*m*)
- Cycle (79CY*m*)
- Lockout (79LO*m*)

where *m* = S, T, U, W, X, Y.

Start (79STRTm)

The autoreclose logic is in the start state during the following conditions:

- Startup
- Restart
- Any relay settings change

The relay stores the previous reclosing state for Relay Word bits 79CY*m*, 79LO*m*, and 79RS*m* when a restart or any relay settings change occurs.

At startup, the recloser logic goes from the start state to the lockout state. For a restart or a settings change, the recloser logic enters the start state, then goes to lockout if the circuit breaker opened before the restart or settings change. If the circuit breaker was previously closed, the recloser logic proceeds through the 79RCLD*m* (Lockout State Reclaim Time Delay) time and then goes to the ready/reset state.

Reset (79RSm)

The autoreclose logic is in the reset or ready state when the circuit breaker is ready to begin an autoreclose cycle. After a successful reclose cycle, the relay goes to the reset state after reclaim times 79RCD*m* (Cycle State Reclaim Time Delay). If the recloser has been in a lockout condition, the ready or reset state cannot occur until the 79RCLD*m* (Lockout State Reclaim Time Delay) timer has expired. Setting 79BRCT*m* (Block Reclaim Timers) prevents timing of reclaim timers 79RCD*m* and 79RCLD*m*.

Cycle (79CYm)

The autoreclose logic is in the autoreclose cycle state if all of the following conditions are satisfied:

- Trip occurs
- Condition(s) to initiate a three-pole autoreclose cycle are satisfied
- Circuit breaker is in service and ready to begin a three-pole autoreclose cycle (that is, reset)

Lockout (79LOm)

The lockout state is the default state of any circuit breaker after startup. The relay recloser has a drive-to-lockout function that you can program for any external or internal condition-use setting 79DTL*m*. The circuit breaker enters the lockout state if any of the following occur:

- The circuit breaker does not open within the Line Open Failure Delay (79RIH*m*) time.
- The circuit breaker does not close within the Close Failure Delay (CFD) time.
- Close supervision Relay Word bit (79CLS*m*) does not assert within the Recloser Supervision Delay (79CLSD*m*) time.
- The number of trips exceeds the maximum number of shots (NSHOT*m*).
- Relay Word bit 3POBK*m* asserts (for a circuit breaker manual opening) during the cycle state reclaim time delay (79RCD*m*).
- Relay Word bit 79DTL*m* asserts.

State Diagram

NOTE: The autoreclose function runs once per power-system cycle. To ensure that the logic detects transient element state changes that initiate closing, you should extend the assertion time of transient element states to 1 cycle.

Figure 5.160 illustrates how the autoreclose logic moves from one state to another with respect to Circuit Breaker *m*. The Relay Word bits that correspond to each state are shown (see *Table 5.26*). A solid path between two states indicates that the logic can move in only one direction. Dashed paths between states indicate the logic can move in either direction between the two states.

Table 5.26 describes each of the four states with respect to Circuit Breaker *m*, along with the corresponding Relay Word bits.

Figure 5.160 Autoreclose State Diagram for Circuit Breaker m

Table 5.26 Autoreclose Logical States for Circuit Breaker m

State	Description	Relay Word Bit
Start	Startup or relay settings change	79STRT*m*
Reset	Circuit Breaker *m* is in reset	79RS*m*
Cycle	Three-pole autoreclose cycling	79CY*m*
Lockout	Circuit Breaker *m* is in lockout	79LO*m*

Use the analog quantity RECST*m* to indicate the autoreclose state as defined by the AutoRecSt data object in IEC 61850-7-4. *Figure 5.161* illustrates how the autoreclose logic moves from one AutoRecSt state to another. RECST*m* is available only as an IEC 61850 quantity and can be in one of the following six states as defined in *Table 5.27*.

Figure 5.161 IEC Autoreclose Logical States for Circuit Breaker m

Table 5.27 IEC Autoreclose Logical States for Circuit Breaker m

RECSTm	IEC State	Description
1	Ready	Circuit Breaker *m* is in reset (79RS*m*)
5[a]	Trip issued by protection	Waiting for Circuit Breaker *m* to open after a trip and associate autoreclose initiate (79ARC*m*).
6[a]	Fault disappeared	Waiting for permission to close. This state starts when Circuit Breaker *m* opens after a trip (3POBK*m*) and ends when the close command is issued to Circuit Breaker *m* (79CL*m*).
7[a]	Wait to complete	Waiting for Circuit Breaker *m* to close. This state starts after the Circuit Breaker *m* close command (79CL*m*) and ends when the close is qualified via ULCL*m*.
8[a]	Circuit breaker closed	This state starts when Circuit Breaker *m* closes (ULCL*m*) and is active while reclaim is in progress.
12	Not ready	This state indicates a relay startup or settings change (79STRT*m*), Circuit Breaker *m* is in lockout (79LO*m*), or Circuit Breaker *m* is not included in the enable setting E79.

[a] See Figure 5.161 for more information on this RECSTm enumeration.

Autoreclose Cycling

Figure 5.164 shows the circuit breaker autoreclose cycle 79CY*m*. The cycle starts when Relay Word bit 79ARC*m* asserts. The recloser checks SELOGIC control equation 79SKP*m* at this point to determine whether to increment the shot counter. If the Line Open Failure Delay is disabled (79RIH*m* = OFF), the recloser waits indefinitely for the circuit breaker to open, as indicated by Relay Word bit 3POBK*m*. The recloser begins timing 79OI1*m* (Open Interval 1 Delay) when the circuit breaker opens. After the open interval time 79OI1*m* expires, the relay asserts Relay Word bit 79CL*m* to reclose the circuit breaker if the supervisory condition 79CLS*m* (Close supervision) is satisfied within the duration of timer 79CLSD*m* (Recloser Supervision Delay). Setting 79CLSD*m* = OFF disables the 79CLSD*m* delay timer, requiring 79CLS*m* to assert before transitioning to the next state.

After the reclose command is issued, the recloser starts timer CFD (Close Failure Delay). If the circuit breaker fails to close, the recloser goes to lockout (79LO*m*) after timer CFD expires.

79RCDm Reclaim Timing

If the circuit breaker successfully closes, the recloser checks if reclaim is blocked via 79BRCT*m*. If reclaim is permitted, the recloser starts timer 79RCD*m* (Cycle State Reclaim Time Delay). The recloser determines subsequent state transitions during reclaim timing according to the status of Relay Word bit 79LSHT*m* (Three-Pole Reclose Last Shot).

79LSHTm Asserted (Last Shot)

The recloser exits the 79CY*m* state via one of the following two methods while 79LSHT*m* is asserted:

- If no further trip conditions occur, the recloser goes to the reset state 79RS*m* after reclaim timer 79CLSD*m* expires.
- If a fault occurs or the breaker opens during the 79RCD*m* reclaim time, the recloser exits the 79CY*m* cycle state and goes to the lockout state 79LO*m*.

79LSHTm Deasserted (Shot Remains)

The recloser exhibits three possible state transitions when 79LSHT*m* is not asserted:

- If no further trip conditions occur, the recloser goes to the reset state 79RS*m* after timer 79RCD*m* expires.
- If a fault occurs during the 79RCD*m* reclaim time, the recloser asserts Relay Word bit 79ARC*m* if all reclose conditions are satisfied (79RI*m* is logical 1, for example) and returns to the beginning of the 79CY*m* cycle state; the recloser increments the shot counter and begins the next open interval timer.
- If the 3POBK*m* condition is detected during the 79RCD*m* reclaim time, the recloser exits the 79CY*m* cycle state and goes to the lockout state, 79LO*m*.

Autoreclose Logic Diagrams

NOTE: If E79 := N, the autoreclose logic is not processed and the resultant Relay Word Bits are forced to zero.

Figure 5.162 Circuit Breaker Pole-Open Logic

Figure 5.163 Three-Pole Reclose Enable Logic

Figure 5.164 Three-Pole Cycle State for Breaker m

Loss-of-Potential (LOP) Logic

Fuses or molded case circuit breakers often protect the secondary windings of the power system potential transformers. Operation of one or more fuses or molded case circuit breakers results in a loss of polarizing potential inputs to the relay. Loss of one or more phase voltages prevents the relay from discriminating fault distance and direction properly.

An occasional loss-of-potential (LOP) at the secondary inputs of a distance relay is unavoidable but detectable. The relay detects a loss-of-potential condition and asserts Relay Word bits LOP (loss-of-potential detected) and ILOP (Internal loss-of-protection from ELOP setting). This allows you to block distance element operation, block or enable forward-looking directional overcurrent elements, and issue an alarm for any true LOP condition.

In general, the following three conditions cause a loss of potential:

- Incorrect operating procedures
- System faults
- Blown PT fuse(s)

Incorrect operating procedures include incidents such as energizing the relay without PT fuses after maintenance. Although the LOP logic alarms for this condition, the logic primarily detects the occurrence of blown PT fuses when the relay is in service.

To distinguish an LOP condition from a system fault condition, the LOP logic correlates the change in voltage with a change in current. Because a system fault causes a change in both voltage and current, the LOP logic compares the present values of the positive-sequence current and angle to the values of the positive-sequence current and angle of the previous cycle. In separate calculations, the LOP logic also compares the present values of the negative-sequence current to the value of the negative-sequence current of the previous cycle.

Figure 5.165 shows the logic that calculates the change in current for Terminal S; other terminals have similar logic. For each terminal included in the ECTTERM setting, the logic calculates the change in current, I*m*DELTA (*m* = S, T, U, W, X, Y), for three possible conditions:

1. Change in positive-sequence current angle is greater than five degrees, provided that the present positive-sequence current magnitude and that of a cycle ago are greater than five percent of the nominal current (nominal current is 5 A or 1 A).
2. Change in positive-sequence current magnitude is greater than two percent of nominal current (5 A or 1 A).
3. Change in negative-sequence current magnitude is greater than six percent of nominal current (5 A or 1 A).

NOTE: The LOP logic only evaluates the change in current-for-current terminals included in the ECTTERM setting.

When any one of these three conditions is true, Relay Word bit ISDELTA asserts, causing Output IDELTA to assert. When IDELTA asserts, the IDELTA Timer maintains the output for 15 cycles. During these 15 cycles, AND Gate 2 (see *Figure 5.165*) cannot turn on, and an LOPV condition is not possible.

Figure 5.165 Logic that Calculates the Change in Current

Figure 5.166 shows the LOP logic for PT V; PT Z has similar logic. Whereas the delta current calculations determine the difference in current, the LOP logic calculates the ratio of the present voltage and the voltage one cycle earlier. AND Gate 1 turns on when the following three conditions are true:

- EPTTERM includes PT V.
- The ratio of the present voltage and the voltage one cycle earlier is below 0.9 (also turns AND Gate 3 off).
- The voltage from one cycle earlier is higher than 10 percent of the nominal voltage of PT V.

Figure 5.166 LOP Logic for Potential Transformer V

AND Gate 1 turns on when there is a drop in voltage greater than 10 percent in the positive-sequence voltage. If there is a simultaneous change in current (IDELTA asserts), then the drop is the result of a system fault, and AND Gate 2 does not turn on. However, if IDELTA does not assert, (no corresponding change in current), then the voltage drop is the result of a LOP condition. Therefore, as shown in *Figure 5.166*, the logic requires AND Gate 1 to assert, IDELTA to not

assert, and the ratio of the present voltage and the one-cycle-earlier voltage to be below 0.9 (AND Gate 3 is off) in order for AND Gate 2 to assert. When AND Gate 2 asserts, the following takes place:

- AND Gate 2 seals itself in through OR Gate 1.
- Output LOPV asserts and blocks all directional elements that have PT V as reference voltage (VREF*m* settings).
- The 15-cycle LOPV Timer starts. If the LOP condition lasts for 15 cycles, then the LOPV Timer expires and asserts the LOPV Latch, which latches the LOPV output. The LOPV Latch resets only when AND Gate 3 turns on.

If you set ELOP to N, the LOP logic operates but does not disable any voltage-polarized elements. This option is for indication only. If you set ELOP to Y and an LOP condition occurs, the voltage-polarized directional elements and all distance elements are disabled via Relay Word bit ILOPV or ILOPZ. The forward-looking directional overcurrent elements effectively become nondirectional and provide overcurrent protection during an LOP condition. If you set ELOP to Y1 and an LOP condition occurs, the voltage-polarized directional elements and all distance elements are disabled. This setting for ELOP also disables the overcurrent elements that these voltage-polarized directional elements control.

When the SEL-487E-5 loses DSS data that are mapped to the V or Z voltage terminals, the relay asserts the corresponding Relay Word bits VVBK or VZBK (V or Z terminal voltage block). When VVBK or VZBK asserts, and no loss of potential was identified on the previous relay processing interval, the corresponding LOP element (LOPV or LOPZ) is prevented from asserting and its associated latch is reset. The LOP indication remains blocked as long as the voltage data are lost.

Relay Word bits ILOPV and ILOPZ (internal loss-of-potential) assert to disable and secure the voltage-polarized directional elements and distance elements when a loss-of-potential condition is detected. Note that when ILOPV or ILOPZ assert via VVBK or VZBK these elements will be disabled regardless of the value of the ELOP setting.

Figure 5.167 shows the logic for detecting an abnormal voltage condition when the transformer is energized, or when a particular winding picks up load. When the circuit breaker is open, the open-phase detection (OPH*m*) asserts. Closing the circuit breaker does not necessarily cause OPH*m* to deassert; OPH*m* deasserts only when current flows. On the falling edge of OPH*m*, the OPH Timer asserts LD (load detected) for 130 cycles, thus asserting the bottom input into AND Gate 1. If the positive-sequence voltage is less than 75 percent and the negative-sequence voltage (3V2) is greater than 60 percent, the logic declares the condition as a possible missing or blown fuse, and it starts the PT Timer. If the condition persists for 120 cycles, then the PT Timer expires and sets the PT Latch. This setting of the PT Latch then asserts Output VALARMV. When the positive-sequence voltage is greater than 85 percent of the nominal voltage, and the ratio of negative-sequence (3V2) voltage to positive-sequence voltage is below 30 percent, the output V1VOK asserts, and the PT Latch resets.

Figure 5.167 Logic to Detect Abnormal Voltage Condition

Circuit Breaker Status

NOTE: The breaker designation (S, T, U, W, X, Y) must be listed in the group setting ECTTERM for the open-phase detection to operate.

Figure 5.168 shows the circuit breaker status logic, which uses the combination of breaker 52A (normally open) auxiliary contact and the open-phase detection function, OPH*m* (*m* = S, T, U, W, X, Y). Because 52B (normally closed) contacts are not always available, and as a means to reduce the number of I/O required, the 52B contacts are not required in the logic. However, for applications where the protection philosophy requires a 52B (normally closed) contact, wire the 52B contact into the relay, but use the negated form of the 52B contact in the logic (i.e., NOT 52B (52A_*m*: = NOT IN201)).

Figure 5.168 Circuit Breaker Status

Relay Word bits 52CL*m* assert when the breaker is closed. Open-phase detection logic (OPH*m*) Relay Word bits are included in the circuit breaker status logic to guard against delayed breaker status declaration resulting from possible breaker

auxiliary contact misalignment. If a discrepancy between the open-phase detection logic and the breaker auxiliary contact exists for as long as five cycles, the logic generates an alarm that indicates one of the following:

- Possible auxiliary contact supply voltage failure
- Possible failure in an auxiliary contact connection circuit
- Possible failure of auxiliary contact mechanism

This page intentionally left blank

SECTION 6

Protection Application Examples

This section provides instructions for setting the SEL-487E Relay protection functions. Use these application examples to help familiarize yourself with the relay and assist you with your own protection settings calculations. This section is not intended to provide a complete settings guide for the relay.

For simplicity, this section omits most networking and topology details and focuses on protection application content. See *Section 1: Introduction and Specifications* for more topology information between the merging units and the SEL-487E-5. The figures in this section use the same merging unit and subscriber configurations. The examples show a merging unit publishing current data, which is mapped to current terminals IS and IT in the SEL-487E-5.

Transformer Winding and CT Connection Compensation Settings Examples

In electromechanical and solid-state transformer differential relays, the standard CT configuration is wye- connected on the delta winding of the transformer and delta connected on the wye winding of the transformer. The CT delta connection is constructed based on the power transformer delta to compensate for the phase shift that occurs on the system primary currents because of the power transformer connection. This CT configuration allows the currents entering the relay for through-load or external faults to be 180 degrees out-of-phase so that the phasor sum of the currents adds to zero (no differential current) in an electromechanical differential relay. Taps on the relay current inputs compensate for magnitude differences. Modern digital relays perform both the connection (or phase) and magnitude compensation mathematically so all CTs can be connected in wye.

NOTE: This section provides a procedure to determine and set the Terminal m CT connection compensation settings (TmCTC [where m = S, T, U, W, or X]).

NOTE: In this section, the term "phase rotation" is synonymous with "phase sequence". This section uses "phase rotation" to be consistent with the relay Global setting PHROT.

The SEL-487E offers connection compensation settings, T*m*CTC, to compensate for the phase shift across the transformer. While it is not entirely accurate to refer to a phase shift across a transformer, it is a well-accepted term. Each of the connection compensation settings offer thirteen 3x3 matrices, CTC(0)–CTC(12), permitting CT connection compensation from 0 degrees to 360 degrees, in increments of 30 degrees, respectively. Refer to *Table 5.3* for each of the compensation matrices. When applied on a system with ABC phase rotation, these matrices perform phase angle correction in a counter-clockwise (CCW) direction in multiples of 30 degrees, as shown in *Table 6.1*. For systems with ACB phase rotation, the direction of correction is clockwise (CW). See *Special Cases on page 6.21* for compensation settings examples on a system with ACB phase rotation.

Table 6.1 TmCTC Setting: Corresponding Phase and Direction of Correction

TmCTC Setting[a]	Matrix	ABC System Rotation Amount and Direction of Correction	ACB System Rotation Amount and Direction of Correction
0	CTC(0)	0°	0°
1	CTC(1)	30° CCW	30° CW
2	CTC(2)	60° CCW	60° CW
3	CTC(3)	90° CCW	90° CW
4	CTC(4)	120° CCW	120° CW
5	CTC(5)	150° CCW	150° CW
6	CTC(6)	180° CCW	180° CW
7	CTC(7)	210° CCW	210° CW
8	CTC(8)	240° CCW	240° CW
9	CTC(9)	270° CCW	270° CW
10	CTC(10)	300° CCW	300° CW
11	CTC(11)	330° CCW	330° CW
12	CTC(12)	0° (360°) CCW	0° (360°) CW

[a] m = S, T, U, W, X.

As shown in *Table 5.3*, the compensation Matrix CTC(0) multiplies the currents by the identity matrix and creates no change in the currents. The compensation Matrix CTC(12) is similar to CTC(0) in that it produces no phase shift (or, more correctly, 360 degrees of shift) in a balanced set of phasors separated by 120 degrees. However, CTC(12) removes zero-sequence components from the measured current, as do all of the matrices having non-zero values.

Transformer Nameplates and System Connections

To determine the phase shift detected by the relay, the following information is required:

- Transformer phasor (vector) diagram (transformer nameplate)
- Three-line connection diagram showing the following:
  - System phase-to-transformer bushing connections
  - CT connections
  - CT-to-relay connections

Figure 6.1 shows the key information from a typical nameplate for a two-winding transformer. The winding connection diagram and the phasor (vector) diagram are needed to determine the winding compensation settings in the relay.

Figure 6.1 Transformer Nameplate

Note that there is no phase designation nor any phase rotation designation on the nameplate. However, the phasor diagram is representative of an H1-H2-H3 sequence. The phase shift on the power system depends on the transformer winding connections, the system phase-to-transformer bushing connections, and the system phase rotation.

Figure 6.2 shows a three-line connection diagram with the transformer of *Figure 6.1* with what this guideline refers to as standard connections. Standard phase-to-bushing connections are A-Phase to H1, B-Phase to H2, C-Phase to H3, a-phase to X1, b-phase to X2, and c-phase to X3. Standard CT connections include wye-connected CTs with polarity marks of both CTs away from the transformer or towards the transformer. *Figure 6.2* shows both H-side and X-side CTs connected in wye and the polarity marks away from the transformer. A CT-to-relay connection is considered to be standard when the polarity of the CT is connected to the polarity of the relay analog current input and the primary system phase current is connected to the same phase input on the relay (e.g., IA system to IAS). Unless otherwise noted, an ABC phase rotation is assumed for the following discussion.

The SEL-401 Protection, Automation, and Control Merging Unit is shown in examples throughout this section, see *Applications on page 1.10* for connection details regarding TiDL systems.

NOTE: The merging unit shown has two separate three-phase current inputs.

Figure 6.2 Three-Line Diagram Showing System Phase-to-Transformer Bushing, CT, and CT-to-Relay Connections

If all the connections are standard as shown in *Figure 6.2*, under a through-load condition the phase relationship between the system primary currents (Ia system and IA system) and corresponding secondary currents as seen by the relay (IAT and IAS) will look like as shown in *Figure 6.3* (Ia lags IA by 30 degrees) and *Figure 6.4* (IAT lags IAS by 210 degrees), respectively. The goal of the compensation settings is to compensate IAT to bring IAT_compensated 180 degrees out-of-phase with IAS.

Figure 6.3 Primary Current Phasors

Figure 6.4 Current at the Relay Terminals

Many applications do not conform to the standard connections so the compensation settings are adaptable to fit the application. The subsequent sections outlines the procedure to determine the phase shift and CT compensation settings along with discussing what to do with non-standard phase-to-bushing, CT, and CT-to-relay connections.

Steps to Determine the Compensation Settings (TmCTC)

Use the following guidelines to determine compensation settings for each application.

Step 1. Determine the phase shift as seen by the relay.

a. Determine the phase shift in the primary load current.

b. Determine if there are non-standard CT connections.

Step 2. Select the reference winding and associated relay terminal.

a. If a delta winding exists and is wired into the relay, choose it as the reference winding. Select Matrix CTC(0) for the compensation of the delta winding. If a zigzag grounding transformer exists on the delta side of the transformer and is within the zone of protection, select Matrix CTC(12).

b. If a delta winding does not exist, select one of the wye windings as the reference and choose Matrix CTC(11) for the compensation.

Step 3. Once the reference winding is selected, determine the required compensation setting for all other windings. Select Matrix CTC(0) for delta windings. Use odd matrices for compensating wye-windings. Avoid the use of even matrices when possible.

There may be applications that require the guidelines to be violated, but they should be followed when possible.

The rest of this section discusses each of the guidelines in detail. Examples and special cases are provided to illustrate the application of the guidelines in determining the compensation settings.

Step 1. Determine the Phase Shift as Seen by the Relay

Determine the Phase Shift in the Primary Load Current

NOTE: Unless otherwise stated, this discussion assumes an ABC system phase rotation.

The first step in selecting the compensation setting in the relay is to determine the phase shift in the primary load current.

Standard System Phase-to-Transformer Bushing Connections

Consider the transformer in *Figure 6.1* and the phase-to-bushing connection of *Figure 6.2*. Assume balanced X-side (wye-winding), three-phase currents Ia, Ib, and Ic, as shown in *Figure 6.5*. The currents in the H-side (delta winding) of the transformer are Ia/N, Ib/N, and Ic/N where N is the turns ratio of the transformer. Because the discussion focuses on the phase shift and not the magnitude, one can assume N = 1 for this discussion.

Figure 6.5 Standard System Phase-to-Transformer Bushing Connections

Kirchhoff's Current Law is used at each H node to determine the primary phase currents on the H-side of the system:

IA = Ia – Ib

IB = Ib – Ic

IC = Ic – Ia

In the following examples start with the currents on the wye-side of the transformer to graphically derive the currents on the delta side of the transformer. *Figure 6.6* shows that system primary current Ia (X-side) lags the system primary current IA (H-side) by 30 degrees.

Figure 6.6 X- and H-Side Current Phasors for Figure 6.5

The primary load phase shift determined in *Figure 6.6* applies for the phase-to-bushing connections shown in *Table 6.2*. In each of these phase-to-bushing connections, the order of the phases (A, B, C) matches the order of the bushings (H1, H2, H3).

Table 6.2 (A, B, C) to (H1, H2, H3) Phase-to-Bushing Connections

	Bushing					
	H1	H2	H3	X1	X2	X3
System Phase	A	B	C	a	b	c
	B	C	A	b	c	a
	C	A	B	c	a	b

Non-Standard Phase-to-Bushing Connections

Consider the transformer connections of *Figure 6.7*. This is the same transformer discussed in *Figure 6.5*, but with different phase-to-bushing connections: A-Phase to H3, B-Phase to H2, C-Phase to H1, a-phase to X3, b-phase to X2, and c-phase to X1.

Figure 6.7 Non-Standard System Phase-to-Transformer Bushing Connections

Assume balanced X-side (wye-winding), three-phase currents Ia, Ib, and Ic. Kirchhoff's Current Law is used at each H node to determine the primary phase currents on the H-side of the system:

$$IA = Ia - Ic$$

$$IB = Ib - Ia$$

$$IC = Ic - Ib$$

Figure 6.8 shows that system primary current Ia (X-side) leads the system primary current IA (H-side) by 30 degrees.

Figure 6.8 X- and H-Side Current Phasors for Figure 6.7

The primary load phase shift determined in *Figure 6.8* applies for the phase-to-bushing connections shown in *Table 6.3*. In each of these phase-to-bushing connections, the order of the phase connections (A, C, B) is opposite the order of the bushings (H1, H2, H3).

Table 6.3 (A, C, B) to (H1, H2, H3) Phase-to-Bushing Connections

	Bushing					
	H1	H2	H3	X1	X2	X3
System Phase	C	B	A	c	b	a
	B	A	C	b	a	c
	A	C	B	a	c	b

The system phase-to-transformer bushing connection diagrams in *Figure 6.5* and *Figure 6.7* are on the same transformer, but with a different order of the phases connected to the transformer bushings. As a result, the X-side primary current shifts 30 degrees in opposite directions in the two systems.

Combination of Standard and Non-Standard Phase-to-Bushing Connections

Consider the transformer connections shown in *Figure 6.9*. The transformer is the same as in previous examples. However, in this example, the H-side phase-to-bushing connections are standard: A-Phase to H1, B-Phase to H2, and C-Phase to H3. The X-side connections are non-standard: a-phase to X2, b-phase to X3, and c-phase to X1.

Figure 6.9 Combination of Standard and Non-Standard Phase-to-Bushing Connection Diagram

Assume balanced X-side (wye-winding), three-phase currents Ia, Ib, and Ic. Kirchhoff's Current Law is used at each H node to determine the primary phase currents on the H-side of the system:

$$IA = Ic - Ia$$

$$IB = Ia - Ib$$

$$IC = Ib - Ic$$

Figure 6.10 shows that system primary current Ia (X-side) lags the system primary current IA (H-side) by 150 degrees.

Figure 6.10 X- and H-Side Current Phasors for Figure 6.9

These three examples show that the same transformer winding connections can produce different phase shifts in the system primary-load current based on the phase-to-bushing connections.

Determine if There Are Non-Standard CT Connections

Figure 6.11 shows the transformer of *Figure 6.2* with standard CT configuration; that is, both the H-side and X-side CTs are connected in wye and the polarity marks are away from the power transformer.

Figure 6.11 Standard CT Connections

Standard CT Connections

In *Figure 6.11*, the polarity of the CT connects to the polarity of the relay analog current input, and the primary system phase current connects to the same phase input on the relay (e.g., IA system to IAW on the merging unit). While the H-side currents map to the S-Terminal and the X-side currents map to the T-Terminal, they can be connected to any two sets of current inputs on the relay. *Figure 6.11* represents the standard connections for the transformer, CTs, and relay.

Figure 6.11 also shows the primary system currents (IA system, Ia system) and the CT secondary currents seen by the relay (IA relay, Ia relay) based on the currents of *Figure 6.6*. For these connections, with power flow from the H-side to X-side of the transformer, currents enter the relay at the polarity mark on the H-side, and leave the relay at the polarity mark on the X-side. Thus, on the primary system, Ia lags IA by 30 degrees but at the relay IAT leads IAS by 150 degrees, as shown in *Figure 6.12*. B- and C-Phases follow this relationship. Only A-Phase is discussed for simplicity, but the concept is the same.

Figure 6.12 Primary System Current and Current as Seen by the Relay

Non-Standard CT Connections: Reversed CT Polarity

Figure 6.13 shows the X-side CT polarity marks toward the transformer. However, because the connections to the relay remain the same, the relay currents flow the same, as in *Figure 6.12*. No additional adjustments needs to be made because of this type of non-standard CT connection.

Figure 6.13 Current Flow With Reversed X-Side CT Polarity

Non-Standard CT Connections: Reversed CT Polarity and Reversed Connections

In *Figure 6.14*, the polarity marks of the X-side CTs are toward the transformer, as in *Figure 6.13*, but the neutral sides of the CTs are away from the transformer. With these connections, the H-side and X-side currents are both entering the relay at the relay polarity mark.

Figure 6.14 Current Flow With Reversed X-Side CT Polarity and Reversed Connections

As shown in *Figure 6.15*, the resulting IAT current measured by the relay is now shifted 180 degrees as compared to the previous example.

Figure 6.15 Results of Reversed X-Side CT Polarity and Reversed Connections

One method to correct this is to reverse the current connections at the relay. Connect the non-polarity terminal of the CT to the polarity terminal of the relay analog current input and the polarity terminal of the CT to the non-polarity terminal of the relay analog current input. These changes result in the connections shown in *Figure 6.13*.

An alternative method corrects the phase shift with the CT compensation setting, T*m*CTC. As shown in *Table 6.1*, each CTC setting results in a counter-clockwise phase shift that is a multiple of 30 degrees for an ABC system phase rotation. Selecting a compensation setting of 6 effectively shifts the current by 180 degrees (6 • 30 degrees = 180 degrees). Further explanation of selecting the final settings for non-standard CT connections is provided in *Example 6.3*.

Step 2. Select the Reference Winding and Associated Relay Terminal

If there is a delta winding on the power transformer, the delta winding should be selected as the reference winding regardless of whether it is the high- or low-voltage winding. The reference winding can be associated with any analog current measurement terminal on the relay. For example, if the delta winding current is measured by the S-Terminal inputs on the relay, TSCTC is the setting that corresponds to the reference winding.

The compensation for the delta winding should be set to Matrix CTC(0) (T*m*CTC = 0) unless there is a grounding bank on the delta winding within the differential zone. Grounding banks are a source of zero-sequence current and this current needs to be filtered to avoid operation of the differential element for external ground faults. If there is a grounding bank within the differential zone, use T*m*CTC = 12. Both T*m*CTC = 0 and T*m*CTC = 12 result in no phase shift, but T*m*CTC = 12 additionally removes zero-sequence current from the differential calculation.

If there is no delta winding, select one of the wye windings as the reference and set the compensation to 11 (T*m*CTC = 11) for the reference winding.

Step 3. Determine the Remaining Compensation Settings for All Other Windings

Use the following guidelines for choosing the remaining CT compensation settings.

1. Compensate delta windings with Matrix CTC(0).
2. Compensate wye windings with odd matrices.
3. Avoid the use of even matrices.

There may be applications that require one or more of the guidelines to be violated, but they should be followed when possible. The following examples will illustrate the steps required to determine the compensation settings for the remaining windings.

Application Examples

Example 6.1 Delta-Wye Transformer With Standard Phase-to-Bushing Connections, Standard CT Connections, and ABC System Phase Rotation

Consider the system shown in *Figure 6.16*. The primary current phase shift for these connections was determined in *Figure 6.6*. The system primary current Ia (X-side) lags the system primary current IA (H-side) by 30 degrees. The CT connections are standard, which results in IAT leading IAS by 150 degrees.

Example 6.1 Delta-Wye Transformer With Standard Phase-to-Bushing Connections, Standard CT Connections, and ABC System Phase Rotation (Continued)

Figure 6.16 Delta-Wye Transformer With Standard Phase-to-Bushing Connections

Select the delta winding as the reference winding. The H-side delta current is mapped to Terminal S of the SEL-487E Relay. Therefore, set TSCTC = 0. The X-side currents are mapped to Terminal T of the SEL-487E Relay, so TTCTC must be determined. *Figure 6.17* shows the phase relationship of both the primary system phase currents and the secondary phase currents as seen by the relay.

Figure 6.17 Differential Current Measured by the Relay

IAT must be rotated 30 degrees (1 multiple of 30 degrees) in the counter-clockwise direction for systems with ABC phase rotation to be 180 degrees out-of-phase with IAS. Therefore, set TTCTC = 1. The resulting compensation settings for *Example 6.1* are TSCTC = 0 and TTCTC = 1.

Example 6.2 Delta-Wye Transformer With Non-Standard Phase-to-Bushing Connections, Standard CT Connections, and ABC System Phase Rotation

This example uses the transformer and relay connections of *Figure 6.18*. This is the same transformer as in *Example 6.1*, but with non-standard phase-to-bushing connections. *Figure 6.8* shows that for this connection, the system current Ia (X-side) leads the system current IA (H-side) by 30 degrees, or lags by 330 degrees. The CT connections are standard, which results in IAT lagging IAS by 150 degrees.

Figure 6.18 Delta-Wye Transformer With Non-Standard Phase-to-Bushing Connections for Example 6.2

Select the delta winding as the reference winding. The H-side delta current is mapped to Terminal S of the SEL-487E Relay. Therefore, set TSCTC = 0. The X-side currents are mapped to Terminal T, so TTCTC must be determined. *Figure 6.19* shows the phase relationship of both the primary system phase currents and the secondary phase currents as seen by the relay.

Example 6.2 Delta-Wye Transformer With Non-Standard Phase-to-Bushing Connections, Standard CT Connections, and ABC System Phase Rotation (Continued)

Figure 6.19 IAS and IAT for Example 6.2

IAT must be rotated 330 degrees (11 multiples of 30 degrees) in the counter-clockwise direction for a system with an ABC phase rotation to be 180 degrees out-of-phase with IAS. Therefore, set TTCTC = 11. The resulting compensation settings for *Example 6.2* are TSCTC = 0 and TTCTC = 11. Although the same transformer is used in *Example 6.1* and *Example 6.2*, notice that the non-standard phase-to-bushing connections affect the compensation settings in both examples.

Example 6.3 Delta-Wye Transformer With Standard Phase-to-Bushing Connections, X-Side Non-Standard CT Connections, and ABC System Phase Rotation

This example uses standard phase-to-bushing connections, as shown in *Figure 6.20*. Notice the X-side CT connections are non-standard. This example differs from the previous examples because the wye winding is now on the high side. The method to solve for the compensation settings is the same.

Example 6.3 Delta-Wye Transformer With Standard Phase-to-Bushing Connections, X-Side Non-Standard CT Connections, and ABC System Phase Rotation (Continued)

Figure 6.20 Wye-Delta Transformer With Non-Standard CT Connections on X-Side

Assume balanced three-phase currents on the wye side of the transformer. In this example, the wye side is associated with the H-side of the transformer. The phase currents on the X-side are:

$$Ia = IA - IC$$

$$Ib = IB - IA$$

$$Ic = IC - IB$$

Figure 6.21 selects IA on the wye side of the transformer as the reference to derive the phasor diagram of the delta-side currents. The system primary current Ia (X-side) lags the system primary current IA (H-side) by 30 degrees.

Figure 6.21 System Currents on H-Side (Wye) and X-Side (Delta) of the Transformer

Example 6.3 Delta-Wye Transformer With Standard Phase-to-Bushing Connections, X-Side Non-Standard CT Connections, and ABC System Phase Rotation (Continued)

With the reversed CT polarity on the X-side, the current is leaving Terminal T at the polarity mark instead of entering the polarity mark, which makes the current seen by the relay 180 degrees out-of-phase compared to a standard CT connection. In *Non-Standard CT Connections: Reversed CT Polarity and Reversed Connections on page 6.11*, two methods were proposed to correct the phase shift for reverse polarity CTs. The first is to rewire the current inputs on the relay so that they match the standard connections. The second is to use the compensation setting by adding or subtracting 6 from the setting. This example explores the latter method.

Following the settings guidelines, select the delta side as the reference. The delta side of the transformer is connected to relay Terminal T, therefore, TTCTC = 0 and is used as the reference. *Figure 6.22* compares the current phasors if the X-side CT connections used standard connections vs. non-standard connections. On the left side of *Figure 6.22*, standard CT connections and ABC phase rotation require IAS to rotate 330 degrees (11 multiples of 30 degrees) counter-clockwise to be 180 degrees out-of-phase with IAT. Therefore, if the X-side CTs had standard connections, set TSCTC = 11. The resulting compensation settings with standard CT connections are TTCTC = 0 and TSCTC = 11.

Figure 6.22 Comparison of Standard and Non-CT Connections on X-Side of Transformer

However, in this example, non-standard CT connections are used on the delta winding which results in IAS leading IAT by 30 degrees. IAS needs to rotate 150 degrees (5 multiples of 30 degrees) counter-clockwise for a system with an ABC phase rotation to be 180 degrees out-of-phase with IAT. Therefore, set TSCTC = 5. The resulting compensation settings for *Example 6.3* with non-standard CT connections on the X-side are TTCTC = 0 and TSCTC = 5.

Example 6.4 Autotransformer, Standard Phase-to-Bushing Connections, Standard CT Connections, and an ABC System Phase Rotation

Consider the autotransformer shown in *Figure 6.23*. The delta tertiary exists but is buried and not brought out to the relay. The primary current phase shift for these connections is shown in *Figure 6.24*. The system primary current Ia (X-side) is in phase with the system primary current IA (H-side). The CT connections are standard, which results in IAT 180 degrees out-of-phase with IAS.

Example 6.4 Autotransformer, Standard Phase-to-Bushing Connections, Standard CT Connections, and an ABC System Phase Rotation (Continued)

Per the guidelines, because there is no delta winding connected to the relay, choose any one of the wye windings, say H-side, as the reference winding and choose matrix CTC(11) for the compensation. The H-side currents are mapped to Terminal S of the SEL-487E Relay. Therefore, set TSCTC = 11. The X-side currents are mapped to Terminal T, so TTCTC must be determined. *Figure 6.24* shows the phase relationship of both the primary system phase currents and the secondary phase currents as seen by the relay. Because Matrix 11 is applied to Winding 1, this will shift IAS 11 multiples of 30 degrees in the counterclockwise direction. To keep Winding 2 current, IAT 180 degrees out-of-phase with IAS, you must also shift IAT by 11 multiples of 30 degrees in the counterclockwise direction. The resulting compensation settings are TSCTC = 11 and TTCTC = 11.

Figure 6.23 Autotransformer With Standard Phase-to-Bushing Connections

Example 6.4 Autotransformer, Standard Phase-to-Bushing Connections, Standard CT Connections, and an ABC System Phase Rotation (Continued)

Figure 6.24 Primary Currents and Secondary Currents as Measured by the Relay

Example 6.5 Delta-Delta Transformer With Standard Phase-to-Bushing Connections, Standard CT Connections, and ABC System Phase Rotation

Figure 6.25 Delta-Delta Transformer With Standard Phase-to-Bushing Connections

This example uses the transformer and relay connections of *Figure 6.25*. The H-side delta current connected to Terminal S is used as the reference terminal in this example. Therefore, set TSCTC = 0. The X-side currents are connected to Terminal T of the SEL-487E, so TTCTC must be determined.

Example 6.5 Delta-Delta Transformer With Standard Phase-to-Bushing Connections, Standard CT Connections, and ABC System Phase Rotation (Continued)

Assume balanced three-phase load currents. Because the H side of the transformer is selected as the reference, the X-side phasors are used to derive the equivalent current as seen by the H-side. Because there are no zero-sequence current sources present in the differential zone, TTZSR = N. The phase currents on the H side in relation to the X side under these conditions are:

IA = –Ib

IB = –Ic

IC = –Ia

Figure 6.26 illustrates the relationship between the H-side and X-side primary currents.

Figure 6.26 X- and H-Side Current Phasors for Figure 6.25

Figure 6.27 shows the phase relationship of both the primary system phase currents and the secondary phase currents as seen by the relay. The system current Ia (X side) lags the system current IA (H side) by 60 degrees. The CT connections are standard, which results in IAT leading IAS by 120 degrees, as shown in *Figure 6.27*. IAT must be rotated 60 degrees (2 multiples of 30 degrees) in the counterclockwise direction for systems with ABC phase rotation to be 180 degrees out-of-phase with IAS. Therefore, set TTCTC = 2 with setting TTZSR = N.

Figure 6.27 Differential Current Measured by the Relay

Special Cases

Example 6.6 Delta-Wye Transformer With Standard Phase-to-Bushing Connections, Standard CT Connections, and ACB System Phase Rotation

Consider the application in *Figure 6.28* with standard phase-to-bushing connections, standard CT connections, and ACB system phase rotation.

Figure 6.28 Delta-Wye Transformer With Standard Phase-to-Bushing Connections With an ACB Phase Rotation

The H-side currents are:

IA = Ia – Ib

IB = Ib – Ic

IC = Ic – Ia

Figure 6.29 uses a balanced set of three phase currents with ACB phase sequence on the wye winding as a reference to derive the delta winding (H-side) currents. When compared to *Example 6.1*, even with the same transformer and the same connections, *Figure 6.29* shows that Ia (X-side) now leads IA (H-side) by 30 degrees because of the system phase rotation. Note that in *Example 6.1*, Ia (X-side) lags IA (H-side) by 30 degrees.

Example 6.6 Delta-Wye Transformer With Standard Phase-to-Bushing Connections, Standard CT Connections, and ACB System Phase Rotation (Continued)

Figure 6.29 X- and H-Side Current Phasors for Figure 6.28

A common misconception is that a different compensation setting is required depending on the system phase rotation. However, closer inspection of the compensation matrices and the direction of correction in *Table 6.1* indicates that the matrix will cause the compensated currents to rotate in the opposite direction depending on the system phase rotation.

Figure 6.30 System Phase Rotation

Thus, the compensation settings required for *Example 6.1* and *Example 6.6* are the same. Following the settings guideline, the delta side of the transformer is selected as the reference, so TSCTC = 0. *Figure 6.31* shows IAT needs to rotate 30 degrees (1 multiple of 30 degrees) clockwise for a system with an ACB phase rotation to be 180 degrees out-of-phase with IAS. Therefore, set TTCTC = 1. The resulting compensation settings for *Example 6.6* are TSCTC = 0 and TTCTC = 1.

Figure 6.31 Primary Currents and Secondary Currents as Measured by the Relay

If the relay is set assuming an ABC phase rotation, but the actual system phase sequence is ACB, the relay compensation settings do not need to be changed. However, the calculated positive- and negative-sequence currents will be incorrect unless the Global setting for phase rotation, PHROT, matches the system phase sequence. PHROT does not affect the compensation settings or differential protection.

Example 6.7 Delta-Wye Transformer With Standard Phase-to-Bushing Connections, Standard CT Connections, and ABC System Phase Rotation With Zigzag Grounding Bank on a Delta Transformer Winding Inside the Differential Zone

This example uses the same transformer and CT connections as in *Example 6.1*, except that it includes a zigzag grounding transformer on the delta side of the transformer within the differential zone. Zigzag transformers are typically used for grounding purposes and act as a source of zero-sequence current. If the zigzag transformer is located outside of the differential zone on the delta side, it can be ignored, and the compensation settings will remain the same as in *Example 6.1*. The same is true if the zigzag transformer is present on the wye side, be it inside or outside the differential zone. If the zigzag transformer is within the differential zone on the delta side, then it has to be accounted for when determining the compensation settings.

The resulting compensation settings in *Example 6.1* were TSCTC = 0 for the delta winding (reference winding) and TTCTC = 1 for the wye winding. When a ground current source is within the differential zone on the delta side, the recommended compensation setting of TSCTC = 0 cannot be used. The zero-sequence current needs to be filtered to avoid operation of differential element for external ground faults. Therefore, set TSCTC = 12. Matrix CTC(12) has no phase shift but removes zero-sequence current from the differential calculation.

Quick Settings Guide for Standard Connections

Figure 6.32 shows examples of common transformer connections. *Table 6.4* is a quick settings guide to be used when all standard phase-to-bushing, CT, and relay connections are present. *Table 6.4* is applicable to both ABC and ACB system phase rotations.

Figure 6.32 Common Transformer Connections

Table 6.4 Quick Settings Guide for Common Transformer Configurations and Standard Connections

XFMR Designation		TSCTC (Winding 1)	TTCTC (Winding 2)
Connection	IEC		
DABY	Dy1	0	1
DACY	Dy11	0	11
YDAC	Yd1	11	0
YDAB	Yd11	1	0
DABDAB DACDAC	Dd0	0	0
YY	Yy0	11	11

The compensation settings of *Table 6.4* assume that the Winding 1 side of the transformer is connected to relay Terminal S and the Winding 2 side of the transformer is connected to relay Terminal T. These settings apply for all standard phase-to-bushing connections shown in *Table 6.2*. In each of these phase-to-bushing connections, the order of the phase connections (A, B, C) matches the order of the bushings (H1, H2, H3).

References

Further discussion on selecting transformer compensations settings can be found in the technical paper *Beyond the Nameplate – Selecting Transformer Compensation Settings for Secure Differential Protection* by Barker Edwards, David G. Williams, Ariana Hargrave, Matthew Watkins, and Vinod K. Yedidi (available at selinc.com).

This page intentionally left blank

SECTION 7

Metering, Monitoring, and Reporting

The SEL-487E provides extensive capabilities for metering important power system parameters, monitoring transformer components, and reporting on system operation. The relay provides the following useful features:

- *Metering on page 7.1*
- *Circuit Breaker Monitor on page 7.14*
- *Station DC Battery System Monitor on page 7.15*
- *Thermal Monitor on page 7.15*
- *Through-Fault Monitor on page 7.35*
- *Analog Signal Profiling on page 7.40*
- *Reporting on page 7.41*

See *Section 7: Metering, Section 8: Monitoring,* and *Section 9: Reporting in the SEL-400 Series Relays Instruction Manual* for general information. This section contains details specific to the SEL-487E.

Metering

NOTE: For the SEL-487E-5, the loss of communications with a merging unit causes the corresponding metering information to be reported as zero.

The SEL-487E provides metering for measuring power system conditions and differential protection values. Each SEL-487E processes 18 currents, six voltages, and one battery monitor.

Table 7.1 shows all the **MET** commands available in the relay.

Table 7.1 MET Command (Sheet 1 of 2)

Command	Description
MET RMS *w*[a]	Display root-mean-square (rms) metering quantities (current and voltage only)
MET *w*[a]	Display fundamental metering quantities
MET N	Display neutral current fundamental metering quantities
MET SEC *w*[a]	Display secondary metering quantities
MET SEC A	Display fundamental secondary metering data for all terminal inputs
MET D	Display demand and peak demand metering quantities
MET RD	Reset demand meter data
MET RP	Reset peak demand data
MET DIF	Display differential data for Zone 1
MET DIF Z*k*[b]	Display differential data for Zone *k*
MET DIF A **MET DIF Z1 A**	Display differential data with additional information for matrix compensation, differential settings, and differential Relay Word bits for Zone 1
MET E	Display energy import and export metering quantities

Table 7.1 MET Command (Sheet 2 of 2)

Command	Description
MET RE	Reset energy data
MET PM	Display synchrophasor data
MET PM *hh:mm:ss*	Triggers a synchrophasor measurement
MET PM HIS	Display most recent MET PM response previously displayed on any port
MET RTC	Display received synchrophasor client data
MET RTD	SEL-2600 temperature quantities
MET PMV	Display protection math variables
MET AMV	Display automation math variables
MET BAT	Display battery data
MET RBM	Reset station battery max/min measurements
MET ANA	Display analog values from MIRRORED BITS analog, and remote analogs

[a] w = S, T, U, W, X, Y, ST, TU, UW, WX.
[b] k = 1, 2.

Note that if an analog quantity is not enabled for a particular application (e.g., VREFS = OFF), those quantities will display dashes (-----).

Instantaneous Metering

Fundamental Meter

Use the **MET** (**F**) ***w*** command (*w* = S, T, U, W, X, Y, ST, TU, UW, WX) to view the fundamental (60 or 50 Hz) metering values. When you type **MET** without an argument, the report defaults to Terminal S. For each terminal, the fundamental meter report provides the quantities shown in *Table 7.3*.

Table 7.2 shows the order of valid reference quantities that the relay uses to display the angular relationship among the metering values.

Table 7.2 Valid Reference Quantities

Reference Quantity	Source	Valid Value
Positive-sequence voltage	PT V	Positive-sequence voltage > 0.1 • VNOMV
Positive-sequence voltage	PT Z	Positive-sequence voltage > 0.1 • VNOMZ
Positive-sequence current	Terminal S	Positive-sequence current > 0.05 • INOMS
Positive-sequence current	Terminal T	Positive-sequence current > 0.05 • INOMT
Positive-sequence current	Terminal U	Positive-sequence current > 0.05 • INOMU
Positive-sequence current	Terminal W	Positive-sequence current > 0.05 • INOMW
Positive-sequence current	Terminal X	Positive-sequence current > 0.05 • INOMX

For example, the positive-sequence voltage calculated from the PT V voltage inputs is reference for all metering quantities, provided that this positive-sequence voltage exceeds 10 percent of the VNOMV setting. If PT V is not available, then the positive-sequence voltage calculated from the PT Z voltage inputs is reference for all metering quantities, provided that this positive-sequence voltage exceeds 10 percent of the VNOMV settings. This sequence continues for all other reference quantities.

Table 7.3 Quantities in the Fundamental Meter Report

Quantity	Description
IA, IB, IC	Terminal *w* A-Phase, B-Phase, and C-Phase primary current. The reference is independent of the VREF*m* settings (*m* = S, T, U, W, X, Y), and is determined as follows, according to *Table 7.2*: 1. Positive-sequence voltage of PT V (if available) 2. Positive-sequence voltage of PT Z (if available, and PT V is not available) 3. Positive-sequence current of Terminal *w* (if no PTs are available) in the order specified by *Table 7.2*.
I1, 3I2, 3I0	Positive-, negative-, and zero-sequence components for Terminal *w*. 3I0 is not available when the CTs are connected in delta (CTCON = D).
VA, VB, VC	Primary voltage of PT *k* (*k* = V, Z) specified by the Terminal *w* voltage reference settings, VREF*m* and ALTV*m*. *Table 7.2* specifies the angle reference. The quantities are not available when PTs are connected in delta (PTCON*k* = D).
V1, 3V2, 3V0	Positive-, negative-, and zero-sequence components of the PT specified by the Terminal *w* voltage reference settings, VREF*m* and ALTV*m*. *Table 7.2* specifies the angle reference. 3V0 is not available when the PTs are connected in delta (PTCON = D).
PA, PB, PC, 3P	A-Phase, B-Phase, C-Phase, and three-phase active (real) power for Terminal *w*. Only three-phase real power is available when either CTs or PTs (or both) are delta-connected. The quantities are not calculated if setting VREF*m* does not include a reference PT and/or setting EPCAL does not include the terminal. Active power calculations (and Q and S calculations) for combined terminals (ST, TU, UW, WX) are automatically calculated when both terminals of the pair are present in the EPCAL setting. Combined terminals also require that the VREF*m* and ALTV*m* settings of the terminal pairs identically match in order to be calculated.
QA, QB, QC, 3Q	A-Phase, B-Phase, C-Phase, and three-phase reactive power for Terminal *w*. Only three-phase reactive power is available when either CTs or PTs (or both) are delta-connected. The quantities are not calculated if setting VREF*m* does not include a reference PT and/or setting EPCAL does not include the terminal.
SA, SB, SC, 3S	A-Phase, B-Phase, C-Phase, and three-phase apparent power for Terminal *w*. Only three-phase power apparent is available when either CTs or PTs (or both) are delta-connected. The quantities are not calculated if setting VREF*m* does not include a reference PT and/or setting EPCAL does not include the terminal.
Power factor	A-Phase, B-Phase, C-Phase, and three-phase power factor for Terminal *w*.
VAB, VBC, CA	AB, BC, and CA line-to-line voltages for PT V. The quantities are not displayed if EPTTERM does not include Terminal V.
VAB, VBC, CA	AB, BC, and CA line-to-line voltages for PT Z. The quantities are not displayed if EPTTERM does not include Terminal Z.
Frequency	Measured system frequency. The frequency specified by the NFREQ Global setting is used when the relay is not tracking the frequency.
Frequency Tracking	When the relay tracks the frequency, the report displays “Y”, and “N” when the relay cannot track the frequency.
Battery Voltage	Measured battery voltage.
Volts/Hertz	Percentage V/Hz. The quantity is not displayed if E24 = N.

Enable current, voltage, and power meter quantities with the following settings:

- Current: include the terminal(s) in the ECTTERM Group setting
- Voltage: include the PT(s) in the EPTTERM Group setting and select the reference PT for each terminal (VREF*m* Group setting and ALTV*m* Group setting, if appropriate)
- Power (fundamental power only): include the terminal(s) in the EPCAL Group setting.

Table 7.4 summarizes the settings for the example of metering Terminal S and PT V.

Table 7.4 Meter Report Settings Summary

I in Report	V in Report	P, Q, S in Report
ECTTERM = S	EPTTERM = V, VREFS = V	EPCAL = S

Figure 7.1 shows the report with the following settings:

- ECTTERM: includes S (ECTTERM = S,…)
- EPTTERM: does not includes V or Z (EPTTERM = OFF)
- VREFS: no reference voltage specified (VREFS = OFF)
- EPCAL = OFF
- E24 = N

With these settings, the report shows only the current values for Terminal S. Notice that there is no indication of the reference PT in the `Phase Voltages - PT -` heading (VREFS = OFF). Also, the positive-sequence current is the reference because there is no PT available, as specified by *Table 7.2*.

```
=>>MET <Enter>

Relay 1                                    Date: 01/01/2019 Time: 02:03:30.014
Station A                                  Serial Number: 0000000000

Fundamental Meter: Terminal S

               Phase Currents                  Sequence Currents
           IA        IB        IC           I1        3I2       3I0
MAG(A,pri)  219.26    219.47    219.96       219.55      1.52      1.92
ANG(deg)     -0.13   -120.14    120.28         0.00    -51.86   -170.31

            Phase Voltages - PT -              Sequence Voltages
           VA        VB        VC           V1        3V2       3V0
MAG (kV)   -------   -------   -------      -------   -------   -------
ANG(deg)   ------    ------    ------       ------    ------    ------

Power Quantities
Active Power P (MW,pri)
     PA          PB          PC          3P
------    ------    ------   ------

Reactive Power Q (MVAr,pri)
     QA          QB          QC          3Q
------    ------    ------   ------

Apparent Power  S (MVA,pri)
     SA          SB          SC          3S
------    ------    ------   ------

Power factor
 Phase A     Phase B     Phase C     3-Phase
----        ----        ----        ----

Line-to-Line Voltage
                    PT - V                            PT - Z
           VAB       VBC       VCA          VAB       VBC       VCA
MAG (kV)   -------   -------   -------      -------   -------   -------
ANG(deg)   ------    ------    ------       ------    ------    ------

FREQ (Hz) 59.991          Frequency Tracking = Y
VDC (V)   115.81          V/Hz      -----%

=>>
```

Figure 7.1 Fundamental Quantities Report With VREFS = OFF and EPTTERM = OFF

In the report shown in *Figure 7.2*, the EPTTERM includes both V and Z PTs, but PT Z is connected to a dead busbar.

Figure 7.2 shows the report with the following settings:

- ECTTERM: includes S (ECTTERM = S,….)
- EPTTERM: includes both V or Z (EPTTERM = V, Z), but PT Z is de-energized
- VREFS: no reference voltage specified (VREFS = OFF)
- EPCAL = OFF
- E24 = N

With these settings, Terminal S current is available, as well as the two PTs. Although there is no reference voltage selected (VREFS = OFF), the phase currents are referenced to the positive-sequence voltage of PT V.

```
=>>MET <Enter>

Relay 1                                    Date: 01/01/2019 Time: 02:08:46.920
Station A                                  Serial Number: 0000000000



Fundamental Meter: Terminal S

                Phase Currents                  Sequence Currents
            IA        IB        IC           I1        3I2       3I0
MAG(A,pri)  219.81    219.28    219.23       219.44      1.20      1.39
ANG(deg)    -16.17   -135.86    104.10       -15.97    -85.85    -76.74

             Phase Voltages - PT -              Sequence Voltages
            VA        VB        VC           V1        3V2       3V0
MAG (kV)   -------   -------   -------      -------   -------   -------
ANG(deg)   ------    ------    ------       ------    ------    ------

Power Quantities
Active Power P (MW,pri)
     PA          PB          PC          3P
------    ------    ------   ------

Reactive Power Q (MVAr,pri)
     QA          QB          QC          3Q
------    ------    ------   ------

Apparent Power  S (MVA,pri)
     SA          SB          SC          3S
------    ------    ------   ------

Power factor
 Phase A     Phase B     Phase C     3-Phase
----        ----        ----        ----

Line-to-Line Voltage
                    PT - V                          PT - Z
            VAB       VBC       VCA          VAB       VBC       VCA
MAG (kV)   217.888   217.704   218.330        0.005     0.007     0.005
ANG(deg)    29.89    -89.93    150.02      -166.32     61.99    -75.31

FREQ (Hz) 59.991          Frequency Tracking = Y
VDC (V)   115.82          V/Hz      -----%

=>>
```

Figure 7.2 Fundamental Quantities Report With VREFS = OFF and EPTTERM = V, Z

In the report shown in *Figure 7.3*, the EPTTERM includes both V and Z PTs (PT Z is hot) and the VREFS setting selects PT V. Additionally, the ALTVS setting is set to NA, indicating no alternative voltage source is present for Terminal S. The Phase Voltages heading now indicates the reference PT (V), and the voltage values are shown. Note that the heading indicates Z and the report displays the Z phase voltage when the ALTVS SELOGIC setting evaluates to logical 1. Because EPCAL = OFF, no power values are shown in the report.

Figure 7.3 shows the report with the following settings:

- ECTTERM: includes S (ECTTERM = S,…)
- EPTTERM: includes both V or Z (EPTTERM = V, Z)
- VREFS: PT V as reference voltage (VREFS = V)
- ALTVS = NA (No alternative voltage for Terminal S)
- EPCAL = OFF
- E24 = Y

```
=>>MET S <Enter>

Relay 1                                    Date: 01/01/2019 Time: 02:23:31.610
Station A                                  Serial Number: 0000000000



Fundamental Meter: Terminal S

               Phase Currents                  Sequence Currents
           IA        IB        IC           I1        3I2       3I0
MAG(A,pri)  219.56    219.68    219.24       219.49      0.96      1.60
ANG(deg)    -16.16   -135.90    104.21       -15.95    -77.23   -117.62

            Phase Voltages - PT V              Sequence Voltages
           VA        VB        VC           V1        3V2       3V0
MAG (kV)   125.839   125.873   125.853      125.854     0.647     0.710
ANG(deg)    -0.14   -120.06    120.21         0.00    -41.95   -138.62

Power Quantities
Active Power P (MW,pri)
     PA          PB          PC          3P
------    ------    ------   ------

Reactive Power Q (MVAr,pri)
     QA          QB          QC          3Q
------    ------    ------   ------

Apparent Power  S (MVA,pri)
     SA          SB          SC          3S
------    ------    ------   ------

Power factor
 Phase A     Phase B     Phase C     3-Phase
----        ----        ----        ----

Line-to-Line Voltage
                    PT - V                           PT - Z
           VAB       VBC       VCA          VAB       VBC       VCA
MAG (kV)   217.911   217.710   218.363      130.809   130.743   130.966
ANG(deg)    29.90    -89.93    150.03       29.96    -89.95    150.03

FREQ (Hz) 59.992          Frequency Tracking = Y
VDC (V)   115.81          V/Hz      99.87%

=>>
```

Figure 7.3 Fundamental Quantities With EPCAL = OFF

In the report shown in *Figure 7.4*, the EPTTERM includes both V and Z PTs, and the EPCAL setting include Terminal S.

Figure 7.4 shows the report with the following settings:

- ECTTERM: includes S (ECTTERM = S,…)
- EPTTERM: includes both V or Z (EPTTERM = V, Z)
- VREFS: PT V as reference voltage (VREFS = V)
- ALTVS = NA (No alternative voltage for Terminal S)
- EPCAL: includes Terminal S (EPCAL = S….)
- E24 = Y

With these settings, all functions are enabled and all values are shown.

```
=>>MET <Enter>

Relay 1                                      Date: 01/01/2019 Time: 05:28:37.595
Station A                                    Serial Number: 0000000000

Fundamental Meter: Terminal S

                Phase Currents                   Sequence Currents
            IA        IB        IC           I1        3I2       3I0
MAG(A,pri)  219.78    219.58    219.29       219.54      1.19      1.37
ANG(deg)    -16.15   -135.94    104.22       -15.96    -59.31   -112.78

             Phase Voltages - PT V               Sequence Voltages
            VA        VB        VC           V1        3V2       3V0
MAG (kV)   125.845   125.866   125.852      125.854     0.662     0.703
ANG(deg)    -0.14   -120.07    120.21         0.00    -41.11   -139.10

Power Quantities
Active Power P (MW,pri)
     PA          PB          PC          3P
    26.58       26.58       26.53       79.70

Reactive Power Q (MVAr,pri)
     QA          QB          QC          3Q
     7.63        7.56        7.60       22.79

Apparent Power  S (MVA,pri)
     SA          SB          SC          3S
    27.66       27.64       27.60       82.89

Power factor
Phase A     Phase B     Phase C     3-Phase
 0.96 Lag    0.96 Lag    0.96 Lag    0.96 Lag

Line-to-Line Voltage
                    PT - V                              PT - Z
            VAB       VBC       VCA          VAB       VBC       VCA
MAG (kV)   217.912   217.694   218.347      130.807   130.728   130.953
ANG(deg)    29.90    -89.93    150.03        29.96    -89.95    150.03

FREQ (Hz) 59.991          Frequency Tracking = Y
VDC (V)   115.21          V/Hz      99.01%

=>>
```

Figure 7.4 Fundamental Quantities Report

Power

Table 7.3 shows the power quantities that the relay measures. The instantaneous power measurements are derived from 1-cycle averages that the SEL-487E reports by using the generator condition of the positive power flow convention; for example, real and reactive power flowing out (export) is positive, and real and reactive power flowing in (import) is negative (see *Figure 7.5*). For power factor, LAG and LEAD refer to whether the current lags or leads the applied voltage. The reactive power Q is positive when the voltage angle is greater than the current angle ($\theta_V > \theta_I$), which is the case for inductive loads where the current lags the applied voltage. Conversely, Q is negative when the voltage angle is less than the current angle ($\theta_V < \theta_I$); this is when the current leads the voltage, as in the case of capacitive loads.

Figure 7.5 Complex Power (P/Q) Plane

The SEL-487E includes Relay Word bits to indicate the leading or lagging power factor (see *Section 11: Relay Word Bits*). In the case of a unity power factor, the resulting power factor angle would be on the real power axis of the complex power (P/Q) plane shown in *Figure 7.5*. This would cause the power factor Relay Word bits to rapidly change state (chatter). Be aware of expected system conditions when monitoring the power factor Relay Word bits. It is not recommended to use chattering Relay Word bits in the SER or as an event trigger condition.

RMS Meter

Use the **MET RMS *w*** command (*w* = S, T, U, W, X, Y, ST, TU, UW, WX) to view the root-mean-square (rms) current and voltage values; the relay does not calculate rms power values. Setting conditions (ECTTERM, EPTTERM, VREF*m*, ALTV*m*, and EPCAL) are the same for rms metering as for fundamental metering. *Table 7.5* shows the quantities in the rms report.

Table 7.5 Quantities in the RMS Meter Report (Sheet 1 of 2)

Quantity	Description
IA, IB, IC	Terminal *w* A-Phase, B-Phase, and C-Phase primary current. The reference is independent of the VREF*m* settings, and is determined as follows, according to *Table 7.2*: 1. Positive-sequence voltage of PT V (if available) 2. Positive-sequence voltage of PT Z (if available, and PT V is not available) 3. Positive-sequence current of Terminal *w* (if no PTs are available) in the order specified by *Table 7.2*
VA, VB, VC	Primary voltage of PT *k* (*k* = V, Z) specified by the Terminal *w* voltage reference settings, VREF*m* and ALTV*m*. *Table 7.2* specifies the angle reference. The quantities are not available when PTs are connected in delta (PTCON*k* = D).
VAB, VBC, CA	Primary voltage AB, BC, and CA line-to-line voltages for PT V. The quantities are not displayed if EPTTERM does not include Terminal V.
VAB, VBC, CA	Primary voltage AB, BC, and CA line-to-line voltages for PT Z. The quantities are not displayed if EPTTERM does not include Terminal Z.

Table 7.5 Quantities in the RMS Meter Report (Sheet 2 of 2)

Quantity	Description
Frequency	Measured system frequency. The frequency specified by the NFREQ Global setting is used when the relay is not tracking the frequency.
Frequency Tracking	When the relay tracks the frequency, the report displays “Y”, and “N” when the relay cannot track the frequency.
Battery Voltage	Measured battery voltage.
Volts/Hertz	Percentage V/Hz. The quantity is not displayed if E24 = N.

Figure 7.6 shows an rms report for Terminal S; other terminals have similar reports.

```
=>>MET RMS <Enter>

Relay 1                                     Date: 01/01/2019 Time: 06:21:32.214
Station A                                   Serial Number: 0000000000

        RMS Meter: Terminal S

Phase Currents, I (A,pri)
IA        IB        IC
  219.73    218.97    219.79

Phase Voltages (kV,pri)  - PT V
VA        VB        VC
125.841   125.847   125.855

Line-to-Line Voltage V (kV,pri)
PT - V                          PT - Z
VAB       VBC       VCA         VAB       VBC       VCA
217.889   217.696   218.336     130.796   130.731   130.945

FREQ (Hz) 59.991          Frequency Tracking = Y
VDC (V)   115.81          V/Hz      99.78%

=>>
```

Figure 7.6 RMS Report for Terminal S

Secondary Meter

Use the **MET SEC** command to see the secondary fundamental current and voltage values. Setting conditions (ECTTERM, EPTTERM, VREF*m*, ALTV*m*, and EPCAL) are the same for rms metering as for fundamental metering. *Figure 7.7* shows the report for Terminal T; other terminals have similar reports. *Table 7.6* shows the quantities in the secondary quantities report.

Table 7.6 Quantities in the MET SEC Report (Sheet 1 of 2)

Quantity	Description
IA, IB, IC	Terminal *w* A-Phase, B-Phase, and C-Phase in secondary current. The reference is independent of the VREF*m* settings, and is determined as follows, according to *Table 7.2*: 1. Positive-sequence voltage of PT V (if available) 2. Positive-sequence voltage of PT Z (if available, and PT V is not available) 3. Positive-sequence current of Terminal *w* (if no PTs are available) in the order specified by *Table 7.2*.
VA, VB, VC	Secondary voltage of PT *k* (*k* = V, Z) specified by the Terminal *w* voltage reference settings, VREF*m* and ALTV*m*. *Table 7.2* specifies the angle reference. The quantities are not available when PTs are connected in delta (PTCON*k* = D).
VAB, VBC, CA	Secondary voltage AB, BC, and CA line-to-line voltages for PT V. The quantities are not displayed if EPTTERM does not include Terminal V.
VAB, VBC, CA	Secondary voltage AB, BC, and CA line-to-line voltages for PT Z. The quantities are not displayed if EPTTERM does not include Terminal Z.
Frequency	Measured system frequency. The frequency specified by the NFREQ Global setting is used when the relay is not tracking the frequency.
Frequency Tracking	When the relay tracks the frequency, the report displays “Y”, and “N” when the relay cannot track the frequency.

Table 7.6 Quantities in the MET SEC Report (Sheet 2 of 2)

Quantity	Description
Battery Voltage	Measured battery voltage
Volts/Hertz	Percentage V/Hz. The quantity is not displayed if E24 = N.

```
=>>MET SEC T <Enter>

Relay 1                                      Date: 01/01/2019 Time: 06:47:23.494
Station A                                    Serial Number: 0000000000

  Secondary Meter: Terminal T

                Phase Currents                   Sequence Currents
            IA         IB         IC           I1         3I2        3I0
MAG(A,sec)    4.37       4.37       4.36         4.37       0.01       0.01
ANG(deg)    164.23     44.32     -75.60       164.32     118.41      63.71

             Phase Voltages - PT V               Sequence Voltages
            VA         VB         VC           V1         3V2        3V0
MAG(V,sec)  62.922     62.937     62.924       62.928      0.324      0.353
ANG(deg)    -0.13    -120.07     120.19        0.00     -40.24    -138.95

Line-to-Line Voltage
                    PT - V                                PT - Z
            VAB        VBC        VCA          VAB        VBC        VCA
Mag(V,sec) 108.962    108.850    109.171      109.014    108.946    109.126
ANG(deg)    29.89     -89.94     150.03        29.95     -89.95     150.03

FREQ (Hz) 59.991          Frequency Tracking = Y
VDC (V)   115.81          V/Hz      99.56%

=>>
```

Figure 7.7 MET SEC Report for Terminal T

Demand Meter

Figure 7.8 shows the Demand report with four of the available ten elements enabled (see *Thermal Demand and Rolling Demand on page 7.6 in the SEL-400 Series Relays Instruction Manual* for more information). *Table 7.7* shows the quantities in the demand metering report. See *Table 7.8* for a list of quantities that may be included in the demand metering report. See *Section 7: Metering in the SEL-400 Series Relays Instruction Manual* for a complete description of how demand metering works.

Table 7.7 Quantities in the Demand Metering Report

Quantity	Description
DM01–DM04	Four of the available ten elements (DM01–DM10 available)
Op_Qty	Displays the analog quantities selected for each enabled element (see *Table 7.8* for a list of available analog quantities)
Type	Displays the selected type (rolling demand or thermal) of demand meter for each element (see *Thermal Demand and Rolling Demand on page 7.6 in the SEL-400 Series Relays Instruction Manual* for more information)
Demand	Displays the accumulated demand and the time and date of the recording
Peak	Displays the peak demand and the time and date of the recording

Table 7.8 Demand Metering Operating Quantities (Sheet 1 of 2)

Analog Quantity	Description
Iϕ*m*RS[a, b]	60-cycle average rms current ϕ phase, Terminal *m*
Iϕ*qp*RS[b, c]	60-cycle average rms current f phase, combined Terminal *qp*
IMX*m*RS[a]	60-cycle average rms maximum phase current, Terminal *m*
IMX*qp*RS[c]	60-cycle average rms maximum phase current, combined Terminal *qp*

Table 7.8 Demand Metering Operating Quantities (Sheet 2 of 2)

Analog Quantity	Description
3I2*m*MS[a]	60-cycle average negative-sequence current angle, Terminal *m*
3I0*m*MS[a]	60-cycle average zero-sequence current angle, Terminal *m*
3I2*qp*MS[c]	60-cycle average negative-sequence current, Combined Terminals *qp*
3I0*qp*MS[c]	60-cycle average zero-sequence current, Combined Terminals *qp*

[a] m = S, T, U, W, X, Y.
[b] ϕ = A, B, C.
[c] qp = ST, TU, UW, WX.

```
=>>MET D <Enter>

Relay 1                                    Date: 01/01/2019 Time: 20:30:08.674
Station A                                  Serial Number: 0000000000

        Op_Qty     Type     Demand       Peak     Date       Time

DM01    IMXSRS     THERM      1.864      2.580 04/18/2008 23:17:10.635
DM02    IMXTRS     ROLL       2.184      2.184 04/20/2008 20:29:14.898
DM03    IMXURS     THERM      0.004      7.664 01/02/1792 03:32:27.834
DM04    IMXXRS     THERM      3.243      3.243 04/20/2008 20:30:08.536

LAST DEMAND RESET: 04/20/2008 20:24:14.615
LAST MAX DEMAND RESET: 04/15/2008 22:51:50.456

=>>
```

Figure 7.8 Demand Report With Four Elements Enabled

Synchrophasor Meter

Use the **MET PM** command to display the synchrophasor values, as shown in *Figure 7.9* (see *Synchrophasors on page 10.69* for more information).

```
=>>MET PM <Enter>

Relay 1                                    Date: 01/01/2019 Time: 12:29:09.000
Station A                                  Serial Number: 0000000000

Time Quality   Maximum time synchronization error:  >999.999 (ms)  TSOK = 0

Synchrophasors
                    VV Phase Voltages             Pos. Sequence Voltage
                 VA        VB        VC                 V1
MAG (kV)          0.003     0.007     0.010              0.005
ANG (DEG)       -84.721   147.645   125.695            -42.686

                    VZ Phase Voltages             Pos. Sequence Voltage
                 VA        VB        VC                 V1
MAG (kV)          0.000     0.000     0.000              0.000
ANG (DEG)         0.000     0.000     0.000              0.000

                    IS Phase Currents          IS Pos. Sequence Current
                 IA        IB        IC                 I1S
MAG (A)           0.178     0.371     0.462              0.042
ANG (DEG)       150.260   116.837   136.352            -47.019

                    IT Phase Currents          IT Pos. Sequence Current
                 IA        IB        IC                 I1T
MAG (A)           0.000     0.000     0.000              0.000
ANG (DEG)         0.000     0.000     0.000              0.000

                    IU Phase Currents          IU Pos. Sequence Current
                 IA        IB        IC                 I1U
MAG (A)           0.000     0.000     0.000              0.000
ANG (DEG)         0.000     0.000     0.000              0.000

                    IW Phase Currents          IW Pos. Sequence Current
                 IA        IB        IC                 I1W
MAG (A)           0.000     0.000     0.000              0.000
ANG (DEG)         0.000     0.000     0.000              0.000
```

Figure 7.9 Synchrophasor Report

```
                      IX Phase Currents          IX Pos. Sequence Current
                  IA        IB        IC                  I1X
MAG (A)            0.000     0.000     0.000               0.000
ANG (DEG)          0.000     0.000     0.000               0.000

                      IY Phase Currents          IY Pos. Sequence Current
                  IA        IB        IC                  I1X
MAG (A)            0.000     0.000     0.000               0.000
ANG (DEG)        0.000    0.000    0.000            0.000

FREQ (Hz) 60.000          Frequency Tracking = N
Rate-of-change of FREQ (Hz/s)    0.00

Digitals

PSV08  PSV07  PSV06  PSV05  PSV04  PSV03  PSV02  PSV01
  0      0      0      0      0      0      0      0
PSV16  PSV15  PSV14  PSV13  PSV12  PSV11  PSV10  PSV09
  0      0      0      0      0      0      0      0
PSV24  PSV23  PSV22  PSV21  PSV20  PSV19  PSV18  PSV17
  0      0      0      0      0      0      0      0
PSV32  PSV31  PSV30  PSV29  PSV28  PSV27  PSV26  PSV25
  0      0      0      0      0      0      0      0
PSV40  PSV39  PSV38  PSV37  PSV36  PSV35  PSV34  PSV33
  0      0      0      0      0      0      0      0
PSV48  PSV47  PSV46  PSV45  PSV44  PSV43  PSV42  PSV41
  0      0      0      0      0      0      0      0
PSV56  PSV55  PSV54  PSV53  PSV52  PSV51  PSV50  PSV49
  0      0      0      0      0      0      0      0
PSV64  PSV63  PSV62  PSV61  PSV60  PSV59  PSV58  PSV57
  0      0      0      0      0      0      0      0

Analogs

PMV49      0.000  PMV50      0.000  PMV51      0.000  PMV52      0.000
PMV53      0.000  PMV54      0.000  PMV55      0.000  PMV56      0.000
PMV57      0.000  PMV58      0.000  PMV59      0.000  PMV60      0.000
PMV61      0.000  PMV62      0.000  PMV63      0.000  PMV64      0.000

=>>
```

Figure 7.9 Synchrophasor Report (Continued)

Differential Meter

Use the **MET DIF Z1** command to see the differential operate, restraint, and percentage harmonic values for the Zone 1 differential element. When you type **MET DIF** without an argument, the report defaults to Zone 1. *Table 7.9* summarizes the quantities in the Zone 1 differential report, and *Figure 7.10* shows the Zone 1 differential element report.

Table 7.9 Quantities in the MET DIF Z1 Report

Quantity	Description
IOPA, IOPB, IOPC	Zone 1 per-unit operating current for Differential Element A, B, and C
IRTA, IRTB, IRTC	Zone 1 per-unit restraint current for Differential Element A, B, and C
IOPAF2, IOPBF2, IOPCF2	Zone 1 second-harmonic currents, expressed as a percentage of the operating current.
IOPAF4, IOPBF4, IOPCF4	Zone 1 fourth-harmonic currents, expressed as a percentage of the operating current.
IOPAF5, IOPBF5, IOPCF5	Zone 1 fifth-harmonic currents, expressed as a percentage of the operating current.
Enabled Terminals	Displays the terminals included in the Zone 1 differential calculations (based on the E87T setting)

```
=>>MET DIF Z1 <Enter>

Relay 1                                    Date: 10/23/2023 Time: 06:06:31.366
Station A                                  Serial Number: 1232969999

Differential Zone 1

Operate Currents (per unit)       Restraint Currents (per unit)
IOPA      IOPB      IOPC          IRTA      IRTB      IRTC
 1.32      1.32      1.32          3.91      3.91      3.91

2nd Harmonic Currents (percentage of IOPA, IOPB, IOPC)
IOPAF2    IOPBF2    IOPCF2
 0.08      0.09      0.01

4th Harmonic Currents (percentage of IOPA, IOPB, IOPC)
IOPAF4    IOPBF4    IOPCF4
 0.05      0.10      0.06

5th Harmonic Currents (percentage of IOPA, IOPB, IOPC)
IOPAF5    IOPBF5    IOPCF5
 0.06      0.11      0.04

Enabled Terminals:  S, T


=>>
```

Figure 7.10 Zone 1 Differential-Element Report

Use the **MET DIF Z2** command to see the differential operate and restraint values for the Zone 2 differential element. *Table 7.10* summarizes the quantities in the Zone 2 differential report, and *Figure 7.11* shows the Zone 2 differential element report.

Table 7.10 Quantities in the MET DIF Z2 Report

Quantity	Description
IOPA2, IOPB2, IOPC2	Zone 2 per-unit operating current for Differential Element A, B, and C
IRTA2, IRTB2, IRTC2	Zone 2 per-unit restraint current for Differential Element A, B, and C

```
=>>MET DIF Z2 <Enter>

Relay 1                                    Date: 10/23/2023 Time: 06:06:31.366
Station A                                  Serial Number: 1232969999

Differential Zone 2

Operate Currents (per unit)       Restraint Currents (per unit)
IOPA2     IOPB2     IOPC2         IRTA2     IRTB2     IRTC2
 1.32      1.32      1.32          3.91      3.91      3.91

Enabled Terminal: S, T


=>>
```

Figure 7.11 Zone 2 Differential-Element Report

The **MET DIF A** command shows the content from the **MET DIF Z1** command and additional information for matrix compensation, differential settings, and differential Relay Word bits. You can use this extra information during commissioning and troubleshooting. For each phase (A, B, and C), the currents for each enabled terminal (e.g., S, T) appear in a table format (see *Figure 7.12*). The left side of the table shows the primary and secondary current magnitudes, along with the corresponding phase angles. The phase angles refer to whichever terminal is listed first in the Enabled Terminals list. As described in *Differential-Element Speed and Security Features on page 5.14*, the secondary currents are divided by taps to make per-unit values before undergoing matrix compensation. The right portion of the **MET DIF A** response shows the per-unit current magnitudes (after tap compensation), as well as the per-unit magnitudes and angles after matrix compensation.

Beneath the current table, the **MET DIF A** command displays the CT connections (Y or D) for each enabled terminal, as well as the associated tap values and matrix compensation numbers (0–13). If Matrix 13 is chosen, the user-settable angle shift is displayed along with the value for zero-sequence removal setting option.

The final portion of the MET DIF A command response displays the differential Relay Word bits from the restrained differential logic (most notably 87RA, 87RB, 87RC, and 87R), as well as the Relay Word bits from the unrestrained differential logic (87UA, 87UB, 87UC, and 87U). To aid in troubleshooting, the command response also displays Relay Word bits associated with harmonic blocking.

```
=>>MET DIF A <Enter>

Relay 1                                     Date: 10/23/2023  Time: 10:05:49.490
Station A                                   Serial Number: 1232969999

Differential Zone 1

Operate Currents (per unit)       Restraint Currents (per unit)
IOPA      IOPB      IOPC          IRTA      IRTB      IRTC
 0.64      1.00      0.75          1.35      1.49      1.72

2nd Harmonic Currents (percentage of IOPA, IOPB, IOPC)
IOPAF2    IOPBF2    IOPCF2
 0.10      0.06      0.11

4th Harmonic Currents (percentage of IOPA, IOPB, IOPC)
IOPAF4    IOPBF4    IOPCF4
 0.09      0.05      0.05

5th Harmonic Currents (percentage of IOPA, IOPB, IOPC)
IOPAF5    IOPBF5    IOPCF5
 0.08      0.05      0.06

Enabled Terminals:  S, T, U

Tap and Matrix Compensation:                        Reference Terminal = S
                  Terminal Currents          Tap Comp.        Matrix Comp.
Phase A     (A,pri)    (A,sec)     (DEG)    (per unit)   (per unit)    (DEG)
 IAS        749.70       3.00       0.00        0.60         0.43      10.03
 IAT       1088.08       1.00    -119.89        0.14         0.30     -43.82
 IAU        919.90       2.00     120.08        0.80         0.61    -130.84
 Phase B
 IBS        249.91       1.00    -119.91        0.20         0.29     -86.87
 IBT       2177.47       2.00     120.07        0.29         0.36     173.45
 IBU       1380.19       3.00       0.03        1.20         0.83     136.18
Phase C
 ICS        499.33       2.00     120.10        0.40         0.49     153.82
 ICT       3268.65       3.00       0.03        0.43         0.22      49.15
 ICU        459.48       1.00    -119.91        0.40         1.01      -6.55

Compensation Settings:
CTCONS: Y     TAPS:   5.00    TSCTC: 13    TSZSR: Y   TSANG:  25.2
CTCONT: Y     TAPT:   7.00    TTCTC:  2    TTZSR: Y
CTCONU: Y     TAPU:   2.50    TUCTC:  4    TTZSR: Y

Relay Word Bits:
P87A    P87B    P87C    87RA    87RB    87RC    87R     87T_M
1       1       1       1       1       1       1       1

87UA    87UB    87UC    87U     87T_SF  87T_SFA 87T_SFB 87T_SFC
0       0       0       0       0       0       0       0

87ABK2  87BBK2  87CBK2  87XBK2  87ABK5  87BBK5  87CBK5  87QB
0       0       0       0       0       0       0       0

=>>
```

Figure 7.12 Expanded Differential-Element Report

Circuit Breaker Monitor

The SEL-487E features advanced circuit breaker monitoring. The general features of the circuit breaker monitor are described in *Section 8: Monitoring* in the *SEL-400 Series Relays Instruction Manual*. The SEL-487E supports monitoring six three-pole breakers, designated S, T, U, W, X, and Y.

Station DC Battery System Monitor

The SEL-487E automatically monitors one station battery system health by measuring the dc voltage, ac ripple, and voltage between each battery terminal and ground. See *Section 8: Monitoring* in the *SEL-400 Series Relays Instruction Manual* for a complete description of the battery monitor.

Thermal Monitor

The SEL-487E provides a thermal element based on IEEE Std C57.91-1995, IEEE Guide for Loading Mineral-Oil-Immersed Transformers. Use this element to activate a control action or issue a warning or alarm when your transformer overheats or is in danger of excessive insulation aging or loss-of-life. Capture current hourly or daily data about your transformer by using the thermal event report. The data acquisition interval is one minute, which constitutes the maximum element timing error. This very short time interval makes the element suitable for both thermal protection and control functions.

Operating Characteristic

The SEL-487E thermal element compares top-oil, Θ_{TO}, and winding hot-spot, Θ_H, temperatures against thresholds beyond which a Relay Word bit asserts. You can use these bits to alarm for overheating of the transformer. Top-oil temperature is a calculation of the transformer oil temperature, while hot-spot temperature is a calculation of the hottest point on the transformer winding. The thermal element uses top-oil temperature and hot-spot temperature to calculate the insulation aging acceleration factor, FAA, daily rate of loss-of-life, RLOL, and total loss-of-life, TLOL. For each of these quantities you can set a threshold beyond which a Relay Word bit will assert.

The thermal element operates in one of three modes, depending upon the presence or lack of measured temperature inputs:

- Measured ambient and top-oil temperature inputs
- Measured ambient temperature only
- No measured temperature inputs

If the relay receives measured ambient and top-oil temperatures, the thermal element calculates hot-spot temperature (*Figure 7.13(a)*). When the relay receives a measured ambient temperature but not a measured top-oil temperature, the thermal element calculates the top-oil temperature and hot-spot temperature (*Figure 7.13(b)*). In the absence of any measured ambient or top-oil temperatures, the thermal element uses a default ambient temperature setting (D_AMB) that you select and calculates the top-oil and hot-spot temperatures (*Figure 7.13(c)*). Regardless of the available measuring inputs, the relay always calculates the top-oil temperature for use in the cooling system efficiency element.

The SEL-487E is capable of supporting temperature inputs from 12 RTD inputs or from remote analog inputs received via IEC 61850 GOOSE messaging. The 12 RTD inputs will be obtained via an EIA-232 communications port connected to an SEL-2600. The Fast Message protocol will be used to transmit data from the SEL-2600 to the relay.

Figure 7.13 Top-Oil and Hot-Spot Temperatures

Thermal Element

Thermal Element With Ambient and Top-Oil Temperature Inputs

In this case the relay receives measured ambient and top-oil temperature inputs and uses the top-oil temperature to calculate the hot-spot temperature. Because the ambient temperature is available, the thermal event reports show the ambient temperature. For a single tank, three-phase transformer, there are as many as two thermal inputs: the ambient temperature input and the top-oil input. For independent, single-phase transformers, there normally are as many as four thermal inputs: one ambient temperature input and a top-oil input for each of the three tanks. During a fixed time interval, $\Delta t = 1$ minute, the relay calculates the winding hot-spot temperature at the end of the interval, according to *Equation 7.1*.

$$\Theta_H = \Theta_{TO} + \Delta\Theta_H$$

Equation 7.1

where:

Θ_H = winding hot-spot temperature, °C
Θ_{TO} = top-oil temperature, °C
$\Delta\Theta_H$ = winding hot-spot rise over top-oil temperature, °C

The relay calculates winding hot-spot rise over top-oil temperature, $\Delta\Theta_H$, according to *Equation 7.2*:

$$\Delta\Theta_H = (\Delta\Theta_{H,U} - \Delta\Theta_{H,i}) \bullet \left(1 - e^{\frac{-\Delta t}{60 \bullet THS}}\right) + \Delta\Theta_{H,i} °C$$

Equation 7.2

where:

$\Delta\Theta_{H,U}$ = the ultimate hot-spot rise over top-oil temperature for any load, °C
$\Delta\Theta_{H,i}$ = initial hot-spot rise over top-oil temperature at the start time of the interval, °C

THS = thermal time constant of hot spot, in hours (set from *Table 7.11*)

Δt = one-minute temperature data acquisition interval

$$\Delta\Theta_{H,U} = K^{(2 \cdot EXPM)} \cdot THGR°C$$

Equation 7.3

where:

K = load expressed in per unit of transformer nameplate rating according to the cooling system in service (phase rms current divided by the nominal current)

EXPM = winding exponent (set from *Table 7.11*)

THGR = rated winding hot-spot rise over top-oil at rated load, °C (set from *Table 7.11*)

Table 7.11 Default Transformer Constants

IEEE	Setting	THWR = 55°			THWR = 65°		
		NUMCS = 1	NUMCS = 2	NUMCS = 3	NUMCS = 1	NUMCS = 2	NUMCS = 3
$\Delta\Theta_{TO,R}$	THOR (°C)	45°	40°	37°	55°	50°	45°
$\Delta\Theta_{H,R}$	THGR (°C)	20°	25°	28°	25°	30°	35°
R	RATL	3.0	3.5	5.0	3.2	4.5	6.5
n	EXPN	0.8	0.9	1.0	0.8	0.9	1.0
$\tau_{TO,R}$	OTR	3.0	2.0	1.25	3.0	2.0	1.25
m	EXPM	0.8	0.8	1.0	0.8	0.8	1.0
τ_H	THS	0.08					

Thermal Element With Ambient Temperature Input Only

In this case the relay receives a measured ambient temperature input and uses this input to calculate top-oil and hot-spot temperatures.

Where the relay has a measured ambient temperature input without a top-oil temperature input, you have one thermal input (for ambient temperature) regardless of whether you have a single three-phase transformer or independent single-phase transformers. The relay calculates winding hot-spot temperature, Θ_H, according to *Equation 7.1*.

$$\Theta_H = \Theta_{TO} + \Delta\Theta_H$$

Equation 7.4

and calculates top-oil temperature, Θ_{TO}, according to *Equation 7.5*:

$$\Theta_{TO} = \Theta_A + \Delta\Theta_{TO}$$

Equation 7.5

where:

Θ_A = ambient temperature, °C

$\Delta\Theta_{TO}$ = top-oil rise over ambient temperature, °C

The relay calculates top-oil rise over ambient temperature according to *Equation 7.6*:

$$\Delta\Theta_{TO} := \left((\Delta\Theta_{TO,U} - \Delta\Theta_{TO,i}) \bullet \left(1 - e^{\frac{-\Delta T}{60 \bullet T_o}} \right) + \Delta\Theta_{TO,i}{}^{\circ}C \right)$$

Equation 7.6

where:

$\Delta\Theta_{TO,U}$ = the ultimate top-oil rise over ambient temperature for any load, °C, and is a function of load and the values in *Table 7.11*

$\Delta\Theta_{TO,i}$ = initial top-oil rise over ambient temperature at the start time of the interval, °C ($\Delta\Theta_{TO,i}$)

T_o = thermal top-oil time constant of transformer, in hours

$$T_o := OTR \bullet \left[\frac{\frac{\Delta\Theta_{TO,U}}{THOR} - \frac{\Delta\Theta_{TO,i}}{THOR}}{\left(\frac{\Delta\Theta_{TO,U}}{THOR}\right)^{\frac{1}{EXPN}} - \left(\frac{\Delta\Theta_{TO,i}}{THOR}\right)^{\frac{1}{EXPN}}} \right]$$

Equation 7.7

where:

OTR = thermal time constant in hours at rated load with initial top-oil temperature equal to ambient temperature (set from *Table 7.11*)

THOR = top-oil rise over ambient temperature at rated load, °C (set from *Table 7.11*)

EXPN = oil exponent (set from *Table 7.11*)

The relay calculates the ultimate top-oil rise over ambient temperature, $\Delta\Theta_{TO,U}$, according to *Equation 7.8*:

$$\Delta\Theta_{TO,U} = \left(\frac{K^2 \bullet RATL + 1}{RATL + 1} \right)^{EXPN} \bullet THOR^{\circ}C$$

Equation 7.8

where:

RATL = ratio of load loss at rated load to no-load loss (set from *Table 7.11*)

Thermal Element With No Measured Temperature Inputs

In this case, the relay uses a default ambient temperature value (D_AMB setting) that you select and calculates a hot-spot temperature and top-oil temperature. The relay calculates hot-spot temperature according to *Equation 7.9*:

$$\Theta_H = \Theta_{TO} + \Delta\Theta_H$$

Equation 7.9

and the top-oil temperature according to *Equation 7.10*:

$$\Theta_{TO} = \Theta_A + \Delta\Theta_{TO}$$

Equation 7.10

The relay has no measured ambient temperature input, so you must select an ambient temperature setting (D_AMB) for the thermal element calculation of top-oil temperature as shown in *Equation 7.11*:

$$\Theta_{TO} = D_AMB + \Delta\Theta_{TO}$$

Equation 7.11

where:

D_AMB = user-selectable default ambient temperature

Top-Oil Temperature Comparison to Indicate Cooling System Efficiency

Figure 7.14 shows the logic the relay uses to calculate the difference between the measured top-oil temperature and the calculated top-oil temperature for Transformer 1. If all probes are in order and all coefficients have been correctly chosen, you can use the element to verify the integrity of both the cooling system and the measuring devices.

Relay Word bits CSE_*x* (*x* = 1, 2, or 3) asserts when the measured top-oil temperature is greater than the calculated top-oil temperature, indicating that the cooling system (fans and/or pumps) operates below the expected efficiency.

Conversely, when the measured top-oil temperature is lower than the calculated top-oil temperature, then Relay Word bits CSCM_*x* assert, indicating wrong RTD probe selection or incorrect cooling coefficients settings.

Relay Word bit CSCM is the OR combination of the CSCM_*x* Relay Word bits, and Relay Word bit CSE is the OR combination of the CSE_*x* Relay Word bits.

Figure 7.14 Cooling System Efficiency Logic

where:[a]

T*x*CSEP = Cooling System Efficiency Pickup setting, °C
MT_OIL*x* = measured oil temperature
T*x*_OILC = calculated oil temperature
MT0*x*_OK = RTD assigned to the top-oil measurement is healthy

[a] x = 1 if TRTYPE = 1; x = 1, 2, 3 if TRTYPE = 3.

SEL-2600 Status Monitoring

The SEL-2600 message contains 2 bytes of data that report the status of the SEL-2600. One status bit reports a power supply failure, and a second bit reports a ram failure within the SEL-2600. The relay decodes the status information from the data package and asserts Relay Word bit RTDFL when either failure occurs. If the relay does not receive data from the SEL-2600 for 1.25 seconds, the relay asserts the communications failure Relay Word bit RTDCOMF. If either of these two Relay Word bits assert, the relay deassert all RTD*mm*OK Relay Word bits.

Insulation Loss-of-Life

Insulation Aging Acceleration Factor

The relay thermal element uses the hot-spot temperature to calculate an insulation aging acceleration factor, FAA, which indicates how fast the transformer insulation is aging. The relay calculates the insulation aging acceleration factor, FAA, for each time interval, Δt, as shown in *Equation 7.12*:

$$FAA := e^{\left(\frac{BFFA}{\Theta_{H,R} + 273} - \frac{BFFA}{\Theta_H + 273}\right)}$$

Equation 7.12

where:

FAA = insulation aging acceleration factor

BFFA = a design constant, typically 15000 (set from *Table 7.11*)

$\Theta_{H,R}$ = winding hot-spot temperature at rated load (95°C if THWR = 55°C, 110°C if THWR = 65°C)

THWR = average winding rise over ambient at rated load (setting)

Daily Rate of Loss-of-Life

The relay calculates daily rate of loss-of-life (RLOL, percent loss-of-life per day) for a 24-hour period as shown in *Equation 7.13*:

$$RLOL := \frac{FEQA \bullet 24}{ILIFE} \bullet 100$$

Equation 7.13

where:

RLOL = rate of loss-of-life in percent per day

ILIFE = expected normal insulation life in hours (set from *Table 7.11*)

The relay stores the RLOL value at midnight each day to provide the user with trend information on the loss of insulation life. *Equation 7.14* shows the equivalent life at the reference hot-spot temperature (95ºC or 110ºC) that will be consumed in a given time period for a given temperature cycle.

$$FEQA := \frac{\sum_{n=1}^{N} FAA_n \bullet \Delta t_n}{\sum_{n=1}^{N} \Delta t_n}$$

Equation 7.14

where:

FEQA = equivalent insulation aging factor for a total time period
n = index of the time interval
N = total number of time intervals for the time period
FAA = insulation aging acceleration factor for the time interval, Δtn
Δt = time interval (fixed at 1 minute)

$$N = \frac{24}{\left(\frac{\Delta t}{60}\right)} = \frac{1440}{\Delta t}$$

Equation 7.15

where:

Δt = time interval (fixed at 1 minute)

Because the time intervals and the total time period used in the thermal model will be constant, we can simplify the calculation of FEQA to the following:

$$FEQA := \frac{\sum_{n=1}^{N} FAA_n}{N}$$

Equation 7.16

Total Accumulated Loss-of-Life

The relay estimates the total accumulated loss of insulation life in percentage of normal insulation life by summing all of the daily RLOL values.

$$TLOL_d := (RLOL_d + TLOL$$

Equation 7.17

where:

$TLOL_d$ = total accumulated loss-of-life, TLOL
$RLOL_d$ = most recent daily calculation
$TLOL_{d-1}$ = previous TLOL

The relay stores the TLOL value at midnight each day. You can use the **THE P** command to load an initial value of TLOL into the relay.

Estimated Time to Assert TLL Alarm

Estimated time to assert TLL bit:

$$TTLt = \frac{TLOLL - TLOL}{RLOL} \bullet 24$$

Equation 7.18

where:

TLLt = estimated time to assert total loss-of-life alarm, in hours
TLOLL = total loss-of-life limit setting
TLOL = total accumulated loss-of-life, TLOL
RLOL = most recent daily rate of loss-of-life calculation

Setting Descriptions

See *Monitor Settings on page 8.8* for the prompts and defaults for these settings.

Number of Transformers (TRTYPE)

A three-phase transformer can consist of one three-phase core and coil assembly in one physical enclosure or three physically separate single-phase transformers connected externally. Set TRTYPE to either 1 for a three-phase unit, or 3 for three single-phase units.

Transformer Winding Connections (TRWCON)

If the power transformer winding associated with the thermal element (see Transformer Winding Selection (*TRWSEL*)) is delta connected OR if the CTs associated with this winding are delta connected, set TRWCON = D (delta). Set TRWCON = Y (wye) only if both the power transformer winding AND CTs are wye-connected.

With TRWCON = Y, the relay uses the measured currents for each phase in the thermal element calculations. This means for three single-phase power transformers (TRTYPE = 3), the thermal element outputs may vary between phases because the phase currents may be different. With TRWCON = D, the relay selects the highest magnitude phase current and sets the other two phase currents to that value to force a balanced condition. In this case, the thermal element outputs for three single-phase transformers will be the same, assuming that each is operating at the same cooling stage and the thermal constants are set identically.

Transformer Winding Selection (TRWSEL)

The TRWSEL setting determines which power transformer winding corresponds with the measured currents the thermal element uses for calculations. The measured currents the thermal element uses must represent either the total current in or the total current out of the power transformer (not both). TRWSEL allows selection of Windings enabled with the ECTTERM setting (S, T, U, W, X, Y, ST [two currents added together], TU, UW, or WX) to be the current for the thermal element calculations. Also see *Delta-Connected CTs on page 5.51*.

For a two-winding power transformer, CTs located on either the high-voltage or low-voltage side would provide the correct current values. You can apply the thermal element on a three-, four- or five- winding power transformer, provided that the TRWSEL setting represents the total current in or out of the power transformer (not both).

Nominal Winding Voltage (TRWNOM)

Set TRWNOM to the rated line-to-line voltage for the winding you select in the TRWSEL setting. The relay uses TRWNOM and the power transformer MVA rating (see *Cooling Stage MVA Rating (MVAcCSb) on page 7.25*) to calculate rated current. The relay then divides measured current by the rated current to determine the per-unit load current, which the relay uses in thermal element calculations.

Enable Default Transformer (EDFTC)

By setting EDFTC = Y, the relay uses the default settings shown in *Table 7.11* for the thermal calculations. When using the default settings, the following settings become unavailable: T*c*THOR*b*, T*c*HGR*b*, T*c*RATL*b*, T*c*OTR*b*, T*c*EXPN*b*, T*c*EXPM*b*, and T*c*THS ($b = c = 1–3$).

Winding Temp/Ambient Temp (THWR)

Rated winding rise over ambient temperature is the difference in degrees Celsius of the winding temperature of a transformer above the ambient temperature. The actual winding temperature will be between the top-oil and hot-spot temperature.

Most power transformers manufactured in 1977 and later are rated for a 65°C rise over ambient. Power transformers manufactured prior to 1977 can be rated for a 55°C rise over ambient. Set THWR for either 55 or 65, based on the rating of the power transformer. This setting determines which set of default transformer constants from *Table 7.11* the relay will use if EDFTC = Y.

Number of Cooling Stages (NUMCS)

Power transformers generally have a self-cooled rating and one or two stages of forced cooling. Set NUMCS to the maximum number of cooling stages associated with the monitored power transformer.

Transformer De-Energized (TRDE)

Transformer heating consists of heating resulting from transformer losses and heating resulting from load. IEEE C57.91-1995 assumes the transformer is energized and calculates an increase in oil and winding temperatures resulting from transformer losses.

Relay Word TRDE provides the thermal element a way to distinguish between the de-energized (no magnetizing current flowing) and energized stages (magnetizing current flowing). To achieve this, wire for example, a 52b (normally closed) circuit breaker auxiliary contact to input IN101 and enter the SELOGIC control equation TRDE = IN101. When IN101 asserts (circuit breaker main contacts open and the 52b auxiliary contacts closed), the thermal element considers the transformer de-energized (no magnetizing current flowing) and the ambient, top-oil, and hot-spot temperatures all have the same value.

Be sure to make up an "effective external contact" from one or more 52a or 52b contacts (from one or more breakers) indicating that all the "source" breakers are open. Failing to assign a properly configured digital input to TRDE causes the relay to consider the transformer as energized, and the top-oil and hot-spot temperatures will increase over the ambient temperature even when the power transformer is actually de-energized (in accordance with the IEEE model).

Default Ambient Temperature (D_AMB)

If the ambient temperature input is unavailable when the relay turns on, the thermal element calculates the required temperatures by using the D_AMB setting. Therefore, select a reasonable value for D_AMB, even if your data acquisition system provides measurement of the ambient temperature (near the power transformer). If your data acquisition system cannot measure ambient temperature, then the thermal element calculations always use the D_AMB value. The D_AMB setting units are degrees Celsius.

Number of RTD Inputs From the SEL-2600 (RTDNUM)

This setting is under the Port Setting Category, but is also included here for the sake of completeness. Connect the temperature devices (ambient and transformer temperatures) to an SEL-2600, and connect the SEL-2600 in turn to any one of the EIA-232 ports of the SEL-487E. The maximum number of thermal inputs is 12.

RTD Type (RTDxxTY)

These settings are under the Port Setting Category, but are also included here for the sake of completeness. Specify the type of RTD metal for each of the (*xx* = 1–12) RTD inputs.

Ambient Temperature Input (AMB_M)

Use this setting to assign one of the selected RTD or remote analog temperature inputs to the ambient temperature variable in the SEL-487E thermal model.

Top-Oil Temperature Input (Ta_OILM)

Use this setting to assign the selected temperature input to the top-oil temperature variables (*a* = 1–3) in the SEL-487E thermal model.

Default Ambient Temperature if RTD Fails (AMBRTDF)

Because remote analog values could be coming from non-SEL devices monitoring transformer temperatures, a setting is provided to deassert the Measured Ambient and Top-Oil Temperature OK status bits (MAMB_OK and MTO*n*_OK) by using a programmable (SELOGIC) setting. The settings AMB_F and T*n*OIL_F are provided for this purpose. Additionally, it is verified that the incoming remote analog values are within acceptable ranges. The ranges from RTD temperature measurement devices must be no lower than –50°C and no higher than +250°C, and so a check is made to ensure that the remote analog values fall within this same range. If either conditions (Failure Booleans are true, or range is exceeded) exist while remote analogs are being used, the respective OK status bit (MAMB_OK or MTO*n*_OK) will deassert.

In most cases, an RTD communication failure is temporary in nature or can be rectified quickly. In general, the thermal element updates the ambient temperature value once a minute, and stores this value in a buffer until the next update. If you set AMBRTDF to BUFF, then the relay uses the stored value in the buffer instead of the D_AMB setting. Because the ambient temperature changes slowly, the temperature calculations will be accurate if the RTD communication is restored quickly. When setting AMBRTDF to SET, the relay uses D_AMB setting instead of the buffered value in the thermal calculations. This setting is not available if AMB_M is set to NA, in which case AMBRTDF = SET.

Transformer Cooling Stage Activation (TaCSb)

The thermal element uses the output of SELOGIC control equations to determine which cooling stage is active, so that thermal element calculations use the correct transformer constants. Settings TRTYPE and NUMCS determine the number of SELOGIC control equations for which the relay prompts the user.

NOTE: a designates the transformer number and b designates the cooling stage.

Because the maximum number of cooling stages is three, the relay evaluates a maximum of two SELOGIC control equations to determine the particular cooling stage. Use auxiliary contacts from the fan control devices as inputs to the SEL-487E with the T*x*CS*y* SELOGIC control equations set to the corresponding digital input. For example, for a single transformer (TRTYPE = 1) with three cooling stages (NUMCS = 3), the relay prompts you to set settings T1CS2S and T1CS3S.

Assume the input from Stage 2 is connected to IN101 and the input from Stage 2 is connected to IN102. Set the two SELOGIC control equations as follows:

T1CS2S := **IN101**

T1CS3S := **IN102**

To determine the cooling stage, the relay first evaluates T1CS2S, and then T1CS3S. *Table 7.12* shows the results of the evaluation.

Table 7.12 T1CS2S and T1CS23 Evaluation

Cooling Stage	T1CS2S	T1CS3S
1	0	0
2	1	0
3	1	1

Therefore, the relay uses the values for cooling Stage 1 when both inputs are deasserted, the values for cooling Stage 2 when T1CS2S is asserted, but T1CS3S is deasserted, and the values for cooling Stage 3 when both inputs are asserted. Be sure to use contacts that assert in the correct order; if T1CS23 asserts and T1CS2S is not asserted, the relay asserts the CSALRM bit and uses cooling Stage 1 values in the thermal calculations.

Cooling Stage MVA Rating (MVAcCSb)

Range: 0.2–5000 MVA, in 0.1-MVA steps

The MVA rating for all types of transformers (TRTYPE = 1 or 3) is taken as the nameplate MVA (MVA) rating and the line-to-line kilovolt (kV) values.

Cooling Stage Constants

Top-Oil Rise Over Ambient Temperature TcTHORb

Top-oil rise over ambient temperature is the difference in degrees Celsius of the top-oil temperature of a transformer above the ambient temperature. The default values listed in *Table 7.11* are from IEEE C57.92-1981. If specific values for a particular transformer are known, you can enter values from within a range of 0° to 100°C.

Hot-Spot Conductor Rise Over Top-Oil Temperature (TcTHGRb)

Range: 0.01° to 100°C, in 0.1°C steps

Hot-spot rise over top-oil temperature is the difference in degrees Celsius of the temperature of the hottest spot on the conductor winding over the top-oil temperature. If not provided, THGR can be calculated from *Equation 7.19*:

$$\mathrm{THGR} = \mathrm{THWR} + \Theta_{\mathrm{hswr}} - \mathrm{THOR}$$

Equation 7.19

where:

THWR = average winding rise over ambient at rated load (55°C or 65°C)

Θ_{hswr} = hot-spot winding rise over average winding rise
= (10°C if THWR = 55 or 15°C if THWR = 65)

Ratio Losses (TcRATLb)

RATL is the ratio of load loss at rated load to no-load loss. The default values listed in *Table 7.11* are from IEEE C57.92-1981, Tables 2 and 4. If specific values for a particular transformer are known, you can enter values from within a range of 0.1 to 100.

Oil Thermal Time Constant (TcOTRb)

The oil thermal time constant is the time it takes the top-oil temperature rise over ambient temperature to reach 63.2 percent of the difference between final rise and initial rise during a load change. If not provided, T*c*OTR can be calculated from *Equation 7.20*:

$$\mathrm{T}c\mathrm{OTR} = \mathrm{C} \bullet \left[\frac{\mathrm{THOR}}{\mathrm{P_r}}\right]$$

Equation 7.20

where:

C = transformer thermal capacity (watt-hours/degree)
= 0.06 • (weight of core and coil assembly in pounds)
+ 0.04 • (weight of tank and fitting in pounds)
+ 1.33 • (gallons of oil)

or C = 0.0272 • (weight of core and coil assembly in kilograms)
+ 0.01814 • (weight of tank and fitting in kilograms)
+ 5.034 • (liters of oil)

$\mathrm{P_r}$ = total loss at rated load (watts)

THOR = top-oil rise over ambient at rated load

1 kilogram = 2.2046 pounds

1 gallon = 3.785 liters

Oil Exponent (TcEXPNb)

This exponent is a constant that the thermal element uses in calculating ultimate top-oil rise over ambient temperature ($\Delta\Theta_{TO}$). The default values listed in *Table 7.11* are from IEEE C57.92-1981, Tables 2 and 4. If specific values for a particular transformer are known, you can enter values from within a range of 0.1 to 5.

Winding Exponent (TcEXPMb)

This exponent is a constant that the thermal unit uses in calculating ultimate hot-spot conductor rise over top-oil temperature ($\Delta\Theta_{H}$). The default values listed in *Table 7.11* are from IEEE C57.92-1981, Tables 2 and 4. If specific values for a particular transformer are known, you can enter values from within a range of 0.1 to 5.

Hot-Spot Thermal Time Constant (TcTHS)

IEEE C57.91-1995 section 7.2.6 states that the winding time constant, τH (THS), is the time it takes the winding-temperature rise over oil-temperature rise to reach 63.2 percent of the difference between final rise and initial rise during a load change. The winding time constant may be estimated from the resistance cooling curve during thermal tests or calculated by the manufacturer by using the mass of the conductor materials.

Normal Insulation Life (TRLIFE)

IEEE C57.91-1995 suggests that normal transformer insulation life is 20.55 years or 180000 hours. You can select other values within a range of 1000–999999 hours.

Constant to Calculate FAA (TdBFFA)

IEEE C57.91-1995 section 5.2 states that B (T*d*BFFA) is an empirical constant equal to 15000. You can select other values from within a range of 0 to 100000. The thermal element uses this constant to calculate the transformer insulation aging acceleration factor (FAA).

Top-Oil Temperature Limit (TOT1, TOT2)

One of the outputs the thermal element provides is top-oil temperature. TOT1 and TOT2 determine limits for top-oil temperature. If the top-oil temperature exceeds either limit, the corresponding TOT1 or TOT2 bit asserts. Using SELOGIC control equations, you can configure the TOT*x* (*x* = 1 or 2) bits to close alarm contacts. When measured temperature inputs are available, the relay compares the TOT1 and TOT2 settings against the measured value. Should the measured value not be available (communications failure or lack of instrumentation), the relay compares the TOT1 and TOT2 settings against the calculated top-oil value.

With TRTYPE = 3 and top-oil temperatures being measured or calculated for each of the three single-phase transformers, the TOT1 or TOT2 bits assert when any of the three values exceeds a limit, as shown in *Figure 7.15*. The thermal report shows which transformer exceeded the limits.

Figure 7.15 Oil Temperature Logic

Hot-Spot Temperature Limit (HST1, HST2)

One of the outputs the thermal element provides is hot-spot temperature. HST1 and HST2 determine limits for hot-spot temperature. If the hot-spot temperature exceeds one of these limits, the corresponding HS1 or HS2 bit asserts, as shown in *Figure 7.16*. Using SELOGIC control equations, you can configure these bits to close alarm contacts.

With TRTYPE = 3 and hot-spot temperatures being calculated for each of the three single-phase transformers, the HST1 or HST2 bits assert when any of the three values exceeds the limits. The thermal report shows which transformer exceeded the limits. *Figure 7.16* shows the oil temperature and hot-spot logic.

Figure 7.16 Hot-Spot Logic

Aging Acceleration Factor Limits (FAAL1, FAAL2)

The insulation of a transformer operating at temperatures higher than the rated temperature ages faster than the same transformer operating at or below rated temperature. One of the outputs the thermal element provides is a transformer insulation aging acceleration factor, which, when multiplied by elapsed time, provides an indication of the how fast the insulation is aging at the present load and temperature. Should load and temperature be greater than normal, this factor is greater than 1. Should load and temperature be less than normal, the factor is less than 1. FAAL1 and FAAL2 determine limits for the aging acceleration factor. If the aging acceleration factor exceeds the limits, the FAA1 or FAA2 bit asserts, as shown in *Figure 7.17*. Using SELOGIC control equations, you can configure these bits to close alarm contacts.

With TRTYPE = 3 and aging acceleration factors being calculated for each of the three single-phase transformers, the FAA1 or FAA2 bit asserts when any of the three values exceeds the limits. The thermal report will show which transformer was above the limits.

Figure 7.17 Aging Acceleration Factors Logic

Daily Rate of Loss-of-Life Limit (RLOLL)

One of the outputs the thermal element provides is daily rate of loss-of-life. This output is a measure, in percent, of the life lost from the transformer during a 24-hour period. RLOLL determines a limit for daily rate of loss-of-life. If the daily rate of loss-of-life exceeds the limit, a RLLOL bit asserts, as shown in *Figure 7.18*. Using SELOGIC control equations, you can configure the RLOLL bit to close an alarm contact. With TRTYPE = 3 and daily rate of loss-of-life being calculated for each of the three single-phase transformers, the RLL bit asserts when any of the three values exceeds the limit. The thermal report will show which transformer exceeded the limit.

Figure 7.18 Daily Rate of Loss-of-Life Logic

Total Loss-of-Life Limit (TLOLL)

Range: 0.00–99.99%, in 0.01% steps

One of the outputs the thermal element provides is total loss-of-life, which is an estimate of the accumulated loss of transformer insulation life as a percentage of normal expected transformer insulation life. TLOLL determines a limit for total loss-of-life. If the total loss-of-life exceeds the limit, a TLL bit asserts, as shown in *Figure 7.19*. Using SELOGIC control equations, you can configure the TLL bit to close an alarm contact. With TRTYPE = 3 and aging acceleration factors being calculated for each of the three single-phase transformers, the TLL bit asserts when any of the three values exceeds the limit. The thermal report will show which transformer exceeded the limit.

Figure 7.19 Total Loss-of-Life Logic

Preload Total Loss-of-Life Limit (TxTLOL)

Because many transformers have been in service for many years, use the preload setting to set an estimated loss-of-life value. This value is usually difficult to estimate because the operating conditions (load current and ambient temperature) for the preload time period are not recorded. Do not use current alone as a guideline; temperature as well as current affects insulation aging.

Cooling System Efficiency Pickup (TxCSEP)

When a measured top-oil temperature is available via the serial port, measured currents are used to determine a calculated top-oil temperature. If the measured top-oil temperature is greater than the calculated top-oil temperature by the value of setting T*x*CSEP (*x* = 1–3), then a Cooling System Efficiency, T*x*CSEP, asserts. Using SELOGIC control equations, the T*x*CSEP bit can be configured to any of the relay outputs to perform alarm or tripping functions. Assertion of the T*x*CSEP bit indicates that the cooling system (fans and/or pumps) is operating below expected efficiency and may require maintenance. With TRTYPE = 3 and

cooling system efficiency being calculated for each of the three single-phase transformers, the CSE bit is set when any of the three values exceeds the limit. The thermal report will show which transformer was above the setting.

Thermal Element Condition

Figure 7.20 shows the logic that reports on the overall thermal health of the transformer by generating four status messages in relation to Normal, Warning 1, Warning 2, and Warning 3. These four messages are composed from various Thermal Element Conditions (TEC), and grouped into three alarm categories, in relation to Level 1, Level 2, and Level 3 alarms. *Figure 7.20* shows the reporting process for Transformer 1 (similar logic for Transformers 2 and 3), starting with the three alarm levels, the assessment of these levels, and the generation of the warning messages (see *Table 7.13*).

Figure 7.20 Thermal Condition (TEC) Logic for Transformer 1

Table 7.13 shows values for analog quantity TEC_1 for various combinations of the three input levels. If all three levels are deasserted, then the TEC_1 value is 1, and the message is "Normal". If any of the Level 1 alarms assert and no alarms from either Level 2 or Level 3 assert, then the value of TEC_1 is 2, and the message is "Warning 1". Likewise, if only Level 2 alarm(s) assert, TEC_1 has a value of 4, and the message is "Warning 2", and if only Level 3 alarm(s) assert, TEC_1 has a value of 8, and the message is "Warning 3". Should Level 1 and Level 2 alarms assert at the same time, Warning 2 has preference over Warning 1; if Level 2 and Level 3 alarms assert at the same time, then Warning 3 has preference over Warning 2.

Table 7.13 Default Transformer Constants

Level 3	Level 2	Level 1	TEC_1	Message
0	0	0	1	Normal
0	0	1	2	Warning 1
0	1	0	4	Warning 2
0	1	1	4	Warning 2
1	0	0	8	Warning 3
1	0	1	8	Warning 3
1	1	0	8	Warning 3
1	1	1	8	Warning 3

While the SEL-487E Relays can communicate directly with the SEL-2600A for gathering temperature readings, some applications may use the SEL-2030 communications processor for retrieving the temperature data from the SEL-2600A.

The SEL-487E obtains temperature information via one of its serial ports. The relay may receive data from as many as four temperature transducers: a single ambient temperature transducer and one transducer for top-oil temperature from each of three single-phase transformers. These data could come from an SEL-2032 or an SEL-2030 Communications Processor, which receives the temperature data from either an SEL-2600A RTD Module or a PLC (see *Figure 7.21*). The SEL communications processor must receive the temperature data in Modbus, SEL Fast Messaging, or ASCII protocol. The SEL communications processor passes these data on to the SEL-487E in the form of an SEL Fast Message. While the SEL-487E can receive temperature data at any rate, the thermal element uses these data only once a minute.

Please refer to SEL Application Guide AG2000-07, *Connection and Configuration of an SEL Communications Processor and an SEL-2600A to Obtain Measured Ambient and Top-Oil Temperatures for the SEL-387-6 Relay Thermal Element*, and Application Guide AG2006-05, *SEL Communications Processor and an SEL-2410 I/O Processor to Obtain Measured Ambient and Top-Oil Temperatures for the SEL-387-6 Relay Thermal Element*, for information about how to set the SEL communications processor to communicate with the SEL-2600A RTD Module and the SEL-487E.

Figure 7.21 Example System Block Diagram

Thermal Monitor Report

The **THERM** or **THE** command, with no additional parameters, displays the present thermal status of the transformer(s) monitored by the relay. If an alarm condition is detected (one or more of the thermal Relay Word bits are set), the relay saves a snapshot of the thermal status of the transformer to EEPROM. The format for the **THE** report is as follows:

```
=>>THE <Enter>

Relay 1                                      Date: 03/28/2008  Time: 02:12:44.594
Station A                                    Serial Number: 2008030645

                                 Transformer 1 Transformer 2 Transformer 3
      Thermal Element Condition : NORMAL     NORMAL      NORMAL
                 Load(Per Unit) :0.81        0.83        0.81
       In Service Cooling Stage :1           1           1
                Ambient (deg. C) :20.0       20.0        20.0
    Calculated Top Oil (deg. C) :25.4        26.1        25.7
      Measured Top Oil (deg. C) :46.6        46.9        46.1
      Winding Hot Spot (deg. C) :55.4        56.8        55.1
 Aging Acceleration Factor, FAA :0.00        0.00        0.00
             Rate of LOL (%/day) :0.00       0.00        0.00
      Total Accumulated LOL (%) :0.00        0.00        0.00
          Time-Assert TLL (hrs) :0.00        0.00        0.00
=>>
```

Thermal Event Report Quantities

Thermal Element Conditions

The load condition value can be Normal, Warning 1, Warning 2, or Warning 3. See *Table 7.13* for more information.

Load Current

The load current is reported as a per-unit value based on transformer rating.

In-Service Cooling Stage

The active cooling system value is 1 for Cooling Stage 1, 2 for Cooling Stage 2, and 3 for Cooling Stage 3. Only one of the cooling stages can be active at a time (see *Transformer Cooling Stage Activation (TaCSb) on page 7.25* for more information).

Ambient Temperature

The value displayed (in degrees Celsius) is either the actual ambient temperature received from the serial port or a stored value (see *Default Ambient Temperature (D_AMB) on page 7.24* and *Default Ambient Temperature if RTD Fails (AMBRTDF) on page 7.24* for more information).

Calculated Top-Oil Temperature

The value displayed (in degrees Celsius) is the top-oil temperature of the transformer computed by using the load current.

Measured Top-Oil Temperature

The value displayed (in degrees Celsius) is the top-oil temperature of the transformer received from the serial port. If no data (or invalid data) are received from the serial port, the value displayed is `-0-`.

Winding Hot-Spot Temperature

The value displayed (in degrees Celsius) is the computed value of the winding hot-spot temperature by using the actual ambient and top-oil temperatures or the load current.

Aging Acceleration Factor

The value displayed is the active insulation aging acceleration factor (FAA). The maximum value of FAA is limited to 9999.0.

Rate of Loss-of-Life

The value displayed is the computed daily rate of loss-of-life (percent) accumulated in a 24-hour period. This value is updated at midnight daily.

Total Loss-of-Life

The value displayed represents the total accumulated loss-of-life (percent) since last reset.

Time to Assert TLL

The value displayed represents the estimated time (in hours) to assert the total loss-of-life alarm (TLL Relay Word bit).

Thermal Event Report (THE n Command)

Whenever a thermal alarm condition is set (load conditions are Warning 1, Warning 2, or Warning 3), the SEL-487E saves a snapshot of the thermal status of the transformer(s) in EEPROM. The five most recent thermal events are saved. If the command for retrieving the *n*th saved thermal event report is **THE *n*** (where *n* = 1–5), **THE 1** will display the most recent event report while **THE 5** will display the oldest thermal event report. The format and data for the **THE *n*** report are the same as for the **THE** report.

Thermal Profile Data Report (THE H and THE D Commands)

The SEL-487E stores two types of trend data: one set on an hourly basis for the last 24 hours, and one set on a daily basis for the last 31 days. The format of the retrieved data report is suitable for display in Microsoft Excel.

Hourly Profile Data Report (THE H Command)

NOTE: When the thermal model is applied on one three-phase transformer (TRTYPE = 1), the SEL-487E displays only the values for Transformer 1. When the thermal model is applied on a set of three single-phase transformers (TRTYPE = 3), the SEL-487E displays the values for Transformer 1, Transformer 2, and Transformer 3.

The SEL-487E stores the following data on an hourly basis for the last 24 hours. The data are stored at the beginning of each hour.

- One-hour average ambient temperature
- One-hour average calculated top-oil temperature
- One-hour average measured top-oil temperature
- One-hour average winding hot-spot temperature
- One-hour average per-unit load current
- One-hour average insulation aging acceleration factor (FAA)

The format for the **THE H** report is as follows:

```
=>>THE H <Enter>

Relay 1                                    Date: 03/28/2008  Time: 02:36:09.634
Station A                                  Serial Number: 2008030645

Transformer 1
                    Ambient   Calc      Measured                Load
Date        Time  Temp      Top Oil   Top Oil   Hot Spot    Current    FAA
03/16/2008  2300     0.0      25.2     25.0       25.2         0.80    0.99
03/15/2008  2200     0.0      25.1     25.0       25.1         0.70    0.99

Transformer 2
                    Ambient   Calc      Measured                Load
Date        Time  Temp      Top Oil   Top Oil   Hot Spot    Current    FAA
03/16/2008  2300     0.0      24.2     25.6       25.2         0.80    0.99
03/15/2008  2200     0.0      24.1     25.6       25.1         0.70    0.99

Transformer 3
                    Ambient   Calc      Measured                Load
Date        Time  Temp      Top Oil   Top Oil   Hot Spot    Current    FAA
03/16/2008  2300     0.0      24.8     25.2       25.2         0.80    0.99
03/15/2008  2200     0.0      24.9     25.3       25.1         0.70    0.99

=>>
```

Daily Profile Data Report Function (THE D Command)

The relay stores the following on a daily basis (at midnight) for the last 30 days:

- Maximum ambient temperature
- Maximum calculated top-oil temperature
- Maximum measured top-oil temperature
- Maximum winding hot-spot temperature
- Maximum per-unit load
- Maximum insulation aging acceleration factor (FAA)
- Daily 24-hour accumulated loss-of-life (value of accumulated 24-hour loss-of-life at midnight)
- Total accumulated loss-of-life (sum of the daily 24-hour accumulated loss-of-life values)

The format for the **THE D** report is as follows:

```
=>>THE D <Enter>

Relay 1                                    Date: 03/28/2008  Time: 02:43:48.623
Station A                                  Serial Number: 2008030645

Transformer 1
         Max     Max Calc Max Msd  Max
Date     Ambient Top Oil  Top Oil  Hot Spot  Max Load  Max FAA  RLOL   TLOL
03/28/2008  15.0    25.3    26.7    45.3      0.60      0.99    0.00    0.00

Transformer 2
         Max     Max Calc Max Msd  Max
Date     Ambient Top Oil  Top Oil  Hot Spot  Max Load  Max FAA  RLOL   TLOL
03/28/2008  15.0    25.9    27.7    44.3      0.60      0.99    0.00    0.00

Transformer 3
         Max     Max Calc Max Msd  Max
Date     Ambient Top Oil  Top Oil  Hot Spot  Max Load  Max FAA  RLOL   TLOL
03/28/2008  15.0    25.7    26.5    43.4      0.60      0.99    0.00    0.00

=>>
```

Retrieving Thermal Data Reports

Thermal data reports are accessed with the **THE** command as shown in *Table 7.14*.

Table 7.14 Using the THE Command to Access Data Reports

Example THE Serial Port Commands	Format
THE	Enter **THE** command with no additional parameters to display the present status of the monitored transformer.
THE 1	Enter **THE** command followed by a number (1 in this example) to display the latest archived thermal event report.
THE D	Enter **THE** command followed by **D** and no additional parameters to display all available daily profile data records.
THE H	Enter **THE** command followed by an **H** but with no additional parameters to display all available hourly profile data records. The chronological progression through the report is down the page and in descending order.
THE H (or **D**) **3/30/00**	Enter **THE H** (or **D**) followed by the date (**3/30/00** in this example) to display all records (if they exist) starting with that date and ending with the present date. The records display with the latest record at the beginning (top) of the report and the oldest record at the end (bottom) of the report. Chronological progression through the report is down the page and in descending order.
THE D (or **H**) **2/17/00 3/07/00**	Enter **THE D** (or **H**) followed by two dates (**2/17/00** chronologically *precedes* **3/07/00** in this example) to display all the records (if they exist) among (and including) those dates. The records display with the latest record (3/07/00) at the beginning (top) of the report and the oldest record (2/17/00) at the end (bottom) of the report.
THE D 3/07/00 2/17/00	Enter **THE D** (or **H**) followed by two dates (**3/07/00** chronologically *follows* date **2/17/00** in this example) to display all records (if they exist) among (and including) those dates. The records display with the latest record (3/07/00) at the beginning (top) of the report and the oldest record (2/17/00) at the end (bottom) of the report.

The date entries in the examples for the **THE H** and **THE D** commands are dependent on the Date Format setting DATE_F. If setting DATE_F = MDY, enter the dates as in the above examples (Month/Day/Year). If setting DATE_F = YMD, enter the dates Year/Month/Day.

If the requested **THE** hourly or daily profile records do not exist, the relay responds: Invalid Record. If there are no data in the hourly or daily profile buffers, the relay responds: `No Data Available`.

Thermal Monitor Reset (THE R and THE P Commands)

The **THE R** (Reset Thermal Function) command clears all the thermal archives (daily profile data, hourly profile data, and thermal event data) and resets the total accumulated loss-of-life value to its preset value (if it exists) or zero. Using the **THE P *n*** (Load Preset Value of Total Loss-of-Life) command, the user can preset the initial loss-of-life values for each phase of the monitored transformer. The command must be followed by a value between zero and 100 percent. This command initializes the total loss-of-life value to the preset value entered by the user, clears all the thermal archive data, and restarts the thermal element.

Through-Fault Monitor

Operating Characteristic

Figure 7.22 shows a though-fault, which is a fault that occurs outside the area of unit protection of the transformer. Through-fault damage to the transformer is cumulative and results from both thermal and mechanical effects, with mechanical stress being much more damaging than thermal stress to transformer insula-

tion for sustained or frequent faults. To this end, the though-fault element calculates the cumulative stress on the transformer, taking into account both mechanical and thermal effects.

Figure 7.22 Transformer Bank Subjected to Through Fault

Figure 7.23 shows through-fault curves for Category IV transformers as published in IEEE C57 (1994 edition). These curves apply to transformers that are covered by the IEEE standard or, in general, to transformers that were built beginning in the early 1970s. For transformer built prior to 1970, consult the manufacturer to obtain the transformer short-circuit withstand capabilities.

Figure 7.23 Category IV Transformers Through-Fault Protection Curves

The curves in *Figure 7.23* are a function of the transformer short-circuit impedance, and is keyed to the maximum I^2t of the worst-case mechanical duty (maximum fault current for 2 seconds). *Equation 7.21* through *Equation 7.23* show how the element uses the measured current and nameplate data to set parameters for the accumulator shown in *Figure 7.24*. To convert the secondary current to primary current, the element multiplies the secondary current by the CT ratio of the particular terminal. For combined terminals, the elements uses the highest CT ratio of the two terminals (see *Delta-Connected CTs on page 5.51*).

$$I_{RMS_PU} = \frac{I_{RMS} \bullet \sqrt{3} \bullet kV_{LL}}{MVA}$$

Equation 7.21

$$I_{MAX_PU} = \frac{100}{Z_{PU}}$$

Equation 7.22

$$K =$$
$$1250 \text{ if: } I_{RMS_PU} \leq 0.5 \bullet I_{MAX_PU}$$
$$2 \bullet (I_{MAX_PU})^2 \text{ if: } I_{RMS_PU} > 0.5 \bullet I_{MAX_PU}$$

Equation 7.23

where:

I_{RMS} = Measured current
MVA = Transformer MVA setting
kV_{LL} = Line-to-line voltage setting, VTERM*m*
Z_{PU} = Transformer per unit impedance setting, TRFRZ

There are only five settings to set the through-fault element, all under the Monitor category (see *Table 8.23*). Enable the element by setting the SELOGIC control equation ETHRFLT for the conditions under which you want to enable the element. Use Setting THFLTD to select the terminal that you want the element to use when calculating the through-fault current. (Switch S1 in *Figure 7.24* selects one of S, T, U, W, X, Y, ST, TU, UW, or WX.) Be sure to select a terminal that is included in the ECTTERM setting. Set the through-fault alarm pickup (THFLTPU) to the desired value, and enter the transformer percentage impedance (in percent) at the TRFRZ setting.

NOTE: The through-fault monitor is designed to work in conjunction with the Zone 1 differential element and shares several settings, such as MVA and VTERMm.

Set the through-fault current pickup setting (TFLTIPU) based on the ratio of measured rms current of the THFLTD terminal to transformer full-load current that is required to qualify a through-fault condition. The relay automatically calculates the transformer full-load current for the selected terminal by using the nominal terminal voltage and transformer MVA (established by the VTERM*m* and MVA settings, respectively). When the ETHRFLT SELOGIC control equation evaluates as logical 1, and the ratio of the measured rms current to transformer full-load current exceeds the TFLTIPU setting, the relay begins running the through-fault logic. The through-fault logic stops running when the rms current falls below 0.95 • TFLTIPU times the full-load current.

Figure 7.24 shows a functional diagram of the through-fault element for the A-Phase of Terminal S (THFLTD = S), the B-Phase and C-Phase elements having identical diagrams. When SELOGIC control equation ETHRFLT asserts and the A-Phase current exceeds TFLTIPU times the transformer full-load current, Enable asserts and the 10-cycle Timer starts. When Enable asserts, the following occur:

- The through-fault element advances the A-Phase fault counter by 1 count
- The through-fault element advances the total fault counter by 1 count
- The through-fault element records the time when the fault starts (rising edge of Enable)

- The process to determine the maximum through-fault current for the fault duration starts
- The integration process starts, whereby the element sums the values calculated each processing interval (1/8 of a power system cycle)

Figure 7.24 Through-Fault Diagram

The 10-cycle Timer avoids the inadvertent increment of the counters or archiving of the data if the fault current momentarily drops below the lower threshold level.

Setting threshold THFLTPU would usually be set to alarm for excessive, cumulative transformer bank stress. When the integration exceeds the value as specified by the THFLTPU setting, Relay Word bit TFLTALA asserts. Assign output Relay Word bit TFLTALA to an output for annunciation or control action such as to modify distribution feeder autoreclosing (e.g., reduce the number of reclosures from 3 to 2).

When the fault current falls below 0.95 • TFLTIPU times the full-load level, the element deasserts, and the following occurs:

- The through-fault element records the stop time; then calculates (and records) the fault duration.
- The through-fault element records the maximum value of the fault current during the fault.
- The integration process stops.

The relay can store (archive) the data of 1200 through faults in a first-in-first-out (FIFO) buffer. The element automatically archives the data when one of the following conditions is true:

- The 10-cycle timer deasserts and the enable signal is deasserted.
- The 10-cycle timer is deasserted and the enable signal deasserts.

Through-Fault Monitor Reports

The format of the **TFE** command is as follows: **TFE *nnnn* A|P|C**

where:

nnnn = Specifies number of through faults to display

A = The relay displays all the Through Fault Records in the memory

P = Use to specify preloading

C = Sets the accumulated values to 0 and deletes the history

Figure 7.25 displays the relay response to the **TFE** (no other parameters) command. Notice that Winding S is the terminal whose current inputs the element uses in the calculations (THFLTD = S). The **TFE** command lists as many as 20 of the most recent through-faults. "Total Number of Transformer Through Faults" is the sum of the detected through faults of all three phases since the last reset, with a maximum of 65,535 counts. "Number of *n* Phase Through Faults" (*n* = A, B, C) refers to the through faults detected for that particular phase since the last reset, also with a maximum of 65,535 counts. The through-fault alarm state is either a 1 (indicating an alarm state), or a 0 (indicating a normal state).

```
=>TFE <Enter>

Winding S
Total Number of Transformer Through Faults:   5
Total Number of A Phase Through Faults:       3
Total Number of B Phase Through Faults:       1
Total Number of C Phase Through Faults:       1

Total Accumulated Percentage of Through Fault Capability:
                                    A-Phase      B-Phase      C-Phase
                                     26.45        12.34        11.78
Through Fault Alarm:   <0>          <0>          <0>

Last Reset: 11/12/07 12:15:23

#      Date           Time                 Duration       IA     IB     IC             A     B      C           Alarm
                                                      (seconds)  (max primary kA)       (Increment %)
xxxx mm/dd/yy hh:mm:ss.sss   sss.sss+   xxx.xx  xxx.xx  xxx.xx      xxx.x xxx.x xxx.x      <alarm>
xxxx mm/dd/yy hh:mm:ss.sss   sss.sss+   xxx.xx  xxx.xx  xxx.xx      xxx.x xxx.x xxx.x      <alarm>
xxxx mm/dd/yy hh:mm:ss.sss   sss.sss+   xxx.xx  xxx.xx  xxx.xx      xxx.x xxx.x xxx.x      <alarm>
xxxx mm/dd/yy hh:mm:ss.sss   sss.sss+   xxx.xx  xxx.xx  xxx.xx      xxx.x xxx.x xxx.x      <alarm>
```

Figure 7.25 Result of the TFE Command

Following is a description of each column (#, Date, Time, etc.) of the event report. Through-fault events are numbered (# column) from 1 (the most recent event, at the top) to a maximum of 1200 through-fault events.

Under the date and time columns, the event shows the date of occurrence and the start time of each event (the date format dependents upon the DATE_F setting).

Although the element processes all values each cycle, event duration (Duration column) is reported in seconds with processing interval resolution (if the event duration is equal to or greater than 136 seconds (60 Hz) or 163 seconds (50 Hz), the element appends a "+" to the time value).

IA, IB, and IC show the maximum primary current for each phase, with a maximum of 100,000 A primary.

A, B, and C show the amount (percent increase) of the present fault for each phase. Alarm shows those phase(s) that were in the alarm state at the end of the through-fault event.

Table 7.15 shows events report messages and the reason why these messages may appear in the events report.

Table 7.15 Through-Fault Events Report Messages

Message	Cause
Invalid Data	The accumulated data are corrupt.
Through Fault Event Monitor Disabled	ETHFLTM = N, ETHRFLT = NA, ETHRFLT evaluates to 0, or MVA = OFF.
Too many events—Data Lost	The memory is full.
Through Fault Event Buffer Empty	There are no event records in the nonvolatile memory.
Memory resources are low; check for activity on other ports	There is insufficient memory to display the event records.

Use the **TFE A** command to list all the stored through-fault events (not only the last 20 events) since the monitor was last reset. To list a particular number of through-fault events, enter the **TFE *n*** command (*n* = 1 to 1200).

To clear event accumulated data, and all event records, use the **TFE C** command. Note that when you change the ETHRFLT setting, the relay also clear the data and records, i.e., it has the same effect as the **TFE C** command.

Use the **TFE P** command to preload or change the values of the through fault event accumulated data, as shown in *Figure 7.26*. Enter these values in percent for each phase, up to a maximum value of 100.0 percent.

```
Winding S Total Accumulated Percentage of Through Fault Capability:
A-Phase = xxx.x? yyy.y
B-Phase = xxx.x? yyy.y
C-Phase = xxx.x? yyy.y
```

Figure 7.26 Preload the Values of the Accumulated Data

Analog Signal Profiling

Use the analog signal profiling function to record and track values of as many as 20 analog quantities. This function provides data in CASCII that is compatible to import directly into applications like spreadsheets. Specify the specific analog quantities for profiling with the SPAQ Report settings.

At the data acquisition rate of 5 minutes, the SEL-487E stores at least 10 days of all analog signals selected for profiling in nonvolatile memory. The report includes the time of acquisitions and the magnitude of each selected analog quantity. By defining conditions in the signal profiling enable SELOGIC variable setting (SPEN), you can record analog values at particular periods or conditions of interest.

SPAQgg (Analog Quantities for Signal Profiling)

Enter any analog quantity available in the relay from the Analog Quantity list (see *Section 12: Analog Quantities*) in this freeform setting.

SPAR (Signal Profile Acquisition Rate)

NOTE: The signal profile update rate does not have an immediate effect. For example, if SPAR is set to update every 60 minutes, then changed to 1 minute, the original timer will expire before the new rate takes effect.

Although you can select as many as 20 analog quantities, the signal acquisition rate is the same for all analog quantities. Select an acquisition rate of 1, 5, 15, 30, or 60 minutes.

SPEN (Signal Profile Enable)

Use this SELOGIC control equation to specify conditions under which the profiling must take place. If there are no conditions, be sure to set SPEN = 1, else no data are recorded (default value of NA disables the function).

Use the Compressed ASCII **CPR** command to view the profile data, as shown in *Figure 7.27*.

```
=>>CPR <Enter>
"#","DATE","TIME","VA_MAG","VB_MAG","VC_MAG","AI301","AI302","AI303","AI304","AI
305","AI306","13D7"
1,"01/01/2019","04:20:51.603",20.000,25.769,15.811,0.020,0.027,0.032,0.034,0.054
,0.045,"1066"

=>>
```

Figure 7.27 Compressed ASCII Data Display

Because the data are optimally formatted for machine-to-machine compatibility, use software such as Excel to display the profile data. *Figure 7.28* shows the data from *Figure 7.27* after importing the data (comma-delimited) into an Excel spreadsheet.

J17 =

	A	B	C	D	E	F	G	H	I	J	K	L	M
1													
2	□"#"	DATE	TIME	VA_MAG	VB_MAG	VC_MAG	AI301	AI302	AI303	AI304	AI305	AI306	13D7
3	1	3/17/2005	10:51.6	9.52	10	2.795	0.02	0.028	0.032	0.034	0.054	0.045	1000
4	2	3/17/2005	05:51.6	9.52	10	2.795	0.02	0.028	0.032	0.034	0.054	0.045	100C
5	3	3/17/2005	00:51.7	9.52	10	2.795	0.02	0.028	0.032	0.034	0.054	0.045	1005
6	□												
7	□=>>□												

Figure 7.28 Profile Data in Excel Spreadsheet

Use the **PRO C**(lear) command to clear all profile data, as shown in *Figure 7.29*.

```
=>>PRO C <Enter>
Reset All Profile Data (Y,N)? Y <Enter>
Reset Complete

=>>
```

Figure 7.29 Profile Data Reset

Reporting

The SEL-487E features comprehensive power system data analysis capabilities. These are described in *Section 9: Reporting in the SEL-400 Series Relays Instruction Manual*. This section describes reporting characteristics that are unique to the SEL-487E.

Duration of Data Captures and Event Reports

The SEL-487E stores high-resolution raw data and filtered data. The number of stored high-resolution raw data captures and event reports is a function of the amount of data contained in each capture.

Table 7.16 lists the maximum number of data captures/event reports the relay stores in nonvolatile memory when ERDIG = S for various report lengths and sample rates. The relay automatically overwrites the oldest events with the newest events when the nonvolatile storage capacity is exceeded.

NOTE: Consider the total capture time when choosing a value for setting LER at the SRATE := 8 kHz. At LER := 3.0, the relay records at least 12 data captures when ERDIG = S. These and smaller LER settings are sufficient for most power system disturbances.

The relay stores high-resolution raw and filtered event data in nonvolatile memory. *Table 7.16* lists the storage capability of the SEL-487E for common event reports.

The lower rows of *Table 7.16* show the number of event reports the relay stores at the maximum data capture times for each SRATE sampling rate setting. Table entries are the maximum number of stored events; these can vary by 10 percent according to relay memory usage.

NOTE: Sampled Values (SV) subscriber relays receive analog data at 4 kHz or 4.8 kHz depending on the global setting NFREQ. Event reports with SRATE := 8kHz have been up-sampled from the received data rate.

Table 7.16 Event Report Nonvolatile Storage Capability When ERDIG = S

Event Report Length	Maximum Number of Stored Reports			
	8 kHz	4 kHz	2 kHz	1 kHz
0.25 seconds	96	119	135	153
0.5 seconds	59	76	89	106
1.0 seconds	32	44	53	66
3.0 seconds	12	16	20	26
6.0 seconds	N/A	8	10	13
12.0 seconds	N/A	N/A	5	7
24.0 seconds	N/A	N/A	N/A	3

When the event report digital setting is set to include all Relay Word bits in the event report (ERDIG = A), the maximum number of stored reports is reduced, as shown in *Table 7.17*.

Table 7.17 Event Report Nonvolatile Storage Capability When ERDIG = A

Event Report Length	Maximum Number of Stored Reports			
	8 kHz	4 kHz	2 kHz	1 kHz
0.25 seconds	71	83	91	98
0.50 seconds	40	49	54	60
1.0 seconds	N/A	27	30	33
3.0 seconds	N/A	N/A	10	12
6.0 seconds	N/A	N/A	N/A	5
12.0 seconds	N/A	N/A	N/A	N/A
24.0 seconds	N/A	N/A	N/A	N/A

Event Reports, Event Summaries, and Event Histories

See *Section 9: Reporting in the SEL-400 Series Relays Instruction Manual* for an overview of event reports, event summaries, and event histories. This section describes the characteristics of these that are unique to the SEL-487E.

Base Set of Relay Word Bits

The following Relay Word bits are always included in COMTRADE event reports: TLED_1–TLED_24, 87R, 87RA, 87RB, 87RC, P87A, P87B, P87C, 87PQ, 87Q, 87T_M, RMB1A–RMB8A, TMB1A–TMB8A, RMB1B–RMB8B, TMB1B–TMB8B, ROKA, RBADA, CBADA, LBOKA, ANOKA, DOKA, ROKB, RBADB, CBADB, LBOKB, ANOKB, DOKB, TRS, TRT, TRU, TRW, TRX, TRY, TRXFMR, CLS, CLT, CLU, CLW, CLX, CLY, 52CLS, 52CLT, 52CLU, 52CLW, 52CLX, 52CLY, 52ALS, 52ALT, 52ALU, 52ALW, 52ALX, 52ALY.

COMTRADE Relay Word Bit Behavior

The ERDG setting specifies Relay Word bits to include in event reporting. In COMTRADE files, the relay captures and records the status of all Relay Word bits in the same row of a Relay Word bit specified in the ERDG setting list. Therefore, additional Relay Word bit statuses is captured in a COMTRADE file that are not specified in the ERDG setting list. See *Section 11: Relay Word Bits* for Relay Word bits and their common row with other bits.

Event Reports

Report Header Section of the Event Report

The first portion of an event report is the report header. See *Figure 7.30* for the location of items included in a sample fixed analog section of an event report.

The report header is the standard SEL-487E header listing the relay identifiers, date, and time. Report headers help you organize report data. Each event report begins with information about the relay and the event, such as the RID setting (Relay ID), the SID setting (Station ID), and the firmware checksum (CID). The FID string identifies the relay model, flash firmware version, and the date code of the firmware. See *Firmware on page A.1* for a description of the FID string. To complete the header, the relay reports a date and time stamp to indicate the internal clock time when the relay triggered the event.

Fixed Analog Section of the Event Report

The fixed analog section follows the header section and starts with column labels. The data underneath the analog column labels contain samples of power system voltages and currents in primary kilovolts and primary amperes, respectively. These quantities are instantaneous values scaled by $\sqrt{2}/2$ (0.707). Although you may not use all 24 channels of the SEL-487E in your application, all 24 channels are always displayed in the event report. To display all 24 channels, the event report consists of three groups. Current channels IAS through ICU are in the first group as shown in *Figure 7.30*. Current channels IAW–IY3 are shown in the second group, and voltage channels VAV–VCZ are shown in the third group.

Figure 7.30 contains selected data from the analog section of a 4-samples/cycle event report for a transformer fault. The bracketed numbers at the left of the report (for example, [11]) indicate the cycle number; *Figure 7.30* presents 11 cycles of 4-samples/cycle data. The trigger row includes a > character to indicate the trigger point. This is the dividing point between the prefault or PRE time and the fault or remainder of the data capture.

```
Relay 1                                    Date: 01/01/2019 Time: 02:03:38.102
Station A                                  Serial Number: 0000000000
FID=SEL-487E-5-R400-V0-Z200200-D20180910 Event Number = 10020     CID=0x5EB8
```

Header

Firmware ID

```
                    Currents (Pri. Amps)
  IAS    IBS    ICS    IAT    IBT    ICT    IAU    IBU    ICU
[1]
   190    -39   -150   -416     84    331      0      0      0
   -64    195   -132    141   -431    289      0      0      0
  -190     39    150    416    -84   -331      0      0      0
    63   -195    132   -141    431   -289      0      0      0
[2]
   190    -39   -150   -416     84    331      0      0      0
   -63    195   -132    141   -432    289      0      0      0
  -190     39    150    416    -84   -331      0      0      0
    64   -195    132   -141    431   -289      0      0      0
[3]
   190    -39   -150   -416     84    331      0      0      0
   -64    195   -132    141   -431    289      0      0      0
  -190     39    150    416    -84   -331      0      0      0
    63   -195    132   -141    431   -289      0      0      0
[4]
   190    -39   -150   -416     84    331      0      0      0
   -63    195   -132    141   -431    289      0      0      0
  -190     39    150    416    -84   -331      0      0      0
    63   -195    132   -141    432   -289      0      0      0
[5]
   189    -39   -150   -416     84    331      0      0      0
   -63    195   -132    141   -432    289      0      0      0
  -190     39    150    416    -84   -331      0      0      0
    85   -195    132   -135    427   -285      0      0      0
[6]
   561    -39   -150   -319     77    327      0      0      0
  -291    195   -132     81   -408    272      0      0      0
 -1177     39    150    158    -73   -312      0      0      0
   475   -195    132    -32    392   -263      0      0      0
[7]
  1422    -39   -150    -94     77    301      0      0     0>
  -475    195   -132     32   -393    263      0      0      0
 -1422     39    150     94    -77   -301      0      0      0
   534   -195    132    -37    392   -263      0      0      0
[8]
  2421    -39   -150   -180     77    301      0      0      0
 -1088    195   -132     85   -392    263      0      0     0*
 -4079     39    150    322    -77   -301      0      0      0
  1583   -195    132   -128    392   -263      0      0      0
[9]
  4740    -39   -150   -378     77    301      0      0      0
 -1583    195   -132    128   -392    263      0      0      0
 -4740     39    150    378    -77   -301      0      0      0
  1583   -195    132   -128    392   -263      0      0      0
[10]
  4739    -39   -150   -378     77    301      0      0      0
 -1583    195   -132    128   -392    263      0      0      0
 -4739     39    150    378    -77   -301      0      0      0
  1517   -185    125   -123    372   -248      0      0      0
[11]
  3308      1   -133   -264     -3    266      0      0      0
  -726     87    -58     59   -175    116      0      0      0
  -939    -20     58     75     42   -115      0      0      0
     0      1      0      0     -1      1      0      0      0
```

One cycle of data

Trigger

125 Cycles after trigger (to Event Summary)

Circuit breaker open

Figure 7.30 Analog Section of the Event Report

Table 7.18 Event Report Analog Quantities (Sheet 1 of 2)

Quantity	Description
IAS, IBS, ICS	Terminal S, filtered phase current vector
IAT, IBT, ICT	Terminal T, filtered phase current vector
IAU, IBU, ICU	Terminal U, filtered phase current vector
IAW, IBW, ICW	Terminal W, filtered phase current vector
IAX, IBX, ICX	Terminal X, filtered phase current vector

Table 7.18 Event Report Analog Quantities (Sheet 2 of 2)

Quantity	Description
IY1, IY2, IY3	Terminal Y1, Y2, and Y3, filtered phase current vectors
VAV, VBV, VCV	Voltage V, filtered phase voltage vector
VAZ, VBZ, VCZ	Voltage Z, filtered phase voltage vector

Fixed Analog Differential Report

The differential report is not a part of the event report. Use the **EVE DIF**[**F**] command (add **DIF**[**F**] to the **EVE** command) to retrieve the most recent differential report. The analog differential report follows the header section. The analog differential report displays operate and restraint quantities for each differential element, and the percentage second-, fourth-, and fifth-harmonic currents in each element, as shown in *Figure 7.31*.

```
Relay 1                                    Date: 01/01/2019 Time: 02:03:38.102
Station A                                  Serial Number: 0000000000
FID=SEL-487E-5-R400-V0-Z200200-D20180910 Event Number = 10020     CID=0x5EB8

   Differential Quantities            2nd Harmonic   4th Harmonic  5th Harmonic
IOPA  IRTA  IOPB  IRTB  IOPC  IRTC  IAH2 IBH2 ICH2 IAH4 IBH4 ICH4 IAH5 IBH5 ICH5

[1]
 0.05  1.96  0.06  1.95  0.05  1.96   2    2    1    1    0    1    1    1    1
 0.05  1.96  0.06  1.95  0.05  1.96   2    2    2    2    1    1    1    1    1
 0.05  1.96  0.06  1.95  0.05  1.96   2    2    2    1    1    1    1    1    2
 0.05  1.96  0.06  1.95  0.05  1.96   2    2    2    1    1    1    1    1    2

[2]
 0.05  1.96  0.06  1.95  0.05  1.96   2    2    2    1    1    1    1    2    1
 0.05  1.96  0.06  1.95  0.05  1.96   2    2    2    1    1    0    1    2    2
 0.05  1.96  0.06  1.95  0.05  1.96   2    2    1    2    2    1    1    2    2
 0.05  1.96  0.06  1.95  0.05  1.96   3    2    1    2    2    1    1    2    2

[3]
 0.05  1.96  0.06  1.95  0.05  1.96   1    2    2    2    2    1    1    1    2
 0.05  1.96  0.06  1.95  0.05  1.96   1    3    2    1    2    1    1    1    1
 0.05  1.96  0.06  1.95  0.05  1.96   1    1    2    2    2    1    0    1    1
 0.05  1.96  0.06  1.95  0.05  1.96   1    1    2    1    1    1    1    1    2

[4]
 0.05  1.96  0.06  1.95  0.05  1.96   1    3    1    1    0    0    1    0    2
 0.05  1.96  0.06  1.95  0.05  1.96   1    1    2    1    1    0    1    1    2
 0.05  1.96  0.06  1.95  0.05  1.96   1    1    2    1    1    0    1    2    2
 0.05  1.96  0.05  1.95  0.05  1.96   2    3    1    1    1    1    1    1    2

[5]
 0.05  1.96  0.05  1.95  0.05  1.96   0    0    0    1    0    0    1    1    2
 0.05  1.96  0.06  1.95  0.05  1.96   0    2    1    1    1    1    1    1    1
 0.05  1.96  0.06  1.95  0.05  1.96   2    2    1    1    2    1    0    1    1
 0.07  1.98  0.01  1.97  0.08  1.93   2    3    1    1    1    1    1    1    2

[6]
 1.29  2.97  0.67  2.22  0.62  2.38   1    2    3    1    1    1    1    1    1
 1.51  3.14  0.78  2.40  0.74  2.28   1    3    3    1    1    0    0    1    0
 3.59  4.74  1.81  3.07  1.79  3.15   1    2    3    1    1    1    1    1    1
 3.79  4.90  1.92  3.19  1.88  3.15   0    0    0    0    0    0    1    6    8

[7]
 4.62  5.53  2.31  3.49  2.31  3.50   0    0    0    0    0    0    0    0    0
 4.62  5.53  2.31  3.49  2.31  3.50   0    0    0    0    0    0    0    0    0
 4.62  5.53  2.31  3.49  2.31  3.50   0    0    0    0    0    0    0    0    0
 4.68  5.60  2.34  3.55  2.34  3.49   0    0    1    1    1    0    0    0    1

[8]
 7.60  8.77  3.80  4.92  3.80  5.12   1    2    3    1    1    1    1    1    1
 8.14  9.35  4.07  5.39  4.06  5.20   1    2    3    1    1    1    1    1    1
12.91 14.53  6.46  7.73  6.45  7.87   1    2    3    1    1    1    1    1    1
13.38 15.04  6.69  8.09  6.68  8.00   1    2    3    1    1    1    1    1    1

[9]
15.27 17.10  7.64  9.04  7.63  9.05   0    0    0    0    0    0    0    0    0
15.27 17.10  7.64  9.04  7.63  9.05   0    0    0    0    0    0    0    0    0
15.27 17.10  7.64  9.04  7.63  9.05   0    0    0    0    0    0    0    0    0
15.27 17.10  7.64  9.04  7.63  9.05   0    0    0    0    0    0    0    0    0
```

Figure 7.31 Differential Report

```
[10]
15.27 17.10  7.64  9.04  7.63  9.05   0    0    0    0    0    0    0    0    0
15.27 17.10  7.64  9.04  7.63  9.05   0    0    0    0    0    0    0    0    0
15.27 17.09  7.64  9.04  7.63  9.05   0    0    0    0    0    0    0    0    0
15.21 17.02  7.61  8.94  7.60  9.01   1    1    1    1    1    1    1    0    1

[11]
11.12 12.45  5.56  6.82  5.56  6.76   1    2    3    1    1    1    1    1    1
10.35 11.59  5.17  5.66  5.18  6.40   0    0    1    1    1    0    0    0    1
 3.63  4.06  1.82  2.43  1.81  2.27   0    0    1    1    1    0    0    0    1
 2.87  3.21  1.43  1.43  1.44  1.97   0    0    1    1    1    0    0    0    1

[12]
 0.00  0.00  0.00  0.00  0.00  0.00   0    0    0    0    0    0    0    0   02
```

Figure 7.31 Differential Report (Continued)

Table 7.19 Differential Report Analog Quantities

Quantity	Description
IOPA, IOPB, IOPC	Operate current for the Zone 1 differential element
IRTA, IRTB, IRTC	Restraint current for the Zone 1 differential element
IAH2, IBH2, ICH2	Second-harmonic percentage of fundamental for Zone 1 operate current
IAH4, IBH4, ICH4	Fourth-harmonic percentage of fundamental for Zone 1 operate current
IAH5, IBH5, ICH5	Fifth-harmonic percentage of fundamental for Zone 1 operate current

Digital Section of the Event Report

The next portion of an event report is the digital section. Inspect the digital data to evaluate relay element response during an event. See *Figure 7.32* for the locations of items in a sample event report digital section. If you want to view only the digital portion of an event report, use the **EVE D** command (see *EVENT on page 14.33 in the SEL-400 Series Relays Instruction Manual* and *Section 9: ASCII Command Reference* for details). In the digital portion of the event report, the relay indicates deasserted elements with a period (.) and asserted elements with an asterisk (*) character.

The element and digital information labels are single character columns. Read these columns from top to bottom. The trigger row includes a > character following immediately after the last digital element column to indicate the trigger point. The relay marks the row used to report the maximum fault current with an asterisk (*) character at the right of the last digital element column. Event reports that are 4-samples/cycle reports show the OR combination of digital elements in the two 8-samples/cycle rows to make the quarter-cycle entry.

The digital report arranges the event report digital settings into 79 column pages. For every 79 columns, the relay generates a new report that follows the previous report. The report displays the digital label header for each column in a vertical fashion, aligned on the last character. For example, if the first digital section elements are TRPXFMR, TRIPS, TRIPT, TRIPU, TRIPW, TRIPX, TRIPY, #, and 87RA, the header appears as in *Figure 7.33*. If the Relay Word bits included in the header were assigned aliases, the alias names appear in the report.

```
T
R                                                                       O
PTTTTTT     888 RRRRRR VV   SSSSSS TTTTTT UUUUUU WWWWWW XXXXXX        IIIIIII U
XRRRRRR 888 777 EEEEEE PPLL FRFRFR FRFRFR FRFRFR FRFRFR FRFRFR FFFFFF NNNNNNN T
FIIIIII 7778RRR FFFFFF OOOO 333333 333333 333333 333333 333333 BBBBBB 1111111 1
MPPPPPP RRR7ABC FFFRRR LLPP 222222 222222 222222 222222 222222 FFFFFF 0000000 0
RSTUWXY ABCQ222 123123 VZVZ PPQQGG PPQQGG PPQQGG PPQQGG PPQQGG STUWXY 1234567 1
```

Digital Column List

```
[1]
....... ....... ...... .... ...... ...... ...... ...... ...... ...... ....... .
....... ....... ...... .... ...... ...... ...... ...... ...... ...... ....... .
....... ....... ...... .... ...... ...... ...... ...... ...... ...... ....... .
....... ....... ...... .... ...... ...... ...... ...... ...... ...... ....... .
```

One Cycle of Data

```
.
.
.
....... ....... ...... .... ...... ...... ...... ...... ...... ...... ....... .
....... ....... ...... .... ...... ...... ...... ...... ...... ...... ....... .
....... ....... ...... .... ...... ...... ...... ...... ...... ...... ....... .
....... ....... ...... .... ...... ...... ...... ...... ...... ...... ....... .
[7]
*...... *...... ...... .... ...... ...... ...... ...... ...... ...... ....... *>
```

Trigger

```
*...... *...... ...... .... ...... ...... ...... ...... ...... ...... ....... *
*...... *...... ...... .... ...... ...... ...... ...... ...... ...... ....... *
*...... *...... ...... .... ...... ...... ...... ...... ...... ...... ....... *
[8]
*...... *...... ...... .... ...... ...... ...... ...... ...... ...... ....... *
*...... *...... ...... .... ...... ...... ...... ...... ...... ...... ....... *
*...... *...... ...... .... ...... ...... ...... ...... ...... ...... ....... *
*...... *...... ...... .... ...... ...... ...... ...... ...... ...... ....... *
[9]
*...... *...... ...... .... ...... ...... ...... ...... ...... ...... ....... *
*...... *...... ...... .... ...... ...... ...... ...... ...... ...... ....... *
*...... *...... ...... .... ...... ...... ...... ...... ...... ...... ....... *
*...... *...... ...... .... ...... ...... ...... ...... ...... ...... ....... *
```

Figure 7.32 Digital Section of the Event Report

Figure 7.33 Sample Digital Portion of the Event Report

Event Summary Section of the Event Report

The next portion of an event report is the summary section. See *Figure 7.34* for the locations of items included in a sample summary section of an event report. If you want to exclude the summary portion from an event report, use the **EVE NSUM** command.

All angles are referenced to the voltage connected to voltage Terminal VAV. If voltage at Terminal VAV is not available, the relay selects VAZ as the reference. In the absence of voltage (>5 V), the relay references the current input of IAS,

provided the current is above 0.25 A. If IAS is not higher than this current level, the relay references the current from IAT, if available. If I02 is not available, the relay continues to IAU, IAW, IAX, and IAY until it finds a current input higher than 0.25 A.

The information in the summary portion of the event report is the same information in the event summary, except that the report header does not appear immediately before the event information when you view a summary in the event report.

```
Event: TRIP                                                Time Source: OTHER
Event Number: 10014                Frequency: 60.003             Group: 1
Targets: TLED_13 TLED_20
```

Event Information

```
Breaker S: OPEN
Breaker T: OPEN
Breaker U: CLOSED
```

```
Fault Analog Data

         IAS    IBS    ICS    IAT    IBT    ICT    IAU    IBU    ICU
MAG(A)     426    426    426    428    428    427      0      0      0
ANG(DEG)   -1.0 -120.8  119.3  179.4   59.5  -60.5 -118.1  -90.9   29.7

         IAW    IBW    ICW    IAX    IBX    ICX    IY1    IY2    IY3
MAG(A)     426      1      0      0      0      0      0      0      0
ANG(DEG)   -0.9 -122.8 -152.1 -137.8 -118.8 -169.8 -143.6 -139.8 -138.1

         VAV    VBV    VCV    VAZ    VBZ    VCZ
MAG(kV)    134    134    134      0      0      0
ANG(DEG)    0.0 -119.9  120.3 -136.1 -112.0 -165.2

         IOPA   IRTA   IOPB   IRTB   IOPC   IRTC
MAG(p.u)  1.05   3.01   1.05   3.00   1.05   3.01

         IOPA2  IRTA2  IOPB2  IRTB2  IOPC2  IRTC2
MAG(p.u)  0.02   0.51   0.87   2.09   1.01   3.02
```

Fault Data

Figure 7.34 Summary Section of the Event Report

Event Summary

You can retrieve a summary version of stored event reports as event summaries. These short-form reports present vital information about a triggered event. The relay generates an event in response to power system faults and other trigger events. See *Figure 7.35* for a sample event summary.

```
Relay 1                                    Date: 10/23/2023 Time: 08:15:52.452
Station A                                  Serial Number: 1232969999
```

Report Header

```
Event: TRIP                                                Time Source: OTHER
Event Number: 10015                Frequency: 60.000             Group: 1
Targets: TLED_13 TLED_14 TLED_15
```

Event Information

```
Breaker S: OPEN
Breaker T: OPEN
Breaker U: CLOSED
```

Breaker Status

```
Fault Analog Data

         IAS    IBS    ICS    IAT    IBT    ICT    IAU    IBU    ICU
MAG(A)     629    629    629      0      0      0      0      0      0
ANG(DEG)  -16.1 -135.8  104.3  -75.9  136.1  161.7  -90.1  -51.3   93.8

         IAW    IBW    ICW    IAX    IBX    ICX    IY1    IY2    IY3
MAG(A)     630      0      0      0      0      0      1      0      0
ANG(DEG)  -15.9  -40.2  -63.6 -101.0 -109.8  -52.7  -74.2  -68.2  -97.0

         VAV    VBV    VCV    VAZ    VBZ    VCZ
MAG(kV)    126    126    126      0      0      0
ANG(DEG)    0.0 -119.9  120.3  -55.9  -52.0  -84.5

         IOPA   IRTA   IOPB   IRTB   IOPC   IRTC
MAG(p.u)  3.00   3.00   2.99   2.99   3.00   3.00

         IOPA2  IRTA2  IOPB2  IRTB2  IOPC2  IRTC2
MAG(p.u)  0.02   0.51   0.87   2.09   1.01   3.02
```

Fault Data

Figure 7.35 Sample Event Summary Report

The event summary contains the following information:

- Standard report header
  - Relay and terminal identification
  - Event date and time
- Event type
- Time source (HIRIG or OTHER)
- Event number
- System frequency
- Active group at trigger time
- Targets
- Circuit breaker trip and close times; and auxiliary contact(s) status
- Fault voltages, currents, sequence current, and operate and restraint currents (from the event report row with the largest current)
- MIRRORED BITS communications channel status (if enabled)

The relay derives the summary target information and circuit breaker trip and close times from the rising edge of relevant Relay Word bits during the event. If no trip or circuit breaker element asserted during the event, the relay uses the last row of the event.

The SEL-487E reports the event type and *Table 7.20* lists event types in fault reporting priority. Differential and restricted earth fault indications have reporting priority over indeterminate fault events. For example, you can trigger an event when there is no fault condition on the power system by using the **TRI** command. In this case, when there is no fault, the relay reports the event type as TRIG.

Table 7.20 Event Types

Event	Description
87 Z1	Zone 1 differential element involved, indicated by the rising edge of 87R
87 Z2	Zone 2 differential element involved, indicated by the rising edge of 87R2
REF	Restricted earth fault element involved, indicated by the rising edge of REF
TRIP	Rising edge of Relay Word bit TRIP
ER (event report trigger)	Rising edge of ER (SELOGIC control equation)
TRIG	Execution of the **TRIGGER** (**TRI**) command (manually triggered)

Event History

The event history gives you a quick look at recent relay activity. The relay labels each new event with a unique number from 10000 to 42767. (At 42767, the top of the numbering range, the relay returns to 10000 for the next event number and then continues to increment.)

The event history contains the following:

- Standard report header
  - Relay and terminal identification
  - Date and time of report

- Event number
- Event date and time
- Event type
- Active group at the trigger instant
- Targets

The event types in the event history are the same as the event types in the event summary (see *Table 7.20* for event types). The event history report indicates events stored in relay nonvolatile memory. The relay places a blank row in the history report output; items that are above the blank row are available for viewing (use the **EVE** and **CEV** commands). Items that are below the blank row are no longer in relay memory; these events appear in the history report to indicate past power system performance.

The relay does not ordinarily modify the numerical or time order in the history report. However, if an event report is corrupted (power was lost during storage, for example), the relay lists the history report line for this event after the blank row.

SECTION 8

Settings

Section 12: Settings in the SEL-400 Series Relays Instruction Manual describes common platform settings. This section contains tables of relay settings for the SEL-487E Relay.

⚠WARNING
Isolate the relay trip circuits while changing settings. When changing settings for multiple classes, it is possible to be in an intermediate state that will cause an unexpected trip.

The relay hides some settings based upon the state of other settings. For example, if you set an enable setting to OFF (disabling the function), the relay hides all settings associated with that function.

The settings prompts in this section are similar to the ASCII terminal and SEL Grid Configurator Software prompts. Prompts in this section are unabbreviated and show all possible setting options.

For information on using settings in protection and automation, see the examples in *Section 6: Protection Application Examples*. The section contains information on the following settings classes.

- *Alias Settings on page 8.1*
- *Automation Freeform SELOGIC Control Equations on page 8.29*
- *Bay Settings on page 8.33*
- *DNP3 Settings—Custom Maps on page 8.33*
- *Front-Panel Settings on page 8.30*
- *Global Settings on page 8.2*
- *Group Settings on page 8.12*
- *Monitor Settings on page 8.8*
- *Notes Settings on page 8.33*
- *Output Settings on page 8.29*
- *Port Settings on page 8.33*
- *Protection Logic: Default Settings on page 8.29*
- *Report Settings on page 8.33*

Alias Settings

See *Section 12: Settings in the SEL-400 Series Relays Instruction Manual* for a complete description of alias settings. *Table 8.1* lists the default alias settings for the SEL-487E.

Table 8.1 Default Alias Settings

Label	Default
EN	RLY_EN

Global Settings

Table 8.2 Global Setting Categories

Settings	Reference
General Global Settings	*Table 8.3*
Global Enables	*Table 8.4*
Control Inputs (Global)	*Table 8.5*
Interface Board #1 Control Inputs	*Table 8.6*
Interface Board #*n* Control Inputs	*Table 8.7*
Settings Group Selection	*Table 8.8*
Frequency Source Selection	*Table 8.9*
Synchronized Phasor Configuration Settings	*Table 8.10*
Time and Date Management	*Table 8.18*
Data Reset Controls	*Table 8.19*
Access Control	*Table 8.20*
DNP	*Table 8.21*
SV and TiDL Application Settings	*Table 8.22*

Table 8.3 General Global Settings

Setting	Prompt	Default
SID	Station Identifier (40 characters)	Station A
RID	Relay Identifier (40 characters)	Relay 1
CONAM	Company Name (5 characters)	abcde
NFREQ	Nominal System Frequency (50, 60 Hz)	60
PHROT	System Phase Rotation (ABC, ACB)	ABC

Table 8.4 Global Enables

Setting	Prompt	Default
EICIS	Independent Control Input Settings (Y, N)	N
EPMU	Synchronized Phasor Measurement (Y, N)	N
EINVPOL	Enable Invert Polarity (OFF or combo of terminals)[a, b]	OFF

[a] Any combination of Terminals V, Z, S, T, U, W, X, or Y, and A-, B-, or C-Phases, or Terminal Y and Inputs 1, 2, or 3. For example, EINVPOL := SA,SB,X,Y3 inverts the polarity of the A- and B-Phases for Terminal S, all phases for Terminal X, and Input 3 for Terminal Y.

[b] Cannot set from front-panel HMI.

Table 8.5 settings are available when Global enable setting EICIS := N.

NOTE: INT2 and INT4 I/O interface boards have optoisolated contact inputs.

NOTE: The 300, 400, and 500 level inputs are virtual inputs that are only available to the TiDL relay and are mapped from connected SEL-TMU according to your configured TiDL topology.

Table 8.5 Control Inputs (Global)

Setting	Prompt	Default	Increment
GINP[a]	Input Pickup Level (16–250 VDC)	85[b]	1
GINDF[a]	Input Dropout Level (10–100% of pickup level)	80[c]	1
IN*a*XXD[d, e]	Int Board #*a* Debounce Time (0.0–30 ms[d])	2.0	0.5

[a] Hidden if EICIS = Y.
[b] Change default to 16 (if I/O Board Position B has 24 V inputs), 34 (if I/O Board Position B has 48 V inputs), 78 (if I/O Board Position B has 110 V inputs), 89 (if I/O Board Position B has 125 V inputs), 156 (if I/O Board Position B has 220 V inputs), or 178 (if I/O Board Position B has 250 V inputs).
[c] Setting value must satisfy GINDF • (GINP / 100) > 15
[d] If the interface board has more than eight input contacts, the upper range is 1 cycle. The interface boards that map to 300, 400, or 500 level inputs in the TiDL relay are virtual input boards and are assumed to have 24 inputs per level.
[e] a = 1, 2, 3, or 4. Interface boards 2, 3, and 4 are virtual and map to 300, 400, and 500 level I/O, respectively.

Table 8.6 settings are available for Interface Board #1 when Global enable setting EICIS := Y.

Table 8.6 Interface Board #1 Control Inputs

Setting	Prompt	Default	Increment
IN201PU	Input IN201 Pickup Delay (0.0–30 ms)	2.0[a]	0.5
IN201DO	Input IN201 Dropout Delay (0.0–30 ms)	2.0[a]	0.5
• • •	• • •	• • •	• • •
IN2*mm*PU[b]	Input IN2*mm* Pickup Delay (0.0–30 ms)	2.0[a]	0.5
IN2*mm*DO[b]	Input IN2*mm* Dropout Delay (0.0–30 ms)	2.0[a]	0.5

[a] Set to Global setting IN2XXD when EICIS := N.
[b] mm is the number of available input contacts on the interface board.

NOTE: The settings listed in Table 8.7 are only in TiDL relays that map inputs from the SEL-TMU when EICIS := Y.

Table 8.7 Interface Board #n[a] Control Inputs

Setting[b, c]	Prompt	Default	Increment
IN*amm*P	Input IN*amm* Pickup Level (16–250 Vdc)	85[d]	
IN*amm*PU	Input IN*amm* Pickup Delay (0.0–30 ms)	2.0	0.5
IN*amm*DO	Input IN*amm* Dropout Delay (0.0–30 ms	2.0	0.5

[a] n = 2, 3, or 4 (Interface Board #2 relates to 300 level mapped inputs, Interface Board #3 relates to 400 level mapped inputs, and Interface Board #4 relates to 500 level mapped inputs)
[b] a = 3, 4, or 5 to indicate 300, 400, or 500 level mapped inputs; mm = 01–24, indicates mapped input within the a input level
[c] Hidden and forced to default if EICIS = N.
[d] Change default to 16 (if I/O Board Position B has 24 V inputs), 34 (if I/O Board Position B has 48 V inputs), 78 (if I/O Board Position B has 110 V inputs), 89 (if I/O Board Position B has 125 V inputs), 156 (if I/O Board Position B has 220 V inputs), or 178 (if I/O Board Position B has 250 V inputs).

Table 8.8 Settings Group Selection (Sheet 1 of 2)

Setting	Prompt	Default
SS1	Select Setting Group 1 (SELOGIC Equation)	NA
SS2	Select Setting Group 2 (SELOGIC Equation)	NA

Table 8.8 Settings Group Selection (Sheet 2 of 2)

Setting	Prompt	Default
SS3	Select Setting Group 3 (SELOGIC Equation)	NA
SS4	Select Setting Group 4 (SELOGIC Equation)	NA
SS5	Select Setting Group 5 (SELOGIC Equation)	NA
SS6	Select Setting Group 6 (SELOGIC Equation)	NA
TGR	Group Change Delay (1–54000 cycles)	180

Table 8.9 Frequency Source Selection

Setting	Prompt	Default
FRQST	Primary Frequency Source Terminal (OFF, V, Z, ADV)	V
EAFSRC	Alternate Frequency Source (SELOGIC Equation)	NA
VF01	Local Frequency Source 1 (ZERO, VAV, VBV, VCV, VAZ, VBZ, VCZ)	VAV
VF02	Local Frequency Source 2 (ZERO, VAV, VBV, VCV, VAZ, VBZ, VCZ)	VBV
VF03	Local Frequency Source 3 (ZERO, VAV, VBV, VCV, VAZ, VBZ, VCZ)	VCV
VF11	Alternate Frequency Source 1 (ZERO, VAV, VBV, VCV, VAZ, VBZ, VCZ)	ZERO
VF12	Alternate Frequency Source 2 (ZERO, VAV, VBV, VCV, VAZ, VBZ, VCZ)	ZERO
VF13	Alternate Frequency Source 3 (ZERO, VAV, VBV, VCV, VAZ, VBZ, VCZ)	ZERO

Table 8.10 Synchronized Phasor Configuration Settings

Setting	Prompt[a]	Default
MFRMT	Message Format (C37.118, FM)	C37.118
MRATE[b]	Messages per Second (1, 2, 4, 5, 10, 12, 15, 20, 30, 60)[c]	2
PMAPP	PMU Application (F, N, 1)[d]	N
PMLEGCY	Synchrophasor Legacy Settings (Y, N, N1)	N1
NUMPHDC[b, e]	Number of Data Configurations (1–5)	1
PMSTN*q*[b, f]	Station Name (16 characters)	STATION A
PMID*q*[f]	PMU Hardware ID (1–65534)[g]	1
PHVOLT[h]	Include Voltage Terminal (combo of V, Z)	V
PHDATAV[h]	Phasor Data Set, Voltages (V1, PH, ALL, NA)	V1
PHCURR[h]	Include Current Terminal (combo of S, T, U, W, X, Y)	S
PHDATAI[h]	Phasor Data Set, Currents (I1, PH, ALL, NA)	NA

[a] "Combo" means "combination"; enter these "combo "settings delimited with either commas or spaces.
[b] Only available if MFRMT = C37.118.
[c] If NFREQ = 50, then the range is 1, 2, 5, 10, 25, 50.
[d] Option 1 is available only if MRATE = 60.
[e] Only available if PMLEGCY = N or N1.
[f] q = 1–5 (determined by NUMPHDC). If PMLEGCY = Y, then these two settings become PMSTN and PMID.
[g] If MFRMT = FM, range is 0–4294967295.
[h] Only available if PMLEGCY = Y.

Phasors Included in the Data q
Terminal Name, Relay Word Bit, Alternative Terminal Name

Specify the terminal for synchrophasor measurement and transmission in the synchrophasor data stream *q*.

This is a freeform setting category for enabling the terminals for synchrophasor measurement and transmission. This freeform setting has three arguments. Specify the terminal name (any one of S, T, U, V, W, X, Y, or Z) for the first argument. Specify any Relay Word bit for the second argument. Specify the alternative terminal name (any one of S, T, U, V, W, X, Y, or Z) for the third argument.

The second and third arguments are optional unless switching between terminals is required. Whenever the Relay Word bit in the second argument is asserted the terminal synchrophasor data are replaced by the alternative terminal data.

Table 8.11 Phasors Included in the Data q

Setting[a]	Prompt	Default
PHDV*q*	Phasor Data Set, Voltages (V1, PH, ALL)[b, c]	V1
PHDI*q*	Phasor Data Set, Currents (I1, PH, ALL)[b, d]	ALL
PHNR*q*	Phasor Num. Representation (I = Integer, F = Float)[e]	I
PHFMT*q*	Phasor Format (R = Rectangular, P = Polar)[f]	R
FNR*q*	Freq. Num. Representation (I = Integer, F = Float)[e]	I

[a] q = 1–5 (determined by NUMPHDC setting).
[b] When MFRMT = FM, then range is (V1, ALL).
[c] Hidden and forced to PHDATAV if PMLEGCY = Y.
[d] Hidden and forced to PHDATAI if PMLEGCY = Y.
[e] Forced to F when MFRMT = FM and EPMU = Y.
[f] Forced to P when MFRMT = FM and EPMU = Y.

Phasor Aliases in Data Configuration q
Phasor Name, Alias

This is a freeform setting category with two arguments. Specify the phasor name and an optional 16-character alias to be included in the synchrophasor data stream *q*. See *Table 10.29* and *Table 10.30* for a list of phasor names that the PMU supports. The PMU can be configured for as many as 32 unique phasors for each PMU configuration.

Table 8.12 Phasor Aliases in Data Configuration q

Setting	Prompt	Default
PMSP*qee*[a, b]	Name of the Synchrophasor (Default Name of Any Synchrophasor)	(blank)
PMSA*qee*[a, b]	Alias of the Synchrophasor (16 characters)	(blank)

[a] q = 1–5 (determined by NUMPHDC setting).
[b] ee = 1–32.

From a terminal emulation program, the setting name is now shown and a freeform settings line appears after a prompt. In SEL Grid Configurator, the setting name is shown and a field is available to enter the setting.

Synchrophasor Analog Quantities in Data Configuration q
Analog Quantity Name, Alias Name

This is a freeform setting category with two arguments. Specify the analog quantity name or its alias to be included in the synchrophasor data stream *q* (see *Section 12: Analog Quantities* for a list of analog quantities that the PMU supports). Optionally provide an alias name to use in the synchrophasor configuration message. The PMU can be configured for as many as 16 unique analog quantities for each data configuration *q*. The analog quantities are floating-point values, so each analog quantity the PMU includes will take four bytes.

Table 8.13 Number of Digital Status Words to Include in Stream q

Setting	Prompt	Default
NUM*ANq*	Number of Analog Quantities (0–16)	0
PMAQ*qcc*[a, b]	Any Analog Quantity (Name of Any Analog Quantity)	(blank)
PMAA*qcc*[a, b]	Alias Name for the Analog Quantity (16 characters)	(blank)

[a] q = 1–5 (determined by NUMPHDC setting).
[b] cc = 1–16.

From a terminal emulation program, the setting name is not shown and a freeform settings line appears after a prompt. In SEL Grid Configurator, the setting name is shown and a field is available to enter the setting.

Synchrophasor Digitals in Data Configuration q Digital Name, Alias Name

This is a freeform setting category with two arguments. Specify the Relay Word bit name or its alias that you need to include in the synchrophasor data stream *q* (see *Section 11: Relay Word Bits* for a list of Relay Word bits that the PMU supports). Optionally, include an alias name as the second parameter to use the synchrophasor configuration message. You can configure the PMU for as many as 64 unique digitals for each data configuration *q*.

Table 8.14 Synchrophasor Digitals in Data Configuration q

Setting	Prompt	Default
NUM*DWa*	Number of 16-bit Digital Status Words (0, 1, 2, 3, 4)	1
PMDG*qdd*[a, b]	Any Relay Word bit (Name of Any Relay Word Bit)	(blank)
PMDA*qdd*[a, b]	Alias Name for the Analog Quantity (16 characters)	(blank)

[a] q = 1–5 (determined by NUMPHDC setting).
[b] dd = 1–16.

From a terminal emulation program, the setting name is not shown and a freeform settings line appears after a prompt. In SEL Grid Configurator, the setting name is shown and a field is available to enter the setting.

Table 8.15 Synchronized Phasor Configuration Settings Part 2

Setting	Prompt	Default	Increment
TREA[4]	Trigger Reason Bit [4] (SELOGIC Equation)	NA	
PMTRIG	Trigger (SELOGIC Equation)	NA	
PMTEST	PMU in Test Mode (SELOGIC Equation)	NA	
V*k*COMP[a]	Comp. Angle Terminal *k* (–179.99° to 180°)	0.00	0.01
I*n*COMP[b]	Comp. Angle Terminal *n* (–179.99° to 180°)	0.00	0.01
PMFRQST	PMU Primary Frequency Source Terminal (V, Z)	V	
PMFRQA	PMU Frequency Application (F, S)	S	
PHCOMP	Freq. Based Phasor Compensation (Y, N)	Y	

[a] k = V and Z.
[b] n = S, T, U, W, X, Y.

Table 8.16 Synchronized Phasor Recorder Settings

Setting	Prompt	Default
EPMDR	Enable PMU Data Recording (Y, N)	N
SPMDR	Select Data Configuration for PMU Recording (1–NUMPHDC)	1
PMLER	Length of PMU Triggered Data (2–120 s)	30
PMPRE	Length of PMU Pre-Triggered Data (1–20 s)	5

Table 8.17 Synchronized Phasor Real-Time Control

Setting	Prompt	Default	Increment
RTCRATE	Remote Messages Per Second (1, 2, 5, 10, or 50 When NFREQ := 50) (1, 2, 4, 5, 10, 12, 15, 20, 30, or 60 When NFREQ := 60)	2	
MRTCDLY	Maximum RTC Synchrophasor Packet Delay (20–1000 ms)	500	1

Table 8.18 Time and Date Management

Setting	Prompt	Default
DATE_F	Date Format (MDY, YMD, DMY)	MDY
IRIGC[a]	IRIG-B Control Bits Definition (None, C37.118)	None
UTCOFF[b]	Offset From UTC to Local Time (–15.5 to 15.5)	–8.0
BEG_DST[c]	Begin DST (hh, n, d, mm, or OFF)	“2, 2, 1, 3”
END_DST	End DST (hh, n, d, mm)	“2, 1, 1, 11”

[a] When EPMU = Y and MFRMT = C37.118, IRIGC is forced to C37.118.

[b] All data, reports, and commands from the relay are stored and displayed in local time, referenced to an internal UTC master clock. Use the UTCOFF setting to specify the time offset from UTC time reference with respect to the relay location. (The only data still displayed in UTC time is streaming synchrophasor and IEC 61850 data.)

[c] The BEG_DST (and END_DST) daylight-saving time setting consists of four fields or OFF:
hh = local time hour (0–23); defines when daylight-saving time begins.
n = the week of the month when daylight-saving time begins (1–3, L); occurs in either the first, second, third, or last week of the month.
d = day of week (1–7); Sunday is the first day of the week.
mm = month (1–12).
OFF = hides the daylight-saving time settings.

Table 8.19 Data Reset Control

Setting	Prompt	Default
RST_DEM	Reset Demand Metering (SELOGIC Equation)	NA
RST_PDM	Reset Peak Demand Metering (SELOGIC Equation)	NA
RST_ENE	Reset Energy Metering (SELOGIC Equation)	NA
RST_79C	Reset Recloser Shot Counters (SELOGIC Equation)	NA
RSTTRGT	Target Reset (SELOGIC Equation)	NA
RSTDNPE	Reset DNP Fault Summary Data (SELOGIC Equation)	TRGTR
RST_HAL	Reset Warning Alarm Pulsing (SELOGIC Equation)	NA

Table 8.20 Access Control

Setting	Prompt	Default
EACC	Enable ACC access level (SELOGIC Equation)	1
E2AC	Enable ACC–2AC access level (SELOGIC Equation)	1

Table 8.21 DNP

Setting	Prompt	Default
EVELOCK	Event Summary Lock Period (0–1000 s)	0
DNPSRC	DNP Session Time Base (LOCAL, UTC)	UTC

Table 8.22 SV and TiDL Application Settings

Setting	Prompt	Default
SVBLK	SV Subscriber Relay: Blocking Condition for SV Applications (SELOGIC Equation) TiDL Relay: Blocking Condition for TiDL Applications (SELOGIC Equation)	ISBK OR ITBK
SVFZDO	SV Subscriber Relay: SV Application Freeze Dropout Time (OFF,0.000–99999 cyc) TiDL Relay: TiDL Application Freeze Dropout Time (OFF,0.000–99999 cyc)	OFF

Monitor Settings

Table 8.23 Monitor Setting Categories

Settings	Reference
Enables	*Table 8.24*
Station DC Monitor	*Table 8.25*
Breaker Monitor Settings	*Table 8.26*
Through-Fault Monitoring	*Table 8.27*
Thermal Model Configuration	*Table 8.28*
Thermal Probe Selection	*Table 8.29*
Cooling Stage Constants for Transformers	*Table 8.30*
Default Transformer Constants (When EDFTC = Y)	*Table 8.31*
Thermal Loss-of-Life	*Table 8.32*
Thermal Alarm Limits	*Table 8.33*
IEC Thermal (49) Elements	*Table 8.34*
Thermal Ambient Compensation	*Table 8.35*

Table 8.24 Enables

Setting	Prompt	Default
EDCMON	Station DC Battery Monitor (Y, N)	N
BK_SEL	Breaker Selection (OFF or combo of S, T, U, W, X, Y)[a]	S,T
EBMON	Enable BK Monitoring (OFF or combo of S, T, U, W, X, Y)[a]	OFF
ETHFLTM	Enable Through Fault Monitoring (Y, N)	N
ETHERM	Enable Transformer Thermal Element (Y, N)	N
ETHRIEC	Enable IEC Thermal Element (N, 1–3)	N

[a] "Combo" means "combination of"; enter these "combo" settings delimited with either commas or spaces.

Table 8.25 settings are available if EDCMON = Y.

Table 8.25 Station DC Monitor

Setting	Prompt	Default	Increment
DCLFP	Low Level Fail Pickup (OFF, 15–300 Vdc)	100	1
DCLWP	Low Level Warn Pickup (OFF, 15–300 Vdc)	127	1
DCHWP	High Level Warn Pickup (OFF, 15–300 Vdc)	137	1
DCHFP	High Level Fail Pickup (OFF, 15–300 Vdc)	142	1
DCRP	Peak-to-Peak AC Ripple Pickup (1–300 Vac)	9	1
DCGF	Ground Detection Factor (1.00–5.00)	1.05	0.01
RST_BAT	Reset Battery Monitoring (SELOGIC Equation)	NA	

Table 8.26 Breaker Monitor Settings

Setting[a]	Prompt	Default	Increment
B*m*_ID	Breaker *m* Identifier (40 characters)	Breaker *m*	
52A_*m*	NO Contact Input—BK*m* (SELOGIC Equation)	IN20*n*[b]	
BM*m*TRP	Breaker Monitor Trip—BK*m* (SELOGIC Equation)	TRIP*m*	
BM*m*CLS	Breaker Monitor Close—BK*m* (SELOGIC Equation)	CLS*m*	
B*m*COSP1	Close/Open Set Point 1—BK*m* (1–65000 Operations)	1000	1
B*m*COSP2	Close/Open Set Point 2—BK*m* (1–65000 Operations)	100	1
B*m*COSP3	Close/Open Set Point 3—BK*m* (1–65000 Operations)	10	1
B*m*KASP1	kA Interrupted Set Point 1—BK*m* (1.0–999 kA)	20.0	0.1
B*m*KASP2	kA Interrupted Set Point 2—BK*m* (1.0–999 kA)	60.0	0.1
B*m*KASP3	kA Interrupted Set Point 3—BK*m* (1.0–999 kA)	100.0	0.1
B*m*BCWAT	Contact Wear Alarm Threshold—BK*m* (0–100%)	90	0.1
B*m*ESTRT	Electrical Slow Trip Alarm Threshold—BK*m* (1–999 ms)	50	1
B*m*ESCLT	Electrical Slow Close Alarm Threshold—BK*m* (1–999 ms)	120	1
B*m*MSTRT	Mechanical Slow Trip Alarm Threshold—BK*m* (1–999 ms)	50	1
B*m*MSCLT	Mechanical Slow Close Alarm Threshold—BK*m* (1–999 ms)	120	1
B*m*ITAT	Inactivity Time Alarm Threshold—BK*m* (N, 1–9999 days)	365	1
B*m*MRTIN	Motor Run Time Contact Input—BK*m* (SELOGIC Equation)	NA	
B*m*MRTAT	Motor Run Time Alarm Threshold—BK*m* (1–999 s)	25	1
B*m*KAIAT	kA Interrupt Capacity Alarm Threshold—BK*m* (N, 1–100%)	90	0.1
B*m*MKAI	Maximum kA Interrupt Rating—BK*m* (1–999 kA)	50	1
RST_BK*m*	Reset Monitoring Breaker *m* (SELOGIC Equation)	PLT04	

[a] m = S, T, U, W, X, Y.
[b] n = 1 if m = S; n = 2 if m = T; n = 3 if m = U, etc. The default value is NA when m = Y.

Table 8.27 settings are available if ETHFLTM := Y.

Table 8.27 Through-Fault Monitoring

Setting	Prompt	Default
ETHRFLT	Through-Fault Monitor Enable Condition (SELOGIC Equation)	NA
THFLTD	Through-Fault Terminal (S, T, U, W, X, Y[a], ST, TU, UW, WX)	S
TFLTIPU	Through-Fault Rated Current Pickup (1.05–20 p.u.)	4.75
THFLTPU	Through-Fault Alarm Pickup (50.0–900.0%)	100.0
TRFRZ	Percentage Transformer Impedance (2.0–40.0%)	10.0

[a] Terminal Y is available when ordered with all 5 A or all 1 A nominal CTs. Do not use Terminal Y for through-fault monitoring when REF protection is enabled (EREF ≠ N).

Table 8.28 Thermal Model Configuration

Setting	Prompt	Default
TRTYPE	Number of Transformers (1, 3)	1
TRWCON	Transformer Winding Connection (Y, D)	Y
TRWSEL	Transformer Winding Selection (S, T, ...Y[a], ST, ..., WX)	S
TRWNOM	Nominal Winding Voltage in kVLL (1.00–1000.00)	132.00
EDFTC	Enable Default Transformer Constants (Y, N)	Y
THWR	TRFR Rated Wdg Temp Rise Over Ambient (55°, 65°C)	65
NUMCS	Number of Cooling Stages (1–3)	1
TRDE	Transformer De-energized (SELOGIC Equation)	NA
D_AMB	Default Ambient Temperature (–50.00° to 100.0°C)	25.0

[a] Terminal Y is available when ordered with all 5 A or all 1 A nominal CTs. Do not use Terminal Y for thermal monitoring when REF protection is enabled (EREF ≠ N).

Table 8.29 Thermal Probe Selection

Setting	Prompt	Default
AMB_M	Ambient Temp. Meas. Probe (NA, RTD01–RTD12, RA001–RA256)	NA
AMB_F	Ambient Temp. Fault Condition (SELOGIC Equation)	NA
T*a*_OILM[a]	TRFR *a* Top-Oil Temp. Probe (NA, RTD01–RTD12, RA001–RA256)	NA
T*a*OIL_F[a]	T*a* Oil Temp. Fault Condition (SELOGIC Equation)	NA
AMBRTDF	Default Temp if Amb Temp RTD Fails (BUFF, SET)	SET

[a] a = 1–3.

Table 8.30 Cooling Stage Constants for Transformers (Sheet 1 of 2)

Setting[a]	Prompt	Default
T*c*CS*b*	TRFR *c* Cooling Stage *b* Activation (SELOGIC Equation)	NA
MVA*c*CS*b*	TRFR *c* MVA Rating Cooling Stage *b* (1.0–1000.0 MVA)	100
T*c*THOR*b*	Top-Oil Rise/Amb (0.1°–100.0°C)	See *Table 7.8*
T*c*THGR*b*	Hot-Spot Cond. Rise/Top Oil (0.1°–100.0°C)	See *Table 7.8*
T*c*RATL*b*	Ratio Losses (0.1–100.0)	See *Table 7.8*
T*c*OTR*b*	Oil Thermal Time Constant (0.10–20.00 hrs)	See *Table 7.8*
T*c*EXPN*b*	Oil Exponent (0.1–5.0)	See *Table 7.8*

Table 8.30 Cooling Stage Constants for Transformers (Sheet 2 of 2)

Setting[a]	Prompt	Default
T*c*EXPM*b*	Winding Exponent (0.1–5.0)	See *Table 7.8*
T*c*THS	Hot-Spot Thermal Time Constant (0.01–20.00 hr)	See *Table 7.8*

[a] b = c = 1–3 (b is the cooling stage; c is the transformer number).

Table 8.31 Default Transformer Constants (When EDFTC = Y)

IEEE	Cooling Stage Setting	THWR = 55°			THWR = 65°		
		CS=1	CS=2	CS=3	CS=1	CS=2	CS=3
$\Delta\Theta_{TO,R}$	THOR (°C)	45°	40°	37°	55°	50°	45°
$\Delta\Theta_{H,R}$	THGR (°C)	20°	25°	28°	25°	30°	35°
R	RATL	3.0	3.5	5.0	3.2	4.5	6.5
n	EXPN	0.8	0.9	1.0	0.8	0.9	1.0
$\tau_{TO,R}$	OTR	3.0	2.0	1.25	3.0	2.0	1.25
m	EXPM	0.8	0.8	1.0	0.8	0.8	1.0
τH	THS	0.08	0.08	0.08	0.08	0.08	0.08

Table 8.32 Thermal Loss-of-Life

Setting	Prompt	Default	Increment
TRLIFE	Nominal Insulation Life (1000–999999 hrs)	180000	1
T*d*BFFA[a]	Constant to Calc. FAA for TRFR *d* (0–100000)	0	1

[a] d = 1–3.

Table 8.33 Thermal Alarm Limits

Setting	Prompt	Default	Increment
TOT*x*[a]	Top-Oil Temp. Limit *x* (50°–150°C)	95	1
HST*x*[a]	Hot-Spot Limit *x* (80°–300°C)	100	1
T*d*CSEP[b]	TRFR *d* Cooling System Efficiency (5°–100°C)	15	1
FAAL*x*[a]	Aging Acceleration Factor Limit *x* (0.00–599.99)	100.00	0.01
RLOLL	Daily Loss-of-Life Limit (0.00–99.99%)	0.00	0.01
TLOLL	Total Loss-of-Life Limit (0.00–99.99%)	0.00	0.01

[a] x = 1 or 2.
[b] d = 1–3.

Table 8.34 settings are available if ETHRIEC := 1, 2, or 3.

Table 8.34 IEC Thermal (49) Elements (Sheet 1 of 2)

Setting	Prompt	Default
THRO1	Thermal Model 1 Operating Quantity	IASRMS
THRO2	Thermal Model 2 Operating Quantity	IBSRMS
THRO3	Thermal Model 3 Operating Quantity	ICSRMS
IBAS1	Basic Current Value in PU 1 (0.1–3)	1.1
IBAS2	Basic Current Value in PU 2 (0.1–3)	1.1
IBAS3	Basic Current Value in PU 3 (0.1–3)	1.1
IEQPU1	Eq. Heating Current Pick Up Value in PU 1 (0.05–1)	0.05

Table 8.34 IEC Thermal (49) Elements (Sheet 2 of 2)

Setting	Prompt	Default
IEQPU2	Eq. Heating Current Pick Up Value in PU 2 (0.05–1)	0.05
IEQPU3	Eq. Heating Current Pick Up Value in PU 3 (0.05–1)	0.05
KCONS1	Basic Current Correction Factor 1 (0.50–1.5)	1
KCONS2	Basic Current Correction Factor 2 (0.50–1.5)	1
KCONS3	Basic Current Correction Factor 3 (0.50–1.5)	1
TCONH1	Heating Thermal Time Constant 1 (1–500 min)	60
TCONH2	Heating Thermal Time Constant 2 (1–500 min)	60
TCONH3	Heating Thermal Time Constant 3 (1–500 min)	60
TCONC1	Cooling Thermal Time Constant 1 (1–500 min)	60
TCONC2	Cooling Thermal Time Constant 2 (1–500 min)	60
TCONC3	Cooling Thermal Time Constant 3 (1–500 min)	60
THLA1	Thermal Level Alarm Limit 1 (1.00–100%)	50
THLA2	Thermal Level Alarm Limit 2 (1.00–100%)	50
THLA3	Thermal Level Alarm Limit 3 (1.00–100%)	50
THLT1	Thermal Level Trip Limit 1 (1.00–150%)	80
THLT2	Thermal Level Trip Limit 2 (1.00–150%)	80
THLT3	Thermal Level Trip Limit 3 (1.00–150%)	80

Table 8.35 Thermal Ambient Compensation

Setting	Prompt	Default
TMAX1	Maximum Temperature of the Equipment 1 (80–300 C)	155
TMAX2	Maximum Temperature of the Equipment 2 (80–300 C)	155
TMAX3	Maximum Temperature of the Equipment 3 (80–300 C)	155

Group Settings

Table 8.36 Group Setting Categories (Sheet 1 of 2)

Settings	Reference
Relay Configuration	*Table 8.37*
CT Data	*Table 8.38*
Potential Transformer Data	*Table 8.39*
Voltage Reference Terminal Selection	*Table 8.40*
Differential Element Zone 1 (87T)	*Table 8.41*
Differential Element Zone 2 (87B)	*Table 8.42*
Restricted Earth Fault Element	*Table 8.43*
Line 1 Elements	*Table 8.44*
Line Configuration	*Table 8.45*
Mho Phase Distance Element Reach	*Table 8.46*
Quad Phase Distance Element Reach	*Table 8.47*
Phase Distance Fault Detectors	*Table 8.48*

Table 8.36 Group Setting Categories (Sheet 2 of 2)

Settings	Reference
Mho Ground Distance Element Reach	*Table 8.49*
Quad Ground Distance Element Reach	*Table 8.50*
Zero-Sequence Compensation Factor	*Table 8.51*
Ground Distance Fault Detectors	*Table 8.52*
Zone/Level Direction	*Table 8.53*
Distance Element Common Time Delay	*Table 8.54*
Line Directional Control Settings	*Table 8.55*
Out-of-Step Blocking	*Table 8.56*
Pole-Open Detection	*Table 8.57*
Switch-Onto-Fault Scheme	*Table 8.58*
Load Encroachment	*Table 8.59*
Line Harmonic Blocking	*Table 8.60*
Terminal *m* Overcurrent and Directional Elements	*Table 8.61*
Terminal *m* Phase Overcurrent Level *a*[a, b]	*Table 8.62*
Terminal *m* Negative-Sequence Overcurrent Element Levels[a]	*Table 8.63*
Terminal *m* Zero-Sequence Overcurrent Element Levels[a]	*Table 8.64*
Terminal *m* Harmonic Blocking	*Table 8.65*
Inverse-Time Overcurrent Elements	*Table 8.66*
Terminal Current Unbalance Elements	*Table 8.67*
Volts-Per-Hertz Elements	*Table 8.68*
Volts-Per-Hertz Level 2 Definite Time	*Table 8.69*
Volts-Per-Hertz Level 2, User-Defined Curve *h*[c]	*Table 8.70*
Synchronism-Check (25) Elements	*Table 8.71*
Undervoltage (27) Elements	*Table 8.72*
Overvoltage (59) Elements	*Table 8.73*
Frequency (81) Elements	*Table 8.74*
Breaker Failure Logic	*Table 8.75*
Overpower (32) Elements	*Table 8.76*
Underpower (32) Elements	*Table 8.77*
Demand Metering Elements	*Table 8.78*
Trip Logic	*Table 8.79*
Close Logic	*Table 8.80*
Reclosing Logic	*Table 8.81*

[a] m = S, T, U, W, X, Y, 1, 2, 3, 4 (combined terminals: 1 = ST, 2 = TU, 3 = UW, 4 = WX).
[b] a = 1–3.
[c] h = 1 or 2.

Table 8.37 Relay Configuration (Sheet 1 of 2)

Setting	Prompt[a]	Default
ECTTERM	Enable Current Terminals (OFF or combo of S, T, U, W, X, Y[b])	S, T
EPTTERM	Enable Voltage Terminals (OFF or combo of V, Z)	OFF

Table 8.37 Relay Configuration (Sheet 2 of 2)

Setting	Prompt[a]	Default
E87	Enable Zone 1 Differential Terminals (OFF or combo of S, T, U, W, X, Y[b, c])	S, T
E87Z2[d]	Enable Zone 2 Differential Terminals (OFF or combo of S, T, U, W, X, Y[b, c])	OFF
EREF[e]	Enable Restricted Earth Fault Element (N, 1–3)	N
E50[f]	Enable 50 Elements (OFF or combo of S, T, U, W, X, Y[b, c], ST, TU, UW, WX)	OFF
E51	Enable Inverse Time Overcurrent Elements (N, 1–20)	N
ELINE[d]	Enable Line Protection Elements (N, 1)	N
E46	Enable Current Unbalance (OFF or combo of S, T, U, W, X, Y[b, c])	OFF
E59	Enable Over Voltage Elements (N, 1–5)	N
E27	Enable Under Voltage Elements (N, 1–5)	N
E81	Enable Frequency Elements (N, 1–6)	N
E24	Enable Volts per Hertz Element (Y, N)	N
E25	Enable Synchronization Check (OFF or combo of S, T, U, W, X, Y[b, c])	OFF
EBFL	Enable Bk Failure Protection (OFF or combo of S, T, U, W, X, Y[b, c])	OFF
BF_SCHM	Breaker Failure Scheme (Y, Y1)	Y
EPCAL	Enable Power Calculation Terminals (OFF or combo of S, T, U, W, X, Y[b, c])	OFF
E32	Enable Over/Under Power Elements (N, 1–10)	N
EDEM	Enable Demand Metering (N, 1–10)	N
ELOP	Enable Loss-of-Potential (Y, Y1, N)	Y1
E79[d]	Enable Reclosing Terminals (OFF or combo of S, T, U, W, X, Y[b])	OFF

[a] "Combo" means "combination"; enter these "combo" settings delimited with either commas or spaces.
[b] Terminal Y is available when ordered with all 5 A or all 1 A nominal CTs.
[c] Cannot be used when REF is enabled.
[d] This feature is included as a relay ordering option.
[e] REF cannot be enabled when Terminal Y is used for Zone 1 or Zone 2 differential elements.
[f] Combination terminals are only available for channels with the same nominal current rating and same CT connection (CTCON).

Table 8.38 CT Data

Setting	Prompt	Default	Increment
CTR*m*[a]	Current Trans. Ratio Terminal *m* (1–15000)	100	1
CTCON*m*[a]	Current Trans. Connection Terminal *m* (Y, D)	Y	
CTRY*n*[b]	Current Trans. Ratio Terminal Y*n* (1–15000)	100	1
CTCOMP*m*[a, c]	CT Connection Compensation Terminal *m* (DAB, DAC)	DAB	

[a] m = S, T, U, W, X, Y.
[b] n = 1, 2, 3.
[c] Available on terminals with CTCONm = D.

Table 8.39 Potential Transformer Data

Setting[a]	Prompt	Default	Increment
PTR*k*	Potential Trans. Ratio Terminal *k* (1.0–10000.0)	2000.0	0.1
PTCON*k*	Potential Trans. Connection Terminal *k* (Y, D)	Y	
VNOM*k*	PT Nominal Voltage (L-L) Term. *k* (30.00–300 V, sec)[b]	110.00	0.01

[a] k = V, Z.
[b] Range is 30.00–430 V, sec, if the Terminal k uses LEA voltage inputs.

Table 8.40 Voltage Reference Terminal Selection

Setting	Prompt	Default
VREF*m*[a]	Voltage Reference For Terminal *m* (OFF, V, Z)	OFF
ALTV*m*[a]	Alternate Voltage Source for Terminal m (SELOGIC Equation)	NA

[a] m = S, T, U, W, X, Y.

Table 8.41 Differential Element Zone 1 (87T) (Sheet 1 of 2)

Setting	Prompt	Default	Increment
E87T*m*[a]	Terminal *m* included in 87 Element (SELOGIC Equation)	1	
ICOM	Internal CT Conn. Compensation Enabled (Y, N)	Y	
T*m*CTC[a]	Terminal *m* CT Conn. Compensation (0–13)	11	1
T*m*ANG[a]	Terminal *m* Angle Compensation (–179.99 to 180 deg)	30.00	0.01
T*m*ZSR[a]	Terminal *m* Zero-Sequence Removal (Y, N)	Y	
MVA	Transformer Power Capacity (OFF, 1–5000 MVA)	OFF	1
VTERM*m*[a]	Terminal *m* Line-to-Line Voltage (1.00–1000 kV)	275.00	0.01
TAP*m*[a]	Terminal *m* Current Tap (0.5–175 A, secondary)[b]	1.00	0.01
O87P	Differential Element Oper. Current PU (0.10–4)	0.30	0.01
SLP1	Slope 1 Percentage (5.00–90%)	15.00	0.01
SLP2	Slope 2 Percentage (5.00–90%)	75.00	0.01
E87U	Enable Unres. Diff. Elem. (OFF or combo of F, R, W)[c]	F	
U87P	Unrestrained Element Current PU (1.00–20)	8.00	0.01
DIOPR	Incr. Operate Current Threshold PU (0.10–10)	1.20	0.01
DIRTR	Incr. Restraint Current Threshold PU (0.10–10)	1.20	0.01
E87HB	Enable Harmonic Blocked Diff. Element (Y, E, N)	N	
E87HR	Enable Harmonic Restrained Diff. Element (Y, W, N)	Y	
E87Q	Enable Neg. Seq. Diff. Element (Y, E, N)	Y	
E87UNB	Enable Waveshape Unblocking Logic (Y, N)	N	
PCT2	Second-Harmonic Percentage (OFF, 5–100%)	15	1
PCT4	Fourth-Harmonic Percentage (OFF, 5–100%)	15	1
PCT5	Fifth-Harmonic Percentage (OFF, 5–100%)	35	1
TH5P	Fifth-Harmonic Alarm Threshold PU (OFF, 0.2–3.2)	OFF	0.1
TH5D	Fifth-Harmonic Alarm Delay (0.000–8000 cyc)	30.000	0.125
87CORE	XFMR Core Type, Three Legs or Single Cores (T, S)	T	
87QP	Neg. Seq. Differential Op current (0.05–1 pu)	0.30	0.01

Table 8.41 Differential Element Zone 1 (87T) (Sheet 2 of 2)

Setting	Prompt	Default	Increment
SLPQ1	Neg. Seq. Differential Slope (5–100%)	25	1
87QD	Neg. Seq. Differential Element Delay (2.000–9999 cyc)	10.000	0.125

[a] m = S, T, U, W, X, Y.
[b] Range is 0.10–35.00 A, sec if the Terminal m uses a 1 A nominal CT.
[c] "Combo" means "combination"; enter these "combo" settings delimited with either commas or spaces.

Table 8.42 Differential Element Zone 2 (87B)

Setting[a]	Prompt	Default	Increment
E87T*m*2[b]	Terminal *m* included in 87 Element (SELOGIC Equation)	1	
T*m*CTP2[b]	Terminal *m* Current Transformer Polarity (P, N)	P	
EATAP2	Enable Automatic TAP Calculation (Y, N)	N	
TAP*m*2[b, c]	Terminal *m* Current Tap (1.0–175 A, secondary)[d]	1.00	0.01
O87P2	Differential Element Oper. Current PU (0.10–4)	1.00	0.01
SLP12	Slope 1 Percentage (5.00–90%)	60.00	0.01
SLP22	Slope 2 Percentage (5.00–90%)	80.00	0.01
DIOPR2	Incr. Operate Current Threshold PU (0.10–10)	1.20	0.01
DIRTR2	Incr. Restraint Current Threshold PU (0.10–10)	1.20	0.01

[a] These features are included as a relay ordering option.
[b] m = S, T, U, W, X, Y.
[c] This setting is set automatically based off the CTR values of terminals included within the differential zone.
[d] Range is 1.00–35.00 A secondary if the Terminal m uses a 1 A nominal CT.

Table 8.43 Restricted Earth Fault Element

Setting[a]	Prompt	Default	Increment
REFRF*a*	Restraint Qty REF Elem. *a* (OFF or combo of S, T, U, W, X)[b, c]	OFF	
REF50G*a*	Residual Current Sensitivity Pickup (0.05–3 pu)	0.25	0.01
TCREF*a*	Torque Control REF Element *a* (SELOGIC Equation)	NOT REF*a*BK	
REF50P*a*	REF Op. Current Inst O/C *a* Pickup (OFF, 0.25–100 A, sec)[d]	OFF	0.01
REF50D*a*	REF Inst O/C *a* Delay (0.00–16000 cyc)	10.00	0.25
REF51P*a*	REF Inv. Time O/C *a* P/U (OFF, 0.25–16 A, sec)[e]	OFF	0.01
REF51C*a*	REF Inv. Time O/C *a* Curve (U1–U5, C1–C5)	U1	
RF51TD*a*	REF Inv. Time O/C *a* Time Dial (0.50–15)	0.50	0.01
RF51RS*a*	REF Inv. Time O/C *a* EM Reset (Y, N)	N	
RF51TC*a*	REF Inv. Time O/C *a* Torque Cont. (SELOGIC Equation)	1	

[a] a = 1–3, as determined by the EREF setting.
[b] "Combo" means "combination"; enter these "combo" settings delimited with either commas or spaces.
[c] Terminals that have delta connection are not supported.
[d] Range is 0.05–20.00 if the terminal uses 1 A nominal CTs.
[e] Range is 0.05–3.20 if the selected terminal, REFRFa, uses 1 A nominal CTs.

Table 8.44 Line 1 Elements

Setting[a]	Prompt	Default
LINEIL1	Line Current Source (OFF, S, T, U, W, X, Y[b, c], ST, TU, UW, WX)	OFF
E21PL1	Phase Distance Characteristic (OFF, Mho, Quad)	OFF
E21GL1	Ground Distance Characteristic (OFF, Mho, Quad)	OFF
E21MPL1	Mho Phase Distance Zones (N, 1–4)	N
E21XPL1	Quadrilateral Phase Distance Zones (N, 1–4)	N
E21MGL1	Mho Ground Distance Zones (N, 1–4)	N
E21XGL1	Quadrilateral Ground Distance Zones (N, 1–4)	N
EXFMRL1	In-Zone Transformer (N or combo of 1, 2, 3, 4)[d]	N
ESPQDL1	Enable Self-Polarized Quadrilateral Elements (Y, N)	N
ECVTL1	Enable Zone 1 CVT Transient Detection (Y, N)	N
ESCMPL1	Enable Series-Compensated Line Logic (Y, N)	N
EOOSL1	Enable Out-of-Step (N or combo of 1, 2, 3, 4)[d]	N
ESOTFL1	Enable Switch-Onto-Fault (Y, N)	N
ELOADL1	Enable Load Encroachment (Y, N)	N
EHBL1	Enable Harmonic Blocking (Y, N)	N
EADVSL1	Enable Advanced Line Settings (Y, N)	N

[a] These features are included as a relay ordering option.
[b] Terminal Y is available when ordered with all 5 A or all 1 A nominal CTs.
[c] Cannot be used when REF is enabled.
[d] "Combo" means "combination"; enter these "combo" settings delimited with either commas or spaces.

Table 8.45 Line Configuration

Setting	Prompt	Default	Increment
Z1MAGL1	Pos.-Seq. Line Impedance Mag. (0.05–255 ohms, sec)[a]	7.8	0.01
Z1ANGL1	Pos.-Seq. Line Impedance Angle (5.00–90 deg)[b]	84	0.01
Z0MAGL1	Zero-Seq. Line Impedance Mag. (0.05–255 ohms, sec)[a]	24.8	0.01
Z0ANGL1	Zero-Seq. Line Impedance Angle (5.00–90 deg)	81.5	0.01

[a] Range is 0.25 to 1275 Ω, sec if the terminal selected by LINEIL1 uses 1 A nominal CTs.
[b] The range of Z1ANGL1 is limited to 45 degrees when out-of-step blocking is enabled by Group setting EOOSL1.

Table 8.46 Mho Phase Distance Element Reach (Sheet 1 of 2)

Setting	Prompt	Default	Increment
Z1MPL1	Zone 1 Reach (OFF, 0.05-64 ohms, sec)[a]	6.24	0.01
Z2MPL1	Zone 2 Reach (OFF, 0.05-64 ohms, sec)[a]	9.36	0.01
Z3MPL1	Zone 3 Reach (OFF, 0.05-64 ohms, sec)[a]	1.87	0.01
Z4MPL1	Zone 4 Reach (OFF, 0.05-64 ohms, sec)[a]	OFF	0.01
Z1MPTC1	Zone 1 Mho Phase Torque Control (SELOGIC Equation)	NOT (H2BKL1 OR H5BKL1 OR ZLOADL1)	

Table 8.46 Mho Phase Distance Element Reach (Sheet 2 of 2)

Setting	Prompt	Default	Increment
Z2MPTC1	Zone 2 Mho Phase Torque Control (SELOGIC Equation)	NOT (H2BKL1 OR H5BKL1 OR ZLOADL1)	
Z3MPTC1	Zone 3 Mho Phase Torque Control (SELOGIC Equation)	NOT (H2BKL1 OR H5BKL1 OR ZLOADL1)	
Z4MPTC1	Zone 4 Mho Phase Torque Control (SELOGIC Equation)	NOT (H2BKL1 OR H5BKL1 OR ZLOADL1)	

[a] Range is 0.25 to 320 Ω, sec if the terminal selected by LINEIL1 uses 1 A nominal CTs.

Table 8.47 Quad Phase Distance Element Reach

Setting	Prompt	Default	Increment
XP1L1	Zone 1 Reactance (OFF, 0.05–64 ohms, sec)[a]	OFF	0.01
RP1L1	Zone 1 Resistance (0.05–50 ohms, sec)[b]	12.48	0.01
XP2L1	Zone 2 Reactance (OFF, 0.05–64 ohms, sec)[a]	OFF	0.01
RP2L1	Zone 2 Resistance (0.05–50 ohms, sec)[b]	18.72	0.01
XP3L1	Zone 3 Reactance (OFF, 0.05–64 ohms, sec)[a]	OFF	0.01
RP3L1	Zone 3 Resistance (0.05–50 ohms, sec)[b]	3.64	0.01
XP4L1	Zone 4 Reactance (OFF, 0.05–64 ohms, sec)[a]	OFF	0.01
RP4L1	Zone 4 Resistance (0.05–150 ohms, sec)[c]	31.2	0.01
TANGPL1[d]	Phase Nonhomogeneous Corr. Ang (–40.0 to 40 deg)	–7	0.1
Z1XPTC1	Zone 1 Quad Phase Torque Control (SELOGIC Equation)	NOT (H2BKL1 OR H5BKL1 OR ZLOADL1)	
Z2XPTC1	Zone 2 Quad Phase Torque Control (SELOGIC Equation)	NOT (H2BKL1 OR H5BKL1 OR ZLOADL1)	
Z3XPTC1	Zone 3 Quad Phase Torque Control (SELOGIC Equation)	NOT (H2BKL1 OR H5BKL1 OR ZLOADL1)	
Z4XPTC1	Zone 4 Quad Phase Torque Control (SELOGIC Equation)	NOT (H2BKL1 OR H5BKL1 OR ZLOADL1)	

[a] Range is 0.25 to 320 Ω, sec if the terminal selected by LINEIL1 uses 1 A nominal CTs.
[b] Range is 0.25 to 250 Ω, sec if the terminal selected by LINEIL1 uses 1 A nominal CTs.
[c] Range is 0.25 to 750 Ω, sec if the terminal selected by LINEIL1 uses 1 A nominal CTs.
[d] Setting only available when Group setting EADVSL1 = Y.

Table 8.48 Phase Distance Fault Detectors

Setting[a]	Prompt	Default	Increment
Z50P1L1	Zone 1 Phase Fault Detector (0.50–170.00 A, sec)[b]	0.5	0.01
Z50P2L1	Zone 2 Phase Fault Detector (0.50–170.00 A, sec)[b]	0.5	0.01
Z50P3L1	Zone 3 Phase Fault Detector (0.50–170.00 A, sec)[b]	0.5	0.01
Z50P4L1	Zone 4 Phase Fault Detector (0.50–170.00 A, sec)[b]	0.5	0.01

[a] Setting only available when Group setting EADVSL1 = Y.
[b] Range is 0.1 to 34.00 A, sec if the terminal selected by LINEIL1 uses 1 A nominal CTs.

Table 8.49 Mho Ground Distance Element Reach

Setting	Prompt	Default	Increment
Z1MGL1	Zone 1 Reach (OFF, 0.05–64 ohms, sec)[a]	6.24	0.01
Z2MGL1	Zone 2 Reach (OFF, 0.05–64 ohms, sec)[a]	9.36	0.01
Z3MGL1	Zone 3 Reach (OFF, 0.05–64 ohms, sec)[a]	1.87	0.01
Z4MGL1	Zone 4 Reach (OFF, 0.05–64 ohms, sec)[a]	OFF	0.01
Z1MGTC1	Zone 1 Mho Ground Torque Control (SELOGIC Equation)	NOT (H2BKL1 OR H5BKL1)	
Z2MGTC1	Zone 2 Mho Ground Torque Control (SELOGIC Equation)	NOT (H2BKL1 OR H5BKL1)	
Z3MGTC1	Zone 3 Mho Ground Torque Control (SELOGIC Equation)	NOT (H2BKL1 OR H5BKL1)	
Z4MGTC1	Zone 4 Mho Ground Torque Control (SELOGIC Equation)	NOT (H2BKL1 OR H5BKL1)	

[a] Range is 0.25 to 320 Ω, sec if the terminal selected by LINEIL1 uses 1 A nominal CTs.

Table 8.50 Quad Ground Distance Element Reach (Sheet 1 of 2)

Setting	Prompt	Default	Increment
XG1L1	Zone 1 Reactance (OFF, 0.05–64 ohms, sec)[a]	OFF	0.01
RG1L1	Zone 1 Resistance (0.05–50 ohms, sec)[b, c]	12.48	0.01
XG2L1	Zone 2 Reactance (OFF, 0.05–64 ohms, sec)[a]	OFF	0.01
RG2L1	Zone 2 Resistance (0.05–50 ohms, sec)[b, c]	18.72	0.01
XG3L1	Zone 3 Reactance (OFF,0.05–64 ohms, sec)[a]	OFF	0.01
RG3L1	Zone 3 Resistance (0.05–50 ohms, sec)[b, c]	3.64	0.01
XG4L1	Zone 4 Reactance (OFF, 0.05–64 ohms, sec)[a]	OFF	0.01
RG4L1	Zone 4 Resistance (0.05–150 ohms, sec)[b]	31.2	0.01
XGPOLL1[d]	Quad Ground Polarizing Quantity (I2, IG)	I2	
TANGGL1[d]	Ground Nonhomogeneous Corr. Ang (–40.0 to 40 deg)	–7	0.1
Z1XGTC1	Zone 1 Quad Ground Torque Control (SELOGIC Equation)	NOT (H2BKL1 OR H5BKL1)	
Z2XGTC1	Zone 2 Quad Ground Torque Control (SELOGIC Equation)	NOT (H2BKL1 OR H5BKL1)	

Table 8.50 Quad Ground Distance Element Reach (Sheet 2 of 2)

Setting	Prompt	Default	Increment
Z3XGTC1	Zone 3 Quad Ground Torque Control (SELOGIC Equation)	NOT (H2BKL1 OR H5BKL1)	
Z4XGTC1	Zone 4 Quad Ground Torque Control (SELOGIC Equation)	NOT (H2BKL1 OR H5BKL1)	

[a] Range is 0.25 to 320 Ω, sec if the terminal selected by LINEIL1 uses 1 A nominal CTs.
[b] Range is 0.25 to 750 Ω, sec if the terminal selected by LINEIL1 uses 1 A nominal CTs.
[c] Range is 0.25 to 250 Ω, sec if the terminal selected by LINEIL1 uses 1 A nominal CTs.
[d] Setting only available when Group setting EADVSL1 = Y.

Table 8.51 Zero-Sequence Compensation Factor

Setting	Prompt	Default	Increment
k0M1L1	Zone 1 ZSC Factor Magnitude (AUTO, 0.000–10)	0.726	0.001
k0A1L1	Zone 1 ZSC Factor Angle (–179.99 to 180 deg)	–3.69	0.01
k0M2L1	Zone 2 ZSC Factor Magnitude (0.000–10)	0.726	0.001
k0A2L1	Zone 2 ZSC Factor Angle (–179.99 to 180 deg)	–3.69	0.01
k0M3L1	Zone 3 ZSC Factor Magnitude (0.000–10)	0.726	0.001
k0A3L1	Zone 3 ZSC Factor Angle (–179.99 to 180 deg)	–3.69	0.01
k0M4L1	Zone 4 ZSC Factor Magnitude (0.000–10)	0.726	0.001
k0A4L1	Zone 4 ZSC Factor Angle (–179.99 to 180 deg)	–3.69	0.01

Table 8.52 Ground Distance Fault Detectors

Setting[a]	Prompt	Default	Increment
Z50G1L1	Zone 1 Ground Fault Detector (0.50–100.00 A, sec)[b]	0.5	0.01
Z50G2L1	Zone 2 Ground Fault Detector (0.50–100.00 A, sec)[b]	0.5	0.01
Z50G3L1	Zone 3 Ground Fault Detector (0.50–100.00 A, sec)[b]	0.5	0.01
Z50G4L1	Zone 4 Ground Fault Detector (0.50–100.00 A, sec)[b]	0.5	0.01

[a] Setting only available when Group setting EADVSL1 = Y.
[b] Range is 0.1 to 20.00 A, sec if the terminal selected by LINEIL1 uses 1 A nominal CTs.

Table 8.53 Zone/Level Direction

Setting	Prompt	Default
DIR1L1	Zone 1 Directional Control (F, R)	F
DIR2L1	Zone 2 Directional Control (F, R)	F
DIR3L1	Zone 3 Directional Control (F, R)	R
DIR4L1	Zone 4 Directional Control (F, R)	R

Table 8.54 Distance Element Common Time Delay

Setting	Prompt	Default	Increment
Z1DL1	Zone 1 Time Delay (OFF,0.00–16000 cyc)	0	0.25
Z2DL1	Zone 2 Time Delay (OFF,0.00–16000 cyc)	20	0.25
Z3DL1	Zone 3 Time Delay (OFF,0.00–16000 cyc)	60	0.25
Z4DL1	Zone 4 Time Delay (OFF,0.00–16000 cyc)	0	0.25

Table 8.55 Line Directional Control Settings

Setting[a]	Prompt	Default	Increment
CTPL1	Current Transformer Polarity Terminal (P, N)	P	
50FPL1	Forward Dir. O/C Pickup (0.25–5 A, sec)[b]	0.5	0.01
50RPL1	Reverse Dir. O/C Pickup (0.25–5 A, sec)[b]	0.25	0.01
Z2FL1	Fwd Dir Z2 Threshold (–64–64 ohms, sec)[c]	–0.3	0.01
Z2RL1	Rev Dir Z2 Threshold (–64–64 ohms, sec)[c]	0.3	0.01
A2L1	Pos.-Seq. Restraint Factor, I2/I1 (0.02–0.50)	0.1	0.01
ORDERL1	Ground Dir. Element Priority (Q,V,QV,VQ)	QV	
K2L1	Zero-Seq. Restraint Factor, I2/I0 (0.10–1.2)	0.2	0.01
Z0FL1	Fwd Dir Z0 Threshold (–64–64 ohms, sec)[c]	–0.3	0.01
Z0RL1	Rev Dir Z0 Threshold (–64–64 ohms, sec)[c]	0.3	0.01
A0L1	Pos.-Seq. Restraint Factor, I0/I1 (0.02–0.5)	0.1	0.01
32GVSL1	Zero-seq. Dir. Voltage Superv. (0.0–20 V, sec)	2	0.1
DIRBKL1	Block Phase and Ground Directional Elements. (SELOGIC Equation)	H2BKL1 OR H5BKL1	

[a] Setting only available when Group setting EADVSL1 = Y.
[b] Range is 0.05 to 1 A, sec if the terminal selected by LINEIL1 uses 1 A nominal CTs.
[c] Range is −320 to 320 Ω, sec if the terminal selected by LINEIL1 uses 1 A nominal CTs.

Table 8.56 Out-of-Step Blocking (Sheet 1 of 2)

Setting	Prompt	Default	Increment
OSBDL1	Out-of-Step Block Time Delay (0.50–8000 cyc)	2	0.25
OSBLTL1	Latch Out-of-Step Blocking (Y, N)	N	
X1TOL1	Outer Zone Reactance -Top (0.05 to 140 ohms, sec)[a]	23	0.01
X1TIL1	Inner Zone Reactance -Top (0.05 to 140 ohms, sec)[a]	21	0.01
R1ROL1	Outer Zone Resistance -Right (0.05 to 140 ohms, sec)[a]	23	0.01
R1RIL1	Inner Zone Resistance -Right (0.05 to 140 ohms, sec)[a]	21	0.01
X1BOL1[b]	Outer Zone Reactance -Bottom (–0.05 to –140 ohms, sec)[c]	–23	0.01
X1BIL1[b]	Inner Zone Reactance -Bottom (–0.05 to –140 ohms, sec)[c]	–21	0.01
R1LOL1[b]	Outer Zone Resistance -Left (–0.05 to –140 ohms, sec)[c]	–23	0.01
R1LIL1[b]	Inner Zone Resistance -Left (–0.05 to –140 ohms, sec)[c]	–21	0.01
50QU1L1[b]	Zone 1 Neg.-Seq. Current Supervision (OFF, 0.50–100 A)[d]	OFF	0.01
UBD1L1[b]	Zone 1 OOS Unblock Delay (0.00–8000 cyc)	0.5	0.25
50QU2L1[b]	Zone 2 Neg.-Seq. Current Supervision (OFF, 0.50–100 A)[d]	OFF	0.01
UBD2L1[b]	Zone 2 OOS Unblock Delay (0.00–8000 cyc)	0.5	0.25
50QU3L1[b]	Zone 3 Neg.-Seq. Current Supervision (OFF, 0.50–100 A)[d]	OFF	0.01
UBD3L1	Zone 3 OOS Unblock Delay (0.00–8000 cyc)	0.5	0.25
50QU4L1[b]	Zone 4 Neg.-Seq. Current Supervision (OFF, 0.50–100 A)[d]	OFF	0.01

Table 8.56 Out-of-Step Blocking (Sheet 2 of 2)

Setting	Prompt	Default	Increment
UBD4L1[b]	Zone 4 OOS Unblock Delay (0.00–8000 cyc)	0.5	0.25
UBOSFL1[b]	Out-of-Step Angle Unblock Rate (1–10)	4	1

[a] Range is 0.25 to 700 Ω, sec if the terminal selected by LINEIL1 uses 1 A nominal CTs.
[b] Setting only available when Group setting EADVSL1= Y.
[c] Range is −0.25 to −700 Ω, sec if the terminal selected by LINEIL1 uses 1 A nominal CTs.
[d] Range is 0.1 to 20 A, sec if the terminal selected by LINEIL1 uses 1 A nominal CTs.

Table 8.57 Pole-Open Detection

Setting	Prompt	Default	Increment
3PODL1	Three-Pole Open Dropout Delay (0.00–60 cyc)	1	0.25
OPHDOL1	Line Open Phase Threshold (0.010–5 A, sec)	0.05	0.001

Table 8.58 Switch-Onto-Fault Scheme

Setting	Prompt	Default	Increment
EVRSL1	Switch-Onto-Fault Voltage Reset (Y, N)	N	
VRSPUL1	Switch-Onto-Fault Reset Voltage (0.60–1.00 pu)	0.8	0.01
52ENDL1	52A Pole Open Time Delay (OFF, 0.00–16000 cyc)	10	0.25
CLENDL1	Close Enable Time Delay (OFF, 0.00–16000 cyc)	OFF	0.25
SOTFDL1	Switch-Onto-Fault Enable Duration (0.50–16000 cyc)	10	0.25
CLMONL1	Close Signal Monitor (SELOGIC Equation)	NA	
TRSOTF1	Switch-Onto-Fault Trip (SELOGIC Equation)	NA	

Table 8.59 Load Encroachment

Setting	Prompt	Default	Increment
ZLFL1	Forward Load Impedance (0.05–64 ohms, sec)[a]	9.22	0.01
ZLRL1	Reverse Load Impedance (0.05–64 ohms, sec)[a]	9.22	0.01
PLAFL1	Forward Load Positive Angle (–90.0 to 90 deg)	30	0.1
NLAFL1	Forward Load Negative Angle (–90.0 to 90 deg)	–30	0.1
PLARL1	Reverse Load Positive Angle (90.0 to 270 deg)	150	0.1
NLARL1	Reverse Load Negative Angle (90.0 to 270 deg)	210	0.1

[a] Range is 0.25 to 320 Ω, sec if the terminal selected by LINEIL1 uses 1 A nominal CTs

Table 8.60 Line Harmonic Blocking

Setting	Prompt	Default	Increment
PCT2L1	Second-Harmonic Percentage (OFF, 5–100%)	15	1
PCT4L1	Fourth-Harmonic Percentage (OFF, 5–100%)	15	1
PCT5L1	Fifth-Harmonic Percentage (OFF, 5–100%)	35	1

Table 8.61 Terminal m Overcurrent and Directional Elements (Sheet 1 of 2)

Setting[a]	Prompt	Default	Increment
E50*m*	Type of O/C Elements Enabled Terminal *m* (Combo of P, Q, G)[b]	P	
E67*m*[c]	Enable Directional Elements Terminal *m* (Y, N)	N	

Table 8.61 Terminal m Overcurrent and Directional Elements (Sheet 2 of 2)

Setting[a]	Prompt	Default	Increment
CTP*m*	Current Transformer Polarity Terminal *m* (P, N)	P	
Z1ANG*m*	Pos.-Seq. Line Impedance Angle (5.00–90 deg)	89.00	0.01
Z0ANG*m*	Zero-Seq. Line Impedance Angle (5.00–90.00)	85.00	0.01
DIRBLK*m*	Block *m* Phase and Ground Dir. Element (SELOGIC equation)	87XBK2 OR 87XBK5	
EADVS	Enable Advanced Settings Terminal *n* (Y, N)	N	
50FP*m*	Forward Dir. O/C Pickup (0.25–5.0 A, sec)[d]	0.50	0.01
50RP*m*	Reverse Dir. O/C Pickup (0.25–5.00 A, sec)[d]	0.25	0.01
Z2F*m*	Forward Dir. Z2 Threshold (–64.00 to 64.00 ohms, sec)[e]	–0.30[f]	0.01
Z2R*m*	Reverse Dir. Z2 Threshold (–64.00 to 64.00 ohms, sec)	0.30[g]	0.01
A2*m*	Pos.-Seq. Restraint Factor, I2/I1 (0.02–0.50)	0.10	0.01
ORDER*m*	Ground Dir. Element Priority (Q, V, QV, VQ)	QV	
K2*m*	Zero-Seq. Restraint Factor, I2/I0 (0.10–1.20)	0.20	0.01
Z0F*m*	Forward Dir. Z0 Threshold (–64.00 to 64.00 ohms, sec)[e]	–0.30[f]	0.01
Z0R*m*	Reverse Dir. Z0 Threshold (–64.00 to 64.00 ohms, sec)[e]	0.30[g]	0.01
A0*m*	Pos.-Seq. Restraint Factor, I0/I1 (0.02–0.50)	0.10	0.01
32GVS*m*	Zero-seq. Dir. Voltage Superv. (0.0–20 V, sec)	2.00	0.1

[a] m = S, T, U, W, X, Y, 1, 2, 3, 4 (combined terminals: 1 = ST, 2 = TU, 3 = UW, 4 = WX).
[b] "Combo" means "combination"; enter these "combo" settings delimited with either commas or spaces.
[c] E67m cannot be enabled on terminals with delta-connected PTs or CTs.
[d] Range is 0.05–1.0 A, sec if Terminal m uses 1 A nominal CTs.
[e] Range is –320.00 to 320.00 ohms, sec if Terminal m uses 1 A nominal CTs.
[f] Default is –1.5 if Terminal m uses 1 A nominal CTs.
[g] Default is 1.5 if Terminal m uses 1 A nominal CTs.

Table 8.62 Terminal m Phase Overcurrent Element Level a

Setting[a, b]	Prompt	Default	Increment
50*m*P*a*P	Phase Inst O/C Pickup Level *a* (OFF, 0.25–100 A, sec)[c]		0.01
67*m*P*a*TC	Phase Inst O/C level *a* Torque Ctrl (SELOGIC Equation)	*m*F32P AND PLT03	
67*m*P*a*D	Phase Inst O/C level *a* Delay (0.00–16000 cyc)	0.00	0.25

[a] m = S, T, U, W, X, Y, 1, 2, 3, 4 (combined terminals: 1 = ST, 2 = TU, 3 = UW, 4 = WX).
[b] a = 1–3.
[c] Range is 0.05–20 A, sec if Terminal m uses 1 A nominal CTs.

Table 8.63 Terminal m Negative-Sequence Overcurrent Element Levels[a]

Setting[b]	Prompt	Default	Increment
50*m*Q*a*P	Neg-Seq Inst O/C pickup level *a* (OFF, 0.25–100 A, sec)[c]	OFF	0.01
67*m*Q*a*TC	Neg-Seq Inst O/C level *a* Torque Ctrl (SELOGIC Equation)	*m*F32Q	
67*m*Q*a*D	Neg-Seq Inst O/C level *a* Delay (0.00–16000 cyc)	0.00	0.25

[a] m = S, T, U, W, X, Y, 1, 2, 3, 4 (combined terminals: 1 = ST, 2 = TU, 3 = UW, 4 = WX).
[b] a = 1–3.
[c] Range is 0.05–20 A, sec if Terminal m uses 1 A nominal CTs.

Table 8.64 Terminal m Zero-Sequence Overcurrent Element Levels

Setting[a, b]	Prompt	Default	Increment
50*m*G*a*P	Zero-Seq Inst O/C Pickup Level *a* (OFF, 0.25–100 A, sec)[c]	OFF	0.01
67*m*G*a*TC	Zero-Seq Inst O/C Lvl *a* Torque Ctrl (SELOGIC Equation)	*m*F32G	
67*m*G*a*D	Zero-Seq Inst O/C Lvl *a* Delay (0.00–16000 cyc)		0.25

[a] m = S, T, U, W, X, Y, 1, 2, 3, 4 (combined terminals: 1 = ST, 2 = TU, 3 = UW, 4 = WX).
[b] a = 1–3.
[c] Range is 0.05–20 A, sec if Terminal m uses 1 A nominal CTs.

Table 8.65 Terminal m Harmonic Blocking

Setting	Prompt	Default	Increment
PCT2*m*[a, b]	Second-Harmonic Percentage Term *m* (OFF, 5–100%)	OFF	1

[a] m = S, T, U, W, X, Y, 1, 2, 3, 4 (combined terminals: 1 = ST, 2 = TU, 3 = UW, 4 = WX).
[b] This feature is included as a relay ordering option.

Table 8.66 Inverse-Time Overcurrent Elements

Setting[a]	Prompt	Default
51O*xx*	Inv. Time O/C *xx* Operating Quantity	IMAXSF
51P*xx*	Inv. Time O/C *xx* Pickup Value (SEL Math Equation)[b]	1.00
51C*xx*	Inv. Time O/C *xx* Curve Selection (U1–U5, C1–C5)	U1
51TD*xx*	Inv. Time O/C *xx* Time Dial (SEL Math Equation)[c]	1.00
51RS*xx*	Inv. Time O/C *xx* EM Reset (Y, N)	N
51TC*xx*	Inv. Time O/C *xx* Torque Control (SELOGIC Equation)	PLT09

[a] xx = 01–20.
[b] Usable range depends on the quantity selected for 51Oxx. For a quantity on a 5 A terminal, the range is 0.25–16.0 A, secondary. For a quantity on a 1 A terminal, the range is 0.05–3.2 A, secondary. See Selectable Time-Overcurrent Element (51) on page 5.68 for more details.
[c] Usable range depends on the curve selected for 51Cxx. For curves U1–U5, the range is 0.50–15.0. For curves C1–C5, the range is 0.05–1.00. See Selectable Time-Overcurrent Element (51) on page 5.68 for more details.

Table 8.67 Terminal Current Unbalance Elements

Setting[a]	Prompt	Default	Increment
46*m*PU	Terminal *m* Current Unbalance Pickup (5%–100%)	20	1
46*m*CD	Terminal *m* Close Delay (0.00–6000 cyc)	10.00	0.25
46*m*BD	Terminal *m* Current Unbalance Delay (0.00–6000 cyc)	10.00	0.25

[a] m = S, T, U, W, X, Y.

Table 8.68 Volts-Per-Hertz Elements

Setting	Prompt	Default	Increment
24VSRC	Voltage Source for V/Hz Calculation (V, Z)	V	
24D1P	Level 1 Volts/Hertz P/U (100%–200%)	110	1
24D1D	Level 1 Time Delay (0.04–6000 s)	10.00	0.01
24TC	Volts/Hertz Torque Control (SELOGIC Equation)	1	
24CCS	Level 2 Composite Curve (OFF, DD, U1, U2)	OFF	

Table 8.69 Volts-Per-Hertz Level 2 Definite Time

Setting	Prompt	Default	Increment
24D2P1	Level 2 Volts/Hertz PU1 (100%–200%)	105	1
24D2D1	Level 2 Time Delay 1 (0.04–6000 s)	10.00	0.01
24D2P2	Level 2 Volts/Hertz PU2 (101%–200%)	110	1
24D2D2	Level 2 Time Delay 2 (0.04–6000 s)	5.00	0.01

Table 8.70 Volts-Per-Hertz Level 2, User-Defined Curve h[a]

Setting	Prompt	Default	Increment
24U*h*TC	User Defined Curve *h* Torque Control (SELOGIC Equation)	1	
24U*h*NP	Number of Points on User *h* Curve (3–20)	3	1
24U*hxx*[b]	User Def. Curve *h*, Point *xx* (100%–200%, 0.04–6000 s)	200, 400.00	1, 0.01
24U*h*CR	User Def. Curve *h* Reset Time (0.01–400 s)	0.01	0.01

[a] h = 1, 2.
[b] xx = 01-20.

Table 8.71 Synchronism-Check (25) Elements (Sheet 1 of 2)

Setting[a]	Prompt	Default	Increment
SYNCP	Synchronism Reference (VAV, VBV, VCV, VAZ, VBZ, VCZ)[b]	VAV	
25_SCHM	Synchronism-Check Voltage Scheme (Y, Y1, Y2)	Y	
25VL[c]	Voltage Window Low Threshold (20.0–200 V, sec)	55.0	0.1
25VH[c]	Voltage Window High Threshold (20.0–200 V, sec)	70.0	0.1
25VDIF[d]	Synchronism Voltage Difference Check (50.0–100.0 V, sec)	10.0	0.1
SYNCS*m*	Synchronism Source *m* (VAV, VBV, VCV, VAZ, VBZ, VCZ)[b]	VAZ	
KS*m*M	Synchronism Source *m* Ratio Factor (0.10–3)	1.00	0.01
KS*m*A	Synchronism Source *m* Angle Shift (–179.99 to +180 deg)	0.00	0.01
ALTS*m*[e]	Alternative Synchronism Source *m* (SELOGIC Equation)	NA	
ASYNCS*m*[e]	Alternative Synchronism Source *m* (VAV, VBV, VCV, VAZ, VBZ, VCZ)[b]	VBZ	
AKS*m*M[e]	Alternative Synchronism Source *m* Ratio Factor (0.10–3)	1.00	0.01
AKS*m*A[e]	Alternative Synchronism Source *m* Angle Shift (–179.99 to +180 deg)	0.00	0.01
25SFBK*m*[f]	Maximum Slip Frequency BK*m* (OFF, 0.005–0.5 Hz)	0.050	0.001

Table 8.71 Synchronism-Check (25) Elements (Sheet 2 of 2)

Setting[a]	Prompt	Default	Increment
ANG1BK*m*	Maximum Angle Difference 1 BK*m* (3.0–80 deg)	10.0	0.1
ANG2BK*m*	Maximum Angle Difference 2 BK*m* (3.0–80 deg)	10.0	0.1
TCLSBK*m*[f]	Breaker *m* Close Time (1.00–30 cyc)	8.00	0.25
BSYNBK*m*	Block Synchronism-Check—BK*m* (SELOGIC Equation)	NA	

[a] m = S, T, U, W, X, Y.
[b] Range is determined by EPTTERM setting. SYNCP, SYNCSm, and ASYNCSm must be unique per Breaker m; otherwise, the following warning message is displayed: "Polarizing and synchronizing voltage sources are not unique."
[c] Hidden if 25_SCHM does not include Y or Y2.
[d] Hidden if 25_SCHM does not include Y1 or Y2.
[e] Set ALTSm to a value other than NA to enable the other alternative settings.
[f] When maximum slip-frequency setting 25SFBKm = OFF, the relay implements the uncompensated synchronism-check logic and Breaker m close time setting (TCLSBKm) is hidden.

Table 8.72 Undervoltage (27) Elements

Setting[a]	Prompt	Default	Increment
27O*n*	U/V Element *n* Operating Quantity	VNMINVF	
27P*n*P1	U/V Element *n* Level 1 P/U (2.00–300 V, sec)[b]	20.00	0.01
27TC*n*	U/V Element *n* Torque Control (SELOGIC Equation)	NOT VVBK	
27P*n*P2	U/V Element *n* Level 2 P/U (2.00–300 V, sec)[b]	15.00	0.01
27P*n*D1	U/V Element *n* Level 1 Delay (0.00–16000 cyc)	10.00	0.25

[a] n = 1–5.
[b] Range is 4.00–520 V, sec for minimum, maximum, and phase-to-phase elements.

Table 8.73 Overvoltage (59) Elements

Setting[a]	Prompt	Default	Increment
59O*n*	O/V Element *n* Operating Quantity	VNMAXVF	
59P*n*P1	O/V Element *n* Level 1 P/U (2.00–300 V, sec)[b]	76.00	0.01
59TC*n*	O/V Element *n* Torque Control (SELOGIC Equation)	1	
59P*n*D1	O/V Element *n* Level 1 Delay (0.00–16000 cyc)	10.00	0.25
59P*n*P2	O/V Element *n* Level 2 P/U (2.00–300 V, sec)[b]	80.00	0.01

[a] n = 1–5.
[b] Range is 4.00–520 V, sec for minimum, maximum, and phase-to-phase elements.

Table 8.74 Frequency (81) Elements

Setting[a]	Prompt	Default	Increment
81UVSP	81 Element Under Voltage Superv. (20.00–200 V, sec)	85.00	0.01
81D*n*P	Level *n* Pickup (40.01–69.99 Hz)	61.00	0.01
81D*n*D	Level *n* Time Delay (0.04–400 s)	2.00	0.01

[a] n = 1–6.

Table 8.75 Breaker Failure Logic (Sheet 1 of 2)

Setting[a]	Prompt	Default	Increment
EXBF*m*	Enable External Breaker Fail—BKR *m* (SELOGIC Equation)	NA	
EXBFSP*m*	External Bkr Fail Superv—BKR *m* (SELOGIC Equation)	1	

Table 8.75 Breaker Failure Logic (Sheet 2 of 2)

Setting[a]	Prompt	Default	Increment
EBFPU*m*	Ext. Brkr Fail Init PU Delay—BKR *m* (0.00–6000 cyc)	6.00	0.125
50FPU*m*	Fault Current Pickup—BKR *m* (0.50–50 A, sec)[b]	10.00	0.01
BFPU*m*	Brkr Fail Init Pickup Delay—BKR *m* (0.00–6000 cyc)	6.00	0.125
RTPU*m*	Retrip Delay—BKR *m* (0.00–6000 cyc)	3.00	0.125
BF*m*	Breaker Fail Initiate—BKR *m* (SELOGIC Equation)	NA	
ATBFI*m*	Alt Breaker Fail Initiate—BKR *m* (SELOGIC Equation)	NA	
ENINBF*m*	Enable Neutral Breaker Failure—BKR *m* (SELOGIC Equation)	NA	
INFPU*m*	Neutral Current Pickup—BKR *m* (0.50–50 A, sec)[c]	0.50	0.01
EBFIS*m*	Breaker Fail Initiate Seal-In—BKR *m* (Y, N)	N	
BFISP*m*	Brkr Fail Init Seal-In Delay—BKR *m* (0.00–1000 cyc)	3.00	0.125
BFIDO*m*	Brkr Fail Init Dropout Delay—BKR *m* (0.00–1000 cyc)	1.50	0.125

[a] m = S, T, U, W, X, Y.
[b] Range is 0.10–10 A, sec if Terminal m uses 1 A nominal CTs.
[c] Range is 0.10–10.00 A, sec if Terminal m uses 1 A nominal CTs.

Table 8.76 Overpower (32) Elements

Setting[a]	Prompt	Default	Increment
32OPO*gg*	Overpower Op. Qty. Elem *gg*	OFF	
32OPP*gg*	Overpower Pickup Elem *gg* (–20000.00 to 20000 VA, sec)[b, c]	2000.00	0.01
32OPD*gg*	Overpower Delay Elem *gg* (0.00–16000 cyc)	10.00	0.25
E32OP*gg*	Enable Overpower Elem *gg* (SELOGIC Equation)	NA	

[a] gg = 01–10.
[b] Settings range is –20000 to –5, 5 to 20000 VA, secondary.
[c] Range is –4000 to –1, 1 to 4000 VA, sec if the selected element, 32OPOgg, is on a 1 A nominal CT.

Table 8.77 Underpower (32) Elements

Setting[a]	Prompt	Default	Increment
32UPO*gg*	Underpower Op. Qty. Elem *gg*	OFF	
32UPP*gg*	Underpower Pickup Elem *gg* (–20000.00 to 20000 VA, sec)[b, c]	5.00	0.01
32UPD*gg*	Underpower Delay Elem *gg* (0.00–16000 cyc)	10.00	0.25
E32UP*gg*	Enable Underpower Elem *gg* (SELOGIC Equation)	NA	

[a] gg = 01–10.
[b] Settings range is –20000 to –5, 5 to 20000 VA, secondary.
[c] Range is –4000.00 to 4000 VA, sec if the selected element, 32UPOgg, is on a 1 A nominal CT.

Table 8.78 Demand Metering Elements (Sheet 1 of 2)

Setting[a]	Prompt	Default	Increment
DMTY*gg*	Demand Met. Type Element *gg* (THM, ROL)	THM	
DMOQ*gg*	Demand Met. Op. Qty. Element *gg*	IMXSRS	
DMPU*gg*	Demand Met. P/U Element *gg* (0.05–16 A, sec)[b]	2.00	0.01

Table 8.78 Demand Metering Elements (Sheet 2 of 2)

Setting[a]	Prompt	Default	Increment
DMTC*gg*	Demand Met. Time Const. Element *gg* (5, 10, ..., 300 min)	5	5
EDM*gg*	Enable Demand Metering Element *gg* (SELOGIC Equation)	1	

[a] gg = 01–10.
[b] Range is 0.01–3.2 A, sec if the selected element, DMOQgg, is on a 1 A nominal CT.

Table 8.79 Trip Logic

Setting	Prompt	Default	Increment
TRXFMR	Trip Transformer (SELOGIC Equation)	(87R OR REFF1) AND NOT SVSTST	
ULTXFMR	Unlatch Trip Transformer (SELOGIC Equation)	TRGTR	
TR*m*[a]	Trip Terminal *m* (SELOGIC Equation)	(50*m*P1 OR 50*m*Q1) AND (NOT SVSTST) OR OC*m*	
ULTR*m*[a]	Unlatch Trip Terminal *m* (SELOGIC Equation)	TRGTR	
TDURD	Minimum Trip Duration (2.000–8000 cyc)	5.00	0.125
ER	Event Report Trigger Equation (SELOGIC Equation)	50SQ1 OR 50TQ1	
FAULT	Fault Condition Equation (SELOGIC Equation)	50SQ1 OR 50TQ1	

[a] m = S, T, U, W, X, Y.

Table 8.80 Close Logic

Setting[a]	Prompt	Default	Increment
CL*m*	Close Terminal *m* (SELOGIC Equation)	LB10 OR CC*m*	
ULCL*m*	Unlatch Close Terminal *m* (SELOGIC Equation)	52CL*m* or TRIP*m*	
CFD	Close Failure Delay (OFF, 2.00–99999 cyc)	4.00	0.125

[a] m = S, T, U, W, X, Y.

Table 8.81 Reclosing Logic (Sheet 1 of 2)

Setting[a]	Prompt	Default	Increment
NSHOT*m*	Number of Reclosures (N, 1–4)	1	
79DTL*m*	Recloser Drive to Lockout (SELOGIC Equation)	NA	
79RI*m*	Reclose Initiation (SELOGIC Equation)	TRIP*m*	
79RIH*m*	Line Open Failure Delay (OFF, 1–99999 cycles)	15	1
79OI1*m*	Open Interval 1 Delay (1–99999 cycles)	300	1
79OI2*m*	Open Interval 2 Delay (1–99999 cycles)	300	1
79OI3*m*	Open Interval 3 Delay (1–99999 cycles)	300	1
79OI4*m*	Open Interval 4 Delay (1–99999 cycles)	300	1
79RCD*m*	Cycle State Reclaim Time Delay (1–99999 cycles)	900	1
79RCLD*m*	Lockout State Reclaim Time Delay (1–99999 cycles)	300	1
79BRCT*m*	Block Reclaim Timers (SELOGIC Equation)	TRIP*m*	

Table 8.81 Reclosing Logic (Sheet 2 of 2)

Setting[a]	Prompt	Default	Increment
79SKP*m*	Skip Reclosing Shot (SELOGIC Equation)	NA	
79CLS*m*	Reclose Supervision (SELOGIC Equation)	1	
79CLSD*m*	Reclose Supervision Delay (OFF, 1–99999 cycles)	60	1

[a] m = S, T, U, W, X, Y.

Protection Logic: Default Settings

The SEL-487E provides 250 lines of freeform SELOGIC control equations in each of the six settings groups. The following are the protection logic default settings.

1: # BREAKER S OPEN AND CLOSE CMD
2: PCT01PU := 60
3: PCT01DO := 0
4: PCT01IN := PB1 AND 52CLS #CMD TO OPEN BKR S
5: PCT02PU := 60
6: PCT02DO := 0
7: PCT02IN := PB7 AND NOT 52CLS #CMD TO CLOSE BKR S
8: # BREAKER T OPEN AND CLOSE CMD
9: PCT03PU := 60
10: PCT03DO := 0
11: PCT03IN := PB2 AND 52CLT #CMD TO OPEN BKR T
12: PCT04PU := 60
13: PCT04DO := 0
14: PCT04IN := PB8 AND NOT 52CLT #CMD TO CLOSE BKR T
15: PLT03S := PB3_PUL AND NOT PLT03 # DIRECTIONAL OVER-CURRENT ENABLED
16: PLT03R := PB3_PUL AND PLT03
17: PLT04S := PB4_PUL AND NOT PLT04 # BREAKER WEAR LEVELS RESET
18: PLT04R := (PB4_PUL AND PLT04) OR RST_BKS OR RST_BKT
19: PLT09S := PB9_PUL AND NOT PLT09 # ADAPTIVE OVERCUR-RENT ENABLED
20: PLT09R := PB9_PUL AND PLT09

Automation Freeform SELOGIC Control Equations

See *Section 12: Settings in the SEL-400 Series Relays Instruction Manual* for a description of automation SELOGIC control equations. The SEL-487E supports 10 blocks of 100 lines.

Output Settings

Section 12: Settings in the SEL-400 Series Relays Instruction Manual contains a description of the output settings of the relay. This section describes SEL-487E specific default values.

Table 8.82 Main Board Defaults

Setting	Default
OUT201	TRIPS OR PCT01Q
OUT202	TRIPT OR PCT03Q
OUT203	PCT02Q
OUT204	PCT04Q
OUT205	NA
OUT206	NA
OUT207	NA
OUT208	NOT (SALARM OR HALARM)

Front-Panel Settings

See *Section 12: Settings in the SEL-400 Series Relays Instruction Manual* for a complete description of front-panel settings. This section lists the SEL-487E specific default settings values.

Table 8.83 Front-Panel Settings Defaults (Sheet 1 of 3)

Setting	Default
FP_TO	15
EN_LEDC	G
TR_LEDC	R
PB1_LED	NOT 52CLS
PB1_COL	GO
PB2_LED	NOT 52CLT
PB2_COL	GO
PB3_LED	PLT03
PB3_COL	AO
PB4_LED	RST_BKS OR RST_BKT
PB4_COL	AO
PB5_LED	NA
PB5_COL	AO
PB6_LED	NA
PB6_COL	AO
PB7_LED	52CLS
PB7_COL	RO
PB8_LED	52CLT
PB8_COL	RO
PB9_LED	PLT09
PB9_COL	AO
PB10LED	NA
PB10COL	AO
PB11LED	NA

Table 8.83 Front-Panel Settings Defaults (Sheet 2 of 3)

Setting	Default
PB11COL	AO
PB12LED	NA
PB12LED	AO
T1_LED	TRIPS
T1LEDL	Y
T1LED	RO
T2_LED	TRIPT
T2LEDL	Y
T2LEDC	RO
T3_LED	87RA OR 87UA
T3LEDL	Y
T3LEDC	RO
T4_LED	87RB OR 87UB
T4LEDL	Y
T4LEDC	RO
T5_LED	87RC OR 87UC
T5LEDL	Y
T5LEDC	RO
T6_LED	REF51T1
T6LEDL	Y
T6LEDC	RO
T7_LED	FBFS
T7LEDL	Y
T7LEDC	RO
T8_LED	FBFT
T8LEDL	Y
T8LEDC	RO
T9_LED	50TP1 OR 67TP1T OR 51T01
T9LEDL	Y
T9LEDC	RO
T10_LED	24D1T OR 24D2T OR 24U1T OR 24U2T
T10LEDL	Y
T10LEDC	RO
T11_LED	271P1T OR 591P1T
T11LEDL	Y
T11LEDC	RO
T12_LED	81D1T
T12LEDL	Y
T12LEDC	RO
T13_LED	32OPT01 OR 32UPT01
T13LEDL	Y

Table 8.83 Front-Panel Settings Defaults (Sheet 3 of 3)

Setting	Default
T13LEDC	RO
T14_LED	NA
T14LEDL	Y
T14LEDC	AO
T15_LEDC	87ABK5 OR 87BBK5 OR 87CBK5 OR 87XBK2
T15LEDL	N
T15LEDC	AO
T16_LED	VAVFM > 55 # VAV ON
T16LEDL	N
T16LEDC	AO
T17_LED	VBVFM > 55 # VBV ON
T17LEDL	N
T17LEDC	AO
T18_LED	VCVFM > 55 # VCV ON
T18LEDL	N
T18LEDC	AO
T19_LED	TFLTALA OR TFLTALB OR TFLTALC
T19LEDL	Y
T19LEDC	AO
T20_LED	LOPV OR LOPZ
T20LEDL	Y
T20LEDC	AO
T21_LED	FAA1
T21LEDL	Y
T21LEDC	AO
T22_LED	TIRIG
T22LEDL	N
T22LEDC	AO
T23_LED	CON
T23LEDL	N
T23LEDC	AO
T24_LED	FREQOK
T24LEDL	N
T24LEDC	AO

The SEL-487E does not use the selectable screens as shown in *Section 4: Front-Panel Operations in the SEL-400 Series Relays Instruction Manual*, but instead uses a freeform settings block for listing the selected screens. The SEL-487E rotating display default (RDD) is the single screen: `RMS_VLL`.

Report Settings

The SEL-487E contains the Report settings described in *Section 12: Settings in the SEL-400 Series Relays Instruction Manual*, except that the SEL-487E does not support HIF event reports.

Port Settings

The SEL-487E port settings are as described in *Section 12: Settings in the SEL-400 Series Relays Instruction Manual*.

The Fast Message read data access settings listed in *Table 12.8 in the SEL-400 Series Relays Instruction Manual* are all included in the SEL-487E.

Table 8.84 Mirrored Bits Protocol Defaults

Setting	Default
MBANA1	I1SM
MBANA2	I1TM
MBANA3	I1UM
MBANA4	I1WM
MBANA5	I1XM
MBANA6	V1VM
MBANA7	V1ZM

DNP3 Settings—Custom Maps

The SEL-487E DNP3 custom map settings operate as described in *Section 12: Settings in the SEL-400 Series Relays Instruction Manual*. See *DNP3 Communication on page 10.10* to see the default map configuration.

Notes Settings

Use the notes settings like a text pad to leave notes about the relay in the Notes area of the relay. See *Section 12: Settings in the SEL-400 Series Relays Instruction Manual* for additional information on notes settings.

Bay Settings

Table 8.85 Bay Settings (Sheet 1 of 3)

Setting	Prompt	Default
MIMIC	Busbar One-line Screen Number (1–999)	1
BAYNAME	Bay Name (max 20 characters)	BAY 1

Table 8.85 Bay Settings (Sheet 2 of 3)

Setting	Prompt	Default
BAYLAB*x*[a]	Bay Label *x* (max 40 pixels, aprox. 8 char.)	BAYLAB*x*
BUSNAM*x*[a]	Busbar *x* Name (max 40 pixels, aprox. 8 char.)	BUSNAM*x*
EQPNAM*n*[e]	Equip. *n* Name (max 40 pixels, aprox. 20 char.)	EQ*n*
BK1	Bkr 1 Assignment (NA, S, T, U, W, X, Y)	S
BK2	Bkr 2 Assignment (NA, S, T, U, W, X, Y)	T
BK3	Bkr 3 Assignment (NA, S, T, U, W, X, Y)	U
BK4	Bkr 4 Assignment (NA, S, T, U, W, X, Y)	W
BK5	Bkr 5 Assignment (NA, S, T, U, W, X, Y)	X
BK6	Bkr 6 Assignment (NA, S, T, U, W, X, Y)	Y
B*y*HMINM[b]	Breaker *y* HMI Name (max 17 pixels, aprox. 3 char.)	BK*y*
B*y*CTLNM[b]	Breaker *y* Cntl. Scr. Name (max 15 characters)	Breaker *y*
52*y*CLSM[b]	Breaker *y* Close Status (SELOGIC Equation)	52CL*y*
52*y*_ALM[b]	Breaker *y* Alarm Status (SELOGIC Equation)	52AL*y*
52*y*RACK	Breaker *y* Racked Status (SELOGIC Equation)	1
52*y*TEST	Breaker *y* Test Status (SELOGIC Equation)	0
D*r*HMIN[c]	Disconnect *m* HMI Name (max 18 pixels, aprox. 4 char.)[d]	SW*m*
D*r*CTLN[c]	Disconnect *m* Control Scr. Name (max 15 char.)[d]	BB *m*
89AM*r*[c]	Disconnect *m* N/O Contact (SELOGIC Equation)[d]	IN203 for 89AM01, 1 for 89AM02–89AM10
89BM*r*[c]	Disconnect *m* N/C Contact (SELOGIC Equation)[d]	IN204 for 89BM01, 0 for 89BM02–89BM10
89ALP*r*[c]	Disconnect *m* Alarm Pickup Delay (1–99999 cyc)[d]	300
89CCN*r*[c]	Dis. *m* Remote Close Control (SELOGIC Equation)[d]	89CC*r*
89OCN*r*[c]	Dis. *m* Remote Open Control (SELOGIC Equation)[d]	89OC*r*
89CST*r*[c]	Dis. *m* Close Seal-in Time (OFF, 1–99999 cyc)[d]	280
89CTL*r*	Dis. *r* Front Panel Ctl. Enable (SELOGIC Equation)	1
89CIT*r*[c]	Dis. *m* Close Immobility Time (OFF, 1–99999 cyc)[d]	20
89CRS*r*[c]	Disconnect *m* Close Reset (SELOGIC Equation)[d]	89CL*r* OR 89CSI*r*
89CBL*r*[c]	Disconnect *m* Close Block (SELOGIC Equation)[d]	NA
89OST*r*[c]	Dis. *m* Open Seal-in Time (OFF, 1–99999 cyc)	280
89OIT*r*[c]	Dis. *m* Open Immobility Time (OFF, 1–99999 cyc)[d]	20
89ORS*r*[c]	Disconnect *m* Open Reset (SELOGIC Equation)[d]	89OPN*r* OR 89OSI*r*
89OBL*r*[c]	Disconnect *m* Open Block (SELOGIC Equation)[d]	NA
89CIR*r*[c]	Dis. *m* Close Immob. Time Reset (SELOGIC Equation)[d]	NOT 89OPN*r*
89OIR*r*[c]	Dis. *m* Open Immob. Time Reset (SELOGIC Equation)[d]	NOT 89CL*r*

Table 8.85 Bay Settings (Sheet 3 of 3)

Setting	Prompt	Default
MDELE*n*[e]	Analog Quantity	<Blank>
MDNAM*x*[a]	Pre-text	<Blank>
MDSET*x*[a]	Text Formatting {w.d}	<Blank>
MDCLR*x*[a]	Post-text	
MDSCA*x*[a]	Scale Format {s}	1
LOCAL	Local Control (SELOGIC Equation)	PLT06

[a] x = 1–9.
[b] y = S, T, U, W, X, Y.
[c] r = 01–20.
[d] m = 1–20.
[e] n = 1–6.

This page intentionally left blank

SECTION 9

ASCII Command Reference

You can use a communications terminal or terminal emulation program to set and operate the relay. This section explains the commands that you send to the SEL-487E-5 Relay by using SEL ASCII communications protocol. The relay responds to commands such as settings, metering, and control operations.

This section lists all the commands supported by the relay, but most are described in *Section 14: ASCII Command Reference in the SEL-400 Series Relays Instruction Manual*. This section provides information on commands and command options that are unique to the SEL-487E.

This section lists ASCII commands alphabetically. Commands, command options, and command variables that you enter are shown in bold. Lowercase italic letters and words in a command represent command variables that you determine based on the application (for example, Circuit Breaker identifier *n* = S, T, U, W, X, or Y, Remote Bit number *nn* = 01–96, and level).

Command options appear with brief explanations about the command function. Refer to the references listed with the commands for more information on the relay function corresponding to the command or examples of the relay response to the command.

You can simplify the task of entering commands by shortening any ASCII command to the first three characters; for example, **ACCESS** becomes **ACC**. Always send a carriage return <CR> character, or a carriage return character followed by a line feed character <CR><LF>, to command the relay to process the ASCII command. Usually, most terminals and terminal programs interpret the **<Enter>** key as a <CR>. For example, to send the **ACCESS** command, type **ACC <Enter>**.

Tables in this section show the access level(s) where the command or command option is active. Access levels in the SEL-487E are Access Level 0, Access Level 1, Access Level B (breaker), Access Level P (protection), Access Level A (automation), Access Level O (output), Access Level 2, and Access Level C.

Description of Commands

Table 9.1 lists all the commands supported by the relay with the corresponding links to the descriptions in *Section 14: ASCII Command Reference in the SEL-400 Series Relays Instruction Manual*.

Command List

Table 9.1 SEL-487E List of Commands (Sheet 1 of 3)

Command	Location of Command in Section 14: ASCII Command Reference in the SEL-400 Series Relays Instruction Manual
2ACCESS	*2ACCESS on page 14.1*
89CLOSE *n*	*89CLOSE n on page 14.2* (The SEL-487E supports 20 disconnects.)
89OPEN *n*	*89OPEN n on page 14.2* (The SEL-487E supports 20 disconnects.)
AACCESS	*AACCESS on page 14.3*
ACCESS	*ACCESS on page 14.3*
BACCESS	*BACCESS on page 14.3*
BNAME	*BNAME on page 14.4*
BREAKER *n*	*BREAKER on page 14.4* (The SEL-487E supports six circuit breakers, designated S, T, U, W, X, and Y.)
CAL	*CAL on page 14.5*
CASCII	*CASCII on page 14.6*
CBREAKER	*CBREAKER on page 14.6* (The SEL-487E supports six circuit breakers, designated S, T, U, W, X, and Y.)
CEVENT	*CEVENT on page 14.7* (The SEL-487E supports an 8-samples/cycle large resolution event report. It does not support the **CEV L** option.)
CFG CTNOM *i j*	*CFG CTNOM on page 14.10* (In the SEL-487E, two digits are used to indicate the nominal CT currents. See *Table 2.8* and *Table 2.9* for a complete list of the parameter options.)
CHISTORY	*CHISTORY on page 14.11*
CLOSE *n*	*CLOSE n on page 14.11* (The SEL-487E supports six circuit breakers, designated S, T, U, W, X, and Y.)
COMMUNICATIONS *c*	*COMMUNICATIONS on page 14.12*
COM HSR	*COM HSR on page 14.14*
COM PRP	*COM PRP on page 14.14*
COM PTP	*COM PTP on page 14.15*
COM RTC	*COM RTC on page 14.17*
COM SV	*COM SV on page 14.18*
CONTROL *nn*	*CONTROL nn on page 14.25*
COPY *m n*	*COPY on page 14.26*
CPR	*CPR on page 14.27*
CSER	*CSER on page 14.27*
CSTATUS	*CSTATUS on page 14.29*
CSUMMARY	*CSUMMARY on page 14.29*
DATE	*DATE on page 14.30*
DNAME X	*DNAME X on page 14.31*
DNP	*DNP on page 14.31*
ETHERNET	*ETHERNET on page 14.31*
EVENT	*EVENT on page 14.33* (The SEL-487E supports standard 4-samples/cycle and large resolution 8-samples/cycle event reports. It does not support the **EVE L** option.)
EVE DIF	See *EVE DIF on page 9.4* in this section.
EXIT	*EXIT on page 14.37*
FILE	*FILE on page 14.37*
GOOSE	*GOOSE on page 14.38*

Table 9.1 SEL-487E List of Commands (Sheet 2 of 3)

Command	Location of Command in Section 14: ASCII Command Reference in the SEL-400 Series Relays Instruction Manual
GROUP	*GROUP on page 14.41*
HELP	*HELP on page 14.41*
HISTORY	*HISTORY on page 14.41*
ID	*ID on page 14.43*
LOOPBACK	*LOOPBACK on page 14.44*
MAC	*MAC on page 14.46*
MAP	*MAP on page 14.46*
METER	*METER on page 14.47* (For all other **METER** options, see *METER on page 9.4* in this section.)
MET AMV	*MET AMV on page 14.47*
MET ANA	*MET ANA on page 14.48*
MET BAT	*MET BAT on page 14.48* (The SEL-487E provides battery metering for one battery monitor channel.)
MET D	*MET D on page 14.48*
MET DIF	See *MET DIF on page 9.5* in this section.
MET DIF A	See *MET DIF A on page 9.5* in this section.
MET E	See *MET E on page 9.6* in this section.
MET PM	*MET PM on page 14.49*
MET PMV	*MET PMV on page 14.50*
MET RMS	See *MET RMS on page 9.6* in this section.
MET RTC	*MET RTC on page 14.50*
MET RTD	*MET T on page 14.50* (The **MET RTD** command in the SEL-487E is the same as the **MET T** command in other SEL-400 Series Relays.)
MET SEC	See *MET SEC on page 9.6* in this section.
OACCESS	*OACCESS on page 14.51*
OPEN *n*	*OPEN n on page 14.51* (The SEL-487E supports six circuit breakers, designated S, T, U, W, X, and Y.)
PACCESS	*PACCESS on page 14.52*
PASSWORD	*PASSWORD on page 14.52*
PING	*PING on page 14.53*
PORT	*PORT on page 14.53*
PROFILE	*PROFILE on page 14.54*
PULSE	*PULSE on page 14.55*
QUIT	*QUIT on page 14.55*
RTC	*RTC on page 14.56*
SER	*SER on page 14.56*
SET	*SET on page 14.58* (*Table 9.9* lists the class and instance options available in the SEL-487E.)
SHOW	*SHOW on page 14.59* (*Table 9.10* lists the class and instance options available in the SEL-487E.)
SNS	*SNS on page 14.60*
STATUS	*STATUS on page 14.60*
SUMMARY	*SUMMARY on page 14.62*
TARGET	*TARGET on page 14.63*
TEC	*TEC on page 14.65*
TEST DB	*TEST DB on page 14.65*

Table 9.1 SEL-487E List of Commands (Sheet 3 of 3)

Command	Location of Command in Section 14: ASCII Command Reference in the SEL-400 Series Relays Instruction Manual
TEST DB2	*TEST DB2 on page 14.66*
TEST FM	*TEST FM on page 14.68*
TEST SV	*TEST SV on page 14.69*
TFE	See *TFE on page 9.8* in this section.
THE	See *THE on page 9.9* in this section.
TIME	*TIME on page 14.71*
TIME Q	*TIME Q on page 14.72*
TRIGGER	*TRIGGER on page 14.73*
VECTOR	*VECTOR on page 14.73*
VERSION	*VERSION on page 14.73*
VIEW	*VIEW on page 14.75*

EVENT

EVE DIF

Use **EVE DIF** to display the differential report.

Table 9.2 EVE DIF Command

Command	Description	Access Level
EVE DIF	Display the differential report	1, B, P, A, O, 2

METER

The **METER** command displays reports about quantities the relay measures in the power system (voltages, currents, frequency, remote analogs, etc.) and internal relay operating quantities (math variables and analog quantities).

MET

Use the **MET** command to view fundamental metering quantities. The relay filters harmonics and subharmonics to present only measured quantities at the power system fundamental operating frequency. Meter values are display only for those terminals included in the ECTTERM setting, otherwise the relay displays `Terminal Not Enabled For Metering`.

For combined terminals, meter values are displayed only for those terminals included in the ECTTERM setting that also have the same VREF*w* and CTCON*w* settings. If this is not the case, the relay displays `Terminal Not Enabled For Metering`. If ECTTERM is set to OFF, then rms, fundamental, and secondary metering are not be available, and the relay displays `No Terminals Enabled For Metering`.

Table 9.3 MET Command

Command[a, b]	Description	Access Level
MET	Display fundamental metering data of the first enabled terminal	1, B, P, A, O, 2
MET *n k*	Display Terminal *n* fundamental metering quantities	1, B, P, A, O, 2
MET N *k*	Display neutral current fundamental metering quantities	1, B, P, A, O, 2

[a] n = S, T, U, W, X, Y, ST, TU, UW, WX.
[b] k = optional parameter to determine the number of times the relay repeats the response.

The **MET** command without options shows the fundamental metering data of the terminal that appears first in the ECTTERM setting. Specify a specific terminal by using the terminal parameter command options. For example, specify **MET T** to view the fundamental metering quantities of Terminal T.

Some situations require that you repeatedly monitor the power system for a brief period; specify a number after any **MET** command to automatically repeat the command.

MET DIF

Use the **MET DIF** command to view the differential current metering data, in multiples of tap.

Table 9.4 MET DIF Command

Command[a]	Description	Access Level
MET DIF	Displays the differential operate and restraint quantities for Zone 1	1, B, P, A, O, 2
MET DIF Z*n* *k*[b]	Displays the differential operate and restraint quantities for Zone *n*	1, B, P, A, O, 2

[a] k = optional parameter to determine the number of times the relay repeats the response.
[b] n = 1, 2.

If differential Zone *n* is disabled (where *n* = 1, 2), the relay displays the message `Differential Element n Disabled`.

MET DIF A

Use the MET DIF A command to view the same quantities as MET DIF, plus additional information for matrix compensation, differential settings, and differential Relay Word bits.

Table 9.5 MET DIF A Command

Command[a]	Description	Access Level
MET DIF A **MET DIF Z1 A *k***	Displays an expanded differential Zone 1 report	1, B, P, A, O, 2

[a] k = optional parameter to determine the number of times the relay repeats the response.

If differential Zone 1 is disabled (E87 = OFF), the relay displays the message `Differential Element 1 Disabled`.

MET E

Use the **MET E** command to view the energy import and export quantities.

Table 9.6 MET E Command

Command[a]	Description	Access Level
MET E *k*	Display energy metering data	1, B, P, A, O, 2
MET RE	Reset energy metering data	P, A, O, 2

[a] k = optional parameter to determine the number of times the relay repeats the response.

The reset command, **MET RE**, resets all energy metering quantities. When you issue the **MET RE** command, the relay responds, `Reset Energy Metering (Y/N)?` If you answer **Y <Enter>**, the relay responds, `Energy Metering Reset`.

MET RMS

Use the **MET RMS** command to view fundamental metering quantities.

Table 9.7 MET RMS Command

Command[a, b]	Description	Access Level
MET RMS	Display root-mean-square (rms) metering quantities of the first enabled terminal	1, B, P, A, O, 2
MET RMS *n k*	Display Terminal *n* rms metering quantities	1, B, P, A, O, 2

[a] n = S, T, U, W, X, Y, ST, TU, UW, WX.
[b] k = optional parameter to determine the number of times the relay repeats the response.

MET SEC

Use the **MET SEC** command to view secondary fundamental metering quantities.

Table 9.8 MET SEC Command

Command[a, b]	Description	Access Level
MET SEC	Display secondary metering quantities of the first enabled terminal	1, B, P, A, O, 2
MET SEC *n k*	Display Terminal *n* secondary metering quantities	1, B, P, A, O, 2
MET SEC A *k*	Display fundamental secondary metering data for all terminal inputs	1, B, P, A, O, 2

[a] n = S, T, U, W, X, Y, ST, TU, UW, WX.
[b] k = optional parameter to determine the number of times the relay repeats the response.

SET

Table 9.9 lists the options specifically available in the SEL-487E.

Table 9.9 SET Command Overview (Sheet 1 of 2)

Command	Description	Access Level
SET	Set the Group relay settings, beginning at the first setting in the active group	P, 2
SET *n*[a]	Set the Group *n* relay settings, beginning at the first setting in the group	P, 2

Table 9.9 SET Command Overview (Sheet 2 of 2)

Command	Description	Access Level
SET A	Set the Automation SELOGIC control equation relay settings in Block 1	A, 2
SET A *m*[b]	Set the Automation SELOGIC control equation relay settings in Block *m*	A, 2
SET B	Bay control settings, beginning at the first setting in this class	P, B, 2
SET D	Set the DNP3 remapping settings, beginning at the first setting in this class for Instance 1	P, A, O, 2
SET D *instance*	Set the DNP3 remapping settings beginning at the first setting of Instance *instance*	P, A, O, 2
SET F	Set the Front-panel relay settings, beginning at the first setting in this class	P, A, O, 2
SET G	Set the Global relay settings, beginning at the first setting in this class	P, A, O, 2
SET L	Set the Protection SELOGIC control equation relay settings for the active group	P, 2
SEL L *n*[a]	Set the Protection SELOGIC relay settings for Group *n*	P, 2
SET M	Monitor settings, beginning at the first setting in this class	P, 2
SET N	Enter text using the text-edit format	P, A, O, 2
SET O	Set the Output SELOGIC control equation relay settings, beginning at OUT201	O, 2
SET P	Set the port presently in use, beginning at the first setting for this port	P, A, O, 2
SET P *p*[c]	Set the communications port relay settings for PORT p, beginning at the first setting for this port	P, A, O, 2
SET R	Set the Report relay settings, beginning at the first setting for this class	P, A, O, 2
SET T	Set the alias settings	P, A, O, 2

[a] n = 1–6; representing Group 1 through Group 6.
[b] m = 1–10; representing Block 1 through Block 10.
[c] p = 1–3, F, or 5; corresponding to PORT 1–PORT 3, PORT F, or PORT 5.

SHOW

Table 9.10 lists the class and instance options available in the SEL-487E.

Table 9.10 SHO Command Overview (Sheet 1 of 2)

Command	Description	Access Level
SHO	Show the Group relay settings, beginning at the first setting in the active group	1, B, P, A, O, 2
SHO *n*[a]	Show the Group *n* relay settings, beginning at the first setting in each instance	1, B, P, A, O, 2
SHO A	Show the Automation SELOGIC control equation relay settings in Block 1	1, B, P, A, O, 2
SHO A *m*[b]	Show the Automation SELOGIC control equation relay settings in Block *m*	1, B, P, A, O, 2
SHO B	Show the Bay control settings, beginning at the first setting in this class	1, B, P, A, O, 2

Table 9.10 SHO Command Overview (Sheet 2 of 2)

Command	Description	Access Level
SHO D	Show the DNP3 remapping settings for Instance 1	P, A, O, 2
SHO D *instance*	Show the DNP3 remapping settings for Instance *instance*	P, A, O, 2
SHO F	Show the Front-panel relay settings, beginning at the first setting in this class	1, B, P, A, O, 2
SHO G	Show the Global relay settings, beginning at the first setting in this class	1, B, P, A, O, 2
SHO L	Show the Protection SELOGIC control equation relay settings for the active group	1, B, P, A, O, 2
SHO L *n*[a]	Show the Protection SELOGIC control equation relay settings for Group *n*	1, B, P, A, O, 2
SHO M	Show the Monitor relay settings, beginning at the first setting in this class	1, B, P, A, O, 2
SHO N	Show notes in the relay	1, B, P, A, O, 2
SHO O	Show the Output SELOGIC control equation relay settings, beginning at OUT201	1, B, P, A, O, 2
SHO P	Show the relay settings for the port presently in use, beginning at the first setting	1, B, P, A, O, 2
SHO P *p*[c]	Show the communications port relay settings for PORT p, beginning at the first setting for this port	1, B, P, A, O, 2
SHO R	Show the Report relay settings beginning at the first setting for this class	1, B, P, A, O, 2
SHO T	Show the alias settings	1, B, P, A, O, 2

[a] n = 1–6; representing Group 1 through Group 6.
[b] m = 1–10; representing Block 1 through Block 10.
[c] p = 1–3, F, and 5; which corresponds to PORT 1–PORT 3, PORT F, and PORT 5.

TFE

Use the **TFE** command to display, set, and clear through-fault data.

Table 9.11 TFE Command

Command	Description	Access Level
TFE	Displays as many as 20 of the most recent through-faults	Level 1 and higher
TFE A	Display all through-fault records	Level 1 and higher
TFE *nnnn*[a]	Displays *nnnn* through faults	Level 1 and higher
TFE P	Preloads through-fault values	Level B and higher
TFE R or **C**	Clears accumulated values and deletes the history	Level B and higher

[a] nnnn = 1-1200.

THE

Use the **THE *n*** (*n* = 1–5) command to display one of five saved thermal reports of the transformer(s) monitored by the relay. For example, **THE 1** displays the most recent event report while **THE 5** displays the oldest thermal event report. Reports are saved in a first-in, first-out (FIFO) type buffer where the newest event will overwrite the oldest report.

Table 9.12 THE Command

Command	Description	Access Level
THE *n*[a]	Displays thermal monitor report *n*	Level 1 and higher
THE P	Load preset value of accumulated insulation loss-of-life for transformer	Level 1 and higher
THE D *x* [*y*][b]	Retrieves daily profile data from day *x* to day *y*	Level 1 and higher
THE H	Retrieves hourly profile data	Level 1 and higher
THE R	Resets all stored thermal data archives and the value of total loss-of-life	Level B and higher
THE C	Clears all stored thermal data archives	Level B and higher

[a] n = 1–5.

[b] x and y:
mm:dd:yy if setting DATE_F = MDY.
yy:mm:dd if setting DATE_F = YMD.
dd:mm:yy if setting DATE_F = DMY.

This page intentionally left blank

SECTION 10

Communications Interfaces

Section 15: Communications Interfaces–Section 19: Digital Secondary Systems in the SEL-400 Series Relays Instruction Manual describe the various communications interfaces and protocols used in SEL-400 Series Relays. This section describes aspects of the communications protocols that are unique to the SEL-487E. The following topics are discussed:

- *Virtual File Interface on page 10.1*
- *Communications Database on page 10.1*
- *DNP3 Communication on page 10.10*
- *IEC 61850 Communication on page 10.27*
- *Synchrophasors on page 10.69*

Virtual File Interface

REPORTS Directory

In addition to the files identified in *Section 15: Communications Interfaces in the SEL-400 Series Relays Instruction Manual*, the SEL-487E also supports the files listed in *Table 10.1*.

Table 10.1 REPORTS Directory Files

File	Usage: All Are Read-Only Files
TFE.TXT	ASCII Through-Fault Event Report
THE.TXT	ASCII Thermal Report
THE_D.TXT	ASCII Daily Thermal Report
THE_H.TXT	ASCII Hourly Thermal Report

Communications Database

The SEL-487E maintains a database to describe itself to external devices via the Fast Message Data Access protocol. This database includes a variety of data within the relay that are available to devices connected in a serial or Ethernet network. The database includes the regions and data described in *Table 10.2*. Use the **MAP** and **VIEW** commands to display maps and contents of the database regions. See *Section 9: ASCII Command Reference* for more information on the **MAP** and **VIEW** commands.

Table 10.2 SEL-487E Database Regions

Region Name	Contents	Update Rate
LOCAL	Relay identification data including FID, Relay ID, Station ID, and active protection settings group	Updated on settings change and whenever monitored values change
METER	Metering and measurement data	0.5 s
DEMAND	Demand and peak demand measurement data	15 s
TARGET	Selected rows of Relay Word bit data	0.5 s
HISTORY	Relay event history records for the 10 most recent events	Within 15 s of any new event
BREAKER	Summary circuit breaker monitor data	15 s
STATUS	Self-test diagnostic status data	5 s
ANALOGS	Protection and automation math variables	0.5 s

Data within the Ethernet card regions are available for access by external devices via the SEL Fast Message protocol.

The LOCAL region contains the device FID, SID, and RID. It will also provide appropriate status points. This region is updated on settings changes and whenever monitored status points change (see *Table 10.3*).

Table 10.3 SEL-487E Database Structure—LOCAL Region

Address (Hex)	Name	Type	Description
0000	FID	char[48]	FID string
0030	BFID	char[48]	SELBOOT FID string
0060	SER_NUM	char[16]	Device Serial number, from factory settings
0070	PART_NUM	char[24]	Device part number, from factory settings
0088	CONFIG	char[8]	Device configuration string (as reported in ID command)
0090	SPECIAL	char[8]	Special device configuration string (as reported in ID command)
0098	DEVICE_ID	char[40]	Relay ID setting, from Global settings
00C0	NODE_ID	char[40]	Station ID from Global settings
00E8	GROUP	int	Active group
00E9	STATUS	int	Status indication: 0 for okay, 1 for failure

The METER region contains all the basic meter and energy information. This region is updated every 0.5 seconds. See *Table 10.4* for the map.

Table 10.4 SEL-487E Database Structure—METER Region (Sheet 1 of 4)

Address (Hex)	Name	Type	Description
1000	_YEAR	int	4-digit year when data were sampled
1001	DAY_OF_YEAR	int	1–366 day when data were sampled
1002	TIME(ms)	long int	Time of day in ms when data were sampled (0–86,400,000)
1004	FREQ	float	System frequency (FREQ)
1006	VDC1	float	Battery 1 voltage (VDC1)
1008	IS(A)	float[6]	Terminal S, 1-cycle average filtered phase-current magnitude and angle (IASFMC, IASFAC, IBSFMC, IBSFAC, ICSFMC, ICSFAC)
1014	IT(A)	float[6]	Terminal T, 1-cycle average filtered phase-current magnitude and angle (IATFMC, IATFAC, IBTFMC, IBTFAC, ICTFMC, ICTFAC)

Table 10.4 SEL-487E Database Structure—METER Region (Sheet 2 of 4)

Address (Hex)	Name	Type	Description
1020	IU(A)	float[6]	Terminal U, 1-cycle average filtered phase-current magnitude and angle (IAUFMC, IAUFAC, IBUFMC, IBUFAC, ICUFMC, ICUFAC)
102C	IW(A)	float[6]	Terminal W, 1-cycle average filtered phase-current magnitude and angle (IAWFMC, IAWFAC, IBWFMC, IBWFAC, ICWFMC, ICWFAC)
1038	IX(A)	float[6]	Terminal X, 1-cycle average filtered phase-current magnitude and angle (IAXFMC, IAXFAC. IBXFMC, IBXFAC, ICXFMC, ICXFAC)
1044	IY(A)	float[6]	Terminal Y, 1-cycle average filtered phase-current magnitude and angle (IY1FMC, IY1FAC, IY2FMC, IY2FAC, IY3FMC, IY3FAC)
1050	VV(V)	float[6]	Terminal V, 1-cycle average filtered phase voltage magnitude and angle (VAVFMC, VAVFAC, VBVFMC, VBVFAC, VCVFMC, VCVFAC)
105C	VZ(V)	float[6]	Terminal Z, 1-cycle average filtered phase voltage magnitude and angle (VAZFMC, VAZFAC, VBZFMC, VBZFAC, VCZFMC, VCZFAC)
1068	IST(A)	float[6]	Terminal ST, 1-cycle average filtered phase-current magnitude and angle (IASTFMC, IASTFAC, IBSTFMC, IBSTFAC, ICSTFMC, ICSTFAC)
1074	ITU(A)	float[6]	Terminal TU, 1-cycle average filtered phase-current magnitude and angle (IATUFMC, IATUFAC, IBTUFMC, IBTUFAC, ICTUFMC, ICTUFAC)
1080	IUW(A)	float[6]	Terminal UW, 1-cycle average filtered phase-current magnitude and angle (IAUWFMC, IAUWFAC, IBUWFMC, IBUWFAC, ICUWFMC, ICUWFAC)
108C	IWX(A)	float[6]	Terminal WX, 1-cycle average filtered phase-current magnitude and angle (IAWXFMC, IAWXFAC, IBWXFMC, IBWXFAC, ICWXFMC, ICWXFAC)
1098	ISEQ_S(A)	float[6]	Terminal S 1-cycle average sequence current magnitude and angle (3I0SMC/3, 3I0SAC, I1SMC, I1SAC, 3I2SMC/3, 3I2SAC)
10A4	ISEQ_T(A)	float[6]	Terminal T 1-cycle average sequence current magnitude and angle (3I0TMC/3, 3I0TAC, I1TMC, I1TAC, 3I2TMC/3, 3I2TAC)
10B0	ISEQ_U(A)	float[6]	Terminal U 1-cycle average sequence current magnitude and angle (3I0UMC/3, 3I0UAC, I1UMC, I1UAC, 3I2UMC/3, 3I2UAC)
10BC	ISEQ_W(A)	float[6]	Terminal W 1-cycle average sequence current magnitude and angle (3I0WMC/3, 3I0WAC, I1WMC, I1WAC, 3I2WMC/3, 3I2WAC)
10C8	ISEQ_X(A)	float[6]	Terminal X 1-cycle average sequence current magnitude and angle (3I0XMC/3, 3I0XAC, I1XMC, I1XAC, 3I2XMC/3, 3I2XAC)
10D4	ISEQ_Y(A)	float[6]	Terminal Y 1-cycle average sequence current magnitude and angle (3I0YMC/3, 3I0YAC, I1YMC, I1YAC, 3I2YMC/3, 3I2YAC)
10E0	ISEQ_ST(A)	float[6]	Terminal ST 1-cycle average sequence current magnitude and angle (3I0STMC/3, 3I0STAC, I1STMC, I1STAC, 3I2STMC/3, 3I2STAC)
10EC	ISEQ_TU(A)	float[6]	Terminal TU 1-cycle average sequence current magnitude and angle (3I0TUMC/3, 3I0TUAC, I1TUMC, I1TUAC, 3I2TUMC/3, 3I2TUAC)
10F8	ISEQ_UW(A)	float[6]	Terminal UW 1-cycle average sequence current magnitude and angle (3I0UWMC/3, 3I0UWAC, I1UWMC, I1UWAC, 3I2UWMC/3, 3I2UWAC)
1104	ISEQ_WX(A)	float[6]	Terminal WX 1-cycle average sequence current magnitude and angle (3I0WXMC/3, 3I0WXAC, I1WXMC, I1WXAC, 3I2WXMC/3, 3I2WXAC)
1110	VV_LL(V)	float[6]	Terminal V, 1-cycle average phase-to-phase voltage magnitude and angle (VABVFMC, VABV-FAC, VBCVFMC, VBCVFAC, VCAVFMC, VCAVFAC)
111C	VZ_LL(V)	float[6]	Terminal Z, 1-cycle average phase-to-phase voltage magnitude and angle (VABZFMC, VABZ-FAC, VBC-ZFMC, VBCZFAC, VCAZFMC, VCAZFAC)
1128	VSEQ_V(V)	float[6]	Terminal V, 1-cycle average sequence voltage magnitude and angle (3V0VMC/3, 3V0VAC, V1VMC, 3V1VAC, 3V2VMC/3, 3V2VAC)
1134	VSEQ_Z(V)	float[6]	Terminal Z, 1-cycle average sequence voltage magnitude and angle (3V0ZMC/3, 3V0ZAC, V1ZMC, 3V1ZAC, 3V2ZMC/3, 3V2ZAC)
1140	PS(W)	float[4]	Terminal S, 60-cycle average fundamental active power (PASFS, PBSFS, PCSFS, 3PSFS)

Table 10.4 SEL-487E Database Structure—METER Region (Sheet 3 of 4)

Address (Hex)	Name	Type	Description
1148	QS(VAR)	float[4]	Terminal S, 60-cycle average fundamental reactive power (QASFS, QBSFS, QCSFS, 3QSFS)
1150	SS(VA)	float[4]	Terminal S, 60-cycle average fundamental apparent power (SASFS, SBSFS, SCSFS, 3SSFS)
1158	PT(W)	float[4]	Terminal T, 60-cycle average fundamental active power (PATFS, PBTFS, PCTFS, 3PTFS)
1160	QT(VAR)	float[4]	Terminal T, 60-cycle average fundamental reactive power (QATFS, QBTFS, QCTFS, 3QTFS)
1168	ST(VA)	float[4]	Terminal T, 60-cycle average fundamental apparent power (SATFS, SBTFS, SCTFS, 3STFS)
1170	PU(W)	float[4]	Terminal U, 60-cycle average fundamental active power (PAUFS, PBUFS, PCUFS, 3PUFS)
1178	QU(VAR)	float[4]	Terminal U, 60-cycle average fundamental reactive power (QAUFS, QBUFS, QCUFS, 3QUFS)
1180	SU(VA)	float[4]	Terminal U, 60-cycle average fundamental apparent power (SAUFS, SBUFS, SCUFS, 3SUFS)
1188	PW(W)	float[4]	Terminal W, 60-cycle average fundamental active power (PAWFS, PBWFS, PCWFS, 3PWFS)
1190	QW(VAR)	float[4]	Terminal W, 60-cycle average fundamental reactive power (QAWFS, QBWFS, QCWFS, 3QWFS)
1198	SW(VA)	float[4]	Terminal W, 60-cycle average fundamental apparent power (SAWFS, SAWFS, SCWFS, 3SWFS)
11A0	PX(W)	float[4]	Terminal X, 60-cycle average fundamental active power (PAXFS, PBXFS, PCXFS, 3PXFS)
11A8	QX(VAR)	float[4]	Terminal X, 60-cycle average fundamental reactive power (QAXFS, QBXFS, QCXFS, 3QXFS)
11B0	SX(VA)	float[4]	Terminal X, 60-cycle average fundamental apparent power (SAXFS, SBXFS, SCXFS, 3SXFS)
11B8	PY(W)	float[4]	Terminal Y, 60-cycle average fundamental active power (PAYFS, PBYFS, PCYFS, 3PYFS)
11C0	QY(VAR)	float[4]	Terminal Y, 60-cycle average fundamental reactive power (QAYFS, QBYFS, QCYFS, 3QYFS)
11C8	SY(VA)	float[4]	Terminal Y, 60-cycle average fundamental apparent power (SAYFS, SBYFS, SCYFS, 3SYFS)
11D0	PST(W)	float[4]	Combined Terminal ST, 60-cycle average fundamental active real power (PASTFS, PBSTFS, PCSTFS, 3PSTFS)
11D8	QST(VAR)	float[4]	Combined Terminal ST, 60-cycle average fundamental reactive power (QASTFS, QBSTFS, QCSTFS, 3QSTFS)
11E0	SST(VA)	float[4]	Combined Terminal ST, 60-cycle average fundamental apparent power (SASTFS, SBSTFS, SCSTFS, 3SSTFS)
11E8	PTU(W)	float[4]	Combined Terminal TU, 60-cycle average fundamental active power (PATUFS, PBTUFS, PCTUFS, 3PTUFS)
11F0	QTU(VAR)	float[4]	Combined Terminal TU, 60-cycle average fundamental reactive power (QATUFS, QBTUFS, QCTUFS, 3QTUFS)
11F8	STU(VA)	float[4]	Combined Terminal TU, 60-cycle average fundamental apparent power (SATUFS, SBTUFS, SCTUFS, 3STUFS)
1200	PUW(W)	float[4]	Combined Terminal UW, 60-cycle average fundamental active power (PAUWFS, PBUWFS, PCUWFS, 3PUWFS)
1208	QUW(VAR)	float[4]	Combined Terminal UW, 60-cycle average fundamental reactive power (QAUWFS, QBUWFS, QCUWFS, 3QUWFS)
1210	SUW(VA)	float[4]	Combined Terminal UW, 60-cycle average fundamental apparent power (SAUWFS, SBUWFS, SCUWFS, 3SUWFS)
1218	PWX(W)	float[4]	Combined Terminal WX, 60-cycle average fundamental active power (PAWXFS, PBWXFS, PCWXFS, 3PWXFS)
1220	QWX(VAR)	float[4]	Combined Terminal WX, 60-cycle average fundamental reactive power (QAWXFS, QBWXFS, QCWXFS, 3QWXFS)
1228	SWX(VA)	float[4]	Combined Terminal WX, 60-cycle average fundamental apparent power (SAWXFS, SBWXFS, SCWXFS, 3SWXFS)
1230	PFS	float[4]	Terminal S, phase power factor (TPFAS, TPFBS, TPFCS, 3TPFS)
1238	PFT	float[4]	Terminal T, phase power factor (TPFAT, TPFBT, TPFCT, 3TPFT)
1240	PFU	float[4]	Terminal U, phase power factor (TPFAU, TPFBU, TPFCU, 3TPFU)

Table 10.4 SEL-487E Database Structure—METER Region (Sheet 4 of 4)

Address (Hex)	Name	Type	Description
1248	PFW	float[4]	Terminal W, phase power factor (TPFAW, TPFBW, TPFCW, 3TPFW)
1250	PFX	float[4]	Terminal X, phase power factor (TPFAX, TPFBX, TPFCX, 3TPFX)
1258	PFY	float[4]	Terminal Y, phase power factor (TPFAY, TPFBY, TPFCY, 3TPFY)
1260	PFST	float[4]	Combined Terminal ST, phase power factor (TPFAST, TPFBST, TPFCST, 3TPFST)
1268	PFTU	float[4]	Combined Terminal TU, phase power factor (TPFATU, TPFBTU, TPFCTU, 3TPFTU)
1270	PFUW	float[4]	Combined Terminal UW, phase power factor (TPFAUW, TPFBUW, TPFCUW, 3TPFUW)
1278	PFWX	float[4]	Combined Terminal WX, phase power factor (TPFAWX, TPFBWX, TPFCWX, 3TPFWX)
1280	ES(kWh)	float[4]	Terminal S, three-phase active/reactive energy export/import in KWh (3PSP_MWh, 3PSN_MWh, 3QSP_Mvarh, 3QSN_Mvarh)
1288	ET(kWh)	float[4]	Terminal T, three-phase active/reactive energy export/import in KWh (3PTP_MWh, 3PTN_MWh, 3QTP_Mvarh, 3QTN_Mvarh)
1290	EU(kWh)	float[4]	Terminal U, three-phase active/reactive energy export/import in KWh (3PUP_MWh, 3PUN_MWh, 3QUP_Mvarh, 3QUN_Mvarh)
1298	EW(kWh)	float[4]	Terminal W, three-phase active/reactive energy export/import in KWh (3PWP_MWh, 3PWN_MWh, 3QWP_Mvarh, 3QWN_Mvarh)
12A0	EX(kWh)	float[4]	Terminal X, three-phase active/reactive energy export/import in KWh (3PXP_MWh, 3PXN_MWh, 3QXP_Mvarh, 3QXN_Mvarh)
12A8	EY(kWh)	float[4]	Terminal Y, three-phase active/reactive energy export/import in KWh (3PYP_MWh, 3PYN_MWh, 3QYP_Mvarh, 3QYN_Mvarh)
12B0	EST(kWh)	float[4]	Combined Terminal ST, three-phase active/reactive energy export/import in KWh (3PSTP_MWh, 3PSTN_MWh, 3QSTP_Mvarh, 3QSTN_Mvarh)
12B8	ETU(kWh)	float[4]	Combined Terminal TU, three-phase active/reactive energy export/import in KWh (3PTUP_MWh, 3PTUN_MWh, 3QTUP_Mvarh, 3QTUN_Mvarh)
12C0	EUW(kWh)	float[4]	Combined Terminal UW, three-phase active/reactive energy export/import in KWh (3PUWP_MWh, 3PUWN_MWh, 3QUWP_Mvarh, 3QUWN_Mvarh)
12C8	EWX(kWh)	float[4]	Combined Terminal WX, three-phase active/reactive energy export/import in KWh (3PWXP_MWh, 3PWXN_MWh, 3QWXP_Mvarh, 3QWXN_Mvarh)

The DEMAND region contains demand and peak demand information. This region is updated every 15 seconds. See *Table 10.5* for the map.

Table 10.5 SEL-487E DNP LAN/WAN Database Structure—DEMAND Region

Address (Hex)	Name	Type	Description
2000	_YEAR	int	4-digit year when data were sampled
2001	DAY_OF_YEAR	int	1–366 day when data were sampled
2002	TIME(ms)	long int	Time of day in ms when data were sampled (0–86,400,00)
2004	DM	float[10]	Demand quantity 01 (DM01–DM10)
2018	DMP	float[10]	Peak demand quantity 01 (DMM01–DMM10)

The TARGET region contains the entire visible Relay Word plus the rows designated specifically for the TARGET region. This region is updated every 0.5 seconds. See *Table 10.6* for the map. See *Section 11: Relay Word Bits* for detailed information on the Relay Word bits.

Table 10.6 SEL-487E Database Structure—TARGET Region

Address (Hex)	Name	Type	Description
3000	_YEAR	int	4-digit year when data were sampled
3001	DAY_OF_YEAR	int	1–366 day when data were sampled
3002	TIME(ms)	long int	Time of day in ms when data were sampled (0–86,400,000)
3004	TARGET	char[~647]	Entire Relay Word with bit labels

The HISTORY region contains all information available in a History report for the most recent 10 events. This region is updated within 15 seconds of any new events. See *Table 10.7* for the map.

Table 10.7 SEL-487E Database Structure—HISTORY Region

Address (Hex)	Name	Type	Description
4000	_YEAR	int	4-digit year when data were sampled
4001	DAY_OF_YEAR	int	1–366 day when data were sampled
4002	TIME(ms)	long int	Time of day in ms when data were sampled (0–86,400,000)
4004	REF_NUM	int[10]	Event serial number (10000–42767)
400E	MONTH	int[10]	Month of event
4018	DAY	int[10]	Day of event
4022	YEAR	int[10]	Year of event
402C	HOUR	int[10]	Hour of event
4036	MIN	int[10]	Minute of event
4040	SEC	int[10]	Second of event
404A	MSEC	int[10]	Milliseconds of event
4054	EVENT	char[60]	Event type string
4090	GROUP	int[10]	Active group during fault
409A	FREQ	float[10]	System frequency at time of fault
40AE	TAR_SMALL	char[320]	System targets from event (32 characters per event)
41EE	TARGETS	char[1000]	System targets from event (100 characters per event)

The BREAKER region contains some of the information available in a summary Breaker report. This region is updated every 15 seconds. See *Table 10.8* for the map.

Table 10.8 SEL-487E Database Structure—BREAKER Region (Sheet 1 of 2)

Address (Hex)	Name	Type	Description
5000	_YEAR	int	4-digit year when data were sampled
5001	DAY_OF_YEAR	int	1–366 day when data were sampled
5002	TIME(ms)	long int	Time of day in ms when data were sampled (0–86,400,000)
5004	BCW_S	float[3]	Breaker S phase breaker wear (%) (BSBCWPA, BSBCWPB, BSBCWPC)
500A	BCW_T	float[3]	Breaker T phase breaker wear (%) (BTBCWPA, BTBCWPB, BTBCWPC)
5010	BCW_U	float[3]	Breaker U phase breaker wear (%) (BUBCWPA, BUBCWPB, BUBCWPC)
5016	BCW_W	float[3]	Breaker W phase breaker wear (%) (BWBCWPA, BWBCWPB, BWBCWPC)

Table 10.8 SEL-487E Database Structure—BREAKER Region (Sheet 2 of 2)

Address (Hex)	Name	Type	Description
501C	BCW_X	float[3]	Breaker X phase breaker wear (%) (BXBCWPA, BXBCWPB, BXBCWPC)
5022	BCW_Y	float[3]	Breaker Y phase breaker wear (%) (BYBCWPA, BYBCWPB, BYBCWPC)
5028	CUR_S	float[3]	Breaker S phase accumulated current (kA) (IASrms_TRIP_ACC, IBSrms_TRIP_ACC, ICS-rms_TRIP_ACC)
502E	CUR_T	float[3]	Breaker T phase accumulated current (kA) (IATrms_TRIP_ACC, IBTrms_TRIP_ACC, ICTrms_TRIP_ACC)
5034	CUR_U	float[3]	Breaker U phase accumulated current (kA) (IAUrms_TRIP_ACC, IBUrms_TRIP_ACC, ICUrms_TRIP_ACC)
503A	CUR_W	float[3]	Breaker W phase accumulated current (kA) (IAWrms_TRIP_ACC, IBWrms_TRIP_ACC, ICWrms_TRIP_ACC)
5040	CUR_X	float[3]	Breaker X phase accumulated current (kA) (IAXrms_TRIP_ACC, IBXrms_TRIP_ACC, ICX-rms_TRIP_ACC)
5046	CUR_Y	float[3]	Breaker Y phase accumulated current (kA) (IAYrms_TRIP_ACC, IBYrms_TRIP_ACC, ICYrms_TRIP_ACC)
504C	NOP_S	long int	Breaker S number of operations (BS_TRP_CNT)
504E	NOP_T	long int	Breaker T number of operations (BT_TRP_CNT)
5050	NOP_U	long int	Breaker U number of operations (BU_TRP_CNT)
5052	NOP_W	long int	Breaker W number of operations (BW_TRP_CNT)
5054	NOP_X	long int	Breaker X number of operations (BX_TRP_CNT)
5056	NOP_Y	long int	Breaker Y number of operations (BY_TRP_CNT)

The STATUS region contains complete relay status information. This region is updated every 5 seconds. See *Table 10.9* for the map.

Table 10.9 SEL-487E Database Structure—STATUS Region (Sheet 1 of 2)

Address (Hex)	Name	Type	Description
6000	_YEAR	int	4-digit year when data were sampled
6001	DAY_OF_YEAR	int	1–366 day when data were sampled
6002	TIME(ms)	long int	Time of day in ms when data were sampled (0–86,400,000)
6004	CH1_24(mV)	int[24]	Channel offsets, use 0 if not measured
601C	MOF(mV)	int	Master offset
601D	MOF2(mV)	int	Master offset 2
601E	OFF_WARN	char[8]	Offset warning string
6026	OFF_FAIL	char[8]	Offset failure string
602E	PS3(V)	float	3.3 Volt power supply voltage
6030	PS5(V)	float	5 Volt power supply voltage
6032	PS_N5(V)	float	–5 Volt regulated voltage
6034	PS15(V)	float	15 Volt power supply voltage
6036	PS_N15(V)	float	–15 Volt power supply voltage
6038	PS_WARN	char[8]	Power supply warning string
6040	PS_FAIL	char[8]	Power supply failure string
6048	HW_FAIL	char[40]	Hardware failure strings

Table 10.9 SEL-487E Database Structure—STATUS Region (Sheet 2 of 2)

Address (Hex)	Name	Type	Description
6070	CC_STA	char[40]	Comm. card status strings
6098	PORT_STA	char[160]	Serial port status strings
6138	TIME_SRC	char[10]	Time source
6142	LOG_ERR	char[40]	SELOGIC error strings
616A	TEST_MD	char[160]	Test mode string
620A	WARN	char[32]	Warning strings for any active warnings
622A	FAIL	char[64]	Failure strings for any active failures

The ANALOGS region contains protection and automation variables. This region is updated every 0.5 seconds. See *Table 10.10* for the map.

Table 10.10 SEL-487E Database Structure—ANALOGS Region

Address (Hex)	Name	Type	Description
7000	_YEAR	int	4-digit year when data were sampled
7001	DAY_OF_YEAR	int	1–366 day when data were sampled
7002	TIME(ms)	long int	Time of day in ms when data were sampled (0–86,400,000)
7004	PMV01_64	float[64]	PMV01–PMV64
7084	AMV001_256	float[256]	AMV001–AMV256

The database is virtual device 1 in the relay. You can display the contents of a region by using the **MAP 1:region** command (where region is one of the database region names listed in *Table 10.2*). An example of the **MAP** command is shown in *Figure 10.1*.

```
=>>MAP 1:meter <Enter>

Virtual Device 1, Data Region METER Map

Data Item    Starting Address   Type

_YEAR        1000h              int
DAY_OF_YEAR  1001h              int
TIME(ms)     1002h              int[2]
FREQ         1004h              float
VDC1         1006h              float
IS(A)        1008h              float[6]
IT(A)        1014h              float[6]
IU(A)        1020h              float[6]
IW(A)        102ch              float[6]
IX(A)        1038h              float[6]
IY(A)        1044h              float[6]
VV(V)        1050h              float[6]
VZ(V)        105ch              float[6]
IST(A)       1068h              float[6]
ITU(A)       1074h              float[6]
IUW(A)       1080h              float[6]
IWX(A)       108ch              float[6]
ISEQ_S(A)    1098h              float[6]
ISEQ_T(A)    10a4h              float[6]
ISEQ_U(A)    10b0h              float[6]
ISEQ_W(A)    10bch              float[6]
ISEQ_X(A)    10c8h              float[6]
ISEQ_Y(A)    10d4h              float[6]
ISEQ_ST(A)   10e0h              float[6]
ISEQ_TU(A)   10ech              float[6]
ISEQ_UW(A)   10f8h              float[6]
ISEQ_WX(A)   1104h              float[6]
```

Figure 10.1 MAP 1:METER Command Example

```
VV_LL(V)      1110h          float[6]
VZ_LL(V)      111ch          float[6]
VSEQ_V(V)     1128h          float[6]
VSEQ_Z(V)     1134h          float[6]
PS(W)         1140h          float[4]
QS(VAR)       1148h          float[4]
SS(VA)        1150h          float[4]
PT(W)         1158h          float[4]
QT(VAR)       1160h          float[4]
ST(VA)        1168h          float[4]
PU(W)         1170h          float[4]
QU(VAR)       1178h          float[4]
SU(VA)        1180h          float[4]
PW(W)         1188h          float[4]
QW(VAR)       1190h          float[4]
SW(VA)        1198h          float[4]
PX(W)         11a0h          float[4]
QX(VAR)       11a8h          float[4]
SX(VA)        11b0h          float[4]
PY(W)         11b8h          float[4]
QY(VAR)       11c0h          float[4]
SY(VA)        11c8h          float[4]
PST(W)        11d0h          float[4]
QST(VAR)      11d8h          float[4]
SST(VA)       11e0h          float[4]
PTU(W)        11e8h          float[4]
QTU(VAR)      11f0h          float[4]
STU(VA)       11f8h          float[4]
PUW(W)        1200h          float[4]
QUW(VAR)      1208h          float[4]
SUW(VA)       1210h          float[4]
PWX(W)        1218h          float[4]
QWX(VAR)      1220h          float[4]
SWX(VA)       1228h          float[4]
PFS           1230h          float[4]
PFT           1238h          float[4]
PFU           1240h          float[4]
PFW           1248h          float[4]
PFX           1250h          float[4]
PFY           1258h          float[4]
PFST          1260h          float[4]
PFTU          1268h          float[4]
PFUW          1270h          float[4]
PFWX          1278h          float[4]
ES(kWh)       1280h          float[4]
ET(kWh)       1288h          float[4]
EU(kWh)       1290h          float[4]
EW(kWh)       1298h          float[4]
EX(kWh)       12a0h          float[4]
EY(kWh)       12a8h          float[4]
EST(kWh)      12b0h          float[4]
ETU(kWh)      12b8h          float[4]
EUW(kWh)      12c0h          float[4]
EWX(kWh)      12c8h          float[4]
```

Figure 10.1 MAP 1:METER Command Example (Continued)

Control Points

SEL communications processors (SEL RTAC and SEL-2032) can automatically pass control messages, called Fast Operate messages, to the SEL-487E. You must enable Fast Operate messages by using the FASTOP setting in the SEL-487E Port settings for the port connected to the communications processor. You must also enable Fast Operate messages in the SEL communications processor.

When you enable Fast Operate functions, the SEL communications processor automatically sends messages to the relay for changes in remote bits RB01–RB32 or breaker bits BR1–BR26. For example, if you set RB01 in the SEL communications processor, it automatically sets RB01 in the SEL-487E.

Breaker bits operate differently than remote bits and require that the **BREAKER** jumper is in the **ON** position. When you set BR1, the SEL communications processor sends a message to the SEL-487E that asserts the manual open command bit OCS for one processing interval. If you clear BR1, the close command bit

CCS asserts for one processing interval. If you are using the default settings, OCS will open Circuit Breaker S and CCS will close Circuit Breaker S. Operation for Circuit Breaker T, U, W, X, and Y is similar.

To control the 20 disconnects, communications processors use breaker bits BR7–BR26. Setting the BR7 bit in a communications processor sends a message to the SEL-487E that asserts Relay Word bit 89OC01 for one processing interval. Clearing the BR7 bit asserts 89CC01 for one processing interval. *Table 10.11* shows the communications processor bits and the corresponding relay bits for remote bit, breaker, and disconnect control. Note that when using the SEL RTAC, trip is used to set breaker bits and close is used to clear them.

Table 10.11 SEL-487E Fast Operate Control Bits

Communication Processor Bits	SEL-487E Bits
RB01	Set RB01: asserts RB01 Clear RB01: deasserts RB01 Pulse RB01: pulses RB01
…	
RB32	Set RB32: asserts RB32 Clear RB32: deasserts RB32 Pulse RB32: pulses RB32
BR1	Set BR1: pulses OCS Clear BR1: pulses CCS
BR2	Set BR2: pulses OCT Clear BR2: pulses CCT
BR3	Set BR3: pulses OCU Clear BR3: pulses CCU
BR4	Set BR4: pulses OCW Clear BR4: pulses CCW
BR5	Set BR5: pulses OCX Clear BR5: pulses CCX
BR6	Set BR6: pulses OCY Clear BR6: pulses CCY
BR7	Set BR7: pulses 89OC01 Clear BR7: pulses 89CC01
…	
BR26	Set BR26: pulses 89OC20 Clear BR26: pulses 89CC20

DNP3 Communication

DNP3 operation is described in *Section 16: DNP3 Communication in the SEL-400 Series Relays Instruction Manual*. This section describes aspects of DNP3 communication that are unique to the SEL-487E.

Reference Data Map

Table 10.12–Table 10.16 shows the SEL-487E DNP3 reference data maps. The reference data maps contain all of the data points available to the DNP3 protocol. You can select the default subset or use the custom DNP3 mapping functions of the SEL-487E to create or edit maps that contain the points required by your application.

Table 10.12 shows the Binary Input reference map. The entire Relay Word (see *Section 11: Relay Word Bits*) is part of the DNP3 reference map. You may include any label in the Relay Word as part of a DNP3 custom map. Note that Binary Inputs registered as SER points (SET R settings) will maintain SER-quality time stamps for DNP3 events.

Table 10.12 SEL-487E Binary Input Reference Data Map

Object	Label	Description
01, 02	RLYDIS	Relay disabled
01, 02	STFAIL	Relay diagnostic failure
01, 02	STWARN	Relay diagnostic warning
01, 02	STSET	Settings change or relay restart
01, 02	UNRDEV	New relay event available
01, 02	NUNREV	An unread event exists, newer than the event in the Event summary AIs
01, 02	Relay Word	Relay Word bit label. See *Section 11: Relay Word Bits*.

Table 10.13 shows the Binary Output reference map. See *Binary Outputs on page 10.18* for additional information.

Table 10.13 SEL-487E Binary Output Reference Data Map (Sheet 1 of 2)

Object	Label	Description
10, 12	RB01–RB64	Remote Bits RB01–RB64
10, 12	RB01:RB01 RB02:RB02 RB03:RB03 • • • RB96:RB96 RB01:RB02 RB03:RB04 RB05:RB06 • • • RB95:RB96	Remote Bit pulse operation, RB01 Remote Bit pulse operation, RB02 Remote Bit pulse operation, RB03 • • • Remote Bit pulse operation, RB96 Remote Bit pairs RB01–RB02 Remote Bit pairs RB03–RB04 Remote Bit pairs RB05–RB06 • • • Remote Bit pairs RB95–RB96
10, 12	OC*m*[a]	Open Circuit Breaker *m* control
10, 12	CC*m*[a]	Close Circuit Breaker *m* control
10, 12	OC*m*:CC*m*[a]	Open/Close Circuit Breaker *m* control pair
10, 12	89OC01–89OC20	Open Disconnect Control 1–20
10, 12	89CC01–89CC20	Close Disconnect Control 1–20

Table 10.13 SEL-487E Binary Output Reference Data Map (Sheet 2 of 2)

Object	Label	Description
10, 12	89OC01:89CC01 89OC02:89CC02 • • • 89OC20:89CC20	Open/Close Disconnect Control Pair 1 Open/Close Disconnect Control Pair 2 • • • Open/Close Disconnect Control Pair 20
10, 12	RST_DEM	Reset demand meter data
10, 12	RST_PDM	Reset peak demand meter data
10, 12	RST_ENE	Reset accumulated energy meter data
10, 12	RST_BK*m*[a]	Reset Breaker *m* monitor data
10, 12	RST_BAT	Reset battery monitoring
10, 12	RST_79C	Reset recloser shot counters
10, 12	RST_HAL	Reset alarm pulsing
10, 12	RSTTRGT	Reset targets
10, 12	RSTDNPE	Reset (clear) DNP event summary registers
10, 12	NXTEVE	Load next event into DNP event summary registers

[a] m = S, T, U, W, X, Y.

Table 10.14 shows the Binary Counter reference map. See *Counters on page 16.23 in the SEL-400 Series Relays Instruction Manual* for additional information.

Table 10.14 SEL-487E Binary Counter Reference Data Map (Sheet 1 of 2)

Object	Label	Description
20, 22	ACTGRP	Active settings group
20, 22	BKR*m*OP[a]	Number of Breaker *m* operations
20, 22	ACN01CV–ACN32CV	Automation SELOGIC counter values
20, 22	PCN01CV–PCN32CV	Protection SELOGIC counter values
20, 22	3P*m*KWHP[a, b]	Three-phase active energy exported (kWh), Terminal *m*
20, 22	3Q*m*KVHP[a, b]	Three-phase reactive energy exported (kVARh), Terminal *m*
20, 22	3P*m*KWHN[a, b]	Three-phase active energy imported (kWh), Terminal *m*
20, 22	3Q*m*KVHN[a, b]	Three-phase reactive energy imported (kVARh), Terminal *m*
20, 22	3STKWHP[b]	Three-phase active energy exported (kWh), Combined Terminals ST
20, 22	3STKVHP[b]	Three-phase reactive energy exported (kVARh), Combined Terminals ST
20, 22	3STKWHN[b]	Three-phase active energy imported (kWh), Combined Terminals ST
20, 22	3STKVHN[b]	Three-phase reactive energy imported (kVARh), Combined Terminals ST
20, 22	3TUKWHP[b]	Three-phase active energy exported (kWh), Combined Terminals TU
20, 22	3TUKVHP[b]	Three-phase reactive energy exported (kVARh), Combined Terminals TU
20, 22	3TUKWHN[b]	Three-phase active energy imported (kWh), Combined Terminals TU
20, 22	3TUKVHN[b]	Three-phase reactive energy imported (kVARh), Combined terminals TU
20, 22	3UWKWHP[b]	Three-phase active energy exported (kWh), Combined Terminals UW
20, 22	3UWKVHP[b]	Three-phase reactive energy exported (kVARh), Combined Terminals UW
20, 22	3UWKWHN[b]	Three-phase active energy imported (kWh), Combined Terminals UW

Table 10.14 SEL-487E Binary Counter Reference Data Map (Sheet 2 of 2)

Object	Label	Description
20, 22	3UWKVHN[b]	Three-phase reactive energy imported (kVARh), Combined Terminals UW
20, 22	3WXKWHP[b]	Three-phase active energy exported (kWh), Combined Terminals WX
20, 22	3WXKVHP[b]	Three-phase reactive energy exported (kVARh), Combined Terminals WX
20, 22	3WXKWHN[b]	Three-phase active energy imported (kWh), Combined Terminals WX
20, 22	3WXKVHN[b]	Three-phase reactive energy imported (kVARh), Combined Terminals WX

[a] m = S, T, U, W, X, Y.
[b] Converts to the absolute value and forces the counter to a positive value.

Table 10.15 shows the Analog Input reference map. The SEL-487E scales analog values by the indicated settings or fixed scaling. Analog inputs for event (fault) summary reporting use a default scale factor of 1 and deadband of ANADBM. Per-point scaling and deadband settings specified in a custom DNP3 map will override defaults.

Table 10.15 SEL-487E Analog Input Reference Data Map (Sheet 1 of 6)

Object	Label	Description
30, 32	FREQPM[a]	Frequency for synchrophasor data (Hz)
30, 32	DFDTPM[a]	Rate-of-change of frequency for synchrophasor data (Hz/s)
30, 32	V*p*VFMC[b, c], V*p*VFAC[a, c]	1-cycle average filtered, *p*-Phase voltage magnitude (kV) and angle, V-PT
30, 32	V*p*ZFMC[b, c], V*p*ZFAC[a, c]	1-cycle average filtered, *p*-Phase voltage magnitude (kV) and angle, Z-PT
30, 32	VABVFMC[b], VABVFAC[a]	1-cycle average filtered, AB-Phase voltage magnitude (kV) and angle, V-PT
30, 32	VBCVFMC[b], VBCVFAC[a]	1-cycle average filtered, BC-Phase voltage magnitude (kV) and angle, V-PT
30, 32	VCAVFMC[b], VCAVFAC[a]	1-cycle average filtered, CA-Phase voltage magnitude (kV) and angle, V-PT
30, 32	VABZFMC[b], VABZFAC[a]	1-cycle average filtered, AB-Phase voltage magnitude (kV) and angle, Z-PT
30, 32	VBCZFMC[b], VBCZFAC[a]	1-cycle average filtered, BC-Phase voltage magnitude (kV) and angle, Z-PT
30, 32	VCAZFMC[b], VCAZFAC[a]	1-cycle average filtered, CA-Phase voltage magnitude (kV) and angle, Z-PT
30, 32	V*p*VRC[b, c]	1-cycle average rms, *p*-Phase voltage magnitude (kV), V-PT
30, 32	V*p*ZRC[b, c]	1-cycle average rms, *p*-Phase voltage magnitude (kV), Z-PT
30, 32	VABVRC[b]	1-cycle average rms, AB-Phase voltage magnitude (kV), V-PT
30, 32	VBCVRC[b]	1-cycle average rms, BC-Phase voltage magnitude (kV), V-PT
30, 32	VCAVRC[b]	1-cycle average rms, CA-Phase voltage magnitude (kV), V-PT
30, 32	VABZRC[b]	1-cycle average rms, AB-Phase voltage magnitude (kV), Z-PT
30, 32	VBCZRC[b]	1-cycle average rms, BC-Phase voltage magnitude (kV), Z-PT
30, 32	VCAZRC[b]	1-cycle average rms, CA-Phase voltage magnitude (kV), Z-PT
30, 32	V1VMC[b], V1VAC[a]	1-cycle average, positive-sequence voltage magnitude (kV) and angle, V-PT
30, 32	V1ZMC[b], V1ZAC[a]	1-cycle average, positive-sequence voltage magnitude (kV) and angle, Z-PT
30, 32	3V2VMC[b], 3V2VAC[a]	1-cycle average, negative-sequence voltage magnitude (kV) and angle, V-PT
30, 32	3V2ZMC[b], 3V2ZAC[a]	1-cycle average, negative-sequence voltage magnitude (kV) and angle, Z-PT
30, 32	3V0VMC[b], 3V0VAC[a]	1-cycle average, zero-sequence voltage magnitude (kV) and angle, V-PT
30, 32	3V0ZMC[b], 3V0ZAC[a]	1-cycle average, zero-sequence voltage magnitude (kV) and angle, Z-PT
30, 32	I*pm*FMC[c, d, e], I*pm*FAC[a, c, e]	1-cycle average filtered phase-current magnitude (amperes primary) and angle, *p*-Phase, Terminal *m*
30, 32	IY1FMC[d], IY1FAC[a]	1-cycle average filtered phase-current magnitude (amperes primary) and angle, Channel 1, Terminal Y

Table 10.15 SEL-487E Analog Input Reference Data Map (Sheet 2 of 6)

Object	Label	Description
30, 32	IY2FMC[d], IY2FAC[a]	1-cycle average filtered phase-current magnitude (amperes primary) and angle, Channel 2, Terminal Y
30, 32	IY3FMC[d], IY3FAC[a]	1-cycle average filtered phase-current magnitude (amperes primary) and angle, Channel 3, Terminal Y
30, 32	I*pm*RC[c, d, e]	1-cycle average rms phase-current magnitude (amperes primary), *p*-Phase, Terminal *m*
30, 32	I*pqp*FMC[c, d, f], I*pqp*FAC[a, c, f]	1-cycle average filtered phase-current magnitude (amperes primary) and angle, *p*-Phase, Combined Terminals *qp*
30, 32	I*pqp*RC[c, d, f]	1-cycle average rms phase-current magnitude (amperes primary), *p*-Phase, Combined Terminals *qp*
30, 32	I1*m*MC[d, e], I1*m*AC[a, e]	1-cycle average positive-sequence current magnitude (amperes primary) and angle, Terminal *m*
30, 32	3I2*m*MC[d, e], 3I2*m*AC[a, e]	1-cycle average negative-sequence current magnitude (amperes primary) and angle, Terminal *m*
30, 32	3I0*m*MC[d, e], 3I0*m*AC[a, e]	1-cycle average zero-sequence current magnitude (amperes primary) and angle, Terminal *m*
30, 32	I1*qp*MC[d, f], I1*qp*AC[a, f]	1-cycle average positive-sequence current magnitude (amperes primary) and angle, Combined Terminals *qp*
30, 32	3I2*qp*MC[d, f], 3I2*qp*AC[a, f]	1-cycle average negative-sequence current magnitude (amperes primary) and angle, Combined Terminals *qp*
30, 32	3I0*qp*MC[d, f], 3I0*qp*AC[a, f]	1-cycle average zero-sequence current magnitude (amperes primary) and angle, Combined Terminals *qp*
30, 32	I*pm*RS[c, d, e]	60-cycle average rms phase-current magnitude (amperes secondary), *p*-Phase, Terminal *m*
30, 32	I*pqp*RS[c, d, f]	60-cycle average rms phase-current magnitude (amperes secondary), *p*-Phase, Combined Terminals *qp*
30, 32	IMX*m*RS[d, e]	60-cycle average maximum rms phase-current magnitude, (amperes secondary), Terminal *m*
30, 32	IMX*qp*RS[d, f]	60-cycle average maximum rms phase-current magnitude, (amperes secondary), Combined Terminals *qp*
30, 32	3I2*m*MS[d, e]	60-cycle average negative-sequence current magnitude, (amperes secondary), Terminal *m*
30, 32	3I2*qp*MS[d, f]	60-cycle average negative-sequence current magnitude, (amperes secondary), Combined Terminals *qp*
30, 32	3I0*m*MS[d, e]	60-cycle average zero-sequence current magnitude, (amperes secondary), Terminal *m*
30, 32	3I0*qp*MS[d, f]	60-cycle average zero-sequence current magnitude, (amperes secondary), Combined Terminals *qp*
30, 32	P*pm*FC[c, e, g]	1-cycle average phase fundamental active power magnitude (megawatts primary), *p*-Phase, Terminal *m*
30, 32	Q*pm*FC[c, e, g]	1-cycle average phase fundamental reactive power magnitude (megavar primary), *p*-Phase, Terminal *m*
30, 32	S*pm*FC[c, e, g]	1-cycle average phase fundamental apparent power magnitude (megavolt-amperes primary), *p*-Phase, Terminal *m*
30, 32	3P*m*FC[e, g]	1-cycle average three-phase fundamental active power magnitude, (megawatts primary), Terminal *m*
30, 32	3Q*m*FC[e, g]	1-cycle average three-phase fundamental reactive power magnitude, (megavars primary), Terminal *m*
30, 32	3S*m*FC[e, g]	1-cycle average three-phase fundamental apparent power magnitude, (megavolt-amperes primary), Terminal *m*
30, 32	P*pqp*FC[c, f, g]	1-cycle average phase fundamental active power magnitude, megawatts primary, *p*-Phase, Combined Terminals *qp*
30, 32	Q*pqp*FC[c, f, g]	1-cycle average phase fundamental reactive power magnitude, megavars primary, *p*-Phase, Combined Terminals *qp*
30, 32	S*pqp*FC[c, f, g]	1-cycle average phase fundamental apparent power magnitude, megavolt-amperes primary, *p*-Phase, Combined Terminals *qp*

Table 10.15 SEL-487E Analog Input Reference Data Map (Sheet 3 of 6)

Object	Label	Description
30, 32	3P*qp*FC[f, g]	1-cycle average three-phase fundamental active power magnitude, megawatts primary, Combined Terminals *qp*
30, 32	3Q*qp*FC[f, g]	1-cycle average three-phase fundamental reactive power magnitude, megavars primary, Combined Terminals *qp*
30, 32	3S*qp*FC[f, g]	1-cycle average three-phase fundamental apparent power magnitude, megavolt-amperes primary, Combined Terminals *qp*
30, 32	DPF*pm*[c, e, g]	Phase displacement power factor, *p*-Phase, Terminal *m*
30, 32	3DPF*m*[e, g]	Three-phase displacement power factor, Terminal *m*
30, 32	DPF*pqp*[c, f, g]	Phase displacement power factor, *p*-Phase, Combined Terminals *qp*
30, 32	3DPF*qp*[f, g]	Three-phase displacement power factor, Combined Terminals *qp*
30, 32	87IOP*p*C[c, d]	Zone 1 1-cycle average differential element operating current (per unit), *p*-Phase
30, 32	87IRT*p*C[c, d]	Zone 1 1-cycle average differential element restraint current (per unit), *p*-Phase
30, 32	DM01[h]	Demand metering Element 1 value, amperes secondary
30, 32	DM02[h]	Demand metering Element 2 value, amperes secondary
30, 32	DM03[h]	Demand metering Element 3 value, amperes secondary
30, 32	DM04[h]	Demand metering Element 4 value, amperes secondary
30, 32	DM05[h]	Demand metering Element 5 value, amperes secondary
30, 32	DM06[h]	Demand metering Element 6 value, amperes secondary
30, 32	DM07[h]	Demand metering Element 7 value, amperes secondary
30, 32	DM08[h]	Demand metering Element 8 value, amperes secondary
30, 32	DM09[h]	Demand metering Element 9 value, amperes secondary
30, 32	DM10[h]	Demand metering Element 10 value, amperes secondary
30, 32	DMM01[h]	Demand metering Element 1 maximum value, amperes secondary
30, 32	DMM02[h]	Demand metering Element 2 maximum value, amperes secondary
30, 32	DMM03[h]	Demand metering Element 3 maximum value, amperes secondary
30, 32	DMM04[h]	Demand metering Element 4 maximum value, amperes secondary
30, 32	DMM05[h]	Demand metering Element 5 maximum value, amperes secondary
30, 32	DMM06[h]	Demand metering Element 6 maximum value, amperes secondary
30, 32	DMM07[h]	Demand metering Element 7 maximum value, amperes secondary
30, 32	DMM08[h]	Demand metering Element 8 maximum value, amperes secondary
30, 32	DMM09[h]	Demand metering Element 9 maximum value, amperes secondary
30, 32	DMM10[h]	Demand metering Element 10 maximum value, amperes secondary
30, 32	RTD01TV[h]	RTD temperature value in degrees C, RTD01
30, 32	RTD02TV[h]	RTD temperature value in degrees C, RTD02
30, 32	RTD03TV[h]	RTD temperature value in degrees C, RTD03
30, 32	RTD04TV[h]	RTD temperature value in degrees C, RTD04
30, 32	RTD05TV[h]	RTD temperature value in degrees C, RTD05
30, 32	RTD06TV[h]	RTD temperature value in degrees C, RTD06
30, 32	RTD07TV[h]	RTD temperature value in degrees C, RTD07
30, 32	RTD08TV[h]	RTD temperature value in degrees C, RTD08
30, 32	RTD09TV[h]	RTD temperature value in degrees C, RTD09
30, 32	RTD10TV[h]	RTD temperature value in degrees C, RTD10

Table 10.15 SEL-487E Analog Input Reference Data Map (Sheet 4 of 6)

Object	Label	Description
30, 32	RTD11TV[h]	RTD temperature value in degrees C, RTD11
30, 32	RTD12TV[h]	RTD temperature value in degrees C, RTD12
30, 32	3P*m*MWHP[e, g]	Three-phase active energy exported, Terminal *m* (megawatt hours, primary)
30, 32	3Q*m*MVHP[e, g]	Three-phase reactive energy exported, Terminal *m* (megavar hours, primary)
30, 32	3P*m*MWHN[e, g]	Three-phase active energy imported, Terminal *m* (megawatt hours, primary)
30, 32	3Q*m*MVHN[e, g]	Three-phase reactive energy imported, Terminal *m* (megavar hours, primary)
30, 32	3P*m*MWHT[e, g]	Total three-phase active energy, Terminal *m* (megawatt hours, primary)
30, 32	3Q*m*MVHT[e, g]	Total three-phase reactive energy, Terminal *m* (megavar hours, primary)
30, 32	3P*qp*WHP[f, g]	Three-phase active energy exported, Combined Terminals *qp* (megawatt hours, primary)
30, 32	3Q*qp*VHP[f, g]	Three-phase reactive energy exported, Combined Terminals *qp* (megavar hours, primary)
30, 32	3P*qp*WHN[f, g]	Three-phase active energy imported, Combined Terminals *qp* (megawatt hours, primary)
30, 32	3Q*qp*VHN[f, g]	Three-phase reactive energy imported, Combined Terminals *qp* (megavar hours, primary)
30, 32	3P*qp*WHT[f, g]	Total three-phase active energy, Combined Terminals *qp* (megawatt hours, primary)
30, 32	3Q*qp*VHT[f, g]	Total three-phase reactive energy, Combined Terminals *qp* (megawatt hours, primary)
30, 32	FREQ[a]	Frequency used for frequency tracking (Hz)
30, 32	FREQP[a]	Frequency used for under- and overfrequency elements (Hz)
30, 32	DFDTP[a]	Rate-of-change of frequency (Hz)
30, 32	VDC[h]	Station battery 1 dc voltage (V)
30, 32	DCPO[h]	Average positive-to-ground dc 1 voltage (V)
30, 32	DCNE[h]	Average negative-to-ground dc 1 voltage (V)
30, 32	DCRI[h]	AC ripple of dc 1 voltage (V)
30, 32	DCMIN[h]	Minimum dc 1 voltage (V)
30, 32	DCMAX[h]	Maximum dc 1 voltage (V)
30, 32	HSRSRTP[h]	Round-trip time for HSR supervision frames on process bus (microseconds)
30, 32	HSRSRTS[h]	Round-trip time for HSR supervision frames on station bus (microseconds)
30, 32	PMV01–PMV64[h]	Protection SELOGIC math variable
30, 32	AMV001–AMV256[h]	Automation SELOGIC math variable
30, 32	PCN01CV–PCN32CV[h]	Protection SELOGIC counter current value
30, 32	ACN01CV–ACN32CV[h]	Automation SELOGIC counter current value
30, 32	ACTGRP[h]	Active group setting
30, 32	TODMS[h]	UTC time of day in milliseconds (0–86400000)
30, 32	THR[h]	UTC time, hour (0–23)
30, 32	TMIN[h]	UTC time, minute (0–59)
30, 32	TSEC[h]	UTC time, seconds (0–59)
30, 32	TMSEC[h]	UTC time, milliseconds (0–999)
30, 32	DDOW[h]	UTC date, day of the week (1–SU, ..., 7–SA)
30, 32	DDOM[h]	UTC date, day of the month (1–31)
30, 32	DDOY[h]	UTC date, day of the year (1–366)
30, 32	DMON[h]	UTC date, month (1–12)
30, 32	DYEAR[h]	UTC date, year (2000–2200)
30, 32	TLODMS[h]	Local time of day in milliseconds (0–86400000)

Table 10.15 SEL-487E Analog Input Reference Data Map (Sheet 5 of 6)

Object	Label	Description
30, 32	TLHR[h]	Local time, hour (0–23)
30, 32	TLMIN[h]	Local time, minute (0–59)
30, 32	TLSEC[h]	Local time, seconds (0–59)
30, 32	TLMSEC	Local time, milliseconds (0–999)
30, 32	DLDOW[h]	Local date, day of the week (1-SU,.., 7-SA)
30, 32	DLDOM[h]	Local date, day of the month (1–31)
30, 32	DLDOY[h]	Local date, day of the year (1–366)
30, 32	DLMON[h]	Local date, month (1–12)
30, 32	DLYEAR[h]	Local date, year (2000–2200)
30, 32	TUTC[h]	Offset from IRIG-B time to UTC time (hours)
30, 32	TQUAL[h]	Worst case IRIG-B clock time error (seconds)
30, 32	RA001–RA256[h]	Remote analogs
30, 32	RLYTEMP[h]	Relay temperature (temperature of the box, degrees C)
30, 32	RAO01–RAO64[h]	Remote analog output
30, 32	B*m*ATRI*p*[c, d, e]	Breaker *m* accumulated trip current for *p*-phase (amperes primary)
30, 32	B*m*BCWP*p*[c, e, h]	Breaker *m* contact wear for Pole *p* (%)
30, 32	B*m*OPCN[e, h]	Breaker *m* number of operations—trip
30, 32	B*m*LTRI*p*[c, e, h]	Breaker *m* last interrupted trip current for *p*-phase (%)
30, 32	B*m*EOTT*p*[c, e, h]	Breaker *m* average electrical operating time—trip for *p*-phase (milliseconds)
30, 32	B*m*EOTC*p*[c, e, h]	Breaker *m* average electrical operating time—close for *p*-phase (milliseconds)
30, 32	B*m*LEOT*p*[c, e, h]	Breaker *m* last electrical operating time—trip for *p*-phase (milliseconds)
30, 32	B*m*LEOC*p*[c, e, h]	Breaker *m* last electrical operating time—close for *p*-phase (milliseconds)
30, 32	B*m*MOTT[e, h]	Breaker *m* average mechanical operating time—trip (milliseconds)
30, 32	B*m*MOTC[e, h]	Breaker *m* average mechanical operating time—close (milliseconds)
30, 32	B*m*LMOTT[e, h]	Breaker *m* last mechanical operating time—trip (milliseconds)
30, 32	B*m*LMOTC[e, h]	Breaker *m* last mechanical operating time—close (milliseconds)
30, 32	25VPFM[b]	25 synchronism-check polarizing voltage magnitude (volts secondary)
30, 32	25VPFA[a]	25 synchronism-check polarizing voltage angle
30, 32	25VP*m*FM[b, e], 25VP*m*FA[a, e]	25 synchronism-check polarizing voltage magnitude for Breaker *m*, (volts secondary) and angle
30, 32	25VS*m*FM[b, e], 25VS*m*FA[a, e]	25 synchronism-check synchronizing voltage magnitude for Breaker *m* (volts secondary) and angle
30, 32	25ANG*m*[a, e]	25 synchronism-check angle difference for Breaker *m*
30, 32	25ANGC*m*[a, e]	25 synchronism-check compensated angle difference for Breaker *m*
30, 32	25SLIP*m*[a, e]	25 synchronism-check slip frequency for Breaker *m*, hertz
30, 32	SMPSYNC[h]	Locally derived SmpSynch value
30, 32	79SH*m*[e, h]	Breaker *m* shot counter present value
30, 32	79SH*m*_1[e, h]	Breaker *m* total number of first shot reclosers
30, 32	79SH*m*_2[e, h]	Breaker *m* total number of second shot reclosers
30, 32	79SH*m*_3[e, h]	Breaker *m* total number of third shot reclosers
30, 32	79SH*m*_4[e, h]	Breaker *m* total number of fourth shot reclosers
30, 32	79SH*m*_T[e, h]	Breaker *m* total number of reclosers

Table 10.15 SEL-487E Analog Input Reference Data Map (Sheet 6 of 6)

Object	Label	Description
30, 32	MAXGRP[h]	Maximum number of protection groups
30, 32	I850MOD[h]	IEC 61850 Mode/Behavior status
Event Summary Analog Inputs[i, j]		
30, 32	FTYPE	Fault type
30, 32	FTAR1	Fault targets (upper byte is 1st target row, lower byte is 2nd target row)
30, 32	FTAR2	Fault targets (upper byte is 3rd target row, lower byte is 0)
30, 32	FFREQ[k]	Fault frequency
30, 32	FGRP	Fault active settings group (1–6)
30, 32	FTIMEH	Fault time (local) in DNP format, high 16 bits
30, 32	FTIMEM	Fault time (local) in DNP format, middle 16 bits
30, 32	FTIMEL	Fault time (local) in DNP format, low 16 bits
30, 32	FTIMEUH	Fault time (UTC) in DNP format, high 16 bits
30, 32	FTIMEUM	Fault time (UTC) in DNP format, middle 16 bits
30, 32	FTIMEUL	Fault time (UTC) in DNP format, low 16 bits
30, 32	FUNR	Number of unread fault summary reports

[a] Default scale factor is 100 and deadband ANADBM.
[b] Default scale factor is DECPLV and deadband ANADBV.
[c] p = A, B, C.
[d] Default scale factor is DECPLA and deadband ANADBA.
[e] m = S, T, U, W, X, Y.
[f] qp = ST, TU, UW, WX.
[g] Default scale factor is DECPLM and deadband is ANADBM.
[h] Default scale factor is 1 and deadband ANADBM.
[i] Unless otherwise indicated, the default scale factor for these points is 1. The default deadband is ANADBM. Per-point scaling and deadband settings specified in a custom DNP map override these defaults.
[j] Event data shall be generated for all Event Summary Analog Inputs if any of them change beyond their deadband after scaling.
[k] Default scale factor is 100.

Figure 10.16 shows the Analog Output reference map. See *Analog Outputs on page 16.23 in the SEL-400 Series Relays Instruction Manual* for additional information.

Table 10.16 SEL-487E Analog Output Reference Data Map

Object	Label	Description
40, 41	ACTGRP	Active settings group (1–6)
40, 41	RA001–RA256	Remote analogs

Binary Outputs

Use the Trip and Close, Latch On/Off and Pulse On operations with Object 12 control relay output block command messages to operate the points shown in *Table 10.17*. Pulse operations provide a pulse with duration of one protection processing interval. Cancel an operation in progress by issuing a NUL Trip/Close Code with a NUL Operation Type.

Table 10.17 SEL-487E Object 12 Control Point Operations (Sheet 1 of 3)

Label	Close/Any	Trip/Any	NUL/Latch On	NUL/Latch Off	NUL/Pulse On	NUL/Pulse Off
RB01–RB96	Pulse on Remote Bits RB01–RB96	Pulse on Remote Bits RB01–RB96	Set Remote Bits RB01–RB96	Clear Remote Bits RB01–RB96	Pulse on Remote Bits RB01–RB96	Clear Remote Bits RB01–RB96
RB*xx*: RB*yy*	Pulse RB*yy*	Pulse RB*xx*	Pulse RB*yy*	Pulse RB*xx*	Pulse RB*yy*	Pulse RB*xx*
OCS	Open Circuit Breaker S (pulse OCS)	Open Circuit Breaker S (pulse OCS)	Set OCS	Clear OCS	Open Circuit Breaker S (pulse OCS)	Clear OCS
CCS	Close Circuit Breaker S (pulse CCS)	Close Circuit Breaker S (pulse CCS)	Set CCS	Clear CCS	Close Circuit Breaker S (pulse CCS)	Clear CCS
OCT	Open Circuit Breaker T (pulse OCT)	Open Circuit Breaker T (pulse OCT)	Set OCT	Clear OCT	Open Circuit Breaker T (pulse OCT)	Clear OCT
CCT	Close Circuit Breaker T (pulse CCT)	Close Circuit Breaker T (pulse CCT)	Set CCT	Clear CCT	Close Circuit Breaker T (pulse CCT)	Clear CCT
OCU	Open Circuit Breaker U (pulse OCU)	Open Circuit Breaker U (pulse OCU)	Set OCU	Clear OCU	Open Circuit Breaker U (pulse OCU)	Clear OCU
CCU	Close Circuit Breaker U (pulse CCU)	Close Circuit Breaker U (pulse CCU)	Set CCU	Clear CCU	Close Circuit Breaker U (pulse CCU)	Clear CCU
OCW	Open Circuit Breaker W (pulse OCW)	Open Circuit Breaker W (pulse OCW)	Set OCW	Clear OCW	Open Circuit Breaker W (pulse OCW)	Clear OCW
CCW	Close Circuit Breaker W (pulse CCW)	Close Circuit Breaker W (pulse CCW)	Set CCW	Clear CCW	Close Circuit Breaker W (pulse CCW)	Clear CCW
OCX	Open Circuit Breaker X (pulse OCX)	Open Circuit Breaker X (pulse OCX)	Set OCX	Clear OCX	Open Circuit Breaker X (pulse OCX)	Clear OCX
CCX	Close Circuit Breaker X (pulse CCX)	Close Circuit Breaker X (pulse CCX)	Set CCX	Clear CCX	Close Circuit Breaker X (pulse CCX)	Clear CCX
OCY	Open Circuit Breaker Y (pulse OCY)	Open Circuit Breaker Y (pulse OCY)	Set OCY	Clear OCY	Open Circuit Breaker Y (pulse OCY)	Clear OCY
CCY	Close Circuit Breaker Y (pulse CCY)	Close Circuit Breaker Y (pulse CCY)	Set CCY	Clear CCY	Close Circuit Breaker Y (pulse CCY)	Clear CCY
OCS: CCS	Pulse CCS, Circuit Breaker S close bit	Pulse OCS, Circuit Breaker S open bit	Pulse CCS, Circuit Breaker S close bit	Pulse OCS, Circuit Breaker S open bit	Pulse CCS, Circuit Breaker S close bit	Pulse OCS, Circuit Breaker S open bit
OCT: CCT	Pulse CCT, Circuit Breaker T close bit	Pulse OCT, Circuit Breaker T open bit	Pulse CCT, Circuit Breaker T close bit	Pulse OCT, Circuit Breaker T open bit	Pulse CCT, Circuit Breaker T close bit	Pulse OCT, Circuit Breaker T open bit
OCU: CCU	Pulse CCU, Circuit Breaker U close bit	Pulse OCU, Circuit Breaker U open bit	Pulse CCU, Circuit Breaker U close bit	Pulse OCU, Circuit Breaker U open bit	Pulse CCU, Circuit Breaker U close bit	Pulse OCU, Circuit Breaker U open bit
OCW: CCW	Pulse CCW, Circuit Breaker W close bit	Pulse OCW, Circuit Breaker W open bit	Pulse CCW, Circuit Breaker W close bit	Pulse OCW, Circuit Breaker W open bit	Pulse CCW, Circuit Breaker W close bit	Pulse OCW, Circuit Breaker W open bit

Table 10.17 SEL-487E Object 12 Control Point Operations (Sheet 2 of 3)

Label	Close/Any	Trip/Any	NUL/Latch On	NUL/Latch Off	NUL/Pulse On	NUL/Pulse Off
OCX: CCX	Pulse CCX, Circuit Breaker X close bit	Pulse OCX, Circuit Breaker X open bit	Pulse CCX, Circuit Breaker X close bit	Pulse OCX, Circuit Breaker X open bit	Pulse CCX, Circuit Breaker X close bit	Pulse OCX, Circuit Breaker X open bit
OCY:CCY	Pulse CCY, Circuit Breaker Y close bit	Pulse OCY, Circuit Breaker Y open bit	Pulse CCY, Circuit Breaker Y close bit	Pulse OCY, Circuit Breaker Y open bit	Pulse CCY, Circuit Breaker Y close bit	Pulse OCY, Circuit Breaker Y open bit
89OC01–89OC20	Pulse 89OC01–89OC20, disconnect open bit	Pulse 89OC01–89OC20, disconnect open bit	Set 89OC01–89OC20, disconnect open bit	Clear 89OC01–89OC20, disconnect open bit	Pulse 89OC01–89OC20, disconnect open bit	Clear 89OC01–89OC20, disconnect open bit
89CC01–89CC20	Pulse 89CC01–89CC20, disconnect close bit	Pulse 89CC01–89CC20, disconnect close bit	Set 89CC01–89CC20, disconnect close bit	Clear 89CC01–89CC20, disconnect close bit	Pulse 89CC01–89CC20, disconnect close bit	Clear 89CC01–89CC20, disconnect close bit
89OC*x*: 89CC*x*	Pulse 89CC*x*, disconnect close bit	Pulse 89OC*x*, disconnect open bit	Pulse 89CC*x*, disconnect close bit	Pulse 89OC*x*, disconnect open bit	Pulse 89CC*x*, disconnect close bit	Pulse 89OC*x*, disconnect open bit
RST_DEM	Reset demand meter data	Reset demand meter data	Reset demand meter data	No action	Reset demand meter data	No action
RST_PDM	Reset peak demand meter data	Reset peak demand meter data	Reset peak demand meter data	No action	Reset peak demand meter data	No action
RST_ENE	Reset energy accumulators	Reset energy accumulators	Reset energy accumulators	No action	Reset energy accumulators	No action
RST_BKS	Reset Breaker Monitor S (pulse RSS_BKS)	Reset Breaker Monitor S (pulse RSS_BKS)	Reset Breaker Monitor S (pulse RSS_BKS)	No action	Reset Breaker Monitor S (pulse RSS_BKS)	No action
RST_BKT	Reset Breaker Monitor T (pulse RSS_BKT)	Reset Breaker Monitor T (pulse RSS_BKT)	Reset Breaker Monitor T (pulse RSS_BKT)	No action	Reset Breaker Monitor T (pulse RSS_BKT)	No action
RST_BKU	Reset Breaker Monitor U (pulse RSS_BKU)	Reset Breaker Monitor U (pulse RSS_BKU)	Reset Breaker Monitor U (pulse RSS_BKU)	No action	Reset Breaker Monitor U (pulse RSS_BKU)	No action
RST_BKW	Reset Breaker Monitor W (pulse RSS_BKW)	Reset Breaker Monitor W (pulse RSS_BKW)	Reset Breaker Monitor W (pulse RSS_BKW)	No action	Reset Breaker Monitor W (pulse RSS_BKW)	No action
RST_BKX	Reset Breaker Monitor X (pulse RSS_BKX)	Reset Breaker Monitor X (pulse RSS_BKX)	Reset Breaker Monitor X (pulse RSS_BKX)	No action	Reset Breaker Monitor X (pulse RSS_BKX)	No action
RST_BKY	Reset Breaker Monitor Y (pulse RSS_BKY)	Reset Breaker Monitor Y (pulse RSS_BKY)	Reset Breaker Monitor Y (pulse RSS_BKY)	No action	Reset Breaker Monitor Y (pulse RSS_BKY)	No action
RST_BAT	Reset battery monitoring (pulse RSS_BAT)	Reset battery monitoring (pulse RSS_BAT)	Reset battery monitoring (pulse RSS_BAT)	No action	Reset battery monitoring (pulse RSS_-BAT)	No action
RST_79C	Reset recloser shot counters	Reset recloser shot counters	Reset recloser shot counters	No action	Reset recloser shot counters	No action
RST_HAL	Reset alarm pulsing (pulse RSS_HAL)	Reset alarm pulsing (pulse RSS_HAL)	Reset alarm pulsing (pulse RSS_HAL)	No action	Reset alarm pulsing (pulse RSS_HAL)	No action

Table 10.17 SEL-487E Object 12 Control Point Operations (Sheet 3 of 3)

Label	Close/Any	Trip/Any	NUL/Latch On	NUL/Latch Off	NUL/Pulse On	NUL/Pulse Off
RSTTRGT	Reset front-panel targets (pulse RSTTRGT)	Reset front-panel targets (pulse RSTTRGT)	Reset front-panel targets	No action	Reset front-panel targets	No action
RSTDNPE	Reset DNP event summary	Reset DNP event summary	Reset DNP event summary	No action	Reset DNP event summary	No action
NXTEVE	Load oldest event summary (FIFO)	Load newest event summary (LIFO)	Load oldest event summary (FIFO)	Load newest event summary (LIFO)	Load oldest event summary (FIFO)	Load newest event summary (LIFO)

Relay Fault Summary Data

When a relay event occurs (TRIP asserts, ER asserts, or TRI asserts), the data shall be made available to DNP.

In either mode, DNP3 events for all event summary analog inputs (see *Table 10.15*) will be generated if any of them change beyond their deadband value after scaling (usually whenever a new relay event occurs and is loaded into the event summary analog inputs). Events are detected approximately twice a second by the scanning process.

See *Table 10.18* for the components of the FTYPE analog input point. The bit asserted in the upper byte indicates the event cause (Trigger, Trip, ER element, etc.). The lower byte of FTYPE is always 0. If no bits are asserted in the upper byte, there is no valid fault summary loaded.

Table 10.18 Object 30, 32, FTYPE Upper Byte-Event Cause

Bit Position								Value	Event Cause
7	6	5	4	3	2	1	0		
								0	No fault summary loaded
							X	1	Trigger command
						X		2	Restricted earth fault trip
					X			4	Trip element
				X				8	Event report element
			X					16	Zone 2 differential trip
		X						32	Zone 1 differential trip

Default Data Map

Table 10.19–Table 10.23 shows the SEL-487E default data maps by DNP3 object or point type. The default data maps are automatically generated subsets of the reference map. All data maps are initialized to these default values. If the default maps do not fit your particular application, you can use the custom DNP mapping commands **SET D *n*** and **SHOW D *n***, where *n* is the map number, to edit or create the map you require.

Table 10.19 SEL-487E DNP3 Default Binary Input Data Map (Sheet 1 of 3)

Object	Default Index	Label	Description
01, 02	0	RLYDIS	Relay disabled
01, 02	1	TRIPLED	Trip LED

Table 10.19 SEL-487E DNP3 Default Binary Input Data Map (Sheet 2 of 3)

Object	Default Index	Label	Description
01, 02	2	STFAIL	Relay diagnostic failure
01, 02	3	STWARN	Relay diagnostic warning
01, 02	4	STSET	Settings have changed or relay restarted
01, 02	5	UNRDEV	An event, as yet unread by DNP, exists
01, 02	6	52CLS	Breaker closed, Terminal S
01, 02	7	52ALS	Breaker alarm, Terminal S
01, 02	8	52CLT	Breaker closed, Terminal T
01, 02	9	52ALT	Breaker alarm, Terminal T
01, 02	10	52CLU	Breaker closed, Terminal U
01, 02	11	52ALU	Breaker alarm, Terminal U
01, 02	12	52CLW	Breaker closed, Terminal W
01, 02	13	52ALW	Breaker alarm, Terminal W
01, 02	14	52CLX	Breaker closed, Terminal X
01, 02	15	52ALX	Breaker alarm, Terminal X
01, 02	16	89CL01	Disconnect 1 closed
01, 02	17	89AL01	Disconnect 1 alarm
01, 02	18	89CL02	Disconnect 2 closed
01, 02	19	89AL02	Disconnect 2 alarm
01, 02	20	89CL03	Disconnect 3 closed
01, 02	21	89AL03	Disconnect 3 alarm
01, 02	22	89CL04	Disconnect 4 closed
01, 02	23	89AL04	Disconnect 4 alarm
01, 02	24	89CL05	Disconnect 5 closed
01, 02	25	89AL05	Disconnect 5 alarm
01, 02	26	89CL06	Disconnect 6 closed
01, 02	27	89AL06	Disconnect 6 alarm
01, 02	28	89CL07	Disconnect 7 closed
01, 02	29	89AL07	Disconnect 7 alarm
01, 02	30	89CL08	Disconnect 8 closed
01, 02	31	89AL08	Disconnect 8 alarm
01, 02	32	89CL09	Disconnect 9 closed
01, 02	33	89AL09	Disconnect 9 alarm
01, 02	34	89CL10	Disconnect 10 closed
01, 02	35	89AL10	Disconnect 10 alarm
01, 02	36	TLED_1	Target LED 1 on relay front panel
01, 02	37	TLED_2	Target LED 2 on relay front panel
01, 02	38	TLED_3	Target LED 3 on relay front panel
01, 02	39	TLED_4	Target LED 4 on relay front panel
01, 02	40	TLED_5	Target LED 5 on relay front panel
01, 02	41	TLED_6	Target LED 6 on relay front panel
01, 02	42	TLED_7	Target LED 7 on relay front panel

Table 10.19 SEL-487E DNP3 Default Binary Input Data Map (Sheet 3 of 3)

Object	Default Index	Label	Description
01, 02	43	TLED_8	Target LED 8 on relay front panel
01, 02	44	TLED_9	Target LED 9 on relay front panel
01, 02	45	TLED_10	Target LED 10 on relay front panel
01, 02	46	TLED_11	Target LED 11 on relay front panel
01, 02	47	TLED_12	Target LED 12 on relay front panel
01, 02	48	TLED_13	Target LED 13 on relay front panel
01, 02	49	TLED_14	Target LED 14 on relay front panel
01, 02	50	TLED_15	Target LED 15 on relay front panel
01, 02	51	TLED_16	Target LED 16 on relay front panel
01, 02	52	TLED_17	Target LED 17 on relay front panel
01, 02	53	TLED_18	Target LED 18 on relay front panel
01, 02	54	TLED_19	Target LED 19 on relay front panel
01, 02	55	TLED_20	Target LED 20 on relay front panel
01, 02	56	TLED_21	Target LED 21 on relay front panel
01, 02	57	TLED_22	Target LED 22 on relay front panel
01, 02	58	TLED_23	Target LED 23 on relay front panel
01, 02	59	TLED_24	Target LED 24 on relay front panel
01, 02	60	VALARMV	Voltage alarm Terminal V
01, 02	61	LOPV	Loss-of-potential Terminal V
01, 02	62	VALARMZ	Voltage alarm Terminal Z
01, 02	63	LOPZ	Loss-of-potential Terminal Z
01, 02	64	IN201	Main Board Input 1 asserted
01, 02	65	IN202	Main Board Input 2 asserted
01, 02	66	IN203	Main Board Input 3 asserted
01, 02	67	IN204	Main Board Input 4 asserted
01, 02	68	IN205	Main Board Input 5 asserted
01, 02	69	IN206	Main Board Input 6 asserted
01, 02	70	IN207	Main Board Input 7 asserted
01, 02	71	OUT201	Main Board Output 1 asserted
01, 02	72	OUT202	Main Board Output 2 asserted
01, 02	73	OUT203	Main Board Output 3 asserted
01, 02	74	OUT204	Main Board Output 4 asserted
01, 02	75	OUT205	Main Board Output 5 asserted
01, 02	76	OUT206	Main Board Output 6 asserted
01, 02	77	OUT207	Main Board Output 7 asserted
01, 02	78	OUT208	Main Board Output 8 asserted

Table 10.20 SEL-487E DNP3 Default Binary Output Data Map (Sheet 1 of 2)

Object	Default Index	Label	Description
10, 12	0–31	RB01–RB32	Remote Bits 1–32
10, 12	32	OCS	Breaker Open command, Terminal S

Table 10.20 SEL-487E DNP3 Default Binary Output Data Map (Sheet 2 of 2)

Object	Default Index	Label	Description
10, 12	33	CCS	Breaker Close command, Terminal S
10, 12	34	OCT	Breaker Open command, Terminal T
10, 12	35	CCT	Breaker Close command, Terminal T
10, 12	36	OCU	Breaker Open command, Terminal U
10, 12	37	CCU	Breaker Close command, Terminal U
10, 12	38	OCW	Breaker Open command, Terminal W
10, 12	39	CCW	Breaker Close command, Terminal W
10, 12	40	OCX	Breaker Open command, Terminal X
10, 12	41	CCX	Breaker Close command, Terminal X
10, 12	42	89OC01	Open Disconnect Control 1
10, 12	43	89CC01	Close Disconnect Control 1
10, 12	44	89OC02	Open Disconnect Control 2
10, 12	45	89CC02	Close Disconnect Control 2
10, 12	46	89OC03	Open Disconnect Control 3
10, 12	47	89CC03	Close Disconnect Control 3
10, 12	48	89OC04	Open Disconnect Control 4
10, 12	49	89CC04	Close Disconnect Control 4
10, 12	50	89OC05	Open Disconnect Control 5
10, 12	51	89CC05	Close Disconnect Control 5
10, 12	52	89OC06	Open Disconnect Control 6
10, 12	53	89CC06	Close Disconnect Control 6
10, 12	54	89OC07	Open Disconnect Control 7
10, 12	55	89CC07	Close Disconnect Control 7
10, 12	56	89OC08	Open Disconnect Control 8
10, 12	57	89CC08	Close Disconnect Control 8
10, 12	58	89OC09	Open Disconnect Control 9
10, 12	59	89CC09	Close Disconnect Control 9
10, 12	60	89OC10	Open Disconnect Control 10
10, 12	61	89CC10	Close Disconnect Control 10
10, 12	62	RSTTRGT	Reset front-panel targets
10, 12	63	RSTDNPE	Reset DNP fault summary data

Table 10.21 SEL-487E DNP3 Default Binary Counter Data Map

Object	Default Index	Label	Description
20, 22	0	BKRSOP	Number of Breaker S operations
20, 22	1	BKRTOP	Number of Breaker T operations
20, 22	2	BKRUOP	Number of Breaker U operations
20, 22	3	BKRWOP	Number of Breaker W operations
20, 22	4	BKRXOP	Number of Breaker X operations

Table 10.22 SEL-487E Default Analog Input Map (Sheet 1 of 3)

Object	Default Index	Label	Description
30, 32	0	IASFMC	1-cycle average filtered phase-current magnitude, A-Phase, Terminal S
30, 32	1	IASFAC	1-cycle average filtered phase-current angle, A-Phase, Terminal S
30, 32	2	IBSFMC	1-cycle average filtered phase-current magnitude, B-Phase, Terminal S
30, 32	3	IBSFAC	1-cycle average filtered phase-current angle, B-Phase, Terminal S
30, 32	4	ICSFMC	1-cycle average filtered phase-current magnitude, C-Phase, Terminal S
30, 32	5	ICSFAC	1-cycle average filtered phase-current angle, C-Phase, Terminal S
30, 32	6	IATFMC	1-cycle average filtered phase-current magnitude, A-Phase, Terminal T
30, 32	7	IATFAC	1-cycle average filtered phase-current angle, A-Phase, Terminal T
30, 32	8	IBTFMC	1-cycle average filtered phase-current magnitude, B-Phase, Terminal T
30, 32	9	IBTFAC	1-cycle average filtered phase-current angle, B-Phase, Terminal T
30, 32	10	ICTFMC	1-cycle average filtered phase-current magnitude, C-Phase, Terminal T
30, 32	11	ICTFAC	1-cycle average filtered phase-current angle, C-Phase, Terminal T
30, 32	12	IAUFMC	1-cycle average filtered phase-current magnitude, A-Phase, Terminal U
30, 32	13	IAUFAC	1-cycle average filtered phase-current angle, A-Phase, Terminal U
30, 32	14	IBUFMC	1-cycle average filtered phase-current magnitude, B-Phase, Terminal U
30, 32	15	IBUFAC	1-cycle average filtered phase-current angle, B-Phase, Terminal U
30, 32	16	ICUFMC	1-cycle average filtered phase-current magnitude, C-Phase, Terminal U
30, 32	17	ICUFAC	1-cycle average filtered phase-current angle, C-Phase, Terminal U
30, 32	18	IAWFMC	1-cycle average filtered phase-current magnitude, A-Phase, Terminal W
30, 32	19	IAWFAC	1-cycle average filtered phase-current angle, A-Phase, Terminal W
30, 32	20	IBWFMC	1-cycle average filtered phase-current magnitude, B-Phase, Terminal W
30, 32	21	IBWFAC	1-cycle average filtered phase-current angle, B-Phase, Terminal W
30, 32	22	ICWFMC	1-cycle average filtered phase-current magnitude, C-Phase, Terminal W
30, 32	23	ICWFAC	1-cycle average filtered phase-current angle, C-Phase, Terminal W
30, 32	24	IAXFMC	1-cycle average filtered phase-current magnitude, A-Phase, Terminal X
30, 32	25	IAXFAC	1-cycle average filtered phase-current angle, A-Phase, Terminal X
30, 32	26	IBXFMC	1-cycle average filtered phase-current magnitude, B-Phase, Terminal X
30, 32	27	IBXFAC	1-cycle average filtered phase-current angle, B-Phase, Terminal X
30, 32	28	ICXFMC	1-cycle average filtered phase-current magnitude, C-Phase, Terminal X
30, 32	29	ICXFAC	1-cycle average filtered phase-current angle, C-Phase, Terminal X
30, 32	30	VAVFMC	1-cycle average filtered phase-to-neutral voltage magnitude, A-Phase, Terminal V
30, 32	31	VAVFAC	1-cycle average filtered phase-to-neutral voltage angle, A-Phase, Terminal V
30, 32	32	VBVFMC	1-cycle average filtered phase-to-neutral voltage magnitude, B-Phase, Terminal V
30, 32	33	VBVFAC	1-cycle average filtered phase-to-neutral voltage angle, B-Phase, Terminal V
30, 32	34	VCVFMC	1-cycle average filtered phase-to-neutral voltage magnitude, C-Phase, Terminal V
30, 32	35	VCVFAC	1-cycle average filtered phase-to-neutral voltage angle, C-Phase, Terminal V
30, 32	36	VAZFMC	1-cycle average filtered phase-to-neutral voltage magnitude, A-Phase, Terminal Z
30, 32	37	VAZFAC	1-cycle average filtered phase-to-neutral voltage angle, A-Phase, Terminal Z
30, 32	38	VBZFMC	1-cycle average filtered phase-to-neutral voltage magnitude, B-Phase, Terminal Z
30, 32	39	VBZFAC	1-cycle average filtered phase-to-neutral voltage angle, B-Phase, Terminal Z
30, 32	40	VCZFMC	1-cycle average filtered phase-to-neutral voltage magnitude, C-Phase, Terminal Z

Table 10.22 SEL-487E Default Analog Input Map (Sheet 2 of 3)

Object	Default Index	Label	Description
30, 32	41	VCZFAC	1-cycle average filtered phase-to-neutral voltage angle, C-Phase, Terminal Z
30, 32	42	PASFC	1-cycle average phase fundamental active power, A-Phase, Terminal S
30, 32	43	PBSFC	1-cycle average phase fundamental active power, B-Phase, Terminal S
30, 32	44	PCSFC	1-cycle average phase fundamental active power, C-Phase, Terminal S
30, 32	45	PATFC	1-cycle average phase fundamental active power, A-Phase, Terminal T
30, 32	46	PBTFC	1-cycle average phase fundamental active power, B-Phase, Terminal T
30, 32	47	PCTFC	1-cycle average phase fundamental active power, C-Phase, Terminal T
30, 32	48	PAUFC	1-cycle average phase fundamental active power, A-Phase, Terminal U
30, 32	49	PBUFC	1-cycle average phase fundamental active power, B-Phase, Terminal U
30, 32	50	PCUFC	1-cycle average phase fundamental active power, C-Phase, Terminal U
30, 32	51	PAWFC	1-cycle average phase fundamental active power, A-Phase, Terminal W
30, 32	52	PBWFC	1-cycle average phase fundamental active power, B-Phase, Terminal W
30, 32	53	PCWFC	1-cycle average phase fundamental active power, C-Phase, Terminal W
30, 32	54	PAXFC	1-cycle average phase fundamental active power, A-Phase, Terminal X
30, 32	55	PBXFC	1-cycle average phase fundamental active power, B-Phase, Terminal X
30, 32	56	PCXFC	1-cycle average phase fundamental active power, C-Phase, Terminal X
30, 32	57	QASFC	1-cycle average phase fundamental reactive power, A-Phase, Terminal S
30, 32	58	QBSFC	1-cycle average phase fundamental reactive power, B-Phase, Terminal S
30, 32	59	QCSFC	1-cycle average phase fundamental reactive power, C-Phase, Terminal S
30, 32	60	QATFC	1-cycle average phase fundamental reactive power, A-Phase, Terminal T
30, 32	61	QBTFC	1-cycle average phase fundamental reactive power, B-Phase, Terminal T
30, 32	62	QCTFC	1-cycle average phase fundamental reactive power, C-Phase, Terminal T
30, 32	63	QAUFC	1-cycle average phase fundamental reactive power, A-Phase, Terminal U
30, 32	64	QBUFC	1-cycle average phase fundamental reactive power, B-Phase, Terminal U
30, 32	65	QCUFC	1-cycle average phase fundamental reactive power, C-Phase, Terminal U
30, 32	66	QAWFC	1-cycle average phase fundamental reactive power, A-Phase, Terminal W
30, 32	67	QBWFC	1-cycle average phase fundamental reactive power, B-Phase, Terminal W
30, 32	68	QCWFC	1-cycle average phase fundamental reactive power, C-Phase, Terminal W
30, 32	69	QAXFC	1-cycle average phase fundamental reactive power, A-Phase, Terminal X
30, 32	70	QBXFC	1-cycle average phase fundamental reactive power, B-Phase, Terminal X
30, 32	71	QCXFC	1-cycle average phase fundamental reactive power, C-Phase, Terminal X
30, 32	72	ACTGRP	Active settings group
30, 32	73	RLYTEMP	Relay temperature (°C temperature of the box)
30, 32	74	FREQ	Tracking frequency
30, 32	75	VDC	Station battery dc voltage
30, 32	76	FTYPE	Fault type
30, 32	77	FTAR1	Fault targets (upper byte is 1st target row, lower byte is 2nd target row)
30, 32	78	FTAR2	Fault targets (upper byte is 3rd target row, lower byte is 0)
30, 32	79	FFREQ	Fault frequency
30, 32	80	FGRP	Fault active settings group (1–6)
30, 32	81	FTIMEUH	Fault time (UTC) in DNP format, high 16 bits

Table 10.22 SEL-487E Default Analog Input Map (Sheet 3 of 3)

Object	Default Index	Label	Description
30, 32	82	FTIMEUM	Fault time (UTC) in DNP format, middle 16 bits
30, 32	83	FTIMEUL	Fault time (UTC) in DNP format, low 16 bits
30, 32	84	FUNR	Number of unread faults

Table 10.23 SEL-487E DNP3 Default Analog Output Data Map

Object	Default Index	Label	Description
40, 41	1	ACTGRP	Active settings group

IEC 61850 Communication

General IEC 61850 operation is described in *Section 17: IEC 61850 Communication in the SEL-400 Series Relays Instruction Manual*. This section describes characteristics of IEC 61850 that are specific to the SEL-487E.

Logical Nodes

NOTE: With the introduction of the Flexible Server Model (FSM) in Architect for ICD files ClassFileVersion 010 or later, use FSM as the primary reference to view and edit the mapping between IEC 61850 data attributes and relay variables. The LN tables provided in this section serve as general guidelines.

Table 10.24 and *Table 10.25* show the logical nodes (LNs) supported in the SEL-487E and the Relay Word bits or Measured Values mapped to those LNs. Additionally, the relay supports the CON and ANN Logical Device LNs as described in *Section 17: IEC 61850 Communication in the SEL-400 Series Relays Instruction Manual*.

Table 10.24 shows the LNs associated with protection elements, defined as Logical Device PRO.

Table 10.24 Logical Device: PRO (Protection) (Sheet 1 of 28)

Logical Node	Attribute	Data Source	Comment
Functional Constraint = CO			
DC01CSWI1	Pos.Oper.ctlVal	89CC01:89OC01[a]	ASCII Close/Open Disconnect 1 command
DC02CSWI1	Pos.Oper.ctlVal	89CC02:89OC02[a]	ASCII Close/Open Disconnect 2 command
DC03CSWI1	Pos.Oper.ctlVal	89CC03:89OC03[a]	ASCII Close/Open Disconnect 3 command
DC04CSWI1	Pos.Oper.ctlVal	89CC04:89OC04[a]	ASCII Close/Open Disconnect 4 command
DC05CSWI1	Pos.Oper.ctlVal	89CC05:89OC05[a]	ASCII Close/Open Disconnect 5 command
DC06CSWI1	Pos.Oper.ctlVal	89CC06:89OC06[a]	ASCII Close/Open Disconnect 6 command
DC07CSWI1	Pos.Oper.ctlVal	89CC07:89OC07[a]	ASCII Close/Open Disconnect 7 command
DC08CSWI1	Pos.Oper.ctlVal	89CC08:89OC08[a]	ASCII Close/Open Disconnect 8 command
DC09CSWI1	Pos.Oper.ctlVal	89CC09:89OC09[a]	ASCII Close/Open Disconnect 9 command
DC10CSWI1	Pos.Oper.ctlVal	89CC10:89OC10[a]	ASCII Close/Open Disconnect 10 command
DC11CSWI1	Pos.Oper.ctlVal	89CC11:89OC11[a]	ASCII Close/Open Disconnect 11 command
DC12CSWI1	Pos.Oper.ctlVal	89CC12:89OC12[a]	ASCII Close/Open Disconnect 12 command
DC13CSWI1	Pos.Oper.ctlVal	89CC13:89OC13[a]	ASCII Close/Open Disconnect 13 command
DC14CSWI1	Pos.Oper.ctlVal	89CC14:89OC14[a]	ASCII Close/Open Disconnect 14 command
DC15CSWI1	Pos.Oper.ctlVal	89CC15:89OC15[a]	ASCII Close/Open Disconnect 15 command
DC16CSWI1	Pos.Oper.ctlVal	89CC16:89OC16[a]	ASCII Close/Open Disconnect 16 command

Table 10.24 Logical Device: PRO (Protection) (Sheet 2 of 28)

Logical Node	Attribute	Data Source	Comment
DC17CSWI1	Pos.Oper.ctlVal	89CC17:89OC17[a]	ASCII Close/Open Disconnect 17 command
DC18CSWI1	Pos.Oper.ctlVal	89CC18:89OC18[a]	ASCII Close/Open Disconnect 18 command
DC19CSWI1	Pos.Oper.ctlVal	89CC19:89OC19[a]	ASCII Close/Open Disconnect 19 command
DC20CSWI1	Pos.Oper.ctlVal	89CC20:89OC20[a]	ASCII Close/Open Disconnect 20 command
SBKRCSWI1	Pos.Oper.ctlVal	CCS:OCS[a]	Circuit breaker close/open command, Terminal S
TBKRCSWI1	Pos.Oper.ctlVal	CCT:OCT[a]	Circuit breaker close/open command, Terminal T
UBKRCSWI1	Pos.Oper.ctlVal	CCU:OCU[a]	Circuit breaker close/open command, Terminal U
WBKRCSWI1	Pos.Oper.ctlVal	CCW:OCW[a]	Circuit breaker close/open command, Terminal W
XBKRCSWI1	Pos.Oper.ctlVal	CCX:OCX[a]	Circuit breaker close/open command, Terminal X
YBKRCSWI1	Pos.Oper.ctlVal	CCY:OCY[a]	Circuit breaker close/open command, Terminal Y
Functional Constraint = ST			
BFRSRBRF1	Str.general	BFIS	Circuit Breaker S breaker failure initiate SELOGIC control equation
BFRSRBRF1	OpEx.general	FBFS	Circuit Breaker S failure
BFRSRBRF1	OpIn.general	RTS	Circuit Breaker S retrip
BFRTRBRF1	Str.general	BFIT	Circuit Breaker T breaker failure initiate SELOGIC control equation
BFRTRBRF1	OpEx.general	FBFT	Circuit Breaker T failure
BFRTRBRF1	OpIn.general	RTT	Circuit Breaker T retrip
BFRURBRF1	Str.general	BFIU	Circuit Breaker U breaker failure initiate SELOGIC control equation
BFRURBRF1	OpEx.general	FBFU	Circuit Breaker U failure
BFRURBRF1	OpIn.general	RTU	Circuit Breaker U retrip
BFRWRBRF1	Str.general	BFIW	Circuit Breaker W breaker failure initiate SELOGIC control equation
BFRWRBRF1	OpEx.general	FBFW	Circuit Breaker W failure
BFRWRBRF1	OpIn.general	RTW	Circuit Breaker W retrip
BFRXRBRF1	Str.general	BFIX	Circuit Breaker X breaker failure initiate SELOGIC control equation
BFRXRBRF1	OpEx.general	FBFX	Circuit Breaker X failure
BFRXRBRF1	OpIn.general	RTX	Circuit Breaker X retrip
BFRYRBRF1	Str.general	BFIY	Circuit Breaker Y breaker failure initiate SELOGIC control equation
BFRYRBRF1	OpEx.general	FBFY	Circuit Breaker Y failure
BFRYRBRF1	OpIn.general	RTY	Circuit Breaker Y retrip
BSSASCBR1	AbrAlm.stVal	BSBCWAL	Breaker contact wear alarm, Breaker S
BSSASCBR1	MechTmAlm.stVal	BSMSOAL	Mechanical slow operation alarm, Breaker S
BSSASCBR1	OpTmAlm.stVal	BSESOAL	Slow electrical operate alarm, Breaker S
BSSASCBR1	ColOpn.stVal	OCS	Breaker open command, Terminal S
BSSBSCBR1	AbrAlm.stVal	BSBCWAL	Breaker contact wear alarm, Breaker S
BSSBSCBR1	MechTmAlm.stVal	BSMSOAL	Mechanical slow operation alarm, Breaker S
BSSBSCBR1	OpTmAlm.stVal	BSESOAL	Slow electrical operate alarm, Breaker S
BSSBSCBR1	ColOpn.stVal	OCS	Breaker open command, Terminal S

Table 10.24 Logical Device: PRO (Protection) (Sheet 3 of 28)

Logical Node	Attribute	Data Source	Comment
BSSCSCBR1	AbrAlm.stVal	BSBCWAL	Breaker contact wear alarm, Breaker S
BSSCSCBR1	MechTmAlm.stVal	BSMSOAL	Mechanical slow operation alarm, Breaker S
BSSCSCBR1	OpTmAlm.stVal	BSESOAL	Slow electrical operate alarm, Breaker S
BSSCSCBR1	OpOpn.general	OCS	Breaker open command, Terminal S
BSTASCBR1	AbrAlm.stVal	BTBCWAL	Breaker contact wear alarm, Breaker T
BSTASCBR1	MechTmAlm.stVal	BTMSOAL	Mechanical slow operation alarm, Breaker T
BSTASCBR1	OpTmAlm.stVal	BTESOAL	Slow electrical operate alarm, Breaker T
BSTASCBR1	ColOpn.stVal	OCT	Breaker open command, Terminal T
BSTBSCBR1	AbrAlm.stVal	BTBCWAL	Breaker contact wear alarm, Breaker T
BSTBSCBR1	MechTmAlm.stVal	BTMSOAL	Mechanical slow operation alarm, Breaker T
BSTBSCBR1	OpTmAlm.stVal	BTESOAL	Slow electrical operate alarm, Breaker T
BSTBSCBR1	ColOpn.stVal	OCT	Breaker open command, Terminal T
BSTCSCBR1	AbrAlm.stVal	BTBCWAL	Breaker contact wear alarm, Breaker T
BSTCSCBR1	MechTmAlm.stVal	BTMSOAL	Mechanical slow operation alarm, Breaker T
BSTCSCBR1	OpTmAlm.stVal	BTESOAL	Slow electrical operate alarm, Breaker T
BSTCSCBR1	OpOpn.general	OCT	Breaker open command, Terminal T
BSUASCBR1	AbrAlm.stVal	BUBCWAL	Breaker contact wear alarm, Breaker U
BSUASCBR1	MechTmAlm.stVal	BUMSOAL	Mechanical slow operation alarm, Breaker U
BSUASCBR1	OpTmAlm.stVal	BUESOAL	Slow electrical operate alarm, Breaker U
BSUASCBR1	ColOpn.stVal	OCU	Breaker open command, Terminal U
BSUBSCBR1	AbrAlm.stVal	BUBCWAL	Breaker contact wear alarm, Breaker U
BSUBSCBR1	MechTmAlm.stVal	BUMSOAL	Mechanical slow operation alarm, Breaker U
BSUBSCBR1	OpTmAlm.stVal	BUESOAL	Slow electrical operate alarm, Breaker U
BSUBSCBR1	ColOpn.stVal	OCU	Breaker open command, Terminal U
BSUCSCBR1	AbrAlm.stVal	BUBCWAL	Breaker contact wear alarm, Breaker U
BSUCSCBR1	MechTmAlm.stVal	BUMSOAL	Mechanical slow operation alarm, Breaker U
BSUCSCBR1	OpTmAlm.stVal	BUESOAL	Slow electrical operate alarm, Breaker U
BSUCSCBR1	OpOpn.general	OCU	Breaker open command, Terminal U
BSWASCBR1	AbrAlm.stVal	BWBCWAL	Breaker contact wear alarm, Breaker W
BSWASCBR1	MechTmAlm.stVal	BWMSOAL	Mechanical slow operation alarm, Breaker W
BSWASCBR1	OpTmAlm.stVal	BWESOAL	Slow electrical operate alarm, Breaker W
BSWASCBR1	ColOpn.stVal	OCW	Breaker open command, Terminal W
BSWBSCBR1	AbrAlm.stVal	BWBCWAL	Breaker contact wear alarm, Breaker W
BSWBSCBR1	MechTmAlm.stVal	BWMSOAL	Mechanical slow operation alarm, Breaker W
BSWBSCBR1	OpTmAlm.stVal	BWESOAL	Slow electrical operate alarm, Breaker W
BSWBSCBR1	ColOpn.stVal	OCW	Breaker open command, Terminal W
BSWCSCBR1	AbrAlm.stVal	BWBCWAL	Breaker contact wear alarm, Breaker W
BSWCSCBR1	MechTmAlm.stVal	BWMSOAL	Mechanical slow operation alarm, Breaker W
BSWCSCBR1	OpTmAlm.stVal	BWESOAL	Slow electrical operate alarm, Breaker W
BSWCSCBR1	OpOpn.general	OCW	Breaker open command, Terminal W
BSXASCBR1	AbrAlm.stVal	BXBCWAL	Breaker contact wear alarm, Breaker X

Table 10.24 Logical Device: PRO (Protection) (Sheet 4 of 28)

Logical Node	Attribute	Data Source	Comment
BSXASCBR1	MechTmAlm.stVal	BXMSOAL	Mechanical slow operation alarm, Breaker X
BSXASCBR1	OpTmAlm.stVal	BXESOAL	Slow electrical operate alarm, Breaker X
BSXASCBR1	ColOpn.stVal	OCX	Breaker open command, Terminal X
BSXBSCBR1	AbrAlm.stVal	BXBCWAL	Breaker contact wear alarm, Breaker X
BSXBSCBR1	MechTmAlm.stVal	BXMSOAL	Mechanical slow operation alarm, Breaker X
BSXBSCBR1	OpTmAlm.stVal	BXESOAL	Slow electrical operate alarm, Breaker X
BSXBSCBR1	ColOpn.stVal	OCX	Breaker open command, Terminal X
BSXCSCBR1	AbrAlm.stVal	BXBCWAL	Breaker contact wear alarm, Breaker X
BSXCSCBR1	MechTmAlm.stVal	BXMSOAL	Mechanical slow operation alarm, Breaker X
BSXCSCBR1	OpTmAlm.stVal	BXESOAL	Slow electrical operate alarm, Breaker X
BSXCSCBR1	OpOpn.general	OCX	Breaker open command, Terminal X
BSYASCBR1	AbrAlm.stVal	BYBCWAL	Breaker contact wear alarm, Breaker Y
BSYASCBR1	MechTmAlm.stVal	BYMSOAL	Mechanical slow operation alarm, Breaker Y
BSYASCBR1	OpTmAlm.stVal	BYESOAL	Slow electrical operate alarm, Breaker Y
BSYASCBR1	ColOpn.stVal	OCY	Breaker open command, Terminal Y
BSYBSCBR1	AbrAlm.stVal	BYBCWAL	Breaker contact wear alarm, Breaker Y
BSYBSCBR1	MechTmAlm.stVal	BYMSOAL	Mechanical slow operation alarm, Breaker Y
BSYBSCBR1	OpTmAlm.stVal	BYESOAL	Slow electrical operate alarm, Breaker Y
BSYBSCBR1	ColOpn.stVal	OCY	Breaker open command, Terminal Y
BSYCSCBR1	AbrAlm.stVal	BYBCWAL	Breaker contact wear alarm, Breaker Y
BSYCSCBR1	MechTmAlm.stVal	BYMSOAL	Mechanical slow operation alarm, Breaker Y
BSYCSCBR1	OpTmAlm.stVal	BYESOAL	Slow electrical operate alarm, Breaker Y
BSYCSCBR1	OpOpn.general	OCY	Breaker open command, Terminal Y
D1PVPH1	Op.general	24D1T	Volts/Hertz Level 1 timed out
D1PVPH1	Str.dirGeneral		Unknown
D1PVPH1	Str.general	24D1	Volts/Hertz Element Level 1 asserted
D2PVPH1	Op.general	24D2T	Volts/Hertz Level 2 timed out
D2PVPH1	Str.dirGeneral		Unknown
D2PVPH1	Str.general	24D1	Volts/Hertz Element Level 1 asserted
D87QPDIF1	Str.general	87PQ	Zone 1 minimum pickup and slope conditions satisfied for negative-sequence differential element
D87QPDIF1	Op.general	87Q	Zone 1 negative-sequence differential element operated
D87R1PDIF1	Op.general	87R	Zone 1 phase percentage-restrained differential element operated
D87R2PDIF1	Op.general	87R2	Zone 2 phase percentage-restrained differential element operated
D87RA1PDIF1	Op.general	87RA	Zone 1 phase percentage-restrained differential element operated, A-Phase
D87RA1PDIF1	Str.dirGeneral		Unknown
D87RA1PDIF1	Str.general	P87A	Zone 1 phase percentage-restrained differential element asserted (no security timer), A-Phase

Table 10.24 Logical Device: PRO (Protection) (Sheet 5 of 28)

Logical Node	Attribute	Data Source	Comment
D87RA2PDIF1	Op.general	87RA2	Zone 2 phase percentage-restrained differential element operated, A-Phase
D87RA2PDIF1	Str.dirGeneral		Unknown
D87RA2PDIF1	Str.general	P87A2	Zone 2 phase percentage-restrained differential element asserted (no security timer), A-Phase
D87RB1PDIF1	Op.general	87RB	Zone 1 phase percentage-restrained differential element operated, B-Phase
D87RB1PDIF1	Str.dirGeneral		Unknown
D87RB1PDIF1	Str.general	P87B	Zone 1 phase percentage-restrained differential element asserted (no security timer), B-Phase
D87RB2PDIF1	Op.general	87RB2	Zone 2 phase percentage-restrained differential element operated, B-Phase
D87RB2PDIF1	Str.dirGeneral		Unknown
D87RB2PDIF1	Str.general	P87B2	Zone 2 phase percentage-restrained differential element asserted (no security timer), B-Phase
D87RC1PDIF1	Op.general	87RC	Zone 1 phase percentage-restrained differential element operated, C-Phase
D87RC1PDIF1	Str.dirGeneral		Unknown
D87RC1PDIF1	Str.general	P87C	Zone 1 phase percentage-restrained differential element asserted (no security timer), C-Phase
D87RC2PDIF1	Op.general	87RC2	Zone 2 phase percentage-restrained differential element operated, C-Phase
D87RC2PDIF1	Str.dirGeneral		Unknown
D87RC2PDIF1	Str.general	P87C2	Zone 2 phase percentage-restrained differential element asserted (no security timer), C-Phase
D87TPDIF1	Op.general	87T	Zone 1 transformer differential element operated (87R OR 87Q OR 87U)
D87UPDIF1	Op.general	87U	Zone 1 unrestrained differential element operated
D87UPDIF1	Op.phsA	87UA	Zone 1 unrestrained differential overcurrent element operated, A-Phase
D87UPDIF1	Op.phsB	87UB	Zone 1 unrestrained differential overcurrent element operated, B-Phase
D87UPDIF1	Op.phsC	87UC	Zone 1 unrestrained differential overcurrent element operated, C-Phase
DC01CILO1	EnaCls.stVal	89ENC01	Disconnect 1 close control operation enabled
DC01CILO1	EnaOpn.stVal	89ENO01	Disconnect 1 open control operation enabled
DC01CSWI1	OpCls.general	89CLS01	Disconnect Close 1 output
DC01CSWI1	OpOpn.general	89OPE01	Disconnect Open 1 output
DC01CSWI1	Pos.stVal	89CL01|89OPN01?0:1:2:3[b]	Disconnect/Isolator 1 status
DC01CSWI1	LocSta.stVal	LOCSTA	Control authority at station level
DC02CILO1	EnaCls.stVal	89ENC02	Disconnect 2 close control operation enabled
DC02CILO1	EnaOpn.stVal	89ENO02	Disconnect 2 open control operation enabled
DC02CSWI1	OpCls.general	89CLS02	Disconnect Close 2 output
DC02CSWI1	OpOpn.general	89OPE02	Disconnect Open 2 output
DC02CSWI1	Pos.stVal	89CL02|89OPN02?0:1:2:3[b]	Disconnect/Isolator 2 status
DC02CSWI1	LocSta.stVal	LOCSTA	Control authority at station level

Table 10.24 Logical Device: PRO (Protection) (Sheet 6 of 28)

Logical Node	Attribute	Data Source	Comment
DC03CILO1	EnaCls.stVal	89ENC03	Disconnect 3 close control operation enabled
DC03CILO1	EnaOpn.stVal	89ENO03	Disconnect 3 open control operation enabled
DC03CSWI1	OpCls.general	89CLS03	Disconnect Close 3 output
DC03CSWI1	OpOpn.general	89OPE03	Disconnect Open 3 output
DC03CSWI1	Pos.stVal	89CL03|89OPN03?0:1:2:3[b]	Disconnect/Isolator 3 status
DC03CSWI1	LocSta.stVal	LOCSTA	Control authority at station level
DC04CILO1	EnaCls.stVal	89ENC04	Disconnect 4 close control operation enabled
DC04CILO1	EnaOpn.stVal	89ENO04	Disconnect 4 open control operation enabled
DC04CSWI1	OpCls.general	89CLS04	Disconnect Close 4 output
DC04CSWI1	OpOpn.general	89OPE04	Disconnect Open 4 output
DC04CSWI1	Pos.stVal	89CL04|89OPN04?0:1:2:3[b]	Disconnect/Isolator 4 status
DC04CSWI1	LocSta.stVal	LOCSTA	Control authority at station level
DC05CILO1	EnaCls.stVal	89ENC05	Disconnect 5 close control operation enabled
DC05CILO1	EnaOpn.stVal	89ENO05	Disconnect 5 open control operation enabled
DC05CSWI1	OpCls.general	89CLS05	Disconnect Close 5 output
DC05CSWI1	OpOpn.general	89OPE05	Disconnect Open 5 output
DC05CSWI1	Pos.stVal	89CL05|89OPN05?0:1:2:3[b]	Disconnect/Isolator 5 status
DC05CSWI1	LocSta.stVal	LOCSTA	Control authority at station level
DC06CILO1	EnaCls.stVal	89ENC06	Disconnect 6 close control operation enabled
DC06CILO1	EnaOpn.stVal	89ENO06	Disconnect 6 open control operation enabled
DC06CSWI1	OpCls.general	89CLS06	Disconnect Close 6 output
DC06CSWI1	OpOpn.general	89OPE06	Disconnect Open 6 output
DC06CSWI1	Pos.stVal	89CL06|89OPN06?0:1:2:3[b]	Disconnect/Isolator 6 status
DC06CSWI1	LocSta.stVal	LOCSTA	Control authority at station level
DC07CILO1	EnaCls.stVal	89ENC07	Disconnect 7 close control operation enabled
DC07CILO1	EnaOpn.stVal	89ENO07	Disconnect 7 open control operation enabled
DC07CSWI1	OpCls.general	89CLS07	Disconnect Close 7 output
DC07CSWI1	OpOpn.general	89OPE07	Disconnect Open 7 output
DC07CSWI1	Pos.stVal	89CL07|89OPN07?0:1:2:3[b]	Disconnect/Isolator 7 status
DC07CSWI1	LocSta.stVal	LOCSTA	Control authority at station level
DC08CILO1	EnaCls.stVal	89ENC08	Disconnect 8 close control operation enabled
DC08CILO1	EnaOpn.stVal	89ENO08	Disconnect 8 open control operation enabled
DC08CSWI1	OpCls.general	89CLS08	Disconnect Close 8 output
DC08CSWI1	OpOpn.general	89OPE08	Disconnect Open 8 output
DC08CSWI1	Pos.stVal	89CL08|89OPN08?0:1:2:3[b]	Disconnect/Isolator 8 status
DC08CSWI1	LocSta.stVal	LOCSTA	Control authority at station level
DC09CILO1	EnaCls.stVal	89ENC09	Disconnect 9 close control operation enabled
DC09CILO1	EnaOpn.stVal	89ENO09	Disconnect 9 open control operation enabled
DC09CSWI1	OpCls.general	89CLS09	Disconnect Close 9 output
DC09CSWI1	OpOpn.general	89OPE09	Disconnect Open 9 output
DC09CSWI1	Pos.stVal	89CL09|89OPN09?0:1:2:3[b]	Disconnect/Isolator 9 status

Table 10.24 Logical Device: PRO (Protection) (Sheet 7 of 28)

Logical Node	Attribute	Data Source	Comment
DC09CSWI1	LocSta.stVal	LOCSTA	Control authority at station level
DC10CILO1	EnaCls.stVal	89ENC10	Disconnect 10 close control operation enabled
DC10CILO1	EnaOpn.stVal	89ENO10	Disconnect 10 open control operation enabled
DC10CSWI1	Loc.stVal	LOC	Control authority at local (bay) level
DC10CSWI1	OpCls.general	89CLS10	Disconnect Close 10 output
DC10CSWI1	OpOpn.general	89OPE10	Disconnect Open 10 output
DC10CSWI1	Pos.stVal	89CL10|89OPN10?0:1:2:3[b]	Disconnect/Isolator 10 status
DC10CSWI1	LocSta.stVal	LOCSTA	Control authority at station level
DC11CILO1	EnaCls.stVal	89ENC11	Disconnect 11 close control operation enabled
DC11CILO1	EnaOpn.stVal	89ENO11	Disconnect 11 open control operation enabled
DC11CSWI1	Loc.stVal	LOC	Control authority at local (bay) level
DC11CSWI1	OpCls.general	89CLS11	Disconnect Close 11 output
DC11CSWI1	OpOpn.general	89OPE11	Disconnect Open 11 output
DC11CSWI1	Pos.stVal	89CL11|89OPN11?0:1:2:3[b]	Disconnect/Isolator 11 status
DC11CSWI1	LocSta.stVal	LOCSTA	Control authority at station level
DC12CILO1	EnaCls.stVal	89ENC12	Disconnect 12 close control operation enabled
DC12CILO1	EnaOpn.stVal	89ENO12	Disconnect 12 open control operation enabled
DC12CSWI1	Loc.stVal	LOC	Control authority at local (bay) level
DC12CSWI1	OpCls.general	89CLS12	Disconnect Close 12 output
DC12CSWI1	OpOpn.general	89OPE12	Disconnect Open 12 output
DC12CSWI1	Pos.stVal	89CL12|89OPN12?0:1:2:3[b]	Disconnect/Isolator 12 status
DC12CSWI1	LocSta.stVal	LOCSTA	Control authority at station level
DC13CILO1	EnaCls.stVal	89ENC13	Disconnect 13 close control operation enabled
DC13CILO1	EnaOpn.stVal	89ENO13	Disconnect 13 open control operation enabled
DC13CSWI1	Loc.stVal	LOC	Control authority at local (bay) level
DC13CSWI1	OpCls.general	89CLS13	Disconnect Close 13 output
DC13CSWI1	OpOpn.general	89OPE13	Disconnect Open 13 output
DC13CSWI1	Pos.stVal	89CL13|89OPN13?0:1:2:3[b]	Disconnect/Isolator 13 status
DC13CSWI1	LocSta.stVal	LOCSTA	Control authority at station level
DC14CILO1	EnaCls.stVal	89ENC14	Disconnect 14 close control operation enabled
DC14CILO1	EnaOpn.stVal	89ENO14	Disconnect 14 open control operation enabled
DC14CSWI1	Loc.stVal	LOC	Control authority at local (bay) level
DC14CSWI1	OpCls.general	89CLS14	Disconnect Close 14 output
DC14CSWI1	OpOpn.general	89OPE14	Disconnect Open 14 output
DC14CSWI1	Pos.stVal	89CL14|89OPN14?0:1:2:3[b]	Disconnect/Isolator 14 status
DC14CSWI1	LocSta.stVal	LOCSTA	Control authority at station level
DC15CILO1	EnaCls.stVal	89ENC15	Disconnect 15 close control operation enabled
DC15CILO1	EnaOpn.stVal	89ENO15	Disconnect 15 open control operation enabled
DC15CSWI1	Loc.stVal	LOC	Control authority at local (bay) level
DC15CSWI1	OpCls.general	89CLS15	Disconnect Close 15 output
DC15CSWI1	OpOpn.general	89OPE15	Disconnect Open 15 output

Table 10.24 Logical Device: PRO (Protection) (Sheet 8 of 28)

Logical Node	Attribute	Data Source	Comment
DC15CSWI1	Pos.stVal	89CL15|89OPN15?0:1:2:3[b]	Disconnect/Isolator 15 status
DC15CSWI1	LocSta.stVal	LOCSTA	Control authority at station level
DC16CILO1	EnaCls.stVal	89ENC16	Disconnect 16 close control operation enabled
DC16CILO1	EnaOpn.stVal	89ENO16	Disconnect 16 open control operation enabled
DC16CSWI1	Loc.stVal	LOC	Control authority at local (bay) level
DC16CSWI1	OpCls.general	89CLS16	Disconnect Close 16 output
DC16CSWI1	OpOpn.general	89OPE16	Disconnect Open 16 output
DC16CSWI1	Pos.stVal	89CL16|89OPN16?0:1:2:3[b]	Disconnect/Isolator 16 status
DC16CSWI1	LocSta.stVal	LOCSTA	Control authority at station level
DC17CILO1	EnaCls.stVal	89ENC17	Disconnect 17 close control operation enabled
DC17CILO1	EnaOpn.stVal	89ENO17	Disconnect 17 open control operation enabled
DC17CSWI1	Loc.stVal	LOC	Control authority at local (bay) level
DC17CSWI1	OpCls.general	89CLS17	Disconnect Close 17 output
DC17CSWI1	OpOpn.general	89OPE17	Disconnect Open 17 output
DC17CSWI1	Pos.stVal	89CL17|89OPN17?0:1:2:3[b]	Disconnect/Isolator 17 status
DC17CSWI1	LocSta.stVal	LOCSTA	Control authority at station level
DC18CILO1	EnaCls.stVal	89ENC18	Disconnect 18 close control operation enabled
DC18CILO1	EnaOpn.stVal	89ENO18	Disconnect 18 open control operation enabled
DC18CSWI1	Loc.stVal	LOC	Control authority at local (bay) level
DC18CSWI1	OpCls.general	89CLS18	Disconnect Close 18 output
DC18CSWI1	OpOpn.general	89OPE18	Disconnect Open 18 output
DC18CSWI1	Pos.stVal	89CL18|89OPN18?0:1:2:3[b]	Disconnect/Isolator 18 status
DC18CSWI1	LocSta.stVal	LOCSTA	Control authority at station level
DC19CILO1	EnaCls.stVal	89ENC19	Disconnect 19 close control operation enabled
DC19CILO1	EnaOpn.stVal	89ENO19	Disconnect 19 open control operation enabled
DC19CSWI1	Loc.stVal	LOC	Control authority at local (bay) level
DC19CSWI1	OpCls.general	89CLS19	Disconnect Close 19 output
DC19CSWI1	OpOpn.general	89OPE19	Disconnect Open 19 output
DC19CSWI1	Pos.stVal	89CL19|89OPN19?0:1:2:3[b]	Disconnect/Isolator 19 status
DC19CSWI1	LocSta.stVal	LOCSTA	Control authority at station level
DC1CSWI1	Loc.stVal	LOC	Control authority at local (bay) level
DC20CILO1	EnaCls.stVal	89ENC20	Disconnect 20 close control operation enabled
DC20CILO1	EnaOpn.stVal	89ENO20	Disconnect 20 open control operation enabled
DC20CSWI1	Loc.stVal	LOC	Control authority at local (bay) level
DC20CSWI1	OpCls.general	89CLS20	Disconnect Close 20 output
DC20CSWI1	OpOpn.general	89OPE20	Disconnect Open 20 output
DC20CSWI1	Pos.stVal	89CL20|89OPN20?0:1:2:3[b]	Disconnect/Isolator 20 status
DC20CSWI1	LocSta.stVal	LOCSTA	Control authority at station level
DC2CSWI1	Loc.stVal	LOC	Control authority at local (bay) level
DC3CSWI1	Loc.stVal	LOC	Control authority at local (bay) level
DC4CSWI1	Loc.stVal	LOC	Control authority at local (bay) level

Table 10.24 Logical Device: PRO (Protection) (Sheet 9 of 28)

Logical Node	Attribute	Data Source	Comment
DC5CSWI1	Loc.stVal	LOC	Control authority at local (bay) level
DC6CSWI1	Loc.stVal	LOC	Control authority at local (bay) level
DC7CSWI1	Loc.stVal	LOC	Control authority at local (bay) level
DC8CSWI1	Loc.stVal	LOC	Control authority at local (bay) level
DC9CSWI1	Loc.stVal	LOC	Control authority at local (bay) level
FLTRRDRE1	FltTyp.stVal	FLTYPE[c]	Affected phases for the latest event
FLTRRDRE1	FltCaus.stVal	FLTCAUS[d]	Event cause for the latest event
FLTRRDRE1	FltNum.stVal	FLRNUM	Event number
FLTRRDRE1	RcdMade.stVal	FLREP	Event report present
HB24L1PHAR1	Str.general	H2BKL1	Second- and fourth-harmonic cross blocking asserted, Line 1
HB24L1PHAR1	Str.phsA	IA2BKL1	Second- and fourth-harmonic blocking asserted, A-Phase
HB24L1PHAR1	Str.phsB	IB2BKL1	Second- and fourth-harmonic blocking asserted, B-Phase
HB24L1PHAR1	Str.phsC	IC2BKL1	Second- and fourth-harmonic blocking asserted, C-Phase
HB24PHAR1	Str.general	87XBK2	Second- and fourth-harmonic cross blocking asserted
HB24PHAR1	Str.phsA	87ABK2	Second- and fourth-harmonic blocking asserted, A-Phase
HB24PHAR1	Str.phsB	87BBK2	Second- and fourth-harmonic blocking asserted, B-Phase
HB24PHAR1	Str.phsC	87CBK2	Second- and fourth-harmonic blocking asserted, C-Phase
HB2SPHAR1	Str.general	H2BKS	Second-harmonic blocking asserted, Terminal S
HB2SPHAR1	Str.phsA	IAS2BK	Second-harmonic blocking asserted, A-Phase, Terminal S
HB2SPHAR1	Str.phsB	IBS2BK	Second-harmonic blocking asserted, B-Phase, Terminal S
HB2SPHAR1	Str.phsC	ICS2BK	Second-harmonic blocking asserted, C-Phase, Terminal S
HB2STPHAR1	Str.general	H2BK1	Second-harmonic blocking asserted, Terminal ST
HB2STPHAR1	Str.phsA	IA12BK	Second-harmonic blocking asserted, A-Phase, Terminal ST
HB2STPHAR1	Str.phsB	IB12BK	Second-harmonic blocking asserted, B-Phase, Terminal ST
HB2STPHAR1	Str.phsC	IC12BK	Second-harmonic blocking asserted, C-Phase, Terminal ST
HB2TPHAR1	Str.general	H2BKT	Second-harmonic blocking asserted, Terminal T
HB2TPHAR1	Str.phsA	IAT2BK	Second-harmonic blocking asserted, A-Phase, Terminal T
HB2TPHAR1	Str.phsB	IBT2BK	Second-harmonic blocking asserted, B-Phase, Terminal T
HB2TPHAR1	Str.phsC	ICT2BK	Second-harmonic blocking asserted, C-Phase, Terminal T
HB2TUPHAR1	Str.general	H2BK2	Second-harmonic blocking asserted, Terminal TU

Table 10.24 Logical Device: PRO (Protection) (Sheet 10 of 28)

Logical Node	Attribute	Data Source	Comment
HB2TUPHAR1	Str.phsA	IA22BK	Second-harmonic blocking asserted, A-Phase, Terminal TU
HB2TUPHAR1	Str.phsB	IB22BK	Second-harmonic blocking asserted, B-Phase, Terminal TU
HB2TUPHAR1	Str.phsC	IC22BK	Second-harmonic blocking asserted, C-Phase, Terminal TU
HB2UPHAR1	Str.general	H2BKU	Second-harmonic blocking asserted, Terminal U
HB2UPHAR1	Str.phsA	IAU2BK	Second-harmonic blocking asserted, A-Phase, Terminal U
HB2UPHAR1	Str.phsB	IBU2BK	Second-harmonic blocking asserted, B-Phase, Terminal U
HB2UPHAR1	Str.phsC	ICU2BK	Second-harmonic blocking asserted, C-Phase, Terminal U
HB2UWPHAR1	Str.general	H2BK3	Second-harmonic blocking asserted, Terminal UW
HB2UWPHAR1	Str.phsA	IA32BK	Second-harmonic blocking asserted, A-Phase, Terminal UW
HB2UWPHAR1	Str.phsB	IB32BK	Second-harmonic blocking asserted, B-Phase, Terminal UW
HB2UWPHAR1	Str.phsC	IC32BK	Second-harmonic blocking asserted, C-Phase, Terminal UW
HB2WPHAR1	Str.general	H2BKW	Second-harmonic blocking asserted, Terminal W
HB2WPHAR1	Str.phsA	IAW2BK	Second-harmonic blocking asserted, A-Phase, Terminal W
HB2WPHAR1	Str.phsB	IBW2BK	Second-harmonic blocking asserted, B-Phase, Terminal W
HB2WPHAR1	Str.phsC	ICW2BK	Second-harmonic blocking asserted, C-Phase, Terminal W
HB2WXPHAR1	Str.general	H2BK4	Second-harmonic blocking asserted, Terminal WX
HB2WXPHAR1	Str.phsA	IA42BK	Second-harmonic blocking asserted, A-Phase, Terminal WX
HB2WXPHAR1	Str.phsB	IB42BK	Second-harmonic blocking asserted, B-Phase, Terminal WX
HB2WXPHAR1	Str.phsC	IC42BK	Second-harmonic blocking asserted, C-Phase, Terminal WX
HB2XPHAR1	Str.general	H2BKX	Second-harmonic blocking asserted, Terminal X
HB2XPHAR1	Str.phsA	IAX2BK	Second-harmonic blocking asserted, A-Phase, Terminal X
HB2XPHAR1	Str.phsB	IBX2BK	Second-harmonic blocking asserted, B-Phase, Terminal X
HB2XPHAR1	Str.phsC	ICX2BK	Second-harmonic blocking asserted, C-Phase, Terminal X
HB2YPHAR1	Str.general	H2BKY	Second-harmonic blocking asserted, Terminal Y
HB2YPHAR1	Str.phsA	IAY2BK	Second-harmonic blocking asserted, A-Phase, Terminal Y
HB2YPHAR1	Str.phsB	IBY2BK	Second-harmonic blocking asserted, B-Phase, Terminal Y
HB2YPHAR1	Str.phsC	ICY2BK	Second-harmonic blocking asserted, C-Phase, Terminal Y

Table 10.24 Logical Device: PRO (Protection) (Sheet 11 of 28)

Logical Node	Attribute	Data Source	Comment
HB5L1PHAR1	Str.general	H5BKL1	Fifth-harmonic cross blocking asserted, Line 1
HB5L1PHAR1	Str.phsA	IA5BKL1	Fifth-harmonic blocking asserted, A-Phase
HB5L1PHAR1	Str.phsB	IB5BKL1	Fifth-harmonic blocking asserted, B-Phase
HB5L1PHAR1	Str.phsC	IC5BKL1	Fifth-harmonic blocking asserted, C-Phase
HB5PHAR1	Str.general	87XBK5	Fifth-harmonic cross blocking asserted
HB5PHAR1	Str.phsA	87ABK5	Fifth-harmonic harmonic blocking asserted, A-Phase
HB5PHAR1	Str.phsB	87BBK5	Fifth-harmonic harmonic blocking asserted, B-Phase
HB5PHAR1	Str.phsC	87CBK5	Fifth-harmonic harmonic blocking asserted, C-Phase
HRPHAR1	Str.general	CSV01	87AHR OR 87BHR OR 87CHR
HRPHAR1	Str.phsA	87AHR	Zone 1 harmonic-restrained phase-differential element asserted (no security timer), A-Phase
HRPHAR1	Str.phsB	87BHR	Zone 1 harmonic-restrained phase-differential element asserted (no security timer), B-Phase
HRPHAR1	Str.phsC	87CHR	Zone 1 harmonic-restrained phase-differential element asserted (no security timer), C-Phase
IT01PTOC1	Op.general	51T01	Inverse-Time Element 01 timed out
IT01PTOC1	Str.dirGeneral		Unknown
IT01PTOC1	Str.general	51S01	Inverse-Time Element 01 picked up
IT02PTOC1	Op.general	51T02	Inverse-Time Element 02 timed out
IT02PTOC1	Str.dirGeneral		Unknown
IT02PTOC1	Str.general	51S02	Inverse-Time Element 02 picked up
IT03PTOC1	Op.general	51T03	Inverse-Time Element 03 timed out
IT03PTOC1	Str.dirGeneral		Unknown
IT03PTOC1	Str.general	51S03	Inverse-Time Element 03 picked up
IT04PTOC1	Op.general	51T04	Inverse-Time Element 04 timed out
IT04PTOC1	Str.dirGeneral		Unknown
IT04PTOC1	Str.general	51S04	Inverse-Time Element 04 picked up
IT05PTOC1	Op.general	51T05	Inverse-Time Element 05 timed out
IT05PTOC1	Str.dirGeneral		Unknown
IT05PTOC1	Str.general	51S05	Inverse-Time Element 05 picked up
IT06PTOC1	Op.general	51T06	Inverse-Time Element 06 timed out
IT06PTOC1	Str.dirGeneral		Unknown
IT06PTOC1	Str.general	51S06	Inverse-Time Element 06 picked up
IT07PTOC1	Op.general	51T07	Inverse-Time Element 07 timed out
IT07PTOC1	Str.dirGeneral		Unknown
IT07PTOC1	Str.general	51S07	Inverse-Time Element 07 picked up
IT08PTOC1	Op.general	51T08	Inverse-Time Element 08 timed out
IT08PTOC1	Str.dirGeneral		Unknown
IT08PTOC1	Str.general	51S08	Inverse-Time Element 08 picked up
IT09PTOC1	Op.general	51T09	Inverse-Time Element 09 timed out
IT09PTOC1	Str.dirGeneral		Unknown
IT09PTOC1	Str.general	51S09	Inverse-Time Element 09 picked up

Table 10.24 Logical Device: PRO (Protection) (Sheet 12 of 28)

Logical Node	Attribute	Data Source	Comment
IT10PTOC1	Op.general	51T10	Inverse-Time Element 10 timed out
IT10PTOC1	Str.dirGeneral		Unknown
IT10PTOC1	Str.general	51S10	Inverse-Time Element 10 picked up
IT11PTOC1	Op.general	51T11	Inverse-Time Element 11 timed out
IT11PTOC1	Str.dirGeneral		Unknown
IT11PTOC1	Str.general	51S11	Inverse-Time Element 11 picked up
IT12PTOC1	Op.general	51T12	Inverse-Time Element 12 timed out
IT12PTOC1	Str.dirGeneral		Unknown
IT12PTOC1	Str.general	51S12	Inverse-Time Element 12 picked up
IT13PTOC1	Op.general	51T13	Inverse-Time Element 13 timed out
IT13PTOC1	Str.dirGeneral		Unknown
IT13PTOC1	Str.general	51S13	Inverse-Time Element 13 picked up
IT14PTOC1	Op.general	51T14	Inverse-Time Element 14 timed out
IT14PTOC1	Str.dirGeneral		Unknown
IT14PTOC1	Str.general	51S14	Inverse-Time Element 14 picked up
IT15PTOC1	Op.general	51T15	Inverse-Time Element 15 timed out
IT15PTOC1	Str.dirGeneral		Unknown
IT15PTOC1	Str.general	51S15	Inverse-Time Element 15 picked up
IT16PTOC1	Op.general	51T16	Inverse-Time Element 16 timed out
IT16PTOC1	Str.dirGeneral		Unknown
IT16PTOC1	Str.general	51S16	Inverse-Time Element 16 picked up
IT17PTOC1	Op.general	51T17	Inverse-Time Element 17 timed out
IT17PTOC1	Str.dirGeneral		Unknown
IT17PTOC1	Str.general	51S17	Inverse-Time Element 17 picked up
IT18PTOC1	Op.general	51T18	Inverse-Time Element 18 timed out
IT18PTOC1	Str.dirGeneral		Unknown
IT18PTOC1	Str.general	51S18	Inverse-Time Element 18 picked up
IT19PTOC1	Op.general	51T19	Inverse-Time Element 19 timed out
IT19PTOC1	Str.dirGeneral		Unknown
IT19PTOC1	Str.general	51S19	Inverse-Time Element 19 picked up
IT20PTOC1	Op.general	51T20	Inverse-Time Element 20 timed out
IT20PTOC1	Str.dirGeneral		Unknown
IT20PTOC1	Str.general	51S20	Inverse-Time Element 20 picked up
LLN0	LocSta.stVal	LOCSTA	Control authority at station level
LLN0	Loc.stVal	LOC	Control authority at local (bay) level
LLN0	Mod.stVal	I60MOD[e]	IEC 61850 Mode/Behavior status
LOPVPTUV1	Str.general	LOPV	Loss-of-potential, Terminal V
LOPVPTUV1	Op.general	LOPV	Loss-of-potential, Terminal V
LOPZPTUV1	Str.general	LOPZ	Loss-of-potential, Terminal Z
LOPZPTUV1	Op.general	LOPZ	Loss-of-potential, Terminal Z
O1P1PTOV1	Op.general	591P1T	Overvoltage Element 1, Level 1 timed out

Table 10.24 Logical Device: PRO (Protection) (Sheet 13 of 28)

Logical Node	Attribute	Data Source	Comment
O1P1PTOV1	Str.dirGeneral		Unknown
O1P1PTOV1	Str.general	591P1	Overvoltage Element 1, Level 1 asserted
O1P2PTOV1	Str.dirGeneral		Unknown
O1P2PTOV1	Str.general	591P2	Overvoltage Element 1, Level 2 asserted
O2P1PTOV1	Op.general	592P1T	Overvoltage Element 2, Level 1 timed out
O2P1PTOV1	Str.dirGeneral		Unknown
O2P1PTOV1	Str.general	592P1	Overvoltage Element 2, Level 1 asserted
O2P2PTOV1	Str.dirGeneral		Unknown
O2P2PTOV1	Str.general	592P2	Overvoltage Element 2, Level 2 asserted
O3P1PTOV1	Op.general	593P1T	Overvoltage Element 3, Level 1 timed out
O3P1PTOV1	Str.dirGeneral		Unknown
O3P1PTOV1	Str.general	593P1	Overvoltage Element 3, Level 1 asserted
O3P2PTOV1	Str.dirGeneral		Unknown
O3P2PTOV1	Str.general	593P2	Overvoltage Element 3, Level 2 asserted
O4P1PTOV1	Op.general	594P1T	Overvoltage Element 4, Level 1 timed out
O4P1PTOV1	Str.dirGeneral		Unknown
O4P1PTOV1	Str.general	594P1	Overvoltage Element 4, Level 1 asserted
O4P2PTOV1	Str.dirGeneral		Unknown
O4P2PTOV1	Str.general	594P2	Overvoltage Element 4, Level 2 asserted
O5P1PTOV1	Op.general	595P1T	Overvoltage Element 5, Level 1 timed out
O5P1PTOV1	Str.dirGeneral		Unknown
O5P1PTOV1	Str.general	595P1	Overvoltage Element 5, Level 1 asserted
O5P2PTOV1	Str.dirGeneral		Unknown
O5P2PTOV1	Str.general	595P2	Overvoltage Element 5, Level 2 asserted
OSB1L1RPSB1	Str.general	OSBL1	Out-of-step block, Line 1
OSB1L1RPSB1	BlkZn.stVal	OSB1L1	Block Zone 1 during an out-of-step condition, Line 1
OSB2L1RPSB1	Str.general	OSBL1	Out-of-step block, Line 1
OSB2L1RPSB1	BlkZn.stVal	OSB2L1	Block Zone 2 during an out-of-step condition, Line 1
OSB3L1RPSB1	Str.general	OSBL1	Out-of-step block, Line 1
OSB3L1RPSB1	BlkZn.stVal	OSB3L1	Block Zone 3 during an out-of-step condition, Line 1
OSB4L1RPSB1	Str.general	OSBL1	Out-of-step block, Line 1
OSB4L1RPSB1	BlkZn.stVal	OSB4L1	Block Zone 4 during an out-of-step condition, Line 1
PROLPHD1	PhyHealth.stVal	EN?3:1[f]	Relay enabled
REF501PIOC1	Str.general	REF501	Neutral Instantaneous Overcurrent Element 1 picked up
REF501PIOC1	Op.general	REF50T1	Neutral Instantaneous Overcurrent Element 1 timed out
REF502PIOC1	Str.general	REF502	Neutral Instantaneous Overcurrent Element 2 picked up
REF502PIOC1	Op.general	REF50T2	Neutral Instantaneous Overcurrent Element 2 timed out
REF503PIOC1	Str.general	REF503	Neutral Instantaneous Overcurrent Element 3 picked up
REF503PIOC1	Op.general	REF50T3	Neutral Instantaneous Overcurrent Element 3 timed out
REF511PTOC1	Str.general	REF511P	Inverse-Time Neutral Overcurrent Element 1 picked up
REF511PTOC1	Op.general	REF51T1	Inverse-Time Neutral Overcurrent Element 1 timed out

Table 10.24 Logical Device: PRO (Protection) (Sheet 14 of 28)

Logical Node	Attribute	Data Source	Comment
REF512PTOC1	Str.general	REF512P	Inverse-Time Neutral Overcurrent Element 2 picked up
REF512PTOC1	Op.general	REF51T2	Inverse-Time Neutral Overcurrent Element 2 timed out
REF513PTOC1	Str.general	REF513P	Inverse-Time Neutral Overcurrent Element 3 picked up
REF513PTOC1	Op.general	REF51T3	Inverse-Time Neutral Overcurrent Element 3 timed out
REFF1PDIF1	Op.general	REFF1	Earth fault inside Restricted Zone 1
REFF2PDIF1	Op.general	REFF2	Earth fault inside Restricted Zone 2
REFF3PDIF1	Op.general	REFF3	Earth fault inside Restricted Zone 3
REFR1PDIF1	Op.general	REFR1	Earth fault outside Restricted Zone 1
REFR2PDIF1	Op.general	REFR2	Earth fault outside Restricted Zone 2
REFR3PDIF1	Op.general	REFR3	Earth fault outside Restricted Zone 3
S52AXCBR1	Loc.stVal	LOCAL	Control authority at local (bay) level
S52AXCBR1	Pos.stVal	52CLS?1:2[g]	Breaker closed, Terminal S
S79RREC1	TrBeh.stVal		3: Next trip is three-pole
S79RREC1	Rec3PhCnt.stVal	F79SHS[h]	Breaker S shot counter present value
S79RREC1	OpCls.general	79CLS	Breaker S supervised close command
S79RREC1	AutoRecSt.stVal	RECSTS	Breaker S autoreclosing status 1: Ready 5: Trip issued by protection 6: Fault disappeared 7: Wait to complete 8: Circuit breaker closed 12: Not ready
SBKRCILO1	EnaCls.stVal	BKENCS	Circuit Breaker S close control operation enabled
SBKRCILO1	EnaOpn.stVal	BKENOS	Circuit Breaker S open control operation enabled
SBKRCSWI1	ColOpn.stVal	OCS	Breaker open command, Terminal S
SBKRCSWI1	LocSta.stVal	LOCSTA	Control authority at station level
SBKRCSWI1	Pos.stVal	52CLS?1:2[g]	Breaker closed, Terminal S
SBKRCSWI1	Loc.stVal	LOC	Control authority at local (bay) level
SBKRCSWI1	OpCls.general	CCS	Breaker Close command, Terminal S
SG1PIOC1	Op.general	50SG1	Residual Definite-Time Element 1, Terminal S asserted
SG1PTOC1	Op.general	67SG1T	Residual Directional/Torque-Controlled Element 1, Terminal S timed out
SG1PTOC1	Str.dirGeneral		Unknown
SG1PTOC1	Str.general	67SG1	Residual Directional/Torque-Controlled Element 1, Terminal S picked up
SG2PIOC1	Op.general	50SG2	Residual Definite-Time Element 2, Terminal S asserted
SG2PTOC1	Op.general	67SG2T	Residual Directional/Torque-Controlled Element 2, Terminal S timed out
SG2PTOC1	Str.dirGeneral		Unknown
SG2PTOC1	Str.general	67SG2	Residual Directional/Torque-Controlled Element 2, Terminal S picked up
SG3PIOC1	Op.general	50SG3	Residual Definite-Time Element 3, Terminal S asserted

Table 10.24 Logical Device: PRO (Protection) (Sheet 15 of 28)

Logical Node	Attribute	Data Source	Comment
SG3PTOC1	Op.general	67SG3T	Residual Directional/Torque-Controlled Element 3, Terminal S timed out
SG3PTOC1	Str.dirGeneral		Unknown
SG3PTOC1	Str.general	67SG3	Residual Directional/Torque-Controlled Element 3, Terminal S picked up
SP1PIOC1	Op.general	50SP1	Phase Definite-Time Element 1, Terminal S asserted
SP1PTOC1	Op.general	67SP1T	Phase Directional/Torque-Controlled Element 1, Terminal S timed out
SP1PTOC1	Str.dirGeneral		Unknown
SP1PTOC1	Str.general	67SP1	Phase Directional/Torque-Controlled Element 1, Terminal S picked up
SP2PIOC1	Op.general	50SP2	Phase Definite-Time Element 2, Terminal S asserted
SP2PTOC1	Op.general	67SP2T	Phase Directional/Torque-Controlled Element 2, Terminal S timed out
SP2PTOC1	Str.dirGeneral		Unknown
SP2PTOC1	Str.general	67SP2	Phase Directional/Torque-Controlled Element 2, Terminal S picked up
SP3PIOC1	Op.general	50SP3	Phase Definite-Time Element 3, Terminal S asserted
SP3PTOC1	Op.general	67SP3T	Phase Directional/Torque-Controlled Element 3, Terminal S timed out
SP3PTOC1	Str.dirGeneral		Unknown
SP3PTOC1	Str.general	67SP3	Phase Directional/Torque-Controlled Element 3, Terminal S picked up
SQ1PIOC1	Op.general	50SQ1	Negative-Sequence Definite-Time Element 1, Terminal S asserted
SQ1PTOC1	Op.general	67SQ1T	Negative-Sequence Directional/Torque-Controlled Element 1, Terminal S timed out
SQ1PTOC1	Str.dirGeneral		Unknown
SQ1PTOC1	Str.general	67SQ1	Negative-Sequence Directional/Torque-Controlled Element 1, Terminal S picked up
SQ2PIOC1	Op.general	50SQ2	Negative-Sequence Definite-Time Element 2, Terminal S asserted
SQ2PTOC1	Op.general	67SQ2T	Negative-Sequence Directional/Torque-Controlled Element 2, Terminal S timed out
SQ2PTOC1	Str.dirGeneral		Unknown
SQ2PTOC1	Str.general	67SQ2	Negative-Sequence Directional/Torque-Controlled Element 2, Terminal S picked up
SQ3PIOC1	Op.general	50SQ3	Negative-Sequence Definite-Time Element 3, Terminal S asserted
SQ3PTOC1	Op.general	67SQ3T	Negative-Sequence Directional/Torque-Controlled Element 3, Terminal S timed out
SQ3PTOC1	Str.dirGeneral		Unknown
SQ3PTOC1	Str.general	67SQ3	Negative-Sequence Directional/Torque-Controlled Element 3, Terminal S picked up
T52AXCBR1	Loc.stVal	LOCAL	Control authority at local (bay) level
T52AXCBR1	Pos.stVal	52CLT?1:2[g]	Breaker closed, Terminal T
T79RREC1	TrBeh.stVal		3: Next trip is three-pole

Table 10.24 Logical Device: PRO (Protection) (Sheet 16 of 28)

Logical Node	Attribute	Data Source	Comment
T79RREC1	Rec3PhCnt.stVal	F79SHTh	Breaker T shot counter present value
T79RREC1	OpCls.general	79CLT	Breaker T supervised close command
T79RREC1	AutoRecSt.stVal	RECSTT	Breaker T autoreclosing status 1: Ready 5: Trip issued by protection 6: Fault disappeared 7: Wait to complete 8: Circuit breaker closed 12: Not ready
TBKRCILO1	EnaCls.stVal	BKENCT	Circuit Breaker T close control operation enabled
TBKRCILO1	EnaOpn.stVal	BKENOT	Circuit Breaker T open control operation enabled
TBKRCSWI1	ColOpn.stVal	OCT	Breaker open command, Terminal T
TBKRCSWI1	LocSta.stVal	LOCSTA	Control authority at station level
TBKRCSWI1	Pos.stVal	52CLT?1:2[g]	Breaker closed, Terminal T
TBKRCSWI1	Loc.stVal	LOC	Control authority at local (bay) level
TBKRCSWI1	OpCls.general	CCT	Breaker Close command, Terminal T
TG1PIOC1	Op.general	50TG1	Residual Definite-Time Element 1, Terminal T asserted
TG1PTOC1	Op.general	67TG1T	Residual Directional/Torque-Controlled Element 1, Terminal T timed out
TG1PTOC1	Str.dirGeneral		Unknown
TG1PTOC1	Str.general	67TG1	Residual Directional/Torque-Controlled Element 1, Terminal T picked up
TG2PIOC1	Op.general	50TG2	Residual Definite-Time Element 2, Terminal T asserted
TG2PTOC1	Op.general	67TG2T	Residual Directional/Torque-Controlled Element 2, Terminal T timed out
TG2PTOC1	Str.dirGeneral		Unknown
TG2PTOC1	Str.general	67TG2	Residual Directional/Torque-Controlled Element 2, Terminal T picked up
TG3PIOC1	Op.general	50TG3	Residual Definite-Time Element 3, Terminal T asserted
TG3PTOC1	Op.general	67TG3T	Residual Directional/Torque-Controlled Element 3, Terminal T timed out
TG3PTOC1	Str.dirGeneral		Unknown
TG3PTOC1	Str.general	67TG3	Residual Directional/Torque-Controlled Element 3, Terminal T picked up
TH1PTTR1	Op.general	THRLT1	Thermal element, Level 1 trip
TH1PTTR1	AlmThm.stVal	THRLA1	Thermal element, Level 1 alarm
TH2PTTR1	Op.general	THRLT2	Thermal element, Level 2 trip
TH2PTTR1	AlmThm.stVal	THRLA2	Thermal element, Level 2 alarm
TH3PTTR1	Op.general	THRLT3	Thermal element, Level 3 trip
TH3PTTR1	AlmThm.stVal	THRLA3	Thermal element, Level 3 alarm
TP1PIOC1	Op.general	50TP1	Phase Definite-Time Element 1, Terminal T asserted
TP1PTOC1	Op.general	67TP1T	Phase Directional/Torque-Controlled Element 1, Terminal T timed out

Table 10.24 Logical Device: PRO (Protection) (Sheet 17 of 28)

Logical Node	Attribute	Data Source	Comment
TP1PTOC1	Str.dirGeneral		Unknown
TP1PTOC1	Str.general	67TP1	Phase Directional/Torque-Controlled Element 1, Terminal T picked up
TP2PIOC1	Op.general	50TP2	Phase Definite-Time Element 2, Terminal T asserted
TP2PTOC1	Op.general	67TP2T	Phase Directional/Torque-Controlled Element 2, Terminal T timed out
TP2PTOC1	Str.dirGeneral		Unknown
TP2PTOC1	Str.general	67TP2	Phase Directional/Torque-Controlled Element 2, Terminal T picked up
TP3PIOC1	Op.general	50TP3	Phase Definite-Time Element 3, Terminal T asserted
TP3PTOC1	Op.general	67TP3T	Phase Directional/Torque-Controlled Element 3, Terminal T timed out
TP3PTOC1	Str.dirGeneral		Unknown
TP3PTOC1	Str.general	67TP3	Phase Directional/Torque-Controlled Element 3, Terminal T picked up
TQ1PIOC1	Op.general	50TQ1	Negative-Sequence Definite-Time Element 1, Terminal T asserted
TQ1PTOC1	Op.general	67TQ1T	Negative-Sequence Directional/Torque-Controlled Element 1, Terminal T timed out
TQ1PTOC1	Str.dirGeneral		Unknown
TQ1PTOC1	Str.general	67TQ1	Negative-Sequence Directional/Torque-Controlled Element 1, Terminal T picked up
TQ2PIOC1	Op.general	50TQ2	Negative-Sequence Definite-Time Element 2, Terminal T asserted
TQ2PTOC1	Op.general	67TQ2T	Negative-Sequence Directional/Torque-Controlled Element 2, Terminal T timed out
TQ2PTOC1	Str.dirGeneral		Unknown
TQ2PTOC1	Str.general	67TQ2	Negative-Sequence Directional/Torque-Controlled Element 2, Terminal T picked up
TQ3PIOC1	Op.general	50TQ3	Negative-Sequence Definite-Time Element 3, Terminal T asserted
TQ3PTOC1	Op.general	67TQ3T	Negative-Sequence Directional/Torque-Controlled Element 3, Terminal T timed out
TQ3PTOC1	Str.dirGeneral		Unknown
TQ3PTOC1	Str.general	67TQ3	Negative-Sequence Directional/Torque-Controlled Element 3, Terminal T picked up
TRIPPTRC1	Tr.general	TRIP	Transformer or terminal trip signal asserted
TRIPSPTRC1	Tr.general	TRIPS	Terminal S trip output asserted
TRIPTPTRC1	Tr.general	TRIPT	Terminal T trip output asserted
TRIPUPTRC1	Tr.general	TRIPU	Terminal U trip output asserted
TRIPWPTRC1	Tr.general	TRIPW	Terminal W trip output asserted
TRIPXPTRC1	Tr.general	TRIPX	Terminal X trip output asserted
TRIPYPTRC1	Tr.general	TRIPY	Terminal Y trip output asserted
TRPXFMRPTRC1	Tr.general	TRPXFMR	Transformer trip output asserted
U1P1PTUV1	Op.general	271P1T	Undervoltage Element 1, Level 1 timed out
U1P1PTUV1	Str.dirGeneral		Unknown

Table 10.24 Logical Device: PRO (Protection) (Sheet 18 of 28)

Logical Node	Attribute	Data Source	Comment
U1P1PTUV1	Str.general	271P1	Undervoltage Element 1, Level 1 asserted
U1P2PTUV1	Op.general	271P2	Undervoltage Element 1, Level 2 asserted
U1P2PTUV1	Str.dirGeneral		Unknown
U1P2PTUV1	Str.general	271P2	Undervoltage Element 1, Level 2 asserted
U1PVPH1	Op.general	24U1T	User-Defined Volts/Hertz Curve 1 timed out
U1PVPH1	Str.dirGeneral		Unknown
U1PVPH1	Str.general	24D1	Volts/Hertz Element Level 1 asserted
U2P1PTUV1	Op.general	272P1T	Undervoltage Element 2, Level 1 timed out
U2P1PTUV1	Str.dirGeneral		Unknown
U2P1PTUV1	Str.general	272P1	Undervoltage Element 2, Level 1 asserted
U2P2PTUV1	Op.general	272P2	Undervoltage Element 2, Level 2 asserted
U2P2PTUV1	Str.dirGeneral		Unknown
U2P2PTUV1	Str.general	272P2	Undervoltage Element 2, Level 2 asserted
U2PVPH1	Op.general	24U2T	User-Defined Volts/Hertz Curve 2 timed out
U2PVPH1	Str.dirGeneral		Unknown
U2PVPH1	Str.general	24D1	Volts/Hertz Element Level 1 asserted
U3P1PTUV1	Op.general	273P1T	Undervoltage Element 3, Level 1 timed out
U3P1PTUV1	Str.dirGeneral		Unknown
U3P1PTUV1	Str.general	273P1	Undervoltage Element 3, Level 1 asserted
U3P2PTUV1	Op.general	273P2	Undervoltage Element 3, Level 2 asserted
U3P2PTUV1	Str.dirGeneral		Unknown
U3P2PTUV1	Str.general	273P2	Undervoltage Element 3, Level 2 asserted
U4P1PTUV1	Op.general	274P1T	Undervoltage Element 4, Level 1 timed out
U4P1PTUV1	Str.dirGeneral		Unknown
U4P1PTUV1	Str.general	274P1	Undervoltage Element 4, Level 1 asserted
U4P2PTUV1	Op.general	274P2	Undervoltage Element 4, Level 2 asserted
U4P2PTUV1	Str.dirGeneral		Unknown
U4P2PTUV1	Str.general	274P2	Undervoltage Element 4, Level 2 asserted
U52AXCBR1	Loc.stVal	LOCAL	Control authority at local (bay) level
U52AXCBR1	Pos.stVal	52CLU?1:2[g]	Breaker closed, Terminal U
U5P1PTUV1	Op.general	275P1T	Undervoltage Element 5, Level 1 timed out
U5P1PTUV1	Str.dirGeneral		Unknown
U5P1PTUV1	Str.general	275P1	Undervoltage Element 5, Level 1 asserted
U5P2PTUV1	Op.general	275P2	Undervoltage Element 5, Level 2 asserted
U5P2PTUV1	Str.dirGeneral		Unknown
U5P2PTUV1	Str.general	275P2	Undervoltage Element 5, Level 2 asserted
U79RREC1	TrBeh.stVal		3: Next trip is three-pole
U79RREC1	Rec3PhCnt.stVal	F79SHU[h]	Breaker U shot counter present value
U79RREC1	OpCls.general	79CLU	Breaker U supervised close command

Table 10.24 Logical Device: PRO (Protection) (Sheet 19 of 28)

Logical Node	Attribute	Data Source	Comment
U79RREC1	AutoRecSt.stVal	RECSTU	Breaker U autoreclosing status 1: Ready 5: Trip issued by protection 6: Fault disappeared 7: Wait to complete 8: Circuit breaker closed 12: Not ready
UBKRCILO1	EnaCls.stVal	BKENCU	Circuit Breaker U close control operation enabled
UBKRCILO1	EnaOpn.stVal	BKENOU	Circuit Breaker U open control operation enabled
UBKRCSWI1	ColOpn.stVal	OCU	Breaker open command, Terminal U
UBKRCSWI1	LocSta.stVal	LOCSTA	Control authority at station level
UBKRCSWI1	Pos.stVal	52CLU?1:2[g]	Breaker closed, Terminal U
UBKRCSWI1	Loc.stVal	LOC	Control authority at local (bay) level
UBKRCSWI1	OpCls.general	CCU	Breaker Close command, Terminal U
UG1PIOC1	Op.general	50UG1	Residual Definite-Time Element 1, Terminal U asserted
UG1PTOC1	Op.general	67UG1T	Residual Directional/Torque-Controlled Element 1, Terminal U timed out
UG1PTOC1	Str.dirGeneral		Unknown
UG1PTOC1	Str.general	67UG1	Residual Directional/Torque-Controlled Element 1, Terminal U picked up
UG2PIOC1	Op.general	50UG2	Residual Definite-Time Element 2, Terminal U asserted
UG2PTOC1	Op.general	67UG2T	Residual Directional/Torque-Controlled Element 2, Terminal U timed out
UG2PTOC1	Str.dirGeneral		Unknown
UG2PTOC1	Str.general	67UG2	Residual Directional/Torque-Controlled Element 2, Terminal U picked up
UG3PIOC1	Op.general	50UG3	Residual Definite-Time Element 3, Terminal U asserted
UG3PTOC1	Op.general	67UG3T	Residual Directional/Torque-Controlled Element 3, Terminal U timed out
UG3PTOC1	Str.dirGeneral		Unknown
UG3PTOC1	Str.general	67UG3	Residual Directional/Torque-Controlled Element 3, Terminal U picked up
UP1PIOC1	Op.general	50UP1	Phase Definite-Time Element 1, Terminal U asserted
UP1PTOC1	Op.general	67UP1T	Phase Directional/Torque-Controlled Element 1, Terminal U timed out
UP1PTOC1	Str.dirGeneral		Unknown
UP1PTOC1	Str.general	67UP1	Phase Directional/Torque-Controlled Element 1, Terminal U picked up
UP2PIOC1	Op.general	50UP2	Phase Definite-Time Element 2, Terminal U asserted
UP2PTOC1	Op.general	67UP2T	Phase Directional/Torque-Controlled Element 2, Terminal U timed out
UP2PTOC1	Str.dirGeneral		Unknown
UP2PTOC1	Str.general	67UP2	Phase Directional/Torque-Controlled Element 2, Terminal U picked up

Table 10.24 Logical Device: PRO (Protection) (Sheet 20 of 28)

Logical Node	Attribute	Data Source	Comment
UP3PIOC1	Op.general	50UP3	Phase Definite-Time Element 3, Terminal U asserted
UP3PTOC1	Op.general	67UP3T	Phase Directional/Torque-Controlled Element 3, Terminal U timed out
UP3PTOC1	Str.dirGeneral		Unknown
UP3PTOC1	Str.general	67UP3	Phase Directional/Torque-Controlled Element 3, Terminal U picked up
UQ1PIOC1	Op.general	50UQ1	Negative-Sequence Definite-Time Element 1, Terminal U asserted
UQ1PTOC1	Op.general	67UQ1T	Negative-Sequence Directional/Torque-Controlled Element 1, Terminal U timed out
UQ1PTOC1	Str.dirGeneral		Unknown
UQ1PTOC1	Str.general	67UQ1	Negative-Sequence Directional/Torque-Controlled Element 1, Terminal U picked up
UQ2PIOC1	Op.general	50UQ2	Negative-Sequence Definite-Time Element 2, Terminal U asserted
UQ2PTOC1	Op.general	67UQ2T	Negative-Sequence Directional/Torque-Controlled Element 2, Terminal U timed out
UQ2PTOC1	Str.dirGeneral		Unknown
UQ2PTOC1	Str.general	67UQ2	Negative-Sequence Directional/Torque-Controlled Element 2, Terminal U picked up
UQ3PIOC1	Op.general	50UQ3	Negative-Sequence Definite-Time Element 3, Terminal U asserted
UQ3PTOC1	Op.general	67UQ3T	Negative-Sequence Directional/Torque-Controlled Element 3, Terminal U timed out
UQ3PTOC1	Str.dirGeneral		Unknown
UQ3PTOC1	Str.general	67UQ3	Negative-Sequence Directional/Torque-Controlled Element 3, Terminal U picked up
W52AXCBR1	Loc.stVal	LOCAL	Control authority at local (bay) level
W52AXCBR1	Pos.stVal	52CLW?1:2[g]	Breaker closed, Terminal W
W79RREC1	TrBeh.stVal		3: Next trip is three-pole
W79RREC1	Rec3PhCnt.stVal	F79SHW[h]	Breaker W shot counter present value
W79RREC1	OpCls.general	79CLW	Breaker W supervised close command
W79RREC1	AutoRecSt.stVal	RECSTW	Breaker W autoreclosing status 1: Ready 5: Trip issued by protection 6: Fault disappeared 7: Wait to complete 8: Circuit breaker closed 12: Not ready
WBKRCILO1	EnaCls.stVal	BKENCW	Circuit Breaker W close control operation enabled
WBKRCILO1	EnaOpn.stVal	BKENOW	Circuit Breaker W open control operation enabled
WBKRCSWI1	ColOpn.stVal	OCW	Breaker open command, Terminal W
WBKRCSWI1	LocSta.stVal	LOCSTA	Control authority at station level
WBKRCSWI1	Pos.stVal	52CLW?1:2[g]	Breaker closed, Terminal W
WBKRCSWI1	Loc.stVal	LOC	Control authority at local (bay) level
WBKRCSWI1	OpCls.general	CCW	Breaker Close command, Terminal W

Table 10.24 Logical Device: PRO (Protection) (Sheet 21 of 28)

Logical Node	Attribute	Data Source	Comment
WG1PIOC1	Op.general	50WG1	Residual Definite-Time Element 1, Terminal W asserted
WG1PTOC1	Op.general	67WG1T	Residual Directional/Torque-Controlled Element 1, Terminal W timed out
WG1PTOC1	Str.dirGeneral		Unknown
WG1PTOC1	Str.general	67WG1	Residual Directional/Torque-Controlled Element 1, Terminal W picked up
WG2PIOC1	Op.general	50WG2	Residual Definite-Time Element 2, Terminal W asserted
WG2PTOC1	Op.general	67WG2T	Residual Directional/Torque-Controlled Element 2, Terminal W timed out
WG2PTOC1	Str.dirGeneral		Unknown
WG2PTOC1	Str.general	67WG2	Residual Directional/Torque-Controlled Element 2, Terminal W picked up
WG3PIOC1	Op.general	50WG3	Residual Definite-Time Element 3, Terminal W asserted
WG3PTOC1	Op.general	67WG3T	Residual Directional/Torque-Controlled Element 3, Terminal W timed out
WG3PTOC1	Str.dirGeneral		Unknown
WG3PTOC1	Str.general	67WG3	Residual Directional/Torque-Controlled Element 3, Terminal W picked up
WP1PIOC1	Op.general	50WP1	Phase Definite-Time Element 1, Terminal W asserted
WP1PTOC1	Op.general	67WP1T	Phase Directional/Torque-Controlled Element 1, Terminal W timed out
WP1PTOC1	Str.dirGeneral		Unknown
WP1PTOC1	Str.general	67WP1	Phase Directional/Torque-Controlled Element 1, Terminal W picked up
WP2PIOC1	Op.general	50WP2	Phase Definite-Time Element 2, Terminal W asserted
WP2PTOC1	Op.general	67WP2T	Phase Directional/Torque-Controlled Element 2, Terminal W timed out
WP2PTOC1	Str.dirGeneral		Unknown
WP2PTOC1	Str.general	67WP2	Phase Directional/Torque-Controlled Element 2, Terminal W picked up
WP3PIOC1	Op.general	50WP3	Phase Definite-Time Element 3, Terminal W asserted
WP3PTOC1	Op.general	67WP3T	Phase Directional/Torque-Controlled Element 3, Terminal W timed out
WP3PTOC1	Str.dirGeneral		Unknown
WP3PTOC1	Str.general	67WP3	Phase Directional/Torque-Controlled Element 3, Terminal W picked up
WQ1PIOC1	Op.general	50WQ1	Negative-Sequence Definite-Time Element 1, Terminal W asserted
WQ1PTOC1	Op.general	67WQ1T	Negative-Sequence Directional/Torque-Controlled Element 1, Terminal W timed out
WQ1PTOC1	Str.dirGeneral		Unknown
WQ1PTOC1	Str.general	67WQ1	Negative-Sequence Directional/Torque-Controlled Element 1, Terminal W picked up
WQ2PIOC1	Op.general	50WQ2	Negative-Sequence Definite-Time Element 2, Terminal W asserted

Table 10.24 Logical Device: PRO (Protection) (Sheet 22 of 28)

Logical Node	Attribute	Data Source	Comment
WQ2PTOC1	Op.general	67WQ2T	Negative-Sequence Directional/Torque-Controlled Element 2, Terminal W timed out
WQ2PTOC1	Str.dirGeneral		Unknown
WQ2PTOC1	Str.general	67WQ2	Negative-Sequence Directional/Torque-Controlled Element 2, Terminal W picked up
WQ3PIOC1	Op.general	50WQ3	Negative-Sequence Definite-Time Element 3, Terminal W asserted
WQ3PTOC1	Op.general	67WQ3T	Negative-Sequence Directional/Torque-Controlled Element 3, Terminal W timed out
WQ3PTOC1	Str.dirGeneral		Unknown
WQ3PTOC1	Str.general	67WQ3	Negative-Sequence Directional/Torque-Controlled Element 3, Terminal W picked up
X52AXCBR1	Loc.stVal	LOCAL	Control authority at local (bay) level
X52AXCBR1	Pos.stVal	52CLX?1:2[g]	Breaker closed, Terminal X
X79RREC1	TrBeh.stVal		3: Next trip is three-pole
X79RREC1	Rec3PhCnt.stVal	F79SHX[h]	Breaker X shot counter present value
X79RREC1	OpCls.general	79CLX	Breaker X supervised close command
X79RREC1	AutoRecSt.stVal	RECSTX	Breaker X autoreclosing status 1: Ready 5: Trip issued by protection 6: Fault disappeared 7: Wait to complete 8: Circuit breaker closed 12: Not ready
X89CL01XSWI1	Loc.stVal	LOCAL	Control authority at local (bay) level
X89CL01XSWI1	Pos.stVal	89CL01?1:2[g]	Disconnect 1 closed
X89CL02XSWI1	Loc.stVal	LOCAL	Control authority at local (bay) level
X89CL02XSWI1	Pos.stVal	89CL02?1:2[g]	Disconnect 2 closed
X89CL03XSWI1	Loc.stVal	LOCAL	Control authority at local (bay) level
X89CL03XSWI1	Pos.stVal	89CL03?1:2[g]	Disconnect 3 closed
X89CL04XSWI1	Loc.stVal	LOCAL	Control authority at local (bay) level
X89CL04XSWI1	Pos.stVal	89CL04?1:2[g]	Disconnect 4 closed
X89CL05XSWI1	Loc.stVal	LOCAL	Control authority at local (bay) level
X89CL05XSWI1	Pos.stVal	89CL05?1:2[g]	Disconnect 5 closed
X89CL06XSWI1	Loc.stVal	LOCAL	Control authority at local (bay) level
X89CL06XSWI1	Pos.stVal	89CL06?1:2[g]	Disconnect 6 closed
X89CL07XSWI1	Loc.stVal	LOCAL	Control authority at local (bay) level
X89CL07XSWI1	Pos.stVal	89CL07?1:2[g]	Disconnect 7 closed
X89CL08XSWI1	Loc.stVal	LOCAL	Control authority at local (bay) level
X89CL08XSWI1	Pos.stVal	89CL08?1:2[g]	Disconnect 8 closed
X89CL09XSWI1	Loc.stVal	LOCAL	Control authority at local (bay) level
X89CL09XSWI1	Pos.stVal	89CL09?1:2[g]	Disconnect 9 closed
X89CL10XSWI1	Loc.stVal	LOCAL	Control authority at local (bay) level
X89CL10XSWI1	Pos.stVal	89CL10?1:2[g]	Disconnect 10 closed

Table 10.24 Logical Device: PRO (Protection) (Sheet 23 of 28)

Logical Node	Attribute	Data Source	Comment
X89CL11XSWI1	Loc.stVal	LOCAL	Control authority at local (bay) level
X89CL11XSWI1	Pos.stVal	89CL11?1:2[g]	Disconnect 11 closed
X89CL12XSWI1	Loc.stVal	LOCAL	Control authority at local (bay) level
X89CL12XSWI1	Pos.stVal	89CL12?1:2[g]	Disconnect 12 closed
X89CL13XSWI1	Loc.stVal	LOCAL	Control authority at local (bay) level
X89CL13XSWI1	Pos.stVal	89CL13?1:2[g]	Disconnect 13 closed
X89CL14XSWI1	Loc.stVal	LOCAL	Control authority at local (bay) level
X89CL14XSWI1	Pos.stVal	89CL14?1:2[g]	Disconnect 14 closed
X89CL15XSWI1	Loc.stVal	LOCAL	Control authority at local (bay) level
X89CL15XSWI1	Pos.stVal	89CL15?1:2[g]	Disconnect 15 closed
X89CL16XSWI1	Loc.stVal	LOCAL	Control authority at local (bay) level
X89CL16XSWI1	Pos.stVal	89CL16?1:2[g]	Disconnect 16 closed
X89CL17XSWI1	Loc.stVal	LOCAL	Control authority at local (bay) level
X89CL17XSWI1	Pos.stVal	89CL17?1:2[g]	Disconnect 17 closed
X89CL18XSWI1	Loc.stVal	LOCAL	Control authority at local (bay) level
X89CL18XSWI1	Pos.stVal	89CL18?1:2[g]	Disconnect 18 closed
X89CL19XSWI1	Loc.stVal	LOCAL	Control authority at local (bay) level
X89CL19XSWI1	Pos.stVal	89CL19?1:2[g]	Disconnect 19 closed
X89CL20XSWI1	Loc.stVal	LOCAL	Control authority at local (bay) level
X89CL20XSWI1	Pos.stVal	89CL20?1:2[g]	Disconnect 20 closed
XBKRCILO1	EnaCls.stVal	BKENCX	Circuit Breaker X close control operation enabled
XBKRCILO1	EnaOpn.stVal	BKENOX	Circuit Breaker X open control operation enabled
XBKRCSWI1	ColOpn.stVal	OCX	Breaker open command, Terminal X
XBKRCSWI1	LocSta.stVal	LOCSTA	Control authority at station level
XBKRCSWI1	Pos.stVal	52CLX?1:2[g]	Breaker closed, Terminal X
XBKRCSWI1	Loc.stVal	LOCAL	Control authority at local (bay) level
XBKRCSWI1	OpCls.general	CCX	Breaker Close command, Terminal X
XG1PIOC1	Op.general	50XG1	Residual Definite-Time Element 1, Terminal X asserted
XG1PTOC1	Op.general	67XG1T	Residual Directional/Torque-Controlled Element 1, Terminal X timed out
XG1PTOC1	Str.dirGeneral		Unknown
XG1PTOC1	Str.general	67XG1	Residual Directional/Torque-Controlled Element 1, Terminal X picked up
XG2PIOC1	Op.general	50XG2	Residual Definite-Time Element 2, Terminal X asserted
XG2PTOC1	Op.general	67XG2T	Residual Directional/Torque-Controlled Element 2, Terminal X timed out
XG2PTOC1	Str.dirGeneral		Unknown
XG2PTOC1	Str.general	67XG2	Residual Directional/Torque-Controlled Element 2, Terminal X picked up
XG3PIOC1	Op.general	50XG3	Residual Definite-Time Element 3, Terminal X asserted

Table 10.24 Logical Device: PRO (Protection) (Sheet 24 of 28)

Logical Node	Attribute	Data Source	Comment
XG3PTOC1	Op.general	67XG3T	Residual Directional/Torque-Controlled Element 3, Terminal X timed out
XG3PTOC1	Str.dirGeneral		Unknown
XG3PTOC1	Str.general	67XG3	Residual Directional/Torque-Controlled Element 3, Terminal X picked up
XP1PIOC1	Op.general	50XP1	Phase Definite-Time Element 1, Terminal X asserted
XP1PTOC1	Op.general	67XP1T	Phase Directional/Torque-Controlled Element 1, Terminal X timed out
XP1PTOC1	Str.dirGeneral		Unknown
XP1PTOC1	Str.general	67XP1	Phase Directional/Torque-Controlled Element 1, Terminal X picked up
XP2PIOC1	Op.general	50XP2	Phase Definite-Time Element 2, Terminal X asserted
XP2PTOC1	Op.general	67XP2T	Phase Directional/Torque-Controlled Element 2, Terminal X timed out
XP2PTOC1	Str.dirGeneral		Unknown
XP2PTOC1	Str.general	67XP2	Phase Directional/Torque-Controlled Element 2, Terminal X picked up
XP3PIOC1	Op.general	50XP3	Phase Definite-Time Element 3, Terminal X asserted
XP3PTOC1	Op.general	67XP3T	Phase Directional/Torque-Controlled Element 3, Terminal X timed out
XP3PTOC1	Str.dirGeneral		Unknown
XP3PTOC1	Str.general	67XP3	Phase Directional/Torque-Controlled Element 3, Terminal X picked up
XQ1PIOC1	Op.general	50XQ1	Negative-Sequence Definite-Time Element 1, Terminal X asserted
XQ1PTOC1	Op.general	67XQ1T	Negative-Sequence Directional/Torque-Controlled Element 1, Terminal X timed out
XQ1PTOC1	Str.dirGeneral		Unknown
XQ1PTOC1	Str.general	67XQ1	Negative-Sequence Directional/Torque-Controlled Element 1, Terminal X picked up
XQ2PIOC1	Op.general	50XQ2	Negative-Sequence Definite-Time Element 2, Terminal X asserted
XQ2PTOC1	Op.general	67XQ2T	Negative-Sequence Directional/Torque-Controlled Element 2, Terminal X timed out
XQ2PTOC1	Str.dirGeneral		Unknown
XQ2PTOC1	Str.general	67XQ2	Negative-Sequence Directional/Torque-Controlled Element 2, Terminal X picked up
XQ3PIOC1	Op.general	50XQ3	Negative-Sequence Definite-Time Element 3, Terminal X asserted
XQ3PTOC1	Op.general	67XQ3T	Negative-Sequence Directional/Torque-Controlled Element 3, Terminal X timed out
XQ3PTOC1	Str.dirGeneral		Unknown
XQ3PTOC1	Str.general	67XQ3	Negative-Sequence Directional/Torque-Controlled Element 3, Terminal X picked up
Y52AXCBR1	Loc.stVal	LOCAL	Control authority at local (bay) level
Y52AXCBR1	Pos.stVal	52CLY?1:2[g]	Breaker closed, Terminal Y
Y79RREC1	TrBeh.stVal		3: Next trip is three-pole

Table 10.24 Logical Device: PRO (Protection) (Sheet 25 of 28)

Logical Node	Attribute	Data Source	Comment
Y79RREC1	Rec3PhCnt.stVal	F79SHY[h]	Breaker Y shot counter present value
Y79RREC1	OpCls.general	79CLY	Breaker Y supervised close command
Y79RREC1	AutoRecSt.stVal	RECSTY	Breaker Y autoreclosing status 1: Ready 5: Trip issued by protection 6: Fault disappeared 7: Wait to complete 8: Circuit breaker closed 12: Not ready
YBKRCILO1	EnaCls.stVal	BKENCY	Circuit Breaker Y close control operation enabled
YBKRCILO1	EnaOpn.stVal	BKENOY	Circuit Breaker Y open control operation enabled
YBKRCSWI1	ColOpn.stVal	OCY	Breaker open command, Terminal Y
YBKRCSWI1	LocSta.stVal	LOCSTA	Control authority at station level
YBKRCSWI1	Pos.stVal	52CLY?1:2[g]	Breaker closed, Terminal Y
YBKRCSWI1	Loc.stVal	LOC	Control authority at local (bay) level
YBKRCSWI1	OpCls.general	CCY	Breaker Close command, Terminal Y
YG1PIOC1	Op.general	50YG1	Residual Definite-Time Element 1, Terminal Y asserted
YG1PTOC1	Op.general	67YG1T	Residual Directional/Torque-Controlled Element 1, Terminal Y timed out
YG1PTOC1	Str.dirGeneral		Unknown
YG1PTOC1	Str.general	67YG1	Residual Directional/Torque-Controlled Element 1, Terminal Y picked up
YG2PIOC1	Op.general	50YG2	Residual Definite-Time Element 2, Terminal Y asserted
YG2PTOC1	Op.general	67YG2T	Residual Directional/Torque-Controlled Element 2, Terminal Y timed out
YG2PTOC1	Str.dirGeneral		Unknown
YG2PTOC1	Str.general	67YG2	Residual Directional/Torque-Controlled Element 2, Terminal Y picked up
YG3PIOC1	Op.general	50YG3	Residual Definite-Time Element 3, Terminal Y asserted
YG3PTOC1	Op.general	67YG3T	Residual Directional/Torque-Controlled Element 3, Terminal Y timed out
YG3PTOC1	Str.dirGeneral		Unknown
YG3PTOC1	Str.general	67YG3	Residual Directional/Torque-Controlled Element 3, Terminal Y picked up
YP1PIOC1	Op.general	50YP1	Phase Definite-Time Element 1, Terminal Y asserted
YP1PTOC1	Op.general	67YP1T	Phase Directional/Torque-Controlled Element 1, Terminal Y timed out
YP1PTOC1	Str.dirGeneral		Unknown
YP1PTOC1	Str.general	67YP1	Phase Directional/Torque-Controlled Element 1, Terminal Y picked up
YP2PIOC1	Op.general	50YP2	Phase Definite-Time Element 2, Terminal Y asserted
YP2PTOC1	Op.general	67YP2T	Phase Directional/Torque-Controlled Element 2, Terminal Y timed out

Table 10.24 Logical Device: PRO (Protection) (Sheet 26 of 28)

Logical Node	Attribute	Data Source	Comment
YP2PTOC1	Str.dirGeneral		Unknown
YP2PTOC1	Str.general	67YP2	Phase Directional/Torque-Controlled Element 2, Terminal Y picked up
YP3PIOC1	Op.general	50YP3	Phase Definite-Time Element 3, Terminal Y asserted
YP3PTOC1	Op.general	67YP3T	Phase Directional/Torque-Controlled Element 3, Terminal Y timed out
YP3PTOC1	Str.dirGeneral		Unknown
YP3PTOC1	Str.general	67YP3	Phase Directional/Torque-Controlled Element 3, Terminal Y picked up
YQ1PIOC1	Op.general	50YQ1	Negative-Sequence Definite-Time Element 1, Terminal Y asserted
YQ1PTOC1	Op.general	67YQ1T	Negative-Sequence Directional/Torque-Controlled Element 1, Terminal Y timed out
YQ1PTOC1	Str.dirGeneral		Unknown
YQ1PTOC1	Str.general	67YQ1	Negative-Sequence Directional/Torque-Controlled Element 1, Terminal Y picked up
YQ2PIOC1	Op.general	50YQ2	Negative-Sequence Definite-Time Element 2, Terminal Y asserted
YQ2PTOC1	Op.general	67YQ2T	Negative-Sequence Directional/Torque-Controlled Element 2, Terminal Y timed out
YQ2PTOC1	Str.dirGeneral		Unknown
YQ2PTOC1	Str.general	67YQ2	Negative-Sequence Directional/Torque-Controlled Element 2, Terminal Y picked up
YQ3PIOC1	Op.general	50YQ3	Negative-Sequence Definite-Time Element 3, Terminal Y asserted
YQ3PTOC1	Op.general	67YQ3T	Negative-Sequence Directional/Torque-Controlled Element 3, Terminal Y timed out
YQ3PTOC1	Str.dirGeneral		Unknown
YQ3PTOC1	Str.general	67YQ3	Negative-Sequence Directional/Torque-Controlled Element 3, Terminal Y picked up
Z1GL1PDIS1	Str.general	Z1GL1	Zone 1 ground distance, Line 1
Z1GL1PDIS1	Str.dirGeneral	RVRS1L1?1:2	Directional status where 0 = no direction, 1 = forward, and 2 = reverse
Z1GL1PDIS1	Op.general	Z1GL1	Zone 1 ground distance, Line 1
Z1L1PDIS1	Str.general	Z1TL1	Zone 1 phase or ground distance, time-delayed, Line 1
Z1L1PDIS1	Str.dirGeneral	RVRS1L1?1:2	Directional status where 0 = no direction, 1 = forward, and 2 = reverse
Z1L1PDIS1	Op.general	Z1L1	Zone 1 phase or ground distance, Line 1
Z1PL1PDIS1	Str.general	Z1PL1	Zone 1 phase distance, Line 1
Z1PL1PDIS1	Str.dirGeneral	RVRS1L1?1:2	Directional status where 0 = no direction, 1 = forward, and 2 = reverse
Z1PL1PDIS1	Op.general	Z1PL1	Zone 1 phase distance, Line 1
Z2GL1PDIS1	Str.general	Z2GL1	Zone 2 ground distance, Line 1
Z2GL1PDIS1	Str.dirGeneral	RVRS2L1?1:2	Directional status where 0 = no direction, 1 = forward, and 2 = reverse
Z2GL1PDIS1	Op.general	Z2GL1	Zone 2 ground distance, Line 1

Table 10.24 Logical Device: PRO (Protection) (Sheet 27 of 28)

Logical Node	Attribute	Data Source	Comment
Z2L1PDIS1	Str.general	Z2TL1	Zone 2 phase or ground distance, time-delayed, Line 1
Z2L1PDIS1	Str.dirGeneral	RVRS2L1?1:2	Directional status where 0 = no direction, 1 = forward, and 2 = reverse
Z2L1PDIS1	Op.general	Z2L1	Zone 2 phase or ground distance, Line 1
Z2PL1PDIS1	Str.general	Z2PL1	Zone 2 phase distance, Line 1
Z2PL1PDIS1	Str.dirGeneral	RVRS2L1?1:2	Directional status where 0 = no direction, 1 = forward, and 2 = reverse
Z2PL1PDIS1	Op.general	Z2PL1	Zone 2 phase distance, Line 1
Z3GL1PDIS1	Str.general	Z3GL1	Zone 3 ground distance, Line 1
Z3GL1PDIS1	Str.dirGeneral	RVRS3L1?1:2	Directional status where 0 = no direction, 1 = forward, and 2 = reverse
Z3GL1PDIS1	Op.general	Z3GL1	Zone 3 ground distance, Line 1
Z3L1PDIS1	Str.general	Z3TL1	Zone 3 phase or ground distance, time-delayed, Line 1
Z3L1PDIS1	Str.dirGeneral	RVRS3L1?1:2	Directional status where 0 = no direction, 1 = forward, and 2 = reverse
Z3L1PDIS1	Op.general	Z3L1	Zone 3 phase or ground distance, Line 1
Z3PL1PDIS1	Str.general	Z3PL1	Zone 3 phase distance, Line 1
Z3PL1PDIS1	Str.dirGeneral	RVRS3L1?1:2	Directional status where 0 = no direction, 1 = forward, and 2 = reverse
Z3PL1PDIS1	Op.general	Z3PL1	Zone 3 phase distance, Line 1
Z4GL1PDIS1	Str.general	Z4GL1	Zone 4 ground distance, Line 1
Z4GL1PDIS1	Str.dirGeneral	RVRS4L1?1:2	Directional status where 0 = no direction, 1 = forward, and 2 = reverse
Z4GL1PDIS1	Op.general	Z4GL1	Zone 4 ground distance, Line 1
Z4L1PDIS1	Str.general	Z4TL1	Zone 4 phase or ground distance, time-delayed, Line 1
Z4L1PDIS1	Str.dirGeneral	RVRS4L1?1:2	Directional status where 0 = no direction, 1 = forward, and 2 = reverse
Z4L1PDIS1	Op.general	Z4L1	Zone 4 phase or ground distance, Line 1
Z4PL1PDIS1	Str.general	Z4PL1	Zone 4 phase distance, Line 1
Z4PL1PDIS1	Str.dirGeneral	RVRS4L1?1:2	Directional status where 0 = no direction, 1 = forward, and 2 = reverse
Z4PL1PDIS1	Op.general	Z4PL1	Zone 4 phase distance, Line 1
Functional Constraint = MX			
BSSASCBR1	AccAbr.instMag.f	BSBCWPA	Circuit Breaker S contact wear percentage for Pole A
BSSBSCBR1	AccAbr.instMag.f	BSBCWPB	Circuit Breaker S contact wear percentage for Pole B
BSSCSCBR1	AccAbr.instMag.f	BSBCQPC	Circuit Breaker S contact wear percentage for Pole C
BSTASCBR1	AccAbr.instMag.f	BTBCWPA	Circuit Breaker T contact wear percentage for Pole A
BSTBSCBR1	AccAbr.instMag.f	BTBCWPB	Circuit Breaker T contact wear percentage for Pole B
BSTCSCBR1	AccAbr.instMag.f	BTBCWPC	Circuit Breaker T contact wear percentage for Pole C
BSUASCBR1	AccAbr.instMag.f	BUBCWPA	Circuit Breaker U contact wear percentage for Pole A

Table 10.24 Logical Device: PRO (Protection) (Sheet 28 of 28)

Logical Node	Attribute	Data Source	Comment
BSUBSCBR1	AccAbr.instMag.f	BUBCWPB	Circuit Breaker U contact wear percentage for Pole B
BSUCSCBR1	AccAbr.instMag.f	BUBCWPC	Circuit Breaker U contact wear percentage for Pole C
BSWASCBR1	AccAbr.instMag.f	BWBCWPA	Circuit Breaker W contact wear percentage for Pole A
BSWBSCBR1	AccAbr.instMag.f	BWBCWPB	Circuit Breaker W contact wear percentage for Pole B
BSWCSCBR1	AccAbr.instMag.f	BWBCWPC	Circuit Breaker W contact wear percentage for Pole C
BSXASCBR1	AccAbr.instMag.f	BXBCWPA	Circuit Breaker X contact wear percentage for Pole A
BSXBSCBR1	AccAbr.instMag.f	BXBCWPB	Circuit Breaker X contact wear percentage for Pole B
BSXCSCBR1	AccAbr.instMag.f	BXBCWPC	Circuit Breaker X contact wear percentage for Pole C
BSYASCBR1	AccAbr.instMag.f	BYBCWPA	Circuit Breaker Y contact wear percentage for Pole A
BSYBSCBR1	AccAbr.instMag.f	BYBCWPB	Circuit Breaker Y contact wear percentage for Pole B
BSYCSCBR1	AccAbr.instMag.f	BYBCWPC	Circuit Breaker Y contact wear percentage for Pole C
Functional Constraint = DC			
LLN0	NamPlt.swRev	VERFID	Relay FID string
HB2SPHAR1	NamPlt.swRev	VERFID	Relay FID string
HB2TPHAR1	NamPlt.swRev	VERFID	Relay FID string
PROLPHD1	PhyNam.model	PARNUM	Relay part number
PROLPHD1	PhyNam.serNum	SERNUM	Relay serial number
PROLPHD1	PhyNam.hwRev	HWREV[i]	Hardware version of the relay mainboard
Functional Constraint = SP			
LLN0	GrRef.setSrcRef	IdName	Functional name
LLN0	MltLec.setVal	MLTLEV	Multi-level control authority

[a] Writing a value of 1 pulses the first bit. Writing a value of 0 pulses the second bit.
[b] If closed, value = 2. If open, value = 1. If intermediate, value = 0. A value of 3 is invalid.
[c] FLTYPE is an internal data source derived from the event summary and is not available to the user. Refer to Table 10.27 for more details.
[d] FLTCAUS is an internal data source derived from the event summary and is not available to the user. Refer to Table 10.28 for more details.
[e] I60MOD is an internal data source derived from the I850MOD analog quantity and is not available to the user.
[f] If enabled, value = 1. If disabled, value = 3.
[g] If closed, value = 2. If open, value = 1.
[h] F79SHm is functionally equivalent to 79SHm but with improved IEC 61850 time-stamp accuracy.
[i] HWREV is an internal data source and is not available to the user.

Table 10.25 shows the LNs associated with measuring elements, defined as Logical Device MET.

Table 10.25 Logical Device: MET (Metering) (Sheet 1 of 13)

Logical Node	Attribute	Data Source	Comment
Functional Constraint = ST			
LLN0	Mod.stVal	I60MOD[a]	IEC 61850 mode/behavior status
LLN0	Loc.stVal	LOC	Control authority at local (bay) level
LLN0	LocSta.stVal	LOCSTA	Control authority at station level
DC1ZBAT1	BatWrn.stVal	DC1W	DC monitor warning alarm
DC1ZBAT1	BatFail.stVal	DC1F	DC monitor fail alarm
DC1ZBAT1	BatGndFlt.stVal	DC1G	DC monitor ground fault alarm
DC1ZBAT1	BatDvAlm.stVal	DC1R	DC monitor alarm for ac ripple
METLPHD1	PhyHealth.stVal	EN?3:1[b]	Relay enabled
Functional Constraint = MX			
DC1ZBAT1	Vol.instMag.f	VDC	Station battery dc voltage
METSMMXU1	TotW.instMag.f	3PSFC	1-cycle average three-phase fundamental active power, Terminal S
METSMMXU1	TotVAr.instMag.f	3QSFC	1-cycle average three-phase fundamental reactive power, Terminal S
METSMMXU1	TotVA.instMag.f	3SSFC	1-cycle average three-phase fundamental apparent power, Terminal S
METSMMXU1	TotPF.instMag.f	3DPFS	Three-phase displacement power factor, Terminal S
METSMMXU1	Hz.instMag.f	FREQ	Tracking frequency
METSMMXU1	A.phsA.instCVal.mag.f	IASFMC	1-cycle average filtered phase-current magnitude, A-Phase, Terminal S
METSMMXU1	A.phsA.instCVal.ang.f	IASFAC	1-cycle average filtered phase-current angle, A-Phase, Terminal S
METSMMXU1	A.phsB.instCVal.mag.f	IBSFMC	1-cycle average filtered phase-current magnitude, B-Phase, Terminal S
METSMMXU1	A.phsB.instCVal.ang.f	IBSFAC	1-cycle average filtered phase-current angle, B-Phase, Terminal S
METSMMXU1	A.phsC.instCVal.mag.f	ICSFMC	1-cycle average filtered phase-current magnitude, C-Phase, Terminal S
METSMMXU1	A.phsC.instCVal.ang.f	ICSFAC	1-cycle average filtered phase-current angle, C-Phase, Terminal S
METSMMXU1	W.phsA.instCVal.mag.f	PASFC	1-cycle average phase fundamental active power, A-Phase, Terminal S
METSMMXU1	W.phsB.instCVal.mag.f	PBSFC	1-cycle average phase fundamental active power, B-Phase, Terminal S
METSMMXU1	W.phsC.instCVal.mag.f	PCSFC	1-cycle average phase fundamental active power, C-Phase, Terminal S
METSMMXU1	VAr.phsA.instCVal.mag.f	QASFC	1-cycle average phase fundamental reactive power, A-Phase, Terminal S
METSMMXU1	VAr.phsB.instCVal.mag.f	QBSFC	1-cycle average phase fundamental reactive power, B-Phase, Terminal S
METSMMXU1	VAr.phsC.instCVal.mag.f	QCSFC	1-cycle average phase fundamental reactive power, C-Phase, Terminal S
METSMMXU1	VA.phsA.instCVal.mag.f	SASFC	1-cycle average phase fundamental apparent power, A-Phase, Terminal S
METSMMXU1	VA.phsB.instCVal.mag.f	SBSFC	1-cycle average phase fundamental apparent power, B-Phase, Terminal S

Table 10.25 Logical Device: MET (Metering) (Sheet 2 of 13)

Logical Node	Attribute	Data Source	Comment
METSMMXU1	VA.phsC.instCVal.mag.f	SCSFC	1-cycle average phase fundamental apparent power, C-Phase, Terminal S
METSMMXU1	PF.phsA.instCVal.mag.f	DPFAS	Phase displacement power factor, A-Phase, Terminal S
METSMMXU1	PF.phsB.instCVal.mag.f	DPFBS	Phase displacement power factor, B-Phase, Terminal S
METSMMXU1	PF.phsC.instCVal.mag.f	DPFCS	Phase displacement power factor, C-Phase, Terminal S
METSTMMXU1	TotW.instMag.f	3PSTFC	1-cycle average three-phase fundamental active power, Combined Terminals ST
METSTMMXU1	TotVAr.instMag.f	3QSTFC	1-cycle average three-phase fundamental reactive power, Combined Terminals ST
METSTMMXU1	TotVA.instMag.f	3SSTFC	1-cycle average three-phase fundamental apparent power, Combined Terminals ST
METSTMMXU1	TotPF.instMag.f	3DPFST	Three-Phase displacement power factor, Combined Terminals ST
METSTMMXU1	Hz.instMag.f	FREQ	Tracking frequency
METSTMMXU1	A.phsA.instCVal.mag.f	IASTFMC	1-cycle average filtered phase-current magnitude, A-Phase, Combined Terminals ST
METSTMMXU1	A.phsA.instCVal.ang.f	IASTFAC	1-cycle average filtered phase-current angle, A-Phase, Combined Terminals ST
METSTMMXU1	A.phsB.instCVal.mag.f	IBSTFMC	1-cycle average filtered phase-current magnitude, B-Phase, Combined Terminals ST
METSTMMXU1	A.phsB.instCVal.ang.f	IBSTFAC	1-cycle average filtered phase-current angle, B-Phase, Combined Terminals ST
METSTMMXU1	A.phsC.instCVal.mag.f	ICSTFMC	1-cycle average filtered phase-current magnitude, C-Phase, Combined Terminals ST
METSTMMXU1	A.phsC.instCVal.ang.f	ICSTFAC	1-cycle average filtered phase-current angle, C-Phase, Combined Terminals ST
METSTMMXU1	W.phsA.instCVal.mag.f	PASTFC	1-cycle average phase fundamental active power, A-Phase, Combined Terminals ST
METSTMMXU1	W.phsB.instCVal.mag.f	PBSTFC	1-cycle average phase fundamental active power, B-Phase, Combined Terminals ST
METSTMMXU1	W.phsC.instCVal.mag.f	PCSTFC	1-cycle average phase fundamental active power, C-Phase, Combined Terminals ST
METSTMMXU1	VAr.phsA.instCVal.mag.f	QASTFC	1-cycle average phase fundamental reactive power, A-Phase, Combined Terminals ST
METSTMMXU1	VAr.phsB.instCVal.mag.f	QBSTFC	1-cycle average phase fundamental reactive power, B-Phase, Combined Terminals ST
METSTMMXU1	VAr.phsC.instCVal.mag.f	QCSTFC	1-cycle average phase fundamental reactive power, C-Phase, Combined Terminals ST
METSTMMXU1	VA.phsA.instCVal.mag.f	SASTFC	1-cycle average phase fundamental apparent power, A-Phase, Combined Terminals ST
METSTMMXU1	VA.phsB.instCVal.mag.f	SBSTFC	1-cycle average phase fundamental apparent power, B-Phase, Combined Terminals ST
METSTMMXU1	VA.phsC.instCVal.mag.f	SCSTFC	1-cycle average phase fundamental apparent power, C-Phase, Combined Terminals ST
METSTMMXU1	PF.phsA.instCVal.mag.f	DPFAST	Phase displacement power factor, A-Phase, Combined Terminals ST
METSTMMXU1	PF.phsB.instCVal.mag.f	DPFBST	Phase displacement power factor, B-Phase, Combined Terminals ST
METSTMMXU1	PF.phsC.instCVal.mag.f	DPFCST	Phase displacement power factor, C-Phase, Combined Terminals ST
METTMMXU1	TotW.instMag.f	3PTFC	1-cycle average three-phase fundamental active power, Terminal T
METTMMXU1	TotVAr.instMag.f	3QTFC	1-cycle average three-phase fundamental reactive power, Terminal T

Table 10.25 Logical Device: MET (Metering) (Sheet 3 of 13)

Logical Node	Attribute	Data Source	Comment
METTMMXU1	TotVA.instMag.f	3STFC	1-cycle average three-phase fundamental apparent power, Terminal T
METTMMXU1	TotPF.instMag.f	3DPFT	Three-phase displacement power factor, Terminal T
METTMMXU1	Hz.instMag.f	FREQ	Tracking frequency
METTMMXU1	A.phsA.instCVal.mag.f	IATFMC	1-cycle average filtered phase-current magnitude, A-Phase, Terminal T
METTMMXU1	A.phsA.instCVal.ang.f	IATFAC	1-cycle average filtered phase-current angle, A-Phase, Terminal T
METTMMXU1	A.phsB.instCVal.mag.f	IBTFMC	1-cycle average filtered phase-current magnitude, B-Phase, Terminal T
METTMMXU1	A.phsB.instCVal.ang.f	IBTFAC	1-cycle average filtered phase-current angle, B-Phase, Terminal T
METTMMXU1	A.phsC.instCVal.mag.f	ICTFMC	1-cycle average filtered phase-current magnitude, C-Phase, Terminal T
METTMMXU1	A.phsC.instCVal.ang.f	ICTFAC	1-cycle average filtered phase-current angle, C-Phase, Terminal T
METTMMXU1	W.phsA.instCVal.mag.f	PATFC	1-cycle average phase fundamental active power, A-Phase, Terminal T
METTMMXU1	W.phsB.instCVal.mag.f	PBTFC	1-cycle average phase fundamental active power, B-Phase, Terminal T
METTMMXU1	W.phsC.instCVal.mag.f	PCTFC	1-cycle average phase fundamental active power, C-Phase, Terminal T
METTMMXU1	VAr.phsA.instCVal.mag.f	QATFC	1-cycle average phase fundamental reactive power, A-Phase, Terminal T
METTMMXU1	VAr.phsB.instCVal.mag.f	QBTFC	1-cycle average phase fundamental reactive power, B-Phase, Terminal T
METTMMXU1	VAr.phsC.instCVal.mag.f	QCTFC	1-cycle average phase fundamental reactive power, C-Phase, Terminal T
METTMMXU1	VA.phsA.instCVal.mag.f	SATFC	1-cycle average phase fundamental apparent power, A-Phase, Terminal T
METTMMXU1	VA.phsB.instCVal.mag.f	SBTFC	1-cycle average phase fundamental apparent power, B-Phase, Terminal T
METTMMXU1	VA.phsC.instCVal.mag.f	SCTFC	1-cycle average phase fundamental apparent power, C-Phase, Terminal T
METTMMXU1	PF.phsA.instCVal.mag.f	DPFAT	Phase displacement power factor, A-Phase, Terminal T
METTMMXU1	PF.phsB.instCVal.mag.f	DPFBT	Phase displacement power factor, B-Phase, Terminal T
METTMMXU1	PF.phsC.instCVal.mag.f	DPFCT	Phase displacement power factor, C-Phase, Terminal T
METTUMMXU1	TotW.instMag.f	3PTUFC	1-cycle average three-phase fundamental active power, Combined Terminals TU
METTUMMXU1	TotVAr.instMag.f	3QTUFC	1-cycle average three-phase fundamental reactive power, Combined Terminals TU
METTUMMXU1	TotVA.instMag.f	3STUFC	1-cycle average three-phase fundamental apparent power, Combined Terminals TU
METTUMMXU1	TotPF.instMag.f	3DPFTU	Three-Phase displacement power factor, Combined Terminals TU
METTUMMXU1	Hz.instMag.f	FREQ	Tracking frequency
METTUMMXU1	A.phsA.instCVal.mag.f	IATUFMC	1-cycle average filtered phase-current magnitude, A-Phase, Combined Terminals TU
METTUMMXU1	A.phsA.instCVal.ang.f	IATUFAC	1-cycle average filtered phase-current angle, A-Phase, Combined Terminals TU
METTUMMXU1	A.phsB.instCVal.mag.f	IBTUFMC	1-cycle average filtered phase-current magnitude, B-Phase, Combined Terminals TU

Table 10.25 Logical Device: MET (Metering) (Sheet 4 of 13)

Logical Node	Attribute	Data Source	Comment
METTUMMXU1	A.phsB.instCVal.ang.f	IBTUFAC	1-cycle average filtered phase-current angle, B-Phase, Combined Terminals TU
METTUMMXU1	A.phsC.instCVal.mag.f	ICTUFMC	1-cycle average filtered phase-current magnitude, C-Phase, Combined Terminals TU
METTUMMXU1	A.phsC.instCVal.ang.f	ICTUFAC	1-cycle average filtered phase-current angle, C-Phase, Combined Terminals TU
METTUMMXU1	W.phsA.instCVal.mag.f	PATUFC	1-cycle average phase fundamental active power, A-Phase, Combined Terminals TU
METTUMMXU1	W.phsB.instCVal.mag.f	PBTUFC	1-cycle average phase fundamental active power, B-Phase, Combined Terminals TU
METTUMMXU1	W.phsC.instCVal.mag.f	PCTUFC	1-cycle average phase fundamental active power, C-Phase, Combined Terminals TU
METTUMMXU1	VAr.phsA.instCVal.mag.f	QATUFC	1-cycle average phase fundamental reactive power, A-Phase, Combined Terminals TU
METTUMMXU1	VAr.phsB.instCVal.mag.f	QBTUFC	1-cycle average phase fundamental reactive power, B-Phase, Combined Terminals TU
METTUMMXU1	VAr.phsC.instCVal.mag.f	QCTUFC	1-cycle average phase fundamental reactive power, C-Phase, Combined Terminals TU
METTUMMXU1	VA.phsA.instCVal.mag.f	SATUFC	1-cycle average phase fundamental apparent power, A-Phase, Combined Terminals TU
METTUMMXU1	VA.phsB.instCVal.mag.f	SBTUFC	1-cycle average phase fundamental apparent power, B-Phase, Combined Terminals TU
METTUMMXU1	VA.phsC.instCVal.mag.f	SCTUFC	1-cycle average phase fundamental apparent power, C-Phase, Combined Terminals TU
METTUMMXU1	PF.phsA.instCVal.mag.f	DPFATU	Phase displacement power factor, A-Phase, Combined Terminals TU
METTUMMXU1	PF.phsB.instCVal.mag.f	DPFBTU	Phase displacement power factor, B-Phase, Combined Terminals TU
METTUMMXU1	PF.phsC.instCVal.mag.f	DPFCTU	Phase displacement power factor, C-Phase, Combined Terminals TU
METUMMXU1	TotW.instMag.f	3PUFC	1-cycle average three-phase fundamental active power, Terminal U
METUMMXU1	TotVAr.instMag.f	3QUFC	1-cycle average three-phase fundamental reactive power, Terminal U
METUMMXU1	TotVA.instMag.f	3SUFC	1-cycle average three-phase fundamental apparent power, Terminal U
METUMMXU1	TotPF.instMag.f	3DPFU	Three-phase displacement power factor, Terminal U
METUMMXU1	Hz.instMag.f	FREQ	Tracking frequency
METUMMXU1	A.phsA.instCVal.mag.f	IAUFMC	1-cycle average filtered phase-current magnitude, A-Phase, Terminal U
METUMMXU1	A.phsA.instCVal.ang.f	IAUFAC	1-cycle average filtered phase-current angle, A-Phase, Terminal U
METUMMXU1	A.phsB.instCVal.mag.f	IBUFMC	1-cycle average filtered phase-current magnitude, B-Phase, Terminal U
METUMMXU1	A.phsB.instCVal.ang.f	IBUFAC	1-cycle average filtered phase-current angle, B-Phase, Terminal U
METUMMXU1	A.phsC.instCVal.mag.f	ICUFMC	1-cycle average filtered phase-current magnitude, C-Phase, Terminal U
METUMMXU1	A.phsC.instCVal.ang.f	ICUFAC	1-cycle average filtered phase-current angle, C-Phase, Terminal U
METUMMXU1	W.phsA.instCVal.mag.f	PAUFC	1-cycle average phase fundamental active power, A-Phase, Terminal U

Table 10.25 Logical Device: MET (Metering) (Sheet 5 of 13)

Logical Node	Attribute	Data Source	Comment
METUMMXU1	W.phsB.instCVal.mag.f	PBUFC	1-cycle average phase fundamental active power, B-Phase, Terminal U
METUMMXU1	W.phsC.instCVal.mag.f	PCUFC	1-cycle average phase fundamental active power, C-Phase, Terminal U
METUMMXU1	VAr.phsA.instCVal.mag.f	QAUFC	1-cycle average phase fundamental reactive power, A-Phase, Terminal U
METUMMXU1	VAr.phsB.instCVal.mag.f	QBUFC	1-cycle average phase fundamental reactive power, B-Phase, Terminal U
METUMMXU1	VAr.phsC.instCVal.mag.f	QCUFC	1-cycle average phase fundamental reactive power, C-Phase, Terminal U
METUMMXU1	VA.phsA.instCVal.mag.f	SAUFC	1-cycle average phase fundamental apparent power, A-Phase, Terminal U
METUMMXU1	VA.phsB.instCVal.mag.f	SBUFC	1-cycle average phase fundamental apparent power, B-Phase, Terminal U
METUMMXU1	VA.phsC.instCVal.mag.f	SCUFC	1-cycle average phase fundamental apparent power, C-Phase, Terminal U
METUMMXU1	PF.phsA.instCVal.mag.f	DPFAU	Phase displacement power factor, A-Phase, Terminal U
METUMMXU1	PF.phsB.instCVal.mag.f	DPFBU	Phase displacement power factor, B-Phase, Terminal U
METUMMXU1	PF.phsC.instCVal.mag.f	DPFCU	Phase displacement power factor, C-Phase, Terminal U
METUWMMXU1	TotW.instMag.f	3PUWFC	1-cycle average three-phase fundamental active power, Combined Terminals UW
METUWMMXU1	TotVAr.instMag.f	3QUWFC	1-cycle average three-phase fundamental reactive power, Combined Terminals UW
METUWMMXU1	TotVA.instMag.f	3SUWFC	1-cycle average three-phase fundamental apparent power, Combined Terminals UW
METUWMMXU1	TotPF.instMag.f	3DPFUW	Three-phase displacement power factor, Combined Terminals UW
METUWMMXU1	Hz.instMag.f	FREQ	Tracking frequency
METUWMMXU1	A.phsA.instCVal.mag.f	IAUWFMC	1-cycle average filtered phase-current magnitude, A-Phase, Combined Terminals UW
METUWMMXU1	A.phsA.instCVal.ang.f	IAUWFAC	1-cycle average filtered phase-current angle, A-Phase, Combined Terminals UW
METUWMMXU1	A.phsB.instCVal.mag.f	IBUWFMC	1-cycle average filtered phase-current magnitude, B-Phase, Combined Terminals UW
METUWMMXU1	A.phsB.instCVal.ang.f	IBUWFAC	1-cycle average filtered phase-current angle, B-Phase, Combined Terminals UW
METUWMMXU1	A.phsC.instCVal.mag.f	ICUWFMC	1-cycle average filtered phase-current magnitude, C-Phase, Combined Terminals UW
METUWMMXU1	A.phsC.instCVal.ang.f	ICUWFAC	1-cycle average filtered phase-current angle, C-Phase, Combined Terminals UW
METUWMMXU1	W.phsA.instCVal.mag.f	PAUWFC	1-cycle average phase fundamental active power, A-Phase, Combined Terminals UW
METUWMMXU1	W.phsB.instCVal.mag.f	PBUWFC	1-cycle average phase fundamental active power, B-Phase, Combined Terminals UW
METUWMMXU1	W.phsC.instCVal.mag.f	PCUWFC	1-cycle average phase fundamental active power, C-Phase, Combined Terminals UW
METUWMMXU1	VAr.phsA.instCVal.mag.f	QAUWFC	1-cycle average phase fundamental reactive power, A-Phase, Combined Terminals UW
METUWMMXU1	VAr.phsB.instCVal.mag.f	QBUWFC	1-cycle average phase fundamental reactive power, B-Phase, Combined Terminals UW

Table 10.25 Logical Device: MET (Metering) (Sheet 6 of 13)

Logical Node	Attribute	Data Source	Comment
METUWMMXU1	VAr.phsC.instCVal.mag.f	QCUWFC	1-cycle average phase fundamental reactive power, C-Phase, Combined Terminals UW
METUWMMXU1	VA.phsA.instCVal.mag.f	SAUWFC	1-cycle average phase fundamental apparent power, A-Phase, Combined Terminals UW
METUWMMXU1	VA.phsB.instCVal.mag.f	SBUWFC	1-cycle average phase fundamental apparent power, B-Phase, Combined Terminals UW
METUWMMXU1	VA.phsC.instCVal.mag.f	SCUWFC	1-cycle average phase fundamental apparent power, C-Phase, Combined Terminals UW
METUWMMXU1	PF.phsA.instCVal.mag.f	DPFAUW	Phase displacement power factor, A-Phase, Combined Terminals UW
METUWMMXU1	PF.phsB.instCVal.mag.f	DPFBUW	Phase displacement power factor, B-Phase, Combined Terminals UW
METUWMMXU1	PF.phsC.instCVal.mag.f	DPFCUW	Phase displacement power factor, C-Phase, Combined Terminals UW
METVMMXU1	PhV.phsA.instCVal.mag.f	VAVFMC	1-cycle average filtered phase-to-neutral voltage magnitude, A-Phase, Terminal V
METVMMXU1	PhV.phsA.instCVal.ang.f	VAVFAC	1-cycle average filtered phase-to-neutral voltage angle, A-Phase, Terminal V
METVMMXU1	PhV.phsB.instCVal.mag.f	VBVFMC	1-cycle average filtered phase-to-neutral voltage magnitude, B-Phase, Terminal V
METVMMXU1	PhV.phsB.instCVal.ang.f	VBVFAC	1-cycle average filtered phase-to-neutral voltage angle, B-Phase, Terminal V
METVMMXU1	PhV.phsC.instCVal.mag.f	VCVFMC	1-cycle average filtered phase-to-neutral voltage magnitude, C-Phase, Terminal V
METVMMXU1	PhV.phsC.instCVal.ang.f	VCVFAC	1-cycle average filtered phase-to-neutral voltage angle, C-Phase, Terminal V
METVMMXU1	PPV.phsAB.instCVal.mag.f	VABVFMC	1-cycle average filtered phase-to-phase voltage magnitude, AB-Phase, Terminal V
METVMMXU1	PPV.phsAB.instCVal.ang.f	VABVFAC	1-cycle average filtered phase-to-phase voltage angle, AB-Phase, Terminal V
METVMMXU1	PPV.phsBC.instCVal.mag.f	VBCVFMC	1-cycle average filtered phase-to-phase voltage magnitude, BC-Phase, Terminal V
METVMMXU1	PPV.phsBC.instCVal.ang.f	VBCVFAC	1-cycle average filtered phase-to-phase voltage angle, BC-Phase, Terminal V
METVMMXU1	PPV.phsCA.instCVal.mag.f	VCAVFMC	1-cycle average filtered phase-to-phase voltage magnitude, CA-Phase, Terminal V
METVMMXU1	PPV.phsCA.instCVal.ang.f	VCAVFAC	1-cycle average filtered phase-to-phase voltage angle, CA-Phase, Terminal V
METWMMXU1	TotW.instMag.f	3PWFC	1-cycle average three-phase fundamental active power, Terminal W
METWMMXU1	TotVAr.instMag.f	3QWFC	1-cycle average three-phase fundamental reactive power, Terminal W
METWMMXU1	TotVA.instMag.f	3SWFC	1-cycle average three-phase fundamental apparent power, Terminal W
METWMMXU1	TotPF.instMag.f	3DPFW	Three-Phase displacement power factor, Terminal W
METWMMXU1	Hz.instMag.f	FREQ	Tracking frequency
METWMMXU1	A.phsA.instCVal.mag.f	IAWFMC	1-cycle average filtered phase-current magnitude, A-Phase, Terminal W
METWMMXU1	A.phsA.instCVal.ang.f	IAWFAC	1-cycle average filtered phase-current angle, A-Phase, Terminal W

Table 10.25 Logical Device: MET (Metering) (Sheet 7 of 13)

Logical Node	Attribute	Data Source	Comment
METWMMXU1	A.phsB.instCVal.mag.f	IBWFMC	1-cycle average filtered phase-current magnitude, B-Phase, Terminal W
METWMMXU1	A.phsB.instCVal.ang.f	IBWFAC	1-cycle average filtered phase-current angle, B-Phase, Terminal W
METWMMXU1	A.phsC.instCVal.mag.f	ICWFMC	1-cycle average filtered phase-current magnitude, C-Phase, Terminal W
METWMMXU1	A.phsC.instCVal.ang.f	ICWFAC	1-cycle average filtered phase-current angle, C-Phase, Terminal W
METWMMXU1	W.phsA.instCVal.mag.f	PAWFC	1-cycle average phase fundamental active power, A-Phase, Terminal W
METWMMXU1	W.phsB.instCVal.mag.f	PBWFC	1-cycle average phase fundamental active power, B-Phase, Terminal W
METWMMXU1	W.phsC.instCVal.mag.f	PCWFC	1-cycle average phase fundamental active power, C-Phase, Terminal W
METWMMXU1	VAr.phsA.instCVal.mag.f	QAWFC	1-cycle average phase fundamental reactive power, A-Phase, Terminal W
METWMMXU1	VAr.phsB.instCVal.mag.f	QBWFC	1-cycle average phase fundamental reactive power, B-Phase, Terminal W
METWMMXU1	VAr.phsC.instCVal.mag.f	QCWFC	1-cycle average phase fundamental reactive power, C-Phase, Terminal W
METWMMXU1	VA.phsA.instCVal.mag.f	SAWFC	1-cycle average phase fundamental apparent power, A-Phase, Terminal W
METWMMXU1	VA.phsB.instCVal.mag.f	SBWFC	1-cycle average phase fundamental apparent power, B-Phase, Terminal W
METWMMXU1	VA.phsC.instCVal.mag.f	SCWFC	1-cycle average phase fundamental apparent power, C-Phase, Terminal W
METWMMXU1	PF.phsA.instCVal.mag.f	DPFAW	Phase displacement power factor, A-Phase, Terminal W
METWMMXU1	PF.phsB.instCVal.mag.f	DPFBW	Phase displacement power factor, B-Phase, Terminal W
METWMMXU1	PF.phsC.instCVal.mag.f	DPFCW	Phase displacement power factor, C-Phase, Terminal W
METWXMMXU1	TotW.instMag.f	3PWXFC	1-cycle average three-phase fundamental active power, Combined Terminals WX
METWXMMXU1	TotVAr.instMag.f	3QWXFC	1-cycle average three-phase fundamental reactive power, Combined Terminals WX
METWXMMXU1	TotVA.instMag.f	3SWXFC	1-cycle average three-phase fundamental apparent power, Combined Terminals WX
METWXMMXU1	TotPF.instMag.f	3DPFWX	Three-phase displacement power factor, Combined Terminals WX
METWXMMXU1	Hz.instMag.f	FREQ	Tracking frequency
METWXMMXU1	A.phsA.instCVal.mag.f	IAWXFMC	1-cycle average filtered phase-current magnitude, A-Phase, Combined Terminals WX
METWXMMXU1	A.phsA.instCVal.ang.f	IAWXFAC	1-cycle average filtered phase-current angle, A-Phase, Combined Terminals WX
METWXMMXU1	A.phsB.instCVal.mag.f	IBWXFMC	1-cycle average filtered phase-current magnitude, B-Phase, Combined Terminals WX
METWXMMXU1	A.phsB.instCVal.ang.f	IBWXFAC	1-cycle average filtered phase-current angle, B-Phase, Combined Terminals WX
METWXMMXU1	A.phsC.instCVal.mag.f	ICWXFMC	1-cycle average filtered phase-current magnitude, C-Phase, Combined Terminals WX
METWXMMXU1	A.phsC.instCVal.ang.f	ICWXFAC	1-cycle average filtered phase-current angle, C-Phase, Combined Terminals WX

Table 10.25 Logical Device: MET (Metering) (Sheet 8 of 13)

Logical Node	Attribute	Data Source	Comment
METWXMMXU1	W.phsA.instCVal.mag.f	PAWXFC	1-cycle average phase fundamental active power, A-Phase, Combined Terminals WX
METWXMMXU1	W.phsB.instCVal.mag.f	PBWXFC	1-cycle average phase fundamental active power, B-Phase, Combined Terminals WX
METWXMMXU1	W.phsC.instCVal.mag.f	PCWXFC	1-cycle average phase fundamental active power, C-Phase, Combined Terminals WX
METWXMMXU1	VAr.phsA.instCVal.mag.f	QAWXFC	1-cycle average phase fundamental reactive power, A-Phase, Combined Terminals WX
METWXMMXU1	VAr.phsB.instCVal.mag.f	QBWXFC	1-cycle average phase fundamental reactive power, B-Phase, Combined Terminals WX
METWXMMXU1	VAr.phsC.instCVal.mag.f	QCWXFC	1-cycle average phase fundamental reactive power, C-Phase, Combined Terminals WX
METWXMMXU1	VA.phsA.instCVal.mag.f	SAWXFC	1-cycle average phase fundamental apparent power, A-Phase, Combined Terminals WX
METWXMMXU1	VA.phsB.instCVal.mag.f	SBWXFC	1-cycle average phase fundamental apparent power, B-Phase, Combined Terminals WX
METWXMMXU1	VA.phsC.instCVal.mag.f	SCWXFC	1-cycle average phase fundamental apparent power, C-Phase, Combined Terminals WX
METWXMMXU1	PF.phsA.instCVal.mag.f	DPFAWX	Phase displacement power factor, A-Phase, Combined Terminals WX
METWXMMXU1	PF.phsB.instCVal.mag.f	DPFBWX	Phase displacement power factor, B-Phase, Combined Terminals WX
METWXMMXU1	PF.phsC.instCVal.mag.f	DPFCWX	Phase displacement power factor, C-Phase, Combined Terminals WX
METXMMXU1	TotW.instMag.f	3PXFC	1-cycle average three-phase fundamental active power, Terminal X
METXMMXU1	TotVAr.instMag.f	3QXFC	1-cycle average three-phase fundamental reactive power, Terminal X
METXMMXU1	TotVA.instMag.f	3SXFC	1-cycle average three-phase fundamental apparent power, Terminal X
METXMMXU1	TotPF.instMag.f	3DPFX	Three-phase displacement power factor, Terminal X
METXMMXU1	Hz.instMag.f	FREQ	Tracking frequency
METXMMXU1	A.phsA.instCVal.mag.f	IAXFMC	1-cycle average filtered phase-current magnitude, A-Phase, Terminal X
METXMMXU1	A.phsA.instCVal.ang.f	IAXFAC	1-cycle average filtered phase-current angle, A-Phase, Terminal X
METXMMXU1	A.phsB.instCVal.mag.f	IBXFMC	1-cycle average filtered phase-current magnitude, B-Phase, Terminal X
METXMMXU1	A.phsB.instCVal.ang.f	IBXFAC	1-cycle average filtered phase-current angle, B-Phase, Terminal X
METXMMXU1	A.phsC.instCVal.mag.f	ICXFMC	1-cycle average filtered phase-current magnitude, C-Phase, Terminal X
METXMMXU1	A.phsC.instCVal.ang.f	ICXFAC	1-cycle average filtered phase-current angle, C-Phase, Terminal X
METXMMXU1	W.phsA.instCVal.mag.f	PAXFC	1-cycle average phase fundamental active power, A-Phase, Terminal X
METXMMXU1	W.phsB.instCVal.mag.f	PBXFC	1-cycle average phase fundamental active power, B-Phase, Terminal X
METXMMXU1	W.phsC.instCVal.mag.f	PCXFC	1-cycle average phase fundamental active power, C-Phase, Terminal X
METXMMXU1	VAr.phsA.instCVal.mag.f	QAXFC	1-cycle average phase fundamental reactive power, A-Phase, Terminal X

Table 10.25 Logical Device: MET (Metering) (Sheet 9 of 13)

Logical Node	Attribute	Data Source	Comment
METXMMXU1	VAr.phsB.instCVal.mag.f	QBXFC	1-cycle average phase fundamental reactive power, B-Phase, Terminal X
METXMMXU1	VAr.phsC.instCVal.mag.f	QCXFC	1-cycle average phase fundamental reactive power, C-Phase, Terminal X
METXMMXU1	VA.phsA.instCVal.mag.f	SAXFC	1-cycle average phase fundamental apparent power, A-Phase, Terminal X
METXMMXU1	VA.phsB.instCVal.mag.f	SBXFC	1-cycle average phase fundamental apparent power, B-Phase, Terminal X
METXMMXU1	VA.phsC.instCVal.mag.f	SCXFC	1-cycle average phase fundamental apparent power, C-Phase, Terminal X
METXMMXU1	PF.phsA.instCVal.mag.f	DPFAX	Phase displacement power factor, A-Phase, Terminal X
METXMMXU1	PF.phsB.instCVal.mag.f	DPFBX	Phase displacement power factor, B-Phase, Terminal X
METXMMXU1	PF.phsC.instCVal.mag.f	DPFCX	Phase displacement power factor, C-Phase, Terminal X
METY1MMXN1	Amp01.instMag.f	IY1FMC	1-cycle average filtered current magnitude, Channel 1, Terminal Y
METY2MMXN1	Amp02.instMag.f	IY2FMC	1-cycle average filtered current magnitude, Channel 2, Terminal Y
METY3MMXN1	Amp03.instMag.f	IY3FMC	1-cycle average filtered current magnitude, Channel 3, Terminal Y
METYMMXU1	TotW.instMag.f	3PYFC	1-cycle average three-phase fundamental active power, Terminal Y
METYMMXU1	TotVAr.instMag.f	3QYFC	1-cycle average three-phase fundamental reactive power, Terminal Y
METYMMXU1	TotVA.instMag.f	3SYFC	1-cycle average three-phase fundamental apparent power, Terminal Y
METYMMXU1	TotPF.instMag.f	3DPFY	Three-phase displacement power factor, Terminal Y
METYMMXU1	Hz.instMag.f	FREQ	Tracking frequency
METYMMXU1	A.phsA.instCVal.mag.f	IAYFMC	1-cycle average filtered phase-current magnitude, A-Phase, Terminal Y
METYMMXU1	A.phsA.instCVal.ang.f	IAYFAC	1-cycle average filtered phase-current angle, A-Phase, Terminal Y
METYMMXU1	A.phsB.instCVal.mag.f	IBYFMC	1-cycle average filtered phase-current magnitude, B-Phase, Terminal Y
METYMMXU1	A.phsB.instCVal.ang.f	IBYFAC	1-cycle average filtered phase-current angle, B-Phase, Terminal Y
METYMMXU1	A.phsC.instCVal.mag.f	ICYFMC	1-cycle average filtered phase-current magnitude, C-Phase, Terminal Y
METYMMXU1	A.phsC.instCVal.ang.f	ICYFAC	1-cycle average filtered phase-current angle, C-Phase, Terminal Y
METYMMXU1	W.phsA.instCVal.mag.f	PAYFC	1-cycle average phase fundamental active power, A-Phase, Terminal Y
METYMMXU1	W.phsB.instCVal.mag.f	PBYFC	1-cycle average phase fundamental active power, B-Phase, Terminal Y
METYMMXU1	W.phsC.instCVal.mag.f	PCYFC	1-cycle average phase fundamental active power, C-Phase, Terminal Y
METYMMXU1	VAr.phsA.instCVal.mag.f	QAYFC	1-cycle average phase fundamental reactive power, A-Phase, Terminal Y
METYMMXU1	VAr.phsB.instCVal.mag.f	QBYFC	1-cycle average phase fundamental reactive power, B-Phase, Terminal Y
METYMMXU1	VAr.phsC.instCVal.mag.f	QCYFC	1-cycle average phase fundamental reactive power, C-Phase, Terminal Y
METYMMXU1	VA.phsA.instCVal.mag.f	SAYFC	1-cycle average phase fundamental apparent power, A-Phase, Terminal Y

Table 10.25 Logical Device: MET (Metering) (Sheet 10 of 13)

Logical Node	Attribute	Data Source	Comment
METYMMXU1	VA.phsB.instCVal.mag.f	SBYFC	1-cycle average phase fundamental apparent power, B-Phase, Terminal Y
METYMMXU1	VA.phsC.instCVal.mag.f	SCYFC	1-cycle average phase fundamental apparent power, C-Phase, Terminal Y
METYMMXU1	PF.phsA.instCVal.mag.f	DPFAY	Phase displacement power factor, A-Phase, Terminal Y
METYMMXU1	PF.phsB.instCVal.mag.f	DPFBY	Phase displacement power factor, B-Phase, Terminal Y
METYMMXU1	PF.phsC.instCVal.mag.f	DPFCY	Phase displacement power factor, C-Phase, Terminal Y
METZMMXU1	PhV.phsA.instCVal.mag.f	VAZFMC	1-cycle average filtered phase-to-neutral voltage magnitude, A-phase, Terminal Z
METZMMXU1	PhV.phsA.instCVal.ang.f	VAZFAC	1-cycle average filtered phase-to-neutral voltage angle, A-phase, Terminal Z
METZMMXU1	PhV.phsB.instCVal.mag.f	VBZFMC	1-cycle average filtered phase-to-neutral voltage magnitude, B-phase, Terminal Z
METZMMXU1	PhV.phsB.instCVal.ang.f	VBZFAC	1-cycle average filtered phase-to-neutral voltage angle, B-phase, Terminal Z
METZMMXU1	PhV.phsC.instCVal.mag.f	VCZFMC	1-cycle average filtered phase-to-neutral voltage magnitude, C-phase, Terminal Z
METZMMXU1	PhV.phsC.instCVal.ang.f	VCZFAC	1-cycle average filtered phase-to-neutral voltage angle, C-phase, Terminal Z
METZMMXU1	PPV.phsAB.instCVal.mag.f	VABZFMC	1-cycle average filtered phase-to-phase voltage magnitude, AB-phase, Terminal Z
METZMMXU1	PPV.phsAB.instCVal.ang.f	VABZFAC	1-cycle average filtered phase-to-phase voltage angle, AB-phase, Terminal Z
METZMMXU1	PPV.phsBC.instCVal.mag.f	VBCZFMC	1-cycle average filtered phase-to-phase voltage magnitude, BC-phase, Terminal Z
METZMMXU1	PPV.phsBC.instCVal.ang.f	VBCZFAC	1-cycle average filtered phase-to-phase voltage angle, BC-phase, Terminal Z
METZMMXU1	PPV.phsCA.instCVal.mag.f	VCAZFMC	1-cycle average filtered phase-to-phase voltage magnitude, CA-phase, Terminal Z
METZMMXU1	PPV.phsCA.instCVal.ang.f	VCAZFAC	1-cycle average filtered phase-to-phase voltage angle, CA-phase, Terminal Z
SEQSMSQI1	SeqA.c1.instCVal.mag.f	I1SMC	1-cycle average positive-sequence current magnitude, Terminal S
SEQSMSQI1	SeqA.c1.instCVal.ang.f	I1SAC	1-cycle average positive-sequence current angle, Terminal S
SEQSMSQI1	SeqA.c2.instCVal.mag.f	3I2SMC	1-cycle average negative-sequence current magnitude, Terminal S
SEQSMSQI1	SeqA.c2.instCVal.ang.f	3I2SAC	1-cycle average negative-sequence current angle, Terminal S
SEQSMSQI1	SeqA.c3.instCVal.mag.f	3I0SMC	1-cycle average zero-sequence current magnitude, Terminal S
SEQSMSQI1	SeqA.c3.instCVal.ang.f	3I0SAC	1-cycle average zero-sequence current angle, Terminal S
SEQSTMSQI1	SeqA.c1.instCVal.mag.f	I1STMC	1-cycle average positive-sequence current magnitude, Combined Terminals ST
SEQSTMSQI1	SeqA.c1.instCVal.ang.f	I1STAC	1-cycle average positive-sequence current angle, Combined Terminals ST
SEQSTMSQI1	SeqA.c2.instCVal.mag.f	3I2STMC	1-cycle average negative-sequence current magnitude, Combined Terminals ST
SEQSTMSQI1	SeqA.c2.instCVal.ang.f	3I2STAC	1-cycle average negative-sequence current angle, Combined Terminals ST
SEQSTMSQI1	SeqA.c3.instCVal.mag.f	3I0STMC	1-cycle average zero-sequence current magnitude, Combined Terminals ST

Table 10.25 Logical Device: MET (Metering) (Sheet 11 of 13)

Logical Node	Attribute	Data Source	Comment
SEQSTMSQI1	SeqA.c3.instCVal.ang.f	3I0STAC	1-cycle average zero-sequence current angle, Combined Terminals ST
SEQTMSQI1	SeqA.c1.instCVal.mag.f	I1TMC	1-cycle average positive-sequence current magnitude, Terminal T
SEQTMSQI1	SeqA.c1.instCVal.ang.f	I1TAC	1-cycle average positive-sequence current angle, Terminal T
SEQTMSQI1	SeqA.c2.instCVal.mag.f	3I2TMC	1-cycle average negative-sequence current magnitude, Terminal T
SEQTMSQI1	SeqA.c2.instCVal.ang.f	3I2TAC	1-cycle average negative-sequence current angle, Terminal T
SEQTMSQI1	SeqA.c3.instCVal.mag.f	3I0TMC	1-cycle average zero-sequence current magnitude, Terminal T
SEQTMSQI1	SeqA.c3.instCVal.ang.f	3I0TAC	1-cycle average zero-sequence current angle, Terminal T
SEQTUMSQI1	SeqA.c1.instCVal.mag.f	I1TUMC	1-cycle average positive-sequence current magnitude, Combined Terminals TU
SEQTUMSQI1	SeqA.c1.instCVal.ang.f	I1TUAC	1-cycle average positive-sequence current angle, Combined Terminals TU
SEQTUMSQI1	SeqA.c2.instCVal.mag.f	3I2TUMC	1-cycle average negative-sequence current magnitude, Combined Terminals TU
SEQTUMSQI1	SeqA.c2.instCVal.ang.f	3I2TUAC	1-cycle average negative-sequence current angle, Combined Terminals TU
SEQTUMSQI1	SeqA.c3.instCVal.mag.f	3I0TUMC	1-cycle average zero-sequence current magnitude, Combined Terminals TU
SEQTUMSQI1	SeqA.c3.instCVal.ang.f	3I0TUAC	1-cycle average zero-sequence current angle, Combined Terminals TU
SEQUMSQI1	SeqA.c1.instCVal.mag.f	I1UMC	1-cycle average positive-sequence current magnitude, Terminal U
SEQUMSQI1	SeqA.c1.instCVal.ang.f	I1UAC	1-cycle average positive-sequence current angle, Terminal U
SEQUMSQI1	SeqA.c2.instCVal.mag.f	3I2UMC	1-cycle average negative-sequence current magnitude, Terminal U
SEQUMSQI1	SeqA.c2.instCVal.ang.f	3I2UAC	1-cycle average negative-sequence current angle, Terminal U
SEQUMSQI1	SeqA.c3.instCVal.mag.f	3I0UMC	1-cycle average zero-sequence current magnitude, Terminal U
SEQUMSQI1	SeqA.c3.instCVal.ang.f	3I0UAC	1-cycle average zero-sequence current angle, Terminal U
SEQUWMSQI1	SeqA.c1.instCVal.mag.f	I1UWMC	1-cycle average positive-sequence current magnitude, Combined Terminals UW
SEQUWMSQI1	SeqA.c1.instCVal.ang.f	I1UWAC	1-cycle average positive-sequence current angle, Combined Terminals UW
SEQUWMSQI1	SeqA.c2.instCVal.mag.f	3I2UWMC	1-cycle average negative-sequence current magnitude, Combined Terminals UW
SEQUWMSQI1	SeqA.c2.instCVal.ang.f	3I2UWAC	1-cycle average negative-sequence current angle, Combined Terminals UW
SEQUWMSQI1	SeqA.c3.instCVal.mag.f	3I0UWMC	1-cycle average zero-sequence current magnitude, Combined Terminals UW
SEQUWMSQI1	SeqA.c3.instCVal.ang.f	3I0UWAC	1-cycle average zero-sequence current angle, Combined Terminals UW
SEQVMSQI1	SeqV.c1.instCVal.mag.f	V1VMC	1-cycle average positive-sequence voltage magnitude, Terminal V
SEQVMSQI1	SeqV.c1.instCVal.ang.f	V1VAC	1-cycle average positive-sequence voltage angle, Terminal V
SEQVMSQI1	SeqV.c2.instCVal.mag.f	3V2VMC	1-cycle average negative-sequence voltage magnitude, Terminal V
SEQVMSQI1	SeqV.c2.instCVal.ang.f	3V2VAC	1-cycle average negative-sequence voltage angle, Terminal V
SEQVMSQI1	SeqV.c3.instCVal.mag.f	3V0VMC	1-cycle average zero-sequence voltage magnitude, Terminal V
SEQVMSQI1	SeqV.c3.instCVal.ang.f	3V0VAC	1-cycle average zero-sequence voltage angle, Terminal V
SEQWMSQI1	SeqA.c1.instCVal.mag.f	I1WMC	1-cycle average positive-sequence current magnitude, Terminal W

Table 10.25 Logical Device: MET (Metering) (Sheet 12 of 13)

Logical Node	Attribute	Data Source	Comment
SEQWMSQI1	SeqA.c1.instCVal.ang.f	I1WAC	1-cycle average positive-sequence current angle, Terminal W
SEQWMSQI1	SeqA.c2.instCVal.mag.f	3I2WMC	1-cycle average negative-sequence current magnitude, Terminal W
SEQWMSQI1	SeqA.c2.instCVal.ang.f	3I2WAC	1-cycle average negative-sequence current angle, Terminal W
SEQWMSQI1	SeqA.c3.instCVal.mag.f	3I0WMC	1-cycle average zero-sequence current magnitude, Terminal W
SEQWMSQI1	SeqA.c3.instCVal.ang.f	3I0WAC	1-cycle average zero-sequence current angle, Terminal W
SEQWXMSQI1	SeqA.c1.instCVal.mag.f	I1WXMC	1-cycle average positive-sequence current magnitude, Combined Terminals WX
SEQWXMSQI1	SeqA.c1.instCVal.ang.f	I1WXAC	1-cycle average positive-sequence current angle, Combined Terminals WX
SEQWXMSQI1	SeqA.c2.instCVal.mag.f	3I2WXMC	1-cycle average negative-sequence current magnitude, Combined Terminals WX
SEQWXMSQI1	SeqA.c2.instCVal.ang.f	3I2WXAC	1-cycle average negative-sequence current angle, Combined Terminals WX
SEQWXMSQI1	SeqA.c3.instCVal.mag.f	3I0WXMC	1-cycle average zero-sequence current magnitude, Combined Terminals WX
SEQWXMSQI1	SeqA.c3.instCVal.ang.f	3I0WXAC	1-cycle average zero-sequence current angle, Combined Terminals WX
SEQXMSQI1	SeqA.c1.instCVal.mag.f	I1XMC	1-cycle average positive-sequence current magnitude, Terminal X
SEQXMSQI1	SeqA.c1.instCVal.ang.f	I1XAC	1-cycle average positive-sequence current angle, Terminal X
SEQXMSQI1	SeqA.c2.instCVal.mag.f	3I2XMC	1-cycle average negative-sequence current magnitude, Terminal X
SEQXMSQI1	SeqA.c2.instCVal.ang.f	3I2XAC	1-cycle average negative-sequence current angle, Terminal X
SEQXMSQI1	SeqA.c3.instCVal.mag.f	3I0XMC	1-cycle average zero-sequence current magnitude, Terminal X
SEQXMSQI1	SeqA.c3.instCVal.ang.f	3I0XAC	1-cycle average zero-sequence current angle, Terminal X
SEQYMSQI1	SeqA.c1.instCVal.mag.f	I1YMC	1-cycle average positive-sequence current magnitude, Terminal Y
SEQYMSQI1	SeqA.c1.instCVal.ang.f	I1YAC	1-cycle average positive-sequence current angle, Terminal Y
SEQYMSQI1	SeqA.c2.instCVal.mag.f	3I2YMC	1-cycle average negative-sequence current magnitude, Terminal Y
SEQYMSQI1	SeqA.c2.instCVal.ang.f	3I2YAC	1-cycle average negative-sequence current angle, Terminal Y
SEQYMSQI1	SeqA.c3.instCVal.mag.f	3I0YMC	1-cycle average zero-sequence current magnitude, Terminal Y
SEQYMSQI1	SeqA.c3.instCVal.ang.f	3I0YAC	1-cycle average zero-sequence current angle, Terminal Y
SEQZMSQI1	SeqV.c1.instCVal.mag.f	V1ZMC	1-cycle average positive-sequence voltage magnitude, Terminal Z
SEQZMSQI1	SeqV.c1.instCVal.ang.f	V1ZAC	1-cycle average positive-sequence voltage angle, Terminal Z
SEQZMSQI1	SeqV.c2.instCVal.mag.f	3V2ZMC	1-cycle average negative-sequence voltage magnitude, Terminal Z
SEQZMSQI1	SeqV.c2.instCVal.ang.f	3V2ZAC	1-cycle average negative-sequence voltage angle, Terminal Z
SEQZMSQI1	SeqV.c3.instCVal.mag.f	3V0ZMC	1-cycle average zero-sequence voltage magnitude, Terminal Z
SEQZMSQI1	SeqV.c3.instCVal.ang.f	3V0ZAC	1-cycle average zero-sequence voltage angle, Terminal Z
Functional Constraint = DC			
LLN0	NamPlt.swRev	VERFID	Relay FID string
METLPHD1	PhyNam.serNum	SERNUM	Relay serial number
METLPHD1	PhyNam.model	PARNUM	Relay part number
METLPHD1	PhyNam.hwRev	HWREV[c]	Hardware version of the relay mainboard

Table 10.25 Logical Device: MET (Metering) (Sheet 13 of 13)

Logical Node	Attribute	Data Source	Comment
Functional Constraint = SP			
LLN0	GrRef.setSrcRef	IdName	Functional name
LLN0	MltLev.setVal	MLTLEV	Multi-level control authority

[a] I60MOD is an internal data source derived from the I850MOD analog quantity and is not available to the user.
[b] If enabled, value = 1. If disabled, value = 3.
[c] HWREV is an internal data source and is not available to the user.

Table 10.26 Logical Device: MU01 (SV Merging Unit)[a] (Sheet 1 of 2)

Logical Node	Attribute	Data Source	Comment
Functional Constraint = ST			
LLN0	Mod.stVal	I60MOD[b]	IEC 61850 mode/behavior status
LLN0	Loc.stVal	LOC	Control authority at local (bay) level
LLN0	LocSta.stVal	LOCSTA	Control authority at station level
MULPHD1	PhyHealth.stVal	EN?3:1[c]	Relay enabled
Functional Constraint = DC			
LLN0	NamPlt.swRev	VERFID	Relay FID string
MULPHD1	PhyNam.serNum	SERNUM	Relay serial number
MULPHD1	PhyNam.model	PARNUM	Relay part number
MULPHD1	PhyNam.hwRev	HWREV[d]	Hardware version of the relay mainboard
Functional Constraint = MX			
IASTCTR1	AmpSv.instMag.i	IAS	Instantaneous primary current, A-Phase, Terminal S
IBSTCTR1	AmpSv.instMag.i	IBS	Instantaneous primary current, B-Phase, Terminal S
ICSTCTR1	AmpSv.instMag.i	ICS	Instantaneous primary current, C-Phase, Terminal S
INSTCTR1	AmpSv.instMag.i	INS	Instantaneous primary current, neutral phase, Terminal S Calculated sum of the three phases of Terminal S
IATTCTR1	AmpSv.instMag.i	IAT	Instantaneous primary current, A-Phase, Terminal T
IBTTCTR1	AmpSv.instMag.i	IBT	Instantaneous primary current, B-Phase, Terminal T
ICTTCTR1	AmpSv.instMag.i	ICT	Instantaneous primary current, C-Phase, Terminal T
INTTCTR1	AmpSv.instMag.i	INT	Instantaneous primary current, neutral phase, Terminal T Calculated sum of the three phases of Terminal T
IAUTCTR1	AmpSv.instMag.i	IAU	Instantaneous primary current, A-Phase, Terminal U
IBUTCTR1	AmpSv.instMag.i	IBU	Instantaneous primary current, B-Phase, Terminal U
ICUTCTR1	AmpSv.instMag.i	ICU	Instantaneous primary current, C-Phase, Terminal U
INUTCTR1	AmpSv.instMag.i	INU	Instantaneous primary current, neutral phase, Terminal U Calculated sum of the three phases of Terminal U
IAWTCTR1	AmpSv.instMag.i	IAW	Instantaneous primary current, A-Phase, Terminal W
IBWTCTR1	AmpSv.instMag.i	IBW	Instantaneous primary current, B-Phase, Terminal W
ICWTCTR1	AmpSv.instMag.i	ICW	Instantaneous primary current, C-Phase, Terminal W
INWTCTR1	AmpSv.instMag.i	INW	Instantaneous primary current, neutral phase, Terminal W Calculated sum of the three phases of Terminal W
IAXTCTR1	AmpSv.instMag.i	IAX	Instantaneous primary current, A-Phase, Terminal X
IBXTCTR1	AmpSv.instMag.i	IBX	Instantaneous primary current, B-Phase, Terminal X

Table 10.26 Logical Device: MU01 (SV Merging Unit)[a] (Sheet 2 of 2)

Logical Node	Attribute	Data Source	Comment
ICXTCTR1	AmpSv.instMag.i	ICX	Instantaneous primary current, C-Phase, Terminal X
INXTCTR1	AmpSv.instMag.i	INX	Instantaneous primary current, neutral phase, Terminal X Calculated sum of the three phases of Terminal X
IAYTCTR1	AmpSv.instMag.i	IAY	Instantaneous primary current, A-Phase, Terminal Y
IBYTCTR1	AmpSv.instMag.i	IBY	Instantaneous primary current, B-Phase, Terminal Y
ICYTCTR1	AmpSv.instMag.i	ICY	Instantaneous primary current, C-Phase, Terminal Y
INYTCTR1	AmpSv.instMag.i	INY	Instantaneous primary current, neutral phase, Terminal Y Calculated sum of the three phases of Terminal Y
VAVTVTR1	VolSv.instMag.i	VAV	Instantaneous primary voltage, A-Phase, Terminal V
VBVTVTR1	VolSv.instMag.i	VBV	Instantaneous primary voltage, B-Phase, Terminal V
VCVTVTR1	VolSv.instMag.i	VCV	Instantaneous primary voltage, C-Phase, Terminal V
VNVTVTR1	VolSv.instMag.i	VNV	Instantaneous primary voltage, neutral phase, Terminal V Calculated sum of the three phases of Terminal V
VAZTVTR1	VolSv.instMag.i	VAZ	Instantaneous primary voltage, A-Phase, Terminal Z
VBZTVTR1	VolSv.instMag.i	VBZ	Instantaneous primary voltage, B-Phase, Terminal Z
VCZTVTR1	VolSv.instMag.i	VCZ	Instantaneous primary voltage, C-Phase, Terminal Z
VNZTVTR1	VolSv.instMag.i	VNZ	Instantaneous primary voltage, neutral phase, Terminal Z Calculated sum of the three phases of Terminal Z
Functional Constraint = SP			
LLN0	GrRef.setSrcRef	IdName	Functional name
LLN0	MltLev.setVal	MLTLEV	Multi-level control authority

[a] Only applicable to the SEL-487E-5 SV Publisher.
[b] I60MOD is an internal data source derived from the I850MOD analog quantity and is not available to the user.
[c] If enabled, value = 1. If disabled, value = 3.
[d] HWREV is an internal data source and is not available to the user.

Table 10.27 FLTYPE—Fault Type

Value	Fault Type
0	No fault type identified/present

Table 10.28 FLTCAUS—Fault Cause

Value	Fault Cause
0	No fault summary loaded
1	Trigger command
2	Trip element
3	Event report element
6	Zone 1 differential trip
7	Zone 2 differential trip
8	Restricted earth fault trip

Synchrophasors

General synchrophasor operation is described in *Section 18: Synchrophasors in the SEL-400 Series Relays Instruction Manual*. This section describes characteristics of synchrophasors that are unique to the SEL-487E.

The SEL-487E has 18 current channels and 6 voltage channels. Current Terminals S, T, U, W, X, and voltage Terminals V, Z are three-phase channels. The SEL-487E considers Channels Y1, Y2, and Y3 as a single Terminal Y.

From these 24 channels, the SEL-487E can measure as many as 32 synchrophasors (24 phase synchrophasors and 8 positive-sequence synchrophasors). Synchrophasors are always in primary, so set the CT and PT ratios in the group settings appropriately. Note that CTRY1 applies to all the channels in Terminal Y.

Table 10.29 shows the default voltage synchrophasor name, enable conditions and the PT ratio used to scale to the primary values.

Table 10.29 Voltage Synchrophasor Names

Phasor Name	Phasor Enable Conditions	PT Ratio
V1VPM	PHDV*q* = V1 or ALL AND Terminal V included	PTRV
VAVPM	PHDV*q* = PH or ALL AND Terminal V included	PTRV
VBVPM	PHDV*q* = PH or ALL AND Terminal V included	PTRV
VCVPM	PHDV*q* = PH or ALL AND Terminal V included	PTRV
V1ZPM	PHDV*q* = V1 or ALL AND Terminal Z included	PTRZ
VAZPM	PHDV*q* = PH or ALL AND Terminal Z included	PTRZ
VBZPM	PHDV*q* = PH or ALL AND Terminal Z included	PTRZ
VCZPM	PHDV*q* = PH or ALL AND Terminal Z included	PTRZ

Table 10.30 shows the default current synchrophasor names, enable conditions, and the CT ratio used to scale to the primary values.

Table 10.30 Current Synchrophasor Names (Sheet 1 of 2)

Phasor Name	Phasor Enable Conditions	CT Ratio
I1SPM	PHDI*q* = I1 or ALL AND Terminal S included	CTRS
IASPM	PHDI*q* = PH or ALL AND Terminal S included	CTRS
IBSPM	PHDI*q* = PH or ALL AND Terminal S included	CTRS
ICSPM	PHDI*q* = PH or ALL AND Terminal S included	CTRS
I1TPM	PHDI*q* = I1 or ALL AND Terminal T included	CTRT
IATPM	PHDI*q* = PH or ALL AND Terminal T included	CTRT
IBTPM	PHDI*q* = PH or ALL AND Terminal T included	CTRT
ICTPM	PHDI*q* = PH or ALL AND Terminal T included	CTRT
I1UPM	PHDI*q* = I1 or ALL AND Terminal U included	CTRU
IAUPM	PHDI*q* = PH or ALL AND Terminal U included	CTRU
IBUPM	PHDI*q* = PH or ALL AND Terminal U included	CTRU
ICUPM	PHDI*q* = PH or ALL AND Terminal U included	CTRU
I1WPM	PHDI*q* = I1 or ALL AND Terminal W included	CTRW
IAWPM	PHDI*q* = PH or ALL AND Terminal W included	CTRW

Table 10.30 Current Synchrophasor Names (Sheet 2 of 2)

Phasor Name	Phasor Enable Conditions	CT Ratio
IBWPM	PHDI*q* = PH or ALL AND Terminal W included	CTRW
ICWPM	PHDI*q* = PH or ALL AND Terminal W included	CTRW
I1XPM	PHDI*q* = I1 or ALL AND Terminal X included	CTRX
IAXPM	PHDI*q* = PH or ALL AND Terminal X included	CTRX
IBXPM	PHDI*q* = PH or ALL AND Terminal X included	CTRX
ICXPM	PHDI*q* = PH or ALL AND Terminal X included	CTRX
I1YPM	PHDI*q* = I1 or ALL AND Terminal Y included	CTRY1
IAYPM	PHDI*q* = PH or ALL AND Terminal Y included	CTRY1
IBYPM	PHDI*q* = PH or ALL AND Terminal Y included	CTRY1
ICYPM	PHDI*q* = PH or ALL AND Terminal Y included	CTRY1

Table 10.31 describes the order of synchrophasors inside the data packet when operating in legacy mode (LEGACY = Y).

Table 10.31 Synchrophasor Order in Data Stream (Voltages and Currents)

Synchrophasors[a] (Analog Quantity Names)				Included When Global Settings Are as Follows:
Polar[b]		Rectangular[c]		
Magnitude	Angle	Real	Imaginary	
V1*m*PMM[d]	V1*m*PMA	V1*m*PMR	V1*m*PMI	PHDATAV := V1 or ALL
VA*m*PMM	VA*m*PMA	VA*m*PMR	VA*m*PMI	PHDATAV := PH or ALL
VB*m*PMM	VB*m*PMA	VB*m*PMR	VB*m*PMI	
VC*m*PMM	VC*m*PMA	VC*m*PMR	VC*m*PMI	
I1*n*PMM[e]	I1*n*PMA	I1*n*PMR	I1*n*PMI	PHDATAI := I1 or ALL
IA*n*PMM	IA*n*PMA	IA*n*PMR	IA*n*PMI	PHDATAI := PH or ALL
IB*n*PMM	IB*n*PMA	IB*n*PMR	IB*n*PMI	
IC*n*PMM	IC*n*PMA	IC*n*PMR	IC*n*PMI	

[a] Synchrophasors are included in the order shown (i.e., voltages, if selected, will always precede currents).
[b] Polar coordinate values are sent when PHFMT := P.
[c] Rectangular (real and imaginary) values are sent when PHFMT := R.
[d] Where:
m = V if PHVOLT includes V.
m = Z if PHVOLT includes Z.
[e] Where:
n = S if PHCURR includes S.
n = T if PHCURR includes T.
n = U if PHCURR includes U.
n = W if PHCURR includes W.
n = X if PHCURR includes X.
n = Y if PHCURR includes Y.

In addition to the Y/N PMLEGCY options available in other SEL-400 Series Relays, the SEL-487E supports an N1 option. The N1 option is the same as the N option, except that the configuration of the analog and digital portions of the messages use the following settings.

NUMANq

Selects the number of user-definable analog values to be included in the synchrophasor data stream *q*.

- NUMAN*q* := 0 sends no user-definable analog values.
- NUMAN*q* := 1–16 sends the user-definable analog values.

NUMDWq

Selects the number of user-definable digital status words to be included in the synchrophasor data stream *q*.

- NUMDW*q* := 0 sends no user-definable binary status words.
- NUMDW*q* := 1, 2, 3, or 4 sends the user-definable binary status words.

This page intentionally left blank

SECTION 11

Relay Word Bits

This section contains tables of the Relay Word bits available within the SEL-487E-5 Relay. *Table 11.1* lists the Relay Word bits in alphabetic order; *Table 11.2* lists every Relay Word bit row and the bits contained within each row.

Alphabetical List

Table 11.1 Alphabetical List of Relay Word Bits (Sheet 1 of 93)

Name	Bit Description	Row
132QE	Negative-sequence phase directional element enabled, Terminal ST	496
132QGE	Negative-sequence ground directional element enabled, Terminal ST	496
132VE	Zero-sequence voltage directional element enabled, Terminal ST	496
150GF	Zero-sequence current above forward threshold, Terminal ST	496
150GR	Zero-sequence current above reverse threshold, Terminal ST	496
150QF	Negative-sequence current above forward threshold, Terminal ST	496
150QR	Negative-sequence current above reverse threshold, Terminal ST	496
1F32G	Forward ground directional element asserted, Terminal ST	497
1F32P	Forward phase directional element asserted, Terminal ST	504
1F32Q	Forward negative-sequence phase directional element asserted, Terminal ST	504
1F32QG	Forward negative-sequence ground directional element asserted, Terminal ST	496
1F32V	Forward zero-sequence ground directional element asserted, Terminal ST	497
1R32G	Reverse ground directional element asserted, Terminal ST	497
1R32P	Reverse phase directional element asserted, Terminal ST	504
1R32Q	Reverse negative-sequence phase directional element asserted, Terminal ST	504
1R32QG	Reverse negative-sequence ground directional element asserted, Terminal ST	497
1R32V	Reverse zero-sequence ground directional element asserted, Terminal ST	497
232QE	Negative-sequence phase directional element enabled, Terminal TU	498
232QGE	Negative-sequence ground directional element enabled, Terminal TU	498
232VE	Zero-sequence voltage directional element enabled, Terminal TU	498
24D1	Volts-Per-Hertz Element Level 1 asserted	98
24D1T	Volts-Per-Hertz Level 1 timed out	98
24D2R	Volts-Per-Hertz Element Level 2 reset	98
24D2T	Volts-Per-Hertz Level 2 timed out	98
24TC	Volts-per-hertz predefined element, torque control	98
24U1R	User-Defined Volts-Per-Hertz Curve 1 reset	99
24U1T	User-Defined Volts-Per-Hertz Curve 1 timed out	99
24U1TC	User-Defined Volts-Per-Hertz Curve 1, torque control	99

Table 11.1 Alphabetical List of Relay Word Bits (Sheet 2 of 93)

Name	Bit Description	Row
24U2R	User-Defined Volts-Per-Hertz Curve 2 reset	99
24U2T	User-Defined Volts-Per-Hertz Curve 2 timed out	99
24U2TC	User-Defined Volts-Per-Hertz Curve 1, torque control	99
250GF	Zero-sequence current above forward threshold, Terminal TU	498
250GR	Zero-sequence current above reverse threshold, Terminal TU	498
250QF	Negative-sequence current above forward threshold, Terminal TU	498
250QR	Negative-sequence current above reverse threshold, Terminal TU	498
25A1BKS	Breaker S voltages within Sync Angle 1	576
25A1BKT	Breaker T voltages within Sync Angle 1	576
25A1BKU	Breaker U voltages within Sync Angle 1	576
25A1BKW	Breaker W voltages within Sync Angle 1	576
25A1BKX	Breaker X voltages within Sync Angle 1	576
25A1BKY	Breaker Y voltages within Sync Angle 1	576
25A1S	Breaker S voltage within Sync Angle 1 window uncompensated	574
25A1T	Breaker T voltage within Sync Angle 1 window uncompensated	574
25A1U	Breaker U voltage within Sync Angle 1 window uncompensated	574
25A1W	Breaker W voltage within Sync Angle 1 window uncompensated	574
25A1X	Breaker X voltage within Sync Angle 1 window uncompensated	575
25A1Y	Breaker Y voltage within Sync Angle 1 window uncompensated	575
25A2BKS	Breaker S voltages within Sync Angle 2	577
25A2BKT	Breaker T voltages within Sync Angle 2	577
25A2BKU	Breaker U voltages within Sync Angle 2	577
25A2BKW	Breaker W voltages within Sync Angle 2	577
25A2BKX	Breaker X voltages within Sync Angle 2	577
25A2BKY	Breaker Y voltages within Sync Angle 2	577
25A2S	Breaker S voltage within Sync Angle 2 window uncompensated	575
25A2T	Breaker T voltage within Sync Angle 2 window uncompensated	575
25A2U	Breaker U voltage within Sync Angle 2 window uncompensated	575
25A2W	Breaker W voltage within Sync Angle 2 window uncompensated	575
25A2X	Breaker X voltage within Sync Angle 2 window uncompensated	575
25A2Y	Breaker Y voltage within Sync Angle 2 window uncompensated	575
25C1S	Breaker S voltages within Sync Angle 1 window compensated	453
25C1T	Breaker T voltages within Sync Angle 1 window compensated	453
25C1U	Breaker U voltages within Sync Angle 1 window compensated	453
25C1W	Breaker W voltages within Sync Angle 1 window compensated	453
25C1X	Breaker X voltages within Sync Angle 1 window compensated	453
25C1Y	Breaker Y voltages within Sync Angle 1 window compensated	451
25C2S	Breaker S voltages within Sync Angle 2 window compensated	453
25C2T	Breaker T voltages within Sync Angle 2 window compensated	454
25C2U	Breaker U voltages within Sync Angle 2 window compensated	454
25C2W	Breaker W voltages within Sync Angle 2 window compensated	454

Table 11.1 Alphabetical List of Relay Word Bits (Sheet 3 of 93)

Name	Bit Description	Row
25C2X	Breaker X voltages within Sync Angle 2 window compensated	454
25C2Y	Breaker Y voltages within Sync Angle 2 window compensated	451
25ENBKS	Breaker S synchronism check enabled	456
25ENBKT	Breaker T synchronism check enabled	456
25ENBKU	Breaker U synchronism check enabled	456
25ENBKW	Breaker W synchronism check enabled	457
25ENBKX	Breaker X synchronism check enabled	457
25ENBKY	Breaker Y synchronism check enabled	448
25W1BKS	Breaker S voltages within Synchronism Angle 1 window uncompensated and unsupervised	578
25W1BKT	Breaker T voltages within Synchronism Angle 1 window uncompensated and unsupervised	578
25W1BKU	Breaker U voltages within Synchronism Angle 1 window uncompensated and unsupervised	578
25W1BKW	Breaker W voltages within Synchronism Angle 1 window uncompensated and unsupervised	578
25W1BKX	Breaker X voltages within Synchronism Angle 1 window uncompensated and unsupervised	578
25W1BKY	Breaker Y voltages within Synchronism Angle 1 window uncompensated and unsupervised	578
25W2BKS	Breaker S voltages within Synchronism Angle 2 window uncompensated and unsupervised	579
25W2BKT	Breaker T voltages within Synchronism Angle 2 window uncompensated and unsupervised	579
25W2BKU	Breaker U voltages within Synchronism Angle 2 window uncompensated and unsupervised	579
25W2BKW	Breaker W voltages within Synchronism Angle 2 window uncompensated and unsupervised	579
25W2BKX	Breaker X voltages within Synchronism Angle 2 window uncompensated and unsupervised	579
25W2BKY	Breaker Y voltages within Synchronism Angle 2 window uncompensated and unsupervised	579
25WC1S	Breaker S voltages within Sync Angle 1 window compensated and unsupervised	452
25WC1T	Breaker T voltages within Sync Angle 1 window compensated and unsupervised	452
25WC1U	Breaker U voltages within Sync Angle 1 window compensated and unsupervised	452
25WC1W	Breaker W voltages within Sync Angle 1 window compensated and unsupervised	452
25WC1X	Breaker X voltages within Sync Angle 1 window compensated and unsupervised	452
25WC1Y	Breaker Y voltages within Sync Angle 1 window compensated and unsupervised	450
25WC2S	Breaker S voltages within Sync Angle 2 window compensated and unsupervised	452
25WC2T	Breaker T voltages within Sync Angle 2 window compensated and unsupervised	452
25WC2U	Breaker U voltages within Sync Angle 2 window compensated and unsupervised	452
25WC2W	Breaker W voltages within Sync Angle 2 window compensated and unsupervised	453
25WC2X	Breaker X voltages within Sync Angle 2 window compensated and unsupervised	453
25WC2Y	Breaker Y voltages within Sync Angle 2 window compensated and unsupervised	450
271P1	Undervoltage Element 1, Level 1 asserted	78
271P1T	Undervoltage Element 1, Level 1 timed out	78
271P2	Undervoltage Element 1, Level 2 asserted	78
272P1	Undervoltage Element 2, Level 1 asserted	78
272P1T	Undervoltage Element 2, Level 1 timed out	78
272P2	Undervoltage Element 2, Level 2 asserted	78
273P1	Undervoltage Element 3, Level 1 asserted	79
273P1T	Undervoltage Element 3, Level 1 timed out	79
273P2	Undervoltage Element 3, Level 2 asserted	79

Table 11.1 Alphabetical List of Relay Word Bits (Sheet 4 of 93)

Name	Bit Description	Row
274P1	Undervoltage Element 4, Level 1 asserted	79
274P1T	Undervoltage Element 4, Level 1 timed out	79
274P2	Undervoltage Element 4, Level 2 asserted	79
275P1	Undervoltage Element 5, Level 1 asserted	80
275P1T	Undervoltage Element 5, Level 1 timed out	80
275P2	Undervoltage Element 5, Level 2 asserted	80
27B81	Frequency elements blocked because of undervoltage	97
27TC1	Undervoltage Element 1, torque control	78
27TC2	Undervoltage Element 2, torque control	78
27TC3	Undervoltage Element 3, torque control	79
27TC4	Undervoltage Element 4, torque control	79
27TC5	Undervoltage Element 5, torque control	80
2F32G	Forward ground directional element asserted, Terminal TU	499
2F32P	Forward phase directional element asserted, Terminal TU	505
2F32Q	Forward negative-sequence phase directional element asserted, Terminal TU	505
2F32QG	Forward negative-sequence ground directional element asserted, Terminal TU	498
2F32V	Forward zero-sequence ground directional element asserted, Terminal TU	499
2R32G	Reverse ground directional element asserted, Terminal TU	499
2R32P	Reverse phase directional element asserted, Terminal TU	505
2R32Q	Reverse negative-sequence phase directional element asserted, Terminal TU	505
2R32QG	Reverse negative-sequence phase directional element asserted, Terminal TU	499
2R32V	Reverse zero-sequence ground directional element asserted, Terminal TU	499
32OP01	Overpower Element 01 picked up	84
32OP02	Overpower Element 02 picked up	84
32OP03	Overpower Element 03 picked up	85
32OP04	Overpower Element 04 picked up	85
32OP05	Overpower Element 05 picked up	86
32OP06	Overpower Element 06 picked up	86
32OP07	Overpower Element 07 picked up	87
32OP08	Overpower Element 08 picked up	87
32OP09	Overpower Element 09 picked up	88
32OP10	Overpower Element 10 picked up	88
32OPT01	Overpower Element 01 timed out	84
32OPT02	Overpower Element 02 timed out	84
32OPT03	Overpower Element 03 timed out	85
32OPT04	Overpower Element 04 timed out	85
32OPT05	Overpower Element 05 timed out	86
32OPT06	Overpower Element 06 timed out	86
32OPT07	Overpower Element 07 timed out	87
32OPT08	Overpower Element 08 timed out	87
32OPT09	Overpower Element 09 timed out	88

Table 11.1 Alphabetical List of Relay Word Bits (Sheet 5 of 93)

Name	Bit Description	Row
32OPT10	Overpower Element 10 timed out	88
32UP01	Underpower Element 01 picked up	89
32UP02	Underpower Element 02 picked up	89
32UP03	Underpower Element 03 picked up	90
32UP04	Underpower Element 04 picked up	90
32UP05	Underpower Element 05 picked up	91
32UP06	Underpower Element 06 picked up	91
32UP07	Underpower Element 07 picked up	92
32UP08	Underpower Element 08 picked up	92
32UP09	Underpower Element 09 picked up	93
32UP10	Underpower Element 10 picked up	93
32UPT01	Underpower Element 01 timed out	89
32UPT02	Underpower Element 02 timed out	89
32UPT03	Underpower Element 03 timed out	90
32UPT04	Underpower Element 04 timed out	90
32UPT05	Underpower Element 05 timed out	91
32UPT06	Underpower Element 06 timed out	91
32UPT07	Underpower Element 07 timed out	92
32UPT08	Underpower Element 08 timed out	92
32UPT09	Underpower Element 09 timed out	93
32UPT10	Underpower Element 10 timed out	93
332QE	Negative-sequence phase directional element enabled, Terminal UW	500
332QGE	Negative-sequence ground directional element enabled, Terminal UW	500
332VE	Zero-sequence voltage directional element enabled, Terminal UW	500
350GF	Zero-sequence current above forward threshold, Terminal UW	500
350GR	Zero-sequence current above reverse threshold, Terminal UW	500
350QF	Negative-sequence current above forward threshold, Terminal UW	500
350QR	Negative-sequence current above reverse threshold, Terminal UW	500
3F32G	Forward ground directional element asserted, Terminal UW	501
3F32P	Forward phase directional element asserted, Terminal UW	506
3F32Q	Forward negative-sequence phase directional element asserted, Terminal UW	506
3F32QG	Forward negative-sequence ground directional element asserted, Terminal UW	500
3F32V	Forward zero-sequence ground directional element asserted, Terminal UW	501
3POBKS	Breaker S three-pole open	725
3POBKT	Breaker T three-pole open	728
3POBKU	Breaker U three-pole open	731
3POBKW	Breaker W three-pole open	734
3POBKX	Breaker X three-pole open	737
3POBKY	Breaker Y three-pole open	740
3R32G	Reverse ground directional element asserted, Terminal UW	501
3R32P	Reverse phase directional element asserted, Terminal UW	506

Table 11.1 Alphabetical List of Relay Word Bits (Sheet 6 of 93)

Name	Bit Description	Row
3R32Q	Reverse negative-sequence phase directional element asserted, Terminal UW	506
3R32QG	Reverse negative-sequence phase directional element asserted, Terminal UW	501
3R32V	Reverse zero-sequence ground directional element asserted, Terminal UW	501
432QE	Negative-sequence phase directional element enabled, Terminal WX	502
432QGE	Negative-sequence ground directional element enabled, Terminal WX	502
432VE	Zero-sequence voltage directional element enabled, Terminal WX	502
450GF	Zero-sequence current above forward threshold, Terminal WX	502
450GR	Zero-sequence current above reverse threshold, Terminal WX	502
450QF	Negative-sequence current above forward threshold, Terminal WX	502
450QR	Negative-sequence current above reverse threshold, Terminal WX	502
46SP	Current unbalance detected Terminal S	76
46ST	Current unbalance Terminal S timed out	76
46TP	Current unbalance detected Terminal T	76
46TT	Current unbalance Terminal T timed out	76
46UP	Current unbalance detected Terminal U	76
46UT	Current unbalance Terminal U timed out	76
46WP	Current unbalance detected Terminal W	76
46WT	Current unbalance Terminal W timed out	76
46XP	Current unbalance detected Terminal X	77
46XT	Current unbalance Terminal X timed out	77
46YP	Current unbalance detected Terminal Y	77
46YT	Current unbalance Terminal Y timed out	77
4F32G	Forward ground directional element asserted, Terminal WX	503
4F32P	Forward phase directional element asserted, Terminal WX	507
4F32Q	Forward negative-sequence phase directional element asserted, Terminal WX	507
4F32QG	Forward negative-sequence ground directional element asserted, Terminal WX	502
4F32V	Forward zero-sequence ground directional element asserted, Terminal WX	503
4R32G	Reverse ground directional element asserted, Terminal WX	503
4R32P	Reverse phase directional element asserted, Terminal WX	507
4R32Q	Reverse negative-sequence phase directional element asserted, Terminal WX	507
4R32QG	Reverse negative-sequence phase directional element asserted, Terminal WX	503
4R32V	Reverse zero-sequence ground directional element asserted, Terminal WX	503
501G1	Residual Definite-Time Element 1, Terminal ST asserted	512
501G2	Residual Definite-Time Element 2, Terminal ST asserted	512
501G3	Residual Definite-Time Element 3, Terminal ST asserted	513
501P1	Phase Definite-Time Element 1, Terminal ST asserted	508
501P2	Phase Definite-Time Element 2, Terminal ST asserted	508
501P3	Phase Definite-Time Element 3, Terminal ST asserted	509
501Q1	Negative-Sequence Definite-Time Element 1, Terminal ST asserted	510
501Q2	Negative-Sequence Definite-Time Element 2, Terminal ST asserted	510
501Q3	Negative-Sequence Definite-Time Element 3, Terminal ST asserted	511

Table 11.1 Alphabetical List of Relay Word Bits (Sheet 7 of 93)

Name	Bit Description	Row
502G1	Residual Definite-Time Element 1, Terminal TU asserted	518
502G2	Residual Definite-Time Element 2, Terminal TU asserted	518
502G3	Residual Definite-Time Element 3, Terminal TU asserted	519
502P1	Phase Definite-Time Element 1, Terminal TU asserted	514
502P2	Phase Definite-Time Element 2, Terminal TU asserted	514
502P3	Phase Definite-Time Element 3, Terminal TU asserted	515
502Q1	Negative-Sequence Definite-Time Element 1, Terminal TU asserted	516
502Q2	Negative-Sequence Definite-Time Element 2, Terminal TU asserted	516
502Q3	Negative-Sequence Definite-Time Element 3, Terminal TU asserted	517
503G1	Residual Definite-Time Element 1, Terminal UW asserted	524
503G2	Residual Definite-Time Element 2, Terminal UW asserted	524
503G3	Residual Definite-Time Element 3, Terminal UW asserted	525
503P1	Phase Definite-Time Element 1, Terminal UW asserted	520
503P2	Phase Definite-Time Element 2, Terminal UW asserted	520
503P3	Phase Definite-Time Element 3, Terminal UW asserted	521
503Q1	Negative-Sequence Definite-Time Element 1, Terminal UW asserted	522
503Q2	Negative-Sequence Definite-Time Element 2, Terminal UW asserted	522
503Q3	Negative-Sequence Definite-Time Element 3, Terminal UW asserted	523
504G1	Residual Definite-Time Element 1, Terminal WX asserted	530
504G2	Residual Definite-Time Element 2, Terminal WX asserted	530
504G3	Residual Definite-Time Element 3, Terminal WX asserted	531
504P1	Phase Definite-Time Element 1, Terminal WX asserted	526
504P2	Phase Definite-Time Element 2, Terminal WX asserted	526
504P3	Phase Definite-Time Element 3, Terminal WX asserted	527
504Q1	Negative-Sequence Definite-Time Element 1, Terminal WX asserted	528
504Q2	Negative-Sequence Definite-Time Element 2, Terminal WX asserted	528
504Q3	Negative-Sequence Definite-Time Element 3, Terminal WX asserted	529
50FS	Phase or neutral current above pickup, Terminal S	110
50FT	Phase or neutral current above pickup, Terminal T	112
50FU	Phase or neutral current above pickup, Terminal U	114
50FW	Phase or neutral current above pickup, Terminal W	116
50FX	Phase or neutral current above pickup, Terminal X	118
50FY	Phase or neutral current above pickup, Terminal Y	744
50SG1	Residual Definite-Time Element 1, Terminal S asserted	39
50SG2	Residual Definite-Time Element 2, Terminal S asserted	39
50SG3	Residual Definite-Time Element 3, Terminal S asserted	40
50SP1	Phase Definite-Time Element 1, Terminal S asserted	35
50SP2	Phase Definite-Time Element 2, Terminal S asserted	35
50SP3	Phase Definite-Time Element 3, Terminal S asserted	36
50SQ1	Negative-Sequence Definite-Time Element 1, Terminal S asserted	37
50SQ2	Negative-Sequence Definite-Time Element 2, Terminal S asserted	37

Table 11.1 Alphabetical List of Relay Word Bits (Sheet 8 of 93)

Name	Bit Description	Row
50SQ3	Negative-Sequence Definite-Time Element 3, Terminal S asserted	38
50TG1	Residual Definite-Time Element 1, Terminal T asserted	45
50TG2	Residual Definite-Time Element 2, Terminal T asserted	45
50TG3	Residual Definite-Time Element 3, Terminal T asserted	46
50TP1	Phase Definite-Time Element 1, Terminal T asserted	41
50TP2	Phase Definite-Time Element 2, Terminal T asserted	41
50TP3	Phase Definite-Time Element 3, Terminal T asserted	42
50TQ1	Negative-Sequence Definite-Time Element 1, Terminal T asserted	43
50TQ2	Negative-Sequence Definite-Time Element 2, Terminal T asserted	43
50TQ3	Negative-Sequence Definite-Time Element 3, Terminal T asserted	44
50UG1	Residual Definite-Time Element 1, Terminal U asserted	51
50UG2	Residual Definite-Time Element 2, Terminal U asserted	51
50UG3	Residual Definite-Time Element 3, Terminal U asserted	52
50UP1	Phase Definite-Time Element 1, Terminal U asserted	47
50UP2	Phase Definite-Time Element 2, Terminal U asserted	47
50UP3	Phase Definite-Time Element 3, Terminal U asserted	48
50UQ1	Negative-Sequence Definite-Time Element 1, Terminal U asserted	49
50UQ2	Negative-Sequence Definite-Time Element 2, Terminal U asserted	49
50UQ3	Negative-Sequence Definite-Time Element 3, Terminal U asserted	50
50WG1	Residual Definite-Time Element 1, Terminal W asserted	57
50WG2	Residual Definite-Time Element 2, Terminal W asserted	57
50WG3	Residual Definite-Time Element 3, Terminal W asserted	58
50WP1	Phase Definite-Time Element 1, Terminal W asserted	53
50WP2	Phase Definite-Time Element 2, Terminal W asserted	53
50WP3	Phase Definite-Time Element 3, Terminal W asserted	54
50WQ1	Negative-Sequence Definite-Time Element 1, Terminal W asserted	55
50WQ2	Negative-Sequence Definite-Time Element 2, Terminal W asserted	55
50WQ3	Negative-Sequence Definite-Time Element 3, Terminal W asserted	56
50XG1	Residual Definite-Time Element 1, Terminal X asserted	63
50XG2	Residual Definite-Time Element 2, Terminal X asserted	63
50XG3	Residual Definite-Time Element 3, Terminal X asserted	64
50XP1	Phase Definite-Time Element 1, Terminal X asserted	59
50XP2	Phase Definite-Time Element 2, Terminal X asserted	59
50XP3	Phase Definite-Time Element 3, Terminal X asserted	60
50XQ1	Negative-Sequence Definite-Time Element 1, Terminal X asserted	61
50XQ2	Negative-Sequence Definite-Time Element 2, Terminal X asserted	61
50XQ3	Negative-Sequence Definite-Time Element 3, Terminal X asserted	62
50YG1	Residual Definite-Time Element 1, Terminal Y asserted	691
50YG2	Residual Definite-Time Element 2, Terminal Y asserted	691
50YG3	Residual Definite-Time Element 3, Terminal Y asserted	692
50YP1	Phase Definite-Time Element 1, Terminal Y asserted	687

Table 11.1 Alphabetical List of Relay Word Bits (Sheet 9 of 93)

Name	Bit Description	Row
50YP2	Phase Definite-Time Element 2, Terminal Y asserted	687
50YP3	Phase Definite-Time Element 3, Terminal Y asserted	688
50YQ1	Negative-Sequence Definite-Time Element 1, Terminal Y asserted	689
50YQ2	Negative-Sequence Definite-Time Element 2, Terminal Y asserted	689
50YQ3	Negative-Sequence Definite-Time Element 3, Terminal Y asserted	690
51MM01	Inverse-Time Element 01 pickup setting outside of specified limits	65
51MM02	Inverse-Time Element 02 pickup setting outside of specified limits	66
51MM03	Inverse-Time Element 03 pickup setting outside of specified limits	67
51MM04	Inverse-Time Element 04 pickup setting outside of specified limits	68
51MM05	Inverse-Time Element 05 pickup setting outside of specified limits	69
51MM06	Inverse-Time Element 06 pickup setting outside of specified limits	70
51MM07	Inverse-Time Element 07 pickup setting outside of specified limits	71
51MM08	Inverse-Time Element 08 pickup setting outside of specified limits	72
51MM09	Inverse-Time Element 09 pickup setting outside of specified limits	73
51MM10	Inverse-Time Element 10 pickup setting outside of specified limits	74
51MM11	Inverse-Time Element 11 pickup setting outside of specified limits	696
51MM12	Inverse-Time Element 12 pickup setting outside of specified limits	697
51MM13	Inverse-Time Element 13 pickup setting outside of specified limits	698
51MM14	Inverse-Time Element 14 pickup setting outside of specified limits	699
51MM15	Inverse-Time Element 15 pickup setting outside of specified limits	700
51MM16	Inverse-Time Element 16 pickup setting outside of specified limits	701
51MM17	Inverse-Time Element 17 pickup setting outside of specified limits	702
51MM18	Inverse-Time Element 18 pickup setting outside of specified limits	703
51MM19	Inverse-Time Element 19 pickup setting outside of specified limits	704
51MM20	Inverse-Time Element 20 pickup setting outside of specified limits	705
51R01	Inverse-Time Element 01 reset	65
51R02	Inverse-Time Element 02 reset	66
51R03	Inverse-Time Element 03 reset	67
51R04	Inverse-Time Element 04 reset	68
51R05	Inverse-Time Element 05 reset	69
51R06	Inverse-Time Element 06 reset	70
51R07	Inverse-Time Element 07 reset	71
51R08	Inverse-Time Element 08 reset	72
51R09	Inverse-Time Element 09 reset	73
51R10	Inverse-Time Element 10 reset	74
51R11	Inverse-Time Element 11 reset	696
51R12	Inverse-Time Element 12 reset	697
51R13	Inverse-Time Element 13 reset	698
51R14	Inverse-Time Element 14 reset	699
51R15	Inverse-Time Element 15 reset	700
51R16	Inverse-Time Element 16 reset	701

Table 11.1 Alphabetical List of Relay Word Bits (Sheet 10 of 93)

Name	Bit Description	Row
51R17	Inverse-Time Element 17 reset	702
51R18	Inverse-Time Element 18 reset	703
51R19	Inverse-Time Element 19 reset	704
51R20	Inverse-Time Element 20 reset	705
51S01	Inverse-Time Element 01 picked up	65
51S02	Inverse-Time Element 02 picked up	66
51S03	Inverse-Time Element 03 picked up	67
51S04	Inverse-Time Element 04 picked up	68
51S05	Inverse-Time Element 05 picked up	69
51S06	Inverse-Time Element 06 picked up	70
51S07	Inverse-Time Element 07 picked up	71
51S08	Inverse-Time Element 08 picked up	72
51S09	Inverse-Time Element 09 picked up	73
51S10	Inverse-Time Element 10 picked up	74
51S11	Inverse-Time Element 11 picked up	696
51S12	Inverse-Time Element 12 picked up	697
51S13	Inverse-Time Element 13 picked up	698
51S14	Inverse-Time Element 14 picked up	699
51S15	Inverse-Time Element 15 picked up	700
51S16	Inverse-Time Element 16 picked up	701
51S17	Inverse-Time Element 17 picked up	702
51S18	Inverse-Time Element 18 picked up	703
51S19	Inverse-Time Element 19 picked up	704
51S20	Inverse-Time Element 20 picked up	705
51T01	Inverse-Time Element 01 timed out	65
51T02	Inverse-Time Element 02 timed out	66
51T03	Inverse-Time Element 03 timed out	67
51T04	Inverse-Time Element 04 timed out	68
51T05	Inverse-Time Element 05 timed out	69
51T06	Inverse-Time Element 06 timed out	70
51T07	Inverse-Time Element 07 timed out	71
51T08	Inverse-Time Element 08 timed out	72
51T09	Inverse-Time Element 09 timed out	73
51T10	Inverse-Time Element 10 timed out	74
51T11	Inverse-Time Element 11 timed out	696
51T12	Inverse-Time Element 12 timed out	697
51T13	Inverse-Time Element 13 timed out	698
51T14	Inverse-Time Element 14 timed out	699
51T15	Inverse-Time Element 15 timed out	700
51T16	Inverse-Time Element 16 timed out	701
51T17	Inverse-Time Element 17 timed out	702

Table 11.1 Alphabetical List of Relay Word Bits (Sheet 11 of 93)

Name	Bit Description	Row
51T18	Inverse-Time Element 18 timed out	703
51T19	Inverse-Time Element 19 timed out	704
51T20	Inverse-Time Element 20 timed out	705
51TC01	Inverse-Time Element 01 enabled	65
51TC02	Inverse-Time Element 02 enabled	66
51TC03	Inverse-Time Element 03 enabled	67
51TC04	Inverse-Time Element 04 enabled	68
51TC05	Inverse-Time Element 05 enabled	69
51TC06	Inverse-Time Element 06 enabled	70
51TC07	Inverse-Time Element 07 enabled	71
51TC08	Inverse-Time Element 08 enabled	72
51TC09	Inverse-Time Element 09 enabled	73
51TC10	Inverse-Time Element 10 enabled	74
51TC11	Inverse-Time Element 11 enabled	696
51TC12	Inverse-Time Element 12 enabled	697
51TC13	Inverse-Time Element 13 enabled	698
51TC14	Inverse-Time Element 14 enabled	699
51TC15	Inverse-Time Element 15 enabled	700
51TC16	Inverse-Time Element 16 enabled	701
51TC17	Inverse-Time Element 17 enabled	702
51TC18	Inverse-Time Element 18 enabled	703
51TC19	Inverse-Time Element 19 enabled	704
51TC20	Inverse-Time Element 20 enabled	705
51TM01	Inverse-Time Element 01 time-dial setting outside of specified limits	65
51TM02	Inverse-Time Element 02 time-dial setting outside of specified limits	66
51TM03	Inverse-Time Element 03 time-dial setting outside of specified limits	67
51TM04	Inverse-Time Element 04 time-dial setting outside of specified limits	68
51TM05	Inverse-Time Element 05 time-dial setting outside of specified limits	69
51TM06	Inverse-Time Element 06 time-dial setting outside of specified limits	70
51TM07	Inverse-Time Element 07 time-dial setting outside of specified limits	71
51TM08	Inverse-Time Element 08 time-dial setting outside of specified limits	72
51TM09	Inverse-Time Element 09 time-dial setting outside of specified limits	73
51TM10	Inverse-Time Element 10 time-dial setting outside of specified limits	74
51TM11	Inverse-Time Element 11 time-dial setting outside of specified limits	696
51TM12	Inverse-Time Element 12 time-dial setting outside of specified limits	697
51TM13	Inverse-Time Element 13 time-dial setting outside of specified limits	698
51TM14	Inverse-Time Element 14 time-dial setting outside of specified limits	699
51TM15	Inverse-Time Element 15 time-dial setting outside of specified limits	700
51TM16	Inverse-Time Element 16 time-dial setting outside of specified limits	701
51TM17	Inverse-Time Element 17 time-dial setting outside of specified limits	702
51TM18	Inverse-Time Element 18 time-dial setting outside of specified limits	703

Table 11.1 Alphabetical List of Relay Word Bits (Sheet 12 of 93)

Name	Bit Description	Row
51TM19	Inverse-Time Element 19 time-dial setting outside of specified limits	704
51TM20	Inverse-Time Element 20 time-dial setting outside of specified limits	705
52ALS	Breaker alarm, Terminal S	120
52ALT	Breaker alarm, Terminal T	120
52ALU	Breaker alarm, Terminal U	120
52ALW	Breaker alarm, Terminal W	120
52ALX	Breaker alarm, Terminal X	121
52ALY	Breaker alarm, Terminal Y	121
52CLS	Breaker closed, Terminal S	120
52CLT	Breaker closed, Terminal T	120
52CLU	Breaker closed, Terminal U	120
52CLW	Breaker closed, Terminal W	120
52CLX	Breaker closed, Terminal X	121
52CLY	Breaker closed, Terminal Y	121
52SRACK	Breaker S rack position	493
52STEST	Breaker S test position	493
52TRACK	Breaker T rack position	493
52TTEST	Breaker T test position	493
52URACK	Breaker U rack position	493
52UTEST	Breaker U test position	493
52WRACK	Breaker W rack position	493
52WTEST	Breaker W test position	494
52XRACK	Breaker X rack position	493
52XTEST	Breaker X test position	494
52YRACK	Breaker Y rack position	494
52YTEST	Breaker Y test position	494
591P1	Overvoltage Element 1, Level 1 asserted	81
591P1T	Overvoltage Element 1, Level 1 timed out	81
591P2	Overvoltage Element 1, Level 2 asserted	81
592P1	Overvoltage Element 2, Level 1 asserted	81
592P1T	Overvoltage Element 2, Level 1 timed out	81
592P2	Overvoltage Element 2, Level 2 asserted	81
593P1	Overvoltage Element 3, Level 1 asserted	82
593P1T	Overvoltage Element 3, Level 1 timed out	82
593P2	Overvoltage Element 3, Level 2 asserted	82
594P1	Overvoltage Element 4, Level 1 asserted	82
594P1T	Overvoltage Element 4, Level 1 timed out	82
594P2	Overvoltage Element 4, Level 2 asserted	82
595P1	Overvoltage Element 5, Level 1 asserted	83
595P1T	Overvoltage Element 5, Level 1 timed out	83
595P2	Overvoltage Element 5, Level 2 asserted	83

Table 11.1 Alphabetical List of Relay Word Bits (Sheet 13 of 93)

Name	Bit Description	Row
59TC1	Overvoltage Element 1, torque-control	81
59TC2	Overvoltage Element 2, torque-control	81
59TC3	Overvoltage Element 3, torque-control	82
59TC4	Overvoltage Element 4, torque-control	82
59TC5	Overvoltage Element 5, torque-control	83
59VDIFS	Breaker S synchronizing voltage difference less than limit	455
59VDIFT	Breaker T synchronizing voltage difference less than limit	455
59VDIFU	Breaker U synchronizing voltage difference less than limit	455
59VDIFW	Breaker W synchronizing voltage difference less than limit	455
59VDIFX	Breaker X synchronizing voltage difference less than limit	455
59VDIFY	Breaker Y synchronizing voltage difference less than limit	455
59VP	Polarizing voltage within healthy voltage window	572
59VPS	Breaker S polarizing voltage within healthy voltage window	572
59VPT	Breaker T polarizing voltage within healthy voltage window	572
59VPU	Breaker U polarizing voltage within healthy voltage window	572
59VPW	Breaker W polarizing voltage within healthy voltage window	572
59VPX	Breaker X polarizing voltage within healthy voltage window	572
59VPY	Breaker Y polarizing voltage within healthy voltage window	572
59VSS	Breaker S synchronizing voltage within healthy voltage window	457
59VST	Breaker T synchronizing voltage within healthy voltage window	457
59VSU	Breaker U synchronizing voltage within healthy voltage window	457
59VSW	Breaker W synchronizing voltage within healthy voltage window	457
59VSX	Breaker X synchronizing voltage within healthy voltage window	457
59VSY	Breaker Y synchronizing voltage within healthy voltage window	457
671G1	Residual Directional/Torque-Controlled Element 1, Terminal ST picked up	512
671G1T	Residual Directional/Torque-Controlled Element 1, Terminal ST timed out	512
671G1TC	Residual Directional/Torque-Control Enable Definite-Time Element 1, Terminal ST	512
671G2	Residual Directional/Torque-Controlled Element 2, Terminal ST picked up	512
671G2T	Residual Directional/Torque-Controlled Element 2, Terminal ST timed out	512
671G2TC	Residual Directional/Torque-Control Enable Definite-Time Element 2, Terminal ST	512
671G3	Residual Directional/Torque-Controlled Element 3, Terminal ST picked up	513
671G3T	Residual Directional/Torque-Controlled Element 3, Terminal ST timed out	513
671G3TC	Residual Directional/Torque-Control Enable Definite-Time Element 3, Terminal ST	513
671P1	Phase Directional/Torque-Controlled Element 1, Terminal ST picked up	508
671P1T	Phase Directional/Torque-Controlled Element 1, Terminal ST timed out	508
671P1TC	Phase Directional/Torque-Control Enable Definite-Time Element 1, Terminal ST	508
671P2	Phase Directional/Torque-Controlled Element 2, Terminal ST picked up	508
671P2T	Phase Directional/Torque-Controlled Element 2, Terminal ST timed out	508
671P2TC	Phase Directional/Torque-Control Enable Definite-Time Element 2, Terminal ST	508
671P3	Phase Directional/Torque-Controlled Element 3, Terminal ST picked up	509
671P3T	Phase Directional/Torque-Controlled Element 3, Terminal ST timed out	509

Table 11.1 Alphabetical List of Relay Word Bits (Sheet 14 of 93)

Name	Bit Description	Row
671P3TC	Phase Directional/Torque-Control Enable Definite-Time Element 3, Terminal ST	509
671Q1	Negative-Sequence Directional/Torque-Controlled Element 1, Terminal ST picked up	510
671Q1T	Negative-Sequence Directional/Torque-Controlled Element 1, Terminal ST timed out	510
671Q1TC	Negative-Sequence Directional/Torque-Control Enable Definite-Time Element 1, Terminal ST	510
671Q2	Negative-Sequence Directional/Torque-Controlled Element 2, Terminal ST picked up	510
671Q2T	Negative-Sequence Directional/Torque-Controlled Element 2, Terminal ST timed out	510
671Q2TC	Negative-Sequence Directional/Torque-Control Enable Definite-Time Element 2, Terminal ST	510
671Q3	Negative-Sequence Directional/Torque-Controlled Element 3, Terminal ST picked up	511
671Q3T	Negative-Sequence Directional/Torque-Controlled Element 3, Terminal ST timed out	511
671Q3TC	Negative-Sequence Directional/Torque-Control Enable Definite-Time Element 3, Terminal ST	511
672G1	Residual Directional/Torque-Controlled Element 1, Terminal TU picked up	518
672G1T	Residual Directional/Torque-Controlled Element 1, Terminal TU timed out	518
672G1TC	Residual Directional/Torque-Control Enable Definite-Time Element 1, Terminal TU	518
672G2	Residual Directional/Torque-Controlled Element 2, Terminal TU picked up	518
672G2T	Residual Directional/Torque-Controlled Element 2, Terminal TU timed out	518
672G2TC	Residual Directional/Torque-Control Enable Definite-Time Element 2, Terminal TU	518
672G3	Residual Directional/Torque-Controlled Element 3, Terminal TU picked up	519
672G3T	Residual Directional/Torque-Controlled Element 3, Terminal TU timed out	519
672G3TC	Residual Directional/Torque-Control Enable Definite-Time Element 3, Terminal TU	519
672P1	Phase Directional/Torque-Controlled Element 1, Terminal TU picked up	514
672P1T	Phase Directional/Torque-Controlled Element 1, Terminal TU timed out	514
672P1TC	Phase Directional/Torque-Control Enable Definite-Time Element 1, Terminal TU	514
672P2	Phase Directional/Torque-Controlled Element 2, Terminal TU picked up	514
672P2T	Phase Directional/Torque-Controlled Element 2, Terminal TU timed out	514
672P2TC	Phase Directional/Torque-Control Enable Definite-Time Element 2, Terminal TU	514
672P3	Phase Directional/Torque-Controlled Element 3, Terminal TU picked up	515
672P3T	Phase Directional/Torque-Controlled Element 3, Terminal TU timed out	515
672P3TC	Phase Directional/Torque-Control Enable Definite-Time Element 3, Terminal TU	515
672Q1	Negative-Sequence Directional/Torque-Controlled Element 1, Terminal TU picked up	516
672Q1T	Negative-Sequence Directional/Torque-Controlled Element 1, Terminal TU timed out	516
672Q1TC	Negative-Sequence Directional/Torque-Control Enable Definite-Time Element 1, Terminal TU	516
672Q2	Negative-Sequence Directional/Torque-Controlled Element 2, Terminal TU picked up	516
672Q2T	Negative-Sequence Directional/Torque-Controlled Element 2, Terminal TU timed out	516
672Q2TC	Negative-Sequence Directional/Torque-Control Enable Definite-Time Element 2, Terminal TU	516
672Q3	Negative-Sequence Directional/Torque-Controlled Element 3, Terminal TU picked up	517
672Q3T	Negative-Sequence Directional/Torque-Controlled Element 3, Terminal TU timed out	517
672Q3TC	Negative-Sequence Directional/Torque-Control Enable Definite-Time Element 3, Terminal TU	517
673G1	Residual Directional/Torque-Controlled Element 1, Terminal UW picked up	524
673G1T	Residual Directional/Torque-Controlled Element 1, Terminal UW timed out	524
673G1TC	Residual Directional/Torque-Control Enable Definite-Time Element 1, Terminal UW	524
673G2	Residual Directional/Torque-Controlled Element 2, Terminal UW picked up	524

Table 11.1 Alphabetical List of Relay Word Bits (Sheet 15 of 93)

Name	Bit Description	Row
673G2T	Residual Directional/Torque-Controlled Element 2, Terminal UW timed out	524
673G2TC	Residual Directional/Torque-Control Enable Definite-Time Element 2, Terminal UW	524
673G3	Residual Directional/Torque-Controlled Element 3, Terminal UW picked up	525
673G3T	Residual Directional/Torque-Controlled Element 3, Terminal UW timed out	525
673G3TC	Residual Directional/Torque-Control Enable Definite-Time Element 3, Terminal UW	525
673P1	Phase Directional/Torque-Controlled Element 1, Terminal UW picked up	520
673P1T	Phase Directional/Torque-Controlled Element 1, Terminal UW timed out	520
673P1TC	Phase Directional/Torque-Control Enable Definite-Time Element 1, Terminal UW	520
673P2	Phase Directional/Torque-Controlled Element 2, Terminal UW picked up	520
673P2T	Phase Directional/Torque-Controlled Element 2, Terminal UW timed out	520
673P2TC	Phase Directional/Torque-Control Enable Definite-Time Element 2, Terminal UW	520
673P3	Phase Directional/Torque-Controlled Element 3, Terminal UW picked up	521
673P3T	Phase Directional/Torque-Controlled Element 3, Terminal UW timed out	521
673P3TC	Phase Directional/Torque-Control Enable Definite-Time Element 3, Terminal UW	521
673Q1	Negative-Sequence Directional/Torque-Controlled Element 1, Terminal UW picked up	522
673Q1T	Negative-Sequence Directional/Torque-Controlled Element 1, Terminal UW timed out	522
673Q1TC	Negative-Sequence Directional/Torque-Control Enable Definite-Time Element 1, Terminal UW	522
673Q2	Negative-Sequence Directional/Torque-Controlled Element 2, Terminal UW picked up	522
673Q2T	Negative-Sequence Directional/Torque-Controlled Element 2, Terminal UW timed out	522
673Q2TC	Negative-Sequence Directional/Torque-Control Enable Definite-Time Element 2, Terminal UW	522
673Q3	Negative-Sequence Directional/Torque-Controlled Element 3, Terminal UW picked up	523
673Q3T	Negative-Sequence Directional/Torque-Controlled Element 3, Terminal UW timed out	523
673Q3TC	Negative-Sequence Directional/Torque-Control Enable Definite-Time Element 3, Terminal UW	523
674G1	Residual Directional/Torque-Controlled Element 1, Terminal WX picked up	530
674G1T	Residual Directional/Torque-Controlled Element 1, Terminal WX timed out	530
674G1TC	Residual Directional/Torque-Control Enable Definite-Time Element 1, Terminal WX	530
674G2	Residual Directional/Torque-Controlled Element 2, Terminal WX picked up	530
674G2T	Residual Directional/Torque-Controlled Element 2, Terminal WX timed out	530
674G2TC	Residual Directional/Torque-Control Enable Definite-Time Element 2, Terminal WX	530
674G3	Residual Directional/Torque-Controlled Element 3, Terminal WX picked up	531
674G3T	Residual Directional/Torque-Controlled Element 3, Terminal WX timed out	531
674G3TC	Residual Directional/Torque-Control Enable Definite-Time Element 3, Terminal WX	531
674P1	Phase Directional/Torque-Controlled Element 1, Terminal WX picked up	526
674P1T	Phase Directional/Torque-Controlled Element 1, Terminal WX timed out	526
674P1TC	Phase Directional/Torque-Control Enable Definite-Time Element 1, Terminal WX	526
674P2	Phase Directional/Torque-Controlled Element 2, Terminal WX picked up	526
674P2T	Phase Directional/Torque-Controlled Element 2, Terminal WX timed out	526
674P2TC	Phase Directional/Torque-Control Enable Definite-Time Element 2, Terminal WX	526
674P3	Phase Directional/Torque-Controlled Element 3, Terminal WX picked up	527
674P3T	Phase Directional/Torque-Controlled Element 3, Terminal WX timed out	527
674P3TC	Phase Directional/Torque-Control Enable Definite-Time Element 3, Terminal WX	527

Table 11.1 Alphabetical List of Relay Word Bits (Sheet 16 of 93)

Name	Bit Description	Row
674Q1	Negative-Sequence Directional/Torque-Controlled Element 1, Terminal WX picked up	528
674Q1T	Negative-Sequence Directional/Torque-Controlled Element 1, Terminal WX timed out	528
674Q1TC	Negative-Sequence Directional/Torque-Control Enable Definite-Time Element 1, Terminal WX	528
674Q2	Negative-Sequence Directional/Torque-Controlled Element 2, Terminal WX picked up	528
674Q2T	Negative-Sequence Directional/Torque-Controlled Element 2, Terminal WX timed out	528
674Q2TC	Negative-Sequence Directional/Torque-Control Enable Definite-Time Element 2, Terminal WX	528
674Q3	Negative-Sequence Directional/Torque-Controlled Element 3, Terminal WX picked up	529
674Q3T	Negative-Sequence Directional/Torque-Controlled Element 3, Terminal WX timed out	529
674Q3TC	Negative-Sequence Directional/Torque-Control Enable Definite-Time Element 3, Terminal WX	529
67QF1L1	Zone 1 forward OSB negative-sequence supervision, Line 1	638
67QF2L1	Zone 2 forward OSB negative-sequence supervision, Line 1	638
67QF3L1	Zone 3 forward OSB negative-sequence supervision, Line 1	638
67QF4L1	Zone 4 forward OSB negative-sequence supervision, Line 1	638
67QR1L1	Zone 1 reverse OSB negative-sequence supervision, Line 1	638
67QR2L1	Zone 2 reverse OSB negative-sequence supervision, Line 1	638
67QR3L1	Zone 3 reverse OSB negative-sequence supervision, Line 1	638
67QR4L1	Zone 4 reverse OSB negative-sequence supervision, Line 1	638
67SG1	Residual Directional/Torque-Controlled Element 1, Terminal S picked up	39
67SG1T	Residual Directional/Torque-Controlled Element 1, Terminal S timed out	39
67SG1TC	Residual Directional/Torque-Control Enable Definite-Time Element 1, Terminal S	39
67SG2	Residual Directional/Torque-Controlled Element 2, Terminal S picked up	39
67SG2T	Residual Directional/Torque-Controlled Element 2, Terminal S timed out	39
67SG2TC	Residual Directional/Torque-Control Enable Definite-Time Element 2, Terminal S	39
67SG3	Residual Directional/Torque-Controlled Element 3, Terminal S picked up	40
67SG3T	Residual Directional/Torque-Controlled Element 3, Terminal S timed out	40
67SG3TC	Residual Directional/Torque-Control Enable Definite-Time Element 3, Terminal S	40
67SP1	Phase Directional/Torque-Controlled Element 1, Terminal S picked up	35
67SP1T	Phase Directional/Torque-Controlled Element 1, Terminal S timed out	35
67SP1TC	Phase Directional/Torque-Control Enable Definite-Time Element 1, Terminal S	35
67SP2	Phase Directional/Torque-Controlled Element 2, Terminal S picked up	35
67SP2T	Phase Directional/Torque-Controlled Element 2, Terminal S timed out	35
67SP2TC	Phase Directional/Torque-Control Enable Definite-Time Element 2, Terminal S	35
67SP3	Phase Directional/Torque-Controlled Element 3, Terminal S picked up	36
67SP3T	Phase Directional/Torque-Controlled Element 3, Terminal S timed out	36
67SP3TC	Phase Directional/Torque-Control Enable Definite-Time Element 3, Terminal S	36
67SQ1	Negative-Sequence Directional/Torque-Controlled Element 1, Terminal S picked up	37
67SQ1T	Negative-Sequence Directional/Torque-Controlled Element 1, Terminal S timed out	37
67SQ1TC	Negative-Sequence Directional/Torque-Control Enable Definite-Time Element 1, Terminal S	37
67SQ2	Negative-Sequence Directional/Torque-Controlled Element 2, Terminal S picked up	37
67SQ2T	Negative-Sequence Directional/Torque-Controlled Element 2, Terminal S timed out	37
67SQ2TC	Negative-Sequence Directional/Torque-Control Enable Definite-Time Element 2, Terminal S	37

Table 11.1 Alphabetical List of Relay Word Bits (Sheet 17 of 93)

Name	Bit Description	Row
67SQ3	Negative-Sequence Directional/Torque-Controlled Element 3, Terminal S picked up	38
67SQ3T	Negative-Sequence Directional/Torque-Controlled Element 3, Terminal S timed out	38
67SQ3TC	Negative-Sequence Directional/Torque-Control Enable Definite-Time Element 3, Terminal S	38
67TG1	Residual Directional/Torque-Controlled Element 1, Terminal T picked up	45
67TG1T	Residual Directional/Torque-Controlled Element 1, Terminal T timed out	45
67TG1TC	Residual Directional/Torque-Control Enable Definite-Time Element 1, Terminal T	45
67TG2	Residual Directional/Torque-Controlled Element 2, Terminal T picked up	45
67TG2T	Residual Directional/Torque-Controlled Element 2, Terminal T timed out	45
67TG2TC	Residual Directional/Torque-Control Enable Definite-Time Element 2, Terminal T	45
67TG3	Residual Directional/Torque-Controlled Element 3, Terminal T picked up	46
67TG3T	Residual Directional/Torque-Controlled Element 3, Terminal T timed out	46
67TG3TC	Residual Directional/Torque-Control Enable Definite-Time Element 3, Terminal T	46
67TP1	Phase Directional/Torque-Controlled Element 1, Terminal T picked up	41
67TP1T	Phase Directional/Torque-Controlled Element 1, Terminal T timed out	41
67TP1TC	Phase Directional/Torque-Control Enable Definite-Time Element 1, Terminal T	41
67TP2	Phase Directional/Torque-Controlled Element 2, Terminal T picked up	41
67TP2T	Phase Directional/Torque-Controlled Element 2, Terminal T timed out	41
67TP2TC	Phase Directional/Torque-Control Enable Definite-Time Element 2, Terminal T	41
67TP3	Phase Directional/Torque-Controlled Element 3, Terminal T picked up	42
67TP3T	Phase Directional/Torque-Controlled Element 3, Terminal T timed out	42
67TP3TC	Phase Directional/Torque-Control Enable Definite-Time Element 3, Terminal T	42
67TQ1	Negative-Sequence Directional/Torque-Controlled Element 1, Terminal T picked up	43
67TQ1T	Negative-Sequence Directional/Torque-Controlled Element 1, Terminal T timed out	43
67TQ1TC	Negative-Sequence Directional/Torque-Control Enable Definite-Time Element 1, Terminal T	43
67TQ2	Negative-Sequence Directional/Torque-Controlled Element 2, Terminal T picked up	43
67TQ2T	Negative-Sequence Directional/Torque-Controlled Element 2, Terminal T timed out	43
67TQ2TC	Negative-Sequence Directional/Torque-Control Enable Definite-Time Element 2, Terminal T	43
67TQ3	Negative-Sequence Directional/Torque-Controlled Element 3, Terminal T picked up	44
67TQ3T	Negative-Sequence Directional/Torque-Controlled Element 3, Terminal T timed out	44
67TQ3TC	Negative-Sequence Directional/Torque-Control Enable Definite-Time Element 3, Terminal T	44
67UG1	Residual Directional/Torque-Controlled Element 1, Terminal U picked up	51
67UG1T	Residual Directional/Torque-Controlled Element 1, Terminal U timed out	51
67UG1TC	Residual Directional/Torque-Control Enable Definite-Time Element 1, Terminal U	51
67UG2	Residual Directional/Torque-Controlled Element 2, Terminal U picked up	51
67UG2T	Residual Directional/Torque-Controlled Element 2, Terminal U timed out	51
67UG2TC	Residual Directional/Torque-Control Enable Definite-Time Element 2, Terminal U	51
67UG3	Residual Directional/Torque-Controlled Element 3, Terminal U picked up	52
67UG3T	Residual Directional/Torque-Controlled Element 3, Terminal U timed out	52
67UG3TC	Residual Directional/Torque-Control Enable Definite-Time Element 3, Terminal U	52
67UP1	Phase Directional/Torque-Controlled Element 1, Terminal U picked up	47
67UP1T	Phase Directional/Torque-Controlled Element 1, Terminal U timed out	47

Table 11.1 Alphabetical List of Relay Word Bits (Sheet 18 of 93)

Name	Bit Description	Row
67UP1TC	Phase Directional/Torque-Control Enable Definite-Time Element 1, Terminal U	47
67UP2	Phase Directional/Torque-Controlled Element 2, Terminal U picked up	47
67UP2T	Phase Directional/Torque-Controlled Element 2, Terminal U timed out	47
67UP2TC	Phase Directional/Torque-Control Enable Definite-Time Element 2, Terminal U	47
67UP3	Phase Directional/Torque-Controlled Element 3, Terminal U picked up	48
67UP3T	Phase Directional/Torque-Controlled Element 3, Terminal U timed out	48
67UP3TC	Phase Directional/Torque-Control Enable Definite-Time Element 3, Terminal U	48
67UQ1	Negative-Sequence Directional/Torque-Controlled Element 1, Terminal U picked up	49
67UQ1T	Negative-Sequence Directional/Torque-Controlled Element 1, Terminal U timed out	49
67UQ1TC	Negative-Sequence Directional/Torque-Control Enable Definite-Time Element 1, Terminal U	49
67UQ2	Negative-Sequence Directional/Torque-Controlled Element 2, Terminal U picked up	49
67UQ2T	Negative-Sequence Directional/Torque-Controlled Element 2, Terminal U timed out	49
67UQ2TC	Negative-Sequence Directional/Torque-Control Enable Definite-Time Element 2, Terminal U	49
67UQ3	Negative-Sequence Directional/Torque-Controlled Element 3, Terminal U picked up	50
67UQ3T	Negative-Sequence Directional/Torque-Controlled Element 3, Terminal U timed out	50
67UQ3TC	Negative-Sequence Directional/Torque-Control Enable Definite-Time Element 3, Terminal U	50
67WG1	Residual Directional/Torque-Controlled Element 1, Terminal W picked up	57
67WG1T	Residual Directional/Torque-Controlled Element 1, Terminal W timed out	57
67WG1TC	Residual Directional/Torque-Control Enable Definite-Time Element 1, Terminal W	57
67WG2	Residual Directional/Torque-Controlled Element 2, Terminal W picked up	57
67WG2T	Residual Directional/Torque-Controlled Element 2, Terminal W timed out	57
67WG2TC	Residual Directional/Torque-Control Enable Definite-Time Element 2, Terminal W	57
67WG3	Residual Directional/Torque-Controlled Element 3, Terminal W picked up	58
67WG3T	Residual Directional/Torque-Controlled Element 3, Terminal W timed out	58
67WG3TC	Residual Directional/Torque-Control Enable Definite-Time Element 3, Terminal W	58
67WP1	Phase Directional/Torque-Controlled Element 1, Terminal W picked up	53
67WP1T	Phase Directional/Torque-Controlled Element 1, Terminal W timed out	53
67WP1TC	Phase Directional/Torque-Control Enable Definite-Time Element 1, Terminal W	53
67WP2	Phase Directional/Torque-Controlled Element 2, Terminal W picked up	53
67WP2T	Phase Directional/Torque-Controlled Element 2, Terminal W timed out	53
67WP2TC	Phase Directional/Torque-Control Enable Definite-Time Element 2, Terminal W	53
67WP3	Phase Directional/Torque-Controlled Element 3, Terminal W picked up	54
67WP3T	Phase Directional/Torque-Controlled Element 3, Terminal W timed out	54
67WP3TC	Phase Directional/Torque-Control Enable Definite-Time Element 3, Terminal W	54
67WQ1	Negative-Sequence Directional/Torque-Controlled Element 1, Terminal W picked up	55
67WQ1T	Negative-Sequence Directional/Torque-Controlled Element 1, Terminal W timed out	55
67WQ1TC	Negative-Sequence Directional/Torque-Control Enable Definite-Time Element 1, Terminal W	55
67WQ2	Negative-Sequence Directional/Torque-Controlled Element 2, Terminal W picked up	55
67WQ2T	Negative-Sequence Directional/Torque-Controlled Element 2, Terminal W timed out	55
67WQ2TC	Negative-Sequence Directional/Torque-Control Enable Definite-Time Element 2, Terminal W	55
67WQ3	Negative-Sequence Directional/Torque-Controlled Element 3, Terminal W picked up	56

Table 11.1 Alphabetical List of Relay Word Bits (Sheet 19 of 93)

Name	Bit Description	Row
67WQ3T	Negative-Sequence Directional/Torque-Controlled Element 3, Terminal W timed out	56
67WQ3TC	Negative-Sequence Directional/Torque-Control Enable Definite-Time Element 3, Terminal W	56
67XG1	Residual Directional/Torque-Controlled Element 1, Terminal X picked up	63
67XG1T	Residual Directional/Torque-Controlled Element 1, Terminal X timed out	63
67XG1TC	Residual Directional/Torque-Control Enable Definite-Time Element 1, Terminal X	63
67XG2	Residual Directional/Torque-Controlled Element 2, Terminal X picked up	63
67XG2T	Residual Directional/Torque-Controlled Element 2, Terminal X timed out	63
67XG2TC	Residual Directional/Torque-Control Enable Definite-Time Element 2, Terminal X	63
67XG3	Residual Directional/Torque-Controlled Element 3, Terminal X picked up	64
67XG3T	Residual Directional/Torque-Controlled Element 3, Terminal X timed out	64
67XG3TC	Residual Directional/Torque-Control Enable Definite-Time Element 3, Terminal X	64
67XP1	Phase Directional/Torque-Controlled Element 1, Terminal X picked up	59
67XP1T	Phase Directional/Torque-Controlled Element 1, Terminal X timed out	59
67XP1TC	Phase Directional/Torque-Control Enable Definite-Time Element 1, Terminal X	59
67XP2	Phase Directional/Torque-Controlled Element 2, Terminal X picked up	59
67XP2T	Phase Directional/Torque-Controlled Element 2, Terminal X timed out	59
67XP2TC	Phase Directional/Torque-Control Enable Definite-Time Element 2, Terminal X	59
67XP3	Phase Directional/Torque-Controlled Element 3, Terminal X picked up	60
67XP3T	Phase Directional/Torque-Controlled Element 3, Terminal X timed out	60
67XP3TC	Phase Directional/Torque-Control Enable Definite-Time Element 3, Terminal X	60
67XQ1	Negative-Sequence Directional/Torque-Controlled Element 1, Terminal X picked up	61
67XQ1T	Negative-Sequence Directional/Torque-Controlled Element 1, Terminal X timed out	61
67XQ1TC	Negative-Sequence Directional/Torque-Control Enable Definite-Time Element 1, Terminal X	61
67XQ2	Negative-Sequence Directional/Torque-Controlled Element 2, Terminal X picked up	61
67XQ2T	Negative-Sequence Directional/Torque-Controlled Element 2, Terminal X timed out	61
67XQ2TC	Negative-Sequence Directional/Torque-Control Enable Definite-Time Element 2, Terminal X	61
67XQ3	Negative-Sequence Directional/Torque-Controlled Element 3, Terminal X picked up	62
67XQ3T	Negative-Sequence Directional/Torque-Controlled Element 3, Terminal X timed out	62
67XQ3TC	Negative-Sequence Directional/Torque-Control Enable Definite-Time Element 3, Terminal X	62
67YG1	Residual Directional/Torque-Controlled Element 1, Terminal Y picked up	691
67YG1T	Residual Directional/Torque-Controlled Element 1, Terminal Y timed out	691
67YG1TC	Residual Directional/Torque-Control Enable Definite-Time Element 1, Terminal Y	691
67YG2	Residual Directional/Torque-Controlled Element 2, Terminal Y picked up	691
67YG2T	Residual Directional/Torque-Controlled Element 2, Terminal Y timed out	691
67YG2TC	Residual Directional/Torque-Control Enable Definite-Time Element 2, Terminal Y	691
67YG3	Residual Directional/Torque-Controlled Element 3, Terminal Y picked up	692
67YG3T	Residual Directional/Torque-Controlled Element 3, Terminal Y timed out	692
67YG3TC	Residual Directional/Torque-Control Enable Definite-Time Element 3, Terminal Y	692
67YP1	Phase Directional/Torque-Controlled Element 1, Terminal Y picked up	687
67YP1T	Phase Directional/Torque-Controlled Element 1, Terminal Y timed out	687
67YP1TC	Phase Directional/Torque-Control Enable Definite-Time Element 1, Terminal Y	687

Table 11.1 Alphabetical List of Relay Word Bits (Sheet 20 of 93)

Name	Bit Description	Row
67YP2	Phase Directional/Torque-Controlled Element 2, Terminal Y picked up	687
67YP2T	Phase Directional/Torque-Controlled Element 2, Terminal Y timed out	687
67YP2TC	Phase Directional/Torque-Control Enable Definite-Time Element 2, Terminal Y	687
67YP3	Phase Directional/Torque-Controlled Element 3, Terminal Y picked up	688
67YP3T	Phase Directional/Torque-Controlled Element 3, Terminal Y timed out	688
67YP3TC	Phase Directional/Torque-Control Enable Definite-Time Element 3, Terminal Y	688
67YQ1	Negative-Sequence Directional/Torque-Controlled Element 1, Terminal Y picked up	689
67YQ1T	Negative-Sequence Directional/Torque-Controlled Element 1, Terminal Y timed out	689
67YQ1TC	Negative-Sequence Directional/Torque-Control Enable Definite-Time Element 1, Terminal Y	689
67YQ2	Negative-Sequence Directional/Torque-Controlled Element 2, Terminal Y picked up	689
67YQ2T	Negative-Sequence Directional/Torque-Controlled Element 2, Terminal Y timed out	689
67YQ2TC	Negative-Sequence Directional/Torque-Control Enable Definite-Time Element 2, Terminal Y	689
67YQ3	Negative-Sequence Directional/Torque-Controlled Element 3, Terminal Y picked up	690
67YQ3T	Negative-Sequence Directional/Torque-Controlled Element 3, Terminal Y timed out	690
67YQ3TC	Negative-Sequence Directional/Torque-Control Enable Definite-Time Element 3, Terminal Y	690
79ARCS	Breaker S reclose initiate qualified	725
79ARCT	Breaker T reclose initiate qualified	728
79ARCU	Breaker U reclose initiate qualified	731
79ARCW	Breaker W reclose initiate qualified	734
79ARCX	Breaker X reclose initiate qualified	737
79ARCY	Breaker Y reclose initiate qualified	740
79CFTS	Breaker S close failure delay timed out	727
79CFTT	Breaker T close failure delay timed out	730
79CFTU	Breaker U close failure delay timed out	733
79CFTW	Breaker W close failure delay timed out	736
79CFTX	Breaker X close failure delay timed out	739
79CFTY	Breaker Y close failure delay timed out	742
79CLS	Breaker S supervised close command	743
79CLSS	Breaker S close supervision (SELOGIC control equation)	727
79CLSSS	Breaker S in close supervision state	727
79CLSST	Breaker T in close supervision state	730
79CLSSU	Breaker U in close supervision state	733
79CLSSW	Breaker W in close supervision state	736
79CLSSX	Breaker X in close supervision state	739
79CLSSY	Breaker Y in close supervision state	742
79CLST	Breaker T close supervision (SELOGIC control equation)	730
79CLSTS	Breaker S close supervision delay timed out	727
79CLSTT	Breaker T close supervision delay timed out	730
79CLSTU	Breaker U close supervision delay timed out	733
79CLSTW	Breaker W close supervision delay timed out	736
79CLSTX	Breaker X close supervision delay timed out	739

Table 11.1 Alphabetical List of Relay Word Bits (Sheet 21 of 93)

Name	Bit Description	Row
79CLSTY	Breaker Y close supervision delay timed out	742
79CLSU	Breaker U close supervision (SELOGIC control equation)	733
79CLSW	Breaker W close supervision (SELOGIC control equation)	736
79CLSX	Breaker X close supervision (SELOGIC control equation)	739
79CLSY	Breaker Y close supervision (SELOGIC control equation)	742
79CLT	Breaker T supervised close command	743
79CLU	Breaker U supervised close command	743
79CLW	Breaker W supervised close command	743
79CLX	Breaker X supervised close command	743
79CLY	Breaker Y supervised close command	743
79CYS	Breaker S in reclose cycle state	725
79CYT	Breaker T in reclose cycle state	728
79CYU	Breaker U in reclose cycle state	731
79CYW	Breaker W in reclose cycle state	734
79CYX	Breaker X in reclose cycle state	737
79CYY	Breaker Y in reclose cycle state	740
79LOS	Breaker S in reclose lockout state	725
79LOT	Breaker T in reclose lockout state	728
79LOU	Breaker U in reclose lockout state	731
79LOW	Breaker W in reclose lockout state	734
79LOX	Breaker X in reclose lockout state	737
79LOY	Breaker Y in reclose lockout state	740
79LSHTS	Breaker S reclose last shot	725
79LSHTT	Breaker T reclose last shot	728
79LSHTU	Breaker U reclose last shot	731
79LSHTW	Breaker W reclose last shot	734
79LSHTX	Breaker X reclose last shot	737
79LSHTY	Breaker Y reclose last shot	740
79OIS	Breaker S open interval timing	726
79OIT	Breaker T open interval timing	729
79OIU	Breaker U open interval timing	732
79OIW	Breaker W open interval timing	735
79OIX	Breaker X open interval timing	738
79OIY	Breaker Y open interval timing	741
79RCLPS	Breaker S reclaim in progress (lockout state)	727
79RCLPT	Breaker T reclaim in progress (lockout state)	730
79RCLPU	Breaker U reclaim in progress (lockout state)	733
79RCLPW	Breaker W reclaim in progress (lockout state)	736
79RCLPX	Breaker X reclaim in progress (lockout state)	739
79RCLPY	Breaker Y reclaim in progress (lockout state)	742
79RCPS	Breaker S reclaim in progress (cycle state)	727

Table 11.1 Alphabetical List of Relay Word Bits (Sheet 22 of 93)

Name	Bit Description	Row
79RCPT	Breaker T reclaim in progress (cycle state)	730
79RCPU	Breaker U reclaim in progress (cycle state)	733
79RCPW	Breaker W reclaim in progress (cycle state)	736
79RCPX	Breaker X reclaim in progress (cycle state)	739
79RCPY	Breaker Y reclaim in progress (cycle state)	742
79RIS	Breaker S reclose initiation (SELOGIC control equation)	725
79RIT	Breaker T reclose initiation (SELOGIC control equation)	728
79RIU	Breaker U reclose initiation (SELOGIC control equation)	731
79RIW	Breaker W reclose initiation (SELOGIC control equation)	734
79RIX	Breaker X reclose initiation (SELOGIC control equation)	737
79RIY	Breaker Y reclose initiation (SELOGIC control equation)	740
79RSS	Breaker S in reclose ready state	725
79RST	Breaker T in reclose ready state	728
79RSU	Breaker U in reclose ready state	731
79RSW	Breaker W in reclose ready state	734
79RSX	Breaker X in reclose ready state	737
79RSY	Breaker Y in reclose ready state	740
79SH0S	Breaker S shot counter = 0	726
79SH0T	Breaker T shot counter = 0	729
79SH0U	Breaker U shot counter = 0	732
79SH0W	Breaker W shot counter = 0	735
79SH0X	Breaker X shot counter = 0	738
79SH0Y	Breaker Y shot counter = 0	741
79SH1S	Breaker S shot counter = 1	726
79SH1T	Breaker T shot counter = 1	729
79SH1U	Breaker U shot counter = 1	732
79SH1W	Breaker W shot counter = 1	735
79SH1X	Breaker X shot counter = 1	738
79SH1Y	Breaker Y shot counter = 1	741
79SH2S	Breaker S shot counter = 2	726
79SH2T	Breaker T shot counter = 2	729
79SH2U	Breaker U shot counter = 2	732
79SH2W	Breaker W shot counter = 2	735
79SH2X	Breaker X shot counter = 2	738
79SH2Y	Breaker Y shot counter = 2	741
79SH3S	Breaker S shot counter = 3	726
79SH3T	Breaker T shot counter = 3	729
79SH3U	Breaker U shot counter = 3	732
79SH3W	Breaker W shot counter = 3	735
79SH3X	Breaker X shot counter = 3	738
79SH3Y	Breaker Y shot counter = 3	741

Table 11.1 Alphabetical List of Relay Word Bits (Sheet 23 of 93)

Name	Bit Description	Row
79SH4S	Breaker S shot counter = 4	726
79SH4T	Breaker T shot counter = 4	729
79SH4U	Breaker U shot counter = 4	732
79SH4W	Breaker W shot counter = 4	735
79SH4X	Breaker X shot counter = 4	738
79SH4Y	Breaker Y shot counter = 4	741
79STRTS	Breaker S in reclose start state	725
79STRTT	Breaker T in reclose start state	728
79STRTU	Breaker U in reclose start state	731
79STRTW	Breaker W in reclose start state	734
79STRTX	Breaker X in reclose start state	737
79STRTY	Breaker Y in reclose start state	740
81D1	Definite-time frequency element picked up, Level 1	94
81D1OVR	Definite-time overfrequency Level 1	94
81D1T	Definite-time over/underfrequency element delay for Level 1	94
81D1UDR	Definite-time underfrequency Level 1	94
81D2	Definite-time frequency element picked up, Level 2	94
81D2OVR	Definite-time overfrequency Level 2	94
81D2T	Definite-time over/underfrequency element delay for Level 2	94
81D2UDR	Definite-time underfrequency Level 2	94
81D3	Definite-time frequency element picked up, Level 3	95
81D3OVR	Definite-time overfrequency Level 3	95
81D3T	Definite-time over/underfrequency element delay for Level 3	95
81D3UDR	Definite-time underfrequency Level 3	95
81D4	Definite-time frequency element picked up, Level 4	95
81D4OVR	Definite-time overfrequency Level 4	95
81D4T	Definite-time over/underfrequency element delay for Level 4	95
81D4UDR	Definite-time underfrequency Level 4	95
81D5	Definite-time frequency element picked up, Level 5	96
81D5OVR	Definite-time overfrequency Level 5	96
81D5T	Definite-time over/underfrequency element delay for Level 5	96
81D5UDR	Definite-time underfrequency Level 5	96
81D6	Definite-time frequency element picked up, Level 6	96
81D6OVR	Definite-time overfrequency Level 6	96
81D6T	Definite-time over/underfrequency element delay for Level 6	96
81D6UDR	Definite-time underfrequency Level 6	96
87ABK2	Zone 1 second- and fourth-harmonic blocking asserted, A-Phase	11
87ABK5	Zone 1 fifth-harmonic blocking asserted, A-Phase	11
87AHB	Zone 1 harmonic-blocked phase-differential element asserted (no security timer), A-Phase	8
87AHR	Zone 1 harmonic-restrained phase-differential element asserted (no security timer), A-Phase	8
87BBK2	Zone 1 second- and fourth-harmonic blocking asserted, B-Phase	11

Table 11.1 Alphabetical List of Relay Word Bits (Sheet 24 of 93)

Name	Bit Description	Row
87BBK5	Zone 1 fifth-harmonic blocking asserted, B-Phase	11
87BHB	Zone 1 harmonic-blocked phase-differential element asserted (no security timer), B-Phase	8
87BHR	Zone 1 harmonic-restrained phase-differential element asserted (no security timer), B-Phase	8
87BK	Zone 1 differential element blocking bit (because of loss of Sampled Values [SV] data)	561
87BK2	Zone 2 differential element blocking bit (because of loss of Sampled Values [SV] data)	561
87BPH	Zone 1 high-set bipolar differential overcurrent condition asserted	464
87BPHA	Zone 1 high-set bipolar differential overcurrent condition asserted, A-Phase	464
87BPHB	Zone 1 high-set bipolar differential overcurrent condition asserted, B-Phase	464
87BPHC	Zone 1 high-set bipolar differential overcurrent condition asserted, C-Phase	464
87BPL	Zone 1 low-set bipolar differential overcurrent condition asserted	464
87BPLA	Zone 1 low-set bipolar differential overcurrent condition asserted, A-Phase	464
87BPLB	Zone 1 low-set bipolar differential overcurrent condition asserted, B-Phase	464
87BPLC	Zone 1 low-set bipolar differential overcurrent condition asserted, C-Phase	464
87CBK2	Zone 1 second- and fourth-harmonic blocking asserted, C-Phase	11
87CBK5	Zone 1 fifth-harmonic blocking asserted, C-Phase	11
87CHB	Zone 1 harmonic-blocked phase-differential element asserted (no security timer), C-Phase	8
87CHR	Zone 1 harmonic-restrained phase-differential element asserted (no security timer), C-Phase	8
87HBPA	Zone 1 minimum pickup and slope conditions satisfied for harmonic-blocked phase differential, A-Phase	465
87HBPB	Zone 1 minimum pickup and slope conditions satisfied for harmonic-blocked phase differential, B-Phase	465
87HBPC	Zone 1 minimum pickup and slope conditions satisfied for harmonic-blocked phase differential, C-Phase	465
87HRPA	Zone 1 minimum pickup and slope conditions satisfied for harmonic-restrained phase differential, A-Phase	465
87HRPB	Zone 1 minimum pickup and slope conditions satisfied for harmonic-restrained phase differential, B-Phase	465
87HRPC	Zone 1 minimum pickup and slope conditions satisfied for harmonic-restrained phase differential, C-Phase	465
87PQ	Zone 1 minimum pickup and slope conditions satisfied for negative-sequence differential element	13
87Q	Zone 1 negative-sequence differential element operated	13
87QB	Zone 1 block negative-sequence differential element	11
87R	Zone 1 phase percentage-restrained differential element operated	10
87R2	Zone 2 phase percentage-restrained differential element operated	710
87RA	Zone 1 phase percentage-restrained differential element operated, A-Phase	10
87RA2	Zone 2 phase percentage-restrained differential element operated, A-Phase	710
87RB	Zone 1 phase percentage-restrained differential element operated, B-Phase	10
87RB2	Zone 2 phase percentage-restrained differential element operated, B-Phase	710
87RC	Zone 1 phase percentage-restrained differential element operated, C-Phase	10
87RC2	Zone 2 phase percentage-restrained differential element operated, C-Phase	710
87T	Zone 1 transformer differential element operated (87R OR 87Q OR 87U)	465
87T_B1A	Zone 1 bipolar low-set signature detected in operate current, A-Phase	7
87T_B1B	Zone 1 bipolar low-set signature detected in operate current, B-Phase	7
87T_B1C	Zone 1 bipolar low-set signature detected in operate current, C-Phase	7
87T_B2A	Zone 1 bipolar high-set signature detected in operate current, A-Phase	12
87T_B2B	Zone 1 bipolar high-set signature detected in operate current, B-Phase	12
87T_B2C	Zone 1 bipolar high-set signature detected in operate current, C-Phase	12

Table 11.1 Alphabetical List of Relay Word Bits (Sheet 25 of 93)

Name	Bit Description	Row
87T_BP1	Zone 1 bipolar low-set signature detected	6
87T_BP2	Zone 1 bipolar high-set signature detected	6
87T_M	Zone 1 sufficient differential current to enable three-legged transformer waveshape logic	10
87T_MA	Zone 1 sufficient differential current to enable non-three-legged transformer waveshape logic, A-Phase	75
87T_MB	Zone 1 sufficient differential current to enable non-three-legged transformer waveshape logic, B-Phase	75
87T_MC	Zone 1 sufficient differential current to enable non-three-legged transformer waveshape logic, C-Phase	75
87T_S	Zone 1 dwell periods identified in differential current, non-three-legged transformer	5
87T_SA	Zone 1 dwell periods identified in differential current, non-three-legged transformer, A-Phase	5
87T_SB	Zone 1 dwell periods identified in differential current, non-three-legged transformer, B-Phase	5
87T_SC	Zone 1 dwell periods identified in differential current, non-three-legged transformer, C-Phase	5
87T_SF	Zone 1 magnetizing inrush current detected by waveshape logic (three-legged transformer)	9
87T_SFA	Zone 1 magnetizing inrush current detected by waveshape logic, A-Phase (non-three-legged transformer)	9
87T_SFB	Zone 1 magnetizing inrush current detected by waveshape logic, B-Phase (non-three-legged transformer)	9
87T_SFC	Zone 1 magnetizing inrush current detected by waveshape logic, C-Phase (non-three-legged transformer)	9
87U	Zone 1 unrestrained differential element operated	9
87UA	Zone 1 unrestrained differential overcurrent element operated, A-Phase	9
87UB	Zone 1 unrestrained differential overcurrent element operated, B-Phase	9
87UC	Zone 1 unrestrained differential overcurrent element operated, C-Phase	9
87UFA	Zone 1 unrestrained differential element operated from filtered current, A-Phase	466
87UFB	Zone 1 unrestrained differential element operated from filtered current, B-Phase	466
87UFC	Zone 1 unrestrained differential element operated from filtered current, C-Phase	466
87UNBL	Zone 1 waveshape-based inrush unblocking condition asserted	467
87UNBLA	Zone 1 waveshape-based inrush unblocking condition asserted, A-Phase	467
87UNBLB	Zone 1 waveshape-based inrush unblocking condition asserted, B-Phase	467
87UNBLC	Zone 1 waveshape-based inrush unblocking condition asserted, C-Phase	467
87URA	Zone 1 unrestrained differential element operated from raw current, A-Phase	466
87URB	Zone 1 unrestrained differential element operated from raw current, B-Phase	466
87URC	Zone 1 unrestrained differential element operated from raw current, C-Phase	466
87WB	Zone 1 magnetizing inrush current detected by waveshape logic	467
87WBA	Zone 1 magnetizing inrush current detected by waveshape logic, A-Phase	467
87WBB	Zone 1 magnetizing inrush current detected by waveshape logic, B-Phase	467
87WBC	Zone 1 magnetizing inrush current detected by waveshape logic, C-Phase	467
87WS	Zone 1 waveshape-based differential element operated (87R OR 87U)	7
87XBK2	Zone 1 second- and fourth-harmonic cross blocking asserted	11
87XBK5	Zone 1 fifth-harmonic cross blocking asserted	8
89AL	Any disconnect alarm	127
89AL01	Disconnect 1 alarm	132
89AL02	Disconnect 2 alarm	132
89AL03	Disconnect 3 alarm	132
89AL04	Disconnect 4 alarm	132
89AL05	Disconnect 5 alarm	132

Table 11.1 Alphabetical List of Relay Word Bits (Sheet 26 of 93)

Name	Bit Description	Row
89AL06	Disconnect 6 alarm	132
89AL07	Disconnect 7 alarm	132
89AL08	Disconnect 8 alarm	132
89AL09	Disconnect 9 alarm	133
89AL10	Disconnect 10 alarm	133
89AL11	Disconnect 11 alarm	133
89AL12	Disconnect 12 alarm	133
89AL13	Disconnect 13 alarm	133
89AL14	Disconnect 14 alarm	133
89AL15	Disconnect 15 alarm	133
89AL16	Disconnect 16 alarm	133
89AL17	Disconnect 17 alarm	134
89AL18	Disconnect 18 alarm	134
89AL19	Disconnect 19 alarm	134
89AL20	Disconnect 20 alarm	134
89AM01	Disconnect 1 N/O auxiliary contact	124
89AM02	Disconnect 2 N/O auxiliary contact	124
89AM03	Disconnect 3 N/O auxiliary contact	124
89AM04	Disconnect 4 N/O auxiliary contact	124
89AM05	Disconnect 5 N/O auxiliary contact	124
89AM06	Disconnect 6 N/O auxiliary contact	124
89AM07	Disconnect 7 N/O auxiliary contact	124
89AM08	Disconnect 8 N/O auxiliary contact	124
89AM09	Disconnect 9 N/O auxiliary contact	125
89AM10	Disconnect 10 N/O auxiliary contact	125
89AM11	Disconnect 11 N/O auxiliary contact	125
89AM12	Disconnect 12 N/O auxiliary contact	125
89AM13	Disconnect 13 N/O auxiliary contact	125
89AM14	Disconnect 14 N/O auxiliary contact	125
89AM15	Disconnect 15 N/O auxiliary contact	125
89AM16	Disconnect 16 N/O auxiliary contact	125
89AM17	Disconnect 17 N/O auxiliary contact	126
89AM18	Disconnect 18 N/O auxiliary contact	126
89AM19	Disconnect 19 N/O auxiliary contact	126
89AM20	Disconnect 20 N/O auxiliary contact	126
89BM01	Disconnect 1 N/C auxiliary contact	128
89BM02	Disconnect 2 N/C auxiliary contact	128
89BM03	Disconnect 3 N/C auxiliary contact	128
89BM04	Disconnect 4 N/C auxiliary contact	128
89BM05	Disconnect 5 N/C auxiliary contact	128
89BM06	Disconnect 6 N/C auxiliary contact	128

Table 11.1 Alphabetical List of Relay Word Bits (Sheet 27 of 93)

Name	Bit Description	Row
89BM07	Disconnect 7 N/C auxiliary contact	128
89BM08	Disconnect 8 N/C auxiliary contact	128
89BM09	Disconnect 9 N/C auxiliary contact	129
89BM10	Disconnect 10 N/C auxiliary contact	129
89BM11	Disconnect 11 N/C auxiliary contact	129
89BM12	Disconnect 12 N/C auxiliary contact	129
89BM13	Disconnect 13 N/C auxiliary contact	129
89BM14	Disconnect 14 N/C auxiliary contact	129
89BM15	Disconnect 15 N/C auxiliary contact	129
89BM16	Disconnect 16 N/C auxiliary contact	129
89BM17	Disconnect 17 N/C auxiliary contact	130
89BM18	Disconnect 18 N/C auxiliary contact	130
89BM19	Disconnect 19 N/C auxiliary contact	130
89BM20	Disconnect 20 N/C auxiliary contact	130
89CBL01	Disconnect 01 close block	668
89CBL02	Disconnect 02 close block	668
89CBL03	Disconnect 03 close block	668
89CBL04	Disconnect 04 close block	668
89CBL05	Disconnect 05 close block	668
89CBL06	Disconnect 06 close block	668
89CBL07	Disconnect 07 close block	668
89CBL08	Disconnect 08 close block	668
89CBL09	Disconnect 09 close block	669
89CBL10	Disconnect 10 close block	669
89CBL11	Disconnect 11 close block	669
89CBL12	Disconnect 12 close block	669
89CBL13	Disconnect 13 close block	669
89CBL14	Disconnect 14 close block	669
89CBL15	Disconnect 15 close block	669
89CBL16	Disconnect 16 close block	669
89CBL17	Disconnect 17 close block	670
89CBL18	Disconnect 18 close block	670
89CBL19	Disconnect 19 close block	670
89CBL20	Disconnect 20 close block	670
89CC01	ASCII Close Disconnect 1 command	168
89CC02	ASCII Close Disconnect 2 command	168
89CC03	ASCII Close Disconnect 3 command	168
89CC04	ASCII Close Disconnect 4 command	168
89CC05	ASCII Close Disconnect 5 command	168
89CC06	ASCII Close Disconnect 6 command	168
89CC07	ASCII Close Disconnect 7 command	168

Table 11.1 Alphabetical List of Relay Word Bits (Sheet 28 of 93)

Name	Bit Description	Row
89CC08	ASCII Close Disconnect 8 command	168
89CC09	ASCII Close Disconnect 9 command	169
89CC10	ASCII Close Disconnect 10 command	169
89CC11	ASCII Close Disconnect 11 command	169
89CC12	ASCII Close Disconnect 12 command	169
89CC13	ASCII Close Disconnect 13 command	169
89CC14	ASCII Close Disconnect 14 command	169
89CC15	ASCII Close Disconnect 15 command	169
89CC16	ASCII Close Disconnect 16 command	169
89CC17	ASCII Close Disconnect 17 command	170
89CC18	ASCII Close Disconnect 18 command	170
89CC19	ASCII Close Disconnect 19 command	170
89CC20	ASCII Close Disconnect 20 command	170
89CCM01	Mimic Disconnect 1 close control	164
89CCM02	Mimic Disconnect 2 close control	164
89CCM03	Mimic Disconnect 3 close control	164
89CCM04	Mimic Disconnect 4 close control	164
89CCM05	Mimic Disconnect 5 close control	164
89CCM06	Mimic Disconnect 6 close control	164
89CCM07	Mimic Disconnect 7 close control	164
89CCM08	Mimic Disconnect 8 close control	164
89CCM09	Mimic Disconnect 9 close control	165
89CCM10	Mimic Disconnect 10 close control	165
89CCM11	Mimic Disconnect 11 close control	165
89CCM12	Mimic Disconnect 12 close control	165
89CCM13	Mimic Disconnect 13 close control	165
89CCM14	Mimic Disconnect 14 close control	165
89CCM15	Mimic Disconnect 15 close control	165
89CCM16	Mimic Disconnect 16 close control	165
89CCM17	Mimic Disconnect 17 close control	166
89CCM18	Mimic Disconnect 18 close control	166
89CCM19	Mimic Disconnect 19 close control	166
89CCM20	Mimic Disconnect 20 close control	166
89CCN01	Close Disconnect 1	176
89CCN02	Close Disconnect 2	176
89CCN03	Close Disconnect 3	176
89CCN04	Close Disconnect 4	176
89CCN05	Close Disconnect 5	176
89CCN06	Close Disconnect 6	176
89CCN07	Close Disconnect 7	176
89CCN08	Close Disconnect 8	176

Table 11.1 Alphabetical List of Relay Word Bits (Sheet 29 of 93)

Name	Bit Description	Row
89CCN09	Close Disconnect 9	177
89CCN10	Close Disconnect 10	177
89CCN11	Close Disconnect 11	177
89CCN12	Close Disconnect 12	177
89CCN13	Close Disconnect 13	177
89CCN14	Close Disconnect 14	177
89CCN15	Close Disconnect 15	177
89CCN16	Close Disconnect 16	177
89CCN17	Close Disconnect 17	178
89CCN18	Close Disconnect 18	178
89CCN19	Close Disconnect 19	178
89CCN20	Close Disconnect 20	178
89CIM01	Disconnect 01 close immobility timer timed out	656
89CIM02	Disconnect 02 close immobility timer timed out	656
89CIM03	Disconnect 03 close immobility timer timed out	656
89CIM04	Disconnect 04 close immobility timer timed out	656
89CIM05	Disconnect 05 close immobility timer timed out	656
89CIM06	Disconnect 06 close immobility timer timed out	656
89CIM07	Disconnect 07 close immobility timer timed out	656
89CIM08	Disconnect 08 close immobility timer timed out	656
89CIM09	Disconnect 09 close immobility timer timed out	657
89CIM10	Disconnect 10 close immobility timer timed out	657
89CIM11	Disconnect 11 close immobility timer timed out	657
89CIM12	Disconnect 12 close immobility timer timed out	657
89CIM13	Disconnect 13 close immobility timer timed out	657
89CIM14	Disconnect 14 close immobility timer timed out	657
89CIM15	Disconnect 15 close immobility timer timed out	657
89CIM16	Disconnect 16 close immobility timer timed out	657
89CIM17	Disconnect 17 close immobility timer timed out	658
89CIM18	Disconnect 18 close immobility timer timed out	658
89CIM19	Disconnect 19 close immobility timer timed out	658
89CIM20	Disconnect 20 close immobility timer timed out	658
89CIR01	Disconnect 01 close immobility timer reset	672
89CIR02	Disconnect 02 close immobility timer reset	672
89CIR03	Disconnect 03 close immobility timer reset	672
89CIR04	Disconnect 04 close immobility timer reset	672
89CIR05	Disconnect 05 close immobility timer reset	672
89CIR06	Disconnect 06 close immobility timer reset	672
89CIR07	Disconnect 07 close immobility timer reset	672
89CIR08	Disconnect 08 close immobility timer reset	672
89CIR09	Disconnect 09 close immobility timer reset	673

Table 11.1 Alphabetical List of Relay Word Bits (Sheet 30 of 93)

Name	Bit Description	Row
89CIR10	Disconnect 10 close immobility timer reset	673
89CIR11	Disconnect 11 close immobility timer reset	673
89CIR12	Disconnect 12 close immobility timer reset	673
89CIR13	Disconnect 13 close immobility timer reset	673
89CIR14	Disconnect 14 close immobility timer reset	673
89CIR15	Disconnect 15 close immobility timer reset	673
89CIR16	Disconnect 16 close immobility timer reset	673
89CIR17	Disconnect 17 close immobility timer reset	674
89CIR18	Disconnect 18 close immobility timer reset	674
89CIR19	Disconnect 19 close immobility timer reset	674
89CIR20	Disconnect 20 close immobility timer reset	674
89CL01	Disconnect 1 closed	144
89CL02	Disconnect 2 closed	144
89CL03	Disconnect 3 closed	144
89CL04	Disconnect 4 closed	144
89CL05	Disconnect 5 closed	144
89CL06	Disconnect 6 closed	144
89CL07	Disconnect 7 closed	144
89CL08	Disconnect 8 closed	144
89CL09	Disconnect 9 closed	145
89CL10	Disconnect 10 closed	145
89CL11	Disconnect 11 closed	145
89CL12	Disconnect 12 closed	145
89CL13	Disconnect 13 closed	145
89CL14	Disconnect 14 closed	145
89CL15	Disconnect 15 closed	145
89CL16	Disconnect 16 closed	145
89CL17	Disconnect 17 closed	146
89CL18	Disconnect 18 closed	146
89CL19	Disconnect 19 closed	146
89CL20	Disconnect 20 closed	146
89CLB01	Disconnect 1 bus-zone protection	152
89CLB02	Disconnect 2 bus-zone protection	152
89CLB03	Disconnect 3 bus-zone protection	152
89CLB04	Disconnect 4 bus-zone protection	152
89CLB05	Disconnect 5 bus-zone protection	152
89CLB06	Disconnect 6 bus-zone protection	152
89CLB07	Disconnect 7 bus-zone protection	152
89CLB08	Disconnect 8 bus-zone protection	152
89CLB09	Disconnect 9 bus-zone protection	153
89CLB10	Disconnect 10 bus-zone protection	153

Table 11.1 Alphabetical List of Relay Word Bits (Sheet 31 of 93)

Name	Bit Description	Row
89CLB11	Disconnect 11 bus-zone protection	153
89CLB12	Disconnect 12 bus-zone protection	153
89CLB13	Disconnect 13 bus-zone protection	153
89CLB14	Disconnect 14 bus-zone protection	153
89CLB15	Disconnect 15 bus-zone protection	153
89CLB16	Disconnect 16 bus-zone protection	153
89CLB17	Disconnect 17 bus-zone protection	154
89CLB18	Disconnect 18 bus-zone protection	154
89CLB19	Disconnect 19 bus-zone protection	154
89CLB20	Disconnect 20 bus-zone protection	154
89CLS01	Disconnect Close 1 output	156
89CLS02	Disconnect Close 2 output	156
89CLS03	Disconnect Close 3 output	156
89CLS04	Disconnect Close 4 output	156
89CLS05	Disconnect Close 5 output	156
89CLS06	Disconnect Close 6 output	156
89CLS07	Disconnect Close 7 output	156
89CLS08	Disconnect Close 8 output	156
89CLS09	Disconnect Close 9 output	157
89CLS10	Disconnect Close 10 output	157
89CLS11	Disconnect Close 11 output	157
89CLS12	Disconnect Close 12 output	157
89CLS13	Disconnect Close 13 output	157
89CLS14	Disconnect Close 14 output	157
89CLS15	Disconnect Close 15 output	157
89CLS16	Disconnect Close 16 output	157
89CLS17	Disconnect Close 17 output	158
89CLS18	Disconnect Close 18 output	158
89CLS19	Disconnect Close 19 output	158
89CLS20	Disconnect Close 20 output	158
89CRS01	Disconnect 01 close reset	188
89CRS02	Disconnect 02 close reset	188
89CRS03	Disconnect 03 close reset	188
89CRS04	Disconnect 04 close reset	188
89CRS05	Disconnect 05 close reset	188
89CRS06	Disconnect 06 close reset	188
89CRS07	Disconnect 07 close reset	188
89CRS08	Disconnect 08 close reset	188
89CRS09	Disconnect 09 close reset	189
89CRS10	Disconnect 10 close reset	189
89CRS11	Disconnect 11 close reset	189

Table 11.1 Alphabetical List of Relay Word Bits (Sheet 32 of 93)

Name	Bit Description	Row
89CRS12	Disconnect 12 close reset	189
89CRS13	Disconnect 13 close reset	189
89CRS14	Disconnect 14 close reset	189
89CRS15	Disconnect 15 close reset	189
89CRS16	Disconnect 16 close reset	189
89CRS17	Disconnect 17 close reset	190
89CRS18	Disconnect 18 close reset	190
89CRS19	Disconnect 19 close reset	190
89CRS20	Disconnect 20 close reset	190
89CSI01	Disconnect 01 close seal-in timer timed out	680
89CSI02	Disconnect 02 close seal-in timer timed out	680
89CSI03	Disconnect 03 close seal-in timer timed out	680
89CSI04	Disconnect 04 close seal-in timer timed out	680
89CSI05	Disconnect 05 close seal-in timer timed out	680
89CSI06	Disconnect 06 close seal-in timer timed out	680
89CSI07	Disconnect 07 close seal-in timer timed out	680
89CSI08	Disconnect 08 close seal-in timer timed out	680
89CSI09	Disconnect 09 close seal-in timer timed out	681
89CSI10	Disconnect 10 close seal-in timer timed out	681
89CSI11	Disconnect 11 close seal-in timer timed out	681
89CSI12	Disconnect 12 close seal-in timer timed out	681
89CSI13	Disconnect 13 close seal-in timer timed out	681
89CSI14	Disconnect 14 close seal-in timer timed out	681
89CSI15	Disconnect 15 close seal-in timer timed out	681
89CSI16	Disconnect 16 close seal-in timer timed out	681
89CSI17	Disconnect 17 close seal-in timer timed out	682
89CSI18	Disconnect 18 close seal-in timer timed out	682
89CSI19	Disconnect 19 close seal-in timer timed out	682
89CSI20	Disconnect 20 close seal-in timer timed out	682
89CTL01	Disconnect 1 control status	148
89CTL02	Disconnect 2 control status	148
89CTL03	Disconnect 3 control status	148
89CTL04	Disconnect 4 control status	148
89CTL05	Disconnect 5 control status	148
89CTL06	Disconnect 6 control status	148
89CTL07	Disconnect 7 control status	148
89CTL08	Disconnect 8 control status	148
89CTL09	Disconnect 9 control status	149
89CTL10	Disconnect 10 control status	149
89CTL11	Disconnect 11 control status	149
89CTL12	Disconnect 12 control status	149

Table 11.1 Alphabetical List of Relay Word Bits (Sheet 33 of 93)

Name	Bit Description	Row
89CTL13	Disconnect 13 control status	149
89CTL14	Disconnect 14 control status	149
89CTL15	Disconnect 15 control status	149
89CTL16	Disconnect 16 control status	149
89CTL17	Disconnect 17 control status	150
89CTL18	Disconnect 18 control status	150
89CTL19	Disconnect 19 control status	150
89CTL20	Disconnect 20 control status	150
89ENC01	Disconnect 1 close control operation enabled	620
89ENC02	Disconnect 2 close control operation enabled	620
89ENC03	Disconnect 3 close control operation enabled	620
89ENC04	Disconnect 4 close control operation enabled	620
89ENC05	Disconnect 5 close control operation enabled	620
89ENC06	Disconnect 6 close control operation enabled	620
89ENC07	Disconnect 7 close control operation enabled	620
89ENC08	Disconnect 8 close control operation enabled	620
89ENC09	Disconnect 9 close control operation enabled	621
89ENC10	Disconnect 10 close control operation enabled	621
89ENC11	Disconnect 11 close control operation enabled	621
89ENC12	Disconnect 12 close control operation enabled	621
89ENC13	Disconnect 13 close control operation enabled	621
89ENC14	Disconnect 14 close control operation enabled	621
89ENC15	Disconnect 15 close control operation enabled	621
89ENC16	Disconnect 16 close control operation enabled	621
89ENC17	Disconnect 17 close control operation enabled	622
89ENC18	Disconnect 18 close control operation enabled	622
89ENC19	Disconnect 19 close control operation enabled	622
89ENC20	Disconnect 20 close control operation enabled	622
89ENO01	Disconnect 1 open control operation enabled	616
89ENO02	Disconnect 2 open control operation enabled	616
89ENO03	Disconnect 3 open control operation enabled	616
89ENO04	Disconnect 4 open control operation enabled	616
89ENO05	Disconnect 5 open control operation enabled	616
89ENO06	Disconnect 6 open control operation enabled	616
89ENO07	Disconnect 7 open control operation enabled	616
89ENO08	Disconnect 8 open control operation enabled	616
89ENO09	Disconnect 9 open control operation enabled	617
89ENO10	Disconnect 10 open control operation enabled	617
89ENO11	Disconnect 11 open control operation enabled	617
89ENO12	Disconnect 12 open control operation enabled	617
89ENO13	Disconnect 13 open control operation enabled	617

Table 11.1 Alphabetical List of Relay Word Bits (Sheet 34 of 93)

Name	Bit Description	Row
89ENO14	Disconnect 14 open control operation enabled	617
89ENO15	Disconnect 15 open control operation enabled	617
89ENO16	Disconnect 16 open control operation enabled	617
89ENO17	Disconnect 17 open control operation enabled	618
89ENO18	Disconnect 18 open control operation enabled	618
89ENO19	Disconnect 19 open control operation enabled	618
89ENO20	Disconnect 20 open control operation enabled	618
89OBL01	Disconnect 01 open block	196
89OBL02	Disconnect 02 open block	196
89OBL03	Disconnect 03 open block	196
89OBL04	Disconnect 04 open block	196
89OBL05	Disconnect 05 open block	196
89OBL06	Disconnect 06 open block	196
89OBL07	Disconnect 07 open block	196
89OBL08	Disconnect 08 open block	196
89OBL09	Disconnect 09 open block	197
89OBL10	Disconnect 10 open block	197
89OBL11	Disconnect 11 open block	197
89OBL12	Disconnect 12 open block	197
89OBL13	Disconnect 13 open block	197
89OBL14	Disconnect 14 open block	197
89OBL15	Disconnect 15 open block	197
89OBL16	Disconnect 16 open block	197
89OBL17	Disconnect 17 open block	198
89OBL18	Disconnect 18 open block	198
89OBL19	Disconnect 19 open block	198
89OBL20	Disconnect 20 open block	198
89OC01	ASCII Open Disconnect 1 command	172
89OC02	ASCII Open Disconnect 2 command	172
89OC03	ASCII Open Disconnect 3 command	172
89OC04	ASCII Open Disconnect 4 command	172
89OC05	ASCII Open Disconnect 5 command	172
89OC06	ASCII Open Disconnect 6 command	172
89OC07	ASCII Open Disconnect 7 command	172
89OC08	ASCII Open Disconnect 8 command	172
89OC09	ASCII Open Disconnect 9 command	173
89OC10	ASCII Open Disconnect 10 command	173
89OC11	ASCII Open Disconnect 11 command	173
89OC12	ASCII Open Disconnect 12 command	173
89OC13	ASCII Open Disconnect 13 command	173
89OC14	ASCII Open Disconnect 14 command	173

Table 11.1 Alphabetical List of Relay Word Bits (Sheet 35 of 93)

Name	Bit Description	Row
89OC15	ASCII Open Disconnect 15 command	173
89OC16	ASCII Open Disconnect 16 command	173
89OC17	ASCII Open Disconnect 17 command	174
89OC18	ASCII Open Disconnect 18 command	174
89OC19	ASCII Open Disconnect 19 command	174
89OC20	ASCII Open Disconnect 20 command	174
89OCM01	Mimic Disconnect 1 open control	184
89OCM02	Mimic Disconnect 2 open control	184
89OCM03	Mimic Disconnect 3 open control	184
89OCM04	Mimic Disconnect 4 open control	184
89OCM05	Mimic Disconnect 5 open control	184
89OCM06	Mimic Disconnect 6 open control	184
89OCM07	Mimic Disconnect 7 open control	184
89OCM08	Mimic Disconnect 8 open control	184
89OCM09	Mimic Disconnect 9 open control	185
89OCM10	Mimic Disconnect 10 open control	185
89OCM11	Mimic Disconnect 11 open control	185
89OCM12	Mimic Disconnect 12 open control	185
89OCM13	Mimic Disconnect 13 open control	185
89OCM14	Mimic Disconnect 14 open control	185
89OCM15	Mimic Disconnect 15 open control	185
89OCM16	Mimic Disconnect 16 open control	185
89OCM17	Mimic Disconnect 17 open control	186
89OCM18	Mimic Disconnect 18 open control	186
89OCM19	Mimic Disconnect 19 open control	186
89OCM20	Mimic Disconnect 20 open control	186
89OCN01	Open Disconnect 1	180
89OCN02	Open Disconnect 2	180
89OCN03	Open Disconnect 3	180
89OCN04	Open Disconnect 4	180
89OCN05	Open Disconnect 5	180
89OCN06	Open Disconnect 6	180
89OCN07	Open Disconnect 7	180
89OCN08	Open Disconnect 8	180
89OCN09	Open Disconnect 9	181
89OCN10	Open Disconnect 10	181
89OCN11	Open Disconnect 11	181
89OCN12	Open Disconnect 12	181
89OCN13	Open Disconnect 13	181
89OCN14	Open Disconnect 14	181
89OCN15	Open Disconnect 15	181

Table 11.1 Alphabetical List of Relay Word Bits (Sheet 36 of 93)

Name	Bit Description	Row
89OCN16	Open Disconnect 16	181
89OCN17	Open Disconnect 17	182
89OCN18	Open Disconnect 18	182
89OCN19	Open Disconnect 19	182
89OCN20	Open Disconnect 20	182
89OIM01	Disconnect 01 open immobility timer timed out	660
89OIM02	Disconnect 02 open immobility timer timed out	660
89OIM03	Disconnect 03 open immobility timer timed out	660
89OIM04	Disconnect 04 open immobility timer timed out	660
89OIM05	Disconnect 05 open immobility timer timed out	660
89OIM06	Disconnect 06 open immobility timer timed out	660
89OIM07	Disconnect 07 open immobility timer timed out	660
89OIM08	Disconnect 08 open immobility timer timed out	660
89OIM09	Disconnect 09 open immobility timer timed out	661
89OIM10	Disconnect 10 open immobility timer timed out	661
89OIM11	Disconnect 11 open immobility timer timed out	661
89OIM12	Disconnect 12 open immobility timer timed out	661
89OIM13	Disconnect 13 open immobility timer timed out	661
89OIM14	Disconnect 14 open immobility timer timed out	661
89OIM15	Disconnect 15 open immobility timer timed out	661
89OIM16	Disconnect 16 open immobility timer timed out	661
89OIM17	Disconnect 17 open immobility timer timed out	662
89OIM18	Disconnect 18 open immobility timer timed out	662
89OIM19	Disconnect 19 open immobility timer timed out	662
89OIM20	Disconnect 20 open immobility timer timed out	662
89OIP	Any Disconnect operation in progress	127
89OIP01	Disconnect 1 operation in progress	136
89OIP02	Disconnect 2 operation in progress	136
89OIP03	Disconnect 3 operation in progress	136
89OIP04	Disconnect 4 operation in progress	136
89OIP05	Disconnect 5 operation in progress	136
89OIP06	Disconnect 6 operation in progress	136
89OIP07	Disconnect 7 operation in progress	136
89OIP08	Disconnect 8 operation in progress	136
89OIP09	Disconnect 9 operation in progress	137
89OIP10	Disconnect 10 operation in progress	137
89OIP11	Disconnect 11 operation in progress	137
89OIP12	Disconnect 12 operation in progress	137
89OIP13	Disconnect 13 operation in progress	137
89OIP14	Disconnect 14 operation in progress	137
89OIP15	Disconnect 15 operation in progress	137

Table 11.1 Alphabetical List of Relay Word Bits (Sheet 37 of 93)

Name	Bit Description	Row
89OIP16	Disconnect 16 operation in progress	137
89OIP17	Disconnect 17 operation in progress	138
89OIP18	Disconnect 18 operation in progress	138
89OIP19	Disconnect 19 operation in progress	138
89OIP20	Disconnect 20 operation in progress	138
89OIR01	Disconnect 01 open immobility timer reset	676
89OIR02	Disconnect 02 open immobility timer reset	676
89OIR03	Disconnect 03 open immobility timer reset	676
89OIR04	Disconnect 04 open immobility timer reset	676
89OIR05	Disconnect 05 open immobility timer reset	676
89OIR06	Disconnect 06 open immobility timer reset	676
89OIR07	Disconnect 07 open immobility timer reset	676
89OIR08	Disconnect 08 open immobility timer reset	676
89OIR09	Disconnect 09 open immobility timer reset	677
89OIR10	Disconnect 10 open immobility timer reset	677
89OIR11	Disconnect 11 open immobility timer reset	677
89OIR12	Disconnect 12 open immobility timer reset	677
89OIR13	Disconnect 13 open immobility timer reset	677
89OIR14	Disconnect 14 open immobility timer reset	677
89OIR15	Disconnect 15 open immobility timer reset	677
89OIR16	Disconnect 16 open immobility timer reset	677
89OIR17	Disconnect 17 open immobility timer reset	678
89OIR18	Disconnect 18 open immobility timer reset	678
89OIR19	Disconnect 19 open immobility timer reset	678
89OIR20	Disconnect 20 open immobility timer reset	678
89OPE01	Disconnect Open 1 output	160
89OPE02	Disconnect Open 2 output	160
89OPE03	Disconnect Open 3 output	160
89OPE04	Disconnect Open 4 output	160
89OPE05	Disconnect Open 5 output	160
89OPE06	Disconnect Open 6 output	160
89OPE07	Disconnect Open 7 output	160
89OPE08	Disconnect Open 8 output	160
89OPE09	Disconnect Open 9 output	161
89OPE10	Disconnect Open 10 output	161
89OPE11	Disconnect Open 11 output	161
89OPE12	Disconnect Open 12 output	161
89OPE13	Disconnect Open 13 output	161
89OPE14	Disconnect Open 14 output	161
89OPE15	Disconnect Open 15 output	161
89OPE16	Disconnect Open 16 output	161

Table 11.1 Alphabetical List of Relay Word Bits (Sheet 38 of 93)

Name	Bit Description	Row
89OPE17	Disconnect Open 17 output	162
89OPE18	Disconnect Open 18 output	162
89OPE19	Disconnect Open 19 output	162
89OPE20	Disconnect Open 20 output	162
89OPN01	Disconnect 1 open	140
89OPN02	Disconnect 2 open	140
89OPN03	Disconnect 3 open	140
89OPN04	Disconnect 4 open	140
89OPN05	Disconnect 5 open	140
89OPN06	Disconnect 6 open	140
89OPN07	Disconnect 7 open	140
89OPN08	Disconnect 8 open	140
89OPN09	Disconnect 9 open	141
89OPN10	Disconnect 10 open	141
89OPN11	Disconnect 11 open	141
89OPN12	Disconnect 12 open	141
89OPN13	Disconnect 13 open	141
89OPN14	Disconnect 14 open	141
89OPN15	Disconnect 15 open	141
89OPN16	Disconnect 16 open	141
89OPN17	Disconnect 17 open	142
89OPN18	Disconnect 18 open	142
89OPN19	Disconnect 19 open	142
89OPN20	Disconnect 20 open	142
89ORS01	Disconnect 01 open reset	192
89ORS02	Disconnect 02 open reset	192
89ORS03	Disconnect 03 open reset	192
89ORS04	Disconnect 04 open reset	192
89ORS05	Disconnect 05 open reset	192
89ORS06	Disconnect 06 open reset	192
89ORS07	Disconnect 07 open reset	192
89ORS08	Disconnect 08 open reset	192
89ORS09	Disconnect 09 open reset	193
89ORS10	Disconnect 10 open reset	193
89ORS11	Disconnect 11 open reset	193
89ORS12	Disconnect 12 open reset	193
89ORS13	Disconnect 13 open reset	193
89ORS14	Disconnect 14 open reset	193
89ORS15	Disconnect 15 open reset	193
89ORS16	Disconnect 16 open reset	193
89ORS17	Disconnect 17 open reset	194

Table 11.1 Alphabetical List of Relay Word Bits (Sheet 39 of 93)

Name	Bit Description	Row
89ORS18	Disconnect 18 open reset	194
89ORS19	Disconnect 19 open reset	194
89ORS20	Disconnect 20 open reset	194
89OSI01	Disconnect 01 open seal-in timer timed out	664
89OSI02	Disconnect 02 open seal-in timer timed out	664
89OSI03	Disconnect 03 open seal-in timer timed out	664
89OSI04	Disconnect 04 open seal-in timer timed out	664
89OSI05	Disconnect 05 open seal-in timer timed out	664
89OSI06	Disconnect 06 open seal-in timer timed out	664
89OSI07	Disconnect 07 open seal-in timer timed out	664
89OSI08	Disconnect 08 open seal-in timer timed out	664
89OSI09	Disconnect 09 open seal-in timer timed out	665
89OSI10	Disconnect 10 open seal-in timer timed out	665
89OSI11	Disconnect 11 open seal-in timer timed out	665
89OSI12	Disconnect 12 open seal-in timer timed out	665
89OSI13	Disconnect 13 open seal-in timer timed out	665
89OSI14	Disconnect 14 open seal-in timer timed out	665
89OSI15	Disconnect 15 open seal-in timer timed out	665
89OSI16	Disconnect 16 open seal-in timer timed out	665
89OSI17	Disconnect 17 open seal-in timer timed out	666
89OSI18	Disconnect 18 open seal-in timer timed out	666
89OSI19	Disconnect 19 open seal-in timer timed out	666
89OSI20	Disconnect 20 open seal-in timer timed out	666
ABFITS	Alternative breaker failure, Terminal S	111
ABFITT	Alternative breaker failure, Terminal T	113
ABFITU	Alternative breaker failure, Terminal U	115
ABFITW	Alternative breaker failure, Terminal W	117
ABFITX	Alternative breaker failure, Terminal X	119
ABFITY	Alternative breaker failure, Terminal Y	745
ACCESS	A user is logged in at Access Level B or above	350
ACCESSP	Pulsed alarm for logins to Access Level B or above	350
ACN01Q	Automation SELOGIC Counter 01 asserted	340
ACN01R	Automation SELOGIC Counter 01 reset	344
ACN02Q	Automation SELOGIC Counter 02 asserted	340
ACN02R	Automation SELOGIC Counter 02 reset	344
ACN03Q	Automation SELOGIC Counter 03 asserted	340
ACN03R	Automation SELOGIC Counter 03 reset	344
ACN04Q	Automation SELOGIC Counter 04 asserted	340
ACN04R	Automation SELOGIC Counter 04 reset	344
ACN05Q	Automation SELOGIC Counter 05 asserted	340
ACN05R	Automation SELOGIC Counter 05 reset	344

Table 11.1 Alphabetical List of Relay Word Bits (Sheet 40 of 93)

Name	Bit Description	Row
ACN06Q	Automation SELOGIC Counter 06 asserted	340
ACN06R	Automation SELOGIC Counter 06 reset	344
ACN07Q	Automation SELOGIC Counter 07 asserted	340
ACN07R	Automation SELOGIC Counter 07 reset	344
ACN08Q	Automation SELOGIC Counter 08 asserted	340
ACN08R	Automation SELOGIC Counter 08 reset	344
ACN09Q	Automation SELOGIC Counter 09 asserted	341
ACN09R	Automation SELOGIC Counter 09 reset	345
ACN10Q	Automation SELOGIC Counter 10 asserted	341
ACN10R	Automation SELOGIC Counter 10 reset	345
ACN11Q	Automation SELOGIC Counter 11 asserted	341
ACN11R	Automation SELOGIC Counter 11 reset	345
ACN12Q	Automation SELOGIC Counter 12 asserted	341
ACN12R	Automation SELOGIC Counter 12 reset	345
ACN13Q	Automation SELOGIC Counter 13 asserted	341
ACN13R	Automation SELOGIC Counter 13 reset	345
ACN14Q	Automation SELOGIC Counter 14 asserted	341
ACN14R	Automation SELOGIC Counter 14 reset	345
ACN15Q	Automation SELOGIC Counter 15 asserted	341
ACN15R	Automation SELOGIC Counter 15 reset	345
ACN16Q	Automation SELOGIC Counter 16 asserted	341
ACN16R	Automation SELOGIC Counter 16 reset	345
ACN17Q	Automation SELOGIC Counter 17 asserted	342
ACN17R	Automation SELOGIC Counter 17 reset	346
ACN18Q	Automation SELOGIC Counter 18 asserted	342
ACN18R	Automation SELOGIC Counter 18 reset	346
ACN19Q	Automation SELOGIC Counter 19 asserted	342
ACN19R	Automation SELOGIC Counter 19 reset	346
ACN20Q	Automation SELOGIC Counter 20 asserted	342
ACN20R	Automation SELOGIC Counter 20 reset	346
ACN21Q	Automation SELOGIC Counter 21 asserted	342
ACN21R	Automation SELOGIC Counter 21 reset	346
ACN22Q	Automation SELOGIC Counter 22 asserted	342
ACN22R	Automation SELOGIC Counter 22 reset	346
ACN23Q	Automation SELOGIC Counter 23 asserted	342
ACN23R	Automation SELOGIC Counter 23 reset	346
ACN24Q	Automation SELOGIC Counter 24 asserted	342
ACN24R	Automation SELOGIC Counter 24 reset	346
ACN25Q	Automation SELOGIC Counter 25 asserted	343
ACN25R	Automation SELOGIC Counter 25 reset	347
ACN26Q	Automation SELOGIC Counter 26 asserted	343

Table 11.1 Alphabetical List of Relay Word Bits (Sheet 41 of 93)

Name	Bit Description	Row
ACN26R	Automation SELOGIC Counter 26 reset	347
ACN27Q	Automation SELOGIC Counter 27 asserted	343
ACN27R	Automation SELOGIC Counter 27 reset	347
ACN28Q	Automation SELOGIC Counter 28 asserted	343
ACN28R	Automation SELOGIC Counter 28 reset	347
ACN29Q	Automation SELOGIC Counter 29 asserted	343
ACN29R	Automation SELOGIC Counter 29 reset	347
ACN30Q	Automation SELOGIC Counter 30 asserted	343
ACN30R	Automation SELOGIC Counter 30 reset	347
ACN31Q	Automation SELOGIC Counter 31 asserted	343
ACN31R	Automation SELOGIC Counter 31 reset	347
ACN32Q	Automation SELOGIC Counter 32 asserted	343
ACN32R	Automation SELOGIC Counter 32 reset	347
ACT01Q–ACT08Q	Automation SELOGIC Conditioning Timer (01–08) asserted	594
ACT09Q–ACT16Q	Automation SELOGIC Conditioning Timer (09–16) asserted	595
ACT17Q–ACT24Q	Automation SELOGIC Conditioning Timer (17–24) asserted	596
ACT25Q–ACT32Q	Automation SELOGIC Conditioning Timer (25–32) asserted	597
ACT33Q–ACT40Q	Automation SELOGIC Conditioning Timer (33–40) asserted	598
ACT41Q–ACT48Q	Automation SELOGIC Conditioning Timer (41–48) asserted	599
AFRTEXA	Automation SELOGIC control equation first execution after Automation settings change	348
AFRTEXP	Automation SELOGIC control equation first execution after Protection settings change	348
ALT01	Automation SELOGIC Latch 01 asserted	324
ALT02	Automation SELOGIC Latch 02 asserted	324
ALT03	Automation SELOGIC Latch 03 asserted	324
ALT04	Automation SELOGIC Latch 04 asserted	324
ALT05	Automation SELOGIC Latch 05 asserted	324
ALT06	Automation SELOGIC Latch 06 asserted	324
ALT07	Automation SELOGIC Latch 07 asserted	324
ALT08	Automation SELOGIC Latch 08 asserted	324
ALT09	Automation SELOGIC Latch 09 asserted	325
ALT10	Automation SELOGIC Latch 10 asserted	325
ALT11	Automation SELOGIC Latch 11 asserted	325
ALT12	Automation SELOGIC Latch 12 asserted	325
ALT13	Automation SELOGIC Latch 13 asserted	325
ALT14	Automation SELOGIC Latch 14 asserted	325
ALT15	Automation SELOGIC Latch 15 asserted	325
ALT16	Automation SELOGIC Latch 16 asserted	325

Table 11.1 Alphabetical List of Relay Word Bits (Sheet 42 of 93)

Name	Bit Description	Row
ALT17	Automation SELOGIC Latch 17 asserted	326
ALT18	Automation SELOGIC Latch 18 asserted	326
ALT19	Automation SELOGIC Latch 19 asserted	326
ALT20	Automation SELOGIC Latch 20 asserted	326
ALT21	Automation SELOGIC Latch 21 asserted	326
ALT22	Automation SELOGIC Latch 22 asserted	326
ALT23	Automation SELOGIC Latch 23 asserted	326
ALT24	Automation SELOGIC Latch 24 asserted	326
ALT25	Automation SELOGIC Latch 25 asserted	327
ALT26	Automation SELOGIC Latch 26 asserted	327
ALT27	Automation SELOGIC Latch 27 asserted	327
ALT28	Automation SELOGIC Latch 28 asserted	327
ALT29	Automation SELOGIC Latch 29 asserted	327
ALT30	Automation SELOGIC Latch 30 asserted	327
ALT31	Automation SELOGIC Latch 31 asserted	327
ALT32	Automation SELOGIC Latch 32 asserted	327
ALT33	Automation SELOGIC Latch 33 asserted	328
ALT34	Automation SELOGIC Latch 34 asserted	328
ALT35	Automation SELOGIC Latch 35 asserted	328
ALT36	Automation SELOGIC Latch 36 asserted	328
ALT37	Automation SELOGIC Latch 37 asserted	328
ALT38	Automation SELOGIC Latch 38 asserted	328
ALT39	Automation SELOGIC Latch 39 asserted	328
ALT40	Automation SELOGIC Latch 40 asserted	328
ALT41	Automation SELOGIC Latch 41asserted	329
ALT42	Automation SELOGIC Latch 42 asserted	329
ALT43	Automation SELOGIC Latch 43 asserted	329
ALT44	Automation SELOGIC Latch 44 asserted	329
ALT45	Automation SELOGIC Latch 45 asserted	329
ALT46	Automation SELOGIC Latch 46 asserted	329
ALT47	Automation SELOGIC Latch 47 asserted	329
ALT48	Automation SELOGIC Latch 48 asserted	329
ALT49	Automation SELOGIC Latch 49 asserted	330
ALT50	Automation SELOGIC Latch 50 asserted	330
ALT51	Automation SELOGIC Latch 51 asserted	330
ALT52	Automation SELOGIC Latch 52 asserted	330
ALT53	Automation SELOGIC Latch 53 asserted	330
ALT54	Automation SELOGIC Latch 54 asserted	330
ALT55	Automation SELOGIC Latch 55 asserted	330
ALT56	Automation SELOGIC Latch 56 asserted	330
ALT57	Automation SELOGIC Latch 57 asserted	331

Table 11.1 Alphabetical List of Relay Word Bits (Sheet 43 of 93)

Name	Bit Description	Row
ALT58	Automation SELOGIC Latch 58 asserted	331
ALT59	Automation SELOGIC Latch 59 asserted	331
ALT60	Automation SELOGIC Latch 60 asserted	331
ALT61	Automation SELOGIC Latch 61 asserted	331
ALT62	Automation SELOGIC Latch 62 asserted	331
ALT63	Automation SELOGIC Latch 63 asserted	331
ALT64	Automation SELOGIC Latch 64 asserted	331
ALT65	Automation SELOGIC Latch 65 asserted	764
ALT66	Automation SELOGIC Latch 66 asserted	764
ALT67	Automation SELOGIC Latch 67 asserted	764
ALT68	Automation SELOGIC Latch 68 asserted	764
ALT69	Automation SELOGIC Latch 69 asserted	764
ALT70	Automation SELOGIC Latch 70 asserted	764
ALT71	Automation SELOGIC Latch 71 asserted	764
ALT72	Automation SELOGIC Latch 72 asserted	764
ALT73	Automation SELOGIC Latch 73 asserted	765
ALT74	Automation SELOGIC Latch 74 asserted	765
ALT75	Automation SELOGIC Latch 75 asserted	765
ALT76	Automation SELOGIC Latch 76 asserted	765
ALT77	Automation SELOGIC Latch 77 asserted	765
ALT78	Automation SELOGIC Latch 78 asserted	765
ALT79	Automation SELOGIC Latch 79 asserted	765
ALT80	Automation SELOGIC Latch 80 asserted	765
ALTPS1	Breaker S first alternative polarizing voltage source selected (SELOGIC control equation)	573
ALTPS2	Breaker S second alternative polarizing voltage source selected (SELOGIC control equation)	573
ALTPT1	Breaker T first alternative polarizing voltage source selected (SELOGIC control equation)	573
ALTPT2	Breaker T second alternative polarizing voltage source selected (SELOGIC control equation)	573
ALTPU1	Breaker U first alternative polarizing voltage source selected (SELOGIC control equation)	573
ALTPU2	Breaker U second alternative polarizing voltage source selected (SELOGIC control equation)	574
ALTPW1	Breaker W first alternative polarizing voltage source selected (SELOGIC control equation)	573
ALTPW2	Breaker W second alternative polarizing voltage source selected (SELOGIC control equation)	574
ALTPX1	Breaker X first alternative polarizing voltage source selected (SELOGIC control equation)	573
ALTPX2	Breaker X second alternative polarizing voltage source selected (SELOGIC control equation)	574
ALTPY1	Breaker Y first alternative polarizing voltage source selected (SELOGIC control equation)	573
ALTPY2	Breaker Y second alternative polarizing voltage source selected (SELOGIC control equation)	574
ALTSS	Breaker S alternative synchronizing voltage source selected (SELOGIC control equation)	454
ALTST	Breaker T alternative synchronizing voltage source selected (SELOGIC control equation)	454
ALTSU	Breaker U alternative synchronizing voltage source selected (SELOGIC control equation)	454
ALTSW	Breaker W alternative synchronizing voltage source selected (SELOGIC control equation)	455
ALTSX	Breaker X alternative synchronizing voltage source selected (SELOGIC control equation)	455
ALTSY	Breaker Y alternative synchronizing voltage source selected (SELOGIC control equation)	449

Table 11.1 Alphabetical List of Relay Word Bits (Sheet 44 of 93)

Name	Bit Description	Row
ALTVS	Alternative voltage source, Terminal S	246
ALTVT	Alternative voltage source, Terminal T	246
ALTVU	Alternative voltage source, Terminal U	246
ALTVW	Alternative voltage source, Terminal W	246
ALTVX	Alternative voltage source, Terminal X	246
ALTVY	Alternative voltage source, Terminal Y	246
AMB_F	Ambient temperature fault condition	213
ANOKA	Analog transfer on MIRRORED BITS Channel A	380
ANOKB	Analog transfer on MIRRORED BITS Channel B	381
AST01Q	Automation SELOGIC Sequencing Timer 01 asserted	332
AST01R	Automation SELOGIC Sequencing Timer 01 reset	336
AST02Q	Automation SELOGIC Sequencing Timer 02 asserted	332
AST02R	Automation SELOGIC Sequencing Timer 02 reset	336
AST03Q	Automation SELOGIC Sequencing Timer 03 asserted	332
AST03R	Automation SELOGIC Sequencing Timer 03 reset	336
AST04Q	Automation SELOGIC Sequencing Timer 04 asserted	332
AST04R	Automation SELOGIC Sequencing Timer 04 reset	336
AST05Q	Automation SELOGIC Sequencing Timer 05 asserted	332
AST05R	Automation SELOGIC Sequencing Timer 05 reset	336
AST06Q	Automation SELOGIC Sequencing Timer 06 asserted	332
AST06R	Automation SELOGIC Sequencing Timer 06 reset	336
AST07Q	Automation SELOGIC Sequencing Timer 07 asserted	332
AST07R	Automation SELOGIC Sequencing Timer 07 reset	336
AST08Q	Automation SELOGIC Sequencing Timer 08 asserted	332
AST08R	Automation SELOGIC Sequencing Timer 08 reset	336
AST09Q	Automation SELOGIC Sequencing Timer 09 asserted	333
AST09R	Automation SELOGIC Sequencing Timer 09 reset	337
AST10Q	Automation SELOGIC Sequencing Timer 10 asserted	333
AST10R	Automation SELOGIC Sequencing Timer 10 reset	337
AST11Q	Automation SELOGIC Sequencing Timer 11 asserted	333
AST11R	Automation SELOGIC Sequencing Timer 11 reset	337
AST12Q	Automation SELOGIC Sequencing Timer 12 asserted	333
AST12R	Automation SELOGIC Sequencing Timer 12 reset	337
AST13Q	Automation SELOGIC Sequencing Timer 13 asserted	333
AST13R	Automation SELOGIC Sequencing Timer 13 reset	337
AST14Q	Automation SELOGIC Sequencing Timer 14 asserted	333
AST14R	Automation SELOGIC Sequencing Timer 14 reset	337
AST15Q	Automation SELOGIC Sequencing Timer 15 asserted	333
AST15R	Automation SELOGIC Sequencing Timer 15 reset	337
AST16Q	Automation SELOGIC Sequencing Timer 16 asserted	333
AST16R	Automation SELOGIC Sequencing Timer 16 reset	337

Table 11.1 Alphabetical List of Relay Word Bits (Sheet 45 of 93)

Name	Bit Description	Row
AST17Q	Automation SELOGIC Sequencing Timer 17 asserted	334
AST17R	Automation SELOGIC Sequencing Timer 17 reset	338
AST18Q	Automation SELOGIC Sequencing Timer 18 asserted	334
AST18R	Automation SELOGIC Sequencing Timer 18 reset	338
AST19Q	Automation SELOGIC Sequencing Timer 19 asserted	334
AST19R	Automation SELOGIC Sequencing Timer 19 reset	338
AST20Q	Automation SELOGIC Sequencing Timer 20 asserted	334
AST20R	Automation SELOGIC Sequencing Timer 20 reset	338
AST21Q	Automation SELOGIC Sequencing Timer 21 asserted	334
AST21R	Automation SELOGIC Sequencing Timer 21 reset	338
AST22Q	Automation SELOGIC Sequencing Timer 22 asserted	334
AST22R	Automation SELOGIC Sequencing Timer 22 reset	338
AST23Q	Automation SELOGIC Sequencing Timer 23 asserted	334
AST23R	Automation SELOGIC Sequencing Timer 23 reset	338
AST24Q	Automation SELOGIC Sequencing Timer 24 asserted	334
AST24R	Automation SELOGIC Sequencing Timer 24 reset	338
AST25Q	Automation SELOGIC Sequencing Timer 25 asserted	335
AST25R	Automation SELOGIC Sequencing Timer 25 reset	339
AST26Q	Automation SELOGIC Sequencing Timer 26 asserted	335
AST26R	Automation SELOGIC Sequencing Timer 26 reset	339
AST27Q	Automation SELOGIC Sequencing Timer 27 asserted	335
AST27R	Automation SELOGIC Sequencing Timer 27 reset	339
AST28Q	Automation SELOGIC Sequencing Timer 28 asserted	335
AST28R	Automation SELOGIC Sequencing Timer 28 reset	339
AST29Q	Automation SELOGIC Sequencing Timer 29 asserted	335
AST29R	Automation SELOGIC Sequencing Timer 29 reset	339
AST30Q	Automation SELOGIC Sequencing Timer 30 asserted	335
AST30R	Automation SELOGIC Sequencing Timer 30 reset	339
AST31Q	Automation SELOGIC Sequencing Timer 31 asserted	335
AST31R	Automation SELOGIC Sequencing Timer 31 reset	339
AST32Q	Automation SELOGIC Sequencing Timer 32 asserted	335
AST32R	Automation SELOGIC Sequencing Timer 32 reset	339
AST33Q	Automation SELOGIC Sequencing Timer 33 asserted	760
AST33R	Automation SELOGIC Sequencing Timer 33 reset	762
AST34Q	Automation SELOGIC Sequencing Timer 34 asserted	760
AST34R	Automation SELOGIC Sequencing Timer 34 reset	762
AST35Q	Automation SELOGIC Sequencing Timer 35 asserted	760
AST35R	Automation SELOGIC Sequencing Timer 35 reset	762
AST36Q	Automation SELOGIC Sequencing Timer 36 asserted	760
AST36R	Automation SELOGIC Sequencing Timer 36 reset	762
AST37Q	Automation SELOGIC Sequencing Timer 37 asserted	760

Table 11.1 Alphabetical List of Relay Word Bits (Sheet 46 of 93)

Name	Bit Description	Row
AST37R	Automation SELOGIC Sequencing Timer 37 reset	762
AST38Q	Automation SELOGIC Sequencing Timer 38 asserted	760
AST38R	Automation SELOGIC Sequencing Timer 38 reset	762
AST39Q	Automation SELOGIC Sequencing Timer 39 asserted	760
AST39R	Automation SELOGIC Sequencing Timer 39 reset	762
AST40Q	Automation SELOGIC Sequencing Timer 40 asserted	760
AST40R	Automation SELOGIC Sequencing Timer 40 reset	762
AST41Q	Automation SELOGIC Sequencing Timer 41 asserted	761
AST41R	Automation SELOGIC Sequencing Timer 41 reset	763
AST42Q	Automation SELOGIC Sequencing Timer 42 asserted	761
AST42R	Automation SELOGIC Sequencing Timer 42 reset	763
AST43Q	Automation SELOGIC Sequencing Timer 43 asserted	761
AST43R	Automation SELOGIC Sequencing Timer 43 reset	763
AST44Q	Automation SELOGIC Sequencing Timer 44 asserted	761
AST44R	Automation SELOGIC Sequencing Timer 44 reset	763
AST45Q	Automation SELOGIC Sequencing Timer 45 asserted	761
AST45R	Automation SELOGIC Sequencing Timer 45 reset	763
AST46Q	Automation SELOGIC Sequencing Timer 46 asserted	761
AST46R	Automation SELOGIC Sequencing Timer 46 reset	763
AST47Q	Automation SELOGIC Sequencing Timer 47 asserted	761
AST47R	Automation SELOGIC Sequencing Timer 47 reset	763
AST48Q	Automation SELOGIC Sequencing Timer 48 asserted	761
AST48R	Automation SELOGIC Sequencing Timer 48 reset	763
ASV001–ASV008	Automation SELOGIC Variable 001–Variable 008 asserted	292
ASV009–ASV016	Automation SELOGIC Variable 009–Variable 016 asserted	293
ASV017–ASV024	Automation SELOGIC Variable 017–Variable 024 asserted	294
ASV025–ASV032	Automation SELOGIC Variable 025–Variable 032 asserted	295
ASV033–ASV040	Automation SELOGIC Variable 033–Variable 040 asserted	296
ASV041–ASV048	Automation SELOGIC Variable 041–Variable 048 asserted	297
ASV049–ASV056	Automation SELOGIC Variable 049–Variable 056 asserted	298
ASV057–ASV064	Automation SELOGIC Variable 057–Variable 064 asserted	299
ASV065–ASV072	Automation SELOGIC Variable 065–Variable 072 asserted	300
ASV073–ASV080	Automation SELOGIC Variable 073–Variable 080 asserted	301
ASV081–ASV088	Automation SELOGIC Variable 081–Variable 088 asserted	302

Table 11.1 Alphabetical List of Relay Word Bits (Sheet 47 of 93)

Name	Bit Description	Row
ASV089–ASV096	Automation SELOGIC Variable 089–Variable 096 asserted	303
ASV097–ASV104	Automation SELOGIC Variable 097–Variable 104 asserted	304
ASV105–ASV112	Automation SELOGIC Variable 105–Variable 112 asserted	305
ASV113–ASV120	Automation SELOGIC Variable 113–Variable 120 asserted	306
ASV121–ASV128	Automation SELOGIC Variable 121–Variable 128 asserted	307
ASV129–ASV136	Automation SELOGIC Variable 129–Variable 136 asserted	308
ASV137–ASV144	Automation SELOGIC Variable 137–Variable 144 asserted	309
ASV145–ASV152	Automation SELOGIC Variable 145–Variable 152 asserted	310
ASV153–ASV160	Automation SELOGIC Variable 153–Variable 160 asserted	311
ASV161–ASV168	Automation SELOGIC Variable 161–Variable 168 asserted	312
ASV169–ASV176	Automation SELOGIC Variable 169–Variable 176 asserted	313
ASV177–ASV184	Automation SELOGIC Variable 177–Variable 184 asserted	314
ASV185–ASV192	Automation SELOGIC Variable 185–Variable 192 asserted	315
ASV193–ASV200	Automation SELOGIC Variable 193–Variable 200 asserted	316
ASV201–ASV208	Automation SELOGIC Variable 201–Variable 208 asserted	317
ASV209–ASV216	Automation SELOGIC Variable 209–Variable 216 asserted	318
ASV217–ASV224	Automation SELOGIC Variable 217–Variable 224 asserted	319
ASV225–ASV232	Automation SELOGIC Variable 225–Variable 232 asserted	320
ASV233–ASV240	Automation SELOGIC Variable 233–Variable 240 asserted	321
ASV241–ASV248	Automation SELOGIC Variable 241–Variable 248 asserted	322
ASV249–ASV256	Automation SELOGIC Variable 249–Variable 256 asserted	323
ATBFIS	Alternative breaker failure initiated, Terminal S	110
ATBFIT	Alternative breaker failure initiated, Terminal T	112
ATBFIU	Alternative breaker failure initiated, Terminal U	114
ATBFIW	Alternative breaker failure initiated, Terminal W	116
ATBFIX	Alternative breaker failure initiated, Terminal X	118
ATBFIY	Alternative breaker failure initiated, Terminal Y	744

Table 11.1 Alphabetical List of Relay Word Bits (Sheet 48 of 93)

Name	Bit Description	Row
ATBFTS	Alternative breaker failure timer timed out, Terminal S	110
ATBFTT	Alternative breaker failure timer timed out, Terminal T	112
ATBFTU	Alternative breaker failure timer timed out, Terminal U	114
ATBFTW	Alternative breaker failure timer timed out, Terminal W	116
ATBFTX	Alternative breaker failure timer timed out, Terminal X	118
ATBFTY	Alternative breaker failure timer timed out, Terminal Y	744
AUNRLBL	Automation SELOGIC control equation unresolved label	348
BADPASS	Invalid password attempt alarm	349
BFIS	Breaker failure initiated, Terminal S	110
BFISPTS	Breaker failure seal-in timer timed out, Terminal S	111
BFISPTT	Breaker failure seal-in timer timed out, Terminal T	113
BFISPTU	Breaker failure seal-in timer timed out, Terminal U	115
BFISPTW	Breaker failure seal-in timer timed out, Terminal W	117
BFISPTX	Breaker failure seal-in timer timed out, Terminal X	119
BFISPTY	Breaker failure seal-in timer timed out, Terminal Y	745
BFIT	Breaker failure initiated, Terminal T	112
BFITS	Breaker failure timer timed out, Terminal S	110
BFITT	Breaker failure timer timed out, Terminal T	112
BFITU	Breaker failure timer timed out, Terminal U	114
BFITW	Breaker failure timer timed out, Terminal W	116
BFITX	Breaker failure timer timed out, Terminal X	118
BFITY	Breaker failure timer timed out, Terminal Y	744
BFIU	Breaker failure initiated, Terminal U	114
BFIW	Breaker failure initiated, Terminal W	116
BFIX	Breaker failure initiated, Terminal X	118
BFIY	Breaker failure initiated, Terminal Y	744
BKENCS	IEC 61850 Breaker S close control operation enabled	685
BKENCT	IEC 61850 Breaker T close control operation enabled	685
BKENCU	IEC 61850 Breaker U close control operation enabled	684
BKENCW	IEC 61850 Breaker W close control operation enabled	684
BKENCX	IEC 61850 Breaker X close control operation enabled	684
BKENCY	IEC 61850 Breaker Y close control operation enabled	684
BKENOS	IEC 61850 Breaker S open control operation enabled	685
BKENOT	IEC 61850 Breaker T open control operation enabled	685
BKENOU	IEC 61850 Breaker U open control operation enabled	684
BKENOW	IEC 61850 Breaker W open control operation enabled	684
BKENOX	IEC 61850 Breaker X open control operation enabled	684
BKENOY	IEC 61850 Breaker Y open control operation enabled	684
BLKLPTS	Block low-priority source from updating relay time	354
BNC_BNP	Bad jitter on BNC port and the IRIG-B signal is lost afterwards	468
BNC_OK	IRIG-B signal from BNC port is available and has sufficient quality	468

Table 11.1 Alphabetical List of Relay Word Bits (Sheet 49 of 93)

Name	Bit Description	Row
BNC_RST	Disqualify BNC IRIG-B time source	468
BNC_SET	Qualify BNC IRIG-B time source	468
BNC_TIM	A valid IRIG-B time source is detected on BNC port	469
BNCSYNC	Synchronized to high-quality BNC IRIG source	469
BRKENAB	Breaker Control Enable Jumper is installed	350
BSBCWAL	Breaker contact wear alarm, Breaker S	200
BSBITAL	Inactivity time alarm, Breaker S	200
BSESOAL	Slow electrical operate alarm, Breaker S	200
BSKAIAL	Interrupted rms current alarm, Breaker S	200
BSMRTAL	Motor run time alarm, Breaker S	200
BSMSOAL	Mechanical slow operation alarm, Breaker S	200
BSYNBKS	Breaker S synchronism check blocked	456
BSYNBKT	Breaker T synchronism check blocked	456
BSYNBKU	Breaker U synchronism check blocked	456
BSYNBKW	Breaker W synchronism check blocked	456
BSYNBKX	Breaker X synchronism check blocked	456
BSYNBKY	Breaker Y synchronism check blocked	448
BTBCWAL	Breaker contact wear alarm, Breaker T	201
BTBITAL	Inactivity time alarm, Breaker T	201
BTESOAL	Slow electrical operation alarm, Breaker T	201
BTKAIAL	Interrupted rms current alarm, Breaker T	201
BTMRTAL	Motor run time alarm, Breaker T	201
BTMSOAL	Mechanical slow operation alarm, Breaker T	201
BUBCWAL	Breaker contact wear alarm, Breaker U	202
BUBITAL	Inactivity time alarm, Breaker U	202
BUESOAL	Slow electrical operation alarm, Breaker U	202
BUKAIAL	Interrupted rms current alarm, Breaker U	202
BUMRTAL	Motor run time alarm, Breaker U	202
BUMSOAL	Mechanical slow operation alarm, Breaker U	202
BWBCWAL	Breaker contact wear alarm, Breaker W	203
BWBITAL	Inactivity time alarm, Breaker W	203
BWESOAL	Slow electrical operation alarm, Breaker W	203
BWKAIAL	Interrupted rms current alarm, Breaker W	203
BWMRTAL	Motor run time alarm, Breaker W	203
BWMSOAL	Mechanical slow operation alarm, Breaker W	203
BXBCWAL	Breaker contact wear alarm, Breaker X	204
BXBITAL	Inactivity time alarm, Breaker X	204
BXESOAL	Slow electrical operation alarm, Breaker X	204
BXKAIAL	Interrupted rms current alarm, Breaker X	204
BXMRTAL	Motor run time alarm, Breaker X	204
BXMSOAL	Mechanical slow operation alarm, Breaker X	204

Table 11.1 Alphabetical List of Relay Word Bits (Sheet 50 of 93)

Name	Bit Description	Row
BYBCWAL	Breaker contact wear alarm, Breaker Y	724
BYBITAL	Inactivity time alarm, Breaker Y	724
BYESOAL	Slow electrical operate alarm, Breaker Y	724
BYKAIAL	Interrupted rms current alarm, Breaker Y	724
BYMRTAL	Motor run time alarm, Breaker Y	724
BYMSOAL	Mechanical slow operation alarm, Breaker Y	724
CBADA	Unavailability threshold exceeded for normal MIRRORED BITS communication, Channel A	380
CBADB	Unavailability threshold exceeded for normal MIRRORED BITS communication, Channel B	381
CCS	Breaker close command, Terminal S	224
CCT	Breaker close command, Terminal T	224
CCU	Breaker close command, Terminal U	224
CCW	Breaker close command, Terminal W	224
CCX	Breaker close command, Terminal X	225
CCY	Breaker close command, Terminal Y	225
CHSG	Settings group changed	244
CLS	Close breaker Terminal S equation	103
CLSS	Close breaker Terminal S output	104
CLST	Close breaker Terminal T output	104
CLSU	Close breaker Terminal U output	104
CLSW	Close breaker Terminal W output	104
CLSX	Close breaker Terminal X output	104
CLSY	Close breaker Terminal Y output	104
CLT	Close breaker Terminal T equation	103
CLU	Close breaker Terminal U equation	103
CLW	Close breaker Terminal W equation	103
CLX	Close breaker Terminal X equation	103
CLY	Close breaker Terminal Y equation	103
CON	Zone 1 external fault detected	5
CON2	Zone 2 external fault detected	709
CONA	Zone 1 external fault detected, A-Phase	5
CONA2	Zone 2 external fault detected, A-Phase	709
CONB	Zone 1 external fault detected, B-Phase	5
CONB2	Zone 2 external fault detected, B-Phase	709
CONC	Zone 1 external fault detected, C-Phase	5
CONC2	Zone 2 external fault detected, C-Phase	709
CSALRM	Cooling stage determination alarm	210
CSCM	Cooling coefficient or measurement alarm	209
CSCM_1	Transformer 1, cooling coefficient or measurement alarm	209
CSCM_2	Transformer 2, cooling coefficient or measurement alarm	209
CSCM_3	Transformer 3, cooling coefficient or measurement alarm	209
CSE	Cooling stage efficiency alarm	209

Table 11.1 Alphabetical List of Relay Word Bits (Sheet 51 of 93)

Name	Bit Description	Row
CSE_1	Transformer 1, cooling stage efficiency alarm	209
CSE_2	Transformer 2, cooling stage efficiency alarm	209
CSE_3	Transformer 3, cooling stage efficiency alarm	209
CTUA	Zone 1 CT in unsaturated state following an external fault, A-Phase	12
CTUB	Zone 1 CT in unsaturated state following an external fault, B-Phase	12
CTUC	Zone 1 CT in unsaturated state following an external fault, C-Phase	12
CVTB1L	Zone 1 CCVT transient blocking logic active, Line 1	631
DC1F	DC Channel 1 failed	220
DC1G	DC Channel 1 ground fault detected	220
DC1R	DC Channel 1 excess ripples detected	220
DC1W	DC Channel 1 warning	220
DIRBLK1	Block Phase and Ground Directional Element ST	504
DIRBLK2	Block Phase and Ground Directional Element TU	505
DIRBLK3	Block Phase and Ground Directional Element UW	506
DIRBLK4	Block Phase and Ground Directional Element WX	507
DIRBLKS	Block Phase and Ground Directional Element S	30
DIRBLKT	Block Phase and Ground Directional Element T	31
DIRBLKU	Block Phase and Ground Directional Element U	32
DIRBLKW	Block Phase and Ground Directional Element W	33
DIRBLKX	Block Phase and Ground Directional Element X	34
DIRBLKY	Block Phase and Ground Directional Element Y	695
DMP01	Demand Metering Element 01 asserted	221
DMP02	Demand Metering Element 02 asserted	221
DMP03	Demand Metering Element 03 asserted	221
DMP04	Demand Metering Element 04 asserted	221
DMP05	Demand Metering Element 05 asserted	222
DMP06	Demand Metering Element 06 asserted	222
DMP07	Demand Metering Element 07 asserted	222
DMP08	Demand Metering Element 08 asserted	222
DMP09	Demand Metering Element 09 asserted	223
DMP10	Demand Metering Element 10 asserted	223
DOKA	MIRRORED BITS Channel A in normal mode	380
DOKB	MIRRORED BITS Channel B in normal mode	381
DST	Daylight-saving time	426
DSTP	IRIG-B daylight-saving time pending	426
E2AC	Enable Level 1–2 access (SELOGIC control equation)	350
E32OP01	Overpower Element 01 enabled	84
E32OP02	Overpower Element 02 enabled	84
E32OP03	Overpower Element 03 enabled	85
E32OP04	Overpower Element 04 enabled	85
E32OP05	Overpower Element 05 enabled	86

Table 11.1 Alphabetical List of Relay Word Bits (Sheet 52 of 93)

Name	Bit Description	Row
E32OP06	Overpower Element 06 enabled	86
E32OP07	Overpower Element 07 enabled	87
E32OP08	Overpower Element 08 enabled	87
E32OP09	Overpower Element 09 enabled	88
E32OP10	Overpower Element 10 enabled	88
E32UP01	Underpower Element 01 enabled	89
E32UP02	Underpower Element 02 enabled	89
E32UP03	Underpower Element 03 enabled	90
E32UP04	Underpower Element 04 enabled	90
E32UP05	Underpower Element 05 enabled	91
E32UP06	Underpower Element 06 enabled	91
E32UP07	Underpower Element 07 enabled	92
E32UP08	Underpower Element 08 enabled	92
E32UP09	Underpower Element 09 enabled	93
E32UP10	Underpower Element 10 enabled	93
E87TS	Zone 1 Terminal S currents included in differential zone	4
E87TS2	Zone 2 Terminal S currents included in differential zone	708
E87TT	Zone 1 Terminal T currents included in differential zone	4
E87TT2	Zone 2 Terminal T currents included in differential zone	708
E87TU	Zone 1 Terminal U currents included in differential zone	4
E87TU2	Zone 2 Terminal U currents included in differential zone	708
E87TW	Zone 1 Terminal W currents included in differential zone	4
E87TW2	Zone 2 Terminal W currents included in differential zone	708
E87TX	Zone 1 Terminal X currents included in differential zone	4
E87TX2	Zone 2 Terminal X currents included in differential zone	708
E87TY	Zone 1 Terminal Y currents included in differential zone	4
E87TY2	Zone 2 Terminal Y currents included in differential zone	708
EACC	Enable Level 1 access (SELOGIC control equation)	350
EAFSRC	Alternative frequency source (SELOGIC control equation)	352
EBFITS	Externally initiated breaker failure timer timed out, Terminal S	110
EBFITT	Externally initiated breaker failure timer timed out, Terminal T	112
EBFITU	Externally initiated breaker failure timer timed out, Terminal U	114
EBFITW	Externally initiated breaker failure timer timed out, Terminal W	116
EBFITX	Externally initiated breaker failure timer timed out, Terminal X	118
EBFITY	Externally initiated breaker failure timer timed out, Terminal Y	744
EBSMON	Breaker monitoring Terminal S enabled	200
EBTMON	Breaker monitoring Terminal T enabled	201
EBUMON	Breaker monitoring Terminal U enabled	202
EBWMON	Breaker monitoring Terminal W enabled	203
EBXMON	Breaker monitoring Terminal X enabled	204
EBYMON	Breaker monitoring Terminal Y enabled	724

Table 11.1 Alphabetical List of Relay Word Bits (Sheet 53 of 93)

Name	Bit Description	Row
EDM01	Demand Metering Element 01 enabled	221
EDM02	Demand Metering Element 02 enabled	221
EDM03	Demand Metering Element 03 enabled	221
EDM04	Demand Metering Element 04 enabled	221
EDM05	Demand Metering Element 05 enabled	222
EDM06	Demand Metering Element 06 enabled	222
EDM07	Demand Metering Element 07 enabled	222
EDM08	Demand Metering Element 08 enabled	222
EDM09	Demand Metering Element 09 enabled	223
EDM10	Demand Metering Element 10 enabled	223
EFDTA	Zone 1 EFD extension timer output, A-Phase	75
EFDTA2	Zone 2 EFD extension timer output, A-Phase	711
EFDTB	Zone 1 EFD extension timer output, B-Phase	75
EFDTB2	Zone 2 EFD extension timer output, B-Phase	711
EFDTC	Zone 1 EFD extension timer output, C-Phase	75
EFDTC2	Zone 2 EFD extension timer output, C-Phase	711
EN	Enable LED on relay front panel	0
ENINBFS	Neutral/residual breaker failure function enabled, Terminal S	111
ENINBFT	Neutral/residual breaker failure function enabled, Terminal T	113
ENINBFU	Neutral/residual breaker failure function enabled, Terminal U	115
ENINBFW	Neutral/residual breaker failure function enabled, Terminal W	117
ENINBFX	Neutral/residual breaker failure function enabled, Terminal X	119
ENINBFY	Neutral/residual breaker failure function enabled, Terminal Y	745
ENX2AB1	Enable AB reactance element, Line 1	647
ENX2AG1	Enable AG reactance element, Line 1	647
ENX2BC1	Enable BC reactance element, Line 1	647
ENX2BG1	Enable BG reactance element, Line 1	647
ENX2CA1	Enable CA reactance element, Line 1	647
ENX2CG1	Enable CG reactance element, Line 1	647
ER	Event report triggered	374
ETHRFLT	Through-fault element enabled	219
EVELOCK	Lock DNP events	431
EXBFS	External breaker failure input initiated, Terminal S	110
EXBFSPS	External breaker failure supervisor, Terminal S	746
EXBFSPT	External breaker failure supervisor, Terminal T	746
EXBFSPU	External breaker failure supervisor, Terminal U	746
EXBFSPW	External breaker failure supervisor, Terminal W	746
EXBFSPX	External breaker failure supervisor, Terminal X	746
EXBFSPY	External breaker failure supervisor, Terminal Y	746
EXBFT	External breaker failure input initiated, Terminal T	112
EXBFU	External breaker failure input initiated, Terminal U	114

Table 11.1 Alphabetical List of Relay Word Bits (Sheet 54 of 93)

Name	Bit Description	Row
EXBFW	External breaker failure input initiated, Terminal W	116
EXBFX	External breaker failure input initiated, Terminal X	118
EXBFY	External breaker failure input initiated, Terminal Y	744
FAA1	Aging insulation acceleration factor alarm, Level 1	207
FAA1_1	Transformer 1, aging insulation acceleration factor alarm, Level 1	207
FAA1_2	Transformer 1, aging insulation acceleration factor alarm, Level 2	207
FAA2	Aging insulation acceleration factor alarm, Level 2	207
FAA2_1	Transformer 2, aging insulation acceleration factor alarm, Level 1	207
FAA2_2	Transformer 2, aging insulation acceleration factor alarm, Level 2	207
FAA3_1	Transformer 3, aging insulation acceleration factor alarm, Level 1	207
FAA3_2	Transformer 3, aging insulation acceleration factor alarm, Level 2	207
FASTS	Breaker S synchronizing voltage slipping faster than polarizing voltage	448
FASTT	Breaker T synchronizing voltage slipping faster than polarizing voltage	448
FASTU	Breaker U synchronizing voltage slipping faster than polarizing voltage	448
FASTW	Breaker W synchronizing voltage slipping faster than polarizing voltage	448
FASTX	Breaker X synchronizing voltage slipping faster than polarizing voltage	448
FASTY	Breaker Y synchronizing voltage slipping faster than polarizing voltage	448
FAULT	Fault detected	374
FBFS	Breaker failure asserted/initiated, Terminal S	111
FBFT	Breaker failure asserted/initiated, Terminal T	113
FBFU	Breaker failure asserted/initiated, Terminal U	115
FBFW	Breaker failure asserted/initiated, Terminal W	117
FBFX	Breaker failure asserted/initiated, Terminal X	119
FBFY	Breaker failure asserted/initiated, Terminal Y	745
FIDEN_S	FIDEN logic enabled, Terminal S	461
FIDEN_T	FIDEN logic enabled, Terminal T	461
FIDEN_U	FIDEN logic enabled, Terminal U	461
FIDEN_W	FIDEN logic enabled, Terminal W	461
FIDEN_X	FIDEN logic enabled, Terminal X	461
FIDEN_Y	FIDEN logic enabled, Terminal Y	463
FIDENL1	FIDEN logic enabled, Line 1	627
FOP1_01	PORT 1 Fast Operate Transmit Bit 1	436
FOP1_02	PORT 1 Fast Operate Transmit Bit 2	436
FOP1_03	PORT 1 Fast Operate Transmit Bit 3	436
FOP1_04	PORT 1 Fast Operate Transmit Bit 4	436
FOP1_05	PORT 1 Fast Operate Transmit Bit 5	436
FOP1_06	PORT 1 Fast Operate Transmit Bit 6	436
FOP1_07	PORT 1 Fast Operate Transmit Bit 7	436
FOP1_08	PORT 1 Fast Operate Transmit Bit 8	436
FOP1_09	PORT 1 Fast Operate Transmit Bit 9	437
FOP1_10	PORT 1 Fast Operate Transmit Bit 10	437

Table 11.1 Alphabetical List of Relay Word Bits (Sheet 55 of 93)

Name	Bit Description	Row
FOP1_11	PORT 1 Fast Operate Transmit Bit 11	437
FOP1_12	PORT 1 Fast Operate Transmit Bit 12	437
FOP1_13	PORT 1 Fast Operate Transmit Bit 13	437
FOP1_14	PORT 1 Fast Operate Transmit Bit 14	437
FOP1_15	PORT 1 Fast Operate Transmit Bit 15	437
FOP1_16	PORT 1 Fast Operate Transmit Bit 16	437
FOP1_17	PORT 1 Fast Operate Transmit Bit 17	438
FOP1_18	PORT 1 Fast Operate Transmit Bit 18	438
FOP1_19	PORT 1 Fast Operate Transmit Bit 19	438
FOP1_20	PORT 1 Fast Operate Transmit Bit 20	438
FOP1_21	PORT 1 Fast Operate Transmit Bit 21	438
FOP1_22	PORT 1 Fast Operate Transmit Bit 22	438
FOP1_23	PORT 1 Fast Operate Transmit Bit 23	438
FOP1_24	PORT 1 Fast Operate Transmit Bit 24	438
FOP1_25	PORT 1 Fast Operate Transmit Bit 25	439
FOP1_26	PORT 1 Fast Operate Transmit Bit 26	439
FOP1_27	PORT 1 Fast Operate Transmit Bit 27	439
FOP1_28	PORT 1 Fast Operate Transmit Bit 28	439
FOP1_29	PORT 1 Fast Operate Transmit Bit 29	439
FOP1_30	PORT 1 Fast Operate Transmit Bit 30	439
FOP1_31	PORT 1 Fast Operate Transmit Bit 31	439
FOP1_32	PORT 1 Fast Operate Transmit Bit 32	439
FOP2_01	PORT 2 Fast Operate Transmit Bit 1	440
FOP2_02	PORT 2 Fast Operate Transmit Bit 2	440
FOP2_03	PORT 2 Fast Operate Transmit Bit 3	440
FOP2_04	PORT 2 Fast Operate Transmit Bit 4	440
FOP2_05	PORT 2 Fast Operate Transmit Bit 5	440
FOP2_06	PORT 2 Fast Operate Transmit Bit 6	440
FOP2_07	PORT 2 Fast Operate Transmit Bit 7	440
FOP2_08	PORT 2 Fast Operate Transmit Bit 8	440
FOP2_09	PORT 2 Fast Operate Transmit Bit 9	441
FOP2_10	PORT 2 Fast Operate Transmit Bit 10	441
FOP2_11	PORT 2 Fast Operate Transmit Bit 11	441
FOP2_12	PORT 2 Fast Operate Transmit Bit 12	441
FOP2_13	PORT 2 Fast Operate Transmit Bit 13	441
FOP2_14	PORT 2 Fast Operate Transmit Bit 14	441
FOP2_15	PORT 2 Fast Operate Transmit Bit 15	441
FOP2_16	PORT 2 Fast Operate Transmit Bit 16	441
FOP2_17	PORT 2 Fast Operate Transmit Bit 17	442
FOP2_18	PORT 2 Fast Operate Transmit Bit 18	442
FOP2_19	PORT 2 Fast Operate Transmit Bit 19	442

Table 11.1 Alphabetical List of Relay Word Bits (Sheet 56 of 93)

Name	Bit Description	Row
FOP2_20	PORT 2 Fast Operate Transmit Bit 20	442
FOP2_21	PORT 2 Fast Operate Transmit Bit 21	442
FOP2_22	PORT 2 Fast Operate Transmit Bit 22	442
FOP2_23	PORT 2 Fast Operate Transmit Bit 23	442
FOP2_24	PORT 2 Fast Operate Transmit Bit 24	442
FOP2_25	PORT 2 Fast Operate Transmit Bit 25	443
FOP2_26	PORT 2 Fast Operate Transmit Bit 26	443
FOP2_27	PORT 2 Fast Operate Transmit Bit 27	443
FOP2_28	PORT 2 Fast Operate Transmit Bit 28	443
FOP2_29	PORT 2 Fast Operate Transmit Bit 29	443
FOP2_30	PORT 2 Fast Operate Transmit Bit 30	443
FOP2_31	PORT 2 Fast Operate Transmit Bit 31	443
FOP2_32	PORT 2 Fast Operate Transmit Bit 32	443
FOP3_01	PORT 3 Fast Operate Transmit Bit 1	444
FOP3_02	PORT 3 Fast Operate Transmit Bit 2	444
FOP3_03	PORT 3 Fast Operate Transmit Bit 3	444
FOP3_04	PORT 3 Fast Operate Transmit Bit 4	444
FOP3_05	PORT 3 Fast Operate Transmit Bit 5	444
FOP3_06	PORT 3 Fast Operate Transmit Bit 6	444
FOP3_07	PORT 3 Fast Operate Transmit Bit 7	444
FOP3_08	PORT 3 Fast Operate Transmit Bit 8	444
FOP3_09	PORT 3 Fast Operate Transmit Bit 9	445
FOP3_10	PORT 3 Fast Operate Transmit Bit 10	445
FOP3_11	PORT 3 Fast Operate Transmit Bit 11	445
FOP3_12	PORT 3 Fast Operate Transmit Bit 12	445
FOP3_13	PORT 3 Fast Operate Transmit Bit 13	445
FOP3_14	PORT 3 Fast Operate Transmit Bit 14	445
FOP3_15	PORT 3 Fast Operate Transmit Bit 15	445
FOP3_16	PORT 3 Fast Operate Transmit Bit 16	445
FOP3_17	PORT 3 Fast Operate Transmit Bit 17	446
FOP3_18	PORT 3 Fast Operate Transmit Bit 18	446
FOP3_19	PORT 3 Fast Operate Transmit Bit 19	446
FOP3_20	PORT 3 Fast Operate Transmit Bit 20	446
FOP3_21	PORT 3 Fast Operate Transmit Bit 21	446
FOP3_22	PORT 3 Fast Operate Transmit Bit 22	446
FOP3_23	PORT 3 Fast Operate Transmit Bit 23	446
FOP3_24	PORT 3 Fast Operate Transmit Bit 24	446
FOP3_25	PORT 3 Fast Operate Transmit Bit 25	447
FOP3_26	PORT 3 Fast Operate Transmit Bit 26	447
FOP3_27	PORT 3 Fast Operate Transmit Bit 27	447
FOP3_28	PORT 3 Fast Operate Transmit Bit 28	447

Table 11.1 Alphabetical List of Relay Word Bits (Sheet 57 of 93)

Name	Bit Description	Row
FOP3_29	PORT 3 Fast Operate Transmit Bit 29	447
FOP3_30	PORT 3 Fast Operate Transmit Bit 30	447
FOP3_31	PORT 3 Fast Operate Transmit Bit 31	447
FOP3_32	PORT 3 Fast Operate Transmit Bit 32	447
FOPF_01	PORT F (front-panel) Fast Operate Transmit Bit 1	432
FOPF_02	PORT F (front-panel) Fast Operate Transmit Bit 2	432
FOPF_03	PORT F (front-panel) Fast Operate Transmit Bit 3	432
FOPF_04	PORT F (front-panel) Fast Operate Transmit Bit 4	432
FOPF_05	PORT F (front-panel) Fast Operate Transmit Bit 5	432
FOPF_06	PORT F (front-panel) Fast Operate Transmit Bit 6	432
FOPF_07	PORT F (front-panel) Fast Operate Transmit Bit 7	432
FOPF_08	PORT F (front-panel) Fast Operate Transmit Bit 8	432
FOPF_09	PORT F (front-panel) Fast Operate Transmit Bit 9	433
FOPF_10	PORT F (front-panel) Fast Operate Transmit Bit 10	433
FOPF_11	PORT F (front-panel) Fast Operate Transmit Bit 11	433
FOPF_12	PORT F (front-panel) Fast Operate Transmit Bit 12	433
FOPF_13	PORT F (front-panel) Fast Operate Transmit Bit 13	433
FOPF_14	PORT F (front-panel) Fast Operate Transmit Bit 14	433
FOPF_15	PORT F (front-panel) Fast Operate Transmit Bit 15	433
FOPF_16	PORT F (front-panel) Fast Operate Transmit Bit 16	433
FOPF_17	PORT F (front-panel) Fast Operate Transmit Bit 17	434
FOPF_18	PORT F (front-panel) Fast Operate Transmit Bit 18	434
FOPF_19	PORT F (front-panel) Fast Operate Transmit Bit 19	434
FOPF_20	PORT F (front-panel) Fast Operate Transmit Bit 20	434
FOPF_21	PORT F (front-panel) Fast Operate Transmit Bit 21	434
FOPF_22	PORT F (front-panel) Fast Operate Transmit Bit 22	434
FOPF_23	PORT F (front-panel) Fast Operate Transmit Bit 23	434
FOPF_24	PORT F (front-panel) Fast Operate Transmit Bit 24	434
FOPF_25	PORT F (front-panel) Fast Operate Transmit Bit 25	435
FOPF_26	PORT F (front-panel) Fast Operate Transmit Bit 26	435
FOPF_27	PORT F (front-panel) Fast Operate Transmit Bit 27	435
FOPF_28	PORT F (front-panel) Fast Operate Transmit Bit 28	435
FOPF_29	PORT F (front-panel) Fast Operate Transmit Bit 29	435
FOPF_30	PORT F (front-panel) Fast Operate Transmit Bit 30	435
FOPF_31	PORT F (front-panel) Fast Operate Transmit Bit 31	435
FOPF_32	PORT F (front-panel) Fast Operate Transmit Bit 32	435
FREQFZ	Assert if relay is not calculating frequency	352
FREQOK	Assert if relay is estimating frequency	352
FROKPM	Synchrophasor frequency measurement OK	417
FSA_L1	A-Phase sector fault (AG or BCG fault), Line 1	627
FSA_S	A-Phase sector fault (AG or BCG fault), Terminal S	461

Table 11.1 Alphabetical List of Relay Word Bits (Sheet 58 of 93)

Name	Bit Description	Row
FSA_T	A-Phase sector fault (AG or BCG fault), Terminal T	461
FSA_U	A-Phase sector fault (AG or BCG fault), Terminal U	461
FSA_W	A-Phase sector fault (AG or BCG fault), Terminal W	462
FSA_X	A-Phase sector fault (AG or BCG fault), Terminal X	462
FSA_Y	A-Phase sector fault (AG or BCG fault), Terminal Y	463
FSB_L1	B-Phase sector fault (BG or CAG fault), Line 1	627
FSB_S	B-Phase sector fault (BG or CAG fault), Terminal S	462
FSB_T	B-Phase sector fault (BG or CAG fault), Terminal T	462
FSB_U	B-Phase sector fault (BG or CAG fault), Terminal U	462
FSB_W	B-Phase sector fault (BG or CAG fault), Terminal W	462
FSB_X	B-Phase sector fault (BG or CAG fault), Terminal X	462
FSB_Y	B-Phase sector fault (BG or CAG fault), Terminal Y	463
FSC_L1	C-Phase sector fault (CG or ABG fault), Line 1	627
FSC_S	C-Phase sector fault (CG or ABG fault), Terminal S	462
FSC_T	C-Phase sector fault (CG or ABG fault), Terminal T	463
FSC_U	C-Phase sector fault (CG or ABG fault), Terminal U	463
FSC_W	C-Phase sector fault (CG or ABG fault), Terminal W	463
FSC_X	C-Phase sector fault (CG or ABG fault), Terminal X	463
FSC_Y	C-Phase sector fault (CG or ABG fault), Terminal Y	463
FSERP1	Fast SER enabled for PORT 1	416
FSERP2	Fast SER enabled for PORT 2	416
FSERP3	Fast SER enabled for PORT 3	416
FSERP5	Fast SER enabled for network port	416
FSERPF	Fast SER enabled for front port	416
GFLTA	Zone 1 Instantaneous fault detector asserted, A-Phase	6
GFLTA2	Zone 2 instantaneous fault detector asserted, A-Phase	707
GFLTB	Zone 1 Instantaneous fault detector asserted, B-Phase	6
GFLTB2	Zone 2 instantaneous fault detector asserted, B-Phase	707
GFLTC	Zone 1 Instantaneous fault detector asserted, C-Phase	6
GFLTC2	Zone 2 instantaneous fault detector asserted, C-Phase	707
GROUNDS	Ground involved in the fault, Terminal S	459
GROUNDT	Ground involved in the fault, Terminal T	460
GROUNDU	Ground involved in the fault, Terminal U	460
GROUNDW	Ground involved in the fault, Terminal W	460
GROUNDX	Ground involved in the fault, Terminal X	460
GROUNDY	Ground involved in the fault, Terminal Y	460
GRPSW	Pulsed alarm for Group switches	349
H2BK1	Second-harmonic blocking asserted, Terminal ST	750
H2BK2	Second-harmonic blocking asserted, Terminal TU	750
H2BK3	Second-harmonic blocking asserted, Terminal UW	751
H2BK4	Second-harmonic blocking asserted, Terminal WX	751

Table 11.1 Alphabetical List of Relay Word Bits (Sheet 59 of 93)

Name	Bit Description	Row
H2BKL1	Second- or fourth-harmonic blocking asserted, Line 1	630
H2BKS	Second-harmonic blocking asserted, Terminal S	747
H2BKT	Second-harmonic blocking asserted, Terminal T	747
H2BKU	Second-harmonic blocking asserted, Terminal U	748
H2BKW	Second-harmonic blocking asserted, Terminal W	748
H2BKX	Second-harmonic blocking asserted, Terminal X	749
H2BKY	Second-harmonic blocking asserted, Terminal Y	749
H5BKL1	Fifth-harmonic blocking asserted, Line 1	630
HALARM	Hardware alarm	349
HALARMA	Pulse stream for unacknowledged diagnostic warnings	349
HALARML	Latched alarm for diagnostic failures	349
HALARMP	Pulsed alarm for diagnostic warnings	349
HS1	Hot-spot alarm Level 1	206
HS1_1	Transformer 1, hot-spot temperature alarm Level 1	206
HS1_2	Transformer 1, hot-spot temperature alarm Level 2	206
HS2	Hot-spot alarm Level 2	206
HS2_1	Transformer 2, hot-spot temperature alarm Level 1	206
HS2_2	Transformer 2, hot-spot temperature alarm Level 2	206
HS3_1	Transformer 3, hot-spot temperature alarm Level 1	206
HS3_2	Transformer 3, hot-spot temperature alarm Level 2	206
HSRAOK	HSR Port 5A status	654
HSRBOK	HSR Port 5B status	654
HSRCOK	HSR Port 5C status	654
HSRDOK	HSR Port 5D status	654
IA12BK	Second-harmonic blocking asserted, A-Phase, Terminal ST	750
IA22BK	Second-harmonic blocking asserted, A-Phase, Terminal TU	750
IA2BKL1	Second- or fourth-harmonic blocking asserted, A-Phase, Line 1	630
IA32BK	Second-harmonic blocking asserted, A-Phase, Terminal UW	751
IA42BK	Second-harmonic blocking asserted, A-Phase, Terminal WX	751
IA5BKL1	Fifth-harmonic blocking asserted, A-Phase, Line 1	630
IAS2BK	Second-harmonic blocking asserted, A-Phase, Terminal S	747
IASBF	A-Phase current above threshold, Terminal S	111
IASBK	A-Phase, Terminal S is not OK (use for blocking)	548
IASMAP	A-Phase, Terminal S is mapped in a subscription	540
IASOK	A-Phase, Terminal S configured channel data OK	544
IAT2BK	Second-harmonic blocking asserted, A-Phase, Terminal T	747
IATBF	A-Phase current above threshold, Terminal T	113
IATBK	A-Phase, Terminal T is not OK (use for blocking)	548
IATMAP	A-Phase, Terminal T is mapped in a subscription	540
IATOK	A-Phase, Terminal T configured channel data OK	544
IAU2BK	Second-harmonic blocking asserted, A-Phase, Terminal U	748

Table 11.1 Alphabetical List of Relay Word Bits (Sheet 60 of 93)

Name	Bit Description	Row
IAUBF	A-Phase current above threshold, Terminal U	115
IAUBK	A-Phase, Terminal U is not OK (use for blocking)	549
IAUMAP	A-Phase, Terminal U is mapped in a subscription	541
IAUOK	A-Phase, Terminal U configured channel data OK	545
IAW2BK	Second-harmonic blocking asserted, A-Phase, Terminal W	748
IAWBF	A-Phase current above threshold, Terminal W	117
IAWBK	A-Phase, Terminal W is not OK (use for blocking)	548
IAWMAP	A-Phase, Terminal W is mapped in a subscription	540
IAWOK	A-Phase, Terminal W configured channel data OK	544
IAX2BK	Second-harmonic blocking asserted, A-Phase, Terminal X	749
IAXBF	A-Phase current above threshold, Terminal X	119
IAXBK	A-Phase, Terminal X is not OK (use for blocking)	548
IAXMAP	A-Phase, Terminal X is mapped in a subscription	540
IAXOK	A-Phase, Terminal X configured channel data OK	544
IAY2BK	Second-harmonic blocking asserted, A-Phase, Terminal Y	749
IAYBF	A-Phase current above threshold, Terminal Y	745
IAYBK	A-Phase, Terminal Y is not OK (use for blocking)	551
IAYMAP	A-Phase, Terminal Y is mapped in a subscription	543
IAYOK	A-Phase, Terminal Y configured channel data OK	547
IB12BK	Second-harmonic blocking asserted, B-Phase, Terminal ST	750
IB22BK	Second-harmonic blocking asserted, B-Phase, Terminal TU	750
IB2BKL1	Second- or fourth-harmonic blocking asserted, B-Phase, Line 1	630
IB32BK	Second-harmonic blocking asserted, B-Phase, Terminal UW	751
IB42BK	Second-harmonic blocking asserted, B-Phase, Terminal WX	751
IB5BKL1	Fifth-harmonic blocking asserted, B-Phase, Line 1	630
IBS2BK	Second-harmonic blocking asserted, B-Phase, Terminal S	747
IBSBF	B-Phase current above threshold, Terminal S	111
IBSBK	B-Phase, Terminal S is not OK (use for blocking)	548
IBSMAP	B-Phase, Terminal S is mapped in a subscription	540
IBSOK	B-Phase, Terminal S configured channel data OK	544
IBT2BK	Second-harmonic blocking asserted, B-Phase, Terminal T	747
IBTBF	B-Phase current above threshold, Terminal T	113
IBTBK	B-Phase, Terminal T is not OK (use for blocking)	549
IBTMAP	B-Phase, Terminal T is mapped in a subscription	541
IBTOK	B-Phase, Terminal T configured channel data OK	545
IBU2BK	Second-harmonic blocking asserted, B-Phase, Terminal U	748
IBUBF	B-Phase current above threshold, Terminal U	115
IBUBK	B-Phase, Terminal U is not OK (use for blocking)	549
IBUMAP	B-Phase, Terminal U is mapped in a subscription	541
IBUOK	B-Phase, Terminal U configured channel data OK	545
IBW2BK	Second-harmonic blocking asserted, B-Phase, Terminal W	748

Table 11.1 Alphabetical List of Relay Word Bits (Sheet 61 of 93)

Name	Bit Description	Row
IBWBF	B-Phase current above threshold, Terminal W	117
IBWBK	B-Phase, Terminal W is not OK (use for blocking)	548
IBWMAP	B-Phase, Terminal W is mapped in a subscription	540
IBWOK	B-Phase, Terminal W configured channel data OK	544
IBX2BK	Second-harmonic blocking asserted, B-Phase, Terminal X	749
IBXBF	B-Phase current above threshold, Terminal X	119
IBXBK	B-Phase, Terminal X is not OK (use for blocking)	549
IBXMAP	B-Phase, Terminal X is mapped in a subscription	541
IBXOK	B-Phase, Terminal X configured channel data OK	545
IBY2BK	Second-harmonic blocking asserted, B-Phase, Terminal Y	749
IBYBF	B-Phase current above threshold, Terminal Y	745
IBYBK	B-Phase, Terminal Y is not OK (use for blocking)	551
IBYMAP	B-Phase, Terminal Y is mapped in a subscription	543
IBYOK	B-Phase, Terminal Y configured channel data OK	547
IC12BK	Second-harmonic blocking asserted, C-Phase, Terminal ST	750
IC22BK	Second-harmonic blocking asserted, C-Phase, Terminal TU	750
IC2BKL1	Second- or fourth-harmonic blocking asserted, C-Phase, Line 1	630
IC32BK	Second-harmonic blocking asserted, C-Phase, Terminal UW	751
IC42BK	Second-harmonic blocking asserted, C-Phase, Terminal WX	751
IC5BKL1	Fifth-harmonic blocking asserted, C-Phase, Line 1	630
ICS2BK	Second-harmonic blocking asserted, C-Phase, Terminal S	747
ICSBF	C-Phase current above threshold, Terminal S	111
ICSBK	C-Phase, Terminal S is not OK (use for blocking)	548
ICSMAP	C-Phase, Terminal S is mapped in a subscription	540
ICSOK	C-Phase, Terminal S configured channel data OK	544
ICT2BK	Second-harmonic blocking asserted, C-Phase, Terminal T	747
ICTBF	C-Phase current above threshold, Terminal T	113
ICTBK	C-Phase, Terminal T is not OK (use for blocking)	549
ICTMAP	C-Phase, Terminal T is mapped in a subscription	541
ICTOK	C-Phase, Terminal T configured channel data OK	545
ICU2BK	Second-harmonic blocking asserted, C-Phase, Terminal U	748
ICUBF	C-Phase current above threshold, Terminal U	115
ICUBK	C-Phase, Terminal U is not OK (use for blocking)	550
ICUMAP	C-Phase, Terminal U is mapped in a subscription	542
ICUOK	C-Phase, Terminal U configured channel data OK	546
ICW2BK	Second-harmonic blocking asserted, C-Phase, Terminal W	748
ICWBF	C-Phase current above threshold, Terminal W	117
ICWBK	C-Phase, Terminal W is not OK (use for blocking)	548
ICWMAP	C-Phase, Terminal W is mapped in a subscription	540
ICWOK	C-Phase, Terminal W configured channel data OK	544
ICX2BK	Second-harmonic blocking asserted, C-Phase, Terminal X	749

Table 11.1 Alphabetical List of Relay Word Bits (Sheet 62 of 93)

Name	Bit Description	Row
ICXBF	C-Phase current above threshold, Terminal X	119
ICXBK	C-Phase, Terminal X is not OK (use for blocking)	549
ICXMAP	C-Phase, Terminal X is mapped in a subscription	541
ICXOK	C-Phase, Terminal X configured channel data OK	545
ICY2BK	Second-harmonic blocking asserted, C-Phase, Terminal Y	749
ICYBF	C-Phase current above threshold, Terminal Y	745
ICYBK	C-Phase, Terminal Y is not OK (use for blocking)	551
ICYMAP	C-Phase, Terminal Y is mapped in a subscription	543
ICYOK	C-Phase, Terminal Y configured channel data OK	547
IFLTA	Zone 1 internal fault detected, A-Phase	7
IFLTA2	Zone 2 internal fault detected, A-Phase	709
IFLTB	Zone 1 internal fault detected, B-Phase	7
IFLTB2	Zone 2 internal fault detected, B-Phase	709
IFLTC	Zone 1 internal fault detected, C-Phase	7
IFLTC2	Zone 2 internal fault detected, C-Phase	709
ILOPL1	Internal loss of potential, Line 1	628
ILOPV	Internal loss of potential, Terminal V	109
ILOPZ	Internal loss of potential, Terminal Z	109
IN201–IN208	Input 201–208 asserted	252
IN209–IN216	Input 209–216 asserted	253
IN217–IN224	Input 217–224 asserted	254
IN301–IN308	Input 301–308 asserted	256
IN309–IN316	Input 309–316 asserted	257
IN317–IN324	Input 317–324 asserted	258
IN401–IN408	Input 401–408 asserted	472
IN409–IN416	Input 409–416 asserted	473
IN417–IN424	Input 417–424 asserted	474
IN501–IN508	Input 501-508 asserted	476
IN509–IN516	Input 509-516 asserted	477
IN517–IN524	Input 517–524 asserted	478
INSBF	Neutral current above threshold, Terminal S	111
INTBF	Neutral/residual current exceeds pickup threshold, Terminal T	113
INUBF	Neutral/residual current exceeds pickup threshold, Terminal U	115
INWBF	Neutral/residual current exceeds pickup threshold, Terminal W	117
INXBF	Neutral/residual current exceeds pickup threshold, Terminal X	119
INYBF	Neutral/residual current exceeds pickup threshold, Terminal Y	745
ISBK	Current Terminal S data not OK (use for blocking)	552
ISFZ	Terminal S freeze bit for use in open phase logic and breaker failure logic	554
ISOK	Current Terminal S data OK	553
ITBK	Current Terminal T data not OK (use for blocking)	552
ITFZ	Terminal T freeze bit for use in open phase logic and breaker failure logic	554

Table 11.1 Alphabetical List of Relay Word Bits (Sheet 63 of 93)

Name	Bit Description	Row
ITOK	Current Terminal T data OK	553
IUBK	Current Terminal U data not OK (use for blocking)	552
IUFZ	Terminal U freeze bit for use in open phase logic and breaker failure logic	554
IUOK	Current Terminal U data OK	553
IWBK	Current Terminal W data not OK (use for blocking)	552
IWFZ	Terminal W freeze bit for use in open phase logic and breaker failure logic	554
IWOK	Current Terminal W data OK	553
IXBK	Current Terminal X data not OK (use for blocking)	552
IXFZ	Terminal X freeze bit for use in open phase logic and breaker failure logic	554
IXOK	Current Terminal X data OK	553
IY1BK	Channel 1, Terminal Y is not OK (use for blocking)	549
IY1MAP	Channel 1, Terminal Y is mapped in a subscription	541
IY1OK	Channel 1, Terminal Y configured channel data OK	545
IY2BK	Channel 2, Terminal Y is not OK (use for blocking)	549
IY2MAP	Channel 2, Terminal Y is mapped in a subscription	541
IY2OK	Channel 2, Terminal Y configured channel data OK	545
IY3BK	Channel 3, Terminal Y is not OK (use for blocking)	550
IY3MAP	Channel 3, Terminal Y is mapped in a subscription	542
IY3OK	Channel 3, Terminal Y configured channel data OK	546
IYBK	Current Terminal Y data not OK (use for blocking)	552
IYFZ	Terminal Y freeze bit for use in open phase logic and breaker failure logic	554
IYOK	Current Terminal Y data OK	553
L132QE	Negative-sequence phase directional element enabled, Line 1	624
L132QGE	Negative-sequence ground directional element enabled, Line 1	624
L132VE	Zero-sequence voltage directional element enabled, Line 1	624
L13PO	Three poles open, Line 1	629
L150GF	Zero-sequence current above forward threshold, Line 1	624
L150GR	Zero-sequence current above reverse threshold, Terminal Line 1	624
L150QF	Negative-sequence current above forward threshold, Line 1	624
L150QR	Negative-sequence current above reserve threshold, Line 1	624
L1F32G	Forward ground directional element asserted, Line 1	625
L1F32P	Forward phase directional element asserted, Line 1	626
L1F32Q	Forward negative-sequence phase directional element asserted, Line 1	626
L1F32QG	Forward negative-sequence ground directional element asserted, Line 1	624
L1F32V	Forward zero-sequence ground directional element asserted, Line 1	625
L1OPHA	A-Phase open, Line 1	629
L1OPHB	B-Phase open, Line 1	629
L1OPHC	C-Phase open, Line 1	629
L1PO	Any pole open, Line 1	629
L1POA	A-Phase pole open, Line 1	629
L1POB	B-Phase pole open, Line 1	629

Table 11.1 Alphabetical List of Relay Word Bits (Sheet 64 of 93)

Name	Bit Description	Row
L1POC	C-Phase pole open, Line 1	629
L1R32G	Reserve ground directional element asserted, Line 1	625
L1R32P	Reverse phase directional element asserted, Line 1	626
L1R32Q	Reverse negative-sequence phase directional element asserted, Line 1	626
L1R32QG	Reverse negative-sequence ground directional element asserted, Line 1	625
L1R32V	Reverse zero-sequence ground directional element asserted, Line 1	625
LB_DP01–LB_DP08	Local Bit 01–Local Bit 08 status display enabled	235
LB_DP09–LB_DP16	Local Bit 09–Local Bit 16 status display enabled	236
LB_DP17–LB_DP24	Local Bit 17–Local Bit 24 status display enabled	237
LB_DP25–LB_DP32	Local Bit 25–Local Bit 32 status display enabled	238
LB_DP33–LB_DP40	Local Bit 33–Local Bit 40 status display enabled	608
LB_DP41–LB_DP48	Local Bit 41–Local Bit 48 status display enabled	609
LB_DP49–LB_DP56	Local Bit 49–Local Bit 56 status display enabled	610
LB_DP57–LB_DP64	Local Bit 57–Local Bit 64 status display enabled	611
LB_DP65–LB_DP72	Local Bit 65–Local Bit 72 status display enabled	720
LB_DP73–LB_DP80	Local Bit 73–Local Bit 80 status display enabled	721
LB_DP81–LB_DP88	Local Bit 81–Local Bit 88 status display enabled	722
LB_DP89–LB_DP96	Local Bit 89–Local Bit 96 status display enabled	723
LB_SP01–LB_SP08	Local Bit 01–Local Bit 08 supervision enabled	231
LB_SP09–LB_SP16	Local Bit 09–Local Bit 16 supervision enabled	232
LB_SP17–LB_SP24	Local Bit 17–Local Bit 24 supervision enabled	233
LB_SP25–LB_SP32	Local Bit 25–Local Bit 32 supervision enabled	234
LB_SP33–LB_SP40	Local Bit 33–Local Bit 40 supervision enabled	604
LB_SP41–LB_SP48	Local Bit 41–Local Bit 48 supervision enabled	605
LB_SP49–LB_SP56	Local Bit 49–Local Bit 56 supervision enabled	606
LB_SP57–LB_SP64	Local Bit 57–Local Bit 64 supervision enabled	607
LB_SP65–LB_SP72	Local Bit 65–Local Bit 72 supervision enabled	716

Table 11.1 Alphabetical List of Relay Word Bits (Sheet 65 of 93)

Name	Bit Description	Row
LB_SP73–LB_SP80	Local Bit 73–Local Bit 80 supervision enabled	717
LB_SP81–LB_SP88	Local Bit 81–Local Bit 88 supervision enabled	718
LB_SP89–LB_SP96	Local Bit 89–Local Bit 96 supervision enabled	719
LB01–LB08	Local Bit 01–Local Bit 08 asserted	227
LB09–LB16	Local Bit 09–Local Bit 16 asserted	228
LB17–LB24	Local Bit 17–Local Bit 24 asserted	229
LB25–LB32	Local Bit 25–Local Bit 32 asserted	230
LB33–LB40	Local Bit 33–Local Bit 40 asserted	600
LB41–LB48	Local Bit 41–Local Bit 48 asserted	601
LB49–LB56	Local Bit 49–Local Bit 56 asserted	602
LB57–LB64	Local Bit 57–Local Bit 64 asserted	603
LB65–LB72	Local Bit 65–Local Bit 72 asserted	712
LB73–LB80	Local Bit 73–Local Bit 80 asserted	713
LB81–LB88	Local Bit 81–Local Bit 88 asserted	714
LB89–LB96	Local Bit 89–Local Bit 96 asserted	715
LBOKA	MIRRORED BITS channel in loopback mode, Channel A	380
LBOKB	MIRRORED BITS channel in loopback mode, Channel B	381
LD_3PFS	Leading three-phase power factor, Terminal S	484
LD_3PFT	Leading three-phase power factor, Terminal T	485
LD_3PFU	Leading three-phase power factor, Terminal U	486
LD_3PFW	Leading three-phase power factor, Terminal W	487
LD_3PFX	Leading three-phase power factor, Terminal X	488
LD_3PFY	Leading three-phase power factor, Terminal Y	122
LD_APFS	Leading power factor, A-Phase, Terminal S	484
LD_APFT	Leading power factor, A-Phase, Terminal T	485
LD_APFU	Leading power factor, A-Phase, Terminal U	486
LD_APFW	Leading power factor, A-Phase, Terminal W	487
LD_APFX	Leading power factor, A-Phase, Terminal X	488
LD_APFY	Leading power factor, A-Phase, Terminal Y	122
LD_BPFS	Leading power factor, B-Phase, Terminal S	484
LD_BPFT	Leading power factor, B-Phase, Terminal T	485
LD_BPFU	Leading power factor, B-Phase, Terminal U	486
LD_BPFW	Leading power factor, B-Phase, Terminal W	487
LD_BPFX	Leading power factor, B-Phase, Terminal X	488
LD_BPFY	Leading power factor, B-Phase, Terminal Y	122
LD_CPFS	Leading power factor, C-Phase, Terminal S	484
LD_CPFT	Leading power factor, C-Phase, Terminal T	485
LD_CPFU	Leading power factor, C-Phase, Terminal U	486
LD_CPFW	Leading power factor, C-Phase, Terminal W	487

Table 11.1 Alphabetical List of Relay Word Bits (Sheet 66 of 93)

Name	Bit Description	Row
LD_CPFX	Leading power factor, C-Phase, Terminal X	488
LD_CPFY	Leading power factor, C-Phase, Terminal Y	122
LD3PFST	Leading three-phase power factor, Combined Terminals ST	489
LD3PFTU	Leading three-phase power factor, Combined Terminals TU	490
LD3PFUW	Leading three-phase power factor, Combined Terminals UW	491
LD3PFWX	Leading three-phase power factor, Combined Terminals WX	492
LDAPFST	Leading power factor, A-Phase, Combined Terminals ST	489
LDAPFTU	Leading power factor, A-Phase, Combined Terminals TU	490
LDAPFUW	Leading power factor, A-Phase, Combined Terminals UW	491
LDAPFWX	Leading power factor, A-Phase, Combined Terminals WX	492
LDBPFST	Leading power factor, B-Phase, Combined Terminals ST	489
LDBPFTU	Leading power factor, B-Phase, Combined Terminals TU	490
LDBPFUW	Leading power factor, B-Phase, Combined Terminals UW	491
LDBPFWX	Leading power factor, B-Phase, Combined Terminals WX	492
LDCPFST	Leading power factor, C-Phase, Combined Terminals ST	489
LDCPFTU	Leading power factor, C-Phase, Combined Terminals TU	490
LDCPFUW	Leading power factor, C-Phase, Combined Terminals UW	491
LDCPFWX	Leading power factor, C-Phase, Combined Terminals WX	492
LG_3PFS	Lagging three-phase power factor, Terminal S	484
LG_3PFT	Lagging three-phase power factor, Terminal T	485
LG_3PFU	Lagging three-phase power factor, Terminal U	486
LG_3PFW	Lagging three-phase power factor, Terminal W	487
LG_3PFX	Lagging three-phase power factor, Terminal X	488
LG_3PFY	Lagging three-phase power factor, Terminal Y	122
LG_APFS	Lagging power factor, A-Phase, Terminal S	484
LG_APFT	Lagging power factor, A-Phase, Terminal T	485
LG_APFU	Lagging power factor, A-Phase, Terminal U	486
LG_APFW	Lagging power factor, A-Phase, Terminal W	487
LG_APFX	Lagging power factor, A-Phase, Terminal X	488
LG_APFY	Lagging power factor, A-Phase, Terminal Y	122
LG_BPFS	Lagging power factor, B-Phase, Terminal S	484
LG_BPFT	Lagging power factor, B-Phase, Terminal T	485
LG_BPFU	Lagging power factor, B-Phase, Terminal U	486
LG_BPFW	Lagging power factor, B-Phase, Terminal W	487
LG_BPFX	Lagging power factor, B-Phase, Terminal X	488
LG_BPFY	Lagging power factor, B-Phase, Terminal Y	122
LG_CPFS	Lagging power factor, C-Phase, Terminal S	484
LG_CPFT	Lagging power factor, C-Phase, Terminal T	485
LG_CPFU	Lagging power factor, C-Phase, Terminal U	486
LG_CPFW	Lagging power factor, C-Phase, Terminal W	487
LG_CPFX	Lagging power factor, C-Phase, Terminal X	488

Table 11.1 Alphabetical List of Relay Word Bits (Sheet 67 of 93)

Name	Bit Description	Row
LG_CPFY	Lagging power factor, C-Phase, Terminal Y	122
LG3PFST	Lagging three-phase power factor, Combined Terminals ST	489
LG3PFTU	Lagging three-phase power factor, Combined Terminals TU	490
LG3PFUW	Lagging three-phase power factor, Combined Terminals UW	491
LG3PFWX	Lagging three-phase power factor, Combined Terminals WX	492
LGAPFST	Lagging power factor, A-Phase, Combined Terminals ST	489
LGAPFTU	Lagging power factor, A-Phase, Combined Terminals TU	490
LGAPFUW	Lagging power factor, A-Phase, Combined Terminals UW	491
LGAPFWX	Lagging power factor, A-Phase, Combined Terminals WX	492
LGBPFST	Lagging power factor, B-Phase, Combined Terminals ST	489
LGBPFTU	Lagging power factor, B-Phase, Combined Terminals TU	490
LGBPFUW	Lagging power factor, B-Phase, Combined Terminals UW	491
LGBPFWX	Lagging power factor, B-Phase, Combined Terminals WX	492
LGCPFST	Lagging power factor, C-Phase, Combined Terminals ST	489
LGCPFTU	Lagging power factor, C-Phase, Combined Terminals TU	490
LGCPFUW	Lagging power factor, C-Phase, Combined Terminals UW	491
LGCPFWX	Lagging power factor, C-Phase, Combined Terminals WX	492
LINK5A	Link status of the PORT 5A connection	428
LINK5B	Link status of the PORT 5B connection	428
LINK5C	Link status of the PORT 5C connection	428
LINK5D	Link status of the PORT 5D connection	428
LINK5E	Link status of the PORT 5E connection	428
LNKFAIL	Link status of the active station bus port	428
LNKFL2	Link status of the active process bus port	428
LOC	Control authority at local (bay) level	592
LOCAL	Local front-panel control	127
LOCSTA	Control authority at station level	592
LOPV	Loss-of-potential Terminal V	113
LOPZ	Loss-of-potential Terminal Z	113
LPHDSIM	IEC 61850 logical node for physical device simulation	382
LPSEC	Leap second is added	426
LPSECP	Leap second pending	426
M1GL1	Zone 1 mho ground element, Line 1	648
M1PL1	Zone 1 mho phase element, Line 1	648
M2GL1	Zone 2 mho ground element, Line 1	648
M2PL1	Zone 2 mho phase element, Line 1	648
M3GL1	Zone 3 mho ground element, Line 1	649
M3PL1	Zone 3 mho phase element, Line 1	649
M4GL1	Zone 4 mho ground element, Line 1	649
M4PL1	Zone 4 mho phase element, Line 1	649
MAB1L1	Zone 1 mho A-B-Phase element, Line 1	632

Table 11.1 Alphabetical List of Relay Word Bits (Sheet 68 of 93)

Name	Bit Description	Row
MAB2L1	Zone 2 mho A-B-Phase element, Line 1	633
MAB3L1	Zone 3 mho A-B-Phase element, Line 1	634
MAB4L1	Zone 3 mho A-B-Phase element, Line 1	635
MAG1L1	Zone 1 mho A-Phase-to-ground element, Line 1	632
MAG2L1	Zone 2 mho A-Phase-to-ground element, Line 1	633
MAG3L1	Zone 3 mho A-Phase-to-ground element, Line 1	634
MAG4L1	Zone 4 mho A-Phase-to-ground element, Line 1	635
MAMB_OK	Ambient temperature measurement RTD healthy	210
MATHERR	SELOGIC control equation Math error	348
MBC1L1	Zone 1 mho B-C-Phase element, Line 1	632
MBC2L1	Zone 2 mho B-C-Phase element, Line 1	633
MBC3L1	Zone 3 mho B-C-Phase element, Line 1	634
MBC4L1	Zone 4 mho B-C-Phase element, Line 1	635
MBG1L1	Zone 1 mho B-Phase-to-ground element, Line 1	632
MBG2L1	Zone 2 mho B-Phase-to-ground element, Line 1	633
MBG3L1	Zone 3 mho B-Phase-to-ground element, Line 1	634
MBG4L1	Zone 4 mho B-Phase-to-ground element, Line 1	635
MCA1L1	Zone 1 mho C-A-Phase element, Line 1	632
MCA2L1	Zone 2 mho C-A-Phase element, Line 1	633
MCA3L1	Zone 3 mho C-A-Phase element, Line 1	634
MCA4L1	Zone 4 mho C-A-Phase element, Line 1	635
MCG1L1	Zone 1 mho C-Phase-to-ground element, Line 1	632
MCG2L1	Zone 2 mho C-Phase-to-ground element, Line 1	633
MCG3L1	Zone 3 mho C-Phase-to-ground element, Line 1	634
MCG4L1	Zone 4 mho C-Phase-to-ground element, Line 1	635
MLTLEV	Multi-level control authority	592
MTO1_OK	Transformer 1, top-oil temperature measurement RTD healthy	210
MTO2_OK	Transformer 2, top-oil temperature measurement RTD healthy	210
MTO3_OK	Transformer 3, top-oil temperature measurement RTD healthy	210
NDREF1	Nondirectional REF Element 1 enabled	14
NDREF2	Nondirectional REF Element 2 enabled	16
NDREF3	Nondirectional REF Element 3 enabled	18
OCS	Breaker open command, Terminal S	224
OCT	Breaker open command, Terminal T	224
OCU	Breaker open command, Terminal U	224
OCW	Breaker open command, Terminal W	224
OCX	Breaker open command, Terminal X	225
OCY	Breaker open command, Terminal Y	225
OPHAS	A-Phase, Terminal S open	106
OPHAT	A-Phase, Terminal T open	106
OPHAU	A-Phase, Terminal U open	107

Table 11.1 Alphabetical List of Relay Word Bits (Sheet 69 of 93)

Name	Bit Description	Row
OPHAW	A-Phase, Terminal W open	107
OPHAX	A-Phase, Terminal X open	108
OPHAY	A-Phase, Terminal Y open	108
OPHBS	B-Phase, Terminal S open	106
OPHBT	B-Phase, Terminal T open	106
OPHBU	B-Phase, Terminal U open	107
OPHBW	B-Phase, Terminal W open	107
OPHBX	B-Phase, Terminal X open	108
OPHBY	B-Phase, Terminal Y open	108
OPHCS	C-Phase, Terminal S open	106
OPHCT	C-Phase, Terminal T open	106
OPHCU	C-Phase, Terminal U open	107
OPHCW	C-Phase, Terminal W open	107
OPHCX	C-Phase, Terminal X open	108
OPHCY	C-Phase, Terminal Y open	108
OPHS	Terminal S open	106
OPHT	Terminal T open	106
OPHU	Terminal U open	107
OPHW	Terminal W open	107
OPHX	Terminal X open	108
OPHY	Terminal Y open	108
OSB1L1	Block Zone 1 during an out-of-step condition, Line 1	636
OSB2L1	Block Zone 2 during an out-of-step condition, Line 1	636
OSB3L1	Block Zone 3 during an out-of-step condition, Line 1	636
OSB4L1	Block Zone 4 during an out-of-step condition, Line 1	636
OSBL1	Out-of-step block, Line 1	636
OUT201–OUT208	Output 201–208 asserted	360
OUT209–OUT216	Output 209–216 asserted	361
OUT301–OUT308	Output 301–308 asserted	362
OUT301S–OUT308S	Mapped OUT301–OUT308 contact status	566
OUT309–OUT316	Output 309–316 asserted	363
OUT309S–OUT316S	Mapped OUT309–OUT316 contact status	567
OUT401–OUT408	Output 401–408 asserted	480
OUT401S–OUT408S	Mapped OUT401–OUT408 contact status	570
OUT409–OUT416	Output 409–416 asserted	481

Table 11.1 Alphabetical List of Relay Word Bits (Sheet 70 of 93)

Name	Bit Description	Row
OUT409S – OUT416S	Mapped OUT409–OUT416 contact status	569
OUT501–OUT508	Output 501–508 asserted	482
OUT501S–OUT508S	Mapped OUT501–OUT508 contact status	570
OUT509–OUT516	Output 509–516 asserted	483
OUT509S–OUT516S	Mapped OUT509–OUT516 contact status	571
P5ABSW	**PORT 5A** or **5B** has just become active	469
P5ASEL	**PORT 5A** active/inactive	429
P5BSEL	**PORT 5B** active/inactive	429
P5CDSW	**PORT 5C** or **5D** has just become active	470
P5CSEL	**PORT 5C** active/inactive	429
P5DSEL	**PORT 5D** active/inactive	429
P5ESEL	**PORT 5E** active/inactive	429
P6AMAP	**PORT 6A** mapped	580
P6AOK	**PORT 6A** OK	584
P6BMAP	**PORT 6B** mapped	580
P6BOK	**PORT 6B** OK	584
P6CMAP	**PORT 6C** mapped	580
P6COK	**PORT 6C** OK	584
P6DMAP	**PORT 6D** mapped	580
P6DOK	**PORT 6D** OK	584
P6EMAP	**PORT 6E** mapped	580
P6EOK	**PORT 6E** OK	584
P6FMAP	**PORT 6F** mapped	580
P6FOK	**PORT 6F** OK	584
P6GMAP	**PORT 6G** mapped	580
P6GOK	**PORT 6G** OK	584
P6HMAP	**PORT 6H** mapped	580
P6HOK	**PORT 6H** OK	584
P87A	Zone 1 phase percentage-restrained differential element asserted (no security timer), A-Phase	10
P87A2	Zone 2 phase percentage-restrained differential element asserted (no security timer), A-Phase	710
P87B	Zone 1 phase percentage-restrained differential element asserted (no security timer), B-Phase	10
P87B2	Zone 2 phase percentage-restrained differential element asserted (no security timer), B-Phase	710
P87C	Zone 1 phase percentage-restrained differential element asserted (no security timer), C-Phase	10
P87C2	Zone 2 phase percentage-restrained differential element asserted (no security timer), C-Phase	710
PASSDIS	Password disable jumper is installed	350
PB1	Pushbutton 01 asserted	364
PB1_LED	Pushbutton 01 LED illuminated	368
PB1_PUL	Pushbutton 01 pulsed for 1 processing interval	366

Table 11.1 Alphabetical List of Relay Word Bits (Sheet 71 of 93)

Name	Bit Description	Row
PB10	Pushbutton 10 asserted	365
PB10LED	Pushbutton 10 LED illuminated	369
PB10PUL	Pushbutton 10 pulsed for 1 processing interval	367
PB11	Pushbutton 11 asserted	365
PB11LED	Pushbutton 11 LED illuminated	369
PB11PUL	Pushbutton 11 pulsed for 1 processing interval	367
PB12	Pushbutton 12 asserted	365
PB12LED	Pushbutton 12 LED illuminated	369
PB12PUL	Pushbutton 12 pulsed for 1 processing interval	367
PB2	Pushbutton 2 asserted	364
PB2_LED	Pushbutton 2 LED illuminated	368
PB2_PUL	Pushbutton 2 pulsed for 1 processing interval	366
PB3	Pushbutton 3 asserted	364
PB3_LED	Pushbutton 3 LED illuminated	368
PB3_PUL	Pushbutton 3 pulsed for 1 processing interval	366
PB4	Pushbutton 4 asserted	364
PB4_LED	Pushbutton 4 LED illuminated	368
PB4_PUL	Pushbutton 4 pulsed for 1 processing interval	366
PB5	Pushbutton 5 asserted	364
PB5_LED	Pushbutton 5 LED illuminated	368
PB5_PUL	Pushbutton 5 pulsed for 1 processing interval	366
PB6	Pushbutton 6 asserted	364
PB6_LED	Pushbutton 6 LED illuminated	368
PB6_PUL	Pushbutton 6 pulsed for 1 processing interval	366
PB7	Pushbutton 7 asserted	364
PB7_LED	Pushbutton 7 LED illuminated	368
PB7_PUL	Pushbutton 7 pulsed for 1 processing interval	366
PB8	Pushbutton 8 asserted	364
PB8_LED	Pushbutton 8 LED illuminated	368
PB8_PUL	Pushbutton 8 pulsed for 1 processing interval	366
PB9	Pushbutton 9 asserted	365
PB9_LED	Pushbutton 9 LED illuminated	369
PB9_PUL	Pushbutton 9 pulsed for 1 processing interval	367
PCN01Q	Protection SELOGIC Counter 01 asserted	284
PCN01R	Protection SELOGIC Counter 01 reset	288
PCN02Q	Protection SELOGIC Counter 02 asserted	284
PCN02R	Protection SELOGIC Counter 02 reset	288
PCN03Q	Protection SELOGIC Counter 03 asserted	284
PCN03R	Protection SELOGIC Counter 03 reset	288
PCN04Q	Protection SELOGIC Counter 04 asserted	284
PCN04R	Protection SELOGIC Counter 04 reset	288

Table 11.1 Alphabetical List of Relay Word Bits (Sheet 72 of 93)

Name	Bit Description	Row
PCN05Q	Protection SELOGIC Counter 05 asserted	284
PCN05R	Protection SELOGIC Counter 05 reset	288
PCN06Q	Protection SELOGIC Counter 06 asserted	284
PCN06R	Protection SELOGIC Counter 06 reset	288
PCN07Q	Protection SELOGIC Counter 07 asserted	284
PCN07R	Protection SELOGIC Counter 07 reset	288
PCN08Q	Protection SELOGIC Counter 08 asserted	284
PCN08R	Protection SELOGIC Counter 08 reset	288
PCN09Q	Protection SELOGIC Counter 09 asserted	285
PCN09R	Protection SELOGIC Counter 09 reset	289
PCN10Q	Protection SELOGIC Counter 10 asserted	285
PCN10R	Protection SELOGIC Counter 10 reset	289
PCN11Q	Protection SELOGIC Counter 11 asserted	285
PCN11R	Protection SELOGIC Counter 11 reset	289
PCN12Q	Protection SELOGIC Counter 12 asserted	285
PCN12R	Protection SELOGIC Counter 12 reset	289
PCN13Q	Protection SELOGIC Counter 13 asserted	285
PCN13R	Protection SELOGIC Counter 13 reset	289
PCN14Q	Protection SELOGIC Counter 14 asserted	285
PCN14R	Protection SELOGIC Counter 14 reset	289
PCN15Q	Protection SELOGIC Counter 15 asserted	285
PCN15R	Protection SELOGIC Counter 15 reset	289
PCN16Q	Protection SELOGIC Counter 16 asserted	285
PCN16R	Protection SELOGIC Counter 16 reset	289
PCN17Q	Protection SELOGIC Counter 17 asserted	286
PCN17R	Protection SELOGIC Counter 17 reset	290
PCN18Q	Protection SELOGIC Counter 18 asserted	286
PCN18R	Protection SELOGIC Counter 18 reset	290
PCN19Q	Protection SELOGIC Counter 19 asserted	286
PCN19R	Protection SELOGIC Counter 19 reset	290
PCN20Q	Protection SELOGIC Counter 20 asserted	286
PCN20R	Protection SELOGIC Counter 20 reset	290
PCN21Q	Protection SELOGIC Counter 21 asserted	286
PCN21R	Protection SELOGIC Counter 21 reset	290
PCN22Q	Protection SELOGIC Counter 22 asserted	286
PCN22R	Protection SELOGIC Counter 22 reset	290
PCN23Q	Protection SELOGIC Counter 23 asserted	286
PCN23R	Protection SELOGIC Counter 23 reset	290
PCN24Q	Protection SELOGIC Counter 24 asserted	286
PCN24R	Protection SELOGIC Counter 24 reset	290
PCN25Q	Protection SELOGIC Counter 25 asserted	287

Table 11.1 Alphabetical List of Relay Word Bits (Sheet 73 of 93)

Name	Bit Description	Row
PCN25R	Protection SELOGIC Counter 25 reset	291
PCN26Q	Protection SELOGIC Counter 26 asserted	287
PCN26R	Protection SELOGIC Counter 26 reset	291
PCN27Q	Protection SELOGIC Counter 27 asserted	287
PCN27R	Protection SELOGIC Counter 27 reset	291
PCN28Q	Protection SELOGIC Counter 28 asserted	287
PCN28R	Protection SELOGIC Counter 28 reset	291
PCN29Q	Protection SELOGIC Counter 29 asserted	287
PCN29R	Protection SELOGIC Counter 29 reset	291
PCN30Q	Protection SELOGIC Counter 30 asserted	287
PCN30R	Protection SELOGIC Counter 30 reset	291
PCN31Q	Protection SELOGIC Counter 31 asserted	287
PCN31R	Protection SELOGIC Counter 31 reset	291
PCN32Q	Protection SELOGIC Counter 32 asserted	287
PCN32R	Protection SELOGIC Counter 32 reset	291
PCT01Q	Protection SELOGIC Conditioning Timer 01 asserted	272
PCT02Q	Protection SELOGIC Conditioning Timer 02 asserted	272
PCT03Q	Protection SELOGIC Conditioning Timer 03 asserted	272
PCT04Q	Protection SELOGIC Conditioning Timer 04 asserted	272
PCT05Q	Protection SELOGIC Conditioning Timer 05 asserted	272
PCT06Q	Protection SELOGIC Conditioning Timer 06 asserted	272
PCT07Q	Protection SELOGIC Conditioning Timer 07 asserted	272
PCT08Q	Protection SELOGIC Conditioning Timer 08 asserted	272
PCT09Q	Protection SELOGIC Conditioning Timer 09 asserted	273
PCT10Q	Protection SELOGIC Conditioning Timer 10 asserted	273
PCT11Q	Protection SELOGIC Conditioning Timer 11 asserted	273
PCT12Q	Protection SELOGIC Conditioning Timer 12 asserted	273
PCT13Q	Protection SELOGIC Conditioning Timer 13 asserted	273
PCT14Q	Protection SELOGIC Conditioning Timer 14 asserted	273
PCT15Q	Protection SELOGIC Conditioning Timer 15 asserted	273
PCT16Q	Protection SELOGIC Conditioning Timer 16 asserted	273
PCT17Q	Protection SELOGIC Conditioning Timer 17 asserted	274
PCT18Q	Protection SELOGIC Conditioning Timer 18 asserted	274
PCT19Q	Protection SELOGIC Conditioning Timer 19 asserted	274
PCT20Q	Protection SELOGIC Conditioning Timer 20 asserted	274
PCT21Q	Protection SELOGIC Conditioning Timer 21 asserted	274
PCT22Q	Protection SELOGIC Conditioning Timer 22 asserted	274
PCT23Q	Protection SELOGIC Conditioning Timer 23 asserted	274
PCT24Q	Protection SELOGIC Conditioning Timer 24 asserted	274
PCT25Q	Protection SELOGIC Conditioning Timer 25 asserted	275
PCT26Q	Protection SELOGIC Conditioning Timer 26 asserted	275

Table 11.1 Alphabetical List of Relay Word Bits (Sheet 74 of 93)

Name	Bit Description	Row
PCT27Q	Protection SELOGIC Conditioning Timer 27 asserted	275
PCT28Q	Protection SELOGIC Conditioning Timer 28 asserted	275
PCT29Q	Protection SELOGIC Conditioning Timer 29 asserted	275
PCT30Q	Protection SELOGIC Conditioning Timer 30 asserted	275
PCT31Q	Protection SELOGIC Conditioning Timer 31 asserted	275
PCT32Q	Protection SELOGIC Conditioning Timer 32 asserted	275
PFRTEX	Protection SELOGIC control equation first execution	348
PHA_S	A-Phase involved in the fault, Terminal S	458
PHA_T	A-Phase involved in the fault, Terminal T	458
PHA_U	A-Phase involved in the fault, Terminal U	458
PHA_W	A-Phase involved in the fault, Terminal W	458
PHA_X	A-Phase involved in the fault, Terminal X	458
PHA_Y	A-Phase involved in the fault, Terminal Y	460
PHB_S	B-Phase involved in the fault, Terminal S	458
PHB_T	B-Phase involved in the fault, Terminal T	458
PHB_U	B-Phase involved in the fault, Terminal U	458
PHB_W	B-Phase involved in the fault, Terminal W	459
PHB_X	B-Phase involved in the fault, Terminal X	459
PHB_Y	B-Phase involved in the fault, Terminal Y	460
PHC_S	C-Phase involved in the fault, Terminal S	459
PHC_T	C-Phase involved in the fault, Terminal T	459
PHC_U	C-Phase involved in the fault, Terminal U	459
PHC_W	C-Phase involved in the fault, Terminal W	459
PHC_X	C-Phase involved in the fault, Terminal X	459
PHC_Y	C-Phase involved in the fault, Terminal Y	460
PLT01–PLT08	Protection SELOGIC Latch 01–Latch 08 asserted	268
PLT09–PLT16	Protection SELOGIC Latch 09–Latch 16 asserted	269
PLT17–PLT24	Protection SELOGIC Latch 17–Latch 24 asserted	270
PLT25–PLT32	Protection SELOGIC Latch 25–Latch 32 asserted	271
PMDOK	Assert if data acquisition system is operating correctly	353
PMTEST	Synchrophasor test mode	417
PMTRIG	Synchrophasor SELOGIC control equation trigger	417
PRPAGOK	PRP PORT 5A GOOSE status	652
PRPASOK	PRP PORT 5A SV status	652
PRPBGOK	PRP PORT 5B GOOSE status	652
PRPBSOK	PRP PORT 5B SV status	652
PRPCGOK	PRP PORT 5C GOOSE status	652
PRPDGOK	PRP PORT 5D GOOSE status	652
PST01Q	Protection SELOGIC Sequencing Timer 01 asserted	276
PST01R	Protection SELOGIC Sequencing Timer 01 reset	280
PST02Q	Protection SELOGIC Sequencing Timer 02 asserted	276

Table 11.1 Alphabetical List of Relay Word Bits (Sheet 75 of 93)

Name	Bit Description	Row
PST02R	Protection SELOGIC Sequencing Timer 02 reset	280
PST03Q	Protection SELOGIC Sequencing Timer 03 asserted	276
PST03R	Protection SELOGIC Sequencing Timer 03 reset	280
PST04Q	Protection SELOGIC Sequencing Timer 04 asserted	276
PST04R	Protection SELOGIC Sequencing Timer 04 reset	280
PST05Q	Protection SELOGIC Sequencing Timer 05 asserted	276
PST05R	Protection SELOGIC Sequencing Timer 05 reset	280
PST06Q	Protection SELOGIC Sequencing Timer 06 asserted	276
PST06R	Protection SELOGIC Sequencing Timer 06 reset	280
PST07Q	Protection SELOGIC Sequencing Timer 07 asserted	276
PST07R	Protection SELOGIC Sequencing Timer 07 reset	280
PST08Q	Protection SELOGIC Sequencing Timer 08 asserted	276
PST08R	Protection SELOGIC Sequencing Timer 08 reset	280
PST09Q	Protection SELOGIC Sequencing Timer 09 asserted	277
PST09R	Protection SELOGIC Sequencing Timer 09 reset	281
PST10Q	Protection SELOGIC Sequencing Timer 10 asserted	277
PST10R	Protection SELOGIC Sequencing Timer 10 reset	281
PST11Q	Protection SELOGIC Sequencing Timer 11 asserted	277
PST11R	Protection SELOGIC Sequencing Timer 11 reset	281
PST12Q	Protection SELOGIC Sequencing Timer 12 asserted	277
PST12R	Protection SELOGIC Sequencing Timer 12 reset	281
PST13Q	Protection SELOGIC Sequencing Timer 13 asserted	277
PST13R	Protection SELOGIC Sequencing Timer 13 reset	281
PST14Q	Protection SELOGIC Sequencing Timer 14 asserted	277
PST14R	Protection SELOGIC Sequencing Timer 14 reset	281
PST15Q	Protection SELOGIC Sequencing Timer 15 asserted	277
PST15R	Protection SELOGIC Sequencing Timer 15 reset	281
PST16Q	Protection SELOGIC Sequencing Timer 16 asserted	277
PST16R	Protection SELOGIC Sequencing Timer 16 reset	281
PST17Q	Protection SELOGIC Sequencing Timer 17 asserted	278
PST17R	Protection SELOGIC Sequencing Timer 17 reset	282
PST18Q	Protection SELOGIC Sequencing Timer 18 asserted	278
PST18R	Protection SELOGIC Sequencing Timer 18 reset	282
PST19Q	Protection SELOGIC Sequencing Timer 19 asserted	278
PST19R	Protection SELOGIC Sequencing Timer 19 reset	282
PST20Q	Protection SELOGIC Sequencing Timer 20 asserted	278
PST20R	Protection SELOGIC Sequencing Timer 20 reset	282
PST21Q	Protection SELOGIC Sequencing Timer 21 asserted	278
PST21R	Protection SELOGIC Sequencing Timer 21 reset	282
PST22Q	Protection SELOGIC Sequencing Timer 22 asserted	278
PST22R	Protection SELOGIC Sequencing Timer 22 reset	282

Table 11.1 Alphabetical List of Relay Word Bits (Sheet 76 of 93)

Name	Bit Description	Row
PST23Q	Protection SELOGIC Sequencing Timer 23 asserted	278
PST23R	Protection SELOGIC Sequencing Timer 23 reset	282
PST24Q	Protection SELOGIC Sequencing Timer 24 asserted	278
PST24R	Protection SELOGIC Sequencing Timer 24 reset	282
PST25Q	Protection SELOGIC Sequencing Timer 25 asserted	279
PST25R	Protection SELOGIC Sequencing Timer 25 reset	283
PST26Q	Protection SELOGIC Sequencing Timer 26 asserted	279
PST26R	Protection SELOGIC Sequencing Timer 26 reset	283
PST27Q	Protection SELOGIC Sequencing Timer 27 asserted	279
PST27R	Protection SELOGIC Sequencing Timer 27 reset	283
PST28Q	Protection SELOGIC Sequencing Timer 28 asserted	279
PST28R	Protection SELOGIC Sequencing Timer 28 reset	283
PST29Q	Protection SELOGIC Sequencing Timer 29 asserted	279
PST29R	Protection SELOGIC Sequencing Timer 29 reset	283
PST30Q	Protection SELOGIC Sequencing Timer 30 asserted	279
PST30R	Protection SELOGIC Sequencing Timer 30 reset	283
PST31Q	Protection SELOGIC Sequencing Timer 31 asserted	279
PST31R	Protection SELOGIC Sequencing Timer 31 reset	283
PST32Q	Protection SELOGIC Sequencing Timer 32 asserted	279
PST32R	Protection SELOGIC Sequencing Timer 32 reset	283
PSV01–PSV08	Protection SELOGIC Variable 01–Variable 08 asserted	260
PSV09–PSV16	Protection SELOGIC Variable 09–Variable 16 asserted	261
PSV17–PSV24	Protection SELOGIC Variable 17–Variable 24 asserted	262
PSV25–PSV32	Protection SELOGIC Variable 25–Variable 32 asserted	263
PSV33–PSV40	Protection SELOGIC Variable 33–Variable 40 asserted	264
PSV41–PSV48	Protection SELOGIC Variable 41–Variable 48 asserted	265
PSV49–PSV56	Protection SELOGIC Variable 49–Variable 56 asserted	266
PSV57–PSV64	Protection SELOGIC Variable 57–Variable 64 asserted	267
PSV65–PSV72	Protection SELOGIC Variable 65–Variable 72 asserted	756
PSV73–PSV80	Protection SELOGIC Variable 73–Variable 80 asserted	757
PSV81–PSV88	Protection SELOGIC Variable 81–Variable 88 asserted	758
PSV89–PSV96	Protection SELOGIC Variable 89–Variable 96 asserted	759
PTP_BNP	Bad jitter on PTP signals and the PTP signal is lost afterwards	470
PTP_OK	PTP is available and has sufficient quality	469
PTP_RST	Disqualify PTP time source	469
PTP_SET	Qualify PTP time source	469
PTP_TIM	A valid PTP time source is detected	469
PTPSYNC	Synchronized to high-quality PTP source	470
PUNRLBL	Protection SELOGIC control equation unresolved label	348
RAB1L1	Zone 1 quad A-B-Phase resistance element, Line 1	643
RAB2L1	Zone 2 quad A-B-Phase resistance element, Line 1	644

Table 11.1 Alphabetical List of Relay Word Bits (Sheet 77 of 93)

Name	Bit Description	Row
RAB3L1	Zone 3 quad A-B-Phase resistance element, Line 1	645
RAB4L1	Zone 4 quad A-B-Phase resistance element, Line 1	646
RAG1L1	Zone 1 quad A-Phase-to-ground resistance element, Line 1	643
RAG2L1	Zone 2 quad A-Phase-to-ground resistance element, Line 1	644
RAG3L1	Zone 3 quad A-Phase-to-ground resistance element, Line 1	645
RAG4L1	Zone 4 quad A-Phase-to-ground resistance element, Line 1	646
RB01–RB08	Remote Bit 01–Remote Bit 08 asserted	243
RB09–RB16	Remote Bit 09–Remote Bit 16 asserted	242
RB17–RB24	Remote Bit 17–Remote Bit 24 asserted	241
RB25–RB32	Remote Bit 25–Remote Bit 32 asserted	240
RB33–RB40	Remote Bit 33–Remote Bit 40 asserted	615
RB41–RB48	Remote Bit 41–Remote Bit 48 asserted	614
RB49–RB56	Remote Bit 49–Remote Bit 56 asserted	613
RB57–RB64	Remote Bit 57–Remote Bit 64 asserted	612
RB65–RB72	Remote Bit 65–Remote Bit 72 asserted	755
RB73–RB80	Remote Bit 73–Remote Bit 80 asserted	754
RB81–RB88	Remote Bit 81–Remote Bit 88 asserted	753
RB89–RB96	Remote Bit 89–Remote Bit 96 asserted	752
RBADA	Outage too large for normal MIRRORED BITS communication, Channel A	380
RBADB	Outage too large for normal MIRRORED BITS communication, Channel B	381
RBC1L1	Zone 1 quad B-C-Phase resistance element, Line 1	643
RBC2L1	Zone 2 quad B-C-Phase resistance element, Line 1	644
RBC3L1	Zone 3 quad B-C-Phase resistance element, Line 1	645
RBC4L1	Zone 4 quad B-C-Phase resistance element, Line 1	646
RBG1L1	Zone 1 quad B-Phase-to-ground resistance element, Line 1	643
RBG2L1	Zone 2 quad B-Phase-to-ground resistance element, Line 1	644
RBG3L1	Zone 3 quad B-Phase-to-ground resistance element, Line 1	645
RBG4L1	Zone 4 quad B-Phase-to-ground resistance element, Line 1	646
RCA1L1	Zone 1 quad C-A-Phase resistance element, Line 1	643
RCA2L1	Zone 2 quad C-A-Phase resistance element, Line 1	644
RCA3L1	Zone 3 quad C-A-Phase resistance element, Line 1	645
RCA4L1	Zone 4 quad C-A-Phase resistance element, Line 1	646
RCG1L1	Zone 1 quad C-Phase-to-ground resistance element, Line 1	643
RCG2L1	Zone 2 quad C-Phase-to-ground resistance element, Line 1	644
RCG3L1	Zone 3 quad C-Phase-to-ground resistance element, Line 1	645
RCG4L1	Zone 4 quad C-Phase-to-ground resistance element, Line 1	646
REF	Earth fault inside REF Element 1, 2, or 3 zones	15
REF1BK	Restricted Earth Fault Element 1 blocking bit (because of loss of SV data)	561
REF2BK	Restricted Earth Fault Element 2 blocking bit (because of loss of SV data)	561
REF3BK	Restricted Earth Fault Element 3 blocking bit (because of loss of SV data)	561
REF501	Neutral (operating current) Instantaneous Overcurrent REF Element 1 picked up	14

Table 11.1 Alphabetical List of Relay Word Bits (Sheet 78 of 93)

Name	Bit Description	Row
REF502	Neutral (operating current) Instantaneous Overcurrent REF Element 2 picked up	16
REF503	Neutral (operating current) Instantaneous Overcurrent REF Element 3 picked up	18
REF50T1	Neutral Instantaneous Overcurrent REF Element 1 timed out	14
REF50T2	Neutral Instantaneous Overcurrent REF Element 2 timed out	16
REF50T3	Neutral Instantaneous Overcurrent REF Element 3 timed out	18
REF511P	REF Element 1 TOC element picked up	15
REF512P	REF Element 2 TOC element picked up	17
REF513P	REF Element 3 TOC element picked up	19
REF51R1	REF Element 1 TOC element reset	15
REF51R2	REF Element 2 TOC element reset	17
REF51R3	REF Element 3 TOC element reset	19
REF51T1	REF Element 1 TOC element timed out	14
REF51T2	REF Element 2 TOC element timed out	16
REF51T3	REF Element 3 TOC element timed out	18
REFBLK1	REF Element 1 phase fault or external ground fault detected	15
REFBLK2	REF Element 2 phase fault or external ground fault detected	17
REFBLK3	REF Element 3 phase fault or external ground fault detected	19
REFF1	Earth Fault Inside REF Element 1 zone	14
REFF2	Earth Fault Inside REF Element 2 zone	16
REFF3	Earth Fault Inside REF Element 3 zone	18
REFR1	Earth Fault Outside REF Element 1 zone	14
REFR2	Earth Fault Outside REF Element 2 zone	16
REFR3	Earth Fault Outside REF Element 3 zone	18
REFOCT1	REF Element 1 open CT, wiring or setting error detected	15
REFOCT2	REF Element 2 open CT, wiring or setting error detected	17
REFOCT3	REF Element 3 open CT, wiring or setting error detected	19
RF51TC1	Inverse-Time Neutral Overcurrent REF Element 1 enabled	14
RF51TC2	Inverse-Time Neutral Overcurrent REF Element 2 enabled	16
RF51TC3	Inverse-Time Neutral Overcurrent REF Element 3 enabled	18
RLL	Rate of loss-of-life alarm	208
RLL_1	Transformer 1, rate of loss-of-life alarm	208
RLL_2	Transformer 2, rate of loss-of-life alarm	208
RLL_3	Transformer 3, rate of loss-of-life alarm	208
RMB1A	Received MIRRORED BITS 1, Channel A	376
RMB1B	Received MIRRORED BITS 1, Channel B	378
RMB2A	Received MIRRORED BITS 2, Channel A	376
RMB2B	Received MIRRORED BITS 2, Channel B	378
RMB3A	Received MIRRORED BITS 3, Channel A	376
RMB3B	Received MIRRORED BITS 3, Channel B	378
RMB4A	Received MIRRORED BITS 4, Channel A	376
RMB4B	Received MIRRORED BITS 4, Channel B	378

Table 11.1 Alphabetical List of Relay Word Bits (Sheet 79 of 93)

Name	Bit Description	Row
RMB5A	Received MIRRORED BITS 5, Channel A	376
RMB5B	Received MIRRORED BITS 5, Channel B	378
RMB6A	Received MIRRORED BITS 6, Channel A	376
RMB6B	Received MIRRORED BITS 6, Channel B	378
RMB7A	Received MIRRORED BITS 7, Channel A	376
RMB7B	Received MIRRORED BITS 7, Channel B	378
RMB8A	Received MIRRORED BITS 8, Channel A	376
RMB8B	Received MIRRORED BITS 8, Channel B	378
ROKA	MIRRORED BITS Channel A normal status in non-loopback mode	380
ROKB	MIRRORED BITS Channel B normal status in non-loopback mode	381
RST_79C	Reset recloser shot counters	373
RST_BAT	Reset battery monitoring	373
RST_BKS	Reset Breaker S monitoring	372
RST_BKT	Reset Breaker T monitoring	372
RST_BKU	Reset Breaker U monitoring	372
RST_BKW	Reset Breaker W monitoring	372
RST_BKX	Reset Breaker X monitoring	372
RST_BKY	Reset Breaker Y monitoring	373
RST_DEM	Reset demand metering	372
RST_ENE	Reset energy metering	372
RST_HAL	Reset HALARMA	373
RST_PDM	Reset peak demand metering	372
RSTDNPE	Reset DNP fault summary data	373
RSTTRGT	Reset front-panel targets	373
RTCAD01	RTC Channel A Remote Data Bit 01	420
RTCAD02	RTC Channel A Remote Data Bit 02	420
RTCAD03	RTC Channel A Remote Data Bit 03	420
RTCAD04	RTC Channel A Remote Data Bit 04	420
RTCAD05	RTC Channel A Remote Data Bit 05	420
RTCAD06	RTC Channel A Remote Data Bit 06	420
RTCAD07	RTC Channel A Remote Data Bit 07	420
RTCAD08	RTC Channel A Remote Data Bit 08	420
RTCAD09	RTC Channel A Remote Data Bit 09	421
RTCAD10	RTC Channel A Remote Data Bit 10	421
RTCAD11	RTC Channel A Remote Data Bit 11	421
RTCAD12	RTC Channel A Remote Data Bit 12	421
RTCAD13	RTC Channel A Remote Data Bit 13	421
RTCAD14	RTC Channel A Remote Data Bit 14	421
RTCAD15	RTC Channel A Remote Data Bit 15	421
RTCAD16	RTC Channel A Remote Data Bit 16	421
RTCBD01	RTC Channel B Remote Data Bit 01	422

Table 11.1 Alphabetical List of Relay Word Bits (Sheet 80 of 93)

Name	Bit Description	Row
RTCBD02	RTC Channel B Remote Data Bit 02	422
RTCBD03	RTC Channel B Remote Data Bit 03	422
RTCBD04	RTC Channel B Remote Data Bit 04	422
RTCBD05	RTC Channel B Remote Data Bit 05	422
RTCBD06	RTC Channel B Remote Data Bit 06	422
RTCBD07	RTC Channel B Remote Data Bit 07	422
RTCBD08	RTC Channel B Remote Data Bit 08	422
RTCBD09	RTC Channel B Remote Data Bit 09	423
RTCBD10	RTC Channel B Remote Data Bit 10	423
RTCBD11	RTC Channel B Remote Data Bit 11	423
RTCBD12	RTC Channel B Remote Data Bit 12	423
RTCBD13	RTC Channel B Remote Data Bit 13	423
RTCBD14	RTC Channel B Remote Data Bit 14	423
RTCBD15	RTC Channel B Remote Data Bit 15	423
RTCBD16	RTC Channel B Remote Data Bit 16	423
RTCCFGA	RTC Channel A configuration complete	418
RTCCFGB	RTC Channel B configuration complete	418
RTCDLYA	Max RTC delay exceeded for Channel A	418
RTCDLYB	Max RTC delay exceeded for Channel B	418
RTCENA	Valid remote synchrophasors received on Channel A	419
RTCENB	Valid remote synchrophasors received on Channel B	419
RTCROK	Valid aligned RTC data available on all enabled channels	418
RTCROKA	Valid aligned RTC data available on Channel A	419
RTCROKB	Valid aligned RTC data available on Channel B	419
RTCSEQA	RTC Channel A data in sequence	418
RTCSEQB	RTC Channel B data in sequence	418
RTD01OC	RTD01 open-circuited	216
RTD01OK	RTD01 healthy	212
RTD01SC	RTD01 short-circuited	214
RTD02OC	RTD02 open-circuited	216
RTD02OK	RTD02 healthy	212
RTD02SC	RTD02 short-circuited	214
RTD03OC	RTD03 open-circuited	216
RTD03OK	RTD03 healthy	212
RTD03SC	RTD03 short-circuited	214
RTD04OC	RTD04 open-circuited	216
RTD04OK	RTD04 healthy	212
RTD04SC	RTD04 short-circuited	214
RTD05OC	RTD05 open-circuited	216
RTD05OK	RTD05 healthy	212
RTD05SC	RTD05 short-circuited	214

Table 11.1 Alphabetical List of Relay Word Bits (Sheet 81 of 93)

Name	Bit Description	Row
RTD06OC	RTD06 open-circuited	216
RTD06OK	RTD06 healthy	212
RTD06SC	RTD06 short-circuited	214
RTD07OC	RTD07 open-circuited	216
RTD07OK	RTD07 healthy	212
RTD07SC	RTD07 short-circuited	214
RTD08OC	RTD08 open-circuited	216
RTD08OK	RTD08 healthy	212
RTD08SC	RTD08 short-circuited	214
RTD09OC	RTD09 open-circuited	217
RTD09OK	RTD09 healthy	213
RTD09SC	RTD09 short-circuited	215
RTD10OC	RTD10 open-circuited	217
RTD10OK	RTD10 healthy	213
RTD10SC	RTD10 short-circuited	215
RTD11OC	RTD11 open-circuited	217
RTD11OK	RTD11 healthy	213
RTD11SC	RTD11 short-circuited	215
RTD12OC	RTD12 open-circuited	217
RTD12OK	RTD12 healthy	213
RTD12SC	RTD12 short-circuited	215
RTDCOMF	SEL-2600 Communication Failure	218
RTDFL	SEL-2600 RAM failure	218
RTS	Retrip Timer timed out/retrip command issued, Terminal S	110
RTT	Retrip Timer timed out/retrip command issued, Terminal T	112
RTU	Retrip Timer timed out/retrip command issued, Terminal U	114
RTW	Retrip Timer timed out/retrip command issued, Terminal W	116
RTX	Retrip Timer timed out/retrip command issued, Terminal X	118
RTY	Retrip Timer timed out/retrip command issued, Terminal Y	744
RVRS1L1	Asserts when Group setting DIR1L1 = R	631
RVRS2L1	Asserts when Group setting DIR2L1 = R	631
RVRS3L1	Asserts when Group setting DIR3L1 = R	631
RVRS4L1	Asserts when Group setting DIR4L1 = R	631
S32QE	Negative-sequence phase directional element enabled, Terminal S	20
S32QGE	Negative-sequence ground directional element enabled, Terminal S	20
S32VE	Zero-sequence voltage directional element enabled, Terminal S	20
S50GF	Zero-sequence current above forward threshold, Terminal S	20
S50GR	Zero-sequence current above reverse threshold, Terminal S	20
S50QF	Negative-sequence current above forward threshold, Terminal S	20
S50QR	Negative-sequence current above reverse threshold, Terminal S	20
SALARM	Software alarm	349

Table 11.1 Alphabetical List of Relay Word Bits (Sheet 82 of 93)

Name	Bit Description	Row
SC850BM	SELOGIC control for IEC 61850 Blocked Mode	564
SC850LS	SELOGIC control for control authority at station level	592
SC850SM	SELOGIC control for IEC 61850 Simulation Mode	564
SC850TM	SELOGIC control for IEC 61850 Test Mode	564
SCBKSBC	SELOGIC control for IEC 61850 close block equation for Circuit Breaker S	686
SCBKSBO	SELOGIC control for IEC 61850 open block equation for Circuit Breaker S	686
SCBKTBC	SELOGIC control for IEC 61850 close block equation for Circuit Breaker T	686
SCBKTBO	SELOGIC control for IEC 61850 open block equation for Circuit Breaker T	686
SCBKUBC	SELOGIC control for IEC 61850 close block equation for Circuit Breaker U	686
SCBKUBO	SELOGIC control for IEC 61850 open block equation for Circuit Breaker U	686
SCBKWBC	SELOGIC control for IEC 61850 close block equation for Circuit Breaker W	686
SCBKWBO	SELOGIC control for IEC 61850 open block equation for Circuit Breaker W	686
SCBKXBC	SELOGIC control for IEC 61850 close block equation for Circuit Breaker X	685
SCBKXBO	SELOGIC control for IEC 61850 open block equation for Circuit Breaker X	685
SCBKYBC	SELOGIC control for IEC 61850 close block equation for Circuit Breaker Y	685
SCBKYBO	SELOGIC control for IEC 61850 open block equation for Circuit Breaker Y	685
SER_BNP	Bad jitter on serial port and the IRIG-B signal is lost afterwards	469
SER_OK	IRIG-B signal from serial PORT 1 is available and has sufficient quality	468
SER_RST	Disqualify serial IRIG-B time source	468
SER_SET	Qualify serial IRIG-B time source	468
SER_TIM	A valid IRIG-B time source is detected on serial port	469
SERSYNC	Synchronized to high-quality serial IRIG source	470
SETCHG	Pulsed alarm for settings changes	349
SF32G	Forward ground directional element asserted, Terminal S	21
SF32P	Forward phase directional element asserted, Terminal S	30
SF32Q	Forward negative-sequence phase directional element asserted, Terminal S	30
SF32QG	Forward negative-sequence ground directional element asserted, Terminal S	20
SF32V	Forward zero-sequence ground directional element asserted, Terminal S	21
SFBKS	Breaker S slip frequency is within acceptable slip-frequency window	451
SFBKT	Breaker T slip frequency is within acceptable slip-frequency window	451
SFBKU	Breaker U slip frequency is within acceptable slip-frequency window	451
SFBKW	Breaker W slip frequency is within acceptable slip-frequency window	451
SFBKX	Breaker X slip frequency is within acceptable slip-frequency window	451
SFBKY	Breaker Y slip frequency is within acceptable slip-frequency window	451
SFZBKS	Breaker S slip frequency is less than 5 MHz	450
SFZBKT	Breaker T slip frequency is less than 5 MHz	450
SFZBKU	Breaker U slip frequency is less than 5 MHz	450
SFZBKW	Breaker W slip frequency is less than 5 MHz	450
SFZBKX	Breaker X slip frequency is less than 5 MHz	450
SFZBKY	Breaker Y slip frequency is less than 5 MHz	450
SG1	Setting Group 1 is active	244

Table 11.1 Alphabetical List of Relay Word Bits (Sheet 83 of 93)

Name	Bit Description	Row
SG2	Setting Group 2 is active	244
SG3	Setting Group 3 is active	244
SG4	Setting Group 4 is active	244
SG5	Setting Group 5 is active	244
SG6	Setting Group 6 is active	244
SLOWS	Breaker S synchronizing voltage slipping slower than polarizing voltage	449
SLOWT	Breaker T synchronizing voltage slipping slower than polarizing voltage	449
SLOWU	Breaker U synchronizing voltage slipping slower than polarizing voltage	449
SLOWW	Breaker W synchronizing voltage slipping slower than polarizing voltage	449
SLOWX	Breaker X synchronizing voltage slipping slower than polarizing voltage	449
SLOWY	Breaker Y synchronizing voltage slipping slower than polarizing voltage	449
SOTFEL1	Switch-onto-fault enable, Line 1	628
SOTFTL1	Switch-onto-fault trip, Line 1	628
SPCER1	Synchrophasor configuration error on PORT 1	351
SPCER2	Synchrophasor configuration error on PORT 2	351
SPCER3	Synchrophasor configuration error on PORT 3	351
SPCERF	Synchrophasor configuration error on PORT F	351
SPEN	Signal profiling enabled	430
SR32G	Reverse ground directional element asserted, Terminal S	21
SR32P	Reverse phase directional element asserted, Terminal S	30
SR32Q	Reverse negative-sequence phase directional element asserted, Terminal S	30
SR32QG	Reverse negative-sequence phase directional element asserted, Terminal S	21
SR32V	Reverse zero-sequence ground directional element asserted, Terminal S	21
SVBK_EX	Extended general blocking bit for SV applications	560
SVBLK	General blocking bit for SV applications	560
SVCC	Coupled clock mode indication	539
SVP01OK	SV publication 01 is enabled	556
SVP02OK	SV publication 02 is enabled	556
SVP03OK	SV publication 03 is enabled	556
SVP04OK	SV publication 04 is enabled	556
SVP05OK	SV publication 05 is enabled	556
SVP06OK	SV publication 06 is enabled	556
SVP07OK	SV publication 07 is enabled	556
SVPTST	SV publication unit in test mode	559
SVS01OK	Subscription 01 is valid	536
SVS02OK	Subscription 02 is valid	536
SVS03OK	Subscription 03 is valid	536
SVS04OK	Subscription 04 is valid	536
SVS05OK	Subscription 05 is valid	536
SVS06OK	Subscription 06 is valid	536
SVS07OK	Subscription 07 is valid	536

Table 11.1 Alphabetical List of Relay Word Bits (Sheet 84 of 93)

Name	Bit Description	Row
SVSALM	General SV subscription alarm	539
SVSTST	SV subscription unit in test mode	539
T1CS2	Transformer 1 Cooling Stage 2	211
T1CS3	Transformer 1 Cooling Stage 3	211
T1OIL_F	Transformer 1 oil temperature fault condition	213
T2CS2	Transformer 2 Cooling Stage 2	211
T2CS3	Transformer 2 Cooling Stage 3	211
T2OIL_F	Transformer 2 oil temperature fault condition	213
T32QE	Negative-sequence phase directional element enabled, Terminal T	22
T32QGE	Negative-sequence ground directional element enabled, Terminal T	22
T32VE	Zero-sequence voltage directional element enabled, Terminal T	22
T3CS2	Transformer 3 Cooling Stage 2	211
T3CS3	Transformer 3 Cooling Stage 3	211
T3OIL_F	Transformer 3 oil temperature fault condition	213
T50GF	Zero-sequence current above forward threshold, Terminal T	22
T50GR	Zero-sequence current above reverse threshold, Terminal T	22
T50QF	Negative-sequence current above forward threshold, Terminal T	22
T50QR	Negative-sequence current above reverse threshold, Terminal T	22
TBNC	The active relay time source is BNC IRIG	355
TCREF1	REF Element 1 enabled	14
TCREF2	REF Element 2 enabled	16
TCREF3	REF Element 3 enabled	18
TDLCMSD	TiDL active topology commissioned	588
TESTDB	Database test bit	382
TESTDB2	Enhanced label-based test bit	382
TESTFM	Fast Meter test bit	382
TESTPUL	Pulse test bit	382
TF32G	Forward ground directional element asserted, Terminal T	23
TF32P	Forward phase directional element asserted, Terminal T	31
TF32Q	Forward negative-sequence phase directional element asserted, Terminal T	31
TF32QG	Forward negative-sequence ground directional element asserted, Terminal T	22
TF32V	Forward zero-sequence ground directional element asserted, Terminal T	23
TFLTALA	Through-fault alarm, A-Phase	219
TFLTALB	Through-fault alarm, B-Phase	219
TFLTALC	Through-fault alarm, C-Phase	219
TGLOBAL	Relay calendar clock and ADC sampling synchronized to a high-priority Global time source	354
TH5AD	Zone 1 fifth-harmonic delayed alarm asserted	12
TH5AP	Zone 1 fifth-harmonic instantaneous alarm asserted	12
THRLA1	Thermal element, Level 1 alarm	534
THRLA2	Thermal element, Level 2 alarm	534
THRLA3	Thermal element, Level 3 alarm	534

Table 11.1 Alphabetical List of Relay Word Bits (Sheet 85 of 93)

Name	Bit Description	Row
THRLT1	Thermal element, Level 1 trip	534
THRLT2	Thermal element, Level 2 trip	534
THRLT3	Thermal element, Level 3 trip	534
TIDLALM	TiDL alarm	588
TIRIG	Assert while time is based on IRIG for both mark and value	353
TLED_1	Target LED 1 on relay front panel	1
TLED_10	Target LED 10 on relay front panel	2
TLED_11	Target LED 11 on relay front panel	2
TLED_12	Target LED 12 on relay front panel	2
TLED_13	Target LED 13 on relay front panel	2
TLED_14	Target LED 14 on relay front panel	2
TLED_15	Target LED 15 on relay front panel	2
TLED_16	Target LED 16 on relay front panel	2
TLED_17	Target LED 17 on relay front panel	3
TLED_18	Target LED 18 on relay front panel	3
TLED_19	Target LED 19 on relay front panel	3
TLED_2	Target LED 2 on relay front panel	1
TLED_20	Target LED 20 on relay front panel	3
TLED_21	Target LED 21 on relay front panel	3
TLED_22	Target LED 22 on relay front panel	3
TLED_23	Target LED 23 on relay front panel	3
TLED_24	Target LED 24 on relay front panel	3
TLED_3	Target LED 3 on relay front panel	1
TLED_4	Target LED 4 on relay front panel	1
TLED_5	Target LED 5 on relay front panel	1
TLED_6	Target LED 6 on relay front panel	1
TLED_7	Target LED 7 on relay front panel	1
TLED_8	Target LED 8 on relay front panel	1
TLED_9	Target LED 9 on relay front panel	2
TLL	Total loss-of-life alarm	208
TLL_1	Transformer 1, total loss-of-life alarm	208
TLL_2	Transformer 2, total loss-of-life alarm	208
TLL_3	Transformer 3, total loss-of-life alarm	208
TLOCAL	Relay calendar clock and ADC sampling synchronized to a high-priority local time source	354
TMB1A	Transmitted MIRRORED BITS 1, Channel A	377
TMB1B	Transmitted MIRRORED BITS 1, Channel B	379
TMB2A	Transmitted MIRRORED BITS 2, Channel A	377
TMB2B	Transmitted MIRRORED BITS 2, Channel B	379
TMB3A	Transmitted MIRRORED BITS 3, Channel A	377
TMB3B	Transmitted MIRRORED BITS 3, Channel B	379
TMB4A	Transmitted MIRRORED BITS 4, Channel A	377

Table 11.1 Alphabetical List of Relay Word Bits (Sheet 86 of 93)

Name	Bit Description	Row
TMB4B	Transmitted MIRRORED BITS 4, Channel B	379
TMB5A	Transmitted MIRRORED BITS 5, Channel A	377
TMB5B	Transmitted MIRRORED BITS 5, Channel B	379
TMB6A	Transmitted MIRRORED BITS 6, Channel A	377
TMB6B	Transmitted MIRRORED BITS 6, Channel B	379
TMB7A	Transmitted MIRRORED BITS 7, Channel A	377
TMB7B	Transmitted MIRRORED BITS 7, Channel B	379
TMB8A	Transmitted MIRRORED BITS 8, Channel A	377
TMB8B	Transmitted MIRRORED BITS 8, Channel B	379
TO1	Top-oil temperature alarm Level 1	205
TO1_1	Transformer 1, top-oil temperature alarm Level 1	205
TO1_2	Transformer 1, top-oil temperature alarm Level 2	205
TO2	Top-oil temperature alarm Level 2	205
TO2_1	Transformer 2, top-oil temperature alarm Level 1	205
TO2_2	Transformer 2, top-oil temperature alarm Level 2	205
TO3_1	Transformer 3, top-oil temperature alarm Level 1	205
TO3_2	Transformer 3, top-oil temperature alarm Level 2	205
TPLLEXT	Update PLL using external signal	354
TPTP	The active relay time source is PTP	355
TQUAL1	Time quality, binary, add 1 when asserted	426
TQUAL2	Time quality, binary, add 2 when asserted	426
TQUAL4	Time quality, binary, add 4 when asserted	426
TQUAL8	Time quality, binary, add 8 when asserted	426
TR32G	Reverse ground directional element asserted, Terminal T	23
TR32P	Reverse phase directional element asserted, Terminal T	31
TR32Q	Reverse negative-sequence phase directional element asserted, Terminal T	31
TR32QG	Reverse negative-sequence phase directional element asserted, Terminal T	23
TR32V	Reverse zero-sequence ground directional element asserted, Terminal T	23
TRDE	Transformer de-energize	211
TREA1	Synchrophasor SELOGIC control equation trigger Reason 1	417
TREA2	Synchrophasor SELOGIC control equation trigger Reason 2	417
TREA3	Synchrophasor SELOGIC control equation trigger Reason 3	417
TREA4	Synchrophasor SELOGIC control equation trigger Reason 4	417
TRGTR	Target reset	374
TRIP	Transformer or terminal trip signal asserted	101
TRIPLED	Trip LED on front of relay front panel	0
TRIPS	Terminal S trip output asserted	101
TRIPT	Terminal T trip output asserted	101
TRIPU	Terminal U trip output asserted	101
TRIPW	Terminal W trip output asserted	101
TRIPX	Terminal X trip output asserted	101

Table 11.1 Alphabetical List of Relay Word Bits (Sheet 87 of 93)

Name	Bit Description	Row
TRIPY	Terminal Y trip output asserted	101
TRPXFMR	Transformer trip output asserted	101
TRS	Terminal S trip equation asserted	100
TRSOTF1	Switch-onto-fault TR equation asserted, Line 1	628
TRT	Terminal T trip equation asserted	100
TRU	Terminal U trip equation asserted	100
TRW	Terminal W trip equation asserted	100
TRX	Terminal X trip equation asserted	100
TRXFMR	Transformer trip equation asserted	100
TRY	Terminal Y trip equation asserted	100
TSER	The active relay time source is serial IRIG	355
TSNTPB	Asserts if time was synchronized with backup NTP server before SNTP time-out period expired	354
TSNTPP	Asserts if time was synchronized with primary NTP server before SNTP time-out period expired	354
TSOK	Assert if current time source accuracy is sufficient for synchronized phasor measurements	353
TSSW	High-priority time source switching	354
TSYNC	Assert when ADC sampling is synchronized to a valid high-priority time source	353
TSYNCA	Assert while the time mark from time source or fixed internal source is not synchronized	353
TUPDH	Assert if update source is high-priority time source	353
TUTC1	IRIG-B offset hours from UTC time, binary, add 1 if asserted	425
TUTC2	IRIG-B offset hours from UTC time, binary, add 2 if asserted	425
TUTC4	IRIG-B offset hours from UTC time, binary, add 4 if asserted	425
TUTC8	IRIG-B offset hours from UTC time, binary, add 8 if asserted	425
TUTCH	IRIG-B offset half-hour from UTC time, binary, add 0.5 if asserted	425
TUTCS	IRIG-B offset hours sign from UTC time, subtract the UTC offset if TUTCS is asserted, add otherwise	425
U32QE	Negative-sequence phase directional element enabled, Terminal U	24
U32QGE	Negative-sequence ground directional element enabled, Terminal U	24
U32VE	Zero-sequence voltage directional element enabled, Terminal U	24
U50GF	Zero-sequence current above forward threshold, Terminal U	24
U50GR	Zero-sequence current above reverse threshold, Terminal U	24
U50QF	Negative-sequence current above forward threshold, Terminal U	24
U50QR	Negative-sequence current above reverse threshold, Terminal U	24
UBOSBL1	Unblock out-of-step blocking, Line 1	636
UF32G	Forward ground directional element asserted, Terminal U	25
UF32P	Forward phase directional element asserted, Terminal U	32
UF32Q	Forward negative-sequence phase directional element asserted, Terminal U	32
UF32QG	Forward negative-sequence ground directional element asserted, Terminal U	24
UF32V	Forward zero-sequence ground directional element asserted, Terminal U	25
ULCLS	Unlatch close Terminal S	105
ULCLT	Unlatch close Terminal T	105
ULCLU	Unlatch close Terminal U	105
ULCLW	Unlatch close Terminal W	105

Table 11.1 Alphabetical List of Relay Word Bits (Sheet 88 of 93)

Name	Bit Description	Row
ULCLX	Unlatch close Terminal X	105
ULCLY	Unlatch close Terminal Y	105
ULTRS	Unlatch Terminal S trip	102
ULTRT	Unlatch Terminal T trip	102
ULTRU	Unlatch Terminal U trip	102
ULTRW	Unlatch Terminal W trip	102
ULTRX	Unlatch Terminal X trip	102
ULTRY	Unlatch Terminal Y trip	102
ULTXFMR	Unlatch transformer trip	102
UPD_BLK	Block updating internal clock period and master time	468
UPD_EN	Enable updating internal clock with selected external time source	354
UR32G	Reverse ground directional element asserted, Terminal U	25
UR32P	Reverse phase directional element asserted, Terminal U	32
UR32Q	Reverse negative-sequence phase directional element asserted, Terminal U	32
UR32QG	Reverse negative-sequence phase directional element asserted, Terminal U	25
UR32V	Reverse zero-sequence ground directional element asserted, Terminal U	25
VALARMV	Voltage alarm Terminal V	109
VALARMZ	Voltage alarm Terminal Z	109
VAVBK	A-Phase, Terminal V is not OK (use for blocking)	550
VAVMAP	A-Phase, Terminal V is mapped in a subscription	542
VAVOK	A-Phase, Terminal V configured channel data OK	546
VAZBK	A-Phase, Terminal Z is not OK (use for blocking)	550
VAZMAP	A-Phase, Terminal Z is mapped in a subscription	542
VAZOK	A-Phase, Terminal Z configured channel data OK	546
VB001–VB008	Virtual Bit 001–Virtual Bit 008	415
VB009–VB016	Virtual Bit 009–Virtual Bit 016	414
VB017–VB024	Virtual Bit 017–Virtual Bit 024	413
VB025–VB032	Virtual Bit 025–Virtual Bit 032	412
VB033–VB040	Virtual Bit 033–Virtual Bit 040	411
VB041–VB048	Virtual Bit 041–Virtual Bit 048	410
VB049–VB056	Virtual Bit 049–Virtual Bit 056	409
VB057–VB064	Virtual Bit 057–Virtual Bit 064	408
VB065–VB072	Virtual Bit 065–Virtual Bit 072	407
VB073–VB080	Virtual Bit 073–Virtual Bit 080	406
VB081–VB088	Virtual Bit 081–Virtual Bit 088	405
VB089–VB096	Virtual Bit 089–Virtual Bit 096	404
VB097–VB104	Virtual Bit 097–Virtual Bit 104	403
VB105–VB112	Virtual Bit 105–Virtual Bit 112	402
VB113–VB120	Virtual Bit 113–Virtual Bit 120	401
VB121–VB128	Virtual Bit 121–Virtual Bit 128	400
VB129–VB136	Virtual Bit 129–Virtual Bit 136	399

Table 11.1 Alphabetical List of Relay Word Bits (Sheet 89 of 93)

Name	Bit Description	Row
VB137–VB144	Virtual Bit 137–Virtual Bit 144	398
VB145–VB152	Virtual Bit 145–Virtual Bit 152	397
VB153–VB160	Virtual Bit 153–Virtual Bit 160	396
VB161–VB168	Virtual Bit 161–Virtual Bit 168	395
VB169–VB176	Virtual Bit 169–Virtual Bit 176	394
VB177–VB184	Virtual Bit 177–Virtual Bit 184	393
VB185–VB192	Virtual Bit 185–Virtual Bit 192	392
VB193–VB200	Virtual Bit 193–Virtual Bit 200	391
VB201–VB208	Virtual Bit 201–Virtual Bit 208	390
VB209–VB216	Virtual Bit 209–Virtual Bit 216	389
VB217–VB224	Virtual Bit 217–Virtual Bit 224	388
VB225–VB232	Virtual Bit 225–Virtual Bit 232	387
VB233–VB240	Virtual Bit 233–Virtual Bit 240	386
VB241–VB248	Virtual Bit 241–Virtual Bit 248	385
VB249–VB256	Virtual Bit 249–Virtual Bit 256	384
VBVBK	B-Phase, Terminal V is not OK (use for blocking)	550
VBVMAP	B-Phase, Terminal V is mapped in a subscription	542
VBVOK	B-Phase, Terminal V configured channel data OK	546
VBZBK	B-Phase, Terminal Z is not OK (use for blocking)	550
VBZMAP	B-Phase, Terminal Z is mapped in a subscription	542
VBZOK	B-Phase, Terminal Z configured channel data OK	546
VCVBK	C-Phase, Terminal V is not OK (use for blocking)	550
VCVMAP	C-Phase, Terminal V is mapped in a subscription	542
VCVOK	C-Phase, Terminal V configured channel data OK	546
VCZBK	C-Phase, Terminal Z is not OK (use for blocking)	550
VCZMAP	C-Phase, Terminal Z is mapped in a subscription	542
VCZOK	C-Phase, Terminal Z configured channel data OK	546
VPOLL1	Polarizing voltage available, Line 1	628
VPOLV	Polarizing voltage available, Terminal V	109
VPOLZ	Polarizing voltage available, Terminal Z	109
VVBK	Voltage Terminal V data not OK (use for blocking)	552
VVOK	Voltage Terminal V data OK	553
VZBK	Voltage Terminal Z data not OK (use for blocking)	552
VZOK	Voltage Terminal Z data OK	553
W32QE	Negative-sequence phase directional element enabled, Terminal W	26
W32QGE	Negative-sequence ground directional element enabled, Terminal W	26
W32VE	Zero-sequence voltage directional element enabled, Terminal W	26
W50GF	Zero-sequence current above forward threshold, Terminal W	26
W50GR	Zero-sequence current above reverse threshold, Terminal W	26
W50QF	Negative-sequence current above forward threshold, Terminal W	26
W50QR	Negative-sequence current above reverse threshold, Terminal W	26

Table 11.1 Alphabetical List of Relay Word Bits (Sheet 90 of 93)

Name	Bit Description	Row
WF32G	Forward ground directional element asserted, Terminal W	27
WF32P	Forward phase directional element asserted, Terminal W	33
WF32Q	Forward negative-sequence phase directional element asserted, Terminal W	33
WF32QG	Forward negative-sequence ground directional element asserted, Terminal W	26
WF32V	Forward zero-sequence ground directional element asserted, Terminal W	27
WFLTA	Zone 1 windowed fault detector asserted, A-Phase	6
WFLTA2	Zone 2 windowed fault detector asserted, A-Phase	707
WFLTB	Zone 1 windowed fault detector asserted, B-Phase	6
WFLTB2	Zone 2 windowed fault detector asserted, B-Phase	707
WFLTC	Zone 1 windowed fault detector asserted, C-Phase	6
WFLTC2	Zone 2 windowed fault detector asserted, C-Phase	707
WR32G	Reverse ground directional element asserted, Terminal W	27
WR32P	Reverse phase directional element asserted, Terminal W	33
WR32Q	Reverse negative-sequence phase directional element asserted, Terminal W	33
WR32QG	Reverse negative-sequence phase directional element asserted, Terminal W	27
WR32V	Reverse zero-sequence ground directional element asserted, Terminal W	27
X1GL1	Zone 1 quad ground element, Line 1	648
X1PL1	Zone 1 quad phase element, Line 1	648
X2GL1	Zone 2 quad ground element, Line 1	648
X2PL1	Zone 2 quad phase element, Line 1	648
X32QE	Negative-sequence phase directional element enabled, Terminal X	28
X32QGE	Negative-sequence ground directional element enabled, Terminal X	28
X32VE	Zero-sequence voltage directional element enabled, Terminal X	28
X3GL1	Zone 3 quad ground element, Line 1	649
X3PL1	Zone 3 quad phase element, Line 1	649
X4GL1	Zone 4 quad ground element, Line 1	649
X4PL1	Zone 4 quad phase element, Line 1	649
X50GF	Zero-sequence current above forward threshold, Terminal X	28
X50GR	Zero-sequence current above reverse threshold, Terminal X	28
X50QF	Negative-sequence current above forward threshold, Terminal X	28
X50QR	Negative-sequence current above reverse threshold, Terminal X	28
XAB1L1	Zone 1 quad A-B-Phase element, Line 1	639
XAB2L1	Zone 2 quad A-B-Phase element, Line 1	640
XAB3L1	Zone 3 quad A-B-Phase element, Line 1	641
XAB4L1	Zone 4 quad A-B-Phase element, Line 1	642
XAG1L1	Zone 1 quad A-Phase-to-ground element, Line 1	639
XAG2L1	Zone 2 quad A-Phase-to-ground element, Line 1	640
XAG3L1	Zone 3 quad A-Phase-to-ground element, Line 1	641
XAG4L1	Zone 4 quad A-Phase-to-ground element, Line 1	642
XBC1L1	Zone 1 quad B-C-Phase element, Line 1	639
XBC2L1	Zone 2 quad B-C-Phase element, Line 1	640

Table 11.1 Alphabetical List of Relay Word Bits (Sheet 91 of 93)

Name	Bit Description	Row
XBC3L1	Zone 3 quad B-C-Phase element, Line 1	641
XBC4L1	Zone 4 quad B-C-Phase element, Line 1	642
XBG1L1	Zone 1 quad B-Phase-to-ground element, Line 1	639
XBG2L1	Zone 2 quad B-Phase-to-ground element, Line 1	640
XBG3L1	Zone 3 quad B-Phase-to-ground element, Line 1	641
XBG4L1	Zone 4 quad B-Phase-to-ground element, Line 1	642
XCA1L1	Zone 1 quad C-A-Phase element, Line 1	639
XCA2L1	Zone 2 quad C-A-Phase element, Line 1	640
XCA3L1	Zone 3 quad C-A-Phase element, Line 1	641
XCA4L1	Zone 4 quad C-A-Phase element, Line 1	642
XCG1L1	Zone 1 quad C-Phase-to-ground element, Line 1	639
XCG2L1	Zone 2 quad C-Phase-to-ground element, Line 1	640
XCG3L1	Zone 3 quad C-Phase-to-ground element, Line 1	641
XCG4L1	Zone 4 quad C-Phase-to-ground element, Line 1	642
XF32G	Forward ground directional element asserted, Terminal X	29
XF32P	Forward phase directional element asserted, Terminal X	34
XF32Q	Forward negative-sequence phase directional element asserted, Terminal X	34
XF32QG	Forward negative-sequence ground directional element asserted, Terminal X	28
XF32V	Forward zero-sequence ground directional element asserted, Terminal X	29
XIABCL1	Impedance inside inner OOS zone, Line 1	637
XOABCL1	Impedance inside outer OOS zone, Line 1	637
XR32G	Reverse ground directional element asserted, Terminal X	29
XR32P	Reverse phase directional element asserted, Terminal X	34
XR32Q	Reverse negative-sequence phase directional element asserted, Terminal X	34
XR32QG	Reverse negative-sequence phase directional element asserted, Terminal X	29
XR32V	Reverse zero-sequence ground directional element asserted, Terminal X	29
Y32QE	Negative-sequence phase directional element enabled, Terminal Y	693
Y32QGE	Negative-sequence ground directional element enabled, Terminal Y	693
Y32VE	Zero-sequence voltage directional element enabled, Terminal Y	693
Y50GF	Zero-sequence current above forward threshold, Terminal Y	693
Y50GR	Zero-sequence current above reverse threshold, Terminal Y	693
Y50QF	Negative-sequence current above forward threshold, Terminal Y	693
Y50QR	Negative-sequence current above reverse threshold, Terminal Y	693
YEAR1	IRIG-B year information (add 1 years if bit asserted)	424
YEAR10	IRIG-B year information (add 10 years if bit asserted)	424
YEAR2	IRIG-B year information (add 2 years if bit asserted)	424
YEAR20	IRIG-B year information (add 20 years if bit asserted)	424
YEAR4	IRIG-B year information (add 4 years if bit asserted)	424
YEAR40	IRIG-B year information (add 40 years if bit asserted)	424
YEAR8	IRIG-B year information (add 8 years if bit asserted)	424
YEAR80	IRIG-B year information (add 80 years if bit asserted)	424

Table 11.1 Alphabetical List of Relay Word Bits (Sheet 92 of 93)

Name	Bit Description	Row
YF32G	Forward ground directional element asserted, Terminal Y	694
YF32P	Forward phase directional element asserted, Terminal Y	695
YF32Q	Forward negative-sequence phase directional element asserted, Terminal Y	695
YF32QG	Forward negative-sequence ground directional element asserted, Terminal Y	693
YF32V	Forward zero-sequence ground directional element asserted, Terminal Y	694
YR32G	Reverse ground directional element asserted, Terminal Y	694
YR32P	Reverse phase directional element asserted, Terminal Y	695
YR32Q	Reverse negative-sequence phase directional element asserted, Terminal Y	695
YR32QG	Reverse negative-sequence phase directional element asserted, Terminal Y	694
YR32V	Reverse negative-sequence ground directional element asserted, Terminal Y	694
Z1GL1	Zone 1 ground element, Line 1	650
Z1L1	Zone 1 phase or ground distance, Line 1	651
Z1MGTC1	Zone 1 mho ground torque control, Line 1	632
Z1MPTC1	Zone 1 mho phase torque control, Line 1	632
Z1PL1	Zone 1 phase element, Line 1	650
Z1TL1	Zone 1 phase or ground distance, time delayed, Line 1	651
Z1XGTC1	Zone 1 quad ground torque control, Line 1	639
Z1XPTC1	Zone 1 quad phase torque control, Line 1	639
Z2GL1	Zone 2 ground element, Line 1	650
Z2L1	Zone 2 phase or ground distance, Line 1	651
Z2MGTC1	Zone 2 mho ground torque control, Line 1	633
Z2MPTC1	Zone 2 mho phase torque control, Line 1	633
Z2PL1	Zone 2 phase element, Line 1	650
Z2TL1	Zone 2 phase or ground distance, time delayed, Line 1	651
Z2XGTC1	Zone 2 quad ground torque control, Line 1	640
Z2XPTC1	Zone 2 quad phase torque control, Line 1	640
Z3GL1	Zone 3 ground element, Line 1	650
Z3L1	Zone 3 phase or ground distance, Line 1	651
Z3MGTC1	Zone 3 mho ground torque control, Line 1	634
Z3MPTC1	Zone 3 mho phase torque control, Line 1	634
Z3PL1	Zone 3 phase element, Line 1	650
Z3TL1	Zone 3 phase or ground distance, time delayed, Line 1	651
Z3XGTC1	Zone 3 quad ground torque control, Line 1	641
Z3XPTC1	Zone 3 quad phase torque control, Line 1	641
Z4GL1	Zone 4 ground element, Line 1	650
Z4L1	Zone 4 phase or ground distance, Line 1	651
Z4MGTC1	Zone 4 mho ground torque control, Line 1	635
Z4MPTC1	Zone 4 mho phase torque control, Line 1	635
Z4PL1	Zone 4 phase element, Line 1	650
Z4TL1	Zone 4 phase or ground distance, time delayed, Line 1	651
Z4XGTC1	Zone 4 quad ground torque control, Line 1	642

Table 11.1 Alphabetical List of Relay Word Bits (Sheet 93 of 93)

Name	Bit Description	Row
Z4XPTC1	Zone 4 quad phase torque control, Line 1	642
ZLINL1	Load-encroachment “load in” element, Line 1	628
ZLOADL1	ZLOUT or ZLIN element picked up, Line 1	628
ZLOUTL1	Load-encroachment “load out” element, Line 1	628

Row List

Table 11.2 Row List of Relay Word Bits (Sheet 1 of 42)

Name	Bit Description	Row
Enable and Tripping Bits		
EN	Enable LED on relay front panel	0
TRIPLED	Trip LED on front of relay front panel	0
TLED_*xx*	Target LED (01–24) on relay front panel	1–3
Zone 1 Phase-Differential Elements		
E87T*m*[a]	Zone 1 terminal *m* currents included in differential zone	4
CON	Zone 1 external fault detected	5
CON*p*[b]	Zone 1 external fault detected, *p*-Phase	5
87T_S	Zone 1 dwell periods identified in differential current, three-legged transformer	5
87T_S*p*[b]	Zone 1 dwell periods identified in differential current, non-three-legged transformer, *p*-Phase	5
GFLT*p*[b]	Zone 1 instantaneous fault detector asserted, *p*-Phase	6
WFLT*p*[b]	Zone 1 windowed fault detector asserted, *p*-Phase	6
87T_BP*x*	Zone 1 bipolar low-/high-set (1, 2) signature detected	6
IFLT*p*[b]	Zone 1 internal fault detected, *p*-Phase	7
87T_B1*p*[b]	Zone 1 bipolar low-set signature detected in operate current, *p*-Phase	7
87WS	Zone 1 waveshape-based tripping element operated (87R OR 87U)	7
87*p*HB[b]	Zone 1 harmonic-blocked phase-differential element asserted (no security timer), *p*-Phase	8
87*p*HR[b]	Zone 1 harmonic-restrained phase-differential element asserted (no security timer), *p*-Phase	8
87XBK5	Zone 1 fifth-harmonic cross blocking asserted	8
87T_SF	Zone 1 magnetizing inrush current detected by waveshape logic (three-legged transformer)	9
87T_SF*p*[b]	Zone 1 magnetizing inrush current detected by waveshape logic, *p*-Phase (non-three-legged transformer)	9
87U	Zone 1 unrestrained differential element operated	9
87U*p*[b]	Zone 1 unrestrained differential overcurrent element operated, *p*-Phase	9
P87*p*[b]	Zone 1 restrained differential element asserted (no security timer), *p*-Phase	10
87R	Zone 1 phase percentage-restrained differential element operated	10
87R*p*[b]	Zone 1 phase-restrained differential element operated, *p*-Phase	10
87T_M	Zone 1 sufficient differential current to enable three-legged transformer waveshape logic	10
87*p*BK2[b]	Zone 1 second- and fourth-harmonic blocking asserted, *p*-Phase	11
87*p*BK5[b]	Zone 1 fifth-harmonic blocking asserted, *p*-Phase	11
87QB	Zone 1 block negative-sequence differential element	11

Table 11.2 Row List of Relay Word Bits (Sheet 2 of 42)

Name	Bit Description	Row
87XBK2	Zone 1 second- and fourth-harmonic cross blocking asserted	11
CTU*p*[b]	Zone 1 CT in unsaturated state following an external fault, *p*-Phase	12
TH5AD	Zone 1 fifth-harmonic delayed alarm asserted	12
TH5AP	Zone 1 fifth-harmonic instantaneous alarm asserted	12
87T_B2*p*[b]	Zone 1 bipolar high-set signature detected in operate current, *p*-Phase	12
Zone 1 Negative-Sequence Differential Elements		
87Q	Zone 1 negative-sequence differential element operated	13
87PQ	Zone 1 minimum pickup and slope conditions satisfied for negative-sequence differential element	13
Restricted Earth Fault Elements		
NDREF*x*	Nondirectional REF Element (1–3) enabled	14, 16, 18
REF50*x*	Neutral (operating current) Instantaneous Overcurrent REF Element (1–3) picked up	14, 16, 18
REF50T*x*	Neutral Instantaneous Overcurrent REF Element (1–3) timed out	14, 16, 18
REF51T*x*	REF Element (1–3) TOC element timed out	14, 16, 18
RF51TC*x*	Inverse-Time Neutral Overcurrent REF Element (1–3) enabled	14, 16, 18
REFF*x*	Earth Fault Inside REF Element (1–3) zone	14, 16, 18
REFR*x*	Earth Fault Outside REF Element (1–3) zone	14, 16, 18
TCREF*x*	REF Element (1–3) enabled	14, 16, 18
REF	Earth fault inside REF Element 1, 2, or 3 zones	15
*		
*		
*		
REF51*x*P	REF Element (1–3) TOC element picked up	15, 17, 19
REF51R*x*	REF Element (1–3) TOC element reset	15, 17, 19
REFBLK*x*	REF Element (1–3) phase fault or external ground fault detected	15, 17, 19
REFOCT*x*	REF Element (1–3) open CT, wiring or setting error detected	15, 17, 19
Ground Directional Elements		
*m*32QE[c]	Negative-sequence phase directional element enabled, Terminal *m*	20, 22, 24, 26, 28
*m*32QGE[c]	Negative-sequence ground directional element enabled, Terminal *m*	20, 22, 24, 26, 28
*m*32VE[c]	Zero-sequence voltage directional element enabled, Terminal *m*	20, 22, 24, 26, 28
*m*50GF[c]	Zero-sequence current above forward threshold, Terminal *m*	20, 22, 24, 26, 28
*m*50GR[c]	Zero-sequence current above reverse threshold, Terminal *m*	20, 22, 24, 26, 28
*m*50QF[c]	Negative-sequence current above forward threshold, Terminal *m*	20, 22, 24, 26, 28
*m*50QR[c]	Negative-sequence current above reverse threshold, Terminal *m*	20, 22, 24, 26, 28
*m*F32QG[c]	Forward negative-sequence ground directional element asserted, Terminal *m*	20, 22, 24, 26, 28
*m*F32G[c]	Forward ground directional element asserted, Terminal *m*	21, 23, 25, 27, 29
*m*F32V[c]	Forward zero-sequence ground directional element asserted, Terminal *m*	21, 23, 25, 27, 29
*m*R32G[c]	Reverse ground directional element asserted, Terminal *m*	21, 23, 25, 27, 29
*m*R32QG[c]	Reverse negative-sequence phase directional element asserted, Terminal *m*	21, 23, 25, 27, 29
*m*R32V[c]	Reverse zero-sequence ground directional element asserted, Terminal *m*	21, 23, 25, 27, 29

Table 11.2 Row List of Relay Word Bits (Sheet 3 of 42)

Name	Bit Description	Row
Phase Directional Elements		
*m*F32P[c]	Forward phase directional element asserted, Terminal *m*	30–34
*m*F32Q[c]	Forward negative-sequence phase directional element asserted, Terminal *m*	30–34
*m*R32P[c]	Reverse phase directional element asserted, Terminal *m*	30–34
*m*R32Q[c]	Reverse negative-sequence phase directional element asserted, Terminal *m*	30–34
DIRBLK*m*[c]	Block phase and ground directional Element *m*	30–34
Definite and Directional Overcurrent Elements		
50*m*P1[c]	Phase Definite-Time Element 1, Terminal *m* asserted	35, 41, 47, 53, 59
50*m*P2[c]	Phase Definite-Time Element 2, Terminal *m* asserted	35, 41, 47, 53, 59
67*m*P1[c]	Phase Directional/Torque-Controlled Element 1, Terminal *m* picked up	35, 41, 47, 53, 59
67*m*P1T[c]	Phase Directional/Torque-Controlled Element 1, Terminal *m* timed out	35, 41, 47, 53, 59
67*m*P1TC[c]	Phase Directional/Torque-Control Enable Definite-Time Element 1, Terminal *m*	35, 41, 47, 53, 59
67*m*P2[c]	Phase Directional/Torque-Controlled Element 2, Terminal *m* picked up	35, 41, 47, 53, 59
67*m*P2T[c]	Phase Directional/Torque-Controlled Element 2, Terminal *m* timed out	35, 41, 47, 53, 59
67*m*P2TC[c]	Phase Directional/Torque-Control Enable Definite-Time Element 2, Terminal *m*	35, 41, 47, 53, 59
50*m*P3[c]	Phase Definite-Time Element 3, Terminal *m* asserted	36, 42, 48, 54, 60
67*m*P3[c]	Phase Directional/Torque-Controlled Element 3, Terminal *m* picked up	36, 42, 48, 54, 60
67*m*P3T[c]	Phase Directional/Torque-Controlled Element 3, Terminal *m* timed out	36, 42, 48, 54, 60
67*m*P3TC[c]	Phase Directional/Torque-Control Enable Definite-Time Element 3, Terminal *m*	36, 42, 48, 54, 60
50*m*Q1[c]	Negative-Sequence Definite-Time Element 1, Terminal *m* asserted	37, 43, 49, 55, 61
50*m*Q2[c]	Negative-Sequence Definite-Time Element 2, Terminal *m* asserted	37, 43, 49, 55, 61
67*m*Q1[c]	Negative-Sequence Directional/Torque-Controlled Element 1, Terminal *m* picked up	37, 43, 49, 55, 61
67*m*Q1T[c]	Negative-Sequence Directional/Torque-Controlled Element 1, Terminal *m* timed out	37, 43, 49, 55, 61
67*m*Q1TC[c]	Negative-Sequence Directional/Torque-Control Enable Definite-Time Element 1, Terminal *m*	37, 43, 49, 55, 61
67*m*Q2[c]	Negative-Sequence Directional/Torque-Controlled Element 2, Terminal *m* picked up	37, 43, 49, 55, 61
67*m*Q2T[c]	Negative-Sequence Directional/Torque-Controlled Element 2, Terminal *m* timed out	37, 43, 49, 55, 61
67*m*Q2TC[c]	Negative-Sequence Directional/Torque-Control Enable Definite-Time Element 2, Terminal *m*	37, 43, 49, 55, 61
50*m*Q3[c]	Negative-Sequence Definite-Time Element 3, Terminal *m* asserted	38, 44, 50, 56, 62
67*m*Q3[c]	Negative-Sequence Directional/Torque-Controlled Element 3, Terminal *m* picked up	38, 44, 50, 56, 62
67*m*Q3T[c]	Negative-Sequence Directional/Torque-Controlled Element 3, Terminal *m* timed out	38, 44, 50, 56, 62
67*m*Q3TC[c]	Negative-Sequence Directional/Torque-Control Enable Definite-Time Element 3, Terminal *m*	38, 44, 50, 56, 62
50*m*G1[c]	Residual Definite-time Element 1, Terminal *m* asserted	39, 45, 51, 57, 63
50*m*G2[c]	Residual Definite-Time Element 2, Terminal *m* asserted	39, 45, 51, 57, 63
67*m*G1[c]	Residual Directional/Torque-Controlled Element 1, Terminal *m* picked up	39, 45, 51, 57, 63
67*m*G1T[c]	Residual Directional/Torque-Controlled Element 1, Terminal *m* timed out	39, 45, 51, 57, 63
67*m*G1TC[c]	Residual Directional/Torque-Control Enable Definite-Time Element 1, Terminal *m*	39, 45, 51, 57, 63
67*m*G2[c]	Residual Directional/Torque-Controlled Element 2, Terminal *m* picked up	39, 45, 51, 57, 63
67*m*G2T[c]	Residual Directional/Torque-Controlled Element 2, Terminal *m* timed out	39, 45, 51, 57, 63
67*m*G2TC[c]	Residual Directional/Torque-Control Enable Definite-Time Element 2, Terminal *m*	39, 45, 51, 57, 63
50*m*G3[c]	Residual Definite-Time Element 3, Terminal *m* asserted	40, 46, 52, 58, 64
67*m*G3[c]	Residual Directional/Torque-Controlled Element 3, Terminal *m* picked up	40, 46, 52, 58, 64

Table 11.2 Row List of Relay Word Bits (Sheet 4 of 42)

Name	Bit Description	Row
67*m*G3T[c]	Residual Directional/Torque-Controlled Element 3, Terminal *m* timed out	40, 46, 52, 58, 64
67*m*G3TC[c]	Residual Directional/Torque-Control Enable Definite-Time Element 3, Terminal *m*	40, 46, 52, 58, 64
Inverse-Time Overcurrent Elements		
51MM*xx*	Inverse-Time Element (01–10) pickup setting outside of specified limits	65–74
51R*xx*	Inverse-Time Element (01–10) reset	65–74
51S*xx*	Inverse-Time Element (01–10) picked up	65–74
51T*xx*	Inverse-Time Element (01–10) timed out	65–74
51TC*xx*	Inverse-Time Element (01–10) enabled	65–74
51TM*xx*	Inverse-Time Element (01–10) time-dial setting outside of specified limits	65–74
Zone 1 Phase-Differential Elements (Continued)		
87T_M*p*[b]	Zone 1 sufficient differential current to enable non-three-legged transformer waveshape logic, *p*-Phase	75
EFDT*p*[b]	Zone 1 EFD extension timer output, *p*-Phase	75
Unbalance Logic		
46*m*P[a]	Current unbalance detected Terminal *m*	76, 77
46*m*T[a]	Current Unbalance Terminal *m* timed out	76, 77
Under- and Overvoltage Elements		
27*x*P1	Undervoltage Element (1–5), Level 1 asserted	78–80
27*x*P1T	Undervoltage Element (1–5), Level 1 timed out	78–80
27*x*P2	Undervoltage Element (1–5), Level 2 asserted	78–80
27TC*x*	Undervoltage Element (1–5), torque-control	78–80
59*x*P1	Overvoltage Element (1–5), Level 1 asserted	81–83
59*x*P1T	Overvoltage Element (1–5), Level 1 timed out	81–83
59*x*P2	Overvoltage Element (1–5), Level 2 asserted	81–83
59TC*x*	Overvoltage Element (1–5), torque-control	81–83
Under- and Overpower Elements		
E32OP*xx*	Overpower Element (01–10) enabled	84–88
32OP*xx*	Overpower Element (01–10) picked up	84–88
32OPT*xx*	Overpower Element (01–10) timed out	84–88
E32UP*xx*	Underpower Element (01–10) enabled	89–93
32UP*xx*	Underpower Element (01–10) picked up	89–93
32UPT*xx*	Underpower Element (01–10) timed out	89–93
Frequency Elements		
81D*x*	Definite-time frequency element picked up, Level (1–6)	94–96
81D*x*OVR	Definite-Time Overfrequency Level (1–6)	94–96
81D*x*T	Definite-time over and underfrequency element delay for Level (1–6)	94–96
81D*x*UDR	Definite-Time Underfrequency Level (1–6)	94–96
27B81	Frequency elements blocked because of undervoltage	97
Volts/Hertz Element		
24D1	Volts-per-hertz element Level 1 asserted	98
24D1T	Volts-per-hertz Level 1 timed out	98

Table 11.2 Row List of Relay Word Bits (Sheet 5 of 42)

Name	Bit Description	Row
24D2R	Volts-per-hertz element Level 2 reset	98
24D2T	Volts-per-hertz Level 2 timed out	98
24TC	Volts-per-hertz predefined element, torque control	98
24U*x*R	User-Defined Volts-Per-Hertz Curve (1–2) reset	99
24U*x*T	User-Defined Volts-Per-Hertz Curve (1–2) timed out	99
24U*x*TC	User-Defined Volts-Per-Hertz Curve (1–2), torque control	99
Breaker Trip and Close Logic Elements		
TR*m*[a]	Terminal *m* trip equation asserted	100
TRXFMR	Transformer trip equation asserted	100
TRIP	Transformer or terminal trip signal asserted	101
TRIP*m*[a]	Terminal *m* trip output asserted	101
TRPXFMR	Transformer trip output asserted	101
ULTR*m*[a]	Unlatch Terminal *m* trip	102
ULTXFMR	Unlatch transformer trip	102
CL*m*[a]	Close breaker Terminal *m* equation	103
CLS*m*[a]	Close breaker Terminal *m* output	104
ULCL*m*[a]	Unlatch close Terminal *m*	105
Open-Phase Detector		
OPH*pm*[a, b]	*p*-Phase, Terminal *m* open	106–108
OPH*m*[a]	Terminal *m* open	106–108
Loss-of-Potential and Polarizing Voltage		
LOP*k*[d]	Loss-of-potential Terminal *k*	109
VALARM*k*[d]	Voltage alarm Terminal *k*	109
VPOL*k*[d]	Polarizing voltage available, Terminal *k*	109
ILOPV	Internal loss of potential, Terminal V	109
ILOPZ	Internal loss of potential, Terminal Z	109
Breaker Failure Elements		
50F*m*[c]	Phase or neutral current above pickup, Terminal *m*	110, 112, 114, 116, 118
ATBFI*m*[c]	Alternative breaker failure initiated, Terminal *m*	110, 112, 114, 116, 118
ATBFT*m*[c]	Alternative breaker failure timer timed out, Terminal *m*	110, 112, 114, 116, 118
BFI*m*[c]	Breaker failure initiated, Terminal *m*	110, 112, 114, 116, 118
BFIT*m*[c]	Breaker failure timer timed out, Terminal *m*	110, 112, 114, 116, 118
EBFIT*m*[c]	Externally initiated breaker failure timer timed out, Terminal *m*	110, 112, 114, 116, 118
EXBF*m*[c]	External breaker failure input initiated, Terminal *m*	110, 112, 114, 116, 118
RT*m*[c]	Retrip timer timed out/retrip command issued, Terminal *m*	110, 112, 114, 116, 118

Table 11.2 Row List of Relay Word Bits (Sheet 6 of 42)

Name	Bit Description	Row
ABFIT*m*[c]	Alternative breaker failure, Terminal *m*	111, 113, 115, 117, 119
BFISPT*m*[c]	Breaker failure seal-in timer timed out, Terminal *m*	111, 113, 115, 117, 119
ENINBF*m*[c]	Neutral/residual breaker failure function enabled, Terminal *m*	111, 113, 115, 117, 119
FBF*m*[c]	Breaker failure asserted/initiated, Terminal *m*	111, 113, 115, 117, 119
I*pm*BF[b, c]	*p*-Phase current above threshold, Terminal *m*	111, 113, 115, 117, 119
IN*m*BF[c]	Neutral current above threshold, Terminal *m*	111, 113, 115, 117, 119
52 Status Elements		
52AL*m*[a]	Breaker alarm, Terminal *m*	120–121
52CL*m*[a]	Breaker closed, Terminal *m*	120–121
Power Factor		
LD_*p*PFY[b]	Leading power factor, *p*-Phase, Terminal Y	122
LD_3PFY	Leading three-phase power factor, Terminal Y	122
LG_*p*PFY[b]	Lagging power factor, *p*-Phase, Terminal Y	122
LG_3PFY	Lagging three-phase power factor, Terminal Y	122
89 Disconnect Switch Status		
89AM*zz*[f]	Disconnect *zz* N/O auxiliary contact	124–126
89AL	Any disconnect alarm	127
89OIP	Any disconnect operation in progress	127
LOCAL	Local front panel control	127
89BM*zz*[f]	Disconnect *zz* N/C auxiliary contact	128–130
89AL*zz*[f]	Disconnect *zz* alarm	132–134
89OIP*zz*[f]	Disconnect *zz* operation in progress	136–138
89OPN*zz*[f]	Disconnect *zz* open	140–142
89CL*zz*[f]	Disconnect *zz* closed	144–146
89CTL*zz*[f]	Disconnect *zz* control status	148–150
89CLB*zz*[f]	Disconnect *zz* bus-zone protection	152–154
89 Disconnect Switch Open and Close Control		
89CLS*zz*[f]	Disconnect Close *zz* output	156–158
89OPE*zz*[f]	Disconnect Open *zz* output	160–162
89CCM*zz*[f]	Mimic Disconnect *zz* close control	164–166
89CC*zz*[f]	ASCII Close Disconnect *zz* command	168–170
89OC*zz*[f]	ASCII Open Disconnect *zz* command	172–174
89CCN*zz*[f]	Close Disconnect *zz*	176–178
89OCN*zz*[f]	Open Disconnect *zz*	180–182
89OCM*zz*[f]	Mimic Disconnect *zz* open control	184–186

Table 11.2 Row List of Relay Word Bits (Sheet 7 of 42)

Name	Bit Description	Row
89 Disconnect Switch Timers and Breaker Status		
89CRS*zz*[f]	Disconnect *zz* close reset	188–190
89ORS*zz*[f]	Disconnect *zz* open reset	192–194
89OBL*zz*[f]	Disconnect *zz* open block	196–198
Breaker Monitor		
B*m*BCWAL[c]	Breaker contact wear alarm, Breaker *m*	200–204
B*m*BITAL[c]	Inactivity time alarm, Breaker *m*	200–204
B*m*ESOAL[c]	Slow electrical operate alarm, Breaker *m*	200–204
B*m*KAIAL[c]	Interrupted rms current alarm, Breaker *m*	200–204
B*m*MRTAL[c]	Motor run time alarm, Breaker *m*	200–204
B*m*MSOAL[c]	Mechanical slow operation alarm, Breaker *m*	200–204
EB*m*MON[c]	Breaker monitoring Terminal *m* enabled	200–204
Thermal Element Bits		
TO*x*_1	Transformer (1–3), Top-Oil Temperature Alarm Level 1	205
TO*x*_2	Transformer (1–3), Top-Oil Temperature Alarm Level 2	205
TO1	Top-Oil Temperature Alarm Level 1	205
TO2	Top-Oil Temperature Alarm Level 2	205
HS*x*_1	Transformer (1–3), hot-spot temperature alarm Level 1	206
HS*x*_2	Transformer (1–3), hot-spot temperature alarm Level 2	206
HS1	Hot-Spot Alarm Level 1	206
HS2	Hot-Spot Alarm Level 2	206
FAA*x*_1	Transformer (1–3), aging insulation acceleration factor alarm, Level 1	207
FAA*x*_2	Transformer (1–3), aging insulation acceleration factor alarm, Level 2	207
FAA1	Aging insulation acceleration factor alarm, Level 1	207
FAA2	Aging insulation acceleration factor alarm, Level 2	207
RLL	Rate of loss-of-life alarm	208
RLL_*x*	Transformer (1–3), rate of loss-of-life alarm	208
TLL	Total loss-of-life alarm	208
TLL_*x*	Transformer (1–3), total loss-of life alarm	208
CSCM	Cooling coefficient or measurement alarm	209
CSCM_*x*	Transformer (1–3), cooling coefficient or measurement alarm	209
CSE	Cooling stage efficiency alarm	209
CSE_*x*	Transformer (1–3), cooling stage efficiency alarm	209
CSALRM	Cooling stage determination alarm	210
MAMB_OK	Ambient temperature measurement RTD healthy	210
MTO*x*_OK	Transformer (1–3), top-oil temperature measurement RTD healthy	210
T*x*CS2	Transformer (1–3) cooling stage 2	211
T*x*CS3	Transformer (1–3) cooling stage 3	211
TRDE	Transformer de-energize	211

Table 11.2 Row List of Relay Word Bits (Sheet 8 of 42)

Name	Bit Description	Row
RTD Status Bits		
RTD*xx*OK	RTD (01–12) healthy	212–213
AMB_F	Ambient temperature fault condition	213
T*x*OIL_F	Transformer (1–3) oil temperature fault condition	213
RTD*xx*SC	RTD (01–12) short-circuited	214–215
RTD*xx*OC	RTD (01–12) open-circuited	216–217
RTDCOMF	SEL-2600 communication failure	218
RTDFL	SEL-2600 RAM failure	218
Through-Fault Monitor		
ETHRFLT	Through-fault element enabled	219
TFLTAL*p*[b]	Through-fault alarm, *p*-Phase	219
Battery Monitor		
DC1F	DC Channel 1 failed	220
DC1G	DC Channel 1 ground fault detected	220
DC1R	DC Channel 1 excess ripples detected	220
DC1W	DC Channel 1 warning	220
Demand Metering		
DMP*xx*	Demand Metering Element (01–10) asserted	221–223
EDM*xx*	Demand Metering Element (01–10) enabled	221–223
52 Open and Close		
CC*m*[a]	Breaker close command, Terminal *m*	224–225
OC*m*[a]	Breaker open command, Terminal *m*	224–225
Local Control and Supervision Bits		
LB*xx*	Local Bit (01–32) asserted	227–230
LB_SP*xx*	Local Bit (01–32) supervision enabled	231–234
LB_DP*xx*	Local Bit (01–32) status display enabled	235–238
Remote Bits		
RB*xx*	Remote Bit (01–32) asserted	240–243
Settings Group Bits		
CHSG	Settings group changed	244
SG*x*	Settings Group (1–6) is active	244
Source Selection		
ALTVS	Alternative voltage source, Terminal S	246
ALTVT	Alternative voltage source, Terminal T	246
ALTVU	Alternative voltage source, Terminal U	246
ALTVW	Alternative voltage source, Terminal W	246
ALTVX	Alternative voltage source, Terminal X	246
ALTVY	Alternative voltage source, Terminal Y	246
I/O Board Position B Inputs		
IN2*xx*	Input 2*xx* (*xx* = 01–24) asserted (if installed)	252–254

Table 11.2 Row List of Relay Word Bits (Sheet 9 of 42)

Name	Bit Description	Row
TiDL I/O Board Virtual Inputs		
IN3*xx*	Input 3*xx* (*xx* = 01–24) asserted (if installed)	256–258
Protection SELOGIC Variables		
PSV*xx*	Protection SELOGIC Variable (01–64) asserted	260–267
Protection SELOGIC Latches		
PLT*xx*	Protection SELOGIC Latch (01–32) asserted	268–271
Protection SELOGIC Conditioning Timers		
PCT*xx*Q	Protection SELOGIC Conditioning Timer (01–32) asserted	272–275
Protection SELOGIC Sequencing Timers		
PST*xx*Q	Protection SELOGIC Sequencing Timer (01–32) asserted	276–279
PST*xx*R	Protection SELOGIC Sequencing Timer (01–32) reset	280–283
Protection SELOGIC Counters		
PCN*xx*Q	Protection SELOGIC Counter (01–32) asserted	284–287
PCN*xx*R	Protection SELOGIC Counter (01–32) reset	288–291
Automation SELOGIC Variables		
ASV*xxx*	Automation SELOGIC Variable (001–256) asserted	292–323
Automation SELOGIC Latches		
ALT*xx*	Automation SELOGIC Latch (01–64) asserted	324–331
Automation SELOGIC Sequencing Timers		
AST*xx*Q	Automation SELOGIC Sequencing Timer (01–32) asserted	332–335
AST*xx*R	Automation SELOGIC Sequencing Timer (01–32) reset	336–339
Automation SELOGIC Counters		
ACN*xx*Q	Automation SELOGIC Counter (01–32) asserted	340–343
ACN*xx*R	Automation SELOGIC Counter (01–32) reset	344–347
SELOGIC Error and Status Reporting		
AFRTEXA	Automation SELOGIC control equation first execution after automation settings change	348
AFRTEXP	Automation SELOGIC control equation first execution after protection settings change	348
AUNRLBL	Automation SELOGIC control equation unresolved label	348
MATHERR	SELOGIC control equation math error	348
PFRTEX	Protection SELOGIC control equation first execution	348
PUNRLBL	Protection SELOGIC control equation unresolved label	348
Alarms and Jumpers		
BADPASS	Invalid password attempt alarm	349
GRPSW	Pulsed alarm for group switches	349
HALARM	Hardware alarm	349
HALARMA	Pulse stream for unacknowledged diagnostic warnings	349
HALARML	Latched alarm for diagnostic failures	349
HALARMP	Pulsed alarm for diagnostic warnings	349
SALARM	Software alarm	349
SETCHG	Pulsed alarm for settings changes	349
ACCESS	A user is logged in at Access Level B or above	350

Table 11.2 Row List of Relay Word Bits (Sheet 10 of 42)

Name	Bit Description	Row
ACCESSP	Pulsed alarm for logins to Access Level B or above	350
EACC	Enable Level 1 access (SELOGIC control equation)	350
E2AC	Enable Level 1–2 access (SELOGIC control equation)	350
BRKENAB	Breaker control enable jumper is installed	350
PASSDIS	Password disable jumper is installed	350
Synchrophasor Configuration Error		
SPCER1	Synchrophasor configuration error on PORT 1	351
SPCER2	Synchrophasor configuration error on PORT 2	351
SPCER3	Synchrophasor configuration error on PORT 3	351
SPCERF	Synchrophasor configuration error on PORT F	351
Frequency Calculation		
EAFSRC	Alternative frequency source (SELOGIC control equation)	352
FREQFZ	Assert if relay is not calculating frequency	352
FREQOK	Assert if relay is estimating frequency	352
Time and Date Management		
PMDOK	Assert if data acquisition system is operating correctly	353
TIRIG	Assert while time is based on IRIG for both mark and value	353
TSOK	Assert if current time source accuracy is sufficient for synchronized phasor measurements	353
TSYNC	Assert when ADC sampling is synchronized to a valid high-priority time source	353
TSYNCA	Assert while the time mark from time source or fixed internal source is not synchronized	353
TUPDH	Assert if update source is high-priority time source	353
BLKLPTS	Block low-priority source from updating relay time	354
UPD_EN	Enable updating internal clock with selected external time source	354
TLOCAL	Relay calendar clock and ADC sampling synchronized to a high-priority local time source	354
TPLLEXT	Update PLL using external signal	354
TSSW	High-priority time source switching	354
TGLOBAL	Relay calendar clock and ADC sampling synchronized to a high-priority Global time source	354
TSNTPP	Asserts if time was synchronized with primary NTP server before SNTP time-out period expired	354
TSNTPB	Asserts if time was synchronized with backup NTP server before SNTP time-out period expired	354
TPTP	The active relay time source is PTP	355
TBNC	The active relay time source is BNC IRIG	355
TSER	The active relay time source is serial IRIG	355
I/O Board Position B Outputs		
OUT2*xx*	Output 2*xx* (*xx* = 01–16) asserted	360–361
I/O Board Position C Outputs		
OUT3*xx*	Output 3*xx* (*xx* = 01–16) asserted	362–363
Pushbuttons		
PB*xx*	Pushbutton (1–12) asserted	364–365
PB*xx*_PUL	Pushbutton (1–12) pulsed for 1 processing interval	366–367

Table 11.2 Row List of Relay Word Bits (Sheet 11 of 42)

Name	Bit Description	Row
Pushbutton LED Bits		
PB*xx*_LED	Pushbutton (1–12) LED illuminated	368–369
Data Reset Bits		
RST_BK*m*[c]	Reset Breaker *m* monitoring	372
RST_DEM	Reset demand metering	372
RST_ENE	Reset energy metering	372
RST_PDM	Reset peak demand metering	372
RST_BAT	Reset battery monitoring	373
RST_HAL	Reset HALARMA	373
RSTDNPE	Reset DNP fault summary data	373
RSTTRGT	Reset front-panel targets	373
RST_BKY	Reset Breaker Y monitoring	373
RST_79C	Reset recloser shot counters	373
Target Logic Bits		
ER	Event report triggered	374
FAULT	Fault detected	374
TRGTR	Target reset	374
Mirrored Bits		
RMB*x*A	Received Mirrored Bits (1–8), Channel A	376
TMB*x*A	Transmitted Mirrored Bits (1–8), Channel A	377
RMB*x*B	Received Mirrored Bits (1–8), Channel B	378
TMB*x*B	Transmitted Mirrored Bits (1–8), Channel B	379
ANOKA	Analog transfer on Mirrored Bits Channel A	380
CBADA	Unavailability threshold exceeded for normal Mirrored Bits communication, Channel A	380
DOKA	Mirrored Bits Channel A in normal mode	380
LBOKA	Mirrored Bits channel in loopback mode, Channel A	380
RBADA	Outage too large for normal Mirrored Bits communication, Channel A	380
ROKA	Mirrored Bits Channel A normal status in non-loopback mode	380
ANOKB	Analog transfer on Mirrored Bits Channel B	381
CBADB	Unavailability threshold exceeded for normal Mirrored Bits communication, Channel B	381
DOKB	Mirrored Bits Channel B in normal mode	381
LBOKB	Mirrored Bits channel in loopback mode, Channel B	381
RBADB	Outage too large for normal Mirrored Bits communication, Channel B	381
ROKB	Mirrored Bits Channel B normal status in non-loopback mode	381
Test Bits		
LPHDSIM	IEC 61850 logical node for physical device simulation	382
TESTDB	Database test bit	382
TESTDB2	Enhanced label-based test bit	382
TESTFM	Fast Meter test bit	382
TESTPUL	Pulse test bit	382

Table 11.2 Row List of Relay Word Bits (Sheet 12 of 42)

Name	Bit Description	Row
Virtual Bits		
VB*xxx*	Virtual Bit (001–256)	384–415
Fast SER Enable Bits		
FSERP*x*	Fast SER enabled for Port (1, 2, 3, or 5)	416
FSERPF	Fast SER enabled for front port	416
Synchrophasor SELOGIC and Frequency OK Bits		
FROKPM	Synchrophasor frequency measurement OK	417
PMTEST	Synchrophasor test mode	417
PMTRIG	Synchrophasor SELOGIC control equation trigger	417
TREA*x*	Synchrophasor SELOGIC control equation trigger Reason (1–4)	417
RTC Synchrophasor Status Bits		
RTCCFGA	RTC Channel A configuration complete	418
RTCCFGB	RTC Channel B configuration complete	418
RTCDLYA	Max RTC delay exceeded for Channel A	418
RTCDLYB	Max RTC delay exceeded for Channel B	418
RTCROK	Valid aligned RTC data available on all enabled channels	418
RTCSEQA	RTC Channel A data in sequence	418
RTCSEQB	RTC Channel B data in sequence	418
RTCENA	Valid remote synchrophasors received on Channel A	419
RTCENB	Valid remote synchrophasors received on Channel B	419
RTCROKA	Valid aligned RTC data available on Channel A	419
RTCROKB	Valid aligned RTC data available on Channel B	419
RTC Remote Digital Status Bits		
RTCAD*xx*	RTC Channel A remote data Bit (01–16)	420–421
RTCBD*xx*	RTC Channel B remote data Bit (01–16)	422–423
IRIG-B Control Bits		
YEAR1	IRIG-B year information (add 1 year if bit asserted)	424
YEAR2	IRIG-B year information (add 2 years if bit asserted)	424
YEAR4	IRIG-B year information (add 4 years if bit asserted)	424
YEAR8	IRIG-B year information (add 8 years if bit asserted)	424
YEAR10	IRIG-B year information (add 10 years if bit asserted)	424
YEAR20	IRIG-B year information (add 20 years if bit asserted)	424
YEAR40	IRIG-B year information (add 40 years if bit asserted)	424
YEAR80	IRIG-B year information (add 80 years if bit asserted)	424
TUTCH	IRIG-B offset half-hour from UTC time, binary, add 0.5 if asserted	425
TUTC1	IRIG-B offset hours from UTC time, binary, add 1 if asserted	425
TUTC2	IRIG-B offset hours from UTC time, binary, add 2 if asserted	425
TUTC4	IRIG-B offset hours from UTC time, binary, add 4 if asserted	425
TUTC8	IRIG-B offset hours from UTC time, binary, add 8 if asserted	425
TUTCS	IRIG-B offset hours sign from UTC time, subtract the UTC offset if TUTCS is asserted, add otherwise	425

Table 11.2 Row List of Relay Word Bits (Sheet 13 of 42)

Name	Bit Description	Row
DST	Daylight-saving time	426
DSTP	IRIG-B daylight-saving time pending	426
LPSEC	Leap second is added	426
LPSECP	Leap second pending	426
TQUAL1	Time quality, binary, add 1 when asserted	426
TQUAL2	Time quality, binary, add 2 when asserted	426
TQUAL4	Time quality, binary, add 4 when asserted	426
TQUAL8	Time quality, binary, add 8 when asserted	426
Ethernet Switch		
LINK5A	Link status of the PORT 5A connection	428
LINK5B	Link status of the PORT 5B connection	428
LINK5C	Link status of the PORT 5C connection	428
LINK5D	Link status of the PORT 5D connection	428
LNKFAIL	Link status of the active station bus port	428
LNKFL2	Link status of the active process bus port	428
LINK5E	Link status of the PORT 5E connection	428
P5ASEL	PORT 5A active/inactive	429
P5BSEL	PORT 5B active/inactive	429
P5CSEL	PORT 5C active/inactive	429
P5DSEL	PORT 5D active/inactive	429
P5ESEL	PORT 5E active/inactive	429
Signal Profiling		
SPEN	Signal profiling enabled	430
DNP Event Lock		
EVELOCK	Lock DNP events	431
Fast Operate Transmit Bits		
FOPF_*xx*	PORT F (front-panel) Fast Operate transmit Bit (01–32)	432–435
FOP1_*xx*	PORT 1 Fast Operate transmit Bit (01–32)	436–439
FOP2_*xx*	PORT 2 Fast Operate transmit Bit (01–32)	440–443
FOP3_*xx*	PORT 3 Fast Operate transmit Bit (01–32)	444–447
Synchronism Check		
FAST*m*[a]	Breaker *m* synchronizing voltage slipping faster than polarizing voltage	448
25ENBKY	Breaker Y synchronism check enabled	448
BSYNBKY	Breaker Y synchronism check blocked	448
SLOW*m*[a]	Breaker *m* synchronizing voltage slipping slower than polarizing voltage	449
ALTSY	Breaker Y alternative synchronizing voltage source selected (SELOGIC control equation)	449
SFZBK*m*[a]	Breaker *m* slip frequency is less than 5 MHz	450
25WC1Y	Breaker Y voltages within Sync Angle 1 window compensated and unsupervised	450
25WC2Y	Breaker Y voltages within Sync Angle 2 window compensated and unsupervised	450
SFBK*m*[a]	Breaker *m* slip frequency is within acceptable slip-frequency window	451
25C1Y	Breaker Y voltages within Sync Angle 1 window compensated	451

Table 11.2 Row List of Relay Word Bits (Sheet 14 of 42)

Name	Bit Description	Row
25C2Y	Breaker Y voltages within Sync Angle 2 window compensated	451
25WC1*m*[c]	Breaker *m* voltages within Sync Angle 1 window compensated and unsupervised	452
25WC2*m*[c]	Breaker *m* voltages within Sync Angle 2 window compensated and unsupervised	452–453
25C1*m*[c]	Breaker *m* voltages within Sync Angle 1 window compensated	453
25C2*m*[c]	Breaker *m* voltages within Sync Angle 2 window compensated	453–454
ALTS*m*[c]	Breaker *m* alternative synchronizing voltage source selected (SELOGIC control equation)	454–455
59VDIF*m*[a]	Breaker *m* synchronizing voltage difference less than limit	455
BSYNBK*m*[c]	Breaker *m* synchronism check blocked	456
25ENBK*m*[c]	Breaker *m* synchronism check enabled	456–457
59VS*m*[a]	Breaker *m* synchronizing voltage within healthy voltage window	457
Faulted Phase and Terminal Identification Logic		
PH*p*_*m*[b, c]	*p*-Phase involved in the fault, Terminal *m*	458–459
GROUND*m*[a]	Ground involved in the fault, Terminal *m*	459–460
PHA_Y	A-phase involved in the fault, Terminal Y	460
PHB_Y	B-phase involved in the fault, Terminal Y	460
PHC_Y	C-phase involved in the fault, Terminal Y	460
Fault Identification Logic		
FIDEN_*m*[c]	FIDEN logic enabled, Terminal *m*	461
FSA_*m*[c]	A-Phase sector fault (AG or BCG fault), Terminal *m*	461–462
FSB_*m*[c]	B-Phase sector fault (BG or CAG fault), Terminal *m*	462
FSC_*m*[c]	C-Phase sector fault (CG or ABG fault), Terminal *m*	462–463
FIDEN_Y	FIDEN logic enabled, Terminal Y	463
FSA_Y	A-Phase sector fault (AG or BCG fault), Terminal Y	463
FSB_Y	B-Phase sector fault (BG or CAG fault), Terminal Y	463
FSC_Y	C-Phase sector fault (CG or ABG fault), Terminal Y	463
Zone 1 Phase-Differential Elements (Continued)		
87BPH	Zone 1 high-set bipolar differential overcurrent condition asserted	464
87BPH*p*	Zone 1 high-set bipolar differential overcurrent condition asserted, *p*-Phase	464
87BPL	Zone 1 low-set bipolar differential overcurrent condition asserted	464
87BPL*p*	Zone 1 low-set bipolar differential overcurrent condition asserted, *p*-Phase	464
87HBP*p*	Zone 1 minimum pickup and slope conditions satisfied for harmonic-blocked phase differential, *p*-Phase	465
87HRP*p*	Zone 1 minimum pickup and slope conditions satisfied for harmonic-restrained phase differential, *p*-Phase	465
87T	Zone 1 transformer differential element operated (87R OR 87Q OR 87U)	465
87UF*p*	Zone 1 unrestrained differential element operated from filtered current, *p*-Phase	466
87UNBL	Zone 1 waveshape-based inrush unblocking condition asserted	467
87UNBL*p*	Zone 1 waveshape-based inrush unblocking condition asserted, *p*-Phase	467
87UR*p*	Zone 1 unrestrained differential element operated from raw current, *p*-Phase	466
87WB	Zone 1 magnetizing inrush current detected by waveshape logic	467
87WB*p*	Zone 1 magnetizing inrush current detected by waveshape logic, *p*-Phase	467

Table 11.2 Row List of Relay Word Bits (Sheet 15 of 42)

Name	Bit Description	Row
Time and Date Management (Continued)		
BNC_BNP	Bad jitter on BNC port and the IRIG-B signal is lost afterwards	468
BNC_OK	IRIG-B signal from BNC port is available and has sufficient quality	468
BNC_RST	Disqualify BNC IRIG-B time source	468
BNC_SET	Qualify BNC IRIG-B time source	468
SER_OK	IRIG-B signal from serial PORT 1 is available and has sufficient quality	468
SER_RST	Disqualify serial IRIG-B time source	468
SER_SET	Qualify serial IRIG-B time source	468
UPD_BLK	Block updating internal clock period and master time	468
BNC_TIM	A valid IRIG-B time source is detected on BNC port	469
SER_BNP	Bad jitter on serial port and the IRIG-B signal is lost afterwards	469
SER_TIM	A valid IRIG-B time source is detected on serial port	469
PTP_TIM	A valid PTP time source is detected	469
PTP_SET	Qualify PTP time source	469
PTP_RST	Disqualify PTP time source	469
PTP_OK	PTP is available and has sufficient quality	469
P5ABSW	PORT 5A or 5B has just become active	469
PTPSYNC	Synchronized to high-quality PTP source	470
PTP_BNP	Bad jitter on PTP signals and the PTP signal is lost afterwards	470
SERSYNC	Synchronized to high-quality serial IRIG source	470
BNCSYNC	Synchronized to high-quality BNC IRIG source	470
P5CDSW	PORT 5C or 5D has become active	470
TiDL I/O Board Virtual Inputs (Continued)		
IN4*xx*	Input 4*xx* (*xx* = 01–24) asserted (if installed)	472–474
IN5*xx*	Input 5*xx* (*xx* = 01–24) asserted (if installed)	476–478
Power Factor (Continued)		
LD_*p*PF*m*[b, c]	Leading power factor, *p*-Phase, Terminal *m*	484–488
LD_3PF*m*[c]	Leading three-phase power factor, Terminal *m*	484–488
LG_*p*PF*m*[b, c]	Lagging power factor, *p*-Phase, Terminal *m*	484–488
LG_3PF*m*[c]	Lagging three-phase power factor, Terminal *m*	484–488
LD*p*PF*qp*[b, e]	Leading power factor, *p*-Phase, Combined Terminals *qp*	489–492
LD3PF*qp*[e]	Leading three-phase power factor, Combined Terminals *qp*	489–492
LG*p*PF*qp*[b, e]	Lagging power factor, *p*-Phase, Combined Terminals *qp*	489–492
LG3PF*qp*[e]	Lagging three-phase power factor, Combined Terminals *qp*	489–492
Bay Control Disconnect Timers and Breaker Status (Continued)		
52SRACK	Breaker S rack position	493
52TRACK	Breaker T rack position	493
52URACK	Breaker U rack position	493
52WRACK	Breaker W rack position	493
52XRACK	Breaker X rack position	493
52STEST	Breaker S test position	493

Table 11.2 Row List of Relay Word Bits (Sheet 16 of 42)

Name	Bit Description	Row
52TTEST	Breaker T test position	493
52UTEST	Breaker U test position	493
52WTEST	Breaker W test position	494
52XTEST	Breaker X test position	494
*	Reserved	494
52YRACK	Breaker Y rack position	494
52YTEST	Breaker Y test position	494
*	Reserved	494
*	Reserved	494
*	Reserved	494
Combined Terminal Ground Directional Elements		
150QF	Negative-sequence current above forward threshold, Terminal ST	496
150QR	Negative-sequence current above reverse threshold, Terminal ST	496
132QE	Negative-sequence phase directional element enabled, Terminal ST	496
132QGE	Negative-sequence ground directional element enabled, Terminal ST	496
150GF	Zero-sequence current above forward threshold, Terminal ST	496
150GR	Zero-sequence current above reverse threshold, Terminal ST	496
132VE	Zero-sequence voltage directional element enabled, Terminal ST	496
1F32QG	Forward negative-sequence ground directional element asserted, Terminal ST	496
1R32QG	Reverse negative-sequence phase directional element asserted, Terminal ST	497
1F32V	Forward zero-sequence ground directional element asserted, Terminal ST	497
1R32V	Reverse zero-sequence ground directional element asserted, Terminal ST	497
1F32G	Forward ground directional element asserted, Terminal ST	497
1R32G	Reverse ground directional element asserted, Terminal ST	497
*	Reserved	497
*	Reserved	497
*	Reserved	497
250QF	Negative-sequence current above forward threshold, Terminal TU	498
250QR	Negative-sequence current above reverse threshold, Terminal TU	498
232QE	Negative-sequence phase directional element enabled, Terminal TU	498
232QGE	Negative-sequence ground directional element enabled, Terminal TU	498
250GF	Zero-sequence current above forward threshold, Terminal TU	498
250GR	Zero-sequence current above reverse threshold, Terminal TU	498
232VE	Zero-sequence voltage directional element enabled, Terminal TU	498
2F32QG	Forward negative-sequence ground directional element asserted, Terminal TU	498
2R32QG	Reverse negative-sequence phase directional element asserted, Terminal TU	499
2F32V	Forward zero-sequence ground directional element asserted, Terminal TU	499
2R32V	Reverse zero-sequence ground directional element asserted, Terminal TU	499
2F32G	Forward ground directional element asserted, Terminal TU	499
2R32G	Reverse ground directional element asserted, Terminal TU	499
*	Reserved	499

Table 11.2 Row List of Relay Word Bits (Sheet 17 of 42)

Name	Bit Description	Row
*	Reserved	499
*	Reserved	499
350QF	Negative-sequence current above forward threshold, Terminal UW	500
350QR	Negative-sequence current above reverse threshold, Terminal UW	500
332QE	Negative-sequence phase directional element enabled, Terminal UW	500
332QGE	Negative-sequence ground directional element enabled, Terminal UW	500
350GF	Zero-sequence current above forward threshold, Terminal UW	500
350GR	Zero-sequence current above reverse threshold, Terminal UW	500
332VE	Zero-sequence voltage directional element enabled, Terminal UW	500
3F32QG	Forward negative-sequence ground directional element asserted, Terminal UW	500
3R32QG	Reverse negative-sequence phase directional element asserted, Terminal UW	501
3F32V	Forward zero-sequence ground directional element asserted, Terminal UW	501
3R32V	Reverse zero-sequence ground directional element asserted, Terminal UW	501
3F32G	Forward ground directional element asserted, Terminal UW	501
3R32G	Reverse ground directional element asserted, Terminal UW	501
*	Reserved	501
*	Reserved	501
*	Reserved	501
450QF	Negative-sequence current above forward threshold, Terminal WX	502
450QR	Negative-sequence current above reverse threshold, Terminal WX	502
432QE	Negative-sequence phase directional element enabled, Terminal WX	502
432QGE	Negative-sequence ground directional element enabled, Terminal WX	502
450GF	Zero-sequence current above forward threshold, Terminal WX	502
450GR	Zero-sequence current above reverse threshold, Terminal WX	502
432VE	Zero-sequence voltage directional element enabled, Terminal WX	502
4F32QG	Forward negative-sequence ground directional element asserted, Terminal WX	502
4R32QG	Reverse negative-sequence phase directional element asserted, Terminal WX	503
4F32V	Forward zero-sequence ground directional element asserted, Terminal WX	503
4R32V	Reverse zero-sequence ground directional element asserted, Terminal WX	503
4F32G	Forward ground directional element asserted, Terminal WX	503
4R32G	Reverse ground directional element asserted, Terminal WX	503
*	Reserved	503
*	Reserved	503
*	Reserved	503
Combined Terminal Phase Directional Elements		
1F32P	Forward phase directional element asserted, Terminal ST	504
1R32P	Reverse phase directional element asserted, Terminal ST	504
1F32Q	Forward negative-sequence phase directional element asserted, Terminal ST	504
1R32Q	Reverse negative-sequence phase directional element asserted, Terminal ST	504
*	Reserved	504
*	Reserved	504

Table 11.2 Row List of Relay Word Bits (Sheet 18 of 42)

Name	Bit Description	Row
*	Reserved	504
DIRBLK1	Block Phase and Ground Directional Element ST	504
2F32P	Forward phase directional element asserted, Terminal TU	505
2R32P	Reverse phase directional element asserted, Terminal TU	505
2F32Q	Forward negative-sequence phase directional element asserted, Terminal TU	505
2R32Q	Reverse negative-sequence phase directional element asserted, Terminal TU	505
*	Reserved	505
*	Reserved	505
*	Reserved	505
DIRBLK2	Block Phase and Ground Directional Element TU	505
3F32P	Forward phase directional element asserted, Terminal UW	506
3R32P	Reverse phase directional element asserted, Terminal UW	506
3F32Q	Forward negative-sequence phase directional element asserted, Terminal UW	506
3R32Q	Reverse negative-sequence phase directional element asserted, Terminal UW	506
*	Reserved	506
*	Reserved	506
*	Reserved	506
DIRBLK3	Block Phase and Ground Directional Element UW	506
4F32P	Forward phase directional element asserted, Terminal WX	507
4R32P	Reverse phase directional element asserted, Terminal WX	507
4F32Q	Forward negative-sequence phase directional element asserted, Terminal WX	507
4R32Q	Reverse negative-sequence phase directional element asserted, Terminal WX	507
*	Reserved	507
*	Reserved	507
*	Reserved	507
DIRBLK4	Block Phase and Ground Directional Element WX	507
Combined Terminal Definite & Directional Overcurrent Elements		
501P1	Phase Definite-Time Element 1, Terminal ST asserted	508
671P1TC	Phase Directional/Torque-Control Enable Definite-Time Element 1, Terminal ST	508
671P1	Phase Directional/Torque-Controlled Element 1, Terminal ST picked up	508
671P1T	Phase Directional/Torque-Controlled Element 1, Terminal ST timed out	508
501P2	Phase Definite-Time Element 2, Terminal ST asserted	508
671P2TC	Phase Directional/Torque-Control Enable Definite-Time Element 2, Terminal ST	508
671P2	Phase Directional/Torque-Controlled Element 2, Terminal ST picked up	508
671P2T	Phase Directional/Torque-Controlled Element 2, Terminal ST timed out	508
501P3	Phase Definite-Time Element 3, Terminal ST asserted	509
671P3TC	Phase Directional/Torque-Control Enable Definite-Time Element 3, Terminal ST	509
671P3	Phase Directional/Torque-Controlled Element 3, Terminal ST picked up	509
671P3T	Phase Directional/Torque-Controlled Element 3, Terminal ST timed out	509
*	Reserved	509
*	Reserved	509

Table 11.2 Row List of Relay Word Bits (Sheet 19 of 42)

Name	Bit Description	Row
*	Reserved	509
*	Reserved	509
501Q1	Negative-sequence definite-time Element 1, Terminal ST asserted	510
671Q1TC	Negative-sequence directional/torque-control enable definite-time Element 1, Terminal ST	510
671Q1	Negative-sequence directional/torque-controlled Element 1, Terminal ST picked up	510
671Q1T	Negative-sequence directional/torque-controlled Element 1, Terminal ST timed out	510
501Q2	Negative-sequence definite-time Element 2, Terminal ST asserted	510
671Q2TC	Negative-sequence directional/torque-control enable definite-time Element 2, Terminal ST	510
671Q2	Negative-sequence directional/torque-controlled Element 2, Terminal ST picked up	510
671Q2T	Negative-sequence directional/torque-controlled Element 2, Terminal ST timed out	510
501Q3	Negative-sequence definite-time Element 3, Terminal ST asserted	511
671Q3TC	Negative-sequence directional/torque-control enable definite-time Element 3, Terminal ST	511
671Q3	Negative-sequence directional/torque-controlled Element 3, Terminal ST picked up	511
671Q3T	Negative-sequence directional/torque-controlled Element 3, Terminal ST timed out	511
*	Reserved	511
*	Reserved	511
*	Reserved	511
*	Reserved	511
501G1	Residual definite-time Element 1, Terminal ST asserted	512
671G1TC	Residual directional/torque-control enable definite-time Element 1, Terminal ST	512
671G1	Residual directional/torque-controlled Element 1, Terminal ST picked up	512
671G1T	Residual directional/torque-controlled Element 1, Terminal ST timed out	512
501G2	Residual definite-time Element 2, Terminal ST asserted	512
671G2TC	Residual directional/torque-control enable definite-time Element 2, Terminal ST	512
671G2	Residual directional/torque-controlled Element 2, Terminal ST picked up	512
671G2T	Residual directional/torque-controlled Element 2, Terminal ST timed out	512
501G3	Residual definite-time Element 3, Terminal ST asserted	513
671G3TC	Residual directional/torque-control enable definite-time Element 3, Terminal ST	513
671G3	Residual directional/torque-controlled Element 3, Terminal ST picked up	513
671G3T	Residual directional/torque-controlled Element 3, Terminal ST timed out	513
*	Reserved	513
*	Reserved	513
*	Reserved	513
*	Reserved	513
502P1	Phase definite-time Element 1, Terminal TU asserted	514
672P1TC	Phase directional/torque-control enable definite-time Element 1, Terminal TU	514
672P1	Phase directional/torque-controlled Element 1, Terminal TU picked up	514
672P1T	Phase directional/torque-controlled Element 1, Terminal TU timed out	514
502P2	Phase definite-time Element 2, Terminal TU asserted	514
672P2TC	Phase directional/torque-control enable definite-time Element 2, Terminal TU	514
672P2	Phase directional/torque-controlled Element 2, Terminal TU picked up	514

Table 11.2 Row List of Relay Word Bits (Sheet 20 of 42)

Name	Bit Description	Row
672P2T	Phase directional/torque-controlled Element 2, Terminal TU timed out	514
502P3	Phase definite-time Element 3, Terminal TU asserted	515
672P3TC	Phase directional/torque-control enable definite-time Element 3, Terminal TU	515
672P3	Phase directional/torque-controlled Element 3, Terminal TU picked up	515
672P3T	Phase directional/torque-controlled Element 3, Terminal TU timed out	515
*	Reserved	515
*	Reserved	515
*	Reserved	515
*	Reserved	515
502Q1	Negative-Sequence Definite-Time Element 1, Terminal TU asserted	516
672Q1TC	Negative-Sequence Directional/Torque-Control Enable Definite-Time Element 1, Terminal TU	516
672Q1	Negative-Sequence Directional/Torque-Controlled Element 1, Terminal TU picked up	516
672Q1T	Negative-Sequence Directional/Torque-Controlled Element 1, Terminal TU timed out	516
502Q2	Negative-Sequence Definite-Time Element 2, Terminal TU asserted	516
672Q2TC	Negative-Sequence Directional/Torque-Control Enable Definite-Time Element 2, Terminal TU	516
672Q2	Negative-Sequence Directional/Torque-Controlled Element 2, Terminal TU picked up	516
672Q2T	Negative-Sequence Directional/Torque-Controlled Element 2, Terminal TU timed out	516
502Q3	Negative-Sequence Definite-Time Element 3, Terminal TU asserted	517
672Q3TC	Negative-Sequence Directional/Torque-Control Enable Definite-Time Element 3, Terminal TU	517
672Q3	Negative-Sequence Directional/Torque-Controlled Element 3, Terminal TU picked up	517
672Q3T	Negative-Sequence Directional/Torque-Controlled Element 3, Terminal TU timed out	517
*	Reserved	517
*	Reserved	517
*	Reserved	517
*	Reserved	517
502G1	Residual Definite-Time Element 1, Terminal TU asserted	518
672G1TC	Residual Directional/Torque-Control Enable Definite-Time Element 1, Terminal TU	518
672G1	Residual Directional/Torque-Controlled Element 1, Terminal TU picked up	518
672G1T	Residual Directional/Torque-Controlled Element 1, Terminal TU timed out	518
502G2	Residual Definite-Time Element 2, Terminal TU asserted	518
672G2TC	Residual Directional/Torque-Control Enable Definite-Time Element 2, Terminal TU	518
672G2	Residual Directional/Torque-Controlled Element 2, Terminal TU picked up	518
672G2T	Residual Directional/Torque-Controlled Element 2, Terminal TU timed out	518
502G3	Residual Definite-Time Element 3, Terminal TU asserted	519
672G3TC	Residual Directional/Torque-Control Enable Definite-Time Element 3, Terminal TU	519
672G3	Residual Directional/Torque-Controlled Element 3, Terminal TU picked up	519
672G3T	Residual Directional/Torque-Controlled Element 3, Terminal TU timed out	519
*	Reserved	519
*	Reserved	519
*	Reserved	519
*	Reserved	519

Table 11.2 Row List of Relay Word Bits (Sheet 21 of 42)

Name	Bit Description	Row
503P1	Phase Definite-Time Element 1, Terminal UW asserted	520
673P1TC	Phase Directional/Torque-Control Enable Definite-Time Element 1, Terminal UW	520
673P1	Phase Directional/Torque-Controlled Element 1, Terminal UW picked up	520
673P1T	Phase Directional/Torque-Controlled Element 1, Terminal UW timed out	520
503P2	Phase Definite-Time Element 2, Terminal UW asserted	520
673P2TC	Phase Directional/Torque-Control Enable Definite-Time Element 2, Terminal UW	520
673P2	Phase Directional/Torque-Controlled Element 2, Terminal UW picked up	520
673P2T	Phase Directional/Torque-Controlled Element 2, Terminal UW timed out	520
503P3	Phase Definite-Time Element 3, Terminal UW asserted	521
673P3TC	Phase Directional/Torque-Control Enable Definite-Time Element 3, Terminal UW	521
673P3	Phase Directional/Torque-Controlled Element 3, Terminal UW picked up	521
673P3T	Phase Directional/Torque-Controlled Element 3, Terminal UW timed out	521
*	Reserved	521
*	Reserved	521
*	Reserved	521
*	Reserved	521
503Q1	Negative-Sequence Definite-Time Element 1, Terminal UW asserted	522
673Q1TC	Negative-Sequence Directional/Torque-Control Enable Definite-Time Element 1, Terminal UW	522
673Q1	Negative-Sequence Directional/Torque-Controlled Element 1, Terminal UW picked up	522
673Q1T	Negative-Sequence Directional/Torque-Controlled Element 1, Terminal UW timed out	522
503Q2	Negative-Sequence Definite-Time Element 2, Terminal UW asserted	522
673Q2TC	Negative-Sequence Directional/Torque-Control Enable Definite-Time Element 2, Terminal UW	522
673Q2	Negative-Sequence Directional/Torque-Controlled Element 2, Terminal UW picked up	522
673Q2T	Negative-Sequence Directional/Torque-Controlled Element 2, Terminal UW timed out	522
503Q3	Negative-Sequence Definite-Time Element 3, Terminal UW asserted	523
673Q3TC	Negative-Sequence Directional/Torque-Control Enable Definite-Time Element 3, Terminal UW	523
673Q3	Negative-Sequence Directional/Torque-Controlled Element 3, Terminal UW picked up	523
673Q3T	Negative-Sequence Directional/Torque-Controlled Element 3, Terminal UW timed out	523
*	Reserved	523
*	Reserved	523
*	Reserved	523
*	Reserved	523
503G1	Residual Definite-Time Element 1, Terminal UW asserted	524
673G1TC	Residual Directional/Torque-Control Enable Definite-Time Element 1, Terminal UW	524
673G1	Residual Directional/Torque-Controlled Element 1, Terminal UW picked up	524
673G1T	Residual Directional/Torque-Controlled Element 1, Terminal UW timed out	524
503G2	Residual Definite-Time Element 2, Terminal UW asserted	524
673G2TC	Residual Directional/Torque-Control Enable Definite-Time Element 2, Terminal UW	524
673G2	Residual Directional/Torque-Controlled Element 2, Terminal UW picked up	524

Table 11.2 Row List of Relay Word Bits (Sheet 22 of 42)

Name	Bit Description	Row
673G2T	Residual Directional/Torque-Controlled Element 2, Terminal UW timed out	524
503G3	Residual Definite-Time Element 3, Terminal UW asserted	525
673G3TC	Residual Directional/Torque-Control Enable Definite-Time Element 3, Terminal UW	525
673G3	Residual Directional/Torque-Controlled Element 3, Terminal UW picked up	525
673G3T	Residual Directional/Torque-Controlled Element 3, Terminal UW timed out	525
*	Reserved	525
*	Reserved	525
*	Reserved	525
*	Reserved	525
504P1	Phase Definite-Time Element 1, Terminal WX asserted	526
674P1TC	Phase Directional/Torque-Control Enable Definite-Time Element 1, Terminal WX	526
674P1	Phase Directional/Torque-Controlled Element 1, Terminal WX picked up	526
674P1T	Phase Directional/Torque-Controlled Element 1, Terminal WX timed out	526
504P2	Phase Definite-Time Element 2, Terminal WX asserted	526
674P2TC	Phase Directional/Torque-Control Enable Definite-Time Element 2, Terminal WX	526
674P2	Phase Directional/Torque-Controlled Element 2, Terminal WX picked up	526
674P2T	Phase Directional/Torque-Controlled Element 2, Terminal WX timed out	526
504P3	Phase Definite-Time Element 3, Terminal WX asserted	527
674P3TC	Phase Directional/Torque-Control Enable Definite-Time Element 3, Terminal WX	527
674P3	Phase Directional/Torque-Controlled Element 3, Terminal WX picked up	527
674P3T	Phase Directional/Torque-Controlled Element 3, Terminal WX timed out	527
*	Reserved	527
*	Reserved	527
*	Reserved	527
*	Reserved	527
504Q1	Negative-Sequence Definite-Time Element 1, Terminal WX asserted	528
674Q1TC	Negative-Sequence Directional/Torque-Control Enable Definite-Time Element 1, Terminal WX	528
674Q1	Negative-Sequence Directional/Torque-Controlled Element 1, Terminal WX picked up	528
674Q1T	Negative-Sequence Directional/Torque-Controlled Element 1, Terminal WX timed out	528
504Q2	Negative-Sequence Definite-Time Element 2, Terminal WX asserted	528
674Q2TC	Negative-Sequence Directional/Torque-Control Enable Definite-Time Element 2, Terminal WX	528
674Q2	Negative-Sequence Directional/Torque-Controlled Element 2, Terminal WX picked up	528
674Q2T	Negative-Sequence Directional/Torque-Controlled Element 2, Terminal WX timed out	528
504Q3	Negative-Sequence Definite-Time Element 3, Terminal WX asserted	529
674Q3TC	Negative-Sequence Directional/Torque-Control Enable Definite-Time Element 3, Terminal WX	529
674Q3	Negative-Sequence Directional/Torque-Controlled Element 3, Terminal WX picked up	529
674Q3T	Negative-Sequence Directional/Torque-Controlled Element 3, Terminal WX timed out	529
*	Reserved	529
*	Reserved	529

Table 11.2 Row List of Relay Word Bits (Sheet 23 of 42)

Name	Bit Description	Row
*	Reserved	529
*	Reserved	529
504G1	Residual Definite-Time Element 1, Terminal WX asserted	530
674G1TC	Residual Directional/Torque-Control Enable Definite-Time Element 1, Terminal WX	530
674G1	Residual Directional/Torque-Controlled Element 1, Terminal WX picked up	530
674G1T	Residual Directional/Torque-Controlled Element 1, Terminal WX timed out	530
504G2	Residual Definite-Time Element 2, Terminal WX asserted	530
674G2TC	Residual Directional/Torque-Control Enable Definite-Time Element 2, Terminal WX	530
674G2	Residual Directional/Torque-Controlled Element 2, Terminal WX picked up	530
674G2T	Residual Directional/Torque-Controlled Element 2, Terminal WX timed out	530
504G3	Residual Definite-Time Element 3, Terminal WX asserted	531
674G3TC	Residual Directional/Torque-Control Enable Definite-Time Element 3, Terminal WX	531
674G3	Residual Directional/Torque-Controlled Element 3, Terminal WX picked up	531
674G3T	Residual Directional/Torque-Controlled Element 3, Terminal WX timed out	531
*	Reserved	531
*	Reserved	531
*	Reserved	531
*	Reserved	531
IEC Thermal Elements		
THRLA1	Thermal element, Level 1 alarm	534
THRLT1	Thermal element, Level 1 trip	534
THRLA2	Thermal element, Level 2 alarm	534
THRLT2	Thermal element, Level 2 trip	534
THRLA3	Thermal element, Level 3 alarm	534
THRLT3	Thermal element, Level 3 trip	534
*	Reserved	534
*	Reserved	534
Sampled Values (SV) Subscription		
*	Reserved	536
SVS07OK	Subscription 07 is valid	536
SVS06OK	Subscription 06 is valid	536
SVS05OK	Subscription 05 is valid	536
SVS04OK	Subscription 04 is valid	536
SVS03OK	Subscription 03 is valid	536
SVS02OK	Subscription 02 is valid	536
SVS01OK	Subscription 01 is valid	536
*	Reserved	537
*	Reserved	537
*	Reserved	537
*	Reserved	537
*	Reserved	537

Table 11.2 Row List of Relay Word Bits (Sheet 24 of 42)

Name	Bit Description	Row
*	Reserved	537
*	Reserved	537
*	Reserved	537
*	Reserved	538
*	Reserved	538
*	Reserved	538
*	Reserved	538
*	Reserved	538
*	Reserved	538
*	Reserved	538
*	Reserved	538
SVSALM	General SV subscription alarm	539
SVSTST	SV subscription unit in test mode	539
SVCC	Coupled clock mode indication	539
*	Reserved	539
*	Reserved	539
*	Reserved	539
*	Reserved	539
*	Reserved	539
SV and TiDL Subscription Mapping Bits		
IAXMAP	A-Phase, Terminal X is mapped in a subscription	540
IATMAP	A-Phase, Terminal T is mapped in a subscription	540
ICWMAP	C-Phase, Terminal W is mapped in a subscription	540
ICSMAP	C-Phase, Terminal S is mapped in a subscription	540
IBWMAP	B-Phase, Terminal W is mapped in a subscription	540
IBSMAP	B-Phase, Terminal S is mapped in a subscription	540
IAWMAP	A-Phase, Terminal W is mapped in a subscription	540
IASMAP	A-Phase, Terminal S is mapped in a subscription	540
IY2MAP	Channel 2, Terminal Y is mapped in a subscription	541
IBUMAP	B-Phase, Terminal U is mapped in a subscription	541
IY1MAP	Channel 1, Terminal Y is mapped in a subscription	541
IAUMAP	A-Phase, Terminal U is mapped in a subscription	541
ICXMAP	C-Phase, Terminal X is mapped in a subscription	541
ICTMAP	C-Phase, Terminal T is mapped in a subscription	541
IBXMAP	B-Phase, Terminal X is mapped in a subscription	541
IBTMAP	B-Phase, Terminal T is mapped in a subscription	541
VCZMAP	C-Phase, Terminal Z is mapped in a subscription	542
VCVMAP	C-Phase, Terminal V is mapped in a subscription	542
VBZMAP	B-Phase, Terminal Z is mapped in a subscription	542
VBVMAP	B-Phase, Terminal V is mapped in a subscription	542
VAZMAP	A-Phase, Terminal Z is mapped in a subscription	542

Table 11.2 Row List of Relay Word Bits (Sheet 25 of 42)

Name	Bit Description	Row
VAVMAP	A-Phase, Terminal V is mapped in a subscription	542
IY3MAP	Channel 3, Terminal Y is mapped in a subscription	542
ICUMAP	C-Phase, Terminal U is mapped in a subscription	542
IAYMAP	A-Phase, Terminal Y is mapped in a subscription	543
IBYMAP	B-Phase, Terminal Y is mapped in a subscription	543
ICYMAP	C-Phase, Terminal Y is mapped in a subscription	543
*	Reserved	543
*	Reserved	543
*	Reserved	543
*	Reserved	543
*	Reserved	543
SV Publish Bits		
*	Reserved	556
SVP07OK	SV publication 07 is enabled	556
SVP06OK	SV publication 06 is enabled	556
SVP05OK	SV publication 05 is enabled	556
SVP04OK	SV publication 04 is enabled	556
SVP03OK	SV publication 03 is enabled	556
SVP02OK	SV publication 02 is enabled	556
SVP01OK	SV publication 01 is enabled	556
*	Reserved	557–558
*	Reserved	559
SVPTST	SV publication unit in test mode	559
*	Reserved	559
SV and TiDL Subscription OK Bits		
IAXOK	A-Phase, Terminal X configured channel data OK	544
IATOK	A-Phase, Terminal T configured channel data OK	544
ICWOK	C-Phase, Terminal W configured channel data OK	544
ICSOK	C-Phase, Terminal S configured channel data OK	544
IBWOK	B-Phase, Terminal W configured channel data OK	544
IBSOK	B-Phase, Terminal S configured channel data OK	544
IAWOK	A-Phase, Terminal W configured channel data OK	544
IASOK	A-Phase, Terminal S configured channel data OK	544
IY2OK	Channel 2, Terminal Y configured channel data OK	545
IBUOK	B-Phase, Terminal U configured channel data OK	545
IY1OK	Channel 1, Terminal Y configured channel data OK	545
IAUOK	A-Phase, Terminal U configured channel data OK	545
ICXOK	C-Phase, Terminal X configured channel data OK	545
ICTOK	C-Phase, Terminal T configured channel data OK	545
IBXOK	B-Phase, Terminal X configured channel data OK	545
IBTOK	B-Phase, Terminal T configured channel data OK	545

Table 11.2 Row List of Relay Word Bits (Sheet 26 of 42)

Name	Bit Description	Row
VCZOK	C-Phase, Terminal Z configured channel data OK	546
VCVOK	C-Phase, Terminal V configured channel data OK	546
VBZOK	B-Phase, Terminal Z configured channel data OK	546
VBVOK	B-Phase, Terminal V configured channel data OK	546
VAZOK	A-Phase, Terminal Z configured channel data OK	546
VAVOK	A-Phase, Terminal V configured channel data OK	546
IY3OK	Channel 3, Terminal Y configured channel data OK	546
ICUOK	C-Phase, Terminal U configured channel data OK	546
IAYOK	A-Phase, Terminal Y configured channel data OK	547
IBYOK	B-Phase, Terminal Y configured channel data OK	547
ICYOK	C-Phase, Terminal Y configured channel data OK	547
*	Reserved	547
*	Reserved	547
*	Reserved	547
*	Reserved	547
*	Reserved	547
SV and TiDL Subscription Blocking Bits		
IAXBK	A-Phase, Terminal X is not OK (use for blocking)	548
IATBK	A-Phase, Terminal T is not OK (use for blocking)	548
ICWBK	C-Phase, Terminal W is not OK (use for blocking)	548
ICSBK	C-Phase, Terminal S is not OK (use for blocking)	548
IBWBK	B-Phase, Terminal W is not OK (use for blocking)	548
IBSBK	B-Phase, Terminal S is not OK (use for blocking)	548
IAWBK	A-Phase, Terminal W is not OK (use for blocking)	548
IASBK	A-Phase, Terminal S is not OK (use for blocking)	548
IY2BK	Channel 2, Terminal Y is not OK (use for blocking)	549
IBUBK	B-Phase, Terminal U is not OK (use for blocking)	549
IY1BK	Channel 1, Terminal Y is not OK (use for blocking)	549
IAUBK	A-Phase, Terminal U is not OK (use for blocking)	549
ICXBK	C-Phase, Terminal X is not OK (use for blocking)	549
ICTBK	C-Phase, Terminal T is not OK (use for blocking)	549
IBXBK	B-Phase, Terminal X is not OK (use for blocking)	549
IBTBK	B-Phase, Terminal T is not OK (use for blocking)	549
VCZBK	C-Phase, Terminal Z is not OK (use for blocking)	550
VCVBK	C-Phase, Terminal V is not OK (use for blocking)	550
VBZBK	B-Phase, Terminal Z is not OK (use for blocking)	550
VBVBK	B-Phase, Terminal V is not OK (use for blocking)	550
VAZBK	A-Phase, Terminal Z is not OK (use for blocking)	550
VAVBK	A-Phase, Terminal V is not OK (use for blocking)	550
IY3BK	Channel 3, Terminal Y is not OK (use for blocking)	550
ICUBK	C-Phase, Terminal U is not OK (use for blocking)	550

Table 11.2 Row List of Relay Word Bits (Sheet 27 of 42)

Name	Bit Description	Row
IAYBK	A-Phase, Terminal Y is not OK (use for blocking)	551
IBYBK	B-Phase, Terminal Y is not OK (use for blocking)	551
ICYBK	C-Phase, Terminal Y is not OK (use for blocking)	551
*	Reserved	551
*	Reserved	551
*	Reserved	551
*	Reserved	551
*	Reserved	551
SV and TiDL Terminal OK, Blocking, and Freeze Bits		
I*m*BK[a]	Current Terminal *m* data not OK (use for blocking)	552
VVBK	Voltage Terminal V data not OK (use for blocking)	552
VZBK	Voltage Terminal Z data not OK (use for blocking)	552
*	Reserved	552
I*m*OK[a]	Current Terminal *m* data OK	553
VVOK	Voltage Terminal V data OK	553
VZOK	Voltage Terminal Z data OK	553
*	Reserved	553
I*m*FZ[a]	Terminal *m* freeze bit for use in open phase logic and breaker failure logic	554
*	Reserved	554
*	Reserved	554
*	Reserved	554
SV and TiDL Application Freeze Bits and Blocking Bits		
*	Reserved	560
*	Reserved	560
*	Reserved	560
*	Reserved	560
*	Reserved	560
SVBLK	General Blocking Bit for SV Applications	560
SVBK_EX	Extended General Blocking Bit for SV Applications	560
*	Reserved	560
87BK	Zone 1 differential element blocking bit (because of loss of SV data)	561
87BK2	Zone 2 differential element blocking bit (because of loss of SV data)	561
REF*x*BK	Restricted Earth Fault Element (1–3) blocking bit (because of loss of SV data)	561
*	Reserved	561
*	Reserved	561
*	Reserved	561
IEC 61850 Control Mode Control Bits		
SC850TM	SELOGIC control for IEC 61850 Test Mode	564
SC850BM	SELOGIC control for IEC 61850 Block Mode	564
SC850SM	SELOGIC control for IEC 61850 Simulation Mode	564
*	Reserved	564

Table 11.2 Row List of Relay Word Bits (Sheet 28 of 42)

Name	Bit Description	Row
*	Reserved	564
*	Reserved	564
*	Reserved	564
*	Reserved	564
TiDL Mapped Output Contact Status		
OUT308S	Mapped OUT308 contact status	566
OUT307S	Mapped OUT307 contact status	566
OUT306S	Mapped OUT306 contact status	566
OUT305S	Mapped OUT305 contact status	566
OUT304S	Mapped OUT304 contact status	566
OUT303S	Mapped OUT303 contact status	566
OUT302S	Mapped OUT302 contact status	566
OUT301S	Mapped OUT301 contact status	566
OUT316S	Mapped OUT316 contact status	567
OUT315S	Mapped OUT315 contact status	567
OUT314S	Mapped OUT314 contact status	567
OUT313S	Mapped OUT313 contact status	567
OUT312S	Mapped OUT312 contact status	567
OUT311S	Mapped OUT311 contact status	567
OUT310S	Mapped OUT310 contact status	567
OUT309S	Mapped OUT309 contact status	567
OUT408S	Mapped OUT408 contact status	568
OUT407S	Mapped OUT407 contact status	568
OUT406S	Mapped OUT406 contact status	568
OUT405S	Mapped OUT405 contact status	568
OUT404S	Mapped OUT404 contact status	568
OUT403S	Mapped OUT403 contact status	568
OUT402S	Mapped OUT402 contact status	568
OUT401S	Mapped OUT401 contact status	568
OUT416S	Mapped OUT416 contact status	569
OUT415S	Mapped OUT415 contact status	569
OUT414S	Mapped OUT414 contact status	569
OUT413S	Mapped OUT413 contact status	569
OUT412S	Mapped OUT412 contact status	569
OUT411S	Mapped OUT411 contact status	569
OUT410S	Mapped OUT410 contact status	569
OUT409S	Mapped OUT409 contact status	569
OUT508S	Mapped OUT508 contact status	570
OUT507S	Mapped OUT507 contact status	570
OUT506S	Mapped OUT506 contact status	570
OUT505S	Mapped OUT505 contact status	570

Table 11.2 Row List of Relay Word Bits (Sheet 29 of 42)

Name	Bit Description	Row
OUT504S	Mapped OUT504 contact status	570
OUT503S	Mapped OUT503 contact status	570
OUT502S	Mapped OUT502 contact status	570
OUT501S	Mapped OUT501 contact status	570
OUT516S	Mapped OUT516 contact status	571
OUT515S	Mapped OUT515 contact status	571
OUT514S	Mapped OUT514 contact status	571
OUT513S	Mapped OUT513 contact status	571
OUT512S	Mapped OUT512 contact status	571
OUT511S	Mapped OUT511 contact status	571
OUT510S	Mapped OUT510 contact status	571
OUT509S	Mapped OUT509 contact status	571
Synchronism Check (Continued)		
59VP*m*[a]	Breaker *m* polarizing voltage within healthy voltage window	572
59VP	Polarizing voltage within healthy voltage window	572
ALTP*m*1[a]	Breaker *m* first alternative polarizing voltage source selected (SELOGIC control equation)	573
ALTP*m*2[a]	Breaker *m* second alternative polarizing voltage source selected (SELOGIC control equation)	573–574
25A1*m*[a]	Breaker *m* voltage within Sync Angle 1 window uncompensated	574–575
25A2*m*[a]	Breaker *m* voltage within Sync Angle 2 window uncompensated	575
25A1BK*m*[a]	Breaker *m* voltages within Synchronism Angle 1	576
25A2BK*m*[a]	Breaker *m* voltages within Synchronism Angle 2	577
25W1BK*m*[a]	Breaker *m* voltages within Synchronism Angle 1 window uncompensated and unsupervised	578
25W2BK*m*[a]	Breaker *m* voltages within Synchronism Angle 2 window uncompensated and unsupervised	579
TiDL Port Map Bits		
P6HMAP	**PORT 6H** mapped	580
P6GMAP	**PORT 6G** mapped	580
P6FMAP	**PORT 6F** mapped	580
P6EMAP	**PORT 6E** mapped	580
P6DMAP	**PORT 6D** mapped	580
P6CMAP	**PORT 6C** mapped	580
P6BMAP	**PORT 6B** mapped	580
P6AMAP	**PORT 6A** mapped	580
*	Reserved	581
*	Reserved	581
*	Reserved	581
*	Reserved	581
*	Reserved	581
*	Reserved	581
*	Reserved	581
*	Reserved	581
*	Reserved	582

Table 11.2 Row List of Relay Word Bits (Sheet 30 of 42)

Name	Bit Description	Row
*	Reserved	582
*	Reserved	582
*	Reserved	582
*	Reserved	582
*	Reserved	582
*	Reserved	582
*	Reserved	582
*	Reserved	583
*	Reserved	583
*	Reserved	583
*	Reserved	583
*	Reserved	583
*	Reserved	583
*	Reserved	583
*	Reserved	583
TiDL Port Status Bits		
P6HOK	PORT 6H OK	584
P6GOK	PORT 6G OK	584
P6FOK	PORT 6F OK	584
P6EOK	PORT 6E OK	584
P6DOK	PORT 6D OK	584
P6COK	PORT 6C OK	584
P6BOK	PORT 6B OK	584
P6AOK	PORT 6A OK	584
*	Reserved	585
*	Reserved	585
*	Reserved	585
*	Reserved	585
*	Reserved	585
*	Reserved	585
*	Reserved	585
*	Reserved	585
*	Reserved	586
*	Reserved	586
*	Reserved	586
*	Reserved	586
*	Reserved	586
*	Reserved	586
*	Reserved	586
*	Reserved	586
*	Reserved	587

Table 11.2 Row List of Relay Word Bits (Sheet 31 of 42)

Name	Bit Description	Row
*	Reserved	587
*	Reserved	587
*	Reserved	587
*	Reserved	587
*	Reserved	587
*	Reserved	587
*	Reserved	587
*	Reserved	588
*	Reserved	588
*	Reserved	588
*	Reserved	588
*	Reserved	588
*	Reserved	588
TDLCMSD	TiDL active topology commissioned	588
TIDLALM	TiDL alarm	588
*	Reserved	589
*	Reserved	589
*	Reserved	589
*	Reserved	589
*	Reserved	589
*	Reserved	589
*	Reserved	589
*	Reserved	589
*	Reserved	590
*	Reserved	590
*	Reserved	590
*	Reserved	590
*	Reserved	590
*	Reserved	590
*	Reserved	590
*	Reserved	590
*	Reserved	591
*	Reserved	591
*	Reserved	591
*	Reserved	591
*	Reserved	591
*	Reserved	591
*	Reserved	591
*	Reserved	591

Table 11.2 Row List of Relay Word Bits (Sheet 32 of 42)

Name	Bit Description	Row
IED Local Remote Bits		
LOC	Control authority at local (bay) level	592
SC850LS	SELOGIC control for control authority at station level	592
MLTLEV	Multi-level control authority	592
LOCSTA	Control authority at station level	592
*	Reserved	592
*	Reserved	592
*	Reserved	592
*	Reserved	592
Automation SELOGIC Conditioning Timers		
ACT*xx*Q	Automation SELOGIC Conditioning Timer (01–48) asserted	594–599
Local Control and Supervision Bits (Continued)		
LB*xx*	Local Bit (33–64) asserted	600–603
LB_SP*xx*	Local Bit (33–64) supervision enabled	604–607
LB_DP*xx*	Local Bit (33–64) status display enabled	608–611
Remote Bits (Continued)		
RB*xx*	Remote Bit (33–64) asserted	612–615
IEC 61850 Interlock		
89ENO*zz*[f]	Disconnect *zz* open control operation enabled	616–618
89ENC*zz*[f]	Disconnect *zz* close control operation enabled	620–622
Line 1 Ground Directional Elements		
L150QF	Negative-sequence current above forward threshold, Line 1	624
L150QR	Negative-sequence current above reverse threshold, Line 1	624
L132QE	Negative-sequence phase directional element enabled, Line 1	624
L132QGE	Negative-sequence ground directional element enabled, Line 1	624
L150GF	Zero-sequence current above forward threshold, Line 1	624
L150GR	Zero-sequence current above reverse threshold, Terminal Line 1	624
L132VE	Zero-sequence voltage directional element enabled, Line 1	624
L1F32QG	Forward negative-sequence ground directional element asserted, Line 1	624
L1R32QG	Reverse negative-sequence ground directional element asserted, Line 1	625
L1F32V	Forward zero-sequence ground directional element asserted, Line 1	625
L1R32V	Reverse zero-sequence ground directional element asserted, Line 1	625
L1F32G	Forward ground directional element asserted, Line 1	625
L1R32G	Reverse ground directional element asserted, Line 1	625
*		625
*		625
*		625
Line 1 Phase Directional Elements		
L1F32P	Forward phase directional element asserted, Line 1	626
L1R32P	Reverse phase directional element asserted, Line 1	626
L1F32Q	Forward negative-sequence phase directional element asserted, Line 1	626

Table 11.2 Row List of Relay Word Bits (Sheet 33 of 42)

Name	Bit Description	Row
L1R32Q	Reverse negative-sequence phase directional element asserted, Line 1	626
*		626
*		626
*		626
*		626
Line 1 Fault Identification		
FSA_L1	A-Phase sector fault (AG or BCG fault), Line 1	627
FSB_L1	B-Phase sector fault (BG or CAG fault), Line 1	627
FSC_L1	C-Phase sector fault (CG or ABG fault), Line 1	627
FIDENL1	FIDEN Logic enabled, Line 1	627
*		627
*		627
*		627
*		627
Miscellaneous Line 1 Elements		
VPOLL1	Polarizing voltage available, Line 1	628
ILOPL1	Internal loss-of-potential, Line 1	628
ZLOADL1	ZLOUT or ZLIN element picked up, Line 1	628
ZLINL1	Load-encroachment “load in” element, Line 1	628
ZLOUTL1	Load-encroachment “load out” element, Line 1	628
TRSOTF1	Switch-onto-fault TR equation asserted, Line 1	628
SOTFEL1	Switch-onto-fault enable, Line 1	628
SOTFTL1	Switch-onto-fault trip, Line 1	628
L1PO	Any pole open, Line 1	629
L13PO	Three poles open, Line 1	629
L1PO*p*[b]	*p*-Phase pole open, Line 1	629
L1OPH*p*[b]	*p*-Phase open, Line 1	629
I*p*2BKL1[b]	Second- or fourth-harmonic blocking asserted, *p*-Phase, Line 1	630
H2BKL1	Second- or fourth-harmonic blocking asserted, Line 1	630
I*p*5BKL1[b]	Fifth-harmonic blocking asserted, *p*-Phase, Line 1	630
H5BKL1	Fifth-harmonic blocking asserted, Line 1	630
CVTB1L1	Zone 1 CCVT transient blocking logic active, Line 1	631
*		631
*		631
*		631
RVRS1L1	Asserts when Group setting DIR1L1 = R	631
RVRS2L1	Asserts when Group setting DIR2L1 = R	631
RVRS3L1	Asserts when Group setting DIR3L1 = R	631
RVRS4L1	Asserts when Group setting DIR4L1 = R	631

Table 11.2 Row List of Relay Word Bits (Sheet 34 of 42)

Name	Bit Description	Row
Line 1 Mho Elements		
MAB1L1	Zone 1 mho A-B-Phase element, Line 1	632
MBC1L1	Zone 1 mho B-C-Phase element, Line 1	632
MCA1L1	Zone 1 mho C-A-Phase element, Line 1	632
Z1MPTC1	Zone 1 mho phase torque control, Line 1	632
M*p*G1L1[b]	Zone 1 mho *p*-Phase-to-ground element, Line 1	632
Z1MGTC1	Zone 1 mho ground torque control, Line 1	632
MAB2L1	Zone 2 mho A-B-Phase element, Line 1	633
MBC2L1	Zone 2 mho B-C-Phase element, Line 1	633
MCA2L1	Zone 2 mho C-A-Phase element, Line 1	633
Z2MPTC1	Zone 2 mho phase torque control, Line 1	633
M*p*G2L1[b]	Zone 2 mho *p*-Phase-to-ground element, Line 1	633
Z2MGTC1	Zone 2 mho ground torque control, Line 1	633
MAB3L1	Zone 3 mho A-B-Phase element, Line 1	634
MBC3L1	Zone 3 mho B-C-Phase element, Line 1	634
MCA3L1	Zone 3 mho C-A-Phase element, Line 1	634
Z3MPTC1	Zone 3 mho phase torque control, Line 1	634
M*p*G3L1[b]	Zone 3 mho *p*-Phase-to-ground element, Line 1	634
Z3MGTC1	Zone 3 mho ground torque control, Line 1	634
MAB4L1	Zone 4 mho A-B-Phase element, Line 1	635
MBC4L1	Zone 4 mho B-C-Phase element, Line 1	635
MCA4L1	Zone 4 mho C-A-Phase element, Line 1	635
Z4MPTC1	Zone 4 mho phase torque control, Line 1	635
M*p*G4L1[b]	Zone 4 mho *p*-Phase-to-ground element, Line 1	635
Z4MGTC1	Zone 4 mho ground torque control, Line 1	635
Line 1 Out-of-Step Elements		
OSB1L1	Block Zone 1 during an out-of-step condition, Line 1	636
OSB2L1	Block Zone 2 during an out-of-step condition, Line 1	636
OSB3L1	Block Zone 3 during an out-of-step condition, Line 1	636
OSB4L1	Block Zone 4 during an out-of-step condition, Line 1	636
OSBL1	Out-of-step block, Line 1	636
*		636
*		636
UBOSBL1	Unblock out-of-step blocking, Line 1	636
XIABCL1	Impedance inside inner OOS zone, Line 1	637
XOABCL1	Impedance inside outer OOS zone, Line 1	637
*		637
*		637
*		637
*		637
*		637

Table 11.2 Row List of Relay Word Bits (Sheet 35 of 42)

Name	Bit Description	Row
*		637
67QF1L1	Zone 1 forward OSB negative-sequence supervision, Line 1	638
67QR1L1	Zone 1 reverse OSB negative-sequence supervision, Line 1	638
67QF2L1	Zone 2 forward OSB negative-sequence supervision, Line 1	638
67QR2L1	Zone 2 reverse OSB negative-sequence supervision, Line 1	638
67QF3L1	Zone 3 forward OSB negative-sequence supervision, Line 1	638
67QR3L1	Zone 3 reverse OSB negative-sequence supervision, Line 1	638
67QF4L1	Zone 4 forward OSB negative-sequence supervision, Line 1	638
67QR4L1	Zone 4 reverse OSB negative-sequence supervision, Line 1	638
Line 1 Quad Elements		
XAB1L1	Zone 1 quad A-B-Phase element, Line 1	639
XBC1L1	Zone 1 quad B-C-Phase element, Line 1	639
XCA1L1	Zone 1 quad C-A-Phase element, Line 1	639
Z1XPTC1	Zone 1 quad phase torque control, Line 1	639
X*p*G1L1[b]	Zone 1 quad *p*-Phase-to-ground element, Line 1	639
Z1XGTC1	Zone 1 quad ground torque control, Line 1	639
XAB2L1	Zone 2 quad A-B-Phase element, Line 1	640
XBC2L1	Zone 2 quad B-C-Phase element, Line 1	640
XCA2L1	Zone 2 quad C-A-Phase element, Line 1	640
Z2XPTC1	Zone 2 quad phase torque control, Line 1	640
X*p*G2L1[b]	Zone 2 quad *p*-Phase-to-ground element, Line 1	640
Z2XGTC1	Zone 2 quad ground torque control, Line 1	640
XAB3L1	Zone 3 quad A-B-Phase element, Line 1	641
XBC3L1	Zone 3 quad B-C-Phase element, Line 1	641
XCA3L1	Zone 3 quad C-A-Phase element, Line 1	641
Z3XPTC1	Zone 3 quad phase torque control, Line 1	641
X*p*G3L1[b]	Zone 3 quad *p*-Phase-to-ground element, Line 1	641
Z3XGTC1	Zone 3 quad ground torque control, Line 1	641
XAB4L1	Zone 4 quad A-B-Phase element, Line 1	642
XBC4L1	Zone 4 quad B-C-Phase element, Line 1	642
XCA4L1	Zone 4 quad C-A-Phase element, Line 1	642
Z4XPTC1	Zone 4 quad phase torque control, Line 1	642
X*p*G4L1[b]	Zone 4 quad *p*-Phase-to-ground element, Line 1	642
Z4XGTC1	Zone 4 quad ground torque control, Line 1	642
RAB1L1	Zone 1 quad A-B-Phase resistance element, Line 1	643
RBC1L1	Zone 1 quad B-C-Phase resistance element, Line 1	643
RCA1L1	Zone 1 quad C-A-Phase resistance element, Line 1	643
R*p*G1L1[b]	Zone 1 quad *p*-Phase-to-ground resistance element, Line 1	643
*		643
*		643
RAB2L1	Zone 2 quad A-B-Phase resistance element, Line 1	644

Table 11.2 Row List of Relay Word Bits (Sheet 36 of 42)

Name	Bit Description	Row
RBC2L1	Zone 2 quad B-C-Phase resistance element, Line 1	644
RCA2L1	Zone 2 quad C-A-Phase resistance element, Line 1	644
R*p*G2L1[b]	Zone 2 quad *p*-Phase-to-ground resistance element, Line 1	644
*		644
*		644
RAB3L1	Zone 3 quad A-B-Phase resistance element, Line 1	645
RBC3L1	Zone 3 quad B-C-Phase resistance element, Line 1	645
RCA3L1	Zone 3 quad C-A-Phase resistance element, Line 1	645
R*p*G3L1[b]	Zone 3 quad *p*-Phase-to-ground resistance element, Line 1	645
*		645
*		645
RAB4L1	Zone 4 quad A-B-Phase resistance element, Line 1	646
RBC4L1	Zone 4 quad B-C-Phase resistance element, Line 1	646
RCA4L1	Zone 4 quad C-A-Phase resistance element, Line 1	646
R*p*G4L1[b]	Zone 4 quad *p*-Phase-to-ground resistance element, Line 1	646
*		646
*		646
ENX2AB1	Enable AB reactance element, Line 1	647
ENX2BC1	Enable BC reactance element, Line 1	647
ENX2CA1	Enable CA reactance element, Line 1	647
ENX2AG1	Enable AG reactance element, Line 1	647
ENX2BG1	Enable BG reactance element, Line 1	647
ENX2CG1	Enable CG reactance element, Line 1	647
*		647
*		647
Line 1 Zone Elements		
M1PL1	Zone 1 mho phase element, Line 1	648
M1GL1	Zone 1 mho ground element, Line 1	648
X1PL1	Zone 1 quad phase element, Line 1	648
X1GL1	Zone 1 quad ground element, Line 1	648
M2PL1	Zone 2 mho phase element, Line 1	648
M2GL1	Zone 2 mho ground element, Line 1	648
X2PL1	Zone 2 quad phase element, Line 1	648
X2GL1	Zone 2 quad ground element, Line 1	648
M3PL1	Zone 3 mho phase element, Line 1	649
M3GL1	Zone 3 mho ground element, Line 1	649
X3PL1	Zone 3 quad phase element, Line 1	649
X3GL1	Zone 3 quad ground element, Line 1	649
M4PL1	Zone 4 mho phase element, Line 1	649
M4GL1	Zone 4 mho ground element, Line 1	649
X4PL1	Zone 4 quad phase element, Line 1	649

Table 11.2 Row List of Relay Word Bits (Sheet 37 of 42)

Name	Bit Description	Row
X4GL1	Zone 4 quad ground element, Line 1	649
Z1PL1	Zone 1 phase element, Line 1	650
Z1GL1	Zone 1 ground element, Line 1	650
Z2PL1	Zone 2 phase element, Line 1	650
Z2GL1	Zone 2 ground element, Line 1	650
Z3PL1	Zone 3 phase element, Line 1	650
Z3GL1	Zone 3 ground element, Line 1	650
Z4PL1	Zone 4 phase element, Line 1	650
Z4GL1	Zone 4 ground element, Line 1	650
Z1TL1	Zone 1 phase or ground distance, time delayed, Line 1	651
Z2TL1	Zone 2 phase or ground distance, time delayed, Line 1	651
Z3TL1	Zone 3 phase or ground distance, time delayed, Line 1	651
Z4TL1	Zone 4 phase or ground distance, time delayed, Line 1	651
Z1L1	Zone 1 phase or ground distance, Line 1	651
Z2L1	Zone 2 phase or ground distance, Line 1	651
Z3L1	Zone 3 phase or ground distance, Line 1	651
Z4L1	Zone 4 phase or ground distance, Line 1	651
Parallel Redundancy Protocol Supervision		
PRPAGOK	PRP **PORT 5A** GOOSE status	652
PRPBGOK	PRP **PORT 5B** GOOSE status	652
PRPCGOK	PRP **PORT 5C** GOOSE status	652
PRPDGOK	PRP **PORT 5D** GOOSE status	652
PRPASOK	PRP **PORT 5A** SV status	652
PRPBSOK	PRP **PORT 5B** SV status	652
High-Availability Seamless Redundancy (HSR) Supervision		
HSRAOK	HSR Port 5A status	654
HSRBOK	HSR Port 5B status	654
HSRCOK	HSR Port 5C status	654
HSRDOK	HSR Port 5D status	654
89 Disconnect Switch Timers and Breaker Status (Continued)		
89CIM*zz*[f]	Disconnect *zz* close immobility timer timed out	656–658
89OIM*zz*[f]	Disconnect *zz* open immobility timer timed out	660–662
89OSI*zz*[f]	Disconnect *zz* open seal-in timer timed out	664–666
89CBL*zz*[f]	Disconnect *zz* close block	668–670
89CIR*zz*[f]	Disconnect *zz* close immobility timer reset	672–674
89OIR*zz*[f]	Disconnect *zz* open immobility timer reset	676–678
89CSI*zz*[f]	Disconnect *zz* close seal-in timer timed out	680–682
IEC 61850 Interlock (Continued)		
BKENC*m*[a]	IEC 61850 Breaker *m* close control operation enabled	684–685
BKENO*m*[a]	IEC 61850 Breaker *m* close control operation enabled	684–685

Table 11.2 Row List of Relay Word Bits (Sheet 38 of 42)

Name	Bit Description	Row
SCBK*m*BC[a]	SELOGIC control for IEC 61850 close block equation for Circuit Breaker *m*	685–686
SCBK*m*BO[a]	SELOGIC control for IEC 61850 open block equation for Circuit Breaker *m*	685–686
Definite and Directional Overcurrent Elements (Continued)		
50YP1	Phase Definite-Time Element 1, Terminal Y asserted	687
50YP2	Phase Definite-Time Element 2, Terminal Y asserted	687
67YP1	Phase Directional/Torque-Controlled Element 1, Terminal Y picked up	687
67YP1T	Phase Directional/Torque-Controlled Element 1, Terminal Y timed out	687
67YP1TC	Phase Directional/Torque-Control Enable Definite-Time Element 1, Terminal Y	687
67YP2	Phase Directional/Torque-Controlled Element 2, Terminal Y picked up	687
67YP2T	Phase Directional/Torque-Controlled Element 2, Terminal Y timed out	687
67YP2TC	Phase Directional/Torque-Control Enable Definite-Time Element 2, Terminal Y	687
50YP3	Phase Definite-Time Element 3, Terminal Y asserted	688
67YP3	Phase Directional/Torque-Controlled Element 3, Terminal Y picked up	688
67YP3T	Phase Directional/Torque-Controlled Element 3, Terminal Y timed out	688
67YP3TC	Phase Directional/Torque-Control Enable Definite-Time Element 3, Terminal Y	688
50YQ1	Negative-Sequence Definite-Time Element 1, Terminal Y asserted	689
50YQ2	Negative-Sequence Definite-Time Element 2, Terminal Y asserted	689
67YQ1	Negative-Sequence Directional/Torque-Controlled Element 1, Terminal Y picked up	689
67YQ1T	Negative-Sequence Directional/Torque-Controlled Element 1, Terminal Y timed out	689
67YQ1TC	Negative-Sequence Directional/Torque-Control Enable Definite-Time Element 1, Terminal Y	689
67YQ2	Negative-Sequence Directional/Torque-Controlled Element 2, Terminal Y picked up	689
67YQ2T	Negative-Sequence Directional/Torque-Controlled Element 2, Terminal Y timed out	689
67YQ2TC	Negative-Sequence Directional/Torque-Control Enable Definite-Time Element 2, Terminal Y	689
50YQ3	Negative-Sequence Definite-Time Element 3, Terminal Y asserted	690
67YQ3	Negative-Sequence Directional/Torque-Controlled Element 3, Terminal Y picked up	690
67YQ3T	Negative-Sequence Directional/Torque-Controlled Element 3, Terminal Y timed out	690
67YQ3TC	Negative-Sequence Directional/Torque-Control Enable Definite-Time Element 3, Terminal Y	690
50YG1	Residual Definite-time Element 1, Terminal Y asserted	691
50YG2	Residual Definite-Time Element 2, Terminal Y asserted	691
67YG1	Residual Directional/Torque-Controlled Element 1, Terminal Y picked up	691
67YG1T	Residual Directional/Torque-Controlled Element 1, Terminal Y timed out	691
67YG1TC	Residual Directional/Torque-Control Enable Definite-Time Element 1, Terminal Y	691
67YG2	Residual Directional/Torque-Controlled Element 2, Terminal Y picked up	691
67YG2T	Residual Directional/Torque-Controlled Element 2, Terminal Y timed out	691
67YG2TC	Residual Directional/Torque-Control Enable Definite-Time Element 2, Terminal Y	691
50YG3	Residual Definite-Time Element 3, Terminal Y asserted	692
67YG3	Residual Directional/Torque-Controlled Element 3, Terminal Y picked up	692
67YG3T	Residual Directional/Torque-Controlled Element 3, Terminal Y timed out	692
67YG3TC	Residual Directional/Torque-Control Enable Definite-Time Element 3, Terminal Y	692

Table 11.2 Row List of Relay Word Bits (Sheet 39 of 42)

Name	Bit Description	Row
Ground Directional Elements (Continued)		
Y32QE	Negative-sequence phase directional element enabled, Terminal Y	693
Y32QGE	Negative-sequence ground directional element enabled, Terminal Y	693
Y32VE	Zero-sequence voltage directional element enabled, Terminal Y	693
Y50GF	Zero-sequence current above forward threshold, Terminal Y	693
Y50GR	Zero-sequence current above reverse threshold, Terminal Y	693
Y50QF	Negative-sequence current above forward threshold, Terminal Y	693
Y50QR	Negative-sequence current above reverse threshold, Terminal Y	693
YF32QG	Forward negative-sequence ground directional element asserted, Terminal Y	693
YF32G	Forward ground directional element asserted, Terminal Y	694
YF32V	Forward zero-sequence ground directional element asserted, Terminal Y	694
YR32G	Reverse ground directional element asserted, Terminal Y	694
YR32QG	Reverse negative-sequence phase directional element asserted, Terminal Y	694
YR32V	Reverse zero-sequence ground directional element asserted, Terminal Y	694
Phase Directional Elements (Continued)		
YF32P	Forward phase directional element asserted, Terminal Y	695
YF32Q	Forward negative-sequence phase directional element asserted, Terminal Y	695
YR32P	Reverse phase directional element asserted, Terminal Y	695
YR32Q	Reverse negative-sequence phase directional element asserted, Terminal Y	695
DIRBLKY	Block phase and ground directional Element Y	695
Inverse-Time Overcurrent Elements (Continued)		
51MM*xx*	Inverse-Time Element (11–20) pickup setting outside of specified limits	696–705
51R*xx*	Inverse-Time Element (11–20) reset	696–705
51S*xx*	Inverse-Time Element (11–20) picked up	696–705
51T*xx*	Inverse-Time Element (11–20) timed out	696–705
51TC*xx*	Inverse-Time Element (11–20) enabled	696–705
51TM*xx*	Inverse-Time Element (11–20) time-dial setting outside of specified limits	696–705
Zone 2 Phase-Differential Elements		
GFLT*p*2[b]	Zone 2 instantaneous fault detector asserted, *p*-Phase	707
WFLT*p*2[b]	Zone 2 windowed fault detector asserted, *p*-Phase	707
E87T*m*2[a]	Zone 2 terminal *m* currents included in differential zone	708
IFLT*p*2[b]	Zone 2 internal fault detected, *p*-Phase	709
CON*p*2[b]	Zone 2 external fault detected, *p*-Phase	709
CON2	Zone 2 external fault detected	709
P87*p*2[b]	Zone 2 phase percentage-restrained differential element asserted (no security timer), *p*-Phase	710
87R2	Zone 2 phase percentage-restrained differential element operated	710
EFDT*p*2[b]	Zone 2 EFD extension timer output, *p*-Phase	711
Local Control and Supervision Bits (Continued)		
LB*xx*	Local Bit (65–96) asserted	712–715
LB_SP*xx*	Local Bit (65–96) supervision enabled	716–719
LB_DP*xx*	Local Bit (65–96) status display enabled	720–723

Table 11.2 Row List of Relay Word Bits (Sheet 40 of 42)

Name	Bit Description	Row
Breaker Monitor (Continued)		
EBYMON	Breaker monitoring Terminal Y enabled	724
BYBCWAL	Breaker contact wear alarm, Breaker Y	724
BYESOAL	Slow electrical operate alarm, Breaker Y	724
BYBITAL	Inactivity time alarm, Breaker Y	724
BYKAIAL	Interrupted rms current alarm, Breaker Y	724
BYMSOAL	Mechanical slow operation alarm, Breaker Y	724
BYMRTAL	Motor run time alarm, Breaker Y	724
Reclosing Elements		
79STRT*m*[a]	Breaker *m* in reclose start state	725, 728, 731, 734, 737, 740
79RS*m*[a]	Breaker *m* in reclose ready state	725, 728, 731, 734, 737, 740
79CY*m*[a]	Breaker *m* in reclose cycle state	725, 728, 731, 734, 737, 740
79LO*m*[a]	Breaker *m* in reclose lockout state	725, 728, 731, 734, 737, 740
79RI*m*[a]	Breaker *m* reclose initiation (SELOGIC control equation)	725, 728, 731, 734, 737, 740
79ARC*m*[a]	Breaker *m* reclose initiate qualified	725, 728, 731, 734, 737, 740
3POBK*m*[a]	Breaker *m* three-pole open	725, 728, 731, 734, 737, 740
79LSHT*m*[a]	Breaker *m* reclose last shot	725, 728, 731, 734, 737, 740
79SH0*m*[a]	Breaker *m* shot counter = 0	726, 729, 732, 735, 738, 741
79SH1*m*[a]	Breaker *m* shot counter = 1	726, 729, 732, 735, 738, 741
79SH2*m*[a]	Breaker *m* shot counter = 2	726, 729, 732, 735, 738, 741
79SH3*m*[a]	Breaker *m* shot counter = 3	726, 729, 732, 735, 738, 741
79SH4*m*[a]	Breaker *m* shot counter = 4	726, 729, 732, 735, 738, 741
79OI*m*[a]	Breaker *m* open interval timing	726, 729, 732, 735, 738, 741
79CLSS*m*[a]	Breaker *m* in close supervision state	727, 730, 733, 736, 739, 742
79CLST*m*[a]	Breaker *m* close supervision delay timed out	727, 730, 733, 736, 739, 742
79CLS*m*[a]	Breaker *m* close supervision (SELOGIC control equation)	727, 730, 733, 736, 739, 742
79RCP*m*[a]	Breaker *m* reclaim in progress (cycle state)	727, 730, 733, 736, 739, 742
79RCLP*m*[a]	Breaker *m* reclaim in progress (lockout state)	727, 730, 733, 736, 739, 742

Table 11.2 Row List of Relay Word Bits (Sheet 41 of 42)

Name	Bit Description	Row
79CFT*m*[a]	Breaker *m* close failure delay timed out	727, 730, 733, 736, 739, 742
79CL*m*[a]	Breaker *m* supervised close command	743
Breaker Failure Elements (Continued)		
50FY	Phase or neutral current above pickup, Terminal Y	744
ATBFIY	Alternative breaker failure initiated, Terminal Y	744
ATBFTY	Alternative breaker failure timer timed out, Terminal Y	744
BFIY	Breaker failure initiated, Terminal Y	744
BFITY	Breaker failure timer timed out, Terminal Y	744
EBFITY	Externally initiated breaker failure timer timed out, Terminal Y	744
EXBFY	External breaker failure input initiated, Terminal Y	744
RTY	Retrip timer timed out/retrip command issued, Terminal Y	744
ABFITY	Alternative breaker failure, Terminal Y	745
BFISPTY	Breaker failure seal-in timer timed out, Terminal Y	745
ENINBFY	Neutral/residual breaker failure function enabled, Terminal Y	745
FBFY	Breaker failure asserted/initiated, Terminal Y	745
I*p*YBF[b]	*p*-Phase current above threshold, Terminal Y	745
INYBF	Neutral current above threshold, Terminal Y	745
EXBFSPS	External breaker failure supervisor, Terminal S	746
EXBFSPT	External breaker failure supervisor, Terminal T	746
EXBFSPU	External breaker failure supervisor, Terminal U	746
EXBFSPW	External breaker failure supervisor, Terminal W	746
EXBFSPX	External breaker failure supervisor, Terminal X	746
EXBFSPY	External breaker failure supervisor, Terminal Y	746
Terminal Harmonic Blocking Elements		
IAS2BK	Second-harmonic blocking asserted, A-Phase, Terminal S	747
IBS2BK	Second-harmonic blocking asserted, B-Phase, Terminal S	747
ICS2BK	Second-harmonic blocking asserted, C-Phase, Terminal S	747
H2BKS	Second-harmonic blocking asserted, Terminal S	747
IAT2BK	Second-harmonic blocking asserted, A-Phase, Terminal T	747
IBT2BK	Second-harmonic blocking asserted, B-Phase, Terminal T	747
ICT2BK	Second-harmonic blocking asserted, C-Phase, Terminal T	747
H2BKT	Second-harmonic blocking asserted, Terminal T	747
IAU2BK	Second-harmonic blocking asserted, A-Phase, Terminal U	748
IBU2BK	Second-harmonic blocking asserted, B-Phase, Terminal U	748
ICU2BK	Second-harmonic blocking asserted, C-Phase, Terminal U	748
H2BKU	Second-harmonic blocking asserted, Terminal U	748
IAW2BK	Second-harmonic blocking asserted, A-Phase, Terminal W	748
IBW2BK	Second-harmonic blocking asserted, B-Phase, Terminal W	748
ICW2BK	Second-harmonic blocking asserted, C-Phase, Terminal W	748
H2BKW	Second-harmonic blocking asserted, Terminal W	748

Table 11.2 Row List of Relay Word Bits (Sheet 42 of 42)

Name	Bit Description	Row
IAX2BK	Second-harmonic blocking asserted, A-Phase, Terminal X	749
IBX2BK	Second-harmonic blocking asserted, B-Phase, Terminal X	749
ICX2BK	Second-harmonic blocking asserted, C-Phase, Terminal X	749
H2BKX	Second-harmonic blocking asserted, Terminal X	749
IAY2BK	Second-harmonic blocking asserted, A-Phase, Terminal Y	749
IBY2BK	Second-harmonic blocking asserted, B-Phase, Terminal Y	749
ICY2BK	Second-harmonic blocking asserted, C-Phase, Terminal Y	749
H2BKY	Second-harmonic blocking asserted, Terminal Y	749
IA12BK	Second-harmonic blocking asserted, A-Phase, Terminal ST	750
IB12BK	Second-harmonic blocking asserted, B-Phase, Terminal ST	750
IC12BK	Second-harmonic blocking asserted, C-Phase, Terminal ST	750
H2BK1	Second-harmonic blocking asserted, Terminal ST	750
IA22BK	Second-harmonic blocking asserted, A-Phase, Terminal TU	750
IB22BK	Second-harmonic blocking asserted, B-Phase, Terminal TU	750
IC22BK	Second-harmonic blocking asserted, C-Phase, Terminal TU	750
H2BK2	Second-harmonic blocking asserted, Terminal TU	750
IA32BK	Second-harmonic blocking asserted, A-Phase, Terminal UW	751
IB32BK	Second-harmonic blocking asserted, B-Phase, Terminal UW	751
IC32BK	Second-harmonic blocking asserted, C-Phase, Terminal UW	751
H2BK3	Second-harmonic blocking asserted, Terminal UW	751
IA42BK	Second-harmonic blocking asserted, A-Phase, Terminal WX	751
IB42BK	Second-harmonic blocking asserted, B-Phase, Terminal WX	751
IC42BK	Second-harmonic blocking asserted, C-Phase, Terminal WX	751
H2BK4	Second-harmonic blocking asserted, Terminal WX	751
Remote Bits (Continued)		
RB*xx*	Remote Bit (65–96) asserted	752–755
Protection SELOGIC Variables (Continued)		
PSV*xx*	Protection SELOGIC Variable (65–96) asserted	756–759
Automation SELOGIC Sequencing Timers (Continued)		
AST*xx*Q	Automation SELOGIC Sequencing Timer (33–48) asserted	760–761
AST*xx*R	Automation SELOGIC Sequencing Timer (33–48) reset	762–763
Automation SELOGIC Latches (Continued)		
ALT*xx*	Automation SELOGIC Latch (65–80) asserted	764–765

[a] m = S, T, U, W, X, Y.
[b] p = A, B, C.
[c] m = S, T, U, W, X.
[d] k = V, Z.
[e] qp = ST, TU, UW, WX.
[f] zz = 01–20.

SECTION 12

Analog Quantities

This section contains tables of the analog quantities available within the SEL-487E-5 Relay.

Use *Table 12.1* and *Table 12.2* as a reference for labels in this manual and as a resource for quantities you use in SELOGIC control equation relay settings. *Table 12.1* lists the analog quantities alphabetically, and *Table 12.2* groups the analog quantities by function.

Table 12.1 Analog Quantities Sorted Alphabetically (Sheet 1 of 11)

Label	Description	Units
24RPU	Volts/hertz ratio	%
25ANG*m*[a]	25 Synchronism-check angle difference for Breaker *m*	° (±180°)
25ANGC*m*[a]	25 Synchronism-check compensated angle difference for Breaker *m*	° (±180°)
25SLIP*m*[a]	25 Synchronism-check slip frequency for Breaker *m*	Hz
25VP*m*FA[a]	25 Synchronism-check polarizing voltage angle for Breaker *m*	V (secondary)
25VP*m*FM[a]	25 Synchronism-check polarizing voltage magnitude for Breaker *m*	V (secondary)
25VPFA	25 Synchronism-check polarizing voltage angle	° (±180°)
25VPFM	25 Synchronism-check polarizing voltage magnitude	V (secondary)
25VS*m*FA[a]	25 Synchronism-check synchronizing voltage angle for Breaker *m*	° (±180°)
25VS*m*FM[a]	25 Synchronism-check synchronizing voltage magnitude for Breaker *m*	V (secondary)
3DPF*m*[a]	Three-phase displacement power factor, Terminal *m*	
3DPF*qp*[b]	Three-phase displacement power factor, comb. Terminals *qp*	
3I0*m*A[a]	Instantaneous zero-sequence current angle, Terminal *m*	° (±180°)
3I0*m*AC[a]	1-cycle average zero-sequence current angle, Terminal *m*	° (±180°)
3I0*m*I[a]	Instantaneous zero-sequence current, imaginary component, Terminal *m*	A (secondary)
3I0*m*M[a]	Instantaneous zero-sequence current magnitude, Terminal *m*	A (secondary)
3I0*m*MC[a]	1-cycle average zero-sequence current magnitude, Terminal *m*	A (primary)
3I0*m*MS[a]	60-cycle average zero-sequence current magnitude, Terminal *m*	A (secondary)
3I0*m*R[a]	Instantaneous zero-sequence current, real component, Terminal *m*	A (secondary)
3I0*qp*A[b]	Instantaneous zero-sequence current angle, comb. Terminals *qp*	° (±180°)
3I0*qp*AC[b]	1-cycle average zero-sequence current angle, comb. Terminals *qp*	° (±180°)
3I0*qp*I[b]	Instantaneous zero-sequence current, imaginary component, comb. Terminals *qp*	A (secondary)
3I0*qp*M[b]	Instantaneous zero-sequence current magnitude, comb. Terminals *qp*	A (secondary)
3I0*qp*MC[b]	1-cycle average zero-sequence current magnitude, comb. Terminals *qp*	A (primary)
3I0*qp*MS[b]	60-cycle average zero-sequence current magnitude, comb. Terminals *qp*	A (secondary)
3I0*qp*R[b]	Instantaneous zero-sequence current, real component, comb. Terminals *qp*	A (secondary)
3I0L1A	Instantaneous zero-sequence current angle, Line 1	° (±180°)
3I0L1M	Instantaneous zero-sequence current magnitude, Line 1	A (secondary)

Table 12.1 Analog Quantities Sorted Alphabetically (Sheet 2 of 11)

Label	Description	Units
3I2*m*A[a]	Instantaneous negative-sequence current angle, Terminal *m*	° (±180°)
3I2*m*AC[a]	1-cycle average negative-sequence current angle, Terminal *m*	° (±180°)
3I2*m*I[a]	Instantaneous negative-sequence current, imaginary component, Terminal *m*	A (secondary)
3I2*m*M[a]	Instantaneous negative-sequence current magnitude, Terminal *m*	A (secondary)
3I2*m*MC[a]	1-cycle average negative-sequence current magnitude, Terminal *m*	A (primary)
3I2*m*MS[a]	60-cycle average negative-sequence current magnitude, Terminal *m*	A (secondary)
3I2*m*R[a]	Instantaneous negative-sequence current, real component, Terminal *m*	A (secondary)
3I2*qp*A[b]	Instantaneous negative-sequence current angle, comb. Terminals *qp*	° (±180°)
3I2*qp*AC[b]	1-cycle average negative-sequence current angle, comb. Terminals *qp*	° (±180°)
3I2*qp*I[b]	Instantaneous negative-sequence current, imaginary component, comb. Terminals *qp*	A (secondary)
3I2*qp*M[b]	Instantaneous negative-sequence current magnitude, comb. Terminals *qp*	A (secondary)
3I2*qp*MC[b]	1-cycle average negative-sequence current magnitude, comb. Terminals *qp*	A (primary)
3I2*qp*MS[b]	60-cycle average negative-sequence current magnitude, comb. Terminals *qp*	A (secondary)
3I2*qp*R[b]	Instantaneous negative-sequence current, real component, comb. Terminals *qp*	A (secondary)
3I2L1A	Instantaneous negative-sequence current angle, Line 1	° (±180°)
3I2L1M	Instantaneous negative-sequence current magnitude, Line 1	A (secondary)
3P*m*F[a]	Instantaneous three-phase fundamental active power, Terminal *m*	W (secondary)
3P*m*FC[a]	1-cycle average three-phase fundamental active power, Terminal *m*	MW (primary)
3P*m*MWhn[a]	Three-phase active energy imported, Terminal *m*	MWh (primary)
3P*m*MWhp[a]	Three-phase active energy exported, Terminal *m*	MWh (primary)
3P*m*MWhT[a]	Total three-phase active energy, Terminal *m*	MWh (primary)
3P*qp*F[b]	Instantaneous three-phase fundamental active power, comb. Terminals *qp*	W (secondary)
3P*qp*FC[b]	1-cycle average three-phase fundamental active power, comb. Terminals *qp*	MW (primary)
3P*qp*WHN[b]	Three-phase active energy imported, comb. Terminals *qp*	MWh (primary)
3P*qp*WHP[b]	Three-phase active energy exported, comb. Terminals *qp*	MWh (primary)
3P*qp*WHT[b]	Total three-phase active energy, comb. Terminals *qp*	MWh (primary)
3Q*m*F[a]	Instantaneous three-phase fundamental reactive power, Terminal *m*	VAR (secondary)
3Q*m*FC[a]	1-cycle average three-phase fundamental reactive power, Terminal *m*	MVAR (primary)
3Q*m*MVHN[a]	Three-phase reactive energy imported, Terminal *m*	MVARh (primary)
3Q*m*MVHP[a]	Three-phase reactive energy exported, Terminal *m*	MVARh (primary)
3Q*m*MVHT[a]	Total three-phase reactive energy, Terminal *m*	MVARh (primary)
3Q*qp*F[b]	Instantaneous three-phase fundamental reactive power, comb. Terminals *qp*	VAR (secondary)
3Q*qp*FC[b]	1-cycle average three-phase fundamental reactive power, comb. Terminals *qp*	MVAR (primary)
3Q*qp*VHN[b]	Three-phase reactive energy imported, comb. Terminals *qp*	MVARh (primary)
3Q*qp*VHP[b]	Three-phase reactive energy exported, comb. Terminals *qp*	MVARh (primary)
3Q*qp*VHT[b]	Total three-phase reactive energy, comb. Terminals *qp*	MVARh (primary)
3S*m*F[a]	Instantaneous three-phase fundamental apparent power, Terminal *m*	VA (secondary)
3S*m*FC[a]	1-cycle average three-phase fundamental apparent power, Terminal *m*	MVA (primary)
3S*qp*F[b]	Instantaneous three-phase fundamental apparent power, comb. Terminals *qp*	VA (secondary)
3S*qp*FC[b]	1-cycle average three-phase fundamental apparent power, comb. Terminals *qp*	MVA (primary)
3V0*k*A[c]	Instantaneous zero-sequence voltage angle, Terminal *k*	° (±180°)

Table 12.1 Analog Quantities Sorted Alphabetically (Sheet 3 of 11)

Label	Description	Units
3V0*k*AC[c]	1-cycle average zero-sequence voltage angle, Terminal *k*	° (±180°)
3V0*k*I[c]	Instantaneous zero-sequence voltage, imaginary component, Terminal *k*	V (secondary)
3V0*k*M[c]	Instantaneous zero-sequence voltage magnitude, Terminal *k*	V (secondary)
3V0*k*MC[c]	1-cycle average zero-sequence voltage magnitude, Terminal *k*	kV (primary)
3V0*k*R[c]	Instantaneous zero-sequence voltage, real component, Terminal *k*	V (secondary)
3V0L1A	Instantaneous zero-sequence voltage angle, Line 1	° (±180°)
3V0L1M	Instantaneous zero-sequence voltage magnitude, Line 1	V (secondary)
3V2*k*A[c]	Instantaneous negative-sequence voltage angle, Terminal *k*	° (±180°)
3V2*k*AC[c]	1-cycle average negative-sequence voltage angle, Terminal *k*	° (±180°)
3V2*k*I[c]	Instantaneous negative-sequence voltage, imaginary component, Terminal *k*	V (secondary)
3V2*k*M[c]	Instantaneous negative-sequence voltage magnitude, Terminal *k*	V (secondary)
3V2*k*MC[c]	1-cycle average negative-sequence voltage magnitude, Terminal *k*	kV (primary)
3V2*k*R[c]	Instantaneous negative-sequence voltage, real component, Terminal *k*	V (secondary)
3V2L1A	Instantaneous negative-sequence voltage angle, Line 1	° (±180°)
3V2L1M	Instantaneous negative-sequence voltage magnitude, Line 1	V (secondary)
46*pm*[a, d]	Current unbalance Phase *p*, Terminal *m*	%
51P01–51P20	51 Element 1–20 pickup value	A (secondary)
51TD01–51TD20	51 Element 1–20 time-dial setting	
79SH*m*[a]	Present value of shot counter for Breaker *m*	
79SH*m*_1[a]	Total number of first shot reclosers for Breaker *m*	
79SH*m*_2[a]	Total number of second shot reclosers for Breaker *m*	
79SH*m*_3[a]	Total number of third shot reclosers for Breaker *m*	
79SH*m*_4[a]	Total number of fourth shot reclosers for Breaker *m*	
79SH*m*_T[a]	Total number of reclosers for Breaker *m*	
87IOP*p*C[d]	Zone 1 1-cycle average differential element operating current	pu
87IRT*p*C[d]	Zone 1 1-cycle average differential element restraint current	pu
ACN01CV–ACN32CV	Automation SELOGIC counter current value	
ACN01PV–ACN32PV	Automation SELOGIC counter preset value	
ACT01DO–ACT48DO	Automation conditioning timer dropout time	s
ACT01PU–ACT48PU	Automation conditioning timer pickup time	s
ACTGRP	Active group setting	
AMV001–AMV256	Automation SELOGIC math variable	
AST01ET–AST48ET	Automation SELOGIC sequencing timer elapsed time	
AST01PT–AST48PT	Automation SELOGIC sequencing timer preset time	
B*m*ATRI*p*[a, d]	Breaker *m* accumulated trip current for Phase *p*	A (primary)
B*m*BCWP*p*[a, d]	Breaker *m* breaker contact wear for Pole *p*	%
B*m*EOTC*p*[a, d]	Breaker *m* average electrical operating time (close for Phase *p*)	ms
B*m*EOTT*p*[a, d]	Breaker *m* average electrical operating time (trip for Phase *p*)	ms
B*m*LEOC*p*[a, d]	Breaker *m* last electrical operating time (close for Phase *p*)	ms
B*m*LEOT*p*[a, d]	Breaker *m* last electrical operating time (trip for Phase *p*)	ms
B*m*LTRI*p*[a, d]	Breaker m last interrupted trip current for Phase *p*	%

Table 12.1 Analog Quantities Sorted Alphabetically (Sheet 4 of 11)

Label	Description	Units
B*m*LMOTC[a]	Breaker *m* last mechanical operating time (close for Phase *p*)	ms
B*m*LMOTT[a]	Breaker *m* last mechanical operating time (trip for Phase *p*)	ms
B*m*MOTC[a]	Breaker *m* average mechanical operating time (close)	ms
B*m*MOTT[a]	Breaker *m* average mechanical operating time (trip)	ms
B*m*OPCN[a]	Breaker *m* number of operations (trip)	
BNCDSJI	BNC port 100PPS data stream jitter	µs
BNCOTJF	Fast converging BNC port ON TIME marker jitter, coarse accuracy	µs
BNCOTJS	Slow converging BNC port ON TIME marker jitter, fine accuracy	µs
BNCTBTW	Time between BNC 100PPS pulses	µs
CTR*m*[a]	CT ratio for Terminal *m*	
CTRY1–CTRY3	CT ratio for Terminal Y1–Y3	
CUR_SRC	Current high-priority time source	
DCMAX	Maximum dc 1 voltage	V
DCMIN	Minimum dc 1 voltage	V
DCNE	Average negative-to-ground dc 1 voltage	V
DCPO	Average positive-to-ground dc 1 voltage	V
DCRI	AC ripple of dc 1 voltage	V
DDOM	UTC date, day of the month (1–31)	day
DDOW	UTC date, day of the week (1–SU,.., 7–SA)	
DDOY	UTC date, day of the year (1–366)	day
DFDTP	Rate-of-change of frequency	Hz/s
DFDTPM	Rate-of-change of frequency for synchrophasor data	Hz/s
DFDTPMD	Rate-of-change of frequency for synchrophasor data, delayed for RTC alignment	Hz/s
DLDOM	Local date, day of the month (1–31)	day
DLDOW	Local date, day of the week (1–SU,.., 7–SA)	
DLDOY	Local date, day of the year (1–366)	day
DLMON	Local date, month (1–12)	month
DLYEAR	Local date, year (2000–2200)	year
DM01–DM10	Demand metering value	A (secondary)
DMM01–DMM10	Demand metering maximum value	A (secondary)
DMON	UTC date, month (1–12)	month
DPF*pm*[a, d]	Phase displacement power factor, Phase *p*, Terminal *m*	
DPF*pqp*[b, d]	Phase displacement power factor, Phase *p*, comb. Terminals *qp*	
DYEAR	UTC date, year (2000–2200)	year
FOSPM	Fraction of second of the synchrophasor data packet	s
FOSPMD	Fraction of second of the synchrophasor data packet, delayed for RTC alignment	s
FREQ	Tracking frequency	Hz
FREQP	Frequency for over- and underfrequency elements	Hz
FREQPM	Frequency for synchrophasor data	Hz
FREQPMD	Frequency for synchrophasor data, delayed for RTC alignment	Hz
HSRSRTP	Round-trip time for HSR supervision frames on process bus	µs

Table 12.1 Analog Quantities Sorted Alphabetically (Sheet 5 of 11)

Label	Description	Units
HSRSRTS	Round-trip time for HSR supervision frames on station bus	µs
I850MOD	IEC 61850 Mode/Behavior status	N/A
I*pm*FA[a, d]	Instantaneous filtered phase-current angle, Phase *p*, Terminal *m*	° (±180°)
I*pm*FAC[a, d]	1-cycle average filtered phase-current angle, Phase *p*, Terminal *m*	° (±180°)
I*pm*FI[a, d]	Instantaneous filtered phase current, imaginary component, Phase *p*, Terminal *m*	A (secondary)
I*pm*FM[a, d]	Instantaneous filtered phase-current magnitude, Phase *p*, Terminal *m*	A (secondary)
I*pm*FMC[a, d]	1-cycle average filtered phase-current magnitude, Phase *p*, Terminal *m*	A (primary)
I*pm*FR[a, d]	Instantaneous filtered phase current, real component, Phase *p*, Terminal *m*	A (secondary)
I*pm*M2[a, d]	Second-harmonic content of Terminal *m* current, Phase *p*	A (secondary)
I*pm*RC[a, d]	1-cycle average rms phase current, Phase *p*, Terminal *m*	A (primary)
I*pm*RMS[a, d]	Instantaneous rms phase-current magnitude, Phase *p*, Terminal *m*	A (secondary)
I*pm*RS[a, d]	60-cycle average rms phase current, Phase *p*, Terminal *m*	A (secondary)
I*pqp*FA[b, d]	Instantaneous filtered phase-current angle, Phase *p*, comb. Terminals *qp*	° (±180°)
I*pqp*FAC[b, d]	1-cycle average filtered phase-current angle, Phase *p*, comb. Terminals *qp*	° (±180°)
I*pqp*FI[b, d]	Instantaneous filtered phase current, imaginary component, Phase *p*, comb. Terminals *qp*	A (secondary)
I*pqp*FM[b, d]	Instantaneous filtered phase-current magnitude, Phase *p*, comb. Terminals *qp*	A (secondary)
I*pqp*FMC[b, d]	1-cycle average filtered phase-current magnitude, Phase *p*, comb. Terminals *qp*	A (primary)
I*pqp*FR[b, d]	Instantaneous filtered phase current, real component, Phase *p*, comb. Terminals *qp*	A (secondary)
I*pqp*M2[b, d]	Second-harmonic content of Terminal *qp* current, Phase *p*	A (secondary)
I*pqp*RC[b, d]	1-cycle average rms phase current, Phase *p*, comb. Terminals *qp*	A (primary)
I*pqp*RMS[b, d]	Instantaneous rms phase current, Phase *p*, comb. Terminals *qp*	A (secondary)
I*pqp*RS[b, d]	60-cycle average rms phase current, Phase *p*, comb. Terminals *qp*	A (secondary)
I*pr*PMA[a, d]	Synchrophasor current angle, Phase *p*, Terminal *r*	° (±180°)
I*pr*PMAD[a, d]	Synchrophasor current angle, Phase *p*, Terminal *r*, delayed for RTC alignment	° (±180°)
I*pr*PMI[a, d]	Synchrophasor current imaginary component, Phase *p*, Terminal *r*	A (primary)
I*pr*PMID[a, d]	Synchrophasor current imaginary component, Phase *p*, Terminal *r*, delayed for RTC alignment	A (primary)
I*pr*PMM[a, d]	Synchrophasor current magnitude, Phase *p*, Terminal *r*	A (primary)
I*pr*PMMD[a, d]	Synchrophasor current magnitude, Phase *p*, Terminal *r*, delayed for RTC alignment	A (primary)
I*pr*PMR[a, d]	Synchrophasor current real component, Phase *p*, Terminal *r*	A (primary)
I*pr*PMRD[a, d]	Synchrophasor current real component, Phase *p*, Terminal *r*, delayed for RTC alignment	A (primary)
I*p*L1FA[d]	Instantaneous filtered phase current angle, Phase *p*, Line 1	° (±180°)
I*p*L1FM[d]	Instantaneous filtered phase current magnitude, Phase *p*, Line 1	A (secondary)
I*p*M2[d]	Zone 1 differential second-harmonic current content of operating current, Phase *p*	pu
I*p*M2L1[d]	Second-harmonic current content of Line 1 current, Phase *p*	A (secondary)
I*p*M4[d]	Zone 1 differential fourth-harmonic current content of operating current, Phase *p*	pu
I*p*M4L1[d]	Fourth-harmonic current content of Line 1 current, Phase *p*	A (secondary)
I*p*M5[d]	Zone 1 differential fifth-harmonic current content of operating current, Phase *p*	pu
I*p*M5L1[d]	Fifth-harmonic current content of Line 1 current, Phase *p*	A (secondary)
I1*m*A[a]	Instantaneous positive-sequence current angle, Terminal *m*	° (±180°)
I1*m*AC[a]	1-cycle average positive-sequence current angle, Terminal *m*	° (±180°)

Table 12.1 Analog Quantities Sorted Alphabetically (Sheet 6 of 11)

Label	Description	Units
I1*m*I[a]	Instantaneous positive-sequence current, imaginary component, Terminal *m*	A (secondary)
I1*m*M[a]	Instantaneous positive-sequence current magnitude, Terminal *m*	A (secondary)
I1*m*MC[a]	1-cycle average positive-sequence current magnitude, Terminal *m*	A (primary)
I1*m*R[a]	Instantaneous positive-sequence current, real component, Terminal *m*	A (secondary)
I1*qp*A[b]	Instantaneous positive-sequence current angle, comb. Terminals *qp*	° (±180°)
I1*qp*AC[b]	1-cycle average positive-sequence current angle, comb. Terminals *qp*	° (±180°)
I1*qp*I[b]	Instantaneous positive-sequence current, imaginary comp, comb. Terminals *qp*	A (secondary)
I1*qp*M[b]	Instantaneous positive-sequence current magnitude, comb. Terminals *qp*	A (secondary)
I1*qp*MC[b]	1-cycle average positive-sequence current magnitude, comb. Terminals *qp*	A (primary)
I1*qp*R[b]	Instantaneous positive-sequence current, real component, comb. Terminals *qp*	A (secondary)
I1*r*PMA[a]	Positive-sequence synchrophasor current angle, Terminal *r*	° (±180°)
I1*r*PMAD[a]	Positive-sequence synchrophasor current angle, Terminal *r*, delayed for RTC alignment	° (±180°)
I1*r*PMI[a]	Positive-sequence synchrophasor current imaginary component, Terminal *r*	A (primary)
I1*r*PMID[a]	Positive-sequence synchrophasor current imaginary component, Terminal *r*, delayed for RTC alignment	A (primary)
I1*r*PMM[a]	Positive-sequence synchrophasor current magnitude, Terminal *r*	A (primary)
I1*r*PMMD[a]	Positive-sequence synchrophasor current magnitude, Terminal *r*, delayed for RTC alignment	A (primary)
I1*r*PMR[a]	Positive-sequence synchrophasor current real component, Terminal *r*	A (primary)
I1*r*PMRD[a]	Positive-sequence synchrophasor current real component, Terminal *r*, delayed for RTC alignment	A (primary)
IMAX*m*F[a]	Instantaneous filtered maximum phase-current magnitude, Terminal *m*	A (secondary)
IMAX*m*R[a]	Instantaneous rms maximum phase current, Terminal *m*	A (secondary)
IMAX*qp*F	Instantaneous filtered maximum phase-current magnitude, comb. Terminals *qp*	A (secondary)
IMAX*qp*R[b]	Instantaneous rms maximum phase current, comb. Terminals *qp*	A (secondary)
IMIN*m*F[a]	Instantaneous filtered minimum phase-current magnitude, Terminal *m*	A (secondary)
IMIN*m*R[a]	Instantaneous rms minimum phase current, Terminal *m*	A (secondary)
IMIN*qp*F[b]	Instantaneous filtered minimum phase-current magnitude, comb. Terminals *qp*	A (secondary)
IMIN*qp*R[b]	Instantaneous rms minimum phase current, comb. Terminals *qp*	A (secondary)
IMX*m*RS[a]	60-cycle average maximum rms phase current, Terminal *m*	A (secondary)
IMX*qp*RS[b]	60-cycle average maximum rms phase current, comb. Terminals *qp*	A (secondary)
IOP*p*[d]	Zone 1 instantaneous operating current, Phase *p*	pu
IOP87Q	Zone 1 negative-sequence operating current	pu
IRT*p*[d]	Zone 1 instantaneous restraint current, Phase *p*	pu
IRT87Q	Zone 1 negative-sequence restraint current	pu
IRTFK*p*[d]	Zone 1 biased instantaneous-restraint current, Phase *p*	pu
IRTHR*p*[d]	Zone 1 instantaneous harmonic-restraint current, Phase *p*	pu
IOP*p*2[d]	Zone 2 instantaneous operating current, Phase *p*	pu
IOP87Q2	Zone 2 negative-sequence operating current	pu
IRT*p*2[d]	Zone 2 instantaneous restraint current, Phase *p*	pu
IRT87Q2	Zone 2 negative-sequence restraint current	pu
IRTFK*p*2[d]	Zone 2 biased instantaneous-restraint current, Phase *p*	pu

Table 12.1 Analog Quantities Sorted Alphabetically (Sheet 7 of 11)

Label	Description	Units
IRTHR*p*2[d]	Zone 2 instantaneous harmonic-restraint current, Phase *p*	pu
IY1FA–IY3FA	Instantaneous filtered current angle, Channel 1–3, Terminal Y	° (±180°)
IY1FAC–IY3FAC	1-cycle average filtered current angle, Channel 1–3, Terminal Y	° (±180°)
IY1FI–IY3FI	Instantaneous filtered current, imaginary component, Channel 1–3, Terminal Y	A (secondary)
IY1FM–IY3FM	Instantaneous filtered current magnitude, Channel 1–3, Terminal Y	A (secondary)
IY1FMC–IY3FMC	1-cycle average filtered current magnitude, Channel 1–3, Terminal Y	A (primary)
IY1FR–IY3FR	Instantaneous filtered current, real component, Channel 1–3, Terminal Y	A (secondary)
M*pp*L1C[a]	Mho phase impedance calculation Phases *pp*, Line 1	Ω (secondary)
M*p*G1L1C[d]	Mho Z1 ground impedance calculation Phase *p*, Line 1	Ω (secondary)
M*p*G2L1C[d]	Mho Z2 ground impedance calculation Phase *p*, Line 1	Ω (secondary)
M*p*G3L1C[d]	Mho Z3 ground impedance calculation Phase *p*, Line 1	Ω (secondary)
M*p*G4L1C[d]	Mho Z4 ground impedance calculation Phase *p*, Line 1	Ω (secondary)
MAMBT	Measured ambient temperature	°C
MB1A–MB7A	A Channel received MIRRORED BITS analog values	
MB1B–MB7B	B Channel received MIRRORED BITS analog values	
MTOIL1–MTOIL3	Measured top-oil temperature, Transformer 1–3	°C
NEW_SRC	Selected high-priority time source	
P*pm*F[a, d]	Instantaneous phase fundamental active power, Phase *p*, Terminal *m*	W (secondary)
P*pm*FC[a, d]	1-cycle average phase fundamental active power, Phase *p*, Terminal *m*	MW (primary)
P*pqp*F[b, d]	Instantaneous phase fundamental active power, Phase *p*, comb. Terminals *qp*	W (secondary)
P*pqp*FC[b, d]	1-cycle average phase fundamental active power, Phase *p*, comb. Terminals *qp*	MW (primary)
PCN01CV–PCN32CV	Protection SELOGIC counter current value	
PCN01PV–PCN32PV	Protection SELOGIC counter preset value	
PCT01DO–PCT32DO	Protection SELOGIC conditioning timer dropout time	cycles
PCT01PU–PCT32PU	Protection SELOGIC conditioning timer pickup time	cycles
PMV01–PMV64	Protection SELOGIC math variable	
PST01ET–PST32ET	Protection SELOGIC sequencing timer elapsed time	cycles
PST01PT–PST32PT	Protection SELOGIC sequencing timer preset time	cycles
PTPDSJI	PTP 100PPS data stream jitter in µs	µs
PTPMCC	PTP master clock class enumerated value	N/A
PTPOFST	Raw clock offset between PTP master and relay time	ns
PTPOTJF	Fast converging PTP ON TIME marker jitter in µs, coarse accuracy	µs
PTPOTJS	Slow converging PTP ON TIME marker jitter in µs, fine accuracy	µs
PTPPORT	Active PTP port number	N/A
PTPSTEN	PTP Port State enumerated value	
PTPTBTW	Time between PTP 100PPS pulses in µs	µs
PTR*k*[c]	Potential transformer ratio for Terminal *k*	
Q*pm*F[a, d]	Instantaneous phase fundamental reactive power, Phase *p*, Terminal *m*	VAR (secondary)
Q*pm*FC[a, d]	1-cycle average phase fundamental reactive power, Phase *p*, Terminal *m*	MVAR (primary)
Q*pqp*F[b, d]	Instantaneous phase fundamental reactive power, Phase *p*, comb. Terminals *qp*	VAR (secondary)
Q*pqp*FC[b, d]	1-cycle average phase fundamental reactive power, Phase *p*, comb. Terminals *qp*	MVAR (primary)

Table 12.1 Analog Quantities Sorted Alphabetically (Sheet 8 of 11)

Label	Description	Units
R*pp*L1C[e]	Quad phase right resistance calculation Phases *pp*, Line 1	Ω (secondary)
R*p*G1L1C[d]	Quad Z1 ground right resistance calculation Phase *p*, Line 1	Ω (secondary)
R*p*G2L1C[d]	Quad Z2 ground right resistance calculation Phase *p*, Line 1	Ω (secondary)
R*p*G3L1C[d]	Quad Z3 ground right resistance calculation Phase *p*, Line 1	Ω (secondary)
R*p*G4L1C[d]	Quad Z4 ground right resistance calculation Phase *p*, Line 1	Ω (secondary)
RA001–RA256	Remote analogs	
RAO01–RAO64	Remote analog output	
REFTQ1–REFTQ3	Restricted earth fault Element 1–3 torque quantity	A (secondary)
RLYTEMP	Relay temperature (temperature of the box)	°C
RTCAA01–RTCAA08	Channel A remote synchrophasor analogs (units depends on remote synchrophasor contents)	
RTCAP01–RTCAP32	Channel A remote synchrophasor phasors (units depends on remote synchrophasor contents)	
RTCBA01–RTCBA08	Channel B remote synchrophasor analogs (units depends on remote synchrophasor contents)	
RTCBP01–RTCBP32	Channel B remote synchrophasor phasors (units depends on remote synchrophasor contents)	
RTCDFA	Rate-of-change of Channel A remote frequency (from remote synchrophasors)	Hz/s
RTCDFB	Rate-of-change of Channel B remote frequency (from remote synchrophasors)	Hz/s
RTCFA	Channel A remote frequency (from remote synchrophasors)	Hz
RTCFB	Channel B remote frequency (from remote synchrophasors)	Hz
RTD01TV–RTD12TV	RTD01–RTD12 temperature value	°C
S*pm*F[a, d]	Instantaneous phase fundamental apparent power, Phase *p*, Terminal *m*	VA (secondary)
S*pm*FC[a, d]	1-cycle average phase fundamental apparent power, Phase *p*, Terminal *m*	MVA (primary)
S*pqp*F[b, d]	Instantaneous phase fundamental apparent power, Phase *p*, comb. Terminals *qp*	VA (secondary)
S*pqp*FC[b, d]	1-cycle average phase fundamental apparent power, Phase *p*, comb. Terminals *qp*	MVA (primary)
SERDSJI	Serial port 100PPS data stream jitter	µs
SEROTJF	Fast converging serial port ON TIME marker jitter, coarse accuracy	µs
SEROTJS	Slow converging serial port ON TIME marker jitter, fine accuracy	µs
SERTBTW	Time between serial 100PPS pulses	µs
SMPSYNC	Locally derived SmpSynch value	N/A
SODPM	Second of day of the synchrophasor data packet	s
SODPMD	Second of day of the synchrophasor data packet, delayed for RTC alignment	s
SQUAL	Synchronization accuracy of the selected high-priority time source	µs
SV01SNC–SV07SNC	Incoming SmpSynch value per subscribed SV stream	N/A
SVND01–SVND07	Network delay for the subscribed SV stream	ms
T1FAA–T3FAA	Insulation aging acceleration factor, Transformer 1–3	
T1HS–T3HS	Calculated hot-spot temperature, Transformer 1–3	°C
T1LOAD–T3LOAD	Percentage of full-load, Transformer 1–3	%
T1OILC–T3OILC	Calculated transformer top-oil temperature, Transformer 1–3	°C
T1RLOL–T3RLOL	Rate of loss-of-life, Transformer 1–3	%
T1TLL–T3TLL	Time to total loss-of-life alarm, Transformer 1–3	hr

Table 12.1 Analog Quantities Sorted Alphabetically (Sheet 9 of 11)

Label	Description	Units
T1TLOL–T3TLOL	Total loss-of-life, Transformer 1–3	%
TEC1–TEC3	Thermal element condition, Transformer 1–3	
THR	UTC time, hour (0–23)	hr
THRL1–THRL3	Thermal element measurement, Levels 1–3	Per unit (pu)
THTCU1–THTCU3	Thermal element capacity used, Levels 1–3	%
THTRIP1–THTRIP3	Thermal element remaining time before trip, Levels 1–3	s
TLHR	Local time, hour (0–23)	hr
TLMIN	Local time, minute (0–59)	min
TLMSEC	Local time, milliseconds (0–999)	ms
TLNSEC	Local time, nanoseconds (0–999999)	ns
TLODMS	Local time of day in milliseconds (0–86400000)	ms
TLSEC	Local time, seconds (0–59)	s
TMIN	UTC time, minute (0–59)	min
TMSEC	UTC time, milliseconds (0–999)	ms
TNSEC	UTC time, nanoseconds (0–999999)	ns
TODMS	UTC time of day in milliseconds (0–86400000)	ms
TQUAL	Worst-case clock time error of the selected high-priority time source	s
TSEC	UTC time, seconds (0–59)	s
TUTC	Offset from local time to UTC time	hr
V*pk*FA[c, d]	Instantaneous filtered phase-to-neutral voltage angle, Phase *p*, Terminal *k*	° (±180°)
V*p*kFAC[c, d]	1-cycle average filtered phase-to-neutral voltage angle, Phase *p*, Terminal *k*	° (±180°)
V*pk*FI[c, d]	Instantaneous filtered phase-to-neutral voltage, imaginary component, Phase *p*, Terminal *k*	V (secondary)
V*pk*FM[c, d]	Instantaneous filtered phase-to-neutral voltage magnitude, Phase *p*, Terminal *k*	V (secondary)
V*pk*FMC[c, d]	1-cycle average filtered phase-to-neutral voltage magnitude, Phase *p*, Terminal *k*	kV (primary)
V*pk*FR[c, d]	Instantaneous filtered phase-to-neutral voltage, real component, Phase *p*, Terminal *k*	V (secondary)
V*pk*PMA[c, d]	Synchrophasor voltage angle, Phase *p*, Terminal *k*	° (±180°)
V*pk*PMAD[c, d]	Synchrophasor voltage angle, Phase *p*, Terminal *k*, delayed for RTC alignment	° (±180°)
V*pk*PMI[c, d]	Synchrophasor voltage imaginary component, Phase *p*, Terminal *k*	kV (primary)
V*pk*PMID[c, d]	Synchrophasor voltage imaginary component, Phase *p*, Terminal *k*, delayed for RTC alignment	kV (primary)
V*pk*PMM[c, d]	Synchrophasor voltage magnitude, Phase *p*, Terminal *k*	kV (primary)
V*pk*PMMD[c, d]	Synchrophasor voltage magnitude, Phase *p*, Terminal *k*, delayed for RTC alignment	kV (primary)
V*pk*PMR[c, d]	Synchrophasor voltage real component, Phase *p*, Terminal *k*	kV (primary)
V*pk*PMRD[c, d]	Synchrophasor voltage real component, Phase *p*, Terminal *k*, delayed for RTC alignment	kV (primary)
V*pk*RC[c, d]	1-cycle average rms phase-to-neutral voltage, Phase *p*, Terminal *k*	kV (primary)
V*pk*RMS[c, d]	Instantaneous rms phase-to-neutral voltage, Phase *p*, Terminal *k*	V (secondary)
V*pk*THD[c, d]	THD voltage calculation, Phase *p*, Terminal *k*	
V*ppk*FA[c, e]	Instantaneous filtered phase-to-phase voltage angle, Phases *pp*, Terminal *k*	° (±180°)
V*ppk*FAC[c, e]	1-cycle average filtered phase-to-phase voltage angle, Phases *pp*, Terminal *k*	° (±180°)
V*ppk*FI[c, e]	Instantaneous filtered phase-to-phase voltage, imaginary component, Phases *pp*, Terminal *k*	V (secondary)

Table 12.1 Analog Quantities Sorted Alphabetically (Sheet 10 of 11)

Label	Description	Units
V*ppk*FM[c, e]	Instantaneous filtered phase-to-phase voltage magnitude, Phases *pp*, Terminal *k*	V (secondary)
V*ppk*FMC[c, e]	1-cycle average filtered phase-to-phase voltage magnitude, Phases *pp*, Terminal *k*	kV (primary)
V*ppk*FR[c, e]	Instantaneous filtered phase-to-phase voltage, real component, Phases *pp*, Terminal *k*	V (secondary)
V*ppk*RC[c, e]	1-cycle average rms phase-to-phase voltage, Phases *pp*, Terminal *k*	kV (primary)
V*ppk*RMS[c, e]	Instantaneous rms phase-to-phase voltage Phases *pp*, Terminal *k*	V (secondary)
V*pp*L1FA[e]	Instantaneous filtered phase-to-phase voltage angle, Phases *pp*, Line 1	° (±180°)
V*pp*L1FM[e]	Instantaneous filtered phase-to-phase voltage magnitude, Phases *pp*, Line 1	V (secondary)
V*p*L1FA[d]	Instantaneous filtered phase-to-neutral voltage angle, Phase *p*, Line 1	° (±180°)
V*p*L1FM[d]	Instantaneous filtered phase-to-neutral voltage magnitude, Phase *p,* Line 1	V (secondary)
V1*k*A[c]	Instantaneous positive-sequence voltage angle, Terminal *k*	° (±180°)
V1*k*AC[c]	1-cycle average positive-sequence voltage angle, Terminal *k*	° (±180°)
V1*k*I[c]	Instantaneous positive-sequence voltage, imaginary component, Terminal *k*	V (secondary)
V1*k*M[c]	Instantaneous positive-sequence voltage magnitude, Terminal *k*	V (secondary)
V1*k*MC[c]	1-cycle average positive-sequence voltage magnitude, Terminal *k*	kV (primary)
V1*k*PMA[c]	Positive-sequence synchrophasor voltage angle, Terminal *k*	° (±180°)
V1*k*PMAD[c]	Positive-sequence synchrophasor voltage angle, Terminal *k*, delayed for RTC alignment	° (±180°)
V1*k*PMI[c]	Positive-sequence synchrophasor voltage imaginary component, Terminal *k*	kV (primary)
V1*k*PMID[c]	Positive-sequence synchrophasor voltage imaginary component, Terminal *k*, delayed for RTC alignment	kV (primary)
V1*k*PMM[c]	Positive-sequence synchrophasor voltage magnitude, Terminal *k*	kV (primary)
V1*k*PMMD[c]	Positive-sequence synchrophasor voltage magnitude, Terminal *k*, delayed for RTC alignment	kV (primary)
V1*k*PMR[c]	Positive-sequence synchrophasor voltage real component, Terminal *k*	kV (primary)
V1*k*PMRD[c]	Positive-sequence synchrophasor voltage real component, Terminal *k*, delayed for RTC alignment	kV (primary)
V1*k*R[c]	Instantaneous positive-sequence voltage, real component, Terminal *k*	V (secondary)
V1L1A	Instantaneous positive-sequence voltage angle, Line 1	° (±180°)
V1L1M	Instantaneous positive-sequence voltage magnitude, Line 1	V (secondary)
VDC	Station Battery 1 dc voltage	V
VNMAX*k*F[c]	Instantaneous filtered maximum phase-to-neutral voltage magnitude, Terminal *k*	V (secondary)
VNMAX*k*R[c]	Instantaneous rms maximum phase-to-neutral voltage, Terminal *k*	V (secondary)
VNMIN*k*F[c]	Instantaneous filtered minimum phase-to-neutral voltage magnitude, Terminal *k*	V (secondary)
VNMIN*k*R[c]	Instantaneous rms minimum phase-to-neutral voltage, Terminal *k*	V (secondary)
VPMAX*k*F[c]	Instantaneous filtered maximum phase-to-phase voltage magnitude, Terminal *k*	V (secondary)
VPMAX*k*R[c]	Instantaneous rms maximum phase-to-phase voltage, Terminal *k*	V (secondary)
VPMIN*k*F[c]	Instantaneous filtered minimum phase-to-phase voltage magnitude, Terminal *k*	V (secondary)
VPMIN*k*R[c]	Instantaneous rms minimum phase-to-phase voltage, Terminal *k*	V (secondary)
X*pp*L1C[e]	Quad phase reactance calculation Phase *pp*, Line 1	Ω (secondary)
X*p*G1L1C[d]	Quad Z1 ground reactance calculation Phase *p*, Line 1	Ω (secondary)
X*p*G2L1C[d]	Quad Z2 ground reactance calculation Phase *p*, Line 1	Ω (secondary)
X*p*G3L1C[d]	Quad Z3 ground reactance calculation Phase *p*, Line 1	Ω (secondary)
X*p*G4L1C[d]	Quad Z4 ground reactance calculation Phase *p*, Line 1	Ω (secondary)

Table 12.1 Analog Quantities Sorted Alphabetically (Sheet 11 of 11)

Label	Description	Units
Z1A*m*[a]	Positive-sequence impedance angle, Terminal *m*	° (±180°)
Z1A*n*[a]	Positive-sequence impedance angle, Terminal *n*	° (±180°)
Z1AL1	Positive-sequence impedance angle, Line 1	° (±180°)
Z1M*m*[a]	Positive-sequence impedance magnitude, Terminal *m*	Ω (secondary)
Z1M*n*[f]	Positive-sequence impedance magnitude, Terminal *n*	Ω (secondary)
Z1ML1	Positive-sequence impedance magnitude, Line 1	Ω (secondary)

[a] m = S, T, U, W, X, Y.
[b] qp = ST, TU, UW, WX.
[c] k = V, Z.
[d] p = A, B, C.
[e] pp = AB, BC, CA.
[f] n = 1, 2, 3, 4 (combined terminals: 1 = ST, 2 = TU, 3 = UW, 4 = WX).

Table 12.2 Analog Quantities Sorted by Function (Sheet 1 of 13)

Analog Labels	Analog Quantity Description	Units	Number of Analogs
Current and Potential Transformer Ratios			
CTR*m*[a]	CT ratio, Terminal *m*		6
CTRY1–CTRY3	CT ratio, Terminal Y1–Y3		3
PTR*k*[b]	Potential transformer ratio, Terminal *k*		2
Instantaneous Voltage			
V*pk*FM[b, c]	Instantaneous filtered phase-to-neutral voltage magnitude, Phase *p*, Terminal *k*	V (secondary)	6
V*pk*FA[b, c]	Instantaneous filtered phase-to-neutral voltage angle, Phase *p*, Terminal *k*	° (±180°)	6
V*pk*FR[b, c]	Instantaneous filtered phase-to-neutral voltage, real component, Phase *p*, Terminal *k*	V (secondary)	6
V*pk*FI[b, c]	Instantaneous filtered phase-to-neutral voltage, imaginary component, Phase *p*, Terminal *k*	V (secondary)	6
V*ppk*FM[b, d]	Instantaneous filtered phase-to-phase voltage magnitude, Phases *pp*, Terminal *k*	V (secondary)	6
V*ppk*FA[b, d]	Instantaneous filtered phase-to-phase voltage angle, Phases *pp*, Terminal *k*	° (±180°)	6
V*ppk*FR[b, d]	Instantaneous filtered phase-to-phase voltage, real component, Phases *pp*, Terminal *k*	V (secondary)	6
V*ppk*FI[b, d]	Instantaneous filtered phase-to-phase voltage, imaginary component, Phases *pp*, Terminal *k*	V (secondary)	6
VNMAX*k*F[b]	Instantaneous filtered maximum phase-to-neutral voltage magnitude, Terminal *k*	V (secondary)	2
VNMIN*k*F[b]	Instantaneous filtered minimum phase-to-neutral voltage magnitude, Terminal *k*	V (secondary)	2
VPMAX*k*F[b]	Instantaneous filtered maximum phase-to-phase voltage magnitude, Terminal *k*	V (secondary)	2
VPMIN*k*F[b]	Instantaneous filtered minimum phase-to-phase voltage magnitude, Terminal *k*	V (secondary)	2
V1*k*M[b]	Instantaneous positive-sequence voltage magnitude, Terminal *k*	V (secondary)	2
V1*k*A[b]	Instantaneous positive-sequence voltage angle, Terminal *k*	° (±180°)	2
V1*k*R[b]	Instantaneous positive-sequence voltage, real component, Terminal *k*	V (secondary)	2
V1*k*I[b]	Instantaneous positive-sequence voltage, imaginary component, Terminal *k*	V (secondary)	2

Table 12.2 Analog Quantities Sorted by Function (Sheet 2 of 13)

Analog Labels	Analog Quantity Description	Units	Number of Analogs
3V2*k*M[b]	Instantaneous negative-sequence voltage magnitude, Terminal *k*	V (secondary)	2
3V2*k*A[b]	Instantaneous negative-sequence voltage angle, Terminal *k*	° (±180°)	2
3V2*k*R[b]	Instantaneous negative-sequence voltage, real component, Terminal *k*	V (secondary)	2
3V2*k*I[b]	Instantaneous negative-sequence voltage, imaginary component, Terminal *k*	V (secondary)	2
3V0*k*M[b]	Instantaneous zero-sequence voltage magnitude, Terminal *k*	V (secondary)	2
3V0*k*A[b]	Instantaneous zero-sequence voltage angle, Terminal *k*	° (±180°)	2
3V0*k*R[b]	Instantaneous zero-sequence voltage, real component, Terminal *k*	V (secondary)	2
3V0*k*I[b]	Instantaneous zero-sequence voltage, imaginary component, Terminal *k*	V (secondary)	2
V*p*L1FM[c]	Instantaneous filtered phase-to-neutral voltage magnitude, Phase *p*, Line 1	V (secondary)	3
V*p*L1FA[c]	Instantaneous filtered phase-to-neutral voltage angle, Phase *p*, Line 1	° (±180°)	3
V*pp*L1FM[d]	Instantaneous filtered phase-to-phase voltage magnitude, Phases *pp*, Line 1	V (secondary)	3
V*pp*L1FA[d]	Instantaneous filtered phase-to-phase voltage angle, Phases *pp*, Line 1	° (±180°)	3
V1L1M	Instantaneous positive-sequence voltage magnitude, Line 1	V (secondary)	1
V1L1A	Instantaneous positive-sequence voltage angle, Line 1	° (±180°)	1
3V2L1M	Instantaneous negative-sequence voltage magnitude, Line 1	V (secondary)	1
3V2L1A	Instantaneous negative-sequence voltage angle, Line 1	° (±180°)	1
3V0L1M	Instantaneous zero-sequence voltage magnitude, Line 1	V (secondary)	1
3V0L1A	Instantaneous zero-sequence voltage angle, Line 1	° (±180°)	1
Instantaneous Current			
I*pm*FM[a, c]	Instantaneous filtered phase-current magnitude, Phase *p*, Terminal *m*	A (secondary)	18
I*pm*FA[a, c]	Instantaneous filtered phase-current angle, Phase *p*, Terminal *m*	° (±180°)	18
I*pm*FR[a, c]	Instantaneous filtered phase current, real component, Phase *p*, Terminal *m*	A (secondary)	18
I*pm*FI[a, c]	Instantaneous filtered phase current, imaginary component, Phase *p*, Terminal *m*	A (secondary)	18
IY1FM–IY3FM	Instantaneous filtered current magnitude, Channel 1–3, Terminal Y	A (secondary)	3
IY1FA–IY3FA	Instantaneous filtered current angle, Channel 1–3, Terminal Y	° (±180°)	3
IY1FR–IY3FR	Instantaneous filtered current, real component, Channel 1–3, Terminal Y	A (secondary)	3
IY1FI–IY3FI	Instantaneous filtered current, imaginary component, Channel 1–3, Terminal Y	A (secondary)	3
I*pqp*FM[c, e]	Instantaneous filtered phase-current magnitude, Phase *p*, comb. Terminals *qp*	A (secondary)	12
I*pqp*FA[c, e]	Instantaneous filtered phase-current angle, Phase *p*, comb. Terminals *qp*	° (±180°)	12
I*pqp*FR[c, e]	Instantaneous filtered phase current, real component, Phase *p*, comb. Terminals *qp*	A (secondary)	12
I*pqp*FI[c, e]	Instantaneous filtered phase current, imaginary component, Phase *p*, comb. Terminals *qp*	A (secondary)	12
IMAX*m*F[a]	Instantaneous filtered maximum phase-current magnitude, Terminal *m*	A (secondary)	6
IMIN*m*F[a]	Instantaneous filtered minimum phase-current magnitude, Terminal *m*	A (secondary)	6
IMAX*qp*F[e]	Instantaneous filtered maximum phase-current magnitude, comb. Terminals *qp*	A (secondary)	4
IMIN*qp*F[e]	Instantaneous filtered minimum phase-current magnitude, comb. Terminals *qp*	A (secondary)	4
I1*m*M[a]	Instantaneous positive-sequence current magnitude, Terminal *m*	A (secondary)	6

Table 12.2 Analog Quantities Sorted by Function (Sheet 3 of 13)

Analog Labels	Analog Quantity Description	Units	Number of Analogs
I1*m*A[a]	Instantaneous positive-sequence current angle, Terminal *m*	° (±180°)	6
I1*m*R[a]	Instantaneous positive-sequence current, real component, Terminal *m*	A (secondary)	6
I1*m*I[a]	Instantaneous positive-sequence current, imaginary component, Terminal *m*	A (secondary)	6
3I2*m*M[a]	Instantaneous negative-sequence current magnitude, Terminal *m*	A (secondary)	6
3I2*m*A[a]	Instantaneous negative-sequence current angle, Terminal *m*	° (±180°)	6
3I2*m*R[a]	Instantaneous negative-sequence current, real component, Terminal *m*	A (secondary)	6
3I2*m*I[a]	Instantaneous negative-sequence current, imaginary component, Terminal *m*	A (secondary)	6
3I0*m*M[a]	Instantaneous zero-sequence current magnitude, Terminal *m*	A (secondary)	6
3I0*m*A[a]	Instantaneous zero-sequence current angle, Terminal *m*	° (±180°)	6
3I0*m*R[a]	Instantaneous zero-sequence current, real component, Terminal *m*	A (secondary)	6
3I0*m*I[a]	Instantaneous zero-sequence current, imaginary component, Terminal *m*	A (secondary)	6
I1*qp*M[e]	Instantaneous positive-sequence current magnitude, comb. Terminals *qp*	A (secondary)	4
I1*qp*A[e]	Instantaneous positive-sequence current angle, comb. Terminals *qp*	° (±180°)	4
I1*qp*R[e]	Instantaneous positive-sequence current, real component, comb. Terminals *qp*	A (secondary)	4
I1*qp*I[e]	Instantaneous positive-sequence current, imaginary comp, comb. Terminals *qp*	A (secondary)	4
3I2*qp*M[e]	Instantaneous negative-sequence current magnitude, comb. Terminals *qp*	A (secondary)	4
3I2*qp*A[e]	Instantaneous negative-sequence current angle, comb. Terminals *qp*	° (±180°)	4
3I2*qp*R[e]	Instantaneous negative-sequence current, real component, comb. Terminals *qp*	A (secondary)	4
3I2*qp*I[e]	Instantaneous negative-sequence current, imaginary component, comb. Terminals *qp*	A (secondary)	4
3I0*qp*M[e]	Instantaneous zero-sequence current magnitude, comb. Terminals *qp*	A (secondary)	4
3I0*qp*A[e]	Instantaneous zero-sequence current angle, comb. Terminals *qp*	° (±180°)	4
3I0*qp*R[e]	Instantaneous zero-sequence current, real component, comb. Terminals *qp*	A (secondary)	4
3I0*qp*I[e]	Instantaneous zero-sequence current, imaginary component, comb. Terminals *qp*	A (secondary)	4
I*p*L1FM[c]	Instantaneous filtered phase current magnitude, Phase *p*, Line 1	° (±180°)	3
I*p*L1FA[c]	Instantaneous filtered phase current angle, Phase *p*, Line 1	A (secondary)	3
I1L1M	Instantaneous positive-sequence current magnitude, Line 1	° (±180°)	1
I1L1A	Instantaneous positive-sequence current angle, Line 1	A (secondary)	1
3I2L1M	Instantaneous negative-sequence current magnitude, Line 1	° (±180°)	1
3I2L1A	Instantaneous negative-sequence current angle, Line 1	A (secondary)	1
3I0L1M	Instantaneous zero-sequence current magnitude, Line 1	° (±180°)	1
3I0L1A	Instantaneous zero-sequence current angle, Line 1	A (secondary)	1
Instantaneous RMS Voltage			
V*pk*RMS[b, c]	Instantaneous rms phase-to-neutral voltage, Phase *p*, Terminal *k*	V (secondary)	6
V*ppk*RMS[b, d]	Instantaneous rms phase-to-phase voltage Phases *pp*, Terminal *k*	V (secondary)	6
VNMAX*k*R[b]	Instantaneous rms maximum phase-to-neutral voltage, Terminal *k*	V (secondary)	2
VNMIN*k*R[b]	Instantaneous rms minimum phase-to-neutral voltage, Terminal *k*	V (secondary)	2

Table 12.2 Analog Quantities Sorted by Function (Sheet 4 of 13)

Analog Labels	Analog Quantity Description	Units	Number of Analogs
VPMAX*k*R[b]	Instantaneous rms maximum phase-to-phase voltage, Terminal *k*	V (secondary)	2
VPMIN*k*R[b]	Instantaneous rms minimum phase-to-phase voltage, Terminal *k*	V (secondary)	2
Instantaneous RMS Current			
I*pm*RMS[a, c]	Instantaneous rms phase-current magnitude, Phase *p*, Terminal *m*	A (secondary)	18
I*pqp*RMS[c, e]	Instantaneous rms phase current, Phase *p*, comb. Terminals *qp*	A (secondary)	12
IMAX*m*R[a]	Instantaneous rms maximum phase current, Terminal *m*	A (secondary)	6
IMIN*m*R[a]	Instantaneous rms minimum phase current, Terminal *m*	A (secondary)	6
IMAX*qp*R[e]	Instantaneous rms maximum phase current, comb. Terminals *qp*	A (secondary)	4
IMIN*qp*R[e]	Instantaneous rms minimum phase current, comb. Terminals *qp*	A (secondary)	4
Instantaneous Power			
P*pm*F[a, c]	Instantaneous phase fundamental active power, Phase *p*, Terminal *m*	W (secondary)	18
Q*pm*F[a, c]	Instantaneous phase fundamental reactive power, Phase *p*, Terminal *m*	VAR (secondary)	18
S*pm*F[a, c]	Instantaneous phase fundamental apparent power, Phase *p*, Terminal *m*	VA (secondary)	18
3P*m*F[a]	Instantaneous three-phase fundamental active power, Terminal *m*	W (secondary)	6
3Q*m*F[a]	Instantaneous three-phase fundamental reactive power, Terminal *m*	VAR (secondary)	6
3S*m*F[a]	Instantaneous three-phase fundamental apparent power, Terminal *m*	VA (secondary)	6
P*pqp*F[c, e]	Instantaneous phase fundamental active power, Phase *p*, comb. Terminals *qp*	W (secondary)	12
Q*pqp*F[c, e]	Instantaneous phase fundamental reactive power, Phase *p*, comb. Terminals *qp*	VAR (secondary)	12
S*pqp*F[c, e]	Instantaneous phase fundamental apparent power, Phase *p*, comb. Terminals *qp*	VA (secondary)	12
3P*qp*F[e]	Instantaneous three-phase fundamental active power, comb. Terminals *qp*	W (secondary)	4
3Q*qp*F[e]	Instantaneous three-phase fundamental reactive power, comb. Terminals *qp*	VAR (secondary)	4
3S*qp*F[e]	Instantaneous three-phase fundamental apparent power, comb. Terminals *qp*	VA (secondary)	4
Instantaneous Positive-Sequence Impedance			
Z1M*m*[a]	Positive-sequence impedance magnitude, Terminal *m*	Ω (secondary)	6
Z1A*m*[a]	Positive-sequence impedance angle, Terminal *m*	° (±180°)	6
Z1M*n*[f]	Positive-sequence impedance magnitude, Terminal *n*	Ω (secondary)	4
Z1A*n*[f]	Positive-sequence impedance angle, Terminal *n*	° (±180°)	4
Synchrophasor Voltages			
V*pk*PMM[b, c]	Synchrophasor voltage magnitude, Phase *p*, Terminal *k*	kV (primary)	6
V*pk*PMA[b, c]	Synchrophasor voltage angle, Phase *p*, Terminal *k*	° (±180°)	6
V*pk*PMR[b, c]	Synchrophasor voltage real component, Phase *p*, Terminal *k*	kV (primary)	6
V*pk*PMI[b, c]	Synchrophasor voltage imaginary component, Phase *p*, Terminal *k*	kV (primary)	6
V1*k*PMM[b]	Positive-sequence synchrophasor voltage magnitude, Terminal *k*	kV (primary)	2
V1*k*PMA[b]	Positive-sequence synchrophasor voltage angle, Terminal *k*	° (±180°)	2
V1*k*PMR[b]	Positive-sequence synchrophasor voltage real component, Terminal *k*	kV (primary)	2
V1*k*PMI[b]	Positive-sequence synchrophasor voltage imaginary component, Terminal *k*	kV (primary)	2
Synchrophasor Currents			
I*pr*PMM[a, c]	Synchrophasor current magnitude, Phase *p*, Terminal *r*	A (primary)	18
I*pr*PMA[a, c]	Synchrophasor current angle, Phase *p*, Terminal *r*	° (±180°)	18

Table 12.2 Analog Quantities Sorted by Function (Sheet 5 of 13)

Analog Labels	Analog Quantity Description	Units	Number of Analogs
I*pr*PMR[a, c]	Synchrophasor current real component, Phase *p*, Terminal *r*	A (primary)	18
I*pr*PMI[a, c]	Synchrophasor current imaginary component, Phase *p*, Terminal *r*	A (primary)	18
I1*r*PMM[a]	Positive-sequence synchrophasor current magnitude, Terminal *r*	A (primary)	6
I1*r*PMA[a]	Positive-sequence synchrophasor current angle, Terminal *r*	° (±180°)	6
I1*r*PMR[a]	Positive-sequence synchrophasor current real component, Terminal *r*	A (primary)	6
I1*r*PMI[a]	Positive-sequence synchrophasor current imaginary component, Terminal *r*	A (primary)	6
SODPM	Second of day of the synchrophasor data packet	s	1
FOSPM	Fraction of second of the synchrophasor data packet	s	1
Synchrophasor Frequency			
FREQPM	Frequency for synchrophasor data	Hz	1
DFDTPM	Rate-of-change of frequency for synchrophasor data	Hz/s	1
Synchrophasor RTC Analogs			
V*pk*PMMD[b, c]	Synchrophasor voltage magnitude, Phase *p*, Terminal *k*, delayed for RTC alignment	kV (primary)	6
V*pk*PMAD[b, c]	Synchrophasor voltage angle, Phase *p*, Terminal *k*, delayed for RTC alignment	° (±180°)	6
V*pk*PMRD[b, c]	Synchrophasor voltage real component, Phase *p*, Terminal *k*, delayed for RTC alignment	kV (primary)	6
V*pk*PMID[b, c]	Synchrophasor voltage imaginary component, Phase *p*, Terminal *k*, delayed for RTC alignment	kV (primary)	6
V1*k*PMMD[b]	Positive-sequence synchrophasor voltage magnitude, Terminal *k*, delayed for RTC alignment	kV (primary)	2
V1*k*PMAD[b]	Positive-sequence synchrophasor voltage angle, Terminal *k*, delayed for RTC alignment	° (±180°)	2
V1*k*PMRD[b]	Positive-sequence synchrophasor voltage real component, Terminal *k*, delayed for RTC alignment	kV (primary)	2
V1*k*PMID[b]	Positive-sequence synchrophasor voltage imaginary component, Terminal *k*, delayed for RTC alignment	kV (primary)	2
I*pr*PMMD[a, c]	Synchrophasor current magnitude, Phase *p*, Terminal *r*, delayed for RTC alignment	A (primary)	18
I*pr*PMAD[a, c]	Synchrophasor current angle, Phase *p*, Terminal *r*, delayed for RTC alignment	° (±180°)	18
I*pr*PMRD[a, c]	Synchrophasor current real component, Phase *p*, Terminal *r*, delayed for RTC alignment	A (primary)	18
I*pr*PMID[a, c]	Synchrophasor current imaginary component, Phase *p*, Terminal *r*, delayed for RTC alignment	A (primary)	18
I1*r*PMMD[a]	Positive-sequence synchrophasor current magnitude, Terminal *r*, delayed for RTC alignment	A (primary)	6
I1*r*PMAD[a]	Positive-sequence synchrophasor current angle, Terminal *r*, delayed for RTC alignment	° (±180°)	6
I1*r*PMRD[a]	Positive-sequence synchrophasor current real component, Terminal *r*, delayed for RTC alignment	A (primary)	6
I1*r*PMID[a]	Positive-sequence synchrophasor current imaginary component, Terminal *r*, delayed for RTC alignment	A (primary)	6
SODPMD	Second of day of the synchrophasor data packet, delayed for RTC alignment	s	1

Table 12.2 Analog Quantities Sorted by Function (Sheet 6 of 13)

Analog Labels	Analog Quantity Description	Units	Number of Analogs
FOSPMD	Fraction of second of the synchrophasor data packet, delayed for RTC alignment	s	1
FREQPMD	Frequency for synchrophasor data, delayed for RTC alignment	Hz	1
DFDTPMD	Rate-of-change of frequency for synchrophasor data, delayed for RTC alignment	Hz/s	1
RTCAP01–RTCAP32	Channel A remote synchrophasor phasors (units depends on remote synchrophasor contents)		32
RTCBP01–RTCBP32	Channel B remote synchrophasor phasors (units depends on remote synchrophasor contents)		32
RTCAA01–RTCAA08	Channel A remote synchrophasor analogs (units depends on remote synchrophasor contents)		8
RTCBA01–RTCBA08	Channel B remote synchrophasor analogs (units depends on remote synchrophasor contents)		8
RTCFA	Channel A remote frequency (from remote synchrophasors)	Hz	1
RTCFB	Channel B remote frequency (from remote synchrophasors)	Hz	1
RTCDFA	Rate of change of Channel A remote frequency (from remote synchrophasors)	Hz/s	1
RTCDFB	Rate of change of Channel B remote frequency (from remote synchrophasors)	Hz/s	1
Averaged Voltage			
V*pk*FMC[b, c]	1-cycle average filtered phase-to-neutral voltage magnitude, Phase *p*, Terminal *k*	kV (primary)	6
V*pk*FAC[b, c]	1-cycle average filtered phase-to-neutral voltage angle, Phase *p*, Terminal *k*	° (±180°)	6
V*ppk*FMC[b, d]	1-cycle average filtered phase-to-phase voltage magnitude, Phases *pp*, Terminal *k*	kV (primary)	6
V*ppk*FAC[b, d]	1-cycle average filtered phase-to-phase voltage angle, Phases *pp*, Terminal *k*	° (±180°)	6
V*pk*RC[b, c]	1-cycle average rms phase-to-neutral voltage, Phase *p*, Terminal *k*	kV (primary)	6
V*ppk*RC[b, d]	1-cycle average rms phase-to-phase voltage, Phases *pp*, Terminal *k*	kV (primary)	6
V1*k*MC[b]	1-cycle average positive-sequence voltage magnitude, Terminal *k*	kV (primary)	2
V1*k*AC[b]	1-cycle average positive-sequence voltage angle, Terminal *k*	° (±180°)	2
3V2*k*MC[b]	1-cycle average negative-sequence voltage magnitude, Terminal *k*	kV (primary)	2
3V2*k*AC[b]	1-cycle average negative-sequence voltage angle, Terminal *k*	° (±180°)	2
3V0*k*MC[b]	1-cycle average zero-sequence voltage magnitude, Terminal *k*	kV (primary)	2
3V0*k*AC[b]	1-cycle average zero-sequence voltage angle, Terminal *k*	° (±180°)	2
Averaged Current			
I*pm*FMC[a, c]	1-cycle average filtered phase-current magnitude, Phase *p*, Terminal *m*	A (primary)	18
I*pm*FAC[a, c]	1-cycle average filtered phase-current angle, Phase *p*, Terminal *m*	° (±180°)	18
IY1FMC–IY3FMC	1-cycle average filtered current magnitude, Channel 1–3, Terminal Y	A (primary)	3
IY1FAC–IY3FAC	1-cycle average filtered current angle, Channel 1–3, Terminal Y	° (±180°)	3
I*pm*RC[a, c]	1-cycle average rms phase current, Phase *p*, Terminal *m*	A (primary)	18
I*pqp*FMC[c, e]	1-cycle average filtered phase-current magnitude, Phase *p*, comb. Terminals *qp*	A (primary)	12
I*pqp*FAC[c, e]	1-cycle average filtered phase-current angle, Phase *p*, comb. Terminals *qp*	° (±180°)	12
I*pqp*RC[c, e]	1-cycle average rms phase current, Phase *p*, comb. Terminals *qp*	A (primary)	12

Table 12.2 Analog Quantities Sorted by Function (Sheet 7 of 13)

Analog Labels	Analog Quantity Description	Units	Number of Analogs
I1*m*MC[a]	1-cycle average positive-sequence current magnitude, Terminal *m*	A (primary)	6
I1*m*AC[a]	1-cycle average positive-sequence current angle, Terminal *m*	° (±180°)	6
3I2*m*MC[a]	1-cycle average negative-sequence current magnitude, Terminal *m*	A Primary)	6
3I2*m*AC[a]	1-cycle average negative-sequence current angle, Terminal *m*	° (±180°)	6
3I0*m*MC[a]	1-cycle average zero-sequence current magnitude, Terminal *m*	A Primary)	6
3I0*m*AC[a]	1-cycle average zero-sequence current angle, Terminal *m*	° (±180°)	6
I1*qp*MC[e]	1-cycle average positive-sequence current magnitude, comb. Terminals *qp*	A (primary)	4
I1*qp*AC[e]	1-cycle average positive-sequence current angle, comb. Terminals *qp*	° (±180°)	4
3I2*qp*MC[e]	1-cycle average negative-sequence current magnitude, comb. Terminals *qp*	A (primary)	4
3I2*qp*AC[e]	1-cycle average negative-sequence current angle, comb. Terminals *qp*	° (±180°)	4
3I0*qp*MC[e]	1-cycle average zero-sequence current magnitude, comb. Terminals *qp*	A (primary)	4
3I0*qp*AC[e]	1-cycle average zero-sequence current angle, comb. Terminals *qp*	° (±180°)	4
I*pm*RS[a, c]	60-cycle average rms phase current, Phase *p*, Terminal *m*	A (secondary)	18
I*pqp*RS[c, e]	60-cycle average rms phase current, Phase *p*, comb. Terminals *qp*	A (secondary)	12
IMX*m*RS[a]	60-cycle average maximum rms phase current, Terminal *m*	A (secondary)	6
IMX*qp*RS[e]	60-cycle average maximum rms phase current, comb. Terminals *qp*	A (secondary)	4
3I2*m*MS[a]	60-cycle average negative-sequence current magnitude, Terminal *m*	A (secondary)	6
3I2*qp*MS[e]	60-cycle average negative-sequence current magnitude, comb. Terminals *qp*	A (secondary)	4
3I0*m*MS[a]	60-cycle average zero-sequence current magnitude, Terminal *m*	A (secondary)	6
3I0*qp*MS[e]	60-cycle average zero-sequence current magnitude, comb. Terminals *qp*	A (secondary)	4
Averaged Power			
P*pm*FC[a, c]	1-cycle average phase fundamental active power, Phase *p*, Terminal *m*	MW (primary)	18
Q*pm*FC[a, c]	1-cycle average phase fundamental reactive power, Phase *p*, Terminal *m*	MVAR (primary)	18
S*pm*FC[a, c]	1-cycle average phase fundamental apparent power, Phase *p*, Terminal *m*	MVA (primary)	18
3P*m*FC[a]	1-cycle average three-phase fundamental active power, Terminal *m*	MW (primary)	6
3Q*m*FC[a]	1-cycle average three-phase fundamental reactive power, Terminal *m*	MVAR (primary)	6
3S*m*FC[a]	1-cycle average three-phase fundamental apparent power, Terminal *m*	MVA (primary)	6
P*pqp*FC[c, e]	1-cycle average phase fundamental active power, Phase *p*, comb. Terminals *qp*	MW (primary)	12
Q*pqp*FC[c, e]	1-cycle average phase fundamental reactive power, Phase *p*, comb. Terminals *qp*	MVAR (primary)	12
S*pqp*FC[c, e]	1-cycle average phase fundamental apparent power, Phase *p*, comb. Terminals *qp*	MVA (primary)	12
3P*qp*FC[e]	1-cycle average three-phase fundamental active power, comb. Terminals *qp*	MW (primary)	4
3Q*qp*FC[e]	1-cycle average three-phase fundamental reactive power, comb. Terminals *qp*	MVAR (primary)	4
3S*qp*FC[e]	1-cycle average three-phase fundamental apparent power, comb. Terminals *qp*	MVA (primary)	4
Averaged Power Factor			
DPF*pm*[a, c]	Phase displacement power factor, Phase *p*, Terminal *m*		18
3DPF*m*[a]	Three-phase displacement power factor, Terminal *m*		6

Table 12.2 Analog Quantities Sorted by Function (Sheet 8 of 13)

Analog Labels	Analog Quantity Description	Units	Number of Analogs
DPF*pqp*[c, e]	Phase displacement power factor, Phase *p*, comb. Terminals *qp*		12
3DPF*qp*[e]	Three-phase displacement power factor, comb. Terminals *qp*		4
Zone 1 Differential Quantities			
IOP*p*[c]	Zone 1 instantaneous operating current, Phase *p*	pu	3
IRT*p*[c]	Zone 1 instantaneous restraint current, Phase *p*	pu	3
IRTFK*p*[c]	Zone 1 biased instantaneous-restraint current, Phase *p*	pu	3
IRTHR*p*[c]	Zone 1 instantaneous harmonic-restraint current, Phase *p*	pu	3
I*p*M2[c]	Zone 1 differential second-harmonic current content of operating current, Phase *p*	pu	3
I*p*M4[c]	Zone 1 differential fourth-harmonic current content of operating current, Phase *p*	pu	3
I*p*M5[c]	Zone 1 differential fifth-harmonic current content of operating current, Phase *p*	pu	3
IOP87Q	Zone 1 negative-sequence operating current	pu	1
IRT87Q	Zone 1 negative-sequence restraint current	pu	1
87IOP*p*C[c]	Zone 1 1-cycle average differential element operating current	pu	3
87IRT*p*C[c]	Zone 1 1-cycle average differential element restraint current	pu	3
Zone 2 Differential Quantities			
IOP*p*2[c]	Zone 2 instantaneous operating current, Phase *p*	pu	3
IRT*p*2[c]	Zone 2 instantaneous restraint current, Phase *p*	pu	3
IRTFK*p*2[c]	Zone 2 biased instantaneous-restraint current, Phase *p*	pu	3
IRTHR*p*2[c]	Zone 2 instantaneous harmonic-restraint current, Phase *p*	pu	3
Demand Metering Analogs			
DM01–DM10	Demand metering value	A (secondary)	10
DMM01–DMM10	Demand metering maximum value	A (secondary)	10
Energy Metering Analogs			
3P*m*MWhp[a]	Three-phase active energy exported, Terminal *m*	MWh (primary)	6
3Q*m*MVhp[a]	Three-phase reactive energy exported, Terminal *m*	MVARh (primary)	6
3P*m*MWhn[a]	Three-phase active energy imported, Terminal *m*	MWh (primary)	6
3Q*m*MVhn[a]	Three-phase reactive energy imported, Terminal *m*	MVARh (primary)	6
3P*m*MWhT[a]	Total three-phase active energy, Terminal *m*	MWh (primary)	6
3Q*m*MVhT[a]	Total three-phase reactive energy, Terminal *m*	MVARh (primary)	6
3P*qp*Whp[e]	Three-phase active energy exported, comb. Terminals *qp*	MWh (primary)	4
3Q*qp*Vhp[e]	Three-phase reactive energy exported, comb. Terminals *qp*	MVARh (primary)	4
3P*qp*Whn[e]	Three-phase active energy imported, comb. Terminals *qp*	MWh (primary)	4
3Q*qp*Vhn[e]	Three-phase reactive energy imported, comb. Terminals *qp*	MVARh (primary)	4
3P*qp*WhT[e]	Total three-phase active energy, comb. Terminals *qp*	MWh (primary)	4
3Q*qp*VhT[e]	Total three-phase reactive energy, comb. Terminals *qp*	MVARh (primary)	4
Restricted Earth Fault Analogs			
REFTQ1–REFTQ3	Restricted earth fault Element 1–3 torque quantity	A (secondary)	3

Table 12.2 Analog Quantities Sorted by Function (Sheet 9 of 13)

Analog Labels	Analog Quantity Description	Units	Number of Analogs
Volts/Hertz Analog			
24RPU	Volts/hertz ratio	%	1
Current Unbalance Analogs			
46*pm*[a, c]	Current unbalance Phase *p*, Terminal *m*	%	18
Breaker Monitoring Analogs			
B*m*ATRI*p*[a, c]	Breaker *m* accumulated trip current for Phase *p*	A (primary)	18
B*m*BCWP*p*[a, c]	Breaker *m* breaker contact wear for Pole *p*	%	18
B*m*EOTC*p*[a, c]	Breaker *m* average electrical operating time (close for Phase *p*)	ms	18
B*m*EOTT*p*[a, c]	Breaker *m* average electrical operating time (trip for Phase *p*)	ms	18
B*m*LEOC*p*[a, c]	Breaker *m* last electrical operating time (close for Phase *p*)	ms	18
B*m*LEOT*p*[a, c]	Breaker *m* last electrical operating time (trip for Phase *p*)	ms	18
B*m*LMOTC[a]	Breaker *m* last mechanical operating time (close for Phase *p*)	ms	6
B*m*LMOTT[a]	Breaker *m* last mechanical operating time (trip for Phase *p*)	ms	6
B*m*LTRI*p*[a, c]	Breaker m last interrupted trip current for Phase *p*	%	18
B*m*MOTC[a]	Breaker *m* average mechanical operating time (close)	ms	6
B*m*MOTT[a]	Breaker *m* average mechanical operating time (trip)	ms	6
B*m*OPCN[a]	Breaker *m* number of operations (trip)		6
Thermal Monitor Analogs			
T1LOAD–T3LOAD	Percentage of full-load, Transformer 1–3	%	3
T1OILC–T3OILC	Calculated transformer top-oil temperature, Transformer 1–3	ºC	3
MAMBT	Measured ambient temperature	ºC	1
MTOIL1–MTOIL3	Measured top-oil temperature, Transformer 1–3	ºC	3
T1HS–T3HS	Calculated hot-spot temperature, Transformer 1–3	ºC	3
T1FAA–T3FAA	Insulation aging acceleration factor, Transformer 1–3		3
T1RLOL–T3RLOL	Rate of loss-of-life, Transformer 1–3	%	3
T1TLOL–T3TLOL	Total loss-of-life, Transformer 1–3	%	3
T1TLL–T3TLL	Time to total loss-of-life alarm, Transformer 1–3	hr	3
RTD01TV–RTD12TV	RTD01–RTD12 temperature value	ºC	12
TEC1–TEC3	Thermal element condition, Transformer 1–3		3
Protection Frequency			
FREQ	Tracking frequency	Hz	1
FREQP	Frequency for over- and underfrequency elements	Hz	1
DFDTP	Rate-of-change of frequency	Hz/s	1
Station DC Monitoring Analogs			
VDC	Station battery dc voltage	V	1
DCPO	Average positive-to-ground dc voltage	V	1
DCNE	Average negative-to-ground dc voltage	V	1
DCRI	AC ripple of dc voltage	V	1
DCMIN	Minimum dc voltage	V	1
DCMAX	Maximum dc voltage	V	1

Table 12.2 Analog Quantities Sorted by Function (Sheet 10 of 13)

Analog Labels	Analog Quantity Description	Units	Number of Analogs
HSR Analogs			
HSRSRTP	Round-trip time for HSR supervision frames on process bus	µs	1
HSRSRTS	Round-trip time for HSR supervision frames on station bus	µs	1
MIRRORED BITS Analogs			
MB1A–MB7A	A Channel received MIRRORED BITS analog values		7
MB1B–MB7B	B Channel received MIRRORED BITS analog values		7
SELOGIC Analogs			
PMV01–PMV64	Protection SELOGIC math variable		64
PCT01PU–PCT32PU	Protection SELOGIC conditioning timer pickup time	cycles	32
PCT01DO–PCT32DO	Protection SELOGIC conditioning timer dropout time	cycles	32
PST01ET–PST32ET	Protection SELOGIC sequencing timer elapsed time	cycles	32
PST01PT–PST32PT	Protection SELOGIC sequencing timer preset time	cycles	32
PCN01CV–PCN32CV	Protection SELOGIC counter current value		32
PCN01PV–PCN32PV	Protection SELOGIC counter preset value		32
AMV001–AMV256	Automation SELOGIC math variable		256
ACT01DO–ACT48DO	Automation conditioning timer dropout time	s	48
ACT01PU–ACT48PU	Automation conditioning timer pickup time	s	48
AST01ET–AST48ET	Automation SELOGIC sequencing timer elapsed time	s	48
AST01PT–AST48PT	Automation SELOGIC sequencing timer preset time	s	48
ACN01CV–ACN32CV	Automation SELOGIC counter current value		32
ACN01PV–ACN32PV	Automation SELOGIC counter preset value		32
Group Switch			
ACTGRP	Active group setting		1
Time and Date Management (UTC and Local Time)			
TODMS	UTC time of day in milliseconds (0–86400000)	ms	1
THR	UTC time, hour (0–23)	hr	1
TMIN	UTC time, minute (0–59)	min	1
TSEC	UTC time, seconds (0–59)	s	1
TMSEC	UTC time, milliseconds (0–999)	ms	1
TNSEC	UTC time, nanoseconds (0–999999)	ns	1
DDOW	UTC date, day of the week (1–SU, ... , 7–SA)		1
DDOM	UTC date, day of the month (1–31)	day	1
DDOY	UTC date, day of the year (1–366)	day	1
DMON	UTC date, month (1–12)	month	1
DYEAR	UTC date, year (2000–2200)	year	1
TLODMS	Local time of day in milliseconds (0–86400000)	ms	1
TLHR	Local time, hour (0–23)	hr	1
TLMIN	Local time, minute (0–59)	min	1
TLSEC	Local time, seconds (0–59)	s	1
TLMSEC	Local time, milliseconds (0–999)	ms	1

Table 12.2 Analog Quantities Sorted by Function (Sheet 11 of 13)

Analog Labels	Analog Quantity Description	Units	Number of Analogs
TLNSEC	Local time, nanoseconds (0–999999)	ns	1
DLDOW	Local date, day of the week (1-SU, ... , 7-SA)		1
DLDOM	Local date, day of the month (1–31)	day	1
DLDOY	Local date, day of the year (1–366)	day	1
DLMON	Local date, month (1–12)	month	1
DLYEAR	Local date, year (2000–2200)	year	1
High-Priority Time Analogs			
TUTC	Offset from local time to UTC time	hr	1
TQUAL	Worst-case clock time error of the selected high-priority time source	s	1
NEW_SRC	Selected high-priority time source		1
CUR_SRC	Current high-priority time source		1
SQUAL	Synchronization accuracy of the selected high-priority time source		1
BNCDSJI	BNC port 100PPS data stream jitter		1
BNCOTJS	Slow coverage BNC port ON TIME marker jitter, fine accuracy	µs	1
BNCOTJF	Fast coverage BNC port ON TIME marker jitter, coarse accuracy	µs	1
BNCTBTW	Time between BNC 100PPS pulses	µs	1
SERDSJI	Serial port 100PPS data stream jitter	µs	1
SEROTJS	Slow converging serial port ON TIME marker jitter, fine accuracy	µs	1
SEROTJF	Fast converging serial port ON TIME marker jitter, coarse accuracy	µs	1
SERTBTW	Time between serial 100PPS pulses	µs	1
Remote Analogs			
RA001–RA256	Remote analogs		256
RAO01–RAO64	Remote analog output		64
Relay Temperature			
RLYTEMP	Relay temperature (temperature of the box)	°C	1
Total Harmonic Distortion			
V*pk*THD[b, c]	THD voltage calculation, Phase *p*, Terminal *k*		6
Time-Overcurrent Analogs			
51P01–51P20	51 Element 1–20 pickup value	A (secondary)	20
51TD01–51TD20	51 Element 1–20 time-dial setting	A (secondary)	20
Terminal Harmonic Blocking Analogs			
I*pm*M2[a, c]	Second-harmonic content of Terminal *m* current, Phase *p*	A (secondary)	18
I*pqp*M2[c, e]	Second-harmonic content of Terminal *qp* current, Phase *p*	A (secondary)	12
IEC Thermal Elements			
THRL1–THRL3	Thermal element measurement, Levels 1–3	Per unit (pu)	3
THTRIP1–THTRIP3	Thermal element remaining time before trip, Levels 1–3	s	10
THTCU1–THTCU3	Thermal element capacity used, Levels 1–3	%	10
25 Synchronism Check Element Analogs			
25VP*m*FM	25 Synchronism-check polarizing voltage magnitude for Breaker *m*	V (secondary)	6
25VPFM	25 Synchronism-check polarizing voltage magnitude	V (secondary)	1

Table 12.2 Analog Quantities Sorted by Function (Sheet 12 of 13)

Analog Labels	Analog Quantity Description	Units	Number of Analogs
25VP*m*FA	25 Synchronism-check polarizing voltage angle for Breaker *m*	V (secondary)	6
25VPFA	25 Synchronism-check polarizing voltage angle	° (±180°)	1
25VS*m*FM[a]	25 Synchronism-check synchronizing voltage magnitude for Breaker *m*	V (secondary)	6
25VS*m*FA[a]	25 Synchronism-check synchronizing voltage angle for Breaker *m*	° (±180°)	6
25ANG*m*[a]	25 Synchronism-check angle difference for Breaker *m*	° (±180°)	6
25ANGC*m*[a]	25 Synchronism-check compensated angle difference for Breaker *m*	° (±180°)	6
25SLIP*m*[a]	25 Synchronism-check slip frequency for Breaker *m*	Hz	6
IEEE 1588 PTP Status			
PTPDSJI	PTP 100PPS data stream jitter in µs	µs	1
PTPMCC	PTP master clock class enumerated value	N/A	1
PTPOTJS	Slow converging PTP ON TIME marker jitter in µs, fine accuracy	µs	1
PTPOTJF	Fast converging PTP ON TIME marker jitter in µs, coarse accuracy	µs	1
PTPOFST	Raw clock offset between PTP master and relay time	ns	1
PTPPORT	Active PTP port number	N/A	1
PTPTBTW	Time between PTP 100PPS pulses in µs	µs	1
PTPSTEN	PTP Port State enumerated value		1
Sampled Values (SV) Analogs			
I850MOD	IEC 61850 Mode/Behavior status	N/A	
SMPSYNC	Locally derived SmpSynch value	N/A	
SV01SNC–SV07SNC	Incoming SmpSynch value per subscribed SV stream	N/A	
SVND01–SVND07	Network delay for the subscribed SV stream	ms	
Line Source Selection			
Z1ML1	Positive-sequence impedance magnitude, Line 1	Ω (secondary)	1
Z1AL1	Positive-sequence impedance angle, Line 1	° (±180°)	1
Line Harmonic Blocking Analogs			
I*p*M2L1[c]	Second-harmonic current content of Line 1 current, Phase *p*	A (secondary)	3
I*p*M4L1[c]	Fourth-harmonic current content of Line 1 current, Phase *p*	A (secondary)	3
I*p*M5L1[c]	Fifth-harmonic current content of Line 1 current, Phase *p*	A (secondary)	3
Mho Impedance Calculations			
M*pp*L1C[d]	Mho phase impedance calculation Phases *pp*, Line 1	Ω (secondary)	3
M*p*G1L1C[c]	Mho Z1 ground impedance calculation Phase *p*, Line 1	Ω (secondary)	3
M*p*G2L1C[c]	Mho Z2 ground impedance calculation Phase *p*, Line 1	Ω (secondary)	3
M*p*G3L1C[c]	Mho Z3 ground impedance calculation Phase *p*, Line 1	Ω (secondary)	3
M*p*G4L1C[c]	Mho Z4 ground impedance calculation Phase *p*, Line 1	Ω (secondary)	3
Quad Resistance and Reactance Calculations			
X*pp*L1C[d]	Quad phase reactance calculation Phases *pp*, Line 1	Ω (secondary)	3
R*pp*L1C[d]	Quad phase right resistance calculation Phases *pp*, Line 1	Ω (secondary)	3
X*p*G1L1C[c]	Quad Z1 ground reactance calculation Phase *p*, Line 1	Ω (secondary)	3
X*p*G2L1C[c]	Quad Z2 ground reactance calculation Phase *p*, Line 1	Ω (secondary)	3
X*p*G3L1C[c]	Quad Z3 ground reactance calculation Phase *p*, Line 1	Ω (secondary)	3

Table 12.2 Analog Quantities Sorted by Function (Sheet 13 of 13)

Analog Labels	Analog Quantity Description	Units	Number of Analogs
X*p*G4L1C[c]	Quad Z4 ground reactance calculation Phase *p*, Line 1	Ω (secondary)	3
R*p*G1L1C[c]	Quad Z1 ground right resistance calculation Phase *p*, Line 1	Ω (secondary)	3
R*p*G2L1C[c]	Quad Z2 ground right resistance calculation Phase *p*, Line 1	Ω (secondary)	3
R*p*G3L1C[c]	Quad Z3 ground right resistance calculation Phase *p*, Line 1	Ω (secondary)	3
R*p*G4L1C[c]	Quad Z4 ground right resistance calculation Phase *p*, Line 1	Ω (secondary)	3
Reclosing Analogs			
79SH*m*[a]	Present value of shot counter for Breaker *m*		6
79SH*m*_1[a]	Total number of first shot reclosers for Breaker *m*		6
79SH*m*_2[a]	Total number of second shot reclosers for Breaker *m*		6
79SH*m*_3[a]	Total number of third shot reclosers for Breaker *m*		6
79SH*m*_4[a]	Total number of fourth shot reclosers for Breaker *m*		6
79SH*m*_T[a]	Total number of reclosers for Breaker *m*		6

[a] m = S, T, U, W, X, Y.
[b] k = V, Z.
[c] p = A, B, C.
[d] pp = AB, BC, CA.
[e] qp = ST, TU, UW, WX.
[f] n = 1, 2, 3, 4 (combined terminals: 1 = ST, 2 = TU, 3 = UW, 4 = WX).

This page intentionally left blank

APPENDIX A

Firmware, ICD File, and Manual Versions

Firmware

Determining the Firmware Version

To determine the firmware version, view the status report by using the serial port **ID** command or the front-panel **LCD View Configuration** menu option. The status report displays the Firmware Identification (FID) number.

The firmware version will be either a standard release or a point release. A standard release adds new functionality to the firmware beyond the specifications of the existing version. A point release is reserved for modifying firmware functionality to conform to the specifications of the existing version.

A standard release is identified by a change in the R-number of the device FID number.

Existing firmware:

FID=SEL-487E-5-**R100**-V0-Z001001-Dxxxxxxxx

Standard release firmware:

FID=SEL-487E-5-**R101**-V0-Z001001-Dxxxxxxxx

A point release is identified by a change in the V-number of the device FID number.

Existing firmware:

FID=SEL-487E-5-R100-**V0**-Z001001-Dxxxxxxxx

Point release firmware:

FID=SEL-487E-5-R100-**V1**-Z001001-Dxxxxxxxx

The firmware version number is after the R, and the date code is after the D. For example, the following is firmware version number R400, date code September 10, 2018.

FID=SEL-487E-5-R400-V0-Z200200-D20180910

Similarly, the device SELBOOT firmware version (BFID) will be reported as:

BFID=SLBT-4XX-Rxx-Vx-Zxxxxxx-Dxxxxxxxx

Revision History

Table A.1 lists the firmware versions, revision descriptions, and corresponding instruction manual date codes. The most recent firmware version is listed first.

Starting with revisions published after March 1, 2022, changes that address security vulnerabilities are marked with “[Cybersecurity]”. Other improvements to cybersecurity functionality that should be evaluated for potential cybersecurity importance are marked with “[Cybersecurity Enhancement]”.

Table A.1 Firmware Revision History (Sheet 1 of 9)

Firmware Identification (FID) Number	Summary of Revisions	Manual Date Code
SEL-487E-5-R408-V0-Z207203-D20250214	➤ Resolved an issue where the relay may not synchronize to a PTP time source when NETMODE = ISOLATEIP and PTPTR = LAYER2. This issue is only applicable if the relay receives PTP messages on the non-designated IP port. ➤ Added Group setting EATAP2 to allow manual or automatic calculation of TAP*m*2 in A secondary (where *m* = S, T, U, W, X, Y). ➤ Increased the number of available Protection SELOGIC variables to 96. ➤ Increased the number of available Automation SELOGIC sequencing timers to 48. ➤ Increased the number of available display points to 256. ➤ Increased the number of available Automation SELOGIC latches to 80. ➤ Resolved an issue that prevented large negative energy values from being displayed on the front-panel energy metering screen or in the **MET E** command response. ➤ Resolved an issue where the energy values of terminals Y, ST, TU, UW, and WX were not displayed correctly on the front-panel energy metering screen. ➤ Updated IEC 61850 protocol implementation to IEC 61850 Edition 2.1. ➤ Added the IEC 61850 quantity RECST*m* to indicate the autoreclose state as defined by the AutoRecSt data object in IEC 61850-7-4 (where *m* = S, T, U, W, X, Y). ➤ Added the IEC 61850 quantity F79SH*m*. This quantity is functionally equivalent to 79SH*m* and is updated once per power system cycle (where *m* = S, T, U, W, X, Y). ➤ Added support for deadband configuration, including the dbRef, dbAngRef, zeroDbRef, and zeroDb attributes, according to IEC 61850-7-3 Edition 2.1. ➤ Added support for indexed buffered and unbuffered MMS reports. ➤ Added support to allow the sAddr attribute to replace the esel:datasrc attribute in ICD files to improve compatibility with third-party system configuration tools. ➤ Added support for the remote bit pulse configuration according to IEC 61850-7-3. ➤ Modified the firmware to update the settings group control block (SGCB) and the LTRK logical node's last activation time-stamp attribute for Group settings switches that were not initiated by MMS and for changes to the active Group settings. ➤ Improved support for IEC 61850 Edition 1 MMS clients. ➤ Modified the firmware to allow the relay to accept GOOSE data with invalid or questionable validity. ➤ Modified the firmware to allow the GOOSE quality attribute to map to a remote analog. Additionally, the processed quality indicator now can be mapped to a virtual bit. ➤ Modified the firmware to accept retransmitted GOOSE messages with the test flag set to TRUE when the relay transitions into Test Mode. ➤ Modified the firmware to provide the IEC 61850 library version (LIB61850ID) to the LPHD logical node. ➤ Modified the IEC 61850 hierarchical relationship for the XCBR.Loc and XSWI.Loc data objects to exclude their inheritance from LLN0.Loc and CSWI.Loc.	20250214

Table A.1 Firmware Revision History (Sheet 2 of 9)

Firmware Identification (FID) Number	Summary of Revisions	Manual Date Code
	➤ Enhanced support for the IEC 61850 logical device hierarchy, which enables additional levels of inheritance. This includes support for the Loc and LocSta data objects. ➤ Resolved an issue where the relay would set the validity attribute to invalid in GOOSE messages when resuming publications from Off to On mode. This is only applicable when EOFFMTX = N and the relay receives a CID file while in Off mode.	
SEL-487E-5-R407-V0-Z206203-D20241022	➤ Added the High-Availability Seamless Redundancy (HSR) protocol feature to the five-port Ethernet card. ➤ Added the 1000BASE-X auto-negotiation feature to the five-port Ethernet card. ➤ Added the IEC 61850-9-2LE Sampled Values (SV) publication capability as an ordering option. This option includes support for the INT2, INT4, INTD, INT7, and INT8 I/O interface boards. ➤ Added support for the INTD I/O interface board for TiDL and SV subscriber models. ➤ Added second-harmonic blocking logic for all current terminals. This feature is included as a relay ordering option. ➤ Added Group setting ALTV*m* (where *m* = S, T, U, W, X, Y) to allow dynamic voltage source selection for each current terminal. ➤ Increased the number of available remote bits to 96. ➤ Resolved an issue where the fundamental metering response incorrectly displayed primary currents in delta-connected CTs applications. ➤ Added Port 5 setting BUSMODE for TiDL models to allow merged mode when using the five-port Ethernet card. ➤ Improved memory voltage performance during voltage inversion when ESCMPL1 = Y. ➤ Modified the firmware to allow different CT ratios for combined terminal applications.	20241022
SEL-487E-5-R406-V0-Z205202-D20240509	➤ [Cybersecurity] Resolved an issue where a maliciously crafted web request sent to the relay from an unauthenticated user could cause a diagnostic restart. By design, three diagnostic restarts within 7 days cause the relay to disable. This issue can only be triggered when the Port 5 setting EHTTP is configured to Y. ➤ Resolved an issue where the relay could indicate an incorrect time-synchronization status when the relay was transitioning between two Grandmaster clock sources and the active clock source was no longer available. This does not apply when both clocks are globally time-synchronized.	20240509
SEL-487E-5-R405-V1-Z205202-D20240416	Includes all the functions of SEL-487E-5-R405-V0-Z205202-D20231207 with the following addition: ➤ Resolved an issue where the Zone 2 differential element was incorrectly supervised with the Zone 1 differential element blocking bit 87BK.	20240416
SEL-487E-5-R405-V0-Z205202-D20231207	➤ Added a second differential element. This feature is included as a relay ordering option. ➤ Added three-pole autoreclose functionality. This feature is included as a relay ordering option. ➤ Added the capability to configure Terminal Y as a single- or three-phase current input. This enhancement is available on model options with matching Terminal Y (IY1, IY2, and IY3) nominal current ratings. ➤ Added support for a sixth circuit breaker, Breaker Y.	20231207

Table A.1 Firmware Revision History (Sheet 3 of 9)

Firmware Identification (FID) Number	Summary of Revisions	Manual Date Code
	➤ Enhanced the capability of the differential element by supporting as many as six three-phase current terminals. ➤ Added the advanced Group setting 32GVS*m* (where *m* = S, T, U, W, X, Y, 1, 2, 3, 4, L1) to allow users to configure the voltage supervision threshold used in zero-sequence directional elements. ➤ Added the Group SELOGIC setting EXBFSP*m* (where *m* = S, T, U, W, X, Y) for additional breaker failure supervision. ➤ Added Y to the range of Group setting ELOP. This allows forward-looking directional overcurrent elements to effectively become nondirectional during an LOP condition. ➤ Modified the Relay Word bit row numbers of the disconnect status and control bits. This impacts Fast Meter addressing in SEL-2030 and SEL-2032 SELOGIC control equations that use Relay Word bits in any row after 122. ➤ Modified the Fast Operate control bits for Breaker Y. This impacts breaker bit addressing for Fast Operate Messages in SEL RTAC, SEL-2030, and SEL-2032 communication processors. ➤ Replaced the Group settings PTCOMPV and PTCOMPZ with CTCOMP*m* (where *m* = S, T, U, W, X, Y) to allow an independent CT connection type on each current terminal. ➤ Improved the accuracy of power analog quantities for applications that use delta-connected CTs. ➤ Modified the firmware to remove zero-sequence analog quantities from setting ranges for applications that use delta-connected CTs or PTs. ➤ Modified the firmware to increase the security of the phase directional overcurrent elements when setting ESERCMP = Y. ➤ Improved the speed of directional elements by 1/4 cycle. ➤ Modified the DNP quantity FTYPE and the IEC 61850 quantity FLTCAUS to report Zone 1 differential trip, Zone 2 differential trip, and restricted earth fault trip. ➤ Modified the firmware to allow overcurrent element Levels 1–3 to be set independently. Previously, these had to be configured sequentially. ➤ Increased the upper range value of the thermal trip limit for the IEC 60255-149 thermal elements from 100% to 150%. ➤ Modified the default value of the settings O87P and SLP1 to 0.3 and 0.15, respectively. ➤ Modified the default value of the settings TR*m* and CL*m* to include the OC*m* and CC*m* Relay Word bits, respectively (where *m* = S, T, U, W, X). ➤ Modified the default value of the settings ESERDEL, SRDLCNT, and SRDLTIM to Y, 10, and 0.5, respectively. ➤ Modified the default value of the setting ERDIG from S to A. ➤ Increased the number of available Automation SELOGIC conditioning timers to 48. ➤ Increased the number of available Automation SELOGIC latch bits to 64. ➤ Increased the number of available local bits to 96. ➤ Increased the number of available inverse-time overcurrent elements to 20. ➤ Added support for the TiDL communications board with SFP ports, which replaces the TiDL communications board with fixed fiber ports.	

Table A.1 Firmware Revision History (Sheet 4 of 9)

Firmware Identification (FID) Number	Summary of Revisions	Manual Date Code
	➤ Modified the **STA T** and **STA A** command responses to include information related to the TiDL communications board with SFP ports. ➤ Resolved an issue where MMS time stamps do not match the SER time stamps for Relay Word bit state changes during a settings or IEC 61850 Mode/Behavior change. ➤ Resolved an issue where a change of an stSeld (status selector) attribute may not generate an MMS buffered or unbuffered report. ➤ Enhanced the SER to automatically include an entry when entering or exiting IEC 61850 Simulation Mode. ➤ Resolved an issue where the relay may not synchronize to a PTP time source on one of the ports when NETMODE = PRP when using the four port Ethernet card. Only firmware version R404 is affected. ➤ Added support for MMS buffered and unbuffered report reservation. ➤ Resolved an issue where the Leap Second Occurred and Leap Second Direction time quality flags could be set incorrectly in the IEEE C37.118 synchrophasor configuration and data frames. This issue is only applicable when the relay is connected to an IRIG clock source. ➤ Modified the firmware to report the data valid flag in the STAT field of the synchrophasor data frame as invalid when the SV publisher or SV subscriber is not globally time-synchronized. ➤ Modified the firmware to report zero for the Time Quality indicator code in the IEEE C37.111-2013 COMTRADE configuration file when the relay is connected to a PTP clock that is locked to a satellite-synchronized clock source.	
SEL-487E-5-R404-V2-Z204201-D20231110	Includes all the functions of SEL-487E-5-R404-V1-Z204201-D20230830 with the following addition: ➤ [Cybersecurity] Resolved an issue where MMS file transfers will cause the relay to disable. Only firmware version R404-V1 is affected.	20231110
SEL-487E-5-R404-V1-Z204201-D20230830	Includes all the functions of SEL-487E-5-R404-V0-Z204201-D20230317 with the following additions: ➤ [Cybersecurity] Improved web server security against session hijacking. ➤ [Cybersecurity] Improved web server security against intentionally large files causing denial of service. ➤ [Cybersecurity] Improved web server security against cross-site scripting and misuse of session tokens. ➤ [Cybersecurity] Resolved a rare issue where continuous event report polling requests from a communication processor can cause the relay to become unresponsive. ➤ Improved the firmware so that access levels defined by the MAXACC setting apply correctly for MMS setting file transfers. Previously, MMS file transfer access was controlled only by MMS authentication. ➤ Improved the performance of protection and automation latch bits during diagnostic restart. ➤ Resolved a rare issue that could prevent the relay from restarting after a diagnostic failure.	20230830
SEL-487E-5-R404-V0-Z204201-D20230317 **NOTE:** SELBOOT R302 or later is required for this and all new firmware versions. This provides the capability to convert to the five-port Ethernet card.	➤ Added support for the five-port Ethernet card. This card provides Parallel Redundancy Protocol (PRP) for both process bus and station bus, a dedicated Ethernet port for engineering access, and greater flexibility in configuring IEC 61850 solutions. ➤ Added the **COM PRP** command for the five-port Ethernet card. Modified the **COM PTP**, **ETH**, **GOO**, **MAC**, **STA**, and **VER** commands to include information related to the five-port Ethernet card.	20230317

Table A.1 Firmware Revision History (Sheet 5 of 9)

Firmware Identification (FID) Number	Summary of Revisions	Manual Date Code
	➤ Modified the synchronization status values reported in IEC 61850 LTMS.TmSyn.stVal to accurately reflect the definitions in IEC 61850-9-2. ➤ Modified firmware to improve the IEC 61850 time accuracy value LTMS.TmAcc.stVal. ➤ Resolved an issue where IEC 61850 simulation mode is not retained following a relay power cycle. This is applicable when simulation mode is entered using IEC 61850 MMS. ➤ Resolved an issue where the relay could become unresponsive after an Ethernet card hardware failure. ➤ Resolved a file transfer issue that could result in a loss of SEL Fast Message communications. ➤ Resolved a PTP issue where the TGLOBAL Relay Word bit could incorrectly assert during the transition from a local to global time source.	
SEL-487E-5-R403-V0-Z203201-D20220517	➤ [Cybersecurity] Resolved a rare, low-risk issue where deliberately crafted Ethernet traffic could cause the relay to perform a diagnostic restart. ➤ [Cybersecurity] Updated a third-party networking software component, which removes low-risk security vulnerabilities that could result in temporary loss of Ethernet communications. ➤ Added support for PTP Power Utility Automation profile (IEC/IEEE 61850-9-3). ➤ Modified the firmware to remove the 1 μs accuracy requirements to assert Relay Word bit TLOCAL. This allows SV protection to remain operational when Global time synchronization is lost. ➤ Modified the firmware to allow for seamless transition from TGLOBAL to TLOCAL. ➤ Added IEC 61850 and PTP settings to COMTRADE event reports. ➤ Resolved an issue where PTP time synchronization could be lost in PRP network applications. ➤ Added voltage THD analog quantities. ➤ Modified the firmware to address SER time-stamping accuracy and IEC 61850 mode control change following a power cycle. ➤ Modified the firmware to ensure combination terminals have matching CT ratios when used for line protection. ➤ Modified the firmware to address an issue where the Simulation mode status SimSt.stVal for the LSVS and LGOS logical nodes does not transition from TRUE to FALSE for a change in the LPHD logical node Sim.stVal.	20220523
SEL-487E-5-R402-V0-Z202201-D20211217	➤ Added mho and quadrilateral distance elements with integrated CVT transient detection, out-of-step blocking, load-encroachment, switch-onto-fault, and harmonic-blocking logic. These features are included as a relay ordering option. ➤ Added the option to either include or remove zero-sequence current for differential compensation Matrices 2, 4, 6, 8, and 10 using Group settings T*m*ZSR (where *m* = S, T, U, W, X). ➤ Added Group setting ELOP to control loss-of-potential (LOP) supervision. ➤ Modified the DIRBLK*m* default settings to 87XBK2 OR 87XBK5 (where *m* = S, T, U, W, X, 1, 2, 3, 4). ➤ Added the **MET SEC A** command to display all secondary terminal quantities.	20211217

Table A.1 Firmware Revision History (Sheet 6 of 9)

Firmware Identification (FID) Number	Summary of Revisions	Manual Date Code
	➤ Modified firmware to support IEC 61850-9-2 neutral current and neutral voltage subscriptions. ➤ Added memorized positive-sequence polarization voltage to filtered event reports. ➤ Added IEC 61850 control interlocking functionality via CILO logical nodes. ➤ Added the blocked-by-interlocking AddCause to the control error response when an operation fails due to a control interlocking (CILO) check. ➤ Added differential compensation Matrix 13. Matrix 13 allows for user-specified compensation angles with the option to include or remove zero-sequence current. ➤ Modified the voltage supervision threshold for zero-sequence directional elements. ➤ Increased the upper range limit of the dc monitor setting DCGF from 2 to 5. ➤ Improved dc monitor ground detection accuracy. ➤ Modified the default settings for 50FP*m*, 50RP*m*, Z2F*m*, Z2R, Z0F*m*, and Z0R*m* (where *m* = S, T, U, W, X, 1, 2, 3, 4). ➤ Added logic to increase the security of the bipolar low-set unblocking logic during transformer energization. ➤ Added the **MET DIF A** command. This command response provides enhanced differential current metering. ➤ Modified the dropout delay for the percentage-restrained differential element adaptive security timer. ➤ Increased the allowable TAPMAX/TAPMIN ratio when using 1 A and 5 A nominal CTs. ➤ Enhanced the REF element internal fault coverage for applications that use neutral-grounding resistors. ➤ Modified firmware to restrict the range of Group settings REFRF1, REFRF2, and REFRF3 to only include terminals with wye-connected current transformer connection. ➤ Enhanced the internal fault detection logic associated with the differential element. ➤ Added the following breaker monitor analog quantities: accumulated trip current, last interrupted current, operating times, and number of operations. ➤ Added settings EACC, E2AC, and EPAC to support port access control by using SELOGIC control equations. ➤ Increased the resolution of Group settings VNOMV and VNOMZ. ➤ Modified firmware to ensure user-defined V/Hz settings are entered in increasing order. ➤ Improved Automation SELOGIC timer accuracy. Automation SELOGIC timer accuracy is now within ± 1% or ± 1 s for values up to 1 month. ➤ Improved CT unsaturate logic for systems with extremely high X/R ratios. ➤ Modified firmware to allow Automation SELOGIC conditioning timer pickup and dropout setting values be assigned to a display point.	

Table A.1 Firmware Revision History (Sheet 7 of 9)

Firmware Identification (FID) Number	Summary of Revisions	Manual Date Code
	➤ Enhanced **STA A** and **CST** command responses to include high-accuracy PTP time status. ➤ Modified firmware by adding warm start (settings change, group switch) ride-through capability for control inputs. In this release, previously asserted control inputs do not change state during warm start. ➤ Resolved a rare issue where the SELBOOT checksum could be reported incorrectly in the **VER** command response. ➤ Reduced maximum relay automatic diagnostic restart response time. ➤ Resolved an issue where uncommon and repetitive command line operations can cause a relay restart when the IEC 61850 GOOSE function is enabled. ➤ Enhanced the relay's logic to use both the BMCA algorithm and the network time-inaccuracy check-in power profile to choose the best Grandmaster clock on a PRP network.	
SEL-487E-5-R401-V1-Z201201-D20211203	Includes all the functions of SEL-487E-5-R401-V0-Z201201-D20210209 with the following additions: ➤ Resolved an issue where an MMS client may report the relay as offline when multiple MMS clients are simultaneously accessing reports. ➤ Resolved an issue where an MMS client may not be able to retrieve file attributes associated with IEEE C37.111-2013 COMTRADE event files.	20211203
SEL-487E-5-R401-V0-Z201201-D20210209 **NOTE:** This firmware release only supports .zds digitally signed firmware files. SELBOOT R301 or newer is required for this and all new firmware versions. See Appendix B: Firmware Upgrade Instructions in the SEL-400 Series Relays Instruction Manual for more information. **NOTE:** You can only use SEL Grid Configurator for settings version Z201 and later.	➤ Added support for Time-Domain Link (TiDL) technology that uses SEL-TMU devices and provides support for multiple point-to-point connections and user-configurable topologies. ➤ Modified the **CFG CTNOM** command to use the default Global and Group settings only on a nominal secondary current configuration change. ➤ Enhanced selective protection disabling logic that results from remote data acquisition data loss. ➤ Improved received GOOSE message processing speed for relay virtual bits mapped to GOOSE Binary data. ➤ Increased the number of available display points to 192. ➤ Increased the number of available local and remote bits to 64. ➤ Increased the number of available DNP binary outputs to 160. ➤ Added IEC 61850 simulation mode indication to the **STA** and **GOO** commands. ➤ Added SELOGIC variable SC850SM to change the IEC 61850 simulation mode of the relay. ➤ Enhanced IEC 61850 processing to indicate when the invalid quality attribute is set in received GOOSE messages. ➤ Added support for the IEC 61850 Local/Remote control feature defined in the IEC 61850-7-4 standard. ➤ Modified firmware to report `SMPCNT RANGE ERR` in the **COM SV** command when the merging unit and the SV relay have mismatched nominal frequency values. ➤ Corrected an issue where the Mode, Beh, and Health quality.validity = good is not maintained when Mode = OFF. ➤ Modified firmware to enable DNP and IEC 61850 breaker control only when the circuit breaker jumper is installed. ➤ Added conditioning timers to Automation SELOGIC.	20210209

Table A.1 Firmware Revision History (Sheet 8 of 9)

Firmware Identification (FID) Number	Summary of Revisions	Manual Date Code
	➤ Improved processing consistency of breaker and disconnect control bits in Automation SELOGIC. ➤ Modified **COM SV** command to report `PDU LENGTH ERR` for an incoming message with an incorrect PDU length. ➤ Modified the synchronism-check function to allow alternate and independent polarizing sources. ➤ Modified firmware to apply DNP scaling of 100 to angles and slip frequency analog quantities related to the synchronism-check element. ➤ Added the ability to remotely upgrade relay firmware over an Ethernet network. ➤ Modified Ethernet communications to automatically correct a loss of synchronization between the communications subsystem and the other relay subsystems. ➤ Improved relay response to three consecutive failed login attempts within a one-minute interval to pulse the BADPASS and SALARM Relay Word bits for all communication interfaces. ➤ Enhanced relay self-tests to detect current or voltage magnitudes that exceed the maximum analog-to-digital converter output and perform an automatic diagnostic restart. ➤ Added support for new IEC 61850 control and settings common data classes. ➤ Enhanced FTP network security. ➤ Modified firmware to retain stored data after successful reads of SER.TXT, CSER.TXT, PRO.TXT, and CPRO.TXT over Ethernet connections. ➤ Modified firmware to support all printable ASCII characters in the password entry HMI screen. ➤ Improved synchrophasor current scaling when Phasor Numeric Representation is set to integer (PHNR = I) and large current transformer ratio (CTR) settings (CTR > 1200) are used. ➤ Modified firmware to support a default profile for Precision Time Protocol when NETMODE = PRP. ➤ Enhanced wildcard parsing used in YMODEM file transfer operations. ➤ Modified firmware to increment the state number (stNum) in GOOSE messages for any change of the quality attribute. ➤ Added breaker wear analog quantities to DNP and IEC 61850 communications. ➤ Improved error handling for Ethernet interface.	
SEL-487E-5-R400-V3-Z200200-D20201009	Includes all the functions of SEL-487E-5-R400-V2-Z200200-D20191210 with the following additions: ➤ Enhanced output contact behavior following a power cycle while the relay is in IEC 61850 “Blocked” or “Test/Blocked” operating mode. ➤ Resolved an extremely rare issue that could cause the relay to perform a diagnostic restart when configured for Parallel Redundancy Protocol (NETMODE = PRP) and the relay received abnormal Ethernet traffic.	20201009
SEL-487E-5-R400-V2-Z200200-D20191210	Includes all the functions of SEL-487E-5-R400-V1-Z200200-D20190211 with the following addition: ➤ Modified processing of pulsed Relay Word bits.	20191210

Table A.1 Firmware Revision History (Sheet 9 of 9)

Firmware Identification (FID) Number	Summary of Revisions	Manual Date Code
SEL-487E-5-R400-V1-Z200200-D20190211	Includes all the functions of SEL-487E-5-R400-V0-Z200200-D20180910 with the following additions: ➤ Resolved an issue with Relay Word bit 87T, which previously would not assert when Group setting E87Q = N. ➤ Resolved an issue with the rotating display, which previously would appear blank after accessing a one-line diagram within the HMI.	20190211
SEL-487E-5-R400-V0-Z200200-D20180910	➤ Initial version.	20180910

SELBOOT

NOTE: R2xx SELBOOT versions only support serial port firmware upgrades with .s19 or .z19 firmware upgrade files. R3xx SELBOOT versions only support .zds digitally signed firmware upgrade files over a serial or Ethernet connection. If upgrading from R2xx SELBOOT to R3xx SELBOOT, load the .s19 file. Do not load a .zds file when using R2xx SELBOOT.

SELBOOT is a firmware package inside the relay/device/computer that handles hardware initialization and provides the functions needed to support firmware upgrades. *Table A.6* lists the SELBOOT versions used with the SEL-487E-5 Relay and revision descriptions.

Table A.2 SELBOOT Revision History

SELBOOT Firmware Identification (BFID) Number	Summary of Revisions
SLBT-4XX-R302-V0-Z001002-D20230317	➤ Modified SELBOOT to support the five-port Ethernet card.
SLBT-4XX-R301-V0-Z001002-D20201204	➤ Modified SELBOOT to support digitally signed firmware on SV and TiDL devices.
SLBT-4XX-R210-V0-Z001002-D20170706	➤ Initial version.

ICD File

NOTE: There are two ICD files for the SEL-487E-5. The ICD file that starts with ICD-487E-5S is exclusively for the SEL-487E-5 SV Subscriber Relay (see Table A.4). The ICD file that starts with ICD-487E-5 is exclusively for the SEL-487E-5 TiDL Relay (see Table A.5).

NOTE: ClassFileVersion 007 supports both the four- and five-port Ethernet cards.

To find the ICD revision number in your relay/device/computer, view the configVersion by using the serial port ID command. The configVersion is the last item displayed in the information returned from the ID command.

configVersion = ICD-487E-5S-R001-V0-Z400006-D20180910

The ICD revision number is after the R (e.g., 001) and the date code is after the D. This revision number is not related to the relay/device/computer firmware revision number. The configVersion revision displays the ICD file version used to create the CID file that is loaded in the relay/device/computer.

The configVersion contains other useful information. The Z-number consists of six digits. The first three digits following the Z represent the minimum IED firmware required to be used with the ICD (e.g., 400). The second three digits represent the ICD ClassFileVersion (e.g., 006). The ClassFileVersion increments when there is a major addition or change to the IEC 61850 implementation of the relay/device/computer.

Table A.3 lists the ICD file versions for the SEL-487E-5 SV Publisher, a description of modifications, and the instruction manual date code that corresponds to the versions. The most recent version is listed first.

Table A.3 SEL-487E-5 SV Publisher ICD File Revision History

configVersion	Summary of Revisions	Minimum Relay Firmware	ClassFile Version	Manual Date Code
ICD-487E-5P-R008-V0-Z408010-D20250214	➤ IEC 61850 Edition 2.1 Conformance ➤ Modified the LPHD logical node to include the IEC 61850 library version SelLibId.val. ➤ Added support for the cmdQual, onDur, offDur, and numPls pulse configuration attributes, according to IEC 61850-7-3. ➤ Added the LocKey data object support and changed the data source mapping for Loc and LocSta. ➤ Modified the ICD file to remove control blocks and default GOOSE and report data sets. ➤ Modified the *m*79RREC logical nodes to include the trip behavior TrBeh.stVal (where *m* = S, T, U, W, X, Y). ➤ Modified the data source of *m*79RREC.AutoRecSt to be RECSTm (where *m* = S, T, U, W, X, Y). ➤ Modified the *m*79RREC logical nodes by replacing RecCyc.stVal with Rec3PhCnt.stVal (where *m* = S, T, U, W, X, Y). ➤ Added support for the valImport and valKind attributes according to IEC 61850-6 for compatibility with third-party system configuration tools. ➤ Reduced the size of all GGIO lnTypes to a maximum of 32 indices. ➤ Modified logical nodes prefixes and instances.	R408	010	20250214
ICD-487E-5P-R007-V0-Z407009-D20241022	➤ SEL-487E-5P ICD file for firmware R407 or higher.	R407	009	20241022

configVersion Details:

ICD-[PN]-R[RN]-V[VS]-Z[FC]-D[RD] where:

[PN] = Product name (e.g., 487E-5P)
[RN][a] = Revision number (e.g., 009)
[VS] = Version specifications (e.g., 0)
[FC][b] = Minimum relay firmware and class file version (e.g., 407)
[RD] = Release date code (e.g., 20241022)

[a] This is the ICD file revision number, not IED firmware revision number.
[b] FC consists of six digits. The first three following the Z represent the minimum IED firmware required to be used with the ICD (e.g., 407). The second three represent the ICD ClassFileVersion (e.g., 009).

Table A.4 lists the ICD file versions for the SEL-487E-5 SV Subscriber Relay, a description of modifications, and the instruction manual date code that corresponds to the versions. The most recent version is listed first.

Table A.4 SEL-487E-5 SV Subscriber ICD File Revision History (Sheet 1 of 4)

configVersion	Summary of Revisions	Minimum Relay/ Device/ Computer Firmware	ClassFile Version	Manual Date Code
ICD-487E-5S-R008-V0-Z408010-D20250214	➤ IEC 61850 Edition 2.1 Conformance ➤ Modified the LPHD logical node to include the IEC 61850 library version SelLibId.val. ➤ Added support for the cmdQual, onDur, off-Dur, and numPls pulse configuration attributes, according to IEC 61850-7-3. ➤ Added the LocKey data object support and changed the data source mapping for Loc and LocSta. ➤ Modified the ICD file to remove control blocks and default GOOSE and report data sets. ➤ Modified the *m*79RREC logical nodes to include the trip behavior TrBeh.stVal (where *m* = S, T, U, W, X, Y). ➤ Modified the data source of *m*79RREC.Auto-RecSt to be RECSTm (where *m* = S, T, U, W, X, Y). ➤ Modified the *m*79RREC logical nodes by replacing RecCyc.stVal with Rec3PhCnt.stVal (where *m* = S, T, U, W, X, Y). ➤ Added support for the valImport and valKind attributes according to IEC 61850-6 for compatibility with third-party system configuration tools. ➤ Reduced the size of all GGIO lnTypes to a maximum of 32 indices. ➤ Modified logical nodes prefixes and instances.	R408	010	20250214
ICD-487E-5S-R007-V0-Z407009-D20241022	➤ Added HSRGGIO logical node for HSR status indication. ➤ Added RBGGIO logical nodes for remote bits 65–96. ➤ Added HB2*m*PHAR logical nodes to support terminal harmonic blocking logic (where *m* = S, T, U, W, X, Y, ST, TU, UW, WX). ➤ Modified the labels of SV channels IY1, IY2, and IY3 to IAY, IBY, and ICY, respectively.	R407	009	20241022
ICD-487E-5S-R006-V0-Z405009-D20231207 **NOTE:** ClassFileVersion 008 did not production release.	➤ Updated IEC 61850 Edition 2 Conformance. ➤ Updated ClassFileVersion to 009. ➤ Modified LBGGIO logical node to include local bits 65–96. ➤ Modified ALTGGIO logical node to include automation SELOGIC latches 33–64. ➤ Modified the data source FLTCAUS to include restricted earth fault and Zone 2 differential trip ➤ Added support for MMS buffered and unbuffered report reservation.	R405	009	20231207

Table A.4 SEL-487E-5 SV Subscriber ICD File Revision History (Sheet 2 of 4)

configVersion	Summary of Revisions	Minimum Relay/ Device/ Computer Firmware	ClassFile Version	Manual Date Code
	➤ Added IT11PTOC–IT20PTOC logical nodes to support inverse-time overcurrent elements 11–20. ➤ Added ASVGGIO logical node to support Automation SELOGIC Variables 129–256. ➤ Added D87R2PDIF logical node to support the second differential element. ➤ Added BFRYRBR, BSYASCBR, BSYBSCBR, BSYCSCBR, TRIPYPTRC, Y52AXCBR, YBKRCILO, and YBKRCSWI logical nodes to support Breaker Y. ➤ Added YP*n*PIOC, YP*n*PTOC, YG*n*PIOC, YG*n*PTOC, YQ*n*PIOC, and YQ*n*PTOC logical nodes to support overcurrent elements on Terminal Y (where *n* = 1–3). ➤ Added METYMMXU and SEQYMSQI logical nodes to support metering quantities on Terminal Y. ➤ Added *m*79RREC logical nodes to support autoreclose functionality (where *m* = S, T, U, W, X, Y). ➤ Included the product and functional name in the CILO logical node path for SrcRef.			
ICD-487E-5S-R005-V0-Z404007-D20230317	➤ Added support for the five-port Ethernet card. Added logical nodes PRPGGIO, PBLCCH, SBLCCH, EALCCH, and an additional ETHGGIO. Added multiple access points to allow for the segregation of process bus and station bus GOOSE transmission.	R404	007	20230317
ICD-487E-5S-R004-V0-Z403006-D20220517	➤ Changed the CSWI logical node Loc.stVal data source from LOC to LOC OR LOCAL.	R403	006	20220523
ICD-487E-5S-R003-V0-Z402006-D20211217	➤ Added Z*n*L1PDIS*n*, OSB*n*L1RPSB*n*, HB24L1PHAR1, and HB5L1PHAR1 logical nodes (where *n* = 1–4). ➤ Removed HBPHAR2 and HRPHAR1 logical nodes. ➤ Added HB24PHAR1 and HB5PHAR1 logical nodes. ➤ Added CILO logical node for each switch control object. ➤ Mapped CILO logical node attributes to the blocking inputs of the CSWI logical nodes for each switch control object.	R402	006	20211217
ICD-487E-5S-R002-V0-Z401006-D20210212	➤ Added support for remote and local bits 33–64. ➤ Modified the data class from MV to CMV for phase-to-phase voltages in the MMXU logical nodes. ➤ Added FltType and FltCaus data attributes to the FLTRDRE1 logical node.	R401	006	20210209

Table A.4 SEL-487E-5 SV Subscriber ICD File Revision History (Sheet 3 of 4)

configVersion	Summary of Revisions	Minimum Relay/ Device/ Computer Firmware	ClassFile Version	Manual Date Code
	➤ Modified the data source of the DCnCSWInn.OpOpn and DCnCSWInn.OpCls to 89OPEnn and 89CLSnn, respectively. ➤ Added support for the IEC 61850 Functional Naming Feature. ➤ Added the IEC 61850 LTRK logical node for service tracking. ➤ Corrected the IEC 61850 Data Object number extensions according to the Ed 2 number usage. ➤ Voltage measurements have been separated into new MMXU logical nodes. ➤ Improved consistency in deadband units for the ICD file to use voltage in kV and power in MW. ➤ Moved IEC 61850 mode/behavior control from logical node LPHD to LLN0. ➤ Added REF50*n*PIOC, REF51*n*PTOC, D87QPDIF, D87TPDIF, REFF*n*PDIF, REFR*n*PDIF, LOP*z*PTUV, BS*mp*SCBR, BFR*m*RBRF, and TH*n*PTTR protection logical nodes (where *n* = 1–3; *m* = S, T, U, W, X; *p* = A, B, C; *z* = V, Z). ➤ Added ALMGGIO, ETHGGIO, and SGGGIO annunciator logical nodes. ➤ Added support for system logical nodes LSVS, LGOS, LTIM, LTMS, and LCCH. ➤ Added status alarms to DCZBAT metering logical node. ➤ Resolved an issue in which the quality data attribute of the MBAGGIO and MBBGGIO logical nodes were referenced to an incorrect value. ➤ Added PRBGGIO logical nodes to support pulsing remote bits. ➤ Added support for the IEC 61850 Local/ Remote control feature defined in the IEC 61850-7-4 standard. Control messages need to include the orCat value associated with the active control authority.			

Table A.4 SEL-487E-5 SV Subscriber ICD File Revision History (Sheet 4 of 4)

configVersion	Summary of Revisions	Minimum Relay/ Device/ Computer Firmware	ClassFile Version	Manual Date Code
ICD-487E-5S-R001-V0-Z400006-D20180910	➤ SEL-487E-5S ICD file for firmware R400 or higher.	R400	006	20180910

configVersion Details:

ICD-[PN]-R[RN]-V[VS]-Z[FC]-D[RD] where:

[PN] = Product name (e.g., 487E-5S)

[RN][a] = Revision number (e.g., 001)

[VS] = Version specifications (e.g., 0)

[FC][b] = Minimum relay/device/computer firmware and class file version (e.g., 400)

[RD] = Release date code (e.g., 20180910)

[a] This is the ICD file revision number, not IED firmware revision number.

[b] FC consists of six digits. The first three following the Z represent the minimum IED firmware required to be used with the ICD (e.g., 516). The second three represent the ICD ClassFileVersion (e.g., 006).

Table A.5 lists the ICD file versions for the SEL-487E-5 TiDL relay, a description of modifications and the instruction manual date code that corresponds to the versions. The most recent version is listed first.

Table A.5 SEL-487E-5 TiDL ICD File Revision History (Sheet 1 of 3)

configVersion	Summary of Revisions	Minimum Relay Firmware	ClassFile Version	Manual Date Code
ICD-487E-5-R008-V0-Z408010-D20250214	➤ IEC 61850 Edition 2.1 Conformance ➤ Modified the LPHD logical node to include the IEC 61850 library version SelLibId.val. ➤ Added support for the cmdQual, onDur, offDur, and numPls pulse configuration attributes, according to IEC 61850-7-3. ➤ Added the LocKey data object support and changed the data source mapping for Loc and LocSta. ➤ Modified the ICD file to remove control blocks and default GOOSE and report data sets. ➤ Modified the *m*79RREC logical nodes to include the trip behavior TrBeh.stVal (where *m* = S, T, U, W, X, Y). ➤ Modified the data source of *m*79RREC.AutoRecSt to be RECSTm (where *m* = S, T, U, W, X, Y). ➤ Modified the *m*79RREC logical nodes by replacing RecCyc.stVal with Rec3PhCnt.stVal (where *m* = S, T, U, W, X, Y). ➤ Added support for the valImport and valKind attributes according to IEC 61850-6 for compatibility with third-party system configuration tools. ➤ Reduced the size of all GGIO lnTypes to a maximum of 32 indices. ➤ Modified logical nodes prefixes and instances.	R408	010	20250214

Table A.5 SEL-487E-5 TiDL ICD File Revision History (Sheet 2 of 3)

configVersion	Summary of Revisions	Minimum Relay Firmware	ClassFile Version	Manual Date Code
ICD-487E-5-R007-V0-Z407009-D20241022	➤ Added HSRGGIO logical node for HSR status indication. ➤ Added RBGGIO logical nodes for remote bits 65–96. ➤ Added HB2*m*PHAR logical nodes to support terminal harmonic blocking logic (where *m* = S, T, U, W, X, Y, ST, TU, UW, WX).	R407	009	20241022
ICD-487E-5-R006-V0-Z405009-D20231207 **NOTE:** ClassFileVersion 008 did not production release.	➤ Updated IEC 61850 Edition 2 Conformance. ➤ Updated ClassFileVersion to 009. ➤ Modified LBGGIO logical node to include local bits 65–96. ➤ Modified ALTGGIO logical node to include automation SELOGIC latches 33–64. ➤ Modified the data source FLTCAUS to include restricted earth fault and Zone 2 differential trip ➤ Added support for MMS buffered and unbuffered report reservation. ➤ Added IT11PTOC–IT20PTOC logical nodes to support inverse-time overcurrent elements 11–20. ➤ Added D87R2PDIF logical node to support the second differential element. ➤ Added ASVGGIO logical node to support Automation SELOGIC Variables 129–256. ➤ Added BFRYRBR, BSYASCBR, BSYBSCBR, BSYCSCBR, TRIPYPTRC, Y52AXCBR, YBKRCILO, and YBKRCSWI logical nodes to support Breaker Y. ➤ Added YP*n*PIOC, YP*n*PTOC, YG*n*PIOC, YG*n*PTOC, YQ*n*PIOC, and YQ*n*PTOC logical nodes to support overcurrent elements on Terminal Y (where *n* = 1–3). ➤ Added METYMMXU and SEQYMSQI logical nodes to support metering quantities on Terminal Y. ➤ Added *m*79RREC logical nodes to support autoreclose functionality (where *m* = S, T, U, W, X, Y). ➤ Included the product and functional name in the CILO logical node path for SrcRef.	R405	009	20231207
ICD-487E-5-R005-V0-Z404007-D20230317	➤ Added support for the five-port Ethernet card. Added logical nodes PRPGGIO, PBLCCH, SBLCCH, EALCCH, and an additional ETHGGIO. Added multiple access points to allow for the segregation of process bus and station bus GOOSE transmission.	R404	007	20230317
ICD-487E-5-R004-V0-Z403006-D20220517	➤ Changed the CSWI logical node Loc.stVal data source from LOC to LOC OR LOCAL.	R403	006	20220523

Table A.5 SEL-487E-5 TiDL ICD File Revision History (Sheet 3 of 3)

configVersion	Summary of Revisions	Minimum Relay Firmware	ClassFile Version	Manual Date Code
ICD-487E-5-R003-V0-Z402006-D20211217	➤ Added Z*n*L1PDIS*n*, OSB*n*L1RPSB*n*, HB24L1PHAR1, and HB5L1PHAR1 logical nodes (where *n* = 1–4). ➤ Removed HBPHAR2 and HRPHAR1 logical nodes. ➤ Added HB24PHAR1 and HB5PHAR1 logical nodes. ➤ Added CILO logical node for each switch control object. ➤ Mapped CILO logical node attributes to the blocking inputs of the CSWI logical nodes for each switch control object.	R402	006	20211217
ICD-487E-5-R002-V0-Z401006-D20210212	➤ SEL-487E-5 ICD file for firmware R401 or higher.	R401	006	20210209

configVersion Details:

ICD-[PN]-R[RN]-V[VS]-Z[FC]-D[RD] where:

[PN] = Product name (e.g., 487E-5)
[RN][a] = Revision number (e.g., 002)
[VS] = Version specifications (e.g., 0)
[FC][b] = Minimum relay/device/computer firmware and class file version (e.g., 401)
[RD] = Release date code (e.g., 20210212)

[a] This is the ICD file revision number, not IED firmware revision number.
[b] FC consists of six digits. The first three following the Z represent the minimum IED firmware required to be used with the ICD (e.g., 401). The second three represent the ICD ClassFileVersion (e.g., 006).

Instruction Manual

The date code at the bottom of each page of this manual reflects the creation or revision date.

Table A.6 lists the instruction manual versions and revision descriptions. The most recent instruction manual version is listed first.

Table A.6 Instruction Manual Revision History (Sheet 1 of 8)

Date Code	Summary of Revisions
20250214	General ➤ Removed references to product literature DVD and firmware CD. Section 1 ➤ Updated *Table 1.12: SEL-487E Relay Characteristics*. ➤ Updated *Specifications*. Section 2 ➤ Updated *IRIG-B Inputs*. Section 5 ➤ Updated *State Diagram*. Section 7 ➤ Updated *Table 7.8: Demand Metering Operating Quantities*.

Table A.6 Instruction Manual Revision History (Sheet 2 of 8)

Date Code	Summary of Revisions
	Section 8 ➤ Updated *Table 8.42: Differential Element Zone 2 (87B)*. **Section 10** ➤ Updated *Table 10.4: SEL-487E Database Structure—METER Region*. ➤ Updated *Control Points*. ➤ Updated *Table 10.15: SEL-487E Analog Input Reference Data Map* and *Table 10.24: Logical Device: PRO (Protection), Table 10.25 Logical Device: MET (Metering),* and *Table 10.26 Logical Device: MU01 (SV Merging Unit)*. **Section 11** ➤ Updated *Table 11.1: Alphabetical List of Relay Word Bits* and *Table 11.2: Row List of Relay Word Bits*. **Section 12** ➤ Updated *Table 12.1: Analog Quantities Sorted Alphabetically* and *Table 12.2: Analog Quantities Sorted by Function.* **Appendix A** ➤ Updated for firmware version R408-V0. ➤ Updated for ICD file version R008.
20241022	**Preface** ➤ Updated *Differentiating Between Relay Versions* and *Specifications*. **Section 1** ➤ Updated *Features, Models and Options, Applications, Product Characteristics*, and *Specifications*. **Section 2** ➤ Updated *Shared Configuration Attributes, Plug-In Boards, Jumpers, Rack Mounting, Connection,* and *Merging Unit AC/DC Connections*. **Section 3** ➤ Updated *Adaptive Inverse-Time Overcurrent, U87P Unrestrained Phase-Differential Element, 87RA, 87RB, and 87RC Restrained Differential Elements*, and *Testing*. ➤ Updated *Table 3.14: Settings for the Negative-Sequence Test* and *Table 3.15: Currents for Negative-Sequence Differential Test*. ➤ Updated *Figure 3.30: Group Settings for the Directional Test*. ➤ Updated *TEST SV*. **Section 4** ➤ Updated *Table 4.2: RMS Values, Table 4.3: Fundamental Values*, and *Table 4.4: Energy Quantities*. ➤ Updated *Meter*. **Section 5** ➤ Updated *Analog Channel Statuses*. ➤ Updated *Figure 5.9: Zone 1 Differential Blocking Logic*. ➤ Added *Potential Transformer (PT) Ratio Settings With LEA Inputs*. ➤ Updated *TAPm2 (Terminal m Current Tap)*. ➤ Added *Voltage Source Selection*. ➤ Updated *Figure 5.29: Zone 1 A-Phase Percentage-Restrained Differential Element, Figure 5.37: Zone 2 A-Phase Percentage-Restrained Differential Element, Figure 5.47: Single-Wye Winding REF Application, Figure 5.48: Autotransformer REF Application, Figure 5.49: Autotransformer With Two-HV CT REF Application*, and *Figure 5.50: Three-Winding Transformer With Two REF Elements*. ➤ Updated *Delta-Connected CTs*, *Combined Terminals*, *Overcurrent Elements*, and *Selectable Time-Overcurrent Element (51)*. ➤ Added *Terminal Harmonic Blocking*. ➤ Updated *Line Protection Elements, Negative-Sequence Internal Enable Function Block, Zero-Sequence Internal Enable Functional Block, Negative-Sequence Directional Calculation Block,* and *Zero-Sequence Directional Calculation Block*. ➤ Updated *Figure 5.106: Negative-Sequence Directional Element, Figure 5.107: Positive-Sequence Directional Element, Figure 5.109: Phase Directional Element*. ➤ Updated *Table 5.17: Directional Element Summary*.

Table A.6 Instruction Manual Revision History (Sheet 3 of 8)

Date Code	Summary of Revisions
	➤ Updated *Figure 5.127: Example Synchronism-Check Voltage Connections to the SEL-487E-5*. ➤ Updated *Over- and Underpower Element*. Section 7 ➤ Updated *Instantaneous Metering, Differential Meter, Operating Characteristic*, and *Through-Fault Monitor Reports*. ➤ Updated *Table 7.18: Event Report Analog Quantities*. ➤ Updated *Figure 7.33: Sample Digital Portion of the Event Report*. Section 8 ➤ Updated *Table 8.37: Relay Configuration, Table 8.38: CT Data, Table 8.40: Voltage Reference Terminal Selection, Table 8.55: Line Directional Control Settings, Table 8.60: Line Harmonic Blocking*, and *Table 8.61: Terminal m Overcurrent and Directional Elements*. ➤ Added *Table 8.65: Terminal m Harmonic Blocking*. Section 9 ➤ Updated *Table 9.1: SEL-487E List of Commands*. ➤ Updated *MET*. Section 10 ➤ Updated *Table 10.13: SEL-487E Binary Output Reference Data Map, Table 10.14: SEL-487E Binary Counter Reference Data Map, Table 10.15: SEL-487E Analog Input Reference Data Map, 10.17: SEL-487E Object 12 Control Point Operations*, and *Table 10.24: Logical Device: PRO (Protection)*. ➤ Added *Table 10.26: Logical Device: MU01 (SV Merging Unit)*. Section 11 ➤ Updated *Table 11.1: Alphabetical List of Relay Word Bits* and *Table 11.2: Row List of Relay Word Bits*. Section 12 ➤ Updated *Table 12.1: Analog Quantities Sorted Alphabetically* and *Table 12.2: Analog Quantities Sorted by Function*. Appendix A ➤ Updated for firmware version R407-V0. ➤ Updated for ICD file version R007.
20240927	Section 1 ➤ Changed *Object Penetration* to *Ingress Protection* and updated contents in *Specifications*.
20240509	Appendix A ➤ [Cybersecurity] Updated for firmware version R406-V0.
20240416	Appendix A ➤ Updated for firmware version R405-V1.
20231207	Section 1 ➤ Updated *Features, Models and Options,* and *Applications*. ➤ Updated *Table 1.19: SEL-487E Relay Characteristics*. ➤ Updated *Specifications*. Section 2 ➤ Updated *Figure 2.4: SEL-487E-5 TiDL Relay Rear Panel* and *Figure 2.15: SEL-487E-5 TiDL Relay Rear Panel*. Section 4 ➤ Updated *Table 4.2: RMS Values, Table 4.3: Fundamental Values, Table 4.4: Energy Quantities*, and *Table 4.6: Meter Availability Conditions*. ➤ Updated *Figure 4.4: RMS Meter Screens*. ➤ Added *Differential Meter*. ➤ Updated *Events*. ➤ Updated *Figure 4.15: Factory-Default Operator Control Pushbuttons*

Table A.6 Instruction Manual Revision History (Sheet 4 of 8)

Date Code	Summary of Revisions
	Section 5 ➤ Added *Differential Elements (87)*. ➤ Updated *Differential Zone and Restricted Earth Fault Element Blocking Logic*, *Overcurrent Elements*, *Fault Identification Logic*, *Directional Control for Ground-Overcurrent Elements*, *Directional Control for Phase and Negative-Sequence Overcurrent Elements*, *Unbalance Current Elements*, *Open-Phase Detection Logic*, *Breaker Failure Elements*, *Synchronism Check*, *IEC Thermal Elements*, *Trip Logic*, *Close Logic*, *Autoreclosing*, *Loss-of-Potential (LOP) Logic,* and *Circuit Breaker Status* for Terminal Y. **Section 7** ➤ Updated *Table 7.1: MET Command, Table 7.2: Valid Reference Quantities, Table 7.3: Quantities in the Fundamental Meter Report, Table 7.8: Demand Metering Operating Quantities*, and *Table 7.17: Event Report Nonvolatile Storage Capability When ERDIG = A*. ➤ Updated *Differential Meter, Circuit Breaker Monitor,* and *Base Set of Relay Word Bits*. ➤ Added *Table 7.19: Differential Report Analog Quantities*. ➤ Updated *Figure 7.32: Digital Section of the Event Report*, *Figure 7.33: Sample Digital Portion of the Event Report*, *Figure 7.34: Summary Section of the Event Report,* and *Figure 7.35: Sample Event Summary Report*. ➤ Updated *Table 7.20: Event Types.* **Section 8** ➤ Updated *Table 8.19: Data Reset Control, Table 8.24: Enables, Table 8.26: Breaker Monitor Settings, Table 8.27: Through-Fault Monitoring, Table 8.28: Thermal Model Configuration, Table 8.34: IEC Thermal (49) Elements, Table 8.36: Group Setting Categories, Table 8.37: Relay Configuration, Table 8.38: CT Data, Table 8.39: Potential Transformer Data, Table 8.41: Differential Element Zone 1 (87T), Table 8.44: Line 1 Elements, Table 8.55: Directional Control Settings, Table 8.61: Overcurrent Elements for Terminals, Table 8.62: Terminal m Phase Overcurrent Element Level a, Table 8.63: Terminal m Negative-Sequence Overcurrent Element Levels, Table 8.64: Terminal m Zero-Sequence Overcurrent Element Levels, Table 8.65: Directional Element Blocking, Table 8.66: Inverse-Time Overcurrent Elements, Table 8.67: Terminal Current Unbalance Elements, Table 8.71: Synchronism-Check (25) Elements, Table 8.75: Breaker Failure Logic, Table 8.79: Trip Logic,* and *Table 8.80: Close Logic*. ➤ Added *Table 8.42: Differential Element Zone 2 (87T)* and *Table 8.81: Reclosing Logic*. ➤ Updated *Protection Logic: Default Settings* and *Bay Settings*. **Section 9** ➤ Updated *Table 9.1: SEL-487E List of Commands*. ➤ Updated *METER*. **Section 10** ➤ Updated *Table 10.4: SEL-487E Database Structure—METER Region, Table 10.12: SEL-487E Binary Output Reference Data Map, Table 10.13: SEL-487E Binary Counter Reference Data Map, Table 10.14: SEL-487E Analog Input Reference Data Map, Table 10.16: SEL-487E Object 12 Control Point Operations, Table 10.17: Object 30, 32, FTYPE Upper Byte-Event Cause, Table 10.23: Logical Device: PRO (Protection), Table 10.24: Logical Device: MET (Metering),* and *Table 10.26: FLTCAUS—Fault Cause*. **Section 11** ➤ Updated *Table 11.1: Alphabetical List of Relay Word Bits* and *Table 11.2: Row List of Relay Word Bits*. **Section 12** ➤ Updated *Table 12.1: Analog Quantities Sorted Alphabetically* and *Table 12.2: Analog Quantities Sorted by Function.* **Appendix A** ➤ Updated for firmware version R405. ➤ Updated for ICD file version R006.
20231110	**Appendix A** ➤ Updated for firmware version R404-V2.
20230830	**Appendix A** ➤ Updated for firmware version R404-V1.
20230317	**Section 1** ➤ Updated *Features, Models and Options,* and *Specifications*.

Table A.6 Instruction Manual Revision History (Sheet 5 of 8)

Date Code	Summary of Revisions
	Section 2 ➤ Updated *Figure 2.3: SEL-487E-5 SV Subscriber Relay Rear Panel, Figure 2.4: SEL-487E-5 TiDL Relay Rear Panel, Figure 2.14: SEL-487E-5 SV Subscriber Relay Rear Panel*, and *Figure 2.15: SEL-487E-5 TiDL Relay Rear Panel*. ➤ Updated *Standard Control Outputs* and *Ethernet Network Connections*. **Section 5** ➤ Updated *Figure 5.63: U.S. Curves: U1, U2, U3, and U4*. **Section 9** ➤ Updated *Table 9.1: SEL-487E List of Commands*. **Section 11** ➤ Updated *Table 11.1: Alphabetical List of Relay Word Bits* and *Table 11.2: Row List of Relay Word Bits*. **Appendix A** ➤ Updated for firmware version R404. ➤ Updated for SELBOOT version R302. ➤ Updated for ICD file versions R005 in *Table A.3: SEL-487E-5 SV Subscriber ICD File Revision History* and *Table A.4: SEL-487E-5 TiDL Relay ICD File Revision History*. **SEL-487E-5 Relay Command Summary** ➤ Added *COM SV*.
20220523	**Preface** ➤ Updated *SEL-487E Relay Versions* table. **Section 1** ➤ Updated *Models and Options, Applications,* and *Specifications*. **Section 2** ➤ Updated *Secondary Circuits, High-Speed, High-Current Interrupting Control Outputs,* and *Ethernet Network Connections*. **Section 3** ➤ Updated *Figure 3.1: Test Network Topology*. **Section 5** ➤ Updated remote data acquisition to DSS. ➤ Updated notes regarding relay operating times. ➤ Updated *Definite-Time Elements*, *Selection of the Restraint Quantity,* and *Combined Terminals*. ➤ Added *Total Harmonic Distortion*. **Section 6** ➤ Updated *Figure 6.2: Three-Line Diagram Showing System Phase-to-Transformer Bushing, CT, and CT-to-Relay Connections, Figure 6.11: Standard CT Connections, Figure 6.13: Current Flow With Reversed X-Side CT Polarity, Figure 6.14: Current Flow With Reversed X-Side CT Polarity and Reversed Connections, Figure 6.16: Delta-Wye Transformer With Standard Phase-to-Bushing Connections, Figure 6.18: Delta-Wye Transformer With Non-Standard Phase-to-Bushing Connections for Example 6.2, Figure 6.20: Wye-Delta Transformer With Non-Standard CT Connections on X-Side, Figure 6.23: Autotransformer With Standard Phase-to-Bushing Connections, Figure 6.25: Delta-Delta Transformer With Standard Phase-to-Bushing Connections,* and *Figure 6.28: Delta-Wye Transformer With Standard Phase-to-Bushing Connections With an ACB Phase Rotation*. **Section 12** ➤ Updated *Table 12.1: Analog Quantities Sorted Alphabetically* and *Table 12.2: Analog Quantities Sorted by Function.* **Appendix A** ➤ Updated for firmware version R403-V0. ➤ Updated *Table A.3: SEL-487E-5 SV Subscriber ICD File Revision History* and *Table A.4: SEL-487E-5 TiDL Relay ICD File Revision History* for ICD file version R004.

Table A.6 Instruction Manual Revision History (Sheet 6 of 8)

Date Code	Summary of Revisions
20211217	**Section 1** ➤ Updated *Features*. ➤ Added *Distance Protection for Transformers*. ➤ Updated *Table 1.19: SEL-487E Relay Characteristics*. ➤ Updated *Specifications*. **Section 3** ➤ Updated *Figure 3.20 REF Characteristic and Test Setup*. **Section 5** ➤ Updated *Figure 5.35: REF Directional Element* and *Figure 5.37: Algorithm That Performs the Directional Calculations*. ➤ Updated *Differential-Element Speed and Security Features, Phase Percentage-Restrained Differential Element (87R), Delta-Connected CTs, Fault Identification Logic, Directional Control for Ground-Overcurrent Elements, Directional Control for Phase and Negative-Sequence Overcurrent Elements,* and *Loss-of-Potential (LOP) Logic*. ➤ Added *Line Protection Elements*. **Section 6** ➤ Added *Example 6.5: Delta-Delta Transformer With Standard Phase-to-Bushing Connections, Standard CT Connections, and ABC System Phase Rotation*. **Section 7** ➤ Updated *Table 7.1: MET Command*. ➤ Updated *Differential Meter*. **Section 8** ➤ Updated *Table 8.2: Global Setting Categories*. ➤ Added *Table 8.20: Access Control*. ➤ Updated *Table 8.39: Potential Transformer Data*, and *Table 8.41: Differential-Element Configuration and Data*. ➤ Added *Table 8.43: Line 1 Elements*, *Table 8.44: Line Configuration*, *Table 8.45: Mho Phase Distance Element Reach*, *Table 8.46: Quad Phase Distance Element Reach*, *Table 8.47: Phase Distance Fault Detectors*, *Table 8.48: Mho Ground Distance Element Reach*, *Table 8.49: Quad Ground Distance Element Reach*, *Table 8.50: Zero-Sequence Compensation Factor*, *Table 8.51: Ground Distance Fault Detectors*, *Table 8.52: Zone/Level Direction*, *Table 8.53: Distance Element Common Time Delay*, *Table 8.54: Directional Control Settings*, *Table 8.55: Out-of-Step Blocking*, *Table 8.56: Pole-Open Detection*, *Table 8.57: Switch-Onto-Fault Scheme*, *Table 8.58: Load Encroachment*, and *Table 8.59: Harmonic Blocking*. ➤ Updated *Table 8.60: Overcurrent Elements for Terminals* and *Table 8.73: Frequency (81) Elements*. **Section 9** ➤ Updated *Table 9.1: SEL-487E List of Commands*. ➤ Added *MET DIF A*. ➤ Updated *Table 9.7: MET SEC Command*. **Section 10** ➤ Updated *Table 10.6: SEL-487E Database Structure—TARGET Region*, *Table 10.14: SEL-487E Analog Input Reference Data Map*, and *Table 10.23: Logical Device: PRO (Protection)*. **Section 11** ➤ Updated *Table 11.1: Alphabetical List of Relay Word Bits* and *Table 11.2: Row List of Relay Word Bits*. **Section 12** ➤ Updated *Table 12.1: Analog Quantities Sorted Alphabetically* and *Table 12.2: Analog Quantities Sorted by Function.* **Appendix A** ➤ Updated for firmware version R402-V0. ➤ Updated *Table A.3: SEL-487E-5 SV Subscriber ICD File Revision History* and *Table A.4: SEL-487E-5 TiDL Relay ICD File Revision History* for ICD file version R003.
20211203	**Appendix A** ➤ Updated for firmware version R401-V1. ➤ Updated Summary of Revisions for ICD file version R002 in *Table A.3: SEL-487E-5 SV Subscriber ICD File Revision History* and *Table A.4: SEL-487E-5 TiDL Relay ICD File Revision History*.

Table A.6 Instruction Manual Revision History (Sheet 7 of 8)

Date Code	Summary of Revisions
20210708	**Section 1** ➤ Updated *Specifications*.
20210701	**Section 1** ➤ Updated *Figure 1.1: SEL-487E-5 SV Subscriber Relay Functional Overview*. ➤ Updated *Specifications*.
20210630	**Section 1** ➤ Updated *Specifications*.
20210514	**Section 1** ➤ Updated *Specifications*. **Appendix A** ➤ Updated Summary of Revisions for R002 in *Table A.3: SEL-487E-5 SV Subscriber ICD File Revision History*.
20210326	**Section 1** ➤ Updated *Specifications*. **Section 11** ➤ Updated *Table 11.1: Alphabetical List of Relay Word Bits* and *Table 11.2: Row List of Relay Word Bits*. **Appendix A** ➤ Updated Summary of Revisions for firmware version R401-V0.
20210209	**Preface** ➤ Added *Differentiating Between Relay Versions*. ➤ Updated *Overview* and *General Information*. **Section 1** ➤ Updated introductory text. ➤ Updated *Features*, *Models and Options*, *Applications*, and *Product Characteristics*. ➤ Updated *Specifications*. **Section 2** ➤ Updated *Relay Sizes*. ➤ Added *Figure 2.4: SEL-487E-5 TiDL Relay Rear Panel* and *Figure 2.15: SEL-487E-5 TiDL Relay Rear Panel*. ➤ Updated *Jumpers, Connection*, and *Merging Unit AC/DC Connections*. **Section 3** ➤ Updated *Relay Test Connections*. **Section 5** ➤ Updated *Analog Channel Statuses* and *Sampled Values Alarm Logic (SEL-487E-5 SV Subscriber Relay)*. ➤ Added *TiDL Alarm Logic (SEL-487E-5 TiDL Relay)*. ➤ Updated *Application Setting SVBLK and Relay Word Bit SVBK_EX*, *Selective Protection Disabling*, *Differential Zone and Restricted Earth Fault Element Blocking Logic,* and *Phase Percentage-Restrained Differential Element (87R)*. ➤ Updated *Equation 5.7*. ➤ Updated *Negative-Sequence Percentage-Restrained Differential Element (87Q)*, *Unrestrained Phase-Differential Element (87U)*, *REF Element, Overcurrent Elements,* and *Selectable Time-Overcurrent Element (51)*. ➤ Updated *Figure 5.69: Internal Enables for Negative-Sequence (m32QE) and Zero-Sequence (m32QGE) Directional Elements*, *Figure 5.70: Internal Enable (m32VE) for Zero-Sequence Directional Element*, *Figure 5.71: Negative-Sequence Directional Calculation Logic (Ground Elements)*, *Figure 5.77: Zero-Sequence Directional Calculation Logic*, *Figure 5.82: Phase Directional Element*, *Figure 5.86: A-Phase Open-Phase Detection Logic*. ➤ Updated *Table 5.12: Directional Element Summary and Example Settings (Terminal S)*. ➤ Updated *Open-Phase Detection Logic*, *Breaker Failure Elements*, *Synchronism Check*, *Over-and Undervoltage Elements*, *Over- and Underpower Element, and Loss-of-Potential (LOP) Logic*. **Section 6** ➤ Updated *Transformer Nameplates and System Connections* under *Transformer Windings and CT Connection Compensation Settings Examples*.

Table A.6 Instruction Manual Revision History (Sheet 8 of 8)

Date Code	Summary of Revisions
	Section 7 ➤ Updated *Metering* note. **Section 8** ➤ Updated *Table 8.5: Control Inputs (Global)*. ➤ Added *Table 8.7: Interface Board #n Control Inputs*. ➤ Updated *Table 8.21: SV and TiDL Application Settings* and *Table 8.53: Undervoltage (27) Elements*. **Section 10** ➤ Updated *Table 10.14: SEL-487E Analog Input Reference Data Map*, *Table 10.21: SEL-487E Default Analog Input Map*, *Table 10.12: SEL-487E Binary Output Reference Data Map*, and *Table 10.16: SEL-487E Object 12 Control Point Operations*. **Section 10** ➤ Updated *Table 11.1: Alphabetical List of Relay Word Bits* and *Table 11.2: Row List of Relay Word Bits*. **Section 12** ➤ Updated *Table 12.1: Analog Quantities Sorted Alphabetically* and *Table 12.2: Analog Quantities Sorted by Function*. **Appendix A** ➤ Updated for firmware version R401-V0. ➤ Updated for SELBOOT version R300-V0 and R301-V0. ➤ Updated for ICD versions R002-V0 in *Table A.3: SEL-487E-5 SV Subscriber ICD File Revision History* and R002-V0 in *Table A.4: SEL-487E-5 TiDL ICD File Revision History*. **Command Summary** ➤ Updated definition for CFG CTNOM *i j*.
20201204	**Preface** ➤ Updated *SEL-400 Series Relays Instruction Manual* and *Safety Marks*.
20201009	**Appendix A** ➤ Updated for firmware version R400-V3.
20191210	**Appendix A** ➤ Updated for firmware version R400-V2.
20190211	**Appendix A** ➤ Updated for R400-V1.
20181030	**Section 1** ➤ Updated *Specifications*. ➤ Updated *Applications*.
20180910	➤ Initial version.

SEL-487E-5 Relay Command Summary

Command[a, b]	Description
2ACCESS	Go to Access Level 2 (full control)
89CLOSE *k*	Close Disconnect *k* (Isolator *k*) (*k* = 1–20)
89OPEN *k*	Open Disconnect *k* (Isolator *k*) (*k* = 1–20)
AACCESS	Go to Access Level A (automation configuration)
ACCESS	Go to Access Level 1 (monitor relay)
BACCESS	Go to Access Level B (monitor and control circuit breakers)
BNAME	ASCII names of Fast Meter status bits
BREAKER *n*	Display circuit breaker reports; preload/reset monitor data (*n* = S, T, U, W, X)
CASCII	Generate the Compressed ASCII response configuration message
CBREAKER	Display Compressed ASCII breaker status report
CEVENT	Display Compressed ASCII event report
CFG CTNOM *i j*	For DSS relays, configure the nominal CT input value *i* to 1, 2, 3, or 4 and *j* to 1, 2, 3, 4, 5, 6, 7, or 8
CHISTORY	Display Compressed ASCII history report
CLOSE *n*	Close Circuit Breaker *n* (*n* = S, T, U, W, X)
COM *c*	Display Channel *c* MIRRORED BITS communications data (*c* = A, B, or M [either enabled single channel])
COM PTP	Display a report on PTP data sets and statistics
COM RTC	Display statistics for synchrophasor client channels
COM SV	Display information and statistics for the configured SV publications or subscriptions
COM PRP	Display PRP information and statistics for the five-port Ethernet card
CONTROL *nn*	Set, clear, or pulse Remote Bit *nn* (*nn* = 01–64)
COPY *m n*	Copy settings between instances in the same class (*m* and *n* are instance numbers; e.g., *m* = 1 is Group 1, *n* = 2 is Group 2, etc.)
CPR	Display Compressed ASCII signal profiling report
CSER	Display Compressed ASCII sequential events report
CSTATUS	Display Compressed ASCII relay status report
CSUMMARY	Display Compressed ASCII summary event report
DATE	Display and set the relay date
DNAME X	ASCII names of all relay digital points reported via Fast Meter
ETHERNET	Displays Ethernet port (`PORT 5`) configuration and status
EVENT	Display and acknowledge event reports
EXIT	Reduce access level to Access Level 0 (exit relay control)
FILE	Transfer files between the relay and external software
GOOSE	Displays transmit and receive GOOSE messaging information
GROUP	Display the active group number or change the active group
HELP	List and describe available commands at each access level
HISTORY	View event summaries/history; clear event summary data
ID	Display the firmware ID, user ID, device code, part number, and configuration information
LOOPBACK	Connect MIRRORED BITS data from transmit to receive on the same port

Command[a, b]	Description
MAC	Display MAC Addresses
MAP 1	View the relay database organization
METER	Display metering data and internal relay operating variables
OACCESS	Go to Access Level O (output configuration)
OPEN *n*	Open Circuit Breaker *n* (*n* = S, T, U, W, X)
PACCESS	Go to Access Level P (protection configuration)
PASSWORD *n*	Change relay password for Access Level *n*
PING *addr*	Sends an ICMP echo request message to the provided IP address *addr* to confirm connectivity
PORT *p*	Connect to remote devices via MIRRORED BITS virtual terminal (for **PORT p**; where *p* = 1–3, F)
PROFILE	Display signal profile records
PULSE OUT*nnn*	Pulse a relay control output (OUT*nnn* is a control output)
QUIT	Reduce access level to Access Level 0 (exit relay control)
RTC	Display configuration of received remote synchrophasors
SER	View Sequential Events Recorder (SER) report
SET	Set or modify relay settings
SHOW	Display relay settings
SNS	Display Sequential Events Recorder settings name strings (Fast SER)
STATUS	Display or clear relay status and SELOGIC control equation errors
SUMMARY	Display a summary event report
TARGET	Display relay elements for a row in the Relay Word bit table
TEC	Display time-error estimate; display or modify time-error correction value
TEST DB	Test interfaces to a virtual device database used by Fast Message protocol
TEST DB2	Test all communications protocols except Fast Message
TEST FM	Display or place values in Fast Meter interface
TEST SV	For SV subscriber relays, accept SV test messages
TFE	Display through-fault events
THE	Display transformer thermal information
TIME	Display and set the relay time clock
TIME Q	Display detailed information on the relay internal clock
TRIGGER	Initiate a data capture and record an event report
VERSION	Display the relay hardware and software configuration
VIEW 1	View data from the Fast Message database

[a] See Section 9: ASCII Command Reference for more information.

[b] For help on a specific command, type **HELP [command] <Enter>** at an ASCII terminal communicating with the relay.

SEL-487E-5 Relay Command Summary

Command[a, b]	Description
2ACCESS	Go to Access Level 2 (full control)
89CLOSE *k*	Close Disconnect *k* (Isolator *k*) (*k* = 1–20)
89OPEN *k*	Open Disconnect *k* (Isolator *k*) (*k* = 1–20)
AACCESS	Go to Access Level A (automation configuration)
ACCESS	Go to Access Level 1 (monitor relay)
BACCESS	Go to Access Level B (monitor and control circuit breakers)
BNAME	ASCII names of Fast Meter status bits
BREAKER *n*	Display circuit breaker reports; preload/reset monitor data (*n* = S, T, U, W, X)
CASCII	Generate the Compressed ASCII response configuration message
CBREAKER	Display Compressed ASCII breaker status report
CEVENT	Display Compressed ASCII event report
CFG CTNOM *i j*	For DSS relays, configure the nominal CT input value *i* to 1, 2, 3, or 4 and *j* to 1, 2, 3, 4, 5, 6, 7, or 8
CHISTORY	Display Compressed ASCII history report
CLOSE *n*	Close Circuit Breaker *n* (*n* = S, T, U, W, X)
COM *c*	Display Channel *c* MIRRORED BITS communications data (*c* = A, B, or M [either enabled single channel])
COM PTP	Display a report on PTP data sets and statistics
COM RTC	Display statistics for synchrophasor client channels
COM SV	Display information and statistics for the configured SV publications or subscriptions
COM PRP	Display PRP information and statistics for the five-port Ethernet card
CONTROL *nn*	Set, clear, or pulse Remote Bit *nn* (*nn* = 01–64)
COPY *m n*	Copy settings between instances in the same class (*m* and *n* are instance numbers; e.g., *m* = 1 is Group 1, *n* = 2 is Group 2, etc.)
CPR	Display Compressed ASCII signal profiling report
CSER	Display Compressed ASCII sequential events report
CSTATUS	Display Compressed ASCII relay status report
CSUMMARY	Display Compressed ASCII summary event report
DATE	Display and set the relay date
DNAME X	ASCII names of all relay digital points reported via Fast Meter
ETHERNET	Displays Ethernet port (`PORT 5`) configuration and status
EVENT	Display and acknowledge event reports
EXIT	Reduce access level to Access Level 0 (exit relay control)
FILE	Transfer files between the relay and external software
GOOSE	Displays transmit and receive GOOSE messaging information
GROUP	Display the active group number or change the active group
HELP	List and describe available commands at each access level
HISTORY	View event summaries/history; clear event summary data
ID	Display the firmware ID, user ID, device code, part number, and configuration information
LOOPBACK	Connect MIRRORED BITS data from transmit to receive on the same port

Command[a, b]	Description
MAC	Display MAC Addresses
MAP 1	View the relay database organization
METER	Display metering data and internal relay operating variables
OACCESS	Go to Access Level O (output configuration)
OPEN *n*	Open Circuit Breaker *n* (*n* = S, T, U, W, X)
PACCESS	Go to Access Level P (protection configuration)
PASSWORD *n*	Change relay password for Access Level *n*
PING *addr*	Sends an ICMP echo request message to the provided IP address *addr* to confirm connectivity
PORT *p*	Connect to remote devices via MIRRORED BITS virtual terminal (for **PORT p**; where *p* = 1–3, F)
PROFILE	Display signal profile records
PULSE OUT*nnn*	Pulse a relay control output (OUT*nnn* is a control output)
QUIT	Reduce access level to Access Level 0 (exit relay control)
RTC	Display configuration of received remote synchrophasors
SER	View Sequential Events Recorder (SER) report
SET	Set or modify relay settings
SHOW	Display relay settings
SNS	Display Sequential Events Recorder settings name strings (Fast SER)
STATUS	Display or clear relay status and SELOGIC control equation errors
SUMMARY	Display a summary event report
TARGET	Display relay elements for a row in the Relay Word bit table
TEC	Display time-error estimate; display or modify time-error correction value
TEST DB	Test interfaces to a virtual device database used by Fast Message protocol
TEST DB2	Test all communications protocols except Fast Message
TEST FM	Display or place values in Fast Meter interface
TEST SV	For SV subscriber relays, accept SV test messages
TFE	Display through-fault events
THE	Display transformer thermal information
TIME	Display and set the relay time clock
TIME Q	Display detailed information on the relay internal clock
TRIGGER	Initiate a data capture and record an event report
VERSION	Display the relay hardware and software configuration
VIEW 1	View data from the Fast Message database

[a] See Section 9: ASCII Command Reference for more information.

[b] For help on a specific command, type **HELP [command] <Enter>** at an ASCII terminal communicating with the relay.

SEL-400 Series Relays

Instruction Manual

20250214

SEL SCHWEITZER ENGINEERING LABORATORIES

© 2016–2025 by Schweitzer Engineering Laboratories, Inc.

Content subject to change without notice. Unless otherwise agreed in writing, all SEL product sales are subject to SEL's terms and conditions located here: https://selinc.com/company/termsandconditions/.
Part Number: PM400-01

Table of Contents

List of Tables v

List of Figures xv

Preface xxiii

Manual Overview xxiii
Safety Information xxv
General Information xxviii

Section 1: Introduction

Common Features 1.1

Section 2: PC Software

SEL Grid Configurator 2.1
ACSELERATOR QuickSet SEL-5030 Software 2.14

Section 3: Basic Relay Operations

Inspecting a New Relay 3.1
Establishing Communication 3.3
Access Levels and Passwords 3.7
Checking Relay Status 3.13
Making Simple Settings Changes 3.15
Examining Metering Quantities 3.34
Examining Relay Elements 3.42
Reading Oscillograms, Event Reports, and SER 3.46
Operating the Relay Inputs and Outputs 3.55
Configuring Timekeeping 3.64
Readying the Relay for Field Application 3.65

Section 4: Front-Panel Operations

Front-Panel Layout 4.1
Front-Panel Menus and Screens 4.14
Front-Panel Automatic Messages 4.32
Operation and Target LEDs 4.33
Front-Panel Operator Control Pushbuttons 4.35

Section 5: Control

Circuit Breaker Status and Control 5.1
Disconnect Logic 5.2
Remote Bits 5.12
Bay Control Front-Panel Operations 5.12
Bay Control Screens 5.29
Customizable Screens 5.36
Bay Control Example Application 5.37

Section 6: Autoreclosing

Autoreclosing States 6.2
One-Circuit-Breaker Autoreclosing 6.4
Two-Circuit-Breaker Autoreclosing 6.10
Autoreclose Logic Diagrams 6.26
Manual Closing 6.39
Voltage Checks for Autoreclosing and Manual Closing 6.42
Settings and Relay Word Bits for Autoreclosing and Manual Closing 6.45

Section 7: Metering

Instantaneous Metering 7.2
Maximum/Minimum Metering 7.5
Demand Metering 7.6
Energy Metering 7.10
Synchrophasor Metering 7.10
Battery Metering 7.11
RTD Metering 7.12
Protection Math Variable Metering 7.12
Automation Math Variable Metering 7.13
MIRRORED BITS Remote Analog Metering 7.13

Section 8: Monitoring

Circuit Breaker Monitor 8.1
Station DC Battery System Monitor 8.21

Section 9: Reporting

Data Processing 9.1
Triggering Data Captures and Event Reports 9.7
Duration of Data Captures and Event Reports 9.9
Oscillography 9.9
Event Reports, Event Summaries, and Event Histories 9.13
Sequential Events Recorder (SER) 9.28
Signal Profiling 9.31

Section 10: Testing, Troubleshooting, and Maintenance

Testing Philosophy 10.1
Testing Features and Tools 10.4
Test Methods 10.7
Relay Self-Tests 10.19
Relay Troubleshooting 10.23
Maintenance 10.27
Technical Support 10.35

Section 11: Time and Date Management

IRIG-B Timekeeping 11.1
PTP Timekeeping 11.2
Time Source Selection 11.5
Time Quality Indications 11.5
Time-Synchronized Events 11.9

Section 12: Settings

Settings Structure 12.1
Multiple Setting Groups 12.4
Port Settings 12.6
DNP3 Settings—Custom Maps 12.19
Front-Panel Settings 12.20
Alias Settings 12.25
Protection Freeform SELOGIC Control Equations 12.26
Automation Freeform SELOGIC Control Equations 12.26
Output Settings 12.26
Report Settings 12.28
Notes Settings 12.29

Section 13: SELOGIC Control Equation Programming

Separation of Protection and Automation Areas 13.1
SELOGIC Control Equation Setting Structure 13.2
SELOGIC Control Equation Capacity 13.5
SELOGIC Control Equation Programming 13.6

SELOGIC Control Equation Elements 13.9
SELOGIC Control Equation Operators 13.24
Effective Programming 13.34
SEL-311 and SEL-351 Series Users 13.36

Section 14: ASCII Command Reference

Command Description 14.1

Section 15: Communications Interfaces

Serial Communication 15.2
Serial Port Hardware Protocol 15.4
Ethernet Communications 15.6
Virtual File Interface 15.21
Software Protocol Selections 15.28
SEL Protocol 15.29
SEL MIRRORED BITS Communication 15.36
SEL Distributed Port Switch Protocol (LMD) 15.43
SEL-2600A RTD Module Operation 15.43
Direct Networking Example 15.45

Section 16: DNP3 Communication

Introduction to DNP3 ..... 16.1
DNP3 in the Relay 16.7
DNP3 Documentation 16.12
DNP3 Serial Application Example 16.26
DNP3 LAN/WAN Application Example 16.31

Section 17: IEC 61850 Communication

Introduction to IEC 61850 ..... 17.2
IEC 61850 Operation 17.3
Sampled Values 17.30
IEC 61850 Simulation Mode 17.38
IEC 61850 Mode/Behavior 17.38
IEC 61850 Configuration 17.47
Logical Nodes 17.53
Protocol Implementation Conformance Statement 17.84
ACSI Conformance Statements 17.89
Potential Client and Automation Application Issues With Ed2 and Ed2.1 Upgrades 17.94
Backward Compatibility With Ed1 Devices 17.97

Section 18: Synchrophasors

Introduction 18.1
Synchrophasor Measurement 18.3
Settings for Synchrophasors 18.6
Synchrophasor Quantities 18.18
View Synchrophasors by Using the MET PM Command 18.21
IEEE C37.118 Synchrophasor Protocol 18.23
SEL Fast Message Synchrophasor Protocol 18.29
Control Capabilities 18.33
PMU Recording Capabilities 18.42

Section 19: Digital Secondary Systems

Time-Domain Link (TiDL) 19.1
IEC 61850-9-2 Sampled Values (SV) 19.23

Appendix A: Manual Versions

Appendix B: Firmware Upgrade Instructions

Upgrading With Digitally Signed Firmware Upgrade Files B.3
Relay Firmware Upgrade Procedure B.4
Verify IEC 61850 Operation (Optional) B.22
Time-Domain Link (TiDL) Centrally Controlled Firmware Upgrade (For Relays Supporting T-Protocol) B.23
Return Relay to Service B.24
Troubleshooting B.24
Technical Support B.26

Appendix C: Cybersecurity Features

Ports and Services C.1
Authentication and Authorization Controls C.2
Malware Protection Features C.3
Logging Features C.3
Physical Access Security C.4
Configuration Control Support C.4
Backup and Restore C.5
Decommissioning C.5
Vulnerability Notification Process C.5

Glossary

List of Tables

Table 2.1 SEL Software 2.1
Table 2.2 Minimum Requirements 2.2
Table 2.3 Differences Between Admin Install and User Install 2.2
Table 2.4 QuickSet Submenu Options 2.21
Table 2.5 QuickSet HMI Tree View Functions 2.30
Table 2.6 Accessing QuickSet Help 2.34
Table 3.1 General Serial Port Settings 3.4
Table 3.2 SEL-400 Series Relays Access Levels 3.8
Table 3.3 Access Level Commands and Passwords 3.8
Table 3.4 SEL-451 Settings Classes and Instances 3.17
Table 3.5 Actions at Settings Prompts 3.21
Table 3.6 Actions at Text-Edit Mode Prompts 3.23
Table 3.7 Phase-Instantaneous Overcurrent Pickup 3.43
Table 3.8 Control Input Characteristics 3.62
Table 3.9 Communications Port Commands That Clear Relay Buffers 3.66
Table 4.1 Front-Panel Inactivity Time-Out Setting 4.4
Table 4.2 SER Point Settings 4.8
Table 4.3 Display Point Settings—Boolean 4.11
Table 4.4 Display Point Settings—Analog 4.11
Table 4.5 Display Point Settings—Boolean and Analog Examples 4.11
Table 4.6 Front-Panel Pushbutton Functions While Viewing SER Events 4.18
Table 4.7 Local Bit Control Settings 4.24
Table 4.8 Local Bit SELOGIC 4.24
Table 4.9 Settings Available From the Front Panel 4.26
Table 5.1 Circuit Breaker and Disconnect Switch Definitions 5.14
Table 5.2 Circuit Breaker State Representations 5.15
Table 5.3 Disconnect Switch State Representations 5.15
Table 5.4 Three-Position Disconnect Switch State Representations 5.26
Table 5.5 Three-Position Disconnect Switch Control Screen Status and Control Options 5.27
Table 5.6 Application Example Bay Control Settings for Bus 1, Bus 2, and Transfer Bus Bay With Ground Switch Application 5.43
Table 5.7 Application Example Front Panel Settings 5.45
Table 5.8 Application Example Output Settings, Output SELOGIC Control Equations 5.45
Table 6.1 Autoreclose Logical States for Circuit Breaker 1 ....6.4
Table 6.2 One-Circuit-Breaker Three-Pole Reclosing Initial Settings 6.8
Table 6.3 One-Circuit-Breaker Single-Pole Reclose Initial Settings 6.8
Table 6.4 One Circuit Breaker Modes of Operation 6.9
Table 6.5 Dynamic Leader/Follower Settings 6.16
Table 6.6 Leader/Follower Selection 6.17
Table 6.7 Example One: Reset and 79CY3 States 6.18
Table 6.8 Example One: Lockout State 6.18
Table 6.9 Example One: Reset State After Reclaim Time 6.18
Table 6.10 Leader/Follower Selection 6.19
Table 6.11 Example Two: Initial Reset State 6.19
Table 6.12 Example Two: Final Reset State 6.20
Table 6.13 Leader/Follower Selection 6.20
Table 6.14 Example Three: Reset State 6.20
Table 6.15 Example Three: Three-Pole Cycle State 6.21
Table 6.16 Example Three: Lockout State, BK 6.21
Table 6.17 Leader/Follower Selection 6.21
Table 6.18 Two Circuit Breakers: Circuit Breaker BK1 Out of Service 6.22
Table 6.19 Two-Circuit-Breaker Three-Pole Reclose Initial Settings 6.22
Table 6.20 Two-Circuit-Breaker Single-Pole Reclose Initial Settings 6.23

Table 6.21 Circuit Breaker BK1 Modes of Operation 6.23
Table 6.22 Circuit Breaker BK2 Modes of Operation 6.24
Table 6.23 Trip Logic Enable Options 6.25
Table 6.24 Autoreclose Logic Relay Word Bits 6.45
Table 7.1 MET Command 7.1
Table 7.2 Instantaneous Metering Accuracy—Voltages, Currents, and Frequency 7.3
Table 7.3 Instantaneous Metering Accuracy—Power 7.4
Table 7.4 Rolling Demand Calculations 7.7
Table 7.5 Information Available With the MET ANA Command 7.13
Table 8.1 Circuit Breaker Monitor Configuration 8.2
Table 8.2 Circuit Breaker Maintenance Information—Example 8.3
Table 8.3 Contact Wear Monitor Settings—Circuit Breaker 1 ....8.4
Table 8.4 Circuit Breaker Monitor Initiate SELOGIC Control Equations 8.7
Table 8.5 Circuit Breaker Monitor Close SELOGIC Control Equations 8.9
Table 8.6 BRE Command 8.18
Table 8.7 DC Monitor Settings and Relay Word Bit Alarms 8.22
Table 8.8 Example DC Battery Voltage Conditions 8.23
Table 8.9 Example DC Battery Monitor Settings—125 Vdc for Vdc1 and 48 Vdc for Vdc2 ....8.23
Table 8.10 Example DC Battery Monitor Settings—AC Ripple Voltages 8.24
Table 8.11 Example DC Battery Monitor Settings—Ground Detection Factor (EGADVS := Y) 8.25
Table 9.1 SUM Command 9.26
Table 9.2 HIS Command 9.28
Table 9.3 SER Commands 9.30
Table 10.1 Acceptance Testing 10.2
Table 10.2 Commissioning Testing 10.2
Table 10.3 Maintenance Testing 10.3
Table 10.4 Selectable Operating Quantity Time-Overcurrent Element (51S1) Test Settings 10.9
Table 10.5 Data Transmitted in GOOSE and SV Messages 10.12
Table 10.6 Message Quality Test and Simulation Flag 10.15
Table 10.7 Secondary Quantities for the SEL-401, SEL-421-7, and SEL-451-6 SV Publishers 10.16
Table 10.8 Alarm Relay Word Bits 10.19
Table 10.9 Troubleshooting Procedures 10.23
Table 10.10 Troubleshooting for Relay Self-Test Warnings and Failures 10.25
Table 11.1 Relay Timekeeping Modes 11.2
Table 11.2 PTPPORT Synchronized to the Best PTP Master 11.4
Table 11.3 CUR_SRC Encoding 11.5
Table 11.4 Time Quality Encoding (IRIG) 11.5
Table 11.5 Time Quality Encoding (PTP) 11.6
Table 11.6 Date/Time Last Update Sources 11.8
Table 11.7 SEL-421 Voltage and Current Measurement 11.12
Table 12.1 Typical Settings Classes and Instances 12.2
Table 12.2 Definitions for Active Setting Group Indication Relay Word Bits SG1 Through SG6 ....12.4
Table 12.3 Definitions for Active Setting Group Switching SELOGIC Control Equation Settings SS1 Through SS6 ....12.5
Table 12.4 Port Settings Categories 12.6
Table 12.5 Protocol Selection (Serial) 12.7
Table 12.6 Communications Settings 12.8
Table 12.7 SEL Protocol Settings 12.8
Table 12.8 Fast Message Read Data Access 12.8
Table 12.9 DNP Configuration (Serial) 12.9
Table 12.10 MIRRORED BITS Protocol Settings 12.10
Table 12.11 RTD Protocol Settings 12.11
Table 12.12 PMU Protocol Settings 12.11
Table 12.13 Protocol Selection (Ethernet) 12.11
Table 12.14 IP/Network Configuration 12.12
Table 12.15 FTP Configuration 12.12
Table 12.16 HTTP Server Configuration 12.12
Table 12.17 Telnet Configuration 12.12

Table 12.18 IEC 61850 Configuration 12.13
Table 12.19 IEC 61850 Mode/Behavior Configuration 12.13
Table 12.20 SV Transmit Configuration 12.13
Table 12.21 SV Receive Configuration 12.13
Table 12.22 IEC SV Channel Settings 12.14
Table 12.23 DNP Configuration (Ethernet) 12.14
Table 12.24 Phasor Measurement Configuration 12.15
Table 12.25 SNTP Selection 12.15
Table 12.26 PTP Settings 12.16
Table 12.27 Protocol Selection (Five-Port Ethernet Card) 12.16
Table 12.28 IP/Network Configuration 12.17
Table 12.29 FTP Configuration (Five-Port Ethernet Card) 12.17
Table 12.30 HTTP Server Configuration (Five-Port Ethernet Card) 12.18
Table 12.31 Telnet Configuration (Five-Port Ethernet Card) 12.18
Table 12.32 Phasor Measurement Configuration (Five-Port Ethernet Card) 12.18
Table 12.33 PTP Settings (Five-Port Ethernet Card) 12.19
Table 12.34 DNP3 Settings Categories 12.19
Table 12.35 Minimum and Maximum Fault Location 12.20
Table 12.36 DNP3 Map Category Headers 12.20
Table 12.37 Front-Panel Settings Categories 12.20
Table 12.38 Front-Panel Settings 12.21
Table 12.39 Selectable Screens for the Front Panel 12.23
Table 12.40 Selectable Operator Pushbuttons 12.24
Table 12.41 Front-Panel Event Display 12.24
Table 12.42 Local Bit SELOGIC 12.25
Table 12.43 SER Parameters 12.25
Table 12.44 Output Settings Categories 12.26
Table 12.45 Remote Analog Outputs 12.27
Table 12.46 MIRRORED BITS Transmit Equations 12.27
Table 12.47 87L Communications Bits 12.27
Table 12.48 Report Settings Categories 12.28
Table 12.49 SER Chatter Criteria 12.28
Table 12.50 Signal Profile 12.28
Table 12.51 Event Reporting 12.28
Table 13.1 Summary of SELOGIC Control Equation Elements 13.9
Table 13.2 First Execution Bit Operation on Startup 13.10
Table 13.3 First Execution Bit Operation on Automation Settings Change 13.10
Table 13.4 First Execution Bit Operation on Protection Settings Change, Group Switch, and Source Selection 13.10
Table 13.5 SELOGIC Control Equation Boolean Variable Quantities 13.10
Table 13.6 SELOGIC Control Equation Math Variable Quantities 13.11
Table 13.7 Latch Bit Quantities 13.12
Table 13.8 Latch Bit Parameters 13.13
Table 13.9 Conditioning Timer Quantities 13.16
Table 13.10 Conditioning Timer Parameters 13.16
Table 13.11 Sequencing Timer Quantities 13.19
Table 13.12 Sequencing Timer Parameters 13.20
Table 13.13 Counter Quantities 13.22
Table 13.14 Counter Parameters 13.22
Table 13.15 Operator Precedence From Highest to Lowest 13.24
Table 13.16 Boolean Operator Summary 13.25
Table 13.17 Parentheses Operation in Boolean Equation 13.25
Table 13.18 NOT Operator Truth Table 13.26
Table 13.19 AND Operator Truth Table 13.26
Table 13.20 OR Operator Truth Table 13.26
Table 13.21 Comparison Operations 13.28
Table 13.22 Math Operator Summary 13.29
Table 13.23 Math Error Examples 13.30

Table 13.24 SEL-351 Series Relays and SEL-400 Series SELOGIC Control Equation Programming Equivalent Functions 13.37
Table 13.25 SEL-400 Series SELOGIC Control Equation Programming Summary 13.37
Table 13.26 SEL-351 Series Relays and SEL-400 Series SELOGIC Control Equation Boolean Operators 13.37
Table 14.1 2AC Command 14.1
Table 14.2 89CLOSE n Command 14.2
Table 14.3 89OPEN n Command 14.3
Table 14.4 AAC Command 14.3
Table 14.5 ACC Command 14.3
Table 14.6 BAC Command 14.3
Table 14.7 BNA Command 14.4
Table 14.8 BRE n Command 14.4
Table 14.9 BRE n C and BRE n R Commands 14.4
Table 14.10 BRE C A and BRE R A Commands 14.5
Table 14.11 BRE n H Command 14.5
Table 14.12 BRE n P Command 14.5
Table 14.13 CAL Command 14.5
Table 14.14 CAS Command 14.6
Table 14.15 CBR Command 14.6
Table 14.16 CBR TERSE Command 14.6
Table 14.17 CEV Command 14.7
Table 14.18 CEV ACK Command 14.7
Table 14.19 CEV C Command 14.7
Table 14.20 CEV L Command 14.8
Table 14.21 CEV Lyyy Command 14.8
Table 14.22 CEV N Command 14.8
Table 14.23 CEV NSET Command 14.8
Table 14.24 CEV NSUM Command 14.9
Table 14.25 CEV Sx Command 14.9
Table 14.26 CEV TERSE Command 14.9
Table 14.27 CEV Command Option Groups 14.10
Table 14.28 CFG CTNOM Command 14.10
Table 14.29 CFG NFREQ Command 14.11
Table 14.30 CHI Command 14.11
Table 14.31 CHI TERSE Command 14.11
Table 14.32 CLOSE n Command 14.12
Table 14.33 COM c Command 14.12
Table 14.34 COM c C and COM c R Command 14.13
Table 14.35 COM c L Command 14.13
Table 14.36 COM HSR Command 14.14
Table 14.37 COM PRP Command 14.15
Table 14.38 COM PTP Command 14.16
Table 14.39 COM RTC Command 14.17
Table 14.40 COM RTC c C and COM RTC c R Command 14.18
Table 14.41 COM SV Command (SEL SV Publishers) 14.18
Table 14.42 Accessible Information for Each SV Publication 14.18
Table 14.43 COM SV Command (SEL SV Subscribers) 14.20
Table 14.44 Accessible Information for Each IEC 61850 SV Subscription 14.21
Table 14.45 Warning and Error Codes for SV Subscriptions 14.22
Table 14.46 Quality Bits in an IEC SV Message 14.23
Table 14.47 CON nn Command 14.25
Table 14.48 COPY Command 14.26
Table 14.49 CPR Command 14.27
Table 14.50 CSE Command 14.27
Table 14.51 CSE TERSE Command 14.28
Table 14.52 CST Command 14.29
Table 14.53 CSU Command 14.29

Table 14.54 CEV ACK Command 14.29
Table 14.55 CSU MB Command....14.29
Table 14.56 CSU N Command....14.30
Table 14.57 CSU TERSE Command....14.30
Table 14.58 DATE Command....14.30
Table 14.59 DNA Command....14.31
Table 14.60 DNP Command....14.31
Table 14.61 ETH Command....14.31
Table 14.62 ETH C and ETH R Command....14.33
Table 14.63 EVE Command....14.33
Table 14.64 EVE A Command....14.33
Table 14.65 EVE ACK Command 14.34
Table 14.66 EVE C Command 14.34
Table 14.67 EVE D Command....14.34
Table 14.68 EVE L Command 14.35
Table 14.69 EVE Lyyy Command 14.35
Table 14.70 EVE N Command....14.35
Table 14.71 EVE NSET Command....14.35
Table 14.72 EVE NSUM Command 14.36
Table 14.73 EVE Sx Command....14.36
Table 14.74 EVE Command Option Groups 14.36
Table 14.75 EVE Command Examples 14.37
Table 14.76 EXIT Command 14.37
Table 14.77 FILE Command 14.37
Table 14.78 GOOSE Command 14.38
Table 14.79 Accessible GOOSE IED Information....14.38
Table 14.80 Warning and Error Codes for GOOSE Subscriptions 14.38
Table 14.81 GOO S Command....14.39
Table 14.82 GROUP Command 14.41
Table 14.83 HELP Command....14.41
Table 14.84 HIS Command 14.42
Table 14.85 HIS C and HIS R Commands 14.42
Table 14.86 HIS CA and HIS RA Commands 14.42
Table 14.87 ID Command 14.43
Table 14.88 IRIG Command 14.44
Table 14.89 LOOP Command 14.45
Table 14.90 LOOP DATA Command 14.45
Table 14.91 LOOP R Command 14.46
Table 14.92 MAC Command 14.46
Table 14.93 MAP 1 Command....14.47
Table 14.94 MAP 1 region Command....14.47
Table 14.95 MET AMV Command....14.47
Table 14.96 MET ANA Command 14.48
Table 14.97 MET BAT Command 14.48
Table 14.98 MET D Command 14.48
Table 14.99 MET M Command....14.49
Table 14.100 MET PM Command 14.49
Table 14.101 MET PMV Command 14.50
Table 14.102 MET RTC Command 14.50
Table 14.103 MET T Command....14.51
Table 14.104 OAC Command 14.51
Table 14.105 OPEN n Command 14.51
Table 14.106 PAC Command....14.52
Table 14.107 PAS level New_Password Command....14.52
Table 14.108 PING Command 14.53
Table 14.109 PORT p Command 14.53
Table 14.110 PORT KILL n Command 14.54
Table 14.111 PRO Command....14.54

Table 14.112 PUL OUTnnn Command 14.55
Table 14.113 QUIT Command 14.55
Table 14.114 RTC Command 14.56
Table 14.115 SER Command 14.56
Table 14.116 SER C and SER R Commands 14.57
Table 14.117 SER CA and SER RA Commands 14.57
Table 14.118 SER CV or SER RV Commands 14.57
Table 14.119 SER D Command 14.58
Table 14.120 SET Command Overview 14.58
Table 14.121 SET TERSE Command Examples 14.59
Table 14.122 SHO Command Overview 14.60
Table 14.123 SNS Command 14.60
Table 14.124 STA Command 14.60
Table 14.125 STA A Command 14.61
Table 14.126 STA C and STA R Command 14.61
Table 14.127 STA S Command 14.61
Table 14.128 STA SC and STA SR Command 14.61
Table 14.129 STA T Command 14.62
Table 14.130 STA T SEL-TMU Error Messages and User Action 14.62
Table 14.131 SUM Command 14.62
Table 14.132 SUM ACK Command 14.63
Table 14.133 SUM N Command 14.63
Table 14.134 TAR Command 14.63
Table 14.135 TAR ALL Command 14.64
Table 14.136 TAR R Command 14.64
Table 14.137 TAR X Command 14.64
Table 14.138 TEC Command 14.65
Table 14.139 TEST DB Command 14.66
Table 14.140 TEST DB OFF Command 14.66
Table 14.141 TEST DB2 Command 14.67
Table 14.142 TEST DB2 OFF Command 14.67
Table 14.143 TEST FM Command 14.68
Table 14.144 TEST FM DEM Command 14.68
Table 14.145 TEST FM OFF Command 14.69
Table 14.146 TEST FM PEAK Command 14.69
Table 14.147 TEST SV Command in an SEL SV Publisher 14.69
Table 14.148 SV Output Values During TEST SV Mode 14.70
Table 14.149 Secondary Values Used During TEST SV Mode 14.70
Table 14.150 TEST SV Command in an SEL SV Subscriber 14.71
Table 14.151 TIME Command 14.72
Table 14.152 TIME Q Command 14.72
Table 14.153 TIME DST Command 14.73
Table 14.154 TRI Command 14.73
Table 14.155 VEC Command 14.73
Table 14.156 VER Command 14.74
Table 14.157 VIEW 1 Commands—Region 14.75
Table 14.158 VIEW 1 Commands—Register Item 14.75
Table 14.159 VIEW 1 Commands—Bit 14.76
Table 15.1 Relay Communications Protocols 15.1
Table 15.2 EIA-232 Pin Assignments 15.3
Table 15.3 Hardware Handshaking 15.5
Table 15.4 Ethernet Protocol Options 15.7
Table 15.5 CIDR Notation 15.8
Table 15.6 Default Router Address Setting Examples 15.9
Table 15.7 SFP Transceivers for the Five-Port Ethernet Card 15.10
Table 15.8 Virtual File Structure 15.21
Table 15.9 Typical Settings Directory Files 15.23
Table 15.10 REPORTS Directory Files 15.24

Table 15.11 C37.111-1999 COMTRADE Event File Names 15.25
Table 15.12 C37.111-2013 COMTRADE Event File Names 15.25
Table 15.13 EVENTS Directory Files (for Event 10001) 15.26
Table 15.14 SYNCHROPHASORS Directory File Sample 15.27
Table 15.15 UPGRADE Directory File Sample 15.27
Table 15.16 FTP and MMS Wildcard Usage Examples 15.27
Table 15.17 Ymodem Wildcard Usage Examples 15.28
Table 15.18 Supported Serial Command Sets 15.28
Table 15.19 Selected ASCII Control Characters 15.29
Table 15.20 Typical Compressed ASCII Commands 15.31
Table 15.21 Fast Commands and Response Descriptions 15.34
Table 15.22 Fast Operate Command Types 15.35
Table 15.23 Fast Message Command Function Codes Used With Fast Messages (A546 Message) and Relay Response Descriptions 15.35
Table 15.24 Commands in Recommended Sequence for Automatic Configuration 15.36
Table 15.25 MIRRORED BITS Communications Features 15.36
Table 15.26 General Port Settings Used With MIRRORED BITS Communications 15.41
Table 15.27 MIRRORED BITS Communications Protocol Settings 15.42
Table 15.28 MIRRORED BITS Communications Message Transmission Period 15.42
Table 15.29 MIRRORED BITS Communications ID Settings for Three-Terminal Application 15.43
Table 15.30 RTD Status Bits 15.44
Table 15.31 MET T Command Status Messages 15.45
Table 15.32 SEL-421 Port 5 Direct Networking Settings 15.46
Table 16.1 DNP3 Implementation Levels 16.1
Table 16.2 Selected DNP3 Function Codes 16.2
Table 16.3 DNP3 Access Methods 16.4
Table 16.4 TCP/UDP Selection Guidelines 16.7
Table 16.5 Relay DNP3 Feature Summary 16.7
Table 16.6 DNP3 Access Methods 16.8
Table 16.7 Relay Event Buffer Capacity 16.9
Table 16.8 Relay DNP3 Object List 16.12
Table 16.9 Relay DNP3 Reference Data Map 16.18
Table 16.10 Sample Custom DNP3 Analog Input Map 16.25
Table 16.11 DNP3 Application Example Data Map 16.27
Table 16.12 SEL-421 PORT 3 Example Settings 16.29
Table 16.13 DNP3 Application Example Data Map 16.31
Table 16.14 DNP3 LAN/WAN Application Example Protocol Settings 16.32
Table 17.1 IEC 61850 Document Set 17.2
Table 17.2 Relay Common Data Classes 17.3
Table 17.3 Example IEC 61850 Descriptor Components 17.5
Table 17.4 Relay Logical Devices 17.7
Table 17.5 CILO Logical Node EnaOpn and EnaCls Equations 17.13
Table 17.6 Originator Categories 17.14
Table 17.7 Control Authority Attributes 17.15
Table 17.8 Control Authority Settings–MLTLEV Set to FALSE 17.15
Table 17.9 Control Authority Settings–MLTLEV Set to TRUE 17.16
Table 17.10 AddCause Descriptions 17.17
Table 17.11 Service Tracking Data Objects 17.19
Table 17.12 IEC 61850 Service Type Enumeration 17.19
Table 17.13 IEC 61850 ACSI Service Error 17.19
Table 17.14 Unbuffered Report Control Block Client Access 17.21
Table 17.15 Buffered Report Control Block Client Access 17.23
Table 17.16 Mechanism of Determining smpSynch Values With an IRIG-B Time Source 17.31
Table 17.17 Mechanism of Determining smpSynch Values With a PTP Time Source 17.31
Table 17.18 IEC 61850 Services Available Based on Mode/Behavior 17.39
Table 17.19 Analog Quantity I850MOD Status Based on the Selected IEC 61850 Mode/Behavior 17.39
Table 17.20 IEC 61850 Incoming Message Handling in On Mode 17.42
Table 17.21 IEC 61850 Outgoing Message Handling in On Mode 17.42

Table 17.22 IEC 61850 Incoming Message Handling in Test Mode 17.43
Table 17.23 IEC 61850 Outgoing Message Handling in Test Mode 17.43
Table 17.24 IEC 61850 Incoming Message Handling in Off Mode....17.45
Table 17.25 IEC 61850 Outgoing Message Handling in Off Mode....17.45
Table 17.26 Output Contact Behavior for IEC 61850 Modes Following a Power Cycle 17.46
Table 17.27 Secondary Quantities for the SEL SV Publishers 17.47
Table 17.28 Logical Device: CFG (Configuration)....17.55
Table 17.29 Logical Device: CON (Remote Control)....17.62
Table 17.30 Logical Device: ANN (Annunciation)....17.67
Table 17.31 SEL Nameplate Data 17.83
Table 17.32 PICS for A-Profile Support 17.84
Table 17.33 PICS for T-Profile Support....17.84
Table 17.34 MMS Service Supported Conformance....17.84
Table 17.35 MMS Parameter CBB....17.87
Table 17.36 AlternateAccessSelection Conformance Statement 17.87
Table 17.37 VariableAccessSpecification Conformance Statement 17.87
Table 17.38 VariableSpecification Conformance Statement....17.88
Table 17.39 Read Conformance Statement 17.88
Table 17.40 GetVariableAccessAttributes Conformance Statement....17.88
Table 17.41 DefineNamedVariableList Conformance Statement 17.88
Table 17.42 GetNamedVariableListAttributes Conformance Statement 17.88
Table 17.43 DeleteNamedVariableList Conformance Statement....17.89
Table 17.44 GOOSE Conformance 17.89
Table 17.45 Basic Conformance Statement....17.89
Table 17.46 ACSI Models Conformance Statement 17.90
Table 17.47 ACSI Service Conformance Statement 17.91
Table 18.1 Synchrophasor Analog Quantities Frequency 18.6
Table 18.2 Global Settings for Configuring the PMU....18.7
Table 18.3 Serial PORT 1, PORT 2, PORT 3, PORT F Settings for Synchrophasors....18.13
Table 18.4 User-Defined Analog Values Selected by NUMANA Setting....18.17
Table 18.5 User-Defined Digital Status Words Selected by the NUMDSW Setting....18.17
Table 18.6 Synchrophasor Trigger Relay Word Bits 18.18
Table 18.7 Time-Synchronization Relay Word Bits 18.18
Table 18.8 Synchrophasor Client Status Bits for Real-Time Control 18.19
Table 18.9 Remote Synchrophasor Data Bits for Real-Time Control....18.19
Table 18.10 Synchrophasor Analog Quantities 18.20
Table 18.11 Synchrophasor Aligned Analog Quantities for Real-Time Control 18.20
Table 18.12 Size of a IEEE C37.118 Synchrophasor Message....18.24
Table 18.13 Serial Port Bandwidth for Synchrophasors (in Bytes)....18.24
Table 18.14 Example Synchrophasor Global Settings 18.28
Table 18.15 Example Synchrophasor Protection Freeform Logic Settings 18.29
Table 18.16 Example Synchrophasor Port Settings 18.29
Table 18.17 Fast Message Command Function Codes for Synchrophasor Fast Write....18.30
Table 18.18 PMU Settings in the Relay for SEL Fast Message Protocol (in Global Settings)....18.30
Table 18.19 Size of an SEL Fast Message Synchrophasor Message....18.31
Table 18.20 Serial Port Bandwidth for Synchrophasors (in Bytes)....18.31
Table 18.21 Serial Port Settings for RTC....18.36
Table 18.22 Global Settings for RTC 18.37
Table 18.23 Synchrophasor Client Status Bits 18.37
Table 18.24 Remote Synchrophasor Data Bits....18.38
Table 18.25 PMU Recording Settings 18.43
Table 19.1 SEL DSS Technologies 19.1
Table A.1 Instruction Manual Revision History A.1
Table B.1 SEL-400 Series Relays Supporting Ethernet Firmware Upgrades....B.3
Table B.2 Firmware Upgrade Files B.4
Table B.3 Firmware Upgrade Scenarios and Available Methods B.5
Table B.4 Ethernet Firmware Upgrade User Messages B.19

Table C.1 IP Port Numbers C.1

This page intentionally left blank

List of Figures

Figure 2.1 Select Typical to Accept All Default Installation Options or Select Custom to View or Modify Them 2.3
Figure 2.2 Select the Install Location for SEL Grid Configurator....2.3
Figure 2.3 Select the Install Location for the ACSELERATOR Database....2.4
Figure 2.4 SEL Grid Configurator Installation Completed Successfully 2.4
Figure 2.5 Option to Remove Database Data on Uninstallation (User Install Only)....2.6
Figure 2.6 Add a New Device Project 2.6
Figure 2.7 New Device in the System Explorer....2.7
Figure 2.8 Protection Elements View 2.7
Figure 2.9 Settings Grid View 2.8
Figure 2.10 Editing Settings and Automatic Validation 2.9
Figure 2.11 Viewing Project Notifications 2.9
Figure 2.12 Configuring Communications Options....2.10
Figure 2.13 Configuring Security Options....2.10
Figure 2.14 Connecting to a Device....2.10
Figure 2.15 Device Commands Menu for Connected Devices....2.11
Figure 2.16 Title Bar During Settings Deployment....2.11
Figure 2.17 Opening the Send Report....2.11
Figure 2.18 SEL Grid Configurator User Interface Overview....2.13
Figure 2.19 Dark Theme 2.13
Figure 2.20 SEL Grid Configurator Report Retrieval....2.14
Figure 2.21 QuickSet Communication Parameters Dialog Box 2.16
Figure 2.22 QuickSet Database Manager Relay Database....2.18
Figure 2.23 QuickSet Database Manager Copy/Move 2.19
Figure 2.24 QuickSet Software Driver Information in the FID String....2.20
Figure 2.25 Relay Settings Driver Version Number 2.20
Figure 2.26 Retrieving the Device Part Number....2.22
Figure 2.27 Setting the Relay Part Number in QuickSet 2.23
Figure 2.28 Station DC Settings 2.24
Figure 2.29 Enable EDCMON in Global Settings....2.24
Figure 2.30 DC Monitor Settings Enabled....2.25
Figure 2.31 QuickSet Settings Editor 2.26
Figure 2.32 Ellipsis Button 2.27
Figure 2.33 Location of Ellipsis Button....2.28
Figure 2.34 QuickSet Expression Builder....2.29
Figure 2.35 Virtual Relay Front Panel 2.30
Figure 2.36 Control Window 2.32
Figure 2.37 Retrieving an Event History 2.34
Figure 3.1 Sample Relay Serial Number Label 3.2
Figure 3.2 PORT F, LCD, and Navigation Pushbuttons....3.3
Figure 3.3 Report Header....3.5
Figure 3.4 HTTP Server Login Screen 3.6
Figure 3.5 Example HTTP Server Meter Page 3.7
Figure 3.6 Access Level Structure 3.8
Figure 3.7 Port Access Control Flow Chart....3.10
Figure 3.8 Relay Status 3.13
Figure 3.9 Relay Status 3.14
Figure 3.10 Retrieving Relay Status in QuickSet 3.14
Figure 3.11 Checking Relay Status From the Front-Panel LCD 3.15
Figure 3.12 Example Relay Settings Structure Overview 3.17
Figure 3.13 Default Alias Settings....3.19

Figure 3.14 Using Text-Edit Mode Line Editing to Set Aliases 3.20
Figure 3.15 Using Text-Edit Mode Line Editing to Set Protection Logic 3.20
Figure 3.16 Components of SET Commands 3.21
Figure 3.17 Example Global Settings 3.22
Figure 3.18 Using Text-Edit Mode Line Editing to Set Display Points 3.25
Figure 3.19 Leave a Note in the Relay 3.27
Figure 3.20 Read a Note in the Relay 3.27
Figure 3.21 Using Text-Edit Mode Line Editing to Delete a Display Point 3.28
Figure 3.22 DATE and TIME Settings From Front-Panel LCD 3.30
Figure 3.23 SET/SHOW Menus 3.33
Figure 3.24 Setting ESS in the Terminal 3.35
Figure 3.25 Setting CTRW and PTRY in the Terminal 3.35
Figure 3.26 Test Connections Using Three Voltage Sources/Three Current Sources 3.36
Figure 3.27 Test Connections Using Two Current Sources for Three-Phase Faults and METER Test 3.36
Figure 3.28 Terminal Screen MET Metering Quantities 3.37
Figure 3.29 Global Alternate Source Selection Settings in QuickSet 3.38
Figure 3.30 Group 1 Terminal Configuration Settings in QuickSet 3.39
Figure 3.31 HMI Phasors View in QuickSet 3.40
Figure 3.32 Instantaneous Metering Quantities in QuickSet HMI 3.41
Figure 3.33 Front-Panel Screens for METER 3.42
Figure 3.34 Sample Targets Display on a Serial Terminal 3.43
Figure 3.35 Viewing Relay Word Bits From the Front-Panel LCD 3.44
Figure 3.36 Sample HIS Command Output in the Terminal 3.47
Figure 3.37 EVENTS Folder Files 3.48
Figure 3.38 Sample Event Oscillogram 3.49
Figure 3.39 Selecting SER Points and Aliases Settings in QuickSet 3.51
Figure 3.40 SER Points and Aliases Settings in QuickSet 3.51
Figure 3.41 Uploading Report Settings to the Relay 3.52
Figure 3.42 Retrieving SER Records With QuickSet 3.53
Figure 3.43 SER Records in the QuickSet HMI 3.53
Figure 3.44 Setting an SER Element: Terminal 3.54
Figure 3.45 Example Reports File Structure 3.55
Figure 3.46 Terminal Display for PULSE Command 3.56
Figure 3.47 Front-Panel Menus for Pulsing OUT104 ....3.57
Figure 3.48 Password Entry Screen 3.58
Figure 3.49 Using Text-Edit Mode Line Editing to Set Local Bit 3 ....3.59
Figure 3.50 Setting Control Output OUT105 in the Terminal 3.60
Figure 3.51 Front-Panel LOCAL CONTROL Screens 3.60
Figure 3.52 Setting 52AA1 in the Terminal 3.63
Figure 3.53 Programming a PSV to Monitor HIRIG in QuickSet 3.65
Figure 4.1 SEL-451 Front Panel (8-Pushbutton Model) 4.2
Figure 4.2 SEL-451 Front Panel (12-Pushbutton Model) with Optional Auxiliary Trip/Close Buttons 4.2
Figure 4.3 SEL-487E Front Panel 4.3
Figure 4.4 LCD and Navigation Pushbuttons 4.4
Figure 4.5 RELAY ELEMENTS Highlighted in Example MAIN MENU 4.5
Figure 4.6 Sample ROTATING DISPLAY 4.6
Figure 4.7 Sample Alarm Points Screen 4.7
Figure 4.8 Deasserted Alarm Point 4.9
Figure 4.9 Clear Alarm Point Confirmation Screen 4.9
Figure 4.10 No Alarm Points Screen 4.9
Figure 4.11 Alarm Points Data Loss Screen 4.10
Figure 4.12 Sample Display Points Screen 4.10
Figure 4.13 Fast Meter Display Points Sample Screen 4.13
Figure 4.14 Contrast Adjustment 4.14
Figure 4.15 Enter Password Screen 4.15
Figure 4.16 Invalid Password Screen 4.15

Figure 4.17 Password Lockout Screen 4.16
Figure 4.18 MAIN MENU 4.16
Figure 4.19 Events Menu Screen 4.17
Figure 4.20 Example EVENT SUMMARY Screens 4.17
Figure 4.21 SER Events Screen 4.18
Figure 4.22 No SER Events Screen 4.18
Figure 4.23 RELAY ELEMENTS Screen 4.19
Figure 4.24 ELEMENT SEARCH Screen 4.20
Figure 4.25 LOCAL CONTROL Initial Menu 4.21
Figure 4.26 Example BREAKER CONTROL Screens 4.22
Figure 4.27 LOCAL CONTROL Example Menus 4.23
Figure 4.28 Local Bit Supervision Logic 4.24
Figure 4.29 OUTPUT TESTING Screen 4.25
Figure 4.30 Example SET/SHOW Screens 4.27
Figure 4.31 Sample Settings Input Screens 4.28
Figure 4.32 Changing the ACTIVE GROUP 4.29
Figure 4.33 DATE/TIME Screen 4.29
Figure 4.34 Edit DATE and Edit TIME Screens 4.30
Figure 4.35 Relay STATUS Screens 4.30
Figure 4.36 DISPLAY TEST Screens 4.31
Figure 4.37 RESET ACCESS LEVEL Screen 4.31
Figure 4.38 One-Line Diagram Screen 4.32
Figure 4.39 Sample Status Warning and Trip EVENT SUMMARY Screens 4.32
Figure 4.40 Sample Status Warning in the LCD Message Area 4.33
Figure 4.41 SEL-451 Factory-Default Front-Panel Target Areas (16 or 24 LEDs) 4.34
Figure 4.42 SEL-451 Default Operator Control Pushbuttons and LEDs (8 or 12 Pushbuttons) 4.35
Figure 5.1 Disconnect Switch Close Logic 5.2
Figure 5.2 Disconnect Switch Open Logic 5.2
Figure 5.3 Disconnect Switch Status and Alarm Logic 5.6
Figure 5.4 Close Immobility Timer Logic 5.8
Figure 5.5 Open Immobility Timer Logic 5.8
Figure 5.6 Disconnect in Transition 5.11
Figure 5.7 SEL-487E Default One-Line Diagram 5.13
Figure 5.8 Bay Control One-Line Diagram 5.13
Figure 5.9 Rack-Type Breaker Mosaics 5.17
Figure 5.10 Screens for Circuit Breaker Selection 5.19
Figure 5.11 Screens During a Pole-Discrepancy Condition 5.20
Figure 5.12 Screens for Disconnect Switch Selection 5.21
Figure 5.13 HMI Disconnect Operation Initiation 5.23
Figure 5.14 HMI Disconnect Operation in Progress 5.24
Figure 5.15 HMI Disconnect Operation Completed 5.25
Figure 5.16 Bay Control One-Line Diagram With Three-Position Disconnect Open 5.25
Figure 5.17 Three-Position Disconnect Control Screens 5.27
Figure 5.18 Bay Control One-Line Diagram With Three-Position Disconnect Closed In-Line 5.28
Figure 5.19 Interactive Bay Control Setting Form 5.29
Figure 5.20 Mimic Diagrams 5.30
Figure 5.21 Local and Remote Control Logic With Key Control 5.31
Figure 5.22 Setting Busbar Names in SEL Grid Configurator 5.31
Figure 5.23 Disconnect Assignment Dialog Box, SW1 ....5.31
Figure 5.24 Breaker Settings, Breaker S 5.33
Figure 5.25 Analog Quantity Setting Form 5.34
Figure 5.26 Analog Quantity Setting Form 5.35
Figure 5.27 Example of an Analog Quantity Expression 5.35
Figure 5.28 Different Types of Circuit Breakers and Disconnects 5.37
Figure 5.29 Power System Components 5.37
Figure 5.30 Illustration of One-Line Diagram After Entering Example Settings 5.38

Figure 5.31 Local and Remote Control Logic With Key Control 5.42
Figure 6.1 Autoreclose State Diagram for Circuit Breaker 1....6.4
Figure 6.2 Multiple Circuit Breaker Arrangement....6.15
Figure 6.3 Multiple Circuit Breaker Arrangement....6.17
Figure 6.4 Leader/Follower Selection by Relay Input....6.22
Figure 6.5 Circuit Breaker Pole-Open Logic Diagram—Single-Pole Relays....6.26
Figure 6.6 Circuit Breaker Pole-Open Logic Diagrams—Three-Pole Relays....6.26
Figure 6.7 Line-Open Logic Diagram When E79 := Y 6.26
Figure 6.8 Line-Open Logic Diagram When E79 := Y1 ....6.27
Figure 6.9 Single-Pole Reclose Enable....6.27
Figure 6.10 Three-Pole Reclose Enable....6.27
Figure 6.11 One Circuit Breaker Single-Pole Cycle State (79CY1)....6.28
Figure 6.12 One Circuit Breaker Three-Pole Cycle State (79CY3)....6.29
Figure 6.13 Two Circuit Breakers Single-Pole Cycle State (79CY1) When E79 := Y 6.30
Figure 6.14 Two Circuit Breakers Single-Pole Cycle State (79CY1) When E79 := Y1 ....6.32
Figure 6.15 Two Circuit Breakers Three-Pole Cycle State (79CY3) When E79 := Y 6.34
Figure 6.16 Two Circuit Breakers Three-Pole Cycle State (79CY3) When E79 := Y1 ....6.37
Figure 6.17 Manual Close Logic....6.41
Figure 6.18 Voltage Check Element Applications....6.43
Figure 6.19 Voltage Check Element Logic (EISYNC := N) 6.44
Figure 6.20 Voltage Check Element Logic (EISYNC := Y) 6.44
Figure 7.1 Complex Power (P/Q) Plane....7.3
Figure 7.2 Typical Current Measuring Accuracy 7.4
Figure 7.3 Thermal Demand Metering 7.7
Figure 7.4 Rolling Demand Metering 7.8
Figure 7.5 Demand Current Logic Outputs 7.9
Figure 7.6 Battery Metering: Terminal 7.11
Figure 7.7 RTD Report 7.12
Figure 7.8 PMV Report....7.12
Figure 7.9 AMV Report 7.13
Figure 8.1 Intelligent Circuit Breaker Monitor....8.2
Figure 8.2 Circuit Breaker Maintenance Curve (Manufacturer's Data) 8.4
Figure 8.3 Circuit Breaker Contact Wear Curve With Relay Settings 8.5
Figure 8.4 Trip Bus Sensing With Relay Input IN206 ....8.8
Figure 8.5 Mechanical Operating Time for Circuit Breaker 1 A-Phase 8.10
Figure 8.6 Electrical Operating Time for Circuit Breaker 1 A-Phase....8.12
Figure 8.7 Timing Illustration for Pole Scatter at Trip 8.13
Figure 8.8 Pole Discrepancy Measurement 8.16
Figure 8.9 SEL-411L Breaker Report (for the Most Recent Operation) 8.19
Figure 8.10 Breaker History Report....8.19
Figure 8.11 Circuit Breaker Preload Data....8.20
Figure 8.12 Typical Station DC Battery System....8.21
Figure 8.13 Ground Detection Factor Areas....8.25
Figure 9.1 Input Processing 9.3
Figure 9.2 Input Processing of SEL-400 Series Relays Supporting DSS Technology....9.5
Figure 9.3 Filtered Current Magnitude With Overcurrent Pickups 9.6
Figure 9.4 Data Capture/Event Report Times....9.9
Figure 9.5 Sample Oscillogram 9.10
Figure 9.6 Sample COMTRADE .HDR Header File....9.11
Figure 9.7 COMTRADE .CFG Configuration File Data....9.12
Figure 9.8 Fixed Analog Section of an Example SEL-421 Event Report 9.16
Figure 9.9 Event Report Current Column Data and RMS Current Magnitude....9.18
Figure 9.10 Event Report Current Column Data and RMS Current Angle 9.20
Figure 9.11 Digital Section of the SEL-411L Event Report....9.22
Figure 9.12 Sample Digital Portion of the Event Report....9.23
Figure 9.13 Example Summary Section of the SEL-411L Event Report 9.24

Figure 9.14 Settings Section of the Event Report 9.24
Figure 9.15 Sample SEL-411L Event History 9.27
Figure 9.16 Sample SER Report 9.29
Figure 9.17 Sample Compressed ASCII SER Report 9.30
Figure 10.1 IEC 61850 Logical Modeling 10.12
Figure 10.2 Isolate an IED Through Use of IEC 61850 Mode/Behavior and Simulation Mode 10.14
Figure 10.3 Inject Simulated Test Signals Through Use of Test Equipment 10.15
Figure 10.4 TEST SV Mode Status in the COM SV Response 10.17
Figure 10.5 TEST SV Mode Indicator 10.17
Figure 10.6 Enter TEST SV Mode in the Relay 10.18
Figure 10.7 TEST SV Mode Indicator 10.18
Figure 10.8 MET Command Response 10.19
Figure 10.9 Relay Status: QuickSet HMI 10.21
Figure 10.10 Relay Status From a STATUS A Command on a Terminal 10.21
Figure 10.11 Example Compressed ASCII Status Message 10.22
Figure 10.12 PS30 Power Supply Fuse Location 10.29
Figure 10.13 SEL-400 Series Relay Rear Panel 10.30
Figure 10.14 Front-Panel Ribbon Cable Connector With Clasps Open 10.31
Figure 10.15 Main Board Cable Connections 10.31
Figure 10.16 I/O Board Jumper Configuration 10.32
Figure 10.17 Screw-Terminal Connector Receptacles 10.32
Figure 10.18 Screw-Terminal Connector Keying 10.33
Figure 10.19 Screw-Terminal Connector With Webs 10.33
Figure 10.20 I/O Board Installation Error Message in the Terminal Window 10.34
Figure 11.1 PTP Time Synchronization Over a PRP Network 11.4
Figure 11.2 Confirming the High-Accuracy Timekeeping Relay Word Bits 11.7
Figure 11.3 TLOCAL and TGLOBAL Logic 11.7
Figure 11.4 Sample TIM Q Command Response 11.8
Figure 11.5 Setting PMV64 With the Expression Builder Dialog Box 11.10
Figure 11.6 230 kV Transmission Line System 11.11
Figure 11.7 500 kV Three-Bus Power System 11.12
Figure 11.8 Power Flow Solution 11.13
Figure 12.1 Typical Relay Settings Structure Overview 12.2
Figure 12.2 Changing a Default Name to an Alias 12.26
Figure 13.1 Protection and Automation Separation 13.2
Figure 13.2 SELOGIC Control Equation Programming Areas 13.3
Figure 13.3 Conditioning Timer With Pickup and No Dropout Timing Diagram 13.16
Figure 13.4 Conditioning Timer With Pickup Not Satisfied Timing Diagram 13.17
Figure 13.5 Conditioning Timer With Dropout and No Pickup Timing Diagram 13.17
Figure 13.6 Conditioning Timer With Pickup and Dropout Timing Diagram 13.18
Figure 13.7 Conditioning Timer Timing Diagram for Example 13.7 ....13.19
Figure 13.8 Sequencing Timer Timing Diagram 13.20
Figure 13.9 R_TRIG Timing Diagram 13.27
Figure 13.10 F_TRIG Timing Diagram 13.28
Figure 14.1 Sample COM HSR Command Response 14.14
Figure 14.2 Sample COM PRP Command Response 14.15
Figure 14.3 Sample COM PTP Command Response 14.16
Figure 14.4 COM SV Command Response When CID Configuration Is Used by the SEL SV Publisher 14.19
Figure 14.5 COM SV Command Response When PORT 5 Settings Are Used by the SEL SV Publisher 14.20
Figure 14.6 COM SV Command Response When CID Configuration Is Used by the SEL SV Subscriber 14.23
Figure 14.7 COM SV Command Response When PORT 5 Settings Are Used by the SEL SV Subscriber 14.24

Figure 14.8 COM SV S ALL L Command Response When CID Configuration Is Used by the SEL SV Subscriber 14.24
Figure 14.9 Sample ETH Command Response for the Two-Port Ethernet Card 14.32
Figure 14.10 Sample ETH Command Response for the Five-Port Ethernet Card 14.32
Figure 14.11 GOOSE Command Response for the Two- or Four-Port Ethernet Card....14.39
Figure 14.12 Example GOO S Command Response 14.40
Figure 14.13 Example GOO S ALL L Command Response 14.40
Figure 14.14 Sample ID Command Response From Ethernet Card 14.44
Figure 14.15 Sample MAC Command Response for the Two- or Four-Port Ethernet Card....14.46
Figure 14.16 Sample MAC Command Response for the Five-Port Ethernet Card 14.46
Figure 14.17 Sample PING Command Response 14.53
Figure 14.18 Sample TIME Q Command Response With IRIG 14.72
Figure 14.19 Sample Time Q Command Response With PTP 14.72
Figure 14.20 Sample VER Command Response 14.74
Figure 15.1 Relay 4U Chassis Front-Panel Layout....15.2
Figure 15.2 Example 4U Rear-Panel Layout in Relay With Bay Cards....15.3
Figure 15.3 EIA-232 Connector Pin Numbers....15.3
Figure 15.4 Example Two-Port Ethernet Card 15.6
Figure 15.5 Example Four-Port Ethernet Card 15.6
Figure 15.6 Five-Port Ethernet Card....15.6
Figure 15.7 Failover Network Topology 15.11
Figure 15.8 Using Internal Ethernet Switch to Add Networked Devices....15.12
Figure 15.9 Example PRP/HSR Network Using SEL-400 Series Relays With Five-Port Ethernet Cards 15.15
Figure 15.10 SEL-2600A RTD Module and the Relay 15.43
Figure 15.11 MET T Command Response 15.44
Figure 15.12 MET T Command Response for Status Problem 15.44
Figure 15.13 Example Direct Networking Topology 15.45
Figure 15.14 Example FTP Session....15.47
Figure 15.15 Partial Contents of SET_P5.TXT 15.48
Figure 15.16 Telnet Connection Dialog Box 15.48
Figure 15.17 Example Telnet Session....15.49
Figure 16.1 DNP3 Multidrop Network Topology 16.4
Figure 16.2 DNP3 Star Network Topology 16.5
Figure 16.3 DNP3 Network With Communications Processor 16.5
Figure 16.4 Sample Response to SHO D Command 16.24
Figure 16.5 Sample Custom DNP3 Analog Input Map Settings 16.26
Figure 16.6 DNP3 Application Network Diagram 16.26
Figure 16.7 SEL-421 Example DNP Map Settings 16.28
Figure 16.8 DNP3 LAN/WAN Application Example Ethernet Network....16.31
Figure 16.9 Add Binary Inputs to SER Point List 16.33
Figure 17.1 Enabling Functional Naming in Architect....17.6
Figure 17.2 Configure Functional Naming in Architect 17.6
Figure 17.3 Server Model View in Architect....17.8
Figure 17.4 Add a Logical Node From the Architect Library 17.8
Figure 17.5 Add Data Objects to a Logical Node....17.9
Figure 17.6 Associate a Data Attribute's Value to a Relay Variable 17.9
Figure 17.7 Data Set Mapping From an FSM Created Attribute....17.10
Figure 17.8 Pulse Behavior in Control Operations 17.12
Figure 17.9 Configure Pulse Control Attributes 17.13
Figure 17.10 CSWI Logical Node Direct Operate Command Request 17.14
Figure 17.11 MMS Client View of the CON Logical Device 17.17
Figure 17.12 Deadband Configuration View for Ed1 and Ed2....17.25
Figure 17.13 Deadband Configuration View for Ed2.1....17.26
Figure 17.14 GOOSE Quality Attributes....17.27
Figure 17.15 Example Current Summation 17.33

Figure 17.16 Example Current-Summation Configuration 17.33
Figure 17.17 Independent Bus Mode With PTP Time Synchronization on the Process Bus 17.35
Figure 17.18 Independent Bus Mode With PTP Time Synchronization on the Station Bus 17.36
Figure 17.19 Independent Bus Mode With IRIG Time Synchronization 17.36
Figure 17.20 Merged Bus Mode With PTP Time Synchronization 17.36
Figure 17.21 Use Ethernet Switch to Engineer Network Path for GOOSE Messages 17.37
Figure 17.22 GOOSE Transmit Interface Selection (Five-Port Ethernet Card) 17.38
Figure 17.23 Set controllableModeSupported = True 17.39
Figure 17.24 Default Quality Check on GOOSE Subscription if Quality Is Present 17.41
Figure 17.25 Relay Operations in On Mode 17.42
Figure 17.26 Relay Operations in Blocked Mode 17.43
Figure 17.27 Relay Operations in Test Mode 17.44
Figure 17.28 Relay Operations in Test/Blocked Mode 17.44
Figure 17.29 Relay Operations in Off Mode 17.45
Figure 17.30 Add ICD to Project Tree 17.48
Figure 17.31 Configure an SV Publication 17.49
Figure 17.32 Example SV Publication Data Set 17.50
Figure 17.33 Configure SV Subscription 17.51
Figure 17.34 Send SEL-401 CID File 17.51
Figure 17.35 Send SEL-421-7 CID File 17.52
Figure 17.36 SEL-401 Publication Status 17.52
Figure 17.37 SEL-421-7 SV Subscription Status 17.52
Figure 18.1 Synchrophasor Processing Block Diagram 18.3
Figure 18.2 Magnitude Frequency Response 18.4
Figure 18.3 TCP Connection 18.14
Figure 18.4 UDP_T and UDP_U Connections 18.15
Figure 18.5 UDP_S Connection 18.15
Figure 18.6 Sample SEL-487E MET PM Command Response 18.22
Figure 18.7 Synchrophasor Control Application 18.34
Figure 18.8 PMU Global Settings 18.35
Figure 18.9 Enabling Fast Operate Messages on PORT 5 ....18.35
Figure 18.10 Ethernet PORT 5 Settings for Communications Using C37.118 Extended Fame 18.35
Figure 18.11 Example COM RTC Command Response 18.38
Figure 18.12 Real-Time Control Application 18.39
Figure 18.13 Local Relay SELOGIC Settings 18.40
Figure 18.14 Remote Relay SELOGIC Settings 18.40
Figure 18.15 Remote Relay Global Settings 18.40
Figure 18.16 Local Relay Global Settings 18.41
Figure 18.17 Remote Relay Port Settings 18.41
Figure 18.18 Local Relay Port Settings 18.41
Figure 18.19 Example COM RTC Command Response 18.42
Figure 19.1 TiDL High-Level Substation Overview 19.2
Figure 19.2 Adding a Device to the SEL Grid Configurator Workspace 19.5
Figure 19.3 Navigating to the TiDL I/O Map Workspace 19.6
Figure 19.4 Configure Port Mapping 19.7
Figure 19.5 Configure I/O Mapping 19.8
Figure 19.6 Configure Device Nominal Secondary Current Configuration 19.9
Figure 19.7 Modifying Nominal Secondary Current Configuration 19.10
Figure 19.8 Binary Input Settings Flow Diagram 19.12
Figure 19.9 Creating Aliases for SEL-TMU I/O 19.13
Figure 19.10 Aliases Shown in TMU I/O Selection Dialog Box 19.14
Figure 19.11 SEL TiDL Relay Commissioning 19.15
Figure 19.12 TiDL Commissioning Report 19.16
Figure 19.13 Sample TiDL System Topology 19.18
Figure 19.14 Rear Panel of Relays With TiDL 19.18
Figure 19.15 Axion Chassis 19.19

Figure 19.16 SEL-2243 Power Coupler 19.19
Figure 19.17 SEL-2244-2 Digital Input Module 19.20
Figure 19.18 SEL-2244-5 Fast High-Current Digital Output Module 19.20
Figure 19.19 SEL-2245-42 AC Analog Input Module 19.21
Figure 19.20 SECINC Setting 19.22
Figure 19.21 SEL-487E Nominal Current Selection 19.22
Figure 19.22 SECINC Disabled 19.23
Figure 19.23 Example SV Network 19.24
Figure 19.24 Example Architect SV Publication Configuration 19.26
Figure 19.25 SEL-421-7 SV Subscriber, 4U Rear Panel 19.27
Figure 19.26 Example Architect SV Subscription Configuration 19.28
Figure B.1 Prepare the Device (Step 1 of 4) B.8
Figure B.2 Load Firmware (Step 2 of 4) B.9
Figure B.3 Load Firmware (Step 3 of 4) B.10
Figure B.4 Verify Device Settings (Step 4 of 4) B.11
Figure B.5 Transferring New Firmware B.14
Figure B.6 Transferring New Firmware B.15
Figure B.7 Firmware Upload File Selection Page B.18
Figure B.8 Firmware Upgrade Confirmation B.19

Preface

This manual provides information and instructions for operating the SEL-400 series relays. This manual is for use by power and integration engineers and others experienced in protective relaying applications and SCADA integration. This manual describes features common to most SEL-400 series relays. Each SEL-400 series product includes its own instruction manual that describes the protection features and unique characteristics of that specific relay.

Manual Overview

This manual is a comprehensive work covering common aspects of SEL-400 series relay application and use. Read the sections that pertain to your application to gain valuable information about using SEL-400 series relays. An overview of each manual section and section topics follows.

Preface. Describes manual organization and conventions used to present information, as well as safety information.

Section 1: Introduction. Introduces SEL-400 series relays common features.

Section 2: PC Software. Explains how to use SEL Grid Configurator and ACSELERATOR QuickSet SEL-5030 Software.

Section 3: Basic Relay Operations. Describes how to perform fundamental operations such as applying power and communicating with the relay, setting and viewing passwords, checking relay status, viewing metering data, reading event reports and Sequential Events Recorder (SER) records, operating relay control outputs and control inputs, and using relay features to make relay commissioning easier.

Section 4: Front-Panel Operations. Describes the LCD messages and menu screens. Shows you how to use front-panel pushbuttons and read targets. Provides information about local substation control and how to make relay settings via the front panel.

Section 5: Control. Describes various control features of the relay, including circuit breaker operation, disconnect operation, remote bits, and one-line diagrams.

Section 6: Autoreclosing. Explains how to operate the two-circuit breaker multishot recloser. Describes how to set the relay for single-pole reclosing, three-pole reclosing, or both. Shows selection of the lead and follow circuit breakers.

Section 7: Metering. Provides information on viewing current, voltage, power, and energy quantities. Describes how to view other common internal operating quantities.

Section 8: Monitoring. Describes how to use the circuit breaker monitors and the substation dc battery monitors.

Section 9: Reporting. Explains how to obtain and interpret high-resolution raw data oscillograms, filtered event reports, event summaries, history reports, and SER reports. Discusses how to enter SER trigger settings.

Section 10: Testing, Troubleshooting, and Maintenance. Describes techniques for testing, troubleshooting, and maintaining the relay. Includes the list of status notification messages and a troubleshooting chart.

Section 11: Time and Date Management. Explains timekeeping principles, synchronized phasor measurements, and estimation of power system states using the high-accuracy time-stamping capability. Presents real-time load flow/power flow application ideas.

Section 12: Settings. Provides a list of all common SEL-400 series relay settings and defaults.

Section 13: SELOGIC Control Equation Programming. Describes multiple setting groups and SELOGIC control equations and how to apply these equations. Discusses expanded SELOGIC control equation features such as PLC-style commands, math functions, counters, and conditioning timers. Provides a tutorial for converting older format SELOGIC control equations to new freeform equations.

Section 14: ASCII Command Reference. Provides an alphabetical listing of all ASCII commands with examples for each ASCII command option.

Section 15: Communications Interfaces. Explains the physical connection of the relay to various communications network topologies. Describes the various software protocols and how to apply these protocols to substation integration and automation. Includes details about Ethernet IP protocols, SEL ASCII, SEL Compressed ASCII, SEL Fast Meter, SEL Fast Operate, SEL Fast SER, and enhanced MIRRORED BITS communications.

Section 16: DNP3 Communication. Describes the DNP3 communications protocol and how to apply this protocol to substation integration and automation. Provides a Job Done example for implementing DNP3 in a substation.

Section 17: IEC 61850 Communication. Describes the IEC 61850 protocol and how to apply this protocol to substation automation and integration. Includes IEC 61850 protocol compliance statements.

Section 18: Synchrophasors. Describes the phasor measurement unit (PMU) functions of the relay. Provides details on synchrophasor measurement and real-time control. Describes the IEEE C37.118 synchrophasor protocol settings. Describes the SEL Fast Message synchrophasor protocol settings.

Section 19: Digital Secondary Systems. Describes the basic concepts of digital secondary systems (DSS). This includes both the Time-Domain Link (TiDL) system and UCA 61850-9-2LE Sampled Values.

Appendix A: Manual Versions. Lists the current manual version and details differences between the current and previous versions.

Appendix B: Firmware Upgrade Instructions. Describes the procedure to update the firmware stored in Flash memory.

Appendix C: Cybersecurity Features. Describes the various features of the relay that impact cybersecurity.

Glossary. Defines various technical terms used in the SEL-400 series instruction manuals.

Safety Information

Dangers, Warnings, and Cautions

This manual uses three kinds of hazard statements, defined as follows:

⚠DANGER
Indicates an imminently hazardous situation that, if not avoided, **will** result in death or serious injury.

⚠WARNING
Indicates a potentially hazardous situation that, if not avoided, **could** result in death or serious injury.

⚠CAUTION
Indicates a potentially hazardous situation that, if not avoided, **may** result in minor or moderate injury or equipment damage.

Safety Symbols

The following symbols are often marked on SEL products.

	⚠CAUTION Refer to accompanying documents.	**⚠ATTENTION** Se reporter à la documentation.
	Earth (ground)	Terre
	Protective earth (ground)	Terre de protection
	Direct current	Courant continu
	Alternating current	Courant alternatif
	Both direct and alternating current	Courant continu et alternatif
	Instruction manual	Manuel d’instructions

Safety Marks

The following statements apply to this device.

General Safety Marks

⚠CAUTION There is danger of explosion if the battery is incorrectly replaced. Replace only with Rayovac no. BR2335 or equivalent recommended by manufacturer. See Owner's Manual for safety instructions. The battery used in this device may present a fire or chemical burn hazard if mistreated. Do not recharge, disassemble, heat above 100°C, or incinerate. Dispose of used batteries according to the manufacturer's instructions. Keep battery out of reach of children.	⚠ATTENTION Une pile remplacée incorrectement pose des risques d'explosion. Remplacez seulement avec un Rayovac no BR2335 ou un produit équivalent recommandé par le fabricant. Voir le guide d'utilisateur pour les instructions de sécurité. La pile utilisée dans cet appareil peut présenter un risque d'incendie ou de brûlure chimique si vous en faites mauvais usage. Ne pas recharger, démonter, chauffer à plus de 100°C ou incinérer. Éliminez les vieilles piles suivant les instructions du fabricant. Gardez la pile hors de la portée des enfants.
⚠CAUTION To ensure proper safety and operation, the equipment ratings, installation instructions, and operating instructions must be checked before commissioning or maintenance of the equipment. The integrity of any protective conductor connection must be checked before carrying out any other actions. It is the responsibility of the user to ensure that the equipment is installed, operated, and used for its intended function in the manner specified in this manual. If misused, any safety protection provided by the equipment may be impaired.	⚠ATTENTION Pour assurer la sécurité et le bon fonctionnement, il faut vérifier les classements d'équipement ainsi que les instructions d'installation et d'opération avant la mise en service ou l'entretien de l'équipement. Il faut vérifier l'intégrité de toute connexion de conducteur de protection avant de réaliser d'autres actions. L'utilisateur est responsable d'assurer l'installation, l'opération et l'utilisation de l'équipement pour la fonction prévue et de la manière indiquée dans ce manuel. Une mauvaise utilisation pourrait diminuer toute protection de sécurité fournie par l'équipement.
For use in Pollution Degree 2 environment.	Pour l'utilisation dans un environnement de Degré de Pollution 2.

Other Safety Marks (Sheet 1 of 3)

⚠DANGER Disconnect or de-energize all external connections before opening this device. Contact with hazardous voltages and currents inside this device can cause electrical shock resulting in injury or death.	⚠DANGER Débrancher tous les raccordements externes avant d'ouvrir cet appareil. Tout contact avec des tensions ou courants internes à l'appareil peut causer un choc électrique pouvant entraîner des blessures ou la mort.
⚠DANGER Contact with instrument terminals can cause electrical shock that can result in injury or death.	⚠DANGER Tout contact avec les bornes de l'appareil peut causer un choc électrique pouvant entraîner des blessures ou la mort.
⚠WARNING Use of this equipment in a manner other than specified in this manual can impair operator safety safeguards provided by this equipment.	⚠AVERTISSEMENT L'utilisation de cet appareil suivant des procédures différentes de celles indiquées dans ce manuel peut désarmer les dispositifs de protection d'opérateur normalement actifs sur cet équipement.
⚠WARNING Have only qualified personnel service this equipment. If you are not qualified to service this equipment, you can injure yourself or others, or cause equipment damage.	⚠AVERTISSEMENT Seules des personnes qualifiées peuvent travailler sur cet appareil. Si vous n'êtes pas qualifiés pour ce travail, vous pourriez vous blesser avec d'autres personnes ou endommager l'équipement.
⚠WARNING This device is shipped with default passwords. Default passwords should be changed to private passwords at installation. Failure to change each default password to a private password may allow unauthorized access. SEL shall not be responsible for any damage resulting from unauthorized access.	⚠AVERTISSEMENT Cet appareil est expédié avec des mots de passe par défaut. A l'installation, les mots de passe par défaut devront être changés pour des mots de passe confidentiels. Dans le cas contraire, un accés non-autorisé á l'équipement peut être possible. SEL décline toute responsabilité pour tout dommage résultant de cet accés non-autorisé.
⚠WARNING Do not look into the fiber ports/connectors.	⚠AVERTISSEMENT Ne pas regarder vers les ports ou connecteurs de fibres optiques.
⚠WARNING Do not look into the end of an optical cable connected to an optical output.	⚠AVERTISSEMENT Ne pas regarder vers l'extrémité d'un câble optique raccordé à une sortie optique.
⚠WARNING Do not perform any procedures or adjustments that this instruction manual does not describe.	⚠AVERTISSEMENT Ne pas appliquer une procédure ou un ajustement qui n'est pas décrit explicitement dans ce manuel d'instruction.
⚠WARNING During installation, maintenance, or testing of the optical ports, use only test equipment qualified for Class 1 laser products.	⚠AVERTISSEMENT Durant l'installation, la maintenance ou le test des ports optiques, utilisez exclusivement des équipements de test homologués comme produits de type laser de Classe 1.

Other Safety Marks (Sheet 2 of 3)

⚠WARNING Incorporated components, such as LEDs and transceivers are not user serviceable. Return units to SEL for repair or replacement.	**⚠AVERTISSEMENT** Les composants internes tels que les leds (diodes électroluminescentes) et émetteurs-récepteurs ne peuvent pas être entretenus par l'usager. Retourner les unités à SEL pour réparation ou remplacement.
⚠CAUTION Equipment components are sensitive to electrostatic discharge (ESD). Undetectable permanent damage can result if you do not use proper ESD procedures. Ground yourself, your work surface, and this equipment before removing any cover from this equipment. If your facility is not equipped to work with these components, contact SEL about returning this device and related SEL equipment for service.	**⚠ATTENTION** Les composants de cet équipement sont sensibles aux décharges électrostatiques (DES). Des dommages permanents non-décelables peuvent résulter de l'absence de précautions contre les DES. Raccordez-vous correctement à la terre, ainsi que la surface de travail et l'appareil avant d'en retirer un panneau. Si vous n'êtes pas équipés pour travailler avec ce type de composants, contacter SEL afin de retourner l'appareil pour un service en usine.
⚠CAUTION Equipment damage can result from connecting ac circuits to Hybrid (high-current interrupting) control outputs. Do not connect ac circuits to Hybrid control outputs. Use only dc circuits with Hybrid control outputs.	**⚠ATTENTION** Des dommages à l'appareil pourraient survenir si un circuit CA était raccordé aux contacts de sortie à haut pouvoir de coupure de type "Hybrid." Ne pas raccorder de circuit CA aux contacts de sortie de type "Hybrid." Utiliser uniquement du CC avec les contacts de sortie de type "Hybrid."
⚠CAUTION Substation battery systems that have either a high resistance to ground (greater than 10 kΩ) or are ungrounded when used in conjunction with many direct-coupled inputs can reflect a dc voltage offset between battery rails. Similar conditions can exist for battery monitoring systems that have high-resistance balancing circuits or floating grounds. For these applications, SEL provides optional ground-isolated (optoisolated) contact inputs. In addition, SEL has published an application advisory on this issue. Contact the factory for more information.	**⚠ATTENTION** Les circuits de batterie de postes qui présentent une haute résistance à la terre (plus grande que 10 kΩ) ou sont isolés peuvent présenter un biais de tension CC entre les deux polarités de la batterie quand utilisés avec plusieurs entrées à couplage direct. Des conditions similaires peuvent exister pour des systèmes de surveillance de batterie qui utilisent des circuits d'équilibrage à haute résistance ou des masses flottantes. Pour ce type d'applications, SEL peut fournir en option des contacts d'entrée isolés (par couplage optoélectronique). De surcroît, SEL a publié des recommandations relativement à cette application. Contacter l'usine pour plus d'informations.
⚠CAUTION If you are planning to install an INT4 I/O interface board in your relay, first check the firmware version of the relay. If the firmware version is R111 or lower, you must first upgrade the relay firmware to the newest version and verify that the firmware upgrade was successful before installing the new board. Failure to install the new firmware first will cause the I/O interface board to fail, and it may require factory service. Complete firmware upgrade instructions are provided when new firmware is ordered.	**⚠ATTENTION** Si vous avez l'intention d'installer une Carte d'Interface INT4 I/O dans votre relais, vérifiez en premier la version du logiciel du relais. Si la version est R111 ou antérieure, vous devez mettre à jour le logiciel du relais avec la version la plus récente et vérifier que la mise à jour a été correctement installée sur la nouvelle carte. Les instructions complètes de mise à jour sont fournies quand le nouveau logiciel est commandé.
⚠CAUTION Field replacement of I/O boards INT1, INT2, INT5, INT6, INT7, or INT8 with INT4 can cause I/O contact failure. The INT4 board has a pickup and dropout delay setting range of 0–1 cycle. For all other I/O boards, pickup and dropout delay settings (IN201PU–IN224PU, IN201DO–IN224DO, IN301PU–IN324PU, and IN301DO–IN324DO) have a range of 0–5 cycles. Upon replacing any I/O board with an INT4 board, manually confirm reset of pickup and dropout delays to within the expected range of 0–1 cycle.	**⚠ATTENTION** Le remplacement en chantier des cartes d'entrées/sorties INT1, INT2, INT5, INT6, INT7 ou INT8 par une carte INT4 peut causer la défaillance du contact d'entrée/sortie. La carte INT4 présente un intervalle d'ajustement pour les délais de montée et de retombée de 0 à 1 cycle. Pour toutes les autres cartes, l'intervalle de réglage du délai de montée et retombée (IN201PU–IN224PU, IN201DO– IN224DO, IN301PU–IN324PU, et IN301DO–IN324DO) est de 0 à 5 cycles. Quand une carte d'entrées/sorties est remplacée par une carte INT4, vérifier manuellement que les délais de montée et retombée sont dans l'intervalle de 0 à 1 cycle.
⚠CAUTION Do not install a jumper on positions A or D of the main board J21 header. Relay misoperation can result if you install jumpers on positions J21A and J21D.	**⚠ATTENTION** Ne pas installer de cavalier sur les positions A ou D sur le connecteur J21 de la carte principale. Une opération intempestive du relais pourrait résulter suite à l'installation d'un cavalier entre les positions J21A et J21D.
⚠CAUTION Insufficiently rated insulation can deteriorate under abnormal operating conditions and cause equipment damage. For external circuits, use wiring of sufficiently rated insulation that will not break down under abnormal operating conditions.	**⚠ATTENTION** Un niveau d'isolation insuffisant peut entraîner une détérioration sous des conditions anormales et causer des dommages à l'équipement. Pour les circuits externes, utiliser des conducteurs avec une isolation suffisante de façon à éviter les claquages durant les conditions anormales d'opération.
⚠CAUTION Relay misoperation can result from applying other than specified secondary voltages and currents. Before making any secondary circuit connections, check the nominal voltage and nominal current specified on the rear-panel nameplate.	**⚠ATTENTION** Une opération intempestive du relais peut résulter par le branchement de tensions et courants secondaires non conformes aux spécifications. Avant de brancher un circuit secondaire, vérifier la tension ou le courant nominal sur la plaque signalétique à l'arrière.

Other Safety Marks (Sheet 3 of 3)

⚠CAUTION Severe power and ground problems can occur on the communications ports of this equipment as a result of using non-SEL cables. Never use standard null-modem cables with this equipment.	⚠ATTENTION Des problèmes graves d'alimentation et de terre peuvent survenir sur les ports de communication de cet appareil si des câbles d'origine autre que SEL sont utilisés. Ne jamais utiliser de câble de modem nul avec cet équipement.
⚠CAUTION Do not connect power to the relay until you have completed these procedures and receive instruction to apply power. Equipment damage can result otherwise.	⚠ATTENTION Ne pas mettre le relais sous tension avant d'avoir complété ces procédures et d'avoir reçu l'instruction de brancher l'alimentation. Des dommages à l'équipement pourraient survenir autrement.
⚠CAUTION Use of controls or adjustments, or performance of procedures other than those specified herein, may result in hazardous radiation exposure.	⚠ATTENTION L'utilisation de commandes ou de réglages, ou l'application de tests de fonctionnement différents de ceux décrits ci-après peuvent entraîner l'exposition à des radiations dangereuses.

General Information

The *SEL-400 Series Relays Instruction Manual* uses certain conventions that identify particular terms and help you find information. To benefit fully from reading this manual, take a moment to familiarize yourself with these conventions.

Typographic Conventions

There are three ways users typically communicate with SEL-400 series relays:

- Using a command line interface on a PC terminal emulation window
- Using the front-panel menus and pushbuttons
- Using SEL Grid Configurator or QuickSet software.

The instructions in this manual indicate these options with specific font and formatting attributes. The following table lists these conventions:

Example	Description
STATUS	Commands, command options, and command variables typed at a command line interface on a PC.
n **SUM *n***	Variables determined based on an application (in bold if part of a command).
<Enter>	Single keystroke on a PC keyboard.
<Ctrl+D>	Multiple/combination keystroke on a PC keyboard.
Start > Settings	PC software dialog boxes and menu selections. The > character indicates submenus.
ENABLE	Relay front- or rear-panel labels and pushbuttons.
MAIN > METER	Relay front-panel LCD menus and relay responses visible on the PC screen. The > character indicates submenus.

Logic Diagrams

Logic diagrams in this manual follow the conventions and definitions shown below.

NAME	SYMBOL	FUNCTION
Comparator		Input A is compared to Input B. Output C asserts if Input A is greater than Input B.
Input Flag		Input A comes from other logic.
OR		If either Input A or Input B asserts, Output C asserts.
Exclusive OR		If either Input A or Input B asserts, Output C asserts. If Input A and Input B are of the same state, Output C deasserts.
NOR		If neither Input A nor Input B asserts, Output C asserts.
AND		If Input A and Input B assert, Output C asserts.
AND w/ Inverted Input		If Input A asserts and Input B deasserts, Output C asserts. Inverter "O" inverts any input or output on any gate.
NAND		If Input A and/or Input B deassert, Output C asserts.
Time-Delayed Pick Up and/or Time-Delayed Drop Out		X is a time-delay-pickup value; Y is a time-delay-dropout value. Output B asserts Time X after Input A asserts; Output B does not assert if Input A does not remain asserted for Time X. If Time X is zero, Output B asserts when Input A asserts. If Time Y is zero, Input B deasserts when Input A deasserts.
Edge Trigger Timer		Rising edge of Input A starts timers. Output B asserts Time X after the rising edge of Input A. Output B remains asserted for Time Y. If Time Y is zero, Output B asserts for a single processing interval. Input A is ignored while the timers are running.
Set-Reset/Flip-Flop		Input S asserts Output Q until Input R asserts. Output Q deasserts or resets when Input R asserts.
Falling Edge	A ⎿ B	Output B asserts at the falling edge of Input A.
Rising Edge	A ⎾ B	Output B asserts at the rising edge of Input A.

Trademarks

All brand or product names appearing in this document are the trademark or registered trademark of their respective holders. No SEL trademarks may be used without written permission.

SEL trademarks appearing in this manual are shown in the following table.

ACSELERATOR Architect®	SELOGIC®
ACSELERATOR QuickSet®	SEL Compass®
Best Choice Ground Directional Element®	SYNCHROWAVE®
MIRRORED BITS®	Time-Domain Link (TiDL®) technology
SEL-2407®	

EtherCAT is registered trademark and patented technology, licensed by Beckhoff Automation GmbH, Germany.

Technical Support

We appreciate your interest in SEL products and services. If you have questions or comments, please contact us at:

Schweitzer Engineering Laboratories, Inc.
2350 NE Hopkins Court
Pullman, WA 99163-5603 U.S.A.
Tel: +1.509.338.3838
Fax: +1.509.332.7990
Internet: selinc.com/support
Email: info@selinc.com

SECTION 1

Introduction

The SEL-400 series of relays feature high-performance protection for a variety of applications. All relays feature extensive metering, monitoring, and data recording, including high-resolution data capture and reporting.

Relays feature expanded SELOGIC control equation programming for easy and flexible implementation of custom protection and control schemes. The relays have separate protection and automation SELOGIC control equation programming areas with extensive protection and automation programming capability.

Relays provide extensive communications interfaces from standard SEL ASCII and enhanced MIRRORED BITS communications protocols to Ethernet connectivity with the optional Ethernet card. With the Ethernet card, you can employ common industry communications tools, including Telnet, File Transfer Protocol (FTP), DNP3 (serial and LAN/WAN), and the IEC 61850 Edition 2 standard suite of protocols.

NOTE: Some SEL-400 series relays are compliant with Edition 1 of the IEC 61850 standard.

NOTE: Some relays are only supported by SEL Grid Configurator. See Section 2: PC Software for more details.

Relays interface with SEL Grid Configurator or ACSELERATOR QuickSet SEL-5030 Software. SEL Grid Configurator or QuickSet assists you in setting, controlling, and acquiring data from the relays, both locally and remotely. ACSELERATOR Architect SEL-5032 Software enables you to view and configure IEC 61850 settings via a GUI.

Most relays support synchrophasor measurement. Synchrophasor measurements are available when a high-accuracy time source is connected to the relay. The relay supports the IEEE C37.118 standard for synchrophasors for power systems.

Most relays feature bay control functionality. The mimic display selected is displayed on the front-panel screen in one-line diagram format. The number of disconnects and breakers that can be controlled by the relay are a function of the selected mimic display screen. Control of the breakers and disconnects is available through front-panel pushbuttons, ASCII interface, Fast Message protocol, or SELOGIC control equations.

A simple and robust hardware design features efficient digital signal processing. Combined with extensive self-testing, these features provide relay reliability and enhance relay availability.

Common Features

Automation. Take advantage of enhanced automation features that include programmable elements for local control, remote control, protection latching, and automation latching. Local metering on the large-format front-panel LCD eliminates the need for separate panel meters. Use serial and Ethernet links to efficiently transmit key information, including metering data, protection element and control I/O status, Sequential Events Recorder (SER) reports, breaker monitor, relay summary event reports, and time synchronization. Use expanded SELOGIC control equa-

tions with math and comparison functions in control applications. Incorporate as many as 1000 lines of automation logic to speed and improve control actions.

Oscillography and Event Reporting. Record voltages, currents, and internal logic points as fast as an 8 kHz sampling rate. Phasor and harmonic analysis features allow investigation of relay and system performance.

Sequential Events Recorder (SER). Record the last 1000 entries, including setting changes, startups, and selectable logic elements.

High-Accuracy Time Stamping. Time-stamp binary COMTRADE event reports with real-time accuracy of better than 10 µs. View system state information to an accuracy of better than 1/4 of an electrical degree.

Digital Relay-to-Relay Communication. Use enhanced MIRRORED BITS communications to monitor internal element conditions between relays within a station, or between stations, by using SEL fiber-optic transceivers. Send digital, analog, and virtual terminal data over the same MIRRORED BITS channel.

Ethernet Access. Access all relay functions with the optional Ethernet card. Interconnect with automation systems by using IEC 61850 or DNP3 LAN/WAN protocols directly or through an SEL-3530 RTAC. Use FTP for high-speed data collection.

Time-Domain Link (TiDL). Reduce costs with TiDL technology. With this simple-to-configure solution, the relay ac inputs and most of its digital inputs and outputs are distributed using TiDL merging units.

Parallel Redundancy Protocol (PRP). Provide seamless recovery from any single Ethernet network failure with this protocol, in accordance with IEC 62439-3. The Ethernet network and all traffic are fully duplicated with both copies operating in parallel.

High-Availability Seamless Redundancy Protocol (HSR). Provide seamless recovery from any single Ethernet network failure with this protocol, in accordance with IEC 62439-3. All HSR compatible devices are connected in a ring and the traffic is fully duplicated and sent in both clockwise and counterclockwise directions around the ring.

Increased Security. Set unique passwords for each access level. The relay divides control and settings into seven relay access levels. The relay has separate breaker, protection, automation, and output access levels, among others.

Rules-Based Settings Editor. Communicate with and set the relay by using an ASCII terminal, or use the PC-based SEL Grid Configurator or QuickSet software.

Settings Reduction. Show only the settings for the functions and elements you have enabled using internal relay programming.

Alias Settings. Use as many as 200 aliases to rename any digital or analog quantity in the relay. The aliases are available for use in customized programming, making initial programming and maintenance easy.

SECTION 2

PC Software

Refer to *Table 2.1* to navigate to the information about the PC software program available based on your relay.

Table 2.1 SEL Software

Relay Model	Available Settings Software
SEL-400G	See *SEL Grid Configurator on page 2.1*
SEL-401	See *SEL Grid Configurator on page 2.1*
SEL-411L-0, -1, -A, -B	See *SEL Grid Configurator on page 2.1* or *ACSELERATOR QuickSet SEL-5030 Software on page 2.14*
SEL-411L-2	See *SEL Grid Configurator on page 2.1*
SEL-421-4, -5	See *ACSELERATOR QuickSet SEL-5030 Software on page 2.14*
SEL-421-7	See *SEL Grid Configurator on page 2.1*
SEL-451-5, -A	See *ACSELERATOR QuickSet SEL-5030 Software on page 2.14*
SEL-451-6	See *SEL Grid Configurator on page 2.1*
SEL-487B-1	See *ACSELERATOR QuickSet SEL-5030 Software on page 2.14*
SEL-487B-2	See *SEL Grid Configurator on page 2.1*
SEL-487E-3, -4	See *ACSELERATOR QuickSet SEL-5030 Software on page 2.14*
SEL-487E-5	See *SEL Grid Configurator on page 2.1*
SEL-487V	See *ACSELERATOR QuickSet SEL-5030 Software on page 2.14*

SEL Grid Configurator

SEL Grid Configurator is a tool for engineers and technicians to quickly and easily design, deploy, and manage device configurations for power system protection, control, metering, and monitoring. Through use of this software, you can perform the following:

- Configure settings for supported devices.
- Organize and manage device settings.
- Read and send settings for supported devices.
- Read reports from supported devices.

Installation

Overview

To install the software, you must have at least the following.

Table 2.2 Minimum Requirements

Supported Operating Systems:	Microsoft Windows 10 (64-bit) Microsoft Server 2016 (64-bit)
Processor Speed:	1 GHz (64-bit) or faster
RAM:	2 GB
Disk Space:	1 GB available
Printer:	Default printer installed for printer settings
Monitor:	1280 x 800 or higher resolution monitor **Note:** For best viewing of the application windows and text, you may need to enter your Windows operating system settings and adjust the screen resolution settings to make text and other items larger or smaller.
Other Peripherals:	Mouse or other pointing device
Communications:	Serial or Ethernet connections to allow communication with SEL devices
Required Third-Party Software:	Microsoft .NET Framework 4.7.2

Two different installations of SEL Grid Configurator are offered: an Admin Install and a User Install. Both install the same version of the software but support different use cases. SEL recommends using the Admin Install in most cases. *Table 2.3* illustrates the differences and the different use cases for the two installation types.

Table 2.3 Differences Between Admin Install and User Install

Admin Install	User Install
Requires administrative privileges to install on the computer.	Does NOT require administrative privileges to install on the computer.
Accessible by all users on the same computer.	Accessible only to the user that installed the software.
Uses the ACSELERATOR Database, the same database used by ACSELERATOR QuickSet Device Manager, if installed. This provides a means to view and access supported devices from both SEL Grid Configurator and Device Manager.	Uses a separate database from QuickSet Device Manager. The User Install of SEL Grid Configurator cannot connect to an ACSELERATOR Database.
May require an update to QuickSet and Device Manager for compatibility. If an update is necessary, the user will be notified during SEL Grid Configurator installation. The user will then have the opportunity to cancel installation at that time.	Never requires an update to an existing installation of QuickSet.

Examples of when to use the User Install:

- A user must install the software but lacks administrative privileges on the computer.
- A user wants to try a new version of SEL Grid Configurator before full deployment.
- A user must use SEL Grid Configurator on the same computer on which an incompatible (and unable to be upgraded) version of QuickSet is installed.

ACSELERATOR QuickSet Compatibility

If using the Legacy Device Driver, QuickSet version 6.3.0.7 or later is required for compatibility with SEL Grid Configurator. If using Device Manager, QuickSet version 6.8.2.0 or later is required for compatibility with SEL Grid Configurator.

Installation Instructions

Once you have decided on the best installation, perform the following:

Step 1. Obtain the SEL Grid Configurator installation files from either the website (selinc.com/products/5037) or SEL Compass software.

Step 2. Run the installation file.

Step 3. If you agree to the terms of the license agreement, select **I accept the license agreement**.

Step 4. If you are running the User Install, select **Install** and go to *Step 6*. If you are running the Admin install, select **Next** and continue to *Step 5*.

NOTE: The following option is only available in the Admin Install. Skip Step 5 if you are running the User Install.

Step 5. Select the desired installation type.

a. Select **Typical** to use all default installation options, and then select **Install** to install the application.

Figure 2.1 Select Typical to Accept All Default Installation Options or Select Custom to View or Modify Them

b. Select **Custom** to choose where to install the application and the ACSELERATOR Database.

c. Select **Next**.

d. Enter the desired folder location or select **Browse** to select a folder and then select **Next**.

Figure 2.2 Select the Install Location for SEL Grid Configurator

e. Enter the desired folder locations for the database binaries and data or select **Browse** to select a folder and then select **Install**.

Figure 2.3 Select the Install Location for the ACSELERATOR Database

Step 6. After the installation process has been completed, select **Next**.

Step 7. Select **Finish** to close the installation wizard.

Figure 2.4 SEL Grid Configurator Installation Completed Successfully

Silent Installation

SEL Grid Configurator supports a command-line interface for silent, automated installations. The following parameters are supported:

- **/Silent**: Requires no end-user interaction and supports automated installs via scripting.
- **/AgreeEULA**: Represents an explicit approval of the License Agreement (EULA) to prevent showing the License Agreement form. This must be included with the /Silent option to perform a silent installation of SEL Grid Configurator.
- **/InstallPath**: Specifies the selected folder location when the default is not desired.
- **/DatabaseBinInstallPath**: Specifies the selected folder location for database binary files.
- **/DatabaseDataInstallPath**: Specifies the selected folder location for database data files.

Examples:

To perform a silent, default installation, execute the following:

```
SEL.Grid.UserInstaller-x.x.x.x.exe /Silent /AgreeEULA
```

To perform a silent installation while specifying the installation paths, execute the following:

```
SEL.Grid.AdminInstaller-x.x.x.x.exe /Silent /AgreeEULA /InstallPath="(Select file
    location)"
/DatabaseBinInstallPath="(Select database binaries location)"
    /DatabaseDataInstallPath=
"(Select Database data location)"
```

Uninstalling SEL Grid Configurator

SEL Grid Configurator supports uninstallation by the following methods:

- Through Windows Apps & features (Admin Install only)
- Through Windows Start Menu via an **Uninstall SEL Grid Configurator** shortcut in the **SEL Applications** folder (User Install only)
- Through SEL Compass
- Silently using the SEL Grid Configurator uninstaller's command-line interface

SEL Grid Configurator Uninstaller

The SEL Grid Configurator uninstaller (uninstall.exe) is located in the Uninstall folder in the SEL Grid Configurator install folder. The following parameters are supported:

- **/Silent**: A silent uninstallation shall be performed.
- **/RemoveDatabaseData**: Database data will be removed as part of uninstallation (User Install only).

Example:

To perform a silent uninstall, execute the following:

```
uninstall.exe /Silent
```

Removing Database Data (User Install Only)

The database data contains device information, settings, and collected device reports. By default, the database data will remain on the machine when uninstalling SEL Grid Configurator. An option to remove the database data is available with the User Uninstall but not the Admin Uninstall. If you intend to reinstall SEL Grid Configurator in the future, it is recommended to not remove this data. To remove the database data, select the box in the User Uninstallation Wizard (see *Figure 2.5*).

Figure 2.5 Option to Remove Database Data on Uninstallation (User Install Only)

In the case of the Admin Uninstall, the ACSELERATOR Database is not automatically removed. The ACSELERATOR Database requires manual removal via Windows Apps & features or SEL Compass.

Getting Started

This section provides the basic process for creating and deploying settings for a new device. More detailed information on each part of the user interface is available in the *SEL Grid Configurator Instruction Manual*. When you create a new device project, the software will prompt you for a part number. If you have none at the present time, start with the default part number; you may change it later.

Step 1. Using a computer on which Windows 10 is installed, open SEL Grid Configurator by selecting the Windows start button (left end of the Taskbar in Windows 10), scroll down and select **SEL Applications**, then select the SEL Grid Configurator icon. Alternatively, you can pin SEL Grid Configurator to the start panel, taskbar, or desktop on your computer.

Step 2. Create a new device by selecting **Add Device** from the context menu at the top of the System Explorer, as *Figure 2.6* illustrates.

Figure 2.6 Add a New Device Project

Step 3. Select the type of device.

Step 4. Fill in a project name, setting version, and part number. Select **OK**. A device project includes all of the information (such as settings, comments, communications parameters, etc.) that SEL Grid Configurator manages for a device, *Figure 2.7* shows how a new device project looks in the System Explorer.

Figure 2.7 New Device in the System Explorer

Step 5. Select **Main Features > Protection Elements** from the Device Explorer, as illustrated in the green highlighted area of *Figure 2.8*. Using the controls next to the Available Protection Elements, enable as many protection functions as necessary. Repeat for each setting group by using the group selector (highlighted in orange in *Figure 2.8*) in the Device Commands menu. The features and groups SEL Grid Configurator shows in this view vary greatly depending upon the relay, meter, or distribution controller you are configuring. Refer to the device instruction manual for detailed information about the features available in your particular device.

Figure 2.8 Protection Elements View

The views and editors available in the Device Explorer vary depending upon the device. The functionality of the device being configured determines the available settings groups. In the Settings Grid view, settings are organized hierarchically in a tree format. Settings categories have a small triangle to the left. When you select this triangle, the settings category expands to show additional available settings related to the overarching category, as shown in *Figure 2.9*. Select the triangle again to collapse that portion of the tree.

In any device settings view, such as Protection Elements or Settings Grid, an indicator displays next to any setting you have changed. The change indicator persists as long as you have the device project open.

Figure 2.9 Settings Grid View

Some settings will be disabled (grayed out) by default. SEL Grid Configurator displays settings as disabled according to such various factors as your part number selection, which protections elements you have enabled, etc. Refer to your device instruction manual to learn details about the specific settings for your device. SEL Grid Configurator makes settings available for editing once you change the options that caused them to be unavailable.

Step 6. In the Settings Grid view, expand the tree to see all settings and groups available in your device. Select an entry in the tree to view the settings editor for that element. Edit the setting value either by directly editing in the grid or by selecting the ellipsis button in the Value cell if available. *Figure 2.10* shows an example of each editing workflow. For setting 50P1P, which requires a numerical entry, you can directly select and edit the necessary value in the Value cell. Setting 67P1TC requires a SELOGIC control equation, which provides a window to help the user build their desired torque-control equation. Select the ellipsis button in the Value cell to open the SELOGIC control equation builder. Create the equation and then select **OK**.

Figure 2.10 Editing Settings and Automatic Validation

If you enter a settings value into a field and that value is invalid or outside the acceptable range, as shown in *Figure 2.10*, SEL Grid Configurator displays an error icon in the Value cell for that setting. A message explaining the error displays if you hover over the Value cell. Correct these errors prior to deploying settings.

Select the alarm icon in the Device Commands menu, as shown in *Figure 2.11*, to see Project Notifications, a report of all settings errors in a device project. Select the notification message to immediately navigate to the invalid setting.

Figure 2.11 Viewing Project Notifications

Step 7. For all remaining settings, navigate the tree or use the search bar to find the necessary settings and alter the appropriate values.

Step 8. Select **Communications > Connections**, as shown in *Figure 2.12*. Enter the connection parameters for your device. SEL Grid Configurator can communicate with devices via serial or network connections.

Figure 2.12 Configuring Communications Options

Step 9. Select **Communications > Security**, as illustrated in *Figure 2.13*. By default, SEL Grid Configurator has the default passwords for your device type. Enter custom passwords if you use them. Refer to your device instruction manual to learn about the access levels and password options for your device.

Figure 2.13 Configuring Security Options

Figure 2.14 Connecting to a Device

Step 10. Select **Connect** in the Device Commands Menu, as shown in *Figure 2.14*. Once the connection is active, you will see a success message and a green dot displays in the device tab and next to the device name in the System Explorer. As long as SEL Grid Configurator has an active connection with the device shown in your workspace, device commands appear similar to *Figure 2.15*.

Figure 2.15 Device Commands Menu for Connected Devices

Step 11. Select the **Send** button, as shown in *Figure 2.15*, to deploy settings to the device. Select the green **Device Operations** icon in the Title Bar, as shown in *Figure 2.16*, to view the progress of the operation.

Figure 2.16 Title Bar During Settings Deployment

Step 12. To cancel an operation, select **Device Operations > Cancel Operation > OK**.

Figure 2.17 Opening the Send Report

Step 13. Select **Disconnect** from the Device Commands Menu to terminate the connection to the device.

SEL Grid Configurator Interface

Introduction

The user interface of SEL Grid Configurator is divided into a number of viewable areas that can generally be categorized as follows:

Navigators: One or more navigators can be open and visible in the user interface at any time. These generally sit vertically (top to bottom) in the user interface and contain content in rows. In some cases, the content will be hierarchical and collapsible so you can focus only on what you need. A scroll bar appears if the content still extends beyond the viewable space. When the scroll bar appears, SEL Grid Configurator offers three navigational options:

1. Press and drag with your mouse on the scroll bar
2. Hover the mouse over the sidebar and use the mouse scroll wheel
3. Touch the scroll bar and drag your finger in the direction you want the view to move

IMPORTANT: Opening multiple navigators on a smaller screen can make the workspace too confining. You can collapse or expand any navigator individually.

Title Bar: The blue bar at the top of the user interface. It contains the application title and a number of icons for common actions that affect the entire application.

Workspace: The previously mentioned sections of the user interface enable and support the core of the application, your workspace. The content (or view) in the workspace changes depending on the project type and workflow, but the workspace generally includes editable content and reports. Enter and edit content as necessary. Reports are read-only and provide information about your project. As with navigators, SEL Grid Configurator displays scroll bars if the content extends beyond the viewable space.

Accessing Contextual Information

The menu system in SEL Grid Configurator primarily displays via context menus. Select the ellipsis button, •••, to display the context menu for the item with which you are working. Select in the title bar to activate application help.

User Interface Sections

1. **Title Bar**: Includes the software title and such application-level controls as the light and dark theme.
2. **System Explorer**: A navigator that includes a hierarchical view of all devices in your system. Open device projects from the System Explorer.
3. **Workspace**: The display of any open view or project. Commands and features differ according to the use case for any particular view.

Figure 2.18 SEL Grid Configurator User Interface Overview

Light and Dark Theme

Figure 2.19 Dark Theme

As shown in *Figure 2.19*, toggle the rocker bar on the right side of the title bar to switch between the light and dark theme for the user interface.

SEL Grid Configurator Report Retrieval

Use SEL Grid Configurator to download the Sequence of Events records or relay oscillography records, as highlighted in *Figure 2.20*.

Figure 2.20 SEL Grid Configurator Report Retrieval

ACSELERATOR QuickSet SEL-5030 Software

This section provides information on the following topics:

➤ *QuickSet Setup on page 2.15*
➤ *Settings Database Management and Drivers on page 2.17*
➤ *QuickSet Main Menu on page 2.21*
➤ *Create and Manage Relay Settings on page 2.21*
➤ *QuickSet HMI on page 2.30*
➤ *Analyze Events on page 2.33*
➤ *QuickSet Help on page 2.34*

SEL-400 series relays come with ACSELERATOR QuickSet SEL-5030 Software, a powerful relay settings, analysis, and measurement tool, to aid you in applying and using the relay. QuickSet reduces engineering costs for relay settings, logic programming, and system analysis. QuickSet makes it easier for you to do the following:

- Create and manage relay settings
  - Create settings for one or more relays
  - Store and retrieve settings with Windows-based PCs
  - Upload and download relay settings files to and from relays
- Analyze events
  - Use the integrated waveform (single event reports) analysis tools

- Control the relay
  - Command relay operation through use of a GUI environment
  - Execute relay serial port commands in terminal mode
- Configure the serial port and passwords

SEL provides QuickSet for easier, more efficient configuration of the relay settings. However, you do not have to use QuickSet to configure a relay; you can use an ASCII terminal or a computer running terminal emulation software to access all relay settings and metering. QuickSet gives you the advantages of rules-based settings checks, SELOGIC control equation Expression Builder, and event analysis.

QuickSet Setup

Obtaining QuickSet

QuickSet can be obtained from the Download area of the SEL website. To have the software automatically update as new relay drivers are released, download and install SEL Compass Software, and then use Compass to download and install QuickSet. When you download QuickSet within Compass, you will be asked to select which relay drivers you wish to include. Select drivers for all SEL relays that you may be required to set. If later you find that additional drivers are required, QuickSet provides an easy method to request new drivers and updates (see *Updating QuickSet on page 2.15*).

QuickSet is also available on DVD upon request.

Updating QuickSet

The QuickSet software consists of a core application plus driver files for individual devices. As new device firmware versions are released, you may need to update QuickSet to add new driver files. This may be accomplished several ways:

- When the **Enable Update Notifications** check box is selected in the **Tools > Options** menu of SEL Compass, the Compass software will automatically check for updates on a specified schedule and facilitate the update process.
- The **Update** icon on the QuickSet startup screen starts SEL Compass and checks for updates.
- The **Install Devices** button on the Settings Editor Selection window starts SEL Compass and presents a menu of available drivers.
- **Check for updates** in the **Help** menu starts SEL Compass and checks for updates.

An Internet connection is required to add new drivers and to receive update notifications.

Serial Communication Parameters

QuickSet can communicate with a relay via any relay serial port set to SEL protocol or via Ethernet. Use the **Communication Parameters** dialog box to configure relay communications settings.

Step 1. Select the **Communication** menu on the top QuickSet toolbar.

Step 2. Select **Parameters** to open this dialog box.

Figure 2.21 shows the QuickSet **Communication Parameters** dialog box.

Figure 2.21 QuickSet Communication Parameters Dialog Box

You can use serial communication via relay Ports 1, 2, 3, and F (front panel). *Figure 2.21* shows the default serial port parameters (9600, 8, N, 1).

Step 1. Enter your relay Access Level 1 and Access Level 2 passwords in the respective text boxes.

Step 2. If you choose a connection type from the **Active Connection Type** dropdown list that is a telephone modem, enter the dial-up telephone number in the **Phone Number** text box.

Ethernet Card

Use the optional Ethernet card for File Transfer Protocol (FTP) and Telnet network communications.

FTP Setup

Step 1. Access the **Network** dialog box from the **Active Connection Type** dropdown list.

Step 2. Select the **FTP File Transfer Option** button to select FTP as the network communications protocol.

Step 3. Enter the IP address of the relay Ethernet port as the Host IP address.

Step 4. Enter the FTP port number.

Step 5. Enter the relay Access Level 1 and Access Level 2 passwords in the respective text boxes.

See *Changing the Default Passwords in the Terminal on page 3.11*.

Step 6. Use the **Save to Address Book** button to save the entered information with a Connection Name for later use.

Step 7. Enable the Ethernet port setting **FTPSERV**.

Telnet Setup

Step 1. Access the **Network** dialog box from the **Active Connection Type** dropdown list.

Step 2. Select the **Telnet File Transfer Option** button to select Telnet as the network communications protocol.

The Telnet session uses the relay passwords on the **Communication Parameters** dialog box (*Figure 2.21*). See *Telnet on page 15.17* for more information on Telnet.

Terminal Window

The terminal window provides an ASCII interface on which you can communicate with the relay. This is a basic terminal emulation. Many third-party terminal emulation programs are available with file transfer encoding schemes.

Step 1. Select the QuickSet **Communication** menu.

Step 2. Select **Terminal** to start the terminal window.

Another convenient method to start the terminal is to press **<Ctrl+T>**.

Terminal Logging

When you select the **Terminal Logging** check box in the **Communication** menu, QuickSet records communications events and errors in a log.

Step 1. Select **Communication > Logging > Connection Log** to view the log.

Step 2. Clear the log by selecting **Communication > Logging > Clear Connection Log**.

Settings Database Management and Drivers

Database Manager

QuickSet uses a relay database to save relay settings. QuickSet contains sets of all settings files for each relay that you specify in the **Database Manager**. Choose appropriate storage backup methods and a secure location for storing your relay database files. Use the **File > Database Manager** menu to retrieve a relay database from computer memory.

Relay Database

The default relay database file already configured in QuickSet is **Relay.rdb**. This database contains example settings files for the SEL products with which you can use QuickSet.

Step 1. Open the **Database Manage**r to access the database.

a. Select **File** in the QuickSet top toolbar.

b. Select the **Database Manager** menu item. You will see a dialog box similar to *Figure 2.22*.

Step 2. If you wish, you can enter descriptions of the database and/or relay in the **Database Description** and/or **Settings Description** text boxes.

A relay description would consist of special operating characteristics that describe the relay settings including the protection scheme settings and communications settings.

Figure 2.22 QuickSet Database Manager Relay Database

Step 3. Highlight one of the relays listed in **Settings**.

Step 4. Select **Copy** to create a new collection of relay settings.

QuickSet prompts you to provide a new name.

Copy/Move Relays Between Databases

You can create multiple relay databases with the **Database Manager**; these databases are useful for grouping similar protection schemes or geographic areas.

Step 1. Select the **Copy/Move Relays Between Settings Databases** tab to access the dialog box shown in *Figure 2.23*.

Step 2. Select the ellipsis next to **Settings Database B** to open a relay database.

Step 3. Navigate to the desired database location.

Step 4. Select **Open**.

For example, **Relay2.rdb** is the B relay database in *Figure 2.23*.

Step 5. Highlight a relay in the A database.

Step 6. Select **Copy** or **Move**.

Step 7. Select the **>** button to create a new relay in the B database.

Reverse this process to take relays from the B database to the A database.

Copy creates an identical relay that appears in both databases. **Move** removes the relay from one database and places the relay in another database.

Figure 2.23 QuickSet Database Manager Copy/Move

Create a New Database

Step 1. To create and copy an existing database of relays to a new database, select the **File > Database Manager** menu.

Step 2. Select **Copy/Move Relays Between Databases** on the **Database Manager** dialog box.

QuickSet opens the last active database and assigns it as Database A (see *Figure 2.23*).

Step 3. Select the ellipsis next to **Settings Database B**.

QuickSet prompts you for a file location.

Step 4. Type a new database name.

Step 5. Select **Open**.

Step 6. Answer **Yes**.

The program creates a new empty database.

Step 7. Load relays into the new database as in *Copy/Move Relays Between Databases on page 2.18*.

Drivers

Relay settings folders in QuickSet are closely associated with the QuickSet relay driver that you used to create the settings. The relay settings and the QuickSet drivers must match.

Step 1. Use one of the following methods to view the relay FID (firmware identification) number to determine the active QuickSet drivers.

- ➢ Enter Access Level 1 and use the **STATUS** command from the serial port terminal emulation window.
- ➢ Type **ID <Enter>** in the computer emulation software window (**<Ctrl+T>** from QuickSet).

Step 2. Locate and record the Z-number in the FID string.

The Z-number helps determine the proper QuickSet relay settings driver version when creating or editing relay settings files.

Step 3. View the QuickSet settings driver information at the bottom of the **Settings Editor** window.

The first portion of the Z-number is the QuickSet settings driver version number (see *Figure 2.24*).

Step 4. Compare the QuickSet driver number and the relay FID number.

This QuickSet driver Z-number and the corresponding part of the relay FID must match.

Figure 2.24 QuickSet Software Driver Information in the FID String

Use the first portion of the Z-number (Z001XXX, for example) to determine the correct **Settings Editor** version to select.

Step 5. View the top of the **Settings Editor** window to check the **Settings Editor** driver number (see *Figure 2.25*).

Figure 2.25 Relay Settings Driver Version Number

As SEL develops new drivers, you can update your existing QuickSet with specific relay drivers for each SEL product that uses QuickSet. Use SEL Compass (selinc.com/products/compass/) to download the latest QuickSet drivers.

QuickSet Main Menu

The main menu provides the following options and submenu options. Selected submenu options are explained in detail in *Table 2.4*.

Table 2.4 QuickSet Submenu Options

File	➤ New—Create new settings for a connected device or offline. ➤ Open—Open existing settings stored in a Relay Database (RDB) file. ➤ Close—Close settings instance that is open in the QuickSet window. ➤ Save/Save As—Save settings instance that is open in the QuickSet window to the active Relay Database (RDB) file. ➤ Print Device Settings—Print standard or custom settings reports. ➤ Read—Read settings from a connected device and display the settings in the QuickSet window. ➤ Send—Send settings instance that is open in the QuickSet window to a connected device. ➤ Active Database—Change which Relay Database (RDB) file is used for the Open and Save/Save As commands. ➤ Database Manager—Open Database Manager to create a new Relay Database (RDB) file, copy settings within the active Relay Database (RDB) file, add descriptions to settings within the database, and copy and move settings between different databases. ➤ Exit—Quit the QuickSet software.
Edit	➤ Copy—Copy settings from one Settings Group to another. ➤ Search—Search for a text string within the settings instance. ➤ Compare—Compare the settings instance that is open in the QuickSet window to another settings instance in the Relay Database file. ➤ Merge—Merge the settings instance that is open in the QuickSet window with another settings instance in the Relay Database file. ➤ Part Number—Change the current part number for the settings instance that is open in the QuickSet window.
Communications	➤ Connect—Request QuickSet to attempt to connect to a device by using the current Connection Parameters. ➤ Parameters—Modify the Communications Parameters, including connection type (Serial, Network, or Modem), PC port numbers, speed, and settings, device passwords, IP addresses, ports, and file transfer options, and modem phone numbers and speeds. ➤ Network Address Book—Select from a list of Ethernet-connected devices. Add or modify devices by specifying the Connection Name, IP Address, Telnet Port Number, User ID, and Password. ➤ Terminal—Open terminal window to issue ASCII commands directly to a connected relay. ➤ Logging—Initiate terminal logging to record terminal communications. View and clear the connection log.
Tools	➤ Settings—Convert settings between settings versions. Import and export settings from and to text files. ➤ HMI—Open HMI for connected device and manage custom HMI Device Overviews. ➤ Events—Collect event and view reports from connected devices. ➤ Options—Control QuickSet options, including Setting Comments, Event Viewer, and Terminal Options. ➤ Firmware Loader—Upgrade relay firmware.
Help	➤ Access program and settings help.

Create and Manage Relay Settings

QuickSet enables you to create settings for one or more relays. You can store existing relay settings downloaded from relays with QuickSet, creating a library of relay settings (see *Database Manager on page 2.17*). You can then modify and upload these settings from your settings library to a relay. QuickSet makes setting the relay easy and efficient.

Relay Part Number

The relay part number determines the settings that QuickSet displays and the functions that the software controls. When configuring QuickSet to control a particular relay, you should confirm that the QuickSet part number matches the relay part number so that you can access all of the settings you need for your relay.

Configuring the Relay Part Number

Step 1. Select the QuickSet **Edit** menu.

Step 2. Select **Part Number** in the dropdown list, as shown in *Figure 2.26*.

Figure 2.26 Retrieving the Device Part Number

You will see the **Device Part Number** dialog box, similar to the one shown in *Figure 2.27* for the SEL-487B.

Step 3. Use the arrows inside the text boxes to match corresponding portions of the **Device Part Number** dialog box to your relay. Alternatively, select **Edit** in the lower left corner of the **Device Part Number** screen and paste in the desired part number.

Figure 2.27 Setting the Relay Part Number in QuickSet

Settings Overview

QuickSet arranges relay settings in easy-to-understand categories (for an explanation of settings organization, see *Making Simple Settings Changes on page 3.15*). These categories of collected settings help you quickly set the relay. *Figure 2.28* is an example of relay settings categories in the **Settings Editor** tree view.

QuickSet shows all of the settings categories in the settings tree view. When you enable and disable settings categories, the tree view remains constant, but when you select the tree view to access the settings in a disabled category, the disabled settings are dimmed. For example try the following steps:

Step 1. Select **Global > Station DC Monitoring** and observe that the settings are dim.

Step 2. To enable the Station DC Monitor settings, select the **Global > General Global Settings/Enables** branch of the settings tree view.

Step 3. Change the **EDCMON Station DC Battery Monitor** setting to **Y**.

Step 4. *Figure 2.28* through *Figure 2.30* illustrates this feature of QuickSet.

Figure 2.28 Station DC Settings

Figure 2.29 Enable EDCMON in Global Settings

Figure 2.30 DC Monitor Settings Enabled

Settings Editor

Use the **Settings Editor** to enter relay settings. *Figure 2.31* illustrates the important features of the editor. These features include the QuickSet settings driver version number (the first three digits of the Z-number) in the lower left corner of the **Settings Editor**.

Figure 2.31 QuickSet Settings Editor

Entering Settings

Step 1. Select the arrows to expand the **Settings Tree View** (see *Figure 2.31*).

Step 2. Select the circle buttons to select the settings class, instance, and category that you want to change.

Step 3. Use the **<Tab>** key to move to the setting text book and from setting to setting when entering and editing.

Step 4. The right-click mouse button allows access to two special functions when you are editing settings: **Previous Value** and **Default Value**. It also allows the user to **Add a Comment** to the selected setting or **Search for Selected Text**.

Step 5. Use the following methods to edit the settings from QuickSet.

- ➢ Restore previous values. Right-click the mouse over the setting and select **Previous Value**.
- ➢ Restore default values. Right-click in the setting dialog box and select **Default Value**.

  If you enter a setting that is out of range or has an error, an error message appears at the bottom of the **Settings Editor** window. To correct the error, proceed to *Step 6*.

Step 6. Correct settings errors.

a. Double-click the error listing in the **Settings Editor** window.

b. Enter a valid input for the setting where the error appears.

Ellipsis Button

QuickSet includes a feature called an **ellipsis button** (see *Figure 2.32*).

Figure 2.32 Ellipsis Button

The ellipsis button is a square button with three dots, as shown in *Figure 2.33*. Use the ellipsis button to build expressions or assist with entering settings in the relay. Whether the ellipsis button is an expression builder or a setting assistant depends on the selected relay function and is preprogrammed in the relay. For example, *Figure 2.33* shows the **ellipsis button** as a setting assistant, entering settings for the SER.

Step 1. Enter the SER settings by selecting on the **Report > SER Settings** in the **Tree View**.

Step 2. Select the **SITM1 SER Points and Alias, Point 1** ellipsis button, which makes the **R1-SITM1** window available.

Step 3. Select the Relay Word bit ellipsis button in the **R1-SITM1** window.

The software displays a list of Relay Word bits available in the relay that you can select to enter in the SER report.

Figure 2.33 Location of Ellipsis Button

Expression Builder

The ellipsis button also allows access to an expression builder. SELOGIC control equations are a powerful means for customizing relay performance. Creating these equations can be difficult because of the large number of relay elements (Relay Word bits) and analog quantities in the relay. QuickSet simplifies this process with the expression builder, a rules-based editor for programming SELOGIC control equations. The expression builder organizes relay elements, analog quantities, and SELOGIC control equation variables and focuses your equation decision making.

Expression Builder Organization

The **Expression Builder** dialog box is organized into two main parts representing the left side (LVALUE) and right side (RVALUE) of the SELOGIC control equation. (The LVALUE is fixed for all settings except Protection Free-Form SELOGIC and Automation Free-Form SELOGIC control equation settings—see *Fixed SELOGIC Control Equations on page 13.6*.) *Figure 2.34* shows the two sides of the **Expression Builder**, with the SELOGIC control equation that you are constructing at the top of the dialog box. Note the dark vertical line and the equals sign (**:=**) separating the equation's left and right sides.

Figure 2.34 QuickSet Expression Builder

Using the Expression Builder

Step 1. For Protection Free-Form SELOGIC and Automation Free-Form SELOGIC control equations, select the type of result (LVALUE) for the SELOGIC control equation to use the **Expression Builder**.

QuickSet shows Relay Word bits available for use in compiling expressions. The program shows the relay elements for each type of SELOGIC control equation (e.g., Boolean Variables, Math Variables).

On the right side of the equation (RVALUE), you can select broad categories of relay elements, analog quantities, counters, timers, latches, Boolean variables, and math variables.

Step 2. Select a category in the RVALUE tree view.

The Expression Builder displays all elements for that category in the list at the bottom right side. Directly underneath the right side of the equation, you can choose operations to include in the RVALUE. These operations include basic logic functions, rising and falling-edge triggers, expression compares, and math functions. For more information on programming SELOGIC control equations, see *Section 13: SELOGIC Control Equation Programming*.

QuickSet HMI

Use the QuickSet HMI feature to view real-time relay information in a graphical format. Use the virtual relay front panel to read metering and targets (see *Figure 2.35*) for a representative example.

Figure 2.35 Virtual Relay Front Panel

Open the QuickSet HMI

Select **Tools > HMI > HMI** in the QuickSet menu bar. QuickSet opens the HMI window and downloads the interface data. The HMI can also be accessed by using the HMI icon.

QuickSet HMI Features

Table 2.5 lists typical functions in the HMI tree view and a brief explanation of each function. The specific options available for any specific relay depend on the features available in that relay.

Table 2.5 QuickSet HMI Tree View Functions (Sheet 1 of 2)

Function	Description
Device Overview	View general metering, selected targets, control input, control outputs, and the virtual front panel
Contact I/O	View status of contact inputs and contact outputs

Table 2.5 QuickSet HMI Tree View Functions (Sheet 2 of 2)

Function	Description
Phasors	A graphical and textual representation of phase and sequence voltages and currents.
Time and Communications	View for Time Quality, MIRRORED BITS Channel A or B, real-time control (RTC) Channel. Precision Time Protocol (PTP), or Sampled Values status.
Fundamental Metering	A table of instantaneous voltages, currents, powers, and frequency.
Zone Metering	View active Zone meter reports.
Differential Metering	View differential currents of all active zones.
Unbalance Metering	View the differential and unbalanced metering data.
Synchrophasor	A table of synchrophasor data.
Demand/Peak	A table showing demand and peak demand values. This display also allows demand and peak demand values to be reset.
Min/Max	A table showing maximum/minimum metering quantities. This display also allows maximum/minimum metering quantities to be reset.
Energy	A table showing energy import/export. This display also allows energy values to be reset.
Temperature	View the temperature measurements received from the SEL-2600A.
Protection Math Variables	View the protection math variable values.
Automation Math Variables	View the automation math variable values.
MIRRORED BITS Communications	View the MIRRORED BITS communications analog quantities.
Through Faults	View the through-fault data.
Thermal Monitoring	View the most recent saved thermal report of the transformer(s) monitored by the device.
Breaker *n* Monitoring (*n* can be S,T,U,W, or X)	View a comprehensive circuit breaker report that includes interrupted currents, number of operations, and mechanical and electrical operating times.
Analog Signal Profile	View the Signal Profile data for as many as 20 user-selectable analog values.
VSSI Report	View the voltage sag, swell, and interruption report.
Targets	View Relay Word bits in a row/column format.
Status	A list of relay status conditions.
LDP	View load profile data.
SER	Sequential Events Recorder (SER) data listed oldest to newest, top to bottom. Set the range of SER records with the dialog boxes at the bottom of the display.
SSI	View voltage Sag, Swell, and Interruption data.
Breaker Monitor Data	A table showing the latest circuit breaker monitor data.
Control Window	Metering and records reset buttons, trip and close control, output pulsing, target reset, time and date set, group switch, and remote bit control.

The flashing LED representation in the lower left of the QuickSet window indicates an active data update via the communications channel (see *Figure 2.35*). Select the button marked **Disable Update** to suspend HMI use of the communications channel.

HMI Device Overview

Select the **Device Overview** branch to display an overview of the relay operation. This view includes a summary of information from many of the other HMI branches, including fundamental metering, contact input/output status, and front-panel LED status.

The **Device Overview** colors and text can be customized. White LED symbols indicate a deasserted condition and LED symbols with any other color indicate an asserted condition. Select an LED symbol to change its assert color.

HMI Control Window

Select the **Control Window** branch to reset metering values, clear event records, trip and close reclosers/breakers, pulse output contacts, and set and clear remote bits (see *Figure 2.36*) for a representative example.

Figure 2.36 Control Window

Other HMI Branches

The remaining HMI branches display metering, targets, status, reporting, and monitoring information.

HMI Configurations

Customized **Device Overviews** can be saved as HMI Configurations. To save the current configuration, select **Tools > HMI > Save Configuration** to save the configuration under the current name, or **Tools > HMI > Save Configuration As** to specify a configuration name.

HMI configurations are identified by relay type and a configuration name. To use an existing configuration, select **Tools > HMI > Select Configuration**. To view available configurations, select **Tools > HMI > Manage Configurations**. To make an existing configuration the default configuration for a given relay type, select the configuration in the **Manage Configurations** window, select **Edit**, and select the **Default** check box.

Analyze Events

QuickSet has integrated analysis tools that help you retrieve information about protection system operations quickly and easily. Use the protection system event information that relays store to evaluate the performance of a protection system.

Event Waveforms

Relays record power system events for all trip situations and for other operating conditions programmed with SELOGIC control equations.

The relays provide two types of event data captures:

- Event report oscillography that uses filtered sample-per-cycle data
- Unfiltered (raw) data

Use QuickSet to view event report oscillograms, phasor diagrams, harmonic analysis, and settings.

Read History

You can retrieve event files stored in the relay and transfer these files to a computer. To download event files from the relay, open the QuickSet **Tools > Events** menu on the QuickSet toolbar and select **Get Event Files**. The **Event History** dialog box will appear (similar to *Figure 2.37*).

Figure 2.37 Retrieving an Event History

Get Event

Highlight the event you want to view and select the **Get Selected Event** button. The **Event Options** dialog box allows selection of Event Type and Event Length. When downloading is complete, QuickSet asks for a location to save the file on your computer. Select **Tools > Events> View Event Files with SynchroWAVe Event** and select an event file to view events saved on your computer.

QuickSet Help

Various forms of QuickSet help are available as shown in *Table 2.6*. Press **<F1>** to open a context-sensitive help file with the appropriate topic as the default. Other ways to access help are shown in *Table 2.6*.

Table 2.6 Accessing QuickSet Help

Help	Description
General QuickSet	Select **Help > Contents** from the main menu bar.
HMI Application	Select **Help > HMI Help** from the main menu bar.
Relay Settings	Select **Help > Settings Help** from the from the main menu bar.
Database Manager	Select **Help** from the bottom of the **Database Manager** window.
Communications Parameters	Select **Help** from the bottom of the **Communications Parameters** window.

SECTION 3

Basic Relay Operations

The SEL-400 series relays are powerful tools for power system protection and control. Understanding basic relay operation principles and methods will help you use the relay effectively. This section presents the fundamental knowledge you need to operate the relay, organized by task. These tasks help you become familiar with the relay and include the following:

- *Inspecting a New Relay on page 3.1*
- *Establishing Communication on page 3.3*
- *Access Levels and Passwords on page 3.7*
- *Checking Relay Status on page 3.13*
- *Making Simple Settings Changes on page 3.15*
- *Examining Metering Quantities on page 3.34*
- *Examining Relay Elements on page 3.42*
- *Reading Oscillograms, Event Reports, and SER on page 3.46*
- *Operating the Relay Inputs and Outputs on page 3.55*
- *Configuring Timekeeping on page 3.64*
- *Readying the Relay for Field Application on page 3.65*

Perform these tasks to gain a good understanding of relay operation, be able to confirm that the relay is properly connected, and be more effective when using the relay. To work through the examples in this section, you need to install the relay either in a final installation or in a laboratory configuration. See *Section 2: Installation* in the product-specific instruction manual for more information.

Inspecting a New Relay

NOTE: Do not connect power to the relay until you have completed your inspection of the relay. See the product-specific Installation section for details on applying power. Failure to follow these instructions can lead to equipment damage.

The following items are included in your shipment from SEL:

- Relay
- SEL Grid Configurator, ACSELERATOR QuickSet SEL-5030 Software, and ACSELERATOR Architect SEL-5032 Software
- Configurable Front-Panel Label Kit
- SEL Contact Card

If any item is missing or damaged, please contact your distributor or SEL immediately.

Initial Inspection

Perform the following initial inspection when the relay arrives:

Step 1. Remove the protective wrapping from the relay.

Step 2. Observe the outside of the front cover and the rear panel.

Step 3. Check that no significant scratches or dents are evident on any outer surface.

Step 4. Confirm that all terminal strips on the rear panel are secure.

Perform the following steps and use care when cleaning the relay:

Step 1. Use a mild soap or detergent solution and a damp cloth to clean the relay chassis.

Be careful cleaning the front and rear panels because a permanent plastic sheet covers each panel; do not use abrasive materials, polishing compounds, or harsh chemical solvents (such as xylene or acetone) on any relay surface.

Step 2. Allow the relay to air dry, or wipe dry with a soft dry cloth.

Verify Relay Configuration

When you first inspect the relay, confirm that the relay power supply voltage and nominal ac signal magnitudes are appropriate for your application. Examine the serial number label on the relay rear panel. *Figure 3.1* shows a sample rear-panel serial number label.

Figure 3.1 Sample Relay Serial Number Label

NOTE: Do not use this page for ordering a relay. For ordering information, refer to the relay Model Option Table available at selinc.com, or contact your SEL Sales Representatives.

Figure 3.1 shows a serial number label for an SEL-451 with additional I/O in a 4U horizontal chassis. This example serial number label is for a 5 A-per-phase secondary CT input relay. For information on CT and PT inputs, Do not use this page for ordering a relay. For ordering information, refer to the SEL-451 Model Option Table available at selinc.com/products/, or contact your SEL Sales Representatives.

The power supply specification in *Figure 3.1* indicates that this relay is equipped with a power supply that accepts a nominal 48–125 Vdc input. This power supply also accepts a 110–120 Vac input. Refer to the serial number label affixed to the back of your relay to determine the power supply voltage you should apply to the relay power supply input terminals. As this label indicates, the voltage source should be capable of providing at least 35 W for dc inputs and 90 VA for ac inputs. See *Section 1: Introduction and Specifications* in the product-specific instruction manual for more information on power supply specifications.

The serial number label does not list power system phase rotation and frequency ratings, because you can use relay settings to configure these parameters. The factory defaults are ABC phase rotation and 60 Hz nominal frequency. See *Making Settings Changes in Initial Global Settings on page 3.21* for details on setting these parameters.

Input Ratings

The serial number label in *Figure 3.1* only lists control input voltages for I/O Interface Boards that have optoisolated inputs, which is determined at ordering time. The other types of control inputs (direct-coupled) have settable pickup voltages, and do not appear on the serial number label. See *Control Input Assignment on page 3.61* for more information.

Establishing Communication

Once you have applied the correct power input successfully, you are ready to operate the relay. Use the relay front panel and the communications ports to communicate with the relay.

Front-panel control of relay functions involves use of a menu system that you access through the LCD and the six navigational pushbuttons shown in *Figure 3.2*. For complete instructions on using the front-panel menu system, see *Front-Panel Menus and Screens on page 4.14*.

Figure 3.2 PORT F, LCD, and Navigation Pushbuttons

Fast and efficient communication with the relay is available through communications ports such as PORT F, also shown in *Figure 3.2*. A design philosophy for all SEL relays is that an ASCII or open terminal is all that you need to communicate with the relay. Many off-the-shelf computer programs provide terminal emulation. These programs are inexpensive and widely available.

Use the cable connections appropriate for your terminal configuration. See *Section 15: Communications Interfaces* for more information on communications ports.

All ASCII commands you send to the relay must terminate with a carriage return or carriage return/line feed; the terminal emulation program appends the necessary carriage return when you press **<Enter>**.

You can truncate commands to the first three characters: EVENT 1 becomes EVE 1. Use upper- and lowercase characters without distinction, except in passwords, which are case-sensitive. For a list of ASCII commands see *Section 14: ASCII Command Reference*.

Help

When you are using a terminal, you can access built-in relay help for each ASCII command. Relay help is access-level sensitive; you see only the ASCII commands for the present access level when you type **HELP <Enter>**. For in-depth information on a particular ASCII command, enter the command name after typing **HELP**. For example, for help on the **EVENT** ASCII command, type **HELP EVE <Enter>**.

When you are using QuickSet, press **<F1>** to get help, or select the **Help** menu from the QuickSet toolbars. The help information in QuickSet gives detailed information and sample screens in a GUI format.

Making an EIA-232 Serial Port Connection

The following steps use any popular computer terminal emulation software and SEL serial cables to connect to the relay.

Use an SEL-C234A cable to connect a 9-pin computer serial port to the relay. Use an SEL-C227A cable to connect a 25-pin computer serial port to the relay. For computers with USB ports, use an SEL-C662 USB-to-serial cable to connect to the relay. See *Section 15: Communications Interfaces* for further information on serial communications connections. These and other cables are available from SEL. Contact the factory or your local distributor for more information.

Step 1. Use the serial cable to connect the computer to the relay via PORT F on the relay front panel.

Step 2. Apply power to both the computer and to the relay.

Step 3. Start the computer terminal emulation program.

Step 4. Set your computer terminal emulation program serial communications parameters.

The default relay communications port settings are listed in *Table 3.1*.

Also set the terminal program to emulate either VT100 or VT52 terminals. These terminal emulations work best with SEL relays.

Table 3.1 General Serial Port Settings

Name	Description	Default
PROTO	Protocol (SEL, DNP, MBA, MBB, RTD, PMU)	SEL
SPEED	Data speed (300 to 57600, SYNC)	9600
DATABIT	Data bits (7, 8 bits)	8
PARITY	Parity (Odd, Even, None)	N
STOPBIT	Stop bits (1, 2 bits)	1
RTSCTS	Enable Hardware Handshaking (Y, N)	N

Step 5. To check the communications link, press **<Enter>** to confirm that you can communicate with the relay.

You will see the Access Level 0 = prompt at the left side of your computer screen (column 1).

If you do not see the prompt, check the cable connections and confirm the settings in your terminal emulation program match the default communications parameters shown in *Table 3.1*.

Step 6. Type **QUIT <Enter>** to view the relay report header.

You will see a computer screen display similar to that shown in *Figure 3.3*. (Text that you type is emphasized in bold letters.)

If you see jumbled characters, change the terminal emulation type in the computer terminal program.

```
=QUIT <Enter>

Relay 1                                    Date: 04/16/2004  Time: 00:01:05.209
Station A                                  Serial Number: 2001001234

=
```

Figure 3.3 Report Header

When you communicate with the relay at the Access Level 0 = prompt, you are in security Access Level 0. You cannot view or control relay functions at this level.

Higher access levels are password-protected and allow increased control over relay operation. For more information on access levels and password protection, see *Changing the Default Passwords in the Terminal on page 3.11*.

Making an Ethernet Telnet Connection

Factory-default settings for the Ethernet ports disable all Ethernet protocols. Enable the Telnet protocol with the SET P 5 command by using any of the serial ports. Command **SET P 5** accesses settings for all Ethernet ports on the relay.

Make the following settings by using the **SET P 5** command:

- EPORT = Y
- IPADDR = IP Address assigned by network administrator in classless inter-domain routing (CIDR) notation
- DEFRTR = Default router gateway IP Address assigned by network administrator
- NETMODE = FAILOVER
- ETELNET = Y

NOTE: For the five-port Ethernet card, set EINTF to **CD** and/or **E**. Then, set ETELNET to **CD** and/or **E**.

Leave all other settings at their default values.

NOTE: If connecting to a single-mode SFP, use an SEL-C809 cable (9 µm single-mode fiber-optic cable).

Connect an Ethernet cable between your PC or a network switch and any non-process bus Ethernet port on the relay. Verify that the amber **LINK** LED illuminates on the connected relay port. Many computers and most Ethernet switches support autocrossover, so nearly any Cat 5 Ethernet cable with RJ45 connectors, such as an SEL-C627 cable, will work. When the computer does not support autocrossover, use a crossover cable, such as an SEL-C628 cable. For fiber-optic Ethernet ports, use an SEL-C807 cable (62.5/200 µm multimode fiber-optic cable) or SEL-C808 cable (62.5/125 µm multimode fiber-optic cable). Use a Telnet client or QuickSet on the host PC to communicate with the relay. During Ethernet transmit or receive activity, the green Activity LED blinks on the relay Ethernet port. To terminate a Telnet session, use the command **EXI <Enter>** from any access level.

Making an Ethernet Web Server (HTTP) Connection

When PORT 5 setting EHTTP is enabled, the relay serves read-only webpages displaying certain settings, metering, and status reports. The relay-embedded HTTP server has been optimized and tested to work with the most popular web browsers, but should work with any standard web browser. As many as four users can access the embedded HTTP server simultaneously.

To begin using the embedded read-only HTTP server, launch your web browser, and browse to http://IPADDR, where IPADDR is the PORT 5 setting IPADDR (e.g., http://192.168.1.2). The relay responds with a login screen as shown in *Figure 3.4*.

Figure 3.4 HTTP Server Login Screen

Choose **ACC** for the username, type in the relay Access Level 1 password, and select **Submit**. The only username allowed is ACC. The relay responds with the homepage shown in *Figure 3.5*. While you remain logged in to the relay, the webpage displays the approximate time as determined by the relay time-of-day clock, and increments the displayed time once per second based on the clock contained in your PC.

Once the user is logged in, the HTTP server displays the Meter webpage. This page will refresh within five seconds and includes all metering options available and enabled on the relay.

Figure 3.5 Example HTTP Server Meter Page

Select any menu selection in the left pane to navigate through the available web-pages.

Access Levels and Passwords

NOTE: Perform the password change steps described in Changing the Default Passwords in the Terminal on page 3.11.

It is extremely important that you change the factory-default passwords programmed in the relay. Setting unique passwords for the relay access levels increases the security of your substation and the power system.

This section begins with information on the access level/password system in SEL-400 series relays and includes an example of changing the default passwords.

Access Levels

Access levels control whether you can perform different operations within the relay. These security levels are labeled 0, 1, B, P, A, O, 2, and C. *Figure 3.6* presents an overview of the general access level structure in the relay.

Figure 3.6 Access Level Structure

Access Level 0 is the least secure and most limited access level, and Access Level 2 is the most secure level at which you have total relay functionality (Level C is reserved for SEL factory operations. Only go to level C to change the level C password or under the direction of an SEL employee). For example, from Access Level 1, you can view settings, but you cannot change settings unless you are at a higher access level.

Table 3.2 lists access levels and operator functions for the relay.

Table 3.2 SEL-400 Series Relays Access Levels

Access Level	Prompt	Allowed Operations
0	=	Log in to Access Level 1.
1	=>	View data and status information.
B	==>	Access Level 1 functions plus breaker control and data.
P	P=>	Access Level B functions plus protection settings.
A	A=>	Access Level B functions plus automation settings.
O	O=>	Access Level B functions plus output settings.
2	=>>	Perform all relay access level functions.
C	==>>	SEL factory-specific functions. For a list of commands available, contact SEL.

The relay performs command interpretation and execution according to your validated access level. Each access level has a password that the relay must verify before you can control the relay at that level. *Table 3.3* lists the access level commands with corresponding passwords.

Table 3.3 Access Level Commands and Passwords

Access Level	Command	Factory-Default Password
0	QUIT	(None)
1	ACCESS	OTTER
B	BACCESS	EDITH
P	PACCESS	AMPERE
A	AACCESS	VOLTA
O	OACCESS	WATT
2	2ACCESS	TAIL
C	CAL	Sel-1

Communications Ports Access Levels

⚠WARNING
This device is shipped with default passwords. Default passwords should be changed to private passwords at installation. Failure to change each default password to a private password may allow unauthorized access. SEL shall not be responsible for any damage resulting from unauthorized access.

Entrance to the higher security levels is sequential. You must first enter a correct password to move from Access Level 0 to Access Level 1.

To enter Access Levels B, P, A, O, and 2, you must enter a correct password from Access Level 1. For example, to go to the O (Output) Access Level from Access Level 1, type **OAC <Enter>**. At the `Password: ?` prompt, type your Access Level O password.

To enter Access Level C, you must enter a correct password from Access Level 2.

Use the relay **QUIT** command from any access level to return the relay to Access Level 0. To reestablish control at a previous access level from Access Level 1, you must use the access level commands and passwords to log in to that previous access level.

When a connection with the relay times out, the relay reduces the access level to Access Level 0 for that communications port connection.

Use the MAXACC port setting to limit the maximum access level permitted on a station bus port. This can be useful to restrict what remote users can do. For the five-port Ethernet card, use the MAXACCE port setting to limit the maximum access level permitted on the engineering access port (**PORT 5E**).

Communications Ports Access Control

Port access control provides a flexible way to manage access permissions on designated ports. For example, a remote administrator (e.g., SCADA) can use this feature to grant temporary or limited access to personnel in the field.

Set port setting EPAC = Y to enable access control on a particular port. Use the Global SELOGIC equations EACC and E2AC to define the access criteria for all EPAC enabled ports. If EACC and E2AC evaluate to 0, all access requests are denied. If EACC evaluates to 1, Access Level 1 requests are permitted. If E2AC evaluates to 1, all access level requests are permitted (see *Figure 3.7*). Note that passwords are still required to escalate privilege.

[1] Requires correct password for the requested access level
[2] Where n = 1, 2, 3, F, or 5

Figure 3.7 Port Access Control Flow Chart

Port access control does not apply when the relay is disabled, the password jumper is installed (PASSDIS = 1), or when EPAC = N, nor can it be used to decrease a user's current access level or exceed the MAXACC setting level of the port.

Front-Panel Access Levels

The lowest access level for the front panel is Access Level 1. To enter Access Levels B, P, A, O, and 2, you must enter a correct password from Access Level 1.

The front-panel LCD displays a password prompt when you attempt to control the relay at any access level higher than Access Level 1. (For more information on entering passwords from the front panel, see *PASSWORD on page 14.52*.)

The front-panel `MAIN MENU` item `RESET ACCESS LEVEL` returns the relay to Access Level 1. In addition, when the front-panel inactivity timer times out (indicated by the `ROTATING DISPLAY` on the front-panel LCD), the relay returns the front-panel access level to Access Level 1.

ACCESS Command

NOTE: You can shorten relay commands to the first three letters of the full command. Section 14: ASCII Command Reference for more information.

Enter the **ACCESS (ACC)** command to change to Access Level 1. Passwords are case-sensitive; you must enter a password exactly as set.

If you enter the password correctly, the relay moves to Access Level 1 and the Access Level 1 => prompt appears. If you are at a higher access level (B, P, A, O, and 2), you can reduce the access level to Access Level 1 by entering the **ACC** command. The relay performs no password validation to reduce the present access level.

Higher Access Level Commands

Enter the commands in *Table 3.3* to enter access levels above Access Level 1. For example, enter the **2ACCESS (2AC)** command to change to Access Level 2.

If you are presently at Access Level 1, B, P, A, or O, typing **2AC <Enter>** causes the relay to prompt you to type the Access Level 2 password. If the present level is Access Level 0, the relay responds with `Invalid Access Level`. The relay pulses alarm Relay Word bit SALARM when entering Access Levels B, P, A, O, and 2 from a lower access level.

If an incorrect password is entered three times, the relay asserts the BADPASS and SALARM Relay Word bits for one second and displays on a communications terminal screen the following error message:

```
WARNING: ACCESS BY UNAUTHORIZED PERSONS STRICTLY PROHIBITED
```

In addition, you cannot make further access level entry attempts for 30 seconds. The relay terminates the communications connection after the third failed attempt when you use Ethernet via an Ethernet card, DNP3 (Distributed Network Protocol version 3.0), or MIRRORED BITS communications virtual terminal mode. For more information on these protocols, see *Section 15: Communications Interfaces* and *Section 16: DNP3 Communication*.

If your connection to the relay has an inactivity time-out (in the **SET P** port settings), the relay automatically closes the communications connection and changes to Access Level 0 when the time-out occurs.

Passwords

⚠WARNING
This device is shipped with default passwords. Default passwords should be changed to private passwords at installation. Failure to change each default password to a private password may allow unauthorized access. SEL shall not be responsible for any damage resulting from unauthorized access.

Valid passwords are character sequences of as many as 12 characters. Valid password characters are any printable ASCII character. HMI password entry is limited to upper- and lowercase letters, numbers, underscore, and period, so you must limit your password to these characters if you need to do privileged operations from the front panel. Passwords are case-sensitive.

It is important that you change all of the passwords from their default values. This will protect you from unauthorized access.

Use strong passwords. Strong passwords contain a mix of the valid password characters in a combination that does not spell common words in any portion of the password.

Changing the Default Passwords in the Terminal

Step 1. Confirm that the relay is operating (see *Establishing Communication on page 3.3*).

Step 2. Establish communication with the relay (see *Making an EIA-232 Serial Port Connection on page 3.4* to learn how to use a terminal to communicate with the relay).

Step 3. Enter Access Level C (Access Level 2 is sufficient except when changing the Access Level C password).

a. Using a communications terminal, type **ACC <Enter>**.

b. Type the Access Level 1 password **OTTER** and press **<Enter>**.

You will see the Access Level 1 => prompt.

c. Type **2AC <Enter>**.

NOTE: Passwords are case-sensitive; you must enter passwords exactly as set.

d. At the password prompt, type **TAIL <Enter>**.

e. You will see the Access Level 2 =>> prompt.

f. Type **CAL <Enter>**.

g. At the password prompt, type **Sel-1 <Enter>**.

You will see the Access Level C ==>> prompt.

Step 4. To set a new password for Access Level 2, type the following:

PAS 2 <Enter>.

Step 5. Before you can change to a new password, the relay prompts you to first confirm the existing password. Enter the existing password and press **<Enter>**.

```
Old Password:  ?**** <Enter>
```

Step 6. The relay prompts you for the new password, and a confirmation of the new password, as follows:

```
New Password:  ?**** <Enter>
Confirm New Password:  ?**** <Enter>
Password Changed
CAUTION: This password can be strengthened. Strong Passwords do not
   include a name, date, acronym or word. They consist of the maximum
   allowable characters, with at least one special character, number,
   lower-case letter, and upper-case letter. A change in password is
   recommended.
```

Notice that the new password is not displayed. After the confirmation, the new password is in effect. The relay will issue a weak password warning if the new password does not include at least one special character, number, lowercase letter, and uppercase letter.

Step 7. Set new passwords for each access level.

In a similar manner as the previous step, create new strong passwords for each access level.

Step 8. Commit these passwords to memory, permanently record your new passwords, and store this permanent record in a secure location.

To eliminate password verification for an access level, enter **DISABLE** in place of the new password. This action will disable the password of that level; therefore, the relay does not check for a password upon entering that access level.

If you forget a password or encounter difficulty changing the default passwords, you can temporarily disable password verification. See *Section 2: Installation* in the product-specific instruction manual for information on the password disable jumper.

Checking Relay Status

With continual self-testing, the relay monitors the internal operation of all circuits to verify optimal performance of relay functions. If an internal circuit, protection algorithm, or automation algorithm enters an out-of-tolerance operating range, the relay reports a status warning. In the unlikely event that an internal failure occurs, the relay reports a status failure. For more information on relay status, see *Relay Self-Tests on page 10.19*.

You can check relay status through a communications port by using a terminal, terminal emulation computer program, or QuickSet. In addition, you can use the relay front panel to view status information.

Checking Relay Status by Using the Terminal

The procedure in the following steps assumes that you have successfully established communication with the relay (see *Making an EIA-232 Serial Port Connection on page 3.4*). In addition, you must be familiar with relay access levels and passwords (see *Changing the Default Passwords in the Terminal on page 3.11* to change the default access level passwords).

Step 1. Enter Access Level 1.

a. Using a communications terminal, type **ACC <Enter>**.

b. Type the Access Level 1 password and press **<Enter>**.

You will see the Access Level 1 => prompt.

Step 2. Type **STA <Enter>**. The relay returns a status terminal screen similar to that in *Figure 3.8*.

```
=>STA <Enter>
Relay 1                                          Date: 03/17/2023  Time:07:02:50.776
Station A                                        Serial Number: 1230769999
FID=SEL-451-5-Rxxx-V0-Zxxxxxx-Dyyyymmdd            CID=0x9aed

Failures
  No Failures
Warnings
  No Warnings

SELogic Relay Programming Environment Errors
  No Errors
Relay Enabled
=>
```

Figure 3.8 Relay Status

Step 3. Type **STA A <Enter>** to view all relay status entries.

For more information on relay status report items, see *STATUS on page 14.60*.

Checking Relay Status in SEL Grid Configurator

You can use SEL Grid Configurator to check relay status.

The following procedure assumes that you are familiar with SEL Grid Configurator.

Step 1. Configure SEL Grid Configurator communications with the relay. See *Section 2: PC Software* for information on communicating with a relay in SEL Grid Configurator.

Step 2. Open a terminal communication session with the relay in SEL Grid Configurator.

a. Type **STA <Enter>**. The relay returns a status terminal similar to that in *Figure 3.9*.

```
=>STA <Enter>
Relay 1                                          Date: 03/17/2023  Time:07:02:50.776
Station A                                        Serial Number: 1230769999
FID=SEL-451-6-Rxxx-V0-Zxxxxxx-Dyyyymmdd            CID=0x9aed

Failures
  No Failures
Warnings
  No Warnings

SELogic Relay Programming Environment Errors
  No Errors
Relay Enabled
=>
```

Figure 3.9 Relay Status

b. Type **STA A <Enter>** to view all relay status entries.

For more information on relay status report items, see *STATUS on page 14.60*.

Checking Relay Status in QuickSet

You can use QuickSet to check relay status. Use the **HMI > Meter Control** menu to view status conditions.

The following procedure assumes that you are familiar with QuickSet.

Step 1. Configure QuickSet communications with the relay. See *Section 2: PC Software* for information on communicating with a relay in QuickSet.

Step 2. Select **Tools** in the top toolbar and select the **HMI** menu to start the QuickSet operator interface.

Step 3. Select the **Status** button of the HMI tree view (see *Figure 3.10*).

QuickSet displays the relay status with a display similar to that in *Figure 3.10*.

Figure 3.10 Retrieving Relay Status in QuickSet

Checking Relay Status From the Front Panel

Use the front-panel display and navigation pushbuttons to check relay status. See *Section 4: Front-Panel Operations* for information on using the relay front panel.

Step 1. Apply power to the relay, and note that the LCD shows a sequence of screens called the ROTATING DISPLAY.

(If you do not operate the front panel for a certain period, the relay will enter front-panel time-out mode and you will see the sequential screens of the ROTATING DISPLAY.)

Step 2. Press the **ENT** pushbutton to display the MAIN MENU as shown in *Figure 3.11*.

Figure 3.11 Checking Relay Status From the Front-Panel LCD

Step 3. View the relay status.

a. Press the **Up Arrow** and **Down Arrow** navigation pushbuttons to highlight the RELAY STATUS action item (see *Figure 3.11*).

b. Press the **ENT** pushbutton.

You will see the RELAY STATUS screen (the second screen of *Figure 3.11*).

Step 4. Press the **ESC** pushbutton to return to the MAIN MENU.

Step 5. Press **ESC** pushbutton again to return to the ROTATING DISPLAY.

For more information on the front-panel screen presentations and the items in the RELAY STATUS screens, see *Relay Status on page 4.30*.

Making Simple Settings Changes

⚠WARNING
Isolate the relay trip circuits while changing settings. When changing settings for multiple classes, it is possible to be in an intermediate state that will cause an unexpected trip.

The relay settings structure makes setting the relay easy and efficient. Settings are grouped logically, and relay elements that are not used in your selected protection scheme are hidden. SEL Grid Configurator or QuickSet uses a similar method to focus your attention on the active settings. Unused relay elements and inactive settings are dimmed (grayed) in the menus. See *Section 2: PC Software* for more information.

Settings Structure

SEL-400 series relays use a settings structure that assigns each relay setting to a specific location based on the setting type. A top-down organization allocates relay settings into these layers:

- Class
- Instance
- Category
- Setting

Examine *Figure 3.12* to understand the settings structure in a typical relay. The top layer of the settings structure contains classes and instances. Class is the primary sort level; all classes have at least one instance, and some classes have multiple instances. Settings classes and related instances for the SEL-451, which are typical of SEL-400 series relays, are listed in *Table 3.4*. See *Section 8: Settings* of the product-specific instruction manual for details on the classes and instances for a given relay.

Figure 3.12 Example Relay Settings Structure Overview

Table 3.4 SEL-451 Settings Classes and Instances (Sheet 1 of 2)

Class	Description	Instance	Description	ASCII Command	Access Level
Global	Relay-wide applications settings	Global		SET G	P, A, O, 2
Group	Individual scheme settings	Group 1 • • • Group 6	Group 1 settings • • • Group 6 settings	SET 1, SET S 1 • • • SET 6, SET S 6	P, 2
Breaker Monitor	Circuit breaker monitoring settings	Breaker Monitor		SET M	P, 2

Table 3.4 SEL-451 Settings Classes and Instances (Sheet 2 of 2)

Class	Description	Instance	Description	ASCII Command	Access Level
Port	Communications port settings	PORT F PORT 1 • • • PORT 3 PORT 5 PORT 6 (TiDL relays only)	Front-panel port PORT 1 settings • • • PORT 3 settings Communications card settings TiDL Topology Settings (TiDL relays only)	SET P F SET P 1 • • • SET P 3 SET P 5 (Only available via Grid Conifgurator)	P, A, O, 2
Report	Report settings	Report		SET R	P, A, O, 2
Front Panel	Front-panel HMI settings	Front Panel		SET F	P, A, O, 2
Protection SELOGIC control equations	Protection-related SELOGIC control equations	Group 1 • • • Group 6	Group 1 protection SELOGIC control equations • • • Group 6 protection SELOGIC control equations	SET L 1 • • • SET L 6	P, 2
Automation SELOGIC control equations	Automation-related SELOGIC control equations	Block 1 • • • Block 10	Block 1 automation SELOGIC control equations • • • Block 10 automation SELOGIC control equations	SET A 1 • • • SET A 10	A, 2
DNP3	Direct Network Protocol data remapping	Map 1 • • • Map 5		SET D 1 • • • SET D 5	P, A, O, 2
Output SELOGIC control equations	Relay control output settings and MIRRORED BITS communication transmit equations	Output		SET O	O, 2
Bay	Bay control settings	Bay		SET B	P, 2
Alias	Set aliases	Analog or digital quantities		SET T	P, A, O, 2
Notes	Freeform programming to leave notes in the relay	Notes	100 lines	SET N	P, A, O, 2

Note that some settings classes have only one instance and you do not specify the instance designator when accessing these classes. An example is the Global settings class. You can view or modify Global settings with a communications terminal by entering **SET G** as shown in the ASCII Command column of *Table 3.4*. The relay presents the Global settings categories at the **SET G** command; no instance numbers follow **SET G**. Conversely, the Port settings command has five instances (PORT F, PORT 1, PORT 2, PORT 3, and PORT 5). To access the PORT 1 settings, type **SET P 1 <Enter>**. If you do not specify which port to set, the relay defaults to the active port (the port you are presently using).

The Group settings can have the optional one-letter acronym S attached to the command; you can enter **SET 1** or **SET S 1** for Group 1 settings, **SET 2** or **SET S 2** for Group 2 settings, etc. If you do not specify which group to set, the

relay defaults to the present active group. If Group 6 is the active group, and you type **SET <Enter>**, for example, you will see the settings prompts for the Group 6 settings.

Alias Settings

Although the relay provides extensive programming facilities and opportunity for comments, troubleshooting customized programs is sometimes difficult. Aliases provide an opportunity to assign more meaningful names to the generic variable names to improve the readability of the program.

Rename, or assign as many as 200 alias names to any Relay Word bit or analog quantity in the relay. The maximum length of an alias is seven characters. Valid characters are 0–9, A–Z (only uppercase), and _ (underscore), and must contain at least one alphabetic character. Ensure that no Relay Word bit or analog quantity appears more than once in the Alias settings. Each alias name must be unique, i.e., you cannot use the name of an existing Relay Word bit or analog quantity. If you remove the alias name, all settings that referenced that alias revert to the original name.

Use the **SHO T** command to view the default settings, as shown in *Figure 3.13*.

```
=>>SHO T <Enter>
Alias
Relay Aliases
(RW Bit or Analog Qty. 7 Character Alias [0-9 A-Z _])
1: EN,"RLY_EN"
=>>
```

Figure 3.13 Default Alias Settings

Making Text-Edit Mode Alias Changes

Assign the alias name THETA to math variable PMV01 and the alias TAN to math variable PMV02. These variables are then used in calculating the tangent of theta, using their alias names in the equation.

Step 1. Prepare to control the relay at Access Level 2.

a. Type **ACC <Enter>** at a communications terminal.

b. Type the Access Level 1 password and press **<Enter>**.

You will see the Access Level 1 => prompt.

c. Type **2AC <Enter>**.

d. Type the correct password to go to Access Level 2.

You will see the =>> prompt.

Step 2. Type **SET T <Enter>** to access the Alias settings.

Figure 3.14 shows a representative computer terminal screen.

Step 3. Type **> <Enter>** for the relay to display the first line that you can edit.

Step 4. Type **PMV01,THETA <Enter>** at the Line 2 ? settings prompt to set the alias for PMV01.

The relay verifies that this is a valid entry, then responds with the next line prompt 3: followed by the ? settings prompt.

Step 5. Type **PMV02,TAN <Enter>** at the Line 3 ? settings prompt to set the alias for PMV02.

The relay verifies that this is a valid entry, then responds with the next line prompt 4: followed by the ? settings prompt.

Step 6. Type **END <Enter>** to end the settings session.

The relay scrolls a readback of all the front-panel settings, eventually displaying the `Save settings (Y, N) ?` prompt. At the end of the readback information, just before the `Save settings (Y, N) ?` prompt, you can verify the new display point information.

Step 7. Type **Y <Enter>** to save the new settings.

```
=>>SET T <Enter>
Alias
Relay Aliases
(RW Bit or Analog Qty. 7 Character Alias [0-9 A-Z _])
1: EN,"RLY_EN"
?   <Enter>
2:
?  PMV01,THETA <Enter>
3:
?  PMV02,TAN <Enter>

4:
?  END <Enter>
Alias
Relay Aliases
(RW Bit or Analog Qty. 7 Character Alias [0-9 A-Z _])
1: EN,"RLY_EN"
2: PMV01,"THETA"
3: PMV02,"TAN"

Save settings (Y,N)  ?Y <Enter>
Saving Settings, Please Wait..........
Settings Saved

=>>
```

Figure 3.14 Using Text-Edit Mode Line Editing to Set Aliases

Use the alias names, instead of the Relay Word bits, in SELOGIC control equation programming. *Figure 3.15* shows an example of an alias used in protection logic programming.

```
=>>SET L <Enter>
Protection 1
1: PLT01S := PB1_PUL AND NOT PLT01 #GROUND ENABLED
?  > <Enter>
15:
?  THETA:=I01FA <Enter>

16:
?  TAN:=SIN(THETA)/COS(THETA) <Enter>
17:
?  END <Enter>
Protection 1
.
.
.

Save settings (Y,N)  ?Y <Enter>
Saving Settings, Please Wait..........
Settings Saved

=>>
```

Figure 3.15 Using Text-Edit Mode Line Editing to Set Protection Logic

Changing Settings by Using the Terminal

When you change settings (with any **SET** command) from a terminal, the relay shows the setting category, prompt, present value, and action prompt.

Figure 3.16 shows two settings examples: multiple-line settings (SID and RID) and an in-line setting (NUMBK) for relay Global settings from Access Level P (protection). The relay prompts you for input by presenting an action prompt. You have many options for navigating the settings at the ? prompt.

Table 3.5 lists the operations possible from a settings action prompt.

```
==>SET G <Enter>
Global

General Global Settings                                          Category

Station Identifier (40 characters)                               Prompt
SID := "Station A"                                               Present Value
? <Enter>                                                        Action Prompt
Relay Identifier (40 characters)
RID := "Relay 1"
? <Enter>
Number of Breakers in Scheme (1,2)      NUMBK   := 1     ? <Enter>
                Prompt                           Present   Action
                                                  Value    Prompt
```

Figure 3.16 Components of SET Commands

Table 3.5 Actions at Settings Prompts

Action	Relay Response
<Enter>	Accept setting and move to the next setting; if at the last setting, exit settings.
[*value*] <Enter>	Enter the given *value* and move to the next setting if valid; if at the last setting, exit settings.
^ <Enter>	Move to the previous setting; if at the top of settings, stay at the present setting.
< <Enter>	Move to the top of the previous settings category; if at the top of settings, stay at the present setting.
> <Enter>	Move to the top of the next settings category; if in the last category, exit settings.
END <Enter>	Go to the end of the present settings session. Prepare to exit settings via the `Save settings (Y,N) ?` prompt.
<Ctrl+X>	Abort the editing session without saving changes.

When you exit settings entry from the **SET** commands, the relay responds with `Save settings (Y,N)?`. If you answer **Y <Enter>**, the relay writes the new settings to nonvolatile storage. If you answer **N <Enter>**, the relay discards any settings changes you have made.

Making Settings Changes in Initial Global Settings

You must configure SEL-400 series relays for specific conditions found in the power system where you are connecting the relay. For example, in most SEL-400 series relays you must set the nominal frequency and phase rotation.

The procedure in the following steps assumes that you have successfully established communication with the relay; see *Making an EIA-232 Serial Port Connection on page 3.4* for a step-by-step procedure. In addition, you must be familiar with relay access levels and passwords. See *Changing the Default Passwords in the Terminal on page 3.11* to change the default access level passwords.

This example jumps to a Global setting that is not at the beginning of the Global settings list. Thus, you enter **SET G**, the setting name, and **<Enter>**. To start at the beginning of the Global settings, simply type **SET G <Enter>** without a settings name.

Step 1. Prepare to control the relay at Access Level 2.

a. Using a communications terminal, type **ACC <Enter>**.

b. Type the Access Level 1 password and press **<Enter>**.

You will see the Access Level 1 => prompt.

c. Type **2AC <Enter>**.

d. Type the correct password to go to Access Level 2.

You will see the Access Level 2 =>> prompt.

Step 2. Type **SET G NFREQ <Enter>** (this sets the nominal system frequency using the **NFREQ** setting, which has options of 50 Hz and 60 Hz).

The relay responds with a terminal screen display similar to that shown in *Figure 3.17*.

```
=>>SET G NFREQ <Enter>
Global

General Global Settings

Nominal System Frequency (50,60 Hz)                NFREQ   := 60     ? <Enter>
System Phase Rotation (ABC,ACB)                    PHROT   := ABC    ? <Enter>
Date Format (MDY,YMD,DMY)                          DATE_F  := MDY    ? YMD <Enter>
Fault Condition Equation (SELogic Equation)
FAULT := 51S1 OR 51S2 OR 50P1
?  END <Enter>

.
.
.

Save settings (Y,N)  ? Y <Enter>
Saving Settings, Please Wait...........
Settings Saved
=>>
```

Figure 3.17 Example Global Settings

Step 3. Accept the default settings.

a. For a 60 Hz system, press **<Enter>** to accept the NFREQ existing value of 60 (Hz).

The relay presents the next setting, which is the PHROT (phase rotation) setting.

b. Type **<Enter>** to accept the ABC phase rotation default.

Step 4. Set the date format:

The relay can report dates in three formats: MDY, YMD, and DMY (where M = month, D = date, and Y = year).

a. For this procedure, type **YMD <Enter>**.

At each setting in turn, the relay presents the settings prompt, name, present value, and action prompt.

Note that SELOGIC control equation settings, such as FAULT in *Figure 3.17*, can appear on multiple lines.

b. If you make a mistake or want to go backward through the settings, type the ^ character (on most computer keyboards, this is a shifted numeral 6) and **<Enter>**.

Refer to *Table 3.5* for this and other navigational aids.

Step 5. End the settings session.

a. Type **END <Enter>** at the `FAULT` action prompt.

(The Fault SELOGIC control equation remains unchanged.)

The relay next scrolls a readback of all the Global settings, eventually displaying the following prompt:

`Save settings (Y,N) ?`

(In *Figure 3.17*, a vertical ellipsis represents the relay information during readback.)

b. Examine the settings readback to verify your new settings.

c. Answer **Y <Enter>** to save your new settings.

The TERSE Option

You can avoid viewing the entire class settings summary the relay displays when you type **END <Enter>** midway through a settings class or instance.

On slow data speed links, waiting for the complete settings readback can clog your automation control system or take too much of your time for a few settings changes. Eliminate the settings readback by appending **TERSE** to the **SET** command.

Text-Edit Mode Line Editing

Some relay settings present multiple input lines to your terminal; you use basic line text editing commands to construct the setting. For display, the relay references each line of the setting by line number, not by the setting name. See *Making Text-Edit Mode Settings Changes on page 3.23* for an example of a text-edit mode setting.

While in the text-edit mode, you see a prompt consisting of the line number and the present setting for that line. You can keep the setting, enter a new setting, or delete the setting. *Table 3.6* lists the commands for text-edit mode.

Table 3.6 Actions at Text-Edit Mode Prompts

Action	Relay Response
<Enter>	Accept the setting and move to the next line; if at the last line or at a blank line, exit settings.
>*n* <Enter>	Move to line *n*. If this is beyond the end of the list, move to a blank line following the last line.
^ <Enter>	Move to the previous line; if at the first line, stay at the present line.
< <Enter>	Move to the first line.
> <Enter>	Move to a blank line following the last line.
LIST <Enter>	List all settings and return to the present action prompt.
DELETE [*n*] <Enter>	Delete the present line and subsequent lines for a total of *n* lines; *n* = 1 if not provided. Lines after deletion shift upward by the number of lines deleted.
INSERT <Enter>	Insert a blank line at the present location; the present line and subsequent lines shift downward.
END <Enter>	Go to the end of the present settings session. Prepare to exit settings via the `Save settings (Y,N) ?` prompt.
<Ctrl+X>	Abort editing session without saving changes.

NOTE: To begin an entry with one of these keywords, especially in notes settings, put the string in quotes: e.g., "END OF REPORT".

Use commas to separate the items in a text-edit mode setting when you are entering multiple items per line. After you enter each line, the relay checks the validity of the setting. If the entered setting is invalid, the relay responds with an error message and prompts you again for the setting.

Making Text-Edit Mode Settings Changes

The procedure in the following steps familiarizes you with basic text-edit mode line editing.

Example 3.1 Text-Edit Mode Line Editing

Set Display Point 1 through Display Point 3 to show the status of Circuit Breaker 1, Circuit Breaker 2, and the operational state (on or off) of the transformer cooling fans near the circuit breaker bay where you have installed the relay. See *Display Points on page 4.10* for information on programming display points.

For this example, use inputs IN101, IN102, and IN105. You can use other inputs for your particular application.

This procedure assumes that you have successfully established communication with the relay (see *Making an EIA-232 Serial Port Connection on page 3.4*). In addition, you must be familiar with relay access levels and passwords (see *Changing the Default Passwords in the Terminal on page 3.11*) to change the default access level passwords.

Step 1. Prepare to control the relay at Access Level 2.

a. Using a communications terminal, type **ACC <Enter>**.

b. Type the Access Level 1 password and press **<Enter>**.

You will see the Access Level 1 => prompt.

c. Type **2AC <Enter>**.

d. Type the Access Level 2 password and press **<Enter>**.

You will see the Access Level 2 =>> prompt.

Step 2. Access the display point settings.

a. Type **SET F <Enter>** to modify the front-panel settings.

b. Advance through the front-panel settings (repeatedly type **>** and then **<Enter>**) until you reach the **Display Points** category.

Figure 3.18 shows a representative terminal screen. The relay displays the first line that you can edit. For the case of display points, the line number is the display point number.

Step 3. At the Line 1 settings ? prompt, type the following to create Display Point 1:

IN101,CB1,CLOSED,OPEN <Enter>

The relay verifies that this is a valid entry, then responds with the next line prompt `2:` followed by the settings ? prompt (see *Figure 3.18*).

Step 4. At the Line 2 settings ? prompt, type the following to create Display Point 2:

IN102,CB2,CLOSED,OPEN <Enter>

The relay verifies that this is a valid entry, then responds with the next line prompt `3:` followed by the settings ? prompt (see *Figure 3.18*).

Step 5. At the `Display Points` prompt, use the text-edit mode line editing commands to list the active display points. Type the following:

LIST <Enter>

After showing the active display points, the relay returns to Line 3 followed by the settings ? prompt.

NOTE: Use quotation marks when entering alias strings that contain spaces or punctuation marks, as shown in the IN105 sample, Step 6.

Step 6. Type the following to create Display Point 3:

IN105,“5 MVA XFMR Fans”,ON,OFF <Enter>

The relay verifies that this is a valid entry, then responds with the next line prompt `4:` followed by the settings ? prompt (see *Figure 3.18*).

Example 3.1 Text-Edit Mode Line Editing (Continued)

Step 7. Type **END <Enter>** to end the editing session.

The relay scrolls a readback of all the front-panel settings, eventually displaying the `Save settings (Y,N) ?` prompt. (A vertical ellipsis in *Figure 3.18* represents the readback.)

At the end of the readback information, just before the `Save settings (Y,N) ?` prompt, you can verify the new display point information.

Step 8. Answer **Y <Enter>** to save the new settings.

```
Display Points
(Boolean) : RWB Name, “Label”, “Set String”, “Clear String”, “Text Size”
(Analog) : Analog Quantity Name, “User Text and Formatting”, “Text Size”


1:
? IN101,CB1,CLOSED,OPEN <Enter>
2:
? IN102,CB2,CLOSED,OPEN <Enter>
3:
? LIST <Enter>
1: IN101,"CB1","CLOSED","OPEN",S
2: IN102,"CB2","CLOSED","OPEN",S

3:
? IN105,“5 MVA XFMR Fans”,ON,OFF <Enter>
4:
? END <Enter>
              .
              .
              .

Display Points
(Boolean) : RWB Name, “Label”, “Set String”, “Clear String”, “Text Size”
(Analog) : Analog Quantity Name, “User Text and Formatting”, “Text Size”
1: IN101,"CB1","CLOSED","OPEN",S
2: IN102,"CB2","CLOSED","OPEN",S
3: IN105,"5 MVA XFMR Fans","ON","OFF",S
              .
              .
              .

Save settings (Y,N)  ? Y <Enter>
Saving Settings, Please Wait...........
Settings Saved
=>>
```

Figure 3.18 Using Text-Edit Mode Line Editing to Set Display Points

This procedure proposes connecting the transformer bank fan sensor to relay input IN105. In the **SET G** (GLOBAL) command, verify that the debounce time settings IN105PU and IN105DO are correct for your fan-running sensor. To access separate input parameters, you must first enable independent control input settings with setting EICIS. To change the input conditioning, enter the following settings:

EICIS := **Y** Enable Independent Control Input Settings (Y, N)

IN105PU := **0.3750** Pickup Delay for Contact Input IN105 (0.0000–5 cyc)

IN105DO := **0.3750** Dropout Delay for Contact Input IN105 (0.0000–5 cyc)

Use the appropriate interface hardware to connect the fan-running sensor to IN105. Choose any relay input that conforms to your requirements.

Example 3.2 Leaving a Note in the Relay

For this example, assume you are testing a line, but you will be away for a few days. You want to leave your colleague, Marius, a note telling him where you left the drawings and settings. Use the Notes function in the relay to leave the note, as shown in *Figure 3.19*. All relevant procedures in this section assume that you have successfully established communication with the relay. In addition, you must be familiar with relay access levels and passwords to change the default access level passwords. Furthermore, *Step 1* applies to all relevant tests, and is not repeated for each test.

Step 1. Prepare to control the relay at Access Level 2.

a. Using a communications terminal, type **ACC <Enter>**.

b. Type the Access Level 1 password and press **<Enter>**.

You will see the Access Level 1 => prompt.

c. Type **2AC <Enter>**.

d. Type the correct password to go to Access Level 2.

You will see the Access Level 2 =>> prompt.

Step 2. Access the Notes settings.

a. Type **SET N <Enter>** to access the Notes settings.

b. At the Line 1 settings `?` prompt, type the Line 1 text shown in *Figure 3.19* (as many as 70 characters without wrap), and press **<Enter>**.

The relay verifies that this is a valid entry, then responds with the next line prompt `2:` followed by the settings `?` prompt.

Step 3. At the Line 2 settings `?` prompt, type the Line 2 text shown in *Figure 3.19*.

Because there are more than 70 characters, the relay rejects the entry.

Re-enter the text, but keep the number of characters at 70 or fewer.

Step 4. After the last entry, type **END <Enter>**.

This tells the relay that you have completed the setting change.

Step 5. Type **Y <Enter>** at the prompt `Save settings (Y,N)` to save the settings.

```
=>>SET N <Enter>
Notes
1:
? Marius, this is the relay for CARR substation <Enter>
2:
? The Sacramento line drawings and setting sheets are in the top drawer in the sub\
station. <Enter>
Note cannot exceed 70 chars

2:
? The Sacramento line drawings and settings are in the <Enter>
3:
? top drawer in the substation. <Enter>
4:
? END <Enter>
Notes
1: Marius, this is the relay for CARR substation
2: The Sacramento line drawings and settings are in the
3: top drawer in the substation.

Save settings (Y,N) ?Y <Enter>
Saving Settings, Please Wait...........
Settings Saved
```

Figure 3.19 Leave a Note in the Relay

To read the note, type **SHO N <Enter>**, as shown in *Figure 3.20*.

```
=>>SHO N <Enter>
Notes
1: Marius, this is the relay for CARR substation
2: Capacitor Bank 1 drawings and settings are in the
3: top drawer in the substation.
=>>
```

Figure 3.20 Read a Note in the Relay

Example 3.3 Deleting a Display Point

This example shows you how to delete a previously used display point. In the **SET F** command, at the Display Points and Aliases prompt, use the text-edit mode line editing commands to set and delete the display points. This procedure shows two previously programmed display points that indicate on the front-panel LCD the status of Circuit Breaker 1 and Circuit Breaker 2. Relay control inputs IN101 and IN102 are the Relay Word bits for the Circuit Breaker 1 and Circuit Breaker 2 display points, respectively (see *Making Text-Edit Mode Settings Changes on page 3.23*). You can use other inputs for your particular application.

The procedure in the following steps assumes that you have successfully established communication with the relay (see *Making an EIA-232 Serial Port Connection on page 3.4*). In addition, you must be familiar with relay access levels and passwords (see *Changing the Default Passwords in the Terminal on page 3.11*).

Step 1. Prepare to control the relay at Access Level 2.

a. Using a communications terminal, type **ACC <Enter>**.

b. Type the Access Level 1 password and press **<Enter>**.

You will see the Access Level 1 => prompt.

c. Type **2AC <Enter>**.

d. Type the correct password to go to Access Level 2.

You will see the Access Level 2 =>> prompt.

Example 3.3 Deleting a Display Point (Continued)

Step 2. Access the `Display Points and Aliases` prompt.

a. Enter the **SET F** command.

b. Advance through the front-panel settings (repeatedly type **>** and then **<Enter>**) until you reach the `Display Points and Aliases` category.

Figure 3.21 shows a representative terminal screen. The relay displays the first line that you can edit. For display points, the line number is the display point number.

```
Display Points
(Boolean) : RWB Name, “Label”, “Set String”, “Clear String”, “Text Size”
(Analog) : Analog Quantity Name, “User Text and Formatting”, “Text Size”
1: IN101,"CB1","CLOSED","OPEN",S
?  LIST <Enter>
1: IN101,"CB1","CLOSED","OPEN",S
2: IN102,"CB2","CLOSED","OPEN",S
3: IN105,"5 MVA XFMR Fans","ON","OFF",S

1: IN101,"CB1","CLOSED","OPEN",S
?  <Enter>
2: IN102,"CB2","CLOSED","OPEN",S
?  DELETE <Enter>
2: IN105,"5 MVA XFMR Fans","ON","OFF",S
?  LIST <Enter>

1: IN101,"CB1","CLOSED","OPEN",S
2: IN105,"5 MVA XFMR Fans","ON","OFF",S
2: IN105,"5 MVA XFMR Fans","ON","OFF",S
?  END <Enter>
              .
              .
              .

Display Points
(Boolean) : RWB Name, “Label”, “Set String”, “Clear String”, “Text Size”
(Analog) : Analog Quantity Name, “User Text and Formatting”, “Text Size”
1: IN101,"CB1","CLOSED","OPEN",S
2: IN105,"5 MVA XFMR Fans","ON","OFF",S
              .
              .
              .

Save settings (Y,N)  ? Y <Enter>
Saving Settings, Please Wait...........
Settings Saved
=>>
```

Figure 3.21 Using Text-Edit Mode Line Editing to Delete a Display Point

Step 3. List the present display points.

a. Type **LIST <Enter>** at the Display Points ? prompt.

b. After showing the active display points, the relay returns to Line 1 followed by the settings ? prompt.

Step 4. Type **<Enter>** once to proceed to the Line 2 present value and settings ? prompt.

Step 5. Type **DELETE <Enter>** to delete Display Point 2.

Step 6. Type **LIST <Enter>** to examine the remaining display points.

Former Display Point 2 is eliminated, and Display Point 3 moves up to Position 2.

The relay returns to Line 2 followed by the settings ? prompt.

Example 3.3 Deleting a Display Point (Continued)

Step 7. Type **END <Enter>** to end the settings process.

The relay next scrolls a readback of all the Front-Panel settings, eventually displaying the `Save settings (Y,N) ?` prompt. (In *Figure 3.21*, a vertical ellipsis represents this scrolling readback.)

At the end of the readback information, just before the `Save settings (Y,N) ?` prompt, you can verify the new display point information.

Step 8. Answer **Y <Enter>** to save your new settings.

Settings in SEL Grid Configurator

See *Getting Started on page 2.6* for steps on creating and deploying settings within SEL Grid Configurator.

Settings in QuickSet

See *Section 2: PC Software* for steps on creating and deploying settings within QuickSet.

Settings From the Front Panel

You can use the relay front panel to enter some of the relay settings. The relay presents the settings in order from class to instance (if applicable) to category to the particular setting, in a manner similar to setting the relay using a terminal.

Use the LCD and the adjacent navigation pushbuttons to enter each character of the setting in sequence. This can be a laborious process for some settings (e.g., long SELOGIC control equations). However, if you need to make a quick correction or have no faster means to make settings, settings functions are available at the front panel. For more information on making settings changes from the front panel, see *Set/Show on page 4.26*.

Entering DATE and TIME From the Front Panel

The purpose of the procedure in the following steps is to familiarize you with entering data from the relay front panel.

Step 1. Prepare to use the front panel by applying power to the relay.

Note that the relay front-panel display shows a sequence of LCD screens called the `ROTATING DISPLAY`. (If you do not operate the front panel for a certain period, the relay will enter front-panel time-out mode and you will see the sequential screens of the `ROTATING DISPLAY`.)

Step 2. Press the **ENT** pushbutton to display the `MAIN MENU` of *Figure 3.22*.

Step 3. View the settings screens.

a. Press the **Up Arrow** and **Down Arrow** navigation pushbuttons to highlight the `SET/SHOW` action item (see *Figure 3.22*).

b. Press the **ENT** pushbutton.

You will see the `SET/SHOW` submenu (the second screen in *Figure 3.22*).

Step 4. View the date/time screen.

a. Press the **Up Arrow** and **Down Arrow** navigation pushbuttons to highlight the `DATE/TIME` action item (*Figure 3.22*, second screen).

b. Press the **ENT** pushbutton.

The relay next displays the `DATE/TIME` submenu (the third screen of *Figure 3.22*).

Figure 3.22 DATE and TIME Settings From Front-Panel LCD

Step 5. Set the date.

a. Press the **ENT** pushbutton.

The relay shows the last screen of *Figure 3.22*, the DATE edit screen.

b. Use the **Up Arrow** and **Down Arrow** navigation pushbuttons to increase and decrease the date position numbers.

Step to the next or previous position by using the **Left Arrow** and **Right Arrow** pushbuttons.

c. When finished adjusting the new date, press **ENT**.

The relay returns the display to the `DATE/TIME` submenu. Note that the relay reports the `TIME SOURCE` as `FP DATE` (front-panel date).

Step 6. Press **ESC** repeatedly to normalize the front-panel display.

Changing a Relay Setting From the Front Panel

The purpose of the procedure in the following steps is to provide additional practice at entering relay settings from the front panel. In this example, you change the `PORT F` front-panel communications port settings.

Step 1. View the `MAIN MENU`.

a. If you have been using the front panel (as in the previous example), press the **ESC** key repeatedly until you see the `MAIN MENU`.

b. If the relay is displaying the `ROTATING DISPLAY`, press the **ENT** pushbutton to display the `MAIN MENU`.

Figure 3.23(a) shows the `MAIN MENU` at the beginning of the front-panel settings process.

Step 2. View the settings screens.

a. Press the **Up Arrow** and **Down Arrow** navigation pushbuttons to highlight the `SET/SHOW` action item, as shown in *Figure 3.23(a)*.

b. Press the **ENT** pushbutton. You will see the `SET/SHOW` submenu screen, as shown in *Figure 3.23(b)*.

Step 3. Select `PORT F`.

a. Highlight `PORT` and press the **ENT** pushbutton.

The relay displays the `PORT` instances screen, as shown in *Figure 3.23(c)*.

b. Choose the port you want to configure by using the **Up Arrow** and **Down Arrow** navigation pushbuttons to move the screen arrow.

For this example, select `PORT F` and press **ENT**.

Step 4. View the **Communications Settings** category screen.

a. The relay displays the `Port F` category screen, as shown in *Figure 3.23(d)*. Use the **Up Arrow** and **Down Arrow** navigation pushbuttons to select the settings category.

b. For this example, highlight **Communications Settings** and press **ENT**.

The relay displays the `Communications Settings` screen, as shown in *Figure 3.23(e)*.

Step 5. Change settings.

a. Highlight the SPEED setting.

b. Press **ENT**.

(The relay possibly requires a password here; see *Passwords on page 3.11* and *Section 4: Front-Panel Operations*.)

The LCD displays the SPEED selection submenu that has all the possible choices for serial data speeds.

The highlighted selection in *Figure 3.23(f)* indicates the default setting of 9600 (bps).

c. Use the **Up Arrow** and **Down Arrow** navigation pushbuttons to select a different speed.

d. Once you have selected a data speed, press the **ENT** pushbutton.

NOTE: Once you have changed communications parameters, you must change the corresponding parameters in your terminal emulation program to communicate with the relay via a communications port.

Step 6. End the settings session.

a. The relay returns to the previous category settings list screen. Press **ESC** to return to the categories screen where you see the Save Settings item at the bottom of the screen.

b. Use the **Up Arrow** and **Down Arrow** pushbuttons to highlight Save Settings and press **ENT**.

c. Highlight YES, and then press **ENT**.

The relay validates the setting and returns to the PORT screen, as shown in *Figure 3.23(c)*.

Step 7. Press **ESC** repeatedly to return to the MAIN MENU.

Figure 3.23 SET/SHOW Menus

Examining Metering Quantities

The SEL-400 series relays feature high-accuracy power system metering. You can view fundamental and rms quantities by using a communications terminal, QuickSet, or the front panel. For more information on relay metering, see *Section 7: Metering, Monitoring, and Reporting* in the product-specific instruction manual.

View Metering by Using the Terminal

The procedure in the following steps shows how to use a terminal or terminal emulation computer program to view power system metering. In this example, you connect specific voltages and currents for a 5 A, 60 Hz relay. Scale these quantities appropriately for your particular relay.

This example assumes that you have successfully established communication with the relay (see *Making an EIA-232 Serial Port Connection on page 3.4*). In addition, you must be familiar with relay access levels and passwords (see *Changing the Default Passwords in the Terminal on page 3.11* to change the default access level passwords). *Step 1* through *Step 7* are necessary if you have not yet configured the relay and want to test metering by using a test source. If the relay is already connected to the system, you may jump to *Step 8* to view the system metering information.

Step 1. Prepare to control the relay at Access Level 2.

a. Using a communications terminal, type **ACC <Enter>**.

b. Type the Access Level 1 password and press **<Enter>**.

You will see the Access Level 1 => prompt.

c. Type **2AC <Enter>**.

d. Type the correct password to go to Access Level 2.

You will see the Access Level 2 =>> prompt.

Step 2. Set the relay to a nominal operation mode.

a. Use a terminal to perform the initial Global settings relay setup in *Making Settings Changes in Initial Global Settings on page 3.21*.

b. Set the relay for 60 Hz operation, ABC phase rotation.

Step 3. Some SEL-400 series relays support voltage and current source selection. In these relays, configure the source selection appropriate for metering testing. The following shows how to do this in an SEL-451 (see *Figure 3.24*). Use the terminal to set Global setting ESS := 1.

a. Type **SET G ESS TERSE <Enter>**.

b. Type **1 <Enter>**.

c. Type **END <Enter>** to finish this settings session.

d. Answer **Y <Enter>** to the save settings prompt.

```
=>>SET G ESS TERSE <Enter>
Global

Current and Voltage Source Selection

Current and Voltage Source Selection (Y,N,1,2,3,4)      ESS   := N    ? 1 <Enter>
Line Current Source (IW,COMB)                           LINEI := IW   ? END <Enter>


Save settings (Y,N) ? Y <Enter>
Saving Settings, Please Wait...........
Settings Saved
=>>
```

Figure 3.24 Setting ESS in the Terminal

Step 4. Set CT and PT ratios. The specific CT and PT configuration settings depends on the relay. The following shows a typical set of configuration choices. Use the terminal to set Group 1 setting CTRW := 200 (the CT W-input ratio), and PTRY := 2000.0 (the PT Y-input ratio).

a. Type **SET CTRW TERSE <Enter>**.

b. If the CTRW setting is not 200, type **200 <Enter>**.

c. Proceed as shown in *Figure 3.25* to PTRY and change PTRY to 2000.0, if needed.

d. Type **END <Enter>** to finish this settings session.

e. Answer **Y <Enter>** to the save settings prompt.

```
=>>SET CTRW TERSE <Enter>
Group 1

Line Configuration

Current Transformer Ratio - Input W (1-50000)       CTRW   := 120    ?200 <Enter>
Current Transformer Ratio - Input X (1-50000)       CTRX   := 120    ? <Enter>
Potential Transformer Ratio - Input Y (1.0-10000)   PTRY   := 180.0  ?2000.0 <Enter>
PT Nominal Voltage (L-L) - Input Y (60-300 V,sec)   VNOMY  := 115    ?END <Enter>


Save settings (Y,N) ? Y <Enter>
Saving Settings, Please Wait...........
Settings Saved

=>>
```

Figure 3.25 Setting CTRW and PTRY in the Terminal

Step 5. Turn the relay off.

Step 6. Connect analog inputs. The specific connections depend on the relay. The following illustrates a typical set of voltage and current connections.

a. If three voltage sources and three current sources are available, connect the sources to the relay as shown in *Figure 3.26*.

If three voltage sources and two current sources are available, use the connection diagram of *Figure 3.27*.

b. Apply 67 V per phase (line-to-neutral) in ABC phase rotation.

c. Apply 2.0 A per phase, in phase with the applied phase voltages.

Figure 3.26 Test Connections Using Three Voltage Sources/Three Current Sources

Figure 3.27 Test Connections Using Two Current Sources for Three-Phase Faults and METER Test

Step 7. Turn the relay on.

Step 8. View metering.

a. Type **ACC <Enter>** to log in to the relay at Access Level 1.

b. Type the password and press **<Enter>**.

c. Type **MET <Enter>**.

The relay displays the fundamental frequency (50 Hz or 60 Hz) metering information in a manner similar to that shown in *Figure 3.28*.

```
=>>MET <Enter>

Relay 1                                    Date: 03/17/2023  Time: 01:35:05.221
Station A                                  Serial Number: 1230769999

                     Phase Currents
                  IA        IB        IC
I MAG (A)       398.882   399.041   398.784
I ANG (DEG)      -1.18   -120.97    119.21

                     Phase Voltages                Phase-Phase Voltages
                  VA        VB        VC           VAB       VBC       VCA
V MAG (kV)      133.994   133.986   133.953      231.903   231.815   232.450
V ANG (DEG)      -0.17   -120.02    120.18       29.91    -89.92    150.01

                   Sequence Currents (A)          Sequence Voltages (kV)
                 I1        3I2       3I0         V1        3V2       3V0
MAG             398.901     2.159     2.588     133.977     0.692     0.713
ANG (DEG)        -0.98    -62.68   -115.80       0.00    -53.25   -120.79

                  A          B          C            3P
P (MW)           53.44      53.46      53.41        160.31
Q (MVAR)          0.95       0.89       0.91          2.75
S (MVA)          53.45      53.47      53.42        160.33
POWER FACTOR      1.00       1.00       1.00          1.00
                   LAG        LAG        LAG           LAG

FREQ (Hz)       60.00       VDC1(V)   125.00   VDC2(V)    48.00

=>>
```

Figure 3.28 Terminal Screen MET Metering Quantities

The metering quantities of *View Metering by Using the Terminal on page 3.34* are the fundamental line quantities. Other variants of the **MET** command give different relay metering quantities. See *Section 8: Metering, Monitoring, and Reporting* of the product-specific instruction manual for more information on the specific metering options available in a specific relay.

View Metering by Using QuickSet

Use the procedures in the following steps to examine the relay metering with the QuickSet HMI.

This example assumes that you have successfully established communication with the relay (see *Making an EIA-232 Serial Port Connection on page 3.4*). In addition, you must be familiar with relay access levels and passwords (see *Changing the Default Passwords in the Terminal on page 3.11* to change the default access level passwords). You should also be familiar with QuickSet (see *Checking Relay Status in QuickSet on page 3.14* and *Section 2: PC Software*).

Step 1. Start QuickSet and establish a connection with the relay. See *Step 1* and *Step 2* of *Checking Relay Status in QuickSet on page 3.14* for details on how to do this.

Step 2. Set the relay to a nominal operation mode, and set it for 60-Hz operation, ABC phase rotation.

Step 3. Set a basic voltage and current configuration.

a. In the QuickSet **Settings** tree view, select the dropdown arrow next to **Global** to expand the **Global** branch (see *Figure 3.29*).

b. Select the **Current and Voltage Source Selection** branch.

You will see the **Current and Voltage Source Selection** dialog box as shown in *Figure 3.29*.

c. Choose **1** from the dropdown list under **ESS Current and Voltage Source Selection**.

Figure 3.29 Global Alternate Source Selection Settings in QuickSet

Step 4. Set PT and CT ratios.

a. In the QuickSet **Settings** tree view, select the dropdown arrow next to **Group 1** to expand this branch (see *Figure 3.30*).

b. Select the dropdown arrow next to **Set 1**.

c. Select **Line Configuration**.

You will see the **Line Configuration** window similar to *Figure 3.30*.

d. Enter setting **CTRW Current Transformer Ratio - Input W** as **200**, and the **PTRY Potential Transformer Ratio - Input Y** as **2000**.

e. Save the settings and send the **Group 1** settings if you change the settings (see *Step 6* and *Step 7*).

Figure 3.30 Group 1 Terminal Configuration Settings in QuickSet

Step 5. Start the QuickSet operator interface.

Step 6. In the top toolbar select **Tools** > **HMI** > **HMI** to start the GUI.

Step 7. Select the **Phasors** button of the HMI tree view (see *Figure 3.31*) to view phasors.

QuickSet displays fundamental line metering quantities with a display similar to *Figure 3.32*. (The test setup is adjusted for an approximately 30-degree lagging current.)

Figure 3.31 HMI Phasors View in QuickSet

Figure 3.32 Instantaneous Metering Quantities in QuickSet HMI

Step 8. Select the **Instantaneous** button of the HMI tree view to see metering information similar to *Figure 3.32*.

View Metering From the Front Panel

In most SEL-400 series relays, you can use the front-panel display and navigation pushbuttons to view the metering quantities of the relay (see *Meter on page 4.16* for more information on viewing metering on the relay front panel). The screens in this procedure are for an SEL-451 with one circuit breaker, and this example assumes that you have not enabled the demand metering or synchronism-check features.

Step 1. Prepare to use the front panel by applying power to the relay.

Note that the LCD shows a sequence of screens called the `ROTATING DISPLAY`. (If you do not operate the front panel for a certain period, the relay will enter front-panel time-out mode and you will see the sequential screens of the `ROTATING DISPLAY`.)

Step 2. Press the **ENT** pushbutton to display the `MAIN MENU` at the top of *Figure 3.33*.

Step 3. View the metering selection screen.

a. Highlight the `METER` action item (see the first screen of *Figure 3.33*).

b. Press the **ENT** pushbutton.

The relay displays the `METER` submenu (the second screen in *Figure 3.33*).

Step 4. View the metering screens.

a. Press the **Up Arrow** and **Down Arrow** navigation pushbuttons to highlight the `FUNDAMENTAL METER` action item, as shown in *Figure 3.33(b)*.

b. Press the **ENT** pushbutton.

The relay displays the first `FUNDAMENTAL METER` screen, shown in *Figure 3.33(c)*.

c. Use the **Up Arrow** and **Down Arrow** navigation pushbuttons to move among the fundamental line quantities metering screens.

Step 5. Press the **ESC** pushbutton repeatedly to return to the `MAIN MENU`.

Figure 3.33 Front-Panel Screens for METER

Examining Relay Elements

Use the communications port **TAR** command or the front panel to display the state of relay elements, control inputs, and control outputs. Viewing a change in relay element (Relay Word bit) status is a good way to verify the pickup settings you have entered for protection elements.

View Relay Elements in the Terminal

The procedure in the following steps shows you how to view a change in state for the SEL-451 50P1 Phase-Instantaneous Overcurrent element from a communications port.

Table 3.7 Phase-Instantaneous Overcurrent Pickup

Setting	Description	Default
50P1P	Level 1 Pickup (OFF, 0.25–100 A secondary)	15.00

For this procedure, you must have a serial terminal or computer with terminal emulation software and a variable current source for relay testing.

This example assumes that you have successfully established communication with the relay (see *Making an EIA-232 Serial Port Connection on page 3.4*). In addition, you must be familiar with relay access levels and passwords (see *Changing the Default Passwords in the Terminal on page 3.11* to change the default access level passwords and enter higher relay access levels).

Step 1. Type **ACC <Enter>** at a communications terminal.

Step 2. Type the Access Level 1 password and press **<Enter>**.

You will see the Access Level 1 => prompt.

Step 3. Connect a test source to the relay.

a. Set the current output of a test source to zero output level.

b. Connect a single-phase current output of the test source to the IAW analog input.

Step 4. Type **TAR 50P1 <Enter>** to view the initial element status.

The relay returns a target terminal screen similar to that shown in *Figure 3.34*.

```
=>TAR 50P1 <Enter>
50P1  50P2  50P3  50P4  67P1  67P2  67P3  67P4
0     0     0     0     0     0     0     0
=>
```

Figure 3.34 Sample Targets Display on a Serial Terminal

Step 5. View the element status change.

a. Type **TAR 50P1 1000 <Enter>** (this command causes the relay to repeat the **TAR 50P1** command 1000 times). For more information on the **TAR** command see *Section 14: ASCII Command Reference*.

b. Increase the current source to produce a current magnitude greater than 15.00 A secondary in the relay.

You will see the 50P1 element status change to 1 when the input current exceeds the 50P1P setting threshold.

c. Type **<Ctrl+X>** to stop the relay from presenting the target display before completion of the 1000 target repeats.

View Relay Elements From the Front-Panel LCD

You can use the front-panel display and navigation pushbuttons to check Relay Word bit elements. See *Section 4: Front-Panel Operations* for more information on using the relay front panel.

This procedure uses the SEL-451 50P1 Phase-Instantaneous Overcurrent element.

Step 1. Display the `MAIN MENU`.

Step 2. If the relay LCD is in the `ROTATING DISPLAY`, press the **ENT** pushbutton to display the `MAIN MENU` similar to that in *Figure 3.35*.

Step 3. Press the **Down Arrow** navigation pushbutton to highlight the `RELAY ELEMENTS` action item, as shown in *Figure 3.35(a)*.

Step 4. Press the **ENT** pushbutton.

You will see a `RELAY ELEMENTS` screen, as shown in *Figure 3.35(b)*.

Figure 3.35 Viewing Relay Word Bits From the Front-Panel LCD

Step 5. Display the 50P1 Relay Word bit on the front-panel LCD screen.

a. Press **ENT** to go to the `ELEMENT SEARCH` submenu of *Figure 3.35(c)*.

b. Use the navigation keys to highlight `5` and then press **ENT** to enter the character `5` in the text input field.

c. Enter the 0, P, and 1 characters in the same manner.

d. Highlight ACCEPT and press **ENT**.

The relay displays the LCD screen containing the 50P1 element, as shown *Figure 3.35(d)*.

Step 6. Connect a test source to the relay.

a. Set the current output of a test source to zero output level.

b. Connect a single-phase current output of the test source to the IAW analog input.

Step 7. View the target status change.

a. Increase the current source to produce a current magnitude greater than 15.00 A secondary in the relay.

b. Observe the 50P1 target on the front-panel display.

You will see the 50P1 element status change to 1 when the input current exceeds the 50P1P setting threshold.

Step 8. Press **ESC** to return to the MAIN MENU.

View Relay Elements by Using the Front-Panel LED

The procedure in the following steps shows you how to use a front-panel LED to view a change in state for the SEL-451 50P1 Phase-Instantaneous Overcurrent element.

In this example, use SEL Grid Configurator or QuickSet to configure the relay. See *Section 2: PC Software* for information on creating and deploying settings. In addition, you need a variable current source suitable for relay testing.

Step 1. Read the relay settings.

Step 2. Set a pushbutton LED SELOGIC control equation.

a. Expand the **Front Panel** branch of the **Settings** tree view and select **Pushbuttons**.

b. Select in the **PB6_LED** text box and type **50P1**.

c. Tab or select to any other text box.

The software checks the validity of the setting.

Step 3. Send the new settings to the SEL-451.

Step 4. Connect a test source to the relay.

a. Set the current output of a test source to zero output level.

b. Connect a single-phase current output of the test source to the IAW analog input.

Step 5. View the target status change.

a. Increase the current source to produce a current magnitude greater than 15.00 A secondary in the relay.

b. Observe the LED next to Pushbutton 6 on the SEL-451 front panel.

You will see the LED illuminate when the input current exceeds the 50P1P setting threshold.

Reading Oscillograms, Event Reports, and SER

SEL-400 series relays have great capabilities for storing and reporting power system events. These include high-resolution oscillography with sampling as high as 8 kHz, event reports that encompass important variables in the power system, and the SER that reports changing power system conditions and relay operating states.

You can view oscillograms taken from high-resolution raw data or from filtered event report data. Each type of presentation gives you a unique view of the power system. High-resolution oscillograms are useful for viewing system transients and dc artifacts outside the relay filter system; event report oscillograms give you a picture of the quantities that the relay used in the protection algorithms.

The examples listed in this section give step-by-step procedures to acquaint you with these features. *Section 9: Reporting* provides a complete discussion of these relay features.

Generating an Event

To view high-resolution raw data oscillograms and event reports, you must generate a relay event. High-resolution oscillography and event reports use the same event triggering methods. The relay uses multiple sources to initiate a data capture, including any of the following: Relay Word bit TRIP asserts, SELOGIC control equation ER (event report trigger), or the **TRI** command. (Factory-default setup does not include the **PUL** command as an event report trigger. You can add the **PUL** command by entering the Relay Word bit TESTPUL in the ER SELOGIC control equation.)

You can use an event trigger to initiate capturing power system data. The procedure in the following steps shows how to use the **TRI** command (see *TRIGGER on page 14.73*), which triggers an event capture. In this example, the relay uses default parameters to record the event. These parameters are at a sampling rate (SRATE) of 2000 samples per second (2 kHz), a pre-trigger or pre-fault recording length (PRE) of 0.1 seconds, and an event report length (LER) of 0.5 seconds. See *Duration of Data Captures and Event Reports on page 9.9* for complete information on changing these default settings to match your application.

This example assumes that you have successfully established communication with the relay (see *Making an EIA-232 Serial Port Connection on page 3.4*). In addition, you must be familiar with relay access levels and passwords (see *Changing the Default Passwords in the Terminal on page 3.11* to change the default access level passwords).

Step 1. Connect voltage and current sources to the relay secondary voltage and secondary current inputs (use the connections of *View Metering by Using the Terminal on page 3.34* and *Figure 3.26* or *Figure 3.27*).

Step 2. Apply power to the relay, and establish a terminal connection with the relay.

Step 3. Trigger an Event by typing **TRIG <Enter>**.

Reading the Event History

The relay has multiple convenient methods for checking whether you successfully captured power system data. The following describes how to view the event history data through use of the ASCII terminal interface.

Reading the Event History in the Terminal

The procedure in the following steps shows how to use the relay **HIS** command to confirm that you captured power system data with an event trigger. This example assumes that you have successfully established communication with the relay (see *Making an EIA-232 Serial Port Connection on page 3.4*). In addition, you must be familiar with relay access levels and passwords (see *Changing the Default Passwords in the Terminal on page 3.11* to change the default access level passwords).

Step 1. Prepare to monitor the relay at Access Level 1.

a. Using a communications terminal, type **ACC <Enter>**.

b. Type the Access Level 1 password and press **<Enter>**.

You will see the Access Level 1 => prompt.

Step 2. Type **HIS <Enter>** to examine the event history

You will see a screen display similar to *Figure 3.36*.

```
=>HIS <Enter>

Relay 1                                    Date: 04/20/2015  Time: 17:27:44.140
Station A                                  Serial Number: 1150019999

#        DATE        TIME     EVENT  LOCAT   CURR GRP TARGETS
10024 03/03/2015 08:33:29.201 TRIP  $$$$.$$     0  1
10023 03/02/2015 15:41:35.777 ER    $$$$.$$     0  1
10022 03/02/2015 15:41:35.227 ER    $$$$.$$     0  1
10021 03/02/2015 15:41:34.577 ER    $$$$.$$     0  1
10020 03/02/2015 15:41:34.152 ER    $$$$.$$     0  1
10019 03/02/2015 15:41:32.702 ER    $$$$.$$     0  1
10018 02/24/2015 15:22:19.496 TRIG  $$$$.$$     1  3

10017 02/24/2015 15:22:17.705 TRIG  $$$$.$$     1  3
10016 02/23/2015 17:42:56.581 TRIG  $$$$.$$     1  3
10015 02/20/2015 19:23:41.369 BCG      0.02  3442  3
10014 02/20/2015 17:14:40.056 CA T     7.28  2449  3  TIME A_FAULT C_FAULT

=>
```

Figure 3.36 Sample HIS Command Output in the Terminal

For more information on the event history, see *Event History on page 9.27*.

Viewing High-Resolution Oscillograms

Once you have successfully generated an event, you can view high-resolution oscillograms and event report oscillograms about this event. When gathered from a field-installed relay, this information helps you assess power system operating conditions. In addition, when you first install the relay, this reporting information helps you confirm that you have connected the relay correctly.

The relay provides high-resolution oscillography data in the binary COMTRADE file format (IEEE/ANSI standard C37.111-1999 and C37.111-2013 formats are supported). File transfer is the only mechanism for retrieving high-resolution COMTRADE data from the relay.

The SEL-5601-2 SYNCHROWAVE Event is a program you can use to view COMTRADE data. Many third-party software suppliers can provide you with programs to display and manipulate COMTRADE files.

Retrieving High-Resolution COMTRADE Data in the Terminal

The relay recorded the event triggered in *Generating an Event on page 3.46*. The procedure in the following steps shows you how to retrieve the high-resolution raw oscillography data for this event.

Perform the steps listed in *Generating an Event on page 3.46* before executing the instructions in this example. For this procedure, you must use a communications terminal emulation computer program capable of file transfers.

If you need help finding a terminal emulation program, contact the SEL factory or your local Technical Service Center.

Step 1. Prepare to monitor the relay at Access Level 1.

a. Using a communications terminal, type **ACC <Enter>**.

b. Type the Access Level 1 password and press **<Enter>**.

You will see the Access Level 1 => prompt.

Step 2. Type **FILE DIR EVENTS <Enter>** to view the contents of the events file directory.

The relay lists file names for recently recorded events in a manner similar to that shown in *Figure 3.37*.

The relay shows three high-resolution oscillography files with the file name extensions .HDR, .CFG, and .DAT for each event.

This example uses the IEEE C37.111-1999 COMTRADE file HR_10000 as the number of the event that you recently triggered; use the event number corresponding to your triggered event.

```
==>>file dir events
171101,155138316,OT,SID,RID,CONAM,HR,10000.CFG          R   11/01/2017 08:51:38
171101,155138316,OT,SID,RID,CONAM,HR,10000.DAT          R   11/01/2017 08:51:38
171101,155138316,OT,SID,RID,CONAM,HR,10000.HDR          R   11/01/2017 08:51:38
C4_10000.TXT                                            R   11/01/2017 08:51:38
C8_10000.TXT                                            R   11/01/2017 08:51:38
CHISTORY.TXT                                            R
E4_10000.TXT                                            R   11/01/2017 08:51:38
E8_10000.TXT                                            R   11/01/2017 08:51:38
HISTORY.TXT                                             R
HR_10000.CFG                                            R   11/01/2017 08:51:38
HR_10000.DAT                                            R   11/01/2017 08:51:38
HR_10000 .HDR                                           R   11/01/2017 08:51:38
```

Figure 3.37 EVENTS Folder Files

Step 3. Type **FILE READ EVENTS HR_10000.* <Enter>** to ready the relay to transfer the HR_10000.HDR, HR_10000.CFG, and HR_10000.DAT files to your computer.

Step 4. Download the files. Perform the steps necessary for your terminal emulation program to receive a file.

Typically, these are the file transfer steps:

- Specify the destination file location in your computer file storage system and file name.
- Select the transfer type as **YModem** (if this transfer type is not already enabled).
- Select **Receive**.

You will usually see a confirmation message when the file transfer is complete.

When these files have transferred successfully, you have the entire COMTRADE file for the high-resolution raw data capture.

Step 5. Use SYNCHROWAVE Event, QuickSet, or other COMTRADE-capable programs to play back high-resolution raw data oscillograms of the high-resolution raw data capture files you just transferred.

Figure 3.38 Sample Event Oscillogram

You can also examine a phasors display, an event harmonic analysis display, and the event summary from the **Event Waveform View** menu. See *Section 9: Reporting* for more information.

Viewing Event Report Data

Examine relay event reports to inspect the operating quantities the relay used at each triggered event. Unlike the raw data samples/second high-resolution oscillography files, these reports contain the filtered samples/cycle data the relay uses to make protection decisions. Event reports are useful for determining why the relay operated for a particular set of power system conditions. For more information on event reports, see *Event Report on page 9.14*.

The relay recorded the event triggered in *Generating an Event on page 3.46*. The procedure in the following steps shows you how to retrieve the event report data files for this event. Perform the steps listed in *Generating an Event on page 3.46* before executing the instructions in this example. For this procedure, you must use a terminal program capable of Ymodem protocol file transfer.

Step 1. Prepare to monitor the relay at Access Level 1.

a. Using a communications terminal, type **ACC <Enter>**.

b. Type the Access Level 1 password and press **<Enter>**.

You will see the Access Level 1 => prompt.

Step 2. Type **FILE DIR EVENTS <Enter>** to view the events file directory.

The relay lists file names for recently recorded events in a manner similar to that shown in *Figure 3.37*.

In the figure, the relay shows two event report files: E4_10000.TXT and E8_10000.TXT, and two Compressed ASCII event report files: C4_10000.TXT and C8_10000.TXT.

Step 3. Type **FILE READ EVENTS C8_10000.TXT <Enter>** to transfer the Compressed ASCII event report file to your computer.

Step 4. Download the file. Perform the steps necessary for your terminal emulation program to receive a file.

Typically, these are the file transfer steps:

- Specify the destination file location in your computer file storage system and file name.
- Select the transfer type as **YModem** (if not already enabled).
- Select **Receive**.

You will usually see a confirmation message when the file transfer is complete.

Step 5. When this file has transferred successfully, use SYNCHROWAVE Event to play back the event report oscillograms of the 8-samples/cycle event report file you just transferred.

Viewing SER Records

The relay SER records relay operating changes and relay element states. In response to an element change of state, the SER logs the element, the element state, and a time stamp. Program the relay elements that the relay stores in the SER records, thus capturing significant system events such as an input/output change of state, element pickup/dropout, recloser state changes, etc.

The relay stores the latest 1000 entries to a nonvolatile record. Use the relay communications ports or QuickSet to view the SER records. For more information on the SER, see *Section 9: Reporting*.

The latest 200 SER events are viewable from the front panel. For more information, see *Section 4: Front-Panel Operations*.

Figure 3.39 Selecting SER Points and Aliases Settings in QuickSet

Figure 3.40 SER Points and Aliases Settings in QuickSet

NOTE: SITMn (where n = 1–250) are the setting names associated with your SER points.

Step 6. Enter SER settings.

a. For this example, open the entry form by selecting the ... button beside the **SITM1 SER Points and Aliases**, **Point 1** entry field. We will change this SER point to report the operation of the TARGET RESET pushbutton.

b. Select the ... button beside the **Relay Word Bit** entry field.

c. Select **Target Logic Bits**, and then double-click **TRGTR** to copy the TRGTR name into the **Relay Word Bit** field. This also copies TRGTR to the Reporting Name (or alias) field.

d. Type **Target Reset PB** in the **Alias Name** field.

e. Type **TEST** in the **Set Alias** field.

f. Type **OFF** in the **Clear Alias** field.

g. Select **OK**.

Step 7. Select **File > Save** to save the new settings in QuickSet.

Step 8. Upload the new settings to the relay.

a. Select **File > Send**.

QuickSet prompts you for the settings class you want to send to the relay, as shown in the first dialog box of *Figure 3.41*.

b. Select the **Report** check box.

c. Select **OK**.

QuickSet responds with the second dialog box of *Figure 3.41*.

If you see no error message, the new settings are loaded in the relay.

Figure 3.41 Uploading Report Settings to the Relay

Step 9. Press and release the front-panel TARGET RESET pushbutton to generate an SER record.

Step 10. View the SER report.

a. Start the QuickSet operator interface.

b. In the top toolbar **Tools** menu, select **HMI > HMI**.

c. Select the **SER** button of the HMI tree view (see *Figure 3.42*).

QuickSet displays the SER records with a display similar to *Figure 3.43*.

Figure 3.42 Retrieving SER Records With QuickSet

Figure 3.43 SER Records in the QuickSet HMI

The relay lists the SER records in chronological order from top to bottom as shown in *Figure 3.43*. In addition, the relay numbers each record with the most recent record as number 1; new events are usually more important for determining the effects of recently occurring power system events.

For each application of power to the relay, the SER reports a "Power-up" indication and the active settings group. A properly operating relay immediately goes to the enabled state, an event that causes the SER to report another SER record. The SER reports the **TARGET RESET** button when you press the pushbutton and it remains asserted for one processing interval.

Setting the SER and Examining the SER Record in the Terminal

The procedure in the following steps shows how to use a terminal connected to a relay communications port to set an element in the SER. Use text-edit mode line editing to enter the SER settings (see *Text-Edit Mode Line Editing on page 3.23*). Also included is a procedure for viewing the SER report with a terminal.

This example assumes that you have successfully established communication with the relay (see *Making an EIA-232 Serial Port Connection on page 3.4*). In addition, you must be familiar with relay access levels and passwords (see *Changing the Default Passwords in the Terminal on page 3.11* to change the default access level passwords).

Step 1. Prepare to control the relay at Access Level 2.

a. Using a communications terminal, type **ACC <Enter>**.

b. Type the Access Level 1 password and press **<Enter>**.

You will see the Access Level 1 => prompt.

c. Type **2AC <Enter>**.

d. Type the correct password to go to Access Level 2.

You will see the Access Level 2 =>> prompt.

Step 2. Enter SER trigger data.

a. Type **SET R TERSE <Enter>** to access the **Report** settings (see *Figure 3.44*).

b. Press **<Enter>** to move past the **SER Chatter Criteria** setting.

c. At the `SER Points ?` prompt line, type the following:

TRGTR,"TARGET RESET PB",TEST,OFF,N <Enter>.

At the next line, type **END <Enter>**.

d. The relay prompts you to save the new setting; type **Y <Enter>**.

```
=>>SET R TERSE <Enter>
Report
SER Chatter Criteria
Automatic Removal of Chattering SER Points (Y,N)   ESERDEL := N   ? <Enter>


SER Points
(Relay Word Bit, Reporting Name, Set State Name, Clear State Name, HMI Alarm)
1:
? TRGTR,"TARGET RESET PB",TEST,OFF,N <Enter>
2:
? END <Enter>

Save settings (Y,N) ? Y <Enter>
Saving Settings, Please Wait..........
Settings Saved
=>>
```

Figure 3.44 Setting an SER Element: Terminal

Step 3. Press and release the front-panel TARGET RESET pushbutton to generate an SER record.

Step 4. Type **SER <Enter>** (at the Access Level 1 prompt or higher) to view the SER report.

The relay presents a screen similar to the SER display of *Figure 3.43*.

Downloading an SER Report File

The procedure in the following steps shows you how to retrieve the SER report stored in the relay as a file. For this procedure, you must use a terminal emulation program with file transfer capability.

Step 1. Prepare to monitor the relay at Access Level 1.

a. Using a communications terminal, type **ACC <Enter>**.

b. Type the Access Level 1 password and press **<Enter>**.

You will see the Access Level 1 => prompt.

Step 2. Type **FILE DIR REPORTS <Enter>** to view the events file directory.

The terminal lists the file names for standard reports as shown in *Figure 3.45*.

Step 3. Prepare the relay to download the SER report.

a. Type **FILE READ REPORTS SER.TXT <Enter>**.

b. If you want the Compressed ASCII file, type the following:

FILE READ REPORTS CSER.TXT <Enter>

```
=>FILE DIR REPORTS <Enter>
BRE_1.TXT                        R
BRE_2.TXT                        R
BRE_S1.TXT                       R
BRE_S2.TXT                       R
CBRE.TXT                         R
CHISTORY.TXT                     R
CPRO.TXT                         R
CSER.TXT                         R
HISTORY.TXT                      R
PRO.TXT                          R
SER.TXT                          R
=>
```

Figure 3.45 Example Reports File Structure

Step 4. Download the SER report. Perform the steps necessary for your terminal emulation program to receive a file.

Typically, these are the file transfer steps:

- ➢ Specify the destination file location in your computer file storage system and file name.
- ➢ Select the transfer type as **YModem** (if not already enabled).
- ➢ Select **Receive**.

You will usually see a confirmation message when the file transfer is complete.

Step 5. When the SER.txt file has transferred successfully, use a word-processing program to view the contents of the file.

You will see the SER records in a format similar to *Figure 3.43*.

NOTE: Transferring SER files (or CSER files) with the **FILE READ REPORTS SER.TXT** command, performs an **SER CV** command as part of the transfer. SER CV clears the SER information from the present port. With the SER information cleared, there are no data available for subsequent SER or CSER transfers from the same port.

Operating the Relay Inputs and Outputs

The SEL-400 series relays give you great ability to perform control actions at bay and substation locations via the relay control outputs. The control outputs close and open circuit breakers, switch disconnects, and operate auxiliary station equipment such as fans and lights. The relay reads data from the power system and interfaces with external signals (contact closures and data) through the control inputs. This section is an introduction to operating the control outputs and control inputs. For more information on connecting and applying the control outputs and control inputs, see *Section 2: Installation* in the product-specific instruction manual.

Control Output

The relay features standard, hybrid (high-current interrupting), and high-speed high-current interrupting control outputs that you can use to control circuit breakers and other devices in an equipment bay or substation control house.

Pulsing a Control Output in the Terminal

When first connecting the relay, or at any time that you want to test relay control outputs, perform the following procedure. The procedure in the following steps shows how to use a communications terminal to pulse the control output contacts. Perform the steps in this example to become familiar with relay control and serial communication. For more information on the **PULSE** command, see *PULSE on page 14.55*.

This example assumes that you have successfully established communication with the relay; see *Making an EIA-232 Serial Port Connection on page 3.4* for a step-by-step procedure. In addition, you must be familiar with relay access levels and passwords (see *Changing the Default Passwords in the Terminal on page 3.11* to change the default access level passwords).

NOTE: To pulse an output, the circuit breaker control enable jumper must be installed on the main board.

Step 1. Prepare to control the relay at Access Level B.

a. Using a communications terminal, type **ACC <Enter>**.

b. Type the Access Level 1 password and press **<Enter>**.

You will see the Access Level 1 => prompt.

c. Type **BAC <Enter>**.

d. Type the correct password to go to Access Level B.

You will see the Access Level B ==> prompt.

Step 2. Attach an indicating device (ohmmeter with a beep sounder or a test set) to the terminals for control output OUT104.

This output is a standard control output and is not polarity-sensitive.

Step 3. Perform the pulse operation.

a. Type **PULSE OUT104 <Enter>**.

The relay confirms your request to pulse an output with a prompt such as that shown in *Figure 3.46*.

b. Type **Y <Enter>** at the prompt.

You will see or hear the indicating device turn on for a second and then turn off.

```
==>PULSE OUT104 <Enter>
Pulse contact OUT104 for 1 seconds(Y/N)       ? Y <Enter>
==>
```

Figure 3.46 Terminal Display for PULSE Command

You can also pulse an output for longer than the default one-second period. If you enter a number after the **PULSE** command, that number specifies the duration in seconds for the pulse. For example, if you enter **PULSE OUT104 3 <Enter>**, the relay pulses OUT104 for three seconds.

Pulsing a Control Output on the Front Panel

The procedure in the following steps shows you how to use the front-panel display and navigation pushbuttons to check for proper operation of the relay control outputs. See *Section 4: Front-Panel Operations* for information on using the relay front panel.

Step 1. Attach an indicating device (an ohmmeter with a beep sounder or a test set) to the terminals for control output OUT104.

This output is a standard control output and is not polarity-sensitive.

Step 2. View the front-panel display.

After applying power to the relay, note that the LCD shows a sequence of screens called the `ROTATING DISPLAY`.

(Also, if you do not operate the front panel for a certain period, the relay will enter front-panel time-out mode and you will see the sequential screens of the `ROTATING DISPLAY`.)

Step 3. Press the **ENT** pushbutton to view the `MAIN MENU`, similar to that in *Figure 3.47(a)*.

Figure 3.47 Front-Panel Menus for Pulsing OUT104

Step 4. View the `LOCAL CONTROL` screen.

a. Press the **Up Arrow** and **Down Arrow** navigation pushbuttons to highlight the `LOCAL CONTROL` action item, as shown in *Figure 3.47(a)*.

b. Press the **ENT** pushbutton.

You will see the `LOCAL CONTROL` submenu as shown in *Figure 3.47(b)*.

Step 5. View the `OUTPUT TESTING` screen.

a. Press the **Up Arrow** and **Down Arrow** navigation pushbuttons to highlight the `--OUTPUT TESTING--` action item, as shown in *Figure 3.47(b)*.

b. Press the **ENT** pushbutton.

The relay displays the `OUTPUT TESTING` submenu, as shown in *Figure 3.47(c)*.

Step 6. Command the relay to pulse the control output.

a. Press the **Up Arrow** and **Down Arrow** navigation pushbuttons to highlight `OUT104` as shown in *Figure 3.47(c)*.

b. Press the **Right Arrow** navigation pushbutton to highlight `YES` under `PULSE OUTPUT?`

c. Press the **ENT** pushbutton.

The relay detects your request for a function at an access level for which you do not yet have authorization. Whenever this condition occurs, the relay displays the password access screen as shown in *Figure 3.48*.

```
PASSWORD REQUIRED
_____________
A B C D E F G H
I J K L M N O P
Q R S T U V W X
Y Z a b c d e f
g h i j k l m n
o p q r s t u v
w x y z 0 1 2 3
4 5 6 7 8 9 _ .
ACCEPT  BACKSPACE
```

Figure 3.48 Password Entry Screen

Step 7. Input a password and pulse the output.

a. Enter a valid Access Level B, P, A, O, or 2 password.

(The front panel is always at Access Level 1, so you do not enter the Access Level 1 password.)

Enter a valid password by using the navigation pushbuttons to select, in sequence, the alphanumeric characters that correspond to your password.

b. Press the **ENT** pushbutton at each password character.

(If you make a mistake, highlight the `BACKSPACE` option and press **ENT** to reenter a character or characters.)

c. After entering all password characters, press the **Up Arrow** or **Down Arrow** pushbuttons to highlight `ACCEPT`, and press **ENT**.

The relay pulses the output, and you will see the indicating device turn on for a second and then turn off.

Controlling a Relay Control Output With a Local Bit in the Terminal

In this example, you set Local Bit 3 to start the transformer cooling fans near the breaker bay where you have installed the SEL-451. Thus, you can use the LCD screen and navigation pushbuttons to toggle relay Local Bit 3 to control the state of the cooling fans. Relay Word bit LB_SP03 provides supervision for Local Bit 3. Relay Word bit LB_SP03 must be asserted for successful Local Bit 3 operations. For more information on local bits, see *Local Control Bits on page 4.22*.

The procedure in the following steps proposes connecting the transformer bank fan control to relay output **OUT105**. You can choose any relay output that conforms to your requirements.

This example assumes that you have successfully established communication with the relay (see *Making an EIA-232 Serial Port Connection on page 3.4*). In addition, you must be familiar with relay access levels and passwords (see *Changing the Default Passwords in the Terminal on page 3.11* to change the default access level passwords).

Step 1. Prepare to control the relay at Access Level 2.

a. Using a communications terminal, type **ACC <Enter>**.

b. Type the Access Level 1 password and press **<Enter>**.

You will see the Access Level 1 => prompt.

c. Type **2AC <Enter>**.

d. Type the correct password to go to Access Level 2.

You will see the Access Level 2 =>> prompt.

Step 2. Access the local control settings.

a. Type **SET F <Enter>**.

b. Repeatedly type **>** and then **<Enter>** to advance through the front-panel settings until you reach the **Local Control** category.

Figure 3.49 shows a representative terminal screen.

```
Local Control
(Local Bit, Local Label, Local Set State, Local Clear State, Pulse Enable)

1:
? LIST <Enter>
1:
? LB03,"5 MVA XFMR Fans",ON,OFF,N <Enter>
2:
? END <Enter>
           .
           .
           .
Local Control
(Local Bit, Local Label, Local Set State, Local Clear State, Pulse Enable)

1: LB03,"5 MVA XMFR Fans","ON","OFF",N
Save settings (Y,N) ? Y <Enter>
Saving Settings, Please Wait...........
Settings Saved
 =>>
```

Figure 3.49 Using Text-Edit Mode Line Editing to Set Local Bit 3

Step 3. Type **LIST <Enter>** at the `Local Control ?` prompt to list the active control points.

This example assumes that you are using no local bits, so the relay returns you to Line 1 followed by the settings `?` prompt.

Step 4. Type **LB03,"5 MVA XFMR Fans",ON,OFF,N <Enter>** at the Line `?` prompt.

The relay checks that this is a valid entry and responds with the next line prompt `2:` followed by the settings `?` prompt.

Step 5. End the settings session.

a. Type **END <Enter>**.

The relay displays a readback of all the front-panel settings, eventually displaying the `Save settings (Y,N) ?` prompt. (In *Figure 3.49* a vertical ellipsis represents the readback.)

At the end of the readback information, just before the `Save settings (Y,N) ?` prompt, you can see the new local bit information.

b. Type **Y <Enter>** to save your new settings.

Step 6. Set OUT105 to respond to Local Bit 3.

a. Type **SET O OUT105 <Enter>** (see *Figure 3.50*).

b. At the `?` prompt, type **LB03 <Enter>**.

c. At the next `?` prompt, type **END <Enter>**.

d. When prompted to save settings, type **Y <Enter>**.

```
=>>SET O OUT105 <Enter>
Output
Main Board
OUT105 :== NA
? LBO3 <Enter>
OUT106 := NA
? END <Enter>
Output

Main Board
OUT101 := T3P1 #BREAKER 1 TRIP
OUT102 := T3P1 #EXTRA BREAKER 1 TRIP
OUT103 := BK1CL #BREAKER 1 CLOSE
OUT104 := NA
OUT105 := LBO3
OUT106 := NA
OUT107 := NA
OUT108 := NOT (HALARM OR SALARM)

Save settings (Y,N) ? Y <Enter>
Saving Settings, Please Wait...........
Settings Saved
=>>
```

Figure 3.50 Setting Control Output OUT105 in the Terminal

Step 7. Test the connection and programming.

a. Use the appropriate interface hardware to connect the fan control start circuit to OUT105.

b. At the relay front-panel `MAIN MENU`, select `LOCAL CONTROL` and press the **ENT** pushbutton as shown in *Figure 3.51(a)*.

c. Select `5 MVA XFMR Fans` on the `LOCAL CONTROL` screen as shown in *Figure 3.51(b)*.

d. Press **ENT** to see the `5 MVA XFMR Fans` as shown in *Figure 3.51(c)*.

e. Highlight `1 ON` and press **ENT**.

The graphical local control handle moves to the 1 position. At this time, the transformer fans will begin running.

Figure 3.51 Front-Panel LOCAL CONTROL Screens

Setting Outputs for Tripping and Closing

To actuate power system circuit breakers, you must configure the control outputs to operate the trip bus and close bus. The relay uses internal logic and SELOGIC control equations to activate the control outputs.

Trip Output Signals

All SEL-400 series relays are capable of three-pole tripping and some are capable of single-pole tripping. There are many Relay Word bits (e.g., T3P1, T3P2, and 3PT) that you can program to drive control outputs to trip circuit breakers. See *Section 5: Protection* in the product-specific instruction manual for complete information on tripping equations and settings. For target illumination at tripping, see *Section 4: Front-Panel Operations*.

Close Output Signals

Some SEL-400 series relays feature an automatic recloser for single-circuit breaker and two-circuit breaker applications, with as many as four autoreclose shots. See *Section 6: Autoreclosing* for more information.

Assigning Control Outputs for Tripping and Closing

The procedure in the following steps shows a method for setting the relay to operate the trip bus and the close bus at a typical substation. This procedure assigns a close output at OUT106. This example is specific to the SEL-451 relay, but similar configuration changes can be made in all SEL-400 series relays.

This example assumes that are familiar with SEL Grid Configurator or QuickSet (see *Section 2: PC Software*).

Step 1. Read the relay settings.

Step 2. Access the **Main Board** output settings.

a. Expand the **Outputs** branch of the Settings tree view.

b. Select **Main Board**.

Step 3. Assign a control output for the close bus.

a. In the **Main Board Outputs** dialog box, select the **OUT106** text box and type the following:

BK1CL #ADDITIONAL BREAKER 1 CLOSE

(The # indicates that a comment follows.)

b. Select or tab to another text box.

The software checks that your entry is valid.

Step 4. Upload the new settings to the relay.

Control Input Assignment

Most SEL-400 series relays have control inputs on the main board (IN101–IN107), and on one or more optional I/O interface boards (IN201–IN2xx, IN301–IN3xx, etc.), if so equipped.

There are two types of input circuitry: direct-coupled and optoisolated. *Table 3.8* lists the main differences between the two types of control inputs. Only the SEL-421 and SEL-451 are available with interface boards that support direct-coupled inputs. All SEL-400 series relays support optoisolated inputs.

Table 3.8 Control Input Characteristics

	Direct-Coupled	Optoisolated
Pickup characteristics:	Pickup voltage can be selected via Global settings. Can have different pickup voltages on each input.	Pickup voltage is determined by hardware: one of six voltage levels determined at time of factory order. All pickup voltages are the same on each I/O interface board.
Polarity-sensitive:	Yes (will not respond to reverse polarity signals). A + polarity mark is printed over the positive terminals.	No (will respond to signals of either polarity). No polarity mark. AC signal detection is possible.[a]
Where found:	INT1, INT5, and INT6 I/O Interface Boards (available in SEL-421 and SEL-451 relays).	SEL-400 Series Main Board (IN101–IN107). All other interface boards.

[a] With appropriate debounce settings (see Section 2: Installation of the product-specific instruction manual).

The default value for Global setting EICIS (Enable Independent Control Input Settings) is N, which hides all individual control input settings and only presents some overall settings that will apply to all control inputs. Set EICIS := Y to gain full access to the individual control input settings.

Setting a Control Input for Circuit Breaker Auxiliary Contacts (52A) in the Terminal

This is a step-by-step procedure to configure a control input that reflects the state of the circuit breaker auxiliary (52A) NO (normally open) contact. A common relay input is from circuit breaker auxiliary contacts; the relay monitors the 52A contacts to detect the closed/open status of the circuit breaker. Perform the following steps to connect three-pole circuit breaker auxiliary contacts to the relay. This example was created using an SEL-451. Refer to the product-specific instruction manual for the correct Relay Word bit names for each product.

This example assumes that you have successfully established communication with the relay (see *Making an EIA-232 Serial Port Connection on page 3.4*). In addition, you must be familiar with relay access levels and passwords (see *Changing the Default Passwords in the Terminal on page 3.11* to change the default access level passwords).

Step 1. Prepare to control the relay at Access Level 2.

a. Using a communications terminal, type **ACC <Enter>**.

b. Type the Access Level 1 password and press **<Enter>**.

You will see the => prompt.

c. Type **2AC <Enter>**.

d. Type the correct password to go to Access Level 2.

You will see the Access Level 2 =>> prompt.

Step 2. Configure the relay to read the circuit breaker auxiliary contact.

a. Type **SET M <Enter>** (see *Figure 3.52*).

These settings are the breaker monitor settings.

b. Type **<Enter>** to bypass the Breaker 1 Monitoring enable, and **<Enter>** again to bypass the Breaker 2 Monitoring enable (NUMBK := 2 in this example).

The relay displays the 52AA1 SELOGIC control equation action prompt.

c. Type **IN101 <Enter>** at the ? prompt to specify input IN101 as the control input that represents the close/open state of Circuit Breaker 1.

Press **<Enter>** until the relay displays the 52AA2 SELOGIC control equation action prompt.

d. Type **IN102 <Enter>** at the ? prompt to specify input IN102 as the control input that represents the close/open state of Circuit Breaker 2.

Step 3. End the settings process. The relay next scrolls a readback of all the Global settings, eventually displaying the `Save settings (Y,N) ?` prompt.

a. In the readback information, just before the `Save settings (Y,N) ?` prompt, confirm the new control input information.

b. Answer **Y <Enter>** to save your new settings.

```
=>>SET M <Enter>
Breaker Monitor
Breaker Configuration
Breaker 1 Monitoring (Y,N) EB1MON  := N ? <Enter>
Breaker 2 Monitoring (Y,N) EB2MON  := N ? <Enter>
Breaker 1 Inputs

N/O Contact Input -BK1 (SELogic Equation)
52AA1 := NA
?  IN101 <Enter>
Breaker 2 Inputs
N/O Contact Input -BK2 (SELogic Equation)
52AA2 := NA
?  IN102 <Enter>
Breaker Monitor

Breaker Configuration
EB1MON  := N        EB2MON  := N
Breaker 1 Inputs
52AA1   := IN101
Breaker 2 Inputs
52AA2   := IN102
Save settings (Y,N)  ? Y <Enter>
Saving Settings, Please Wait...........
Settings Saved
=>>
```

Figure 3.52 Setting 52AA1 in the Terminal

Setting a Control Input for Circuit Breaker Auxiliary Contacts (52A) Via Software

The procedure in the following steps shows how to program the relay control input IN101 to read the state of circuit breaker auxiliary contacts. This example uses a single three-pole tripping breaker. Modify the procedure listed here for your application.

This example assumes that you are familiar with SEL Grid Configurator or QuickSet (see *Section 2: PC Software*).

Step 1. Read the relay settings.

Step 2. Access the **Control Inputs** settings.

a. Select the arrow next to the **Global** branch of the **Settings** tree view.

b. Select the arrow next to the **Control Inputs** branch of the **Settings** tree view.

Step 3. Set **EICIS Independent Control Input Settings** to **Y**.

Step 4. Set the control input IN101 debounce time.

For this example, assume that the auxiliary contacts are slow and noisy; you must provide a slightly longer debounce time for these contacts.

a. Double-click the mouse cursor (or press **<Tab>**) to highlight **IN101PU Pickup Delay for Contact Input**.

b. Delete the present setting by pressing **<Delete>**.

c. Type **0.25 <Enter>**.

d. Similarly change the **IN101DO Input IN101 Dropout Delay** to **0.25**.

The software checks the value.

Step 5. Configure the relay to read the circuit breaker auxiliary contact.

a. Expand the **Breaker Monitor** branch of the **Settings** tree view by selecting the **+** button.

b. In the tree view, select **Breaker 1** to select circuit breaker monitor settings for Circuit Breaker 1.

c. Set the 52AA1 SELOGIC control equation by selecting in the text box labeled **52AA1 N/O Contact Input**.

d. Type **IN101**, and then select or **<Tab>** to another field to specify input IN101 as the control input that represents the close/open state of Circuit Breaker 1.

Step 6. Upload the new settings to the SEL-451.

Special Considerations for TiDL

In Time-Domain Link (TiDL) systems, IN301–IN324, OUT301–OUT316, IN401–IN424, OUT401–OUT416, IN501–IN524, and OUT501–OUT516 are provided from TiDL merging units. See *Section 19: Digital Secondary Systems* for more information on TiDL I/O.

Configuring Timekeeping

The relay features high-accuracy timekeeping when supplied with an IRIG-B or Ethernet Precision Time Protocol (PTP) signal. When the supplied clock signal is sufficiently accurate, most SEL-400 series relays can act as a phasor measurement unit (PMU) and transmit synchrophasor data representative of the power system at fixed time periods to an external data processor. The relay can also record COMTRADE event report data by using the high-accuracy time stamp. See *Oscillography on page 9.9* and *Time-Synchronized Triggers on page 11.9* for details on these applications.

IRIG-B and PTP

NOTE: The SEL-487V does not support PTP.

The relay has two input connectors that accept IRIG-B (Inter-Range Instrumentation Group-B) demodulated time-code format: the IRIG-B pins of aerial PORT 1, and the IRIG-B BNC connector. In relays with Ethernet, Precision Time Protocol (PTP) can also be used to provide high-accuracy time. See *Section 11: Time and Date Management* for more information on using IRIG-B and PTP.

Monitoring High-Accuracy Time Source Status

The purpose of the procedure in the following steps is to show one method for deriving the TIME Q Time Source information from Relay Word bits TSOK and TIRIG when using an IRIG Time Source. The TSOK Relay Word bit is at logical 1 when the relay is in HIRIG time mode. For this application example, use a protection SELOGIC variable (PSV) to monitor timekeeping status.

PSV02 asserts when the relay is synchronized to the HIRIG source. A departure from this condition asserts the relay alarm output (OUT108 for this application example).

This example assumes that you are familiar with SEL Grid Configurator or QuickSet (see *Section 2: PC Software*).

Step 1. Read the relay settings

Step 2. Access the protection free-form SELOGIC settings.

a. Select the arrow next to **Group 1** in the **Settings** tree view.

b. Select the **Protection Logic 1** settings.

Step 3. Enter the two lines of SELOGIC control equation programming in the **Protection Free-Form Logic Settings** shown in *Figure 3.53*.

```
SET L <Enter>
17: #CHECK THE TIME SYNCHRONIZATION RELAY WORD BIT FOR HIRIG
18: PSV02 := TSOK
```

Figure 3.53 Programming a PSV to Monitor HIRIG in QuickSet

Step 4. Configure a control output to alarm a loss-of-HIRIG mode.

a. In the **Settings** tree view, select **Outputs** and then select **Main Board**.

b. In the **OUT108 Main Board Outputs** text box, enter the OR NOT PSV02 condition to the preexisting OUT108 := NOT (SALARM OR HALARM) equation.

Step 5. Upload the new settings to the relay.

To confirm that you have prepared an out-of-synchronization/loss-of-HIRIG mode alarm, disconnect the IRIG-B input. The relay alarm will activate.

Readying the Relay for Field Application

Before applying the relay in your power system, set the relay for your particular field application. Be sure to modify the relay factory-default settings for your power system conditions to enable relay features to help you protect and control your system.

This procedure is a guide to help you ready the relay for field application. If you are unfamiliar with the steps in this procedure, see the many relay usage examples presented in this section. This is a suggested procedure; modify the procedure as necessary to conform to your standard company practices.

Step 1. Open the appropriate low-voltage breaker(s) and remove fuses to verify removal of control power and ac signals from the relay.

Step 2. Isolate the relay TRIP control output.

Step 3. Perform point-to-point continuity checks on the circuits associated with the relay to verify the accuracy and correctness of the ac and dc connections.

Step 4. Apply power to the relay.

The green **ENABLED** LED on the front panel will illuminate.

Step 5. Use an SEL-C234A cable to connect a serial terminal to the relay.

Step 6. Start the terminal (usually a PC with terminal emulation software).

Step 7. Establish communication with the relay at Access Level 0.

Step 8. Proceed to Access Level 2 (see *Changing the Default Passwords in the Terminal on page 3.11*).

Step 9. Change the default passwords (see *Changing the Default Passwords in the Terminal on page 3.11*).

Step 10. Set the DATE and TIME (see *Making Simple Settings Changes on page 3.15*).

Step 11. Use test sources to verify relay ac connections (see *Examining Metering Quantities on page 3.34*).

Step 12. Verify control input connections.

Step 13. Verify control output connections.

Step 14. Perform protection element tests.

Step 15. Set the relay (see *Making Simple Settings Changes on page 3.15, Section 12: Settings,* and *Section 6: Protection and Protection Application Examples* in the product-specific instruction manual).

Step 16. Connect the relay for tripping/closing duty.

Step 17. From Access Level 2, use a communications terminal to issue applicable commands (listed in *Table 3.9*) to clear the relay data buffers.

Table 3.9 Communications Port Commands That Clear Relay Buffers

Communications Port Command	Task Performed
MET RD	Reset demand meter data
MET RP	Reset peak demand meter data
MET RE	Reset energy meter data
MET RM	Reset maximum/minimum meter data
HIS CA	Reset event report and history buffers
SER CA	Reset Sequential Events Recorder data

Step 18. Connect the secondary voltage and current inputs.

Step 19. Use the **MET** command or the QuickSet HMI to view relay metering to confirm secondary connections (see *Examining Metering Quantities on page 3.34*).

SECTION 4

Front-Panel Operations

The relay front panel makes power system data collection and system control quick and efficient. Using the front panel, you can analyze power system operating information, view and change relay settings, and perform relay control functions. The relay features a straightforward menu-driven control structure presented on the front-panel LCD. Front-panel targets and other LED indicators provide a quick look at relay operation status. You can perform often-used control actions rapidly by using the large direct-action pushbuttons. All of these features help you operate the relay from the front panel and include:

- Reading metering
- Inspecting targets
- Accessing settings
- Controlling relay operations

This section describes features found in many, but not necessarily all, SEL-400 series relays. See the relay-specific instruction manuals to determine which front-panel features are supported in that relay. This section includes the following:

- *Front-Panel Layout on page 4.1*
- *Front-Panel Menus and Screens on page 4.14*
- *Front-Panel Automatic Messages on page 4.32*
- *Operation and Target LEDs on page 4.33*
- *Front-Panel Operator Control Pushbuttons on page 4.35*

Front-Panel Layout

Some SEL-400 series relays come with a front panel with 16 target LEDs and 8 operator pushbuttons. Others come with 24 target LEDs and 12 operator pushbuttons. Refer to the product-specific instruction manual to see which displays are available for any specific relay. *Figure 4.1*, *Figure 4.2*, and *Figure 4.3* show what these front-panel options look like in the SEL-451 and the SEL-487E relays. Some relays are also available with direct-action pushbuttons for breaker control, which is illustrated in *Figure 4.2*.

Figure 4.1 SEL-451 Front Panel (8-Pushbutton Model)

Figure 4.2 SEL-451 Front Panel (12-Pushbutton Model) with Optional Auxiliary Trip/Close Buttons

Figure 4.3 SEL-487E Front Panel

A 128 x 128 pixel LCD shows relay operating data including event summaries, metering, settings, and relay self-test information.

Six navigation pushbuttons adjacent to the LCD window control the relay menus and information screens. Sequentially rotating display screens provide important power system metering parameters; you can easily change this `ROTATING DISPLAY` to suit your particular onsite monitoring needs. Use a simple and efficient menu structure to operate the relay from the front panel. With these menus you can quickly access relay metering, control, and settings.

Front-panel LEDs indicate the relay operating status. You can confirm that the relay is operational by viewing the **ENABLED** LED. The relay illuminates the **TRIP** LED target to indicate a tripping incident. The relay is factory programmed for particular relay elements to illuminate the other target LEDs. You can program these target LEDs to show the results of the most recent relay trip event. The asserted and deasserted colors for the LEDs are programmable.

Select relay models feature auxiliary **TRIP/CLOSE** pushbuttons. These pushbuttons are electrically isolated from the rest of the relay.

The relay front panel features large operator control pushbuttons with annunciator LEDs that facilitate local control. Factory-default settings associate specific relay functions with these direct-action pushbuttons and LEDs. Using SELOGIC control equations or front-panel settings PB*n*_HMI, you can readily change the default direct-action pushbutton functions and LED indications to fit your specific control and operational needs. Change the pushbutton and pushbutton LED labels with the slide-in labels adjacent to the pushbuttons. The asserted and deasserted colors for the LEDs are programmable in 12-pushbutton models.

The relay front panel includes an EIA-232 serial port (labeled **PORT F**) for connecting a communications terminal or using the ACSELERATOR QuickSet SEL-5030 Software program. Use the common EIA-232 open ASCII communications protocol to communicate with the relay via front-panel **PORT F**. Other communications protocols available with the front-panel port are MIRRORED BITS communications, and DNP3. For more information on communications protocols and **PORT F**, see *Section 15: Communications Interfaces*.

Front-Panel LCD

The LCD is the prominent feature of the relay front panel. *Figure 4.4* shows the following areas contained in the LCD:

- Title area
- Main area
- Message area
- Scroll bars

The scroll bars are present only when a display has multiple screens.

Figure 4.4 LCD and Navigation Pushbuttons

Front-Panel Inactivity Time-Out

An LCD backlight illuminates the screen when you press any front-panel pushbutton. This backlight extinguishes after a front-panel inactivity time-out period. You can control the duration of the time-out with relay setting FP_TO, listed in *Table 4.1*.

To set FP_TO, use the SET F (set front panel) settings from any communications port or use the Front Panel branch of the QuickSet Settings tree view. The maximum backlight time is 60 minutes (FP_TO = 60). When the front panel times out, the relay displays an automatic `ROTATING DISPLAY`, described later in this section under *Screen Scrolling on page 4.5*.

Table 4.1 Front-Panel Inactivity Time-Out Setting

Name	Description	Range	Default
FP_TO	Front-panel display time-out	OFF, 1–60 minutes	15 minutes

Navigating the Menus

The relay front panel presents a menu system for accessing metering, settings, and control functions. Use the LCD and the six pushbuttons adjacent to the display (see *Figure 4.4*) to navigate these front-panel menus.

The navigation pushbutton names and functions are the following:

- **ESC**—Escape pushbutton
- **ENT**—Enter pushbutton
- **Left Arrow**, **Right Arrow**, **Up Arrow**, and **Down Arrow**—Navigation pushbuttons

Menus show lists of items that display information or control the relay. A rectangular box around an action or choice indicates the menu item you have selected. This rectangular box is the menu item highlight.

Figure 4.5 shows an example of `RELAY ELEMENTS` highlighted in an example `MAIN MENU`. When you highlight a menu item, pressing the **ENT** pushbutton selects the highlighted item.

```
MAIN MENU
METER
EVENTS
BREAKER MONITOR
RELAY ELEMENTS
LOCAL CONTROL
SET/SHOW
RELAY STATUS
VIEW CONFIGURATION
DISPLAY TEST
RESET ACCESS LEVEL
```

Figure 4.5 RELAY ELEMENTS Highlighted in Example MAIN MENU

The **Up Arrow** pushbutton and **Down Arrow** pushbutton scroll the highlight box to the previous or next menu selection, respectively. When there is more than one screen of menu items, pressing the **Up Arrow** while at the first menu item causes the display to show the previous set of full-screen menu items, with the last menu item highlighted. Pressing the **Down Arrow** while at the bottom menu item causes the display to show the next set of full-screen menu items, with the first menu item highlighted.

Pressing the **ESC** pushbutton reverts the LCD to the previous screen. Pressing **ESC** repeatedly returns you to the `MAIN MENU`. If a status warning, alarm condition, or event condition is active (not acknowledged or reset), the relay displays the full-screen status warning, alarm screen, or trip event screen in place of the `MAIN MENU`.

Screen Scrolling

SEL-400 series relays have two screen scrolling modes: autoscrolling mode and manual-scrolling mode. After front-panel time-out, the LCD presents each of the display screens in this sequence:

- One-line diagram (if applicable)
- Any active (filled) alarm points screens
- Any active (filled) display points screens
- Other enabled screens

See the product-specific instruction manual for the details of the other screens that are supported and how they are enabled.

Figure 4.6 Sample ROTATING DISPLAY

Figure 4.6 illustrates an example rotating display sequence. The active alarm points are the first screens in the `ROTATING DISPLAY` (see *Alarm Points on page 4.7*). Each alarm points screen shows as many as 11 alarm conditions. The relay can present a maximum of six alarm points screens.

NOTE: The SEL-487E supports 256 display points. The SEL-487V supports 96 display points.

The active display points are the next screens in the `ROTATING DISPLAY` after alarm points (see *Display Points on page 4.10*). Each display points screen shows as many as 11 enabled display points (with 192 display points, the relay can present a maximum of 18 display points screens). If a display point does not have text to display, the screen space for that display point is maintained.

Autoscrolling Mode

Autoscrolling mode shows each screen for a user-configurable period of time. Front Panel setting SCROLD defines the period of time for which each screen is shown. When you first apply power to the relay, the LCD shows the autoscrolling ROTATING DISPLAY. With SCROLD := OFF, the screen remains on the first screen in the rotating display order; automatic rotation of additional screens is disabled.

The autoscrolling ROTATING DISPLAY also appears after a front-panel inactivity time-out (see *Front-Panel Inactivity Time-Out on page 4.4*). The relay retrieves data prior to displaying each new screen. The relay does not update screen information during the display interval. At any time during autoscrolling mode, pressing **ENT** takes you to the MAIN MENU. Pressing any of the four navigation pushbuttons switches the display to manual-scrolling mode.

Manual-Scrolling Mode

In manual-scrolling mode, you can use the directional navigation arrow pushbuttons to select the next or previous screen. Pressing the **Down Arrow** or **Right Arrow** pushbuttons switches the display to the next screen; pressing the **Up Arrow** or **Left Arrow** pushbuttons switches the display to the previous screen.

In manual-scrolling mode, the display shows arrows at the top and bottom of the vertical scroll bar. The screen arrows indicate that you can navigate between the different screens at will. The relay retrieves data prior to displaying each new screen. Unlike the autoscrolling mode, the relay continues to update screen information while you view it in the manual-scrolling mode. To return to autoscrolling mode, press **ESC** or wait for a front-panel time-out.

Alarm Points

You can display messages on the front-panel LCD that indicate alarm conditions in the power system. The relay uses alarm points to place these messages on the LCD.

Figure 4.7 shows a sample alarm points screen. The relay is capable of displaying as many as 66 alarm points. The relay automatically displays new alarm points while in manual-scrolling mode and in autoscrolling mode. While you navigate the HMI menu structure, the relay does not automatically display the alarm points. Instead, ALARM EVENT displays in the footer. When you escape the HMI menu structure, the relay will display the alarm points screen.

Figure 4.7 Sample Alarm Points Screen

The alarm point setting is an element of the SER settings. To enable an alarm point, enable the HMI alarm parameter of the SER Point Settings listed in *Table 4.2*. The format for entering the SER point data is the following comma-delimited string:

Relay Word Bit, Reporting Name, Set State Name, Clear State Name, HMI Alarm

Names can contain any valid ASCII character. Enclose the name within quotation marks. See *Example 4.1* for particular information on the format for entering SER point data.

Table 4.2 SER Point Settings

Description	Range
Relay Word Bit	Any valid relay element
Reporting Name	20-character maximum ASCII string
SET State Name (logical 1)	20-character maximum ASCII string
CLR State Name (logical 0)	20-character maximum ASCII string
HMI Alarm	Y, N

If you enter a Relay Word bit that does not match a valid relay element, the relay displays: `Unknown relay word reference`. If you enter an alias or name that is too long, the relay displays: `Alias label too long`.

The relay displays alarm points in a similar fashion as the SER. As many as 19 characters of the given alias are displayed, with one character reserved for the "*." The asterisk denotes if the element is asserted. Initially, an alarm point must be asserted to be displayed; after the corresponding element deasserts, the asterisk is removed, but the alias is not. The relay displays alarm points in reverse chronological order, just as in the SER, with the most recently asserted alarm displayed on the top. Deasserted alarms may be removed from the display with user acknowledgment, as shown in *Example 4.1*.

Example 4.1 Creating an Alarm Point

Alarm points screens provide operator feedback about the status of system conditions. An alarm points screen contains 11 alarm points; this example demonstrates a method to set the alarm point message that is shown in *Figure 4.7*. This example is based on the Relay Word bit IN101 asserting when Circuit Breaker 1 is in an alarm condition.

In the Report settings (SET R), enter the following after the SER Points Line 1 prompt:

1: **IN101,"Circuit BK1 SF6 Gas","Alarm","Normal","Y"**

The circuit breaker alarm condition is indicated by the set state, "Alarm" and the circuit breaker normal condition is indicated by the clear state "Normal." The HMI Alarm parameter is set to "Y" to enable alarm points screen display of this element.

While in the scrolling mode, the assertion of IN101 will cause the alarm points screen (as shown in *Figure 4.7*) to be automatically displayed. Upon the deassertion of IN101, the asterisk will disappear, as shown in *Figure 4.8*.

Example 4.1 Creating an Alarm Point (Continued)

```
ALARM POINTS
 Circuit BK1 SF6 Gas

Press ↵ to acknldge
```

Figure 4.8 Deasserted Alarm Point

Pressing the ENT pushbutton will allow the user to acknowledge and clear deasserted alarms. Before clearing, you will be prompted to confirm that this is the intended action, as shown in *Figure 4.9*.

```
ALARM POINTS
 Circuit BK1 SF6 Gas

 Are you sure you
 want to clear
 inactive alarms?
 Press ↵ to clear

Press ↵ to acknldge
```

Figure 4.9 Clear Alarm Point Confirmation Screen

In the case that all alarms are deasserted, pressing the ENT pushbutton will allow the user to acknowledge and clear all alarms. After clearing, a screen showing the results of the action will be shown, as in *Figure 4.10*.

```
ALARM POINTS
NO ALARM POINTS
EXIST.
```

Figure 4.10 No Alarm Points Screen

Alarm points are not updated for a particular element if it has been deleted from the SER because of chatter criteria (see *Automatic Deletion and Reinsertion on page 9.31*). Upon reinsertion, the element state will be updated on the alarm point display. If the relay enters a period of SER data loss, the status of alarm points cannot be determined. The screen shown in *Figure 4.11* will appear until you exit the data loss condition, at which point the alarm point elements will be polled and displayed if asserted. Subsequent alarm point assertions will be displayed above the data loss message.

Example 4.1 Creating an Alarm Point (Continued)

Figure 4.11 Alarm Points Data Loss Screen

Display Points

You can display messages on the relay front-panel LCD that indicate conditions in the power system. The relay uses display points to place these messages on the LCD.

Figure 4.12 shows a sample display points screen. Display points can show the status of Relay Word bits or display the value of analog quantities. The relay has 192 possible display points; *Table 4.3* and *Table 4.4* list the display points settings. The relay updates the display points data once per second if you are viewing the display points in manual-scrolling mode; in autoscrolling mode the relay updates the display points information each time the screen appears in the `ROTATING DISPLAY` sequence.

Figure 4.12 Sample Display Points Screen

To enable a display point, enter the display point settings listed in *Table 4.3* or *Table 4.4*. All display points occupy one, and only one, line on the display at all times. The height of the line is determined by the "Text Size" setting parameter. Display points of single-line height span one screen in total width. Display points of double-line height span two screens in total width. You can use multiple display points to simulate multiple lines.

Use the following syntax to display the given Relay Word bit exactly as seen in the navigational menu (name and value).

DPxx := **Name**

Use the following syntax to display the given Relay Word bit as seen in the navigational menu, replacing the name of the value with the given alias string. The text size determines if the display will be in single font or double font. If the text size is empty, the display will be in single font.

DPxx := **Name, "Alias", "Text Size"**

Use the following syntax to display the given Relay Word bit with the given alias. If the Relay Word bit is asserted (logical 1), the LCD displays the set string in the place of the value. If the Relay Word bit is deasserted (logical 0), the LCD displays the clear string in the place of the value. One or all of Alias, Set String, or Clear String can be empty. If Alias is empty, then the LCD displays only the Set or Clear Strings. If either Set String or Clear String is empty, then an empty line is displayed when the bit matches that state. The text size determines if the display will be in single font or double font. If the text size is empty, the display will be in single font.

DPxx := **Name, "Alias", "Set String", "Clear String", "Text Size"**

Use the following syntax to display the given analog quantity with the given text and formatting. Formatting must be in the form Width.Decimal,Scale with the value of Name, scaled by "Scale," formatted with total width "Width" and "Decimal" decimal places. The width value includes the decimal point and sign character, if applicable. The "Scale" value is optional; if omitted, the scale factor is processed as 1. If the numeric value is smaller than the field size requested, the field is padded with spaces to the left of the number. If the numeric value will not fit within the field width given, "$" characters are displayed. The text size determines if the display will be in single font or double font. If the text size is empty, the display will be in single font.

DPxx := **Name, "(Text1 Width.Decimal,Scale) Text2", "Text Size"**

Table 4.3 Display Point Settings—Boolean

Description	Range
Relay Word Bit Name	See the relay-specific instruction manual for a list of Relay Word bits available in that relay.
Alias	ASCII string
Set String	ASCII string
Clear String	ASCII string
Text Size	S, D

Table 4.4 Display Point Settings—Analog

Description	Range
Analog Quantity Name	See the relay-specific instruction manual for a list of available analog quantities
"User Text and Formatting"	ASCII string
Text Size	S, D

Table 4.5 Display Point Settings—Boolean and Analog Examples (Sheet 1 of 2)

Example Display Point Setting Value	Example Display
IN101	`IN101=1` `IN101=0`
MWHAIN,"{7.2}"	`1234.56`
50P1,Overcurrent,,	`Overcurrent=1` `Overcurrent=0`
PSV01,Control,On,Off	`Control=On` `Control=Off`
PSV02,Breaker,Tripped,	`Breaker=Tripped` *Empty Line*

Table 4.5 Display Point Settings—Boolean and Analog Examples (Sheet 2 of 2)

Example Display Point Setting Value	Example Display
50P1,,,Overcurrent	*Empty Line* `Overcurrent`
MWHAIN,“A Ph Import={7.2}”	`A Ph Import=1234.56`
MWHAIN,“A Ph Import={7.3}”	`A Ph Import=$$$.$$$`
MWHAIN,“A Ph Imp {4}MWh”	`A Ph Imp 1234MWh`
PAD,“{7.2}”	`1234.56`
PAD,“A Ph Dem Pwr={4.1}”	`A Ph Dem Pwr=1234.5`
ICD,“C Demand={5}”	`C Demand= 1230`
ICD,“C Demand={4.2,0.001} kA”	`C Demand=1.23 kA`
MWHAOUT,“A Phase Out={3, 1000}”	`A Phase Out=1234`
MWHAOUT,“A Phase Out={3, 1000} kWH”	`A Phase Out=$$$ kWh`
1,“Fixed Text”	`Fixed Text`
0,“Fixed Text”	`Fixed Text`
1,	*Empty Line*
0,	*Empty Line* *Display Point is hidden*

If you enter a Relay Word bit or Analog Quantity that does not match a valid relay element, the relay displays: `Invalid element`. If you enter a display point that exceeds the allowable length, the relay displays: `Too many characters`. If you enter an invalid scale factor, invalid width, too many parameters, or omit necessary quotation marks or brackets, the relay displays an error message. If a display point was used previously and you want to remove the display point, you can delete the display point. In the Front Panel settings (SET F), at the Display Points and Aliases prompt, use the text-edit mode line editing commands to set the display points (see *Text-Edit Mode Line Editing on page 3.23* for information on text-edit mode line editing). To delete Display Point 1, type **DELETE <Enter>** at the Front Panel settings Line 1 prompt.

Example 4.2 Creating a Display Point

Display points screens can be used to provide operator feedback about the readiness of equipment connected to the relay. A display points screen contains 11 display points; this example demonstrates a method to set the display point messages that are shown in *Figure 4.12*. This example uses an SEL-451 with an additional I/O interface board.

This example is based on a three-pole circuit breaker. Relay Word bit 52AA1 will assert when Circuit Breaker 1 is in the closed position.

IN109 will assert when Circuit Breaker 1 is in an alarm condition. B2IAFIM is the filtered instantaneous magnitude for the A-Phase current through Circuit Breaker 2.

In the Front Panel settings (**SET F**), enter the following after the Display Points and Aliases Line 1 prompt:

1: **1,“Circuit Breaker 1”**

2: **52AA1,,“ --Closed--”,“ --Open--”**

Example 4.2 Creating a Display Point (Continued)

3: **0**

4: **0,“Circuit BK1 SF6 Gas”**

5: **IN109,,“ --Alarm--”,“ --Normal--”**

6: **1**

7: **1,“Circuit Breaker 2”**

8: **B2IAFIM,“ A PH=(6.1,1) A pri”**

9: **IN109,, “SF6 ALARM”, D**

Fixed text is set by assigning an alias to a “1” or “0.” Blank lines are set by assigning a blank alias to a “1” or “0.” The circuit breaker closed condition is indicated by the set state, “--Closed--” where leading spaces are added to center the set state message. Add a clear state named “--Open--” to show that the circuit breaker is open. The circuit breaker alarm condition is indicated by the set state, “--Alarm--” where leading spaces are added to center the set state message. Add a clear state named “--Normal--” to show that the circuit breaker is not in alarm. User text “A PH=” and “A pri” allows for customized display of the Circuit Breaker 2 A-Phase current, which has been formatted to display numerically as XXXX.X. Double font display is used to give greater visibility to the SF6 Alarm. A horizontal scroll appears while in manual-scrolling mode regardless of whether or not the display point label width requires two full screens to display.

Example 4.3 Monitoring Test Modes With Display Points

This example uses the Relay Word bit TESTFM (Fast Meter test running) to activate a front-panel display point that alerts an onsite operator that the relay is in Fast Meter test mode.

In the Front Panel settings (**SET F**), enter the following after the Line 10 prompt:

10: **TESTFM,,“FAST METER TEST!!!!”**

The LCD displays the screen shown in *Figure 4.13* as a part of the `ROTATING DISPLAY` if the Fast Meter test is running. (Instruct the operator to view the relay front panel for messages or warnings as the last item on a “Leaving the Substation” checklist.)

Again, this display point application example does not require a clear state, so the clear state is blank. If the Fast Meter test is not running and no other display points are active, the relay shows a blank screen in the `ROTATING DISPLAY`.

Figure 4.13 Fast Meter Display Points Sample Screen

Front-Panel Menus and Screens

Operate the relay front panel through a sequence of menus that you view on the front-panel display. The MAIN MENU is the introductory menu for other front-panel menus (see *Figure 4.5*). These additional menus allow you onsite access to metering, control, and settings for configuring the relay to your specific application needs. The following menus and screens are representative of what is typically found in SEL-400 series relays, but each relay has a slightly different list. See the relay-specific instruction manual to see what is available in that relay.

- Support Screens
  - Contrast
  - Password
- MAIN MENU
  - METER
  - EVENTS
  - BREAKER MONITOR
  - RELAY ELEMENTS
  - LOCAL CONTROL
  - SET/SHOW
  - RELAY STATUS
  - VIEW CONFIGURATION
  - DISPLAY TEST
  - RESET ACCESS LEVEL
  - ONE LINE DIAGRAM

Support Screens

The relay displays special screens over the top of the menu or screen that you are using to control the relay or view data. These screens are the ADJUST CONTRAST screen and the PASSWORD REQUIRED screen.

Contrast

You can adjust the LCD screen contrast to suit your viewing angle and lighting conditions. To change screen contrast, press and hold the **ESC** pushbutton for one second. The relay displays a contrast adjustment box superimposed over the display.

Figure 4.14 shows the contrast adjustment box with the MAIN MENU screen in the background. Pressing the **Right Arrow** pushbutton increases the contrast. Pressing the **Left Arrow** pushbutton decreases the screen contrast. When finished adjusting the screen contrast, press the **ENT** pushbutton.

Figure 4.14 Contrast Adjustment

Password

The relay uses passwords to control access to settings and control menus. The relay has six access-level passwords. See *Access Levels and Passwords on page 3.7* for more information on access levels and setting passwords. The relay front panel is at Access Level 1 upon initial power-up and after front-panel time out.

⚠WARNING
This device is shipped with default passwords. Default passwords should be changed to private passwords at installation. Failure to change each default password to a private password may allow unauthorized access. SEL shall not be responsible for any damage resulting from unauthorized access.

Password validation occurs only when you request a menu function that is at a higher access level than the presently authorized level. At this point, the relay displays a password entry screen, shown in *Figure 4.15*. This screen has a blank password field and an area containing alphabetic, numeric, and special password characters with a movable highlight box.

Figure 4.15 Enter Password Screen

Enter the password by pressing the navigation pushbuttons to move the highlight box through the alphanumeric field. When at the desired character, press **ENT**. The relay enters the selected character in the password field and moves the dark box cursor one space to the right. You can backspace at any time by highlighting the `BACKSPACE` character and then pressing **ENT**. When finished, enter the password by highlighting the `ACCEPT` option and then pressing **ENT**.

If you entered a valid password for an access level greater than or equal to the required access level, the relay authorizes front-panel access to the combination of access levels (new level and all lower levels) for which the password is valid. The relay replaces the password screen with the menu screen that was active before the password validation routine. When you enter Access Levels B, P, A, O, and 2, the Relay Word bit SALARM pulses for one second.

If you did not enter a valid password, the relay displays the error screen shown in *Figure 4.16*. Entering a valid password for an access level below the required access level also causes the relay to generate the error screen. In both password failure cases, the relay does not change the front-panel access level (it does not reset to Access Level 1 if at a higher access level). The relay displays the `PASSWORD INVALID` screen for five seconds. If you do not want to wait for the relay to remove the message, press any of the six navigational pushbuttons during the five-second error message to return to the previous screen in which you were working.

Figure 4.16 Invalid Password Screen

If three failed login attempts occur within a 1-minute interval, the relay disables login attempts for 30 seconds and pulses the SALARM and BADPASS Relay Word bits for 1 second. If the user tries to login within the 30 seconds, the error message in *Figure 4.17* displays for 4 to 6 seconds. Pressing the navigation buttons while this message is displayed removes the error message sooner but the password entry remains disabled for the original 30 seconds.

```
Access Denied


Maximum Passord
Attempts Exceeded,
Access Temporarily
Denied
```

Figure 4.17 Password Lockout Screen

Main Menu

The MAIN MENU is the starting point for all other front-panel menus. A representative relay MAIN MENU is shown in *Figure 4.18*. When the front-panel LCD is in the ROTATING DISPLAY, press the **ENT** pushbutton to show the MAIN MENU.

```
MAIN MENU
METER
EVENTS
BREAKER MONITOR
RELAY ELEMENTS
LOCAL CONTROL
SET/SHOW
RELAY STATUS
VIEW CONFIGURATION
DISPLAY TEST
RESET ACCESS LEVEL
```

Figure 4.18 MAIN MENU

Meter

The relay displays metering screens on the LCD. Highlight METER and press **ENT** on the MAIN MENU screen to select these screens. The metering screens available are relay-specific and are described in each relay-specific instruction manuals.

Events

The relay front panel features summary event reporting, which simplifies post-fault analysis. These summary event reports include all trip events, event and data capture triggering (via the ER SELOGIC control equation), and manual triggers. The relay displays event reports based on the Relay Word bit elements in the ER (event report trigger) SELOGIC control equation. See *Event Report on page 9.14* for more information on event reports.

The front-panel event buffer size is 100 summaries. The relay numbers summary events in order from 10000 through 42767 and displays the most recent summaries on the LCD.

You can view summary event reports from the relay front-panel display by selecting `EVENTS` from the `MAIN MENU`. The relay presents the `Events Menu` as shown in *Figure 4.19*. Select `Event Summary` from the `Events Menu` to view event summary data. *Figure 4.20* shows sample `Event Summary` screens for a phase-to-phase-to-ground fault. Use the **Right Arrow** and **Left Arrow** pushbuttons to show each of the summary screens for the event. Event reports can also be viewed via a front-panel automatic message (see *Front-Panel Automatic Messages on page 4.32*) or programmable front-panel operator control pushbutton (see *Front-Panel Operator Control Pushbuttons on page 4.35*).

Figure 4.19 Events Menu Screen

The horizontal scroll bar indicates that you can view other event 10002 screens. Use the **Up Arrow** and **Down Arrow** pushbuttons to move among the events in the summary buffer. Press **ESC** to return to the `Events Menu` and **ESC** again to return to the `MAIN MENU`.

Figure 4.20 Example EVENT SUMMARY Screens

SER

The Sequential Events Recorder (SER) records state changes of user-programmable Relay Word bits. State changes are time-tagged for future analysis of relay operations during an event. See *Sequential Events Recorder (SER) on page 9.28* for more information on SER events. To view SER events from the front panel, select `EVENTS` from the `MAIN MENU` and `SER Events` from the `Events Menu` as shown in *Figure 4.19*. SER events are also viewable using programmable front-panel operator control pushbuttons; see *Front-Panel Operator Control Pushbuttons on page 4.35*.

Figure 4.21 illustrates the SER Events display screen. Data reported in this screen for each event are the SER Point Alias Name, Asserted or Deasserted state, and the Date and Time of the event. When in the `SER Events` screen, three SER records are displayed on one screen. Using the navigation pushbuttons, the most recent 200 SER events are viewable on the front-panel display. The top event is the most recent event, and the bottom event is the oldest. The upper right of the screen displays the sequential indexes of the SER events currently being viewed. If a new event occurs while viewing the SER events, the display does not update with the new event automatically. To include the new SER event in the

display, exit the SER screen by pressing **ESC** and re-enter the `SER Events` screen by pressing **ENT** with the `SER Events` selection highlighted. This rebuilds the `SER Events` display and contains the latest SER events triggered.

```
SER Events    001-003
Local
Disabled
02/16/06 11:11:01.993

Local
Enabled
02/16/06 10:11:19.090

IN101
Asserted
02/16/06 03:22:01.988
```

Figure 4.21 SER Events Screen

If no SER events are available, the message shown in *Figure 4.22* is displayed.

```
SER Events

    No SER Events
      Available
```

Figure 4.22 No SER Events Screen

While viewing the SER events, front-panel pushbuttons provide navigation and control functions as indicated in *Table 4.6*.

Table 4.6 Front-Panel Pushbutton Functions While Viewing SER Events

Pushbutton	Description
Up Arrow, **Down Arrow**	Navigates one screen at a time up or down. Each screen contains three SER events. Accelerated scrolling is obtained when the pushbutton remains pressed (see accelerated scrolling behavior below).
Left Arrow, **Right Arrow**	Navigates between SER events to allow adjacent SER events to be displayed on one screen. For example, if events 1, 2, and 3 are displayed, press the **Right Arrow** once to display events 2, 3, and 4 in the same screen. No accelerated scrolling is provided with the **Left Arrow** and **Right Arrow** pushbuttons.
ESC	Returns to the `Events Menu`
ENT	Does nothing

Hold down either the **Up Arrow** or **Down Arrow** to achieve accelerated scrolling. Holding down the **Up Arrow** or **Down Arrow** navigates one screen at a time for the first five screens, and then increases to five screens at a time if the button remains pressed. Accelerated scrolling stops at the newest or oldest SER event record available, depending on the direction of the scrolling.

When the upper limit of the SER events is reached, press the **Down Arrow** one more time and the report will wrap around to display the screen containing the first SER event. Similarly, when the lower limit of the SER events is reached, press the **Up Arrow** one more time and the report will wrap around to display the screen containing the last SER event.

By default, three SER events are shown per screen. You can change this to five per screen by setting SER_PP to Y. This will cause the element name and state information to be shown on the same line, with the element name truncated to ten characters and the state truncated to eight characters.

Breaker Monitor

Some SEL-400 series relays feature an advanced circuit breaker monitor. Select BREAKER MONITOR from the MAIN MENU to view circuit breaker monitor alarm data on the front-panel display. See the relay-specific instruction manual for the supported options and example screens.

Relay Elements (Relay Word Bits)

You can view the RELAY ELEMENTS screen to check the state of the Relay Word bits in the relay. The relay has two unique manual-scrolling features for viewing these elements:

- Accelerated navigation
- Search

These Relay Word bit scrolling features make selecting elements from among the many relay targets easy and efficient. *Figure 4.23* shows an example of the RELAY ELEMENTS screen. If an alias exists for an element, the alias name is displayed instead of the element name. An asterisk character (*—shown in *Figure 4.23*) indicates that this Relay Word bit position is reserved for future use.

Figure 4.23 RELAY ELEMENTS Screen

When you move item by item through the Relay Word bit table, pressing the **Up Arrow** or **Down Arrow** pushbuttons shows each previous or next screen in turn.

Accelerated navigation occurs when you press and hold the **Up Arrow** or **Down Arrow** pushbuttons. Holding the **Up Arrow** or **Down Arrow** pushbuttons repeats the regular pushbutton action at two rows every second for the first ten rows. Continue pressing the **Up Arrow** or **Down Arrow** pushbutton to cause the relay screen scrolling to accelerate to 20 rows per second. When you are scrolling up in accelerated scrolling, scrolling will stop at the first relay elements screen. When you are scrolling down, scrolling will stop at the last screen.

Figure 4.24 ELEMENT SEARCH Screen

Search mode allows you to find a specific relay target element quickly. *Figure 4.24* shows the menu screen that the relay displays when you select the SEARCH option of the RELAY ELEMENTS initial menu.

When you first enter this search menu, the block cursor is at the beginning of the element name field and the highlight box in the alphanumeric field is around the letter A. Use the navigation pushbuttons to move through the alphanumeric characters. If the highlight is on one of the characters, pressing **ENT** enters the character at the block cursor location in the element name field. Next, the block cursor moves automatically to the character placeholder to the right. If the block cursor was already at the first character position on the left, the block cursor remains at the end of the name field. To backspace the cursor in the element name field, move the highlight to BACKSPACE and press **ENT**. When you have finished entering an element name, move the highlight to ACCEPT and press **ENT**. At any time, pressing **ESC** returns the display to the RELAY ELEMENTS screen.

If the highlight is on ACCEPT, the relay finds the matching relay element when you press **ENT**. The relay first searches for alias names, seeking an exact match. If the relay does not find an exact alias name match, it searches for an exact primitive name match. If there is no exact primitive name match, the relay initiates a partial alias name string search, followed by a partial primitive name string search. If the relay finds no match, the screen displays an error message and stays in the ELEMENT SEARCH screen. If the relay finds a match, the screen displays the element row containing the matching element.

Local Control

The relay provides great flexibility in power system control through the LOCAL CONTROL menus. You can use the front-panel LOCAL CONTROL menus to perform these relay functions:

- Trip and close circuit breakers (password required)
- Assert, deassert, and pulse relay control outputs to command station control actions
- Test relay outputs (password required)

In the first LOCAL CONTROL submenu of *Figure 4.25*, you can choose BREAKER CONTROL, LOCAL BITS CONTROL, or OUTPUT TESTING. You must install the circuit breaker control enable jumper to enable circuit breaker control and output testing capability. The submenu will not display the --BREAKER CONTROL-- option and the --OUTPUT TESTING-- option if the breaker jumper is not installed. (The relay checks the status of the breaker jumper whenever you activate the front-panel settings and at power-up.) If the breaker jumper is not installed, and there are no local bits enabled, the relay displays an information message when you attempt to enter LOCAL CONTROL and the screen returns to the MAIN MENU after a short delay.

Local bit names that you have programmed (see *Example 4.4*) appear in the local control bit names field between --BREAKER CONTROL-- and --OUTPUT TESTING--, as shown in *Figure 4.25*. Use the **Up Arrow** and **Down Arrow** pushbuttons to highlight the local control action you want to perform. Pressing **ENT** takes you to the specific LOCAL CONTROL screen.

```
LOCAL CONTROL
--BREAKER CONTROL--
Enable Bus Switching
North Bus MOD
South Bus MOD
Bus Tie Interlock
Alternate Settings 3
--OUTPUT TESTING--
```

Figure 4.25 LOCAL CONTROL Initial Menu

Breaker Control

The BREAKER CONTROL option presents a circuit breaker selection submenu if the relay is configured to control multiple breakers. Use the navigation pushbuttons and **ENT** to select the circuit breaker you want to control.

Figure 4.26 shows the BREAKER CONTROL submenu and sample circuit breaker control screens for BREAKER 1. Use the **Up Arrow** and **Down Arrow** pushbuttons to highlight the TRIP BREAKER 1 or CLOSE BREAKER 1 control actions.

When you highlight the trip option and press **ENT**, the relay displays the confirmation message OPEN COMMAND ISSUED and trips Circuit Breaker 1 (Relay Word bit OC1 pulses). The BREAKER 1 STATUS changes to OPEN.

When you highlight the close option and press **ENT**, the relay displays the confirmation message CLOSE COMMAND ISSUED and closes Circuit Breaker 1 (Relay Word bit CC1 pulses). The BREAKER 1 STATUS changes to CLOSED. (Be aware that not all SEL-451 relays support breaker close operations.)

Figure 4.26 Example BREAKER CONTROL Screens

Local Control Bits

NOTE: The SEL-487E supports 96 local bits.

NOTE: The default settings for LB_SPnn are "1". The default settings satisfy the local bit supervision logic so that local bit operations can take place.

NOTE: The default settings for LB_DPnn are LBnn. The default settings cause the local bit switch to move to the corresponding state of the local bit (asserted = 1, deasserted = 0).

The relay provides 64 local control bits with SELOGIC control equation supervision. These local bits replace substation control handles to perform switching functions such as bus transfer switching. The relay saves the states of the local bits in nonvolatile memory and restores the local bit states at relay power-up.

Local control bit supervision is available through a SELOGIC control equation provided in the Front Panel settings (LB_SP*nn*). For local bit operations to take place, the corresponding LB_SP*nn* must be asserted. *Table 4.8* defines the local bit SELOGIC settings available in the Front Panel settings class. *Figure 4.28* illustrates the logic that supervises all local bit operations (Set, Clear, Pulse).

The SELOGIC control equation local bit status (LB_DP*nn*) is provided to return the status of a device that is being controlled by the local bit. The LB_DP*nn* Relay Word bit drives the state of the graphical switch on the display (i.e., with LB_DP*nn* deasserted, the switch points to 0).

Any unused local control bits default to the clear (logical 0) state. Also, any reconfigured local bit retains the existing bit state after you change the bit setting. Deleting a local bit sets that bit to the clear (logical 0) state.

In the top part of *Figure 4.27*, the following custom-labeled functions are those controlled by local control bit operation.

- Enable Bus Switching
- North Bus MOD
- South bus MOD
- Bus Tie Interlock
- Alternate Settings 3

In addition, *Figure 4.27* gives an example of a custom labeled function, Bus Tie Interlock. The LCD shows a graphic representation of a substation control handle. The LB_DP*nn* SELOGIC control equation determines the state of the switch position on the LCD. If the LB_DP*nn* Relay Word bit is deasserted, the graphic control handle points to 0; if the LB_DP*nn* Relay Word bit is asserted, the switch points to 1.

You can program names or aliases for the local bit clear and set states—these appear next to logical 0 and logical 1, respectively, in the lower portion of the sample Bus Tie Interlock screens of *Figure 4.27*. Use the **Up Arrow** and **Down Arrow** pushbuttons to highlight the set (1) or clear (0) control actions. Highlighting the set option (shown in *Figure 4.27* as `Closed (OK to TIE)`) and pressing **ENT** changes the local control bit and performs the required control action. If the LB_DP*nn* Relay Word bit asserts, the graphical switch moves to 1 to indicate the asserted local bit status.

Figure 4.27 LOCAL CONTROL Example Menus

To enable a local bit, enter the local bit settings in *Table 4.7*. The format for entering the local bit data is the comma-delimited string:

local bit,control function name,alias for the set state,alias for the clear state,pulse enable

Names or aliases can contain any printable ASCII character except double quotation marks. Use double quotation marks to enclose the name or alias. See *Example 4.4* for particular information on enabling a local control bit.

NOTE: The SEL-487E supports 96 local bits.

Table 4.7 Local Bit Control Settings[a]

Description	Range	Default
Local Bit *n*	1–64	1
Local Bit *n* Name	20-character maximum ASCII string	(blank)
Local Bit *n* Set Alias (1 state)	20-character maximum ASCII string	(blank)
Local Bit *n* Clear Alias (0 state)	20-character maximum ASCII string	(blank)
Pulse Local Bit *n*	Y, N	N

[a] n = 1–64.

The pulse state enable setting at the end of the setting string is optional. If your application requires a pulsed or momentary output, you can activate an output pulse by setting the option at the end of the local bit command string to Y (for Yes). The default for the pulse state is N (for No); if you do not specify Y, the local bit defaults at N and gives a continuous set or clear switch level.

If you enter an invalid setting, the relay displays an error message prompting you to correct your input. If you do not enter a valid local bit number, the relay displays A local bit element must be entered. If you enter a local bit number and that local bit is already in use, the relay displays the local bit element is already in use. Likewise, if you do not enter valid local bit name, set alias, and clear alias, the relay returns an error message. If an alias is too long, the relay displays the message `Too many characters`.

Table 4.8 Local Bit SELOGIC[a]

Description	Range	Default
Local Bit Supervision *n*	SELOGIC Control Equation, NA	1
Local Bit Status Display *n*	SELOGIC Control Equation, NA	LB*n*

[a] n = 1–64, and only available if the corresponding local bit is defined.

The Local Bit Supervision SELOGIC control equation provides supervision of Local Bit Set, Clear, and Pulse operations.

The Local Bit Status Display SELOGIC control equation returns the status of the local bit switch state.

Figure 4.28 Local Bit Supervision Logic

Example 4.4 Enabling Local Bit Control

This application example demonstrates a method to create one of the control points in the LOCAL CONTROL screens of *Figure 4.27* to control the interlock on a power bus tie circuit breaker. Perform the following actions to create a local control bit:

- Eliminate previous usage of the local bit and condition the state of the local bit
- Set the local bit
- Assign the local bit to a relay output

If you are using a previously used local bit, delete all references to the local bit from the SELOGIC control equations already programmed in the relay. A good safety practice would be to disconnect any relay output that was programmed to that local bit.

To change the local bit state, select the bit and set it to the state you want. In addition, you can delete the local bit, which changes the state of this local bit to logical 0 when you save the settings. To delete, use the front-panel settings. When using a communications port and terminal, use the text-edit mode line setting editing commands at the Local Bits and Aliases prompt to go to the line that lists Local Bit 9. (See *Text-Edit Mode Line Editing on page 3.23* for information on text-edit mode line editing.) To delete Local Bit 9, type **DELETE <Enter>** after the line that displays Local Bit 9 information. For example, if a previously programmed Local Bit 9 appears in the **SET F** line numbered listings on Line 1, then typing **DELETE <Enter>** at Line 1 deletes Local Bit 9.

Next, set the local bit. In the Front Panel settings (SET F), enter the following:

1: **LB09,"Bus Tie Interlock","Closed (OK to TIE)","Open (No TIE)",N**

This sets Local Bit 9 to "Bus Tie Interlock" with the set state as "Closed (OK to TIE)" and the clear state as "Open (No TIE)."

Assign the local bit to a relay output. In the Output settings (**SET O**), set the SELOGIC control equation, OUT201, to respond to Local Bit 9.

OUT201 := **LB09**

Use the appropriate interface hardware to connect the circuit breaker interlock to OUT201.

Output Testing

NOTE: The circuit breaker control enable jumper BREAKER must be installed to perform output testing.

You can check for proper operation of the relay control outputs by using the OUTPUT TESTING submenu of the LOCAL CONTROL menu. A menu screen similar to *Figure 4.29* displays a list of the control outputs available in your relay configuration.

Figure 4.29 OUTPUT TESTING Screen

Set/Show

You can use the SET/SHOW menus to examine or modify relay port settings, Global settings, active Group settings, and date/time. See *Table 4.9* for a list of settings classes and settings that you can change from the front panel.

Table 4.9 Settings Available From the Front Panel

Class/Setting	Description
PORT	Relay communications port settings
GLOBAL	Global relay settings
GROUP	Relay Group settings
ACTIVE GROUP	Active settings group number 1–6
DATE/TIME	Date and time settings

Figure 4.30 shows an example of entering the SEL-451 setting CTRW (Terminal W CT ratio) from the front panel. At the MAIN MENU, select the SET/SHOW item and press **ENT**. The LCD screen displays the SET/SHOW screen as shown in *Figure 4.30*. You can use the navigation pushbuttons to select the relay settings class (PORT, GROUP, and GLOBAL) or to change the ACTIVE GROUP or the DATE/TIME. For this example, select the GROUP class.

Next, select the particular instance of the settings class. For the PORT settings class, the instances are PORT 1, PORT 2, PORT 3, PORT F, and PORT 5. For the GROUP class, the instances are the numbered groups from 1 through 6 and M, the breaker monitor (see the GROUP screen in *Figure 4.30*). The class GLOBAL, the setting ACTIVE GROUP = n (where *n* is a number from 1 to 6), and the settings for DATE/TIME have no settings instance screens. In the GROUP screen, move the highlight box to 3 and press **ENT**.

Proceed to selecting the settings category. The GROUP submenu in *Figure 4.30* is an example of settings Group 3 categories. Once you have highlighted the settings category, pressing **ENT** causes the relay to display the particular settings in that category. The LINE CONFIGURATION screen in *Figure 4.30* shows the settings that you can set in the line configuration settings category.

To edit or examine a setting, use the **Up Arrow** and **Down Arrow** pushbuttons to highlight that setting, then press **ENT**. The relay displays a settings entry screen with the existing setting value (see the SET CTRW screen in *Figure 4.30*). If the prompt for the selected setting does not fit on the line, the relay scrolls the setting prompt across the screen.

Enter the setting name by using a method similar to the method described in *Relay Elements (Relay Word Bits) on page 4.19*. Place characters in the element name field (with the block cursor) by using the navigation pushbuttons.

For the SEL-411L, SEL-421, SEL-451, and SEL-487E, if you are setting an element that supports combinations, and the number of possible combinations is small, the relay displays the possible combinations allowed for the setting that you can select. If there is a high number of possible combinations for a setting, a window of selectable ASCII characters displays (see the **Character or String or SELOGIC control equations** display in *Figure 4.31*), and you will need to input the necessary combination by using the ASCII character display.

If the data you entered are valid (within settings range checks), the front-panel display returns to the settings category screen that shows each setting and corresponding present value (see the LINE CONFIGURATION screen of *Figure 4.30*). If

the data you entered are invalid, the relay displays an error message screen, then returns to the particular settings entry screen so you can attempt a valid settings entry (see the `CTRW` screen of *Figure 4.30*).

When finished entering the new settings data, press **ESC**. The relay prompts you with a `Save Settings` screen. Using the navigation pushbuttons, answer `YES` to make the settings change(s), or `NO` to abort the settings change(s).

Figure 4.30 Example SET/SHOW Screens

The relay displays different settings entry screens depending on the settings type. For the CTRW setting in *Figure 4.30*, the relay requires basic alphanumeric input. Other settings can have other data input requirements. The front-panel settings input data types are the following:

- Basic alphanumeric
- Character or string or SELOGIC control equations
- Setting options

For alphanumeric settings, the relay presents the character or string input screen. Some settings have specific options; use the setting options screens to select these options. *Figure 4.31* shows examples of the settings input screens.

Basic Alphanumeric | Character or String or SELOGIC Control Equations | Setting Options

Figure 4.31 Sample Settings Input Screens

Active Group

Perform the following steps to change the active setting group:

Step 1. Select the ACTIVE GROUP option of the SET/SHOW submenu screen (shown in *Figure 4.30*) to change the settings group.

The relay performs a password validation test at this point to confirm that you have Breaker Access Level authorization or above.

Step 2. If access is allowed, and all the results of SELOGIC control equations SS1–SS6 are not logical 1 (asserted), then the relay displays the EDIT ACTIVE GROUP screen in *Figure 4.32*.

The relay shows the active group and underlines the group number after NEW GROUP =.

Step 3. Use the **Up Arrow** and **Down Arrow** pushbuttons to increase or decrease the NEW GROUP number.

Step 4. Once you have selected the new active group, press **ENT** to change the relay settings to this new settings group.

Figure 4.32 Changing the ACTIVE GROUP

Date/Time

Another submenu item of the SET/SHOW first screen (*Figure 4.30*) is the DATE/TIME screen shown in *Figure 4.33*. By default, the relay generates date and time information internally; you can also use external high-accuracy time modes with time sources such as a GPS receiver.

Figure 4.33 shows the relay date/time screen when a high-accuracy source is in use. Possible time sources, qqqqq, are listed in *Table 11.6*. If you use a high-accuracy time source, edits are disabled, the DATE/TIME display does not show the highlight, and the screen does not show the help message on the bottom line.

Figure 4.33 DATE/TIME Screen

When no external time source is connected, you can use the front-panel DATE and TIME entry screens to set the date and time.

Figure 4.34 shows an example of these edit screens. Use the **Left Arrow** and **Right Arrow** navigation pushbuttons to move the underscore cursor; use the **Up Arrow** and **Down Arrow** navigation pushbuttons to increment or decrement each date and time digit as appropriate to set the date and time. For a description of the LAST UPDATE SOURCE field, see *Configuring Timekeeping on page 3.64*.

```
DATE   (MM/DD/YYYY)

  03/15/2001
```

```
TIME

  00:00:00
```

Figure 4.34 Edit DATE and Edit TIME Screens

To enable a high-accuracy external time source, connect an IRIG-B or Precision Time Protocol (PTP) clock to the relay. For a discussion of the timing modes in the relay see *Section 11: Time and Date Management*.

Relay Status

The relay performs continuous hardware and software self-checking. If any vital system in the relay approaches a failure condition, the relay issues a status warning. If the relay detects a failure, the relay displays the status failure `RELAY STATUS` screen immediately on the LCD.

For both warning and failure conditions, the relay shows the error message for the system or function that caused the warning or failure condition. You can access the `RELAY STATUS` screen via the `MAIN MENU`. The `RELAY STATUS` screen shows the firmware identification number (FID), serial number, whether the relay is enabled, and any status warnings.

Figure 4.35 shows examples of a normal `RELAY STATUS` screen, a status warning `RELAY STATUS` screen, and a status failure `RELAY STATUS` screen. For more information on status warning and status failure messages, see *Relay Self-Tests on page 10.19*.

```
RELAY STATUS
SEL-421-R101-V0-
Z001001-D20010315

S/N=2001001234
RELAY ENABLED
NO FAILURES OR
WARNINGS
```

Normal

```
RELAY STATUS
SEL-421-R101-V0-
Z001001-D20010315

S/N=2001001234
RELAY ENABLED
TEMPERATURE WARNING
```

Status Warning

```
RELAY STATUS
SEL-421-R101-V0-
Z001001-D20010315

S/N=2001001234
RELAY DISABLED
MASTER OFFSET FAILED
```

Status Failure

Figure 4.35 Relay STATUS Screens

View Configuration

You can use the front panel to view detailed information about the configuration of the firmware and hardware components in the relay. In the `MAIN MENU`, highlight the `VIEW CONFIGURATION` option by using the navigation pushbuttons. A series of screens will be presented describing the relay configuration. See the relay-specific instruction manual to see the specific information provided in that relay.

Display Test

You can use the DISPLAY TEST option of the MAIN MENU to confirm operation of all of the LCD pixels. The LCD screen alternates the on/off state of the display pixels once every time you press **ENT**. *Figure 4.36* shows the resulting two screens. The DISPLAY TEST option also illuminates all of the front-panel LEDs. To exit the test mode, press **ESC**.

NOTE: The LCD DISPLAY TEST does NOT reset the front-panel LED targets.

Figure 4.36 DISPLAY TEST Screens

Reset Access Level

The relay uses various passwords to control access to front-panel functions. As you progress through these menus, the relay detects the existing password level and prompts you for valid passwords before allowing you access to levels greater than Access Level 1 (see *Password on page 4.15*). When you want to return the front-panel to the lowest access level (Access Level 1), highlight RESET ACCESS LEVEL item on the MAIN MENU. Pressing **ENT** momentarily displays the screen of *Figure 4.37* and places the front panel at Access Level 1.

The relay automatically resets the access level to Access Level 1 upon front-panel time-out (setting FP_TO is not set to OFF). Use this feature to reduce the front-panel access level before the time-out occurs.

Figure 4.37 RESET ACCESS LEVEL Screen

One-Line Diagram

Most SEL-400 series relays support one-line diagrams on the front-panel LCD. The ONE-LINE DIAGRAM option from the front-panel MAIN MENU displays the one-line diagram that has been selected in the Bay settings class. From this screen, disconnect switch open and close operations, as well as breaker open and close operations can be performed. This screen also displays labels for the different apparatus in the bay configuration and Analog Quantity metering values. The one-line diagram, display labels, and Analog Quantities are settable in the Bay class settings. See *Figure 4.38* for an illustration of the one-line diagram.

For navigation and control operations in the one-line diagram screen, see *Bay Control Front-Panel Operations on page 5.12*.

Figure 4.38 One-Line Diagram Screen

Front-Panel Automatic Messages

The relay automatically displays alert messages. Any message generated because of an alert condition takes precedence over the normal ROTATING DISPLAY and the MAIN MENU. Alert conditions include these significant events:

- Alarm Point asserts
- Event reports and trips (user-defined)
- Status warnings
- Status failures

To display event reports automatically from the ROTATING DISPLAY, you must set front-panel setting DISP_ER to Y. Front-panel setting TYPE_ER allows the user to define which types of event reports will be automatically displayed from the normal ROTATING DISPLAY; ALL will display all event types defined in the relay, and TRIP will display only the event types that include the assertion of the TRIP Relay Word bit.

For alarm point assertions, qualified event reports (including trip events) and status warnings, the relay displays the corresponding full-screen automatic message, only if the front-panel display is in the time-out or standby condition (the relay is scrolling through the default display points/enabled metering screens of the ROTATING DISPLAY or is displaying the MAIN MENU). When a status warning, alarm, or event is triggered, the relay full-screen presentation is similar to the screens of *Figure 4.39*.

Figure 4.39 Sample Status Warning and Trip EVENT SUMMARY Screens

If you are on site using the relay front panel in menus and screens other than the MAIN MENU and a status warning occurs, an alarm point asserts, or an event report triggers, the relay shows automatic messages at the bottom of the active screen in the message area.

For example, the message area shows RELAY STATUS WARNING for a status warning. *Figure 4.40* is an example of a status warning notification that appears in the message area of a LOCAL CONTROL (local bit) screen. If an alarm point asserts while you are using a front-panel screen, the message area notification reads: ALARM EVENT. If a trip event occurs while you are using a front-panel screen, the message area notification reads RELAY EVENT. When you repeatedly press **ESC** (as if returning to the MAIN MENU) during this warning or trip alert situation, the relay displays the corresponding full-screen automatic message concerning the warning or trip in place of the MAIN MENU. If the front-panel display is at the MAIN MENU and a status warning occurs, the full-screen warning replaces the MAIN MENU. After you view the warning, alarm, or trip screen, pressing **ESC** returns the LCD to the MAIN MENU.

Figure 4.40 Sample Status Warning in the LCD Message Area

For a status failure, the relay immediately displays the full-screen status alert regardless of the present front-panel operating state. The relay displays no further LCD screens until the status failure clears. Should an unlikely status failure event occur, contact your local Technical Service Center or an SEL factory representative (see *Technical Support on page 10.35*).

Operation and Target LEDs

The relay gives you at-a-glance confirmation of relay conditions via operation and target LEDs. These LEDs are located in the middle of the relay front panel. SEL-400 series relays provide either 16 or 24 LEDs depending on ordering option.

You can reprogram all of these indicators except the **ENABLED** and **TRIP** LEDs to reflect other operating conditions than the factory-default programming described in this section. Settings T*n*_LED are SELOGIC control equations that, when asserted during a relay trip event, light the corresponding LED (*n* = 1–24). LED positions are described in parentheses next to each LED in *Figure 4.41*.

Set T*n*LEDL := Y to latch the LEDs during trip events; when you set T*n*LEDL := N, the trip latch supervision has no effect and the LED follows the state of the T*n*_LED SELOGIC control equation. The relay reports these targets in event reports; set the alias name listed in the report (as many as seven characters) by aliasing the T*n*_LED bits with the **SET T** command or with QuickSet. In 12-pushbutton models, the asserted and deasserted colors for the LED are determined with settings T*n*LEDC. Options include red, green, amber, or off. In some SEL-400 series relays, if T*n*LEDL = Y, the relay latches the target on the rising edge of the target bit. In these relays, to cause the bits to latch with trip, modify the equation to include AND R_TRIG TRIP. Refer to the *Target LEDs* section in the relay-specific *Front-Panel Operations* section to determine if the LED latches with the rising edge of TRIP or on the rising edge of T*n*_LED.

After setting the target LEDs, issue the **TAR R** command to reset the target LEDs. For a description of the default LED behavior for a specific relay, see the *Front Panel Operations* section in the relay-specific instruction manual.

Use the slide-in labels to mark the LEDs with custom names. Configurable label templates available to download from selinc.com allow you to customize the front-panel labels.

Figure 4.41 SEL-451 Factory-Default Front-Panel Target Areas (16 or 24 LEDs)

Operational

The **ENABLED** LED indicates that the relay is active. Trip events illuminate the **TRIP** LED. The prominent location of the **TRIP** LED in the top target area helps you recognize a trip event quickly. Program settings EN_LEDC and TR_LEDC to determine the color of the respective LED. Options include red or green.

TARGET RESET and Lamp Test

For a trip event, the relay latches the trip-involved target LEDs. Press the **TARGET RESET** pushbutton to reset the latched target LEDs. When a new trip event occurs and you have not reset the previously latched trip targets, the relay clears the latched targets and displays the new trip targets.

Pressing the **TARGET RESET** pushbutton illuminates all the LEDs. Upon releasing the **TARGET RESET** pushbutton, two possible trip situations can exist: the conditions that caused the relay to trip have cleared, or the trip conditions remain present at the relay inputs. If the trip conditions have cleared, the latched target LEDs turn off. If the trip event conditions remain, the relay re-illuminates the corresponding target LEDs. The **TARGET RESET** pushbutton also removes the trip automatic message displayed on the LCD menu screens if the trip conditions have cleared.

Lamp Test Function With TARGET RESET

The **TARGET RESET** pushbutton also provides a front-panel lamp test. Pressing **TARGET RESET** illuminates all the front-panel LEDs, and these LEDs remain illuminated for as long as you press **TARGET RESET**. The target LEDs return to a normal operational state after you release the **TARGET RESET** pushbutton.

Other Target Reset Options

You can reset the target LEDs with the ASCII command **TAR R**; see *TARGET on page 14.63* for more information.

The **TAR R** command and the TARGET RESET pushbutton also control the TRGTR Relay Word bit, which can be used for other functions. TRGTR is the factory-default setting for the unlatch trip SELOGIC control equation, ULTR, in Group settings.

You can reset the targets from the QuickSet **Control** branch of the HMI tree view. Programming specific conditions in the SELOGIC control equation RST-TRGT is another method to reset the relay targets. Access RSTTRGT in the relay Global settings (**Data Reset Control**); to use RSTTRGT, you must enable data reset control with Global setting EDRSTC := Y.

Front-Panel Operator Control Pushbuttons

The relay front panel features large operator control pushbuttons coupled with amber annunciator LEDs for local control. *Figure 4.42* shows this region of the relay front panel with example factory-default configurable front-panel label text. SEL-400 series relays provide either 8 or 12 pushbuttons depending on the product and ordering option.

Figure 4.42 SEL-451 Default Operator Control Pushbuttons and LEDs (8 or 12 Pushbuttons)

See *Section 4: Front-Panel Operations* of the product-specific instruction manual for a description of the default configuration of operator control pushbuttons and LEDs.

This page intentionally left blank

SECTION 5

Control

The SEL-400 series relays provide many control features, including circuit breaker controls, disconnect controls, remote bit controls, and bay control. This section describes these control capabilities.

- *Circuit Breaker Status and Control on page 5.1*
- *Disconnect Logic on page 5.2*
- *Remote Bits on page 5.12*
- *Bay Control Front-Panel Operations on page 5.12*
- *Bay Control Screens on page 5.29*
- *Customizable Screens on page 5.36*
- *Bay Control Example Application on page 5.37*

See the specific relay instruction manuals to see how many breakers, disconnects, and remote bits are available and to determine whether or not bay control is supported.

To provide reliable detection of pulsed control bits that assert for one protection logic processing interval within automation logic, conditioning is applied to the control bit to extend the momentary assertion through the automation processing interval. This conditioning ensures the reliable detection of control bit (OC*n*, CC*n*, 89OC*m*, 89CC*m*, 89OCM*m*, 89CCM*m*, and RB01–RB64) assertion in automation logic (where *n* and *m* are product-specific designations). Control bits that assert and deassert multiple times within the same automation logic processing interval will be processed as asserting continuously for the entire automation logic processing interval.

Circuit Breaker Status and Control

SEL-400 series relays include circuit breaker status logic for all supported circuit breakers. The circuit breaker status logic uses the 52A_*k* setting (SELOGIC control equation) and open-phase detection logic to determine the state of Circuit Breaker *k*, and declare Circuit Breaker *k* alarm conditions. See *Section 5: Protection Functions* of the product-specific instruction manual for a description of circuit breaker status logic Relay Word bits and circuit breaker status logic diagrams.

SEL-400 series relays support opening and closing breakers. These operations can be controlled via the terminal commands **OPEN** and **CLOSE**, the binary terminal Fast Operate messages, various supported communications protocols, the front-panel menus, and through the bay control one-line screens. These controls operate the open control (OC*k*) and close control (CC*k*) bits. These bits are used in the relay trip and close logic to integrate these external controls with the relay automatic trip and close behavior. See *Section 6: Protection Application Examples* in the product-specific instruction manual for more information on the trip and close logic.

Disconnect Logic

Disconnect Switch Close and Open Control Logic

NOTE: Disconnect logic is processed four times per power cycle for all products except the SEL-400G. The SEL-400G processes disconnect logic at a rate of 5 ms.

Figure 5.1 and *Figure 5.2* shows the Disconnect Logic that generates open and close output signals necessary to perform the open and close disconnect operations. Use the seal-in timers (89CST*m* and 89OST*m*) to monitor and control disconnect operations. All disconnect control methods (HMI, ASCII, SELOGIC control equations, and Fast Operate) drive the Close and Open Control Logic in the relay.

Figure 5.1 Disconnect Switch Close Logic

Figure 5.2 Disconnect Switch Open Logic

Disconnect Switch Close and Open Control Logic Status Inputs

89CLSm, 89OPEm

Disconnect Switch Close Logic (*Figure 5.1*) and Open Logic (*Figure 5.2*) generate Relay Word bits 89CLS*m* and 89OPE*m,* which drive the open and close operations. To ensure that an open and close disconnect signal cannot occur at the same time, 89CLS*m* and 89OPE*m* also block operation of the opposing logic. Therefore, Relay Word bit 89CLS*m* is an input to the Disconnect Open Logic, and Relay Word bit 89OPE*m* is an input to the Disconnect Close Logic.

89CBLm, 89OBLm

The 89CBL*m* and 89OBL*m* SELOGIC control equations provide an alternative customizable method for blocking the initiation of a disconnect switch open or close command, respectively.

89CRSm, 89ORSm

The 89CRS*m* and 89ORS*m* SELOGIC control equations provide the flexibility to select the signals that reset the close (89CLS*m*) or open (89OPE*m*) outputs. 89CRS*m* defaults to (89CL*m* OR 89CSI*m*), and 89ORS*m* defaults to (89OPN*m* OR 89OSI*m*).

89CSIm, 89OSIm

Set 89CST*m* and 89OST*m* to seal in the open and close signals for each individual installation. Relay Word bits 89CSI*m* and 89OSI*m* are the outputs of the close and open seal-in timers, and assert after the appropriate timers expire. By default, 89CSI*m* and 89OSI*m* are used in the 89CRS*m* and 89ORS*m* SELOGIC control equations to reset the close and open signals, 89CLS*m* and 89OPE*m*, that drive the disconnect switch motor.

89CLm, 89OPNm

The 89CL*m* and 89OPN*m* Relay Word bits report the state of the disconnect switches. If the disconnect switch is closed, Relay Word bit 89CL*m* is asserted; if the disconnect switch is open, Relay Word bit 89OPN*m* is asserted. See *Figure 5.3* for a description of these inputs. With the default settings, when Relay Word bit 89CL*m* asserts, the close seal-in circuit is blocked, causing 89CLS*m* to deassert. Likewise, with the default settings, when Relay Word bit 89OPN*m* asserts, the open seal-in circuit is blocked, causing 89OPE*m* to deassert.

89ALm

The disconnect switch status and alarm logic in *Figure 5.3* generates the 89ALm Relay Word bit. When Relay Word bit 89ALm asserts, it resets the seal-in circuits, deasserting the 89CLS*m*/89OPE*m* signals.

LOCAL

The LOCAL Relay Word bit asserts when LOCAL SELOGIC control equation asserts to a logical 1. When the LOCAL Relay Word bit asserts, only the HMI commands (89CCM*m* and 89OCM*m*), can initiate close and open operations. When the LOCAL Relay Word bit is deasserted, the 89CLOSE, 89OPEN, SELOGIC disconnect close/open, and Fast Operate disconnect close/open commands can perform disconnect close and open operations. The default value for this setting is NA.

Disconnect Switch Close and Open Control Logic Action Inputs

89CCNm, 89OCNm

89CCN*m* and 89OCN*m* SELOGIC control equations are for programmable close and open disconnect switch operations. The LOCAL Relay Word bit must be deasserted for the close or open SELOGIC equations to initiate a disconnect switch operation. Use care when using SELOGIC control equations for disconnect switch operations; this disconnect operate method is not supervised by the breaker jumper or appropriate relay access levels as is the case with other disconnect operation methods.

89CTLm

This SELOGIC control equation identifies Disconnect *m* as controllable (89CTL*m* := 1) or status-only (89CTL*m* := 0). When controllable, all control functionality is available for Disconnect *m*. When status-only, the disconnect is not selectable when navigating the one-line diagram from the relay front-panel HMI. For three-position disconnects, there is a 89CTL*m* setting for each disconnect position.

89CCMm, 89OCMm

89CCM*m* and 89OCM*m* Relay Word bits pulse for one-quarter cycle when close or open disconnect operations are initiated from the one-line diagram on the front-panel screen. If the LOCAL Relay Word bit is not asserted, then Relay Word bits 89CCM*m* or 89OCM*m* cannot assert.

89CCm, 89OCm

The **89CLOSE** command or Fast Operate disconnect close message, pulses Relay Word bit 89CC*m* for one-quarter cycle. The **89OPEN** command or Fast Operate disconnect open message, pulses Relay Word bit 89OC*m* for one-quarter cycle. The LOCAL Relay Word bit must be deasserted for a disconnect switch operation to be initiated by a Fast Operate message or **89CLOSE** and **89OPEN** commands.

Disconnect Seal-In Timer Settings

89CSTm, 89OSTm

89CST*m* and 89OST*m* settings are for defining the time required for the disconnect switch to complete a close or open operation.

Disconnect Switch Close and Open Control Logic Output

89CLSm, 89OPEm

The 89CLS*m* and 89OPE*m* Relay Word bits are used in SELOGIC output equations to perform close and open disconnect switch operations.

Disconnect Switch Close and Open Control Logic Processing

Figure 5.1 shows the Disconnect Switch Close Logic and *Figure 5.2* shows the Disconnect Switch Open Logic.

Some motor-operated disconnect switches have their own seal-in circuits to seal the closing and opening signals in. Other motor-operated disconnect switches, however, require external sealed-in circuits to maintain the closing and opening signals for the duration of the disconnect operation.

⚠CAUTION
The outputs in the relay are not designed to break the coil current in the disconnect motor. An auxiliary contact with adequate current interrupting capacity must clear the coil current in the disconnect motor before the output on the relay opens. Failure to observe this safeguard could result in damage to the relay output contacts.

With SELOGIC control equations 89CRS*m* and 89ORS*m* set to the default settings (include Relay Word bits 89CSI*m* and 89OSI*m*), the open and close signals remain asserted for the time settings of the Close and Open Seal-In Timers, 89CST*m* and 89OST*m*.

If the 89OBL*m* SELOGIC control equation and the 89OPE*m* and the LOCAL Relay Word bits are deasserted, then any of the relay close disconnect operate methods can assert Relay Word bit 89CLS*m*, and initiate the Close Seal-In Timer, 89CST*m*. Enter Relay Word bit 89CLS*m* into a SELOGIC output equation to drive the motor of the disconnect.

Set the Close Seal-In Timer, 89CST*m*, long enough to keep Relay Word bit 89CLS*m* asserted long enough to complete the disconnect operation.

To account for slow operate times because of cold weather or low battery voltage, set the 89CST*m* time 10 to 15 percent longer than the expected operate time. This guarantees that the disconnect switch has fully operated before the 89CLS*m* signal is removed. When the 89CST*m* seal-in timer expires, 89CSI*m* asserts, or the disconnect switch normally open contact closes (89CL*m* asserted), the 89CLS*m* output deasserts. This completes an open-to-close cycle of the Disconnect Close Logic; the Disconnect Open Logic in *Figure 5.2* behaves in the same manner.

Disconnect switch status and alarm logic in *Figure 5.3* generates Relay Word bit 89AL*m*. When Relay Word bit 89ALm asserts, a disconnect alarm condition exists. The 89AL*m* Relay Word bit ensures that the close or open signal does not remain asserted when a disconnect switch alarm condition exists. When Relay Word bit 89AL*m* asserts or the seal-in timer expires, the 89CLS*m* or 89OPE*m* signals deassert.

When a close operation is inadvertently initiated with the disconnect switch already closed, and the 89CRS*m* SELOGIC control equation is set as defaulted (89CL*m* OR 89CSI*m*), the asserted 89CL*m* Relay Word bit (close status) will block the seal-in circuit before the timer expires. This will deassert the 89CLS*m* Relay Word bit, which drives the disconnect switch motor. In this way, 89CLS*m* asserts for only one processing interval.

If an open command was sent within the 89CSI*m* time, an open and close signal could be sent to the disconnect switch at the same time. The 89CLS*m* Relay Word bit input to the Disconnect Switch Open Logic guarantees that open and close commands are not transmitted to the disconnect switch simultaneously. When the 89CLS*m* Relay Word bit deasserts, an open command can be performed. The 89OBL*m* SELOGIC control equation provides an additional customizable method for blocking the initiation of a close command. The Relay Word bit 89OPE*m*, and 89CBL*m* inputs to the Disconnect Switch Close Logic serves the same purpose.

Disconnect Switch Status and Alarm Logic

The disconnect switch auxiliary contacts are inputs to the Disconnect Switch Status and Alarm Logic as shown in *Figure 5.3*. SELOGIC control equation 89AM*m* is the input for the normally open an auxiliary contact, and SELOGIC control equation 89BM*m* is the input for the normally closed Form B auxiliary contact. For the Status and Alarm Logic to function correctly, wire the Form A and Form B contacts each to separate inputs on the relay. When ordering a relay, con-

sider the number of inputs required for the disconnects being controlled. The number of auxiliary contacts for some systems may require that the relay be configured with additional I/O boards.

Disconnect operations are possible with only one auxiliary contact input, but with this implementation the Status and Alarm Logic will not provide accurate Alarm, Operation in Progress, or Bus-zone protection reporting. When only one auxiliary contact is available for input, set one SELOGIC control equation to the available auxiliary contact input and invert the other SELOGIC control equation:

89AM*m* := **IN102**

89BM*m* := **NOT IN102**

Figure 5.3 Disconnect Switch Status and Alarm Logic

Disconnect Switch Status and Alarm Logic Inputs

89AMm, 89BMm

The 89AM*m* and 89BM*m* SELOGIC control equations represent the normally open and normally closed disconnect switch auxiliary contacts. Typically, these are set to relay inputs that are wired to the auxiliary contacts.

89CIMm, 89OIMm

Input 89CIM*m* asserts for expiration of the close immobility timer, while input 89OIM*m* asserts for expiration of the open immobility timer. Timer expiration indicates one of two conditions. The first is that an open-to-close operation of the disconnect switch failed to move the switch enough to open the normally closed auxiliary contact 89BM*m*. The second is that a close-to-open operation of the disconnect switch failed to move the switch sufficiently to open the normally open auxiliary contact 89AM*m*.

Disconnect Switch Status and Alarm Logic Settings

89ALPm

This setting in the Bay settings class defines the disconnect switch alarm time.

Disconnect Switch Status and Alarm Logic Outputs

89ALm

If a disconnect switch operation initiated from the front panel does not complete, the 89ALP*m* timer expires and the 89AL*m* Relay Word bit asserts. Expiration of the 89ALP*m* timer indicates that an initiated disconnect operation failed to complete and the disconnect switch is in an undetermined state. In addition, the 89CST*m* or 89OST*m* timer also expires to deassert the output signal (89CLS*m* or 89OPE*m*), thus ensuring that there is not a constant signal applied to the disconnect.

89OIPm

When Relay Word bit 89OIP*m* asserts, a disconnect switch operation is in progress. Relay Word bit 89OIP asserts when the states of the 89BM*m* and 89AM*m* Relay Word bits are the same, i.e., both asserted or both deasserted.

89CLBm

This Relay Word bit is used for bus-zone protection and asserts when the disconnect is no longer open (89BM*m* deasserted).

89CLm

When Relay Word bit 89CL*m* asserts, the disconnect switch is closed.

89OPNm

When Relay Word bit 89OPN*m* asserts, the disconnect switch is open.

Disconnect Switch Status and Alarm Logic Processing

Figure 5.3 shows the Disconnect Switch Status and Alarm Logic. Inputs to this logic are the normally open (89AM*m*) and normally closed (89BM*m*) disconnect switch auxiliary contacts.

To understand the logic in *Figure 5.3*, consider an open-to-close operation. The first disconnect operation scenario looks at a successful open-to-close disconnect switch operation; a successful close-to-open operation is similar. In the open state, 89AM*m* is deasserted and 89BM*m* is asserted. Once a close command is initiated in the relay, the disconnect switch starts to move and 89BM*m* deasserts. When 89BM*m* deasserts, the 89ALP*m* pickup timer starts to time. With 89BM*m* deasserted, the state of the disconnect switch cannot be determined, because both disconnect switch auxiliary contacts are deasserted. Set the 89ALP*m* timer longer than the expected undetermined disconnect state time, but less than the 89CST*m* or 89OST*m* seal-in timers. If the 89ALP*m* timer expires, the 89AL*m* Relay Word bit asserts. Relay Word bit 89AL*m* asserts when the disconnect operation does not complete successfully. When the 89ALP*m* timer begins timing, the operation in progress, Relay Word bit 89OIP*m*, and Relay Word bit 89CLB*m* assert. The 89CLB*m* Relay Word bit is for bus-zone protection, this bit asserts when the 89BM*m* input deasserts.

During the disconnect switch operation-in-progress condition, Relay Word bits 89CL*m* and 89OPN*m* are both deasserted because the state of the disconnect switch is undetermined. Once the disconnect switch auxiliary contact Relay Word bit 89AM*m* asserts, the condition has been met to declare the disconnect switch closed. When 89AM*m* asserts, the 89CL*m* Relay Word bit asserts,

89ALP*m* stops timing, Relay Word bit 89OIP*m* deasserts, and Relay Word bit 89CLB*m* remains asserted. This sequence completes a successful open-to-close disconnect switch operation.

The second disconnect operation scenario is for an unsuccessful open-to-close operation, which, until 89ALP*m* starts timing, is identical to the successful operation in the previously discussed first scenario.

During operation of the 89ALP*m* timer, the disconnect switch begins moving. The close disconnect switch output signal 89CLS*m* clears upon expiration of the 89CST*m* seal-in timer. The logic then provides the disconnect switch additional time to complete the close operation, in case some inertia from the motor rotor keeps the disconnect motor in motion. By setting the 89ALP*m* timer longer than the 89CST*m* seal-in timer, you can ensure retention of the close signal until the disconnect switch closes completely. If there is no complete disconnect switch operation during the time 89ALP*m* defines, the relay asserts Relay Word bit 89AL*m* and reports that the disconnect switch is in an undetermined state.

The scenario in which both 89AM*m* and 89BM*m* are asserted simultaneously would occur on a rare disconnect switch failure or a short-circuited auxiliary contact wire connection. When this condition occurs for 89ALP*m* seconds, the 89AL*m* alarm status output will assert.

Disconnect Switch Close and Open Immobility Timer Logic

The Close and Open Immobility Timer Logic detects when a disconnect operation failed to initiate.

Figure 5.4 Close Immobility Timer Logic

Figure 5.5 Open Immobility Timer Logic

Close and Open Immobility Timer Logic Inputs

LOCAL

The LOCAL Relay Word bit supervises local disconnect control and is based on the LOCAL SELOGIC control equation in the Bay settings class. Disconnect switch operations from the front panel are possible when the LOCAL Relay Word bit is asserted, in other words, the LOCAL Relay Word bit prevents control from the HMI without proper supervision.

89CBLm, 89OBLm

The 89CBL*m* and 89OBL*m* SELOGIC control equations provide an alternative customizable method for blocking the initiation of a disconnect switch open or close command, respectively.

89CIRm, 89OIRm

The 89CIR*m* and 89OIR*m* SELOGIC control equations provide the flexibility to customize resetting the Close and Open Immobility Timers. By default, 89CIR*m* is set to NOT 89OPN*m*, and 89OIR*m* is set to NOT 89CL*m*.

89CLm, 89OPNm

The 89CL*m* and 89OPN*m* Relay Word bits report the state of the disconnect switches. If the disconnect switch is closed, Relay Word bit 89CL*m* is asserted; if the disconnect switch is open, Relay Word bit 89OPN*m* is asserted. See *Figure 5.3* for a description of these inputs.

Disconnect Switch Close and Open Control Logic Action Inputs

89CCNm, 89OCNm

89CCN*m* and 89OCN*m* SELOGIC control equations are for programmable close and open disconnect switch operations. The LOCAL Relay Word bit must be deasserted for the SELOGIC close or open to initiate a disconnect switch operation. Use care when using SELOGIC control equations for disconnect switch operations; this disconnect operate method is not supervised by the breaker jumper or appropriate relay access levels as is the case with other disconnect operation methods.

89CTLm

This SELOGIC control equation identifies Disconnect *m* as controllable (89CTL*m* := 1) or status-only (89CTL*m* := 0). When controllable, all control functionality is available for Disconnect *m*. When status-only, the disconnect is not selectable when navigating the one-line diagram from the relay front-panel HMI. For three-position disconnects, there is a 89CTL*m* setting for each disconnect position.

89CCMm, 89OCMm

89CCM*m* and 89OCM*m* Relay Word bits pulse for one-quarter cycle when close or open disconnect operations are executed from the one-line diagram on the front-panel screen. The LOCAL Relay Word bit must be asserted, for Relay Word bits 89CCM*m* or 89OCM*m* to assert.

89CCm, 89OCm

The **89CLOSE** command or Fast Operate disconnect close message, pulses Relay Word bit 89CC*m* for one-quarter cycle. The **89OPEN** command or Fast Operate disconnect open message, pulses Relay Word bit 89OC*m* for one-quarter cycle. The LOCAL Relay Word bit must be deasserted for a disconnect switch operation to be initiated by a Fast Operate message or **89CLOSE** and **89OPEN** commands.

Disconnect Switch Close and Open Immobility Timer Logic Settings

89CITm, 89OITm

89CIT*m* and 89OIT*m* timer settings in the Bay settings class define the close and open immobility timers.

Disconnect Switch Close and Open Immobility Timer Logic Outputs

89CIMm, 89OIMm

When 89CIM*m* or 89OIM*m* asserts, the close or open immobility timer has expired.

Disconnect Switch Close and Open Immobility Timer Logic Processing

The Close and the Open Immobility Timer Logic detect when one of the close or open disconnect switch methods does not initiate successfully. In other words, it reports when the disconnect switch failed to start moving. The open and close immobility timer logic circuits are similar. When a close operation is initiated, the rising-edge-triggered Close Immobility Timer starts timing. Once the disconnect switch starts to move away from its open position, Relay Word bit 89OPN*m* deasserts (see *Figure 5.3*). If the 89OPN*m* Relay Word bit deasserts, the close immobility timer resets and 89CIM*m* remains deasserted. On the other hand, if the 89OPN*m* Relay Word bit stays asserted, the close immobility timer does not reset. After the close immobility timer expires, 89CIM*m* asserts for one second. When 89CIM*m* asserts, the close operation is considered to have failed to initiate. 89CIM*m* is an input to the disconnect switch status and alarm logic for alarm condition indications.

This logic also uses the LOCAL Relay Word bit to supervise front-panel operations. With the LOCAL Relay Word bit deasserted, no disconnect operations can be initiated from the one-line diagram. With the LOCAL Relay Word bit asserted, Relay Word bit 89CCM*m* asserts for one-quarter cycle when the **ENT** pushbutton is pressed and a disconnect switch is highlighted in the one-line diagram.

Close, Open, and Undetermined State Indications

This section discusses the way the close and open immobility timers work in conjunction with the disconnect alarm timer to provide disconnect control and alarm indications. When the disconnect switch main contact is stationary (closed or open) the state of the disconnect switch is easily determined.

If the disconnect switch main contact is open:

- Normally closed Form B auxiliary contact (89BM*m* asserted) is closed
- Normally open Form A auxiliary contact (89AM*m* deasserted) is open

If the disconnect switch main contact is closed:

- Normally closed Form B auxiliary contact (89BM*m* deasserted) is open
- Normally open Form A auxiliary contact (89AM*m* asserted) is closed

If an operation of the disconnect switch is in progress, the state of the disconnect switch main contact is undetermined:

- Normally closed Form B auxiliary contact (89BM*m* deasserted) is open
- Normally open Form A auxiliary contact (89AM*m* deasserted) is open

Any undetermined state of the disconnect switch main contact should be monitored. The relay can be configured to wait for the disconnect switch operation to complete, and issue an alarm if the disconnect switch remains in the undetermined state longer than the 89ALP*m* time. *Figure 5.6* illustrates how the state of the auxiliary contacts change for an open-to-close operation in progress and how the 89CST*m*, 89CIT*m*, and 89ALP*m* timers are configured to manage the undetermined time. The close-to-open scenario would be similar.

With the disconnect switch in the open state, the normally closed Form B auxiliary contact is closed (89BM*m* asserted) and the normally open Form A auxiliary contact is open (89AM*m* deasserted). The 89CST*m* seal-in timer starts timing when a disconnect switch close command is issued. The output of the 89CST*m* seal-in timer keeps the close signal asserted for the duration of the expected disconnect switch operate time. Set the seal-in timer 10 to 15 percent longer than the expected disconnect operate time, to allow for slow disconnect operation times caused by cold temperatures or low battery voltages.

Figure 5.6 Disconnect in Transition

When the normally closed auxiliary contact (SELOGIC input 89BM*m*) deasserts, the disconnect switch is in an undetermined state. No proper position indication from either of the disconnect switch auxiliary contacts (89BM*m* or 89AM*m*) is available. Once the auxiliary normally closed contact (SELOGIC input 89BM*m*) deasserts, the 89ALP*m* timer starts timing. The 89ALP*m* timer monitors the undetermined state of the disconnect switch. For the 89ALP*m* timer to initialize, the disconnect switch has to move a minimum distance to open the normally closed auxiliary contact (open-to-close operation). Set the 89ALP*m* timer longer

than the expected undetermined state time, but less than the 89CST*m* seal-in timer. If the normally open auxiliary contact fails to close within the undetermined state time, the 89ALP*m* timer expires and an alarm condition is declared.

The Close Immobility Logic starts the Close Immobility Timer for an operation where the disconnect switch does not move the minimum distance to open the normally closed auxiliary contact (open-to-close operation). When the close immobility timer expires, an alarm condition is declared and Relay Word bit 89AL*m* asserts. If the disconnect moves enough to open the normally closed auxiliary contact, the Close Immobility timer resets and no alarm condition is declared (see *Figure 5.4*).

Remote Bits

Remote bits provide a means for sending remote control commands to relay logic. As indicated in *Table 14.47*, remote bits have three operating states: clear, set, and pulse. It is important to understand the differences between the use of pulsed remote bits in automation and protection SELOGIC control equations. Remote bits can be operated from multiple communications interfaces, including the **CON** command from a terminal (serial or Telnet), Fast Operate messages, and DNP3.

NOTE: The SEL-487E supports 96 remote bits. The SEL-487B supports 96 remote bits and has a processing interval of 1/12 of a power system cycle.

A pulsed remote bit will assert the respective remote bit Relay Word bit (RB*nn*, *nn* = 01–64) for one processing interval (1/8 of a power system cycle). When used in Protection SELOGIC, which also executes at one processing interval, pulsed remote bits provide a momentary means for operating a variety of logic functions, including Protection Latches, Boolean logic expressions, and Protection Logic Counters. Because the pulsed remote bit and Protection processing both operate within the same processing interval, the use of pulsed remote bits is reliable and deterministic.

Bay Control Front-Panel Operations

Each relay has a default one-line diagram. Sometimes these diagrams fit on a single screen and sometimes they require more than one screen that you can pan across. For example, *Figure 5.7* shows the default one-line diagram for the SEL-487E. You can display either of two parts of the diagram by using the **Up Arrow** and **Down Arrow** pushbuttons to pan between an upper screen and a lower screen. The upper screen shows the HV equipment and transformer, while the lower screen shows the transformer and LV equipment. The relay displays the upper screen by default.

NOTE: Not all SEL-400 series relays support bay control operations.

Figure 5.7 SEL-487E Default One-Line Diagram

One-Line Diagram and Labels

Figure 5.8 is an example of a default one-line diagram. The Bay settings class has settings for defining labels and analog quantities. One-line diagrams are comprised of the following:

- Bay Names and Bay Labels
- Busbars and Busbar Labels
- Breakers and Breaker Labels
- Disconnect Switches and Disconnect Switch Labels
- Equipment and Equipment Labels
- Analog Display Points

Figure 5.8 Bay Control One-Line Diagram

Front-Panel Pushbutton Navigation Operations in the One-Line Diagram

Navigation within the one-line diagram requires that the front-panel access level be at Breaker Access Level or higher and the Breaker Jumper be installed. If navigation is attempted when:

- The front panel is not at the Breaker Access Level or higher and passwords are enabled, the relay prompts you to enter the appropriate passwords.
- The Breaker Jumper is not installed, the `Breaker Control Disabled Please Install the Breaker Jumper` message briefly appears on the screen.

Use the arrow pushbuttons on the front panel to navigate within the one-line diagram. When you first select the one-line diagram, none of the apparatus on the one-line diagram are highlighted. Press the **Left Arrow** or **Right Arrow** pushbutton to enter the one-line diagram and highlight the apparatus. Once you enter the one-line diagram, navigation between the disconnect switch and circuit breaker symbols as follows:

- Pressing the **Right Arrow** pushbutton highlights the elements from left-to-right and top-to-bottom.
- When reaching the right-most bottom element, the following **Right Arrow** keystroke "rolls over" and again highlights the left-most top element.
- The **Left Arrow** pushbutton operates in reverse, i.e., from right-to-left, and bottom-to-top.
- Pressing the **ENT** pushbutton selects the highlighted symbol.
- Pressing the **ESC** pushbutton returns you to the previous screen.

Additionally, if the one-line diagram spans multiple screens, you can pan between the portions of the diagram by using the up and down arrows:

- Pressing the **Down Arrow** pushbutton while displaying the top bay control screen, displays the bottom bay control screen.
- Pressing the **Down Arrow** pushbutton while displaying the bottom bay control screen or the **Up Arrow** pushbutton while displaying the top bay control screen, does nothing.
- Pressing the **Up Arrow** pushbutton while displaying the bottom bay control screen displays the top bay control screen.

Circuit Breaker and Disconnect Definitions and State Representations

Table 5.1 shows the apparatus definitions and symbols displayed on the one-line diagram.

Table 5.1 Circuit Breaker and Disconnect Switch Definitions

Circuit Breaker Open	Circuit Breaker Closed	Disconnect Open	Disconnect Closed

NOTE: The intermediate states only apply to disconnect switches because circuit breaker operations have a short duration.

Each apparatus (circuit breaker or disconnect switch) can be in one of the following six states:

- Open, not highlighted
- Open, highlighted

- Closed, not highlighted
- Closed, highlighted
- Intermediate, not highlighted (intermediate = transition between open and closed states)
- Intermediate, highlighted

Table 5.2 describes how the one-line diagram represents the different states of the breakers, and how highlighting the breaker affects the display of the symbol.

Table 5.2 Circuit Breaker State Representations

Apparatus Position	Symbol	Asserted Relay Word Bit
Circuit breaker open, not highlighted		NOT 52CLSM*m*
Circuit breaker open, highlighted[a]		NOT 52CLSM*m*
Circuit breaker closed, not highlighted		52CLSM*m*
Circuit breaker closed, highlighted		52CLSM*m*

[a] When the circuit breaker is highlighted, the two symbols shown alternate in the display.

Table 5.3 describes how the one-line diagram represents the different states of the disconnect switches, and how highlighting the disconnect switch affects the display of the symbol. Unlike the fast operation time of the circuit breaker, the disconnect switch operation-in-progress time is longer than the breaker operation time. *Table 5.3* describes how apparatus appear in the one-line diagram when a disconnect operation is in progress.

Table 5.3 Disconnect Switch State Representations (Sheet 1 of 2)

Apparatus Position	Symbol	Asserted Relay Word Bit
Disconnect open, not highlighted		89OPN*m*
Disconnect closed, not highlighted		89CL*m*
Disconnect open, highlighted[a]		89OPN*m*

Table 5.3 Disconnect Switch State Representations (Sheet 2 of 2)

Apparatus Position	Symbol	Asserted Relay Word Bit
Disconnect closed, highlighted[a]		89CL*m*
Disconnect Operation In Progress, not highlighted[b]		89OIP*m*
Disconnect Operation In Progress, highlighted[c]		89OIP*m*

[a] When the disconnect switch is highlighted and no operation is in progress, a square box alternately frames the switch symbol.

[b] For a disconnect switch operation in progress where the disconnect switch is not highlighted, the symbol displayed is the present state symbol and then the opposite state symbol. This sequence repeats until the disconnect switch operation completes.

[c] For a disconnect switch operation in progress where the disconnect is highlighted, the symbol displayed is the present state symbol, then the present state symbol highlighted, then the opposite state symbol, and finally the opposite state symbol highlighted. This sequence repeats until the disconnect switch operation completes.

The one-line diagram indicates highlighted text with a box around the current selection.

Rack-Type Breaker Mosaics

The SEL-400 series relays support the display of three-position rack-type breakers (also referred to as truck-type breakers) in the bay mimic screens on the front-panel LCD. The three positions, (racked out, test, and racked in) are determined by the combination of the 52*n*RACK and 52*n*TEST bay settings (breaker *n* designation depends on the relay model). Navigate to the Mimic Busbar Layout Screen Number setting under Bay Control in the ACSELERATOR QuickSet SEL-5030 Software to identify mimic screens that contain a rack-type breaker.

Figure 5.9 shows the displayed mosaics based on the combination of the 52*n*RACK and 52*n*TEST settings. For non-rack type breakers, the 52*n*RACK and 52*n*TEST settings do not impact any display and control of the non-rack type breakers.

Figure 5.9 Rack-Type Breaker Mosaics

When 52*n*RACK = 52*n*TEST = 0, as shown in *Figure 5.9(a)*, the racked-out breaker mosaic appears. Because the breaker is racked out, the 52*n*CLSM setting is irrelevant for the purposes of the display. When 52*n*TEST = 1 and 52*n*RACK = 0, as shown in *Figure 5.9(b)*, the breaker is in the test position. In this position, the breaker can either be open or closed, depending on the 52*n*CLSM setting. When 52*n*RACK = 1 and 52*n*TEST = 0, as shown in *Figure 5.9(c)*, the breaker is in the racked-in position. While in the racked-in position, the breaker can be open or closed depending on the 52*n*CLSM setting. When 52*n*RACK = 52*n*TEST = 1, as shown in *Figure 5.9(d)*, the display alternates between the mosaics shown to indicate an indeterminate state for the breaker position because the breaker cannot physically be in both the test and racked-in position at the same time.

For relays that support and are set for single-pole breakers (BK*n*TYP := 1), the rack-type breaker mosaics follow functionality similar to non-rack type breaker mosaics, depending on pole status and the EPOLDIS setting. The breaker must also be in the test or racked-in position; if the breaker is in the racked out position, only *Figure 5.9(a)* appears. If the logic declares a pole discrepancy and EPOLDIS := 1, the one-line diagram follows the same alternating pattern as shown in *Figure 5.9(d)*. When you select the breaker on the front-panel HMI, a pole discrepancy screen appears, showing the state (OPENED or CLOSED) for each pole. If EPOLDIS := 0, the one-line diagram still has the alternating pattern shown in *Figure 5.9(d)*, but the pole discrepancy screen does not appear and only shows `STATUS UNKNOWN` for the status field in *Figure 5.9(b)*.

When in the test or racked-in position, the breaker alarm setting, 52*n*_ALM, is checked. If 52*n*_ALM := 1, the displayed breaker alternates between a closed and open breaker in either the test (*Figure 5.9[b]*) or racked-in (*Figure 5.9[c]*) position regardless of breaker contact state. However, for single-pole breakers, if the logic declares a pole discrepancy, the pole discrepancy screen displays when you select the breaker on the front-panel HMI.

You can access breaker control of available breakers regardless of rack position (racked-in, test, racked-out) and breaker state (open, closed). Some breakers in the one-line diagrams are status-only and are not controllable. See *One-Line Diagrams* in *Section 4: Front-Panel Operations* of the product-specific instruction manuals for information on breakers that have control or status-display-only functionality.

Status-Only Disconnects

The SEL-400 series relays can display status-only disconnects. The Disconnect Front Panel Control Enable setting, 89CTL*n*, (see *Section 11: Relay Word Bits* in the product-specific instruction manuals for the number of supported disconnects) applies to both two- and three-position disconnects in the HMI one-line diagram, and it determines whether a selected disconnect can be controlled from the front-panel HMI (89CTL*n* := 1) or cannot (89CTL*n* := 0 or NA). The 89CTL*n* setting differs from the LOCAL setting in that the LOCAL setting is a global local control enable setting and 89CTL*n* is a control enable setting on a per-disconnect level. The LOCAL setting has priority over the 89CTL*n* setting.

The default setting of 89CTL*n* := 1 allows for disconnect control and maintains disconnect front-panel control functionality after a relay firmware upgrade (even when upgrading from a firmware that does not support status-only disconnects). When 89CTL*n* := 1, the relay follows the control functionality outlined in this section. When 89CTLn := 0 or NA, you cannot select the specified disconnect when you are navigating the one-line diagram from the relay front-panel HMI, preventing you from selecting the disconnect for a control function.

Three-position disconnects have a 89CTL*n* disconnect control enable setting for each disconnect position (in-line or ground). The disconnect is selectable for control from the one-line diagram when either 89CTL*n* := 1 and the switch is open, or when either 89CTL*n* := 1 and the switch is closed in the corresponding position to the 89CTL*n* := 1 setting. When in the control window, only control options available based on the 89CTL*n* settings display. For example, if the disconnect is open, and the ground 89CTL*n* := 0 and the in-line 89CTL*n* := 1, the only control option displayed will be to close the in-line disconnect. If the switch is closed to a position whose 89CTL*n* := 0, the switch is not selectable when navigating the one-line diagram. However, should the 89AL*n* Relay Word bit assert for either disconnect position, the disconnect is selectable from the front panel regardless of the 89CTL*n* setting, and a view-only window for the disconnect appears that has no control functions available for the disconnect.

If the corresponding 89CTL*n* disconnect control enable setting transitions from an asserted to a deasserted state while in the control window, the front panel displays `NOT ALLOWED` when you have selected an open or close function.

Circuit Breaker and Disconnect Switch Operations From the Front Panel

Circuit Breaker Open/Close

Figure 5.10 shows the Breaker Control Screens available after pressing the **ENT** pushbutton (`ONELINE` bay control screen), with the circuit breaker highlighted (Only highlighted breakers on the one-line diagram can initiate breaker open or close operations). Pressing the **ENT** pushbutton with the breaker highlighted and the LOCAL Relay Word bit asserted displays the Breaker Control Screen in *Figure 5.10(b)*. If the LOCAL Relay Word bit is not asserted when the **ENT** pushbutton is pressed, the relay displays the screen in *Figure 5.10(c)* for three seconds and then returns to the screen in *Figure 5.10(a)*.

Figure 5.10 Screens for Circuit Breaker Selection

Single-Pole Tripping

With a single-pole breaker, the individual poles operate independently, and normal operation is for one pole to be open for a short period, while the other two poles are closed. However, it is possible that one (or more) poles may fail to complete a particular operation, resulting in a pole-discrepancy condition. For example, if the breaker is issued a **CLOSE** command, two poles may close but one pole may remain open. If this condition lasts for longer than 1.5 seconds, the HMI displays the pole discrepancy screen shown in *Figure 5.11(c)* so that the operator can immediately identify the offending pole. You can operate the breaker from the pole discrepancy screen after the discrepancy has been rectified. All other screens are the same as when you set the relay to three-pole operations.

Figure 5.11 Screens During a Pole-Discrepancy Condition

Disconnect Switch Open/Close

Figure 5.12(a) shows the Disconnect Control Screens available when you press the **ENT** pushbutton, in ONELINE bay control screen, with the disconnect switch highlighted. If the LOCAL Relay Word bit is asserted and the disconnect switch is highlighted when you press the **ENT** pushbutton, the Disconnect Control Screen in *Figure 5.12(b)* appears. Use the **Up Arrow** and **Down Arrow** pushbuttons to navigate between the disconnect control functions in *Figure 5.12(b)*. If the LOCAL Relay Word bit is not asserted when the **ENT** pushbutton is pressed, the relay displays screen in *Figure 5.12(c)* for three seconds and then returns to the screen in *Figure 5.12(a)*.

Figure 5.12 Screens for Disconnect Switch Selection

Figure 5.13, *Figure 5.14*, and *Figure 5.15* show all the possible screens during an open-to-close operation of Disconnect 1. Operation of the remaining disconnects is identical. Close-to-open operations are similar, the only difference being that the open Relay Word bits apply instead of the close Relay Word bits. The screen in *Figure 5.13(a)* is displayed after you press the **ENT** pushbutton with Disconnect 1 open and highlighted in the one-line diagram.

When you enter the disconnect screen in *Figure 5.13(a)*, the state that the disconnect switch is in is highlighted, in other words, if Relay Word bit 89OPN1 is asserted, the `OPEN DISCONNECT` text has a box drawn around it.

To close the disconnect switch, use the **Up Arrow** or **Down Arrow** pushbutton to highlight the `CLOSE DISCONNECT` text.

If Relay Word bit 89CCM1 asserts after you press the **ENT** key, the relay displays the screen with the caption `CLOSE COMMAND ISSUED` in *Figure 5.13(c)* for three seconds. While the disconnect operation is in progress, the relay displays the screen with the caption `IN PROGRESS` in *Figure 5.14(a)* and the disconnect symbol alternately displays the present state symbol and the opposite state symbol. If another disconnect operation attempt is made while a disconnect operation is in

progress, the relay displays the screen with the caption `*NOT ALLOWED*` in *Figure 5.14(b)* for three seconds and then the relay returns to the screen in *Figure 5.14(a)*.

If Relay Word bit 89CCM1 does not assert, the relay displays the `*NOT ALLOWED*` error message shown in *Figure 5.13(d)* for three seconds and then displays again the screen in *Figure 5.13(b)*.

When Relay Word bit 89CCMD1 asserts, the Close Immobility Timer starts. If Relay Word bit 89CCMD1 asserts, two scenarios are possible: the disconnect fails to close, or the disconnect closes successfully. In the case of a successful close operation, the relay displays the screen in *Figure 5.15(b)*.

Failing to close also has two possible scenarios: the disconnect starts to move, but does not complete the operation, or the disconnect switch operation does not initiate.

When Relay Word bit 89OPN1 deasserts, the Close Immobility timer resets, indicating that the disconnect switch has started to move. If Relay Word bit 89CL1 fails to assert in the expected operation time, the disconnect switch has failed to complete the close operation in the expected time. Failure of the 89CL1 Relay Word bit to assert in the expected disconnect switch operation time causes the 89AL1 Relay Word bit to assert. When Relay Word bit 89AL1 asserts, the relay displays the screen *Figure 5.15(a)* (see *Disconnect Switch Status and Alarm Logic on page 5.5*).

If Relay Word bit 89OPN1 fails to deassert before the Close Immobility Timer expires, Relay Word bit 89ICM1 asserts and the relay displays the screen with the caption `STATUS UNKNOWN` in *Figure 5.15(a)*. See *Disconnect Switch Close and Open Immobility Timer Logic on page 5.8* for more information regarding the close and open immobility timer logic.

When the disconnect operation completes successfully, the relay displays the screen in *Figure 5.15(b)* until the front-panel timer times out or the **ESC** pushbutton is pressed.

Figure 5.13 HMI Disconnect Operation Initiation

Figure 5.14 HMI Disconnect Operation in Progress

When you initially enter the Disconnect Control Screen, the disconnect switch is in one of four states: disconnect open (89OPN*m*), disconnect closed (89CL*m*), disconnect undetermined without alarm (89OIP*m*), or disconnect undetermined with alarm (89AL*m*). If Relay Word bit 89OIP*m* is asserted, the relay displays the screen in *Figure 5.14(a)*; if Relay Word bit 89AL*m* is asserted, the relay displays the screen in *Figure 5.15(a)*. If both Relay Word bits 89OIP*m* and 89AL*m* are asserted, Relay Word bit 89AL*m* takes priority. If Relay Word bit 89OPN*m* is asserted, the relay displays the screen in *Figure 5.13(a)*. This is the initial screen for an open-to-close operation. If Relay Word bit 89CL*m* is asserted, the relay displays the screen in *Figure 5.15(b)*. This is the initial screen for a close-to-open operation.

(a) Disconnect Control Screen (b) Disconnect Control Screen

Figure 5.15 HMI Disconnect Operation Completed

Three-Position Disconnect State Representation and Operations From the Front Panel

A three-position disconnect switch consists of two standard disconnects that operate together to form a three-position disconnect. All logic diagrams of the standard disconnect apply to the three-position disconnect, including all settings and Relay Word bits associated with the two individual disconnects. The three-position disconnect has two labels, one for the in-line branch and one for the ground (perpendicular) branch. In the example shown in *Figure 5.16*, the three-position disconnect is made up of Disconnect SW3 and Disconnect SW4. As with the standard disconnect, be sure to correlate the disconnect wiring and settings with the disconnects assigned to the three-position disconnect image on the one-line diagram.

Figure 5.16 Bay Control One-Line Diagram With Three-Position Disconnect Open

Table 5.4 displays how the bay screen one-line diagram represents the different states of the three-position disconnect switch.

Table 5.4 Three-Position Disconnect Switch State Representations

Apparatus Position	Symbol	Asserted Relay Word Bits
Both disconnects open		89OPN3 and 89OPN4
Disconnect 3 (in-line) closed Disconnect 4 (ground) opened		89CL3 and 89OPN4
Disconnect 3 (in-line) opened Disconnect 4 (ground) closed		89OPN3 and 89CL4
Disconnect 3 (in-line) intermediate[a] Disconnect 4 (ground) opened	[b]	(89OIP3 or 89AL3) and 89OPN4
Disconnect 3 (in-line) opened Disconnect 4 (ground) intermediate[a]	[b]	89OPN3 and (89OIP4 or 89AL4)
All other status combinations Disconnect 3 closed, Disconnect 4 closed Disconnect 3 closed, Disconnect 4 intermediate[a] Disconnect 3 intermediate[a], Disconnect 4 closed Disconnect 3 intermediate[a], Disconnect 4 intermediate[a]	[b]	89CL3 and 89CL4 89CL3 and (89OIP4 or 89AL4) (89OIP3 or 89AL3) and 89CL4 (89OIP3 or 89AL3) and (89OIP4 or 89AL4)

[a] Intermediate = transition between open and closed states.
[b] The image alternates between the two symbols shown.

Similar to the standard disconnect, if a three-position disconnect is highlighted on the one-line diagram and the **ENT** pushbutton is pressed, a control screen is displayed. The control screen shows the present status of the disconnect based on the disconnect status bits (89CL*m*, 89OPN*m*, 89OIP*m*, and 89AL*m*) from both disconnects that make up the three-position disconnect. The status is shown via the disconnect symbol and the status labels as shown in *Figure 5.17(a)*.

Figure 5.17(a) shows the control screen of a three-position disconnect with both disconnects in the open state. *Figure 5.17(b)* shows the control screen of a three-position disconnect with the in-line disconnect closed and the ground disconnect open. Likewise, *Figure 5.17(c)* shows the control screen of a three-position disconnect with the in-line disconnect open and the ground disconnect closed.

(a) Three-Position Disconnect Open

(b) Three-Position Disconnect Closed In-Line

(c) Three-Position Disconnect Closed to Ground

Figure 5.17 Three-Position Disconnect Control Screens

The three-position disconnect logic is identical to two standard disconnects, but control actions are limited as shown in *Table 5.5*. A control action is only available if the disconnect name is listed next to the action as indicated in the Control Options Displayed column. For example, in the second set of control actions, where Disconnect SW3 is closed and Disconnect SW4 is open, the only control actions available are to open or close Disconnect SW3. *Figure 5.17(b)* shows the control screen for this condition.

Table 5.5 Three-Position Disconnect Switch Control Screen Status and Control Options (Sheet 1 of 2)

State of Disconnects	Status Displayed	Control Options Displayed	Control Actions Available
Disconnect SW3: Open Disconnect SW4: Open	OPENED SW3 OPENED SW4	CLOSE SW3 OPEN[a] CLOSE SW4	CLOSE SW3 NO OPEN CONTROL CLOSE SW4
Disconnect SW3: Closed Disconnect SW4: Open	CLOSED SW3 OPENED SW4	CLOSE SW3[b] OPEN SW3 CLOSE	CLOSE SW3 OPEN SW3 NO CONTROL for SW4
Disconnect SW3: Open Disconnect SW4: Closed	OPENED SW3 CLOSED SW4	CLOSE OPEN SW4 CLOSE SW4[c]	NO CONTROL for SW3 OPEN SW4 CLOSE SW4
Disconnect SW3: Open Disconnect SW4: Alarm	OPENED SW3 UNKNOWN SW4	CLOSE OPEN CLOSE	NO CONTROL for either disconnect

Table 5.5 Three-Position Disconnect Switch Control Screen Status and Control Options (Sheet 2 of 2)

State of Disconnects	Status Displayed	Control Options Displayed	Control Actions Available
Disconnect SW3: Alarm Disconnect SW4: Open	UNKNOWN SW3 OPENED SW4	CLOSE OPEN CLOSE	NO CONTROL for either disconnect
Disconnect SW3: Closed Disconnect SW4: Alarm	CLOSED SW3 UNKNOWN SW4	CLOSE OPEN CLOSE	NO CONTROL for either disconnect
Disconnect SW3: Alarm Disconnect SW4: Closed	UNKNOWN SW3 CLOSED SW4	CLOSE OPEN CLOSE	NO CONTROL for either disconnect
Disconnect SW3: Closed Disconnect SW4: Closed	CLOSED SW3 CLOSED SW4	CLOSE OPEN CLOSE	NO CONTROL for either disconnect
Disconnect SW3: Alarm Disconnect SW4: Alarm	UNKNOWN SW3 UNKNOWN SW4	CLOSE OPEN CLOSE	NO CONTROL for either disconnect

[a] See Figure 5.17(a).
[b] See Figure 5.17(b).
[c] See Figure 5.17(c).

The following example shows the process of changing a three-position disconnect from closed in-line to closed to ground. This process requires that you first open the in-line disconnect before you can close the ground disconnect.

Starting with the one-line diagram in *Figure 5.18*, highlight the three-position disconnect and press the **ENT** pushbutton. If the LOCAL Relay Word bit is asserted, the control screen shown in *Figure 5.17(b)* is displayed on the screen. Note that the only options at this point are to open or close Disconnect SW3. Therefore, use the **Up Arrow** or **Down Arrow** pushbutton to move the highlight box to the OPEN SW3 position. Then press the **ENT** pushbutton to open Disconnect SW3. If Disconnect SW3 successfully opens, the control screen will change as shown in *Figure 5.17(a)*. Note that the control actions changed so that Disconnect SW4 can now be closed. At this point, use the **Up Arrow** or **Down Arrow** pushbutton to move the highlight box to the `CLOSE SW4` position and press the **ENT** pushbutton to close Disconnect SW4. If Disconnect SW4 is successfully closed, the control screen will change as show in *Figure 5.17(c)*.

Figure 5.18 Bay Control One-Line Diagram With Three-Position Disconnect Closed In-Line

The relay does not include any default bay mimic screens with three-position disconnects. Should your application require different bay mimic screens with three-position disconnects, contact SEL.

Bay Control Screens

QuickSet and SEL Grid Configurator provide an easy and intuitive way to configure and set the bay control function. The following screenshots show the bay control screens in SEL Grid Configurator; the functionality shown is similar in QuickSet but it does not include the bay screen search tool.

Select the **Bay Control** button from the tree to see the first interactive bay forms in SEL Grid Configurator, as shown in *Figure 5.19*.

Figure 5.19 Interactive Bay Control Setting Form

Use the bay screen mimic diagram lookup tool to find the mimic diagrams applicable to your application by filtering by the number of displayed breakers and disconnections, as shown in *Figure 5.20*.

Figure 5.20 Mimic Diagrams

MIMIC

In most SEL-400 series relays, a single one-line diagram needs to be selected. However, in some relays, such as the SEL-487E, multiple screens need to be selected to build up the total composite one-line diagram.

Bay Name

There are 20 characters available for the bay name. This name appears on all the bay control screens.

Local

The LOCAL SELOGIC control equation enables local and remote control of the disconnect switch. This example illustrates how the input contact IN107 can accommodate existing bay controls that use a key to manually change from remote to local control. The key switch is made to actuate a contact when the key is turned, as shown in *Figure 5.21*. With the contact of the switch wired to the input, the key switch provides local and remote control. Make the following setting to enable LOCAL control when IN107 is asserted.

LOCAL := **IN107**

Figure 5.21 Local and Remote Control Logic With Key Control

Bus Names

Figure 5.22 shows the bay screen settings filter automatically to only display settings associated with the item you selected in your mimic diagram. Enter the name of the busbar (e.g., **132 Bus No 1**), and select **OK**.

Figure 5.22 Setting Busbar Names in SEL Grid Configurator

Disconnect Assignments

To configure disconnects, select the disconnect switch. The settings filter automatically to only show the selected disconnect settings, as shown in *Figure 5.23*.

Figure 5.23 Disconnect Assignment Dialog Box, SW1

D01HMIN

Enter a Disconnect 1 label on the HMI (*Figure 5.23*). The number of characters is limited to a maximum string width of 18 pixels (approximately four characters).

D01CTLN

Enter a Disconnect 1 label on the control screen. Enter a descriptive name (there are 15 characters available) that clearly identifies the disconnect.

89AM01, 89BM01

These SELOGIC control equations report the state of Disconnect 1 auxiliary contacts. Both equations must be programmed for the Disconnect Switch Status and Alarm Logic to function correctly.

89ALP01

This timer counts down when both 89AM01 and 89BM01 are in the same state (both asserted or both deasserted). When this disconnect alarm timer expires, an alarm condition exists and the 89AL01 Relay Word bit asserts.

Set the 89ALP01 timer longer than the expected operation (undetermined state) time, but less than the 89CST01 or 89OST01 seal-in timers.

89CCN01, 89OCN01

These SELOGIC control equations close or open Disconnect 1. Take care when programming these equations, because there is no breaker jumper supervision or access level safeguard in place for this disconnect operate method. These settings only work when the LOCAL Relay Word bit is deasserted.

89CTL01

This SELOGIC control equation identifies Disconnect 1 as controllable (89CTL01 := 1) or status-only (89CTL01 := 0). When controllable, all control functionality is available for Disconnect 1. When status-only, the disconnect is not selectable when navigating the one-line diagram from the relay front-panel HMI. For three-position disconnects, there is a 89CTL*n* setting for each disconnect position.

89CST01, 89OST01

These seal-in timers are intended to keep the close or open signal asserted long enough to allow the Disconnect 1 operation to complete. Set the seal-in timers 10 to 15 percent longer than the expected disconnect operate time to give the disconnect switch time to complete the operation.

Cold weather and low battery voltages can impact disconnect switch operation times. Be sure to consider these conditions when setting the seal-in timers.

89CIT01, 89OIT01

The close/open Disconnect 1 immobility timers are triggered at the same time as the seal-in timers. Expiration of these immobility timers indicates that the Disconnect 1 auxiliary contact status failed to change state within the expected time frame.

Set the immobility timers longer than the expected time for the disconnect to leave the initial state (as reported by the 89AM01 and 89BM01 Relay Word bits), but less than the seal-in timer.

Cold weather and low battery voltages can impact disconnect switch operation times. Be sure to consider these conditions when setting the immobility timers.

89CRS01, 89ORS01

These settings reset the seal-in circuit when either the seal-in timer expires or the intended open/close status signal asserts. This is intended to stop driving the Disconnect 1 motor to close or open when the desired state has been reached.

89CBL01, 89OBL01

These SELOGIC control equations provide an optional custom method for blocking all means of close/open control for Disconnect 1.

89CIR01, 89OIR01

These SELOGIC control equations reset the Disconnect 1 close/open immobility timers.

Breaker Assignments

Configure the breaker by selecting the box next to the breakers. The settings filter automatically, as shown in *Figure 5.24*.

Figure 5.24 Breaker Settings, Breaker S

BKq

In some relays, each numbered breaker (q = 1, 2, 3, 4, or 5) can be assigned to NA or one of the terminals. No terminal can be assigned twice. Unused breaker numbers are forced to NA.

BmHMINM

Enter a Breaker m label on the HMI (one-line diagram). The number of characters is limited to a maximum string width of 17 pixels (approximately four characters).

BmCTLNM

Enter a Breaker m label on the control screen. Enter a descriptive breaker name (as many as 15 characters).

52mCLSM, 52m_ALM

These SELOGIC control equations report breaker close status and breaker alarm status. Any bit in the Relay Word, as well as logical operators, can be programmed into these SELOGIC control equations.

52mRACK, 52mTEST

These SELOGIC control equations modify the display of rack-type breaker mosaics. The settings are shown for both rack-type and non-rack type breakers, but only impact the display of rack-type breakers. The settings do not have any control functionality impact on any breaker. See *Figure 5.9* for settings impact on the rack-type breaker mosaic display.

Analog Display

If analog display points are not required, leave the setting(s) blank, because the relay displays only the defined display points.

Select analog display label `MDELE1` in the interactive one-line diagram to display the form shown in *Figure 5.25*. Select the Expression Builder button to display the form shown in *Figure 5.26*. The Expression Builder helps build the analog quantity setting string. Press the Expression Builder button on the form shown in *Figure 5.26* to find the Analog or Fixed Element to be displayed.

Figure 5.25 Analog Quantity Setting Form

To display fixed text instead of analog quantities, enter the number 1 in the Analog or Fixed Element field.

Figure 5.26 Analog Quantity Setting Form

Select the FREQ System Frequency (see *Figure 5.27*). Enter a Pre-Text, for example 'Frq=', as shown in *Figure 5.27*. Set the numerical display format to 5.2; this displays frequency up to two decimal places. You can scale the numerical value of FREQ to display a scaled value of the analog quantity. For example, a scaling value of 0.5 displays only half the value of FREQ, while a scaling value of 2 displays twice the value of FREQ. Enter text, such as the units of the analog quantity in the Post-Text field. Test the entries by typing a value of 60.51 in the preview analog display field. Select the **Preview** button, and verify that all entries are correct and will fit on the screen.

Figure 5.27 Example of an Analog Quantity Expression

SEL recommends that you use the MDELE*n* expression builder within QuickSet or SEL Grid Configurator when creating these settings. However, if you enter the expression from the ASCII command line, the format of the user input is as follows:

Analog Quantity Label,"Pre-Text = {x.y,z} Post-Text"

where:

x = total number of digits of the number to display (includes number of digits following a decimal point)

y = total number of digits to display following a decimal point

z = scaling factor

For example, if you wanted to display the VAZFM analog quantity with 3 total digits with 1 digit following a decimal point and no scaling, enter the following on the command line:

VAZFM,"VAZ = {3.1,1} V"

The setting value reported in QuickSet or SEL Grid Configurator is expected to be reported differently than what is accepted on the ASCII command line.

Customizable Screens

SEL-400 series relays support custom mimic display screens. Custom mimic display screens are developed by the SEL factory by using your requirements, and then added to the QuickSet relay driver. The following images show the breaker and power system variants supported in custom mimic display screens. For a complete list of mimic display screens available in SEL-400 series relays, see selinc.com/app/mimic-diagram/.

Available Circuit Breakers

Figure 5.28 shows the different types of circuit breakers and disconnects available.

Figure 5.28 Different Types of Circuit Breakers and Disconnects

Available Power System Components

Figure 5.29 shows the different types of power system components available.

Figure 5.29 Power System Components

Bay Control Example Application

This example demonstrates configuring a bay control screen for an SEL-451. Similar configurations can be done with other SEL-400 series relays.

Bus 1, Bus 2, and Transfer BUS Bay With Ground Switch (MIMIC := 4)

Figure 5.30 illustrates the Bus 1, Bus 2, and Transfer Bus Bay with Ground Switch (MIMIC := 4). The Bay configuration used in this example provides five disconnect switches, one breaker, and the ability to display as many as six Analog Quantities. The labels and Analog Quantities shown in *Figure 5.30* are all a result of the settings entered in this example. See *Table 5.6* for a complete list of Bay settings for this application.

Figure 5.30 Illustration of One-Line Diagram After Entering Example Settings

Bay Control Settings

General One-Line Settings

One-Line Diagram

This setting selects the one-line diagram that defines the bay configuration, and it must exactly match the bay configuration being controlled. Failure to select the exact one-line diagram that describes the bay configuration being controlled could result in misapplications.

MIMIC := **4**

Bay Name

Enter a bay name (as many as 20 characters) that defines the bay being controlled.

BAYNAME := **BAY CONTROL**

Bay Label

As many as two bay labels are available in one-line diagrams 14, 17, 18, and 23. BAYLAB1 and BAYLAB2 settings can accept as many as eight characters, depending on the pixel width of the string.

BAYLAB1 or BAYLAB2 are not required because the MIMIC setting selected in this example does not include bay labels. If MIMIC 14, 17, 18, or 23 had been selected, the relay would have prompted for BAYLAB1 and BAYLAB2 settings.

Busbar Information

Bus-Name Labels

Based on the MIMIC setting, the relay provides as many as nine bus-name labels in the one-line diagram. With MIMIC set to 4, the relay requires three bus-name labels, one for the transfer bus, one for Bus 2, and one for Bus 1. The top-most

bus in the one-line diagram is BUSNAM1 and the bottom-most bus in the one-line diagram is the highest number bus available for the selected MIMIC setting, three in this case.

Enter bus-name labels (as many as ten characters) that describe each bus in the one-line diagram.

The actual number of characters accepted depends on the pixel width of the string.

BUSNAM1 := **Bus T**

BUSNAM2 := **Bus 2**

BUSNAM3 := **Bus 1**

Breaker Information

The relay displays breaker information for as many as three breakers. For the bay configuration in this example, the relay displays one. If more breakers were supported, based on the MIMIC setting selected, the settings associated with additional breakers would follow Breaker 1 settings.

Breaker Name Label

Enter a breaker name (as many as six characters) that describes each circuit breaker in the one-line diagram.

The actual number of characters accepted depends on pixel width of the string.

B1HMINM := **Bkr 1**

Breaker Status

This SELOGIC control equation reports breaker close status and breaker alarm status. Any bit in the Relay Word can be programmed into this SELOGIC control equation, as well as logical operators. The equations below return the state of the Bkr 1 status and any Bkr 1 alarm conditions.

521CLSM := **52ACL1**

521_ALM := **52AAL1**

Disconnect Information

The relay provides disconnect switch information for as many as ten disconnect switches. For the bay configuration selected in this example, the relay supports five disconnect switches.

Disconnect Name Label

Enter disconnect labels of as many as six characters in length that describe each disconnect switch in the one-line diagram. The actual number of characters accepted depends on pixel width of the string.

D01HMIN := **Dis 1**

Disconnect Status

Wire the normally open and normally closed auxiliary contacts from the disconnect switch to relay inputs, and program the relay inputs into 89AM01 and 89BM01 SELOGIC control equations. These equations report the state of the disconnect switch auxiliary contacts. Both equations must be programmed for the Disconnect Switch Status and Alarm Logic to function correctly.

89AM01 := **IN103**

89BM01 := **IN104**

Disconnect Alarm Pickup Delay

This setting monitors disconnect open/close operations (the undetermined time) of the disconnect switch. When the disconnect alarm timer expires, an alarm condition exists and the 89AL1 Relay Word bit asserts. Set the 89ALP*m* timer longer than the expected operation (undetermined state) time, but less than the 89CSIT*m* or 89OSIT*m* seal-in timers. The expected disconnect operation time in this example is 250 cycles. 89ALP*m* is entered in cycles and has a range of 1–99999.

89ALP01 := **260**

Disconnect Close/Open Control

Program SELOGIC control equations 89CCN*n* and 89OCN*n* to close or open disconnect switch *n*, respectively. Great care needs to be used when programming these equations because there are no breaker jumper supervision or access level safeguards in place for this disconnect operate method. The settings in this example close the disconnect switch when Remote Bit 1 is set and open the disconnect switch when Remote Bit 1 is cleared. The 89CCN01 SELOGIC example below also includes additional supervision logic where the close operation only operates if Breaker 1 is open (NOT 52CLS1) and the disconnect switch is in the opposite state (89OPN1). When these conditions are met, a close disconnect operation will initiate. Relay Word bit 89CLS1 is the output of the seal-in timer and asserts when Relay Word bit 89CCN01 asserts. Relay Word bit 89OPN1 deasserts as soon as the disconnect switch starts to move. The OR combination of Relay Word bit 89CLS1 and 89OPN1 keeps the close disconnect signal asserted until the disconnect operation has completed. The SELOGIC control equations below demonstrate disconnect lockout control in the relay. The 89OCN01 SELOGIC control equation illustrates the same type of supervision for the disconnect switch open logic.

89CCN01 := **RB01 AND (89OPN1 OR 89CLS1) AND NOT 52CLSM1**

89OCN01 := **NOT RB01 AND (89CL1 OR 89OPEN1) AND NOT 52CLSM1**

Disconnect Front-Panel Control Enable

Program SELOGIC control equation 89CTL*n* to identify a disconnect as controllable (89CTL*n* := 1) or status-only (89CTL*n* := 0). When a disconnect is identified as controllable, the disconnect can be selected when navigating the relay front-panel HMI. When a disconnect is identified as status-only, the disconnect cannot be selected when navigating the relay front-panel HMI. Three-position disconnects have a control equation for each disconnect position. The SELOGIC control equation below identifies the disconnect as controllable.

89CTL01 := **1**

Disconnect Close/Open Seal-in Timers

The seal-in timers assert the close or open signal long enough to allow the disconnect operation to complete. Set the seal-in timer 10 to 15 percent longer than the expected disconnect operate time to give the disconnect switch time to complete the operation. 89CST*m* and 89OST*m* are entered in cycles and have a range of 1–99999. The example shown anticipates a disconnect switch operate time of approximately 250 cycles.

Cold weather and low battery voltages can impact operation times. Be sure to consider these conditions when setting the seal-in timers.

The output contacts must not be used to break the motor coil current. An auxiliary contact with adequate current interrupting capacity must first interrupt current supply to the motor before the relay contact opens. Include the auxiliary contact clearing time when setting the disconnect seal-in timer.

89CST01 := **280**

89OST01 := **280**

Disconnect 2–5

Disconnect switch settings 2–5 are similar to the Disconnect Switch 1 examples above. See *Table 5.6* for a complete list of Bay Class settings for this application.

One-Line Analog Display

One-line diagrams in the relay can contain as many as six Analog Quantity display points. The MIMIC setting selected in this example displays six Analog Display points. See *Display Points on page 4.10* for Display Point programming. The settings below illustrate how to display text and Analog Quantities available in the mimic display. If analog display points are not required to appear in the one-line diagram, leave the setting(s) blank, and the relay will only display the defined display points.

1. 1, “Analogs”
2. IAWM, “IA:(4.0,1)A”
3. VABFM, “V:(3.0,1)kV”
4. FREQ, “F:(4.1,1)Hz”
5. 3P, “P:(3.0,1)MW”
6. 3Q_F, “Q:(3.0,1)MVR”

Control Selection

The LOCAL SELOGIC control equation enables local and remote control of the disconnect switch. This example illustrates how the SEL-451 input contact IN107 can accommodate existing bay controls that use a key to manually change from remote to local control. The key switch is made to actuate a contact when the key is turned, as shown in *Figure 5.31*. With the contact of the switch wired to the SEL-451 input, the key switch provides local and remote control. Make the following setting to enable LOCAL control when IN107 is asserted.

LOCAL := **IN107**

Figure 5.31 Local and Remote Control Logic With Key Control

Front Panel Settings

The one-line diagram is one of the screens that are available for display in the rotating display. To display RMS_V, RMS_I, and ONELINE screens on the rotating display every five seconds, make the following Front Panel settings.

SCROLD := **5**

RMS_V := **Y**

RMS_I := **Y**

RMS_VPP := **N**

RMS_W := **N**

FUNDVAR := **N**

RMS_VA := **N**

RMS_PF := **N**

RMS_BK1 := **N**

RMS_BK2 := **N**

STA_BAT := **N**

FUND_VI := **N**

FUNDSEQ := **N**

FUND_BK := **N**

ONELINE := **Y**

The following settings in the Front Panel settings provide immediate display of the one-line diagram screen when Pushbutton 2 is pressed.

PB2_HMI := **BC**

Output Settings

Output Logic Settings

This illustrates the ability to program disconnect lockout protection for the selected one-line diagram. To eliminate the danger of closing or opening the ground switch on an energized line, the disconnect switch cannot operate unless Breaker 1 is open. When the Disconnect 1 close command is executed (89CLS1),

OUT103 only asserts if the state of Breaker 1 is open (NOT 52CLS1). This illustrates disconnect switch lockout protection through SELOGIC control equations. The SELOGIC control equation for OUT104 below illustrates similar lockout protection for the disconnect switch open operation. Wire OUT103 to the disconnect switch closing circuit and OUT104 to the disconnect switch opening circuit.

OUT103 := **89CLS1 AND NOT 52CLSM1**

OUT104 := **89OPEN1 AND NOT 52CLSM1**

⚠CAUTION
The outputs in the relay are not designed to break the coil current in the disconnect motor. An auxiliary contact with adequate current-interrupting capacity must clear the coil current in the disconnect motor before the output opens. Failure to observe this safeguard could result in damage to the output contacts.

Another example of disconnect lockout would be to ensure that Dis 3 never closes when the ground disconnect switch Dis 5 is closed. Enter the SELOGIC control equation below for Dis 3 switch lockout protection. 89CLS3 is the close disconnect switch Relay Word bit for Disconnect 3 and the 89OPN5 Relay Word bit is the status of Disconnect 5. The SELOGIC control equation below will not assert OUT201 unless both conditions are true.

OUT201 := **89CLS3 AND 89OPN5**

These are just a few examples of disconnect lockout control. Use Relay Word bits and SELOGIC programming to design lockout control scenarios required for the configuration being controlled.

The SELOGIC Output settings listed in *Table 5.6* are example close and open disconnect equations with disconnect lockout control for Switches 1–5.

Table 5.6 Application Example Bay Control Settings for Bus 1, Bus 2, and Transfer Bus Bay With Ground Switch Application (Sheet 1 of 3)

Setting	Description	Entry
General One-Line Settings		
MIMIC	One-line Screen Number (1–999)	4
BAYNAME	Bay Name (20 characters)	BAY CONTROL
Busbar Information		
BUSNAM1	Busbar 1 Name (40 pixels, 6–10 characters)	Bus T
BUSNAM2	Busbar 2 Name (40 pixels, 6–10 characters)	Bus 2
BUSNAM3	Busbar 3 Name (40 pixels, 6–10 characters)	Bus 1
Breaker Information		
B1HMINM	Breaker 1 HMI Name (max 3–17 characters)	Bkr 1
B1CTLNM	Breaker 1 HMI Cntl Scr. Name (max. 15 characters)	Bkr 1
521CLSM	Breaker 1 Close Status (SELOGIC Equation)	52ACL1
521_ALM	Breaker 1 Alarm Status (SELOGIC Equation)	52AAL1
Disconnect Information		
D1HMIN	Disconnect 1 HMI Name (max 3–17 characters)	D1
D1CTLN	Disconnect 1 Name (25 pixels, max. 15 characters)	Dis 1
89AM1	Disconnect 1 N/O Contact (SELOGIC Equation)	IN103
89BM1	Disconnect 1 N/C Contact (SELOGIC Equation)	IN104
89ALP1	Disconnect 1 Alarm Pickup Delay (1–99999 cyc)	260
89CCN1	Disconnect 1 Close Control (SELOGIC Equation)	89CC01
89OCN1	Disconnect 1 Open Control (SELOGIC Equation)	89OC01
89CST1	Disconnect 1 Close Seal-in Time (1–99999 cyc)	280
89OST1	Disconnect 1 Open Seal-in Time (1–99999 cyc)	280
D2HMIN	Disconnect 2 HMI Name (max. 3–17 characters)	D2

Table 5.6 Application Example Bay Control Settings for Bus 1, Bus 2, and Transfer Bus Bay With Ground Switch Application (Sheet 2 of 3)

Setting	Description	Entry
D2CTLN	Disconnect 2 Name (25 pixels, 4–6 characters)	Dis 2
89AM2	Disconnect 2 N/O Contact (SELOGIC Equation)	1
89BM2	Disconnect 2 N/C Contact (SELOGIC Equation)	0
89ALP2	Disconnect 2 Alarm Pickup Delay (1–99999 cyc)	260
89CCN2	Disconnect 2 Close Control (SELOGIC Equation)	89CC02
89OCN2	Disconnect 2 Open Control (SELOGIC Equation)	89OC02
89CST2	Disconnect 2 Close Seal-in Time (1–99999 cyc)	280
89OST2	Disconnect 2 Open Seal-in Time (1–99999 cyc)	280
D3HMIN	Disconnect 3 HMI Name (max. 3–17 characters)	D3
D3CTLN	Disconnect 3 Name (25 pixels, 4–6 characters)	Dis 3
89AM3	Disconnect 3 N/O Contact (SELOGIC Equation)	1
89BM3	Disconnect 3 N/C Contact (SELOGIC Equation)	0
89ALP3	Disconnect 3 Alarm Pickup Delay (1–99999 cyc)	260
89CCN3	Disconnect 3 Close Control (SELOGIC Equation)	89CC03
89OCN3	Disconnect 3 Open Control (SELOGIC Equation)	89OC03
89CST3	Disconnect 3 Close Seal-in Time (1–99999 cyc)	280
89OST3	Disconnect 3 Open Seal-in Time (1–99999 cyc)	280
D4HMIN	Disconnect 4 HMI Name (1–99999 cyc)	D4
D4CTLN	Disconnect 4 Name (25 pixels, 4–6 characters)	Dis 4
89AM4	Disconnect 4 N/O Contact (SELOGIC Equation)	1
89BM4	Disconnect 4 N/C Contact (SELOGIC Equation)	0
89ALP4	Disconnect 4 Alarm Pickup Delay (1–99999 cyc)	260
89CCN4	Disconnect 4 Close Control (SELOGIC Equation)	89CC04
89OCN4	Disconnect 4 Open Control (SELOGIC Equation)	89OC04
89CST4	Disconnect 4 Close Seal-in Time (1–99999 cyc)	280
89OST4	Disconnect 4 Open Seal-in Time (1–99999 cyc)	280
D5HMIN	Disconnect 5 HMI Name (1–9999)	D5
89AM5	Disconnect 5 N/O Contact (SELOGIC Equation)	0
89BM5	Disconnect 5 N/C Contact (SELOGIC Equation)	0
89ALP5	Disconnect 5 Alarm Pickup Delay (1–99999 cyc)	260
89CCN5	Disconnect 5 Close Control (SELOGIC Equation)	89CC05
89OCN5	Disconnect 5 Open Control (SELOGIC Equation)	89OC05
89CST5	Disconnect 5 Close Seal-in Time (1–99999 cyc)	280
89OST5	Disconnect 5 Open Seal-in Time (1–99999 cyc)	280
One-Line Analog Display		
1		1, “Analogs”
2		IAWM, “IA:(4.0,1)A”
3		VABFM, “V:(3.0,1)kV”
4		FREQ, “F:(4.1,1)Hz”

Table 5.6 Application Example Bay Control Settings for Bus 1, Bus 2, and Transfer Bus Bay With Ground Switch Application (Sheet 3 of 3)

Setting	Description	Entry
5		3P, "P:(3.0,1)MW"
6		3Q_F, "Q:(3.0,1)MVR"
Control Selection		
LOCAL	Local Control (SELOGIC control equation)	IN107

Table 5.7 Application Example Front Panel Settings

Setting	Description	Entry
Selectable Screens for the Front Panel		
SCROLD	Front Panel Display Update Rate (OFF, 1–15 secs)	5
RMS_V	RMS Line Voltage Screen (Y, N)	Y
RMS_I	RMS Line-Current Screen (Y, N)	Y
RMS_VPP	RMS Line Voltage Phase-to-Phase Screen	N
RMS_W	RMS Active Power Screen	N
FUNDVAR	Fundamental Reactive Power Screen	N
RMS_VA	RMS Apparent Power Screen	N
RMS_PF	RMS Power Factor Screen	N
RMS_BK1	RMS Breaker 1 Currents Screen	N
RMS_BK2	RMS Breaker 2 Currents Screen	N
STA_BAT	Station Battery Screen	N
FUND_VI	Fundamental Voltage and Current Screen	N
FUNDSEQ	Fundamental Sequence Quantities Screen	N
FUND_BK	Fundamental Breaker Currents Screen	N
ONELINE	One-Line Bay Control Diagram	Y
Selectable Operator Pushbuttons		
PB2_HMI	Pushbutton 2 HMI Screen	BC

Table 5.8 Application Example Output Settings, Output SELOGIC Control Equations

Setting	Description	Entry
OUT103	OUT103 SELOGIC control equation	89CLS1 AND NOT 52CLSM1
OUT104	OUT104 SELOGIC control equation	89OPEN1 AND NOT 52CLSM1
OUT105	OUT105 SELOGIC control equation	89CLS2 AND NOT 52CLSM1
OUT106	OUT106 SELOGIC control equation	89OPEN2 AND NOT 52CLSM1
OUT201	OUT201 SELOGIC control equation	89CLS3 AND 89OPN5
OUT202	OUT202 SELOGIC control equation	89OPEN3 AND 52CLSM1
OUT203	OUT203 SELOGIC control equation	89CLS4 AND NOT 52CLSM1
OUT204	OUT204 SELOGIC control equation	89OPEN4 AND NOT 52CLSM1
OUT205	OUT205 SELOGIC control equation	89CLS5 AND NOT 52CLSM1
OUT206	OUT206 SELOGIC control equation	89OPEN5 AND NOT 52CLSM1

This page intentionally left blank

SECTION 6

Autoreclosing

This section describes the operation of autoreclose logic in SEL-400 series relays that include an autorecloser. This section covers the following topics:

- *Autoreclosing States on page 6.2*
- *One-Circuit-Breaker Autoreclosing on page 6.4*
- *Two-Circuit-Breaker Autoreclosing on page 6.10*
- *Autoreclose Logic Diagrams on page 6.26*
- *Manual Closing on page 6.39*
- *Voltage Checks for Autoreclosing and Manual Closing on page 6.42*
- *Settings and Relay Word Bits for Autoreclosing and Manual Closing on page 6.45*

The relay autoreclose function provides complete control for single circuit breaker and two circuit breaker reclosing schemes. The autoreclose function accommodates both single-pole and three-pole reclosing. Some SEL-400 series relays only support three-pole operations. See the *Features* section in *Section 1: Introduction and Specifications* in the product-specific instruction manual to determine the reclosing capability of each relay. Relays that support single-pole breaker operations can be set for a total of two single-pole reclose shots. Three-pole breaker operations can be set for as many as four three-pole reclose shots.

NOTE: The SEL-487E autoreclose logic is designed to operate as many as six breakers independently, which differs from the rest of the SEL-400 series relays. See the SEL-487E instruction manual for details on SEL-487E autoreclose logic.

You can designate the leader and follower circuit breakers in a two-circuit breaker configuration. The relay recloser can dynamically change leader and follower designations based on settings and operating conditions.

You can program the autoreclose logic to perform one shot of high-speed three-pole reclose. This high-speed three-pole shot replaces one of the four delayed time three-pole shots. There is no difference between a shot of high-speed three-pole reclose and a shot of delayed three-pole autoreclose; simply select the open interval time accordingly.

NOTE: The relay voltage check elements (for bus and line voltages) may be used without the synchronism-check feature, however, for certain voltage connections, some of the synchronism-check settings need to be entered to ensure that the correct voltages are used.

Two autoreclose modes are available when using the relay to control two circuit breakers:

- Combined two-breaker mode (setting E79 := Y)—both circuit breakers must trip before any reclosing can occur.
- Independent two-breaker mode (setting E79 := Y1)—the follower circuit breaker can trip and reclose even when the lead breaker has not operated. This is useful on both ring bus and breaker-and-a-half schemes, where the follower breaker is a tie breaker that can be tripped by protection on either side.

For single circuit breaker applications, use setting E79 := Y.

Autoreclosing States

The autoreclose logic for either circuit breaker can be in one of the following five states (see *Figure 6.1*):

- Start (common to both circuit breakers) (79STRT)
- Reset per circuit breaker (BK1RS, BK2RS)
- Single-pole autoreclose cycle (common to both circuit breakers) (79CY1)
- Three-pole autoreclose cycle (common to both circuit breakers) (79CY3)
- Lockout, per circuit breaker (BK1LO, BK2LO)

Start (79STRT)

The autoreclose logic is in the Start state for both circuit breakers during the following conditions:

- Startup
- Restart
- Any relay settings change

The relay stores the previous reclosing state for Relay Word bits 79CY1, 79CY3, BK1LO, BK2LO, BK1RS, and BK2RS when a restart or any relay settings change occurs.

At startup, the recloser logic goes from the start state to the lockout state. For a restart or a settings change, the recloser logic enters the start state, then goes to lockout if the circuit breakers were open before the restart or settings change. If the circuit breakers were previously closed, then the recloser logic proceeds through the 3PMRCD (Manual Close Reclaim Time Delay) time and then goes to the ready state.

Reset (BK1RS, BK2RS)

The autoreclose logic is in the reset or ready state for either circuit breaker when the circuit breaker is ready to begin an autoreclose cycle. There are three reset state timers. After a successful reclose cycle, the relay goes to the reset state after reclaim times SPRCD (Single-Pole Reclaim Time Delay) for single-pole automatic and 3PRCD (Three-Pole Reclaim Time Delay) for three-pole automatic reclosing. If the recloser has been in a lockout condition, the Ready or Reset state cannot occur until the 3PMRCD (Manual Close Reclaim Time Delay) timer has expired. You can only block the reclaim time after a successful reclose cycle. Setting 79BRCT (Block Reclaim Timer) prevents timing of reclaim timers SPRCD, 3PRCD, and 3PMRCD.

Single-Pole Autoreclose (79CY1)

This state does not apply to relays that only support three-pole reclosing. The autoreclose logic is in a single-pole autoreclose cycle for either circuit breaker if all of the following conditions are satisfied:

- Single-pole trip occurs
- Condition(s) to initiate a single-pole autoreclose cycle are satisfied
- Circuit breaker(s) is in service and ready to begin a single-pole autoreclose cycle (that is, reset)

Three-Pole Autoreclose (79CY3)

The autoreclose logic is in a three-pole autoreclose cycle for either circuit breaker if all of the following conditions are satisfied:

- Three-pole trip occurs
- Condition(s) to initiate a three-pole autoreclose cycle are satisfied
- Circuit breaker(s) is in service and ready to begin a three-pole autoreclose cycle (that is, reset)

Lockout (BK1LO, BK2LO)

The lockout state is the default state of any circuit breaker after startup. Other conditions place the recloser in the LO state. The relay recloser has a drive-to-lockout function that you can program for any external or internal condition—use setting 79DTL. A circuit breaker can go to lockout by two methods. The circuit breaker enters the lockout state if either of the following occur:

- Supervisory Relay Word bits SP*n*CLS or 3P*n*CLS do not assert within the BK*n*CLSD time
- The circuit breaker does not close within the BKCFD time

The timer for both supervisory Relay Word bits SP*n*CLS and 3P*n*CLS is setting BK*n*CLSD. Setting BK*n*CLSD = OFF disables the BK*n*CLSD delay timer, requiring either SP*n*CLS or 3P*n*CLS to assert before transitioning to the next state.

In applications using two circuit breakers, you can designate one circuit breaker as the leader and the other circuit breaker as the follower. The relay freezes the leader/follower decision during an autoreclose cycle unless the autoreclose logic receives another initiation.

If the recloser receives another initiation, the logic reevaluates the leader and follower circuit breakers to determine the number of circuit breakers in a scheme (NBK*n*), the leader circuit breaker (LEADBK*n*), and the follower circuit breaker (FOLBK*n*). This determination is based on the service status of the circuit breakers. The logic considers a circuit breaker out of service if the circuit breaker goes to lockout. The logic considers a circuit breaker to be in service as soon as the circuit breaker closes and is no longer in lockout.

State Diagram

NOTE: The autoreclose function runs once per power-system cycle. To ensure that the logic detects transient element state changes that initiate closing, you should extend the assertion time of transient element states to 1 cycle.

Figure 6.1 illustrates how the autoreclose logic moves from one state to another with respect to Circuit Breaker 1. (This diagram is identical for Circuit Breaker 2; replace the 1 in the Relay Word bits with 2.) The Relay Word bits that correspond to each state are shown (see *Table 6.1*). A solid path between two states indicates that the logic can move in only one direction. Two broken paths between two states indicate the logic can move in either direction between the two states. The dashed vertical line that runs through the center of the figure indicates the states common to both circuit breakers.

Table 6.1 describes each of the five states with respect to Circuit Breaker 1, along with the corresponding Relay Word bits.

Figure 6.1 Autoreclose State Diagram for Circuit Breaker 1

Table 6.1 Autoreclose Logical States for Circuit Breaker 1

State	Description	Relay Word Bit
Start	Startup, or relay settings change	79STRT
Reset	Circuit Breaker 1 reset	BK1RS
Single-pole autoreclose cycle[a]	Single-pole autoreclose	79CY1
Three-pole autoreclose cycle	Three-pole autoreclose cycle	79CY3
Lockout	Lockout	BK1LO

[a] 79CY1 is only available in relays that support single-pole breaker operations.

One-Circuit-Breaker Autoreclosing

Modes

The autoreclose logic can operate in one of three modes, depending upon the relay autoreclose capabilities:

- Single-pole mode (SPAR)
- Three-pole mode (3PAR)
- Single- and three-pole mode (SPAR/3PAR)

Relay settings ESPR1 (Single-Pole Reclose Enable—BK1) and E3PR1 (Three-Pole Reclose Enable—BK1) determine the autoreclose mode (see *Recloser Mode Enables on page 6.8*). These settings are inputs to the recloser initiation Relay Word bits SPARC (Single-Pole Reclose Initiate Qualified) and 3PARC (Three-Pole Reclose Initiate Qualified); see *Figure 6.8* and *Figure 6.9*. SPARC asserts when all necessary conditions to begin a single-pole autoreclose cycle are satisfied (ESPR1, for example) and the recloser receives a single-pole reclose initiation SPRI (see *Figure 6.8*). Relay Word bit 3PARC asserts when all necessary conditions to begin a three-pole autoreclose cycle are satisfied (E3PR1, for example) and the recloser receives a three-pole reclose initiation 3PRI (see *Figure 6.9*).

Other recloser settings include the initial recloser settings (see *Enable Autoreclose Logic for Two Circuit Breakers on page 6.22*) and the trip logic enable settings E3PT, E3PT1, and E3PT2. When SELOGIC control equations E3PT, E3PT1, and E3PT2 are deasserted, a single-pole reclose follows a single-pole trip; when these SELOGIC control equations are asserted, only three-pole tripping and reclosing result (see *Trip Logic and Reclose Sources for Single-Pole Breaker Applications on page 6.9*).

Single-Pole Mode

NOTE: Single-pole mode is only supported in relays that provide single-pole breaker control.

Figure 6.11 shows the one circuit breaker single-pole autoreclose cycle 79CY1. The cycle starts when Relay Word bit SPARC asserts. The recloser waits as long as 10 cycles for the circuit breaker to open (indicated by Relay Word bit SPO) and then begins timing SPOID (Single-Pole Open Interval Delay) when the circuit breaker opens. After single-pole open interval time SPOID expires, the relay recloses the circuit breaker if supervisory condition SP1CLS (Single-Pole BK1 Reclose Supervision) is satisfied within the duration of timer BK1CLSD (BK1 Reclose Supervision Delay).

At the reclose command, the recloser starts timer BKCFD (Breaker Close Failure Delay). If the circuit breaker fails to close, the recloser goes to lockout (BK1LO) after timer BKCFD expires.

SPRCD Reclaim Timing

If the circuit breaker closes, the recloser starts timer SPRCD (Single-Pole Reclaim Time Delay). The recloser determines subsequent state transitions during reclaim timing according to the status of Relay Word bit SPLSHT (Single-Pole Reclose Last Shot). When SPLSHT is asserted, the recloser forces all subsequent relay trips to three-pole only mode.

SPLSHT Asserted (Last Shot)

The recloser exits the 79CY1 state via one of the following three methods while SPLSHT is asserted:

- If no further trip conditions occur, the recloser goes to the reset state BK1RS after reclaim timer SPRCD expires.
- If a fault occurs during the SPRCD reclaim time, then the recloser asserts Relay Word bit 3PARC if all three-pole reclose conditions are satisfied and proceeds to the autoreclose three-pole cycle state 79CY3.
- If a fault occurs during the SPRCD reclaim time, and the three-pole reclose conditions are not satisfied (E3PR1 is logical 0, for example) the recloser exits the 79CY1 cycle state and goes to the lockout state BK1LO.

SPLSHT Deasserted (Single-Pole Shot Remains)

The recloser exhibits four possible state transitions when SPLSHT is not asserted:

- If no further trip conditions occur, the recloser goes to the reset state BK1RS after timer SPRCD expires.
- If a single-phase fault occurs while the SPRCD reclaim timer is timing, the recloser asserts SPARC for single-pole initiate conditions and returns to the beginning of the 79CY1 cycle state; the recloser increments the shot counter and begins the next open interval timer.

- If a multiphase fault occurs during the SPRCD reclaim time, then the recloser asserts Relay Word bit 3PARC if all three-pole reclose conditions are satisfied (E3PR1 is logical 1, for example) and proceeds to the autoreclose three-pole cycle state 79CY3.
- If a multiphase fault occurs during the SPRCD reclaim time, and the three-pole reclose conditions are not satisfied (E3PR1 is logical 0, for example), the recloser exits the 79CY1 cycle state and goes to the lockout state BK1LO.

Lockout State From 79CY1

The recloser goes to lockout (BK1LO) when any of the following occur:

- The number of trips exceeds the maximum number of shots (NSPSHOT).
- Supervision condition SP1CLS fails to assert in BK1CLSD time.
- Relay Word bit 3POLINE asserts (for a circuit breaker manual opening).
- The circuit breaker fails to close within BKCFD time.
- Any time Relay Word bit 79DTL asserts.

Three-Pole Mode

Figure 6.12 shows the one circuit breaker autoreclose cycle 79CY3. The cycle starts when Relay Word bit 3PARC asserts. The recloser checks SELOGIC control equation 79SKP at this point to determine whether to increment the shot counter. The recloser waits indefinitely for the circuit breaker to open, as indicated by Relay Word bit 3POLINE. The recloser begins timing 3POID1 (Three-Pole Open Interval 1 Delay) when the circuit breaker opens. After the open interval time 3POID1 expires, the relay asserts Relay Word bit BK1CL to reclose the circuit breaker if supervisory condition 3P1CLS (Three-Pole BK1 Reclose Supervision) is satisfied within the duration of timer BK1CLSD (BK1 Reclose Supervision Delay).

At the reclose command, the recloser starts timer BKCFD (Breaker Close Failure Delay). If the circuit breaker fails to close, the recloser goes to lockout (BK1LO) after timer BKCFD expires.

3PRCD Reclaim Timing

If the circuit breaker closes, the recloser starts timer 3PRCD (Three-Pole Reclaim Time Delay). The recloser determines subsequent state transitions during reclaim timing according to the status of Relay Word bit 3PLSHT (Three-Pole Reclose Last Shot).

3PLSHT Asserted (Last Shot)

The recloser exits the 79CY3 state via one of the following two methods while 3PLSHT is asserted:

- If no further trip conditions occur, the recloser goes to the reset state BK1RS after reclaim timer 3PRCD expires.
- If a fault occurs during the 3PRCD reclaim time, then the recloser exits the 79CY3 cycle state and goes to the lockout state BK1LO.

3PLSHT Deasserted (Three-Pole Shot Remains)

The recloser exhibits three possible state transitions when 3PLSHT is not asserted:

- If no further trip conditions occur, the recloser goes to the reset state BK1RS after timer 3PRCD expires.
- If a fault occurs during the 3PRCD reclaim time, then the recloser asserts Relay Word bit 3PARC if all three-pole reclose conditions are satisfied (E3PR1 is logical 1, for example) and returns to the beginning of the 79CY3 cycle state; the recloser increments the shot counter and begins the next open interval timer.
- If a fault occurs during the 3PRCD reclaim time, and the three-pole reclose conditions are not satisfied (E3PR1 is logical 0, for example), the recloser exits the 79CY3 cycle state and goes to the lockout state BK1LO.

Lockout State From 79CY3

The recloser goes to lockout (BK1LO) when any of the following occur:

- The number of trips exceeds the maximum number of shots (N3PSHOT)
- Supervision condition 3P1CLS fails to assert in BK1CLSD time
- Relay Word bit 3POLINE asserts (for a circuit breaker manual opening)
- The circuit breaker fails to close within BK1CFD time
- Relay Word bit 79DTL asserts

Single- and Three-Pole Mode

NOTE: Single- and three-pole mode is only supported in breakers that provide single-pole breaker control.

The single- and three-pole mode (SPAR/3PAR) uses elements of both the single-pole mode (SPAR) and the three-pole mode (3PAR). Reclosing begins after a single-pole trip in the single-pole cycle 79CY1 with a valid SPARC as described in *Single-Pole Mode on page 6.5*. The recloser closes the circuit breaker and proceeds to the reclaim timer SPRCD. If a fault occurs during the SPRCD reclaim time and SPLSHT is asserted, then the recloser asserts Relay Word bit 3PARC if all three-pole reclose conditions are satisfied. Upon asserting 3PARC, the recloser exits the 79CY1 cycle state and goes to the beginning of the three-pole autoreclose cycle state 79CY3. The recloser proceeds through the 79CY3 state and exits this state as described in *Three-Pole Mode on page 6.6*.

Three-Pole Priority

If a single-pole autoreclose cycle 79CY1 is in progress and the relay receives an initiation for three-pole reclosing 3PRI, the recloser immediately starts a three-pole autoreclose cycle 79CY3.

Active Circuit Breakers

Two Relay Word bits describe when Circuit Breaker 1 is active for the autoreclose logic:

- NBK0, No Breaker Active in Reclose Scheme
- NBK1, One Breaker Active in Reclose Scheme

NBK1 equals logical 1 when Circuit Breaker 1 is closed and the autoreclose logic is reset, or if the autoreclose logic is in an autoreclose cycle (79CY1 or 79CY3). NBK0 equals logical 1 when Circuit Breaker 1 is open and not in an autoreclose cycle (79CY1 or 79CY3), or if the autoreclose logic is locked out (BK1LO).

Enable Autoreclose Logic for One Circuit Breaker

Three-Pole Trip Circuit Breaker

The initial settings necessary to enable autoreclose for a single three-pole trip circuit breaker are shown in *Table 6.2*.

Table 6.2 One-Circuit-Breaker Three-Pole Reclosing Initial Settings

Setting	Description	Entry
General Global Settings (Global)		
NUMBK	Number of Breakers in Scheme	1
Breaker Configuration (Breaker Monitor)		
BK1TYP[a]	Breaker 1 Trip Type	3
Breaker 1 Inputs (Breaker Monitor)		
52AA1	N/O Contact Input—BK1 (SELOGIC control equation)	IN101
Relay Configuration (Group)		
E79	Reclosing	Y

[a] Only applies to relays that support single-pole breaker operations.

Single-Pole Trip Circuit Breaker

The initial settings necessary to enable autoreclose for one single-pole trip circuit breaker are shown in *Table 6.3*.

Table 6.3 One-Circuit-Breaker Single-Pole Reclose Initial Settings

Setting	Description	Entry
General Global Settings (Global)		
NUMBK	Number of Breakers in Scheme	1
Breaker Configuration (Breaker Monitor)		
BK1TYP	Breaker 1 Trip Type	1
Breaker 1 Inputs (Breaker Monitor)		
52AA1	A-Phase N/O Contact Input—BK1 (SELOGIC Equation)	IN101
52AB1	B-Phase N/O Contact Input—BK1 (SELOGIC Equation)	IN102
52AC1	C-Phase N/O Contact Input—BK1 (SELOGIC Equation)	IN103
Relay Configuration (Group)		
E79	Reclosing	Y

Recloser Mode Enables

The SELOGIC control equations E3PR1 and ESPR1 are used to set the relay autoreclose modes. *Table 6.4* illustrates how to enable the autoreclose modes for Circuit Breaker 1.

Table 6.4 One Circuit Breaker Modes of Operation

E3PR1	ESPR1[a]	Result
0	0	Autoreclose disabled
0	1	Single-pole autoreclose only enabled
1	0	Three-pole autoreclose only enabled
1	1	Single- and three-pole autoreclose enabled

[a] ESPR1 only applies to relays that support single-pole reclosing.

E3PR1 is the SELOGIC control equation that enables three-pole autoreclose for Circuit Breaker 1. You can assign this setting to a control input. When E3PR1 equals logical 1, the relay can attempt a three-pole autoreclose cycle for Circuit Breaker 1. If E3PR1 equals logical 0, the relay goes to lockout following a three-pole trip for Circuit Breaker 1.

ESPR1 is the SELOGIC control equation that enables single-pole autoreclose for Circuit Breaker 1. You can assign this setting to a control input. When ESPR1 equals logical 1, the relay can attempt a single-pole autoreclose cycle for Circuit Breaker 1. If ESPR1 equals logical 0, the relay cannot initiate a single-pole autoreclose cycle.

Set either or both E3PR1 and ESPR1 according to your reclosing requirements and relay reclosing capabilities. For single-pole reclosing, set ESPR1 to evaluate to logical 1 and set NSPSHOT to the desired number of single-pole reclose shots. For three-pole reclosing, set E3PR1 to evaluate to logical 1 and set N3PSHOT for the desired number of three-pole shots. For both single-pole and three-pole reclosing, set ESPR1 to evaluate to logical 1, set E3PR1 to evaluate to logical 1, and configure settings NSPSHOT and N3PSHOT for the desired number of reclose shots of each type (see *Recloser Mode Enables on page 6.8*).

Trip Logic and Reclose Sources for Single-Pole Breaker Applications

Internal Recloser

Program the recloser function to drive the trip logic with Relay Word bits R3PTE (recloser three-pole trip enable) and R3PTE1 (recloser three-pole trip enable Circuit Breaker 1) as follows:

E3PT := **R3PTE** Three-Pole Trip Enable (SELOGIC equation)

E3PT1 := **R3PTE1** Breaker 1 3PT (SELOGIC equation)

These settings connect the internal recloser for both three-pole reclosing and single-pole reclosing. Enter enable settings ESPR1 and E3PR1 as appropriate for your application.

Relay Word bits R3PTE and R3PTE1 are logical 1 for either of the following conditions when the setting NUMBK (number of breakers in scheme) is logical 1 and SPLSHT (single-pole last shot) is asserted (see *Figure 6.9*):

- BK1TYP := 3 (Breaker 1 Trip Type)
- NSPSHOT := N (Number of Single-Pole Reclosures)

External Recloser

If reclosing is performed by an external relay, assert SELOGIC control equations E3PT and E3PT1 via a control input (for example):

E3PT := **NOT IN104** Three-Pole Trip Enable (SELOGIC equation)

E3PT1 := **NOT IN104** Breaker 1 3PT (SELOGIC equation)

Connect the external recloser single-pole trip output signal to IN104. Other external recloser signals are required; consult the external recloser documentation for interconnection with the relay.

Two-Circuit-Breaker Autoreclosing

Modes

The autoreclose logic can operate in one of three modes, depending upon the relay reclose capabilities:

- Single-pole mode (SPAR)
- Three-pole mode (3PAR)
- Single- and three-pole mode (SPAR/3PAR)

NOTE: In the following discussion, n = 1 or 2 for Circuit Breaker BK1 or BK2.

Relay settings ESPR*n* (Single-Pole Reclose Enable—BK*n*) and E3PR*n* (Three-Pole Reclose Enable—BK*n*) determine the autoreclose mode (see *Recloser Mode Enables on page 6.8*). These settings are inputs to the recloser initiation Relay Word bits SPARC (Single-Pole Reclose Initiate Qualified) and 3PARC (Three-Pole Reclose Initiate Qualified); see *Figure 6.9* and *Figure 6.10*. SPARC asserts when all necessary conditions to begin a single-pole autoreclose cycle are satisfied (ESPR*n*, for example) and the recloser receives a single-pole reclose initiation SPRI (see *Figure 6.9*). Relay Word bit 3PARC asserts when all necessary conditions to begin a three-pole autoreclose cycle are satisfied (E3PR*n*, for example) and the recloser receives a three-pole reclose initiation 3PRI (see *Figure 6.10*).

Single-pole recloser settings also include the initial recloser settings (see *Enable Autoreclose Logic for One Circuit Breaker on page 6.8*) and the trip logic enable settings E3PT, E3PT1, and E3PT2. When SELOGIC control equations E3PT, E3PT1, and E3PT2 are deasserted, a single-pole reclose follows a single-pole trip; when these SELOGIC control equations are asserted, only three-pole tripping and reclosing result (see *Trip Logic and Reclose Sources for Single-Pole Breaker Applications on page 6.24*).

Single-Pole Mode

Figure 6.13 and *Figure 6.14* show the two circuit breaker single-pole autoreclose cycle 79CY1 when E79 := Y and E79 := Y1, respectively. The cycle starts when Relay Word bit SPARC asserts. The recloser freezes calculation of the number of breakers, the leader circuit breaker, and the follower circuit breaker. Depending on the calculation, the recloser asserts the appropriate Relay Word bits NBK0, NBK1, NBK2, LEADBK0, LEADBK1, LEADBK2, FOLBK0, FOLBK1, and FOLBK2.

The recloser checks for an SPO (Single-Pole Open) condition for either the leader or follower, and waits as long as 10 cycles for the circuit breakers to open. If the leader or follower shows a single-pole open inside the 10-cycle window, the

recloser proceeds to timing SPOID (Single-Pole Open Interval Delay). The recloser goes to lockout if the circuit breakers fail to open (no close attempts follow). If an evolving fault results in a three-pole trip condition that asserts 3PARC, then the recloser exits the 79CY1 cycle and goes to the three-pole cycle 79CY3. When E79 := Y1, a Single-Pole Open Interval Supervision Condition (SPOISC) must be satisfied before the recloser can proceed to timing SPOID. If the supervisory condition is not met within the duration of timer SPOISD (Single-Pole Open Interval Supervision Delay), the recloser goes to lockout.

After single-pole open interval time SPOID expires, the recloser closes the leader if the single-pole open condition is still in effect and supervisory condition SP*n*CLS (Single-Pole BK*n* Reclose Supervision) is satisfied within the duration of timer BK*n*CLSD (BK*n* Reclose Supervision Delay). If the leader circuit breaker has more than one pole open at the end of the SPOID time, the recloser sends the leader to lockout BK*n*LO.

At the leader close command, the recloser starts timer BKCFD (Breaker Close Failure Delay). If the leader fails to close, the recloser sends the leader to lockout after timer BKCFD expires. If the leader closes within the BKCFD time, the recloser goes to SPRCD (Single-Pole Reclaim Time Delay) reclaim timing if NBK1 is asserted, or prepares to close the follower circuit breaker if NBK2 is asserted.

To close the follower circuit breaker, the recloser checks for two active circuit breakers in the scheme. If NBK2 is asserted, the recloser checks for a single-pole open on the follower and starts timer TBBKD (Time Between Breakers For ARC). If multiple poles of the follower circuit breaker are open, the recloser sends the follower to lockout BK*n*LO. When TBBKD expires, the recloser closes the follower breaker if FBKCEN (Follower Breaker Closing Enable) is asserted and supervisory condition SP*n*CLS is satisfied within the duration of timer BK*n*CLSD. At the follower close command, the recloser starts timer BKCFD (Breaker Close Failure Delay). If the follower fails to close, the recloser sends the follower to lockout after timer BKCFD expires. If the leader circuit breaker is not in lockout, the recloser begins timing SPRCD reclaim time for the leader.

If the follower breaker closes successfully, the recloser starts the SPRCD (Single-Pole Reclaim Time Delay) timer if 79BRCT (Block Reclaim Timer) is not asserted.

SPRCD Reclaim Timing

The recloser determines subsequent state transitions during reclaim timing according to the status of Relay Word bit SPLSHT (Single-Pole Reclose Last Shot). When SPLSHT is asserted, the recloser forces all subsequent relay trips to three-pole only mode.

SPLSHT Deasserted (Single-Pole Shot Remains)

The recloser exhibits four possible state transitions when SPLSHT is not asserted:

- If no further trip conditions occur and timer SPRCD expires, the recloser returns to the reset states BK*n*RS.
- If a single-phase fault occurs while the SPRCD reclaim timer is timing, then the recloser asserts SPARC if all single-pole initiate conditions are satisfied and goes to the beginning of the 79CY1 cycle. The recloser then recalculates and freezes the calculation for the number of active circuit breakers, the leader, and the follower. The recloser then increments the shot counter and begins the next open interval timer.

- If a multiphase fault occurs during the SPRCD reclaim time, then the recloser asserts Relay Word bit 3PARC if all three-pole reclose conditions are satisfied (E3PR*n* is logical 1, for example) and recalculates the number of active circuit breakers, the leader, and the follower before proceeding to the autoreclose three-pole cycle state 79CY3.
- If a multiphase fault occurs during the SPRCD reclaim time, SPLSHT is not asserted, and the three-pole reclose conditions are not satisfied (E3PR*n* is logical 0, for example) and the recloser exits the 79CY1 cycle state and goes to the lockout state BK*n*LO.

SPLSHT Asserted (Last Shot)

The recloser exits the 79CY1 state via three methods while SPLSHT is asserted:

- If no further trip conditions occur and timer SPRCD expires, the recloser returns to the reset states BK*n*RS.
- If a fault occurs during the SPRCD reclaim time, then the recloser asserts Relay Word bit 3PARC if all three-pole reclose conditions are satisfied and proceeds to the autoreclose three-pole cycle state 79CY3.
- If a fault occurs during the SPRCD reclaim time and the three-pole reclose conditions are not satisfied (E3PR*n* is logical 0, for example), then the recloser exits the 79CY1 cycle state and goes to the lockout state Bk*n*LO.

Lockout State From 79CY1

The recloser goes to lockout (BK*n*LO) when the number of trips exceeds the maximum number of shots (NSPSHOT), supervision condition SP*n*CLS fails to assert in BK*n*CLSD time, Relay Word bit 3POLINE asserts (for a circuit breaker manual opening), the circuit breaker fails to close within BKCFD time, or any time Relay Word bit 79DTL asserts.

Three-Pole Mode

Figure 6.15 and *Figure 6.16* show the two circuit breaker three-pole autoreclose cycle 79CY3 when E79 := Y and E79 := Y1, respectively. The cycle starts when Relay Word bit 3PARC asserts. The recloser freezes calculation of the number of breakers, the leader circuit breaker, and the follower circuit breaker. Depending on the calculation, the recloser asserts the appropriate Relay Word bits NBK0, NBK1, NBK2, LEADBK0, LEADBK1, LEADBK2, FOLBK0, FOLBK1, and FOLBK2. The recloser checks SELOGIC control equation 79SKP at this point to determine whether to increment the shot counter.

The recloser waits for 3POLINE to assert:

- if E79 := Y, 3POLINE asserts when both breakers (leader and follower) open (see *Figure 6.15*)
- if E79 := Y1, 3POLINE asserts when at least one breaker (leader or follower) opens (see *Figure 6.16*)

NOTE: The recloser logic is only processed every 1 cycle. To ensure proper timing and to avoid going to lockout unnecessarily, add an additional 1 cycle to the 3PRIH setting to properly account for processing delays.

If 3POLINE asserts within the 3PRIH time delay, the recloser proceeds to timing 3POID1 (Three-Pole Open Interval 1 Delay). If 3POLINE fails to assert within the 3PRIH time-delay setting, the recloser goes to lockout. If the 3PRIH setting = OFF, the recloser will wait indefinitely for 3POLINE to assert before proceeding to timing 3POID1. If SELOGIC control equation 3PFARC (Three-Pole Fast ARC Enable) is asserted, the recloser times the open interval time from setting 3PFOID (Three-Pole Fast Open Interval Delay). When E79 := Y1, a Three-Pole Open Interval Supervision Condition (3POISC) must be satisfied

before the recloser can proceed to timing 3POID1. If the supervisory condition is not met within the duration of timer 3POISD (Three-Pole Open Interval Supervision Delay), the recloser goes to lockout.

After three-pole open interval time 3POID or 3PFOID expires.

- and E79 := Y, the recloser attempts to close the leader breaker, as discussed below (first checking the supervisory condition 3P*n*CLS).
- and E79 := Y1, the recloser checks if the leader breaker is open. If open, it attempts to close the leader breaker, as discussed below (first checking the supervisory condition 3P*n*CLS). If the leader breaker is closed (it never opened at the outset), the recloser skips the leader breaker close logic and attempts to close the follower breaker, as discussed further below (first checking for two active breakers and an open follower breaker, before starting timer TBBKD [Time Between Breakers for ARC]).

The recloser closes the leader if supervisory condition 3P*n*CLS (Three-Pole BK*n* Reclose Supervision) is satisfied within the duration of timer BK*n*CLSD (BK*n* Reclose Supervision Delay).

At the leader close command, the recloser starts timer BKCFD (Breaker Close Failure Delay). If the leader fails to close, the recloser sends the leader to lockout BK*n*LO after timer BKCFD expires. If the leader closes within the BKCFD time, the recloser goes to 3PRCD (Three-Pole Reclaim Time Delay) reclaim timing if NBK1 is asserted, or prepares to close the follower circuit breaker if NBK2 is asserted.

To close the follower circuit breaker, the recloser checks for two active circuit breakers in the scheme. If NBK2 is asserted, the recloser checks for a three-pole open on the follower and starts timer TBBKD (Time Between Breakers For ARC). When TBBKD expires, the recloser closes the follower breaker if FBKCEN (Follower Breaker Closing Enable) is asserted and supervisory condition 3P*n*CLS is satisfied within the duration of timer BK*n*CLSD. At the follower close command, the recloser starts timer BKCFD (Breaker Close Failure Delay). If the follower fails to close, the recloser sends the follower to lockout after timer BKCFD expires. If the leader circuit breaker is not in lockout, the recloser begins timing 3PRCD reclaim time for the leader.

If the follower breaker closes successfully, the recloser starts the 3PRCD (Three-Pole Reclaim Time Delay) timer if 79BRCT (Block Reclaim Timer) is not asserted.

3PRCD Reclaim Timing

The recloser determines subsequent state transitions during reclaim timing according to the status of Relay Word bit 3PLSHT (Three-Pole Reclose Last Shot).

3PLSHT Deasserted (Three-Pole Shot Remains)

The recloser exhibits two possible state transitions when 3PLSHT is not asserted:

- If no further trip conditions occur and timer 3PRCD expires, the recloser returns to the reset states BK*n*RS.
- If a fault occurs while the 3PRCD reclaim timer is timing, then the recloser asserts 3PARC if all three-pole initiate conditions are satisfied and goes to the beginning of the 79CY3 cycle. The recloser then recalculates and freezes the number of active circuit breakers, the leader, and the follower. The recloser then increments the shot counter and begins the next open interval timer.

3PLSHT Asserted (Last Shot)

The recloser exits the 79CY3 state via two methods while 3PLSHT is asserted:

- If no further trip conditions occur and timer 3PRCD expires, the recloser returns to the reset states BK*n*RS.
- If a fault occurs during the 3PRCD reclaim time and 3PLSHT is asserted, then the recloser goes to lockout BK*n*LO.

Lockout State From 79CY3

The recloser goes to lockout (BK*n*LO) when any of the following occur:

- The number of trips exceeds the maximum number of shots (N3PSHOT)
- Supervision condition 3P*n*CLS fails to assert in BK*n*CLSD time
- Relay Word bit 3POLINE asserts for a circuit breaker manual opening (no qualified autoreclose initiation 3PARC)
- The circuit breaker fails to close within BKCFD time
- SELOGIC equation 79DTL asserts

Single- and Three-Pole Mode

The single- and three-pole mode (SPAR/3PAR) uses elements of both the single-pole mode (SPAR) and the three-pole mode (3PAR). Reclosing begins after a single-pole trip in the single-pole cycle 79CY1 with a valid SPARC as described in *Single-Pole Mode on page 6.10*. The recloser closes the circuit breakers and proceeds to the reclaim timer SPRCD. If a fault occurs during the SPRCD reclaim time and SPLSHT is asserted, then the recloser asserts Relay Word bit 3PARC if all three-pole reclose conditions are satisfied. Upon asserting 3PARC, the recloser exits the 79CY1 cycle state and goes to the beginning of the three-pole autoreclose cycle state 79CY3. The recloser proceeds through the 79CY3 state and exits this state as described in *Three-Pole Mode on page 6.12*.

Three-Pole Priority

If a single-pole autoreclose cycle is in progress (79CY1) and the relay receives an initiation for three-pole reclosing (3PRI), the recloser immediately starts a three-pole autoreclose cycle (79CY3).

Active Circuit Breakers

The following three Relay Word bits describe when Circuit Breaker BK1 and Circuit Breaker BK2 are active for the autoreclose logic:

- NBK0, No Breaker Active in Reclose Scheme
- NBK1, One Breaker Active in Reclose Scheme
- NBK2, Two Breakers Active in Reclose Scheme

Leader and Follower Circuit Breakers

One circuit breaker is the leader and the other is the follower for circuit breaker-and-a-half and ring-bus arrangements. *Figure 6.2* illustrates a multiple circuit breaker arrangement. The leader recloses first. If the leader recloses successfully, the follower also typically recloses.

Figure 6.2 Multiple Circuit Breaker Arrangement

Choose Circuit Breaker BK1 as the leader and Circuit Breaker BK2 as the follower. If Circuit Breaker BK1 is out of service (for maintenance, for example), the relay can automatically make Circuit Breaker BK2 the leader.

The relay freezes the leader, follower, and number of active circuit breaker designations during an autoreclose cycle. If the logic receives another reclose initiation, the relay reevaluates the leader, follower, and number of active circuit breaker designations. The logic considers a circuit breaker out of service if the circuit breaker goes to lockout, and declares a circuit breaker to be in service as soon as the circuit breaker closes and is no longer in lockout.

Leader Logic

Relay settings SLBK1 (Leader Breaker = Breaker 1) and SLBK2 (Leader Breaker = Breaker 2) SELOGIC control equations determine the criteria for relay selection of the active leader. Set SLBK1 := 1 to select Circuit Breaker BK1 as the leader; set SLBK2 := 1 to select Circuit Breaker BK2 as the leader. SLBK1 has priority over SLBK2; if you set both settings to 1 or both to 0, Circuit Breaker BK1 is the leader.

Circuit Breaker BK1 is the leader for the following conditions:

- BK1 is the only circuit breaker in service
- BK1 and BK2 are in service and BK1 is selected as the leader (SLBK1 := 1)
- BK1 and BK2 are in service and the setting combination SLBK1 := 0 and SLBK2 := 1 is not in effect

Circuit Breaker BK2 is the leader for the following conditions:

- BK2 is the only circuit breaker in service
- BK1 and BK2 are in service and BK2 is selected as the leader (SLKBK1 := 0 and SLBK2 := 1)
- If neither circuit breaker is in service, there is no leader

The following three Relay Word bits describe which circuit breaker is the leader:

- LEADBK0, No Breaker In Service
- LEADBK1, Leader Breaker = Breaker 1
- LEADBK2, Leader Breaker = Breaker 2

The relay loads the corresponding circuit breaker settings into the leader Relay Word bits (LEADBK0, LEADBK1, and LEADBK2). If there is no leader (no circuit breaker is active), the relay loads a logical 0 into LEADBK1 and LEADBK2, and a logical 1 into LEADBK0.

Follower Logic

The FBKCEN SELOGIC control equation, Follower Breaker Closing Enable, defines the conditions necessary for the follower breaker to reclose.

The relay selects the follower as follows:

- If Circuit Breaker BK1 is the leader and Circuit Breaker BK2 is not locked out, then Circuit Breaker BK2 is the follower.
- If Circuit Breaker BK2 is the leader and Circuit Breaker BK1 is not locked out, then Circuit Breaker BK1 is the follower.
- If fewer than two circuit breakers are in service (NBK0 or NBK1 is asserted), then there is no follower.

The following three Relay Word bits describe which circuit breaker is the follower:

- FOLBK0, No Follower Breaker
- FOLBK1, Follower Breaker = Breaker 1
- FOLBK2, Follower Breaker = Breaker 2

If there is no follower (in the case of only one circuit breaker, for example), the relay loads a logical 0 into the follower SELOGIC control equation FBKCEN.

Dynamic Selection of Leader and Follower Circuit Breakers

The relay dynamically selects the leader and follower circuit breakers during the reclose cycle. The relay calculates the leader in the ready (reset) state. At the start of the reclose cycle, the relay freezes this calculation and sets circuit breaker designations. The leader/follower designation can dynamically change in the cycle if the leader circuit breaker goes to lockout and FBKCEN is asserted.

Set the initial leader/follower designation and follower close conditions with settings SLBK1 (Lead Breaker = Breaker 1), SLBK2 (Lead Breaker = Breaker 2), and FBKCEN (Follower Breaker Closing Enable). *Table 6.5* shows the permutations of these settings.

Table 6.5 Dynamic Leader/Follower Settings

SLBK1	SLBK2	FBKCEN	Comments
0	0	0	BK1 is the leader; BK2 is the leader only if BK1→ LO and BK2 is closed. BK2 will not close as the follower upon successful close of leader BK1.
0	0	1	BK1 is the leader; BK2 is the leader only if BK1→ LO and BK2 is closed. BK2 will close as the follower if BK1→ LO after BKCFD. BK2 will close as the follower upon successful close of the leader BK1.
0	1	0	BK2 is the leader; BK1 is the leader only if BK2→ LO and BK1 is closed. BK1 will not close as the follower upon successful close of leader BK2.
0	1	1	BK2 is the leader; BK1 is the leader only if BK2→ LO. BK1 will close if BK2→ LO after BKCFD. BK1 will close as the follower after TBBKD upon successful close of the leader BK1.
1	0	0	BK1 is the leader; BK2 is the leader only if BK1→ LO and BK2 is closed. BK2 will not close as the follower upon successful close of leader BK1.
1	0	1	BK1 is the leader; BK2 is the leader only if BK1→ LO and BK2 is closed. BK2 will close as the follower if BK1→ LO after BKCFD. BK2 will close as the follower upon successful close of the leader BK1.
1	1	0	Same as 1/0/0.
1	1	1	Same as 1/0/1.
1	0	52AA1	BK1 is the leader; BK2 to LO is the leader if BK1→ LO. BK2 will close as the follower after TBBKD upon successful close of the leader BK1.

Circuit Breaker BK1 is always the leader if SLBK1 is asserted and BK1 is not locked out. Circuit Breaker BK2 is the leader if SLBK2 is asserted, BK2 is not locked out, and SLBK1 is not asserted. The second circuit breaker can become the leader when the leader is locked out.

Setting FBKCEN does not pick the follower, but decides when the second circuit breaker can reclose. If the leader goes to lockout, then the follower goes to lockout if FBKCEN := 0. If, however, the leader is manually opened, the follower breaker can become the leader (after being manually closed) and can close via a reclose cycle if FBKCEN := 1. If you want the follower breaker to close only for specific conditions, use the enable settings to force this close requirement. For example, Circuit Breaker BK2 can dynamically become the leader if BK1 is locked out and BK2 is closed. If you do not want BK2 to become the leader, set FBKCEN := 52AA1. Also see *Example One: No Follower on page 6.17* for another method to prevent BK2 from becoming the leader.

The following examples help illustrate how the relay autoreclose logic dynamically determines the leader and follower circuit breakers. These examples describe a two circuit breaker scheme (such as used in a circuit breaker-and-a-half arrangement) as shown in *Figure 6.3*.

Example One: No Follower

This example describes recloser states when Circuit Breaker BK1 fails to reclose following the first three-pole open interval delay. Set the FBKCEN SELOGIC control equation to prevent Circuit Breaker BK2 from closing as the follower. The leader and follower selection settings are shown in *Table 6.6*.

Figure 6.3 Multiple Circuit Breaker Arrangement

Table 6.6 Leader/Follower Selection

Setting Label	Value
SLBK1	1
SLBK2	0
FBKCEN	0

Reset State and 79CY3 Cycle State

Prior to receiving initiation for a three-phase fault, the autoreclose logic resets for both circuit breakers. *Table 6.7* defines the logical state of the autoreclose logic for this example prior to the initiation of an autoreclose cycle.

Table 6.7 Example One: Reset and 79CY3 States

Relay Word Bit	Description	Logical State
NBK0	No Active Breakers in Reclose Scheme	0
NBK1	One Breaker Active in Reclose Scheme	0
NBK2	Two Active Breakers in Reclose Scheme	1
LEADBK0	No Leader Breaker	0
LEADBK1	Leader Breaker = Breaker 1	1
LEADBK2	Leader Breaker = Breaker 2	0
FOLBK0	No Follower Breaker	0
FOLBK1	Follower Breaker = Breaker 1	0
FOLBK2	Follower Breaker = Breaker 2	1

Lockout State

Circuit Breaker BK1 fails to close when the first three-pole open interval expires and goes to lockout. Circuit Breaker BK2 goes to lockout. *Table 6.8* defines the logical state of the autoreclose logic at this point.

Table 6.8 Example One: Lockout State

Relay Word Bit	Description	Logical State
NBK0	No Active Breakers in Reclose Scheme	1
NBK1	One Breaker Active in Reclose Scheme	0
NBK2	Two Active Breakers in Reclose Scheme	0
LEADBK0	No Leader Breaker	1
LEADBK1	Leader Breaker = Breaker 1	0
LEADBK2	Leader Breaker = Breaker 2	0
FOLBK0	No Follower Breaker	1
FOLBK1	Follower Breaker = Breaker 1	0
FOLBK2	Follower Breaker = Breaker 2	0

Reset State After Reclaim Time

Circuit Breaker BK2 is manually closed and now becomes active as the leader after 3PMRCD (Manual Close Reclaim Time Delay). Subsequent reclosing occurs with BK2. *Table 6.9* defines the logical state of the autoreclose logic at this point.

Table 6.9 Example One: Reset State After Reclaim Time (Sheet 1 of 2)

Relay Word Bit	Description	Logical State
NBK0	No Active Breakers in Reclose Scheme	0
NBK1	One Breaker Active in Reclose Scheme	1
NBK2	Two Active Breakers in Reclose Scheme	0
LEADBK0	No Leader Breaker	0
LEADBK1	Leader Breaker = Breaker 1	0
LEADBK2	Leader Breaker = Breaker 2	1
FOLBK0	No Follower Breaker	1

Table 6.9 Example One: Reset State After Reclaim Time (Sheet 2 of 2)

Relay Word Bit	Description	Logical State
FOLBK1	Follower Breaker = Breaker 1	0
FOLBK2	Follower Breaker = Breaker 2	0

Block Reclosing With Enable Settings

To block BK2 as leader use the enable settings; set ESPR2 := NBK2 and E3PR2 := NBK2. With these enable settings BK2 never becomes the leader circuit breaker.

Example Two: BK2 as Successful Follower and Dynamic Leader

Another example is similar to the first with SLBK1/SLBK2/FBKCEN at 1/0/1 (see *Table 6.10*).

Table 6.10 Leader/Follower Selection

Setting Label	Value
SLBK1	1
SLBK2	0
FBKCEN	1

Reset State

Prior to receiving initiation for a three-phase fault, the autoreclose logic resets for both circuit breakers. At the start of the reclose cycle, Relay Word bits LEADBK1, FOLBK2, and NBK2 are asserted (see *Table 6.11*).

Table 6.11 Example Two: Initial Reset State

Relay Word Bit	Description	Logical State
NBK0	No Active Breakers in Reclose Scheme	0
NBK1	One Breaker Active in Reclose Scheme	0
NBK2	Two Active Breakers in Reclose Scheme	1
LEADBK0	No Leader Breaker	0
LEADBK1	Leader Breaker = Breaker 1	1
LEADBK2	Leader Breaker = Breaker 2	0
FOLBK0	No Follower Breaker	0
FOLBK1	Follower Breaker = Breaker 1	0
FOLBK2	Follower Breaker = Breaker 2	1

When BK1 successfully recloses, BK2 closes as the follower after timer TBBKD (Time Between Breakers for ARC).

If BK1 goes to lockout during a reclose cycle (after BKCFD time), then BK2 will close as the follower. After timer 3PRCD (Three-Pole Reclaim Time Delay) expires, the recloser enters the reset state for BK2 (BK2RS). The recloser dynamically recalculates the leader and follower circuit breakers. BK2 becomes the leader with Relay Word bits LEADBK2, FOLBK0, and NBK1 asserted (see *Table 6.12*). When BK2 becomes the leader, the recloser immediately issues the close command to BK2 and does not add any additional SPOID or 3POID interval time.

Table 6.12 Example Two: Final Reset State

Relay Word Bit	Description	Logical State
NBK0	No Active Breakers in Reclose Scheme	0
NBK1	One Breaker Active in Reclose Scheme	1
NBK2	Two Active Breakers in Reclose Scheme	0
LEADBK0	No Leader Breaker	0
LEADBK1	Leader Breaker = Breaker 1	0
LEADBK2	Leader Breaker = Breaker 2	1
FOLBK0	No Follower Breaker	1
FOLBK1	Follower Breaker = Breaker 1	0
FOLBK2	Follower Breaker = Breaker 2	0

Example Three: BK2 as Conditional Follower

One method to program BK2 for closing only after a successful BK1 close is to set SLBK1/SLBK2/FBKCEN as in *Table 6.13*.

Table 6.13 Leader/Follower Selection

Setting Label	Value
SLBK1	1
SLBK2	0
FBKCEN	52AA1

Reset State

Prior to receiving initiation for a three-phase fault, the autoreclose logic resets for both circuit breakers. *Table 6.14* defines the logical state of the autoreclose logic for this example prior to the initiation of an autoreclose cycle.

Table 6.14 Example Three: Reset State

Relay Word Bit	Description	Logical State
NBK0	No Active Breakers in Reclose Scheme	0
NBK1	One Breaker Active in Reclose Scheme	0
NBK2	Two Active Breakers in Reclose Scheme	1
LEADBK0	No Leader Breaker	0
LEADBK1	Leader Breaker = Breaker 1	1
LEADBK2	Leader Breaker = Breaker 2	0
FOLBK0	No Follower Breaker	0
FOLBK1	Follower Breaker = Breaker 1	0
FOLBK2	Follower Breaker = Breaker 2	1

79CY3 Cycle State

The autoreclose logic receives a three-pole initiation. *Table 6.15* defines the logical state of the autoreclose logic for this example during the three-pole autoreclose cycle.

Table 6.15 Example Three: Three-Pole Cycle State

Relay Word Bit	Description	Logical State
NBK0	No Active Breakers in Reclose Scheme	0
NBK1	One Breaker Active in Reclose Scheme	0
NBK2	Two Active Breakers in Reclose Scheme	1
LEADBK0	No Leader Breaker	0
LEADBK1	Leader Breaker = Breaker 1	1
LEADBK2	Leader Breaker = Breaker 2	0
FOLBK0	No Follower Breaker	0
FOLBK1	Follower Breaker = Breaker 1	0
FOLBK2	Follower Breaker = Breaker 2	1

BK2 closes as the follower when BK1 successfully closes (after timer TBBKD).

Lockout State

Circuit Breaker BK1 must close before Circuit Breaker BK2. If Circuit Breaker BK1 fails to close and goes to lockout, then Circuit Breaker BK2 goes to lockout as well because BK2 cannot close as the follower and cannot dynamically become the leader. *Table 6.16* defines the logical state of the autoreclose logic for this example following the unsuccessful reclose attempt.

Table 6.16 Example Three: Lockout State, BK

Relay Word Bit	Description	Logical State
NBK0	No Active Breakers in Reclose Scheme	1
NBK1	One Breaker Active in Reclose Scheme	0
NBK2	Two Active Breakers in Reclose Scheme	0
LEADBK0	No Leader Breaker	1
LEADBK1	Leader Breaker = Breaker 1	0
LEADBK2	Leader Breaker = Breaker 2	0
FOLBK0	No Follower Breaker	1
FOLBK1	Follower Breaker = Breaker 1	0
FOLBK2	Follower Breaker = Breaker 2	0

Example Four: Input Selection of Leader

Figure 6.4 illustrates a circuit breaker-and-a half configuration for this particular example. The leader and follower selection settings are shown in *Table 6.17*. Circuit Breaker BK1 is out of service for maintenance and Disconnect Switch 1 is open.

Table 6.17 Leader/Follower Selection

Setting Label	Setting
SLBK1	IN106 (Disconnect 1 a contacts)
SLBK2	IN107 (Disconnect 2 a contacts)
FBKCEN	0

Figure 6.4 Leader/Follower Selection by Relay Input

Table 6.18 defines the logical state of the autoreclose logic for this example prior to the initiation of an autoreclose cycle. These conditions are frozen during an autoreclose cycle. The relay autoreclose logic can unfreeze these conditions if the relay receives another initiation.

Table 6.18 Two Circuit Breakers: Circuit Breaker BK1 Out of Service

Relay Word Bit	Description	Logical State
NBK0	No Active Breakers in Reclose Scheme	0
NBK1	One Breaker Active in Reclose Scheme	1
NBK2	Two Active Breakers in Reclose Scheme	0
LEADBK0	No Leader Breaker	0
LEADBK1	Leader Breaker = Breaker 1	0
LEADBK2	Leader Breaker = Breaker 2	1
FOLBK0	No Follower Breaker	1
FOLBK1	Follower Breaker = Breaker 1	0
FOLBK2	Follower Breaker = Breaker 2	0

Enable Autoreclose Logic for Two Circuit Breakers

Three-Pole Trip Circuit Breakers

The initial settings necessary to enable autoreclose for two three-pole trip circuit breakers are shown in *Table 6.19*.

Table 6.19 Two-Circuit-Breaker Three-Pole Reclose Initial Settings

Setting	Description	Entry
NUMBK	Number of Breakers in Scheme	2
Breaker Configuration (Breaker Monitor)		
BK1TYP[a]	Breaker 1 Trip Type	3
BK2TYP[a]	Breaker 2 Trip Type	3
Breaker 1 Inputs (Breaker Monitor)		
52AA1	N/O Contact Input—BK1 (SELOGIC Equation)	IN101
Breaker 2 Inputs (Breaker Monitor)		
52AA2	N/O Contact Input—BK2 (SELOGIC Equation)	IN102
Relay Configuration (Group)		
E79	Reclosing	Y or Y1

[a] Only applicable to products that support single-pole tripping and reclosing.

Single-Pole Trip Circuit Breakers

The initial settings necessary to enable autoreclose for two single-pole trip circuit breakers are shown in *Table 6.20*.

Table 6.20 Two-Circuit-Breaker Single-Pole Reclose Initial Settings

Setting	Description	Entry
NUMBK	Number of Breakers in Scheme	2
Breaker Configuration (Breaker Monitor)		
BK1TYP	Breaker 1 Trip Type	1
BK2TYP	Breaker 2 Trip Type	1
Breaker 1 Inputs (Breaker Monitor)		
52AA1	A-Phase N/O Contact Input—BK1 (SELOGIC Equation)	IN101
52AB1	B-Phase N/O Contact Input—BK1 (SELOGIC Equation)	IN102
52AC1	C-Phase N/O Contact Input—BK1 (SELOGIC Equation)	IN103
Breaker 2 Inputs (Breaker Monitor)		
52AA2	A-Phase N/O Contact Input—BK2 (SELOGIC Equation)	IN104
52AB2	B-Phase N/O Contact Input—BK2 (SELOGIC Equation)	IN105
52AC2	C-Phase N/O Contact Input—BK2 (SELOGIC Equation)	IN106
Relay Configuration (Group)		
E79	Reclosing	Y or Y1

Recloser Mode Enables

The SELOGIC control equations E3PR*n* and ESPR*n* set the relay for the three autoreclose modes. *Table 6.21* and *Table 6.22* illustrate how to enable the autoreclose modes per circuit breaker.

Table 6.21 Circuit Breaker BK1 Modes of Operation

E3PR1	ESPR1[a]	Result
0	0	Autoreclose disabled
0	1	Single-pole autoreclose only enabled
1	0	Three-pole autoreclose only enabled
1	1	Single- and three-pole autoreclose enabled

[a] Only applicable to relays that support single-pole reclosing.

E3PR1 is the SELOGIC control equation that enables three-pole autoreclose for Circuit Breaker BK1. You can assign this setting to a control input. ESPR1 is the SELOGIC control equation that enables single-pole autoreclose for Circuit Breaker BK1. You can assign this setting to a control input.

When ESPR1 equals logical 1, the relay can attempt a single-pole autoreclose cycle for Circuit Breaker BK1. If ESPR1 equals logical 0, the relay cannot initiate a single-pole autoreclose cycle for Circuit Breaker BK1.

When E3PR1 equals logical 1, the relay can attempt a three-pole autoreclose cycle for Circuit Breaker BK1. If E3PR1 equals logical 0, the relay goes to lockout following a three-pole trip for Circuit Breaker BK1 and the corresponding leader logic transfers automatically to Circuit Breaker BK2.

Table 6.22 Circuit Breaker BK2 Modes of Operation

E3PR2	ESPR2[a]	Result
0	0	Autoreclose disabled
0	1	Single-pole autoreclose only enabled
1	0	Three-pole autoreclose only enabled
1	1	Single- and three-pole autoreclose enabled

[a] Only applicable to relays that support single-pole reclosing.

E3PR2 is the SELOGIC control equation that enables three-pole autoreclose for Circuit Breaker BK2. You can assign this setting to a control input. ESPR2 is the SELOGIC control equation that enables single-pole autoreclose for Circuit Breaker BK2. You can assign this setting to a control input.

When ESPR2 equals logical 1, the relay can attempt a single-pole autoreclose cycle for Circuit Breaker BK2. If ESPR2 equals logical 0, the relay cannot initiate a single-pole autoreclose cycle for Circuit Breaker BK2.

When E3PR2 equals logical 1, the relay can attempt a three-pole autoreclose cycle for Circuit Breaker BK2. If E3PR2 equals logical 0, the relay goes to lockout following a three-pole trip for Circuit Breaker BK2.

Assert one or all SELOGIC control equations E3PR1, E3PR2, ESPR1, and ESPR2 according to your reclosing requirements.

For single-pole reclosing, set ESPR1 := 1 and set NSPSHOT to the desired number of single-pole reclose shots. For three-pole reclosing, set E3PR1 := 1 and set N3PSHOT for the desired number of three-pole shots. For both single-pole and three-pole reclosing, set ESPR1 := 1, E3PR1 := 1, and configure settings NSPSHOT and N3PSHOT for the desired number of reclose shots of each type (see *Recloser Mode Enables on page 6.8*).

Example 6.1 Conditional Three-Pole Tripping for Circuit Breaker BK2

Your system reclosing requirement is that Circuit Breaker BK2 always three-pole trips, unless Circuit Breaker BK2 is the leader. (This occurs when Circuit Breaker BK1 is out of service.) Program SELOGIC control equation ESPR2 as follows:

ESPR2 := **LEADBK2 AND BK1LO** Single-Pole Reclose Enable—BK2 (SELOGIC Equation)

Trip Logic and Reclose Sources for Single-Pole Breaker Applications

Internal Recloser

Program the recloser function to drive the trip logic with Relay Word bits R3PTE (Recloser Three-Pole Trip Enable), R3PTE1 (Circuit Breaker BK1 Recloser Three-Pole Trip Enable) and R3PTE2 (Circuit Breaker BK2 Recloser Three-Pole Trip Enable) as follows:

E3PT := **R3PTE** Three-Pole Trip Enable (SELOGIC Equation)

E3PT1 := **R3PTE1** Breaker 1 Three-Pole Trip (SELOGIC Equation)

E3PT2 := **R3PTE2** Breaker 2 Three-Pole Trip (SELOGIC Equation)

These settings connect the internal recloser for both three-pole reclosing and single-pole reclosing.

Enter enable settings ESPR1 and E3PR1 as appropriate for your application. By default, the relay is a single-pole tripping relay; that is, if E3PT is logical 0 and E3PT1 equals logical 0, the relay can single-pole trip Circuit Breaker BK1. If E3PT1 equals logical 1, the relay can only three-pole trip Circuit Breaker BK1. The same conditions apply to setting E3PT2 and Circuit Breaker BK2.

Table 6.23 summarizes the relay trip logic enable options.

Table 6.23 Trip Logic Enable Options

Enable Condition			Circuit Breaker BK1		Circuit Breaker BK2	
E3PT	E3PT1	E3PT2	Single-Pole Trip	Three-Pole Trip	Single-Pole Trip	Three-Pole Trip
0	0	0	x		x	
0	0	1	x			x
0	1	0		x	x	
0	1	1		x		x
1	0	0		x		x
1	0	1		x		x
1	1	0		x		x
1	1	1		x		x

Relay Word bits R3PTE1 and R3PTE2 both equal logical 1 for any of the following conditions when Global setting NUMBK (Number of Breakers in Scheme) is 2 and SPLSHT (Single-Pole Last Shot) is asserted (see *Figure 6.9*):

- BK1TYP and BK2TYP equal 3 (Circuit Breaker 1 and Circuit Breaker 2 Trip Type)
- NSPSHOT := N (Number of Single-Pole Reclosures)

External Recloser

If reclosing is performed by an external relay, assert SELOGIC control equations E3PT, E3PT1, and E3PT2 via control inputs (for example):

E3PT := **IN104** Three-Pole Trip Enable (SELOGIC Equation)

E3PT1 := **IN105** Breaker 1 Three-Pole Trip (SELOGIC Equation)

E3PT2 := **IN106** Breaker 2 Three-Pole Trip (SELOGIC Equation)

Connect the external recloser single-pole trip output signal to IN104, the Circuit Breaker BK1 trip type signal to IN105, and the Circuit Breaker BK2 trip type signal to IN106. Other external recloser signals are required; consult the external recloser documentation for interconnection with the relay.

In installations where the external reclosing relay does not provide three-phase trip control signals, the TOP (Trip during Open-Pole) Relay Word bit can be used in the E3PT setting. This Relay Word bit will assert just after a single- or two-pole trip, and remain asserted until the TOPD timer expires. If a new trip occurs during this time, the E3PT := TOP setting would then cause a three-pole trip.

Autoreclose Logic Diagrams

NOTE: If E79 := N, the autoreclose logic is not processed and the resultant Relay Word Bits are forced to zero.

Figure 6.5 Circuit Breaker Pole-Open Logic Diagram—Single-Pole Relays

Figure 6.6 Circuit Breaker Pole-Open Logic Diagrams—Three-Pole Relays

Figure 6.7 Line-Open Logic Diagram When E79 := Y

Figure 6.8 Line-Open Logic Diagram When E79 := Y1

Figure 6.9 Single-Pole Reclose Enable

Figure 6.10 Three-Pole Reclose Enable

Figure 6.11 One Circuit Breaker Single-Pole Cycle State (79CY1)

Figure 6.12 One Circuit Breaker Three-Pole Cycle State (79CY3)

Figure 6.13 Two Circuit Breakers Single-Pole Cycle State (79CY1) When E79 := Y

Figure 6.13 Two Circuit Breakers Single-Pole Cycle State (79CY1) When E79 := Y (Continued)

Figure 6.14 Two Circuit Breakers Single-Pole Cycle State (79CY1) When E79 := Y1

Figure 6.14 Two Circuit Breakers Single-Pole Cycle State (79CY1) When E79 := Y1 (Continued)

Figure 6.15 Two Circuit Breakers Three-Pole Cycle State (79CY3) When E79 := Y

Figure 6.15 Two Circuit Breakers Three-Pole Cycle State (79CY3) When E79 := Y (Continued)

Figure 6.15 Two Circuit Breakers Three-Pole Cycle State (79CY3) When E79 := Y (Continued)

Figure 6.16 Two Circuit Breakers Three-Pole Cycle State (79CY3) When E79 := Y1

Figure 6.16 Two Circuit Breakers Three-Pole Cycle State (79CY3) When E79 := Y1 (Continued)

Figure 6.16 Two Circuit Breakers Three-Pole Cycle State (79CY3) When E79 := Y1 (Continued)

Manual Closing

Manual closing is available via the relay to issue a close to the circuit breaker(s) via the same close logic outputs used in autoreclosing (Relay Word bits BK1CL and BK2CL for as many as two circuit breakers). The manual close logic can be user-configured in most any manner with SELOGIC settings BK1MCL and BK2MCL. *Figure 6.17* is a flowchart of the manual close logic. This logic is enabled with Manual Closing enable setting EMANCL := Y.

Figure 6.17 only details the manual close logic for one circuit breaker (breaker BK1). The manual close logic for a second circuit breaker (breaker BK2), if enabled (Global setting NUMBK := 2), is similar. The only difference between the breaker BK1 and breaker BK2 manual close logic in *Figure 6.17* is the substitution of settings and logic outputs (BK2MCL for BK1MCL, ULCL2 for ULCL1, etc.). A manual close is issued for breaker BK1 if all of the following are true:

- A new manual close signal for breaker BK1 is detected (rising-edge assertion of SELOGIC setting BK1MCL)
- No unlatch close conditions are present (SELOGIC setting ULCL1 deasserted)
- No close is presently in progress for breaker BK1 (Relay Word bit output BK1CL is deasserted)

If a manual close is successfully issued for breaker BK1, then:

- Close logic output BK1CL asserts
- The close failure timer starts timing

If breaker BK1 closes successfully, then:

- The unlatch close condition asserts (indicating breaker closure)
- Close logic output BK1CL deasserts

If breaker BK1 does not close successfully, then:

- The close failure timer times out (Relay Word bit BK1CFT asserts momentarily)
- Close logic output BK1CL deasserts

Note in *Figure 6.17* that if breaker BK1 manual close logic is actively operating (as described in the preceding steps), then breaker BK2 manual close logic cannot be actively operating. Breaker BK2 manual close logic only has a chance to operate if breaker BK1 manual close logic is not actively operating and two breakers are enabled for the scheme (Global setting NUMBK := 2). Thus, manual closing can only be attempted for one breaker at a time.

Figure 6.17 Manual Close Logic

Voltage Checks for Autoreclosing and Manual Closing

Voltage elements are available for a final check of line and bus voltages before an autoreclose or manual close is issued. These voltage elements and corresponding pickup settings are enabled with Reclosing Voltage Check enable setting EVCK := Y. *Figure 6.18* shows the application of these voltage elements and *Figure 6.19* and *Figure 6.20* show their implementation. Check voltages for arrangements of as many as two circuit breakers (Global setting NUMBK := 2), as shown in *Figure 6.18*. If the relay is only connected to a single breaker (Global setting NUMBK := 1), then settings 27BK2P and 59BK2P and their associated elements (LLDB2, DLDB2, and DLLB2) are not available.

NOTE: For SV subscriber and TiDL relays, logic that includes the LLDB1, DLLB1, DLDB1, LLDB2, DLLB2, DLDB2 Relay Word bits must be supervised with logic that ensures that the line and bus voltages are OK. For example, LLDB1 AND (NOT(VYBK OR VZBK)).

Voltages VS1 and VS2 in *Figure 6.18*, *Figure 6.19*, and *Figure 6.20* are populated by the synchronism-check settings. For VS1 and VS2, the voltages are determined by the corresponding SYNCS1, ASYNCS1, and ALTS1 settings for VS1, and the SYNCS2, ASYNCS2, and ALTS2 settings for VS2. When EISYNC := N, *Figure 6.19* logic is active and VP is determined by the SYNCP setting. When EISYNC := Y, *Figure 6.20* logic is active and VP1 is the Breaker 1 synchronism-check polarizing voltage determined by the SYNCP1, ASYNP11, ASYNP12, ALTP11, and ALTP12 settings, and VP2 is the Breaker 2 synchronism-check polarizing voltage determined by the SYNCP2, ASYNP21, ASYNP22, ALTP21, and ALTP22 settings. Review details of synchronism checking in the Protection section of the desired product-specific instruction manual.

When EISYNC := N, the pickup settings in *Figure 6.19* are made on the VP voltage base. VP is the voltage reference for voltage angle and magnitude. Only voltage magnitude is of concern for the settings in *Figure 6.19*, not voltage angle.

When EISYNC := Y, pickup settings 27LP and 59LP in *Figure 6.20* are not breaker-independent and must be made to take into account both the VP1 (Breaker 1) and VP2 (Breaker 2) voltage bases. Take into account any compensating factors by using the synchronism-check logic; review details of synchronism checking in *Section 5: Protection Functions* in the product-specific instruction manual for the impact of compensating factors and active, alternative polarizing voltages.

Figure 6.18 implies that three-phase voltage is available from the line PTs. But, resultant voltage VP corresponds to only one phase of this three-phase voltage (e.g., setting SYNCP = VAY; VP is the normalized voltage from voltage input VAY). All the voltage elements in *Figure 6.19* are single-phase voltage elements, detecting live or dead voltage on the bus side with a single-phase voltage element, and likewise on the line side.

Whether or not synchronism-check logic is used, it still has to be enabled for the respective breaker (E25BK1 := Y, Y1, or Y2 and E25BK2 := Y, Y1, or Y2) to allow the corresponding voltage source selection settings to be made.

Live Line/Live Bus

Note in *Figure 6.18* that live line/live bus is not available for either circuit breaker. Voltage elements 59VP, 59VS1, and 59VS2, described in the *Section 5: Protection Functions* of the desired product-specific instruction manual, are available for such a function (e.g., 59VP AND 59VS1 for live line/live bus 1).

Supervising Circuit Breaker Closing with Voltage Checks

Supervising Autoreclosing

For a fault on the line in *Figure 6.18*, both breakers trip open and the lead breaker recloses first. For example, presume the lead breaker closes only if its respective bus is live and the line is dead (dead line/live bus; see *Figure 6.18*). Then, after successful reclose of the lead breaker, the follower breaker closes on synchronism check. Such reclose supervision logic is realized as follows for respective breakers BK1 and BK2:

3P1CLS := **LEADBK1 AND DLLB1 OR FOLBK1 AND 25A1BK1 OR …**

3P2CLS := **LEADBK2 AND DLLB2 OR FOLBK2 AND 25A1BK2 OR …**

Note that the lead breaker and follower breaker supervision (Relay Word bits LEADBK*n* and FOLBK*n*, respectively) provides dynamic control for reclose supervision. One, but not both, of the breakers can reclose for a dead line/live bus condition (lead breaker), while the other then closes for a synchronism-check condition (follower breaker).

Supervising Manual Closing

Voltage checks can also be used to supervise manual closing. For example, presume that manual closing of breaker BK1 (*Figure 6.18*) should not be allowed if the respective bus is dead (dead line/dead bus or live line/dead bus condition):

BK1MCL := **NOT(DLDB1 OR AND LLDB1) AND (…)**

NOTE: This is an example application with EISYNC := N.

Figure 6.18 Voltage Check Element Applications

NOTE: Active logic when EISYNC := N.

Figure 6.19 Voltage Check Element Logic (EISYNC := N)

NOTE: Active logic when EISYNC := Y.

Figure 6.20 Voltage Check Element Logic (EISYNC := Y)

Settings and Relay Word Bits for Autoreclosing and Manual Closing

See the product-specific instruction manual Group Settings tables related to Reclose under the Settings section for a complete list of all autoreclose related settings. *Table 6.24* provides all of the Relay Word bits for autoreclosing.

Table 6.24 Autoreclose Logic Relay Word Bits (Sheet 1 of 2)

Name	Description
BK1RS	Breaker 1 in Reset State
BK2RS	Breaker 2 in Reset State
79CY1[a]	Relay in Single-Pole Reclose Cycle State
79CY3	Relay in Three-Pole Reclose Cycle State
BK1LO	Breaker 1 in Lockout State
BK2LO	Breaker 2 in Lockout State
SPARC[a]	Single-Pole Reclose Initiate Qualified
SPOISC[a]	Single-Pole Open Interval Supervision Condition
SPOI[a]	Single-Pole Open Interval Timing
SPSHOT0[a]	Single-Pole Shot Counter = 0
SPSHOT1[a]	Single-Pole Shot Counter = 1
SPSHOT2[a]	Single-Pole Shot Counter = 2
SPLSHT[a]	Single-Pole Reclose Last Shot
SPRCIP[a]	Single-Pole Reclaim In-Progress
3PARC	Three-Pole Reclose Initiate Qualified
3POISC	Three-Pole Open Interval Supervision Condition
3POI	Three-Pole Open Interval Timing
3PSHOT0	Three-Pole Shot Counter = 0
3PSHOT1	Three-Pole Shot Counter = 1
3PSHOT2	Three-Pole Shot Counter = 2
3PSHOT3	Three-Pole Shot Counter = 3
3PSHOT4	Three-Pole Shot Counter = 4
3PLSHT	Three-Pole Reclose Last Shot
3PRCIP	Three-Pole Reclaim In-Progress
SPOBK1[a]	Single-Pole Open Breaker 1
2POBK1[a]	Two Poles Open Breaker 1
3POBK1	Three-Pole Open Breaker 1
SPOBK2[a]	Single-Pole Open Breaker 2
2POBK2[a]	Two Poles Open Breaker 2
3POBK2	Three-Pole Open Breaker 2
3POBK1	Three-Pole Open Breaker 1
3POLINE	Three-Pole Open Line
R3PTE	Three-Pole Tripping and Reclosing Only
R3PTE1	Recloser Three-Pole Trip Enable -BK1

Table 6.24 Autoreclose Logic Relay Word Bits (Sheet 2 of 2)

Name	Description
R3PTE2	Recloser Three-Pole Trip Enable -BK2
BK1CL	Breaker 1 Close Command
BK2CL	Breaker 2 Close Command
BK1CLST	Breaker 1 Close Supervision Delay Timed Out
BK2CLST	Breaker 2 Close Supervision Delay Timed Out
BK1CFT	Breaker 1 Close Failure Delay Timed Out
BK2CFT	Breaker 2 Close Failure Delay Timed Out
BK1CLSS	Breaker 1 in Close Supervision State
BK2CLSS	Breaker 2 in Close Supervision State
BK1EXT	Breaker 1 Closed Externally
BK2EXT	Breaker 2 Closed Externally
BK1RCIP	BK1 Reclaim in Progress
BK2RCIP	BK2 Reclaim in Progress
79STRT	Relay in Start State
TBBK	Time Between Breakers Timing
LEADBK0	No Leader Breaker
LEADBK1	Leader Breaker = Breaker 1
LEADBK2	Leader Breaker = Breaker 2
FOLBK0	No Follower Breaker
FOLBK1	Follower Breaker = Breaker 1
FOLBK2	Follower Breaker = Breaker 2
NBK0	No Breaker Active in Reclose Scheme
NBK1	One Breaker Active in Reclose Scheme
NBK2	Two Breakers Active in Reclose Scheme
LLDB1	Live Line—Dead Bus 1 (59L AND 27BK1)
DLLB1	Dead Line—Live Bus 1 (27L AND 59BK1)
DLDB1	Dead Line—Dead Bus 1 (27L AND 27BK1)
LLDB2	Live Line—Dead Bus 2 (59L AND 27BK2)
DLLB2	Dead Line—Live Bus 2 (27L AND 59BK2)
DLDB2	Dead Line—Dead Bus 2 (27L AND 27BK2)

[a] Only applicable to products that support single-pole reclosing.

SECTION 7

Metering

The relay provides extensive capabilities for metering important power system parameters.

This section provides basic information about metering capabilities in typical SEL-400 series relays. Not all SEL-400 series relays support every metering feature described in this section. See *Section 7: Metering, Monitoring, and Reporting* of the product-specific instruction manual for information on the specific metering capabilities of a specific relay.

The SEL-400 series relays typically provide the following metering modes for measuring power system operations:

- *Instantaneous Metering on page 7.2*
- *Maximum/Minimum Metering on page 7.5*
- *Demand Metering on page 7.6*
- *Energy Metering on page 7.10*
- *Synchrophasor Metering on page 7.10*
- *Battery Metering on page 7.11*
- *RTD Metering on page 7.12*
- *Protection Math Variable Metering on page 7.12*
- *Automation Math Variable Metering on page 7.13*
- *MIRRORED BITS Remote Analog Metering on page 7.13*

Monitor present power system operating conditions with instantaneous metering. Maximum/Minimum metering displays the largest and smallest system deviations since the last reset. Demand metering includes either thermal or rolling analysis of the power system and peak demand metering. Energy metering displays the megawatt-hours imported, megawatt-hours exported, and total megawatt-hours. Time-synchronized metering displays the line voltage and current synchrophasors.

The relay processes various sets of currents and voltages, depending on the specific relay.

Use the **MET** command to access the metering functions. Issuing the **MET** command with no options returns fundamental measurement quantities. The **MET** command followed by a number, **MET *k***, specifies the number of times the command will repeat (*k* can range from 1–32767). This is useful for troubleshooting or investigating uncharacteristic power system conditions.

Table 7.1 lists some common **MET** command variants.

Table 7.1 MET Command (Sheet 1 of 2)

Name	Description
MET	Display fundamental line metering information
MET RMS	Display rms line metering information

Table 7.1 MET Command (Sheet 2 of 2)

Name	Description
MET M	Display line maximum/minimum metering information
MET RM	Reset line maximum/minimum metering information
MET D	Display demand line metering information
MET RD	Reset demand line metering information
MET RP	Reset peak demand line metering information
MET E	Display energy line metering information
MET RE	Reset energy line metering information
MET BAT	Display dc battery monitor information
MET RBM	Reset battery monitor min/max measurements
MET PM	Display phasor measurement (synchrophasor) metering information
MET RTD	Display SEL-2600 temperature quantities
MET PMV	Display protection math variable values
MET AMV	Display automation math variable values
MET ANA	Display remote analogs received from MIRRORED BITS

Instantaneous Metering

Use instantaneous metering to monitor power system parameters in real time. The relay typically provides these fundamental frequency readings:

- Fundamental frequency phase voltages and currents
- Phase-to-phase voltages
- Sequence voltages and currents
- Fundamental real, reactive, and apparent power
- Displacement power factor

NOTE: After startup, automatic restart, or a warm start, including settings change and group switch, in the beginning period of 20 cycles, the 10-cycle average values are initialized with the latest calculated 1-cycle average values.

You can also typically monitor these real-time rms quantities (with harmonics included):

- RMS phase voltages and currents
- Real and apparent rms power
- True power factor

Power

The instantaneous power measurements are derived from 10-cycle averages that the relay reports by using the generator condition of the positive power flow convention; for example, real and reactive power flowing out (export) is positive, and real and reactive power flowing in (import) is negative (see *Figure 7.1*).

NOTE: The SEL-487B does not include power and power factor in its metering reports.

For power factor, LAG and LEAD refer to whether the current lags or leads the applied voltage. The reactive power Q is positive when the voltage angle is greater than the current angle ($\theta V > \theta I$), which is the case for inductive loads where the current lags the applied voltage. Conversely, Q is negative when the voltage angle is less than the current angle ($\theta V < \theta I$); this is when the current *leads* the voltage, as in the case of capacitive loads.

Figure 7.1 Complex Power (P/Q) Plane

Some products include Relay Word bits to indicate the leading or lagging power factor (see *Section 11: Relay Word Bits* in the product-specific instruction manual). In the case of a unity power factor or loss of phase or potential condition, the resulting power factor angle would be on this axis of the complex power (P/Q) plane shown in *Figure 7.1*. This would cause the power factor Relay Word bits to rapidly change state (chatter). Be aware of expected system conditions when monitoring the power factor Relay Word bits. It is not recommended to use chattering Relay Word bits in the SER or anything that will trigger an event.

High-Accuracy Instantaneous Metering

The relay is a high-accuracy metering instrument. *Table 7.2* and *Table 7.3* show the metering accuracy for the relay instantaneous metering quantities at nominal power system frequency and at 20°C. Use a method similar to that in *Example 7.1* to compute exact error coefficients.

NOTE: The SEL-487B does not provide frequency metering because it does not support frequency tracking.

Table 7.2 Instantaneous Metering Accuracy—Voltages, Currents, and Frequency

Quantity	Magnitude Accuracy		Phase Accuracy
	Range	Specification	
Vϕ, Vϕϕ	33.5 – 200 $V_{L–N}$	± 0.1%	±0.5°
3V0, V1, 3V2	33.5 – 200 $V_{L–N}$	± 0.15%	±0.1°
Iϕ	(0.5 – 3)• I_{NOM}	±0.2% ± (0.8 mA) • I_{NOM}	±0.2°
3I0, I1, 3I2	(0.5 – 3)• I_{NOM}	± 0.3% ± (1.0 mA) • I_{NOM}	±0.3°
FREQ	40–65 Hz	±0.01 Hz	

Table 7.3 Instantaneous Metering Accuracy—Power

Quantity	Description	Power Factor	Accuracy (%)[a]
At 0.1 • I_{NOM}			
3P	Three-phase rms real power	Unity	±0.40
		–0.5 or +0.5	±0.70
$3Q_1$	Reactive power	–0.5 or +0.5	±0.50
At 1.0 • I_{NOM}			
3P	Three-phase fundamental real power	Unity	±0.40
		–0.5 or +0.5	±0.40
$3Q_1$	Reactive power	–0.5 or +0.5	±0.40

[a] Power accuracy is valid for applied currents in the range (0.1–1.2) • I_{NOM}, and applied voltages from 33.5–75 V.

Example 7.1 Calculating Exact Error Coefficients

Consider the case of a 5 A relay during normal operating conditions. The secondary current in the CT is 1.0 A for nominal system operation. Noting that this current is greater than 10 percent of I_{NOM} (1 A > 0.5 A), calculate the error coefficient:

$$\begin{aligned} \text{error} &= \pm(0.2\% \bullet 1.0\text{ A}) \pm (0.8\text{ mA} \bullet I_{NOM}) \\ &= \pm(0.002 \bullet 1.0\text{ A}) \pm (0.0008\text{ A} \bullet 5) \\ &= \pm(0.002\text{A} \pm 0.004\text{A}) \\ &= +0.002\text{ A to } +0.006\text{ A} \\ &\quad \text{and} \\ &= -0.006\text{ A to } -0.002\text{ A} \end{aligned}$$

Equation 7.1

Figure 7.2 represents the calculated accuracy range. The error is very small, indicating that the relay measures normal operating currents accurately.

Figure 7.2 Typical Current Measuring Accuracy

Example 7.1 Calculating Exact Error Coefficients (Continued)

When you use *Equation 7.1*, you add an error amount related to the nominal current rating of the relay, $I_{NOM.}$ Use just the numeric portion of I_{NOM}, either "5" for a 5 A relay or "1" for a 1 A relay; do not use the unit (A). The errors in *Equation 7.1* are very small and qualify the relay as a high-accuracy meter.

Maximum/Minimum Metering

The relay measures and retains the deviations of the power system since the last maximum/minimum reset. Knowing these maximum and minimum quantities can help you operate your power system more effectively in a variety of ways. For example, you can benefit from maximum/minimum metering information by using it to track power flow for troubleshooting, planning future expansion, and scheduling maintenance.

NOTE: Not all SEL-400 series relays support maximum/minimum metering.

The relay provides maximum/minimum metering for a variety of line and breaker quantities, as well as for dc battery voltage. The relay also records the maximum values of the sequence voltages and sequence currents.

View or Reset Maximum/Minimum Metering Information

The relay shows time-stamped maximum/minimum quantities when you use a communications port or ACSELERATOR QuickSet SEL-5030 Software to view these quantities. In addition, you can read the maximum/minimum quantities on the relay front-panel LCD screen.

To reset the maximum/minimum values, use the **MET RM** command from a communications terminal, or use the RESET button in the QuickSet **HMI > Meter and Control > Maximum/Minimum** window, or answer `Y` and press ENT at the `Maximum/Minimum` submenu reset prompt on the front-panel LCD screen. You can also reset maximum/minimum metering with Global settings (typically RST-MML, RSTMMB1, and RSTMMB2).

Maximum/Minimum Metering Updating and Storage

The relay updates maximum/minimum values once per power system cycle. The relay stores maximum/minimum values and the corresponding dates and times to nonvolatile storage once per day. If greater than a previously stored maximum or less than a previously stored minimum, the new value overwrites the previous value. Should the relay lose control power, it will restore the maximum/minimum information saved at 23:50 hours on the previous day.

The relay updates maximum/minimum values under the following conditions:

- DFAULT is deasserted (equals logical 0)
- The metering value is greater than the previous maximum, or less than the previous minimum, for 2 cycles
- Voltage input is greater than 13 V secondary
- Current input is greater than 0.05 • I_{NOM} (in secondary amperes)

Megawatt and megavar maximum/minimum values are subject to the above voltage thresholds, current thresholds, and conditions.

FAULT SELOGIC Control Equation

The relay suspends updating maximum/minimum metering when SELOGIC control equation FAULT asserts to logical 1. If there is a fault, the elements programmed in FAULT pick up and assert Relay Word bit DFAULT (Delayed FAULT Suspend). This Relay Word bit remains asserted for one minute after SELOGIC control equation FAULT deasserts. While DFAULT is asserted, the relay does not record maximum/minimum data.

In addition, the relay also suspends demand metering during the time that Relay Word bit DFAULT is asserted.

Demand Metering

Economic operation of the power system involves the proper allocation of the load demand among the available generating units. By knowing the demand requirements at different points in the system and at different times of the day you can optimize your system generation resources or your consumption of electric power. The relay provides you this demand information and enables you to operate your power system with an effective economic strategy.

NOTE: Not all SEL-400 series relays support demand metering.

The relay uses longer-term accumulations of the metering quantities for reliable demand data.

Thermal Demand and Rolling Demand

Two methods exist for measuring power system current and power demand. These methods are thermal demand metering and rolling demand metering. *Figure 7.3* and *Figure 7.4* illustrate the step input response of the two demand measuring methods with setting DMTC (demand meter time constant) at 15 minutes.

Thermal Demand

Thermal demand is a continuous exponentially increasing or decreasing accumulation of metered quantities. Thermal demand measurement is similar to parallel RC network integration. Thermal demand metering response is at 90 percent (0.9 per unit) of the full applied value after a period equal to the DMTC setting (15 minutes in *Figure 7.3*).

Figure 7.3 Thermal Demand Metering

Rolling Demand

Rolling demand is a sliding time-window arithmetic average. Rolling demand measurement is similar to a step-sampled A/D conversion system. *Figure 7.4* shows the rolling demand response for a step input for a demand meter time constant of 15 minutes (DMTC := 15). The relay divides the DMTC period into three 5-minute intervals and averages the three DMTC subinterval samples every DMTC period. *Table 7.4* lists the rolling demand response for four DMTC periods shown in *Figure 7.4*. Rolling demand metering response is at 100 percent (1.0 per unit) of the full applied value after a time equal to the fourth DMTC period (see *(d)* in *Figure 7.4*).

Table 7.4 Rolling Demand Calculations

DMTC Period (see Figure 9.18)	1/3 DMTC Interval (minutes)	Interval Sample (per unit)	Rolling Demand Total	Rolling Demand Calculation	Rolling Demand Response (per unit)
(a)	–5 to 0	0	0	0 / 3	0
(b)	0 to 5	1	1	1 / 3	0.33
(c)	5 to 10	1	2	2 / 3	0.67
(d)	10 to 15	1	3	3 / 3	1.00

Figure 7.4 Rolling Demand Metering

Demand Metering Settings

Use the demand metering enable setting EDEM to select the demand metering type (thermal or rolling) appropriate to your needs. Use demand pickup settings (typically PDEMP, QDEMP, and GDEMP) to set alarm thresholds to notify you when demand currents exceed preset operational points.

NOTE: Changing EDEM or DMTC resets the demand meter values to zero. This also applies to changing the active settings group where either setting EDEM or DMTC is different in the new active settings group. (Changing demand current pickup settings PDEMP, GDEMP, and QDEMP will not affect the demand meters.)

Figure 7.5 shows how the relay applies the demand current pickup settings over time. When residual-ground demand current IG(DEM) exceeds the corresponding demand pickup setting GDEMP, Relay Word bit GDEM asserts to logical 1. Use these demand current logic outputs (PDEM, GDEM, and QDEM) for control or alarm for high loading or unbalance conditions.

Figure 7.5 Demand Current Logic Outputs

View or Reset Demand Metering Information

The relay shows demand metering quantities and time-stamped peak demand quantities when you use a communications port or QuickSet to view these quantities. In addition, you can read the demand and peak demand quantities on the relay front-panel LCD screen.

To reset the demand metering values use the **MET RD** command from a communications terminal, or use the RESET button in the QuickSet **HMI > Meter and Control > Demand/Peak** window, or answer Y and press ENT at the Demand Submenu reset demand prompt on the front-panel LCD screen. The relay begins the demand meter sampling period from the time of the demand meter reset.

To reset the peak demand metering values, enter the **MET RP** command from a communications terminal, or use the RESET button in the QuickSet **HMI > Meter and Control > Demand/Peak** window, or answer Y and press ENT at the Demand Submenu reset peak demand prompt on the front-panel LCD screen. You can also reset demand metering with Global settings RST_DEM and RST_PDM (for demand and peak demand) when EDRSTC (Data Reset Control) is Y.

Demand Metering Updating and Storage

The relay updates demand and peak demand values once per second. The relay also stores peak demand values and the date and time these occurred to nonvolatile storage once per day (it overwrites the previous stored value if it is exceeded). Should the relay lose control power, it will restore the peak demand information saved at 23:50 hours on the previous day.

Demand metering updating and peak recording is suspended during the time that SELOGIC control equation FAULT asserts Relay Word bit DFAULT (Delayed FAULT Suspend).

Energy Metering

Energy is the power consumed or developed in the electric power system measured over time. You can use accurate accounting of power system energy flow to manage billing revenues, whether your system is a net energy producer or consumer. Time-synchronized demand and energy measurements make demand and energy metering information even more useful for power system status applications.

NOTE: Not all SEL-400 series relays support energy metering. The SEL-487E performs energy calculations using fundamental active and reactive power quantities.

The relay integrates energy imported and exported on a per-phase basis every second. As in demand metering, the relay uses the longer-term accumulations of rms or true real power for reliable energy data.

View or Reset Energy Metering Information

You can read the energy metering quantities by using a communications port, QuickSet, or the relay front-panel LCD screen.

To reset the energy values, use the **MET RE** command from a communications terminal, or use the RESET button in the QuickSet **HMI > Meter and Control > Energy** window, or answer Y and press ENT at the Energy Meter submenu reset prompt on the front-panel LCD screen. You can also reset energy metering with Global setting RST_ENE when EDRSTC (Data Reset Control) is Y.

Energy Metering Updating and Storage

The relay updates energy values once per second. The relay also stores energy values to nonvolatile storage once every four hours, referenced from 23:50 hours (it overwrites the previously stored value if it is exceeded). Should the relay lose control power, it restores the energy values saved at the end of the last four-hour period.

Synchrophasor Metering

The relay provides synchrophasor measurement with an angle reference according to IEEE C37.118. The relay calculates the phasor measurement quantities 50 or 60 times per second, depending on the nominal system frequency contained in Global setting NFREQ.

NOTE: Not all SEL-400 series relays support synchrophasor measurements.

When you issue the **MET PM** ***time*** command, the relay captures the time-synchronized data for the given trigger time (specify ***time*** in 24-hour format). The relay displays the synchrophasor data immediately after the time trigger.

The synchrophasor measurements are only valid when a suitable high-accuracy IRIG-B or Precision Time Protocol (PTP) time source is connected to the relay, as indicated by Relay Word bit TSOK = logical 1.

The **MET PM** command is only available when the relay is configured for phasor measurement functions (Global settings) and the relay is in high-accuracy time-keeping mode.

Battery Metering

The relay monitors battery system voltages and records time stamps for voltage excursions. In addition, the relay records maximum and minimum battery voltages. *Figure 7.6* shows a sample dc battery monitor meter report. Use the **MET BAT** command from a communications terminal to obtain this report.

```
=>>MET BAT <Enter>

Relay 1                                    Date: 06/07/2008  Time: 22:51:47.067
Station A                                  Serial Number: 2008030645

Station Battery        VDC      VDCPO     VDCNE      VAC
   VDC1 (V)            115.86    57.32    -58.54     0.01

             VDC1(V)    Date       Time
Minimum       105.86 04/07/2008  22:43:04.022
Enter L-Zone         04/07/2008  22:40:14.162
Exit L-Zone          04/07/2008  22:44:09.223


Maximum       125.86 04/09/2008  12:34:14.321
Enter H-Zone         04/09/2008  12:31:32.543
Exit H-Zone          04/09/2008  12:35:12.657

LAST DC RESET:  01/15/2008  20:10:31.427

=>>
```

Figure 7.6 Battery Metering: Terminal

Any battery voltage between setting DCLWP and the dc battery monitor low limit of 15 Vdc is in the L-Zone. Battery voltages in the H-Zone are voltages higher than the DCHWP setting.

Use the **MET RBM** command from a communications terminal to reset the dc battery monitor. You can program a SELOGIC control equation RST_BAT (in Monitor settings) to control dc battery monitor reset.

RTD Metering

Use the **MET RTD** command to display the resistance temperature detector (RTD) values, as shown in *Figure 7.7*.

```
=>>MET RTD <Enter>

Relay 1                                    Date: 04/12/2008  Time: 06:06:31.366
Station A                                  Serial Number: 2008030645


RTD Input Temperature Data (deg. C)
RTD  1 = -50
RTD  2 = 250

RTD  3 = 0
RTD  4 = 45
RTD  5 = 34
RTD  6 = 65
RTD  7 = -23
RTD  8 = 39
RTD  9 = 23
RTD 10 = 11
RTD 11 = 54
RTD 12 = 78

=>>
```

Figure 7.7 RTD Report

Protection Math Variable Metering

Use the **MET PMV** command to display all 64 PMV values, as shown in *Figure 7.8*.

```
=>>MET PMV <Enter>

Relay 1                                    Date: 04/07/2008  Time: 21:03:40.451
Station A                                  Serial Number: 2008030645

Protection Analog Quantities
  PMV01 =      0.000        PMV02 =      0.000        PMV03 =      0.000
  PMV04 =      0.000        PMV05 =      0.000        PMV06 =      0.000
  PMV07 =      0.000        PMV08 =      0.000        PMV09 =      0.000
  PMV10 =      0.000        PMV11 =      0.000        PMV12 =      0.000
  PMV13 =      0.000        PMV14 =      0.000        PMV15 =      0.000
  PMV16 =      0.000        PMV17 =      0.000        PMV18 =      0.000

  PMV19 =      0.000        PMV20 =      0.000        PMV21 =      0.000
  PMV22 =      0.000        PMV23 =      0.000        PMV24 =      0.000
  PMV25 =      0.000        PMV26 =      0.000        PMV27 =      0.000
  PMV28 =      0.000        PMV29 =      0.000        PMV30 =      0.000
  PMV31 =      0.000        PMV32 =      0.000        PMV33 =      0.000
  PMV34 =      0.000        PMV35 =      0.000        PMV36 =      0.000
  PMV37 =      0.000        PMV38 =      0.000        PMV39 =      0.000
  PMV40 =      0.000        PMV41 =      0.000        PMV42 =      0.000

  PMV43 =      0.000        PMV44 =      0.000        PMV45 =      0.000
  PMV46 =      0.000        PMV47 =      0.000        PMV48 =      0.000
  PMV49 =      0.000        PMV50 =      0.000        PMV51 =      0.000
  PMV52 =      0.000        PMV53 =      0.000        PMV54 =      0.000
  PMV55 =      0.000        PMV56 =      0.000        PMV57 =      0.000
  PMV58 =      0.000        PMV59 =      0.000        PMV60 =      0.000
  PMV61 =      0.000        PMV62 =      0.000        PMV63 =      0.000
  PMV64 =      0.000
=>>
```

Figure 7.8 PMV Report

Automation Math Variable Metering

Use the **MET AMV** command to display all 256 AMV values, as shown in *Figure 7.9*.

```
=>>MET AMV <Enter>

Relay 1                                    Date: 04/07/2008  Time: 21:04:33.579
Station A                                  Serial Number: 2008030645

Automation Analog Quantities
 AMV001 =      0.000       AMV002 =      0.000       AMV003 =      0.000
 AMV004 =      0.000       AMV005 =      0.000       AMV006 =      0.000
 AMV007 =      0.000       AMV008 =      0.000       AMV009 =      0.000
 AMV010 =      0.000       AMV011 =      0.000       AMV012 =      0.000

 AMV013 =      0.000       AMV014 =      0.000       AMV015 =      0.000
 .
 .
 .

 AMV238 =      0.000       AMV239 =      0.000       AMV240 =      0.000
 AMV241 =      0.000       AMV242 =      0.000       AMV243 =      0.000
 AMV244 =      0.000       AMV245 =      0.000       AMV246 =      0.000
 AMV247 =      0.000       AMV248 =      0.000       AMV249 =      0.000

 AMV250 =      0.000       AMV251 =      0.000       AMV252 =      0.000
 AMV253 =      0.000       AMV254 =      0.000       AMV255 =      0.000
 AMV256 =      0.000
=>>
```

Figure 7.9 AMV Report

MIRRORED BITS Remote Analog Metering

Use the **MET ANA** command to display the analog values used with MIRRORED BITS communications, as shown in *Table 7.5*.

Table 7.5 Information Available With the MET ANA Command

Command	Information
MET ANA	Analog value in channel A Analog value in channel B

This page intentionally left blank

SECTION 8

Monitoring

The relay provides extensive capabilities for monitoring substation components. Most SEL-400 series relays provide the following useful features:

- *Circuit Breaker Monitor on page 8.1*
- *Station DC Battery System Monitor on page 8.21*

This section describes monitoring capabilities that are common to many SEL-400 series relays. Some relays include additional monitoring capabilities that are not common to other SEL-400 series relays. See the relay-specific instruction manuals to determine the specific monitoring features available in each relay.

Circuit Breaker Monitor

The relay features advanced circuit breaker monitoring. *Figure 8.1* shows that the relay processes phase currents, circuit breaker auxiliary contacts, and the substation dc battery voltages to detect out-of-tolerance and maximum life circuit breaker parameters. These parameters include current interrupted, operating times, and contact wear. By using relay monitoring, maintenance personnel can determine the extent of a developing circuit breaker problem and select an appropriate response to correct the problem. These monitoring features are available online in real-time; you can detect impending problems immediately. The result is better power system reliability and improved circuit breaker life expectancy.

NOTE: This section lists settings for Circuit Breaker 1. The number of circuit breakers and the circuit breaker references vary between relays. See the product-specific instruction manual for the specific breakers available for circuit breaker monitoring.

One of the many circuit breaker monitor features is the circuit breaker contact wear monitor. The relay tracks the number of circuit breaker close-open operations and respective fault interrupting levels for each of two circuit breakers. The relay uses data from the circuit breaker manufacturer to compare the recorded operational data with the manufacturer's recommended maintenance requirements. The relay notifies you when each set of circuit breaker pole contacts exceeds preset wear thresholds. Using this information, you can operate your substation more economically by accurately scheduling circuit breaker maintenance.

You can also collect the following data on these circuit breaker parameters:

- Circuit breaker wear
- Electrical operating time
- Mechanical operating time
- Circuit breaker inactivity time
- Interrupted current
- Pole scatter (for single-pole breakers only)
- Pole discrepancy (for single-pole breakers only)
- Motor run time

Figure 8.1 Intelligent Circuit Breaker Monitor

You can program the relay to alarm when any of the above quantities exceed a preset threshold. In addition, the relay stores a 128-event circuit breaker history in nonvolatile memory. The circuit breaker history report includes circuit breaker mechanical operation times, electrical operation times, interrupted currents, and other important parameters. The alarm and reporting features help you operate your substation safely and reliably.

Enabling the Circuit Breaker Monitor

NOTE: Some SEL-400 series relays do not support single-pole tripping breakers. In these cases, the corresponding BKnTYP setting is not available and only information related to three-pole breakers will be available.

Enable and configure the relay circuit breaker monitor by using the settings listed in *Table 8.1* for each of two possible circuit breakers. Power system circuit breakers are either single-pole tripping or three-pole tripping circuit breakers; set the relay for the circuit breaker type that the relay controls. For a single-pole tripping circuit breaker, set BK1TYP := 1, and for a three-pole tripping circuit breaker, set BK1TYP := 3. The factory-default setting is BK1TYP := 1. Be sure to configure the relay with the settings that match your circuit breakers.

NOTE: Some SEL-400 series relays use a BK_SEL setting to list enabled breakers, rather than the EBnMON settings shown here.

Table 8.1 Circuit Breaker Monitor Configuration

Name	Description	Range
EB1MON	Enable Circuit Breaker 1 monitoring	Y, N
BK1TYP	Circuit Breaker 1 type	1, 3
EB2MON	Enable Circuit Breaker 2 monitoring	Y, N
BK2TYP	Circuit Breaker 2 type	1, 3

Circuit Breaker Contact Wear Monitor

The circuit breaker contact wear monitor in the relay provides information that helps you schedule circuit breaker maintenance. This monitoring function accumulates the number of close-open operations and integrates the per-phase current during each opening operation. The relay compares this information to a predefined circuit breaker maintenance curve to calculate the percent contact wear on a per-pole basis.

The circuit breaker maintenance curve also incorporates the accumulated fault current arcing time (ΣI^2t), assuming an identical arcing time for each trip. You can obtain the one-cycle arcing time from circuit breaker manufacturer data.

The relay updates and stores the contact wear information and the number of trip operations in nonvolatile memory. You can view this information through any communications port.

Any phase wear percentage that exceeds the threshold setting B1BCWAT asserts the alarm Relay Word bit, B1BCWAL, for Circuit Breaker 1. You can use this Relay Word bit in a SELOGIC control equation to alert operations personnel, or you can control other functions such as blocking reclosing. The relay limits the maximum reported circuit breaker wear percentage to 150 percent.

NOTE: In the following discussion, three elements are specified, one for each phase: ϕ = A, B, and C.

The relay integrates currents and increments the trip counters for the contact wear monitor each time the SELOGIC control equation BM1TRPϕ asserts. Set the logic for this function from a communications port with the **SET M** ASCII command, with the ACSELERATOR QuickSet SEL-5030 software program **Breaker Monitor Settings** tree view, or by using the front-panel `SET/SHOW` menu. (See *Making Simple Settings Changes on page 3.15* for information on setting the relay by using these methods.) The default settings cause the contact wear monitor to integrate and increment each time the relay trip logic asserts.

Perform the following specific steps to use the circuit breaker contact wear monitor:

Step 1. Enable the circuit breaker monitor.

Step 2. Load the manufacturer's circuit breaker maintenance data.

Step 3. Preload any existing circuit breaker wear (if setting up the contact wear monitor on a circuit breaker with preexisting service time).

Step 4. Program the SELOGIC control equations for trip and close conditions.

Enable the Circuit Breaker Monitor

You must enable the circuit breaker monitor before you load the manufacturer's data, preload any existing circuit breaker wear, and set the trip initiate and close initiate SELOGIC control equations. Set the circuit breaker monitor enable setting EB*x*MON to Y (for Yes) for Breaker *x*.

Load Manufacturer Circuit Breaker Maintenance Data

Load the maintenance data supplied by the circuit breaker manufacturer. Circuit breaker maintenance information lists the number of permissible operating cycles (close/open operations) for a given current interruption level. *Table 8.2* shows typical circuit breaker maintenance information from an actual SF6 circuit breaker. The *Figure 8.2* log/log plot is the circuit breaker maintenance curve, produced from the *Table 8.2* data.

Table 8.2 Circuit Breaker Maintenance Information—Example (Sheet 1 of 2)

Current Interruption Level (kA)	Permissible Close/Open Operations
0.00–1.2	10000
2.00	3700
3.00	1500
5.00	400
8.00	150

Table 8.2 Circuit Breaker Maintenance Information—Example (Sheet 2 of 2)

Current Interruption Level (kA)	Permissible Close/Open Operations
10.00	85
20.00	12

Figure 8.2 Circuit Breaker Maintenance Curve (Manufacturer's Data)

The three set points necessary to reproduce this circuit breaker maintenance curve in the relay are listed in *Table 8.3* for Circuit Breaker 1. *Figure 8.3* shows how to determine these three set points from the maintenance curve shown in *Figure 8.2*.

Table 8.3 Contact Wear Monitor Settings—Circuit Breaker 1

Setting	Definition	Range
B1COSP1	Close/open set point 1—max	0–65000 close/open operations
B1COSP2	Close/open set point 2—mid	0–65000 close/open operations
B1COSP3	Close/open set point 3—min	0–65000 close/open operations
B1KASP1[a]	kA interrupted set point 1—min	1.0–999 kA in 0.1-kA steps
B1KASP2	kA interrupted set point 2—mid	1.0–999 kA in 0.1-kA steps
B1KASP3[a]	kA interrupted set point 3—max	1.0–999 kA in 0.1-kA steps

[a] The ratio of settings B1KASP3/B1KASP1 must be in the range: 5 ≤ B1KASP3/B1KASP1 ≤ 100.

Figure 8.3 Circuit Breaker Contact Wear Curve With Relay Settings

Circuit Breaker Contact Wear Curve Details

Circuit breaker maintenance information from the two end values of *Table 8.2* or *Figure 8.2* determine set point (B1KASP1, B1COSP1) and set point (B1KASP3, B1COSP3) for the contact wear curve of *Figure 8.3*. Set point (B1KASP2, B1COSP2) is the middle maintenance point in these data. There are two philosophies for selecting the middle set point. One method places the middle set point to provide the best "curve-fit" for your plot of the manufacturer's circuit breaker maintenance data (shown in *Figure 8.2*). Another philosophy is to set the middle point based on actual experience or fault studies of the typical system faults.

Example 8.1 Creating the Circuit Breaker Contact Wear Curve

Acquire the manufacturer's maintenance information (this example uses the data of *Table 8.2* for Circuit Breaker 1). If you receive the data in tabular form, plot the manufacturer's maintenance information on log/log paper in a manner similar to *Figure 8.2*.

Choose the left and right set points from the extremes of the curve you just plotted. Select the left set point on the contact wear curve corresponding to (B1KASP1, B1COSP1) by setting B1KASP1 := 1.2 and B1COSP1 := 10000. Plot the right set point (B1KASP3, B1COSP3) by setting B1KASP3 := 20.0 and B1COSP3 := 12.

Choose the midpoint of the contact wear curve based on your experience and system fault studies. The majority of operations for a typical circuit breaker are to interrupt single-line-to-ground faults. Therefore, plot the midpoint (B1KASP2, B1COSP2) by setting B1KASP2 at or slightly greater than the expected single-line-to-ground fault current: B1KASP2 := 8.0 and B1COSP2 := 150.

There are two other notable portions of the circuit breaker contact wear curve in *Figure 8.3*. The curve is horizontal below the left set point (B1KASP1, B1COSP1). This is the close/open operation limit regardless of interrupted current value (for the *Example 8.1* circuit breaker, this is at B1COSP1 := 10000). Some manufacturers call this point the mechanical circuit breaker service life.

Another part of the circuit breaker maintenance curve falls vertically at the right set point (B1KASP3, B1COSP3). This is the maximum interrupted current limit (for the *Example 8.1* circuit breaker, this is at B1KASP3 := 20.0). If the interrupted current exceeds setting B1KASP3, the relay sets contact wear at 105 percent.

Example 8.2 I^2t Criteria Application

Some circuit breaker manufacturers do not provide a circuit breaker maintenance curve, but specify the accumulated fault current arcing time (ΣI^2t) for circuit breaker maintenance. For example, manufacturer's data specify ΣI^2t per phase at 750 kA^2 seconds for a particular circuit breaker, at a rated arcing duration for each trip of 1 cycle. The circuit breaker maximum interrupting current rating is 40 kA, and the continuous load current rating is 2 kA.

You can construct the contact wear curve for this circuit breaker from the specified ΣI^2t. Choose B1KASP1 := 2.0 (the continuous current rating) and B1KASP3 := 40.0 (the maximum interrupting current rating). Choose the middle of the contact wear curve based on experience and system fault studies. The majority of faults a typical circuit breaker interrupts are single-line-to-ground faults. Therefore, set B*n*KASP2 at or slightly greater than the expected single-line-to-ground fault current (B1KASP2 := 10.0 kA in this example). Using the following equations, calculate these settings points to obtain the number of close/open operations:

$$\text{B1COSP1} = \frac{\sum I^2t}{(\text{B1KASP1})^2 \cdot t_{arc}} = \frac{750}{2^2 \cdot (0.01667 \cdot 1)} := 11250$$

Equation 8.1

$$\text{B1COSP2} = \frac{\sum I^2t}{(\text{B1KASP2})^2 \cdot t_{arc}} = \frac{750}{10^2 \cdot (0.01667 \cdot 1)} := 450$$

Equation 8.2

$$\text{B1COSP3} = \frac{\sum I^2t}{(\text{B1KASP3})^2 \cdot t_{arc}} = \frac{750}{40^2 \cdot (0.01667 \cdot 1)} := 28$$

Equation 8.3

In these equations, t_{arc} is the arcing time in seconds; $t_{arc} = (1/f_{NOM}) \cdot$ (arc duration in cycles); f_{NOM} is the nominal power system frequency (50 Hz or 60 Hz). These calculations show the number of close/open operations rounded to the nearest unit.

Preloading Contact Wear Data

Upon the first commissioning of the relay, the associated circuit breakers can already have some wear. You can preload a separate amount of wear for each pole of each circuit to preload existing contact wear data. The relay accepts integer values of percentage wear as great as 100 percent. The relay adds the incremental contact wear at the next circuit breaker monitor initiation (and at all subsequent initiations) to the preloaded value to obtain a total wear value. The limit for reporting circuit breaker contact wear is 150 percent for each pole.

Program the SELOGIC Control Equations for Trip and Close Conditions

Circuit Breaker Monitor Trip Initiation Settings: BM1TRPϕ

NOTE: In the following discussion, three elements are specified. There is one element for each phase: ϕ = A, B, and C. With three-pole breakers, only phase A is used to represent the entire breaker. Some three-pole relays include A in the names and others disregard it.

The relay employs SELOGIC control equations to initiate the circuit breaker monitor. For Circuit Breaker 1, this setting is BM1TRPϕ. These SELOGIC control equations use Relay Word bits to determine when the circuit breaker monitor accumulates circuit breaker operating parameters from phases A, B, and C. When detecting a rising edge (a transition from logical 0 to logical 1) of the initiation settings, the relay accumulates the interrupted rms currents and advances the trip counter by one count. There are separate current accumulators and trip counters for each circuit breaker pole. *Table 8.4* shows the factory-default settings for circuit breaker monitor initiation.

NOTE: Factory defaults differ for single-pole tripping and three-pole tripping. Three-pole tripping uses the single setting BM1TRPA for all three poles.

Table 8.4 Circuit Breaker Monitor Initiate SELOGIC Control Equations

Name	Description	Comment[a]
BM1TRPA	BK1 monitor initiate equation	If BK1TYP := 3
BM1TRPA	A-Phase BK1 monitor initiate equation	If BK1TYP := 1
BM1TRPB	B-Phase BK1 monitor initiate equation	If BK1TYP := 1
BM1TRPC	C-Phase BK1 monitor initiate equation	If BK1TYP := 1

[a] See Table 8.1.

Initiation settings can include both internal and external tripping conditions. To capture trip information initiated by devices other than the relay, you must program the SELOGIC control equation BM1TRPϕ to sense these trips.

Example 8.3 Circuit Breaker Monitor External Trip Initiation

Connect external trip signals to the relay control inputs. This example uses input IN201; you can use any control inputs that are appropriate for your installation. Control Input IN201, an optoisolated input, is located on the relay I/O Interface Board #1.

If you want Circuit Breaker Monitor 1 to initiate for the trip elements TPA1, TPB1, and TPC1, or for external trips, set these SELOGIC control equations from the **SET M** ASCII command or the QuickSet **Breaker Monitor Settings** tree view:

BK1TYP := **1** Breaker 1 Trip Type (Single Pole = 1, Three Pole = 3)

BM1TRPA := **TPA1 OR IN201** Breaker Monitor A-Phase Trip Initiate—BK1

BM1TRPB := **TPB1 OR IN202** Breaker Monitor B-Phase Trip Initiate—BK1

BM1TRPC := **TPC1 OR IN203** Breaker Monitor C-Phase Trip Initiate—BK1

Example 8.4 Using a Control Input to Capture External and Internal Trip Commands

You can also capture all trip information for circuit breaker trips by using a relay control input to monitor the trip bus for the given circuit breaker. *Figure 8.4* shows an illustration of this method in which IN206 connects to the Circuit Breaker 1 A-Phase trip bus (via a parallel connection across the trip bus), and asserts for any trip from any source. This example uses inputs IN206; you can use any control inputs that are appropriate for your installation. Vdc for this example is 125 Vdc.

Figure 8.4 Trip Bus Sensing With Relay Input IN206

Many U.S. substation trip bus configurations have an incandescent trip indicator lamp from the battery + terminal to the trip bus. This lamp presents an impedance that can provide sufficient "pull-up" on the trip bus to falsely assert the control input. The worst case for this condition occurs when the circuit breaker is open (auxiliary circuit breaker (52A) contact in *Figure 8.4* is open). You can change the input debounce time IN206PU for slow or noisy mechanical switches; the default debounce time of 1/8 cycle should be sufficient for most trip bus arrangements.

Use the **SET G** (GLOBAL) command or the QuickSet **Global > Control Inputs Settings** tree view to confirm that the debounce time (settings IN206PU and IN206DO) are correct for your trip bus control voltage. You must enable independent control input conditioning by using Global setting EICIS. Enter these settings:

EICIS := **Y** Independent Control Input Settings (Y, N)

IN206PU := **0.1250** Input IN206 Pickup Delay (0.0000–5 cyc)

IN206DO := **0.1250** Input IN206 Dropout Delay (0.0000–5 cyc)

BM1TRPA := **IN206** Breaker Monitor Trip—BK1 (SELOGIC Equation)

Use this procedure to cause the circuit breaker monitor to initiate for either external or internal Circuit Breaker 1 A-Phase trips.

Circuit Breaker Monitor Close Initiation Settings: BM1CLSϕ

NOTE: In the following discussion, three elements are specified. There is one element for each phase: ϕ = A, B, and C. With three-pole breakers, only phase A is used to represent the entire breaker. Some three-pole relays include A in the names and others drop it.

The relay employs SELOGIC control equations to initiate the circuit breaker monitor duration timers for close functions. For Circuit Breaker 1, this setting is BM1CLSϕ. These SELOGIC control equations use Relay Word bits to determine when the circuit breaker monitor times mechanical closing, electrical closing, and pole scatter. *Table 8.5* shows the factory-default settings for circuit breaker monitor close initiation.

Table 8.5 Circuit Breaker Monitor Close SELOGIC Control Equations

Name	Description	Comment[a]
BM1CLSA	Breaker Monitor 1 close equation	If BK1TYP := 3
BM1CLSA	Breaker Monitor 1 A-Phase close equation	If BK1TYP := 1
BM1CLSB	Breaker Monitor 1 B-Phase close equation	If BK1TYP := 1
BM1CLSC	Breaker Monitor 1 C-Phase close equation	If BK1TYP := 1

[a] See Table 8.1.

As in *Example 8.4* (connection of the trip bus to a control input), you can also capture the circuit breaker close information by using a relay input to monitor the close bus for the given circuit breaker.

Other Circuit Breaker Monitor Functions

kA Interrupt Monitoring

The relay monitors the amount of phase current that each pole of the circuit breaker interrupts at each trip operation. The relay records the interrupted current as a percentage of the circuit breaker maximum interrupting rating specified by the manufacturer. Set the maximum interruption current with setting B1MKAI (Maximum kA Interrupt Rating—BK1). If the percent of current interrupt that the relay records exceeds threshold setting B1KAIAT (kA Interrupt Capacity Alarm Threshold—BK1), the relay asserts breaker monitor alarm Relay Word bit B1KAIAL.

Mechanical Operating Time

The mechanical operating time is the time between trip initiation or close initiation and the associated phase circuit breaker 52A normally open contact status change. (Assertion of 52Aϕ1 indicates that a particular circuit breaker phase has closed). The relay measures the tripping times for each phase from the assertion of the respective BM1TRPϕ Relay Word bit to the dropout of the respective 52Aϕ1 Relay Word bit. Similarly, for mechanical closing time, the relay measures the closing times for each phase from the assertion of the BM1CLSϕ Relay Word bit to the pickup of the 52Aϕ1 Relay Word bit. The relay compares these tripping or closing times to the mechanical slow operation time thresholds for tripping and closing, B1MSTRT and B1MSCLT, respectively. The relay issues a mechanical slow operation alarm, B1MSOAL, for 5 seconds when trip or close times exceed these thresholds. See *Figure 8.5* for a Circuit Breaker 1 A-Phase timing diagram.

Figure 8.5 Mechanical Operating Time for Circuit Breaker 1 A-Phase

Example 8.5 Mechanical Operating Time Settings

Use Circuit Breaker 1, a single-pole tripping circuit breaker, for this example. Connect the circuit breaker normally open 52A contacts through station battery power to IN201, IN202, and IN203. This example uses inputs IN201, IN202, and IN203 for A-, B-, and C-Phases, respectively; you can use any control inputs that are appropriate for your installation. The control voltage for this example is 125 Vdc.

Control Inputs IN201–IN203 are direct-coupled inputs.

Set the Relay Word bits to respond to these inputs.

52AA1 := **IN201** A-Phase N/O Control Input—BK1 (SELOGIC Equation)

52AB1 := **IN202** B-Phase N/O Control Input—BK1 (SELOGIC Equation)

52AC1 := **IN203** A-Phase N/O Control Input—BK1 (SELOGIC Equation)

Connect external trip signals to IN301, IN302, and IN303, and external close signals to IN304, IN305, and IN306 for the A-, B-, and C-Phases, respectively. Use the default settings for input conditioning (debounce time and assertion level), as with inputs IN201 to IN203 above.

Set the mechanical operating time threshold for the slow trip alarm (B1MSTRT) to 30 ms, and the slow close alarm threshold (B1MSCLT) to 70 ms. Use your company standard practices to determine these settings for your application. For this example, enter the following settings:

B1MSTRT := **30** Mechanical Slow Trip Alarm Threshold—BK1 (1–999 ms)

B1MSCLT := **70** Mechanical Slow Close Alarm Threshold—BK1 (1–999 ms)

EB1MON := **Y** Breaker 1 Monitoring (Y, N)

BK1TYP := **1** Breaker 1 Trip Type (Single Pole = 1, Three Pole = 3)

BM1TRPA := **TPA1 OR IN301** Breaker Monitor A-Phase Trip—BK1 (SELOGIC Equation)

BM1TRPB := **TPB1 OR IN302** Breaker Monitor B-Phase Trip—BK1 (SELOGIC Equation)

BM1TRPC := **TPC1 OR IN303** Breaker Monitor C-Phase Trip—BK1 (SELOGIC Equation)

Example 8.5 Mechanical Operating Time Settings (Continued)

BM1CLSA := **BK1CL OR IN304** Breaker Monitor A-Phase Close—BK1 (SELOGIC Equation)

BM1CLSB := **BK1CL OR IN305** Breaker Monitor B-Phase Close—BK1 (SELOGIC Equation)

BM1CLSC **:= BK1CL OR IN306** Breaker Monitor C-Phase Close—BK1 (SELOGIC Equation)

Assertion of the Relay Word bit B1MSOAL indicates any one of the following four conditions:

- The mechanical operating time for a trip operation exceeds 30 ms (the slow trip alarm setting)
- The mechanical operating time for a close operation exceeds 70 ms (the slow close setting)
- No 52Aϕ1 status change occurred during the time B1MSTRT plus approximately 100 ms after trip initiation (a trip time-out condition)
- No 52Aϕ1 status change occurred during the time B1MSCLT plus approximately 100 ms after close initiation (a close time-out condition)

The relay makes a further check on the auxiliary circuit breaker (52A) contacts by testing whether these circuit breaker contacts have changed state within approximately 100 ms after the end of the trip or close threshold times. Thus, this additional check serves as the trip time-out and close time-out condition. This check verifies that the circuit breaker actually closed or opened, and it alerts you if maintenance is required on the circuit breaker mechanical linkages or auxiliary (52) contacts.

Electrical Operating Time

The electrical operating time is the time between trip or close initiation and an open-phase status change. For both circuit breakers, the relay measures the tripping time for each phase from the assertion of the BM1TRPϕ Relay Word bit to the time the relay detects an open-phase condition. Similarly, the relay measures electrical operating time for closing each phase from the assertion of BM1CLSϕ to the restoration of phase quantities. The relay compares these tripping or closing times to the electrical slow operation time thresholds for tripping and closing, B1ESTRT and B1ESCLT, respectively. The relay issues an electrical slow operation alarm, B1ESOAL, for 5 seconds when trip or close times exceed these thresholds. *Figure 8.6* shows the timing diagram for the A-Phase pole of Circuit Breaker 1.

Figure 8.6 Electrical Operating Time for Circuit Breaker 1 A-Phase

Primary load/fault current can indicate contact closing, contact opening, and arc extinction, depending upon the actual circuit breaker monitor setup. You can detect problems within the circuit breaker arcing chamber by timing the interval from trip/close initiation to electric arc extinction.

Example 8.6 Electrical Operating Time Settings

Use Circuit Breaker 1, a single-pole tripping circuit breaker, for this example. Connect external trip signals to IN201, IN202, and IN203, and external close signals to IN204, IN205, and IN206 for the A-, B-, and C-Phases, respectively. This example uses control inputs IN201–IN206; you can use any control inputs that are appropriate for your installation. The control voltage for this example is 125 Vdc.

Control Inputs IN201–IN206 are located on the relay I/O Interface board #1.

Set the electrical operating time threshold for the slow trip alarm (B1ESTRT) at 25 ms, and the slow close alarm threshold (B1ESCLT) at 65 ms. Use your company standard practices to determine these settings for your application. For this example, enter the following settings.

B1ESTRT := **25** Electrical Slow Trip Alarm Threshold—BK1 (1–999 ms)

B1ESCLT := **65** Electrical Slow Close Alarm Threshold—BK1 (1–999 ms)

EB1MON := **Y** Breaker 1 Monitoring (Y, N)

BK1TYP := **1** Breaker 1 Trip Type (Single Pole = 1, Three Pole = 3)

BM1TRPA := **TPA1 OR IN201** Breaker Monitor A-Phase Trip—BK1 (SELOGIC Equation)

BM1TRPB := **TPB1 OR IN202** Breaker Monitor B-Phase Trip—BK1 (SELOGIC Equation)

BM1TRPC := **TPC1 OR IN203** Breaker Monitor C-Phase Trip—BK1 (SELOGIC Equation)

BM1CLSA := **BK1CL OR IN204** Breaker Monitor A-Phase Close—BK1 (SELOGIC Equation)

Example 8.6 Electrical Operating Time Settings (Continued)

BM1CLSB := **BK1CL OR IN205** Breaker Monitor B-Phase Close—BK1 (SELOGIC Equation)

BM1CLSC := **BK1CL OR IN206** Breaker Monitor C-Phase Close—BK1 (SELOGIC Equation)

Assertion of the Relay Word bit B1ESOAL indicates any one of the following four conditions:

- The electrical operating time for a trip operation exceeds 25 ms (the slow trip alarm setting)
- The electrical operating time for a close operation exceeds 65 ms (the slow close setting)
- No pole-open logic status change occurred during the time B1ESTRT plus approximately 100 ms after trip initiation (a trip time-out condition)
- No pole-open logic status change occurred during the time B1ESCLT plus approximately 100 ms after close initiation (a close time-out condition)

The relay further checks the circuit breaker by testing whether the circuit breaker has interrupted or restored current within 100 ms after the end of the trip or close threshold times. Thus, this additional check serves as the trip time-out and close time-out condition. This verifies that the circuit breaker actually closed or opened, and alerts you if maintenance is required on circuit breaker mechanical linkages.

Pole Scatter

The relay records and compares the operation time of each circuit breaker pole to detect time deviations between pairs of circuit breaker poles when tripping and closing all three poles simultaneously on single-pole-capable circuit breakers. The relay measures the differences in operating times resulting from auxiliary circuit breaker (52A) contact status changes. The logic compares the operation time of each individual circuit breaker pole against the time for each of the other poles. The relay triggers an alarm, B1PSAL, for any time deviation greater than the preset time threshold settings B1PSTRT and B1PSCLT for Circuit Breaker 1.

NOTE: Pole scatter applies only to single-pole mechanism circuit breakers (BK1TYP := 1). These circuit breakers have an auxiliary circuit breaker (52A) contact for each phase.

Figure 8.7 shows the operating time for each pole (A, B, and C) of Circuit Breaker 1. TAB represents the operating time deviation between poles A and B. TBC is the time between B and C, and TCA is the time between C and A. Once activated, the pole scatter alarm remains asserted for five seconds.

Figure 8.7 Timing Illustration for Pole Scatter at Trip

Example 8.7 Pole Scatter Settings

Use Circuit Breaker 1, a single-pole tripping circuit breaker, for this example. This example uses control inputs IN301, IN302, and IN303 for the A-, B-, and C-Phases, respectively; you can use any control inputs that are appropriate for your installation.

The control voltage for this example is 125 Vdc. Control Inputs IN301–IN303 are located on I/O Board #3. Connect the circuit breaker normally open auxiliary circuit breaker (52A) contacts through station battery power to IN301, IN302, and IN303.

Set the relay to respond to these inputs by using the QuickSet **Breaker Monitor (SET M)** settings:

52AA1 := **IN301** A-Phase Normally Open Control Input—BK1 (SELOGIC Equation)

52AB1 := **IN302** B-Phase Normally Open Control Input—BK1 (SELOGIC Equation)

52AC1 := **IN303** C-Phase Normally Open Control Input—BK1 (SELOGIC Equation)

Connect external trip signals to IN201, IN202, and IN203, and external close signals to IN204, IN205, and IN206 for the A-, B-, and C-Phases, respectively. This example uses control inputs IN201–IN206; you can use any control inputs that are appropriate for your installation.

Set the pole scatter trip alarm time threshold (B1PSTRT) at 4 ms, the pole scatter close alarm time threshold (B1PSCLT) at 6 ms, and the pole discrepancy time delay (B1PDD) at 1400 ms. Use your company standard practices to determine these settings for your application. For this example, enter the following settings:

B1PSTRT := **4** Pole Scatter Trip Alarm Threshold—BK1 (1–999 ms)

B1PSCLT := **6** Pole Scatter Close Alarm Threshold—BK1 (1–999 ms)

B1PDD := **1400** Pole Discrepancy Time Delay—BK1 (1–9999 ms)

EB1MON := **Y** Breaker 1 Monitoring (Y, N)

BK1TYP := **1** Breaker 1 Trip Type (Single Pole = 1, Three Pole = 3)

BM1TRPA := **TPA1 OR IN201** Breaker Monitor A-Phase Trip—BK1 (SELOGIC Equation)

BM1TRPB := **TPB1 OR IN202** Breaker Monitor B-Phase Trip—BK1 (SELOGIC Equation)

BM1TRPC := **TPC1 OR IN203** Breaker Monitor C-Phase Trip—BK1 (SELOGIC Equation)

BM1CLSA := **BK1CL OR IN204** Breaker Monitor A-Phase Close—BK1 (SELOGIC Equation)

BM1CLSB := **BK1CL OR IN205** Breaker Monitor B-Phase Close—BK1 (SELOGIC Equation)

BM1CLSC := **BK1CL OR IN206** Breaker Monitor C-Phase Close—BK1 (SELOGIC Equation)

Example 8.7 Pole Scatter Settings (Continued)

If any of the pole-open times (TAB, TBC, and TCA in *Figure 8.7*) exceed 4 ms, or if any of the pole close times exceed 6 ms, the relay asserts the Relay Word bit B1PSAL. Assertion of B1PSAL indicates any one of the following four conditions:

- The pole scatter time for trip operation exceeds the alarm setting time (4 ms)
- The pole scatter time for close operation exceeds the alarm setting time (6 ms)
- One phase auxiliary circuit breaker (52A) contact status change exceeds B1PSTRT plus approximately 5 ms after the trip initiation
- One phase auxiliary circuit breaker (52A) contact status change exceeds B1PSCLT plus approximately 5 ms after the close initiation

Note that the relay provides a time out of approximately 200 ms after the trip or 300 ms after the close threshold to end detection of pole scatter alarms.

Pole Discrepancy

The relay continuously monitors the status of each circuit breaker pole to detect open or close deviations among the three poles. In addition, at tripping and closing, the relay measures the differences in operating times during the auxiliary circuit breaker (52A) contact status changes or open-phase logic operation. The relay triggers an alarm Relay Word bit, B1PDAL, if the status of any pole compared to another pole exceeds the time window setting B1PDD for the circuit breaker.

NOTE: Pole discrepancy applies only to single-pole mechanism circuit breakers (BK1TYP := 1). These circuit breakers have an auxiliary circuit breaker (52A) contact output for each phase.

You can set the relay to use the current flowing through the circuit breaker to supervise pole discrepancy timing of the auxiliary circuit breaker (52A) contacts. Enable this supervision by setting E1PDCS to Y for Circuit Breaker 1.

Pole discrepancy setting B1PDD should be longer than the single-pole reclosing dead time.

$$\text{B1PDD} := (\text{SPOID} + \text{circuit breaker pole operating time} + \text{contact latency}) \bullet 1.2$$

Equation 8.4

where:

SPOID is the single-pole open interval time and the factor 1.2 is a safety factor.

Round this time to the next higher hundreds of milliseconds value to give the pole discrepancy setting.

Figure 8.8 shows a Circuit Breaker 1 operation where Pole B closes first, followed by Pole C; Pole A closes slowly. If the time from a change in 52AB1 to the change in 52AA1 exceeds the pole discrepancy time threshold setting B1PDD, then the relay asserts the B1PDAL alarm. Once activated, the relay asserts the pole discrepancy alarm for five seconds.

Figure 8.8 Pole Discrepancy Measurement

Example 8.8 Pole Discrepancy Alarm for Circuit Breaker 1—No Other Circuit Breaker Monitor Functions

Use Circuit Breaker 1, a single-pole tripping circuit breaker, for this example. This example uses control inputs IN301, IN302, and IN303 for the A-, B-, and C-Phases, respectively; you can use any control inputs that are appropriate for your installation.

The control voltage for this example is 125 Vdc. Control Inputs IN301–IN303 are located on I/O Board #2. Connect the circuit breaker normally open auxiliary circuit breaker (52A) contacts through station battery power to IN301, IN302, and IN303.

Set the relay internal Relay Word bits to respond to these inputs by using the QuickSet **Breaker Monitor (SET M)** settings:

52AA1 := **IN301** A-Phase Normally Open Control Input—BK1 (SELOGIC Equation)

52AB1 := **IN302** B-Phase Normally Open Control Input—BK1 (SELOGIC Equation)

52AC1 := **IN303** C-Phase Normally Open Control Input—BK1 (SELOGIC Equation)

Connect external trip signals to IN301, IN302, and IN303, and external close signals to IN304, IN305, and IN306 for the A-, B-, and C-Phases, respectively. This example uses control inputs IN301–IN306; you can use any control inputs that are appropriate for your installation.

Set the pole discrepancy time delay (B1PDD) at 1400 ms. This time delay assumes a dead time of 1000 ms plus a pole closing time of 100 ms (including contact latency), plus 20 percent (for security), rounded to the next higher hundreds of milliseconds value. This pole discrepancy time is longer than the single-pole open interval time default of 900 ms; confirm that this is the case for your application settings.

Enter the following settings:

B1PDD := **1400** Pole Discrepancy Time Delay—BK1 (1–9999 ms)

EB1MON := **Y** Breaker 1 Monitoring (Y, N)

BK1TYP := **1** Breaker 1 Trip Type (Single Pole = 1, Three Pole = 3)

The pole discrepancy timing window is B1PDD := 1400 (ms). Assertion of the Relay Word bit B1PDAL indicates that the status of the three Circuit Breaker 1 poles disagrees for 1400 ms or longer.

Circuit Breaker Inactivity Time Elapsed

The relay circuit breaker inactivity time monitor detects the elapsed time (measured in days) since the last trip or close operation of a circuit breaker. Use setting B1ITAT to set the circuit breaker inactivity time. An alarm Relay Word bit, B1BITAL, asserts if the elapsed time exceeds a predefined setting. This alarm is useful to detect circuit breakers that are not operated on a regular basis. These circuit breakers can fail to operate when needed to perform a protection trip. If a breaker operation occurs after the alarm asserts, the alarm resets at time 00:00:00.000.

Example 8.9 Inactivity Time Settings

Use Circuit Breaker 1 for this example. To assert an alarm if Circuit Breaker 1 has not operated within the last 365 days, enter the following settings:

EB1MON := **Y** Breaker 1 Monitoring (Y, N)

B1ITAT := **365** Inactivity Time Alarm Threshold—BK1 (N, 1–9999 days)

Assertion of the Relay Word bit B1BITAL indicates that it has been more than 365 days since the last Circuit Breaker 1 operation.

When testing the inactivity timer, you must measure actual relay clock transitions across time 00:00:00.000 (to increment the day counter). If you set the relay to a specific date, enable the circuit breaker monitor (EB1MON := Y), then advance the date setting to a new date, the inactivity timer shows only one day of elapsed time.

Motor Running Time

The relay circuit breaker monitor measures circuit breaker motor running time. Depending on your circuit breaker, you can use the motor running time to monitor the charge time of the circuit breaker springs or the running time of the compressed air motor. An alarm asserts if the elapsed motor running time exceeds the predefined threshold setting B1MRTAT.

Setting B1MRTIN is a SELOGIC control equation to activate the motor running timer. The rising edge of B1MRTIN indicates the motor starting time; a falling edge indicates the motor stop time. The motor running time logic asserts the alarm Relay Word bit, B1MRTAL, for 5 seconds when the motor running time exceeds the predefined threshold. Setting B1MRTIN to logical 0 disables the motor running time feature of the circuit breaker monitor.

Example 8.10 Motor Running Time Settings

Use Circuit Breaker 1 for this example.

Connect the motor control contact to IN207. This example uses control input IN207; you can use any control inputs that are appropriate for your installation.

To determine the motor run time value, take the circuit breaker out of service by using your company standard circuit breaker maintenance policy. Issue a trip and close command while you measure the time that the circuit breaker motor requires for recharging the spring or reestablishing the return air pressure to normal. Add 20 percent to this time measurement to avoid false alarms. Use the resulting time value for the motor running time alarm setting B1MRTAL.

Example 8.10 Motor Running Time Settings (Continued)

The control voltage for this example is 125 Vdc. Control Input IN207 is located on the relay I/O Interface board #1.

The recharge time measurement for this circuit breaker was 20 seconds; add 20 percent (4 seconds) to give an alarm time of 24 seconds. To set the motor running time alarm threshold at 24 seconds, enter the following settings:

EB1MON := **Y** Breaker 1 Monitoring (Y, N)

B1MRTIN := **IN207** Motor Run Time Control Input—BK1 (SELOGIC Equation)

B1MRTAT := **24** Motor Run Time Alarm Threshold—BK1 (1–9999 seconds)

Assertion of the Relay Word bit B1MRTAL indicates the following condition: motor running time exceeds 24 seconds because IN207 was asserted for more than 24 seconds.

BREAKER Command

Use the **BRE** command to access vital information about the condition of substation circuit breakers and preset or reset circuit breaker monitor data. The relay monitors two separate circuit breakers; you must specify Circuit Breaker 1 and Circuit Breaker 2 for most **BRE** commands. *Table 8.6* shows the **BRE** commands. For more information on the **BRE** command, see *BREAKER on page 14.4*.

Table 8.6 BRE Command

Command	Description	Access Level
BRE C A	Clear all circuit breaker monitor data to zero.	B, P, A, O, 2
BRE *n* C[a]	Clear Circuit Breaker *n* data to zero.	B, P, A, O, 2
BRE *n*[a]	Display the breaker report for the most recent Circuit Breaker *n* operation.	1, B, P, A, O, 2
BRE *n* H[a]	Display history data for the last 128 Circuit Breaker *n* operations.	1, B, P, A, O, 2
BRE *n* P[a]	Preload previously accumulated Circuit Breaker *n* data.	B, P, A, O, 2

[a] n is the breaker reference.

The **BRE *n* C** command resets the accumulated circuit breaker monitor data for Circuit Breaker *n*. The clear command **BRE C A** clears all data for both circuit breakers.

The **BRE *n*** command displays the circuit breaker report for the most recent Circuit Breaker *n* operation.

You can also reset the circuit breaker report with Global SELOGIC setting RST_BK*n* for the Circuit Breaker *n* report. You must first set EDRSTC (Data Reset Control) to Y to access these Global settings.

The relay also displays the operation summary and the circuit breaker alarms. When the circuit breaker maintenance curve reaches 150 percent for a particular pole, the percentage wear for this pole remains at 150 percent (even if additional current is interrupted) until reset. However, the relay continues to advance the operation counter to as many as 9999999 operations per pole until reset. Accumulated circuit breaker wear/operations data are retained if the relay loses power or if the circuit breaker monitor is disabled (EB*n*MON := N).

Circuit Breaker Report

Figure 8.9 shows a sample breaker report (with typical data). The relay reports dc battery monitor voltages for the minimum dc voltage during a 20-cycle period at circuit breaker monitor trip initiation (BM1TRPϕ) and for a 30-cycle window at circuit breaker monitor close initiation (BM1CLSϕ). The circuit breaker report contains data only for options that you have enabled.

```
=>BRE 1 <Enter>

Relay 1                                    Date: 03/20/2001  Time: 17:21:42.577
Station A                                  Serial Number: 2001001234
Breaker 1
Breaker 1 Report

                                 Trip A  Trip B  Trip C   Cls A   Cls B   Cls C
Avg Elect Op Time (ms)                                     5.8     7.5     8.4
Last Elect Op Time (ms)          18.2    20.0    17.9     8.4    10.4     8.4
Avg Mech Op Time (ms)
Last Mech Op Time (ms)           25.8    24.4    26.5    30.1    26.3    34.2
Inactivity Time (days)              1       1       1       1       1       1

                                     3 Pole Trip             3 Pole Close
                                   AB      BC      CA      AB      BC      CA
Max Pole Scatter (ms)             5.1     3.1     5.0     6.3     4.1     2.1
Last Pole Scatter (ms)            2.1     1.0     3.1     4.1     2.1     2.1

                                Pole A  Pole B  Pole C
Accum Pri Current (kA)        3.13657 0.43533 0.41785
Accum Contact Wear (%)            0.5     0.5     0.5
Max Interrupted Current (%)       1.6     0.2     0.2
Last Interrupted Current(%)       1.6     0.2     0.2
Number of Operations                5       5       5

                                Alarm   Total Count
Mechanical Operating Time       MSOAL       4
Electrical Operating Time       ESOAL       3
Breaker Inactivity Time         BITAL       0
Pole Scatter                     PSAL       2
Pole Discrepancy                 PDAL       1
Current (kA) Interrupted        KAIAL       0
LAST BREAKER MONITOR RESET   03/15/2001   07:21:31.067

=>
```

Figure 8.9 SEL-411L Breaker Report (for the Most Recent Operation)

Breaker History

The relay displays the circuit breaker history report when you issue the **BRE *n* H** command. The report consists of as many as 128 circuit breaker monitor events stored in nonvolatile memory. These events are determined by settings BM*n*TRPϕ and BM*n*CLSϕ. The breaker history report is similar to that shown in *Figure 8.10* (shown with typical data).

NOTE: If the breaker electrical or mechanical operating time exceeds a closing or tripping setting, the relay flags the data as overflowed by appending the + symbol to the corresponding operating time.

```
=>BRE 1 H <Enter>
Breaker 1 History Report
Relay 1                                    Date: 03/15/2001  Time: 07:19:27.156
Station A                                  Serial Number: 2001001234

No.     Date         Time        Bkr.Op Op Time(ms)   Pri I   VDC1   VDC2
                                        Elect Mech     (A)    (V)    (V)
1    06/01/2000  12:24:36.216    Trp A   26  28        5460   119    118
2    06/01/2000  12:24:36.216    Trp B   26  28        5260   119    118
3    06/01/2000  12:24:36.216    Trp C   26  28        5160   119    119
4    09/26/1999  16:24:36.214    Cls A   39  35        1020   118    118
5    09/26/1999  16:24:36.214    Cls B   39  35        990    118    118
6    09/26/1999  16:24:36.214    Cls C   39  35        1010   118    118
7    03/26/1999  11:24:36.218    Cls C   39  35        1100   117    115
8    03/26/1999  11:24:31.218    Trp C   26  28        3460   116    112
128
=>
```

Figure 8.10 Breaker History Report

Preload Breaker Wear

You can preload a separate contact wear value for each pole of each circuit breaker by using the command **BRE *n* P** for Circuit Breaker *n*. The relay adds the incremental contact wear at all subsequent circuit breaker monitor initiations to your preloaded value to obtain a total wear value. You can enter integer values of percentage wear from 1 to 100 percent. In addition to preloading contact wear data, you can enter values for previous operations and accumulated currents. The maximum number of operations or accumulated primary current (in kA) you can enter is 9999999. The circuit breaker preload terminal screen is similar to *Figure 8.11* for both the terminal and QuickSet.

```
=>BRE 1 P <Enter>
Accum Contact Wear (%)            A-phase % :=  5 ? 12 <Enter>
                                  B-phase % := 10 ? 15 <Enter>
                                  C-phase % :=  7 ? 10 <Enter>
Accum Num of Operations:          A-phase := 25 ? 11 <Enter>
                                  B-phase := 25 ? 11 <Enter>
                                  C-phase := 25 ? 11 <Enter>

Accum Pri Current (kA)            Trip A := 99.0 ? 299 <Enter>
                                  Trip B := 98.0 ? 254 <Enter>
                                  Trip C := 98.0 ? 257 <Enter>
                                    Pole A      Pole B      Pole C
Accum Contact Wear (%)                12          15          10
Accum Num of Operations               11          11          11
Accum Pri Current (kA)               299         254         257
```

Figure 8.11 Circuit Breaker Preload Data

When performing circuit breaker testing, capture the **BRE *n* P** information (write the date or use a terminal screen capture) before testing. Test the circuit breaker, then enter the previously recorded preload data with the **BRE *n* P** command. Using this method, you can eliminate testing operations from actual usage data in the circuit breaker monitor.

SEL Compressed ASCII Circuit Breaker Report

You can retrieve a Compressed ASCII circuit breaker report by using the **CBR** command from any communications port.

The relay arranges items in the Compressed ASCII circuit breaker report in a special order. For the purpose of improving products and services, SEL sometimes changes the items and item order.

The information presented below explains the message and serves as a guide to the items in a Compressed ASCII configuration circuit breaker report.

The format of the Compressed ASCII **CBR** message is the following.

```
“RID”,“SID”,“FID”,“yyyy”
relayid,station,fidstring,"yyyy"
"BID","yyyy"
breakerid,"yyyy"
"AVG_TR_ELE","LST_TR_ELE","AVG_TR_MEC","LST_TR_MEC","LST_TRmDC1",
   "LST_TRmDC2","TR_INAC(d)","MAX_TR_SCA","LST_TR_SCA", "AVG_CL_ELE",
   "LST_CL_ELE","AVG_CL_MEC","LST_CL_MEC","LST_CLmDC1",
   "LST_CLmDC2","CL_INAC(d)","MAX_CL_SCA","LST_CL_SCA", "ACC_I(kA)",
   "ACC_WEAR(%)","MAX_INT_I(%)","LAST_INT_I(%)","NUM_OPS","yyyy"

fff,fff,fff,fff,fff,fff,iii,fff,fff,fff,fff,fff,fff,fff,fff,iii,fff,fff,
   fff,fff,fff,fff,iii,"yyyy"
fff,fff,fff,fff,fff,fff,iii,fff,fff,fff,fff,fff,fff,fff,fff,iii,fff,fff,
   fff,fff,fff,fff,iii,"yyyy"
fff,fff,fff,fff,fff,fff,iii,fff,fff,fff,fff,fff,fff,fff,fff,iii,fff,fff,
   fff,fff,fff,fff,iii,"yyyy"
"AVG_MOT_RT","LST_MOT_RT","RST_MONTH","RST_DAY","RST_YEAR","RST_HOUR","RST_MIN",
  "RST_SEC","yyyy"
iii,iii,iii,iii,iii,iii,iii,iii,"yyyy"
```

Definitions for the items and fields in the Compressed ASCII configuration are the following:

- yyyy is the checksum
- iii is an integer value
- fff is a floating-point value

The relay reports the data as A-Phase in the first line, B-Phase in the second line, and C-Phase in the third line. Pole scatter data are slightly different: TAB is in the first line, TBC is in the second line, and TCA is in the third line.

Station DC Battery System Monitor

NOTE: This section lists settings for Station DC Battery Monitor 1; settings for Station DC Battery Monitor 2 are similar; replace 1 in the setting with 2.

The relay automatically monitors station battery system health by measuring the dc voltage, ac ripple, and voltage between each battery terminal and ground. SEL-400 series relays provide either one or two dc monitor channels. See the product-specific instruction manual to see how many breaker monitor channels the relay supports. Four voltage thresholds give you the ability to create five sensing zones (low failure, low warning, normal, high warning, and high failure) for the dc voltage.

The ac ripple quantity indicates battery charger health. When configuring the ac ripple setting DC1RP, we can define the ripple content of a dc supply as the peak-to-peak ac component of the output supply waveform.

The relay also makes measurements between the battery terminal voltages and station ground to detect positive and negative dc ground faults. *Figure 8.12* shows a typical dual-battery dc system.

Figure 8.12 Typical Station DC Battery System

The dc battery monitor measures the station battery voltage applied at the rear-panel terminals labeled Vdc1 (+ and –) and Vdc2 (+ and –). Monitoring dc voltage during circuit breaker operation gives a quick test of the battery system, which includes wiring and junctions from the batteries to the circuit breaker. In the breaker report and in the breaker history report, the relay displays the minimum value of station battery voltage during circuit breaker operation on a per-pole basis.

NOTE: First enable Station DC Monitoring (with the Global setting EDCMON) to access station dc battery monitor settings.

Table 8.7 lists the station dc battery monitor settings and the corresponding Relay Word bits that assert when battery quantities exceed these settings thresholds. Use the **SET G** ASCII command from a terminal or use the QuickSet **Global > Station DC Monitoring** branch of the Settings tree view to access the DC Monitor settings.

Table 8.7 DC Monitor Settings and Relay Word Bit Alarms

Setting[a]	Definition	Relay Word Bit[a]
DC1LFP	Low Level Fail Pickup (OFF, 15–300 Vdc)	DC1F
DC1LWP	Low Level Warn Pickup (OFF, 15–300 Vdc)	DC1W
DC1HWP	High Level Warn Pickup (OFF, 15–300 Vdc)	DC1W
DC1HFP	High Level Fail Pickup (OFF, 15–300 Vdc)	DC1F
DC1RP	Peak-to-Peak AC Ripple Pickup (1–300 Vac)	DC1R
DC1GF	Ground Detection Factor (1.00–2.00) (advanced setting)	DC1G

[a] For DC2 Monitor Settings and Relay Word bit alarms, substitute 2 for 1 in the setting names and Relay Word bit names.

Station DC Battery System Monitor Application

In addition to providing a view of how much the station dc battery voltage dips when tripping, closing, and when other dc control functions occur, the dc monitor also alarms for under- or overvoltage dc battery conditions in five sensing regions. The following describes how to apply the dc battery monitor to a typical 125 Vdc protection battery system with a 48 Vdc communications equipment battery system. Adjust the values used here to meet the specifications of your company.

Battery Voltage

When setting the station dc battery monitor, you must determine the minimum and maximum dc levels in the battery system. In addition, you must also establish the threshold levels for different battery system states or conditions. The following voltage levels describe these battery system conditions:

- Trip/Close—the lowest dc voltage point at which circuit breaker trip and close operations occur
- Open-circuit—the dc battery voltage when all cells are fully charged and not connected to the battery charger
- Float low—the lowest charging voltage supplied by the battery charger
- Float high—the highest charging voltage supplied by the battery charger
- Equalize mode—a procedure during which the batteries are overcharged intentionally for a preselected time to bring all cells to a uniform output

Set the low end of the allowable dc battery system voltage according to the recommendations of C37.90–1989 (R1994) IEEE Standard for Relays and Relay Systems Associated with Electric Power. Section 6.4 in this standard is titled Allowable Variation from Rated Voltage for Voltage Operated Auxiliary Relays. This section calls for an 80 percent low-end voltage and 28, 56, 140, or 280 Vdc high-end voltages for the popular nominal station battery voltages. *Table 8.8* lists expected battery voltages under various conditions that use commonly accepted per-cell voltages.

Table 8.8 Example DC Battery Voltage Conditions

Condition	Calculation	Battery Voltage (Vdc)
Trip/Close	80% • 125 Vdc	100.0
Open-Circuit	60 (cells) • 2.06 (volts/cell)	123.6
Float Low	60 (cells) • 2.15 (volts/cell)	129.0
Float High	60 (cells) • 2.23 (volts/cell)	133.8
Equalize Mode	60 (cells) • 2.33 (volts/cell)	139.8
Trip/Close	80% • 48 Vdc	38.4
Open-Circuit	24 (cells) • 2.06 (volts/cell)	49.4
Float Low	24 (cells) • 2.15 (volts/cell)	51.6
Float High	24 (cells) • 2.23 (volts/cell)	53.5
Equalize Mode	24 (cells) • 2.33 (volts/cell)	55.9
Trip/Close	80% • 24 Vdc	19.2
Open-Circuit	12 (cells) • 2.06 (volts/cell)	24.7
Float Low	12 (cells) • 2.15 (volts/cell)	25.8
Float High	12 (cells) • 2.23 (volts/cell)	26.8
Equalize Mode	12 (cells) • 2.33 (volts/cell)	28.0

Use the expected battery voltages of *Table 8.9* to determine the relay station dc battery monitor threshold settings. *Table 8.9* shows these threshold settings for a nominal 125-Vdc battery system (the Vdc1 input) and a nominal 48-Vdc battery system (the Vdc2 input).

Table 8.9 Example DC Battery Monitor Settings—125 Vdc for Vdc1 and 48 Vdc for Vdc2

Setting	Description	Indication	Value (Vdc)
DC1LFP	Low-fail threshold, Mon. 1	Poor battery performance	100
DC1LWP	Low-warning threshold, Mon. 1	Charger malfunction	127
DC1HWP	High-warning threshold, Mon. 1	Equalization	137
DC1HFP	High-fail threshold, Mon. 1	Charger malfunction	142
DC2LFP	Low-fail threshold, Mon. 2	Poor battery performance	38
DC2LWP	Low-warning threshold, Mon. 2	Charger malfunction	50
DC2HWP	High-warning threshold, Mon. 2	Equalization	55
DC2HFP	High-fail threshold, Mon. 2	Charger malfunction	57

AC Ripple

Another method for determining whether the substation battery charger has failed is to monitor the amount of ac ripple on the station dc battery system. The IEEE C37.90-1989 standard also identifies an “Allowable AC Component in DC Con-

trol Voltage Supply" (Section 6.5) as an alternating component (ripple) of 5 percent peak or less. (This definition is valid if the minimum instantaneous voltage is not less than 80 percent of the rated voltage.) The relay measures ac ripple as a peak-to-peak waveform, consequently, DC1RP and DC2RP should be set at or greater than 10 percent (2 • 5% peak) of the equalizing voltage. *Table 8.10* shows the ac ripple threshold settings for this example.

Table 8.10 Example DC Battery Monitor Settings—AC Ripple Voltages

Setting	Description	Indication	Value (Vac)
DC1RP	AC ripple threshold, Mon. 1	Charger malfunction	14
DC2RP	AC ripple threshold, Mon. 2	Charger malfunction	6

DC Ground

If a battery system is centered around chassis ground, then the magnitude of the voltage measured from the positive terminal-to-ground and from the negative terminal of the battery to ground should be approximately one-half of the nominal battery system voltage. The ratio of the positive-to-ground battery voltage to the negative-to-ground battery voltage is 1 to 1, or 1.00. *Equation 8.5* is the balanced (no grounding) ratio for a 125-Vdc battery system.

$$k = \frac{Vdc1_{pos}}{Vdc1_{neg}} = \frac{62.50\ V}{62.50\ V} = 1.00$$

Equation 8.5

If either terminal is partially or completely shorted to chassis ground, then the terminal voltage will be less than the nominal terminal-to-ground voltage. This causes the ratio of positive voltage to negative voltage to differ from 1.00. *Equation 8.6* is an example of the unbalanced (grounding) ratio for a partial short circuit to ground on the negative side of a 125-Vdc battery system.

$$k = \frac{Vdc1_{pos}}{Vdc1_{neg}} = \frac{62.50\ V}{59.10\ V} = 1.06$$

Equation 8.6

The relay uses this voltage ratio to calculate a ground detection factor. *Figure 8.13* shows a graphical representation of the ground detection factor setting and battery system performance.

Figure 8.13 Ground Detection Factor Areas

NOTE: Only the upper ground detection factor in Figure 8.12 is entered as a setting. The relay calculates the lower factor by taking the reciprocal of the upper factor: 1/1.05 = 0.952 in this case.

If the ground detection factor ratio exceeds a setting threshold, the relay asserts the DCIG Relay Word bit. To set the ground detection factor threshold, enable the advanced Global settings (set EGADVS := Y), and set the DC1GF and the DC2GF thresholds at a value close to 1.05 (the factory-default setting) to allow for some slight battery system unbalance of around 5 percent. *Table 8.11* lists the ground detection factor threshold settings for this example.

Table 8.11 Example DC Battery Monitor Settings—Ground Detection Factor (EGADVS := Y)

Setting	Description	Indication	Value
DC1GF	Ground detection factor, Mon. 1	Battery wiring ground(s)	1.05
DC2GF	Ground detection factor, Mon. 2	Battery wiring ground(s)	1.05

DC Battery Monitor Alarm

You can use the battery monitor Relay Word bits to alert operators for out-of-tolerance conditions in the battery systems. Add the appropriate Relay Word bit to the SELOGIC control equation that drives the relay control output you have selected for alarms. For example, use the Form B contact of control output OUT214. Set the SELOGIC control equation to include the battery monitor thresholds.

OUT214 := **NOT (HALARM OR SALARM OR DC1F OR DC1W OR DC1R OR DC1G)** (Output SELOGIC Equation)

This is one method; you can implement many other methods as well.

This page intentionally left blank

SECTION 9

Reporting

The relay features comprehensive power system data analysis capabilities. The relay provides these useful analysis tools:

- *Data Processing on page 9.1*
- *Triggering Data Captures and Event Reports on page 9.7*
- *Duration of Data Captures and Event Reports on page 9.9*
- *Oscillography on page 9.9*
- *Event Reports, Event Summaries, and Event Histories on page 9.13*
- *Sequential Events Recorder (SER) on page 9.28*
- *Signal Profiling on page 9.31*

An event is a representation of the operating conditions of the power system at a specific time. Events include instances such as a relay trip, an abnormal situation in the power system that triggers a relay element, or an event capture command.

Information from oscillograms, relay event reports, SER, and signal profiling data are very valuable if you are responsible for outage analysis, outage management, or relay settings coordination.

The relay accepts high-accuracy timing, such as IRIG-B. When a suitable external clock is used (such as the SEL-2407 Satellite-Synchronized Clock), the relay synchronizes the data acquisition system to the received signal. Knowledge of the precise time of sampling allows comparisons of data across the power system. Use a coordinated network of time-synchronized relays to create moment-in-time "snapshots" of the power system. These data are useful for determining power system dynamic voltage and current phasors, impedances, load flow, and system states.

Data Processing

SEL-400 series relays are numeric, or microprocessor-based, relays that sample power system conditions. The relay converts analog inputs received via CT and PT inputs to digital information for processing to determine relaying quantities for protection and automation. *Figure 9.1* shows a general overview of the input processing diagram for the relay. *Figure 9.2* shows a general overview of the input processing for a relay with Sampled Values (SV).

The relay outputs two types of analytical data: high-resolution raw data and filtered data. *Figure 9.1* shows the path a power system VT and CT signals take through relay input processing. A CT or PT analog input begins at hardware acquisition and sampling, continues through software filtering, and progresses to protection and automation processing. The initial hardware low-pass filter half-power or –3 dB point is 3.0 kHz. Next, the relay samples the power system voltage or current with an 8000 samples/second A/D (analog to digital) converter. This is the tap point for high-resolution raw data captures. You can select 8000 samples/second, 4000 samples/second, 2000 samples/second, and 1000 samples/

second effective sampling rates for presentation and storage of the high-resolution raw data COMTRADE format (see *Oscillography on page 9.9*). From the same 8 kHz downsampled data, a dashed lined showing SV data packet creation is provided and only occurs on SEL-400 series SV publisher devices.

Figure 9.2 shows the path a power system signal received via DSS technology takes through relay processing. The received data streams are first filtered, decoded, scaled, and resampled. The resampled data then continues through software filtering and progresses to protection and automation processing. The relay resamples incoming data to 8 kHz analog samples. This is the tap point for high-resolution raw data captures.

Figure 9.1 Input Processing

The software portion of input signal processing receives the high-resolution raw data sampled quantities and passes these to the Anti-Aliasing Digital Filter. The half-power or –3 dB point of the anti-aliasing filter is 640 Hz. Subsequent processing decimates the sampled data to the processing interval by using additional digital filtering. This information is the filtered data for event reports and other relay functions. The relay downsamples the filtered data to present 4-samples/cycle event reports.

The relay samples the control inputs at a rate of 2 kHz. The raw input digital status is available in high-resolution (COMTRADE) data files. Contact bounce may be visible when the raw data are viewed.

The relay filters both types of control inputs with settable debounce timers, and updates the resulting Relay Word bits every processing interval. Event reports can include the filtered control input Relay Word bits.

Control input state changes will appear to occur faster in COMTRADE oscillography files than in event reports (**EVE** command) or Sequential Events Recorder reports (**SER** command) because of the control input debounce time delays.

Figure 9.2 Input Processing of SEL-400 Series Relays Supporting DSS Technology

Effect of Full-Cycle Cosine Filtering on Protection Speed

Most of the protection elements within an SEL-400 series relay use data that have been processed through a full-cycle cosine filter (see *Figure 9.1*). This digital filter removes harmonic content and removes the decaying dc component that is present during a fault. To accomplish this, the relay maintains a data buffer for each of the input analog channels (e.g., VAY, IAW), containing a full-power system cycle of data. The oldest data sample in the buffer is from one power system

cycle in the past, and the newest data sample is from the present. The output of the filter is a weighted sum of these buffered data samples, with the weights being points from a cosine function (hence the name cosine filter).

When a fault occurs, the cosine filter is initially full of pre-fault data. It takes a full-power system cycle for the filter buffer to completely fill up with fault data. It takes an additional quarter cycle for the phasor magnitudes to fully stabilize at their new values because the relay calculates phasor magnitudes by using two samples separated by a quarter cycle. Consequently, the full-cycle cosine filtered protection quantities take as long as 1.25 power system cycles to reach a new steady state after the onset of a fault.

Figure 9.3 illustrates this behavior. At time $t = 0$, the relay sees a step change in secondary current from 5 A to 15 A rms secondary. The full-cycle filtered current magnitude reaches the new steady-state value of 15 A after approximately 1.25 power system cycles. To illustrate the effect on protection speed, consider three hypothetical overcurrent elements within the relay, each with a different pickup value. The pickup values are PU1 = 6 A, PU2 = 10 A, and PU3 = 14 A, respectively, and these are plotted on the graph alongside the filtered current magnitude. It is evident from the graph that the overcurrent elements with the smaller pickup values operate more quickly. Element 1 operates in 0.125 cycles, Element 2 operates in 0.625 cycles, and Element 3 operates in 1.125 cycles. The smaller the pickup threshold is relative to the applied current, the faster the element operates. This is a direct consequence of the fact that it takes approximately a cycle for the cosine filter to fully charge.

Figure 9.3 Filtered Current Magnitude With Overcurrent Pickups

The processing rate of the protection logic combines with the cosine filter delay to influence protection speed. Most SEL-400 series protection elements run at either 8 samples/cycle or 4 samples/cycle. When the applied current is very large relative to the pickup threshold (e.g., PU1 for Element 1), the processing rate is very influential in determining the protection speed. This is because the effective cosine filter delay is only around one processing interval in that case. When the

applied current is barely over the pickup (e.g., PU3 for Element 3), the protection speed is mostly determined by the cosine filter delay because a full cycle is a considerably longer time than one processing interval.

Triggering Data Captures and Event Reports

Oscillograms and event reports are triggered both internally and externally depending on the event trigger that you program in the relay.

Use an event trigger to initiate capturing power system data. High-resolution raw data oscillography and event reports use the same triggering methods. The trigger for data captures comes from four possible sources:

- Relay Word bit TRIP assertions
- SELOGIC control equation ER (Event Report Trigger)
- **TRI** command
- SEL Grid Configurator (see *Section 2: PC Software*)

In some SEL relays, the **PUL** command initiated event recording. If you want the **PUL** command to initiate data capture, add the Relay Word bit TESTPUL to the SELOGIC control equation ER.

Relay Word Bit TRIP

If Relay Word bit TRIP asserts, the relay automatically generates a data capture event trigger on the rising edge of the TRIP Relay Word bit state change. In every instance, TRIP causes the relay to begin recording data. You therefore do not have to enter any condition that causes a trip in the ER SELOGIC control equation.

SELOGIC Control Equation ER

Program the SELOGIC control equation ER to trigger high-resolution raw data oscillography, traveling-wave data oscillography, and standard event reports for conditions other than TRIP conditions. When ER asserts, the relay begins recording data if the relay is not already capturing data initiated by another trigger.

Example 9.1 Triggering Event Report/Data Capture by Using the ER SELOGIC Control Equation

This example shows how the elements in the ER SELOGIC control equation initiate relay data capture.

An example of a factory-default setting for Group setting SELOGIC control equation ER in the SEL-411L is:

ER := **R_TRIG Z2P OR R_TRIG Z2G OR R_TRIG 51S01 OR R_TRIG Z3P OR R_TRIG Z3G** Event Report Trigger Equation (SELOGIC Equation)

Example 9.1 Triggering Event Report/Data Capture by Using the ER SELOGIC Control Equation (Continued)

The element transitions in this setting are from the following Relay Word bits:

- Z2P, Z3P: Zone 2 phase distance element, Zone 3 phase distance element
- Z2G, Z3G: Zone 2 ground distance element, Zone 3 ground distance element
- 51S01: Instantaneous output of Inverse-Time Overcurrent Element 1

The rising-edge operator, R_TRIG, occurs in front of each of the elements in the factory-default ER equation. Rising-edge operators are especially useful for generating an event report at fault inception. The triggering element causes ER to assert, then clears the way for other elements to assert ER because the relay uses only the beginning of a long element assertion. The starting element in a continuously occurring fault does not mask other possible element triggers. This allows another rising-edge sensitive element to generate another event report later in that same continuously occurring fault (such as an overcurrent situation with the R_TRIG 51S01 element).

In the example factory-default ER SELOGIC control equation, if the Z3G element remains asserted for the duration of the ground fault, the rising-edge operator, R_TRIG, in front of Z3G causes ER to assert for only one processing interval (a 1/8-cycle pulse). Other elements in the ER SELOGIC control equation can trigger event reports while the Z3G element remains asserted throughout the fault duration.

You can also use the falling-edge operator, F_TRIG, to initiate data captures.

Example 9.2 Including PUL Command Triggering in the ER SELOGIC Control Equation

This example shows you how to add the effect of the PUL command to emulate previous SEL relays. The relay asserts Relay Word bit, TESTPUL, when any output is pulsed via the PUL command.

Program the Group settings SELOGIC control equation ER as follows:

ER := **R_TRIG Z2P OR R_TRIG Z2G OR R_TRIG 51S01 OR R_TRIG Z3P OR R_TRIG Z3G OR TESTPUL** Event Report Trigger Equation (SELOGIC Equation)

TRI (Trigger Event Report) Command

Use the **TRI** command from any communications port to trigger the relay to begin recording high-resolution raw data, traveling-wave data, and event report data. When testing with the **TRI** command, you can gain information on power system operating conditions that occur immediately after you issue the **TRI** command.

Duration of Data Captures and Event Reports

The relay stores unfiltered, high-resolution raw data (sampled at either 8 kHz, 4 kHz, 2 kHz, or 1 kHz) and filtered event reports. The number of stored high-resolution raw data captures and event reports is a function of the amount of data contained in each capture. You can configure the relay to record long data captures at high sampling rates, although this reduces the total number of stored events you can retrieve from the relay.

To use the data capture functions, select the effective sampling rate and data capture times. Relay setting SRATE determines the number of data points the relay records per second. You can set SRATE to 8 kHz, 4 kHz, 2 kHz, and 1 kHz.

The length of the data capture/event report (setting LER) and the pre-trigger or pre-fault time (setting PRE) are related, as shown in *Figure 9.4*. The LER setting is the overall length of the event report data capture; the PRE setting determines the time reserved in the LER period when the relay records pre-trigger (pre-fault) data. Typically, you set the PRE time to 20 percent of the total LER period. Traveling-wave records have a fixed sampling rate of 1.5625 MHz and a fixed event length of 7.5 ms.

NOTE: PRE has a dynamic range based on the current value of LER. The upper range of PRE = LER – 0.05.

Figure 9.4 Data Capture/Event Report Times

The relay stores all data captures to volatile RAM and then moves these data to nonvolatile memory storage. There is enough volatile RAM to store one maximum length capture (maximum LER time) for a given SRATE. No data captures can be triggered while the volatile RAM is full; the relay must move at least one data capture to nonvolatile storage to re-enable data capture triggering. Thus, to record sequential events, you must set LER to half or less of the maximum LER setting. The relay stores more sequential data captures as you set LER smaller.

See *Section 7: Metering, Monitoring, and Reports* in the product-specific instruction manual, to determine the event storage capacity for any specific relay. The relay automatically overwrites the oldest events with the newest events when the nonvolatile storage capacity is exceeded.

Oscillography

NOTE: Relays with DSS technology adjust COMTRADE files automatically by the channel delay associated with the DSS technology used. This allows for comparison with COMTRADE files gathered from traditional, non-DSS relays. CEV files, however, retain the channel delay because those files show how the relay operated based on the received signals.

The relay features the following types of oscillography:

- Raw data oscillography—effective sampling rate as fast as 8000 samples/second
- Event report oscillography from filtered data

Use high-resolution raw data oscillography to view transient conditions in the power system. You can set the relay to report these high-resolution oscillograms at 8000 samples/second, 4000 samples/second, 2000 samples/second, and 1000 samples/second effective sampling rates. The high-resolution raw data and

traveling-wave data oscillograms are available as files through the use of Ymodem file transfer and File Transfer Protocol (FTP) in the binary COMTRADE file format output (IEEE Std C37.111-1999 and C37.111-2013, Common Format for Transient Data Exchange (COMTRADE) for Power Systems).

NOTE: The SEL-400G provides both filtered and raw high-resolution oscillograms by using the IEEE C37.111-2013 COMTRADE file format.

The filtered data oscillograms give you accurate information on the relay protection and automation processing quantities. The relay outputs filtered event reports through a terminal or as files in ASCII format and Compressed ASCII format, through FTP and Ymodem file transfers. *Figure 9.5* shows a sample filtered-data oscillogram.

Figure 9.5 Sample Oscillogram

Raw Data Oscillography

Raw data oscillography produces oscillograms that track power system anomalies that occur outside relay digital filtering.

COMTRADE files always include all eight Relay Word bits from each row of the Relay Word used as the base set for the relay (see *Section 7: Metering, Monitoring, and Reporting* in the product-specific instruction manual for a list of these bits). Additionally, it includes the rows containing those Relay Word bits configured for inclusion by the ERDG setting.

The relay stores high-resolution raw data oscillography in binary format and uses COMTRADE file types to output these data:

- .HDR—header file
- .CFG—configuration file
- .DAT—high-resolution raw data file

The .HDR file contains summary information about the event in ASCII format. The .CFG file is an ASCII configuration file that describes the layout of the .DAT file. The .DAT file is in binary format and contains the values for each input

channel for each sample in the record. These data conform either to the IEEE C37.111-1999 or C37.111-2013 COMTRADE standard, depending on the relay report settings.

.HDR File

The .HDR file contains the summary and relay settings information that appears in the event report for the data capture (see *Event Summary Section of the Event Report on page 9.23* and *Settings Section of the Event Report on page 9.24*). The settings portion is as illustrated in *Figure 9.6*.

```
Relay 1                                     Date: 02/02/2011  Time: 14:11:21.000
Station A                                   Serial Number: 2010265004

Event: ABG T   Location: 59.61 (mi)   From: LOCAL   FLM: TW   Time Source: HIRIG
Event Number: 10121      Shot 1P: 0   Shot 3P: 0        Freq: 59.99     Group: 1
Targets:
Breaker 1: CLOSED
Breaker 2: OPEN
PreFault:     IA     IB     IC     IG    3I2       VA       VB       VC    V1mem
MAG(A/kV)    200    200    200      1      1  133.946  133.938  133.941  133.935
ANG(DEG)    -0.7 -120.5  119.4  -51.7  -88.7      0.0   -119.9    120.2      0.1

Fault:
MAG(A/kV)   2200   2200   2200      7    376  133.937  133.926  133.957  133.933
ANG(DEG)    -0.7 -120.6  119.5 -102.0  -83.5      0.0   -119.9    120.2      0.1

                 87 Differential Currents
PreFault:     IA     IB     IC     IQ     IG
MAG(pu)     0.00   0.00   0.00   0.00   0.00
ANG(DEG)     0.0    0.0    0.0    0.0    0.0

Fault:
MAG(pu)     0.00   0.00   0.00   0.00   0.00
ANG(DEG)     0.0    0.0    0.0    0.0    0.0
```

Summary Event Information

```
SET_G1.TXT
[INFO]
RELAYTYPE=SEL-411L
FID=SEL-411L-X136-V0-Z001001-D20110114
BFID=SLBT-4XX-R205-V0-Z001002-D20100128
PARTNO=0411L0X6X1B6BCXH5C4E4XX
[IOBOARDS]
INT4_E, , , 24, 8, 0, 0, 1
CFSINT8, , , 8, 8, 0, 0, 2
[G1]
"SID","Station A"
"RID","Relay 1"
"NUMBK",2
"BID1","Breaker 1"
"BID2","Breaker 2"
"NFREQ",60
.
.
.
"AR197",
"AR198",
"AR199",
"AR200",
```

Relay Settings

Figure 9.6 Sample COMTRADE .HDR Header File

.CFG File

The .CFG file contains data such as sample rates, number of channels, line frequency, channel information, and transformer ratios (see *Figure 9.7*). A <CR><LF> follows each line. If control inputs or control outputs are not available because of board loading and configuration, the relay does not report these inputs and outputs in the analog and digital sections of the .CFG file. *Figure 9.7* shows a typical C37.111-1999 COMTRADE file format. C37.111-2013 COMTRADE file formats are also provided.

Station A,FID=SEL-411L-1-R100-V0-Z001001-D20110311,1999	Relay Information (1999 = COMTRADE Standard)
398,14A,384D	398 = sum of analogs and digitals 14A = total number of analog channels 384D = total number of digital points[a]
1,IAW,A,,A,0.324059,0,0,-32767,32767,200.0,1,P 2,IBW,B,,A,0.324059,0,0,-32767,32767,200.0,1,P 3,ICW,C,,A,0.324059,0,0,-32767,32767,200.0,1,P 4,IAX,A,,A,0.324059,0,0,-32767,32767,200.0,1,P 5,IBX,B,,A,0.324059,0,0,-32767,32767,200.0,1,P 6,ICX,C,,A,0.324059,0,0,-32767,32767,200.0,1,P 7,VAY,A,,kV,0.032406,0,0,-32767,32767,2000.0,1,P 8,VBY,B,,kV,0.032406,0,0,-32767,32767,2000.0,1,P 9,VCY,C,,kV,0.032406,0,0,-32767,32767,2000.0,1,P 10,VAZ,A,,kV,0.032406,0,0,-32767,32767,2000.0,1,P 11,VBZ,B,,kV,0.032406,0,0,-32767,32767,2000.0,1,P 12,VCZ,C,,kV,0.032406,0,0,-32767,32767,2000.0,1,P 13,VDC1,,,V,0.011178,-0.000000,0,-32767,32767,1,1,P 14,VDC2,,,V,0.011178,-0.000000,0,-32767,32767,1,1,P	14 Analog Channels
1,87USAFE,,,0 2,UNUSED2,,,0 3,UNUSED3,,,0 4,UNUSED4,,,0 5,OC1,,,0 6,CC1,,,0 7,OC2,,,0 8,CC2,,,0 9,87LA,,,0 10,87LB,,,0 11,87LC,,,0 12,87LQ,,,0 13,87LG,,,0 14,87FLSOK,,,0 15,87DTTRX,,,0 . . . 382,PCT06Q,,,0 383,PCT07Q,,,0 384,PCT08Q,,,0	384 Digital Points
60	Nominal System Frequency (INFREQ Setting)
1	
2000,1000	2000 = Sample Rate (SRATE setting) 1000 = Length of the Report x Sample Rate (LER x SRATE)
17/03/2011,08:36:38.697687	Time Stamp of the First Data Point
17/03/2011,08:36:38.799850	Time Stamp of the Trigger Point
BINARY	
1	

Figure 9.7 COMTRADE .CFG Configuration File Data

[a] If ERDIG is set to S, the digital points are all the Relay Word bits set in ERDG as well as the Relay Word bits that are always included in the event report. If ERDIG is set to A, the digital points are all the Relay Word bits in the device.

The configuration file has the following format:

- Station name, device identification, COMTRADE standard year
- Number and type of channels
- Channel name units and conversion factors
- Line frequency
- Sample rate and number of samples
- Date and time of first data point
- Date and time of trigger point
- Data file type
- Time stamp multiplication factor

.DAT File

NOTE: The analog data are time-aligned to when the data changed on the input terminals. Similarly, the contact inputs are time-aligned to when the data changed on the input terminals. All other digital data are time-aligned to when the value changed in the relay.

The .DAT file follows the COMTRADE binary standard. The format of the binary data files is sample number, time stamp, data value for each analog channel, and grouped status channel data for each sample in the file. There are no data separators in the binary file, and the file contains no carriage return/line feed characters. The sequential position of the data in the binary file determines the data translation. Refer to the IEEE Std C37.111-1999 or C37.111-2013, Common Format for Transient Data Exchange (COMTRADE) for Power Systems for more information.

Generating Raw Data Oscillograms

To use high-resolution raw data oscillography, select the type of triggering event and use a trigger event method described in *Triggering Data Captures and Event Reports on page 9.7*. Use the settings SRATE, LER, and PRE to set the relay for the appropriate data sampling rate and data capture time (see *Duration of Data Captures and Event Reports on page 9.9*).

Retrieving Raw Data Oscillograms

Use a computer terminal emulation program and the **FILE** commands at any communications port to retrieve the stored high-resolution raw data capture from the relay file structure. If the relay has an Ethernet port, you can also use FTP to retrieve these files. You can also use QuickSet.

Event Report Oscillography

Use a terminal or SEL-supplied PC software to retrieve filtered event report files stored in the relay and transfer these files to your computer. SYNCHROWAVE Event can be used to view the compressed event files that the relay generates for an event.

Event Reports, Event Summaries, and Event Histories

Event reports simplify post-fault analysis and help you improve your understanding of protection scheme operations. Event reports also aid in testing and troubleshooting relay settings and protection schemes because these reports contain detailed data on voltage, current, and relay element status. For further analysis assistance, the relay appends the active relay settings to each event report. The relay stores event reports in nonvolatile memory, and you can clear the event report memory on a port-by-port basis.

You decide the amount of information and length in an event report (see *Duration of Data Captures and Event Reports on page 9.9*).

The relay records the filtered power system data that the relay uses in protection and automation processing. You can view filtered information about an event in one or more of the following forms.

- Event report
- Event summary
- Event history

Alias Names

NOTE: If Alias names were changed after an event was recorded, the relay uses the present alias names in subsequent event reports.

To customize your event report, rename any Relay Word bit or analog quantity with more meaningful names to improve the readability of fault analysis and customized programming. After renaming the primitive quantities, the alias names rather than the primitive names appear in the event reports for the user-selectable analog and digital channels. The primitive names of the analog channels still appear in the event reports.

Event Report

The relay generates event reports to display analog data, digital data (control inputs, control outputs, and the state of Relay Word bits), and relay settings. The event report is a complete description of the data that the relay recorded in response to an event trigger. Each event report includes these components:

- Report header and analog section—Currents and voltages, sometimes including calculated quantities such as differential currents
- Digital section—Relay Word bit elements, control outputs, control inputs
- Event summary
- Settings
  - Group settings
  - Global settings
  - Output settings
  - **PORT 5** settings[1]
  - SELOGIC control equations protection logic

Viewing the Event Report

Access event reports from the communications ports and communications cards at Access Level 1 and higher. (You cannot view event reports at the front panel, although you can view event summary information at the front-panel display.) You can independently acknowledge the oldest event report at each communications port (**EVE ACK** command) so that you and users at other ports (SCADA, Engineering, etc.) can retrieve complete sets of event reports. To acknowledge the oldest event report, you must first view that event report at a particular port by using the **EVE N(EXT)** command.

You can use the **EVE** command and a terminal to retrieve event reports by event order or by event serial number. (The relay labels each new event with a unique serial number as reported in the **HIS** command history report [see *Event History on page 9.27*].)

Events are referenced two ways: by relative reference or by event serial number. Relative references are in the range 1–9999, where 1 refers to the most recent event, 2 to the next most recent, and so on. Event serial numbers are in the range 10000–42767. You can find the event serial number in the event history report. With the **EVE** and **CEV** commands, you can retrieve events by using either type of reference. Event files are names based on the event serial number.

[1] The following **PORT 5** settings are available in COMTRADE .HDR files: EPORT, E61850, EGSE, EMMSFS, E850MBC, SVRXEN (SV subscribers), SVTXEN (SV publishers), CH_DLY, EPTP, PTPPRO, PTPTR, DOMNUM, PTHDLY, PDINT, BUSMODE, NETMODE, and NETPORT.

By applying modifiers to the **EVE** command, you can retrieve only analog or digital information, and you can exclude the summary or settings portions of the report. The default **EVE** command event report data resolution is 4 samples/cycle and the default report length is 0.5 seconds (30 cycles at 60 Hz or 25 cycles at 50 Hz) with the factory-default setting for LER.

See the **EVE** command description in *Section 9: ASCII Command Reference* in the product-specific instruction manual for a complete list of options.

You can retrieve event reports with the QuickSet **Tools > Events > View Event Files** menu. The **Analysis > View Event Files** menu gives you oscillogram/element displays, phasor displays, harmonic analysis, and an event summary for each event you select in the **Event History** dialog box.

You can also download event report files from the relay by using a terminal emulation program with file transfer capability. At an Access Level 1 prompt or higher, type **FILE READ EVENTS E8_*nnnnn*.TXT <Enter>** for the 8-samples/cycle event report and type **FILE READ EVENTS E4_*nnnnn*.TXT <Enter>** for the 4-samples/cycle event report (*nnnnn* is the event serial number). Start the terminal download routine to store the file on your computer. If you want the Compressed ASCII file, use the C8_*nnnnn*.TXT and C4_*nnnnn*.TXT file names for the 8-samples/cycle and 4-samples/cycle Compressed ASCII event reports, respectively.

The following discussion shows sample portions of an event report that you download from the relay by using a terminal and the **EVE** command. An event report contains analog, digital, summary, and settings sections without breaks.

Inverse Polarity in Event Reports

In COMTRADE event reports, terminals that have EINVPOL enabled do not show the polarity as inverted. The COMTRADE must display the values as they are applied to the CT and PT inputs of the measuring device. This also ensures that when you use an event playback, the setting applies to the signals coming in the back of the relay and recreates the event properly.

Compressed event reports (CEV), show the polarity as inverted. The CEV displays the analogs as the relay uses them in processed logic; therefore, the relay displays the inverted polarity. See *Section 5: Protection Functions* in the product-specific instruction manual for information on inverting polarity on current and voltage inputs.

Report Header and Analog Section of the Event Report

The first portion of an event report is the report header and the analog section. Some relays have more than one analog section. See *Section 7: Metering, Monitoring, and Reports* in the product-specific instruction manual for details on what the event reports look like in each relay. See *Figure 9.8* for an example of a SEL-421 event report.

The report header is the standard relay header listing the relay identifiers, date, and time. Report headers help you organize report data. Each event report begins with information about the relay and the event. The report lists the RID setting (Relay ID) and the SID setting (Station ID). The FID string identifies the relay model, flash firmware version, and the date code of the firmware. The relay reports a date and time stamp to indicate the internal clock time when the relay triggered the event. The relay reports the firmware checksum as Configured IED Description (CID).

The event report column labels follow the header. The data underneath the analog column labels contain samples of power system voltages and currents.

```
Relay 1                                   Date: 03/15/2001  Time: 23:30:49.026
Station A                                 Serial Number: 2001001234
FID=SEL-421-R101-V0-Z001001-D20010315     Event Number = 10007      CID=0x3425

Currents (Amps Pri)            Voltages (kV Pri)
    IA     IB     IC     IG     VA     VB     VC    VS1    VS2  V1mem

[1]
  -267    167     44    -56 -288.0  337.7  -47.8  215.3  144.9 -287.9
   -76   -203    241    -37 -223.7 -138.4  361.3 -290.5  331.3 -223.7
   266   -166    -45     55  288.2 -337.5   47.5 -215.2 -145.0  288.1
    76    202   -242     36  223.4  138.7 -361.4  290.5 -331.2  223.5
                                    •
                                    •
                                    •
[6]
  -269    167     46    -56 -289.3  336.9  -45.8  215.5  144.7 -289.4
   -74   -202    240    -35 -222.2 -140.2  361.5 -290.2  331.4 -221.8
   268   -165    -45     57  289.4 -336.7   45.6 -215.4 -144.6  289.5
    93    151   -888   -643  221.1  133.5 -335.0  290.2 -331.4  220.8

[7]
  -208   2701  -3760  -1267 -288.7  293.7  -24.1  215.5  144.5 -286.3
  -146   2941    173   2968 -219.6  -87.6  261.6 -290.1  331.4 -214.0>
   134  -5748   8310   2696  286.9 -232.4    3.5 -215.6 -144.4  273.3
   179  -6677   1811  -4688  219.8   47.4 -214.2  290.0 -331.5  202.8

[8]
  -125   5661  -8506  -2971 -286.1  213.6   -3.8  215.8  144.2 -256.5
  -177   6857  -1950   4730 -220.8  -46.9  214.2 -289.9  331.6 -193.2*
   129  -5508   8382   3003  286.9 -213.8    3.6 -216.0 -144.0  243.9
   174  -6726   1839  -4712  220.4   47.2 -214.2  289.8 -331.6  185.9

[9]
  -128   5623  -8479  -2984 -287.1  213.9   -3.5  216.1  143.8 -234.5
  -173   6821  -1924   4724 -219.8  -47.3  214.0 -289.7  331.7 -180.4
   126  -5540   8404   2990  286.6 -213.7    3.5 -216.3 -143.7  227.3
   177  -6749   1860  -4713  220.0   47.4 -212.9  289.6 -331.8  176.2

[10]
  -126   4616  -6204  -1714 -282.9  178.6   41.9  216.4  143.5 -222.1
  -106   4288  -1047   3135 -231.6  -64.5   95.3 -289.4  331.9 -162.6
    65  -1722   1878    221  140.2  -72.1  -43.6 -216.6 -143.3  194.6
    16   -807      4   -786  105.1   41.3   10.5  289.2 -332.0  130.7

[11]
    -1     -1     -2     -5   13.8    1.1    0.3  216.8  143.1 -147.1
     2      3      4      9   54.8   -0.7   -0.3 -289.1  332.1  -93.5
     1      1      2      5   -8.1   -1.6   -1.1 -217.0 -142.8  109.8
    -2     -2     -3     -8  -58.2    0.2    0.2  289.0 -332.2   65.3
```

Header
Firmware ID in bold

1 Cycle of Data
See *Figure 9.9* and *Figure 9.10* to calculate phasors for the data in bold.

Trigger

Largest Current (to Event Summary)

Circuit Breaker Open

Figure 9.8 Fixed Analog Section of an Example SEL-421 Event Report

Within an event report, there are bracketed numbers at the left of the report (for example, [11]) that indicate the cycle number.

The trigger row is indicated by a > character following immediately after the last analog data column. This is the dividing point between the pre-fault or PRE time and the fault or remainder of the data capture.

The relay indicates which row has the largest current magnitudes, which are reported in the event summary, with an asterisk (*) character immediately after the last analog data column. The (*) takes precedence over the > if both occur on the same row in the analog section of the event report.

ERAQc (Analog Quantities)

NOTE: Analog quantities programmed in the Event Reporting Analog Quantities (ERAQc) are only added to the filtered event reports. These added analog quantities will not be visible in COMTRADE files.

To supplement the fixed analog quantities in the event report, select as many as 20 additional analog quantities in the event report. For example, say you programmed a function in the relay by using Protection Math Variables PMV01–PMV06, and you want to include these six PMVs in the event report. Enter the six PMVs in the Event Reporting Analog Quantities as shown below.

```
Event Reporting Analog Quantities
(Maximum 20 Analog Quantities)
1: PMV01
2: PMV02
3: PMV03
4: PMV04
5: PMV05
6: PMV06
```

The relay correlates the freeform line number chronologically with the ERAQ*c* quantities. In this example, ERAQ01 = PMV01, ERAQ02 = PMV02, etc.

In the event report, the ERAQ quantities follow the fixed analog quantities.

```
PMV01      PMV02      PMV03      PMV04      PMV05      PMV06
[1]
    20.000     25.000    102.000     34.000     67.000     54.000
    20.000     25.000    102.000     34.000     67.000     54.000
    20.000     25.000    102.000     34.000     67.000     54.000
    20.000     25.000    102.000     34.000     67.000     54.000
[2]
    20.000     25.000    102.000     34.000     67.000     54.000
    20.000     25.000    102.000     34.000     67.000     54.000
    20.000     25.000    102.000     34.000     67.000     54.000
    20.000     25.000    102.000     34.000     67.000     54.000
```

Obtaining RMS Phasors From 4-Samples/Cycle Event Reports

Use the column data in an event report to calculate rms values. You can use a calculator to convert rectangular data to phasor data, or use hand-calculations to separately determine the magnitude and angle of the rms phasor.

Hand Calculation Method

The procedure in the following steps explains a method for obtaining a current phasor from the IA channel data in the event report of *Figure 9.8*. You can process voltage data columns similarly. The drawings in *Figure 9.9* and *Figure 9.10* show 1 cycle of A-Phase current in detail. *Figure 9.9* shows how to relate the event report ac current column data to the sampled waveform and rms values. *Figure 9.10* shows how to find the phasor angle. If you use the larger 8-samples/cycle event report, take every other sample and apply those values in this procedure.

This examples assumes you have captured an event report and are prepared to calculate phasors from it.

Step 1. Calculate the phasor magnitude:

a. Select a cycle of data from the IA column of the event report.

Figure 9.8 Cycle [1] data for this example are shown in *Figure 9.9*.

There are three pairs of scaled instantaneous current samples from Cycle [1].

Compute phasor magnitude by using the following expression:

$$\sqrt{X^2 + Y^2} = |\text{Phasor}|$$

Equation 9.1

b. In *Equation 9.1*, Y is the first row of IA column current of a data pair, and the next row is X, the present value of the pair.

For this example, the computation shown in *Figure 9.9* yields 277.0 A.

c. Compute phasor magnitudes from the remaining data pairs for Cycle [1].

d. Confirm that all values are similar.

Figure 9.9 Event Report Current Column Data and RMS Current Magnitude

Step 2. Calculate the immediate phase angle.

a. Select the same cycle of data from the IA column of the event report as you did when finding the magnitude (Cycle [1] data for this example).

b. Compute phasor angle by using the following expression:

$$\theta = \arctan\left(\frac{Y}{X}\right) = \angle \text{Phasor}$$

Equation 9.2

In *Equation 9.2*, Y is the first (or previous value) IA column current of a data pair, and X is the present value of the pair.

For this example, the computation shown in *Figure 9.10* yields –105.9 degrees.

c. Compute phasor angles from the remaining data pairs for Cycle [1].

NOTE: The arctan function of many calculators and computing programs does not return the correct angle for the second and third quadrants (when X is negative). When in doubt, graph the X and Y quantities to confirm that the angle that your calculator reports is correct.

Figure 9.10 Event Report Current Column Data and RMS Current Angle

Step 3. Calculate the reference phase angle. Usually, you compare power system angles to a reference phasor (positive-sequence A-Phase voltage, for example):

Repeat *Step 2* for the row data in the VA column that correspond to the IA column data values you used in *Step 2*.

The angle calculation for the VA data is the following:

$$\begin{aligned}\theta &= \angle VA \\ &= \arctan\left(\frac{Y}{X}\right) \\ &= \arctan\left(\frac{-288.0}{-223.7}\right) \\ &= -127.8°\end{aligned}$$

Equation 9.3

(This is an example of an arctan calculation that yields the incorrect answer from some calculators and math programs.)

Step 4. Calculate the absolute phase angle:

Subtract the IA angle from the VA angle to obtain the A-Phase-referenced phasor angle for IA.

$$\angle VA - \angle IA = -127.8° - (-105.9°) = -21.9°$$

Equation 9.4

IA leads VA; thus, the rms phasor for current IA at the present sample is 277.0 A ∠21.9°, referenced to VA.

In the procedure above, you use two rows of current data from the event report to calculate an rms phasor current. At the first sample pair of Cycle [1], the rms phasor is I_A = 277.0 A ∠–105.9°.

The present sample of the sample pair (X = –76) is a scaled instantaneous current value (not an rms quantity) that relates to the rms phasor current value by the expression.

$$X = -76 = 277.0 \bullet \cos(-105.9°)$$

Equation 9.5

Polar Calculator Method

A method for finding the phasor magnitude and angle from event report quarter-cycle data pairs is to use a polar-capable calculator or computer program. Many calculators and computer programs convert Cartesian (X and Y) coordinate data to polar data. Key or enter the X value (present value or lower value of a column pair) and the Y value (later value or upper value in a column pair) as Cartesian (rectangular) coordinates. Perform the keystrokes necessary for your calculator or computing program to convert to polar coordinates. This is the phasor value for the data pair.

Digital Section of the Event Report

The second portion of an event report is the digital section. Inspect the digital data to evaluate relay element response during an event. See *Figure 9.11* for an example from the SEL-411L. If you want to view only the digital portion of an event report, use the **EVE D** command. In the digital portion of the event report, the relay indicates deasserted elements with a period (.) and asserted elements with an asterisk (*) character.

The element and digital information labels are single character columns. Read these columns from top to bottom. The trigger row includes a > character following immediately after the last digital element column to indicate the trigger point. The relay marks the row used to report the maximum fault current with an asterisk (*) character at the right of the last digital element column. Event reports that are 4-samples/cycle reports show the OR combination of digital elements in the two 8-samples/cycle rows to make the quarter-cycle entry.

The digital report arranges the event report digital settings into 79 column pages. For every 79 columns, the relay generates a new report that follows the previous report.

The report displays the digital label header for each column in a vertical fashion, aligned on the last character. For example, if the first digital section elements are IN201, #, RMBA5, Z2P, LBOKA, #, OUT203, OUT204, and HALARM, the header appears as in *Figure 9.12*. If the Relay Word bits included in the header were assigned aliases, the alias names appear in the report.

```
                                                                  22 B B
                                                        C           55 F F
                     VZ             S      66     66  55    O BBBBBB AA T T
          MMM      ZZZ PL        3333 05 666 77 666 77 511  Z M KKKKKK 11 RFRF
TTT MMMM 234 ZZZZ 234 OOL OO 3S 2222 T0 777 GG 777 QQ 1SS  3KP 121212 BB IBIB
PPP 1234 PPP 1234 GGG LAO SS PP QQGG FP GGG 23 QQQ 23 S11 PRER RRLLCC KK PFPF
ABC PPPP TTT GGGG TTT VDP BT OO FRFR T1 123 TT 123 TT 1TR TBYM SSOOLL 12 1122
```

Digital Column Labels

```
[1]

 ... .... ... .... ... *.. .. .. .... .. ... .. ... .. ... .... ...... .. ....
 ... .... ... .... ... *.. .. .. .... .. ... .. ... .. ... .... ...... .. ....
 ... .... ... .... ... *.. .. .. .... .. ... .. ... .. ... .... ...... .. ....
 ... .... ... .... ... *.. .. .. .... .. ... .. ... .. ... .... ...... .. ....
```

1 Cycle of Data

```
                                    •
                                    •
                                    •

[6]
... .... ... .... ... *.. .. .. .... .. ... .. ... .. ... .... ...... .. ....
... .... ... .... ... *.. .. .. .... .. ... .. ... .. ... .... ...... .. ....
... .... ... .... ... *.. .. .. .... .. ... .. ... .. ... .... ...... .. ....
... .... ... .... ... *.. .. .. .... .. ... .. ... .. ... .... ...... .. ....
[7]
*** **.. ... .... ... *.. .. .. .... .. ... .. ... .. ... .... ...... .. ....
*** **.. ... .... ... *.. .. .. *.*. .. ... .. ... .. ... .... ...... .. ....>
```

Trigger

```
*** **.. ... .... ... *.. .. .. *.*. .. ... .. ... .. ... .... ...... .. ....
*** **.. ... .... ... *.. .. .. *.*. .. ... .. ... .. ... .... ...... .. ....
[8]
*** **.. ... .... ... *.. .. .. *.*. .. ... .. ... .. ... .... ...... .. ....
*** **.. ... .... ... *.. .. .. *.*. .. ... .. ... .. ... .... ...... .. ....*
```

Values used in the Event Summary

```
*** **.. ... .... ... *.. .. .. *.*. .. ... .. ... .. ... .... ...... .. ....
*** **.. ... .... ... *.. .. .. *.*. .. ... .. ... .. ... .... ...... .. ....
[9]
*** **.. ... .... ... *.. .. .. *.*. .. ... .. ... .. ... .... ...... .. ....
*** **.. ... .... ... *.. .. .. *.*. .. ... .. ... .. ... .... ...... .. ....
*** **.. ... .... ... *.. .. .. *.*. .. ... .. ... .. ... .... ...... .. ....
*** **.. ... .... ... *.. .. .. *.*. .. ... .. ... .. ... .... ...... .. ....
[10]
*** **.. ... .... ... *.. .. .. *.*. .. ... .. ... .. ... .... ...... .. ....
*** **.. ... .... ... *.. .. .. *.*. .. ... .. ... .. ... .... ...... .. ....
*** .... ... .... ... *.. .. .* .... .. ... .. ... .. ... .... ...... .. ....
*** .... ... .... ... *.. .. *. .... .. ... .. ... .. ... .... ...... .. ....
```

Circuit Breaker Open

```
[11]

*** .... ... .... ... *.. .. *. *.*. .. ... .. ... .. ... .... ...... .. ....
*** .... ... .... ... *.. .. *. .... .. ... .. ... .. ... .... ...... .. ....
*** .... ... .... ... *.. .. *. .... .. ... .. ... .. ... .... ...... .. ....
*** .... ... .... ... *.. .. *. .... .. ... .. ... .. ... .... ...... .. ....
```

Figure 9.11 Digital Section of the SEL-411L Event Report

```
                    IN201
                    #
                    RMBA5
                    Z2P
                    LBOKA
                    #
                    OUT203
                    OUT204
                    HALARM

                   00H
I  R    UUA
N  M L  TTL
2  BM0  22A
0  A2K  00R
1  5PA  34M

.  ...  ...
   ..   ...
*  ..*  ...
*  ..*  ...
```

Figure 9.12 Sample Digital Portion of the Event Report

Selecting Event Digital Elements

NOTE: The compressed event reports and COMTRADE files from the relay may contain additional digital elements as compared to standard (ASCII) event reports (see CEVENT on page 9.25).

Specify the digital elements in the digital section of the event report by using the Event Reporting Digital Elements settings found in the Report settings (the **SET R** command from a terminal or the **Report** branch of the Settings tree view of SEL Grid Configurator or QuickSet). You can enter as many as 800 Relay Word bits from a maximum of 100 target rows. The # symbol places a blank column in the digital report. Use the # symbol to organize the digital section of the event report.

Digital Section INnnn Times

Reported assertion times for input digital elements differ, although these elements have the same name in both high-resolution raw data reports and in the filtered event reports. When you enter an input (IN*nnn*) in the event digitals list, the relay displays the filtered input with time latency in the event report and the Compressed ASCII event report. However, in the binary COMTRADE file event report, the relay reports the actual high-sample rate capture time for relay inputs.

Event Summary Section of the Event Report

The third portion of an event report is the summary section. See *Figure 9.13* for the locations of items included in an example summary section of an event report. The specific values available depend on the specific relay. See *Section 7: Metering, Monitoring, and Reports* in the product-specific instruction manual to see what specific data are reported in the summary of a relay. If you want to exclude the summary portion from an event report, use the **EVE NSUM** command.

The information in the summary portion of the event report is the same information in the event summary, except that the report header does not appear immediately before the event information when you view a summary in the event report.

```
Event: TRIP   Location: $$$$.$$      From: LOCAL     FLM: SE  Time Source: OTHER
Event Number: 10030      Shot 1P: 0   Shot 3P: 0        Freq: 60.00     Group: 1
Targets: INST COMM 87L
Breaker 1: CLOSED        Trip Time: 11:18:49.016
Breaker 2: NA
```

Event Information

```
PreFault:     IA     IB     IC     IG    3I2       VA       VB       VC    V1mem

MAG(A/kV)    426    426    427      1      0  286.420  286.638  286.302  286.453

 ANG(DEG)     1.3 -118.7  121.3  130.6  -99.2      0.0   -120.0    120.0      0.0

 Fault:

MAG(A/kV)    426    426    427      1      1  286.397  286.632  286.298  286.450

ANG(DEG)     1.3 -118.7  121.3  106.1  -92.6      0.0   -120.0    120.0      0.0
```

Pre-Fault Data

Fault Data

```
                 87 Differential Currents

PreFault:     IA     IB     IC     IQ     IG
MAG(pu)     0.36   0.35   0.36   0.00   0.00
ANG(DEG)     1.4 -118.9  120.9   92.9   59.5

Fault:
MAG(pu)     0.00   0.00   0.00   0.00   0.00
ANG(DEG)   -20.6  -20.6  -20.6  -20.6  -20.6
```

Line-Current Differential Status

Figure 9.13 Example Summary Section of the SEL-411L Event Report

Settings Section of the Event Report

The final portion of an event report is the settings section. See *Figure 9.14* for the locations of items included in a sample settings section of an event report. If you want to exclude the settings portion from an event report, use the **EVE NSET** command.

The settings portion of the event report lists important relay settings at the time the relay event triggered. The event report shows Group, Global, Output, protection SELOGIC control equation settings, Alias settings, and some Port 5 settings. For the Group settings and the protection SELOGIC settings, the relay reports only the active group. The settings order in the event report is the same order as when you issue a **SHOW** command from a terminal.

```
Group 1
Line Configuration
CTRW    := 400      CTRX    := 400      PTRY    := 3636     VNOMY   := 115
PTRZ    := 3636     VNOMZ   := 115      Z1MAG   := 4.72     Z1ANG   := 82.60
ZOMAG   := 14.50    ZOANG   := 75.70    EFLOC   := Y
  •
  •
  •
```

Active Group Settings

```
Global
General Global Settings
SID     := "Station A"
RID     := "Relay 1"
NUMBK   := 2
BID1    := "Breaker 1"
BID2    := "Breaker 2"
NFREQ   := 60       PHROT   := ABC      DATE_F  := MDY
FAULT   := NA
  •
  •
  •
```

Global Settings

Figure 9.14 Settings Section of the Event Report

```
Output
Interface Board #1
OUT201  := 3PT
OUT202  := BK1CL
OUT203  := BK2CL
OUT204  := NA
OUT205  := NA
OUT206  := NA
OUT207  := NA
OUT208  := NA
  •
  •
  •
```

Output Settings

```
Remote Analog Outputs

RAO01   := NA
RAO02   := NA
  •
  •
  •
RAO61   := NA
RAO62   := NA
RAO63   := NA
RAO64   := NA
```

Remote Analog Settings

```
Mirrored Bits Transmit Equations

TMB1A   := NA
  •
  •
  •
TMB8B   := NA
```

MIRRORED BITS Settings

```
Protection 1
Freeform Protection SELOGIC
1:  ###    PROTECTION FREEFORM AUTOMATION EXAMPLE
2:  ###
3:  ### SET CONTROL VARIABLE 1
4:  ### ASSERTS WHEN PRIMARY POSITIVE SEQUENCE IS
5:  ### GREATER THAN 90% OF 230 KV DIVIDED BY SQRT 3
6:  PSV01 := V1M >= 119.5 #90% OF 230 KV DIVIDED BY SQRT 3
```

Active Protection Logic Settings

```
Alias

Relay Aliases
(Relay Word Bit or Analog Quantity name, 7 Character Alias [0-9 A-Z _])

1: EN,"REL_EN"
```

Alias Settings

Figure 9.14 Settings Section of the Event Report (Continued)

CEVENT

The relay provides a Compressed ASCII event report for SCADA and other automation applications. QuickSet uses Compressed ASCII commands to gather event report data. If you want to view the Compressed ASCII event report data, use a terminal to issue ASCII command **CEV**. This is a comma-delimited ASCII file. The relay appends a four-digit hex checksum at the end of the lines in the Compressed ASCII report.

Items included in the Compressed ASCII event report are similar to the event report, although the relay reports the items in a special order. CEV files (like COMTRADE files) include all eight Relay Word bits from each row of the Relay Word used as the base set for the relay (see *Section 7: Metering, Monitoring, and Reporting* in the product-specific instruction manual for a list of these bits). Additionally, it includes the rows containing those Relay Word bits configured for inclusion by the ERDG setting. For the purpose of improving products and services, SEL sometimes changes the items and item order.

Event Summary

You can retrieve a summary version of stored event reports as event summaries. These short-form reports present vital information about a triggered event. The relay generates an event in response to power system faults and other trigger events (see *Triggering Data Captures and Event Reports on page 9.7*). The summary information available depends on the specific relay. See *Section 7: Metering, Monitoring, and Reports* in the product-specific instruction manual for the details of the summary event report for a specific relay.

The relay can be configured to automatically send an event summary on serial ports (see *Automatic Messages on page 15.33*).

Viewing the Event Summary

Access the event summary from the communications ports and communications cards. View and download event summaries from Access Level 1 and higher. You can independently acknowledge a summary (with the **SUM ACK** command) at each communications port so that you and users at other ports (SCADA, Engineering, etc.) can retrieve a complete set of summary reports. To acknowledge and remove a summary, you must first use the **SUM N(EXT)** command to view that summary.

You can use the **SUM** command to retrieve event summaries by date or date range, and by event number. (The relay labels each new event with a unique number as reported in the **HIS** command history report; see *Event History on page 9.27*.)

Table 9.1 lists the **SUM** commands. See *SUMMARY on page 14.62* for complete information on the **SUM** command.

Table 9.1 SUM Command

Command	Description
SUM	Return the most recent event summary (with header).
SUM *n*	Return a particular *n*[a] event summary (with header).
SUM ACK	Acknowledge the event summary on the present communications port.
SUM N	View the oldest unacknowledged event summary (**N** = next).

[a] The parameter n indicates event order or serial number.

You can also view event summaries by using SYNCHROWAVE Event.

CSUMMARY

The relay outputs a Compressed ASCII summary report for SCADA and other automation applications. Issue ASCII command CSU to view the Compressed ASCII summary report. This is a comma-delimited ASCII file. The relay appends a four-digit hex checksum at the end of the lines in the Compressed ASCII report.

Items included in the Compressed ASCII summary report are similar to those included in the summary report, although the relay reports the items in a special order. For the purpose of improving products and services, SEL sometimes changes the items and item order.

Event History

The event history gives you a quick look at recent relay activity. The relay labels each new event with a unique number from 10000 to 42767. (At 42767 the relay returns to 10000 for the next event number and then continues to increment.) See *Figure 9.15* for a sample event history.

The event history typically contains the following:

- Standard report header
  - Relay and terminal identification
  - Date and time of report
- Event number
- Event date and time
- Event type
- Location of fault (if applicable)
- Maximum phase current from summary fault data
- Active group at the trigger instant
- Targets

Figure 9.15 is a sample event history from a terminal.

```
Relay 1                                          Date: 03/16/2001  Time: 11:57:27.803
Station A                                        Serial Number: 2001001234
#        DATE        TIME      EVENT  LOCAT   CURR GRP TARGETS
10007 03/15/2001 23:30:49.026 BCG T   48.17  8892  1  INST TIME ZONE_1 B_PHASE
10006 03/15/2001 07:15:00.635 ABC T   22.82  8203  1  INST ZONE_1 A_PHASE bk1rs
10005 03/15/2001 06:43:53.428  TRIG  $$$$.$$    0  1
```

Event Number — Event Type — Fault Location — Active Group

Figure 9.15 Sample SEL-411L Event History

The event types in the event history are the same as the event types in the event summary.

The event history report indicates events stored in relay nonvolatile memory. The relay places a blank row in the history report output; items that are above the blank row are available for viewing (use the **EVE** and **CEV** commands). Items that are below the blank row are no longer in relay memory; these events appear in the history report to indicate past power system performance. The relay does not ordinarily modify the numerical or time order in the history report. However, if an event report is corrupted (power was lost during storage, for example), the relay lists the history report line for this event after the blank row.

Viewing the Event History

Access the history report from the communications ports and communications cards. View and download history reports from Access Level 1 and higher. You can also clear or reset history data from Access Levels 1 and higher. You can independently clear/reset history data at each communications port so that you and users at other ports (SCADA, Engineering, etc.) can retrieve complete history reports. You can also clear all history data from all ports (with the **HIS CA** command).

Use the **HIS** command from a terminal to obtain the event history. You can view event histories by date or by date range, or you can specify the number of the most recent events that the relay returns. See *HISTORY on page 14.41* for information on the **HIS** command. *Table 9.2* lists the **HIS** commands.

Table 9.2 HIS Command

Command	Description
HIS	Return event histories with the oldest at the bottom of the list and the most recent at the top of the list.
HIS *k*	Return the *k* most recent event summaries with the oldest at the bottom of the list and the most recent at the top of the list.
HIS *date1*	Return the event summaries on date *date1*[a].
HIS *date1 date2*	Return the event summaries from date1 to date2, with date1 at the bottom of the list and date2 at the top of the list.
HIS C	Clear all event data on the present port.
HIS R	Clear all event data on the present port.
HIS CA	Clear event data for all ports.
HIS RA	Clear event data for all ports.

[a] Use the same date format as Global setting DATE_F.

You can use QuickSet to retrieve the relay event history. Use the **Tools > Events > Get Event Files** menu to view the Event History dialog box. See *Analyze Events on page 2.33* for information and examples.

CHISTORY

The relay outputs a Compressed ASCII history report for SCADA and other automation applications. Issue the **CHI** command to view the Compressed ASCII history report. This is a comma-delimited ASCII file. The relay appends a four-digit hex checksum at the end of each history in the Compressed ASCII history report.

Items included in the Compressed ASCII history report are similar to those included in the history report, although the relay reports the items in a special order. For the purpose of improving products and services, SEL sometimes changes the items and item order.

History File Download

You can also download the history report file from the relay. Use a terminal emulation program with file transfer capability. At an Access Level 1 prompt or higher type **FILE READ REPORTS HISTORY.TXT <Enter>**. Start the terminal download routine to store the file on your computer. If you want the Compressed ASCII file, type **FILE READ REPORTS CHISTORY.TXT <Enter>**. In addition, you can use QuickSet to download history files.

Sequential Events Recorder (SER)

The Sequential Events Recorder (SER) gives you detailed information on relay states and relay element operation. The SER captures and time-tags state changes of Relay Word bit elements and relay conditions. These conditions include power-up, relay enable and disable, group changes, settings changes, memory overflow, diagnostic restarts, SER autoremoval/reinsertion, and Ethernet firmware upgrade attempts. The relay stores the latest 1000 SER entries to nonvolatile memory. *Figure 9.16* is a sample SER report.

The SER report contains the following:

- Standard report header
  - Relay and terminal identification
  - Date and time of report
- SER number
- SER date and time
- Relay element or condition
- Element state
- TiDL commissioning statuses. (Applies only to TiDL [T-Protocol] relays.)

```
Relay 1                                        Date: 03/16/2001  Time: 13:09:29.341
Station A                                      Serial Number: 2001001234
FID=SEL-411L-R101-V0-Z001001-D20010315
#      DATE        TIME           ELEMENT              STATE
6    03/15/2001  00:00:00.004   Power-up             Group 1
5    03/15/2001  00:00:00.022   Relay                Enabled
4    03/15/2001  00:30:00.021   GROUND O/C 1 LINE 1  51S1 PICKED UP
3    03/15/2001  00:30:03.221   GROUND O/C 1 LINE 1  51S1 TIMEOUT
2    03/15/2001  00:32:00.114   GROUND O/C 1 LINE 1  51S1 RESET
1    03/15/2001  00:32:00.114   GROUND O/C 1 LINE 1  51S1 DROPOUT
```

SER Number

Relay Element or Condition

Figure 9.16 Sample SER Report

In the SER report, the oldest information has the highest number. The newest information is always #1. When using a terminal, you can order the positions of the SER records in the SER report.

Viewing the SER Report

The relay displays the SER records in ASCII and binary formats.

Access the SER report from the communications ports and communications cards in Access Level 1 and higher. You can independently clear/reset already viewed SER data at each communications port (with the **SER CV** or **SER RV** command) so that users at other ports (SCADA, Engineering, for example) can retrieve complete SER reports. The **SER CV** or **SER RV** command will not clear any SER data that has been recorded, but not viewed, on a particular serial port. To clear all SER data on a serial port, use the **SER C** or **SER R** command.

To clear all SER data from all serial ports, use the **SER CA** or **SER RA** command, available only from Access Levels P, A, O, and 2. This procedure would normally be used after relay commissioning or testing.

Use an ASCII terminal, SEL Grid Configurator, or QuickSet to examine SER records. You can use the **SER** command to view the SER report by date, date range, SER number, or SER number range. The relay labels each new SER record with a unique number.

Table 9.3 SER Commands

Command	Description
SER	Return the 20 most recent records from the SER, with the oldest (highest number) at the top of the list and the most recent (lowest number) at the bottom of the list.
SER *k*	Return the *k* most recent records from the SER, with the oldest (highest number) at the top of the list and the most recent (lowest number) at the bottom of the list.
SER *m n*[a]	Return the SER records from *m* to *n*. If *m* is greater than *n*, records appear with the oldest (highest number) at the top of the list and the most recent (lowest number) at the bottom of the list. If *m* is less than *n*, records appear with the most recent (lowest number) at the top of the list and the oldest (highest number) at the bottom of the list.
SER *date1*[b]	Return the SER records on date *date1*.
SER *date1 date2*	Return the SER records from *date1* at the top of the list to *date2* at the bottom of the list.
SER C or **SER R**	Clear SER records on the present port.
SER CA or **SER RA**	Clear SER data for all ports.
SER CV or **SER RV**	Clear viewed SER records on the present port.
SER D	List chattering SER elements that the relay is removing from the SER records.

[a] The parameters m and n indicate SER numbers that the relay assigns at each SER trigger.
[b] Use the same date format as Global setting DATE_F.

You can retrieve SER records with QuickSet. The **HMI > Meter and Control** menu item gives you the SER report. The latest 200 SER events are viewable on the front-panel display through the front-panel EVENTS MENU.

CSER

The relay outputs a Compressed ASCII SER report for SCADA and other automation applications. Issue the CSE command to view the Compressed ASCII SER report. A sample of the SER report appears in *Figure 9.17*; this is a comma-delimited ASCII file. The relay appends a four-digit hex checksum at the end of the lines in the Compressed ASCII report.

Items included in the Compressed ASCII SER report are similar to the SER report, although the relay reports the items in a special order. For the purpose of improving products and services, SEL sometimes changes the items and item order.

```
"RID","SID","FID","03e2"
"Relay 1","Station A","SEL-411L-R101-V0-Z001001-D20010315","0dfc"
```

Report Header

```
"#","MONTH","DAY","YEAR","HOUR","MIN","SEC","MSEC","ELEMENT","STATE","0FC8"
1,3,15,2001,00,32,00,114,"GROUND_0/C_1_LINE_1","51S1_DROPOUT","09D2"
2,3,15,2001,00,32,00,114,"GROUND_0/C_1_LINE_1","51S1_RESET","08E7"
3,3,15,2001,00,30,03,221,"GROUND_0/C_1_LINE_1","51S1_TIMEOUT","09B0"
4,3,15,2001,00,30,00,021,"GROUND_0/C_1_LINE_1","51S1_PICK_UP","097B"
5,3,15,2001,00,00,00,222,"Relay","Enabled","09BA"
6,3,15,2001,00,00,00,004,"Power-up","Group 1","0A0A"
```

SER Data (six records)

Figure 9.17 Sample Compressed ASCII SER Report

SER File Download

You can also download the SER data as a file from the relay. Use a terminal emulation program with file transfer capability. At an Access Level 1 prompt or higher type **FILE READ REPORTS SER.TXT <Enter>**. Start the terminal download routine to store the file on your computer. If you want the Compressed ASCII file, type **FILE READ REPORTS CSER.TXT <Enter>**.

Setting SER Points

NOTE: The relay is limited to storing SER points at a rate of approximately 6000 per hour. Be careful to select points that will not lead to this rate being exceeded.

You program the relay elements that trigger an SER record. You can select as many as 250 elements. These triggers, or points, can include control input and control output state changes, element pickups and dropouts, recloser state changes, and so on. Use the **SET R** command from a terminal, or use the SEL Grid Configurator or QuickSet **Report** branch of the Settings tree view to enter **SER Points**.

Use the text-edit line mode settings method to enter or delete SER elements. To set an SER element, enter the five items of this comma-delimited string (all but the first parameter are optional): Relay Word Bit, Reporting Name, Set State Name, Clear State Name, HMI Alarm.

The relay defaults to the element name when you do not provide a reporting name. The default names for the set and clear states are Asserted and Deasserted, respectively. By default, SER Points are not configured for HMI alarm display. The relay always creates an SER record for power-up, relay enable and relay disable, any group change and settings change, diagnostic restart, and memory overflow.

Automatic Deletion and Reinsertion

The SER also includes an automatic deletion and reinsertion function. The relay automatically deletes oscillating SER items from SER recording. This function prevents overfilling the SER buffer with “chattering” information. Set Report setting ESERDEL (Enable SER Delete) to Y to enable this function, and select values for the setting SRDLCNT (SER Delete Count) and the setting SRDLTIM (SER Delete Time) that mask the chattering SER element. The relay removes an item from all SER recordings once a point has changed state more than SRDLCNT times in an SRDLTIM period. Once deleted from SER recording, the relay ignores the item for a 10 • SRDLTIM period. At the end of this period, the relay checks the chatter criteria and, if the point does not exceed the criteria, the relay automatically reinserts the item into SER recording. To see a list of deleted SER points, use the **SER D** command.

Signal Profiling

Use the analog signal profiling function to record and track values of as many as 20 analog quantities. This function provides data in CASCII that is compatible to import directly into applications like spreadsheets. Specify the specific analog quantities for profiling with the SPAQ Report settings. At the data acquisition rate of 5 minutes, the relay stores at least 10 days of all analog signals selected for profiling in nonvolatile memory. The report includes the time of acquisitions

and the magnitude of each selected analog quantity. By defining conditions in the signal profiling enable SELOGIC variable setting (SPEN), you can record analog values at particular periods or conditions of interest.

SPAQgg (Analog Quantities for Signal Profiling)

Enter any analog quantity available in the relay from the Analog Quantity list in this freeform setting.

SPAR (Signal Profile Acquisition Rate)

Although you can select as many as 20 analog quantities, the signal acquisition rate is the same for all analog quantities. Select an acquisition rate of 1, 5, 15, 30, or 60 minutes.

SPEN (Signal Profile Enable)

Use this SELOGIC control equation to specify conditions under which the profiling must take place. If there are no conditions, be sure to set SPEN = 1, or else no data are recorded (default value of NA disables the function).

SECTION 10

Testing, Troubleshooting, and Maintenance

This section address the philosophy of relay testing, general approaches to testing and troubleshooting, troubleshooting common problems, and a few maintenance items. This section begins with guidelines for determining and establishing test routines for SEL-400 series relays. Follow the standard practices of your company in choosing testing philosophies, methods, and tools. The relay incorporates self-tests to help you diagnose potential difficulties should they occur. The section Relay Troubleshooting contains a quick-reference table for common relay operation problems.

Topics presented in this section include the following:

- *Testing Philosophy on page 10.1*
- *Testing Features and Tools on page 10.4*
- *Test Methods on page 10.7*
- *Relay Self-Tests on page 10.19*
- *Relay Troubleshooting on page 10.23*
- *Maintenance on page 10.27*
- *Technical Support on page 10.35*

All SEL-400 series relays are factory-calibrated; this section contains no calibration information. If you suspect that the relay is out of calibration, contact your Technical Service Center or the SEL factory.

Testing Philosophy

Protective relay testing generally consists of three categories: acceptance testing, commissioning testing, and maintenance testing. The categories differ in testing complexity and according to when these activities take place in the life of the relay.

Each testing category includes particular details as to when to perform the test, the testing goals at that time, and the relay functions that you need to test. This information is a guide to testing SEL-400 series relays; be sure to follow the practices of your company for relay testing.

Acceptance Testing

SEL performs detailed acceptance testing on all new relay models and versions. We are certain that your relay meets published specifications. Even so, you can perform acceptance testing on a new relay model to become familiar with the relay operating theory and settings; this familiarity helps you apply the relay accurately and correctly. A summary of acceptance testing guidelines is presented in *Table 10.1*.

Table 10.1 Acceptance Testing

Details	Description
Time	Test when qualifying a relay model for use on the utility system.
Goals	a) Confirm that the relay meets published critical performance specifications such as operating speed and element accuracy. b) Confirm that the relay meets the requirements of the intended application. c) Gain familiarity with relay settings and capabilities.
Test	Test all protection elements and logic functions critical to your intended application.

Commissioning Testing

SEL performs a complete functional check and calibration of each SEL-400 series relay before shipment so that your relay operates correctly and accurately. You should perform commissioning tests to verify proper connection of the relay to the power system and all auxiliary equipment. Check control signal inputs and outputs. Check breaker auxiliary inputs, SCADA control inputs, and monitoring outputs. Use an ac connection test to verify that the relay current and voltage inputs are the proper magnitude and phase rotation.

Brief fault tests confirm that the relay settings and protection scheme logic are correct. You do not need to test every relay element, timer, and function in these tests.

At commissioning, use the relay **METER** command to verify the ac current and voltage magnitude and phase rotation (see *Examining Metering Quantities on page 3.34*).

Use the **PUL** command to pulse relay control output operation. Use the **TAR** command to view relay targets and verify that control inputs are operational. Use **TEST DB**, **TEST DB2**, and **TEST FM** to check SCADA interfaces. (See *TEST DB on page 14.65*, *TEST DB2 on page 14.66*, and *TEST FM on page 14.68* for information on these relay commands.)

Table 10.2 lists guidelines for commissioning testing. For further discussion of these tests, see *Checking Relay Operation* in *Section 3: Testing* of the product-specific instruction manual.

Table 10.2 Commissioning Testing

Details	Description
Time	Test when installing a new protection system.
Goals	a) Validate all system ac and dc connections. b) Confirm that the relay functions as intended using your settings. c) Check that all auxiliary equipment operates as intended. d) Check SCADA interface.
Tests	Test all connected/monitored inputs and outputs, and the polarity and phase rotation of ac connections. Make simple checks of protection elements. Test communications interfaces.

TiDL System Commissioning

See *Section 19: Digital Secondary Systems* for information on commissioning a TiDL system.

Maintenance Testing

All SEL-400 series relays use extensive self-testing routines and feature detailed metering and event reporting functions. These features reduce your dependence on routine maintenance testing. When you want to perform maintenance testing, follow the recommendations in *Table 10.3*.

Table 10.3 Maintenance Testing

Details	Description
Time	Test at scheduled intervals or when there is an indication of a problem with the relay or power system.
Goals	a) Confirm that the relay is measuring ac quantities accurately. b) Check that scheme logic and protection elements function correctly. c) Verify that auxiliary equipment functions correctly.
Tests	Test all relay features/power system components that did not operate during an actual fault within the past maintenance interval.

You can use the relay reporting features as maintenance tools. Periodically compare the relay **METER** command output to other meter readings on a line to verify that the relay measures currents and voltages correctly and accurately. Use the circuit breaker monitor, for example, to detect slow breaker auxiliary contact operations and increasing or varying breaker pole operating times. For details on these features, see *Circuit Breaker Monitor on page 8.1*.

Each occurrence of a fault tests the protection system and relay application. Review relay event reports in detail after each fault to determine the areas needing your attention. Use the event report current, voltage, and relay element data to determine that the relay protection elements and communications channels operate properly. Inspect event report input and output data to determine whether the relay asserts outputs at the correct times and whether auxiliary equipment operates properly.

At each maintenance interval, the only items to be tested are those that have not operated (via fault conditions and otherwise) during the maintenance interval. The basis for this testing philosophy is simple: you do not need to perform further maintenance testing for a correctly set and connected relay that measures the power system properly and for which no relay self-test has failed.

SEL-400 series relays are based on microprocessor technology; the relay internal processing characteristics do not change over time. For example, if time-overcurrent element operating times change, these changes occur because of alterations to relay settings and/or differences in the signals applied to the relay. You do not need to verify relay element operating characteristics as a part of maintenance checks.

SEL recommends that you limit maintenance tests on SEL relays according to the guidelines listed in *Table 10.3*. You will spend less time checking relay operations that function correctly. You can use the time you save to analyze event data and thoroughly test systems needing more attention.

Testing Features and Tools

All SEL-400 series relays provide the following features that can assist you during relay testing:

- Metering
- High-resolution oscillography
- Event reports
- Event summary reports
- Sequential Events Recorder (SER) reports
- IEC 61850 Mode/Behavior*
- IEC 61850 Simulation Mode*

  *Only available on IEC 61850-enabled relays.

Certain relay commands are useful in confirming relay operation. The following commands, for example, aid you in testing the relay:

- **TAR**
- **PUL**
- **TEST DB**
- **TEST DB2**
- **TEST FM**
- **TEST SV**

In addition, the relay incorporates a low-level test interface where you can interrupt the connection between the relay input transformers and the input processing module. Use the low-level test interface to apply reduced-scale test quantities from the SEL-4000 Relay Test System; you do not need to use large power amplifiers to perform relay testing.

You can use the **TEST SV** and **COM SV** commands to verify Sampled Values (SV) communications

Metering

NOTE: Some relays support a single dc battery monitor. See the relay-specific instruction manual to determine whether one or two dc battery monitors are supported.

The specific metering data available depends on the relay model. See *Section 7: Metering, Monitoring, and Reporting* in the product-specific instruction manual for detailed information. In general, the metering data show the ac currents and voltages (magnitude and phase angle) connected to the relay in primary values. In addition, metering shows many other quantities including the power system frequency (FREQ) and the voltage input to the station dc battery monitors (Vdc1 and Vdc2). Compare these quantities against quantities from other devices of known accuracy. The metering data are available at the serial ports, from the ACSELERATOR QuickSet SEL-5030 Software HMI, and at the front-panel LCD METER menu. See *METER on page 14.47*, *Meter on page 4.16*, *QuickSet HMI on page 2.30*, and *Examining Metering Quantities on page 3.34* for more information.

High-Resolution Oscillography

NOTE: Control Inputs are sampled at 2 kHz, and the raw binary data (prior to debounce timer conditioning) is available in high-resolution oscillography. The COMTRADE data labels for raw control input data are IN101–IN107, IN201–IN2nn, IN301–IN3nn,IN401–IN4nn, IN501–IN5nn, based on installed hardware, where nn = 01–08 or 01–24.

The relay takes an unfiltered data snapshot of the power system at each event trigger or trip. The relay samples power system data at high sample rates from 1 kHz to 8 kHz. You can use SEL-5601-2 SYNCHROWAVE Event Software or other COMTRADE viewing program to export and view these raw data in a binary COMTRADE file format. Use high-resolution oscillography to capture fast power system transients or to examine low-frequency anomalies in the power system. See *Raw Data Oscillography on page 9.10* for more information.

Event Reports

NOTE: Control Inputs are sampled at 2 kHz, and then conditioned by a debounce timer. The resulting Relay Word bits are updated 8 times/cycle and are available in standard event report files.

The relay also generates a filtered-quantities event report in response to faults or disturbances. Each event report contains information on current and voltage, relay element states, control inputs, and control outputs. If you are unsure of the relay response or your test method, the event report provides you with information on the operating quantities that the relay used at the event trigger. The relay provides oscillographic displays of the filtered event report data, which give you a visual tool for testing relay operating quantities. You can use the serial ports and QuickSet to view event reports. See *Event Reports, Event Summaries, and Event Histories on page 9.13* for a complete discussion of event reports.

Event Summary Reports

The relay generates an event summary for each event report; use these event summaries to quickly verify proper relay operation. With event summaries, you can quickly compare the reported fault current and voltage magnitudes and angles against the reported fault location and fault type. If you question the relay response or your test method, you can obtain the full event report and the high-resolution oscillographic report for a more detailed analysis. See *Event Summary on page 9.26* for more information on the event summary.

SER Reports

The relay provides an SER report that time tags changes in relay elements, control inputs, and control outputs. Use the SER for convenient verification of the pickup and dropout of any relay element. For a complete discussion of the SER, see *Sequential Events Recorder (SER) on page 9.28*.

IEC 61850 Mode/Behavior and Simulation Mode

An IEC 61850 technology-based substation differs from traditional substations in that analog and binary signals are exchanged between process-level, bay-level, and substation-level IEDs via Ethernet messaging. The IEC 61850 standard supports various types of testing via IEC 61850 Mode/Behavior and Simulation mode. Refer to *IEC 61850 Testing on page 10.10*.

Test Commands

TAR Command

Use the **TAR** command to view the state of relay control inputs, relay outputs, and relay elements individually during a test. You can see relay targets at the serial ports, and from the front-panel LCD (see *TARGET on page 14.63* and *Operation and Target LEDs on page 4.33*).

PUL Command

Use the **PUL** command to test the control output circuits. The specified output closes if open, or opens if closed. You can use the **PUL** command at the serial ports, in the QuickSet HMI, and from the front-panel LCD (see *PULSE on page 14.55*, *QuickSet HMI on page 2.30*, and *Operation and Target LEDs on page 4.33*).

TEST DB Command

Use the **TEST DB** command for testing the relay database, which is used for Fast Message Data Access. The **TEST DB** command can be used to override any value in the relay database. Use the **MAP 1** command and the **VIEW 1** command to inspect the relay database (see *MAP on page 14.46*). You must be familiar with the relay database structure to use the **TEST DB** command effectively; see *Section 10: Communications Interfaces* in the product-specific instruction manual for more information.

TEST DB2 Command

Use the **TEST DB2** command to test the DNP3 and IEC 61850 interfaces. Values you enter are "override values." For more information on DNP3, see *Section 16: DNP3 Communication*. For more information on IEC 61850, see *Section 17: IEC 61850 Communication*.

TEST FM Command

Use the **TEST FM** command to override normal Fast Meter quantities for testing purposes. You can only override "reported" Fast Meter values (per-phase voltages and currents). You cannot directly test Fast Meter values that the relay derives from the reported values (power, sequence components, etc.). For more information on Fast Meter, see *SEL Fast Meter, Fast Operate, Fast SER Messages, and Fast Message Data Access on page 15.34*.

TEST SV Command

NOTE: The **TEST SV** command is not supported in the SEL-487E-5 SV Publisher.

Use the **TEST SV** command on SEL merging unit, e.g., SEL-401 to enter SEL TEST SV mode. While in this mode, the merging unit publishes fixed secondary quantities scaled by the CTR and PTR ratios.

When you use the **TEST SV** command on the SEL SV subscriber, the SV relay enters the SEL TEST SV mode. The relay accepts SV messages from a merging unit that is also in TEST SV mode. Refer to *TEST SV on page 14.69* for more details.

Test Methods

Use the following methods to conveniently test the pickup and dropout of relay elements and other relay functions:

- Target indications (element pickup/dropout)
- Control output closures
- SER reports

The tests and procedures in the following sections are for 5 A relays. Scale values appropriately for 1 A relays.

Once you have completed a test, return the relay settings that you modified for the test to default or operational values.

Testing With Relay Word Bits

Use the communications port **TAR** command or the front panel to display the state of relay elements, control inputs, and control outputs. Viewing a change in relay element (Relay Word bit) status is a good way to verify the pickup settings you have entered for protection elements. See *Examining Relay Elements on page 3.42* for more information on examining relay elements by using a terminal and from the front panel.

Testing With Control Outputs

You can set the relay to operate a control output to test a single element. Set the SELOGIC control equation for a particular output (OUT101–OUT108, for example) to respond to the Relay Word bit for the element under test. See *Operating the Relay Inputs and Outputs on page 3.55* for configuring control inputs and control outputs. *Section 11: Relay Word Bits* in the product-specific instruction manual lists the names of the relay element logic outputs.

Example 10.1 Testing the 50P1 Element With a Control Output

This procedure shows how to set control output OUT105 to test the SEL-451 50P1 Phase Instantaneous Overcurrent element.

For this test, you must have a variable current source for relay testing and a control output closure indicating device such as a test set or a digital multimeter (DMM).

In this example, use Grid Configuator or QuickSet to configure the relay (see *Section 2: PC Software*).

Step 1. Establish communication with the relay through either SEL Grid Configurator or QuickSet, then read settings.

Step 2. Navigate to Main Board Outputs contact settings in the settings tree structure.

Example 10.1 Testing the 50P1 Element With a Control Output (Continued)

Step 3. Set OUT105 to respond to the 50P1 element pickup.

The software checks the validity of the setting you entered.

An invalid setting (you could have mistyped the element name) results in an error.

Step 4. Upload the new settings to the SEL-451.

If you see no error message, the new settings are loaded in the relay.

Step 5. Connect an indicating device to OUT105 on the relay rear panel.

A DMM measuring resistance can show an open circuit (open contact) or a low-resistance short (closed contact).

Step 6. Connect a test source to the relay.

a. Set the current output of a test source to zero output level.

b. Connect a single-phase current output of the test source to the IAW analog input.

Step 7. Increase the current source to produce a current magnitude greater than 15.00 A secondary in the relay (to test the element).

When the 50P1 element picks up, the relay changes the 50P1 Relay Word bit to logical 1 and closes the output contacts of control output OUT105.

The indicating device operates.

Testing With SER

You can set the relay to generate a report from the SER to test relay elements; include the element that you want to test in the SER **Points and Aliases** list. Set aliases for the element name, set state, and clear state in the relay SER to simplify reading the SER report. See *Sequential Events Recorder (SER) on page 9.28* for complete information on the SER.

Example 10.2 Testing the SEL-451 51S1 Element by Using the SER

The SER gives exact time data for testing time-overcurrent element time-outs. Subtract the 51S1T assertion time from the 51S1 assertion time to check the operation time for this element. Use the factory defaults for the operating quantity, pickup level, curve, time dial, electromechanical reset, and torque control (*Table 10.4*).

The procedure in the following steps shows how to set the SER trigger lists to capture the selectable operating quantity time-overcurrent element 51S1 operating times. The procedure also shows how to set the torque control supervision for the 51S1 element.

Example 10.2 Testing the SEL-451 51S1 Element by Using the SER (Continued)

Table 10.4 Selectable Operating Quantity Time-Overcurrent Element (51S1) Test Settings

Setting	Description	5A
51S1O	51S1 Operating Quantity (IA*n*, IB*n*, IC*n*, IMAX*n*, IA*n*R, IB*n*R, IC*n*R, IMAX*n*R, I1L, 3I2L, 3I0*n*)[a]	3I0L
51S1P	51S1 Overcurrent Pickup (0.25–16 A, secondary)	0.75
51S1C	51S1 Inverse-Time Overcurrent Curve (U1–U5, C1–C5)	U3
51S1TD	51S1 Inverse-Time Overcurrent Time Dial (0.50–15.00)	1.00
51S1RS	51S1 Inverse-Time Overcurrent EM Reset (Y, N)	N
51S1TC	51S1 Torque Control (SELOGIC control equation)	1

[a] n = L, 1, and 2 for Line, Circuit Breaker 1, and Circuit Breaker 2, respectively. R suffix selects rms quantities. For more information on rms, refer to RMS in the Glossary.

The relay uses *Equation 10.1* and *Equation 10.2* to determine the operating time for the 51S1 element. For a current input 50 percent greater than the default pickup, the test value, I_{TEST}, is:

$$\begin{aligned} I_{TEST} &= M \bullet (51S1P) \\ &= 1.5 \bullet (0.75\ A) \\ &= 1.125\ A \end{aligned}$$

Equation 10.1

where M is the pickup multiple and 51S1P is the element pickup value (see *Table 10.4*).

The operating time (t_p) for a time dial (TD) equal to 1 for the U3 (Very Inverse) Curve is:

$$\begin{aligned} t_p &= TD \bullet \left(0.0963 + \frac{3.88}{M^2 - 1}\right) \\ &= 1 \bullet 0.0963 + \frac{3.88}{1.5^2 - 1} \\ &= 3.2\ \text{seconds} \end{aligned}$$

Equation 10.2

In this example, use SEL Grid Configurator or QuickSet to configure the relay. You must have a computer that is communicating with the SEL-451 and running SEL Grid Configurator or QuickSet (see *Section 2: PC Software*). You also need a variable current source for relay testing.

Step 1. Establish communication with the relay through either SEL Grid Configurator or QuickSet, then read settings.

Step 2. Set the selectable operating quantity time-overcurrent element for test operation.

a. From Protection Elements View in SEL Grid Configurator, select the first 51 element available or open the **Group 1 > Set 1> Relay Configuration > Time Overcurrent** branch of the Settings tree view.

b. Verify that enable setting E51S (Selectable Inverse-Time Overcurrent Element) is set to 1.

Example 10.2 Testing the SEL-451 51S1 Element by Using the SER (Continued)

c. Change setting **51S1O Operating Quantity** to **3I0L**.

d. Change the remaining element configurations to match *Table 10.4*.

Step 3. View the SER settings.

a. Navigate to Report in the Settings tree view structure.

b. Select the **SER Points and Aliases** branch.

Step 4. Enter SER element names and aliases.

a. Assign an available SER Points and Aliases setting (SITM1 for example) to **51S1T**.

b. Type **GROUND O/C 1 LINE 1** in the **Reporting Name** field.

c. Type **51S1 TIMEOUT** in the **Set State Name** field.

d. Type **51S1 DROPOUT** in the **Clear State Name** field.

e. Repeat *Step a–Step d* for a second SER Points and Aliases setting (SITM2 for example), with setting values **51S1, GROUND O/C 1 LINE 1, 51S1 PICKED UP, 51S1 RESET**.

You can enter as many as 250 relay elements in the **SER Points and Aliases** list (see *Sequential Events Recorder (SER) on page 9.28*).

Step 5. Upload the new settings to the SEL-451.

If you see no error message, the new settings are loaded in the relay.

Step 6. Connect a test source to the relay.

a. Set the current output of a test source to zero output level.

b. Connect a single-phase current output of the test source to the IAW analog input.

Step 7. Test the element.

a. Increase the current source to produce a current magnitude of 1.125 A secondary in the relay.

b. Keep the current source at this level past the expected element time-out (longer than 3.2 seconds).

c. Return the current source to zero after the element times out.

Step 8. Navigate to the SER report on the relay front panel and verify the `51S1 PICKED UP` and `51S1 TIMEOUT` entries are shown.

The time difference between SER entries **51S1 PICKED UP** and **51S1 TIMEOUT** is approximately 3.2 seconds.

IEC 61850 Testing

Commissioning and maintenance testing of a relay typically involves applying an alternative source of secondary voltages and currents as well as isolating relay output contacts used to trip circuit breakers. Traditionally, physical panel switches have facilitated these testing operations. More recently, the IEC 61850 standard has introduced mechanisms for emulating these switching and isolation functions within the communications protocol itself. This gives testing personnel

additional flexibility in designing test procedures. This section discusses three testing mechanisms: IEC 61850 Mode/Behavior, IEC 61850 Simulation mode, and the SEL **TEST SV** command.

NOTE: The example in this section is meant to illustrate the use of IEC 61850 standard operating modes. Always follow the testing practices and philosophy of your company.

IEC 61850 describes different protection and automation functions according to standardized language (IEC 61850-7-4). It describes substation protection and automation functions in abstract models and organizes components in hierarchical structures. A CID file describes components of an IED that is composed of logical devices and logical nodes (protection and automation functions, such as the distance protection element PDIS). An IED can host multiple logical devices, and, in turn, logical devices may host a group of logical nodes. Additionally, logical nodes inside a logical device can serve as supervision signals to logical nodes of other logical devices.

IEC 61850 Mode/Behavior are tools to isolate specific IEDs and logical nodes for testing, analogous to how test switches are used to physically isolate specific devices in a testing procedure. IEC 61850 Simulation mode is used to inject test signals into the network that will be used by subscribing IEDs being tested.

When in IEC 61850 Simulation mode, and the normal messages and simulated messages are both present, the IED processes the simulated messages and ignores the normal ones. For example, if an SV subscriber in IEC 61850 Simulation mode sees an SV message and a similar SV message with the simulated flag set in the header, the subscriber processes the simulated SV messages and ignores the normal SV messages until the relay is no longer in Simulation mode. IEC 61850 Simulation mode has no effect on the Manufacturing Message Specification (MMS) communications service.

IEC 61850 Simulation mode is applied at the IED level. Additionally, messages produced by the IED in response to simulated data do not have their own simulation flag set. The simulation flag does not propagate automatically. For these reasons, IEC 61850 Simulation mode is insufficient to handle many testing scenarios, especially when device isolation in an energized substation is necessary.

IEC 61850 Mode/Behavior is a mechanism that enables isolation of one IED or a set of IEDs in a system. While the IED or a logical node is placed in different modes, the IED reports its status by setting or clearing the quality attribute validity and test. While other IEDs or logical nodes do not participate in the testing, they remain in the On mode and discard messages with test quality set. *Example 10.3* describes an example of applying IEC 61850 Mode/Behavior and Simulation mode.

See *IEC 61850 Simulation Mode on page 17.38* and *IEC 61850 Mode/Behavior on page 17.38* for operation details.

Example 10.3 Maintenance Testing SEL-487B Bus Differential Protection

Figure 10.1 describes a partial logical diagram for a breaker-and-a-half bus protection. In this application, SEL-401 #1 and SEL-401 #3 provide current measurements to the SEL-487B SV Subscriber for bus differential protection. If the SEL-487B detects an internal fault, it sends a trip signal to SEL-401 #1 and SEL-401 #3 to operate Circuit Breaker 1 and Circuit Breaker 3, respectively. The logical models for current and voltage measurement are logical nodes TCTR and TVTR. The logical model for circuit breakers is represented by logical node XCBR. The logical node PDIS represents distance protection. Logical node IHMI represents the human-machine interface. *Figure 10.1* describes the logical model of the application. *Table 10.5* describes the data GOOSE and SV messages transmit.

Example 10.3 Maintenance Testing SEL-487B Bus Differential Protection (Continued)

Figure 10.1 IEC 61850 Logical Modeling

Table 10.5 Data Transmitted in GOOSE and SV Messages

Messages	Information Transmitted
GOOSE 1	PTRC1.Op.general PTRC1.q
GOOSE 2	PTRC.Op.general PTRC2.q
SV1	TCTR2
SV2	TCTR5
SV3	TCTR1, TVTR
SV4	TCTR3

Example 10.3 Maintenance Testing SEL-487B Bus Differential Protection (Continued)

NOTE: The procedures specified in this section are for initial relay testing only. Follow your company policy for connecting the relay to the power system.

To test a device in an energized substation, perform the following general steps:

Step 1. Isolate the device(s) under test.

Step 2. Connect a test set to those device(s) under test.

Step 3. Apply test signals and execute test.

Step 4. Disconnect the test equipment and place the device(s) back in normal operation.

Figure 10.2 illustrates use of IEC 61850 Mode/Behavior and IEC 61850 Simulation mode in the process of testing PDIF of the SEL-487B in *Figure 10.1*.

Step 1. Isolate the SEL-487B by placing the device into Test/Blocked mode and then Simulation mode.

Change SEL-487B IEC 61850 Mode/Behavior and Simulation mode so that Mod.stVal = Test/Blocked and Sim.stVal = True. The IED is isolated, so SV messages from SEL-401 #1 and SEL-401 #3 are not processed. The outgoing GOOSE messages from the SEL-487B sent to control CB1 and CB3 are not processed because they are flagged with q.test = True and the SEL-401 #1 and SEL-401 #3 are in the On mode. The MMS communication between the PDIF and logical node IHMI is also flagged with q.test = True. The SEL-487B is logically isolated and its contact outputs are physically blocked as *Figure 10.2* shows. If the device is placed into Test mode (as opposed to Test/Blocked mode), the physical contact outputs operate if the device detects a bus fault based on received testing SV messages.

SEL-400 series relays support other communications protocols such as MIRRORED BITS and IEEE C37.118 Synchrophasor Protocols. If the device under test communicates with other IEDs over protocols that IEC 61850 does not define, it is necessary to consider the impact of IEC 61850 Simulation mode and Mode/Behavior. For example, consider the impact on block signals exchanged via MIRRORED BITS protocol when testing requires that there be no misoperation on IEDs that receive MB messages.

To support such situations, you may need to build logic to provide supervisory information that is transmitted via MB.

For example, if we want to block MB from transmitting a status change of PLT01 while the relay is in Blocked or Test/Blocked mode, we can supply the following custom logic example to the protection logic.

PSV01 := (I850MOD = 2) OR (I850MOD = 4)

Example 10.3 Maintenance Testing SEL-487B Bus Differential Protection (Continued)

PSV01 can thus supervise transmitted MIRRORED BITS.

For example, TMB1A := PLT01 AND NOT PSV01.

If using IEEE C37.238 Synchrophasor Protocol, engineers can use SELOGIC control equation PMTEST to associate IEC 61850 Mode/Behavior with Synchrophasor data quality. PMTEST is the SELOGIC control equation that indicates PMU is in a test mode.

PSV01 := (I850MOD = 2) OR (I850MOD = 4)

PMTEST := PSV01

Figure 10.2 Isolate an IED Through Use of IEC 61850 Mode/Behavior and Simulation Mode

Step 2. Connect test equipment and start injecting testing signals. In this example, the test set transmits SV messages SV1_Test and SV2_Test with q.test = True and the simulation flag = True.

Step 3. Use the testing equipment to vary testing signals, and execute required test cases to verify the PDIF function. *Table 10.6* lists the quality test and simulation flag for the normal and simulated GOOSE and SV messages.

Example 10.3 Maintenance Testing SEL-487B Bus Differential Protection (Continued)

Figure 10.3 Inject Simulated Test Signals Through Use of Test Equipment

NOTE: The IEC 61850 Mode/Behavior and IEC 61850 Simulation mode are implemented at the physical device level on SEL-400 series relays.

Table 10.6 Message Quality Test and Simulation Flag

Message	q.test	Simulation Flag
SV1_Test	True	True
SV2_Test	True	True
GOOSE1	True	False
SV1	False	False
SV2	False	False

Step 4. Return the device to normal operation by first taking the device under test out of Simulation mode (Sim.stVal = False). The relay stops processing test signals from the test equipment to avoid any possible misoperation resulting from the presence of simulated messages. Then change the relay IEC 61850 mode to On mode (Mod.stVal = On) to cause the IED to resume normal operation.

Example 10.4 Checking Data Acquisition With the TEST SV Command

SV subscribers do not support copper connections to instrument transformers. Because of this, it is necessary to check the validity of the digital samples. To provide assistance with this validity check, the SEL subscriber supports the SEL TEST SV mode.

This example uses the **TEST SV** command and the **COM SV** command. Refer to *Section 9: ASCII Command Reference* in the product-specific instruction manual for descriptions of the **TEST SV** and **COM SV** commands.

SEL created the TEST SV mode as a commissioning tool to help users perform easy validation of the process bus communication and the SV samples. While in TEST SV mode, the SEL merging unit generates test signals on all configured SV streams. The test bit in the quality attribute asserts for all published SV messages. The published signals are scaled from secondary (*Table 10.7*) to primary, in accordance with the CT and PT ratio setting as follows:

- CTRW is used for both IW and IX scaling
- PTRY is used for both VY and VZ scaling

Table 10.7 Secondary Quantities for the SEL-401, SEL-421-7, and SEL-451-6 SV Publishers

IEC	SEL	Magnitude (RMS)		Angle (Degrees)	
		5 A[a]	1 A[a]	ABC Rotation	ACB Rotation
I1	IA	5	1	0	0
I2	IB	5	1	–120	120
I3	IC	5	1	120	–120
I4	IN	0[b]	0[b]	0[b]	0[b]
V1	VA	67	67	0	0
V2	VB	67	67	–120	120
V3	VC	67	67	120	–120
V4	VN	0[b]	0[b]	0[b]	0[b]

[a] 1 A or 5 A nominal current.
[b] The neutral channel is the sum of the waveforms for A-, B-, and C-Phase.

NOTE: The **TEST SV** command is not supported in the SEL-487E-5 SV Publisher.

The neutral channel is the sum of the waveforms for A-, B-, and C-Phase. The published SV message rate is determined by the NFREQ setting.

Whenever the **TEST SV** command is entered, the relay starts or restarts a 15-minute timer to run in TEST SV mode before terminating TEST SV mode.

See the following procedure for verifying SV process bus communications between configured merging units and SV relays.

NOTE: Users can also see TEST SV mode indications from the ASCII commands **COM SV**, **STA A**, and **CST**.

On a merging unit that is configured to publish the desired current and voltage channels, enter TEST SV mode by issuing the **TEST SV** command.

Step 1. Issue the **COM SV** command to view the publication status (shown in *Figure 10.4*).

Step 2. Issue the **TAR SVPTST** command to view the TEST SV mode indicator, as shown in *Figure 10.5*. If SVPTST asserts, the merging unit is operating in TEST SV mode.

Example 10.4 Checking Data Acquisition With the TEST SV Command (Continued)

```
=>>TEST SV
WARNING: Test mode is not a regular operation.
Actual values will be overridden by test values.

Are you sure (Y/N)?Y

Relay 1                                    Date: 03/17/2023  Time: 10:42:33:331
Station A                                  Serial Number: 1230769999

Test mode active. Use TEST SV OFF to exit test mode.
Test mode will automatically terminate after 15 minutes.

=>>COM SV

IEC 61850 Mode/Behavior: On

SEL TEST SV Mode: On

IEC 61850 Simulation Mode: Off

SV Publication Information

 MultiCastAddr   Ptag:Vlan AppID  smpSynch
_____________________________________________________________________________

A0421_7P_006_ICD_1CFG/LLN0$MS$MSVCB01
 01-0C-CD-04-00-66  4:1    4000      1
 SV ID: 4000
 Data Set: A0421_7P_006_ICD_1CFG/LLN0$PhsMeas1
A0421_7P_006_ICD_1CFG/LLN0$MS$MSVCB02
 01-0C-CD-04-00-67  4:1    4000      1
 SV ID: 4000
 Data Set: A0421_7P_006_ICD_1CFG/LLN0$PhsMeas1

=>>
```

```
=>>TAR SVPTST

*       SVPTST  *       *       *       *       *       *
0       1       0       0       0       0       0       0

=>>
```

Figure 10.5 TEST SV Mode Indicator

On the SV subscriber, enter TEST SV mode by issuing the **TEST SV** command.

Step 1. Issue the **COM SV** command to view the subscription status, as shown in *Figure 10.6*. *Figure 10.6* also shows that before entering the TEST SV mode, the relay indicates **INVALID QUAL** for the incoming SV stream. After the relay enters the TEST SV mode, the relay recognizes the quality and indicates that the quality attribute test bit asserts by displaying the **QUALITY (TEST)** code.

Example 10.4 Checking Data Acquisition With the TEST SV Command (Continued)

```
=>>COM SV

IEC 61850 Mode/Behavior: On

SEL TEST SV Mode: Off

IEC 61850 Simulation Mode: Off

SV Subscription Status

 MultiCastAddr   Ptag:Vlan AppID  smpSynch    Code          Network Delay(ms)
_____________________________________________________________________________
A0421_7P_006_ICD_1CFG/LLN0$MS$MSVCB01
 01-0C-CD-04-00-66  4:1    4000      1      INVALID QUAL          NA
 SV ID: 4000
 Data Set: A0421_7P_006_ICD_1CFG/LLN0$PhsMeas1
A0421_7P_006_ICD_1CFG/LLN0$MS$MSVCB02
 01-0C-CD-04-00-67  4:1    4000      1      INVALID QUAL          NA
 SV ID: 4000
 Data Set: A0421_7P_006_ICD_1CFG/LLN0$PhsMeas1

=>>TEST SV

WARNING: Test mode is not a regular operation.
Actual values will be overridden by test values.

Are you sure (Y/N)?Y

Relay 1                                     Date: 03/17/2023  Time: 10:49:39:552
Station A                                   Serial Number: 1230769999

Test mode active. Use TEST SV OFF to exit test mode.
Test mode will automatically terminate after 15 minutes.

=>>COM SV

IEC 61850 Mode/Behavior: On

SEL TEST SV Mode: On

IEC 61850 Simulation Mode: Off

SV Subscription Status

 MultiCastAddr   Ptag:Vlan AppID  smpSynch    Code          Network Delay(ms)
_____________________________________________________________________________
A0421_7P_006_ICD_1CFG/LLN0$MS$MSVCB01
 01-0C-CD-04-00-66  4:1    4000      1      QUALITY (TEST)        0.63
 SV ID: 4000
 Data Set: A0421_7P_006_ICD_1CFG/LLN0$PhsMeas1
A0421_7P_006_ICD_1CFG/LLN0$MS$MSVCB02
 01-0C-CD-04-00-67  4:1    4000      1      QUALITY (TEST)        0.63
 SV ID: 4000
 Data Set: A0421_7P_006_ICD_1CFG/LLN0$PhsMeas1

=>>
```

Figure 10.6 Enter TEST SV Mode in the Relay

Step 2. Issue the **TAR SVTST** command to view the TEST SV mode indicator, as shown in *Figure 10.7*.

```
=>>TAR SVSTST

SVSALM  SVSTST  SVCC    *       *       *       *       *
0       1       1       0       0       0       0       0

=>>
```

Figure 10.7 TEST SV Mode Indicator

Step 3. Issue the **MET** command to verify that the relay current and voltage inputs are the proper magnitude and phase rotation (see *Examining Metering Quantities on page 3.34*). *Figure 10.8* shows the output of the **MET** command in this example.

Example 10.4 Checking Data Acquisition With the TEST SV Command (Continued)

```
=>>MET <Enter>

Relay 1                                    Date: 03/17/2023 Time: 02:08:46.920
Station A                                  Serial Number: 1230769999



Fundamental Meter: Terminal S

               Phase Currents                  Sequence Currents
           IA         IB         IC           I1         3I2       3I0
MAG(A,pri)  999.293   999.319   999.317      999.310    0.008      0.059
ANG(deg)     -0.00   -120.00    120.00        -0.00     1.46    -177.41

            Phase Voltages - PT -              Sequence Voltages
           VA         VB         VC           V1         3V2       3V0
MAG (kV)    133.903   133.903   133.903      133.903    0.00       0.00
ANG(deg)     -0.00   -120.00    120.00         0.00   137.62     173.77

Power Quantities
Active Power P (MW,pri)
     PA          PB          PC           3P
 133.81      133.81      133.81       401.43

Reactive Power Q (MVAr,pri)
     QA          QB          QC           3Q
   0.00        0.00       -0.00         0.00

Apparent Power  S (MVA,pri)
     SA          SB          SC           3S
 133.81      133.81      133.81       401.43

Power factor
 Phase A     Phase B     Phase C     3-Phase
 1.00        1.00        1.00        1.00

Line-to-Line Voltage
                   PT - V                              PT - Z
           VAB       VBC       VCA          VAB       VBC       VCA
MAG (kV)   231.925   231.930   231.923        0.005     0.007     0.005
ANG(deg)    30.00    -90.00    150.00      -166.32     61.99    -75.31

FREQ (Hz) 60.00           Frequency Tracking = Y
VDC (V)   115.82          V/Hz      -----%

=>>
```

Figure 10.8 MET Command Response

Commissioning tests help you verify that you have properly connected the relay to the power system and all auxiliary equipment. These tests confirm proper connection of control inputs and control outputs as well (see *Operating the Relay Inputs and Outputs on page 3.55*).

Relay Self-Tests

The relay continuously runs many self-tests to detect out-of-tolerance conditions. These tests run at the same time as relay protection and automation logic, but do not degrade relay performance.

The relay provides a number of alarms to indicate different conditions, as shown in *Table 10.8*.

Table 10.8 Alarm Relay Word Bits (Sheet 1 of 2)

Alarm Relay Word Bit	Description
HALARML	Latches for any relay failures.
HALARMP	Asserts for approximately five seconds when a warning condition occurs.

Table 10.8 Alarm Relay Word Bits (Sheet 2 of 2)

Alarm Relay Word Bit	Description
HALARMA	Starts pulsing for five seconds every minute whenever a new warning condition occurs and continues to pulse until the RST_HAL logic reset is asserted.
RST_HAL	Resets the HALARMA operation (similar to the other logic resets in the relay).
HALARM	Equivalent to HALARML OR HALARMP.
SETCHG	Pulses for at least one second whenever settings are changed.
GRPSW	Pulses for at least one second whenever groups are switched.
ACCESS	This bit is set when a user is logged in at Access Level B or higher.
BADPASS	Pulses for at least one second whenever a user enters three successive bad passwords.
SALARM	BADPASS OR SETCHG OR GRPSW OR Ethernet FW upgrade attempt.

The relay reports out-of-tolerance conditions as a status warning or status failure. For conditions that do not compromise relay protection, yet are beyond expected limits, the relay issues a status warning and continues to operate. A severe out-of-tolerance condition causes the relay to declare a status failure and enter a protection-disabled state. During a protection-disabled state, the relay suspends protection element processing and trip logic processing and de-energizes all control outputs. When disabled, the **ENABLED** front-panel LED is not illuminated.

The relay signals a status warning by pulsing the HALARMP, HALARMA, and HALARM Relay Word bits (hardware alarm) to logical 1 for five seconds. For a status failure, the relay latches the HALARML and HALARM Relay Word bits at logical 1. Some hardware failures prevent the relay from operating. In such cases, Relay Word bits HALARML and HALARM do not assert.

Once HALARMP pulses, Relay Word bit HALARMA continues to assert for approximately five seconds once per minute to indicate that a hardware warning has occurred. HALARMA continues to pulse until it is reset by pulsing SELOGIC control equation RST_HAL. Restarting the relay also resets HALARMA. HALARMP does not assert again for the same alarm condition, unless the condition is cleared and returns.

The relay will automatically restart as many as two times on certain diagnostic failures. In many instances, this will correct the failure. When this occurs, the relay will log a `Diagnostic Restart` in the SER.

To provide remote status indication, connect the b contact of OUT108 to your control system remote alarm input and program the output SELOGIC control equation to respond to NOT (SALARM OR HALARM).

If you repeatedly receive status warnings, check relay operating conditions as soon as possible. Take preventive action early during the development of potential problems to avoid system failures. For any status failure, contact your Technical Service Center or the SEL factory immediately (see *Technical Support on page 10.35*).

The relay generates an automatic status report at the serial ports for a self-test status failure if you set Port setting AUTO := Y. The relay issues a status message with a format identical to the **STATUS** command output, but includes the power supply information from the **STA A** response. The relay also displays status warning and status failure automatic messages on the front-panel LCD. Use the serial port **STATUS** and **CSTATUS** commands and the front-panel `RELAY STA-`

TUS menu to display status warnings and status failures. See *STATUS on page 14.60*, *Checking Relay Status on page 3.13*, and *Relay Status on page 4.30* for more information on automatic status notifications and on viewing relay status.

The relay includes self-diagnostics that monitor settings, hardware, and communication. The settings diagnostic checks if an internal error may have caused the calibration settings to be lost or corrupted, which would introduce errors in the magnitude and angles of the voltages and currents measured. The hardware diagnostics monitor any component change that does not match the part number, as well as hardware failures in the power supply, processors, and digital samplers. For relays that support DSS, the relay will monitor the connection to the DSS data or the communication board in the relay that receives the DSS data. Finally, the diagnostics monitor communications such as Ethernet, serial, and 87L connections. The **STATUS** command notifies the user if any of the diagnostics trigger a warning or a failure. In cases where the issue is a failure the relay will become disabled and protection will be inhibited.

Status

Figure 10.9 is a sample **STATUS** screen from the Status option of the QuickSet **HMI > Meter and Control** tree view (the terminal **STATUS** report is similar). *Figure 10.10* is a sample **STATUS A** report that shows all status information from an SEL-411L-2 with the five-port Ethernet card installed.

Figure 10.9 Relay Status: QuickSet HMI

```
=>STA A <Enter>

Relay 1                                    Date: 03/17/2023  Time: 04:48:49.938
Station A                                  Serial Number: 1230769999

FID=SEL-411L-2-Rxxx-V0-Zxxxxxx-Dyyyymmdd       CID=0xxxxx

Failures
  No Failures

Warnings
  No Warnings

Channel Offsets (mV)   W=Warn    F=Fail
  MOF
    3
```

Figure 10.10 Relay Status From a STATUS A Command on a Terminal

```
Mainboard Power Supply Voltages (V)   W=Warn    F=Fail
  3.3V_PS  5V_PS  N5V_PS  15V_PS   N15V_PS
     3.30   5.01   -5.00   15.00    -14.99

Five-Port Ethernet Card Power Supply Voltages (V)
  0.85V_PS  1.20V_PS  1.35V_PS  1.80V_PS  3.30V_PS  15.00V_PS
      0.84      1.19      1.35      1.78      3.27      14.96

Temperature (C)
  Mainboard    5-Port Eth SoC
       37.3              55.5

Communication Interfaces

Active High Accuracy Time Synchronization Source: PTP
  IRIG-B Source ABSENT
  PTP Source PRESENT

SELogic Relay Programming Environment Errors
  No Errors

IEC 61850 Mode/Behavior
   On

IEC 61850 Simulation Mode
   Off

Relay Enabled

=>
```

Figure 10.10 Relay Status From a STATUS A Command on a Terminal (Continued)

CSTATUS

The relay also reports status information in the Compressed ASCII format when you issue the CST command. An example Compressed ASCII status message is shown in *Figure 10.11*.

```
"RID","SID","FID","yyyy",
"relay_name","station_name","SEL-451-x-Rxx-Vx-Zxxxxxx-Dxxxxxxxx","yyyy"
"MONTH","DAY","YEAR","HOUR","MIN","SEC","MSEC","yyyy"
(Month),(Day),(Year),(Hour),(Min),(Sec),(MSec),"yyyy"

"CPU_RAM","CPU_PROG","SELBOOT","CPU_SET","DSP_RAM","DSP","DSP_CSUM","DSP_T_OUT","CPUDSP_RAM","FRNT_PNL","CAL_BOARDA","CCRD_
   CHG","COMM_CARD","ANA_CONV","IO_1","IO_2","yyyy"
"(Ok or F)","(Ok or F)","(Ok or F)","(Ok or F)","(Ok or F)","(Ok or F)","(Ok or F)","(Ok or F)","(Ok or F)","(Ok or
   F)","(Ok or F)","(Ok or F)","(Ok or F)","(Ok or F)","(Ok or F)","(Ok or F)","yyyy"
"ATOD_OFFST","MSTR_OFFST","3.3V_PS","5V_PS","N5V_PS","15V_PS","N15V_PS","TEMP_STA","TEMP","PRT_O_LOAD","LCD_ERROR","FPGA","
   yyyy"

"(Ok or F)","(Ok or F)","(Ok or F)","(Ok or F)","(Ok or F)","(Ok or F)","(Ok or F)","(Ok or F)",(Temp value),"(Ok or
   F)","(Ok or F)","(Ok or F)","yyyy"
"MBA","MBB","ACTTIM_SRC","SELOG_MATH","FM_TEST","DB_TEST","DB2_TEST","RLY_STA","PRT_F_TP","PRT_1_TP","PRT_2_TP","PRT_3_TP",
   "PRT_5_TP", "87L_TEST", "SV_TEST", "I850_MOD", "SIM_MOD","yyyy"
(Inac or Ok or F),(Inac or Ok or F),(HIRIG or IRIG or HPTP or " "),(Enabled or Disabled), (Enabled or Disabled), (Enabled
   or Disabled), (Enabled or Disabled),(F,0-5), (F,0-5), (F,0-5), (F,0-5), (F,0-5),(Enabled or Disabled), (Enabled or
   Disabled), (Enabled or Disabled), (Enabled or Disabled)"yyyy"
```

Figure 10.11 Example Compressed ASCII Status Message

Definitions for the items and fields in the Compressed ASCII configuration are listed below:

- *yyyy* is the checksum
- *x* is text in the FID (Firmware ID) string
- (description) is text that the relay supplies
- (Ok or W or F) is normal, warning, or failure, respectively

Firmware Version Number

At the top of each status report the relay displays the present firmware version number that identifies the software program that controls relay functions. The firmware version is the four-place designator immediately following the relay

model number (the first characters in the firmware identification or FID string). The first character in the four-place firmware version number is R (representing Release).

Figure 10.9 and *Figure 10.10* show the location of the FID sting, with a blank or generic response. To see the actual FID string for the firmware version described in this manual, see *Appendix A: Firmware, ICD File, and Manual Versions* in the product-specific instruction manual for firmware version information.

Relay Troubleshooting

Inspection Procedure

Complete the following inspection procedure before disturbing the system. After you finish the inspection, proceed to *Troubleshooting Procedures on page 10.23*.

Step 1. Confirm that the power is on. Do not turn the relay off.

Step 2. Measure and record the control power voltage at the relay **POWER** terminals marked **+** and **–** on the rear-panel terminal strip.

Step 3. Measure and record the voltages at all control inputs.

Step 4. Measure and record the state of all control outputs.

Step 5. Inspect the serial communications ports cabling to be sure that a communications device is connected to at least one communications port.

Troubleshooting Procedures

Troubleshooting procedures for common problems are listed in *Table 10.9* and *Table 10.10*. The table lists each symptom, possible causes, and corresponding diagnoses/solutions. Related ASCII commands are listed in bold capitals. See *Section 14: ASCII Command Reference* for details on SEL-400 series commands and *Section 12: Settings* for details on relay settings.

Table 10.9 Troubleshooting Procedures[a] (Sheet 1 of 3)

Symptom/Cause	Diagnosis/Solution
Dark Front Panel	
Power is off.	Verify that substation battery power is operational.
Input power is not present.	Verify that power is present at the rear-panel terminal strip.
Blown power supply fuse.	Replace the fuse (see *Power Supply Fuse Replacement on page 10.28*).
Poor HMI contrast.	Press and hold **ESC** for two seconds. Press **Up Arrow** and **Down Arrow** pushbuttons to adjust contrast.
Status Failure Notice on Front Panel	
Self-test failure.	See *Table 10.10* for guidance on the specific failure type. The OUT108 relay control output b contacts will be closed if you programmed NOT HALARM to OUT108.
Alarm Output Asserts	
Power is off.	Restore power.
Blown power supply fuse.	Replace the fuse (see *Power Supply Fuse Replacement on page 10.28*).
Power supply failure.	LCD displays `STATUS FAILURE` screen. See *Table 10.10*.

Table 10.9 Troubleshooting Procedures[a] (Sheet 2 of 3)

Symptom/Cause	Diagnosis/Solution
Main board or interface board failure.	LCD displays `STATUS FAILURE` screen. See *Table 10.10*.
Other self-test failure.	LCD displays `STATUS FAILURE` screen. See *Table 10.10*.
System Does Not Respond to Commands	
NOTE: If Port setting PROTO := PMU, that serial port will not respond to ASCII commands. Additionally, a PROTO := PMU port will not respond to any messages when Global setting EPMU := N.	
No communication.	Confirm cable connections and types. If correct, type **<Ctrl+X> <Enter>**. This resets the terminal program.
Communications device is not connected to the system.	Connect a communications device.
Incorrect data speed (baud rate) or other communications parameters.	Configure your terminal port parameters to the particular relay port settings. Use the front panel to check port settings (see *Set/Show on page 4.26*).
Incorrect communications cables.	Use SEL communications cables, or cables you build according to SEL specifications (see *Serial Communication on page 15.2*).
Communications cabling error.	Check cable connections.
Handshake line conflict; system is attempting to transmit information, but cannot do so.	Check communications cabling. Use SEL communications cables, or cables you build according to SEL specifications (see *Serial Communication on page 15.2*).
System is in the XOFF state, halting communications.	Type **<Ctrl+Q>** to put the system in the XON state.
Terminal Displays Meaningless Characters	
Data speed (baud rate) is set incorrectly.	Check the terminal parameters configuration (see *Serial Communication on page 15.2*).
Terminal emulation is not optimal.	Try other terminal types, including VT-100 and VT-52 terminal emulations.
System Does Not Respond to Faults	
Relay is set improperly.	Review the relay settings.
Improper test settings.	Restore operating settings.
PT or CT connection wiring error.	Confirm PT and CT wiring.
Input voltages and currents phasing, and rotation errors.	Use relay metering. Use the **TRI** event trigger command and examine the generated event report (see *Examining Metering Quantities on page 3.34*).
The analog input (flat multipin ribbon) cable between the input module board and the main board is loose or defective.	Reseat both ends of the analog input cable, observing proper ESD precautions (see *Installing Optional I/O Interface Boards on page 10.30*).
Check the relay self-test status.	Take preventive action as directed by relay Status Warning and Status Failure information (see *Checking Relay Status on page 3.13*).
Sequence of Events Recorder	
SER DATA LOSS Reported	This is caused by an internal buffer overrun, which can occur if SER points are being triggered faster than they can be processed. It will recover as soon as the SER processing can catch up. SER data loss can also be caused by excessive SER triggering (>6000 points per hour), causing the relay to temporarily suspend storing points. In this case, it will normally recover within an hour, but the SER DATA LOSS END message will not be reported until the first SER point is triggered after the suspension ends.
Tripping Output Relay Remains Closed Following a Fault	
Auxiliary contact control inputs are improperly wired.	Check circuit breaker auxiliary contacts wiring.
Control output relay contacts have burned closed.	Remove relay power. Remove the control output connection. Check continuity—Form A contacts should be open and Form B contacts should be closed. Contact the SEL factory or your Technical Service Center if continuity checks fail.
I/O interface board failure.	LCD displays `STATUS FAILURE` screen. Contact the SEL factory or your Technical Service Center.

Table 10.9 Troubleshooting Procedures[a] (Sheet 3 of 3)

Symptom/Cause	Diagnosis/Solution
Time/Date Errors	
External IRIG time source error.	Check IRIG-B time source or cables. Check **TIME Q** command or `HMI SET/SHOW | Date/Time` screen.
A low-priority time source error.	Check last update source (**TIME Q** command or `HMI SET/SHOW | Date/Time` screen) (see *Table 11.6 on page 11.8*).
Lithium clock battery failure.	Verify that the battery has failed before replacing the battery–it should last for 10 years if the relay is energized (see *Replacing the Lithium Battery on page 10.27*).
TiDL (T-Protocol)	
TiDL system will not successfully commission.	Check all fiber connections and verify link budget and received/transmit power of both the TiDL relay and SEL-TMU.
Loss of communications with an SEL-TMU.	Check the SEL-TMU front panel. If disabled (see SEL-TMU instruction manual), see *VECTOR on page 14.73*. If the SEL-TMU is enabled, check fiber connections and verify the link budget and received/transmit power of both the TiDL relay and the SEL-TMU.
TiDL (EtherCAT) Applications	
Relay will not successfully commission.	Check the configuration of axion CT/PT modules and verify that they match a supported topology (see *Section 2: Installation* in the product-specific instruction manual).
Relay disabled.	Check the CT/PT modules for failure. If a module is identified as failed, replace the CT/PT module and then press the commissioning button on the back of the relay (see *TiDL System Commissioning on page 10.2*).
Firmware Upgrade	
Model mismatch.	Firmware file does not match relay model (see *Resolving Model Mismatch on page B.24*).
SELBOOT flash mismatch.	SELBOOT checksum has failed. Try to reload the SELBOOT firmware with the **REC BOOT** command. If reload fails, return to SEL (see *E Upload New SELBOOT Firmware to the Relay on page B.13*).
CID File	
Out of memory error when sending a CID file to the relay	This can be caused by a large number of data attributes in the configured datasets and/or by a large number of supervised subscriptions (LGOS and/or LSV logical nodes). Reduce either the number of supervised subscriptions or the number of data attributes in the configured Datasets, or remove any default datasets not required in the application. By default, all GOOSE/SV subscriptions are supervised. Supervised GOOSE/SV subscriptions can be removed in Architect by right-clicking in the data field in GOOSE/SV Subscriptions and selecting **Disable supervision**.

[a] For SV applications, refer to Table 14.45.

Table 10.10 Troubleshooting for Relay Self-Test Warnings and Failures (Sheet 1 of 3)

Diagnostic Message	Diagnosis/Solution
Memory Failures	
RAM Error[b]	This indicates a processor memory device detected an error. Contact your Technical Service Center for analysis of the error.
Memory Failures	
RAM Failure[b]	This indicates a failure of a memory device. Contact the SEL factory or your Technical Service Center.
Flash Failure	
EEPROM Failure	
Settings Failed	
Default Settings Failure	
Default Cal Settings	This indicates that something has occurred that has caused the relay to lose its calibration. Contact the SEL factory or your Technical Service Center.

Table 10.10 Troubleshooting for Relay Self-Test Warnings and Failures (Sheet 2 of 3)

Diagnostic Message	Diagnosis/Solution
MAC Address Warning	
MAC Address Conflict	Not all MAC Addresses are unique. Contact the SEL factory or your Technical Service Center.
Missing MAC Address	Not all MAC Addresses are valid. Contact the SEL factory or your Technical Service Center.
Five-Port Ethernet Card	
Comm Card Error or Failure	Contact the SEL factory or your Technical Service Center.
Comm Card Firmware Mismatch	The five-port Ethernet card is installed, but either the relay firmware or SELBOOT is not compatible with the Ethernet card. To resolve the error, verify SELBOOT R302 or later is installed and load any relay firmware that supports the five-port Ethernet card (see *Appendix A: Firmware, ICD File, and Manual Versions* in the product-specific manuals). If supported firmware is already loaded, reload the firmware. If the error persists, contact SEL for assistance.
Port *n*[a] SFP Not Compliant	An SFP transceiver is connected to an enabled `PORT n` but could not be authenticated because it is not compatible. See *Table 15.7* or selinc.com/products/sfp for a list of compatible SFP transceivers.
Port *n*[a] SFP Speed Not Compliant	An SFP transceiver is connected to an enabled `PORT n` but has a speed that is not compatible with that port. Replace the transceiver with one with the correct speed.
SFP Speed Mismatch Port 5A, 5B Disabled	The SFP transceivers in `PORT 5A` and `PORT 5B` have mismatching speeds. Replace one of the transceivers so that they have matching speeds.
Port *n*[a] SFP Not Installed	`PORT n` is enabled but has no SFP transceiver installed. Install a compatible transceiver in that port.
Port *n*[a] SFP Error	An SFP transceiver is connected to an enabled `PORT n` but has a hardware failure. Replace the failed transceiver and report the error to the SEL factory or your Technical Service Center.
Port *n*[a] SFP TX Fault	The relay logs this warning when the transmit voltage of an SFP transceiver goes out of range on enabled `PORT n`. The relay attempts to resolve the condition by disabling and re-enabling the affected port. If the condition occurs three times in one week, the relay permanently disables the affected port until the SFP is replaced.
Line-Current Differential Warnings	
87L Watchdog Alarm	This alarm indicates that the relay has received more than three unwarranted 87L pickup operations associated with 87L communication channel impairments. This logic asserts Relay Word bit 87ALARM and does not inhibit 87L protection. This alarm can be reset at Access Level 2 by issuing a **COM 87L WD C** command.
87L Watchdog Error 1	This error indicates that the relay has received more than five unwarranted 87L pickup operations associated with 87L communication channel impairments. This logic asserts Relay Word bit 87ERR1 and inhibits 87L protection. This alarm can be reset at Access Level 2 by issuing a **COM 87L WD C** command.
87L Watchdog Error 2	This error indicates that the relay has received more than ten unwarranted 87L pickup operations associated with 87L communications channel impairments and non-channel related issues. This logic asserts Relay Word bit 87ERR2 and inhibits 87L protection. This alarm can be reset at Access Level 2 by issuing a **COM 87L WD C** command. **NOTE:** In firmware R105 and older, this alarm can only be reset at Access Level C.
87L Watchdog Reset	This warning occurs when the **COM 87L WD C** command is issued.
Hardware Changes	
Card or Board Change	This indicates that the installed hardware does not match the part number. If the hardware was intentionally changed, use the **STA** command from Access Level 2 to accept the new hardware configuration. If the hardware was not changed, make sure all connections are fully seated and then restart the relay. If the error persists, contact the SEL factory or your Technical Service Center.
Power Supply Voltage Status Warning	
Power supply voltage(s) are out-of-tolerance.	Log the Status Warning. If repeated warnings occur, take preventive action.
A/D converter failure.	LCD displays `STATUS FAILURE` screen. Contact the SEL factory or your Technical Service Center.

Table 10.10 Troubleshooting for Relay Self-Test Warnings and Failures (Sheet 3 of 3)

Diagnostic Message	Diagnosis/Solution
Power Supply Voltage Status Failure	
Power supply voltage(s) are out-of-tolerance.	LCD displays `STATUS FAILURE` screen. Contact the SEL factory or your Technical Service Center.
A/D OFFSET WARN Status Warning	
Loose ribbon cable between the input module board and the main board.	Reseat both ends of the analog input cable.
A/D converter drift.	Log the Status Warning. If repeated warnings occur, contact the SEL factory or your Technical Service Center.
Master offset drift.	LCD displays `STATUS FAILURE` screen. Contact the SEL factory or your Technical Service Center.
FPGA Error	
FPGA diagnostics identified an out-of-tolerance condition.[b]	In this rare event, the relay will automatically restart to clear the error and resume protection. If the failure occurs three times in seven days, the LCD displays the FPGA FAIL screen and the relay safely disables. Contact the SEL factory or your Technical Service Center. **NOTE:** In older firmware versions, the relay did not automatically restart. Contact the SEL factory or your Technical Service Center.
Serial Port Power Overload	
+5V EIA-232 Overload	The relay rear serial ports are capable of providing +5 V power to an external transceiver, but have a limited power output. This warning indicates that the power limit has been exceeded and the current has been limited. Check what is connected to the serial ports to ensure that there is no unintentional load on the +5 V outputs.
All Other Warnings and Failures	
	Contact the SEL factory or your Technical Service Center.

[a] Where n = 5A, 5B, 5C, 5D, or 5E
[b] The relay will automatically restart for some of these failures. Contact the factory if the failure reoccurs.

Maintenance

Instructions for Cleaning

Use care when cleaning the relay. Use a mild soap or detergent solution and a damp cloth to clean the chassis. Do not use abrasive materials, polishing compounds, or harsh chemical solvents (such as xylene or acetone) on any surface.

Replacing the Lithium Battery

You can replace the lithium battery in the relay. Perform the following steps to replace the lithium battery.

⚠CAUTION
There is danger of explosion if the battery is incorrectly replaced. Replace only with Rayovac no. BR2335 or equivalent recommended by manufacturer. See Owner's Manual for safety instructions. The battery used in this device may present a fire or chemical burn hazard if mistreated. Do not recharge, disassemble, heat above 100°C or incinerate. Dispose of used batteries according to the manufacturer's instructions. Keep battery out of reach of children.

Step 1. Remove the relay from service.

a. Follow your company standard procedure for removing a relay from service.

b. Disconnect power from the relay.

c. Remove the relay from the rack or panel.

d. Retain the **GND** connection, if possible, and ground the equipment to an ESD mat.

Step 2. Remove the front panel from the relay.

Step 3. Disconnect the front-panel cable from the front panel.

Step 4. Disconnect the power cable, interface board cable(s), and input board analog cable from the main board.

Step 5. Pull out the drawout tray containing the main board. In some SEL-400 series relays, the main board is not in a drawout tray. In these cases, you will need to remove the top cover to access the battery.

Step 6. Locate the lithium battery.

The lithium battery is at the front of the main board.

Step 7. Remove the spent battery from beneath the clip of the battery holder.

⚠CAUTION
Equipment components are sensitive to electrostatic discharge (ESD). Undetectable permanent damage can result if you do not use proper ESD procedures. Ground yourself, your work surface, and this equipment before removing any cover from this equipment. If your facility is not equipped to work with these components, contact SEL about returning this device and related SEL equipment for service.

Step 8. Replace the battery with an exact replacement.

Use a 3 V lithium coin cell, Rayovac No. BR2335 or equivalent. The positive side (+) of the battery faces up.

Step 9. Reinstall the relay main board drawout tray.

Step 10. Reattach the power cable, interface board cable(s), and input board analog cable.

Step 11. Reconnect the front-panel cable to the front panel.

Step 12. Reattach the front panel.

Step 13. Set the relay date and time via the communications ports or front panel (see *Making Simple Settings Changes on page 3.15*).

Step 14. Follow your company's standard procedure to return the relay to service.

Power Supply Fuse Replacement

⚠DANGER
Disconnect or de-energize all external connections before opening this device. Contact with hazardous voltages and currents inside this device can cause electrical shock resulting in injury or death.

⚠WARNING
Have only qualified personnel service this equipment. If you are not qualified to service this equipment, you can injure yourself or others, or cause equipment damage.

You can replace a bad fuse in a relay power supply, or you can return the relay to SEL for fuse replacement. If you decide to replace the fuse, perform the following steps:

Step 1. Follow your company standard to remove the relay from service.

Step 2. Disconnect power from the relay.

Step 3. Remove the relay from the rack or panel.

Step 4. Retain the **GND** connection, if possible, and ground the equipment to an ESD mat.

Step 5. Remove the communications cable connected to the front-panel serial port, if applicable.

Step 6. Remove the rear-panel **EIA-232 PORT** mating connectors.

Unscrew the keeper screws and disconnect any serial cables connected to the **PORT 1**, **PORT 2**, and **PORT 3** rear-panel receptacles.

⚠CAUTION
Equipment components are sensitive to electrostatic discharge (ESD). Undetectable permanent damage can result if you do not use proper ESD procedures. Ground yourself, your work surface, and this equipment before removing any cover from this equipment. If your facility is not equipped to work with these components, contact SEL about returning this device and related SEL equipment for service.

Step 7. Loosen the four front-panel screws (they remain attached to the front panel), and remove the relay front panel.

Step 8. Remove the 34-pin ribbon cable from the front panel by pushing the extraction ears away from the connector.

Step 9. Disconnect the power, the interface board, and the analog input board cables from the main board.

Step 10. Remove the screw-terminal connectors.

a. Loosen the attachment screws at each end of the 100-addresses, 200-addresses, and 300-addresses screw-terminal connectors.

b. Pull straight back to remove.

Step 11. Remove the top chassis plate by unscrewing seven screws from the chassis.

Step 12. Pull out the drawout tray containing the main board.

Step 13. Pull out the drawout tray containing the I/O interface board(s).

Step 14. Locate the power supply. Fuse F1 is at the rear of the power supply circuit board (see *Figure 10.12*).

Step 15. Examine the power supply for blackened parts or other damage. If you can see obvious damage, reinstall all boards and contact SEL to arrange return of the relay for repair.

Step 16. Remove the spent fuse from the fuse clips.

Step 17. Replace the fuse with an exact replacement (see *Section 2: Installation* in the product-specific instruction manual for the proper fuse for your power supply).

Step 18. Reinstall the interface board.

Step 19. Reinstall the main board, and reconnect the power, the interface board, and the analog input board cables.

Step 20. Replace the chassis top on the relay and secure it with seven screws.

Step 21. Reconnect the cable removed in *Step 8* and reinstall the relay front-panel cover.

Step 22. Reattach the rear-panel connections.

Affix the screw-terminal connectors to the appropriate 100-addresses, 200-addresses, and 300-addresses locations on the rear panel.

Step 23. Reconnect any serial cables that you removed from the **EIA-232 PORTS** in the disassembly process.

Step 24. Follow your company standard procedure to return the relay to service.

NOTE: Some versions of this relay will have the PS50 power supply. The fuse is located in the same location as the PS30, but it is rotated 90 degrees.

Figure 10.12 PS30 Power Supply Fuse Location

Installing Optional I/O Interface Boards

Perform the following steps to install SEL-400 series relay I/O interface boards.

⚠CAUTION
Equipment components are sensitive to electrostatic discharge (ESD). Permanent damage can result if you do not use proper ESD procedures. Ground yourself, your work surface, and this equipment before removing any cover from this equipment. If your facility is not equipped to work with these components, contact SEL about returning this device and related SEL equipment for service.

Step 1. Follow your company standard to remove the relay from service. It will be necessary to remove power from the relay as part of this process.

Step 2. Disconnect power from the relay. Isolate any contact inputs or outputs that will be affected by the installation of the I/O interface board.

Step 3. Retain the **GND** connection, located to the right of the power supply terminals to the relay, and ground the equipment to an ESD mat, or other grounding point.

Step 4. Remove the communications cable connected to the front-panel serial port, if applicable.

Step 5. Remove the rear-terminal block connectors for the I/O board that is being installed. Two screws are used to retain each connector. Once these screws are loosened, pull the connector firmly to remove it from the rear of the relay. Note that these connectors are keyed to their mating connectors in the relay.

Figure 10.13 SEL-400 Series Relay Rear Panel

Step 6. Remove the front panel.

a. Unscrew the front cover of the relay.

b. Slowly pull the front cover off of the relay.

There will be a short ribbon cable between the front panel of the relay and the main board of the relay that will prevent the relay front panel from being pulled more than five inches from the relay. Do not let the relay front panel hang from this ribbon cable.

c. Remove the ribbon cable at the front panel by pushing the cable retention levers toward the back of the front panel, as shown in *Figure 10.14*.

If your front panel is equipped with auxiliary trip and close pushbuttons, remove the connectors to the pushbuttons connected at the front panel and the expansion I/O board.

Figure 10.14 Front-Panel Ribbon Cable Connector With Clasps Open

Step 7. Remove the power supply, expansion I/O and calibration board ribbon cables from their connectors on the main board (see *Figure 10.15*).

Figure 10.15 Main Board Cable Connections

Step 8. Remove the main board power cable (white connector) from the main board by lifting up the retaining tabs on top of the header and sliding the connector out.

Do not bend the retaining tabs any higher than is necessary to remove the connector as this could damage the tabs.

Step 9. Use the Jumper Configuration table shown in *Figure 10.16* to confirm that the jumper arrangement on the I/O board matches the correct jumper configuration for the interface board being installed. For example, the jumper configuration in *Figure 10.16(a)* is for an interface board being installed at the 300 level (i.e., the jumpers are set to ON, OFF, ON, OFF).

Figure 10.16 I/O Board Jumper Configuration

Step 10. Install the drawout tray with the I/O interface board.

a. Position the drawout tray edges into the left-side and right-side internally mounted slots.

b. Slide the I/O interface board into the relay by pushing the front edge of the board drawout tray.

c. Apply firm pressure to fully seat the I/O interface board.

If you encounter resistance, STOP and withdraw the board.

Inspect the drawout tray edge guide slots for damage.

If you see no damage, take all of the precautions outlined above and try again to insert the board.

Step 11. Confirm screw-terminal connector keying.

a. Inspect the screw-terminal connector receptacles on the rear of the I/O interface board.

Figure 10.17 shows the I/O board section without terminal blocks. The yellow dividers are the connector keying for each terminal block.

b. Refer to *Figure 10.18* for the corresponding key positions inside the receptacle.

Figure 10.17 Screw-Terminal Connector Receptacles

Figure 10.18 Screw-Terminal Connector Keying

c. If the keys inside the I/O interface board receptacles are not in the positions indicated in *Figure 10.18*, grasp the key edge with long-nosed pliers to remove the key and reinsert the key in the correct position.

d. Break the webs of the screw-terminal connectors in the position that matches the receptacle key, as shown in *Figure 10.19*.

Figure 10.19 Screw-Terminal Connector With Webs

Step 12. Attach the screw-terminal connector.

a. Mount the screw-terminal connectors to the rear panel of the relay.

b. Tighten the screw-terminal connector mounting screws to between 7 in-lb and 12 in-lb (0.8 Nm to 1.4 Nm).

Step 13. Reconnect the power, the interface board, and the analog input board cables to the relay main board.

Step 14. Reconnect the cables removed in *Step 6*–*Step 8* and reinstall the relay front-panel cover.

Step 15. Apply power.

Step 16. Reconnect any serial cables that you removed from the communications ports in the disassembly process.

Step 17. Establish a terminal emulation session with the relay by using QuickSet or another terminal emulation program.

Step 18. Using the terminal emulation program, enter Access Level 2.

Step 19. From Access Level 2, issue the **STA** command, and answer **Y <Enter>** if prompted to accept the new hardware configuration. (Note: If the I/O board was replaced with exactly the same board, you will not be prompted to accept new hardware.)

Step 20. Inspect the relay targets to confirm that the relay reads the I/O interface board(s).

a. Verify the I/O interface board control inputs and outputs in the target listings by using a terminal or the QuickSet software.

b. Use a communications terminal to issue the following commands.

TAR IN*n*01 <Enter>

TAR OUT*n*01 <Enter>

n = 1–5 for boards in the 100–500 address slots

Step 21. Follow your company's standard procedure to return the relay to service.

Troubleshooting

Step 1. If the I/O board jumpers were not correctly configured in *Step 9* and *Step 10*, the front panel will display the error `RELAY DISABLED SETTINGS FAILED`. You will also receive a `SETTINGS FAILED` failure in the terminal emulation window following an **STA** command, as shown in *Figure 10.20*.

```
Level 2
=>>STA

Relay 1                                Date: 01/10/2000   Time: 18:13:10.769
Station A                              Serial Number: 1130320464

FID=SEL-487B-1-R305-V0-Z007005-D20121221    CID=0XF3A0

Failures
  SETTINGS FAILED


Warnings
  No Warnings

SELogic Relay Programming Environment Errors
  No Errors

Relay Disabled
```

Figure 10.20 I/O Board Installation Error Message in the Terminal Window

Step 2. Disconnect power to the relay and return to *Step 8* to verify you have correctly configured the jumpers (*Step 9*). If the jumpers are not correct, repeat the I/O board installation instructions, beginning with *Step 9*.

Step 3. If the jumpers are correct, enter Access Level C (CAL).

a. Enter the **VEC D** command.

b. If you see the error `SETTINGS FAILURE in C n`

(*n* = 1–4), enter the **SET C *n*** command.

c. When prompted to do so, save the settings.

d. Return to Access Level 2, and enter the **STA** command to verify that the status is free of warnings.

If the problem persists, please contact your SEL representative.

Technical Support

We appreciate your interest in SEL products and services. If you have questions or comments, please contact us at:

Schweitzer Engineering Laboratories, Inc.
2350 NE Hopkins Court
Pullman, WA 99163-5603 U.S.A.
Tel: +1.509.338.3838
Fax: +1.509.332.7990
Internet: selinc.com/support
Email: info@selinc.com

This page intentionally left blank

SECTION 11

Time and Date Management

The SEL-400 series relays can determine the time from a variety of sources, including IRIG-B, Precision Time Protocol (PTP) (IEEE 1588), SNTP, DNP3, MIRRORED BITS, terminal **TIME** and **DATE** commands, and HMI settings. (Refer to the appropriate sections in the product-specific instruction manual to learn about using these various time sources.) Most of these sources provide only an approximate measure of time. For high-accuracy time synchronization, which is needed to support synchrophasors and to ease comparison of system-wide events, a high-accuracy time source must be provided, such as IRIG-B with C37.118 extensions or PTP with power system profile. This section focuses on issues related to high-accuracy timekeeping. The relay records power system events with very high accuracy when you provide high-accuracy clock input signals. Relays placed at key substations can give you information on power system operating conditions in real time.

NOTE: Not all SEL-400 series relays support synchrophasors.

Based on the high-accuracy time input, the relay calculates synchrophasors for currents and line voltages (for each phase and for positive-sequence), as specified in IEEE C37.118, Standard for Synchrophasor Measurements for Power Systems. You can then perform detailed analysis and calculate load flow from the synchrophasors. See *Section 18: Synchrophasors* for more information about phasor measurement functions in the relay.

This section presents details on these measurements as well as suggestions for further application areas. The topics of this section are the following:

- *IRIG-B Timekeeping on page 11.1*
- *PTP Timekeeping on page 11.2*
- *Time Source Selection on page 11.5*
- *Time Quality Indications on page 11.5*
- *Time-Synchronized Events on page 11.9*

IRIG-B Timekeeping

The relay is capable of high-accuracy timekeeping when supplied with an IRIG-B signal. When the supplied clock signal is sufficiently accurate, the relay can act as a phasor measurement unit (PMU) and transmit synchrophasor data representative of the power system at fixed time periods to an external data processor. The relay can also record COMTRADE event report data by using the high-accuracy time stamp.

The relay has two input connectors that accept IRIG-B demodulated time-code format: the IRIG-B pins of serial **PORT 1**, and the IRIG-B BNC connector. See *Section 2: Installation* in the product-specific instruction manual for more information on connecting these inputs.

NOTE: The SEL-2407 Satellite-Synchronized Clock meets both the relay accuracy and IEEE C37.118 requirements for a high-accuracy time source.

The IRIG-B inputs can be used for high-accuracy timekeeping purposes with as high as 1 µs accuracy with an appropriate time source. See *Table 11.1* for relay timekeeping mode details.

Table 11.1 Relay Timekeeping Modes

Item	Internal Clock	IRIG	HIRIG (or High-Accuracy IRIG)	PTP	HPTP
Best accuracy (condition)	Depends on last method of setting, or synchronization[a]	500 µs (when time-source jitter is less than 3 ms)	1 µs (when time-source jitter is less than 500 ns, and time-error is less than 1 µs)[b]	Determined by PTP master (Master clock sync and announce interval <= 4 s)	1 µs (Master clock sync and announce interval <= 4 s, and TQUAL <1 µs)
IRIG-B connection required	None	BNC connector (preferred), or serial PORT 1	BNC connector (preferred), or serial PORT 1	PTP time source connected	PTP time source connected
Relay Word bits	TIRIG = 0 TSOK = 0 BNC_TIM = 0 SER _TIM = 0 BNC_OK = 0 SER_OK = 0 TLOCAL = 0 TGLOBAL = 0	TIRIG = 1 TSOK = 0 BNC_TIM = 1 or SER_TIM = 1 BNC_OK = 1 or SER_OK = 1 TLOCAL = 1 TGLOBAL = 0	TIRIG = 1 TSOK = 1 BNC_TIM = 1 or SER_TIM = 1 BNC_OK = 1 or SER_OK = 1 TLOCAL = 0 TGLOBAL = 1	TPTP = 1 TSOK = 0 TLOCAL = 1 TGLOBAL = 0 PTP_OK = 1	TPTP = 1 TSOK = 1 TLOCAL = 0 TGLOBAL = 1 PTP_OK = 1

[a] The internal clock in the relay can be synchronized via SNTP, DNP3, SEL-2030 Communications Processor, or MIRRORED BITS communications.
[b] The time source must include the IEEE C37.118 IRIG-B control bit assignments and the Global setting IRIGC must be set to C37.118 to provide the time-error estimate for the clock. In products that support line-current differential protection, the jitter requirement for HIRIG is 50 ns.

NOTE: If the time-code signal connected to the BNC connector degrades in quality, the relay will not switchover to the IRIG-B pins of serial PORT 1. The relay will only switch to serial PORT 1 if the signal on the BNC connector completely fails or the accuracy is better on serial PORT 1 than on the BNC input (e.g., the cable is unplugged).

Only one IRIG-B time source can be used by the relay, and the signal connected to the IRIG-B BNC connector takes priority over the serial PORT 1 IRIG-B pins. If a signal is detected on the IRIG-B BNC input, the IRIG-B pins of serial PORT 1 will be ignored, unless the serial PORT 1 IRIG-B has better quality than the BNC input.

The relay determines the suitability of the IRIG-B signal connected to the BNC connector for high-accuracy timekeeping by applying two tests:

- Measuring whether the jitter between positive-transitions (rising edges) of the clock signal is less than 500 ns.
- Decoding the time-error information contained in the IRIG-B control field and determining that analog quantity TQUAL is less than 10^{-6} seconds (1 µs).

If a valid source is detected on the BNC or serial port IRIG inputs, BNC_TIM and BNC_OK or SER_TIM and SER_OK will be set, respectively.

PTP Timekeeping

NOTE: The SEL-487V does not support PTP.

In addition to IRIG-B, Precision Time Protocol (PTP), as specified in IEEE 1588-2008, can be used for high-accuracy timekeeping. The relay can only be synchronized by a grandmaster on the PTP timescale, not an arbitrary (ARB) timescale. With the ARB timescale, the epoch is set by an administrative procedure and can change at any time during normal operation. The PTP timescale uses the PTP epoch of January 1 1970 00:00:00 TAI (International Atomic Time), which corresponds to December 31 1969 23:59:51.999918 UTC (Coordinated Universal Time). Its unit of time is the SI second and accounts for leap seconds.

The offset between TAI and UTC time is included in the PTP announce message, along with a flag that indicates whether or not the offset is valid. The relay will use the offset sent by the Grand Master (GM) clock to determine UTC time

regardless of validity. Because of this, all SEL devices (and other slave devices that share this behavior) synchronized with the GM will retain relational accuracy with each other even if, in certain cases, the GM may be incorrect in relation to UTC.

The announce message may also include the current TAI to Local offset value (required in the C37.238 profile). In accordance with IEEE 1588-2008 16.3.3.4, this value must include the TAI to UTC offset to reflect local time at the node, or slave device. If the relay receives a TAI to Local offset value that does not include the TAI to UTC offset, it may incorrectly calculate UTC and Local time. Also, if the announce message does not include the TAI to Local offset value, the relay will use its configured Time and Date settings (UTCOFF, BEG_DST, and END_DST) to calculate local time. This is one reason that the relay Time and Date settings must match the settings in the GM clock, or devices that are synchronized may have issues with time-alignment.

To use PTP, the relay part number must include the Ethernet card option that supports PTP and PTP must be enabled in **PORT 5** settings and properly configured. The relay must be connected to a network containing an appropriate PTP master, and all intervening switches must be IEEE 1588 aware. For SEL-400 series relays with a two- or four-port Ethernet card, PTP is only available on Ethernet **PORT 5A** and **PORT 5B**. For SEL-400 series relays with the five-port Ethernet card, PTP is available on either Ethernet **PORT 5A** and **PORT 5B** or **PORT 5C** and **PORT 5D**. PTPPORT is an analog quantity that can be used to identify the active port. PTPPORT = 1 if **PORT A** is the active port, PTPPORT = 2 if **PORT B** is the active port, PTPPORT = 3 if **PORT C** is the active port, PTPPORT = 4 if **PORT D** is the active port, and PTPPORT = 0 if PTP is not synchronized. See *Precision Time Protocol (PTP) on page 15.18* for more information on configuring the relay and the Ethernet network for PTP.

To achieve basic synchronization to PTP, the master clock sync and announce interval must not exceed four seconds. The Relay Word bit PTP_TIM indicates that this basic level of synchronization has been achieved. If the network is not introducing excessive jitter in the time-synchronized messages, PTP_OK will be set indicating the presence of time synchronization. The analog quantity PTPSTEN can be used to indicate the state of the PTP port as follows: 1 = Initializing, 2 = Faulty, 3 = Disabled, 4 = Listening, 8 = Uncalibrated, 9 = Slave.

PTP Over PRP Networks

SEL-400 series relays support PTP time synchronization over a PRP network. When the relay operates in this network mode, the default, C37.238, and 61850-9-3 PTP profiles are available. When using PTP time synchronization over a PRP network, you must use the LAYER2 option for the PTP transport mechanism setting PTPTR.

The SEL-400 series relays support PTP time synchronization over Parallel Redundancy Protocol (PRP) networks. In a PRP network, a dual attached node (DAN) receives a pair of duplicated packets.

PTP messages that transverse through two distinct networks suffer a different amount of delays. *Figure 11.1* shows that path delays via LAN A and LAN B are different. These delays include link delays and residence time. PTP-capable Ethernet switches in these LANs should update PTP messages with the actual residence time and request/reply to path delay messages. It should not alter PTP messages by appending RCTs. The dual attached slave clock receives two different sets of PTP messages, as shown in *Figure 11.1*. The two ports independently determine its port state.

Figure 11.1 PTP Time Synchronization Over a PRP Network

NOTE: For the five-port Ethernet card, configure the PTHDLY setting to **P2P** to cause the relay to synchronize both the primary and standby ports. This allows the relay to seamlessly maintain PTP synchronization during a failover operation. This does not apply when PTHDLY is set to E2E or when using the two- or four-port Ethernet card.

As shown in *Figure 11.1*, the SEL-400 Series Relay Best Master Clock Algorithm (BMCA) synchronizes to one grandmaster clock on either LAN A or LAN B. The relay synchronizes to the best grandmaster based on the characteristics of the grandmaster and the locally derived offset from the relay to each grandmaster. For applications such as synchrophasors requiring high-accuracy time synchronization, the accuracy of both the grandmaster (TQUAL) and the locally derived offset (PTPOFST) must be better or equal to 1 µs. The SEL-400 series relays use the analog quantity PTPPORT to indicate the port to which the relay is synchronized to the best PTP master (see *Table 11.2*).

Table 11.2 PTPPORT Synchronized to the Best PTP Master

PTPPORT	Ethernet Port
1	5A
2	5B
3	5C
4	5D

The ASCII command **COM PTP 5*n*** displays PTP statistics for the specific interface on **PORT 5**. The ASCII command **COM PTP** also displays the port status in *COM PTP on page 14.15*. If a port is selected to synchronize the relay, the port status is ACTIVE; otherwise, it is PASSIVE.

Time Source Selection

IRIG-B via BNC connection, IRIG-B via serial PORT 1, and PTP can all be connected to the relay. Each of these can provide a high-quality time value. The relay selects between these sources by using the following priority scheme:

1. BNC IRIG if BNC_OK and BNC time quality ≤ 1 µs
2. Serial IRIG if SER_OK and serial time quality ≤ 1 µs
3. PTP if PTP_OK and PTP time quality ≤ 1 µs
4. BNC IRIG if BNC_OK
5. Serial IRIG if SER_OK
6. PTP if PTP_OK

The **TIME** command indicates what source is being used. This is also available in the analog quantity CUR_SRC as shown in *Table 11.3*.

Table 11.3 CUR_SRC Encoding

Source	CUR_SRC value
BNC IRIG-B	1
Serial Port IRIG-B	2
PTP	4
None of the above	8

If IRIG-B and PTP are not available, then the time can be set via any low-priority time source: SNTP, DNP3, **TIME** and **DATE** commands, front-panel set date/time, and extended MIRRORED BITS.

Time Quality Indications

Analog Quantities and Relay Word Bits

You can check the status of timekeeping by checking the relevant analog quantities or Relay Word bits. Once a time source is connected, wait at least 20 seconds to allow for a solid synchronization to take place.

If you are using a time source that provides time-quality information (IRIG-B with C37.118 or PTP), then the presently reported time quality is available via the TQUAL analog quantity and the TQUAL1, TQUAL2, TQUAL4, and TQUAL8 Relay Word bits. *Table 11.4* and *Table 11.5* show how these are encoded for IRIG and the three supported PTP Profiles.

Table 11.4 Time Quality Encoding (IRIG) (Sheet 1 of 2)

IRIG					
Master Clock Accuracy (ns)	TQUAL8	TQUAL4	TQUAL2	TQUAL1	TQUAL (seconds)
Clock failure, time not reliable	1	1	1	1	Unknown[a]
10 seconds	1	0	1	1	10
1 second	1	0	1	0	1
100 milliseconds	1	0	0	1	0.1
10 milliseconds	1	0	0	0	0.01

Table 11.4 Time Quality Encoding (IRIG) (Sheet 2 of 2)

IRIG					
1 millisecond	0	1	1	1	0.001
100 microseconds	0	1	1	0	0.0001
10 microseconds	0	1	0	1	0.00001
1 microsecond	0	1	0	0	0.000001
100 nanoseconds	0	0	1	1	0.0000001
10 nanoseconds	0	0	1	0	0.00000001
1 nanosecond	0	0	0	1	0.000000001

[a] The relay reports the 32-bit float limit (i.e., 3.40282347E+38).

Table 11.5 Time Quality Encoding (PTP)

PTP Profile (PTPPRO = DEFAULT, C37.238, 61850-9-3)					
Time_inaccuracy = Grandmaster timeinaccuracy + Network timeinaccuracy (ns)[a]	TQUAL8	TQUAL4	TQUAL2	TQUAL1	TQUAL (seconds)
Grandmaster timeinaccuracy ≥ 4294967295 or Network timeinaccuracy ≥ 4294967295[a]	1	1	1	1	Grandmaster timeinaccuracy + Network timeinaccuracy[a]
1,000,000,000 ≤ time_inaccuracy < 10,000,000,000	1	0	1	1	
100,000,000 ≤ time_inaccuracy < 1,000,000,000	1	0	1	0	
10,000,000 ≤ time_inaccuracy < 100,000,000	1	0	0	1	
1,000,000 ≤ time_inaccuracy < 10,000,000	1	0	0	0	
100,000 ≤ time_inaccuracy < 1,000,000	0	1	1	1	
10,000 ≤ time_inaccuracy < 100,000	0	1	1	0	
1,000 ≤ time_inaccuracy < 10,000	0	1	0	1	
100 ≤ time_inaccuracy < 1,000	0	1	0	0	
10 ≤ time_inaccuracy < 100	0	0	1	1	
1 ≤ time_inaccuracy < 10[a]	0	0	1	0	
time_inaccuracy = 0[a]	0	0	0	0	

[a] This only applies to C37.238.

PTP supports Default profile, C37.238 Power Profile, and IEC/IEEE 61850-9-3 Power Utility Automation Profile, which is set by the PORT 5 setting PTPPRO. PTP reports the time quality through TQUAL1, TQUAL2, TQUAL4, and TQUAL8 Relay Word bits, which are the same bits used if IRIG-B is the time source. If PTPPRO = DEFAULT or 61850-9-3, the time quality is reported based only on the accuracy of the master clock. If PTPPRO = C37.238, the time quality is reported based on the accuracy of the master clock (Grandmaster timeinaccuracy) plus the inaccuracy of the network (Network timeinaccuracy). For this profile, if either Grandmaster timeinaccuracy or Network time-inaccuracy is the maximum value, the relay will set all TQUAL bits to 1.

If the relay is synchronized to an IRIG-B or PTP time source, the TSYNC bit will be set. If the quality of this synchronization is 1 µs or better, then TSOK is set, indicating this bit has sufficient accuracy for synchrophasors. TGLOBAL will assert if a high-accuracy source is being used and the source indicates it is providing 1 µs or better accuracy, and the Global setting IRIGC = C37.118 for BNC IRIG applications. Refer to *Figure 11.3* for TLOCAL qualifying criteria.

As an example of checking IRIG status, use the command **TAR TIRIG** to view the relevant Relay Word bits, as shown in *Figure 11.2*. Only the state of the TIRIG and TSOK Relay Word bits are discussed in the troubleshooting steps below. The other Relay Word bits of interest to this discussion are TUPDH, which indicates that the relay internal clock is presently being updated by the HIRIG source, TSYNCA, which acts as an alarm bit that asserts when the relay is not synchronized to either an internal or an external source. TSYNCA will only assert briefly when the HIRIG time source is connected or disconnected.

```
=>TAR TIRIG <Enter>

*       *       TIRIG   TUPDH   TSYNCA  TSOK    PMDOK   FREQOK
0       0       1       1       0       1       1       0
=>
```

Figure 11.2 Confirming the High-Accuracy Timekeeping Relay Word Bits

The TIRIG and TSOK Relay Word bits should be asserted (logical 1), indicating that the relay is in the high-accuracy IRIG timekeeping mode (HIRIG).

If TSOK is not asserted, but TIRIG is asserted, the relay is in regular IRIG time-keeping mode. Following is a list of possible reasons for not entering HIRIG mode:

- The IRIG-B clock does not use the IEEE C37.118 control bit assignments, or the IRIG-B signal is not of sufficient accuracy.
- The termination resistor, required by some IRIG clocks, is not installed.
- The time-source clock is reporting that its time error is greater than 1 µs.

If neither TSOK nor TIRIG is asserted, the relay is not in an IRIG time-source mode. Following is a list of possible reasons for not entering IRIG mode:

- The IRIG-B clock signal is improperly configured.
- The termination resistor, required by some IRIG clocks, is not installed.

NOTE: At startup, TPTP can assert as fast as 1.5 seconds after PTP_TIM asserts.

TBNC asserts when BNC IRIG is used to update the relay master time. Likewise, TSER asserts when serial IRIG is selected and TPTP asserts when PTP is the active source updating the relay master time. At any given time, only one of these three bits can equal logical 1.

Global Time Source vs Local Time Source

An SEL-400 series relay indicates that it is synchronized with either a global or local time source according to the logic as shown in *Figure 11.3*. When CUR_SRC is IRIG or PTP and TSYNC is asserted, the relay determines the status of TGLOBAL or TLOCAL following the logic diagram in *Figure 11.3*.

Figure 11.3 TLOCAL and TGLOBAL Logic

The relay can maintain a 1 µs time accuracy for at least 8 seconds after the loss of time synchronization.

TIME Q Command

The **TIM Q** command provides details about relay timekeeping (see *Table 11.4* and *Table 11.5*). The internal clock of the relay is initially calibrated at the SEL factory. An external IRIG or PTP source is required to eliminate clock drift. The `Time Source` field provides the present high-accuracy timing input source; entries for this line are HIRIG, IRIG, HPTP, PTP, or OTHER. The `Last Update Source` reports the source from which the relay referenced the last time value measurement. Entries for this line can be high-priority or low-priority sources. *Table 11.6* lists the possible `Last Update Source` values for the relay.

```
=>>TIM Q <Enter>

Relay 1                                    Date: 03/17/2023 Time: 15:08:41.468
Station A                                  Serial Number: 1230769999

Time Source: HPTP
Last Update Source: HPTP
Grandmaster Clock Quality
    Clock Class : Synchronized with PTP timescale (6)
    Time Traceable : TRUE
    Clock Accuracy : Within 25 ns
    Offset Log Variance : 0

Time Mark Period:  1000.000061 ms

Internal Clock Period:  19.999935 ns

=>>
```

Figure 11.4 Sample TIM Q Command Response

Table 11.6 Date/Time Last Update Sources

Time Input Source Mode	Priority	Time Source
HIRIG	High	Time/date from the high-accuracy IRIG-B input
SNTP	Low	Simple Network Time Protocol
IRIG	High	Time/date from the IRIG-B format time base signal
HPTP	High	Time/date from a high-accuracy PTP source
PTP	High	Time/date from a PTP source
DNP	Low	Time/date from the DNP3 communications port
MIRRORED BITS	Low	Time/date from the Mirrored Bit port
SNTP	Low	Time/date from SNTP server
ASCII TIME	Low	Time from the relay serial ports
ASCII DATE	Low	Date from the relay serial ports
NONV CLK	Low	Time/date from the nonvolatile memory clock
FRONT PANEL TIME	Low	Time from the front-panel TIME entry screen
FRONT PANEL DATE	Low	Time from the front-panel DATE entry screen

The `Time Mark Period` value indicates the instantaneous period in which the relay measures the time-source inputs. The relay displays the time mark periods showing the present time precision derived from the applied time-source signals.

The **TIME Q** command is also helpful for troubleshooting IRIG and PTP problems. If the `Time Mark Period` value changes significantly between successive **TIME Q** commands, there may be too much noise in the time signal for the relay timekeeping function.

Adaptive Internal Clock Period Adjustment

The Internal Clock Period, as shown in the **TIME Q** command response in *Figure 11.4*, is the internal relay timekeeping period. The relay adjusts this master internal clock when you apply HIRIG or HPTP mode timekeeping, adapting the internal relay clock for your installation temperature conditions. If you lose the timing lock, the relay internal clock operates at this precisely adapted clock period until HIRIG or HPTP mode is restored. Time tags for event reports during a loss of high-accuracy timekeeping remain very accurate. Lower-accuracy time sources do not adaptively adjust the internal relay clock period.

COM PTP Command

The **COM PTP** command provides a report of the PTP data sets maintained by the device as well as statistics for the measured time offsets with the parent (master) clock. The PTP data sets contain information about the state, identity, and configuration of the local, parent, and grandmaster clocks in addition to properties of the time being distributed by the grandmaster clock. See *COM PTP on page 14.15* for more information on this command.

Daylight-Saving Time (DST)

The status of DST time can be determined by one of three possible high-priority sources (BNC, SER, or PTP). The daylight-saving time pending Relay Word bit (DSTP) is valid only when IRIG is the active source. When PTP is selected, it sets the DSTP bit to zero at all times. If no high-priority source with daylight-saving time information is available, the DST bit is determined based on the BEG_DST and END_DST Global settings.

When using PTP as the Time Synchronization source, the PTP master may not provide valid DST information as the relay powers up. To ensure the relay powers up with the correct time when synced to a PTP source, you must ensure that the relay Time and Date Management settings and the PTP master configuration are in agreement.

Time-Synchronized Events

Time-Synchronized Triggers

You can program the relay to perform data captures at *specific* times. Relays that are time-locked by using HIRIG mode provide high-accuracy time-synchronized data captures. When you use this method on multiple relays, the actual trigger times can differ by as much as 5 ms, but the information in the binary COMTRADE file outputs from each relay is time-stamped at very high accuracy. Do not assume that the relay triggers are locked with high accuracy; rather, compare corresponding time-stamped data points from each COMTRADE file.

Time Triggering the Relay

NOTE: The **MET PM time** command can be used to capture synchrophasor data at a specific time if synchrophasors are enabled with Global setting EPMU := Y.

Perform the following steps to trigger an event data capture in the relay at a specific time. These settings cause the relay to initiate a data capture at 12:00:30 p.m. Use other SELOGIC control equations in a similar manner to trigger relay event recordings.

Step 1. Start SEL Grid Configurator and establish communications with the relay.

Step 2. Select **Read** to read the present configuration in the relay.

The relay sends all configuration and settings data to SEL Grid Configurator.

Step 3. Select the **Settings Grid > Protection > Protection Logic**. Leave the Protection Group dropdown menu set at 1.

Step 4. Enter time trigger settings:

a. Select in the first available line of protection logic.

b. In the Edit Pane for the line, enter or search for **PMV64**, then enter := to continue building the equation.

c. On the right side of the equation, search for and select **THR** (which is the Time in Hours analog quantity) or enter **THR** after the equation equal sign.

d. Double-click **THR** (Time in Hours).

e. Use the **#** character to add a comment to the line.

Figure 11.5 Setting PMV64 With the Expression Builder Dialog Box

NOTE: In this example, the event report trigger will occur between 12:30:00.002 and 12:30:00.005 because of the method of relay protection logic processing.

Step 5. In a similar manner, build a freeform SELOGIC control equation program in **Protection Logic** that causes protection freeform SELOGIC control equation variable PSV02 to assert to logical 1 at 12:00:30.005 p.m. Use the following expressions:

PMV64 := THR # Clock hours

PMV63 := TMIN # Clock minutes

PMV62 := TSEC # Clock seconds

PSV02 := (PMV64=12) AND (PMV63=00) AND (PMV62=30) # Set PSV02 at 12:00:30

NOTE: You should be careful to remove this event report trigger once you have completed your testing. Otherwise, the relay will continue to trigger new events every day at the programmed time.

Step 6. Navigate to the **ER** setting in your Settings Grid view under Group 1 settings.

Step 7. Select in the **ER Event Report Trigger Equation** (SELOGIC) text box and add **OR R_TRIG PSV02** to the end of elements already in this SELOGIC control equation.

COMTRADE File Information

Retrieve the COMTRADE files for the time-triggered data captures from each relay with the **FILE READ** command.

Parse the binary COMTRADE data for the power system currents and voltages you need to calculate system quantities.

Fault Analysis

Use the relay measurement and communications capabilities to obtain precise simultaneous measurements from the power system at different locations. Combining system measurements from a number of key substations gives you a snapshot picture of the phasor relationships in the power system at a particular time. You can perform extensive fault analysis by evaluating the simultaneous measurements gathered at a central computer or data server.

Install at least two relays in the power system to implement dynamic phasor determination. *Figure 11.6* shows an example of a 230 kV overhead transmission line with a relay at each terminal. Connect GPS clocks (such as the SEL-2407) at each substation to provide high-accuracy time-signal inputs for each relay.

Figure 11.6 230 kV Transmission Line System

With synchronized and time-stamped binary COMTRADE data, you can develop automated computer algorithms for comparing these data from different locations in the power system.

In particular, you can use fault data extracted from two relays. Use third-party software to filter the binary COMTRADE data so that the signals are composed of fundamental quantities only (50 Hz or 60 Hz). You can also use third-party software to convert the binary COMTRADE data to ASCII COMTRADE files. Use the Phasor Diagram in the SEL-5601-2 SYNCHROWAVE Event Software to select the appropriate pre-fault and post-fault quantities.

Power Flow Analysis

Use SEL-400 series relays to develop instantaneous power flow data. Obtain the voltage and current phasors from different power system buses at the same instant and use these measurements to determine power flow at that instant. Use

the synchronized phasor measurement capabilities of the relay and the **METER PM** command or a Synchrophasor Protocol to collect synchronized voltage and current data. Use this information to confirm your power flow models.

For example, consider four SEL-421 Relays installed in the power system as shown in *Figure 11.7*. Substations S and R provide generation for the load at Substation T.

Figure 11.7 500 kV Three-Bus Power System

Table 11.7 lists the voltage and current measured by the four SEL-421 Relays at one particular time.

Table 11.7 SEL-421 Voltage and Current Measurement

Voltage		Current	
SEL-421 at Substation S			
V_{AS}	288.675 kV ∠0°	I_{AS}	238.995 A ∠41.9°
V_{BS}	288.675 kV ∠240°	I_{BS}	238.995 A ∠–78.1°
V_{CS}	288.675 kV ∠120°	I_{CS}	238.995 A ∠161.9°
SEL-421 at Substation R			
V_{AR}	303.109 kV ∠–0.2°	I_{AR}	234.036 A ∠–44.2°
V_{BR}	303.109 kV ∠239.8°	I_{BR}	234.036 A ∠195.8°
V_{CR}	303.109 kV ∠119.8°	I_{CR}	234.036 A ∠75.8°
SEL-421 at Substation T Looking Toward Substation S			
$V_{AT–S}$	295.603 kV ∠–1.6°	$I_{AT–S}$	238.995 A ∠–138.1°
$V_{BT–S}$	295.603 kV ∠238.4°	$I_{BT–S}$	238.995 A ∠101.9°
$V_{CT–S}$	295.603 kV ∠118.4°	$I_{CT–S}$	238.995 A ∠–18.1°
SEL-421 at Substation T Looking Toward Substation R			
$V_{AT–R}$	295.603 kV ∠–1.6°	$I_{AT–R}$	234.036 A ∠135.8°
$V_{BT–R}$	295.603 kV ∠238.4°	$I_{BT–R}$	234.036 A ∠15.8°
$V_{CT–R}$	295.603 kV ∠118.4°	$I_{CT–R}$	234.036 A ∠–104.2°

Use *Equation 11.1* to calculate the generation supplied from Substation S and Substation R, plus the load at Substation T.

$$S_{3\phi} = P_{3\phi} + jQ_{3\phi}$$
$$= \sqrt{3} \bullet V_{pp} \bullet I^*_L$$
$$= 3 \bullet V_p \bullet I^*_L$$

Equation 11.1

where:

$S_{3\phi}$ = Three-phase complex power (MVA)
$P_{3\phi}$ = Three-phase real power (MW)
$Q_{3\phi}$ = Three-phase imaginary power (MVAR)
V_{pp} = Phase-to-phase voltage
V_p = Phase-to-neutral voltage
I^*_L = Complex conjugate of the line current

The complex power generation supplied by Substation S is:

$$S_S = (3 \bullet 288.675\ \text{kV}\angle 0°) \bullet (238.995\ \text{A}\angle -41.9°)$$
$$= 154.1\ \text{MW} - j138.2\ \text{MVAR}$$

The complex power generation supplied by Substation R is:

$$S_R = (3 \bullet 303.109\ \text{kV}\angle -0.2°) \bullet (234.036\ \text{A}\angle 44.2°)$$
$$= 152.6\ \text{MW} + j148.3\ \text{MVAR}$$

The load at Substation T supplied by Substation S is:

$$S_{T-S} = (3 \bullet 295.603\ \text{kV}\angle -1.6°) \bullet (238.995\ \text{A}\angle 138.1°)$$
$$= -153.7\ \text{MW} + j145.9\ \text{MVAR}$$

The load at Substation T supplied by Substation R is:

$$S_{T-R} = (3 \bullet 295.603\ \text{kV}\angle -1.6°) \bullet (234.036\ \text{A}\angle -135.8°)$$
$$= -152.8\ \text{MW} - j140.5\ \text{MVAR}$$

The total load at Substation T is:

$$S_T = S_{T-S} + S_{T-R}$$
$$= -306.5\ \text{MW} + j5.4\ \text{MVAR}$$

Figure 11.8 Power Flow Solution

Use the power flow solution to verify the instantaneous positive-sequence impedances of your system transmission lines.

State Estimation Verification

Electric utility control centers have used state estimation to monitor the state of the power system for the past 20 years. The state estimator calculates the state of the power system by using measurements such as complex power, voltage magnitudes, and current magnitudes received from different substations. State estimation uses an iterative, nonlinear estimation technique. The state of the power system is the set of all positive-sequence voltage phasors in the network. Typically, several seconds or minutes elapse from the time of the first measurement to the time of the first estimation. Therefore, state estimation is a steady-state representation of the power system.

Consider using precise simultaneous positive-sequence voltage measurements from the power system to verify your state estimation model. Take time-synchronized high-resolution positive-sequence voltage measurements at all substations. Send the relay synchrophasor messages to a central database to determine the power system state.

Power system contingency analysis models rely on state-estimation techniques, and may have inaccuracies caused by incorrect present-state information, or errors in system characteristics, such as incorrect line and source impedance estimates. The simultaneous event-report triggering technique described earlier in this section can be used to verify present models.

NOTE: Not all SEL-400 series relays support synchrophasors.

With SEL-400 series relays acting as phasor measurement units (PMUs) installed in several substations, synchrophasor measurements can be transmitted to a central processor in near-real time, providing very accurate snapshots of the power system. This type of data processing system provides system-state measurements that are a few seconds old, rather than state estimates that may be several minutes old. In addition, the synchrophasor results are real measurements, rather than estimates.

See *Section 18: Synchrophasors* for information on the PMU settings and the communications protocols available for synchrophasor data collection.

SECTION 12

Settings

This section contains tables of relay settings that are common to most SEL-400 series relays. See the product-specific instruction manuals for details of all settings available in the relay.

The relay hides some settings based upon other settings. If you set an enable setting to OFF, for example, the relay hides all settings associated with that enable setting. This section does not explain rules for hiding settings; these rules are discussed in *Section 6: Protection Application Examples* in the product-specific instruction manuals, where appropriate.

⚠WARNING
Isolate the relay trip circuits while changing settings. When changing settings for multiple classes, it is possible to be in an intermediate state that will cause an unexpected trip.

The settings prompts in this section are similar to the ASCII terminal and SEL Grid Configurator software prompts. The prompts in this section are unabbreviated and show all possible setting options.

This section describes how settings are organized, explains the concept of settings groups, and then describes some common relay settings:

- *Settings Structure on page 12.1*
- *Multiple Setting Groups on page 12.4*
- *Port Settings on page 12.6*
- *DNP3 Settings—Custom Maps on page 12.19*
- *Front-Panel Settings on page 12.20*
- *Alias Settings on page 12.25*
- *Protection Freeform SELOGIC Control Equations on page 12.26*
- *Automation Freeform SELOGIC Control Equations on page 12.26*
- *Output Settings on page 12.26*
- *Report Settings on page 12.28*
- *Notes Settings on page 12.29*

Settings Structure

The settings structure assigns each relay setting to a specific location based on the setting type. A top-down organization allocates relay settings into these layers:

- Class
- Instance
- Category
- Setting

Examine *Figure 12.1* to understand the settings structure in a typical SEL-400 series relay. The top layer of the settings structure contains classes and instances. Class is the primary sort level; all classes have at least one instance, and some classes have multiple instances. Typical settings classes and related instances are listed in *Table 12.1*.

Figure 12.1 Typical Relay Settings Structure Overview

Table 12.1 Typical Settings Classes and Instances (Sheet 1 of 2)

Class	Description	Instance	Description	ASCII Command	Access Level
Global	Relay-wide applications settings	Global	Global settings	SET G	P, A, O, 2
Group	Individual scheme settings	Group 1 • • • Group 6	Group 1 settings • • • Group 6 settings	SET 1, SET S 1 • • • SET 6, SET S 6	P, 2
Breaker Monitor	Circuit breaker monitoring settings	Breaker Monitor		SET M	P, 2
Bay Control	Bay Control Settings	Bay Control		SET B 1	P, A, O, 2

Table 12.1 Typical Settings Classes and Instances (Sheet 2 of 2)

Class	Description	Instance	Description	ASCII Command	Access Level
Port	Communications port settings	PORT F PORT 1 • • • PORT 3 PORT 5 PORT 6 (TiDL [T-Protocol] relays only)	Front-panel port PORT 1 settings • • • PORT 3 settings Ethernet card settings TiDL topology settings (TiDL [T-Protocol] relays only)	SET P F SET P 1 • • • SET P 3 SET P 5 (Only available via SEL Grid Configurator)	P, A, O, 2
Report	Event report and SER settings	Report		SET R	P, A, O, 2
Front Panel	Front-panel HMI settings	Front Panel		SET F	P, A, O, 2
Protection	Protection-related SELOGIC control equations	Protection 1 • • • Protection 6	Group 1 protection SELOGIC control equations • • • Group 6 protection SELOGIC control equations	SET L 1 • • • SET L 6	P, 2
Automation	Automation-related SELOGIC control equations	Automation 1 • • • Automation 10	Block 1 automation SELOGIC control equations • • • Block 10 automation SELOGIC control equations	SET A 1 • • • SET A 10	A, 2
DNP	Distributed Network Protocol data remapping	DNP 1 • • • DNP 5		SET D 1 • • • SET D 5	P, A, O, 2
Output	Relay control output settings and MIRRORED BITS communications transmit equations	Output		SET O	O, 2
Alias	Alias settings	Alias		SET T	P, A, O, 2
Notes	Freeform programming to include notes	Notes	100 lines	SET N	P, A, O, 2

Note that some settings classes have only one instance and you do not specify the instance designator when accessing these classes. An example is the Global settings class. You can view or modify Global settings with a communications terminal by entering **SET G** as shown in the ASCII Command column of *Table 12.1*. The relay presents the Global settings categories at the **SET G** command; no instance numbers follow **SET G**. Conversely, the Port settings command has five instances (PORT F, PORT 1, PORT 2, PORT 3, and PORT 5). To access the PORT 1 settings, type **SET P 1 <Enter>**. If you do not specify which port to set, the relay defaults to the active port (the port you are presently using).

The Group settings can have the optional one-letter acronym S attached to the command; you can enter SET 1 or SET S 1 for Group 1 settings, SET 2 or SET S 2 for Group 2 settings, etc. If you do not specify which group to set, the

relay defaults to the present active group. If Group 6 is the active group, and you type **SET <Enter>**, for example, you will see the settings prompts for the Group 6 settings.

Multiple Setting Groups

The SEL-400 series relays have six independent setting groups. Each setting group has complete relay settings and protection SELOGIC settings. The active setting group can be:

- Shown or selected with the SEL ASCII serial port **GROUP** command—see *GROUP on page 14.41*.
- Shown or selected from the front-panel LCD with the `MAIN` menu `Set/Show` menu item and the `Active Group` submenu item as described in *Figure 4.32*.
- Selected with SELOGIC control equation settings SS1 through SS6. Settings SS1 through SS6 have priority over all other selection methods. Use remote bits in these equations to select setting groups with Fast Operate commands as described in *SEL Fast Meter, Fast Operate, Fast SER Messages, and Fast Message Data Access on page 15.34*.
- Shown with DNP3 Objects 20 and 22 and selected with Objects 40 and 41.

Setting Groups: Application Ideas

Setting groups can be used for such applications as:

- Environmental conditions such as winter storms, periods of high summer heat, etc.
- Hot-line tag that disables closing and sensitizes protection
- Commissioning and operation

Active Setting Group Indication

Only one setting group can be active at a time. Relay Word bits SG1 through SG6 indicate the active setting group, as shown in *Table 12.2*.

Table 12.2 Definitions for Active Setting Group Indication Relay Word Bits SG1 Through SG6

Relay Word Bit	Definition
CHSG	Indication that a group switch timer is operating or a group switch change is underway
SG1	Indication that setting Group 1 is the active setting group
SG2	Indication that setting Group 2 is the active setting group
SG3	Indication that setting Group 3 is the active setting group
SG4	Indication that setting Group 4 is the active setting group
SG5	Indication that setting Group 5 is the active setting group
SG6	Indication that setting Group 6 is the active setting group

For example, if setting Group 4 is the active setting group, Relay Word bit SG4 asserts to logical 1, and the other Relay Word bits SG1, SG2, SG3, SG5, and SG6 are all deasserted to logical 0.

Active Setting Group Selection

The Global settings class contains the SELOGIC control equation settings SS1 through SS6, as shown in *Table 12.3*.

NOTE: The settings group switching settings are checked once per cycle. When setting TGR := 0, in order for a transient assertion to be recognized, it should be conditioned to remain asserted for at least 1 cycle.

Table 12.3 Definitions for Active Setting Group Switching SELOGIC Control Equation Settings SS1 Through SS6

Setting	Definition
SS1	Go to (or remain in) setting Group 1
SS2	Go to (or remain in) setting Group 2
SS3	Go to (or remain in) setting Group 3
SS4	Go to (or remain in) setting Group 4
SS5	Go to (or remain in) setting Group 5
SS6	Go to (or remain in) setting Group 6

The operation of these settings is explained with the following example.

Assume the active setting group starts out as setting Group 3. Corresponding Relay Word bit SG3 is asserted to logical 1 as an indication that setting Group 3 is the active setting group.

With setting Group 3 as the active setting group, setting SS3 has priority. If setting SS3 is asserted to logical 1, setting Group 3 remains the active setting group, regardless of the activity of settings SS1, SS2, SS4, SS5, and SS6. With settings SS1 through SS6 all deasserted to logical 0, setting Group 3 still remains the active setting group.

With setting Group 3 as the active setting group, if setting SS3 is deasserted to logical 0 and one of the other settings (e.g., setting SS5) asserts to logical 1, the relay switches from setting Group 3 as the active setting group to another setting group (e.g., setting Group 5) as the active setting group, after qualifying time setting TGR (Global settings):

TGR	Group Change Delay Setting	(settable from 0 to 54000 cycles)

NOTE: The CHSG Relay Word bit does not operate for settings changes initiated by the serial port or front panel methods.

In this example, TGR qualifies the assertion of setting SS5 before it can change the active setting group. Relay Word bit CHSG asserts when the TGR timer is picked up and timing, and also when a setting group change has been initiated.

Active Setting Group Changes

NOTE: The SEL-487E and SEL-487B support 96 remote bits and all 96 are retained.

NOTE: The SEL-487E supports 96 local bits and all 96 are retained.

The relay is disabled for less than one second while in the process of changing active setting groups. Relay elements, timers, and logic are reset, unless indicated otherwise in the specific logic description. For example, local bit (LB01 through LB64), remote bit (RB01 through RB64), and latch bit (PLT01 through PLT32) states are retained during an active setting group change. The output contacts do not change state until the relay enables in the new settings group and the SELOGIC control equations are processed to determine the output contact status for the new group.

After a group change, an automatic message will be sent to any serial port that has setting AUTO := Y (see *Table 12.7*).

Active Setting: Nonvolatile State

Power Loss

The active setting group is retained if power to the relay is lost and then restored. If a particular setting group is active (e.g., setting Group 5) when power is lost, the same setting group is active when power is restored.

Settings Change

If individual settings are changed for the active setting group or one of the other setting groups, the active setting group is retained, much like in the preceding explanation.

If individual settings are changed for a setting group other than the active setting group, there is no interruption of the active setting group, so the relay is not momentarily disabled.

If the individual settings change causes a change in one or more SELOGIC control equation settings SS1 through SS6, the active setting group can be changed, subject to the newly enabled SS1 through SS6 settings.

Port Settings

Table 12.4 Port Settings Categories (Sheet 1 of 2)

Settings	Reference
Serial Settings	
Protocol Section (Serial)	*Table 12.5*
Communications Settings	*Table 12.6*
SEL Protocol Settings	*Table 12.7*
Fast Message Read Data Access	*Table 12.8*
DNP Configuration (Serial)	*Table 12.9*
MIRRORED BITS Protocol Settings	*Table 12.10*
RTD Protocol Settings	*Table 12.11*
PMU Protocol Settings	*Table 12.12*
Ethernet Settings (Two- or Four-Port Ethernet Card)	
Protocol Selection (Ethernet)	*Table 12.13*
SEL Protocol Settings	*Table 12.7*
Fast Message Read Data Access	*Table 12.8*
IP Configuration	*Table 12.14*
FTP Configuration	*Table 12.15*
HTTP Server Configuration	*Table 12.16*
Telnet Configuration	*Table 12.17*
IEC 61850 Configuration	*Table 12.18*
IEC 61850 Mode/Behavior Configuration	*Table 12.19*

Table 12.4 Port Settings Categories (Sheet 2 of 2)

Settings	Reference
SV Transmit Configuration	*Table 12.20*
SV Receive Configuration	*Table 12.21*
IEC SV Channel Settings	*Table 12.22*
DNP Configuration (Ethernet)	*Table 12.23*
Phasor Measurement Configuration	*Table 12.24*
SNTP Selection	*Table 12.25*
PTP Settings	*Table 12.26*
Ethernet Settings (Five-Port Ethernet Card)	
Protocol Selection (Five-Port Ethernet Card)	*Table 12.27*
SEL Protocol Settings	*Table 12.7*
Fast Message Read Data Access	*Table 12.8*
IP/Network Configuration	*Table 12.28*
FTP Configuration (Five-Port Ethernet Card)	*Table 12.29*
HTTP Server Configuration (Five-Port Ethernet Card)	*Table 12.30*
Telnet Configuration (Five-Port Ethernet Card)	*Table 12.31*
IEC 61850 Configuration	*Table 12.18*
IEC 61850 Mode/Behavior Configuration	*Table 12.19*
SV Transmit Configuration	*Table 12.20*
SV Receive Configuration	*Table 12.21*
IEC SV Channel Settings	*Table 12.22*
DNP Configuration	*Table 12.23*
Phasor Measurement Configuration (Five-Port Ethernet Card)	*Table 12.32*
SNTP Selection	*Table 12.25*
PTP Settings (Five-Port Ethernet Card)	*Table 12.33*
TiDL Settings	
TiDL Channel Map (Port 6)	See *TiDL (T-Protocol) on page 19.1*

NOTE: SV configuration settings are only available in SV relays.

NOTE: TiDL Channel Map is only available in SEL Grid Configurator and only for TiDL (T-Protocol) relays.

Serial Settings

Table 12.5 Protocol Selection (Serial)

Setting	Prompt	Default
EPORT[a]	Enable Port (Y, N)	Y
EPAC	Enable Port Access Control (Y, N)	N
MAXACC	Maximum Access Level (1, B, P, A, O, 2, C)	C
PROTO	Protocol (SEL, DNP, MBA, MBB, MBGA, MBGB, RTD, PMU)	SEL

[a] Setting EPORT to N on PORT 1 has no effect on the operation of IRIG-B on PORT 1.

Table 12.6 settings are available for serial ports if the preceding setting PROTO ≠ RTD.

Table 12.6 Communications Settings

Setting	Prompt	Default
MBT[a]	Using Pulsar 9600 modem? (Y, N)	N
SPEED[b]	Data Speed (300, 600, 1200, 2400, 4800, 9600, 19200, 38400, 57600, SYNC[c])	9600
DATABIT[d]	Data Bits (7, 8 bits)	8
PARITY[c]	Parity (Odd, Even, None)	N
STOPBIT[e]	Stop Bits (1, 2 bits)	1
RTSCTS[f]	Enable Hardware Handshaking (Y, N)	N

[a] Only applicable if PROTO := MBA, MBB, MBGA, or MBGB.
[b] For PROTO := MBA, MBB, MBGA, or MBGB, 57600 is not available.
[c] SYNC option only available for PROTO := MBA, MBB, MBGA, or MBGB on rear-panel serial ports.
[d] For PROTO := SEL only.
[e] For PROTO := SEL, DNP, MBA, MBB, MBGA, MBGB, or PMU only.
[f] For PROTO := SEL or PMU only.

Table 12.7 settings are available if Port setting PROTO := SEL, DNP, or PMU.

Table 12.7 SEL Protocol Settings

Setting	Prompt	Default
TIMEOUT[a]	Port Time-Out (OFF, 1–60 minutes)	5
AUTO[b]	Send Auto-Messages to Port (Y, N)	Y
FASTOP[c]	Enable Fast Operate Messages (Y, N)	N
TERTIM1[d]	Initial Delay-Disconnect Sequence (0–600 seconds)	1
TERSTRN[d]	Termination String-Disconnect Sequence (9 characters maximum)[e]	"\005"
TERTIM2[d]	Final Delay-Disconnect Sequence (0–600 seconds)	0

[a] Hidden for PROTO := PMU. For Ethernet ports, TIMEOUT := TIDLE.
[b] Hidden for PROTO := DNP or PMU.
[c] Hidden for PROTO := DNP.
[d] Hidden for PROTO := PMU.
[e] TERSTRN set at /005 is <Ctrl+E>.

NOTE: Not all of these settings are available in every SEL-400 series relay. Just those that apply to features in the relay are available.

Table 12.8 Fast Message Read Data Access

Setting	Prompt	Default
FMRENAB	Enable Fast Message Read Data Access (Y/N)	Y
FMRLCL	Enable Local Region for Fast Message Access (Y/N)	N
FMRMTR	Enable Meter Region for Fast Message Access (Y/N)	Y
FMRDMND	Enable Demand Region for Fast Message Access (Y/N)	Y
FMRTAR	Enable Target Region for Fast Message Access (Y/N)	Y
FMRHIS	Enable History Region for Fast Message Access (Y/N)	N
FMRBRKR	Enable Breaker Region for Fast Message Access (Y/N)	N
FMRSTAT	Enable Status Region for Fast Message Access (Y/N)	N
FMRANA	Enable Analog Region for Fast Message Access (Y/N)	Y

Table 12.9 settings are available if Port setting PROTO := DNP.

Table 12.9 DNP Configuration (Serial) (Sheet 1 of 2)

Setting	Prompt	Default
DNPADR	DNP Address (0–65519)	0
DNPID	DNP ID for Object 0, Var 246 (20 characters)	"Relay1-DNP"
DNPMAP	DNP Session Map (1–5)	1
ECLASSB	Class for Binary Event Data (OFF, 1–3)	1
ECLASSC	Class for Counter Event Data (OFF, 1–3)	OFF
ECLASSA	Class for Analog Event Data (OFF, 1–3)	2
ECLASSV	Class for Virtual Terminal Data (OFF, 1–3)	OFF
TIMERQ	Time-Set Request Interval (I, M, 1–32767 minutes)	I
DECPLA	Currents Scaling (0–3 decimal places)	1
DECPLV	Voltages Scaling (0–3 decimal places)	1
DECPLM	Misc Data Scaling (0–3 decimal places)	1
STIMEO	Select/Operate Time-Out (0.0–60.0 seconds)	1.0
DRETRY	Data Link Retries (OFF, 1–15)	OFF
DTIMEO	Data Link Time-Out (0.0–30.0 seconds)	1.0
MINDLY	Minimum Delay from DCD to TX (0.00–1.00 seconds)	0.05
MAXDLY	Maximum Delay from DCD to TX (0.00–1.00 seconds)	0.10
PREDLY	Settle Time -RTS On to TX (OFF, 0.00–30.00 seconds)	0.00
PSTDLY	Settle Time -TX to RTS Off (0.00–30.00 seconds)	0.00
DNPCL	Enable Control Operations (Y, N)	N
AIVAR	Default Variation for Analog Inputs (1–6)	2
ANADBA	Analog Reporting Deadband for Currents (0–32767)	100
ANADBV	Analog Reporting Deadband for Voltages (0–32767)	100
ANADBM	Analog Reporting Deadband (0–32767)	100
ETIMEO	Event Message Confirm Time-Out (1–50 seconds)	2
UNSOL	Enable Unsolicited Reporting (Y, N)	N
PUNSOL	Enable Unsolicited Reporting at Power-Up (Y, N)	N
REPADR	DNP Address to Report to (0–65519)	1
NUMEVE	Number of Events to Transmit On (1–200)	10
AGEEVE	Age of Oldest Event to Transmit On (0–99999)	2
URETRY	Unsolicited Message Max Retry Attempts (2–10)	3
UTIMEO	Unsolicited Message Offline Time-Out (OFF, 1–5000 sec)	60
EVEMOD	Event Mode (SINGLE, MULTI)	SINGLE
MODEM	Modem Connected to Port (Y, N)	N
MSTR	Modem Startup String (30 chars max)	"E0X0&D0S0=4"
PH_NUM1	Phone Number for Dial-Out (30 chars max)	""
PH_NUM2	Backup Phone Number for Dial-Out (30 chars max)	""
RETRY1	Retry Attempts for Phone 1 Dial-Out (1–20)	5
RETRY2	Retry Attempts for Phone 2 Dial-Out (1–20)	5

Table 12.9 DNP Configuration (Serial) (Sheet 2 of 2)

Setting	Prompt	Default
MDTIME	Time to Attempt Dial (5–300 seconds)	60
MDRET	Time Between Dial-Out Attempts (5–3600 seconds)	120

Table 12.10 settings are available if Port setting PROTO := MBA, MBB, MBGA, or MBGB.

Table 12.10 MIRRORED BITS Protocol Settings (Sheet 1 of 2)

Setting	Prompt	Default
TX_ID	MIRRORED BITS ID of This Device (1–4)	2
RX_ID	MIRRORED BITS ID of Device Receiving From (1–4)	1
RBADPU	Outage Duration to Set RBAD (0–10000 seconds)	10
CBADPU	Channel Unavailability to Set CBAD (1–100000 ppm)	20000
TXMODE	Transmission Mode (N-Normal, P-Paced)	N
MBNUM	Number of MIRRORED BITS Channels (0–8)	8
RMB1FL	RMB1 Channel Fail State (0, 1, P)	P
RMB1PU	RMB1 Pickup Time (1–8 messages)	1
RMB1DO	RMB1 Dropout Time (1–8 messages)	1
RMB2FL	RMB2 Channel Fail State (0, 1, P)	P
RMB2PU	RMB2 Pickup Time (1–8 messages)	1
RMB2DO	RMB2 Dropout Time (1–8 messages)	1
RMB3FL	RMB3 Channel Fail State (0, 1, P)	P
RMB3PU	RMB3 Pickup Time (1–8 messages)	1
RMB3DO	RMB3 Dropout Time (1–8 messages)	1
RMB4FL	RMB4 Channel Fail State (0, 1, P)	P
RMB4PU	RMB4 Pickup Time (1–8 messages)	1
RMB4DO	RMB4 Dropout Time (1–8 messages)	1
RMB5FL	RMB5 Channel Fail State (0, 1, P)	P
RMB5PU	RMB5 Pickup Time (1–8 messages)	1
RMB5DO	RMB5 Dropout Time (1–8 messages)	1
RMB6FL	RMB6 Channel Fail State (0, 1, P)	P
RMB6PU	RMB6 Pickup Time (1–8 messages)	1
RMB6DO	RMB6 Dropout Time (1–8 messages)	1
RMB7FL	RMB7 Channel Fail State (0, 1, P)	P
RMB7PU	RMB7 Pickup Time (1–8 messages)	1
RMB7DO	RMB7 Dropout Time (1–8 messages)	1
RMB8FL	RMB8 Channel Fail State (0, 1, P)	P
RMB8PU	RMB8 Pickup Time (1–8 messages)	1
RMB8DO	RMB8 Dropout Time (1–8 messages)	1
MBTIME	Accept Mirrored Bits Time Synchronization (Y, N)	N
MBNUMAN	Number of Analog Channels (0–7)	0
MBANA1	Selection for Analog Channel 1 (analog label)	[a]
MBANA2	Selection for Analog Channel 2 (analog label)	[a]

Table 12.10 Mirrored Bits Protocol Settings (Sheet 2 of 2)

Setting	Prompt	Default
MBANA3	Selection for Analog Channel 3 (analog label)	[a]
MBANA4	Selection for Analog Channel 4 (analog label)	[a]
MBANA5	Selection for Analog Channel 5 (analog label)	[a]
MBANA6	Selection for Analog Channel 6 (analog label)	[a]
MBANA7	Selection for Analog Channel 7 (analog label)	[a]
MBNUMVT	Number of Virtual Terminal Channels (OFF, 0-7)	OFF

[a] The default of the MBANAn settings is relay-specific. See the product-specific instruction manual to find these defaults.

Table 12.11 settings are available if Port setting PROTO := RTD.

Table 12.11 RTD Protocol Settings

Setting	Prompt	Default
RTDNUM	RTD Number of Inputs (0–12)	12
RTD*n*TY[a]	RTD *n* Type (NA, PT100, NI100, NI120, CU10)[b]	PT100

[a] Where n is the number of RTD inputs enabled in the RTDNUM setting.
[b] NA designates an input that is not connected to an RTD device.

Table 12.12 settings are available if Port setting PROTO := PMU.

Table 12.12 PMU Protocol Settings

Setting	Prompt	Default
PMUMODE	PMU Mode (CLIENTA, CLIENTB, SERVER)	SERVER
RTCID[a]	Remote PMU Hardware ID (1–65534)	1
PMODC[b]	PMU Output Data Configuration (1–5)	1

[a] Setting hidden when PMUMODE := SERVER.
[b] Setting hidden when PMUMODE := CLIENTA or CLIENTB.

Ethernet Settings

Two- or Four-Port Ethernet Card

Table 12.13 Protocol Selection (Ethernet)

Setting	Prompt	Default
EPORT	Enable Port (Y, N)	Y
EPAC[a]	Enable Port Access Control (Y, N)	N
MAXACC[a]	Maximum Access Level (1, B, P, A, O, 2, C)	C
EETHFWU	Enable Ethernet Firmware Upgrade (Y, N)	N

[a] Does not apply to TiDL Channel Map (PORT 6).

See *Table 12.7* for SEL protocol settings.

See *Table 12.8* for Fast Message read data access settings.

Table 12.14 IP/Network Configuration

Setting	Prompt	Default
ETCPKA	Enable TCP Keep-Alive (Y, N)	Y
KAIDLE	TCP Keep-Alive Idle Range (1–20 seconds)	10
KAINTV	TCP Keep-Alive Interval Range (1–20 seconds)	1
KACNT	TCP Keep-Alive Count Range (1–20)	6
IPADDR	Device IP Address / CIDR Prefix (w.x.y.z/t)	192.168.1.2/24
DEFRTR	Default router (w.x.y.z)	192.168.1.1
BUSMODE[a]	Bus Operating Mode (INDEPEND, MERGED)	INDEPEND
NETMODE	Operating Mode (FIXED, FAILOVER, SWITCHED, PRP...)	FAILOVER
NETPORT	Primary Network Port (A, B, C, D)[b]	A
PRPTOUT	PRP Entry Time-Out (100–10000 milliseconds)	500
PRPINTV	PRP Supervision TX Interval (1–10 seconds)	2
PRPADDR	PRP Supervision Address LSB (0–255)[c]	0
FTIME	Failover Time-Out (0–65535 milliseconds)	1
NETASPD[d]	Port 5A Speed (Auto, 10, 100)	AUTO
NETBSPD[d]	Port 5B Speed (Auto, 10, 100)	AUTO
NETCSPD[d]	Port 5C Speed (Auto, 10, 100)	AUTO
NETDSPD[d]	Port 5D Speed (Auto, 10, 100)	AUTO

[a] Available on devices with IEC 61850 Sampled Values (SV) publication or subscription capability.
[b] The specific options available depend on the physical ports installed in the hardware.
[c] LSB stands for least significant bit.
[d] This setting applies only if the port is installed and it is a twisted-pair port (10/100BASE-T).

NOTE: SEL advises against enabling anonymous File Transfer Protocol (FTP) logins (FTPANMS = Y) except under test conditions. The Ethernet card does not require a password for the special FTP username "anonymous". If you enable anonymous FTP logins, you are allowing unrestricted access to the SEL-400 series relay and host files.

Table 12.15 FTP Configuration

Setting	Prompt	Default
FTPSERV	Enable FTP Server (Y, N)	N
FTPCBAN	FTP Connect Banner	FTP SERVER:
FTPIDLE	FTP Idle Time-Out (5-255 minutes)	5
FTPANMS	Enable Anonymous FTP Login (Y, N)	N
FTPAUSR	Anonymous User Access Level	0

NOTE: Ethernet setting changes result in a restart of the Ethernet card. This closes active network connections and briefly pauses network operation.

Table 12.16 HTTP Server Configuration

Setting	Prompt	Default
EHTTP	Enable HTTP Server (Y, N)	N
HTTPPOR	HTTP Server TCP/IP Port Number (1–65534)	80
HIDLE	HTTP Session Inactivity Timeout (1–30 minutes)	5

Table 12.17 Telnet Configuration

Setting	Prompt	Default
ETELNET	Enable Telnet (Y, N)	N
TCBAN	Telnet Connect Banner	TERMINAL SERVER:
TPORT	Telnet Port (23, 1025–65534)	23
TIDLE	Telnet Port Time-Out (1–30 minutes)	15

Table 12.18 IEC 61850 Configuration

Setting	Prompt	Default
E61850	Enable IEC 61850 Protocol (Y, N)	N
EGSE[a]	Enable IEC 61850 GSE (Y, N)	N
EMMSFS[a]	Enable MMS File Services (Y, N)	N

[a] Hidden if E61850 := N.

Table 12.19 IEC 61850 Mode/Behavior Configuration

Setting	Prompt	Default
E850MBC	Enable 61850 Mode/Behavior Control (Y, N)	N
EOFFMTX	Enable GOOSE and SV Tx in Off Mode (Y, N)	N

Table 12.20 settings are available in relays that support IEC 61850-9-2 SV publications.

NOTE: SV configuration settings are only available in SV relays.

NOTE: The destination MAC addresses of all published multicast messages (SV, GOOSE) must be unique. Otherwise, messages may be incorrectly routed. The relay issues a diagnostic warning if any SVT destination MAC address (SVTADRp) is the same as a GOOSE destination MAC address.

Table 12.20 SV Transmit Configuration

Setting[a]	Prompt	Default
SVTXEN	Enable SV Transmission (Number of streams 0–7)	0
SVTADR*p*[b]	SVT *p* Destination MAC Address[c]	01-0C-CD-04-00-0p
TAPPID*p*[b]	SV Stream *p* Tx APPID (0x4000–0x7FFF)[d]	0x4000
TSVID*p*[b]	SVID *p* (String of 63 characters a–z, A–Z, _, 0–9)[e]	"4000"
TVLAN*p*[b]	SV *p* Transmit VLAN ID (1–4094)	1
TPRIO*p*[b]	SV *p* Transmit VLAN Priority (0–7)	4
SVT*p*ICH[b]	SVTX*p* Channel Current Terminal (W, X)	W
SVT*p*VCH[b]	SVTX*p* Channel Voltage Terminal (Y, Z)	Y

[a] Available for SV publishers only. Hidden and disabled if E61850 := N.
[b] p represents the publication number. Only settings for publications enabled by SVTXEN will be visible.
[c] Layer 2 multicast address only. Broadcast address is not allowed.
[d] The 0x prefix is used to indicate that this setting is in hexadecimal.
[e] The 9-2LE guideline supports as many as 34 characters in SVID strings. Consider this limit when configuring interoperable SV systems.

Table 12.21 settings are available in relays that support IEC 61850-9-2 SV subscriptions.

NOTE: SV configuration settings are only available in SV relays.

Table 12.21 SV Receive Configuration (Sheet 1 of 2)

Setting[a]	Prompt	Default
SVRXEN	Enable SV Reception (Number of streams 0–7)[b]	0
SVRADR*s*[c]	SV Stream *s* Subscribed MAC Address[d]	01-0C-CD-04-00-0s
RAPPID*s*[c]	SV Stream *s* Rx APPID (0x4000–0x7FFF)[e]	0x4000

Table 12.21 SV Receive Configuration (Sheet 2 of 2)

Setting[a]	Prompt	Default
SVRsICH[c, f]	SVRX*s* Channel Current Terminal (OFF, W, X)	W
SVRsVCH[c, g]	SVRX*s* Channel Voltage Terminal (OFF, Y, Z)	Y

[a] Available for SV subscribers only. Hidden and disabled if E61850 := N.
[b] The SEL-411L, SEL-421, and SEL-451 support 0–4 streams.
[c] s represents the subscription number. Only settings for subscriptions enabled by SVRXEN will be visible.
[d] Layer 2 multicast address only. Broadcast address is not allowed.
[e] The 0x prefix is used to indicate that this setting is in hexadecimal.
[f] The SEL-487E supports current Terminals S, T, U, W, X, and Y with Terminal S serving as default. The SEL-487B supports current Terminals I01–I19 with Terminal I01 serving as default. Each terminal option listed refers to three terminals grouped together. For example, I01 refers to I01–I03, I04 refers to I04–I06, etc.
[g] The SEL-487E supports voltage Terminals V and Z with Terminal V serving as default. The SEL-487B only supports the voltage Terminal V01, which serves as default. The setting V01 includes voltage terminals V01, V02, and V03.

NOTE: SV channel delay settings are only available in SV relays.

Table 12.22 IEC SV Channel Settings

Setting	Prompt	Default
CH_DLY	Sampled Value Channel Delay (1.00–3.00 milliseconds)	1.50

Table 12.23 settings are available if Port setting PROTO := DNP.

Table 12.23 DNP Configuration (Ethernet) (Sheet 1 of 2)

Setting	Prompt	Default
EDNP	Enable DNP Sessions (0–6)	0
DNPADR[a]	DNP Address (0–65519)	0
DNPPNUM[a]	DNP TCP and UDP Port (1025–65534)	20000
DNPID[a]	DNP ID for Object 0, Var 246 (20 characters)	"RELAY1-DNP"
Ethernet DNP3 Master n Configuration, n = 1 to value of EDNP, max 6[a]		
DNPIP*n*	IP Address (w.x.y.z)	192.168.1.[100+*n*]
DNPTR*n*	Transport Protocol (UDP, TCP)	TCP
DNPUDP*n*[b]	UDP Response Port (REQ, 1025–65534)	20000
DNPMAP*n*	DNP Session Map (1–5)	1
CLASSB*n*	Class for Binary Event Data (OFF, 1–3)	1
CLASSC*n*	Class for Counter Event Data (OFF, 1–3)	OFF
CLASSA*n*	Class for Analog Event Data (OFF, 1–3)	2
TIMERQ*n*	Time-Set Request Interval (I, M, 1–32767 minutes)	I
DECPLA*n*	Currents Scaling (0–3 decimal places)	1
DECPLV*n*	Voltages Scaling (0–3 decimal places)	1
DECPLM*n*	Misc Data Scaling (0–3 decimal places)	1
STIMEO*n*	Select/Operate Time-Out (0.0–60.0 seconds)	1.0
DNPINA*n*[c]	Seconds to Send Data Link Heartbeat (0–7200)	120
DNPCL*n*	Enable Control Operations (Y, N)	N
AIVAR*n*	Default Variation for Analog Inputs (1–6)	2
ANADBA*n*[d]	Analog Reporting Deadband for Currents (0–32767)	100
ANADBV*n*[d]	Analog Reporting Deadband for Voltages (0–32767)	100
ANADBM*n*[d]	Analog Reporting Deadband (0–32767)	100

Table 12.23 DNP Configuration (Ethernet) (Sheet 2 of 2)

Setting	Prompt	Default
ETIMEO*n*	Event Message Confirm Time-Out (1–50 seconds)	2
UNSOL*n*[e]	Enable Unsolicited Reporting (Y, N)	N
PUNSOL*n*[f]	Enable Unsolicited Reporting at Power-Up (Y, N)	N
REPADR*n*[f]	DNP Address to Report to (0–65519)	1
NUMEVE*n*[f]	Number of Events to Transmit On (1–200)	10
AGEEVE*n*[f]	Age of Oldest Event to Transmit On (0–99999)	2
URETRY*n*[f]	Unsolicited Message Max Retry Attempts (2–10)	3
UTIMEO*n*[f]	Unsolicited Message Offline Time-Out (1–5000 seconds)	60
EVEMOD*n*	Event Mode (SINGLE, MULTI)	SINGLE

[a] Hidden if EDNP := O.
[b] Hidden if DNPTRn := TCP.
[c] Hidden if DNPTRn := UDP.
[d] Hidden if CLASSAn := OFF.
[e] Hidden if CLASSAn := CLASSBn := CLASSCn := OFF.
[f] Hidden if UNSOLn := N.

Table 12.24 Phasor Measurement Configuration

Setting	Prompt	Default
EPMIP[a]	Enable C37.118 Communications (Y, N)	N
PMOTS1	PMU Output 1 Scheme (OFF, TCP, UDP_S, UDP_T, UDP_U)	OFF
PMODC1	PMU Output 1 Data Configuration (1–5)	1
PMOIPA1[b]	PMU Output 1 Client IP Address (w.x.y.z)	192.168.1.3
PMOTCP1[b, c]	PMU Output 1TCP/IP Port Number (1–65534)[d]	4712
PMOUDP1[b, e]	PMU Output 1 UDP/IP Data Port Number (1–65534)	4713
PMOTS2	PMU Output 2 Scheme (OFF, TCP, UDP_S, UDP_T, UDP_U)	OFF
PMODC2	PMU Output 2 Data Configuration (1–5)	1
PMOIPA2[f]	PMU Output 2 Client IP Address (w.x.y.z)	192.168.1.4
PMOTCP2[f, g]	PMU Output 2 TCP/IP Port Number (1–65534)[d]	4722
PMOUDP2[f, h]	PMU Output 2 UDP/IP Data Port Number (1–65534)	4714

[a] Set EPMIP := Y to access remaining settings.
[b] Setting hidden when PMOTS1 := OFF.
[c] Setting hidden when PMOTSI := UDP_S.
[d] Port number must be unique compared to TPORT and DNPPNUM.
[e] Setting hidden when PMOTS1 := TCP.
[f] Setting hidden when PMOTS2 := OFF.
[g] Setting hidden when PMOTS2 := UDP_S.
[h] Setting hidden when PMOTS2 := TCP.

Table 12.25 SNTP Selection (Sheet 1 of 2)

Setting	Prompt	Default
ESNTP	SNTP Enable (OFF, UNICAST, MANYCAST, BROADCAST)	OFF
SNTPRAT	SNTP Request Update Rate (15–3600 seconds)	60
SNTPTO[a]	SNTP Timeout (5–20 seconds)	5
SNTPPIP	SNTP Primary Server IP Address (w.x.y.z)[b]	192.168.1.110

Table 12.25 SNTP Selection (Sheet 2 of 2)

Setting	Prompt	Default
SNTPBIP[c]	SNTP Backup Server IP Address (w.x.y.z)[b]	192.168.1.111
SNTPPOR	SNTP IP Local Port Number (1–65534)	123

[a] Setting hidden and forced to 5 if ESNTP := BROADCAST.
[b] Where w: 0–126, 128–239, x: 0–255, y: 0–255, z: 0–255 if ESNTP := MANYCAST or where w: 0–126, 128-223, x: 0–255, y: 0–255, z: 0–255 if ESNTP := UNICAST or BROADCAST.
[c] This setting is hidden if ESNTP ≠ UNICAST.

NOTE: PTP is only supported on Ethernet PORT 5A and PORT 5B. Most SEL-400 series relays only support two ports at a time and must have PORT 5A and PORT 5B selected by the MOT option in these relays. Relays that support four ports will have PTP on PORT 5A and PORT 5B but will not require selection of a different MOT option to have PTP available.

Table 12.26 PTP Settings

Setting	Prompt	Default
EPTP[a]	Enable PTP (Y, N)	N
PTPPRO	PTP Profile (DEFAULT, C37.238, 61850-9-3)	DEFAULT
PTPTR[b]	PTP Transport Mechanism (UDP, LAYER2)	UDP
DOMNUM	PTP Domain Number (0–255)	0
PTHDLY	PTP Path Delay Mechanism (P2P, E2E, OFF)[c]	E2E
PDINT[d]	Peer Delay Request Interval (1, 2, 4, ...64 seconds)	1
AMNUM	PTP Number of Acceptable Masters (OFF, 1–5)	OFF
AMIP*n*[e]	PTP Acceptable Master *n* IP (w.x.y.z)	192.168.1.12n
AMMAC*n*[f]	PTP Acceptable Master *n* MAC (xx:xx:xx:xx:xx:xx)	00.30.A7:00:00:0[p]
ALTPRI*n*[g]	PTP Alternate Priority1 for Master *n* (0–255)	0
PVLAN[h]	PTP VLAN Identifier (1–4094)	1
PVLANPR[h]	PTP VLAN Priority (0–7)	4

[a] This setting is not available if the hardware does not support PORT 5A and PORT 5B or if the ports are used in SWITCHED mode.
[b] Hidden and forced to LAYER2 if PTPPRO := C37.238 or 61850-9-3. Hidden and forced to LAYER2 if NETMODE := PRP and NETPORT := A or B. Also hidden and forced to LAYER2 if NETPORT := C or D.
[c] If PTPPRO := C37.238 or 61850-9-3, E2E is removed from the setting range.
[d] Hidden if PTHDLY := E2E or OFF.
[e] Hidden if AMNUM := OFF or if PTPTR := LAYER2.
[f] Hidden if AMNUM := OFF or if PTPTR := UDP.
[g] Hidden if AMNUM := OFF.
[h] Hidden if PTPPRO := DEFAULT or 61850-9-3.

Five-Port Ethernet Card

Table 12.27 Protocol Selection (Five-Port Ethernet Card) (Sheet 1 of 2)

Setting	Prompt	Default
EPORT	Enable Port (Y, N)	Y
BUSMODE	Bus Operating Mode (INDEPEND, MERGED)	INDEPEND
EINTF	Enable Interface (combo of AB, CD, E)	AB, CD, E
EPAC[a]	Enable Port Access Control (Y, N)	N
MAXACC[a, b]	Max Acc Level for Stn Bus (1, B, P, A, O, 2, C)	C

Table 12.27 Protocol Selection (Five-Port Ethernet Card) (Sheet 2 of 2)

Setting	Prompt	Default
MAXACCE[a, c]	Max Acc Level for Eng Acc (1, B, P, A, O, 2, C)	C
EETHFWU	Enable Ethernet Firmware Upgrade (Y, N)	N

[a] Does not apply to TiDL Channel Map (PORT 6).
[b] Hidden if EINTF does not contain CD and BUSMODE := INDEPEND. If BUSMODE := MERGED, the prompt is "Max ACC Level for Prc Bus (1, B, P, A, O, 2, C)."
[c] Hidden if EINTF does not contain E.

See *Table 12.7* for SEL protocol settings. See *Table 12.8* for Fast Message read data access settings. *Table 12.28* settings are available on the five-port Ethernet card (PORT 5).

Table 12.28 IP/Network Configuration

Setting	Prompt	Default
ETCPKA	Enable TCP Keep-Alive (Y, N)	Y
KAIDLE	TCP Keep-Alive Idle Range (1–20 seconds)	10
KAINTV	TCP Keep-Alive Interval Range (1–20 seconds)	1
KACNT	TCP Keep-Alive Count Range (1–20)	6
NETMODP	Operating Mode for 5A, 5B (FIXED, FAILOVER, PRP, HSR)	FAILOVER
NETPORP	Primary Network Port for 5A, 5B (A, B)	A
PRPINTP	PRP Supervision TX Interval for 5A, 5B (1–10 seconds)	2
PRPADDP	PRP Supervision Address LSB for 5A, 5B (0–255)[a]	0
HSRADDP	HSR Supervision Address LSB for 5A, 5B, (0–255)[a]	0
IPADDR	Device IP Address / CIDR Prefix (w.x.y.z/t)	192.168.1.2/24
DEFRTR	Default Router (w.x.y.z)	192.168.1.1
NETMODE	Operating Mode for 5C, 5D (FIXED, FAILOVER, PRP, HSR)	FAILOVER
NETPORT	Primary Network Port for 5C, 5D (C, D)	C
PRPINTV	PRP Supervision TX Interval for 5C, 5D (1–10 seconds)	2
PRPADDR	PRP Supervision Address LSB for 5C, 5D (0–255)[a]	0
FTIME[b]	Failover Time-Out for 5C, 5D (0–65535 milliseconds)	1
PRPTOUT	PRP Entry Time-Out (100–10000 milliseconds)	500
HSRADDR	HSR Supervision Address LSB for 5C, 5D, (0–255)[a]	0
IPADDRE	Device IP Address / CIDR Prefix for 5E (w.x.y.z/t)	192.168.2.2/24
DEFRTRE	Default Router for 5E (w.x.y.z)	192.168.2.1

[a] LSB stands for least significant bit.
[b] If BUSMODE := MERGED, the prompt is "Failover Time-Out for 5A, 5B (0-65535 milliseconds)."

NOTE: SEL advises against enabling anonymous File Transfer Protocol (FTP) logins (FTPANMS = Y) except under test conditions. The Ethernet card does not require a password for the special FTP username "anonymous". If you enable anonymous FTP logins, you are allowing unrestricted access to the SEL-400 series relay and host files.

Table 12.29 FTP Configuration (Five-Port Ethernet Card) (Sheet 1 of 2)

Setting	Prompt	Default
FTPSERV[a]	Enable FTP Server (OFF or combo of CD, E)	OFF
FTPCBAN	FTP Connect Banner	FTP SERVER:
FTPIDLE	FTP Idle Time-Out (5-255 minutes)	5

Table 12.29 FTP Configuration (Five-Port Ethernet Card) (Sheet 2 of 2)

Setting	Prompt	Default
FTPANMS	Enable Anonymous FTP Login (Y, N)	N
FTPAUSR	Anonymous User Access Level	0

[a] If BUSMODE := MERGED, the range is (OFF or combo of AB, E).

NOTE: Ethernet setting changes result in a restart of the Ethernet card. This closes active network connections and briefly pauses network operation.

Table 12.30 HTTP Server Configuration (Five-Port Ethernet Card)

Setting	Prompt	Default
EHTTP[a]	Enable HTTP Server (OFF or combo of CD, E)	OFF
HTTPPOR	HTTP Server TCP/IP Port Number (1-65534)	80
HIDLE	HTTP Session Inactivity Timeout (1-30 minutes)	5

[a] If BUSMODE := MERGED, the range is (OFF or combo of AB, E).

Table 12.31 Telnet Configuration (Five-Port Ethernet Card)

Setting	Prompt	Default
ETELNET[a]	Enable Telnet Server (OFF or combo of CD, E)	OFF
TCBAN	Telnet Connect Banner	TERMINAL SERVER:
TPORT	Telnet Port (23, 1025–65534)	23
TIDLE	Telnet Port Time-Out (1–30 minutes)	15

[a] If BUSMODE := MERGED, the range is (OFF or combo of AB, E).

NOTE: If BUSMODE := INDEPEND and EINTF contains CD and E, enabling SEL protocol, MMS, or DNP allows the protocol to be processed on both the station bus and engineering access interfaces. Similarly, if BUSMODE := MERGED and EINTF contains E, enabling these protocols allows them to be processed on both the process bus and engineering access interfaces.

See *Table 12.18* for IEC 61850 configuration settings.

See *Table 12.19* for IEC 61850 mode/behavior configuration settings.

See *Table 12.20* for SV transmit configuration settings.

See *Table 12.21* for SV receive configuration settings.

See *Table 12.22* for IEC SV channel settings.

See *Table 12.23* for DNP configuration settings.

Table 12.32 Phasor Measurement Configuration (Five-Port Ethernet Card) (Sheet 1 of 2)

Setting	Prompt	Default
EPMIP[a]	Enable C37.118 Comms (N, CD, E)	N
PMOTS1	PMU Output 1 Scheme (OFF, TCP, UDP_S, UDP_T, UDP_U)	OFF
PMODC1	PMU Output 1 Data Configuration (1–5)	1
PMOIPA1[b]	PMU Output 1 Client IP Address (w.x.y.z)	192.168.1.3
PMOTCP1[b, c]	PMU Output 1TCP/IP Port Number (1–65534)[d]	4712
PMOUDP1[b, e]	PMU Output 1 UDP/IP Data Port Number (1–65534)	4713
PMOTS2	PMU Output 2 Scheme (OFF, TCP, UDP_S, UDP_T, UDP_U)	OFF
PMODC2	PMU Output 2 Data Configuration (1–5)	1
PMOIPA2[f]	PMU Output 2 Client IP Address (w.x.y.z)	192.168.1.4

Table 12.32 Phasor Measurement Configuration (Five-Port Ethernet Card) (Sheet 2 of 2)

Setting	Prompt	Default
PMOTCP2[f, g]	PMU Output 2 TCP/IP Port Number (1–65534)[d]	4722
PMOUDP2[f, h]	PMU Output 2 UDP/IP Data Port Number (1–65534)	4714

[a] If BUSMODE := MERGED, the range is (N, AB, E). Set EPMIP := AB, CD, or E to access remaining settings.
[b] Setting hidden when PMOTS1 := OFF.
[c] Setting hidden when PMOTSI := UDP_S.
[d] Port number must be unique compared to TPORT and DNPPNUM.
[e] Setting hidden when PMOTS1 := TCP.
[f] Setting hidden when PMOTS2 := OFF.
[g] Setting hidden when PMOTS2 := UDP_S.
[h] Setting hidden when PMOTS2 := TCP.

See *Table 12.25* for SNTP selection settings.

Table 12.33 PTP Settings (Five-Port Ethernet Card)

Setting	Prompt	Default
EPTP	Enable PTP (N, AB, CD)	N
PTPPRO	PTP Profile (DEFAULT, C37.238, 61850-9-3)	DEFAULT
PTPTR[a]	PTP Transport Mechanism (UDP, LAYER2)	UDP
DOMNUM	PTP Domain Number (0–255)	0
PTHDLY	PTP Path Delay Mechanism (P2P, E2E, OFF)[b]	E2E
PDINT[c]	Peer Delay Request Interval (1, 2, 4, ...64 seconds)	1
AMNUM	PTP Number of Acceptable Masters (OFF, 1–5)	OFF
AMIP*n*[d]	PTP Acceptable Master *n* IP (w.x.y.z)	192.168.1.12*n*
AMMAC*n*[e]	PTP Acceptable Master *n* MAC (xx:xx:xx:xx:xx:xx)	00.30.A7:00:00:0[p]
ALTPRI*n*[f]	PTP Alternate Priority1 for Master *n* (0–255)	0
PVLAN[g]	PTP VLAN Identifier (1–4094)	1
PVLANPR[g]	PTP VLAN Priority (0–7)	4

[a] Hidden and forced to LAYER2 if PTPPRO := C37.238 or 61850-9-3. Hidden and forced to LAYER2 if EPTP := AB and BUSMODE := INDEPEND. Hidden and forced to LAYER2 if EPTP := AB and BUSMODE := MERGED and NETMODP := PRP. Also hidden and forced to LAYER2 if EPTP := CD and NETMODE := PRP.
[b] If PTPPRO := C37.238 or 61850-9-3, E2E is removed from the setting range.
[c] Hidden if PTHDLY := E2E or OFF.
[d] Hidden if AMNUM := OFF or if PTPTR := LAYER2.
[e] Hidden if AMNUM := OFF or if PTPTR := UDP.
[f] Hidden if AMNUM := OFF.
[g] Hidden if PTPPRO := DEFAULT or 61850-9-3.

DNP3 Settings—Custom Maps

Table 12.34 DNP3 Settings Categories (Sheet 1 of 2)

Settings	Reference
DNP3 Fault Location Min and Max	*Table 12.35*
Binary Input Map	*Table 12.36*
Binary Output Map	*Table 12.36*

Table 12.34 DNP3 Settings Categories (Sheet 2 of 2)

Settings	Reference
Counter Map	*Table 12.36*
Analog Input Map	*Table 12.36*
Analog Output Map	*Table 12.36*

The fault location minimum and maximum settings determine what fault data are sent to a DNP3 master. This affects all DNP3 sessions that use the current DNP3 map.

NOTE: MINDIST and MAXDIST only apply to relays that provide a fault location.

Table 12.35 Minimum and Maximum Fault Location

Setting	Prompt	Default
MINDIST	Min Fault Location to Capture (OFF, –1000.0 to 1000.0)	OFF
MAXDIST	Max Fault Location to Capture (OFF, –1000.0 to 1000.0)	OFF

The remainder of this settings class consists of a set of freeform categories for configuring the map for the various DNP3 data types. The category headers indicate the syntax of the entries. *Table 12.36* shows these headers. All entries require a data label. The deadband and scale-factor parameters are optional. The defaults are relay-specific, so refer to the product-specific instruction manual to see the defaults for these settings.

Table 12.36 DNP3 Map Category Headers

Binary Input Map (Binary Input Label)
Binary Output Map (Binary Output Label)
Counter Map (Counter Label, Deadband)
Analog Input Map (Analog Input Label, Scale Factor, Deadband)
Analog Output Map (Analog Output Label)

Front-Panel Settings

Table 12.37 Front-Panel Settings Categories

Settings	Reference
Front-Panel Settings	*Table 12.38*
Selectable Screens for the Front Panel	*Table 12.39*
Selectable Operator Pushbuttons	*Table 12.40*
Front-Panel Event Display	*Table 12.41*
Display Points	
Local Control	
Local Bit SELOGIC	*Table 12.42*
SER Parameters	*Table 12.43*

The defaults for the pushbuttons and targets in the Front-Panel Settings category are relay-specific. See the product-specific instruction manual to find these defaults.

Table 12.38 Front-Panel Settings (Sheet 1 of 3)

Setting	Prompt
FP_TO	Front Panel Display Time-Out (OFF,1–60 min)
EN_LEDC	Enable LED Asserted Color (R,G)
TR_LEDC	Trip LED Asserted Color (R,G)
PB1_LED	Pushbutton LED 1 (SELOGIC Equation)
PB1_COL	PB1_LED Assert and Deassert Color (Enter 2: R,G,A,O)
PB2_LED	Pushbutton LED 2 (SELOGIC Equation)
PB2_COL	PB2_LED Assert and Deassert Color (Enter 2: R,G,A,O)
PB3_LED	Pushbutton LED 3 (SELOGIC Equation)
PB3_COL	PB3_LED Assert and Deassert Color (Enter 2: R,G,A,O)
PB4_LED	Pushbutton LED 4 (SELOGIC Equation)
PB4_COL	PB4_LED Assert and Deassert Color (Enter 2: R,G,A,O)
PB5_LED	Pushbutton LED 5 (SELOGIC Equation)
PB5_COL	PB5_LED Assert and Deassert Color (Enter 2: R,G,A,O)
PB6_LED	Pushbutton LED 6 (SELOGIC Equation)
PB6_COL	PB6_LED Assert and Deassert Color (Enter 2: R,G,A,O)
PB7_LED	Pushbutton LED 7 (SELOGIC Equation)
PB7_COL	PB7_LED Assert and Deassert Color (Enter 2: R,G,A,O)
PB8_LED	Pushbutton LED 8 (SELOGIC Equation)
PB8_COL	PB8_LED Assert and Deassert Color (Enter 2: R,G,A,O)
PB9_LED[a]	Pushbutton LED 9 (SELOGIC Equation)
PB9_COL[a]	PB9_LED Assert and Deassert Color (Enter 2: R,G,A,O)
PB10LED[a]	Pushbutton LED 10 (SELOGIC Equation)
PB10COL[a]	PB10LED Assert and Deassert Color (Enter 2: R,G,A,O)
PB11LED[a]	Pushbutton LED 11 (SELOGIC Equation)
PB11COL[a]	PB11LED Assert and Deassert Color (Enter 2: R,G,A,O)
PB12LED[a]	Pushbutton LED 12 (SELOGIC Equation)
PB12COL[a]	PB12LED Assert and Deassert Color (Enter 2: R,G,A,O)
T1_LED	Target LED 1 (SELOGIC Equation)
T1LEDL	Target LED 1 Latch (Y, N)
T1LEDC	T_LED Assert and Deassert Color (Enter 2: R,G,A,O)
T2_LED	Target LED 2 (SELOGIC Equation)
T2LEDL	Target LED 2 Latch (Y, N)
T2LEDC	T_LED Assert and Deassert Color (Enter 2: R,G,A,O)
T3_LED	Target LED 3 (SELOGIC Equation)
T3LEDL	Target LED 3 Latch (Y, N)
T3LEDC	T_LED Assert and Deassert Color (Enter 2: R,G,A,O)
T4_LED	Target LED 4 (SELOGIC Equation)
T4LEDL	Target LED 4 Latch (Y, N)
T4LEDC	T_LED Assert and Deassert Color (Enter 2: R,G,A,O)
T5_LED	Target LED 5 (SELOGIC Equation)
T5LEDL	Target LED 5 Latch (Y, N)

Table 12.38 Front-Panel Settings (Sheet 2 of 3)

Setting	Prompt
T5LEDC	T_LED Assert and Deassert Color (Enter 2: R,G,A,O)
T6_LED	Target LED 6 (SELOGIC Equation)
T6LEDL	Target LED 6 Latch (Y, N)
T6LEDC	T_LED Assert and Deassert Color (Enter 2: R,G,A,O)
T7_LED	Target LED 7 (SELOGIC Equation)
T7LEDL	Target LED 7 Latch (Y, N)
T7LEDC	T_LED Assert and Deassert Color (Enter 2: R,G,A,O)
T8_LED	Target LED 8 (SELOGIC Equation)
T8LEDL	Target LED 8 Latch (Y, N)
T8LEDC	T_LED Assert and Deassert Color (Enter 2: R,G,A,O)
T9_LED	Target LED 9 (SELOGIC Equation)
T9LEDL	Target LED 9 Latch (Y, N)
T9LEDC	T_LED Assert and Deassert Color (Enter 2: R,G,A,O)
T10_LED	Target LED 10 (SELOGIC Equation)
T10LEDL	Target LED 10 Latch (Y, N)
T10LEDC	T_LED Assert and Deassert Color (Enter 2: R,G,A,O)
T11_LED	Target LED 11 (SELOGIC Equation)
T11LEDL	Target LED 11 Latch (Y, N)
T11LEDC	T_LED Assert and Deassert Color (Enter 2: R,G,A,O)
T12_LED	Target LED 12 (SELOGIC Equation)
T12LEDL	Target LED 12 Latch (Y, N)
T12LEDC	T_LED Assert and Deassert Color (Enter 2: R,G,A,O)
T13_LED	Target LED 13 (SELOGIC Equation)
T13LEDL	Target LED 13 Latch (Y, N)
T13LEDC	T_LED Assert and Deassert Color (Enter 2: R,G,A,O)
T14_LED	Target LED 14 (SELOGIC Equation)
T14LEDL	Target LED 14 Latch (Y, N)
T14LEDC	T_LED Assert and Deassert Color (Enter 2: R,G,A,O)
T15_LED	Target LED 15 (SELOGIC Equation)
T15LEDL	Target LED 15 Latch (Y, N)
T15LEDC	T_LED Assert and Deassert Color (Enter 2: R,G,A,O)
T16_LED	Target LED 16 (SELOGIC Equation)
T16LEDL	Target LED 16 Latch (Y, N)
T16LEDC	T_LED Assert and Deassert Color (Enter 2: R,G,A,O)
T17_LED[b]	Target LED 17 (SELOGIC Equation)
T17LEDL[b]	Target LED 17 Latch (Y, N)
T17LEDC[b]	T_LED Assert and Deassert Color (Enter 2: R,G,A,O)
T18_LED[b]	Target LED 18 (SELOGIC Equation)
T18LEDL[b]	Target LED 18 Latch (Y, N)
T18LEDC[b]	T_LED Assert and Deassert Color (Enter 2: R,G,A,O)
T19_LED[b]	Target LED 19 (SELOGIC Equation)

Table 12.38 Front-Panel Settings (Sheet 3 of 3)

Setting	Prompt
T19LEDL[b]	Target LED 19 Latch (Y, N)
T19LEDC[b]	T_LED Assert and Deassert Color (Enter 2: R,G,A,O)
T20_LED[b]	Target LED 20 (SELOGIC Equation)
T20LEDL[b]	Target LED 20 Latch (Y, N)
T20LEDC[b]	T_LED Assert and Deassert Color (Enter 2: R,G,A,O)
T21_LED[b]	Target LED 21 (SELOGIC Equation)
T21LEDL[b]	Target LED 21 Latch (Y, N)
T21LEDC[b]	T_LED Assert and Deassert Color (Enter 2: R,G,A,O)
T22_LED[b]	Target LED 22 (SELOGIC Equation)
T22LEDL[b]	Target LED 22 Latch (Y, N)
T22LEDC[b]	T_LED Assert and Deassert Color (Enter 2: R,G,A,O)
T23_LED[b]	Target LED 23 (SELOGIC Equation)
T23LEDL[b]	Target LED 23 Latch (Y, N)
T23LEDC[b]	T_LED Assert and Deassert Color (Enter 2: R,G,A,O)
T24_LED[b]	Target LED 24 (SELOGIC Equation)
T24LEDL[b]	Target LED 24 Latch (Y, N)
T24LEDC[b]	T_LED Assert and Deassert Color (Enter 2: R,G,A,O)

[a] PB9–PB12 settings are only available on 12 pushbutton models.
[b] T17–T24 settings are only available on 12 pushbutton models.

NOTE: The specific settings available in this category for a relay depends on the features of that relay.

NOTE: In some relays, rather than picking from a list of screens, as shown here, there is a freeform settings block in which you can list the screens you want in the order you want them displayed.

Table 12.39 Selectable Screens for the Front Panel

Setting	Prompt	Default
SCROLD	Front-Panel Display Update Rate (OFF, 1–15 sec)	5
ONELINE	One-Line Bay Control Diagram (Y,N)	Y
RMS_V	RMS Line Voltage Screen (Y,N)	N
RMS_I	RMS Line Current Screen (Y,N)	Y
RMS_VPP	RMS Line Voltage Phase to Phase Screen (Y,N)	N
RMS_W	RMS Active Power Screen (Y,N)	N
FUNDVAR	Fundamental Reactive Power Screen (Y,N)	N
RMS_VA	RMS Apparent Power Screen (Y,N)	N
RMS_PF	RMS Power Factor Screen (Y,N)	N
RMS_BK1	RMS Breaker 1 Currents Screen (Y,N)	N
RMS_BK2	RMS Breaker 2 Currents Screen (Y,N)	N
STA_BAT	Station Battery Screen (Y,N)	N
FUND_VI	Fundamental Voltage and Current Screen (Y,N)	Y
FUNDSEQ	Fundamental Sequence Quantities Screen (Y,N)	N
FUND_BK	Fundamental Breaker Currents Screen (Y,N)	N
DIFF_L	Differential Metering Local Currents Screen (Y,N)	Y
DIFF_T	Differential Metering Total Currents Screen (Y,N)	Y
DIFF	Differential Metering (Y,N)	Y
ZONECFG	Terminals Associated with Zones (Y,N)	Y

Table 12.40 Selectable Operator Pushbuttons

Setting	Prompt	Default
PB1_HMI	Pushbutton 1 HMI Screen (OFF,AP,DP,EVE,SER)[a, b]	OFF
PB2_HMI	Pushbutton 2 HMI Screen (OFF,AP,DP,EVE,SER)[a, b]	OFF
PB3_HMI	Pushbutton 3 HMI Screen (OFF,AP,DP,EVE,SER)[a, b]	OFF
PB4_HMI	Pushbutton 4 HMI Screen (OFF,AP,DP,EVE,SER)[a, b]	OFF
PB5_HMI	Pushbutton 5 HMI Screen (OFF,AP,DP,EVE,SER)[a, b]	OFF
PB6_HMI	Pushbutton 6 HMI Screen (OFF,AP,DP,EVE,SER)[a, b]	OFF
PB7_HMI	Pushbutton 7 HMI Screen (OFF,AP,DP,EVE,SER)[a, b]	OFF
PB8_HMI	Pushbutton 8 HMI Screen (OFF,AP,DP,EVE,SER)[a, b]	OFF
PB9_HMI[c]	Pushbutton 9 HMI Screen (OFF,AP,DP,EVE,SER)[a, b]	OFF
PB10HMI[c]	Pushbutton 10 HMI Screen (OFF,AP,DP,EVE,SER)[a, b]	OFF
PB11HMI[c]	Pushbutton 11 HMI Screen (OFF,AP,DP,EVE,SER)[a, b]	OFF
PB12HMI[c]	Pushbutton 12 HMI Screen (OFF,AP,DP,EVE,SER)[a, b]	OFF

[a] PBn_HMI can only be set to DP if a valid display point has been set.
[b] Each instance (AP, DP, EVE, SER) can only be set to a single operator pushbutton.
OFF = No HMI Pushbutton Operation
AP = Alarm Points
DP = Display Points
EVE = Event Summaries
SER = SER HMI Display
[c] PB9–PB12 settings are only available on 12-pushbutton models.

Table 12.41 Front-Panel Event Display

Setting	Prompt	Default
DISP_ER	Enable HMI Auto Display of Events Summaries (Y,N)	Y
TYPE_ER	Types of Events for HMI Auto Display (ALL,TRIP)[a]	ALL
NUM_ER	Operator Pushbutton Events to Display (1–100)[b]	10[c]

[a] Setting is only available if DISP_ER := Y.
[b] Setting is only available if an operator pushbutton has been set to EVE.
[c] Some relays default NUM_ER to 3.

Boolean display points are selected by using freeform settings fields. Two types of display points can be entered: Boolean and analog. For Boolean display points, the entry syntax is:

Bit name, "Label", "Set String", "Clear String", Text Size"

For an analog display point, the syntax is:

Analog name, "User Text and Formatting", "Text Size"

See the Front-Panel Operations section for more information on configuring display points.

Local control bits are configured by using the Local Control category. This is a freeform category. Each entry has the following syntax:

Local bit name, "Label", "Set State", "Clear State", Pulse enable

See *Local Control on page 4.20* for more information on configuring local control bits.

Table 12.42 Local Bit SELOGIC[a]

Setting	Prompt	Default
LB_SPmm	Local Bit Supervision (SELOGIC Equation, NA)	1
LB_DPmm	Local Bit Status Display (SELOGIC Equation, NA)	LBmm

[a] Settings in Table Table 12.42 appear if the associated local bit is defined. If no local bits are defined, the whole category is hidden.

Table 12.43 SER Parameters

Setting	Prompt	Default
SER_PP	Five Events per SER Events page? (Y for 5, N for 3)	N

Alias Settings

Although SEL-400 series relays provide extensive programming facilities and opportunity for comments, troubleshooting customized programs is sometimes difficult. Aliases provide an opportunity to assign more meaningful names to the generic variable names to improve the readability of the program. These aliases can be used in settings and SELOGIC equations and are used in most relay reports. Assign a valid seven-character alias name to any Relay Word bit or any Analog Quantity. (Some SEL-400 series relays support aliasing additional types of data.)

Invalid alias names include the following keywords used by settings and SELOGIC control equations:

- END
- INSERT
- DELETE
- LIST
- NA
- OFF

SELOGIC control equation operators (e.g., NOT, AND, OR, COS) cannot be used as alias names. A quantity may only be assigned one alias. An alias cannot match an existing Relay Word or analog quantity name.

Alias names are valid when the following are true:

- They consist of a maximum of seven characters.
- They are constructed using characters 0–9, uppercase A–Z, or the underscore (_).

For example, the default name for contact output OUT101 is OUT101. You could change the default name to an alias, BK1_TR, for example.

Alias settings consists of a single freeform settings category. As many as 200 aliases may be assigned. The default alias configuration is relay-specific. See the relay instruction manual for the default aliases. *Figure 12.2* shows an example that uses the **SET T** command to set two aliases.

```
=>>SET T <Enter>
Alias
Relay Aliases
(RW Bit or Analog Qty. 7 Character Alias [0-9 A-Z _])

1: EN,"RLY_EN"
? <Enter>
2:
?  OUT101, BK1_TR
3:
? END <Enter>

Alias
Relay Aliases
(RW Bit or Analog Qty. 7 Character Alias [0-9 A-Z _])
1: EN,"RLY_EN"
2: OUT101,"BK1_TR"
.
.
.
Save settings (Y,N)  ?Y <Enter>
Saving Settings, Please Wait...........
Settings Saved

=>>
```

Figure 12.2 Changing a Default Name to an Alias

Protection Freeform SELOGIC Control Equations

Protection freeform SELOGIC control equations are in Classes 1 through 6 corresponding to settings Groups 1 through Group 6 (see *Multiple Setting Groups on page 12.4*).

As many as 250 lines of freeform equations may be entered in each of six settings groups, although the actual maximum capacity may be less. See *SELOGIC Control Equation Capacity on page 13.5* for more information. The default configuration of the protection SELOGIC control equations is relay-specific. See the product-specific instruction manual to see the defaults.

Automation Freeform SELOGIC Control Equations

Automation freeform SELOGIC control equations are in Blocks 1 through 10.

NOTE: Some versions of some SEL-400 series relays have only one automation setting block with a capacity of 100 lines of automation freeform SELOGIC control equations.

The SEL-400 series relays do not contain any automation freeform SELOGIC settings in the factory-default settings.

The relay has a capacity of 100 lines of automation freeform SELOGIC control equations in each of 10 automation setting blocks. See *SELOGIC Control Equation Capacity on page 13.5* for more information.

Output Settings

Table 12.44 Output Settings Categories (Sheet 1 of 2)

Settings	Reference
Main Board	
Interface Board #1	
Interface Board #2	

Table 12.44 Output Settings Categories (Sheet 2 of 2)

Settings	Reference
Interface Board #3	
Interface Board #4	
Remote Analog Outputs	*Table 12.45*
MIRRORED BITS Transmit Equations	*Table 12.46*
87L Communications Bits[a]	*Table 12.47*

[a] Only available in products that support 87L communication.

The Main Board output settings consists of SELOGIC control equations OUT101–OUT108. The defaults are relay-specific; see the relay-specific instruction manual to see the defaults. Some SEL-400 series relays do not have any main board outputs, in which case this category is not available.

NOTE: In TiDL (EtherCAT) relays, Interface Boards 2–4 are always considered to be available. Depending on the Axion modules connected, these outputs may or may not be physically present. In TiDL (T-Protocol) relays, Interface Boards 1–4 are always considered to be available. Depending on the SEL-TMU modules connected, Outputs 2–4 may or may not be physically present.

The Interface Board output settings consists of SELOGIC control equations OUT*x*01–OUT*x*16 where *x* = 2–5, corresponding to Interface Boards 1 to 4. The category for any interface board is only available if the interface board is installed. The defaults are relay-specific; see the relay-specific instruction manual to see the defaults.

Table 12.45 settings are available if an Ethernet card is present and IEC 61850 is ordered.

Table 12.45 Remote Analog Outputs

Setting	Prompt	Default
RAO01 • • • RAO64	Remote Analog Output 01 (SELOGIC) • • • Remote Analog Output 64 (SELOGIC)	NA • • • NA

Table 12.46 MIRRORED BITS Transmit Equations

Setting	Prompt	Default
TMB1A • • • TMB8A	Mirrored Bit 1 Channel A Equation (SELOGIC) • • • Mirrored Bit 8 Channel A Equation (SELOGIC)	NA • • • NA
TMB1B • • • TMB8B	Mirrored Bit 1 Channel B Equation (SELOGIC) • • • Mirrored Bit 8 Channel B Equation (SELOGIC)	NA • • • NA

NOTE: This category is only available in relays that support 87L communications.

Table 12.47 87L Communications Bits

Setting[a, b]	Prompt	Default
87T*x*P1	Serial Comm. Transmit Bit *x* Port 1 (SELOGIC)	NA
87T*x*P2	Serial Comm. Transmit Bit *x* Port 2 (SELOGIC)	NA
87T*nn*E	Ethernet Comm. Transmit Bit *nn* (SELOGIC)	NA

[a] x = 1–8. These settings are hidden when E87CH = N or 2E or 3E or 4E. Also hidden if there is no serial communications card installed.

[b] nn = 01–32. These settings are visible when E87CH = 2E, 3E, or 4E, and are hidden in all other cases.

Report Settings

Table 12.48 Report Settings Categories

Settings	Reference
SER Chatter Criteria	*Table 12.49*
SER Points	
Signal Profile	*Table 12.50*
Event Reporting	*Table 12.51*
Event Reporting Analog Quantities	
Event Reporting Digital Elements	

Table 12.49 SER Chatter Criteria

Setting	Prompt	Default
ESERDEL	Automatic Removal of Chattering SER Points (Y, N)	Y
SRDLCNT[a]	Number of Counts Before Auto-Removal (2–20)	10
SRDLTIM[a]	Time for Auto-Removal (0.1–30 seconds)	0.5

[a] Setting is only available if ESERDEL := Y.

The SER Points category is a freeform category for listing points to record in the SER. Each point can be given a reporting name, a set state name, and a clear state name. You can also indicate whether or not to make this point visible as an alarm point on the front-panel LCD. The syntax for entry is:

> Relay Word Bit Label, "Reporting Name", "Set State Name", "Clear State Name", HMI Alarm Indication

Each of the names may consist of any printable ASCII character. The HMI alarm condition is a Y/N choice. By default, there are no SER points configured.

The signal profile settings category consists of a freeform block for selecting analog quantities to include in the signal profile followed by the settings described in *Table 12.50*. Any of the analog quantities listed in *Section 12:Analog Quantities* in the product-specific instruction manual may be selected. As many as 20 analog quantities can be included in the signal profile.

Table 12.50 Signal Profile

Setting	Prompt	Default
SPAR	Signal Profile Acq. Rate (1,5,15,30,60 min)	5
SPEN	Signal Profile Enable (SELOGIC Eqn.)	0

Table 12.51 Event Reporting (Sheet 1 of 2)

Setting	Prompt	Default
ERDIG	Store Selected (S) or All (A) Relay Word Bits for COMTRADE events	A
SRATE	Sample Rate of Event Report (1, 2, 4, 8 kHz)	2
LER[a]	Length of Event Report (0.25–3.00 seconds); SRATE := 8	0.50
PRE[b]	Length of Pre-Fault (0.05–0.25 seconds); SRATE := 8	0.10
LER[a]	Length of Event Report (0.25–6.00 seconds); SRATE := 4	0.50
PRE[b]	Length of Pre-Fault (0.05–0.25 seconds); SRATE := 4	0.10

Table 12.51 Event Reporting (Sheet 2 of 2)

Setting	Prompt	Default
LER[a]	Length of Event Report (0.25–12.00[c] seconds); SRATE := 2	0.50
PRE[b]	Length of Pre-Fault (0.05–0.25 seconds); SRATE := 2	0.10
LER[a]	Length of Event Report (0.25–24.00[d] seconds); SRATE := 1	0.50
PRE[b]	Length of Pre-Fault (0.05–0.25 seconds); SRATE := 1	0.10

[a] The upper end of the range is reduced by a factor of 4 if ERDIG is set to A.
[b] The upper limit for PRE is the set LER minus 0.05 s.
[c] In the SEL-411L, the upper bound is 9.00 s.
[d] In the SEL-411L, the upper bound is 12.00 s.

The Event Report Analog Quantities category is a freeform category in which you can select as many as 20 analog quantities to report in the filtered relay event reports. By default, no analog quantities are configured.

The Event Reporting Digital Elements category is a freeform settings area in which as many as 800 Relay Words from as many as 100 Relay Word bit rows may be selected. See the product-specific instruction manual for the default configuration. The 100 row limit includes the base set of Relay Word bits always included in oscillography and event reports as described in *Section 7: Metering, Monitoring, and Reporting* in the product-specific instruction manual.

Notes Settings

Avoid losing important information about the relay. Use the Notes settings like a text pad to leave notes about the relay in the Notes area of the relay. Notes entries are in a single block of 100 lines. By default, there is no text stored in the Notes settings.

This page intentionally left blank

SECTION 13

SELOGIC Control Equation Programming

This section describes use of SELOGIC control equations and programming to customize relay operation and automate substations. This section covers the following topics:

- *Separation of Protection and Automation Areas on page 13.1*
- *SELOGIC Control Equation Setting Structure on page 13.2*
- *SELOGIC Control Equation Capacity on page 13.5*
- *SELOGIC Control Equation Programming on page 13.6*
- *SELOGIC Control Equation Elements on page 13.9*
- *SELOGIC Control Equation Operators on page 13.24*
- *Effective Programming on page 13.34*
- *SEL-311 and SEL-351 Series Users on page 13.36*

Separation of Protection and Automation Areas

SEL-400 series relays act as protective relays and as smart nodes in distributed substation automation. The relay collects data, coordinates inputs from many interfaces, and automatically controls substation equipment. The relay performs protection and automation functions but keeps programming of these functions separate. For example, someone modifying or testing a capacitor bank control system or station restoration system created in automation programming should not be able to corrupt programming for protection tasks. Similarly, extended protection algorithms must operate at protection speeds unaffected by the volume of automation programming.

SEL-400 series relays contain several separate programming areas discussed in SELOGIC Control Equation Setting Structure. Separate access levels and passwords control access to each programming area and help eliminate accidental programming changes. For example, use Access Level P to modify protection configuration and protection freeform SELOGIC control equation programming and Access Level A to access automation programming. If you want unlimited access to both automation and protection configuration and programming, use Access Level 2.

NOTE: If you want unlimited access to both automation and protection configuration and programming, log in to Access Level 2.

Protection and automation areas must interact and exchange information. Protection and automation interact and exchange information through separate storage areas (variables) for results of automation and protection programming. The relay combines the results in the output settings that drive relay outputs to control substation equipment. Separation of protection and automation storage areas is illustrated in *Figure 13.1*.

Figure 13.1 Protection and Automation Separation

Figure 13.1 illustrates how the SEL-400 series relays keep protection and automation programming separate while still exchanging information. The arrows indicate data flow between components. The Relay Word Bits and Analog Quantities are visible to protection, automation, and output programming. Protection programming uses the Relay Word Bits, Analog Quantities, Protection Variables, and Automation Variables as inputs, but only writes and stores information to the Protection Variables. Similarly, automation programming uses data from all parts of the relay, but only stores data in the Automation Variables.

The Output SELOGIC control equation settings use the Relay Word Bits, Analog Quantities, Protection Variables, and Automation Variables to control outputs and other information leaving the relay. Use the output settings to create a custom combination of the results of protection and automation operations. For example, an OR operation will activate an output when protection or automation programming results necessitate activating the output. You can use more complicated logic to supervise control of the output with other external and internal information. For example, use a command from the SCADA master to supervise automated control of a motor-operated disconnect in the substation.

SELOGIC Control Equation Setting Structure

SEL-400 series relays use SELOGIC control equations in three major areas. First, you can customize protection operations with SELOGIC control equation settings and freeform programming. Second, there is a freeform programming area for more sophisticated automation SELOGIC control equation programming. Third, there is a fixed area for relay output programming. The SELOGIC control equation programming areas are shown in *Figure 13.2*. There are also a small number of fixed SELOGIC control equations in other settings areas including front-panel settings that allow you to customize relay features not directly related to protection or automation.

NOTE: Some versions of some SEL-400 series relays only support one block of automation SELOGIC control equations.

Figure 13.2 SELOGIC Control Equation Programming Areas

Protection

Protection SELOGIC control equation programming includes a fixed area and a freeform area. You can configure many protection settings within the relay (for example TR) with fixed SELOGIC control equation programming. Use these settings to control protection operation and customize relay operation. The programming and operation of fixed SELOGIC control equations in this area is very similar to programming in SEL-300 series relays.

There is a freeform SELOGIC control equation programming area associated with protection. Because this area operates at the protection processing interval along with protection algorithms and outputs, use this area to extend and customize protection operation. Protection freeform SELOGIC control equation programming includes a complete set of timers, counters, and variables.

For all protection settings, including protection SELOGIC control equation programming, there are six groups of settings that you activate with the protection settings group selection. Only one group is active at a time. When you switch groups, for example, you can activate completely different programming that corresponds to the conditions indicated by the active group. See *Multiple Setting Groups on page 12.4* for more information.

If you want the programming to operate identically in all groups, develop the settings in one group and copy these to all groups. You can copy settings by using the **COPY** command documented in *COPY on page 14.26*. You can also perform cut-and-paste operations in the ACSELERATOR QuickSet SEL-5030 software.

NOTE: Perform operations that are not time critical in automation SELOGIC control equation programming. You can use this automation to reduce the demand and complexity of protection SELOGIC control equation programming.

All of the SELOGIC control equation programming in the protection area executes at the same deterministic interval as the protection algorithms. Because of this type of programming execution, you can use protection freeform and fixed programming to extend and customize protection operation.

Automation

Automation SELOGIC control equation programming is a large freeform programming area that provides as many as ten blocks. The relay executes each block sequentially from the first block to the last. You do not need to fill a block completely or enter any equations in a block before starting to write SELOGIC control equations in the following blocks.

SEL-400 series relays dedicate a minimum processing time when executing automation SELOGIC control equations. If the processing load is light, the relay uses more processing time for executing automation programming. This means that the overall execution time fluctuates. You can display the average and peak execution time with the **STATUS S** ASCII command. Use the **STATUS SC** command to reset the peak execution time.

NOTE: Organize automation SELOGIC control equation programming into blocks based on function. It is easier to edit and troubleshoot small partially filled blocks that contain related programming.

Use automation SELOGIC control equation programming to automate tasks that do not require time-critical, deterministic execution. For example, if you are coordinating control inputs from a substation HMI and SCADA master, use automation freeform SELOGIC control equations and set the output contact setting to the automation SELOGIC control equation variable that contains the result.

Perform time-critical tasks with protection freeform SELOGIC control equations. For example, if you require a SELOGIC control equation for TR (trip) that contains more than 15 elements, you must perform that calculation in several steps. Because detection of a TR condition is a time-critical activity, perform the calculation with protection freeform SELOGIC control equations and set TR to the protection SELOGIC control equation variable that contains the result.

Because automation runs at a slower rate than protection, you must be careful when using protection bits within automation equations. Protection bits can assert and deassert again too fast for automation equations to consistently see them. Therefore, you may need to hold protection bits asserted for a second, by using conditioning timers, before using them in SELOGIC equations.

Outputs

To provide protection and automation area separation, the output settings are in a fixed SELOGIC control equation area separate from protection and automation programming. You can take advantage of this separation to combine protection and automation in a manner that best fits your application. Outputs include the relay control outputs, outgoing MIRRORED BITS points, and remote analog outputs. The relay executes output logic and processes outputs at the protection processing interval.

SELOGIC Control Equation Capacity

SELOGIC control equation capacity is a measure of how much remaining space you have available for programming. In both protection and automation, SELOGIC control equation capacity includes execution capacity and settings storage capacity.

The relay will reject any setting that exceeds the available settings storage capacity and execution capacity. You can then accept the previous settings you have entered and examine your settings.

Protection

SEL-400 series relays typically provide storage space for as many as 250 lines of protection freeform programming. See the product-specific instruction manual for the number of lines limit for any specific product. Because the relay executes protection fixed and freeform logic at a deterministic interval, there is a limit to the amount of SELOGIC control equation programming that the relay can execute. The relay calculates total capacity in terms of settings capacity and execution capacity.

NOTE: The SEL-487B supports 100 lines of protection freeform programming.

Rather than limit parameters to guarantee that your application not exceed the maximum processing requirements, the relay measures and calculates the available capacity when you enter SELOGIC control equations. The relay will not allow you to enter programming that will cause the relay to be unable to complete all protection SELOGIC control equations each protection processing interval.

There are six protection settings groups. Only one protection settings group can be active. When a protection settings group is active, the relay executes SELOGIC control equations in the Global Settings, Protection Group Settings, Protection Freeform Settings, Output Settings, and several other settings areas. The relay calculates protection capacities based on the total amount of SELOGIC control equation programming executed when the protection settings group is active. Use the **STATUS S** command to display the remaining settings capacity and execution capacity for protection fixed and freeform logic.

Automation

SEL-400 series relays provide storage space for as many as 10 blocks of as many as 100 lines of automation freeform programming each. Use the **STATUS S** command to display the remaining settings capacity and execution capacity for automation freeform logic.

There is a maximum execution capacity and settings storage capacity. If you enter a setting that exceeds maximum capacity, the relay will reject the setting. You will have the opportunity to reenter the setting or save any other settings you entered during that session.

SELOGIC Control Equation Programming

There are two major areas where SEL-400 series relays use SELOGIC control equations. First, fixed SELOGIC control equations define the operation of fixed protection elements or outputs. As with SEL-300 series relay programming, protection programming and outputs use fixed SELOGIC control equations. Second, you can use freeform SELOGIC control equations for freeform programming that includes mathematical operations, custom logic execution order, extended relay customization, and automated operation.

Fixed SELOGIC Control Equations

Fixed result SELOGIC control equations are equations in which the left side (result storage location), or LVALUE, is fixed. Programming in SEL-300 series relays consists of all fixed SELOGIC control equations. Fixed equations include protection and output settings that you set with SELOGIC control equations.

Fixed SELOGIC control equations are Boolean equations. Fixed result control equations can be as simple as a single element reference (for example PSV01) or can include a complex equation. An example of fixed programming is shown in *Example 13.1*.

Example 13.1 Fixed SELOGIC Control Equations

The following equations are examples of fixed SELOGIC control equations for relay Output OUT101. The text after the # character is a comment included in the equation and stored in the relay for future reference and documentation.

OUT101 := **1** # Turn on OUT101

OUT101 := **NA** # Do not evaluate an equation for OUT101

OUT101 := **OUT102 AND RB02** # Turn on OUT101 if OUT102 and RB02 are on

Fixed SELOGIC control equations include expressions that evaluate to a Boolean value, True or False, represented by a logical 1 or logical 0.

OUT101 := **PSV04** # Turn on OUT101 if protection PSV04 is on

More complex programming in the freeform area controls OUT101. The result of the freeform programming is available as an element in a fixed equation.

OUT101 := **AMV003 > 5** # Turn on OUT101 if AMV003 is greater than 5

While you cannot perform mathematical operations in fixed programming, you can perform comparisons on the results of mathematical operations performed elsewhere.

Freeform SELOGIC Control Equations

Freeform SELOGIC control equations provide advanced relay customization and automation programming. There are freeform SELOGIC control equation programming areas used for protection and automation. You can use freeform SELOGIC control equation programming to enter program steps sequentially so that the relay will perform steps in the order that you specify. You can refer to storage locations multiple times and build up intermediate results in successive

equations. You can also enter entire line comments to help document programming. Mathematical operations are available only in freeform SELOGIC control equation programming areas. An example of freeform SELOGIC control equation programming is shown in *Example 13.2*.

Example 13.2 Freeform SELOGIC Control Equations

The following equations are examples of freeform SELOGIC control equations. The text after the # character is a comment included in the equation and stored in the relay for future reference and documentation.

```
# Freeform equation example programming
#
# Is 80% of A-Phase fundamental voltage greater than 12kV?
PMV01 := VAFM * 0.8 # 80% of A-Phase fundamental voltage
PSV04 := PMV01 >= 12000 # True if A-Phase fundamental voltage
is greater than or equal to 12000
```

Use comments to Group settings in the freeform SELOGIC control equations by task and to document individual equations. In this example, an intermediate calculation generates the value we want to test to determine if PSV04 will be turned on.

Assignment Statements

Both fixed and freeform SELOGIC control equations are a basic type of computer programming statement called an assignment statement. Assignment statements have a basic structure similar to that shown below:

LVALUE := Expression

Starting at the left, the LVALUE is the location where the result of an evaluation of the expression on the right will be stored. The := symbol marks the statement as an assignment statement and provides a delimiter or separator between the LVALUE and the expression. Type the := symbol as a colon and equal sign. The assignment symbol is different than a single equal sign (=) to avoid confusion with a logical comparison between two values. The type of LVALUE must match the result of evaluating the expression on the right.

There are two basic types of assignment statements that form SELOGIC control equations. In the first type, Boolean SELOGIC control equations, the relay evaluates the expression on the right to a result that is a logical 1 or a logical 0. The LVALUE must be some type of Boolean storage location or setting that requires a Boolean value. For example, the setting for the Protection Conditioning Timer 7 Input, PCT07IN, requires a value of 0 or 1, which you set with a Boolean SELOGIC control equation.

The second type is a math SELOGIC control equation. Use the math SELOGIC control equation to perform numerical calculations on data in the relay. For example, in protection freeform programming in an SEL-451, enter AMV034 := 5 * BK1IAFM to store the product of 5 and the Circuit Breaker 1 A-Phase current in automation math variable 34. *Example 13.3* lists several examples of Boolean and math SELOGIC control equations.

Example 13.3 Boolean and Math SELOGIC Control Equations

The equations below are examples of Boolean SELOGIC control equations.

Example Boolean SELOGIC control equations

PSV01 := **IN101** # Store the value of IN101 in PSV01

PSV02 := **IN101 AND RB03** # Store result of logical AND in PSV02

PST01IN := **IN104** # Use IN104 as the input value for PST01

PSV03 := **PMV33 >= 7** # Set PSV03 when PMV33 greater than or equal to 7

The lines below are examples of math SELOGIC control equations.

Example math SELOGIC control equations

PMV01 := **5** # Store the constant 5 in PMV01

PMV02 := **0.5 * VAFM** # Store the product of A-Phase voltage and 0.5 in PMV02

Comments

Include comment statements in SELOGIC control equations to help document SELOGIC control equation programming. The relay provides the following two type of comments:

- in-line comments: (*comment*)
- end-of-line comments: #xxx

Example of in-line comment:

PCT01IN := (*this is an in-line comment*) PMV04 (*this is an in-line comment *)

Example of end-of-line comment:

PCT01IN := **10** # this is an end-of-line comment

If you begin a SELOGIC control equation with an end-of-line comment character, then the entire line is a comment.

NOTE: During troubleshooting or testing, reenter a line and insert the comment character to disable it. Enter the line without the comment character to enable the line later when you want it to be executed.

Comments are a powerful documentation tool for helping both you and others understand the intent of programming and configuration of the settings. You can use comments liberally; comments do not reduce SELOGIC control equation execution capacity.

SELOGIC Control Equation Elements

SELOGIC control equation elements are a collection of storage locations, timers, and counters that you can use to customize the operation of your relay and to automate substation operation. The elements that you can use in SELOGIC control equations are summarized in *Table 13.1*. The specific number of the various types of elements varies between SEL-400 series relays. See the product-specific instruction manual to determine the number of each type of element in that relay.

Table 13.1 Summary of SELOGIC Control Equation Elements

Element	Description
Relay Word bits	Boolean value data
Analog quantities	Received, measured, and calculated values
Special condition bits	Bits that indicate special SELOGIC control equation execution conditions
SELOGIC control equation variables	Storage locations for the results of Boolean SELOGIC control equations
SELOGIC control equation math variables	Storage locations for the results of math SELOGIC control equations
Latch bits	Nonvolatile storage for the results of Boolean SELOGIC control equations
Conditioning timers	Pickup and dropout style timers similar to those used in SEL-300 series relays
Sequencing timers	On-delay timers similar to those used in programmable logic controllers
Counters	Counters that count rising edges of Boolean value inputs

Relay Word Bits and Analog Quantities

Data within the relay are available for use in SELOGIC control equations. Relay Word bits are binary data that include protection elements, input status, and output status. See *Section 11: Relay Word Bits* in each product-specific instruction manual to view a list of Relay Word bits available within that relay. Analog quantities are analog values within the relay including measured and calculated values. *Section 12: Analog Quantities* in each product-specific instruction manual contains a list of analog quantities available within the relay.

Special Condition Bits

Several Relay Word bits are available for special conditions related to SELOGIC control equation programming in the relay. You can use these bits in SELOGIC control equation programming to react to these conditions. You can also send these bits to other devices through relay interfaces including MIRRORED BITS communications and DNP3. The special condition bits are shown in *Table 13.2*.

The relay sets the first execution bits AFRTEXA, AFRTEXP, and PFRTEX momentarily to allow you to detect changes in the relay operation. The relay sets these bits and clears them as described in *Table 13.2*, *Table 13.3*, and *Table 13.4*. You can use these bits to force logic and calculations to reset or take a known state on power-up or settings change operations.

Table 13.2 First Execution Bit Operation on Startup

Name	Description
AFRTEXA	Relay sets on startup and clears after each automation programming block has been executed once.
AFRTEXP	Relay sets on startup. Relay clears after it enables protection and all automation programming blocks have been executed once.
PFRTEX	Relay sets on startup. Relay clears after protection runs for 1 cycle.

Table 13.3 First Execution Bit Operation on Automation Settings Change

Name	Description
AFRTEXA	Relay sets on settings change and clears after each automation programming block has been executed once.
AFRTEXP	Relay sets on settings change. Relay clears after it enables protection and all automation programming blocks have been executed once.
PFRTEX	Relay sets on settings change. Relay clears after protection runs for 1 cycle.

Table 13.4 First Execution Bit Operation on Protection Settings Change, Group Switch, and Source Selection

Name	Description
AFRTEXA	Relay does not set.
AFRTEXP	Relay sets when listed event occurs. Relay clears after it enables protection and all automation programming blocks have been executed once.
PFRTEX	Relay sets when listed event occurs. Relay clears after protection runs for 1 cycle.

SELOGIC Control Equation Variables

There are two types of SELOGIC control equation variables: Boolean and math.

SELOGIC Control Equation Boolean Variables

SELOGIC control equation Boolean variables are binary storage locations. Each variable equals either logical 1 or logical 0. This manual refers to these variables and the relay displays these as 1 and 0, respectively. Think also of the states 1 and 0 as True and False, respectively, when you evaluate Boolean logic statements. The quantities of SELOGIC control equation Boolean variables available in the different programming areas are listed in *Table 13.5*.

NOTE: The SEL-487E supports 96 protection SELOGIC variables.

Table 13.5 SELOGIC Control Equation Boolean Variable Quantities

Type	Typical Quantity	Name Range
Protection SELOGIC control equation Boolean variables	64	PSV01–PSV64
Automation SELOGIC control equation Boolean variables	256	ASV001–ASV256

Use the SELOGIC control equation Boolean variables in freeform logic statements in any order you want. Use a SELOGIC control equation Boolean variable more than once in freeform logic programming, and use SELOGIC control equation Boolean variables as arguments in SELOGIC control equations. *Example 13.4* illustrates SELOGIC control equation variable usage. You can view the status of individual control equation Boolean bits in the Relay Word using the **TARGET**

command. Use the **TAR PSV*nn*** command or the **TAR ASV*nnn*** command to view the Relay Word row containing the protection or automation Boolean bit specified by the number *nn*. You can also view the status of Boolean bits through the relay LCD front-panel display by selecting `RELAY ELEMENTS` from the Main Menu and scrolling through the rows of Relay Word bits.

Example 13.4 SELOGIC Control Equation Boolean Variables

The equations below show freeform SELOGIC control equation programming examples that use SELOGIC control equation Boolean variables. Each line has a comment after the # that provides additional detail.

PSV01 := **1** # Set PSV01 to 1 always

PSV09 := **PSV54 AND ASV005** # Set to result of Boolean AND

PSV02 := **PMV05 > 5** # Set if PMV05 is greater than 5

You can use SELOGIC control equation variables more than once in freeform programming. The SELOGIC control equations below use ASV100 and ASV101 to calculate intermediate results.

Remote control 1

ASV100 := **RB14 AND ALT01** # Supervise remote control with ALT01

ASV101 := **RB15 AND PLT07** # Supervise remote control with PLT07

ASV201 := **ASV100 OR ASV101** # Store desired control in ASV201

Remote control 2

ASV100 := **RB18 AND ALT09** # Supervise remote control with ALT09

ASV101 := **RB19 AND PLT13** # Supervise remote control with PLT13

ASV202 := **ASV100 OR ASV101** # Store desired control in ASV202

SELOGIC Control Equation Math Variables

SELOGIC control equation math variables are math calculation storage results. As with protection and automation SELOGIC control equation Boolean variables, there are separate storage areas for protection and automation math calculations. The quantities of SELOGIC control equation math variables available in the SEL-400 series relays are shown in *Table 13.6*.

Table 13.6 SELOGIC Control Equation Math Variable Quantities

Type	Typical Quantity	Name Range
Protection SELOGIC control equation math variables	64	PMV01–PMV64
Automation SELOGIC control equation math variables	256	AMV001–AMV256

Use math variables in freeform programming to store the results of math calculations as arguments in math calculations and comparisons. *Example 13.5* illustrates SELOGIC control equation math variable usage. You can view the results of protection and automation math variables by using the **METER** command. Use the **MET PMV** command to see all protection math variable results (PMV01–PMV64). Similarly, use the **MET AMV** command to see all automation math variable results (AMV001–AMV256).

Example 13.5 SELOGIC Control Equation Math Variables

The equations below show freeform SELOGIC control equation programming examples that use SELOGIC control equation math variables by using analog quantities available in the SEL-421. Each line has a comment after the # that provides additional description.

PMV01 := **378.62** # Store 387.62 in PMV01

PMV09 := **5 + VAFM** # Store sum of 5 and A-Phase voltage in kV in PMV09

You can use SELOGIC control equation math variables more than once in freeform programming. Use AMV010 in the following SELOGIC control equations to calculate intermediate results.

Determine if any phase voltage is greater than 13 kV

A-Phase

AMV010 := **VAFIM/1000** # VA in kV

ASV010 := **AMV010 > 13** # Set if greater than 13 kV

B-Phase

AMV010 := **VBFIM/1000** # VB in kV

ASV011 := **AMV010 > 13** # Set if greater than 13 kV

C-Phase

AMV010 := **VCFIM/1000** # VC in kV

ASV012 := **AMV010 > 13** # Set if greater than 13 kV

Combine phase results

ASV013 := **ASV010 OR ASV011 OR ASV012**

Latch Bits

Latch bits are nonvolatile storage locations for Boolean information. Latch bits are in several settings areas of the relay, as shown in *Table 13.7*. Latch bits have two input parameters, Reset and Set, and one Latched Value, as shown in *Table 13.8*.

Table 13.7 Latch Bit Quantities

Type	Typical Quantity	Name Range
Protection freeform latch bits	32	PLT01–PLT32
Automation latch bits	32	ALT01–ALT32

Table 13.8 Latch Bit Parameters

Type	Item	Description	Setting	Name Examples
Input	Reset	Reset latch when on	Boolean SELOGIC control equation	PLT01R ALT01R
Input	Set	Set latch when on	Boolean SELOGIC control equation	PLT01S ALT01S
Output	Latched Value	Latched Value of 0 or 1	Value for use in Boolean SELOGIC control equations	PLT01 ALT24

Latch bits provide nonvolatile storage of binary information. A latch can have the value of logical 0 or logical 1. Latch bits also retain their state through changes in the active protection settings group. Because storage of latch bits is in nonvolatile memory, the state of latch bits remains unchanged indefinitely, even when power is lost to the relay.

As with logic latches used in digital electronics, each latch bit has a Set input and a Reset input. The relay evaluates the latch bit value at the end of each logic processing interval by using the values for Set and Reset calculated during the processing interval. Latch bits are reset dominant. If the Set and Reset inputs are both asserted, the relay will reset the latch.

NOTE: The SEL-487E supports 80 automation latch bits.

Latch bits are available in two different programming areas of the relay. First, there are 32 latch bits, PLT01–PLT32, that are associated with protection settings. Second, there are 32 latch bits, ALT01–ALT32, available in automation freeform programming. You can view the status of individual latch bits in the Relay Word using the **TARGET** command. Use the **TAR PLT*nn*** command or the **TAR ALT*nn*** command to view the Relay Word row containing the protection or automation latch bit specified by the two-digit number, *nn*. You can also view the status of latch bits through the relay LCD front-panel display by selecting `RELAY ELEMENTS` from the Main Menu and scrolling through the rows of Relay Word bits.

Protection Latch Bits

Program the 32 latch bits, PLT01–PLT32, in the protection freeform SELOGIC control equation programming area. There is a separate protection freeform SELOGIC control equation programming area associated with each protection settings group. The latches in protection can have separate programming for Set and Reset in each protection settings group. While each protection latch value remains unchanged for a change in the active protection settings group, you can enter different Set and Reset programming for each protection settings group.

There are Set and Reset settings for each latch bit available in each group. For example, PLT01R and PLT01S are available in all six freeform settings groups and all control the same Latch Bit, PLT01. This structure allows you to either program each latch to operate in the same way for each group or behave differently based on the active protection settings group. For example, you could program the protection latch to set on IN107 when Protection Settings Group 1 is active and program the latch to set on IN106 when Protection Settings Group 2 is active. If you do not enter a setting for the Reset and Set in a protection settings group, the latch bit will remain unchanged when that protection settings group is active. *Example 13.6* illustrates protection latch bit usage.

Example 13.6 Protection Latch Bits

This example studies the factory settings for the HOT LINE TAG operator control logic in the SEL-451. Protection Latch Bit 4 (PLT04) is used as a close enable signal, which is deasserted during Hot Line Tag conditions. When the HOT LINE TAG operator control is pressed, Relay Word bit PB5_PUL pulses for one processing interval, and one of two actions will occur, depending on the previous state of PLT04:

- If PLT04 was previously asserted, the PB5_PUL is ANDed with PLT04 in the PLT04R SELOGIC equation, causing PLT04 to deassert. In this state, closing is blocked.
- If PLT04 was previously deasserted, the PB5_PUL is ANDed with NOT PLT04 in the PLT04S SELOGIC equation, causing PLT04 to assert. In this state, closing is permitted.

The settings below are duplicated in the Protection SELOGIC control equation freeform programming areas corresponding to each of six setting groups:

Store HOT LINE TAG state in PLT04, controlled by front-panel pushbutton

#

PLT04S := PB5_PUL AND NOT PLT04

PLT04R := PB5_PUL AND PLT04 # HOT LINE TAG (WHEN PLT04 DEASSERTED)

#

PLT04 defeats the RECLOSE ENABLED operator control function

PLT02R := PB2_PUL AND PLT02 OR **NOT PLT04** # HOT LINE TAG DISABLES RECLOSE

In the factory settings for PLT04S and PLT04R, rising-edge operators are not required because Relay Word bit PB5_PUL only asserts for one processing interval. If the application required control input IN103 to set or clear the Hot Line Tag function in addition to the operator control pushbutton, the settings would look like this:

PLT04S := (PB5_PUL OR R_TRIG IN103) AND NOT PLT04

PLT04R := (PB5_PUL OR R_TRIG IN103) AND PLT04 # HOT LINE TAG (WHEN PLT04 DEASSERTED)

If the R_TRIG operators were not present, Protection Latch Bit 4 (PLT04) would oscillate whenever IN103 was asserted, and the final state after IN103 deasserts would be indeterminate. To prevent contact bounce sensed by Control Input IN103 from triggering multiple rising edges, make appropriate debounce time settings.

Protection Latch Bit 4 (PLT04) appears in the factory settings for several SELOGIC control equations in the SEL-451:

- In the Protection SELOGIC control equation freeform programming area, PLT04 defeats the RECLOSE ENABLED operator control function

  PLT02R := PB2_PUL AND PLT02 OR **NOT PLT04** # HOT LINE TAG DISABLES RECLOSE

- In the front-panel settings, PB5_LED follows the inverted state of PLT04:

  PB5_LED := **NOT PLT04** #HOT LINE TAG

Example 13.6 Protection Latch Bits (Continued)

- In Group settings, PLT04 supervises close and reclose conditions:
  - Autoreclose enable

    E3PR1 := PLT02 **AND PLT04**
  - Autoreclose drive-to-lockout

    79DTL := NOT (PLT02 **AND PLT04**) AND (3PT OR NOT 52AA1)
  - Manual close

    BK1MCL := (CC1 OR PB7_PUL) **AND PLT04**

The above settings allow the HOT LINE TAG operator control pushbutton to enable or disable close operations in the SEL-451. Any changes to these factory settings should be carefully designed and tested to ensure proper operation.

Evaluation of the latch bit value occurs at the end of the protection SELOGIC control equation execution cycle. The values evaluated for Reset (PLT*nn*R) and Set (PLT*nn*S) during SELOGIC control equation execution remain unchanged until after the evaluation of all SELOGIC control equations, when the relay evaluates the latch bit value (PLT*nn*). For example, if you have multiple SELOGIC control equations for set, the last equation in the protection freeform area dominates, and the relay uses this equation to evaluate the latch.

Automation Latch Bits

NOTE: The SEL-487E supports 80 automation latch bits.

The automation latch bits, ALT01–ALT32, are available in automation freeform settings. Write freeform SELOGIC control equations to set and reset these bits. As with protection latch bits, the relay stores automation latch bits in nonvolatile memory and preserves these through a relay power cycle and group change operations. With protection latch bits, you can implement Set and Reset programming for each protection settings group. Automation SELOGIC control equation programming, however, has only one programming area active for all protection settings groups.

The relay evaluates the latch bit value at the end of the automation freeform SELOGIC control equation execution cycle. The values for Reset (ALT*nn*R) and Set (ALT*nn*S) remain unchanged until evaluation of all SELOGIC control equations, when the relay evaluates the latch (ALT*nn*). For example, if you have multiple SELOGIC control equations for set, the last equation in the automation freeform area dominates, and the relay uses this equation to evaluate the latch.

Conditioning Timers

Use conditioning timers to condition Boolean values. Conditioning timers either stretch incoming pulses or allow you to require that an input take a state for a certain period before reacting to the new state. Conditioning timers are available in the protection freeform area and automation freeform area, as shown in *Table 13.9*. Conditioning timers have the three input parameters and one output shown in *Table 13.10*.

NOTE: Times for protection timers must not exceed 2,000,000 cycles for proper operation.

NOTE: The SEL-487B supports 16 protection conditioning timers.

IMPORTANT: The SEL-400G uses seconds for conditioning timer settings.

NOTE: The SEL-487E supports 48 automation conditioning timers.

Table 13.9 Conditioning Timer Quantities

Type	Quantity	Name Range
Automation freeform conditioning timers	32	ACT01–ACT32
Protection freeform conditioning timers	32	PCT01–PCT32

Table 13.10 Conditioning Timer Parameters

Type	Item	Description	Setting	Name Examples
Input	Pickup Time	Time that the input must be on before the output turns on	Time value. Protection uses the relay protection logic processing interval[a], and automation uses seconds.	PCT01PU ACT01PU
Input	Dropout Time	Time that the output stays on after the input turns off	Time value. Protection uses the relay protection logic processing interval[a], and automation uses seconds.	PCT01DO ACT01DO
Input	Input	Value that the relay times	Boolean SELOGIC control equation setting	PCT01IN ACT01IN
Output	Output	Timer output	Value for Boolean SELOGIC control equations	PCT01Q ACT01Q

[a] The SEL-400G uses seconds for both protection and automation conditioning timers.

A conditioning timer output turns on and becomes logical 1, after the input turns on and the Pickup Time expires. An example timing diagram for a conditioning timer, PCT01, with a Pickup Time setting greater than zero and a Dropout Time setting of zero is shown in *Figure 13.3*. In the example timing diagram, the Input, PCT01IN, turns on and the timer Output, PCT01Q, turns on after the Pickup Time, PCT01PU, expires. Because the Dropout Time setting is zero, the Output turns off when the Input turns off.

Figure 13.3 Conditioning Timer With Pickup and No Dropout Timing Diagram

If the Pickup Time is not satisfied, the timer Output never turns on, as illustrated in *Figure 13.4*. If the input reasserts again, one or more processing intervals later, the conditioning timer pickup timer begins timing again from zero.

Figure 13.4 Conditioning Timer With Pickup Not Satisfied Timing Diagram

A conditioning timer output turns off when the input turns off and the Dropout Time expires. An example timing diagram for a conditioning timer, PCT02, with a Pickup Time setting of zero and a Dropout Time setting greater than zero is shown in *Figure 13.5*. Because the Pickup Time, PCT02PU, setting is zero, the Output, PCT02Q, turns on when the Input, PCT02IN, turns on. The Output turns off after the Input turns off and the Dropout Time, PCT02DO, expires. If the input reasserts before the dropout time expires, the dropout timer resets so it begins timing again from zero when the input drops out again.

Figure 13.5 Conditioning Timer With Dropout and No Pickup Timing Diagram

Combining the features shown above, *Figure 13.6* illustrates conditioning timer operation for use of both the pickup and dropout characteristics. The Output, PCT03Q, turns on after the Input, PCT03IN, turns on and the Pickup Time, PCT03PU, expires. The Output turns off after the Input turns off and the Dropout Time, PCT03DO, expires.

Figure 13.6 Conditioning Timer With Pickup and Dropout Timing Diagram

For protection conditioning timers, set the Pickup Time and Dropout Time in cycles and fractions of a cycle (represented in decimal form). In the SEL-400G, the pickup and dropout timers are set in seconds. The relay processes protection conditioning timers once for each protection processing interval. The relay asserts the timer output on the first processing interval when the elapsed time exceeds the setting. In most SEL-400 series relays, the protection processing interval is 1/8 cycle (or 0.125 cycles). See the product-specific instruction manual to determine the specific processing interval. Actual settings, programming, and operation are illustrated in *Example 13.7*.

For automation conditioning timers, set the Pickup Time and Dropout Time in seconds. The relay processes automation conditioning timers once for each automation processing interval. The execution interval depends on the amount of automation programming. Determine the average automation execution interval with the **STATUS S** command.

IMPORTANT: This example shows timer pickup and dropout settings in cycles. The SEL-400G uses seconds for these settings.

Example 13.7 Conditioning Timer Programming and Operation

This example uses protection freeform conditioning timer seven, PCT07. The freeform settings are as shown here:

PCT07PU := **5.3** # Pickup set to 5.3 cycles

PCT07D0 := **6.0** # Dropout set to 6.0 cycles

PCT07IN := **IN101** # Operate on the first input on the main board

PSV29 := **PCT07Q** # Protection SELOGIC control equation variable follows the timer output

The operation of the timer when IN101 turns on for 7 cycles is shown in the timing diagram in *Figure 13.7*. Because the pickup setting is an uneven number of protection processing intervals (1/8 cycle), the pickup occurs on the first 1/8th cycle after the Pickup Time of 5.3 cycles expires.

Example 13.7 Conditioning Timer Programming and Operation (Continued)

Figure 13.7 Conditioning Timer Timing Diagram for Example 13.7

In freeform programming, the relay evaluates the timer at execution of the timer Input SELOGIC control equation (PCT*nn*IN or ACT*nn*IN). The relay loads the Pickup Time (PCT*nn*PU or ACT*nn*PU) and Dropout Time (PCT*nn*DO or ACT*nn*DO) into the timer when the relay observes the appropriate edge in the input. If you enter a math expression for Pickup Time or Dropout Time, the relay uses the value calculated before the Input SELOGIC control equation. If your Pickup Time or Dropout Time equation is below the Input equation (has a higher expression line number), the relay will use the value calculated on the previous SELOGIC control equation execution interval. Because the relay calculates the last value for pickup or dropout in this manner, we recommend for most applications that you enter the Pickup Time, Dropout Time, and Input statements together in the order shown in *Example 13.7*. You can view the status of the conditioning timer output Relay Word bits by using the **TAR PCT*nn*Q** or **TAR ACT*nn*Q** command, where *nn* is the number of the conditioning timer. You can also view the status of these timer elements through the relay front-panel LCD by selecting `RELAY ELEMENTS` from the Main Menu and scrolling through the rows of Relay Word bits.

Sequencing Timers

NOTE: Times for protection timers with timer settings based on power system cycles must not exceed 2,000,000 cycles for proper operation.

IMPORTANT: The SEL-400G uses seconds for sequencing timer settings.

NOTE: The SEL-487E supports 48 automation conditioning timers.

Sequencing timers are useful for sequencing operation. There are two main differences between sequencing timers and conditioning timers. First, sequencing timers integrate pulses of the input to count up a total time. Second, the elapsed time a sequencing timer counts is visible; you can use this time in other SELOGIC control equation programming or make this time visible through one of the relay communications protocol interfaces. Sequencing timers are available in the protection freeform area and automation freeform area as shown in *Table 13.11*. Sequencing timers have three input parameters and two outputs listed in *Table 13.12*.

Table 13.11 Sequencing Timer Quantities

Type	Typical Quantity	Name Range
Protection freeform sequencing timers	32	PST01–PST32
Automation freeform sequencing timers	32	AST01–AST32

Table 13.12 Sequencing Timer Parameters

Type	Item	Description	Setting	Name Examples
Input	Preset Time	Time the input must be on before the output turns on	Time value. Protection uses the relay protection logic processing interval[a], while automation uses seconds.	PST01PT AST07PT
Input	Reset	Timer reset	Boolean SELOGIC control equation setting	PST01R AST07R
Output	Elapsed Time	Time accumulated since the last reset	Value for math SELOGIC control equations. Protection uses the relay protection logic processing interval[a], while automation uses seconds.	PST01ET AST07ET
Input	Input	Value that the relay times	Boolean SELOGIC control equation setting	PST01IN AST07IN
Output	Output	Timer output	Value for Boolean SELOGIC control equations	PST01Q AST07Q

[a] The SEL-400G uses seconds for both protection and automation conditioning timers.

A sequencing timer counts time by incrementing the Elapsed Time when SELOGIC control equation execution reaches the Input equation if the Reset is off and the Input is on. The Output turns on when the Elapsed Time reaches or exceeds the Preset Time. Whenever the Reset is on, the relay sets the Output to zero, then clears the Elapsed Time, and stops accumulating time (even if Input is on).

Figure 13.8 is a timing diagram for typical sequencing timer operation.

Figure 13.8 Sequencing Timer Timing Diagram

Timers in protection programming operate in the relay protection logic processing interval, while timers in automation programming operate in seconds. In the SEL-400G, the pickup and dropout timers are set in seconds. As with protection conditioning timers, operation depends on the logic processing interval. For example, in most SEL-451 series relays the logic processing interval is 1/8 cycle, so the relay effectively rounds up all operation to the nearest 0.125 cycles. With automation programming, the execution interval depends on the amount of automation programming. Determine the average automation execution interval with the **STATUS S** command.

The automation timers operate using a real-time clock. Each time the relay evaluates the Input (AST*nn*IN) the relay adds the elapsed time since the last execution to the Elapsed Time (AST*nn*ET). The accuracy of the timer in stopping and starting when the input of the timer turns on averages half an automation execution cycle. If you change automation freeform programming, you must also check the new automation average execution cycle to verify that you will obtain satisfactory accuracy for your application. *Example 13.8* describes typical timer programming and describes the resulting operation.

IMPORTANT: This example shows the timer pickup and dropout settings in cycles. The SEL-400G uses seconds for these settings.

Example 13.8 Automation Sequencing Timer Programming

The equations below are an example of programming for an automation sequencing timer, AST01. Each timer input is programmed as a separate statement in automation SELOGIC control equation programming.

Example programming of sequencing timer to time Input IN101 and IN102

AST01PT := **7.5** # Timer Preset Time of 7.5 seconds

AST01R := **RB03** # Reset timer when RB03 turns on

AST01IN := **IN101 AND IN102** # Timing time when IN101 and IN102 are on

ASV001 := **AST01Q** # ASV001 tracks output of timer

AMV256 := **AST01ET** # AMV256 tracks timing progress

In this example, timer AST01 times the quantity IN101 AND IN102 and turns on when the total time reaches 7.5 seconds. If the Input, AST01IN, is on for approximately 1 second every minute, the Output, AST01Q, will turn on during the eighth minute, when the accumulated elapsed time exceeds 7.5 seconds.

In freeform programming, the relay evaluates the timer at the timer Input SELOGIC control equation (PST*nn*IN or AST*nn*IN). If you enter an expression for the timer Reset (PST*nn*R or AST*nn*R) or Preset Time (PST*nn*PT or AST*nn*PT), the values for Reset and Preset Time that the relay uses are the last values that the relay calculates before the input SELOGIC control equation calculation. Because the relay uses the last values for Reset and Preset Time value in this manner, we recommend for most applications that you enter the Preset Time, Reset, and Input statements together in the order shown in *Example 13.8*. You can view the current state of the timer by assigning the elapsed time output of the sequencing timer to a math variable. *Example 13.8* shows how you would assign the elapsed time output for automation sequence timer AST01 to automation math variable AMV256. To see the elapsed time value, issue the **MET AMV** command to display the values of the automation math variables. Likewise, you can assign the elapsed time output of a protection sequence timer to a protection math variable.

The elapsed time output is stored in volatile memory. Elapsed time resets to zero for both protection and automation sequential timers when relay power cycles, you change settings or settings groups, or you perform any function that restarts the relay.

Counters

NOTE: Preset values for counters must not exceed 8,000,000 for proper operation.

Use counters to count changes or edges in Boolean values. Each time the value changes from logical 0 to logical 1 (a rising edge), the counter Current Value increments. Counters are available in the protection freeform area and automation freeform area, as shown in *Table 13.13*. Counters have three input parameters, Input, Preset Value, and Reset; and two outputs, Current Value and Output, as listed in *Table 13.14*.

Table 13.13 Counter Quantities

Type	Typical Quantity	Name Range
Protection counters	32	PCN01–PCN32
Automation counters	32	ACN01–ACN32

Table 13.14 Counter Parameters

Type	Item	Description	Setting	Name Examples
Input	Preset Value	Number of counts before the output turns on	Constant or expression for the number of counts	PCN01PV ACN09PV
Input	Reset	Counter reset	Boolean SELOGIC control equation setting	PCN01R ACN09R
Output	Current Value	Current accumulated count	Value for math SELOGIC control equations	PCN01CV ACN09CV
Input	Input	Value that the relay counts	Boolean SELOGIC control equation setting	PCN01IN ACN09IN
Output	Output	Counter output	Value for Boolean SELOGIC control equations	PCN01Q ACN09Q

In freeform programming, the relay evaluates the counter at execution of the counter Input SELOGIC control equation (PCN*nn*IN or ACN*nn*IN). If you enter an expression for the counter Reset (PCN*nn*R) or the counter Preset (PCN*nn*PV), the values for Reset and Preset that the relay uses are the last values the relay calculates before the input SELOGIC control equation calculation. Because the relay uses the last values for Reset and Preset in this manner, we recommend for most applications that you enter the Preset, Reset, and Input statements together in the order shown in *Example 13.9*. You can view the current value of the counter by assigning the protection counter current value, PCN*nn*CV, to a protection math variable or by assigning the automation counter current value, ACN*nn*CV, to an automation math variable. View the math variable values by issuing the appropriate **MET PMV** or **MET AMV** commands.

The current value count is stored in volatile memory. The count resets to zero for both protection and automation sequential timers when relay power cycles, you change settings or settings groups, or you perform any function that restarts the relay.

Example 13.9 Counter Programming

The freeform programming equations that follow demonstrate how to enter settings to control a protection counter in protection freeform SELOGIC control equation programming. Programming for an automation counter is similar.

Example 13.9 Counter Programming (Continued)

Protection Counter 1 counts close operations of the circuit breaker associated with the 52AA1 element. Initially, the current value, PCN01CV, is zero. The relay increments the current value each time the circuit breaker closes. The relay increases the count value, PCN01CV, each time the circuit breaker closes and the element 52AA1 value changes from 0 to 1 (a rising edge). When the count reaches 1000, the timer automatically resets and begins counting again.

Example protection counter programming

#

This example counts how many times a circuit breaker closes

The counter automatically resets every 1,000 operations

PCN01PV := **1000**

PCN01R := **PCN01Q**

PCN01IN := **52AA1**

The SELOGIC control equations below provide multiple-change detection counting both close and open operations of the circuit breaker. The intermediate value PSV01 turns on for one processing interval each time the circuit breaker closes. The intermediate value PSV02 turns on for one processing interval each time the circuit breaker opens. The OR combination of PSV01 and PSV02 contains a rising edge for each circuit breaker operation, open or closed, that Protection Counter 1 counts.

Example protection counter programming

#

This example counts how many times a circuit breaker operates either open or closed

#

Detect OPEN and CLOSE and combine

PSV01 := **R_TRIG 52AA1** # Pulse for each close

PSV02 := **F_TRIG 52AA1** # Pulse for each open

PSV03 := **PSV01 OR PSV02** # Pulse for each open or close

#

The counter automatically resets every 1,000 operations

PCN01PV := **1000**

PCN01R := **PCN01Q**

PCN01IN := **PSV03** # Count open and close operations

PSV04 := **PCN01CV >900** # PSV04 signals impending reset

SELOGIC Control Equation Operators

There are two types of SELOGIC control equations. Boolean SELOGIC control equations comprise the first type. These equations are expressions that evaluate to a Boolean value of 0 or 1. Math SELOGIC control equations constitute the second type. The relay evaluates these equations to yield a result having a numerical value (for example, 6.25 or 1055).

Left value, LVALUE, determines the type of SELOGIC control equation you need for a setting or for writing freeform programming. If the LVALUE is a Boolean type (ER, ASV001, etc.) then the type of expression you need is a Boolean SELOGIC control equation. If the LVALUE is a numerical (non-Boolean) value (PMV12, PCT01PV, etc.), the type of expression you need is a math SELOGIC control equation.

Writing SELOGIC control equations requires that you use the appropriate operators and correct SELOGIC control equation syntax to combine relay elements including analog values, Relay Word bits, incoming control points, and SELOGIC control equation elements within the relay. The operators are grouped into two types, according to the type of SELOGIC control equation in which you can apply these operators.

Operator Precedence

When you combine several operators and operations within a single expression, the relay evaluates the operations from left to right, starting with the highest precedence operators working down to the lowest precedence. This means that if you write an equation with three AND operators, for example PSV01 AND PSV02 AND PSV03, each AND will be evaluated from the left to the right. If you substitute NOT PSV04 for PSV03 to make PSV01 AND PSV02 AND NOT PSV04, the relay evaluates the NOT operation of PSV04 first and uses the result in subsequent evaluation of the expression. While you cannot use all operators in any single equation, the overall operator precedence follows that shown in *Table 13.15*.

Table 13.15 Operator Precedence From Highest to Lowest (Sheet 1 of 2)

Operator	Description
(Expression)	Parenthesis
Identifier (argument list)	Function evaluation
–	Negation
NOT	Complement
R_TRIG	
F_TRIG	Edge Trigger
SQRT, LN, EXP, LOG, COS, SIN, ACOS, ASIN, ABS, CEIL, FLOOR	Math Functions
*	Multiply
/	Divide
+	Add
–	Subtract
<, >, <=, >=	Comparison
=	Equality
<>	Inequality

Table 13.15 Operator Precedence From Highest to Lowest (Sheet 2 of 2)

Operator	Description
AND	Boolean AND
OR	Boolean OR

Boolean Operators

Use Boolean operators to combine values with a resulting Boolean value. The arguments of the operator may be either numbers or Boolean values, but the result of the operation must be a Boolean value. Combine the operators to form statements that evaluate complex Boolean logic. *Table 13.16* contains a summary of Boolean operators available in SEL-400 series relays.

Table 13.16 Boolean Operator Summary

Operator	Description
( )	Parentheses
NOT	Logical inverse
AND	Logical AND
OR	Logical OR
R_TRIG	Rising-edge trigger
F_TRIG	Falling-edge trigger
>, <, =, <=, >=, <>	Comparison of values

Parentheses

Use paired parentheses to control the execution order of operations in a SELOGIC control equation. Use as many as 14 nested sets of parentheses in each SELOGIC control equation. The relay calculates the result of the operation on the innermost pair of parentheses first and then uses this result with the remaining operations. *Table 13.17* is a truth table for an example operation that illustrates how parentheses can affect equation evaluation.

Table 13.17 Parentheses Operation in Boolean Equation

A	B	C	A AND B OR C	A AND (B OR C)
0	0	0	0	0
0	0	1	1	0
0	1	0	0	0
0	1	1	1	0
1	0	0	0	0
1	0	1	1	1
1	1	0	1	1
1	1	1	1	1

NOT

Use NOT to calculate the inverse of a Boolean value according to the truth table shown in *Table 13.18*.

Table 13.18 NOT Operator Truth Table

Value A	NOT A
0	1
1	0

AND

Use AND to combine two Boolean values according to the truth table shown in *Table 13.19*.

Table 13.19 AND Operator Truth Table

Value A	Value B	A AND B
0	0	0
0	1	0
1	0	0
1	1	1

OR

Use OR to combine two Boolean values according to the truth table shown in *Table 13.20*.

Table 13.20 OR Operator Truth Table

Value A	Value B	A OR B
0	0	0
0	1	1
1	0	1
1	1	1

R_TRIG

R_TRIG is a time-based function that creates a pulse when another value changes, as shown in *Figure 13.9*. Use R_TRIG to sense when a value changes from logical 0 to logical 1 and take action only once when the value changes. The R_TRIG output is a pulse of one protection processing interval duration (typically 1/8th cycle). This rising-edge pulse output asserts one processing interval after the monitored element asserts.

Figure 13.9 R_TRIG Timing Diagram

The argument of an R_TRIG statement must be a single bit within the relay. An example of the relay detecting a rising edge of a calculated quantity is shown in *Example 13.10*.

Example 13.10 R_TRIG Operation

The SELOGIC control equation below is invalid.

PSV15 := **R_TRIG (PSV01 AND PSV23)** # Invalid statement, do not use

Use a SELOGIC control equation variable to calculate the quantity and then use the R_TRIG operation on the result, as shown below.

PSV14 := **PSV01 AND PSV23** # Calculate quantity in an intermediate result variable

PSV15 := **R_TRIG PSV14** # Perform an R_TRIG on the quantity

F_TRIG

F_TRIG is a time-based function that creates a pulse when another value changes, as shown in *Example 13.10*. Use F_TRIG to sense when a value changes from logical 1 to logical 0 and take action only after the value changes state. The F_TRIG output is a pulse of one protection processing interval duration (typically 1/8th cycle). This pulse output asserts one processing interval after the monitored element deasserts.

Figure 13.10 F_TRIG Timing Diagram

The argument of an F_TRIG statement must be a single bit within the relay. An example of the relay detecting a falling edge of a calculated quantity is shown in *Example 13.11*.

Example 13.11 F_TRIG Operation

The SELOGIC control equation below shows an invalid use of the F_TRIG operation.

ASV015 := **F_TRIG (ASV001 AND ALT11)** # Invalid statement, do not use

Use a SELOGIC control equation variable to calculate the quantity and then use the F_TRIG operation on the result, as shown below.

ASV014 := **ASV001 AND ALT11** # Calculate quantity in an intermediate result variable

ASV015 := **F_TRIG ASV14** # Perform an F_TRIG on the quantity

Comparison

Comparison is a mathematical operation that compares two numerical values with a result of logical 0 or logical 1. AND and OR operators compare Boolean values; comparison functions compare floating-point values such as currents and other quantities. Comparisons and truth tables for operation of comparison functions are shown in *Table 13.21*.

NOTE: Be careful how you use the equal (=) and the inequality (<>) operators. Because the relay uses a floating-point format to calculate analog values, only integer numbers will match exactly. Allow a small hysteresis of the following form: PSV01 := I01FM < 10.002 AND I01FM > 9.988.

Table 13.21 Comparison Operations

A	B	A > B	A ≥ B	A = B	A <> B	A ≤ B	A < B
6.35	7.00	0	0	0	1	1	1
5.10	5.10	0	1	1	0	1	0
4.25	4.00	1	1	0	1	0	0

Math Operators

Use math operators when writing math SELOGIC control equations. Math SELOGIC control equations manipulate numerical values and provide a numerical base 10 result. *Table 13.22* summarizes the operators available for math SELOGIC control equations.

Table 13.22 Math Operator Summary

Operator	Description
( )	Parentheses
+, –, *, /	Arithmetic
SQRT	Square root
LN, EXP, LOG	Natural logarithm, exponentiation of e, base 10 logarithm
COS, SIN, ACOS, ASIN	Cosine, sine, arc cosine, arc sine
ABS	Absolute value
CEIL	Rounds to the nearest integer toward infinity
FLOOR	Rounds to the nearest integer toward minus infinity
–	Negation

Parentheses

Use parentheses to control the order in which the relay evaluates math operations within a math SELOGIC control equation. Also use parentheses to group expressions that you use as arguments to function operators such as SIN and COS. Include as many as 14 levels of nested parentheses in your math SELOGIC control equation. *Example 13.12* shows how parentheses affect the operation and evaluation of math operations.

Example 13.12 Using Parentheses in Math Equations

The freeform math SELOGIC control equations below show examples of parentheses usage.

Examples of parenthesis usage

AMV001 := **AMV005 * (AMV004 + AMV003)** # Calculate sum first, then product

AMV002 := **AMV010 * (AMV009 + (AMV016 / AMV015))** # Nest parentheses

AMV003 := **SIN (AMV037 + PMV42)** # Group terms for a function

Math Error Detection

If a math operation results in an error, the relay turns on the math error bit, MATHERR, in the Relay Word. A settings change or the **STATUS SC** command resets this bit. For example, if you attempt to take the square root of a negative number (SQRT –5), the math error bit will be asserted until you clear the bit with a **STATUS SC** command or change settings.

Table 13.23 Math Error Examples

Example	Value in PMV01	Type	MATHERR
PMV01 := PMV02 / 0	0[a]	Divide by zero	Yes
PMV01 := LN (0)	0[a]	LN of 0	Yes
PMV01 := LN (-1)	0[a]	LN of negative number	Yes
PMV01 := SQRT (-1)	0[a]	Square root of a negative number	Yes

[a] Evaluation of expression results in an error and prevents storage of new result. In the example, PMV01 remains 0. If the argument were a variable, PMV01 would contain the result of the last evaluation when the argument is valid.

Arithmetic

Use arithmetic operators to perform basic mathematical operations on numerical values. Arguments of an arithmetic operation can be either Boolean or numerical values. In a numerical operation, the relay converts logical 0 or logical 1 to the numerical value of 0 or 1. For example, multiply numerical values by Boolean values to perform a selection operation. Use parentheses to group terms in math SELOGIC control equations and control the evaluation order and sequence of arithmetic operations.

NOTE: IEEE 32-bit floating-point numbers have a precision of approximately seven significant digits. This means that numbers bigger than 10,000,000 will lose precision in the least significant digit. Do not implement counters expecting them to get bigger than 10,000,000. Do not expect precise accuracy in analog quantities when they get bigger than 10,000,000.

The relay uses IEEE 32-bit floating-point numbers to perform SELOGIC control equation mathematical operations. If an operation results in a quantity that is not a numerical value, the SELOGIC control equation status bit that signals a math error, MATHERR, asserts. The value that the relay stored previously in the specified result location is not replaced. The relay clears the corresponding math error bits if you change SELOGIC control equation settings (protection or automation), or if you issue a **STATUS SC** command. *Example 13.13* contains examples of arithmetic operations in use.

Example 13.13 Using Arithmetic Operations

The freeform math SELOGIC control equations below show examples of arithmetic operator usage.

Arithmetic examples

AMV001 := **AMV005 + AMV034** # Calculate sum

AMV002 := **AMV005 – AMV034** # Calculate difference

AMV003 := **AMV005 * AMV034** # Calculate product

AMV004 := **AMV005 / AMV034** # Calculate quotient

The lines below demonstrate the use of Boolean values with the multiplication operation.

Use of multiplication to select numerical values based on active settings group

Use 7 if protection settings group 1 active

Use 5 if protection settings group 2 active

AMV005 := **7 * SG1 + 5 * SG2**

Example 13.13 Using Arithmetic Operations (Continued)

The lines below demonstrate math calculation error detection.

The line below results in a math error if AMV029 becomes 0

AMV006 := **732 / AMV029**

In the second line, if AMV029 is 6 on the first pass through the automation programming, the relay stores the result 122 in AMV006. If on the next pass AMV029 is 0, the MATHERR bit asserts and the value in AMV006 does not update.

SQRT

Use the SQRT operation to calculate the square root of the argument. Use parentheses to delimit the argument of a SQRT operation. A negative argument for the SQRT operation results in a math error and assertion of the corresponding math error bit described in Arithmetic. *Example 13.14* shows examples of the SQRT operator in use.

Example 13.14 Using the SQRT Operator

The freeform math SELOGIC control equations below show examples of SQRT operator usage.

SQRT examples

AMV001 := **SQRT (AMV005)** # Single argument version of SQRT

AMV002 := **SQRT (AMV005 + AMV034)** # Calculates the square root of the sum

AMV003 := **SQRT (AMV007)** # Produces a math error if AMV007 is negative

LN, EXP, and LOG

LN and EXP are complementary functions for operating with natural logarithms or logarithms calculated to the natural base e. LN calculates the natural logarithm of the argument. LOG calculates the base 10 logarithm of the argument. A negative or zero argument for the LN and LOG operation results in a math error and assertion of the corresponding math error bit described in Arithmetic. EXP calculates the value of e raised to the power of the argument. *Example 13.15* shows examples of expressions that use the LN, EXP, and LOG operators. Use parentheses to delimit the argument of a LN, EXP, or LOG operation.

Example 13.15 Using the LN, EXP, and LOG Operators

The freeform math SELOGIC control equations below are examples of LN, EXP, and LOG operator usage.

LN examples

AMV001 := **LN (AMV009)** # Natural logarithm of AMV009

AMV002 := **LN (AMV009 + AMV034)** # Natural logarithm of the sum

AMV003 := **LN (AMV010)** # Produces error if AMV010 is 0 or negative

Example 13.15 Using the LN, EXP, and LOG Operators (Continued)

EXP examples

AMV004 := **EXP (2)** # Calculates e squared

AMV005 := **EXP (AMV003)** # Calculates e to the power AMV003

AMV006 := **EXP (AMV046 + AMV047)** # e raised to the power of the sum

LOG examples

AMV007 := **LOG (AMV012)** # Base 10 logarithm of AMV012

AMV008 := **LOG (AMV012 + AMV022)** # Base 10 logarithm of the sum

AMV009 := **LOG (AMV100)** # Produces an error if AMV100 is 0 or negative

SIN and COS

Use the SIN or COS operators to calculate the sine or cosine of the argument. SIN and COS operate in degrees, the unit of angular measure the SEL-451 uses to express metering quantities. *Example 13.16* shows examples of SIN and COS. Use parentheses to delimit the argument of a SIN or COS operation.

Example 13.16 Using the SIN and COS Operators

The freeform math SELOGIC control equations below are examples of SIN and COS.

SIN examples

AMV001 := **SIN (AMV005)** # Sine of AMV005

AMV002 := **SIN (AMV005 + AMV034)** # Sine of the sum

COS examples

AMV003 := **COS (AMV005)** # Cosine of AMV005

AMV004 := **COS (AMV005 + AMV006)** # Cosine of the sum

ASIN and ACOS

Use the ASIN or ACOS operators to calculate the angle resulting from the trigonometric function equivalent to a given number (the argument), where the function is sine or cosine. ASIN and ACOS operate in degrees. An argument less than –1 or larger than 1 results in a math error and assertion of the corresponding math bit described in *Arithmetic on page 13.30*. *Example 13.17* shows examples of ASIN and ACOS. Use parentheses to delimit the argument of an ASIN or ACOS operation.

Example 13.17 Using the ASIN and ACOS Operators

The freeform math SELOGIC control equations below are examples of ASIN and ACOS.

ASIN examples

AMV001 := **ASIN (AMV010)** # Arc sine of AMV010

AMV002 := **ASIN (AMV010 + AMV011)** # Arc sine of the sum

AMV003 := **ASIN (AMV012)** # Produces an error if |AMV012| > 1

ACOS examples

AMV004 := **ACOS (AMV010)** # Arc cosine of AMV010

AMV005 := **ACOS (AMV010 + AMV011)** # Arc cosine of the sum

AMV006 := **ACOS (AMV012)** # Produces an error if |AMV012| > 1

ABS

Use the ABS operation to calculate absolute value of the argument. Use parentheses to group a math expression as the argument of an ABS operation. If the argument of the ABS operation is negative, the result is the value multiplied by –1. If the argument of the ABS operation is positive, the result is the same quantity as the argument. *Example 13.18* contains examples of the ABS operator in use.

Example 13.18 Using the ABS Operator

The freeform math SELOGIC control equations below show examples of the ABS operator usage.

ABS examples

AMV001 := **ABS (-6)** # Stores 6 in AMV001

AMV002 := **ABS (6)** # Stores 6 in AMV002

AMV003 := **ABS (AMV009)** # Absolute value of AM009

AMV004 := **ABS (AMV005 + AMV034)** # Absolute value of the sum

CEIL

Use the CEIL operator to round the argument to the nearest integer toward positive infinity. Use parentheses to group a math expression as the argument of a CEIL operation. *Example 13.19* contains examples of the CEIL operator.

Example 13.19 Using the CEIL Operator

The freeform math SELOGIC control equations below show examples of the CEIL operator usage.

CEIL examples

AMV001 := **CEIL (5.99)** # Stores 6 in AMV001

AMV002 := **CEIL (–4.01)** # Stores –4 in AMV002

FLOOR

Use the FLOOR operator to round the argument to the nearest integer toward minus infinity. Use parentheses to group a math expression as the argument of a FLOOR operation. *Example 13.20* contains examples of the FLOOR operator.

Example 13.20 Using the FLOOR Operator

The freeform math SELOGIC control equations below show examples of the FLOOR operator usage.

FLOOR examples

AMV001 := **FLOOR (5.99)** # Stores 5 in AMV001

AMV002 := **FLOOR (–4.01)** # Stores –5 in AMV002

Negation

Use the negation (–) operation to change the sign of the argument. The argument of the negation operation is multiplied by –1. Negation of a positive value results in a negative value, while negation of a negative value results in a positive value. *Example 13.21* contains examples of expressions that use the negation operator.

Example 13.21 Using the Negation Operator

The freeform math SELOGIC control equations below show examples of negation operator usage.

Negation examples

AMV001 := **-AMV009** # If AMV009 is 5, stores –5 in AMV001

AMV002 := **-AMV009** # If AMV009 is –5, stores 5 in AMV002

Effective Programming

This section contains several ideas useful for creating, maintaining, and troubleshooting programming in SEL-451 series relays protection and automation SELOGIC control equation programming environments.

Planning and Documentation

When you begin to configure the relay to perform a new automation task or customize protection operation, take time to design, document, and implement your project. Scale the planning effort to match the overall size of the project, but spend sufficient time planning to do the following:

- Document the inputs and outputs of your programming. This may include protection elements, physical inputs and outputs, metering quantities, user inputs, and other information within the relay.
- Document the processing or outcome of the programming. List the major tasks you want the relay to perform and provide detail about the algorithm you will use for each task. For example, if you need a timer or a counter, make a note of the requirements and how you will use these elements.

- Work in a top-down method, specifying and moving to more detailed levels, until you have sufficient information to create the settings. For simple tasks, one level may be sufficient. For complex tasks, such as automated station restoration, you may need several levels to move from idea to implementation.

Comments

SELOGIC control equation comments are very powerful tools for dividing, documenting, and clarifying your programming. Even if you completely understand your programming during installation and commissioning, comments will be very helpful if you need to modify operation a year later.

Create these comments in the fixed and freeform SELOGIC control equations, and store these comments in the relay. Obtain comments to assist you in using the ASCII interface or SEL configuration software, regardless of whether you have the original files downloaded to the relay.

Comments add structure to freeform programming environments such as Visual Basic, C, and freeform SELOGIC control equations. *Example 13.22* shows how to use comments to divide and structure freeform SELOGIC control equation programming.

Example 13.22 Comments in Freeform SELOGIC Control Equation Programming

Use comments to divide and direct your eye through freeform programming.

```
#
# This is a header comment that divides sections of freeform programming
#
AMV003 := 15 * AMV003 # Explain this line here
#
# This comment is a header for the next section.
# Inputs: provide more detail for more complex tasks
# Outputs: describe how the programming affects the relay operation
# Processing: discuss how the programming itself operates
#
ASV004 := ACN01Q AND RB03 # First line of next section
```

Many texts on programming in various computer programming languages suggest that you cannot include too many comments. The main reason to include comments is that something you find obvious may not be obvious to your coworker who will have to work with your programming in the future. Adding comments also gives you the opportunity to think about whether the program performs the function you intended.

Aliases

SEL-400 series relays provide the ability to alias Relay Word bit and analog quantity names. To make SELOGIC programming more understandable, alias the names of variables being used to something meaningful. For example, you could assign PMV01 an alias of THETA and PMV02 an alias of TAN and then write a SELOGIC equation of:

TAN := SIN(THETA)/COS(THETA)

See *Alias Settings on page 12.25* for more information on creating aliases.

Testing

After documentation and comments, the next essential element of an effective approach to programming is testing. Two types of testing are critical for determining if programming for complex tasks operates properly. First, test and observe whether the program performs the function you want under the conditions you anticipated. Second, look for opportunities to create conditions that are abnormal and determine how your program reacts to unusual conditions.

For example, test your system in unanticipated, but possible conditions such as loss of power, loss of critical field inputs, unexpected operator inputs, and conditions that result from likely failure scenarios of the equipment in your system. It is unlikely that you will find every possible weakness, but careful consideration and testing for abnormal conditions will help you avoid a failure and may reveal deficiencies in the normal operation of your system. Alternatively, you can substitute a remote bit or local bit that you can manually control to help exercise your logic.

Modify your SELOGIC control equations to simulate the process. While you may be unable to change the state of a discrete input easily, such as IN101, you can substitute a logical 1 or logical 0 in your logic to simulate the operation of IN101 and observe the results. Alternatively, you can substitute a remote bit or local bit that you can manually control to help exercise your logic.

Use the SER capabilities of the relay to monitor and record inputs, internal calculations, and outputs. For operations that occur very quickly, use the SER during testing to reconstruct the operation of your logic.

Use the **MET PMV** and **MET AMV** commands to display the contents of the protection or automation math variables.

SEL-311 and SEL-351 Series Users

You can convert logic that you have used in SEL-311 and SEL-351 series relays to logic for an SEL-400 series relay. In the SEL-351 series relays, SELOGIC control equation programming is restricted to equations where the left-side value, LVALUE, is fixed. SEL-400 series relays use a combination of fixed and freeform programming. *Table 13.24* shows comparable features between the fixed logic settings of the SEL-351-5, -6, -7 series relays and the corresponding logic elements that can be programmed in an SEL-400 series relay by using freeform logic programming.

Table 13.24 SEL-351 Series Relays and SEL-400 Series SELOGIC Control Equation Programming Equivalent Functions

Feature	SEL-351 Series	SEL-400 Series Protection Freeform Style
SELOGIC control equation variables	SV1–SV16	PSV01–PSV64
Timer Input	SV1–SV16	PCT01–PCT32
Timer Pickup settings	SV1PU–SV16PU	PCT01PU–PCT32PU
Timer Dropout settings	SV1DO–SV16DO	PCT01DO–PCT32DO
Timer Outputs	SV1T–SV16T	PCT01Q–PCT32Q
Latch Bit Set Control	SET1–SET16	PLT01S–PLT16S
Latch Bit Reset Control	RST1–RST16	PLT01R–PLT16R
Latch Bit	LT1–LT16	PLT01–PLT16

Table 13.25 is a summary that compares SELOGIC control equation programming in SEL-351 series relays and SEL-311 series relays with typical SEL-400 series relays.

Table 13.25 SEL-400 Series SELOGIC Control Equation Programming Summary

Element	SEL-351 Series/ SEL-311 Series	Typical SEL-400 Series	
		Protection Free Form	Automation Free Form
SELOGIC control equation variables	16	64[a]	256
SELOGIC math variables	0	64	256
Conditioning timers[b]	16	32[c]	32[d]
Sequencing timers	0	32	32[e]
Counters	0	32	32
Latch bits	16	32	32[f]

[a] The SEL-487E supports 96 protection SELOGIC variables.
[b] Similar to SEL-300 series relay SELOGIC control equation programming.
[c] The SEL-487B supports 16 protection conditioning timers.
[d] The SEL-487E supports 48 automation conditioning timers.
[e] The SEL-487E supports 48 automation sequencing timers.
[f] The SEL-487E supports 80 automation latch bits.

Table 13.26 shows the SEL-400 series Boolean operators compared to the operators used in the SEL-351 series relays.

Table 13.26 SEL-351 Series Relays and SEL-400 Series SELOGIC Control Equation Boolean Operators

Feature	SEL-351 Series	SEL-400 Series
Logical AND operator	*	AND
Logical OR operator	+	OR
Logical NOT operator	!	NOT
Parentheses	( )	( )
Rising, falling-edge operators	/, \	R_TRIG, F_TRIG

In the SEL-351 series relays, SELOGIC control equation variables and timers are connected. Each SELOGIC control equation variable is the input to a timer. In SEL-400 series relays, timers and SELOGIC control equation variables are independent.

The SELOGIC control equation Boolean operators in SEL-400 series relays are different from those used in SEL-300 series relays. For example, if you wish to convert programming from an SEL-311 or SEL-351 series relay to an SEL-400 series relay, you must convert the operators. *Example 13.23* and *Example 13.24* demonstrate conversion of several settings to the SEL-451 setting.

Example 13.23 Converting SEL-351 Series Relay SELOGIC Control Equation Variables

If you have the following SELOGIC control equation in an SEL-351 series relay, convert it as shown below.

```
SV1 = IN101 + RB3 * LT4
```

In an SEL-400 series relay, use the line shown below.

PSV01 := **IN101 OR RB03 AND PLT04** # Freeform example

In the example above, first convert the + and * operators in the expression to the OR and AND operators. In the freeform example, use a protection SELOGIC control equation variable for the result. In the protection Group settings example, use the input of a timer, as shown in *Table 13.21*.

NOTE: Not all SEL-400 series relay SELOGIC timers are set in cycles. See the product-specific instruction manual for the applicable timer settings.

Example 13.24 Converting SEL-351 Series Relay SELOGIC Control Equation Timers

If you have the following SELOGIC control equation timer in an SEL-351 series relay, convert it as shown below.

```
SV1 = IN101
SV1PU = 5.25
SV1DO = 3.50
OUT101 = SV1T
```

In an SEL-400 series relay, use the format shown below.

#

Freeform programming conversion of timer

#

PCT01PU := **5.25** # Pickup of 5.25 cycles

PCT01DO := **3.5** # Dropout of 3.5 cycles

PCT01IN := **IN101** # Use the timer to monitor IN101

In the output settings, set OUT101 as shown below:

OUT101 := **PCT01Q**

Example 13.25 Converting SEL-351 Series Relay Latch Bits

If you have the following SELOGIC control equation latch programming in an SEL-351 series relay, convert it as shown below.

```
SET1 = RB4
RST1 = RB5
OUT101 = LT1
```

Example 13.25 Converting SEL-351 Series Relay Latch Bits (Continued)

In an SEL-400 series relay, use the format shown below.

Protection freeform style settings:

```
#
# Freeform programming conversion of latch bit
#
PLT01S := RB04 # Set if RB04
PLT01R := RB05 # Reset if RB05
```

In the output settings, set OUT101 as shown below:

```
OUT101 := PLT01
```

This page intentionally left blank

SECTION 14

ASCII Command Reference

You can use a communications terminal or terminal emulation program to set and operate the relay. This section explains common SEL-400 series relay commands that you send to the relay by using SEL ASCII communications protocol. The relay responds to commands such as settings, metering, and control operations.

Not every command listed in this section is supported by every SEL-400 series relay. Additionally, some SEL-400 series relays support additional commands. See the product-specific instruction manual to see what specific commands are supported in that relay.

This section lists ASCII commands alphabetically. Commands, command options, and command variables that you enter are shown in bold. Lowercase italic letters and words in a command represent command variables that you determine based on the application (for example, circuit breaker number *n* = 1 or 2, remote bit number *nn* = 01–32, and level).

Command options appear with brief explanations about the command function. Refer to the references listed with the commands for more information on the relay function corresponding to the command or examples of the relay response to the command.

You can simplify the task of entering commands by shortening any ASCII command to the first three characters; for example, **ACCESS** becomes **ACC**. Always send a carriage return <CR> character, or a carriage return character followed by a line feed character <CR><LF> to command the relay to process the ASCII command. Usually, most terminals and terminal programs interpret the **<Enter>** key as a <CR>. For example, to send the **ACCESS** command, type **ACC <Enter>**. For more information on SEL ASCII protocol, including handshaking, see *Section 15: Communications Interfaces*.

Tables in this section show the access level(s) where the command or command option is active. Access levels in the relay are Access Level 0, Access Level 1, Access Level B (breaker), Access Level P (protection), Access Level A (automation), Access Level O (output), and Access Level 2. For information on access levels see *Changing the Default Passwords in the Terminal on page 3.11*.

Command Description

2ACCESS

Use the **2AC** command to gain access to Access Level 2 (full relay control). See *Access Levels and Passwords on page 3.7* for more information.

Table 14.1 2AC Command

Command	Description	Access Level
2AC	Go to Access Level 2 (full relay control).	1, B, P, A, O, 2

89CLOSE n

Use the **89CLOSE *n*** command to close disconnect switches. (The number of disconnects supported, *n*, depends on the relay.) The main board circuit breaker jumper (on jumper **BREAKER**) must be in place.

NOTE: The SEL-487B does not support disconnect control operations.

If the disconnect switch is open and Relay Word bit LOCAL is deasserted, the **89CLOSE *n*** command asserts Relay Word bit 89CLS*n* for the 89CSIT*n* time. See *Disconnect Switch Close and Open Control Logic on page 5.2*. If the Relay Word bit 89OIP*n* asserts, indicating that the disconnect has started to close, the relay displays `Operation in Progress...` With Relay Word bit 89OIP*n* asserted and Relay Word bit 89ALP*n* deasserted, a dot (.) is appended to the above message every half second to show progress. While the operation is in progress, communications are unavailable on the port where the **89CLOSE** command was executed. Assertion of Relay Word bit 89OIP*n* starts the 89ALP*n* alarm timer. The relay waits for the 89ALP*n* timer to expire and then checks the status of the 89AM*n* and 89BM*n* disconnect inputs. If the 89ALP*n* timer does not expire within 30 seconds, the relay exits the **89CLOSE** command and reads the status of the disconnect inputs. The state of Relay Word bits 89AM*n* and 89BM*n* determine which disconnect status message the relay displays (`Disconnect OPEN`, `Disconnect CLOSED`, or `Status Undetermined - check wiring`). Use the 89CLS*n* Relay Word bit as part of a SELOGIC Output control equation to close the appropriate disconnect switch.

Table 14.2 89CLOSE n Command

Command	Description	Access Level
8**9CLOSE *n***	Set Relay Word bit 89CLS*n*	B, P, A, O, 2

If the relay is disabled and you attempt an **89CLOSE *n*** command, the relay responds with `Command aborted because the relay is disabled`. If the circuit breaker control enable jumper **J18C** (BREAKER) is not in place, the relay aborts the command and responds, `Aborted: the breaker jumper is not installed`.

When the **89CLOSE *n*** command is issued and the circuit breaker control enable jumper is in place, the relay responds, `CLOSE DISNAM`*n* `(Y/N)?`. If you answer **Y <Enter>**, the relay responds with `Are you sure (Y/N)?`. If you answer **Y <Enter>**, the command is executed. If the response to either prompt is not y or Y, the relay responds with `Command Aborted`.

89OPEN n

Use the **89OPEN *n*** command to open disconnect switches. (The number of disconnects supported, *n*, depends on the relay.) The main board circuit breaker jumper (on jumper BREAKER) must be in place.

NOTE: The SEL-487B does not support disconnect control operations.

If the disconnect switch is closed and Relay Word bit LOCAL is deasserted, the **89OPEN n** command asserts Relay Word bit 89OPEN*n* for the 89OSIT*n* time. See *Disconnect Switch Close and Open Control Logic on page 5.2*. If the Relay Word bit 89OIP*n* asserts, indicating that the disconnect has started to open, the relay displays `Operation in Progress...` With Relay Word bit 89OIP*n* asserted and Relay Word bit 89ALP*n* deasserted, a dot (.) is appended to the above message every half second to show progress. While the operation is in progress, communications are unavailable on the port where the **89OPEN** command was executed. Assertion of Relay Word bit 89OIP*n* starts the 89ALP*n* alarm timer. The relay waits for the 89ALP*n* timer to expire and then checks the status of the 89AM*n* and 89BM*n* disconnect inputs. If the 89ALP*n* timer does not expire

within 30 seconds, the relay exits the **89OPEN** command and reads the status of the disconnect inputs. The state of Relay Word bits 89AM*n* and 89BM*n* determine which disconnect status message the relay displays (`Disconnect OPEN`, `Disconnect CLOSED`, or `Status Undetermined - check wiring`). Use Relay Word bit 89OPEN*n* as part of a SELOGIC Output control equation to open the appropriate disconnect switch.

Table 14.3 89OPEN n Command

Command	Description	Access Level
89OPEN *n*	Set Relay Word bit 89OPEN*n*	B, P, A, O, 2

If the relay is disabled and you attempt an **89OPEN *n*** command, the relay responds with `Command Aborted` because the relay is disabled. If the circuit breaker control enable jumper **J18C** (BREAKER) is not in place, the relay aborts the command and responds `Aborted: the breaker jumper is not installed`.

When the **89OPEN *n*** command is issued and the circuit breaker control enable jumper is in place, the relay responds with `Open DISNAM`*n* `(Y/N)?`. If you answer **Y <Enter>**, the relay responds `Are you sure (Y/N)?`. If you answer **Y <Enter>**, the command is executed. If the response to either prompt is not y or Y, the relay responds with `Command Aborted`.

AACCESS

Use the **AAC** command to gain access to Access Level A (automation). See *Access Levels and Passwords on page 3.7* for more information.

Table 14.4 AAC Command

Command	Description	Access Level
AAC	Go to Access Level A (automation).	1, B, P, A, O, 2

ACCESS

Use the **ACC** command to gain access to Access Level 1 (monitor). See *Access Levels and Passwords on page 3.7* for more information.

Table 14.5 ACC Command

Command	Description	Access Level
ACC	Go to Access Level 1 (monitoring).	0, 1, B, P, A, O, 2

BACCESS

Use the **BAC** command to gain access to Access Level B (breaker). See *Access Levels and Passwords on page 3.7* for more information.

Table 14.6 BAC Command

Command	Description	Access Level
BAC	Go to Access Level B (breaker).	1, B, P, A, O, 2

BNAME

The **BNA** command produces ASCII names of all relay Fast Meter status bits in a Compressed ASCII format. See *SEL Protocol on page 15.29* for more information on Fast Meter and the Compressed ASCII command set.

Table 14.7 BNA Command

Command	Description	Access Level
BNA	Display ASCII names of all relay status bits.	0, 1, B, P, A, O, 2

BREAKER

NOTE: Not all SEL-400 series relays support breaker monitoring.

Use the **BREAKER** command to display circuit breaker reports and the circuit breaker history reports. You can also preload accumulated breaker monitor data. The **BRE** command also resets the circuit breaker monitor data. To use the **BRE** command, you must enable the circuit breaker monitors for the circuit breakers of interest. See *Circuit Breaker Monitor on page 8.1* for more information.

BRE n

The **BRE *n*** command displays the comprehensive circuit breaker report that includes interrupted currents, number of operations, and mechanical and electrical operating times, among many parameters. The relay displays a listing of breaker monitor alarms with the breaker report.

Table 14.8 BRE n Command

Command	Description	Access Level
BRE *n* [a]	Display the breaker report for the most recent Circuit Breaker n operation.	1, B, P, A, O, 2

[a] Parameter n = breaker identification character.

BRE n C and BRE n R

The **BRE *n* C** and **BRE *n* R** commands clear/reset the circuit breaker monitor data. Options **C** and **R** are identical.

Table 14.9 BRE n C and BRE n R Commands

Command	Description	Access Level
BRE *n* [a] **C**	Clear Circuit Breaker *n* data to zero.	B, P, A, O, 2
BRE *n* R	Clear Circuit Breaker *n* data to zero.	B, P, A, O, 2

[a] Parameter n = breaker identification character.

BRE C A and BRE R A

The **BRE C A** and **BRE R A** commands clear all circuit breaker monitor data for all circuit breakers from memory. Options **C A** and **R A** are identical.

Table 14.10 BRE C A and BRE R A Commands

Command	Description	Access Level
BRE C A	Clear all circuit breaker data.	B, P, A, O, 2
BRE R A	Clear all circuit breaker data.	B, P, A, O, 2

BRE n H

Display the circuit breaker monitor history report with the **BRE *n* H** command. The breaker history report is a summary of recent circuit breaker operations.

Table 14.11 BRE n H Command

Command	Description	Access Level
BRE *n*[a] H	Display history data for the last 128 Circuit Breaker *n* operations.	1, B, P, A, O, 2

[a] Parameter n = breaker identification character.

BRE n P

Use the **BRE *n* P** command to preload existing circuit breaker contact wear, operation counts, and accumulated currents to the circuit breaker monitor.

Table 14.12 BRE n P Command

Command	Description	Access Level
BRE *n*[a] P	Preload previously accumulated Breaker *n* data.	B, P, A, O, 2

[a] Parameter n = breaker identification character.

CAL

Use the **CAL** command to gain access to Access Level C. See *Access Levels and Passwords on page 3.7* for more information. Only go to Level C to modify the default password or under the direction of an SEL employee. The additional commands available at Level C are not intended for normal operational purposes.

Table 14.13 CAL Command

Command	Description	Access Level
CAL	Go to Access Level C.	2, C

CASCII

The **CAS** command produces the Compressed ASCII configuration message. This configuration instructs an external computer on the method for extracting data from other Compressed ASCII commands. See *SEL Compressed ASCII Commands on page 15.30* for an example of the **CAS** command configuration message and for further information on the Compressed ASCII command set.

Table 14.14 CAS Command

Command	Description	Access Level
CAS	Return the Compressed ASCII configuration message.	0, 1, B, P, A, O, 2

CBREAKER

NOTE: Not all SEL-400 series relays support breaker monitoring

The **CBREAKER** command provides a Compressed ASCII response circuit breaker report that is similar to the **BREAKER** command. You must enable the Breaker Monitor function for at least one breaker to generate the Compressed ASCII report. You can specify a specific circuit breaker to retrieve a report for one circuit breaker only. See *SEL Compressed ASCII Commands on page 15.30* for information on the Compressed ASCII command set.

CBR

Use the **CBR** command to gather the comprehensive circuit breaker report in Compressed ASCII format.

Table 14.15 CBR Command

Command	Description	Access Level
CBR	Return the most recent circuit breaker reports for all circuit breakers in Compressed ASCII format.	1, B, P, A, O, 2
CBR *n*[a]	Return the most recent circuit breaker report for Circuit Breaker *n* in Compressed ASCII format.	1, B, P, A, O, 2

[a] Parameter n = breaker identification character.

CBR TERSE

The **CBR TERSE** command omits the breaker report labels.

Table 14.16 CBR TERSE Command

Command	Description	Access Level
CBR TERSE	Return the most recent circuit breaker report for all circuit breakers in Compressed ASCII format; suppress the labels; transmit only the data lines.	1, B, P, A, O, 2
CBR *n*[a] **TERSE**	Return the most recent circuit breaker report for Circuit Breaker *n* in Compressed ASCII format; suppress the labels; transmit only the data lines.	1, B, P, A, O, 2

[a] Parameter n = breaker identification character.

CEVENT

NOTE: The SEL-400G relay does not support Compressed ASCII events.

The **CEVENT** command provides a Compressed ASCII response similar to the **EVENT** command. See *SEL Compressed ASCII Commands on page 15.30* for information on the Compressed ASCII command set.

CEV

Use the **CEV** command to gather relay event reports. When parameter *n* is 1–9999, *n* indicates the order of the event report. The most recent event report is 1, the next most recent report is 2, and so on. When parameter n is 10000–42767, *n* indicates the absolute serial number of the event report.

Table 14.17 CEV Command

Command	Description	Access Level
CEV	Return the most recent event report (including settings and summary) at full length with 4-samples/cycle data in Compressed ASCII format.	1, B, P, A, O, 2
CEV *n*[a]	Return particular *n* event report (including settings and summary) at full length with 4-samples/cycle data in Compressed ASCII format.	1, B, P, A, O, 2

[a] Parameter n indicates event order or serial number.

CEV ACK

Use **CEV ACK** to acknowledge viewing the oldest unacknowledged event on the present communications port. View this event with the **CEV NEXT** or **EVE NEXT** commands.

Table 14.18 CEV ACK Command

Command	Description	Access Level
CEV ACK	Acknowledge the oldest unacknowledged event at the present communications port.	1, B, P, A, O, 2

CEV C

Use **CEV C** to return a 15-cycle length event report with analog and digital information in Compressed ASCII format. The L*yyy* option overrides the **C** option (see **CEV L*yyy***).

Table 14.19 CEV C Command

Command	Description	Access Level
CEV C	Return the most recent event report at a 15-cycle length with 8-samples/cycle data in Compressed ASCII format.	1, B, P, A, O, 2
CEV C *n*	Return particular n event report at a 15-cycle length with 8-samples/cycle data in Compressed ASCII format.	1, B, P, A, O, 2

CEV L

Use **CEV L** to return a large resolution event report in Compressed ASCII format. The **S*x*** option overrides the **L** option (see **CEV S*x***).

NOTE: Not all SEL-400 series relays support the CEV L option.

Table 14.20 CEV L Command

Command[a]	Description	Access Level
CEV L	Return the most recent event report at full length with large resolution data in Compressed ASCII format.	1, B, P, A, O, 2
CEV *n* L	Return particular n event report at full length with large resolution data in Compressed ASCII format.	1, B, P, A, O, 2

[a] Parameter n indicates event order or serial number; see CEV on page 14.7.

CEV Lyyy

Command **CEV L*yyy*** returns a specified length event report in Compressed ASCII format, where **L*yyy*** indicates a length of *yyy* cycles. You can specify *yyy* from 1 cycle to a value including and beyond the event report total cycle length. If *yyy* is longer than the total length, the relay returns the full event report. The **L*yyy*** option overrides the **C** option.

Table 14.21 CEV Lyyy Command

Command	Description	Access Level
CEV L*yyy*	Return *yyy* cycles of the most recent event report (including settings) with 4-samples/cycle data in Compressed ASCII format.	1, B, P, A, O, 2
CEV *n*[a] L*yyy*	Return *yyy* cycles of a particular n event report with 4-samples/cycle data in Compressed ASCII format.	1, B, P, A, O, 2

[a] Parameter n indicates event order or serial number; see CEV on page 14.7.

CEV NEXT

CEV NEXT returns the oldest unacknowledged event report on the present communications port in Compressed ASCII format.

Table 14.22 CEV N Command

Command	Description	Access Level
CEV N	Return the oldest unacknowledged event report with 4-samples/cycle sampling in Compressed ASCII format.	1, B, P, A, O, 2

CEV NSET

The **CEV NSET** command returns the Compressed ASCII event report with no relay settings.

Table 14.23 CEV NSET Command

Command	Description	Access Level
CEV NSET	Return the most recent event report without settings at full length with 4-samples/cycle data in Compressed ASCII format.	1, B, P, A, O, 2
CEV *n*[a] NSET	Return a particular n event report without settings at full length with 4-samples/cycle data in Compressed ASCII format.	1, B, P, A, O, 2

[a] Parameter n indicates event order or serial number.

CEV NSUM

The **CEV NSUM** returns the Compressed ASCII event report with no event summary.

Table 14.24 CEV NSUM Command

Command	Description	Access Level
CEV NSUM	Return the most recent event report without the event summary at full length with 4-samples/cycle data in Compressed ASCII format.	1, B, P, A, O, 2
CEV *n*[a] NSUM	Return a particular n event report without the event summary at full length with 4-samples/cycle data in Compressed ASCII format.	1, B, P, A, O, 2

[a] Parameter n indicates event order or serial number; see CEV on page 14.7.

CEV Sx

Use the **CEV S*x*** command to specify the sample data resolution of the Compressed ASCII event report. The sample data resolution *x* can be 4, 8, or 12, depending on the relay; the default value is 4-samples/cycle if you do not specify **S*x***. The **S*x*** option overrides the **L** option.

Table 14.25 CEV Sx Command

Command	Description	Access Level
CEV S*x*	Return the most recent event report at full length with *x*-samples/cycle data in Compressed ASCII format.	1, B, P, A, O, 2
CEV *n*[a] S*x*	Return a particular n event report at full length with *x*-samples/cycle data in Compressed ASCII format.	1, B, P, A, O, 2

[a] Parameter n indicates event order or serial number; see CEV on page 14.7.

CEV TERSE

The **CEV TERSE** command returns a Compressed ASCII event report without the event report labels.

Table 14.26 CEV TERSE Command

Command	Description	Access Level
CEV TERSE	Return the most recent event report at full length without the report labels with 4-samples/cycle data in Compressed ASCII format.	1, B, P, A, O, 2
CEV *n*[a] TERSE	Return a particular n event report at full length without the report labels with 4-samples/cycle data in Compressed ASCII format.	1, B, P, A, O, 2

[a] Parameter n indicates event order or serial number.

Use the **TERSE** option with any of the **CEV** commands except **CEV ACK**.

CEV Command Option Combinations

You can combine options **C**, **L**, **L*yyy***, ***n***, **NSET**, **NSUM**, **S*x***, and **TERSE** in one command. Enter the options according to the following guidelines:

- The **L*yyy*** option overrides the **C** option
- The **S*x*** option overrides the **L** option
- Enter the options in any order

Table 14.27 lists the choices you can make in the **CEV** command. Combine options on each row, selecting one option from each column, to create a **CEV** command.

Table 14.27 CEV Command Option Groups

Acknowledge	Event Number	Data Resolution	Report Type	Report Length	Omit
ACK	*n*, **NEXT**	**S***x*, **L**	**C**	**L***yyy*, **C**	**NSET, NSUM, TERSE**

The following examples illustrate some possible option combinations.

Example	Description
CEV L10 S8	Return 10 cycles of an 8-samples/cycle Compressed ASCII event report for the most recent event.
CEV L10 L	Return 10 cycles of an large resolution Compressed ASCII event report for the most recent event (same as above).
CEV 2 C NSUM TERSE	For the second most recent event, return 15 cycles of the event in Compressed ASCII format with no event summary and no report label lines with large resolution data.

CFG

In TiDL and IEC Sampled Values (SV) subscribers, certain aspects of the relay must be configured before the relay can be set. This command is used to perform this configuration.

CFG CTNOM

NOTE: The SEL-487E-5 includes additional user inputs. See the SEL-487E-5 instruction manual for the additional user inputs.

NOTE: See the firmware entries in product-specific Appendix A tables for the following entry:

Modified **CFG CTNOM** command to only default global and group settings on a nominal secondary current configuration change.

The firmware versions prior to this change default all settings.

In TiDL and IEC SV subscribers, use the **CFG CTNOM** command to inform the relay which CT inputs are 1 A nominal and which are 5 A nominal. (By default, the relay assumes all CT inputs are 5 A nominal.) This is necessary so the relay scales the information correctly. See *Section 2: Installation* of the product-specific instruction manual for more information on using this command as part of configuring the relay. On a secondary current configuration change, the relay defaults the global and protection Group settings and then performs a restart, so make this command before sending Global or Group settings.

Table 14.28 CFG CTNOM Command

Command	Description	Access Level
CFG CTNOM *n* [a]	Change nominal CT configuration to selected value	2

[a] The parameter n (or parameters) is relay-specific.

CFG NFREQ

In TiDL (EtherCAT) relays that support SEL-2240 Axion nodes only, use the **CFG NFREQ** command to set the nominal frequency of the relay (which is 60 Hz by default). In relays that do not support TiDL (EtherCAT), the nominal frequency is controlled by the NFREQ Global setting. This should be configured after the nominal currents are configured (through the use of the **CFG CTNOM** command) and before settings are loaded into the relay. This will restart the relay.

Table 14.29 CFG NFREQ Command

Command	Description	Access Level
CFG NFREQ *f*	Change nominal frequency to *f* (50 or 60)	2

CHISTORY

The **CHISTORY** command provides a **HISTORY** report in the Compressed ASCII format.

CHI

Use the **CHI** command to gather one-line descriptions of event reports.

Table 14.30 CHI Command

Command	Description	Access Level
CHI	Return the data as contained in the History report (short form descriptions) for the most recent 100 event reports in Compressed ASCII format (for SEL-2030 compatibility).	1, B, P, A, O, 2
CHI A	Return one-line descriptions of the most recent 100 event reports in Compressed ASCII format.	1, B, P, A, O, 2
CHI *k*	Return one-line descriptions of the most recent *k* number of event reports in Compressed ASCII format.	1, B, P, A, O, 2

CHI TERSE

The **CHI TERSE** command returns a Compressed ASCII event report without the event report label lines.

Table 14.31 CHI TERSE Command

Command	Description	Access Level
CHI TERSE	Return one-line descriptions for the most recent 100 event reports without the label lines in Compressed ASCII format.	1, B, P, A, O, 2
CHI *k* TERSE	Return one-line descriptions for the most recent k number of event reports without the label lines in Compressed ASCII format.	1, B, P, A, O, 2

CLOSE n

Use the **CLOSE *n*** command to close a circuit breaker. The main board circuit breaker jumper (on jumper BREAKER) must be in place. Further, you must enable breaker control for any breakers you want to control.

NOTE: The SEL-487B does not support the **CLOSE** command.

The **CLOSE *n*** command asserts Relay Word bit CC*n*. The CC*n* bit must be included in the close SELOGIC equation for breaker *n* (BK*n*MCL) for this command to effect a close operation. The relay uses these equations and additional relay logic to assert a control output (for example, OUT103 := BK1CL) to close a circuit breaker.

NOTE: CCn Relay Word bits are pulsed for two processing intervals in the SEL-487E.

Table 14.32 CLOSE n Command

Command	Description	Access Level
CLOSE *n*	Command the relay to close Circuit Breaker *n*.	B, P, A, O, 2

If the circuit breaker control enable jumper BREAKER is in place, the relay responds with `Close breaker (Y/N)?`. When you answer **Y <Enter>** (for yes), the relay prompts, `Are you sure (Y/N)?`. If you again answer **Y <Enter>**, the relay asserts the Relay Word bit for one processing interval.

If you have assigned a circuit breaker auxiliary contact (52A) to a relay control input (based on the 52AA*n*, 52AB*n*, 52AC*n* settings), the relay waits 0.5 second, checks the state of the circuit breaker, and issues either a `Breaker OPEN` or `Breaker CLOSED` message.

If circuit breaker control enable jumper BREAKER is not in place, the relay aborts the command and responds, `Aborted: the breaker jumper is not installed`. If the relay is disabled, the relay responds with `Command aborted because relay is disabled`. If Breaker *n* is not enabled and you issue the **CLOSE *n*** command, the relay responds with `Breaker n is not available`.

COMMUNICATIONS

The **COMMUNICATIONS** command displays communications statistics for the MIRRORED BITS communications channels and for synchrophasor client channels. Some relays support additional options to the **COM** command besides those described here.

COM c

Use the **COM *c*** command to view records of the MIRRORED BITS communications buffers for specific relay communications channels.

Table 14.33 COM c Command[a]

Command	Description	Access Level
COM A	Return a summary report of the last 255 records in the communications buffer for MIRRORED BITS communications Channel A.	1, B, P, A, O, 2
COM B	Return a summary report of the last 255 records in the communications buffer for MIRRORED BITS communications Channel B.	1, B, P, A, O, 2
COM M	Return a summary report of the last 255 records in the communications buffer for either MIRRORED BITS communications Channel A or Channel B when only one channel is enabled.	1, B, P, A, O, 2

[a] Parameter c is A, B, or M for Channel A, Channel B, and MIRRORED BITS communications channels, respectively.

The *c* option in the **COM** command is **A** for MIRRORED BITS communications Channel A, B for MIRRORED BITS communications Channel B, and Channel M for the MIRRORED BITS communications channels in general. If both MIRRORED BITS communications channels are in use, then the **M** option does not function and you must specify **A** or **B**.

COM c C and COM c R

The **COM *c* C** and **COM *c* R** commands clear/reset the communications buffer data for the specified Channel *c*. Options **C** and **R** are identical.

Table 14.34 COM c C and COM c R Command

Command	Description	Access Level
COM A C	Clear/reset communications buffer data for MIRRORED BITS communications Channel A.	P, A, O, 2
COM B R	Clear/reset communications buffer data for MIRRORED BITS communications Channel B.	P, A, O, 2
COM M C	Clear/reset communications buffer data for either MIRRORED BITS communications Channel A or Channel B when only one channel is enabled.	P, A, O, 2

COM c L m n and COM c L date1 date2

Use **COM *c* L** to list the records in the communications buffer in a specified manner. The relay returns the list of records in rows. You can specify a range of buffer records in forward or reverse chronological order or in forward or reverse date order. Date parameter entries depend on the setting DATE_F format you chose in the relay Global settings.

The relay organizes the records in rows in a 256-entry buffer in newest to oldest time order. The relay puts the newest record in the buffer and discards the oldest record if the buffer is full.

Table 14.35 is a representative list of options for listing records in the communications buffer.

Table 14.35 COM c L Command

Command	Description	Access Level
COM A L	Display all available records from MIRRORED BITS communications Channel A; the most recent record is Row 1 (at the top of the report) and the oldest record is at the bottom of the report.	1, B, P, A, O, 2
COM B L *k*[a]	Display the first *k* records for MIRRORED BITS communications Channel B; the most recent record is Row 1 (at the top of the report) and the oldest record is at the bottom of the report.	1, B, P, A, O, 2
COM M L *m n*[b]	Display the records for either MIRRORED BITS communications Channel A or Channel B when only one channel is enabled; show the records with Record *m* at the top of the report through Record *n* at the bottom of the report.	1, B, P, A, O, 2
COM A L *date1*[c]	Display the records from MIRRORED BITS communications Channel A on the date *date1*.	1, B, P, A, O, 2
COM B L *date1 date2*[c]	Display the records from MIRRORED BITS communications Channel B between the dates *date1* and *date2*. The date listed first, *date1*, is at the top of the report; the date listed second, *date2*, is at the bottom of the report.	1, B, P, A, O, 2

[a] Parameter k indicates a specific number of communications buffer records.
[b] Parameters m and n are communications buffer row numbers.
[c] Enter date1 and date2 in the same format as Global setting DATE_F.

COM HSR

NOTE: The **COM HSR** command is only relevant when the relay is receiving HSR traffic while connected in a ring topology with other HSR compatible devices. The HSR supervision bits are time-delayed. SEL recommends using them for monitoring purposes only.

The **COM HSR** command is only available when using the five-port Ethernet card. The command displays the health of your HSR ring. The logic used to generate the status information is processed once per second and is designed to detect persistent errors in the ring. The logic is not intended to detect intermittent packet loss. If a device receives HSR messages on one port and receives a matching message on the other port pair, the relay asserts the applicable HSR supervision Relay Word bits HSRAOK, HSRBOK, HSRCOK, and HSRDOK and reports OK in the **COM HSR** response. If a port does not receive HSR messages within 12 seconds of receiving them on the other port, or if the relay does not receive the HSR supervision frame it initiated, the relay deasserts the applicable HSR supervision bits and reports `WARNING` in the **COM HSR** response. If the link is down on any of the ports, the relay reports `FAIL` for that port. If the station bus or process bus is not configured for HSR, the command reports `HSR DISABLED` for that bus.

Additionally, the command provides statistics for the process and station bus ports including the number of GOOSE and SV messages received on one port but not the other, the number of link-down incidents, and the accumulated link downtime since the last reset.

Table 14.36 COM HSR Command

Command	Description	Access Level
COM HSR	Display HSR information and statistics for the five-port Ethernet card.	1, B, P, A, O, 2
COM HSR C	Clear HSR statistics.	1, B, P, A, O, 2

Figure 14.1 shows an example response to the **COM HSR** command for an SV subscriber.

```
=>>COM HSR <Enter>

Relay 1                                        Date: 10/01/2024  Time: 15:35:00.450
Station A                                      Serial Number: 1242759999

PROCESS BUS
HSR Port 5A Status: OK
HSR Port 5B Status: OK
HSR Ring Latest Roundtrip Time: 12 us
HSR Ring MAX Roundtrip Time:    19 us

STATION BUS
HSR Port 5C Status: OK
HSR Port 5D Status: OK
HSR Ring Latest Roundtrip Time: 12 us
HSR Ring MAX Roundtrip Time:    $$$$$ us

HSR Statistics
                                        PORT 5A    PORT 5B    PORT 5C    PORT 5D
-------------------------------------------------------------------------------
Duplicate SV HSR Pkts Not RCVD               0          0          0          0
Other Duplicate Packets Not RCVD             0          0          0          5
Link Down Counter                            0          0          0          1
Link Downtime (s)                            0          0          0          4

Date and Time from the last reset: 10/01/2024 - 13:58:00
```

Figure 14.1 Sample COM HSR Command Response

COM PRP

NOTE: The **COM PRP** command is only relevant when the relay is receiving PRP traffic from the network. The PRP supervision bits are time-delayed. SEL recommends using them for monitoring purposes only.

The **COM PRP** command is only available when using the five-port Ethernet card. The command displays the health of your PRP network for GOOSE and SV. The logic used to generate the status information is processed once per second and is designed to detect persistent network errors. The logic is not intended to detect intermittent packet loss. If a port receives PRP messages on LAN A that

match those received on LAN B, the relay asserts the applicable PRP supervision Relay Word bits PRPAGOK, PRPBGOK, PRPCGOK, PRPDGOK, PRPASOK, and PRPBSOK and reports `OK` in the **COM PRP** response. If a port does not receive PRP messages on one LAN within 6 seconds of receiving them on the other LAN, the relay deasserts the applicable PRP supervision bits and reports `WARNING` in the **COM PRP** response. If a port does not receive any expected PRP duplicates on one of the LANs, the relay reports `FAIL` for that port. If the station bus or process bus is not configured for PRP, the command reports `PRP DISABLED` for that bus. Note that a loss of link deasserts associated PRP supervision bits immediately. Also, these bits only supervise the PRP network and not the quality status of the SV and GOOSE protocols themselves.

Additionally, the command provides statistics for the process and station bus ports including the number of GOOSE and SV messages received on one LAN but not the other, the number of link-down incidents, and the accumulated link downtime since the last reset.

Table 14.37 COM PRP Command

Command	Description	Access Level
COM PRP	Display PRP information and statistics for the five-port Ethernet card.	1, B, P, A, O, 2
COM PRP C	Clear PRP statistics.	1, B, P, A, O, 2

Figure 14.2 shows an example response to the **COM PRP** command for an SV Subscriber.

```
=>>COM PRP <Enter>

Relay 1                                    Date: 03/17/2023  Time: 14:43:22.620
Station A                                  Serial Number: 1230769999

PROCESS BUS
PRP PORT 5A GOOSE Status: OK
PRP PORT 5A SV Status:    OK
PRP PORT 5B GOOSE Status: WARNING
PRP PORT 5B SV Status:    FAIL

STATION BUS
PRP PORT 5C GOOSE Status: OK
PRP PORT 5D GOOSE Status: FAIL

PRP Statistics Information
                                       PORT 5A    PORT 5B    PORT 5C    PORT 5D
-------------------------------------------------------------------------------
Duplicate SV PRP Pkts Not RCVD             0      99999          0         20
Duplicate GOOSE PRP Pkts Not RCVD          0          0          0         20
Link Down Counter                          0          1          0          1
Link Downtime (s)                          0          2          0         60

Date and Time from the last reset: 01/23/2023 - 13:11:09

=>>
```

Figure 14.2 Sample COM PRP Command Response

COM PTP

The **COM PTP** command provides a report of the Precision Time Protocol (PTP) data sets maintained by the device as well as statistics for the measured time offsets with the parent (master) clock. The PTP data sets contain informa-

tion about the state, identity, and configuration of the local, parent, and grandmaster clocks in addition to properties of the time being distributed by the grandmaster clock.

Table 14.38 COM PTP Command

Command	Description	Access Level
COM PTP	Display PTP data sets and offset statistics	2
COM PTP 5*n*	Display PTP data sets and offset statistics for `PORT 5n` (*n* = A, B, C, D)	2
COM PTP C	Clears PTP offset statistics	2

If PTP is disabled or the relay hardware does not support PTP, then the **COM PTP** command will respond with `PTP Not Enabled`. If a settings change is in progress or if the hardware is not yet initialized, then the **COM PTP** command will respond with `Data unavailable, please try again later`.

```
=>>COM PTP <Enter>

Relay 1                                    Date: 03/17/2023  Time: 15:08:43.516
Station A                                  Serial Number: 1230769999

PTP offset statistics previously cleared on 02/24/2016 14:08:36.303 (UTC)

Settings Data Set
  PTP Profile : Default
  Transport Mechanism : Layer2
  Path Delay : P2P

Default Data Set
  Two Step : true
  Clock Identity : 00 30 A7 FF FE 44 55 66
  Number of Ports : 1
  Clock Quality
    Clock Class : 255
    Clock Accuracy : 254
    Offset Log Variance : 0
  Priority1 : 255
  Priority2 : 255
  Domain Number : 1
  Slave Only : true

Current Data Set
  Steps Removed : 1
  Offset from Master : -5 ns
  Mean Path Delay : 0 ns

Parent Data Set
  Parent Port Identity
    Clock Identity : 00 30 A7 FF FE 04 7C 22
    Port Number : 1
  Grandmaster Clock Identity : 00 30 A7 FF FE 04 7C 22
  Grandmaster Clock Quality
    Clock Class : Synchronized with PTP timescale (6)
    Clock Accuracy : Within 25 ns
    Offset Log Variance : 0
  Grandmaster Priority1 : 0
  Grandmaster Priority2 : 0

Time Properties Data Set
  Current UTC Offset : 0
  Current UTC Offset Valid : true
  Leap59 : false
  Leap61 : false
  Time Traceable : true
  Frequency Traceable : true
  PTP Timescale : true
  Time Source : PTP
  Local Time Offset
    Offset Valid : true
    Name : PST
    Current Offset : 3600
    Jump Seconds : 3600
    Time of Next Jump : 1456797635
```

Figure 14.3 Sample COM PTP Command Response

```
Port Data Set
  Port Identity
    Clock Identity : 00 30 A7 FF FE 44 55 66
    Port Number: 1
  Port State : SLAVE
  Log Pdelay Request Interval : 0
  Peer Mean Path Delay : 0 ns
  Announce Receipt Timeout : 2 intervals
  Path Delay Mechanism : Peer-to-Peer
  Failed to Receive Response : true
  Received Multiple Pdelay Responses : false
  Reason for Non-synchronization :
  Port status : A, ACTIVE

Time Offset Statistics
  Mean : -0.013393 ns
  Standard Deviation : 5.291062 ns
  Latest Time Offsets with respect to Reference Time (in ns)
    #1 :                        -5
    #2 :                        -1
    #3 :                         0
    #4 :                         1
    #5 :                        -1
    #6 :                         2
    #7 :                         8
    #8 :                         3
    #9 :                         1

    #10 :                       -9
    #11 :                        2
    #12 :                        0
    #13 :                        3
    #14 :                       -4
    #15 :                       -9
    #16 :                        5
    #17 :                       -1
    #18 :                       -4
    #19 :                       -4
    #20 :                        1
    #21 :                        5
    #22 :                        7
    #23 :                       -7
    #24 :                       -1
    #25 :                        6
    #26 :                       -2
    #27 :                       -2
    #28 :                        8
    #29 :                       -5
    #30 :                        2
    #31 :                        0
    #32 :                       -2

=>>
```

Figure 14.3 Sample COM PTP Command Response (Continued)

COM RTC

Use the **COM RTC** to get a report on the status of the configured synchrophasor client channels.

NOTE: Not all SEL-400 series relays support synchrophasors.

Table 14.39 COM RTC Command

Command[a]	Description	Access Level
COM RTC	Return a report describing the communications on all enabled synchrophasor client channels.	1, B, P, A, O, 2
COM RTC A	Return a report describing the communications on synchrophasor client Channel A.	1, B, P, A, O, 2
COM RTC B	Return a report describing the communications on synchrophasor client Channel B.	1, B, P, A, O, 2

[a] Parameter c is A, B, or absent for Channel A, Channel B, or all enabled channels, respectively.

COM RTC c C and COM RTC c R

The **COM RTC C** and **COM RTC R** commands clear/reset the maximum packet delay. The **C** and **R** options are identical.

Table 14.40 COM RTC c C and COM RTC c R Command

Command	Description	Access Level
COM RTC C	Clear/reset the maximum packet delay on all enabled synchrophasor client channels.	P, A, O, 2
COM RTC A R	Clear/reset the maximum packet delay on synchrophasor client Channel A.	P, A, O, 2
COM RTC B C	Clear/reset the maximum packet delay on synchrophasor client Channel B.	P, A, O, 2

COM SV

COM SV (SEL SV Publishers)

NOTE: Not all SEL-400 series relays support the **COM SV** command

The **COM SV** command displays information and statistics for the SV publications that can be used for troubleshooting purposes.

Table 14.41 COM SV Command (SEL SV Publishers)

Command	Description	Access Level
COM SV	Displays information for the SV publications	1, B, P, A, O, 2
COM SV *k*	Displays information for the SV publications successively for *k* times	1, B, P, A, O, 2

The information displayed for each SV publication is described in *Table 14.42*.

Table 14.42 Accessible Information for Each SV Publication (Sheet 1 of 2)

Data Field	Description
SEL TEST SV Mode	When SEL TEST SV Mode = Off, the SEL SV publisher is publishing normal SV messages. When SEL TEST SV Mode = On, the SEL SV publisher is publishing TEST SV messages. When SEL TEST SV Mode = On, Relay Word bit SVPTST is asserted; SVPTST is deasserted otherwise. See *TEST SV on page 14.69* in this section for more information.
SV Control Reference	This field represents the control reference for the SV publication. When the SEL SV publisher is configured via Configured IED Description (CID) file, this field includes the iedName (IED name), ldInst (Logical Device Instance), LN0 lnClass (Logical Node Class) and the SampledValueControl name (SV Control Block Name). e.g., SEL_421CFG/LLN0MSMSVCB01 When the SEL SV publisher is configured via the **PORT 5** SV settings, this field is blank.
Multicast Address (MultiCastAddr)	This field is the multicast destination address for the SV publication and is expressed as six sets of hexadecimal values.
Priority Tag (Ptag)	This decimal field is the priority tag value. Spaces are used if the priority tag is unavailable or unknown.
VLAN (Vlan)	This decimal field is the virtual LAN of the SV publication. Spaces are used if the VLAN is unavailable or unknown.
AppID	This hexadecimal field is the value of the Application Identifier for the SV publication.

Table 14.42 Accessible Information for Each SV Publication (Sheet 2 of 2)

Data Field	Description
Sampled Value Identifier (SV ID)	This field is the identifier string value for the SV publication (as many as 63 characters).
Synchronization State (smpSynch)	This field represents the time-synchronization source of the SEL SV publisher at the time of the most recent SV published message. 0: Not synchronized. 1: Synchronized by an unspecified local area clock signal (low-accuracy). 2: Synchronized by a global area clock signal (high-accuracy). 3, 4: Reserved. 5–254: Synchronized by a grandmaster clock identified with this ID (PTP power profile only).
Data Set Reference	This field contains the DataSetReference (Data Set Reference) for the SV publication. When the SEL SV publisher is configured via CID file, this field includes the iedName (IED name), ldInst (Logical Device Instance), LN0 lnClass (Logical Node Class) and SampledValueControl datSet (Data Set Name), e.g., SEL_421CFG/LLN0$PhsMeas1. When the SEL SV publisher is configured via the PORT 5 SV settings, this field is blank.

Figure 14.4 shows an example response to the **COM SV** command with the SEL SV publisher configured via CID file.

```
=>>COM SV <Enter>

IEC 61850 Mode /Behavior: On
SEL TEST SV Mode: Off
IEC 61850 Simulation Mode: Off

SV Publication Information

 MultiCastAddr   Ptag:Vlan AppID  smpSynch
--------------------------------------------------------------------------------

SEL_421CFG/LLN0$MS$MSVCB01
 01-0C-CD-04-00-01  4:1    4001      2
 SV ID: 4001
 Data Set: SEL_421CFG/LLN0$PhsMeas1

SEL_421CFG/LLN0$MS$MSVCB02
 01-0C-CD-04-00-02  4:1    4002      2
 SV ID: 4002
 Data Set: SEL_421CFG/LLN0$PhsMeas2

SEL_421CFG/LLN0$MS$MSVCB03
 01-0C-CD-04-00-03  4:1    4003      2
 SV ID: 4003
 Data Set: SEL_421CFG/LLN0$PhsMeas3
```

Figure 14.4 COM SV Command Response When CID Configuration Is Used by the SEL SV Publisher

Figure 14.5 shows an example response to the **COM SV** command with the SEL SV publisher configured via PORT 5 Settings.

```
=>>COM SV <Enter>

IEC 61850 Mode /Behavior: On
SEL TEST SV Mode: Off
IEC 61850 Simulation Mode: Off

SV Publication Information

 MultiCastAddr   Ptag:Vlan AppID  smpSynch
-------------------------------------------------------------------------------

 01-0C-CD-04-00-01  4:1    4101      2
 SV ID: 4101
 Data Set:

 01-0C-CD-04-00-02  4:1    4102      2
 SV ID: 4102
 Data Set:

 01-0C-CD-04-00-03  4:1    4103      2
 SV ID: 4103
 Data Set:
```

Figure 14.5 COM SV Command Response When PORT 5 Settings Are Used by the SEL SV Publisher

If the **COM SV** command is issued during CID file processing or right after SV settings change in PORT 5, the relay responds with `IEC 61850 configuration is in progress. No SV statistics available.`

If the PORT 5 settings for SV are not in use (SVTXEN = 0), and the CID file is not present or is invalid when the **COM SV** command is issued, the relay responds with `Error detected in parsing the CID file. All SV processing disabled.`

If the PORT 5 SV settings are not in use and no SV publications or subscriptions are configured in the CID file when the **COM SV** command is issued, the relay responds with `No SV publications configured.`

COM SV (SV Subscribers)

The **COM SV** command displays information and statistics for the SV subscriptions that can be used for troubleshooting purposes.

Table 14.43 COM SV Command (SEL SV Subscribers)

Command	Description	Access Level
COM SV	Displays information for the SV subscriptions.	1, B, P, A, O, 2
COM SV *k*	Displays information for the SV subscriptions successively for *k* times.	1, B, P, A, O, 2
COM SV S	Displays a list with the SubsID, AppID, and ControlBlockReference identifier for each of the SV subscriptions configured.	1, B, P, A, O, 2
COM SV S [id|ALL]	Displays statistics information and downtime timers for all [ALL] or a specific SV subscription [id] based on the parameters entered.	1, B, P, A, O, 2
COM SV S [id|ALL] [L]	Displays an extended report containing statistics information, downtime timers and occurred failures for all [ALL] or a specific SV subscription [id] based on the parameters entered.	1, B, P, A, O, 2
COM SV S [id|ALL] C	Clears the statistics for a particular SV subscription if the identifier [id] is entered. Otherwise clears the statistics for all the configured SV subscriptions whether or not the [ALL] parameter is entered.	1, B, P, A, O, 2

Table 14.44 describes the available information for each SV subscription when commands in *Table 14.43* are entered.

Table 14.44 Accessible Information for Each IEC 61850 SV Subscription (Sheet 1 of 2)

Data Field	Description
SEL TEST SV Mode	This field indicates whether or not the SEL SV subscriber is in SEL TEST SV Mode. If On, then the SEL SV subscriber accepts SV publications that have the TEST bit of the quality attribute set. While in Test mode, the SEL SV subscriber continues to accept SV publications that do not have the TEST bit of the quality attribute set. When SEL TEST SV Mode = On, Relay Word bit SVSTST is asserted; SVSTST is deasserted otherwise. See *TEST SV on page 14.69* for more information.
SIMULATED Mode	This field indicates whether or not the SEL SV subscriber is currently accepting simulated SV publications. If On, then the SEL SV subscriber accepts all the SV publications that have the LPHDSIM mode set. See the *Section 17: IEC 61850 Communication* for more information about the Simulated Mode.
SV Control Reference	This field represents the control reference for the SV subscriptions. When the SEL SV subscriber is configured via CID file, this field includes the iedName (IED name), ldInst (Logical Device Instance), LN0 lnClass (Logical Node Class) and the SampledValueControl name (SV Control Block Name). e.g., SEL_421CFG/LLN0MSMSVCB01 When the SEL SV subscriber is configured via the `PORT 5` SV settings, this field is blank.
AppID	This hexadecimal field represents the value of the Application Identifier for the SV subscription.
Accumulated downtime duration (since last reset)	Displays the accumulated downtime duration attributed to errors since the last time the statistics were cleared.
Maximum downtime duration	Displays the maximum duration of continuous downtime attributed to errors, accumulated over the previous 30-second maximum rolling window to the issue of the **COM SV** command.
Code (SV Subscriptions Failure Report)	Displays one of the values under *Table 14.45* either for warning or error code. This code indicates a warning or error code for each SV subscription in effect at the time the command was executed. If multiple warnings or errors are present for an SV subscription, only the code with the highest priority is displayed. If the **COM SV S [id|ALL] L** is executed, a listed report containing the last eight most recent failures with the highest priority error code will be displayed for one or all the SV subscriptions based in the parameters entered.
Multicast Address (MultiCastAddr)	This field is the multicast destination address for the received SV message expressed as six sets of hexadecimal values.
Priority Tag (Ptag)	This decimal field is the priority tag value. Spaces are used if the priority tag is unavailable or unknown.
VLAN (Vlan)	This decimal field is the virtual LAN of the received SV message. Spaces are used if the VLAN is unavailable or unknown.
Sampled Value Identifier (SV ID)	This field is the identifier string value for the received SV message (as many as 63 characters).
Synchronization State (smpSynch)	This field represents the time-synchronization source for the most recent received SV message. 0: Not synchronized. 1: Synchronized by an unspecified local area clock signal (low-accuracy). 2: Synchronized by a global area clock signal (high-accuracy). 3, 4: Reserved. 5–254: Synchronized by a grandmaster clock identified with this ID (PTP power profile only).

Table 14.44 Accessible Information for Each IEC 61850 SV Subscription (Sheet 2 of 2)

Data Field	Description
Data Set Reference	This field contains the DataSetReference (Data Set Reference) for the received SV message. When the SEL SV subscriber is configured via CID file, this field includes the iedName (IED name), ldInst (Logical Device Instance), LN0 lnClass (Logical Node Class) and SampledValueControl datSet (Data Set Name), e.g., SEL_421CFG/LLN0$PhsMeas1. When the SEL SV subscriber is configured via the PORT 5 SV settings, this field is blank.
Network Delay	This field contains the calculated real-time network delay SVND*mm*[a] for an SV subscription. When the SEL SV subscriber is in coupled clock mode (SVCC = 1) and subscribed to an SV publication (SVS*mm*OK = 1), this field contains the value of the network delay (SVND*mm*) for this particular SV subscription. If SVND*mm* > 9.99 ms, this field is $$$. When the SEL SV subscriber is not in coupled clock mode (SVCC = 0) or not subscribed to an SV publication (SVS*mm*OK = 0), this field is NA.

[a] Parameter mm = 1–7, representing the SV identifier for that SV subscription.

Table 14.45 Warning and Error Codes for SV Subscriptions (Sheet 1 of 2)

Code	Enumeration[a]	Definition	Error/Warning
–	0	No errors present.	–
–	1	The subscribing device is disabled or becomes unresponsive.	Error
MSG CORRUPTED	2	Displayed when a received SV message does not meet the proper format or is corrupted.	Error
ASDU ERROR	3	Displayed when the noASDU (Number of Application Service Data Units [ASDUs]) is greater than one. The SEL SV subscriber only supports a maximum of one ASDU per stream.	Error
SVID RANGE ERR	4	Displayed when the SVID of the received SV message is less than 1 character or greater than 63 characters long.	Error
SMPCNT RANGE ERR	5	Displayed when the out-of-range (OOR) error occurs. This error is present when the smpCnt exceeds the expected range (0–3999 for 4 kHz or 0–4799 for 4.8 kHz).	Error
CONF REV MISMA	6	Displayed when the value of the configuration revision number in the received SV message does not match with the value of the configuration revision number present in the CID file.	Error
SMPSYNC MISMA	7	Displayed when the SmpSynch of the received SV message does not match with the SmpSynch value of the first configured SV subscription. This message is also displayed if a received SV message is rejected because its SmpSynch value is zero.	Error
PDU LENGTH ERR	8	Displayed when the length of received SV message does not match with the length reported in the header of the SV message structure.	Error
INVALID QUAL	9	Displayed when any of the quality bits in *Table 14.46* are non-zero for any of the subscribed current or voltage channels (excluding the neutral channels) in a received SV message and the SEL SV subscriber is not in TEST Mode (SVSTST = 0). After three consecutive invalid SV messages are interpolated, subsequent received packets are discarded.	Error
SV STREAM LOST	10	Displayed after the SEL SV subscriber has not received four or more consecutive SV messages.	Error
CH DLY EXCEEDED	11	Displayed when the measured network delay (SVND*mm*[b]) of any subscribed SV messages exceeds the configured CH_DLY setting when in coupled clock mode (SVCC = 1).	Warning
INTERPOLATED	12	Displayed after the loss of 1–3 consecutive SV messages when the SEL SV subscriber starts to interpolate the lost SV message.	Warning

Table 14.45 Warning and Error Codes for SV Subscriptions (Sheet 2 of 2)

Code	Enumeration[a]	Definition	Error/Warning
OUT OF SEQUENC	13	Displayed when the out-of-sequence (OOS) error occurs. This error is present when the smpCnt value between the received SV messages is not sequential.	Warning
QUALITY (TEST)	14	Displayed when the TEST bit of the quality attribute in a received SV message is set and the SEL SV subscriber is in TEST mode (SVSTST = 1).	Warning
SIMULATED	–[c]	Displayed when the LPHDSIM mode in the received SV message is set.	Warning

[a] Enumerations are used to communicate SV error codes in the LSVS logical node.
[b] Parameter mm = 1–7, representing the SV identifier for that SV subscription.
[c] Simulation mode is indicated in the LSVS logical node by SimSt.stVal and is not part of the ErrSt.stVal enumeration list.

Table 14.46 details the quality bits defined by the IEC 61850-7-3:2010 standard (Section 6.2.1, Table 2) as well as the derived extension from the IEC 61850 9-2LE_R2-1 standard. If any of the quality bits (shown in italics) in *Table 14.46* is non-zero for any of the subscribed current or voltage channels excluding the neutral channels and unmapped channels in a received SV message, the corresponding incoming SV message is discarded.

Table 14.46 Quality Bits in an IEC SV Message

Attribute	Default Value
validity	Good
detailQual	
Overflow	FALSE
outOfRange	FALSE
badReference	FALSE
oscillatory	FALSE
Failure	FALSE
oldData	FALSE
inconsistent	FALSE
inaccurate	FALSE
Source	process
Test	FALSE
operatorBlocked	FALSE
Derived[a]	FALSE

[a] All values of the derived quality attribute are accepted.

Figure 14.6 gives an example response to the **COM SV** command with the SEL SV subscriber configured via CID file.

```
=>>COM SV <Enter>

IEC 61850 Mode /Behavior: On
SEL TEST SV Mode: Off
IEC 61850 Simulation Mode: Off

SV Subscription Status
```

Figure 14.6 COM SV Command Response When CID Configuration Is Used by the SEL SV Subscriber

```
 MultiCastAddr   Ptag:Vlan AppID  smpSynch    Code          Network Delay(ms)
--------------------------------------------------------------------------------
SEL_4217_MU01CFG/LLN0$MS$MU01_MSVCB01
 01-0C-CD-04-00-A1  4:5    41A1      2                            0.83
 SV ID: 41A1
 Data Set: SEL_4217_MU01CFG/LLN0$PhsMeas1

SEL_4217_MU02CFG/LLN0$MS$MU02_MSVCB01
 01-0C-CD-04-00-A2  4:5    41A2      1        SIMULATED           0.83
 SV ID: 41A2
 Data Set: SEL_4217_MU02CFG/LLN0$PhsMeas1

SEL_4217_MU03CFG/LLN0$MS$MU03_MSVCB01
 01-0C-CD-04-00-A3  4:5    41A3      2                            NA
 SV ID: 41A3
 Data Set: SEL_4217_MU03CFG/LLN0$PhsMeas1

SEL_4217_MU04CFG/LLN0$MS$MU04_MSVCB01
 01-0C-CD-04-00-A4  4:5    41A4      1        INTERPOLATED        1.83
 SV ID: 41A4
 Data Set: SEL_4217_MU04CFG/LLN0$PhsMeas1
```

Figure 14.6 COM SV Command Response When CID Configuration Is Used by the SEL SV Subscriber (Continued)

Figure 14.7 gives an example response to the **COM SV** command with the SEL SV subscriber configured via PORT 5 settings.

```
=>>COM SV <Enter>

IEC 61850 Mode /Behavior: On
SEL TEST SV Mode: Off
IEC 61850 Simulation Mode: Off

SV Subscription Status

 MultiCastAddr   Ptag:Vlan AppID  smpSynch    Code          Network Delay(ms)
--------------------------------------------------------------------------------

 01-0C-CD-04-00-A1   :     41A1      2       QUALITY (TEST)       0.63
 SV ID:
 Data Set:

 01-0C-CD-04-00-A2   :     41A2      2                            0.63
 SV ID:
 Data Set:

01-0C-CD-04-00-A3   :      41A3      2                            0.63
 SV ID:
 Data Set:

01-0C-CD-04-00-A4   :      41A4      2       INTERPOLATED         0.63
 SV ID:
 Data Set:
```

Figure 14.7 COM SV Command Response When PORT 5 Settings Are Used by the SEL SV Subscriber

Figure 14.8 gives an example response to the **COM SV S ALL L** command with the SEL SV subscriber configured via CID file.

```
=>>COM SV S ALL L <Enter>

TEST SV Mode: Off

IEC 61850 Simulation Mode: Off

SV Subscription Status

 SV SubsID 1
--------------------------------------------------------------------------------
 Ctrl Ref: SEL_4217_MU01CFG/LLN0$MS$MU01_MSVCB01
 AppID   : 41A1
 Last Update : 05/12/2017 17:42:00

 Accumulated downtime duration (since last reset)   : 0000:00:00.002
 Maximum downtime duration                          : 00.000

 #    Date          Time        Failure
 1    05/13/2017    00:30:19    SV STREAM LOST
 2    05/13/2017    00:29:05    SMPSYNC MISMA

*Note - Only the highest priority error code for each stream is displayed
```

Figure 14.8 COM SV S ALL L Command Response When CID Configuration Is Used by the SEL SV Subscriber

```
 SV SubsID 2
-------------------------------------------------------------------------------
 Ctrl Ref: SEL_4217_MU02CFG/LLN0$MS$MU02_MSVCB01
 AppID   : 41A2
 Last Update : 05/12/2017 17:42:00

 Accumulated downtime duration (since last reset)   : 0000:00:00.000
 Maximum downtime duration                          : 00.000

 #    Date          Time        Failure

*Note - Only the highest priority error code for each stream is displayed

 SV SubsID 3
-------------------------------------------------------------------------------
 Ctrl Ref: SEL_4217_MU03CFG/LLN0$MS$MU03_MSVCB01
 AppID   : 41A3
 Last Update : 05/12/2017 17:42:00

 Accumulated downtime duration (since last reset)   : 0000:01:00.000
 Maximum downtime duration                          : 50.000

 #    Date          Time        Failure
 1    05/13/2017    23:10:19    SVID RANGE ERR

*Note - Only the highest priority error code for each stream is displayed

 SV SubsID 4
-------------------------------------------------------------------------------
 Ctrl Ref: SEL_4217_MU04CFG/LLN0$MS$MU04_MSVCB01
 AppID   : 41A4
 Last Update : 05/12/2017 17:42:01

 Accumulated downtime duration (since last reset)   : 0000:00:10.006
 Maximum downtime duration                          : 00.000

 #    Date          Time        Failure

*Note - Only the highest priority error code for each stream is displayed
```

Figure 14.8 COM SV S ALL L Command Response When CID Configuration Is Used by the SEL SV Subscriber (Continued)

If the **COM SV** command is issued during CID file processing or right after an SV settings change in **PORT 5**, the relay responds with `IEC 61850 configuration is in progress. No SV statistics available.`

If the **PORT 5** settings for SV are not in use (SVTXEN = 0), and the CID file is not present or is invalid when the **COM SV** command is issued, the relay responds with `Error detected in parsing the CID file. All SV processing disabled.`

If the **PORT 5** SV settings are not in use and no SV subscriptions are configured in the CID file when the **COM SV** command is issued, the relay responds with `No SV Subscriptions configured.`

CONTROL nn

Use the **CONTROL *nn*** command to set, clear, or pulse internal Relay Word bits. Remote bits in SELOGIC control equations are similar to hardwired control inputs, in that you use these bits to affect relay operation from outside sources. For control inputs, external input to the relay comes through the rear panel; in the case of the **CON *nn*** command, external control signals come through the communications ports. See *Remote Bits on page 5.12* for information on remote bits.

Table 14.47 CON nn Command

Command	Description	Access Level
CON *nn*[a] C	Clear Remote Bit *nn*.	P, A, O, 2
CON *nn* P	Pulse Remote Bit *nn* for one processing cycle.	P, A, O, 2
CON *nn* S	Set Remote Bit *nn*.	P, A, O, 2

[a] Parameter nn is the remote bit reference for RBnn.

If you enter **CON *nn*** with no set, clear, or pulse option specified, the relay responds, `Control RBnn:`. You must then provide the control action (set, clear, or pulse) that you want to perform. (The relay checks only the first character; you can type **Set** and **Clear**.) When you issue a valid **CON** command, the relay performs the control action immediately and displays `Remote Bit Operated`.

COPY

The **COPY** command copies the settings from one class instance to another instance in the same class. For example, you can copy Group settings from one group to another. You cannot copy Group settings to Port settings.

This command is limited to the same access level as the **SET** command for the class of settings you are copying.

Table 14.48 COPY Command

Command	Description	Access Level
COPY *m n*[a]	Copy settings from instance m of the Group settings to instance n of the Group settings.	P, A, O, 2
COPY *class m n*[b]	Copy settings from instance *m* of Class *class* to instance *n* of Class *class*.	P, A, O, 2

[a] Parameters m and n are 1 to 6 for the Group class and 1, 2, 3, and F for the Port class.
[b] Parameter class is S, P, and L for Group settings, port settings, and protection SELOGIC control equations, respectively.

The parameters *m* and *n* must be valid and distinct (not the same) instance numbers. You can typically choose from classes of group (S), port (P), and protection SELOGIC control equations (L). Some SEL-400 series relays support copying additional classes. The **COPY** command is not available within the Automation class and is not available for the Breaker Monitor settings.

In addition, port settings instances must be compatible; you cannot copy from/to **PORT 5** and the other communications ports settings. You cannot copy to a port that is presently in transparent communication. If you attempt such a copy, the relay responds with `Cannot copy to a port involved in transparent communication`. In addition, you cannot copy to the present port (the port you are using to communicate with the relay). If you attempt such a copy, the relay responds with `Cannot copy port settings to present port`.

When you enter the **COPY** command with valid parameters, the relay responds with `Are you sure (Y/N)?`. Answer **Y <Enter>** (for yes) to complete copying.

If the destination instance is the active group, the relay changes to the new settings and pulses the SALARM Relay Word bit.

CPR

Use the **CPR** command to access the Signal Profile data for as many as 20 user-selectable analog values in Compressed ASCII format. Notice that the CPR records are in reverse chronological progression as compared to the PRO reports.

Table 14.49 CPR Command

Command	Description	Access Level
CPR	Displays the first 20 rows of the profile report, with the oldest row at the bottom and the latest row at the top.	1, B, P, A, O, 2
CPR *m*	Displays the first *m* rows of the profile report, with the oldest row at the bottom and the latest row at the top.	1, B, P, A, O, 2
CPR *m n (m > n)*	Displays the row between *m* and *n*, (including *m* and *n*).	1, B, P, A, O, 2
CPR *date1*	Displays all the rows that were recorded on that date, with the latest row at the bottom and the oldest row at the top.	1, B, P, A, O, 2
CPR *date1 date2*	Displays all the rows that were recorded on and between (including) *date1* and *date2* (*date1* chronologically precedes *date2*), with the latest row at the bottom and the oldest row at the top.	1, B, P, A, O, 2
CPR *date2 date1*	Displays all the rows that were recorded on and between (including) *date1* and *date2* (*date2* chronologically precedes *date1*), with the latest row at the bottom and the oldest row at the top.	1, B, P, A, O, 2
CPR TERSE	The **CPR TERSE** command omits the report labels.	1, B, P, A, O, 2

CSER

The **CSER** command provides an **SER** report in Compressed ASCII format. The default order of the **CSER** command (chronologically newest to oldest from list top to list bottom) is the reverse of the **SER** command (oldest to newest from list top to list bottom).

CSE

Use the **CSE** command to gather Sequential Events Recorder (SER) records. You can sort these records in numerical or date order.

Table 14.50 CSE Command (Sheet 1 of 2)

Command	Description	Access Level
CSE	Return all records from the SER in Compressed ASCII format, with the most recent (lowest number) at the beginning of the list and the oldest (highest number) at the end of the list.	1, B, P, A, O, 2
CSE *k*[a]	Return the *k* most recent records from the SER in Compressed ASCII format, with the most recent (lowest number) at the beginning of the list and the oldest (highest number) at the end of the list.	1, B, P, A, O, 2

Table 14.50 CSE Command (Sheet 2 of 2)

Command	Description	Access Level
CSE *m n*[b]	Return the SER records in Compressed ASCII format from *m* to *n*. If *m* is greater than *n*, then records appear with the oldest (highest number) at the beginning of the list and the most recent (lowest number) at the end of the list. If *m* is less than *n*, then records appear with the most recent (lowest number) at the beginning of the list and the oldest (highest number) at the end of the list.	1, B, P, A, O, 2
CSE *date1*[c]	Return the SER records in Compressed ASCII format on date *date1*.	1, B, P, A, O, 2
CSE *date1 date2*[c]	Return the SER records in Compressed ASCII format from date *date1* to date *date2*.	1, B, P, A, O, 2

[a] Parameter k indicates a specific number of SER records.
[b] Parameters m and n indicate an SER record number.
[c] Enter date1 and date2 in the same format as Global setting DATE_F.

CSE TERSE

The **CSE TERSE** command returns a SER report in Compressed ASCII format without labels; the relay sends only the data (including header data). You can apply the **TERSE** option with any of the **CSE** commands.

Table 14.51 CSE TERSE Command

Command	Description	Access Level
CSE TERSE	Return all SER records without the label lines in Compressed ASCII format.	1, B, P, A, O, 2
CSE *k* TERSE[a]	Return the *k* most recent SER records without the label lines in Compressed ASCII format.	1, B, P, A, O, 2
CSE *m n* TERSE[b]	Return the SER records in Compressed ASCII format from *m* to *n* without the label lines in Compressed ASCII format. If *m* is greater than *n*, then records appear with the oldest (highest number) at the beginning of the list and the most recent (lowest number) at the end of the list. If *m* is less than *n*, then records appear with the most recent (lowest number) at the beginning of the list and the oldest (highest number) at the end of the list.	1, B, P, A, O, 2
CSE *date1* TERSE[c]	Return the SER records in Compressed ASCII format on date date1 without the label lines in Compressed ASCII format.	1, B, P, A, O, 2
CSE *date1 date2* TERSE[c]	Return the SER records in Compressed ASCII format from date *date1* to date *date2* without the label lines in Compressed ASCII format.	1, B, P, A, O, 2

[a] Parameter k indicates a specific number of SER records.
[b] Parameters m and n indicate an SER record number.
[c] Enter date1 and date2 in the same format as Global setting DATE_F.

CSTATUS

The **CSTATUS** command provides a **STATUS** report in the Compressed ASCII format. The **TERSE** option eliminates the report label lines.

Table 14.52 CST Command

Command	Description	Access Level
CST	Return the relay status in Compressed ASCII.	1, B, P, A, O, 2
CST TERSE	Return the relay status in Compressed ASCII; suppress the label lines and transmit only the data lines.	1, B, P, A, O, 2

CSUMMARY

The **CSUMMARY** provides the same information as the **SUMMARY** command but in Compressed ASCII format. You can combine the *n*, **ACK**, **MB**, and **TERSE** options.

CSU

Use the **CSU** command to gather event report summaries.

Table 14.53 CSU Command

Command	Description	Access Level
CSU	Return the most recent event summary (with label lines) in Compressed ASCII format.	1, B, P, A, O, 2
CSU *n*[a]	Return a particular *n* event summary (with label lines) in Compressed ASCII format.	1, B, P, A, O, 2

[a] Parameter n indicates event order or serial number.

When parameter *n* is 1–9999, *n* indicates the order of the event report. The most recent event report is 1, the next most recent report is 2, and so on. When parameter *n* is 10000–42767, *n* indicates the absolute serial number of the event report.

CSU ACK

Use the **CSU ACK** command to acknowledge an event summary that you recently retrieved with the **CSU NEXT** command on the present communications port.

Table 14.54 CEV ACK Command

Command	Description	Access Level
CSU ACK	Acknowledge the oldest unacknowledged event summary at the present communications port for Compressed ASCII format.	1, B, P, A, O, 2

CSU MB

The **CSU MB** command causes the relay to output the labels for the MIRRORED BITS communications channel data in Compressed ASCII format.

Table 14.55 CSU MB Command

Command	Description	Access Level
CSU MB	Return the MIRRORED BITS communications channel labels.	1, B, P, A, O, 2

CSU NEXT

Use the **CSU NEXT** command to view the oldest unacknowledged event summary in Compressed ASCII format.

Table 14.56 CSU N Command

Command	Description	Access Level
CSU N	View the oldest unacknowledged event summary.	1, B, P, A, O, 2

CSU TERSE

The **TERSE** command option returns an event summary report in Compressed ASCII format without labels; the relay sends only the data (including header data).

Table 14.57 CSU TERSE Command

Command	Description	Access Level
CSU TERSE	Return the event summary report without the label lines in Compressed ASCII format.	1, B, P, A, O, 2
CSU *n*[a] **TERSE**	Return a particular *n* event summary report without the label lines in Compressed ASCII format.	1, B, P, A, O, 2
CSU N TERSE	View the oldest unacknowledged event summary without the label lines in Compressed ASCII format.	1, B, P, A, O, 2

[a] Parameter n indicates event number or serial order.

You can apply the **TERSE** option with any of the **CSU** commands except **CSU ACK** and **CSU MB**.

DATE

Use the **DATE** command to view and set the relay date. The relay can overwrite the date that you enter by using other time sources, such as IRIG and DNP3. Enter the **DATE** command with a date to set the internal clock date. You can separate the month, day, and year parameters with spaces, commas, slashes, colons, and semicolons.

Set the year in two-digit form (for dates 2000–2099) or four-digit form. If you enter the year as **12**, the relay date is 2012. You must enter the data in the format specified in the Global setting DATE_F.

If an IRIG-B time synchronization signal is connected to the relay, the DAT command cannot alter the month or day portion of the date. If the IRIG-B time SNTP time source is connected, the **DAT** command cannot alter any time setting.

Table 14.58 DATE Command

Command	Description	Access Level
DATE	Display the internal clock date.	1, B, P, A, O, 2
DATE ***date***[a]	Set the internal clock date.	1, B, P, A, O, 2

[a] Enter date parameters in the same order as Global setting DATE_F.

DNAME X

The **DNA X** command produces the ASCII names of all relay digital I/O (input/output) quantities reported in a Fast Meter message in Compressed ASCII format.

Table 14.59 DNA Command

Command	Description	Access Level
DNA X	Display ASCII names of all relay digital I/O.	0, 1, B, P, A, O, 2

DNP

The **DNP** command accesses the serial port DNP3 settings and is similar to the **SHOW D** command. Use the **DNP** or **DNP VIEW** command to show the relay serial port DNP3 settings beginning at the first setting label just like **SHOW D**. Issue the **DNP** command with any parameter *param* to set the serial port DNP3 settings; the relay begins at the first DNP3 setting just like **SET D**.

Table 14.60 DNP Command

Command	Description	Access Level
DNP	Show the serial port DNP3 settings (same as **SHOW D**).	1, B, P, A, P, O, 2
DNP VIEW	Show the serial port DNP3 settings (same as **SHOW D**).	1, B, P, A, P, O, 2
DNP *param*	Set the serial port DNP3 settings (same as **SET D**); begin at the first DNP3 setting.	P, A, O, 2

ETHERNET

The **ETH** command displays the current Ethernet port (PORT 5) configuration and status. Communications statistics, such as the number of packets, bytes, and errors received and sent, are displayed for the ports that carry standard Ethernet, DNP3 or optional IEC 61850 communications. Other commands are available to display similar statistics for ports that exclusively carry other types of traffic, for example, **COM 87L** for 87L traffic.

ETH

Use the **ETH** command when troubleshooting Ethernet connections.

Table 14.61 ETH Command

Command	Description	Access Level
ETH	Displays information about Ethernet port(s)	1, B, P, A, O, 2

Figure 14.9 shows a sample **ETH** command response for a relay with four copper Ethernet ports and **PORT 5** setting NETMODE = FAILOVER. Different Ethernet configurations and different NETMODE settings result in slightly different information being displayed.

```
==>>ETH <Enter>

Relay 1                                     Date: 03/17/2023  Time: 16:07:59.368
Station A                                   Serial Number: 1230769999

MAC 1: 00-30-A7-06-21-EE
MAC 2: 00-30-A7-06-21-EF
IP ADDRESS: 192.168.1.89/20
DEFAULT GATEWAY: 192.168.1.1

NETMODE: FAILOVER

PRIMARY PORT:      5C
ACTIVE PORT:       5D

             LINK   SPEED  DUPLEX  MEDIA
PORT 5C      Down   ---    ---     FX
PORT 5D      Up     100M   Full    TX

        PACKETS                 BYTES               ERRORS
      SENT     RCVD         SENT       RCVD      SENT    RCVD
    318292   326702     40080159   22834008         0       4
```

Figure 14.9 Sample ETH Command Response for the Two-Port Ethernet Card

Figure 14.10 shows a sample **ETH** command response for a relay with the five-port Ethernet card, BUSMODE set to INDEPEND, NETMODE and NETMODP set to PRP, and all interfaces enabled.

```
=>>ETH <Enter>

Relay 1                                     Date: 03/17/2023  Time: 14:41:24.123
Station A                                   Serial Number: 1230769999

BUSMODE: INDEPENDENT

PROCESS BUS
MODE: PRP
PORTS 5A/5B MAC: 00-30-A7-00-00-03

STATION BUS
MODE: PRP
PORTS 5C/5D MAC: 00-30-A7-00-00-04
IP ADDRESS: 192.168.1.31/24
DEFAULT GATEWAY: 192.168.1.1

ENGINEERING ACCESS
PORT 5E MAC: 00-30-A7-00-00-05
IP ADDRESS: 192.168.2.31/24
DEFAULT GATEWAY: 192.168.2.1

ETHERNET PORT STATUS
             LINK  SPEED  DUPLEX  MEDIA
-------------------------------------------------------------------
PORT 5A      Up    1000M  Full    SX
PORT 5B      Up    1000M  Full    SX
PORT 5C      Up    100M   Full    FX
PORT 5D      Up    100M   Full    FX
PORT 5E      Up    100M   Full    FX

PACKET COUNT
             SENT     RCVD     DISC     ERROR
-------------------------------------------------------------------
PORT 5A    284003  4238102        0        0
PORT 5B    283878  4238078        0        0
PORT 5C    137629   418243   355859        0
PORT 5D    137609   961288   960074        0
PORT 5E     12020    14880      640        0

SFP TRANSCEIVER INFO
             RX Power(dBm)  TX Power(dBm)  Temp(C)
-------------------------------------------------------------------
PORT 5A       -15.90        -17.06          41.1
PORT 5B       -33.98        -17.14          41.0
PORT 5C       -18.73        -17.06          40.2
PORT 5D       -18.01        -17.14          39.6
PORT 5E       -18.12        -17.08          49.2

=>>
```

Figure 14.10 Sample ETH Command Response for the Five-Port Ethernet Card

ETH C and ETH R

The **ETH C** and **ETH R** commands clear the Ethernet connection statistics. Option **C** and **R** are identical.

Table 14.62 ETH C and ETH R Command

Command	Description	Access Level
ETH C	Clears the statistics on PORT 5 Ethernet connection	1, B, P, A, O, 2
ETH R	Clears the statistics on PORT 5 Ethernet connection	1, B, P, A, O, 2

When you issue the **ETH C** and **ETH R** command, the relay sends the following prompt: `Are you sure (Y/N)?`. If you answer **Y <Enter>**, the relay clears the Ethernet statistics and response: `Ethernet Statistics Cleared`.

EVENT

NOTE: The SEL-400G relay does not support 4-sample/cycle events. Filtered and unfiltered events are presented in the COMTRADE format.

Use the **EVENT** command to view the relay filtered event reports (see *Event Report on page 9.14* for information on event reports).

EVE

The **EVE** command displays the full-length event reports stored in relay memory. When parameter *n* is 1–9999, *n* indicates the order of the event report. The most recent event report is 1, the next most recent report is 2, and so on. When parameter *n* is 10000–42767, *n* indicates the absolute serial number of the event report.

Table 14.63 EVE Command

Command	Description	Access Level
EVE	Return the most recent event report (including settings and summary) at full length with 4-samples/cycle data.	1, B, P, A, O, 2
EVE *n*[a]	Return a particular n event report (including settings and summary) at full length with 4-samples/cycle data.	1, B, P, A, O, 2

[a] Parameter n indicates event order or serial number.

EVE A

The **EVE A** command returns only the analog information in the event report.

Table 14.64 EVE A Command

Command	Description	Access Level
EVE A	Return only the analog information for the most recent event report with 4-samples/cycle data.	1, B, P, A, O, 2
EVE A ***n***[a]	Return only the analog information for a particular n event report with 4-samples/cycle data.	1, B, P, A, O, 2

[a] Parameter n indicates event order or serial number; see EVE on page 14.33.

EVE ACK

Use **EVE ACK** to acknowledge the oldest unacknowledged event that you recently viewed with the **EVE NEXT** or the **CEV NEXT** commands on the present communications port.

Table 14.65 EVE ACK Command

Command	Description	Access Level
EVE ACK	Acknowledge the oldest unacknowledged event at the present communications port.	1, B, P, A, O, 2

If you attempt to acknowledge an event summary that you have not viewed on the present port with the **EVE NEXT** command, the relay responds with `Event summary number n has not been viewed with the NEXT option`.

EVE C

Use **EVE C** to return a 15-cycle length event report with both analog and digital data. You cannot mix the A and D options with the **EVE C** command. The L*yyy* option overrides the C option (see *EVE Lyyy on page 14.35*).

Table 14.66 EVE C Command

Command	Description	Access Level
EVE C	Return the most recent event report at a 15-cycle length with large resolution data.	1, B, P, A, O, 2
EVE C *n*[a]	Return a particular *n* event report at a 15-cycle length with large resolution data.	1, B, P, A, O, 2

[a] Parameter n indicates event order or serial number; see EVE on page 14.33.

EVE D

Use **EVE D** to return only the digital information in the event report.

Table 14.67 EVE D Command

Command	Description	Access Level
EVE D	Return only the digital information for the most recent event report with 4-samples/cycle data.	1, B, P, A, O, 2
EVE D *n*[a]	Return only the digital information for a particular n event report with 4-samples/cycle data.	1, B, P, A, O, 2

[a] Parameter n indicates event order or serial number; see EVE on page 14.33.

EVE L

Use **EVE L** to return a large resolution event report. The **S*x*** option overrides the **L** option (see *EVE Sx on page 14.36*).

Table 14.68 EVE L Command

Command	Description	Access Level
EVE L	Return the most recent event report at full length with large resolution data.	1, B, P, A, O, 2
EVE *n*[a] L	Return a particular *n* event report at full length with large resolution data.	1, B, P, A, O, 2

[a] Parameter n indicates event order or serial number.

EVE Lyyy

Command **EVE L*yyy*** returns a specified length event report, where **L*yyy*** indicates a length of *yyy* cycles. You can specify *yyy* from 1 cycle up to a value including and exceeding the event report total cycle length. If *yyy* is longer than the total length, the relay returns the full duration event report. The **L*yyy*** option overrides the **C** option.

Table 14.69 EVE Lyyy Command

Command[a]	Description	Access Level
EVE L*yyy*	Return *yyy* cycles of the most recent event report (including settings) with 4-samples/cycle data.	1, B, P, A, O, 2
EVE *n* L*yyy*	Return *yyy* cycles of a particular n event report with 4-samples/cycle data.	1, B, P, A, O, 2

[a] Parameter n indicates event order or serial number; see EVE on page 14.33.

EVE NEXT

EVE NEXT returns the oldest unacknowledged event report on the present communications port.

Table 14.70 EVE N Command

Command	Description	Access Level
EVE N	Return the oldest unacknowledged event report with 4-samples/cycle data.	1, B, P, A, O, 2

EVE NSET

The **EVE NSET** command returns the event report with no relay settings.

Table 14.71 EVE NSET Command

Command	Description	Access Level
EVE NSET	Return the most recent event report without settings at full length with 4-samples/cycle data.	1, B, P, A, O, 2
EVE *n*[a] NSET	Return a particular n event report without settings at full length with 4-samples/cycle data.	1, B, P, A, O, 2

[a] Parameter n indicates event order or serial number; see EVE on page 14.33.

EVE NSUM

The **EVE NSUM** returns the event report with no event summary.

Table 14.72 EVE NSUM Command

Command	Description	Access Level
EVE NSUM	Return the most recent event report without the event summary at full length with 4-samples/cycle data.	1, B, P, A, O, 2
EVE *n*[a] NSUM	Return a particular n event report without the event summary at full length with 4-samples/cycle data.	1, B, P, A, O, 2

[a] Parameter n indicates event order or serial number.

EVE Sx

Use the **EVE S*x*** command to specify the sample data resolution of the event report. The sample data resolution x is either 4-samples/cycle or large resolution; the default value is 4-samples/cycle if you do not specify **S*x***. The **S*x*** option overrides the **L** option.

Table 14.73 EVE Sx Command

Command	Description	Access Level
EVE S*x*	Return the most recent event report at full length with *x*-samples/cycle data.	1, B, P, A, O, 2
EVE *n*[a] S*x*	Return a particular n event report at full length with *x*-samples/cycle data.	1, B, P, A, O, 2

[a] Parameter n indicates event order or serial number; x is 4, 8, or 12 to represent data at 4 samples/cycle, 8 samples/cycle, or 12 samples/cycle respectively. See the product-specific instruction manual to see whether 8 or 12 samples/cycle are supported for larger resolution reports.

EVE Command Option Combinations

You can combine options **C**, **L**, **L*yyy***, ***n***, **NSET**, **NSUM**, and **S*x***, in one command. Enter the options according to the following guidelines:

- The **L*yyy*** option overrides the **C** option.
- The **S*x*** option overrides the **L** option.
- When choosing option **A** or option **D** as a report type, you cannot use option **C** to specify the report length at 15 cycles. Use option **L*yyy*** at L015 to specify a 15-cycle report.
- Enter the options in any order.

Table 14.74 lists the choices you can make in the **EVE** command. Combine options on each row, selecting one option from each column, to create an **EVE** command.

Table 14.74 EVE Command Option Groups

Acknowledge	Event Number	Data Resolution	Report Type	Report Length	Omit
ACK	***n*, NEXT**	**S*x*, L**	**C, A, D**	**L*yyy*, C**	**NSET, NSUM**

The following examples illustrate some possible option combinations.

Table 14.75 EVE Command Examples

Example	Description
EVE L010 S8	Return 10 cycles of an 8-samples/cycle event report for the most recent event.
EVE L10 A	Return 10 cycles of the analog portion only of the most recent event report at 4-samples/cycle resolution.
EVE 2 C NSUM	For the second most recent event, return the event with 8-samples/cycle data, and omit the event summary.

EXIT

Use the **EXIT** command to terminate a Telnet session and revert to Access Level 0 (exit relay control).

Table 14.76 EXIT Command

Command	Description	Access Level
EXIT	Terminate the Ethernet port Telnet sessions and go to Access Level 0 (exit relay control)	0, 1, B, P, A, O, 2

FILE

The **FILE** command provides a safe and efficient means of transferring files between IEDs and external support software (ESS) by providing Ymodem file transfer. The **FILE** commands are especially useful for retrieving high-resolution sampled data in binary COMTRADE format from the relay.

Table 14.77 FILE Command

Command	Description	Access Level
FILE DIR ***directory***	Returns a list of filenames in specified directory *(directory)*. If not specified, then the list of files and directories in the root directory is returned.	1, B, P, A, O, 2
FILE READ ***directory filename***	Initiates a file transfer of the file *filename* (in the folder *directory*) from the relay to ESS. The *filename* parameter is required.	1, B, P, A, O, 2
FILE WRITE SETTINGS ***filename***	Initiates a file transfer of the file *filename* from ESS to the relay. If the *filename* parameter is not specified, the file name must be given in the Ymodem header.	P, A, O, 2

All text enclosed in [brackets] indicates optional command line parameters. The specific directories available in the relay depends on the relay model, but typically includes EVENTS, REPORTS, SETTINGS, and SYNCHROPHASOR directories. For **FILE READ** operations, specify the directory parameters as needed. The **FILE WRITE** command is available only for the SETTINGS directory.

GOOSE

Use the **GOOSE** command to display transmit and receive GOOSE messaging information, which can be used for troubleshooting.

Table 14.78 GOOSE Command

Command	Description	Access Level
GOOSE	Displays GOOSE information	1, B, P, A, O, 2
GOOSE *k*	Displays GOOSE information successively for *k* times	1, B, P, A, O, 2

The information displayed for each GOOSE IED is described in *Table 14.79*.

Table 14.79 Accessible GOOSE IED Information

IED	Description
Transmit GOOSE Control Reference	This field represents the GOOSE control reference information that includes the IED name, ldInst (Logical Device Instance), LN0 lnClass (Logical Node Class), and GSEControl name (GSE Control Block Name) (e.g., SEL_411L_OtterCFG/LLN0$DSet13).
Receive GOOSE Control Reference	This field shall contain the goCbRef (GOOSE Control Block Reference) information that includes the iedName (IED name), ldInst (Logical Device Instance), LN0 lnClass (Logical Node Class) and cbName (GSE Control Block Name) (e.g., SEL_411L_1CFG/LLN0$DSet13).
Multicast Address (MultiCastAddr)	This hexadecimal field represents the GOOSE multicast address.
Priority Tag (Ptag)	This three-bit decimal field represents the priority tag value, where spaces are used if the priority tag is unknown.
VLAN (Vlan)	This 12-bit decimal field represents the virtual LAN setting, where spaces are used if the virtual LAN is unknown.
State Number (StNum)	This hexadecimal field represents the state number that increments with each state change.
Sequence Number (SqNum)	This hexadecimal field represents the sequence number that increments with each GOOSE message sent.
Time to Live (TTL)	This field contains the time (in ms) before the next message is expected.
Transmit Data Set Reference	This field represents the datSetRef (Data Set Reference) that includes the IED name, LN0 lnClass (Logical Node Class), and GSEControl datSet (Data Set Name) (e.g., SEL_411L_1CFG/LLN0$DSet13).
Receive Data Set Reference	This field represents the datSetRef (Data Set Reference) that includes the iedName (IED name), ldInst (Logical Device Instance), LN0 lnClass (Logical Node Class) and datSet (Data Set Name) (e.g., SEL_411L_1CFG/LLN0$DSet13).

Table 14.80 Warning and Error Codes for GOOSE Subscriptions (Sheet 1 of 2)

Code	Enumeration[a]	Definition	Error/Warning
–	0	No errors present.	–
HOST DISABLED	1	Optional code for when the subscribing device is disabled or becomes unresponsive after the **GOOSE** command has been issued.	Error
CONF REV MISMA	2	Configuration revision mismatch. Displayed when the value of the configuration revision number in the received GOOSE message does not match with the value of the configuration revision number present in the CID file.	Error
NEED COMMISSIO	3	Needs commissioning. Displayed when the received GOOSE message has NdsCom = true.	Error
MSG CORRUPTED	4	Message corrupted. Displayed when a received GOOSE message does not meet the proper format or is corrupted.	Error
TTL EXPIRED	5	Time-to-live expired.	Error

Table 14.80 Warning and Error Codes for GOOSE Subscriptions (Sheet 2 of 2)

Code	Enumeration[a]	Definition	Error/Warning
OUT OF SEQUENC	6	Out-of-sequence (OOS) error. This error is present when the StNum or SqNum value between received GOOSE messages is not sequential.	Warning
INVALID QUAL	7	Invalid data quality received	Warning

[a] Enumerations are used to communicate GOOSE error codes in the LGOS logical node.

An example response to the **GOOSE** command is shown in *Figure 14.11*.

```
=>>GOOSE <Enter>

GOOSE Transmit Status

   MultiCastAddr   Ptag:Vlan  StNum      SqNum      TTL    Code
-------------------------------------------------------------------------------

SEL_411L_OtterCFG/LLN0$GO$GooseDSet13
   01-0C-CD-01-00-10  4:1     1          166        457
   Data Set: SEL_411L_OtterCFG/LLN0$DSet13

GOOSE Receive Status

   MultiCastAddr   Ptag:Vlan  StNum      SqNum      TTL    Code
-------------------------------------------------------------------------------

SEL_411L_1CFG/LLN0$GO$GooseDSet13
   01-0C-CD-01-00-04   :      0          0          0      TTL EXPIRED
   Data Set: SEL_487B_1CFG/LLN0$DSet13


SEL_2440_1CFG/LLN0$GO$GooseDSet13
   01-0C-CD-01-00-0A   :      0          0          0      TTL EXPIRED
   Data Set: SEL_2440_1CFG/LLN0$DSet13


SEL_487E_1CFG/LLN0$GO$GooseDSet13
   01-0C-CD-01-00-10   :      0          0          0      TTL EXPIRED
   Data Set: SEL_487E_1CFG/LLN0$DSet13

SEL_710_1CFG/LLN0$GO$GooseDSet13
   01-0C-CD-01-00-08   :      0          0          0      TTL EXPIRED
   Data Set: SEL_710_1CFG/LLN0$DSet13

IEC 61850 Mode/Behavior: Blocked
IEC 61850 Simulation Mode: On
```

Figure 14.11 GOOSE Command Response for the Two- or Four-Port Ethernet Card

If the **GOOSE** command is issued during CID file processing, the relay responds with `CID file is currently being processed. No GOOSE statistics available`. When **GOOSE** is disabled by settings (EGSE = N), the relay sends `Command is not available` in responding to a **GOOSE** command. If an error is detected during the processing of the IEC 61850 file, the relay responds with `Error detected in parsing the CID file. All GOOSE processing disabled` to a **GOOSE** command.

GOO S

The **GOO S** command provides statistics for GOOSE subscriptions.

Table 14.81 GOO S Command (Sheet 1 of 2)

Command	Description	Access Level
GOO S	Display a list of GOOSE subscriptions with their ID.	1,B,P,A,O,2
GOO S *n*	Display GOOSE statistics for subscription ID *n*.	1,B,P,A,O,2
GOO S ALL	Display GOOSE statistics for all subscriptions.	1,B,P,A,O,2
GOO S *n* L	Display GOOSE statistics for subscription ID *n* including error history.	1,B,P,A,O,2

Table 14.81 GOO S Command (Sheet 2 of 2)

Command	Description	Access Level
GOO S ALL L	Display GOOSE statistics for all subscriptions including error history.	1,B,P,A,O,2
GOO S *n* C	Clear GOOSE statistics for subscription ID *n*.	1,B,P,A,O,2
GOO S ALL C	Clear GOOSE statistics for all subscriptions.	1,B,P,A,O,2

When reporting a list of subscriptions with the **GOO S** command, the response includes the subscription ID, the application identifier, and the GOOSE control block reference. The other variants of **GOO S** provide statistics on the selected subscriptions. *Figure 14.12* and *Figure 14.13* illustrates this.

```
=>>GOO S 2 <Enter>

 SubsID 2
-------------------------------------------------------------------------------
 Ctrl Ref: GOOSE_SIM_CFG/LLN0$GO$GooseDSet02
 AppID   : 4114
 From    : 06/30/2014 10:59:29.760  To: 06/30/2014 11:10:32.817

 Accumulated downtime duration                      : 0000:10:59.325
 Maximum downtime duration                          : 0000:10:59.325
 Date & time maximum downtime began                 : 06/30/2014 10:59:33.492
 Number of messages received out-of-sequence(OOS)   : 0
 Number of time-to-live(TTL) violations detected    : 1
 Number of messages received with invalid quality   : 1
 Number of messages incorrectly encoded or corrupted: 654
 Number of messages lost due to receive overflow    : 0
 Calculated max. sequential messages lost due to OOS: 0
 Calculated number of messages lost due to OOS      : 0
```

Figure 14.12 Example GOO S Command Response

```
=>>GOO S ALL L <Enter>

 SubsID 1
-------------------------------------------------------------------------------
 Ctrl Ref: GOOSE_SIM_CFG/LLN0$GO$GooseDSet01
 AppID   : 4113
 From    : 07/01/2014 11:23:13.851  To: 07/01/2014 11:37:54.790

 Accumulated downtime duration                      : 0000:00:34.002
 Maximum downtime duration                          : 0000:00:13.000
 Date & time maximum downtime began                 : 07/01/2014 11:35:36.048
 Number of messages received out-of-sequence(OOS)   : 4
 Number of time-to-live(TTL) violations detected    : 0
 Number of messages received with invalid quality   : 1
 Number of messages incorrectly encoded or corrupted: 0
 Number of messages lost due to receive overflow    : 0
 Calculated max. sequential messages lost due to OOS: 12
 Calculated number of messages lost due to OOS      : 30

 #    Date        Time          Duration        Failure
 1    07/01/2014  11:37:02.051  0000:00:01.000  OUT OF SEQUENCE
 2    07/01/2014  11:36:59.051  0000:00:03.000  CONF. REV. MISMATCH
 3    07/01/2014  11:36:38.050  0000:00:00.999  OUT OF SEQUENCE
 4    07/01/2014  11:36:29.049  0000:00:09.000  NEEDS COMMISSIONING
 5    07/01/2014  11:36:09.049  0000:00:00.999  OUT OF SEQUENCE
 6    07/01/2014  11:36:03.049  0000:00:06.000  CONF. REV. MISMATCH
 7    07/01/2014  11:35:48.048  0000:00:00.999  OUT OF SEQUENCE

 SubsID 2
-------------------------------------------------------------------------------
 Ctrl Ref: GOOSE_SIM_CFG/LLN0$GO$GooseDSet02
 AppID   : 4114
 From    : 07/01/2014 11:37:45.158  To: 07/01/2014 11:37:54.796
```

Figure 14.13 Example GOO S ALL L Command Response

```
Accumulated downtime duration                      : 0000:00:09.638
Maximum downtime duration                          : 0000:00:09.638
Date & time maximum downtime began                 : 07/01/2014 11:37:45.158
Number of messages received out-of-sequence(OOS)   : 0
Number of time-to-live(TTL) violations detected    : 0
Number of messages received with invalid quality   : 1
Number of messages incorrectly encoded or corrupted: 0
Number of messages lost due to receive overflow    : 0
Calculated max. sequential messages lost due to OOS: 0
Calculated number of messages lost due to OOS      : 0

#    Date        Time          Duration        Failure
```

Figure 14.13 Example GOO S ALL L Command Response (Continued)

GROUP

Use the **GROUP** command to view the present group number or to change the active group.

Table 14.82 GROUP Command

Command	Description	Access Level
GROUP	Display the presently active group.	1, B, P, A, O, 2
GROUP *n* [a]	Change the active group to Group n.	B, P, A, O, 2

[a] Parameter n indicates group numbers 1–6.

When you change the active group, the relay responds with a confirmation prompt: `Are you sure (Y/N)?`. Answer **Y <Enter>** to change the active group. The relay asserts the Relay Word bit SALARM for at least one second when you change the active group.

If any of the SELOGIC control equations SS1–SS6 are set when you issue the **GROUP *n*** command, the group change will fail. The relay responds with `No group change: SELogic equations SS1-SS6 have priority over GROUP command.`

HELP

The **HELP** command gives a list of commands available at the present access level. You can also get a description of any particular command; type **HELP** followed by the name of the command for help on each command.

Table 14.83 HELP Command

Command	Description	Access Level
HELP	Display a list of each command available at the present access level with a one-line description.	1, B, P, A, O, 2
HELP *command*	Display information on the command *command*.	1, B, P, A, O, 2

HISTORY

The **HISTORY** command displays a quick synopsis of the last 100 events that the relay has captured. The rows in the **HISTORY** report typically contains the event serial number, date, time, location, maximum current, active group, and targets. (The specific content depends on the relay.) See *Section 9: Reporting* and *Section 7: Metering, Monitoring, and Reporting* in the product-specific instruction manual for more information on history reports.

HIS

Use the **HIS** command to list one-line descriptions of relay events. You can list event histories by number or by date.

Table 14.84 HIS Command

Command	Description	Access Level
HIS	Return event histories with the oldest at the bottom of the list and the most recent at the top of the list.	1, B, P, A, O, 2
HIS *k*[a]	Return the *k* most recent event histories with the oldest at the bottom of the list and the most recent at the top of the list.	1, B, P, A, O, 2
HIS *date1*[b]	Return the event histories on date *date1*.	1, B, P, A, O, 2
HIS *date1 date2*[b]	Return the event histories from *date1* to *date2*, with *date1* at the bottom of the list and *date2* at the top of the list.	1, B, P, A, O, 2

[a] Parameter k indicates an event number.
[b] Enter date1 and date2 in the order selected by the Global setting DATE_F.

HIS C and HIS R

The **HIS C** and **HIS R** commands clear/reset the history data and corresponding high-resolution/event report data on the present port. Options **C** and **R** are identical.

Table 14.85 HIS C and HIS R Commands

Command	Description	Access Level
HIS C	Clear/reset event data on the present port only.	1, B, P, A, O, 2
HIS R	Clear/reset event data on the present port only.	1, B, P, A, O, 2

The relay prompts you with `Are you sure (Y/N)?` when you issue the **HIS C** and **HIS R** commands. If you answer **Y <Enter>**, the relay clears the present port history data.

HIS CA and HIS RA

The **HIS CA** and **HIS RA** commands clear all history data and event reports from memory. Use these commands to completely delete high-resolution/event report data captures.

Table 14.86 HIS CA and HIS RA Commands

Command	Description	Access Level
HIS CA	Clear all event data for all ports.	P, A, O, 2
HIS RA	Clear all event data for all ports.	P, A, O, 2

If you issue the **HIS CA** and **HIS RA** commands, the relay prompts you with `Are you sure (Y/N)?`. If you answer **Y <Enter>**, the relay clears all history data and event reports. The relay resets the event report number to 10000.

ID

Use the **ID** command to extract relay identification codes.

Table 14.87 ID Command

Command	Description	Access Level
ID	Return a list of relay identification codes.	0, 1, B, P, A, O, 2

Each line of the **ID** command report contains an identification code and a line checksum. The relay presents these codes in the following order:

FID: the Firmware Identification string

BFID: the Boot Firmware Identification string

CID: the checksum of the firmware

DEVID: the RID string as stored in the relay settings of the IED

DEVCODE: a unique Device Code (for Modbus identification purposes)

PARTNO: the Part Number

SERIALNO: the serial number of the relay

CONFIG: abcdef

The designator positions indicate a specific relay configuration:

"a" represents the nominal frequency, where 0 = N/A, 1 = 60 Hz, and 2 = 50 Hz.

"b" represents the phase rotation, where 0 = N/A, 1 = ABC, and 2 = ACB.

"c" represents the phase input current scaling, where 0 = N/A, 1 = 5 A, and 2 = 1 A.

"d" represents the neutral input current scaling, where 0 = N/A, 1 = 5 A, 2 = 1 A.

"e" represents the voltage input connection, where 0 = N/A, 1 = Delta, and 2 = Wye.

"f" represents the current input connection, where 0 = N/A, 1 = Delta, and 2 = Wye.

SPECIAL: the Special Configuration Designators—a mechanism for anticipating future product enhancements

If the device supports IEC 61850 and the IEC 61850 protocol is enabled, the **ID** command will display the following additional information.

- iedName: the IED name (e.g., SEL-411L_OtterTail)
- type: the IED type (e.g., SEL-411L)
- configVersion: the CID file configuration version (e.g., ICD-411L-R100-V0-Z001001-20060512)
- LIB61850ID: an eight-character code indicating the IEC 61850 library version within the product

A sample **ID** command response from the relay (with IEC 61850 enabled) is shown in *Figure 14.14*.

```
=ID <ENTER>
"FID=SEL-451-5-R319-V0-Z024013-D20170608","0916"
"BFID=SLBT-4XX-R209-V0-Z001002-D20150130","097C"
"CID=85F4","0264"
"DEVID=Relay 1","0467"
"DEVCODE=40","030B"
"PARTNO=04515415XC4X4H60X0XXX","07B3"
"SERIALNO=1230769999","0517"
"CONFIG=11102200","03EA"
"SPECIAL=000000","03CE"
"iedName=SEL_451_1","05CD"
"type=SEL_451","044C"
"configVersion=ICD-451-R301-V0-Z316006-D20170130","0D1C"
"LIB61850ID=9048BE8A","04EA"

=
```

Figure 14.14 Sample ID Command Response From Ethernet Card

IRIG

The **IRIG** command directs the relay to use the next available demodulated IRIG-B time code to update the relay internal clock. For information on the IRIG time mode, see *IRIG-B Timekeeping on page 11.1*.

Table 14.88 IRIG Command

Command	Description	Access Level
IRIG	Lock the relay internal clock to the IRIG-B time-code input.	1, B, P, A, O, 2

NOTE: Not all SEL-400 series relays support the **IRIG** command.

The **IRIG** command was originally provided in the relay as a testing aid. The **IRIG** command was used to update the relay internal clock with the IRIG-B time value without waiting for the 30-second confirmation time delay.

There is no longer a 30-second confirmation time delay—the relay uses the IRIG time source as soon as it determines that the signal is valid, a process that may take several seconds. Once the IRIG signal is verified, the relay clock is updated once per second. The **IRIG** command is still available, but is no longer necessary. To check IRIG status, use the **TIME Q** command instead—see *TIME Q Command on page 11.8*.

If the relay has no valid IRIG-B time code at the rear panel, or if the **TIME Q** command reports a relay time source other than IRIG or HIRIG, the relay responds to the **IRIG** command with the following error message, `IRIG-B DATA ERROR`. See the **TIME** command for more information.

LOOPBACK

Use the **LOOPBACK** command to instruct the relay to receive the transmitted MIRRORED BITS communications data on the same serial port. See *SEL MIRRORED BITS Communication on page 15.36* for more information on MIRRORED BITS communications.

LOOP

The **LOOP** command puts the relay serial port in loopback if you have previously configured the port for MIRRORED BITS communications. If you have enabled both of the MIRRORED BITS communications channels (A and B), then you must specify the channel parameter. If you have only one of the channels

enabled, then the relay assumes that channel if you do not specify that channel in the command. If you do not specify a time-out period, the relay provides a 5-minute time-out.

Table 14.89 LOOP Command

Command	Description	Access Level
LOOP	Begin loopback of a single enabled MIRRORED BITS communications channel (either Channel A or Channel B) for 5 minutes; ignore input data and force receive bits (RMB) to defaults.	P, A, O, 2
LOOP *c*[a]	Begin loopback of MIRRORED BITS communications Channel *c* for 5 minutes; ignore input data and force receive bits (RMB) to defaults.	P, A, O, 2
LOOP *t*	Begin loopback of a single MIRRORED BITS communications channel (either Channel A or Channel B) and end the loopback after time-out *t* minutes; ignore input data and force receive bits (RMB) to defaults; *t* range is 1–5000 minutes.	P, A, O, 2
LOOP *t c*	Begin loopback of a single MIRRORED BITS communications channel (either Channel A or Channel B) and end the loopback after time-out t minutes; ignore input data and force receive bits (RMB) to defaults; *t* range is 1–5000 minutes.	P, A, O, 2

[a] Parameter c is A or B, representing Channel A or Channel B.

You can enter the options in any order. If you operate the relay by using both MIRRORED BITS communications channels (A and B), then you must specify the channel parameter by using the **LOOP A** command and the **LOOP B** command.

When you issue the **LOOP** command, the relay responds with statements about the loopback time, status of the RMB (Receive MIRRORED BITS), and `Are you sure (Y/N)?`. If you answer **Y <Enter>**, the relay responds with `Loopback Mode Started`.

In the loopback mode, ROK drops out and the relay uses LBOK to indicate whether the data transmissions are satisfactory. The relay collects COM data as usual. Time synchronization and virtual terminal modes are not available during loopback. The relay continues passing analog quantities.

LOOP DATA

The **LOOP DATA** command tells the relay to pass input MIRRORED BITS communications data through to the receive (RMB) bits, as in the nonloopback mode.

Table 14.90 LOOP DATA Command

Command	Description	Access Level
LOOP DATA	Begin loopback of a single MIRRORED BITS communications channel (either Channel A or Channel B) for 5 minutes: pass input data to receive data as in nonloopback mode.	P, A, O, 2
LOOP *c* DATA	Begin loopback of MIRRORED BITS communications Channel *c* only for 5 minutes: pass input data to receive data as in nonloopback mode.	P, A, O, 2
LOOP *c* DATA *t*	Begin loopback of MIRRORED BITS communications Channel *c* only for *t* minutes: pass input data to receive data as in nonloopback mode.	P, A, O, 2

The relay ignores received values if you do not specify the **DATA** option. You can enter the options in any order.

LOOP R

The **LOOP R** command terminates the loopback condition on MIRRORED BITS communications channels in loopback. If you do not specify a Channel *c*, then the relay disables loopback on both channels. If you specify a channel, you can enter the options in any order.

Table 14.91 LOOP R Command

Command	Description	Access Level
LOOP R	Cease loopback on all MIRRORED BITS communications channels. (Reset the channels to normal use.)	P, A, O, 2
LOOP *c* R	Cease loopback on MIRRORED BITS communications Channel *c*. (Reset Channel *c* to normal use.)	P, A, O, 2

MAC

The **MAC** command returns the Media Access Control (MAC) addresses of the Ethernet ports.

Table 14.92 MAC Command

Command	Description	Access Level
MAC	Display all Ethernet ports MAC addresses	1, B, P, A, O, 2

A sample **MAC** command response for a relay with the four-port Ethernet card is shown in *Figure 14.15*.

```
=>>MAC <Enter>
Port 5-1 MAC Address:  01-30-A7-00-00-01
Port 5-2 MAC Address:  01-30-A7-00-00-02
```

Figure 14.15 Sample MAC Command Response for the Two- or Four-Port Ethernet Card

A sample **MAC** command response for a relay with the five-port Ethernet card is shown in *Figure 14.16*. The first MAC address is associated with the station bus, the second with the process bus, and the third with the engineering access network.

```
=>MAC <Enter>
Port 5-1 MAC Address:  00-30-A7-00-00-03
Port 5-2 MAC Address:  00-30-A7-00-00-04
Port 5-3 MAC Address:  00-30-A7-00-00-05
=>
```

Figure 14.16 Sample MAC Command Response for the Five-Port Ethernet Card

MAP

Use the **MAP** command to view the organization of the relay database. The **MAP** command in the relay is very similar to the **MAP** command in the SEL-2020 and SEL-2030 Communications Processors.

MAP 1

The **MAP 1** command lists the relay database regions. Typical database region names are LOCAL, METER, DEMAND, TARGET, HISTORY, BREAKER, STATUS, and ANALOGS.

Table 14.93 MAP 1 Command

Command	Description	Access Level
MAP 1	List the database regions in the relay.	1, B, P, A, O, 2

MAP 1 region and MAP 1 region BL

Use the **MAP 1** command with the region option to view the layout of a specific region.

Table 14.94 MAP 1 region Command

Command	Description	Access Level
MAP 1 ***region***	List the data labels, database address, and data type.	1, B, P, A, O, 2
MAP 1 ***region*** **BL**	List the data labels, database address, and data type; list the bit labels, if assigned.	1, B, P, A, O, 2

The *region* option is the database region name shown in the simple **MAP 1** command response. The region map consists of columns for data item labels, database address, and data type.

If you specify the **BL** option and the region contains items with bit labels, the relay lists these bit labels in MSB (most significant bit) to LSB (least significant bit) order. The TARGET region is usually the only region containing bit labels.

METER

The **METER** command displays reports about quantities the relay measures in the power system (voltages, currents, frequency, remote analogs, and so on) and internal relay operating quantities (math variables and synchronism-check values).

All SEL-400 series relays support a **METER** command, but the options and responses are device specific. See the product-specific instruction manual for details of the **METER** command. Included below are the variants of the **METER** command that are common.

MET AMV

The **MET AMV** command lists automation math variables.

Table 14.95 MET AMV Command

Command	Description	Access Level
MET AMV	Display all automation math variables.	1, B, P, A, O, 2
MET AMV ***k***	Display all automation math variables successively for *k* times.	1, B, P, A, O, 2

The relay displays three places after the decimal point for these numerals. The relay shows variables with absolute value greater than 99999.999 or less than 0.100 as scientific notation (for example, –1.002E+22).

MET ANA

Use the **MET ANA** command to view the analog quantities from the MIRRORED BITS communications channels.

Table 14.96 MET ANA Command

Command	Description	Access Level
MET ANA	Display the MIRRORED BITS communications analog quantities.	1, B, P, A, O, 2
MET ANA *k*	Display the MIRRORED BITS communications analog quantities successively for *k* times.	1, B, P, A, O, 2

If you have not enabled the MIRRORED BITS communications channels and the remote analog data, the relay response to this command will not include any values. If MIRRORED BITS communications is enabled but not communicating, the relay will display `ERROR` under the `RMBA` or `RMBB` entries, depending on settings.

MET BAT

Use the **MET BAT** command to view the station dc monitor quantities for the battery voltages.

NOTE: Some relays provide one battery monitor channel and some support two.

Table 14.97 MET BAT Command

Command	Description	Access Level
MET BAT	Display station battery measurements.	1, B, P, A, O, 2
MET BAT *k*	Display station battery measurements successively for *k* times.	1, B, P, A, O, 2
MET RBM	Reset station battery measurements.	P, A, O, 2

If you have not enabled the Station DC Battery Monitor, the relay responds with `DC Monitor Is Not Enabled`. (Enable the dc monitor with the Global setting EDCMON.)

The reset command, **MET RBM**, resets the dc monitor maximum/minimum metering quantities. When you issue the **MET RBM** command, the relay responds with `Reset Max/Min Battery Metering (Y/N)?`. If you answer **Y <Enter>**, the relay responds, `Max/Min Battery Reset`.

MET D

Use the **MET D** command to view the demand and peak demand quantities.

NOTE: Not all SEL-400 series relays support demand metering.

Table 14.98 MET D Command

Command	Description	Access Level
MET D	Display demand metering data.	1, B, P, A, O, 2
MET D *k*	Display demand metering data successively for *k* times	1, B, P, A, O, 2
MET RD	Reset demand metering data.	P, A, O, 2
MET RP	Reset peak demand metering data.	P, A, O, 2

The reset command (**MET RD**) resets the demand metering quantities. When you issue the **MET RD** command, the relay responds, `Reset Demands (Y/N)?`. If you answer **Y <Enter>**, the relay responds, `Demands Reset`.

The reset command, **MET RP**, resets the peak demand metering quantities. When you issue the **MET RP** command, the relay responds, `Reset Peak Demands (Y/N)?`. If you answer **Y <Enter>**, the relay responds, `Peak Demands Reset`.

MET M

NOTE: Not all SEL-400 series relays support maximum/minimum metering.

Use the **MET M** command to view power system maximum and minimum quantities.

Table 14.99 MET M Command

Command	Description	Access Level
MET M	Display maximum/minimum metering data.	1, B, P, A, O, 2
MET M *k*	Display maximum/minimum metering data successively for *k* times.	1, B, P, A, O, 2
MET BK*n*[a] M	Display Breaker *n* maximum/minimum metering data.	1, B, P, A, O, 2
MET BK*n* M *k*	Display Breaker *n* maximum/minimum metering data successively for *k* times.	1, B, P, A, O, 2
MET RM	Reset maximum/minimum metering data.	P, A, O, 2

[a] Parameter n is the breaker indication.

The reset command, **MET RM**, resets the maximum/minimum metering quantities. When you issue the **MET RM** command, the relay responds, `Reset Max/Min Metering (Y/N)?` If you answer **Y <Enter>**, the relay responds, `Max/Min Reset`.

MET PM

NOTE: Not all SEL-400 series relays support synchrophasors.

Use the **MET PM** command to view the time-synchronized quantities. The relay must be in the high-accuracy timekeeping HIRIG or HPTP mode. For more information on high-accuracy timekeeping, see *Section 11: Time and Date Management*.

Table 14.100 MET PM Command

Command	Description	Access Level
MET PM	Display time-synchronized values.	1, B, P, A, O, 2
MET PM *k*	Display time-synchronized values successively for *k* times.	1, B, P, A, O, 2
MET PM *time*	Display time-synchronized values captured at trigger *time*.	1, B, P, A, O, 2
MET PM HIS	Display time-synchronized values captured for the previous **MET PM** command.	1, B, P, A, O, 2

If the relay is not in the high-accuracy IRIG (HIRIG) timekeeping mode, it will respond to the **MET PM** command with the following message:

```
Aborted: A High Accuracy Time Source is Required
```

If Global enable setting EPMU := N, the relay will respond to the **MET PM** command with:

```
Synchronized phasor measurement is not enabled
```

To request a report of the synchrophasor data at a specific time, enter the optional *time* parameter as a time of day. For example, the relay will respond to the **MET PM 16:40:10** command with:

```
Synchronized Phasor Measurement Data Will Be Displayed at
16:40:10.000
```

In this example, when the internal clock reaches 16:40:10.000, the relay will display the synchrophasor data from that exact time. If the relay is not in HIRIG mode at that time, it will display the following message:

```
Aborted: A High Accuracy Time Source is Required
```

After the **MET PM *time*** command is issued, other **MET PM** commands may be entered without affecting the timed request, even if the stated time has not arrived. However, issuing a second **MET PM *time*** command while the first command is still pending will cancel the first command request in favor of the newer request.

If you are not connected to the relay when the **MET PM *time*** command issues its timed response, you can use the **MET PM HIS** command to view this response. This permits you to issue **MET PM *time*** to multiple relays by using a common time and then go back later to see the results from all the relays at this common instant in time.

See *Section 18: Synchrophasors* for more information on phasor measurement functions, and *View Synchrophasors by Using the MET PM Command on page 18.21* for sample **MET PM** responses.

MET PMV

Use the **MET PMV** command to view the protection math variables.

Table 14.101 MET PMV Command

Command	Description	Access Level
MET PMV	Display all protection math variables.	1, B, P, A, O, 2
MET PMV *k*	Display all protection math variables.	1, B, P, A, O, 2

The relay displays three places after the decimal point for these numerals. The relay shows variables with absolute value greater than 99999.999 or less than 0.100 as scientific notation (for example, –1.002E+22).

MET RTC

Use the **MET RTC** command to view the data received on all active synchrophasor client channels.

Table 14.102 MET RTC Command

Command	Description	Access Level
MET RTC	Display received synchrophasor client data	1, B, P, A, O, 2
MET RTC *k*	Display received synchrophasor client data *k* times	1, B, P, A, O, 2

MET T

Use the **MET T** command to view the temperature data from the SEL-2600A RTD Module. This command requires setting PROTO = RTD for the serial port connected to the SEL-2600A RTD Module.

NOTE: Some SEL-400 series relays use the option MET RTD to get this same information.

Table 14.103 MET T Command

Command	Description	Access Level
MET T	Display as many as 12 temperature analog values from the SEL-2600A RTD Module.	1, B, P, A, O, 2
MET T *k*	Display as many as 12 temperature analog values from the SEL-2600A RTD Module successively for *k* times.	1, B, P, A, O, 2

NOTE: The SEL-487B does not support RTD inputs.

The relay displays the number of resistance temperature detector (RTD) channels specified by the RTDNUM Port Setting. If the RTD protocol is not enabled on any of the relay ports, the relay displays the following:

```
No data available
```

If there is a communications failure between the relay and the SEL-2600A, as indicated by the RTDCOMF Relay Word bit, the relay displays the following:

```
Communication Failure
```

If the RTDFL Relay Word bit is set to indicate a SEL-2600A failure, the relay displays the following:

```
SEL-2600 Failure
```

If any of the RTD*x*TY Port Settings are set to NA, the relay displays the following for that channel:

```
Channel Not Used
```

If the RTD*xx*ST Relay Word bit is set for any of the RTDNUM channels being reported, the relay displays the following:

```
Channel Failure
```

OACCESS

Use the **OACCESS** command to gain access to Access Level O (output). See *Access Levels and Passwords on page 3.7* for more information.

Table 14.104 OAC Command

Command	Description	Access Level
OAC	Go to Access Level O (output).	1, B, P, A, O, 2

OPEN n

Use the **OPEN *n*** command to open a circuit breaker(s). The **OPEN *n*** command pulses Relay Word bit OC*n*. Usually, you configure these Relay Word bits as part of the SELOGIC control equations that trip the appropriate circuit breaker. See *Trip Logic* in *Section 5: Protection Functions* of the product-specific instruction manual for information on trip SELOGIC control equations.

Table 14.105 OPEN n Command

Command	Description	Access Level
OPEN *n*	Pulse Relay Word bit OC*n*.	B, P, A, O, 2

If you have disabled the relay and attempt an **OPEN *n*** command, the relay responds, `Command aborted because the relay is disabled`. If the circuit breaker control enable jumper BREAKER is not in place, the relay aborts the command and responds, `Aborted: the breaker jumper is not installed`.

When you issue the **OPEN *n*** command, and the circuit breaker control enable jumper is in place, the relay responds, `Open breaker (Y/N)?`. If you answer **Y <Enter>**, the relay responds, `Are you sure (Y/N)?`. If you answer **Y <Enter>**, the relay asserts OC*n* for one processing interval.

If you have assigned auxiliary contact 52A inputs for this circuit breaker, the relay waits 0.5 seconds, checks the state of the breaker auxiliary contacts, and responds `Breaker OPEN` or `Breaker CLOSED`, as appropriate.

If Breaker *n* is not enabled, the relay responds, `Breaker n is not available`.

PACCESS

Use the **PACCESS** command to gain access to Access Level P (protection). See *Access Levels and Passwords on page 3.7* for more information.

Table 14.106 PAC Command

Command	Description	Access Level
PAC	Go to Access Level P (protection).	1, B, P, A, O, 2

PASSWORD

Use the **PASSWORD** command to control password protection for relay access levels.

PAS n

The relay changes the existing password for the specified access level that you specify when you issue the **PAS *n*** command. To change a password at any level, you must be Access Level 2.

⚠WARNING
This device is shipped with default passwords. Default passwords should be changed to private passwords at installation. Failure to change each default password to a private pass word may allow unauthorized access. SEL shall not be responsible for any damage resulting from unauthorized access.

Table 14.107 PAS level New_Password Command

Command	Description	Access Levels
PAS *n*[a]	Set a new password for Access Level *n*.	2

[a] Parameter n represents the relay Access Levels 1, B, P, A, O, or 2.

Relay access levels that have passwords are 1, B, P, A, O, 2, and C. Valid passwords are character sequences of as many as 12 characters. Valid characters are any printable ASCII character.

All passwords are case-sensitive. When you successfully enter a new password, the relay pulses the Relay Word bit SALARM for at least one second, and responds, `Set`.

Passwords for each access level can be disabled by setting the new password to DISABLE. When the password for a certain access level is set to DISABLE, no password is required for entering that access level in the **ACC** command, and the relay does not prompt for an old password when changing the password. The relay issues a `Password Disabled` message instead of `Password Changed` after disabling the password.

Entering **PAS *n*** and entering a new password re-enables the password requirement for that access level. SEL does not recommend disabling passwords.

PING

NOTE: The relay uses one router to route **PING** commands outside the local network. If default routers associated with station bus (DEFRTR) and engineering access (DEFRTRE) are configured, the relay sends ping requests to the router specified by the DEFRTR setting.

Use the **PING** command to determine whether the network is connected properly and other network devices are reachable.

Table 14.108 PING Command

Command	Description	Access Level
PING ***addr***[a]	Send ICMP echo request messages to remote device at *addr*.	1, B, P, A, O, 2

[a] IP address of device to ping in the format of four decimal numbers (0–255) separated by periods.

When the IP address parameter is not of a valid format, the relay responds with `Invalid IP address`. After a valid **PING** command is issued, the relay sends out an Internet Control Message Protocol (ICMP) echo request messages at one second intervals until receiving a carriage return **<CR>** or five minutes elapses. A sample **PING** command response is shown in *Figure 14.17*.

```
=>>PING 192.9.201.1 <Enter>

Pinging 192.9.201.1
Press <Enter> to Terminate Ping Test.

Ping Echo Message Received.
Ping Echo Message Received.
Ping Echo Message Received.
Ping Echo Message Received.


Ping Results:

   Number of Ping Messages:
      Transmitted:   4
      Received:      4

   Elapsed Time:    11 seconds

=>>
```

Figure 14.17 Sample PING Command Response

PORT

The **PORT** command can be used to connect to a remote relay.

PORT p

The **PORT *p*** command connects a relay serial port to another device through a virtual terminal session.

NOTE: The BAY1 and BAY2 options only apply to relays that support 87L communications and have the corresponding bay card installed.

In the relay, serial port virtual terminal capability is available in MIRRORED BITS communications. You must have previously configured the serial port for MIRRORED BITS communications operation, set port setting MBNUM less than 8, and have at least one virtual terminal session available (set MBNUMVT to 0 or greater). Choosing MBNUMVT to 0 uses virtual terminal within the synchronization channel only. See *SEL MIRRORED BITS Communication on page 15.36* for information on the MIRRORED BITS communications protocol.

Table 14.109 PORT p Command

Command	Description	Access Level
PORT ***p***[a]	Connect to a remote device through `PORT` p (over MIRRORED BITS communications virtual terminal mode).	1, B, P, A, O, 2

[a] Parameter p is 1, 2, 3, and F to indicate Communications PORT 1 — PORT 3 and PORT F, or BAY1 or BAY2 for 87L ports.

When the relay establishes a connection, the relay responds, `Transparent session to Port p established`. To quit the transparent connection, type the control string that you specify in port setting TERSTRN; the default is **<Ctrl+E>**. Only one transparent port connection to each MIRRORED BITS communications port is possible at one time. If you issue a **PORT *p*** command when the selected session is already active, the relay responds, `Transparent session already in use`.

If you issue the **PORT *p*** command to **PORT 1**, **PORT 2**, **PORT 3**, **PORT F**, **BAY 1**, or **BAY 2** (87L ports) and you have not properly configured the MIRRORED BITS communications port, the MBNUMVT is not set to 1 or larger, `Invalid destination port`.

PORT KILL n

It is possible to forcefully disconnect a transparent session from another port (a port not involved in the present transparent connection) by using the **PORT KILL *n*** command (shown in *Table 14.110*).

Table 14.110 PORT KILL n Command

Command	Description	Access Level
PORT KILL *n*[a]	Terminate the virtual terminal connection with a remote device through port *n* by using a port not involved in the connection.	P, A, O, 2

[a] Parameter n is 1, 2, 3, F, BAY1, or BAY2 (for 87L ports) to indicate Communications Ports 1, 2, 3, or F, BAY1, or BAY2; n is not the present port.

The port parameter *n* can refer to either of the ports involved in the session you want to kill. When you issue the **PORT KILL *n*** command, the relay responds, `Kill connection between ports m and n (Y/N)?` Answer **Y <Enter>** to terminate the connection. The relay sends a character sequence to the remote relay (to make sure the remote device is left in a known state) and responds, `Connection between ports m and n disconnected`.

PROFILE

Use the **PROFILE** command (**PRO**) to access the Signal Profile data for as many as 20 user selectable analog values.

Table 14.111 PRO Command (Sheet 1 of 2)

Command	Description	Access Level
PRO	Displays the first 20 rows of the profile report, with the oldest row at the top and the latest row at the bottom.	1, B, P, A, O, 2
PRO *m*	Displays the first *m* rows of the report, with the oldest row at the top and the latest row at the bottom.	1, B, P, A, O, 2
PRO *m n* (*m* > *n*)	Displays the row between *m* and *n*, (including *m* and *n*) with the oldest row at the top and the latest row at the bottom.	1, B, P, A, O, 2
PRO *date1*	Displays all the rows that were recorded on that date, with the oldest row at the top and the latest row at the bottom.	1, B, P, A, O, 2
PRO *date1 date2*	Displays all the rows that were recorded on and between (including) *date1* and *date2* (*date1* chronologically precedes *date2*, with the oldest row (*date1*) at the top and the latest row (*date2*) at the bottom.	1, B, P, A, O, 2
PRO *date2 date1*	Displays all the rows that were recorded on and between (including) *date1* and *date2* (*date2* chronologically precedes *date1*, with the oldest row (*date2*) at the top and the latest row (*date1*) at the bottom.	1, B, P, A, O, 2

Table 14.111 PRO Command (Sheet 2 of 2)

Command	Description	Access Level
PRO D	Displays, for each port, the maximum number of days data may be acquired with the present settings before data overwrite occurs.	1, B, P, A, O, 2
PRO C or R	Clears the signal profile data from nonvolatile memory on a per-port basis. The data are still visible to other ports and to file transfer accesses and is cleared independently for those points-of-view.	B, P, A, O, 2
PRO CA or RA	Completely clears all signal profile data from nonvolatile memory.	P, A, O, 2

PULSE

Use the **PULSE OUT*nnn*** command to pulse any of the relay control outputs for a specified time. This function aids you in relay testing and commissioning. If the output is open, the **PUL** command momentarily closes the output; if the output is closed, the **PUL** command momentarily opens the output. The control outputs are **OUT*nnn***, where *nnn* represents the 100-series, 200-series, 300-series, 400-series, and 500-series addresses.

Table 14.112 PUL OUTnnn Command

Command	Description	Access Level
PUL OUT*nnn*[a]	Pulse output OUT*nnn* for 1 second.	B, P, A, O, 2
PUL OUT*nnn s*[b]	Pulse output OUT*nnn* for *s* seconds.	B, P, A, O, 2

[a] Parameter nnn is a control output number.
[b] Parameter s is time in seconds, with a range of 1–30.

If the circuit breaker control enable jumper BREAKER is not in place, the relay aborts the command and responds, `Aborted: the breaker jumper is not installed`.

When you issue the **PUL** command and the breaker jumper is in place, the relay responds, `Pulse contact OUTnnn for s seconds (Y/N)?`. If you answer **Y <Enter>**, the relay asserts OUT*nnn* for the time you specify.

During the **PUL** operation, the Relay Word bit corresponding to the control output you specified (OUT*nnn*) asserts; Relay Word bit TESTPUL also asserts during any **PUL** command, so you can monitor pulse operation by programming TESTPUL into event triggers and alarm outputs.

NOTE: The **PULSE** command does not update the OUTnnn Relay Word bit when it is used in other SELOGIC control equations. If the output Relay Word bit is assigned to another SELOGIC setting, the SER will report that OUTnnn asserted, but the corresponding SELOGIC setting will not be updated.

QUIT

Use the **QUIT** command to revert to Access Level 0 (exit relay control).

Table 14.113 QUIT Command

Command	Description	Access Level
QUIT	Go to Access Level 0 (exit relay control).	0, 1, B, P, A, O, 2

Access Level 0 is the lowest access level; the relay performs no password check to descend to this level (or remain at this level).

In a Telnet session, **QUIT** terminates the connection.

RTC

Use the **RTC** command to display a description of all data being received on synchrophasor client channels. This report will list the analog quantity and Relay Word bits the data gets stored in locally, matched up with a label provided by the sending PMU. Use this information as aid to understanding the local values.

NOTE: Not all SEL-400 series relays support synchrophasors.

Table 14.114 RTC Command

Command	Description	Access Level
RTC	Display report of all configured synchrophasor client data labels.	1, B, P, A, O, 2

SER

The **SER** command retrieves SER records. The relay SER captures state changes of Relay Word bit elements and relay conditions. Relay conditions include startup, relay enable/disable, group changes, settings changes, memory queue overflow, and SER autoremoval/reinsertion. For more information on the SER, see *Sequential Events Recorder (SER) on page 9.28*.

SER

The default order of the **SER** command is oldest to newest from list top to list bottom. You can view the SER records in numerical or date order.

Table 14.115 SER Command

Command	Description	Access Level
SER	Return the 20 most recent records from the SER, with the oldest (highest number) at the top of the list and the most recent (lowest number) at the bottom of the list.	1, B, P, A, O, 2
SER *k*	Return the *k* most recent records from the SER, with the oldest (highest number) at the top of the list and the most recent (lowest number) at the bottom of the list.	1, B, P, A, O, 2
SER *m n* [a]	Return the SER records from *m* to *n*. If *m* is greater than *n*, records appear with the oldest (highest number) at the top of the list and the most recent (lowest number) at the bottom of the list. If *m* is less than *n*, records appear with the most recent (lowest number) at the top of the list and the oldest (highest number) at the bottom of the list.	1, B, P, A, O, 2
SER *date1* [b]	Return the SER records on date *date1*.	1, B, P, A, O, 2
SER *date1 date2* [b]	Return the SER records from *date1* at the top of the list, to *date2* at the bottom of the list.	1, B, P, A, O, 2

[a] Parameters m and n indicate an SER number, which the relay assigns at each SER trigger.
[b] Enter date1 and date2 in the same format as Global setting DATE_F.

SER C and SER R

The **SER C** and **SER R** commands clear/reset the SER records for the present port. Options **C** and **R** are identical.

Table 14.116 SER C and SER R Commands

Command	Description	Access Level
SER C	Clear/reset SER records on the present port.	1, B, P, A, O, 2
SER R	Clear/reset SER records on the present port.	1, B, P, A, O, 2

The relay prompts you with `Clear the sequential events recorder for this port. Are you sure (Y/N)?` when you issue the **SER C** or **SER R** command. If you answer **Y <Enter>**, the relay clears the particular port SER records.

SER CA and SER RA

The **SER CA** and **SER RA** commands clear all SER records from memory.

Table 14.117 SER CA and SER RA Commands

Command	Description	Access Level
SER CA	Clear SER data for all ports.	P, A, O, 2
SER RA	Clear SER data for all ports.	P, A, O, 2

If you issue the **SER CA** or **SER RA** command, the relay prompts you with `Clear the sequential events recorder for all ports. Are you sure (Y/N)?` commands. If you answer **Y <Enter>**, the relay clears all SER records in nonvolatile memory.

SER CV and SER RV

The **SER CV** and **SER RV** commands clear any SER data records that have been viewed from the present port. The two commands are equivalent.

Table 14.118 SER CV or SER RV Commands

Command	Description	Access Level
SER CV	Clear viewed SER data for this port.	1, B, P, A, O, 2
SER RV	Clear viewed SER data for this port.	1, B, P, A, O, 2

If you issue the **SER CV** or **SER R**V command, the relay prompts you with `Clear viewed SER records for this port. Are you sure (Y/N)?`. If you answer **Y <Enter>**, the relay clears all SER records viewed from this port. The data are still visible to other ports and to file transfer accesses, and they must be cleared independently for those ports. Data not yet viewed remain available.

SER D

The **SER D** command shows a list of SER items that the relay has automatically removed. These are "chattering" elements. You can automatically remove chattering SER elements in the SER Chatter Criteria category of the Report settings; the enable setting is ESERDEL.

Table 14.119 SER D Command

Command	Description	Access Level
SER D	List chattering SER elements that the relay is removing from the SER records.	1, B, P, A, O, 2

If you issue the **SER D** command and you have not enabled automatic removal of chattering SER elements (Report setting ESERDEL), the relay responds, `Automatic removal of chattering SER elements not enabled`.

SET

Use the **SET** command to change relay settings. The relay settings structure is ordered and contains these items (in structure order): classes, instances, categories, and settings. An outline of the relay settings structure is as follows:

Classes (Global, Group, Breaker Monitor, Protection, Automation, Outputs, Front Panel, Report, DNP3, and Ports)

Instances (some classes have instances: Group = 1–6; Protection = 1–6; Automation = 1–10; PORTs = 1–3, F, 5)

Categories (collections of similar settings)

Settings (specific relay settings with values)

The **SET** and **SHOW** commands contain these settings structure items, which you must specify in order from class to instance (if applicable) to setting. The order that specific settings appear in the relay settings structure is factory programmed.

SET

The **SET** command with no options or parameters accesses the relay settings Group class and the instance corresponding to the active group. To set a different instance, specify the instance number (1–6).

Table 14.120 SET Command Overview (Sheet 1 of 2)

Command[a]	Description	Access Level
SET	Set the Group relay settings, beginning at the first setting in the active group.	P, 2
SET *n*	Set the Group *n* relay settings, beginning at the first setting *n* each instance.	P, 2
SET *label*	Set the Group relay settings, beginning at the active group setting label *label*.	P, 2
SET *n label*	Set the Group n relay settings, beginning at setting label *label*.	P, 2
SET *c*	Set class *c,* using the default instance beginning at the first setting.	P,A,O,2

Table 14.120 SET Command Overview (Sheet 2 of 2)

Command[a]	Description	Access Level
SET *c i*	Set class *c*, instance *i*, beginning at the first setting.	P,A,O,2
SET *c i label*	Set class *c*, instance *i*, beginning at setting *label*.	P,A,O,2

[a] Parameter n = 1–6, representing Group 1–6.
c = settings class (relay specific).
i = class instance (choices depends on the class).

The specific classes and instances available depends on the relay. See the relay-specific instruction manual for the specific options that are available. The relay validates your settings entries as you enter each setting. At the end of a settings instance session, the relay responds with a readback of all the settings in the settings instance, then prompts you with `Save settings (Y,N)?.` If you answer **Y <Enter>**, the relay pulses the Relay Word bit SALARM, and responds, `Saving Settings, Please Wait.....` The relay saves the new settings, then responds, `Settings Saved`. If you answer **N <Enter>** to the save settings prompt, the relay responds, `Settings aborted`.

SET TERSE

Use the **TERSE** option to inhibit the relay from sending the settings class or instance readback when you end a settings session. SEL recommends that you use the **TERSE** option sparingly; you should review the readback information to confirm that you have entered the settings that you intended.

Table 14.121 SET TERSE Command Examples

Command	Description	Access Level
SET TERSE	SET Group relay settings for the active group, beginning at the first setting in this instance; omit settings readback.	P, 2
SET 3 TE[a] *label*	SET Group 3 settings, beginning at the settings label *label*; omit settings readback.	P, 2
SET P *p label* TERSE	Set the communications port relay settings for `PORT` p, beginning at the settings label *label*; omit readback.	P, A, O, 2

[a] TERSE may be entered as TE, as shown in this example.

You can use the **TERSE** option in any **SET** command at any position after typing **SET**. When you end the settings edit session, the relay responds, `Save settings (Y,N)?.` If you answer **Y <Enter>**, the relay pulses the Relay Word bit SALARM, and responds, `Saving Settings, Please Wait.....` The relay saves the new settings, then responds, `Settings Saved`. If you answer **N <Enter>** to the save settings prompt, the relay responds, `Settings aborted`.

SHOW

The **SHOW** command shows the relay settings. When showing settings, the relay displays the settings label and the present value from nonvolatile memory.

The relay organizes settings in classes, instances, categories, and specific settings; see *SET on page 14.58* for information on settings organization. The relay displays each setting in the order specified in the settings tables. When you are

using a terminal and you specify a setting in the middle of a settings category, the relay displays the category title, then proceeds with the class or instance settings from the setting that you specified.

Table 14.122 SHO Command Overview

Command[a]	Description	Access Level
SHO	Show the Group relay settings, beginning at the first setting in the active group.	1, B, P, A, O, 2
SHO *n*	Show the Group *n* relay settings, beginning at the first setting in each instance.	1, B, P, A, O, 2
SHO *label*	Show the Group relay settings, beginning at the active Group settings label *label*.	1, B, P, A, O, 2
SHO *n label*	Show the Group *n* relay settings, beginning at the settings label *label*.	1, B, P, A, O, 2
SHO *c*	Show class *c* using the default instance beginning at the first setting.	P, A, O, 2
SHO *c i*	Show class *c*, instance *i* beginning at the first setting.	P, A, O, 2
SHO *c i label*	Show class *c*, instance *i*, beginning at setting *label*.	P, A, O, 2

[a] Parameter n = 1–6, representing Group 1–6.
c = settings class (relay specific).
i = class instance (choices depends on the class).

SNS

In response to the **SNS** command, the relay sends the names of the SER elements. This is a comma-delimited string used to support the SEL Fast SER report.

Table 14.123 SNS Command

Command	Description	Access Level
SNS	Send the names of SER elements.	0, 1, B, P, A, O, 2

STATUS

The **STATUS** command reports relay status information that the relay derives from internal diagnostic routines and self-tests. See *Relay Self-Tests on page 10.19* for information on relay diagnostics.

STA

The **STA** command with no options displays a short-form relay status report. Items in the STA report are the header, failures, warnings, SELOGIC control equation programming environment errors, and relay operational status. See *Checking Relay Status on page 3.13* for information on relay status reports.

Table 14.124 STA Command

Command	Description	Access Level
STA	Return the relay status.	1, B, P, A, O
STA	Return the relay status and show a new hardware configuration prompt.	2

If you change an I/O interface board, the relay detects the new configuration and initiates a status warning. When you issue the **STA** command at Access Level 2, the relay responds to this situation with `Accept new hardware configuration (Y/N)?`. If you answer **Y <Enter>**, the relay responds, `New configuration accepted`. If you answer **N <Enter>**, the relay responds, `Command aborted`.

STA A

Use the **STA A** command to view the entire relay status report. Items in the full status report include the short-form status report items plus data on A/D (analog/digital) channel offsets, power supply voltages, temperature, communications interfaces, time-source synchronization, IEC 61850 Mode/Behavior, and IEC 61850 Simulation Mode.

Table 14.125 STA A Command

Command	Description	Access Level
STA A	Display all items of the status report.	1, B, P, A, O, 2

STA C and STA R

The **STA C** and **STA R** commands restart the relay. Thus, these commands clear a transient failure should this unlikely event occur. Options **C** and **R** are identical. Contact your Technical Service Center or the SEL Factory before using this command.

Table 14.126 STA C and STA R Command

Command	Description	Access Level
STA C	Reset the relay.	2
STA R	Reset the relay.	2

STA S

Use the **STA S** command to view all SELOGIC control equation storage and execution capacity and operating errors.

Table 14.127 STA S Command

Command	Description	Access Level
STA S	Display detailed SELOGIC control equation error information.	1, B, P, A, O, 2

STA SC and STA SR

The **STA SC** and **STA SR** commands clear/reset the SELOGIC control equation operating errors from the status report if the errors are no longer present. In addition, these commands reset the Automation SELOGIC Peak and Average Execution Cycle Time statistics.

Table 14.128 STA SC and STA SR Command

Command	Description	Access Level
STA SC	Clear SELOGIC control equation errors and reset SELOGIC cycle time statistics.	P, A, O, 2
STA SR	Clear SELOGIC control equation errors and reset SELOGIC cycle time statistics.	P, A, O, 2

STA T

NOTE: The **STA T** command is only available in TiDL relays that support T-Protocol.

In the **STA T** command, SEL-TMU type (1 or 2) is indicated. SEL-TMU type indicates the following:

1: 4CT/4PT SEL-TMU

2: 8CT SEL-TMU

Use the **STA T** command to view the status of the TiDL ports of your relay and connected SEL-TMUs.

Table 14.129 STA T Command

Command	Description	Access Level
STA T	Display TiDL system status	1, B, P, A, 0, 2

Table 14.130 shows the error messages that could be displayed and the appropriate action.

Table 14.130 STA T SEL-TMU Error Messages and User Action

Error Message	User Action
SFP NOT INSTALLED	Port is mapped but has no SFP transceiver installed. Install a compatible transceiver in that port.
SFP NOT COMPLIANT	An SFP transceiver is connected to a mapped port but could not be authenticated because it is not compatible. See *Table 15.7* or selinc.com/products/sfp for a list of compatible SFP transceivers.
TMU STREAM LOSS	Check the SEL-TMU and fiber connections. If the issue persists, issue the **VEC** command and contact SEL technical support.
WRONG TMU CONNECTED	The SEL-TMU connected to the port does not match what is expected according to the current commissioned system. Reconnect the appropriate SEL-TMU to this port.
TMU ERROR	Issue the **VEC** command, and contact SEL technical support.
BAD TMU DATA	Issue the **VEC** command, and contact SEL technical support.
CHANNEL DELAY EXCEEDED	Issue the **VEC** command, and contact SEL technical support.
TMU RX ERROR	Check the SEL-TMU and fiber connections. If the issue persists, issue the **VEC** command and contact SEL technical support.

SUMMARY

The **SUMMARY** command displays a summary event report. See *Event Summary on page 9.26* for information on summary event reports.

SUM

Use the **SUM** command to view the event summary reports in the relay memory.

Table 14.131 SUM Command

Command	Description	Access Level
SUM	Return the most recent event summary.	1, B, P, A, O, 2
SUM *n*[a]	Return an event summary for event *n*.	1, B, P, A, O, 2

[a] Parameter n indicates event order or serial number; see the event history report (HIS on page 14.42 command).

When parameter *n* is 1–9999, *n* indicates the order of the event report. The most recent event report is 1, the next most recent report is 2, and so on. When parameter *n* is 10000–42767, *n* indicates the absolute serial number of the event report.

SUM ACK

Use **SUM ACK** to acknowledge an event summary that you recently viewed with the **SUM NEXT** command on the present communications port. Acknowledge the oldest summary (specify no event number).

Table 14.132 SUM ACK Command

Command	Description	Access Level
SUM ACK	Acknowledge the oldest unacknowledged event summary at the present communications port.	1, B, P, A, O, 2

If you attempt to acknowledge an event summary that you have not viewed on the present port with the **SUM NEXT** command, the relay responds, `Event summary number n has not been viewed with the NEXT option`.

SUM NEXT

Use the **SUM N** command to view the oldest (next) unacknowledged event summary.

Table 14.133 SUM N Command

Command	Description	Access Level
SUM N	View the oldest unacknowledged event summary at the present communications port.	1, B, P, A, O, 2

TARGET

The **TARGET** command displays the elements for a selected row in the Relay Word bit table.

TAR

Use the **TAR** command to view a row of Relay Word bit elements or aliases. When using the **TAR** command, you can specify the row number or element name.

Table 14.134 TAR Command

Command	Description	Access Level
TAR	Display target Row 0 or display the most recently viewed target row.	1, B, P, A, O, 2
TAR *n*	Display target Row *n*.	1, B, P, A, O, 2
TAR *n k*[a]	Display target Row *n* and repeat for *k* times; the repeat count *k* must follow the row number.	1, B, P, A, O, 2
TAR *name*	Display the target row with the element name *name*.	1, B, P, A, O, 2
TAR *name k*	Display the target row with the element name *name* and repeat for *k* times; the repeat count *k* can be before or after the name option.	1, B, P, A, O, 2

[a] Parameter k is the repeat count from 1–32767.

The relay memorizes the latest target row input conditioned by your present access level. The relay displays Row 0 if you have not specified a row since the relay was turned on, the access level has timed out, or you have issued the **QUIT** command.

If you specify the repeat count k at a number greater than 8, the relay displays the repeated target rows on the terminal screen in groups of eight, with the target row elements listed above each grouping.

TAR ALL

Use the **TAR ALL** command to display all of the relay targets.

Table 14.135 TAR ALL Command

Command	Description	Access Level
TAR ALL	Display all target rows.	1, B, P, A, O, 2

TAR R

The **TAR R** command has two functions. Use this command to reset any latched relay targets resulting from a tripping event. Also employ the **TAR R** command to reset to Row 0 the memorized target row that the relay reports when you issue a simple **TAR** command.

Table 14.136 TAR R Command

Command	Description	Access Level
TAR R	Reset latched targets and return memorized row to Row 0.	1, B, P, A, O, 2

TAR X

Use the **TAR X** command to view a different target row in the Relay Word bit table than the target row in the target row repeat memory. This function is useful for relay testing. See *Testing With Relay Word Bits on page 10.7* for more information.

Table 14.137 TAR X Command

Command[a]	Description	Access Level
TAR *n* X	Display target Row *n*, but do not memorize Row *n*.	1, B, P, A, O, 2
TAR X *n k*	Display target Row *n* and repeat for *k* times, but do not memorize Row *n*. The repeat count *k* must follow the row number.	1, B, P, A, O, 2
TAR *name* X	Display the target row with the element name *name*, but do not memorize the row *n*umber.	1, B, P, A, O, 2
TAR *name* X *k*	Display the target row with the element name *name* and repeat for *k* times, but do not memorize the row number. The repeat count *k* can be at any position in the command after **TAR**.	1, B, P, A, O, 2

[a] Parameter k is the repeat count from 1–32767.

You can place the **X** option at any position in the **TAR** command.

TEC

Enter the **TEC** (time-error calculation) command to display the present time-error estimate and the status of the time-error control equations, and to modify the time-error correction value.

NOTE: Not all SEL-400 series relays support the **TEC** command.

Table 14.138 TEC Command

Command	Description	Access Level
TEC	Display time-error data.	1, B, P, A, O, 2
TEC *n*	Preload time-error correction value *n*, where –30.000 <= *n* <= 30.000.	B, P, A, O, 2

Use the **TEC *n*** command to preload the time-error correction value, TECORR. If the value *n* is within range, the relay will prompt you with `Are you sure (Y/N)?`. If the prompt is acknowledged, the relay sets analog quantity TECORR = *n*, and asserts Relay Word bit PLDTE for approximately 1.5 cycles. The relay then displays the new TECORR value, along with the remaining **TEC** command data.

The TECORR value does not affect the TE (time-error) estimate until the LOADTE SELOGIC equation asserts.

TEST DB

The **TEST DB** command is used for testing access of the virtual device database used for Fast Message Data Access.

TEST DB

Use the **TEST DB** command to write temporary values to the virtual device database to verify the database values. The relay contains a database that describes the relay to external devices. When other devices access the relay via the Fast Message protocol, the relay appears as a virtual device described by the database. The relay is Virtual Device 1.

The virtual database is accessible to master stations of supported Fast Message protocol connected to the relay through serial communication or Ethernet network. You can therefore test the read functionality of the Fast Message protocol in the serial port or Ethernet interface with this command.

Use the **TEST DB 1** command to override any value in the relay database. You must understand the relay database structure to effectively use the **TEST DB** command. Use the **MAP** and **VIEW** commands to see the organization and contents of the database.

Values you enter in the relay database are override values. Use the **TEST DB** command to write override values in the database accessed through the Fast Message Data Access operations.

Table 14.139 TEST DB Command

Command	Description	Access Level
TEST DB	Display present override values by virtual device number and address.	1, B, P, A, O, 2
TEST DB 1 ***addr value1***	Write new data *value1* to the database at an address *addr*.	B, P, A, O, 2
TEST DB 1 ***addr value1 M D Y h m s***	Write new data value1 to the database at an address *addr* and include the provided date/time stamp *M D Y h m s*.	B, P, A, O, 2

The database address *addr* can be any legitimate decimal or hexadecimal address. (A hexadecimal address is a numeral with an "h" suffix or a "0x" prefix.)

You can enter the override value *value1* as an integer, a floating-point number (which overrides two registers), a character (which must be in single quotes), or a string (which must be in double quotes and overrides the number of registers corresponding to the length of the string).

If a date/time stamp is also provided (*M D Y h m s*), the relay will change the static state given and, for any bits being changed by this operation, queued entries will be pushed with the provided date/time stamp. If no queue is associated with the database region (determined by *addr*), the date/time stamp will be ignored.

The order that the date should be entered on the command line depends upon the DATE_F (Global) setting. For example, if DATE_F := DMY, you would enter **TEST DB 1** ***addr value D M Y h m s***.

While there are active test data, the relay asserts Relay Word bit TESTDB.

TEST DB OFF

Use the **TEST DB OFF** command to end the testing session and remove the override values. The relay returns the database registers to the pretest values.

Table 14.140 TEST DB OFF Command

Command	Description	Access Level
TEST DB OFF	Clear all override testing values from all virtual devices.	B, P, A, O, 2
TEST DB OFF 1	Clear all override testing values from Virtual Device 1 (the relay).	B, P, A, O, 2
TEST DB OFF 1 ***region***	Clear all override testing values from the region *region* in Virtual Device 1 (the relay).	B, P, A, O, 2

TEST DB2

The **TEST DB2** command is used to test DNP3 and IEC 61850 communications protocols.

TEST DB2

In addition to Fast Message Protocol, the communications protocols supported by the relay include DNP3, IEC 61850 MMS, and GOOSE. These data include both digital quantities and analog quantities.

Use the **TEST DB2** command to override any DNP3 or IEC 61850 value. The data that can be overridden include both digital and analog quantities.

Table 14.141 TEST DB2 Command

Command	Description	Access Level
TEST DB2	Display present analog and digital override names and values.	1, B, P, A, O, 2
TEST DB2 D *name1*[a] *value1*	Write the specified override value *value1* into the digital quantity *name1*.	B, P, A, O, 2
TEST DB2 A *name2*[b] *value2*	Write the specified override value *value2* into the analog quantity *name2*.	B, P, A, O, 2

[a] Digital name1 can be any Relay Word bits or additional binary input points in DNP3 map.
[b] The analog name2 is any analog available in the DNP3 reference map and any analog listed as a data source for IEC 61850 logical devices. This excludes the event summary analog inputs.

The override value *value1* can be logical 0 or logical 1 for digital and status elements. The analog *value2* can be an integer or a floating-point number.

The Relay Word bit TESTDB2 will be asserted while there are points in this test mode.

If IEC 61850 Mode/Behavior is not On, the relay will not process the **TEST DB2** command.

TEST DB2 OFF

Use the **TEST DB2 OFF** command to end the testing session and remove the override values. The relay returns the modified registers to the pretest values.

Table 14.142 TEST DB2 OFF Command

Command	Description	Access Level
TEST DB2 D OFF	Clear all digital override testing values.	B, P, A, O, 2
TEST DB2 D *name1*[a] OFF	Clear digital override testing value specified by name *name1*.	B, P, A, O, 2
TEST DB2 A OFF	Clear all analog override testing values.	B, P, A, O, 2
TEST DB2 A *name2*[b] OFF	Clear analog override testing value specified by name *name2*.	B, P, A, O, 2

[a] Digital name1 can be any Relay Word bits or additional binary input points in DNP3 map.
[b] See Section 12: Analog Quantities in the product-specific instruction manual for available analog name2.

When removing all existing digital override values, the relay responds, `Digital Overrides Removed`. If no digital override is ever configured, the `Overrides Not Found` message will be displayed. The analog override removal acknowledgment messages are similar.

If IEC 61850 Test Mode/Behavior changes from On, the **TEST DB2** command deactivates. All overrides clear and the TESTDB2 Relay Word bit deasserts.

TEST FM

NOTE: For the list of available bits to Fast Meter, see DNAME X on page 14.31.

The **TEST FM** command overrides normal Fast Meter quantities for testing purposes. You can override only "reported" Fast Meter values. For more information on Fast Meter and the relay, see *SEL Fast Meter, Fast Operate, Fast SER Messages, and Fast Message Data Access on page 15.34*.

TEST FM

Values you enter in Fast Meter storage are "override values." Use the **TEST FM** command to display override values and write override values in the Fast Meter report.

Table 14.143 TEST FM Command

Command	Description	Access Level
TEST FM	Display present override values.	1, B, P, A, O, 2
TEST FM *label value1 value2*	Write new data *value1* and *value2* to the Fast Meter report at the item label *label*. Parameter *value2* is optional.	B, P, A, O, 2

When you display Fast Meter data overrides with the **TEST FM** command, the relay shows the item label, and override values.

To force a value, use the **TEST FM *label value1 value2*** command. The item label *label* is any analog channel label in the Fast Meter configuration (if available), any digital element label (from the **DNA** command), and any status element label (from the **BNA** command) except the TEST and FMTEST items.

The value *value1* can be logical 0 or logical 1 for digital and status elements, or a floating-point value for all meter quantities. For meter items that report a pair of values in the Fast Meter message, *value1* is the magnitude and *value2*, if provided, is the angle. If you do not specify *value2*, the relay uses an angle of 0.

When you have successfully added a new Fast Meter test value (for example, **TEST FM IA1 3.7 0.0**), the relay responds, `Override Added`.

The relay asserts Relay Word bit TESTFM while any Fast Meter override data are present in the relay.

Fast Meter Status Byte

Bits labeled TEST and FMTEST reside in the Fast Meter status byte. If any item within the Fast Meter message is in test mode, the relay sets the TEST bit. Similarly, if any item in any Fast Meter message is in test mode, the FMTEST is set in all three Fast Meter responses.

TEST FM DEM

Use the **TEST FM DEM** command to insert override values in Fast Meter demand metering.

NOTE: Not all SEL-400 series relays support demand metering. These relays will not support the **TEST FM DEM** command.

Table 14.144 TEST FM DEM Command

Command	Description	Access Level
TEST FM DEM *label value1*	Write new data value1 to the Fast Meter demand meter report at the item label *label*.	B, P, A, O, 2

TEST FM OFF

Use the **TEST FM OFF** command to remove override values. The relay returns the Fast Meter registers to the pretest values.

Table 14.145 TEST FM OFF Command

Command	Description	Access Level
TEST FM *label* OFF	Clear the override values for the Fast Meter item *label*.	B, P, A, O, 2
TEST FM OFF	Clear all override testing values from Fast Meter.	B, P, A, O, 2

When you have successfully removed a Fast Meter test value (for example, **TEST FM IA1 OFF**), the relay responds, `Override Removed`. When an attempt to remove an FM test value fails, the relay responds, `Override Not Found`. When removing all FM test values (for example, **TEST FM OFF**), the relay responds, `All Overrides Removed`.

TEST FM PEAK

Use the **TEST FM PEAK** command to insert override values in Fast Meter peak demand metering.

NOTE: Not all SEL-400 series relays support demand metering. These relays will not support the **TEST FM PEAK** command.

Table 14.146 TEST FM PEAK Command

Command	Description	Access Level
TEST FM PEAK *label value1*	Write new data *value1* to the Fast Meter peak demand meter report at the item label *label*.	B, P, A, O, 2

TEST SV

TEST SV (SEL SV Publisher)

NOTE: The **TEST SV** command is only available on SV subscriber or SV publisher models, with the exception of the SEL-487E-5 SV Publisher.

The **TEST SV** command is a SEL SV testing command. Do not confuse this with IEC 61850 Test Mode, which is enabled by **PORT 5** setting E850MBC. The **TEST SV** command allows the SEL SV publisher to generate and publish test signals on all the configured SV publications. The **TEST SV** command provides a facility to test SV publishing functionality without the need for current and/or voltage sources present in the terminals of the SEL SV publisher.

Table 14.147 TEST SV Command in an SEL SV Publisher

Command	Description	Access Level
TEST SV[a]	Initiates the SV publication of test signals. When TEST SV Mode = ON, Relay Word bit SVPTST is asserted; SVPTST is deasserted otherwise.	B, P, A, O, 2
TEST SV OFF	Ends the SV publication of test signals. Relay Word bit SVPTST is cleared.	B, P, A, O, 2

[a] The test mode does not influence GOOSE or MMS functionality.

When you enable the TEST SV mode, a 15-minute timer starts. After 15 minutes, the SEL SV publisher automatically disables the TEST SV mode. This timer restarts each time the **TEST SV** command is entered. With the TEST SV mode enabled, the test bit in the quality attribute asserts in all outgoing SV publications. The mode of the device (LLN0.Mod) is not changed and it remains in normal operation mode. PubSim and Sim bits are also not modified.

Table 14.148 shows a detailed description of how the output values for the SEL SV publisher are calculated while in TEST SV mode.

Table 14.148 SV Output Values During TEST SV Mode

Physical Measurement	Description	Setting Source
CURRENT	The value for each Channel IA, IB, and IC is scaled from secondary values (Magnitude in *Table 14.149*) to primary values, in accordance with the CT ratio setting from the presently active Group settings. A-Phase starts at 0 degrees; the other phase angles are relative to the PHROT setting from the presently active Group settings. The value for Channel IN in each winding is the sum of IA, IB, and IC values.	CTRS, CTRT, CTRU, CTRW, CTRX, CTRY, CTRY1, CTRY2, CTRY3, ACTGRP, PHROT
VOLTAGE	The value for each Channel VA, VB, and VC is scaled from secondary values (Magnitude in *Table 14.149*) to primary values, in accordance with the PT ratio setting from the presently active Group settings. A-Phase starts at 0 degrees; the other phase angles are relative to the PHROT setting from the presently active Group settings. The value for Channel VN in each winding is the sum of VA, VB, and VC values.	PTRV, PTRY, PTRZ, ACTGRP, PHROT
FREQUENCY	The value for the frequency corresponds to the NFREQ setting.	NFREQ
PHASE ROTATION	The phase sequence corresponds to the PHROT setting.	PHROT

Table 14.149 shows the secondary values used while the SEL SV publisher is in TEST SV mode.

Table 14.149 Secondary Values Used During TEST SV Mode

IEC Notation	SEL Notation	Magnitude (RMS)		Angle (degrees)	
		5A	1A	ABC ROT	ACB ROT
I1	IA	5	1	0	0
I2	IB	5	1	–120	120
I3	IC	5	1	120	–120
I4	IN	0	0	0	0
V1	VA	67	67	0	0
V2	VB	67	67	–120	120
V3	VC	67	67	120	–120
V4	VN	0	0	0	0

When you enable or disable the SEL TEST SV mode, the SV publications are disabled momentarily, causing a brief interruption in the outgoing SV publications.

If the `PORT 5` SV settings are not in use and no SV publications are configured in the CID file when the **TEST SV** command is issued, the relay responds with `Cannot enter test mode. No SV publications configured.`

You cannot use the **TEST SV** command if IEC 61850 Test Mode is enabled and active mode is not on.

TEST SV (SEL SV Subscriber)

The **TEST SV** command provides a facility to test SV functionality. The **TEST SV** command allows the SEL SV subscriber to accept SV test messages on all the configured SV subscriptions.

Table 14.150 TEST SV Command in an SEL SV Subscriber

Command	Description	Access Level
TEST SV[a]	Instructs the SEL SV subscriber to accept SV test messages. When TEST SV Mode = ON, Relay Word bit SVSTST is asserted; SVSTST is deasserted otherwise.	B, P, A, O, 2
TEST SV OFF	Instructs the SEL SV subscriber to reject the received SV messages with the test bit of the quality attribute asserted. Relay Word bit SVSTST is cleared.	B, P, A, O, 2

[a] The Test mode does not influence GOOSE or MMS functionality.

When you enable the TEST SV mode, a 15-minute timer starts. After 15 minutes, the SEL SV subscriber automatically disables the TEST SV mode. This timer restarts each time the **TEST SV** command is entered.

If the PORT 5 SV settings are not in use and no SV subscriptions are configured in the CID file when the **TEST SV** command is issued, the relay responds with `Cannot enter test mode. No SV subscriptions configured.`

Considerations for an SEL SV Subscriber During TEST SV Mode

The SEL SV subscriber will process and execute all the associated protection logic, operating in the same way as if the SEL SV subscriber were receiving valid SV messages.

The SEL SV subscriber will continue to accept incoming SV messages that do not have the TEST bit of the quality attribute asserted.

For TEST SV mode to function, the IEC 61850 Mode/Behavior must be On.

TIME

Use the **TIME** command to view and set the relay time clock. The ASCII interface is just one source by which you can set the internal clock. Other sources can override the ASCII **TIME** command; overriding occurs in HIRIG time mode, IRIG time mode, and when using DNP3. See *Section 11: Time and Date Management* for more information on configuring time functions.

TIME

The **TIME** command returns information about the internal relay clock. You can also set the clock to local time if you specify hours and minutes (seconds data are optional). Separate the hours, minutes, and seconds with colons, semicolons, spaces, commas, or slashes.

```
=>>TIME <Enter>
local: 16:48:33     UTC: 23:48:33     UTC Offset: -07.0 hrs
```

If a valid IRIG-B, PTP, or SNTP signal is connected to the relay, the **TIM** command cannot be used to set the relay time.

Table 14.151 TIME Command

Command	Description	Access Level
TIME	Display the present relay internal clock time, in three formats: local, UTC, and UTC offset.	1, B, P, A, O, 2
TIME *hh:mm*	Set the relay internal clock to *hh:mm*.	1, B, P, A, O, 2
TIME *hh:mm:ss*	Set the relay internal clock to *hh:mm:ss*.	1, B, P, A, O, 2

Use the **TIME *hh:mm*** and **TIME *hh:mm:ss*** commands to set the relay internal clock time. The value *hh* is for hours from 0–23, the value *mm* is for minutes from 0–59, and the value *ss* is for seconds from 0–59. If you enter a valid time, the relay updates and saves the time in the nonvolatile clock, and displays the time you just entered. If you enter an invalid time, the relay responds, `Invalid Time`.

TIME Q

The **TIME Q** command returns detailed information on the relay internal clock. Use this command to query the status of high-accuracy time source inputs and the present clock time mode.

Table 14.152 TIME Q Command

Command	Description	Access Level
TIME Q	Display detailed information about the internal relay clock; query relay time.	1, B, P, A, O, 2

When you issue the **TIME Q** command, the relay reports statistics on the relay time sources. These statistics include the present time source and the last time value update source (see *TIME Q Command on page 11.8*).

```
=>TIME Q <Enter>

Station A                                   Date: 03/17/2023  Time: 23:04:16.336
Relay 1                                     Serial Number: 1230769999


Time Source: HIRIG
Last Update Source: HIRIG

IRIG Time Quality:   0.000 ms

Time Mark Period:   999.990539 ms

Internal Clock Period:  20.000006 ns
```

Figure 14.18 Sample TIME Q Command Response With IRIG

```
=>>TIME Q <Enter>

Relay 1                                     Date: 03/17/2023  Time: 15:08:41.468
Station A                                   Serial Number: 1230769999


Time Source: HPTP
Last Update Source: HPTP

Grandmaster Clock Quality
    Clock Class : Synchronized with PTP timescale (6)
    Time Traceable : TRUE
    Clock Accuracy : Within 25 ns
    Offset Log Variance : 0

Time Mark Period:  1000.000061 ms

Internal Clock Period:  19.999935 ns
```

Figure 14.19 Sample Time Q Command Response With PTP

TIME DST

In response to the **TIME DST** command, the relay displays local time, UTC time and UTC Offset, followed by daylight-saving time rules and information.

```
=>>TIME DST <Enter>
local: 11:28:19     UTC: 18:28:19     UTC Offset: -07.0 hrs


Daylight Savings Time Begin Rule: 2nd Sunday of March at 02:00
Daylight Savings Time End Rule: 1st Sunday of November at 02:00


Daylight Savings Time Presently Active

Next Daylight Savings Time Beginning: 03/11/2012 02:00
Next Daylight Savings Time Ending: 11/06/2011 02:00
=>>
```

Table 14.153 TIME DST Command

Command	Description	Access Level
TIME DST	Daylight-saving time rules and information	1, B, P, A, O

TRIGGER

The **TRIGGER** command initiates data captures for high-resolution oscillography and event reports. For information on high-resolution oscillography and event reports see *Triggering Data Captures and Event Reports on page 9.7*.

Use the **TRI** command to trigger the relay to record data for high-resolution oscillography and event reports.

Table 14.154 TRI Command

Command	Description	Access Level
TRI	Trigger relay data capture.	1, B, P, A, O, 2

When you issue the **TRI** command, the relay responds, `Triggered`. If the event did not trigger within 1 second, the relay responds, `Did not trigger`.

VECTOR

The **VECTOR** command displays information useful to the factory for troubleshooting purposes.

Use the **VEC** command to view diagnostic information recorded by the relay. In TiDL relays, you can also view the diagnostic information of connected SEL-TMUs.

Table 14.155 VEC Command

Command	Description	Access Level
VEC	Report relay internal diagnostics information.	2

VERSION

The **VERSION** command displays the relay hardware and software configuration.

Use the **VER** command to list the part numbers, serial numbers, checksums, software release numbers, and other important relay configuration information.

Table 14.156 VER Command

Command	Description	Access Level
VER	Display the hardware and software configurations.	1, B, P, A, O, 2

When you issue the **VER** command, the relay displays the latest release numbers for various items, typically including:

- FID
- CID
- Part number
- Serial number
- SELBOOT BFID
- Main board memory types and sizes
- Front-panel hardware
- Analog inputs ratings
- Interface board inputs and outputs
- Bay cards
- Extended relay features list

A sample **VER** command response is shown in *Figure 14.20*.

```
=>VER <Enter>
FID=SEL-451-6-R404-V0-Z104102-D20230317
CID=XXXX
Part Number:  04516XX0X600XE9H4C4XXXXXX
Serial Number:  1230769999
SELboot:
    BFID= SLBT-4XX-R302-V0-Z001002-D20230317
    Checksum:  XXXX

Mainboard:
    Code FLASH Size:   12 MB
    Data FLASH Size:   52 MB
    RAM Size:          64 MB
    EEPROM Size:      128 kB

Front Panel: installed
Analog Inputs:
    W:  Currents:  5 Amp
    X:  Currents:  5 Amp
    Y:  Voltage:   67 Volts
    Z:  Voltage:   67 Volts

Interface Boards:
    Board 1:  24 inputs   8 outputs
    Board 2: not installed
    Board 3: not installed
    Board 4: not installed

Bay Cards:
    Bay 1:  not installed
    Bay 2:  not installed
    Bay 3:  Ethernet Configuration 9
             Port 5A: 1000BASE-SX (8131-01)
             Port 5B: 1000BASE-SX (8131-01)
             Port 5C: 100BASE-FX (8103-01)
             Port 5D: 100BASE-FX (8103-01)
             Port 5E: 100BASE-FX (8103-01)
    Bay 4:  RS-232 and IRIG-B

Extended Relay Features:
    IEC 61850

If the above information is not as expected, contact SEL for assistance.

=>>
```

Figure 14.20 Sample VER Command Response

If an item is not installed, the **VER** report indicates `Not installed` at the appropriate line. If a detected hardware configuration does not match the component part number, the relay adds the statement `Warning - hardware does not match part number` on the corresponding line.

VIEW

Use the **VIEW** command to examine data within the relay database. You can view these data in three ways:

- Region
- Register item
- Bit

The **VIEW** command in the relay is very similar to the **VIEW** command in SEL Communications Processors. See *Section 10: Communications Interfaces* in the product-specific instruction manual for more information on the relay database regions and data types.

Typical relay regions are LOCAL, METER, DEMAND, TARGET, HISTORY, BREAKER, STATUS, and ANALOGS; view this list with the **MAP 1** command.

The relay is Virtual Device 1; all commands begin with VIEW 1. In all database views, if a data item is in test mode (controlled by **TEST DB** command), the relay displays an asterisk (*) mark following the data value.

VIEW 1 Commands—Region

Use the commands in *Table 14.157* to view the contents of the database regions.

Table 14.157 VIEW 1 Commands—Region

Command	Description	Access Level
VIEW 1 ***region***	Display the data in the relay database in the region *region*.	1, B, P, A, O, 2
VIEW 1 ***region*** **BL**	Display the data in the region *region* and include bit labels.	1, B, P, A, O, 2

VIEW 1 Commands—Register Item

Use the commands in *Table 14.158* to view register items in the relay database. Typical examples of register items in the METER region are IA1, I0_1, VB, and PF. Examples of register items in the LOCAL region are FID, SER_NUM, and PART_NUM.

Table 14.158 VIEW 1 Commands—Register Item (Sheet 1 of 2)

Command	Description	Access Level
VIEW 1 ***addr***	Display the data in the relay database at register address *addr*.	1, B, P, A, O, 2
VIEW 1 ***addr*** **NR** ***m***[a]	Display the data beginning at register address *addr* and continue for *m* registers.	1, B, P, A, O, 2
VIEW 1 ***region item_label***	Display the data for the addresses in the *region item_label* area of the database.	1, B, P, A, O, 2
VIEW 1 ***region item_label*** **NR** ***m***	Display the data for addresses in the *region item_label* area of the database; begin at the start of *item_label* and proceed for *m* registers.	1, B, P, A, O, 2

Table 14.158 VIEW 1 Commands—Register Item (Sheet 2 of 2)

Command	Description	Access Level
VIEW 1 ***region offset***	Display the data for the address in the database region *region* at the offset *offset* from the beginning of the region.	1, B, P, A, O, 2
VIEW 1 ***region offset*** **NR** ***m***	Display the data for the addresses in the database region *region*; begin at the offset *offset* from the beginning of the region and proceed for *m* registers.	1, B, P, A, O, 2

[a] Parameter m is an integer value representing the number of registers.

In the **VIEW 1** ***addr*** commands, option *addr* is the register address. Use the **MAP 1** ***region*** command to find the register address. You can specify register addresses as a decimal or hexadecimal number. (A hexadecimal address is a numeral with an "h" suffix or a "0x" prefix.) If you specify the data by address or by offset with the *addr* and *offset* options, the relay returns the data in hexadecimal number format. The **NR** option specifies the number of registers *m* that the relay includes in the data listing.

VIEW 1 Commands—Bit

Use commands in *Table 14.159* to inspect a specific bit in the relay database. The relay displays bit data as the bit label or number and the value logical 1 or logical 0. An example of a relay response for bit commands is `1:TARGET:ALTI = 0`, where `ALTI` is the bit label and `0` is the bit value.

Table 14.159 VIEW 1 Commands—Bit[a]

Command	Description	Access Level
VIEW 1 ***addr bit***	Display the value at register address *addr* for the bit number *bit*.	1, B, P, A, O, 2
VIEW 1 ***bit_label***	Display the value for the bit with the bit label *bit_label*.	1, B, P, A, O, 2
VIEW 1 ***region bit_label***	Display the value for the particular bit with the bit label *bit_label* in the region *region*.	1, B, P, A, O, 2
VIEW 1 ***region offset bit***[b]	Display the value for the bit *bit* in the region *region* that is offset from the beginning of the region by offset *offset*.	1, B, P, A, O, 2

[a] Parameter bit is a number from 0–15, with 0 as the LSB (least significant bit).
[b] Parameter offset is a decimal or hexadecimal number to indicate the offset.

The command option *bit* is the bit number. If you access bit data, the relay displays the bit label or number and the value (logical 0 or logical 1). If you reference the data by label with the **BL** and *bit_label* options, the relay returns the data according to the data type.

Use the **VIEW 1** ***bit_label*** command as a shorthand method to inspect a specific data bit in the relay database. The relay searches the entire relay database structure for the bit label you specified; this process takes more time and processing than narrowing the search by using the **VIEW 1** ***region*** command and the **VIEW 1** ***addr*** command with the bit label option *bit_label*.

SECTION 15

Communications Interfaces

This section provides information on communications interface options for SEL-400 series relays. The following topics are discussed:

- *Serial Communication on page 15.2*
- *Serial Port Hardware Protocol on page 15.4*
- *Ethernet Communications on page 15.6*
- *Virtual File Interface on page 15.21*
- *Software Protocol Selections on page 15.28*
- *SEL Protocol on page 15.29*
- *SEL MIRRORED BITS Communication on page 15.36*
- *SEL Distributed Port Switch Protocol (LMD) on page 15.43*
- *SEL-2600A RTD Module Operation on page 15.43*
- *Direct Networking Example on page 15.45*

The relay collects, stores, and calculates a variety of data. These include electrical power system measurements, calculated quantities, diagnostic data, equipment monitoring data, fault oscillography, and sequential event reports. A communications interface is the physical connection on the relay that you can use to collect data from the relay, set the relay, and perform relay test and diagnostic functions.

The relay has three rear-panel serial ports and one front-panel serial port. These serial ports conform to the EIA-232 standard (often called RS-232). Several optional SEL devices are available to provide alternative physical interfaces, including EIA-485 and fiber-optic cable. The relay also has an Ethernet card to support a variety of communication protocols. TiDL relays also have a TiDL communications board that replaces the local CT/PT inputs.

Once you have established a physical connection, you must use a communications protocol to interact with the relay. A communications protocol is a language that you can use to perform relay operations and collect data. For information on protocols that you can use with the relay, see the instruction manual sections listed in *Table 15.1*.

Table 15.1 Relay Communications Protocols (Sheet 1 of 2)

Communications Protocol	Communications Interface	For More Information See
ASCII Commands	EIA-232[a] or Telnet using Ethernet	*Section 14: ASCII Command Reference*
High-Availability Seamless Redundancy (HSR) Protocol	Ethernet	*Network Connection by Using HSR Operating Mode on page 15.15*
Distributed Port Switch (LMD)	SEL-2885 EIA-232 to EIA-485 transceiver on an EIA-232 port	*SEL Distributed Port Switch Protocol (LMD) on page 15.43*
DNP3	EIA-232[a] or Ethernet	*Section 16: DNP3 Communication*
File Transfer Protocol (FTP)	Ethernet	*FTP on page 15.16*
HTTP	Ethernet	*HTTP (Hypertext Transfer Protocol) Server on page 15.20*

Table 15.1 Relay Communications Protocols (Sheet 2 of 2)

Communications Protocol	Communications Interface	For More Information See
IEC 61850	Ethernet	*Section 17: IEC 61850 Communication*
MIRRORED BITS Communications	EIA-232[a]	*SEL MIRRORED BITS Communication on page 15.36*
Phasor Measurement Protocols (IEEE C37.118 and SEL Fast Message)	EIA-232[a] Ethernet[b]	*Section 18: Synchrophasors*
Precision Time Protocol (PTP)	Ethernet	*Precision Time Protocol (PTP) on page 15.18*
Parallel Redundancy Protocol (PRP)	Ethernet	*Network Connection by Using PRP Operating Mode on page 15.12* and *Network Connection by Using PRP Operating Mode on page 15.14*
SEL Binary Protocols (Fast Meter, Fast Operate, Fast SER)	EIA-232[a] or Telnet using Ethernet	*SEL Fast Meter, Fast Operate, Fast SER Messages, and Fast Message Data Access on page 15.34*
SEL Fast Message RTD Protocol	EIA-232[a]	*SEL Fast Meter, Fast Operate, Fast SER Messages, and Fast Message Data Access on page 15.34*
SNTP	Ethernet	*SNTP on page 15.17*
Telnet	Ethernet	*Telnet on page 15.17*
T-Protocol	TiDL Communications	*TiDL (T-Protocol) on page 19.1*

[a] You can add converters to transform EIA-232 to other physical interfaces.
[b] Phasor Measurement over the Ethernet card is only available via IEEE C37.118 protocol.

Serial Communication

Each relay has four serial ports that you can use for serial communication with other devices.

EIA-232 Interfaces

The relay has four EIA-232 communications interfaces. The serial port locations for the 4U chassis are shown in *Figure 15.1* and *Figure 15.2*; other chassis sizes are similar. The port on the front panel is PORT F and the three rear-panel ports are PORT 1, PORT 2, and PORT 3.

Figure 15.1 Relay 4U Chassis Front-Panel Layout

Figure 15.2 Example 4U Rear-Panel Layout in Relay With Bay Cards

The EIA-232 ports are standard female 9-pin connectors with the pin numbering shown in *Figure 15.3*. The pin functions are listed in *Table 15.2*. Pin 1 can provide power to an external device.

Figure 15.3 EIA-232 Connector Pin Numbers

Table 15.2 EIA-232 Pin Assignments

Pin	Signal Name	Description	Comments
1	5 Vdc	Modem power	Jumper selectable on **PORT 1**–**PORT 3**. No connection on **PORT F**.
2	RXD	Receive data	
3	TXD	Transmit data	
4	+IRIG-B	Time-code signal positive	**PORT 1** only. No connection on **PORT F**, **PORT 2**, and **PORT 3**.
5	GND	Signal ground	Also connected to chassis ground.
6	–IRIG-B	Time-code signal negative	**PORT 1** only. No connection on **PORT F**, **PORT 2**, and **PORT 3**.
7	RTS	Request to send	
8	CTS	Clear to send (input)	
8	TX/RX CLK (for SPEED := SYNC, only available when PROTO := MBA or MBB)	Transmit and receive clock (input)	Rear-panel serial ports only
9	GND	Chassis ground	

NOTE: Pins 5 and 9 are not intended to provide a chassis ground connection.

The +5 V serial port supply that is common to all three rear serial ports is monitored by the relay. If the +5 V supply is overloaded, the relay issues an HALARM warning (pulses HALARM bit for 5 seconds) and displays a port overload message in the relay status report. The serial port keeps working, regardless of this condition.

EIA-232 Communications Cables

For most installations, you can obtain information on the proper EIA-232 cable configuration from the SEL-5801 Cable Selector Program. Using the SEL-5801 software, you can choose a cable by application. The software provides the SEL

cable number with wiring and construction information, so you can order the appropriate cable from SEL or construct one. If you do not see information for your application, please contact SEL and we will assist you. You can obtain a copy of the SEL-5801 software by contacting SEL or from selinc.com.

Severe power and ground problems can occur on the communications ports of this equipment as a result of using non-SEL cables. Never use standard null-modem cables with this equipment.

You can connect to a standard 9-pin computer port with an SEL-C234A cable for relay configuration and programming with a terminal program or with the ACSELERATOR QuickSet SEL-5030 software.

Fiber-Optic Interface

You can add transceivers to the EIA-232 ports to use fiber-optic cables to connect devices. We strongly recommend that you use fiber-optic cables to connect devices within a substation. Power equipment and control circuit switching can cause substantial interference with communications circuits. You can also experience significant ground potential differences during fault conditions that can interfere with communications and damage equipment. Fiber-optic cables provide electrical isolation that increases safety and equipment protection.

Use the SEL-2800 product series transceivers for multimode or single-mode fiber-optic communications. All of these transceivers are port powered, require no settings, and operate automatically over a broad range of data rates. SEL-2800 series transceivers operate over the same wide temperature ranges as SEL relays, providing reliable operations in extreme conditions.

EIA-485

There is no EIA-485 port integral to the relay. You can install an SEL-2885 or SEL-2886 transceiver to convert one of the rear-panel EIA-232 ports (**PORT 1**–**PORT 3**) on the relay to an EIA-485 port. The SEL-2885 and SEL-2886 are powered by the +5 Vdc output on Pin 1. These transceivers offer transformer isolation not found on most EIA-232-to-EIA-485 transceivers. See the transceiver product fliers for more information.

The SEL-2885 offers the SEL Distributed Port Switch Protocol (LMD). With this protocol you can selectively communicate with multiple devices on an EIA-485 network. You can communicate with other network nodes including EIA-232 devices with an SEL-2885 and SEL devices having integral EIA-485 ports. You can find more information about using SEL LMD in *SEL Distributed Port Switch Protocol (LMD) on page 15.43*.

Serial Port Hardware Protocol

The serial ports comply with the EIA-232 Standard (formerly known as RS-232). The serial ports support RTS/CTS hardware flow control. See also *Software Flow Control on page 15.32*.

Hardware Flow Control

Hardware handshaking is one form of flow control that two serial devices use to prevent input buffer information overflow and loss of characters. To support hardware handshaking, connect the RTS output pin of each device to the CTS input pin of the other device. To enable hardware handshaking, use the **SET P** command (or front-panel **SET** pushbutton sequence) to set RTSCTS := Y. Disable hardware handshaking by setting RTSCTS := N. *Table 15.3* shows actions the relay takes for the RTSCTS setting values and the conditions relevant to hardware flow control.

Table 15.3 Hardware Handshaking

Setting RTSCTS Value	Condition	Relay Action
N	All	Assert RTS output pin and ignore CTS input pin.
Y	Normal input reception	Assert RTS output pin.
Y	Local input buffer is close to full	Deassert RTS pin to signal remote device to stop transmitting.
Y	Normal transmission	Sense CTS input is asserted, transmit normally.
Y	Remote device buffer is close to full, so remote device deasserts RTS	Sense CTS input is deasserted, stop transmitting.

Note that the relay must assert the RTS pin to provide power for some modems, fiber-optic transceivers, and hardware protocol converters that are port powered. Check the documentation for any port-powered device to determine if the device supports hardware handshaking or if you must always assert RTS (RTSCTS := N) for proper operation.

Data Frame

The relay ports use asynchronous data frames to represent each character of data. Four port settings influence the framing: SPEED, DATABIT, PARITY, and STOPBIT. The time allocated for one bit is the reciprocal of the SPEED. For example, at 9600 bits per second, one bit-time is 0.104 milliseconds (ms).

The default port framing uses one start bit, eight data bits, no parity bit, and one stop bit. The transmitter asserts the TXD line for one data frame, as described in the following steps:

The TXD pin is normally in a deasserted state.

- To send a character, the transmitter first asserts the TXD pin for one bit time (start bit).
- For each data bit, if the bit is set, the transmitter asserts TXD for one bit time. If the bit is not set, it deasserts the pin for one bit time (data bits).
- If the PARITY setting is E, the transmitter asserts or deasserts the parity bit so that the number of asserted data bits plus the parity bit is an even number. If the PARITY setting is O, the transmitter asserts or deasserts the parity bit so that the number of asserted data bits plus the parity bit is an odd number. If the PARITY setting is N, the data frame does not include a parity bit.

- At the completion of the data bits and parity bit (if any), the transmitter deasserts the line for one bit time (stop bit). If STOPBIT is set to 2, the transmitter deasserts the line for one more bit time (stop bit).
- Until the relay transmits another character, the TXD pin will remain in the unasserted state.

Ethernet Communications

Ethernet Card

⚠CAUTION
The Ethernet card is not hot-swappable. To avoid equipment damage, remove power from the relay before removing or installing the Ethernet card.

The SEL-400 series relays support an Ethernet card. In some SEL-400 series devices, this is a daughter card to the main board, as shown in *Figure 15.4*. In others, it goes into **BAY 3**, as shown in *Figure 15.5* and *Figure 15.6*. The Ethernet card is optional except in relays configured for SV and TiDL. You can either field install the card or order the relay with the card installed at the factory. As with other SEL products, SEL has designed and tested SEL Ethernet cards for operation in harsh environments.

Figure 15.4 Example Two-Port Ethernet Card

Figure 15.5 Example Four-Port Ethernet Card

Figure 15.6 Five-Port Ethernet Card

In some relay models, the Ethernet card has two or four ports and is available with standard twisted-pair and fiber-optic physical interfaces. Other models support a five-port Ethernet card with small form-factor pluggable (SFP) ports, as shown in *Figure 15.6*. The Ethernet card includes redundant physical interfaces with the capability to automatically transfer communications to the backup interface in the event that the primary network fails. For information on substation integration architectures, see *Section 16: DNP3 Communication* and *Section 17: IEC 61850 Communication*.

Once installed in a relay, the settings needed for network operation and data exchange protocols, including DNP3 and IEC 61850, are available in the Port 5 settings.

Ethernet Network Operation

You should carefully design your Ethernet network to maximize reliability, minimize system administration effort, and provide adequate security. SEL recommends that you work with a networking professional to design your substation Ethernet network.

Use the network configuration settings shown in *Table 12.14* and *Table 12.28* to configure the relay for operation on an IP network and to set other parameters affecting the physical Ethernet network interface operation. Depending on the model and ordering selection, the relay is equipped with either two, four, or five Ethernet ports. See *Table 15.4* for information on what protocols are available on which ports for various Ethernet cards and configurations.

Table 15.4 Ethernet Protocol Options

Ethernet Card Type[a, b, c]	PORT 5A and PORT 5B	PORT 5C and PORT 5D	PORT 5E
Two-Port			
5A, 5B	PRP, PTP, GOOSE, IP	—	—
5C, 5D	—	PRP, GOOSE, IP	—
Four-Port			
Independent Bus Mode, Station Bus = (5A, 5B)	PRP, PTP, GOOSE, IP	GOOSE, SV	—
Independent Bus Mode, Station Bus = (5C, 5D)	PTP, GOOSE, SV	PRP, GOOSE, IP	—
Merged Bus Mode	PTP, GOOSE, SV, IP	—	—
Five-Port			
Independent Bus Mode	PRP, HSR, PTP[d], GOOSE, SV	PRP, HSR, PTP[d], GOOSE, IP	IP[e]
Merged Bus Mode	PRP, HSR, PTP[d], GOOSE, SV, IP	—	IP[e]

[a] IP refers to FTP, HTTP, Telnet, SNTP, MMS, DNP, and IEEE C37.118.
[b] The SEL-487B does not support IEEE C37.118.
[c] Some relay models do not support SV.
[d] PTP is not available on ports with HSR enabled.
[e] PORT E does not support SNTP.

The relay IP address setting uses Classless Inter-Domain Routing (CIDR) notation and a variable-length subnet mask (VLSM) to define its local network and host address.

An IP address consists of two parts: a prefix that identifies the network followed by a host address within that network. Early network devices used a subnet mask to define the network prefix of an associated host address. Within the mask, subnet boundaries were defined by the 8-bit segments of the 32-bit IP address. These boundaries constrained network prefixes to 8, 16, or 24 bits, defining Class A, B, and C networks, respectively.

This classful networking often created subnetworks that were not sized efficiently for actual requirements. CIDR allows more effective usage of a given range of IP addresses. In CIDR notation, you enter the IP address setting in the form a.b.c.d/p, where a.b.c.d is the host address in standard dotted decimal form and p is the network prefix expressed as the number of “1” bits in the mask. For example, if IPADDR := 192.168.1.2/24, the host address is 192.168.1.2 and the

network prefix is the first 24 bits of the address, or 192.168.1. The network address is derived by applying the network prefix to the IP address and filling the remaining bits with zeros (in our example, it is 192.168.1.0). The broadcast address is derived similarly, but the remaining bits are filled with ones (192.168.1.255 for the example above). Neither the network (base) address nor the broadcast address can be used for any host or router addresses on the network.

Table 15.5 CIDR Notation

CIDR Value	Subnet Mask
/32	255.255.255.255
/31	255.255.255.254
/30	255.255.255.252
/29	255.255.255.248
/28	255.255.255.240
/27	255.255.255.224
/26	255.255.255.192
/25	255.255.255.128
/24	255.255.255.000
/23	255.255.254.000
/22	255.255.252.000
/21	255.255.248.000
/20	255.255.240.000
/19	255.255.224.000
/18	255.255.192.000
/17	255.255.128.000
/16	255.255.000.000
/15	255.254.000.000
/14	255.252.000.000
/13	255.248.000.000
/12	255.240.000.000
/11	255.224.000.000
/10	255.192.000.000
/9	255.128.000.000
/8	255.000.000.000
/7	254.000.000.000
/6	252.000.000.000
/5	248.000.000.000
/4	240.000.000.000
/3	224.000.000.000
/2	192.000.000.000
/1	128.000.000.000
/0	000.000.000.000

The relay uses the default router address setting to determine how to communicate with nodes on other local networks. The relay communicates with the default router to send data to nodes on other local networks. The default router

must be on the same local network as the relay or the relay will reject the default router setting. You must also coordinate the default router with your general network implementation and administration plan. See *Table 15.6* for examples of how the IP address and subnet mask define the network and node and how these settings affect the default router setting.

If there is no router on the network, enter a null string (“”).

Table 15.6 Default Router Address Setting Examples

IP Address (CIDR)	Network Address	Broadcast Address	Default Router Range[a]
192.168.1.2/28	192.168.1.0	192.168.1.15	192.168.1.0–192.168.1.15
192.168.1.2/24	192.168.1.0	192.168.1.255	192.168.1.a[b]
192.168.1.2/20	192.168.0.0	192.168.15.255	192.168.0.a[b]–192.168.15.a[b]
192.168.1.2/16	192.168.0.0	192.168.255.255	192.168.a[b].b[b]
192.168.1.2/12	192.160.0.0	192.175.255.255	192.160.a[b].b[b]–192.175.a[b].b[b]
192.168.1.2/8	192.0.0.0	192.255.255.255	192.a[b].b[b].c[b]
192.168.1.2/4	192.0.0.0	207.255.255.255	192.a[b].b[b].c[b]–207.a[b].b[b].c[b]

[a] The Default Router cannot be the same as the IP Address, Network Address, or Broadcast Address.

[b] Value in the range 0–255.

NOTE: The ETCPKA setting applies to all TCP traffic on Ethernet ports, including Telnet, FTP, DNP3, IEC 61850 MMS, and IEEE C37.118.

The ETCPKA setting, along with the KAIDLE, KAINTV, and KACNT settings, can be used to verify that the computer at the remote end of a TCP connection is still available. If ETCPKA is enabled and the relay does not transmit any TCP data within the interval specified by the KAIDLE setting, the relay sends a keep-alive packet to the remote computer. If the relay does not receive a response from the remote computer within the time specified by KAINTV, the keep-alive packet is retransmitted as many as KACNT times. After this count is reached, the relay considers the remote device no longer available, so the relay can terminate the connection without waiting for the idle timer (TIDLE or FTPIDLE) to expire.

The relay monitors Manufacturing Message Specification (MMS) inactivity to identify and disconnect MMS clients that have stopped communicating with it. You can set it from 0 to 42000000 seconds via the IED Properties MMS Settings in ACSELERATOR Architect SEL-5032 Software. The MMS Inactivity default value is either 120 seconds or 900 seconds, depending on the relay. Setting this value to 0 disables the MMS Inactivity timer. If enabled, the relay starts a timer for an MMS session after it receives an MMS request from the client on that session. It resets the timer whenever it receives a new MMS request from that client. When the timer runs out, the relay disconnects the MMS session, making it available for other MMS clients.

This feature was implemented in addition to the TCP keep-alive timer to specifically handle MMS clients that do not disconnect properly. As there are a limited number of MMS sessions available, this ensures that misbehaving MMS clients do not take up multiple MMS sessions. Note that the MMS inactivity time-out can still disconnect an MMS session even if the relay receives TCP keep-alive messages from that MMS client.

The two-port and four-port Ethernet cards operate over either twisted-pair or fiber-optic media. Each Ethernet card is equipped with two or four network ports. You can select the medium for each port (10/100 Mbps twisted-pair or 100 Mbps fiber-optic).

The five-port Ethernet card uses SFP ports with compatible SFP transceivers. The transceivers are not included with the card and must be ordered separately. See *Table 15.7* or selinc.com/products/sfp/ for a list of compatible SFP transceivers.

Table 15.7 SFP Transceivers for the Five-Port Ethernet Card

Transceiver Part Number	Interface	Mode[a, b]	Type	Max. Distance	Wavelength	TX Power (dBm)	RX Sens. Max. (dBm)	RX Sens. Min. (dBm)
8131-01	1000BASE-SX	MM	Dual-fiber	300 m (62.5/125 μm) 550 m (50/125 μm)	850 nm	–2.5 to –9	0	–18
8103-01	100BASE-FX	MM	Dual-fiber	2 km	1310 nm	–14 to –24	–12	–31
8109-01	100BASE-FX	MM	Dual-fiber	2 km	1310 nm	–14 to –24	–12	–31
8130-01	1000BASE-LX	SM	Dual-fiber	10 km	1310 nm	–3 to –9.5	–3	–21
8130-02	1000BASE-LX	SM	Dual-fiber	20 km	1310 nm	–1 to –6	–3	–22
8130-03	1000BASE-LX	SM	Dual-fiber	30 km	1310 nm	0 to –5	–3	–24
8130-04	1000BASE-LX	SM	Dual-fiber	40 km	1310 nm	3 to –2	–3	–24
8130-05	1000BASE-XD	SM	Dual-fiber	50 km	1550 nm	0 to –5	–3	–24
8130-06	1000BASE-ZX	SM	Dual-fiber	80 km	1550 nm	5 to 0	–3	–24
8130-08	1000BASE-ZX	SM	Dual-fiber	160 km	1550 nm	5 to 1	–10	–36
8130-10	1000BASE-ZX	SM	Dual-fiber	200 km	1550 nm	8 to 5	–10	–36

[a] MM = multimode.
[b] SM = single-mode.

The five-port Ethernet card is only supported in certain products with a compatible firmware version. See *Appendix A: Firmware, ICD File, and Manual Versions* in the product-specific instruction manual for firmware that supports the five-port Ethernet card. Upgrading to this firmware while retaining an existing card will not impact your settings or functionality. Converting an existing card to the five-port Ethernet card will default the Port 5 settings.

Redundant Ethernet Ports (Two- or Four-Port Ethernet Card)

PORT 5A, PORT 5B and PORT 5C, PORT 5D are Ethernet port pairs. One port pair is for TCP/IP or UDP/IP Ethernet communications, including FTP, Telnet, DNP3 LAN/WAN, etc., and IEC 61850 GOOSE. You can configure these ports for redundant network architectures, or force the relay to use a single Ethernet port for these protocols. If the relay has four ports, the second port pair can be used for relay-specific functionality. PTP is only available on PORT 5A and PORT 5B when using the two- or four-port Ethernet card.

Redundant Ethernet Network by Using FAILOVER Operating Mode

The following settings are available in Port 5 to configure the relay for FAILOVER mode.

- NETMODE := FAILOVER
- NETPORT := the preferred primary network port
- FTIME := desired time-out for the active port before failover to the backup port

NOTE: The process bus on the four-port Ethernet card uses FAILOVER operating mode with no time-out delay.

Connect the relay to redundant networks as shown in *Figure 15.7*.

Figure 15.7 Failover Network Topology

NOTE: The TiDL relay Ethernet ports operate with a BUSMODE setting of INDEPEND. This allows for process bus GOOSE messages to be received by the relay on the non-IP ports. The non-IP ports operate in a fixed FAILOVER mode.

NOTE: For very small values of FTIME, or for a failover event on the process bus, the assertion or deassertion of LNKFAIL and LNKFL2 can be too short for a state change to register in the SER.

On startup, the relay communicates using the primary network port selected by the NETPORT setting. If the relay detects a link failure on the primary port, it asserts the LNKFAIL Relay Word bit. If the standby port's link is up, the relay activates the standby network port after time FTIME. If the link status on the primary port returns to normal before time FTIME, the failover timer resets and operation continues on the primary network port. Similarly, if the relay detects a link failure on the standby port and the primary port's link is up, the relay activates the primary network port after time FTIME.

The relay asserts the LNKFAIL Relay Word bit when it detects a link failure on the station bus. The relay asserts LNKFL2 when it detects a link failure on the process bus. LNKFAIL deasserts when at least one station bus port is active. LNKFL2 deasserts when at least one process bus port is active.

Network Connection by Using Isolated IP Operating Mode

The Isolated IP mode (NETMODE = ISOLATEIP) permits IEC 61850 GOOSE messages on two ports, but restricts IP traffic to just one port. This mode is useful for cases where it is desired to connect one port to a secured network (the IP port) but have the other port leave the security perimeter.

NOTE: If NETMODE = ISOLATEIP, Precision Time Protocol (PTP) is only supported on the port designated as the IP port.

The NETPORT setting selects which port will be the IP port. The other port will only support GOOSE traffic. IP transmissions will only go out the IP port. IP receptions will only be processed from the IP port. GOOSE publications will go out both ports. GOOSE subscriptions will be accepted from either port. Any non-GOOSE traffic received on the non-IP port will be ignored. No traffic will go from one external port to the other.

Network Connection by Using SWITCHED Operating Mode

Make Port 5 setting NETMODE = SWITCHED to activate the internal Ethernet switch. The internal switch connects a single Ethernet stack inside the relay to two external Ethernet ports. The combination of relay and internal switch operate the same as if a single Ethernet port on a relay were connected to an external unmanaged Ethernet switch. Use the internal switch to add devices to a network, as shown in *Figure 15.8*.

Figure 15.8 Using Internal Ethernet Switch to Add Networked Devices

Using this topology, the internal network switch of the relay supports connecting Ethernet devices in series. Each relay in the chain acts as a network hub. Network traffic originating from a relay is forwarded to the adjacent relay, and so on, until the traffic reaches its destination. In this SWITCHED mode, each relay is forced to process and filter traffic not intended for it, which results in a reduced overall network performance. This configuration is only recommended for temporary use. Note that PTP functionality is not available in SWITCHED operating mode.

When using this switched mode, do not to connect the last device back to the Managed Ethernet Switch, thereby creating a loop or ring.

In switched mode, the internal Ethernet switch of the relay is an unmanaged Ethernet switch and does not provide RSTP functionality. You will experience very large RSTP healing times in such a network.

Network Connection by Using Fixed Operating Mode

Force the relay to use a single station bus Ethernet port by making setting NETMODE := FIXED. When NETMODE := FIXED, only the port selected by NETPORT is active. The other port is disabled.

Network Connection by Using PRP Operating Mode

PRP is part of an IEC standard for high availability automation networks (IEC 62439-3). The purpose of the protocol is to provide seamless recovery from any single Ethernet network failure.

The basic concept is that the Ethernet network and all traffic are fully duplicated with the two copies operating in parallel.

The following settings are available in Port 5 to configure the relay for PRP mode.

- NETMODE := PRP
- PRPTOUT := desired time-out for PRP frame entry
- PRPINTV := desired supervision frame transmit interval
- PRPADDR := PRP supervision frame's destination MAC address least significant byte

When NETMODE is not set to PRP, the PRP settings are hidden.

Enabling PRP doubles the number of Ethernet packets received on the station bus. You may need to reduce the number of incoming GOOSE subscriptions so that you do not exceed the relay's incoming GOOSE buffers, which are sized to accommodate a maximum of 128 GOOSE messages.

Redundant Ethernet Ports (Five-Port Ethernet Card)

The five-port Ethernet card includes many of the same capabilities and settings as the two- and four-port Ethernet cards. It also provides new and enhanced capabilities such as PRP, HSR, and fast failover on both the station bus and process bus. **PORT 5A** and **PORT 5B** are reserved for process bus network. **PORT 5C** and **PORT 5D** are reserved for the station bus network. **PORT 5E** operates on an isolated network with a unique IP address making it ideal for engineering and data access. **PORT 5E** supports IP protocols including FTP, HTTP, Telnet, MMS, DNP, and IEEE C37.118. PTP is available on either port pair **PORT 5A**, **PORT 5B** or **PORT 5C**, **PORT 5D**. All ports support 100 Mbps speeds. **PORT 5A** and **PORT 5B** also support 1 Gbps speeds to satisfy potentially large traffic requirements on the process bus. Use the enable interface setting, EINTF, to enable the network interfaces required for your application. If a network interface is not included in EINTF setting, the relay hides the settings associated with that interface.

Redundant Ethernet Network by Using FAILOVER Operating Mode

The following settings are available in Port 5 to configure port pairs **PORT 5A**, **PORT 5B** and **PORT 5C**, **PORT 5D** for FAILOVER mode.

- NETMODP := FAILOVER (for the process bus)
- NETPORP := the preferred primary network port for the process bus
- NETMODE := FAILOVER (for the station bus)
- NETPORT := the preferred primary network port for the station bus
- FTIME := desired time-out for the active port before failover to the backup port for the station bus

NOTE: For a 1000BASE-X connection, auto-negotiation is supported.

For a 100BASE-FX connection, the far-end fault feature is supported to detect asymmetric link failures.

Connect the relay to a redundant network like the one shown in *Figure 15.7*. On startup, the relay communicates using the primary network ports selected by the NETPORT and NETPORP settings. If the relay detects a link failure on the primary port and the standby port's link is up, the relay activates the standby network port. The failover time on the process bus is immediate (less than 100 microseconds) and will drop no more than one SV sample. The failover time on the station bus occurs after time FTIME. If the link status on the primary port on the station bus returns to normal before time FTIME, the failover timer resets and operation continues on the primary network port. Similarly, if the relay detects a link failure on the standby port on the station bus and the primary port's link is up, the relay activates the primary network port after time FTIME.

NOTE: For very small values of FTIME, or for a failover event on the process bus, the assertion or deassertion of LNKFAIL and LNKFL2 can be too short for a state change to register in the SER.

The relay asserts the LNKFAIL Relay Word bit when it detects a link failure on the station bus. The relay asserts LNKFL2 when it detects a link failure on the process bus. LNKFAIL deasserts when at least one station bus port is active. LNKFL2 deasserts when at least one process bus port is active.

Network Connection by Using Fixed Operating Mode

The following settings are available in Port 5 to configure ports PORT 5A, PORT 5B and PORT 5C, PORT 5D for FIXED mode.

- NETMODP := FIXED (for the process bus)
- NETPORP := the preferred primary network port for the process bus
- NETMODE := FIXED (for the station bus)
- NETPORT := the preferred primary network port for the station bus

Only the ports selected by NETPORT and NETPORP are active. PORT 5E is not affected by these settings.

Network Connection by Using PRP Operating Mode

PRP is part of an IEC standard for high availability automation networks (IEC 62439-3). The purpose of the protocol is to provide seamless recovery from any single Ethernet network failure.

The basic concept is that the Ethernet network and all traffic are fully duplicated with the two copies operating in parallel.

The following settings are available in Port 5 to configure port pairs PORT 5A, PORT 5B and PORT 5C, PORT 5D for PRP mode.

- NETMODP := PRP (for the process bus)
- PRPINTP := desired supervision frame transmit interval for the process bus
- PRPADDP := PRP supervision frame's destination MAC address least significant byte for the process bus
- NETMODE := PRP (for the station bus)
- PRPINTV := desired supervision frame transmit interval for the station bus
- PRPADDR := PRP supervision frame's destination MAC address least significant byte for the station bus
- PRPTOUT := desired time-out for PRP frame entry

Enabling PRP on a port pair doubles the number of Ethernet packets received on that interface. You may need to reduce the number of incoming GOOSE subscriptions on the port pairs so that you do not exceed the relay's incoming GOOSE buffers which are sized to accommodate a maximum of 128 GOOSE messages.

Configure the PTHDLY setting to **P2P** to cause the relay to synchronize both the primary and standby ports. This allows the relay to seamlessly maintain PTP synchronization during a failover operation. This does not apply when PTHDLY is set to E2E.

The relay provides PRP supervision bits for GOOSE and SV. See *COM PRP on page 14.14* for more information.

Figure 15.9 shows an example PRP/HSR network with an SEL-421-7 and SEL-401. The five-port Ethernet cards in the relays allow for PRP on both the station bus and process bus, as well as a separate network for engineering access.

Figure 15.9 Example PRP/HSR Network Using SEL-400 Series Relays With Five-Port Ethernet Cards

Network Connection by Using HSR Operating Mode

HSR, similar to PRP, is part of the IEC standard for high-availability automation networks (IEC 62439-3). The purpose of the protocol is to ensure seamless recovery from any single device failure within an HSR ring. This is achieved by fully duplicating the messages and sending it in both clockwise and counter-clockwise directions around the ring. Messages received from other devices in the ring are simply forwarded to the next device, unless they originate from the device itself or are intended solely for that device. Non-HSR capable devices can be attached to the HSR ring through a Redundancy Box (RedBox). The SEL-400 series products support Mode H according to the IEC 62439-3 standard.

The following settings are available in Port 5 to configure port pairs **PORT 5A**, **PORT 5B** and **PORT 5C**, **PORT 5D** for HSR mode.

- NETMODP := HSR (for the process bus)
- HSRADDP := HSR supervision frame's destination MAC address least significant byte for the process bus
- NETMODE := HSR (for the station bus)
- HSRADDR := HSR supervision frame's destination MAC address least significant byte for the station bus

The relay provides supervision bits and logical nodes that monitor the status of the HSR ring. See *COM HSR on page 14.14* for more information.

The five-port Ethernet card in the relay allows for HSR on both the station bus and process bus. However, PTP is not supported on the process bus or station bus ports when they are configured to use HSR operating mode.

For best performance and minimal latency, SEL recommends limiting the number of devices in the ring to 18.

Refer to the following general guidelines to reduce HSR ring latency:

- Use 1 Gbit/s SFPs
- Use devices that operate in cut-through mode
- Use smaller GOOSE frame sizes, typically less than 200 bytes.

Figure 15.9 shows an example HSR network for a process bus and a PRP with PTP for the station bus network that uses an SEL-421-7 and SEL-401.

Ethernet Protocols

NOTE: The relay prioritizes processing IEC 61850 GOOSE data over the data access protocols listed above. With GOOSE enabled, high GOOSE traffic to and from the relay sustained over long periods may cause slowed responsiveness to data transfer requests via TCP/IP protocols.

Access data by using either the standard TCP/IP Telnet and FTP interfaces or, optionally, through the (Web) HTTP Server, DNP3 LAN/WAN or IEC 61850 interface. You cannot access all data through all interfaces. See the appropriate interface section below for details on data access.

FTP

FTP is a standard application-level protocol for exchanging files between computers over a TCP/IP network. The relay Ethernet card operates as an FTP server, presenting files to FTP clients. The relay Ethernet card supports one FTP connection at a time. Subsequent requests to establish FTP sessions will be denied. If your FTP client does not work properly, be sure to set your client to use a single session.

Table 12.15 and *Table 12.29* list lists the settings that affect FTP server operation.

File Structure

The basic file structure is organized as a directory and subdirectory tree similar to that used by Unix, DOS, Windows, and other common operating systems. See *Virtual File Interface on page 15.21* for information on the basic file structure.

Access Control

The standard FTP logins consist of the three-character access level command (e.g., ACC, BAC) with their respective passwords. For example, with default passwords, if you use the username of 2AC and password of TAIL, you will connect with Access Level 2 privileges.

The relay validates FTP clients and controls access by limiting failed password attempts. If a user attempts to log into the relay with three consecutive invalid login attempts within a 1-minute period, the relay disables login requests for 30 seconds and pulses the SALARM and BADPASS Relay Word bits.

FTP settings control anonymous file access features. The special FTP username “anonymous” does not require a password. It has the access rights of the access level selected by the FTPAUSR setting. For example, if FTPAUSR is set to 1 (for Access Level 1), the FTP anonymous user has Access Level 1 rights.

SEL advises against enabling anonymous FTP logins (FTPANMS = Y) except under test conditions. The Ethernet card does not require a password for the special FTP username “anonymous”. If you enable anonymous FTP logins, you are allowing unrestricted access to the relay and host files.

Telnet

Telnet is part of the TCP/IP protocol suite. A Telnet connection provides access to the relay user interface. The relay supports as many as three Telnet connections at a time. When you connect with Telnet and log in to the relay, you can use all of the ASCII and Compressed ASCII commands described in *Section 14: ASCII Command Reference* to configure and interact with the relay. You can also use the SEL binary Fast Meter and Fast Operate commands described in *SEL Fast Meter, Fast Operate, Fast SER Messages, and Fast Message Data Access on page 15.34*.

Use a Telnet client or QuickSet on the host PC to communicate with the relay. To terminate a Telnet session, use the **EXI** command from any access level.

Table 12.17 and *Table 12.31* list the settings that affect Telnet operation.

SNTP

When SNTP is enabled (Port 5 setting ESNTP is not OFF), the relay internal clock conditionally synchronizes to the time of day served by a Network Time Protocol (NTP) server. The relay uses a simplified version of NTP called the SNTP. SNTP is not as accurate as IRIG-B or PTP. The relay can use SNTP as a less accurate primary time source, or as a backup to the higher accuracy IRIG-B or PTP time sources.

If an IRIG-B time source is connected and either Relay Word bits TSOK or TIRIG assert, then the relay synchronizes the internal time-of-day clock to the incoming IRIG-B time-code signal, even if SNTP is configured in the relay and an NTP server is available. If the IRIG-B source is disconnected (TIRIG deassert) then the relay synchronizes the internal time-of-day clock to the NTP server if available. In this way an NTP server acts as either the primary time source, or as a backup time source to the more accurate IRIG-B time source. The above is also true if the relay is connected to an accurate PTP time source, but TPTP (not TIRIG) will deassert when the PTP time source is disconnected.

Three SEL application notes available from the SEL website describe how to create an NTP server.

- AN2009-10: Using an SEL-2401, SEL-2404, or SEL-2407 to Serve NTP Via the SEL-3530 RTAC
- AN2009-38: Using SEL Satellite-Synchronized Clocks With the SEL-3332 or SEL-3354 to Output NTP
- AN2010-03: Using an SEL-2401, SEL-2404, or SEL-2407 to Create a Stratum 1 Linux NTP Server

Configuring SNTP Client in the Relay

To enable SNTP in the relay, set Port 5 setting ESNTP to UNICAST, MANYCAST, or BROADCAST. *Table 12.25* lists the settings associated with SNTP.

SNTP Operation Modes

The following sections explain the setting associated with each SNTP operation mode (UNICAST, MANYCAST, and BROADCAST).

ESNTP = UNICAST

In unicast mode of operation the SNTP client in the relay requests time updates from the primary (IP address setting SNTPPIP) or backup (IP address setting SNTPBIP) NTP server at a rate defined by setting SNTPRAT. If the NTP server

does not respond with the period defined by the sum of setting SNTPTO and SNTPRAT then the relay tries the other SNTP server. When the relay successfully synchronizes to the primary NTP time server, Relay Word bit TSNTPP asserts. When the relay successfully synchronizes to the backup NTP time server, Relay Word bit TSNTPB asserts.

ESNTP = MANYCAST

In manycast mode of operation the relay initially sends an NTP request to the broadcast address contained in setting SNTPPIP. The relay continues to broadcast requests at a rate defined by setting SNTPRAT. When a server replies, the relay considers that server to be the primary NTP server, and switches to UNICAST mode, asserts Relay Word bit TSNTPP, and thereafter requests updates from the primary server. If the NTP server stops responding for time SNTPTO, the relay deasserts TSNTPP and begins to request time from the broadcast address again until a server responds.

ESNTP = BROADCAST

Setting SNTPPIP = 0.0.0.0 while ESNTP = BROADCAST, the relay will listen for and synchronize to any broadcasting NTP server. If setting SNTPPIP is set to a specific IP address while setting ESNTP = BROADCAST, then the relay will listen for and synchronize to only NTP server broadcasts from that address. When synchronized the relay asserts Relay Word bit TSNTPP. Relay Word bit TNSTPP deasserts if the relay does not receive a valid broadcast within the SNTPT0 setting value after the period defined by setting SNTPRAT.

SNTP Accuracy Considerations

SNTP time synchronization accuracy is limited by the accuracy of the SNTP Server and by the networking environment. The highest degree of SNTP time synchronization can be achieved by minimizing the number of switches and routers between the SNTP Server and the relay.

When installed on a network with low burden configured with one Ethernet switch between the relay and the SNTP Server, and when using ESNTP = UNICAST or MANYCAST, the relay time synchronization error to the SNTP server is typically less than ±1 millisecond.

Precision Time Protocol (PTP)

NOTE: PTP is not supported when ports are configured in HSR operating mode.

The two-port and four-port Ethernet cards support PTP on port pair **PORT 5A**, **PORT 5B**. The five-port Ethernet card supports PTP on either port pair **PORT 5A**, **PORT 5B** or **PORT 5C**, **PORT 5D**. The relay supports Precision Time Protocol version 2 (PTPv2) as a slave-only clock as defined by IEEE-1588-2008. PTP provides high accuracy timing over an Ethernet network, eliminating the need for a separate IRIG-B cable and connection. To achieve the best accuracy (<1 µs), it is necessary to have one or more PTP master clocks and that all intervening equipment (e.g., Ethernet switches) need to be 1588-aware (i.e., all intervening network devices need to be transparent or boundary clocks).

NOTE: The SEL-2488 with the PTP option is a PTP grandmaster clock capable GPS receiver.

In PTP, a clock that provides time to other devices, typically based on GPS input, is a master clock. The intervening switches are transparent clocks. It is also possible to connect networks together and pass time from one network to another by using boundary clocks. Transparent and boundary clocks are important because they provide time correction in the PTP messages that pass through them, whereas devices that are not 1588-aware would not provide this correction. Because it is possible for a network to have multiple master clocks, PTP clocks implement algorithms to select the best available clock. The one selected for use

by an end device is the grandmaster clock. A complete description of possible PTP networking configurations is beyond the scope of this manual. You can learn more about configuring a PTP network in these application guides:

> "Using the SEL-2488 to Provide IEEE 1588 Version 2 Grandmaster Functionality in a Redundant Network Topology" (AN2015-07)
>
> "Using the SEL-2488 to Provide IEEE 1588 Version 2 Grandmaster Functionality to Isolated Ethernet Networks" (AN2015-06)

NOTE: See Appendix A: Firmware, ICD File, and Manual Versions in the product-specific instruction manual for firmware that supports PTP over PRP.

To configure PTP, update the Port 5 PTP settings as described in *Table 12.26* and *Table 12.33*. By default, PTP is disabled in the relay. Enable PTP to make the other PTP settings available.

Within PTP, there are multiple clock profiles available. A profile defines the set of PTP features available in a specific application domain. SEL-400 series relays support three profiles: Default, Power System profile (C37.238-2011), and Power Utility Automation profile (IEC/IEEE 61850-9-3-2016).

The Power profile provides predictable performance and the highest accuracy with compensation for network inaccuracies. This Power profile also allows for unique identification of grandmaster clocks, providing better security when operating in local clock mode.

The Power profile is only supported on Layer 2 networks and exclusively uses the peer-to-peer Delay Mechanism. All messages must be sent at 1-second intervals, must have 802.1Q VLAN tags, and Announce messages must include grandmaster ID and (maximum) inaccuracy fields. Transparent clocks are mandatory in a power profile network; boundary clocks are not allowed. For a network with less than 16 hops between Grandmaster and IED, the Power profile can deliver time with better accuracy than 1 µs. Select the profile by using the PTPPRO setting.

The Default profile has many optional features. It was intended to address common applications, so has been implemented by most PTP-capable devices. The Default profile supports both UDP or Layer 2 (802.3) Ethernet transport, and can use either end-to-end (E2E) or peer-to-peer (P2P) Delay Mechanism. Grandmaster clocks can send Announce, Sync, and Delay request messages over a wide range of intervals. A Default profile network can consist of boundary clocks or transparent clocks anywhere between the grandmaster and the end devices. A well-designed Default profile network with an accurate grandmaster can achieve better than 1 µs accuracy

The 61850-9-3 Power Utility Automation profile is only supported on Layer 2 networks and exclusively uses the peer-to-peer delay mechanism. Grandmaster clocks can send Announce and Sync messages over a wide range of intervals. A 61850-9-3 profile network can consist of boundary clocks or transparent clocks anywhere between the grandmaster and the end devices. The performance requirements for this profile are listed in the IEC 61850 standard part 9-3 documentation. This profile does not account for network time inaccuracy calculations, but a well-designed network can achieve better than 1 µs accuracy.

PTP defines a logical grouping of clocks in a network as a clock domain. This allows a logical separation between clocks that participate in different application domains to coexist on the same network. Domains are identified by domain numbers. The domain number for the relay is selected by the DOMNUM setting. Set DOMNUM to match the domain number configured in the master clocks the relay should synchronize with.

The relay supports transport of PTP messages over UDP or layer 2 (Ethernet). Use the PTPTR setting to select the PTP transport mechanism. This needs to match the transport mechanism used in the master clocks. Layer 2 Ethernet transport is available with both the Default and Power System profiles. If operating in a UDP network, PTP will operate on port 320. Except for peer delay messages, the relay sets the time allowed to live (TTL) value in the UDP/IP header of PTP messages to 64. This allows the possibility of synchronizing relay time through routers across a WAN to a PTP master. High-accuracy synchronization may not be achievable across the WAN, so it is left to the user to determine if the accuracy meets the needs of their application.

When using the Power System profile, use the VLAN number and priority settings PVLAN and PVLANPR to set the VLAN ID and priority, respectively, of the Ethernet frames. Be sure to set PVLAN unique from other VLANs used within the relay.

NOTE: For the five-port Ethernet card, configure the PTHDLY setting to **P2P** to cause the relay to synchronize both the primary and standby ports. This allows the relay to seamlessly maintain PTP synchronization during a failover operation. This does not apply when PTHDLY is set to E2E or when using the two- or four-port Ethernet card.

PTP defines two methods for calculating and correcting for the communications path delay between the relay and the master clock: end-to-end (Delay Request-Response) and peer-to-peer (Peer Delay Request-Response). The end-to-end mechanism calculates the total path delay between the relay and the master clock. The peer-to-peer mechanism calculates the total path delay in a piecemeal fashion between each device in the path. Peer-to-peer is the more accurate method and is recommended for use in SEL relays. The relay periodically initiates path delay calculations. Use the PTHDLY and PDINT settings to configure the path delay method and the path delay request rate. If PTHDLY is set to OFF, then the relay will not calculate and correct for path delay. Only the peer-to-peer mechanism is available for Power System profile and 61850-9-3.

By default, the relay will synchronize to any clock on the network that it evaluates to be the best clock based on the Best Master Clock Algorithm (BMCA). Use the Acceptable Master Table settings to specify a list of master (grandmaster or boundary) clocks to which the relay may synchronize. The relay will not synchronize to any master clock that is not in the list. It is recommended to use this feature for additional security. The AMNUM setting selects the number of master clocks you will list in this table. The default value is OFF, which means the relay will synchronize to any master clock on the network. If AMNUM is set to a value other than OFF, that number of allowable masters must be identified in accordance with the PTP transport chosen, i.e., MAC address for 802.3 or IP address for UDP transport.

If the PTP transport (PTPTR) is set to UDP, use the AMIP*n* settings to specify the IP addresses of the clocks the relay is permitted to synchronize to. If PTP transport is set to layer 2, use the AMMAC*n* settings to specify the MAC addresses of the clocks the relay is permitted to synchronize to.

NOTE: The Acceptable Master Table feature may not work for transport over Layer 2 if the intervening Ethernet switch(es) modify the source MAC address of Announce messages passing through them. With transport over Layer 2, the relay uses the source MAC address to identify if an Announce message is coming from a master clock in the table.

If the ALTPRI*n* (alternate priority 1 for master *n*) setting is set to a positive value, the priority1 value in received Announce messages from the corresponding master clock will be replaced by the ALTPRI*n* value before applying the BMCA. The ALTPRI*n* values reprioritize the master clocks locally. A discussion of reasons to apply alternative priorities is beyond the scope of this manual. If you are not familiar with the Best Master Clock Algorithm, leave the setting set to 0.

HTTP (Hypertext Transfer Protocol) Server

The relay provides an HTTP (Web) server to provide read-only access to selected settings, metering, and reports. The HTTP server supports as many as four sessions at a time. *Table 12.16* and *Table 12.30* list the settings that affect HTTP server operation.

When enabled, the HTTP server opens TCP/IP Port 80 by default. Set HTTPPOR to configure any other port as needed.

The relay validates HTTP server access by limiting failed password attempts. If a user attempts to log into the relay with three consecutive invalid login attempts within a 1-minute period, the relay disables login requests for 30 seconds and pulses the SALARM and BADPASS Relay Word bits.

Virtual File Interface

You can retrieve and send data as files through the virtual file interface of the relay. Devices with embedded computers can also use the virtual file interface. When using serial ports or virtual terminal links, use the FILE DIR command. When you use an Ethernet card, the FTP protocol supported by Ethernet presents the file structure and sends and receives files.

The relay has a two-level file structure. There are a few files at the root level and three or more subdirectories or folders. Some SEL-400 series relays support directories in addition to those listed here. *Table 15.8* shows the directories and the contents of each directory.

Table 15.8 Virtual File Structure

Directory	Usage	Access Level
Root	CFG.TXT file, CFG.XML[a] file, SWCFG.ZIP file and the following directories	1
SETTINGS	Relay Settings	1
REPORTS	SER, circuit breaker, protection and history reports	1
EVENTS	EVE, CEV, COMTRADE, and history reports	1
SYNCHROPHASORS[b]	Synchrophasor recording files	1
UPGRADE[c]	Digitally signed firmware upgrades	2

[a] Present only if the Ethernet card is installed.
[b] Only present in SEL-400 series relays that support synchrophasors.
[c] Only present in SEL-400 series relays running SELBOOT R300 or newer and relay firmware that supports firmware upgrades over Ethernet. Directory is not available if Port 5 settings EETHFWU := N.

System Data Format

Settings files and the CFG.TXT file use the system data format (SDF) unless otherwise specified. The files may contain keywords to aid external support software (ESS) parsing. A keyword is defined as a string surrounded by the open and close bracket characters, followed by a carriage return and line feed. Only one keyword is allowed per line in the file. For example, the keyword INFO would look like this in the file: [INFO]<CR><LF>.

Records are defined as comma-delimited text followed by a carriage return and line feed. One line in a text file equals one record. Fields are defined as comma-delimited text strings.

Comma-Delimited Text Rules

Field strings are separated by commas or spaces and may be enclosed in optional double quotation marks. Double quotes within the field string are repeated to distinguish these double quotes from the quotes that surround the field string. Delimiters are spaces and commas that are not contained within double quotes. Two adjacent commas indicate an empty string, but spaces that appear next to another delimiter are ignored. Consider the following examples for converting a list of fields to comma-delimited text. Consider the following list of fields.

Stri,ng 1

Stri"ng 2

String 3

String4

The translation to comma-delimited text is as follows:

"Stri,ng 1","Stri""ng 2","String 3","String4"

Root Directory

The root directory contains three or more subdirectories and two or three files (CFG.TXT, CFG.XML, and SWCFG.ZIP). CFG.XML is only present if an Ethernet card is installed. SWCFG.ZIP is for internal use.

CFG.TXT File (Read-Only)

The CFG.TXT file contains general configuration information about the relay and each setting class. ESS retrieves the CFG.TXT file to interact automatically with the connected relay.

CFG.XML File (Read-Only)

Present only in units with an Ethernet card installed, the CFG.XML file is supplementary to the CFG.TXT file. The CFG.XML file describes the IED configuration and includes firmware identification, settings class names, and configuration file information.

SWCFG.ZIP File (Read/Write)

The SWCFG.ZIP file is a compressed file used to store ESS settings. It is readable at Access Level 1 and above, and writable at Access Level 2 and above.

Settings Directory

You can access the relay settings through files in the SETTINGS directory. We recommend that you use support software to access the settings files, rather than directly accessing them via other means. External settings support software reads settings from all of these files to perform its functions. The relay only allows you to write to the individual SET_*cn* files, where c is the settings class code and *n* is the settings instance. Except for the SET_61850 CID file, changing settings with ESS involves the following steps:

Step 1. The PC software reads the CFG.TXT and SET_ALL.TXT files from the relay.

Step 2. You modify the settings at the PC. For each settings class that you modify, the software sends a SET_*cn*.TXT file to the relay.

Step 3. The PC software reads the ERR.TXT file. If it is not empty, the relay detects errors in the SET_*cn*.TXT file.

Step 4. For any detected errors, modify the settings and send the settings until the relay accepts your settings.

Step 5. Repeat *Step 2–Step 4* for each settings class that you want to modify.

Step 6. Test and commission the relay.

SET_ALL.TXT File (Read-Only)

The SET_ALL.TXT file contains the settings for all of the settings classes in the relay.

SET_cn.TXT Files (Read and Write)

There is a file for each instance of each setting class. *Table 15.9* summarizes the typical settings files. The exact list of settings files depends on the specific settings classes available in each relay model. The settings class is designated by *c*, and the settings instance number is *n*.

BAY_SCREEN.TXT

NOTE: Not all SEL-400 series relays support bay mimic screens.

The BAY_SCREEN.TXT file describes the content of the custom bay mimic screen that can be selected for display on the HMI. This file is generated by QuickSet and may be downloaded to the relay when Bay Control settings are changed.

ERR.TXT (Read-Only)

The ERR.TXT file contents are based on the most recent SET_cn.TXT or SET_61850.CID file written to the relay. If there were no errors, the file is empty. If errors occurred, the relay logs these errors in the ERR.TXT file.

SET_61850.CID

Present if ordered with the IEC 61850 protocol option, the SET_61850.CID file contains the IEC 61850 Configured IED Description (CID) in XML. This file is generated by Architect and downloaded to the relay. See *Section 17: IEC 61850 Communication* for more information on the SET_61850.CID file.

Table 15.9 Typical Settings Directory Files (Sheet 1 of 2)

Settings Class	Filename	Settings Description	Read Access Level	Write Access Level
A	SET_A*n*.TXT	Automation; *n* in range 1–10 For relay-0, *n* = 1	1, B, P, A, O, 2	A, 2
B	SET_B1.TXT	Bay Control	1, B, P, A, O, 2	P, A, O, 2
D	SET_D*n*.TXT	DNP3 remapping; *n* in range 1–5	1, B, P, A, O, 2	P, A, O, 2
F	SET_F1.TXT	Front panel	1, B, P, A, O, 2	P, A, O, 2
G	SET_G1.TXT	Global	1, B, P, A, O, 2	P, A, O, 2
L	SET_L*n*.TXT	Protection logic; *n* in range 1–6	1, B, P, A, O, 2	P, 2

Table 15.9 Typical Settings Directory Files (Sheet 2 of 2)

Settings Class	Filename	Settings Description	Read Access Level	Write Access Level
M	SET_SM.TXT	Breaker monitor settings	1, B, P, A, O, 2	P, 2
N	SET_N1.TXT	Notes	1, B, P, A, O, 2	P, A, O, 2
O	SET_O1.TXT	Contact outputs	1, B, P, A, O, 2	O, 2
P	SET_P*n*.TXT	Port; *n* in range 1, 2, 3, 5, F	1, B, P, A, O, 2	P, A, O, 2
R	SET_R1.TXT	Report	1, B, P, A, O, 2	P, A, O, 2
S	SET_S*n*.TXT	Group *n*; *n* in range 1–6	1, B, P, A, O, 2	P, 2
T	SET_T1.TXT	Alias settings	1, B, P, A, O, 2	P, A, O, 2
All	SET_ALL.TXT	All instances of all setting classes	1, B, P, A, O, 2	N/A
All	ERR.TXT	Error log for most recently written settings file	1, B, P, A, O, 2	N/A
NA	SET_61850.CID	IEC 61850 configured IED description file	1, B, P, A, O, 2	2
NA	BAY_SCREEN.TXT	Custom bay mimic screen content	1, B, P, A, O, 2	P, A, O, 2

Reports Directory

Use the REPORTS directory to retrieve files that contain the reports shown in *Table 15.10*. Note that the relay provides a report file that contains the latest information each time you request the file.

NOTE: Not all SEL-400 series relays support breaker monitoring and corresponding breaker files.

Table 15.10 REPORTS Directory Files

File[a]	Usage: All Are Read-Only Files
SER.TXT[b]	SER report
CSER.TXT[b]	Compressed ASCII SER report
BRE_*n*.TXT	BRE *n* H report, *n* is the breaker reference
BRE_S*n*.TXT	BRE S*n* report, *n* is the breaker reference
CBRE.TXT	Compressed ASCII breaker monitor report
HISTORY.TXT	History file
CHISTORY.TXT	Compressed ASCII History file
PRO.TXT[b]	Profiling report
CPRO.TXT[b]	Compressed ASCII profiling report
TFE.TXT[b, c]	Through-fault event report
THE.TXT[b, c]	Thermal report
THE_D.TXT[b, c]	Daily thermal report
THE_H.TXT[b, c]	Hourly thermal report
VSS.TXT[b, c]	Voltage sag swell report

[a] Report files are read-only
[b] Report clears/resets when retrieved though use of a serial port.
[c] Not available on all SEL-400 series relays. See the product-specific instruction manual for availability.

Events Directory

NOTE: Most SEL-400 series relays provide large resolution event reports of 8 samples/cycle. The SEL-487B provides large resolution event reports of 12 samples/cycle. The SEL-400G provides all event reports in IEEE C37.111-2013 COMTRADE format. Filtered event reports use a 2.5 millisecond sample rate.

The relay provides history, event reports, and oscillography files in the EVENTS directory. Event reports are available in a variety of formats. Depending on the relay, these may include SEL ASCII 4- or 8-samples/cycle reports and Compressed ASCII 4- or 8-samples/cycle reports. The size of each event report file is determined by the LER setting in effect at the time the event is triggered. Higher resolution oscillography is available in binary COMTRADE (IEEE C37.111-1999 and C37.111-2013) format at the sample rate (SRATE) and length (LER) settings in effect at the time the event is triggered.

The 4- and 8-samples/cycle report files (files with names that begin with E or C) are text files with the same format as the **EVENT** and **CEVENT** command responses. Event file names start with the prefix E4_, E8_, E12, C4_, C8_, C12, or HR_, followed by a unique event serial number. For example, if one event is triggered, with serial number of "10001", the EVENTS directory contains the files shown in *Table 15.13*. Event oscillography in COMTRADE format consists of three files (.CFG, .DAT, and .HDR).

The file names for the C37.111-1999 COMTRADE event files have the following format:

pq_nnnnn.rrr

Table 15.11 C37.111-1999 COMTRADE Event File Names

Variable	Description
pq	One of the following: HR (indicating high-resolution event file) HF (indicating high-impedance fault event reports, if supported by the relay) TW (indicating traveling-wave event reports, if supported by the relay)
nnnnn	The unique serial number associated with the event file
rrr	CFG (indicating configuration file) or DAT (indicating data file) or HDR (indicating header file)

The file names for the C37.111-2013 COMTRADE event files have the following format:

yymmdd,hhMMssmmm,0T,aaaaa,bbbbb,ccccc,pq,nnnnn.rrr

Table 15.12 C37.111-2013 COMTRADE Event File Names (Sheet 1 of 2)

Variable	Description
yy	Last two digits of year
mm	The month (01 to 12)
dd	The day (01 to 31)
hh	The hour (00 to 23)
MM	The minute (00 to 59)
ss	The second (00 to 59)
mmm	The millisecond (000 to 999)
aaaaa	The last five characters of the SID setting (after removing spaces)
bbbbb	The last five characters of the RID setting (after removing spaces)
ccccc	The CONAM setting

Table 15.12 C37.111-2013 COMTRADE Event File Names (Sheet 2 of 2)

Variable	Description
pq	One of the following: HR (indicating high-resolution event file) LR (indicating low-resolution event file, if supported by the relay) DR (indicating disturbance recording event files, if supported by the relay) HF (indicating high-impedance fault event reports, if supported by the relay) TW (indicating traveling-wave event reports, if supported by the relay)
nnnnn	The unique serial number associated with the event file
rrr	CFG (indicating configuration file) or DAT (indicating data file) or HDR (indicating header file)

the *yymmdd* and *hhMMss* values are based on the SOC (second of century) of the first triggered data point as specified in the COMTRADE C37.111 standard.

Spaces and characters **? " / \ < > * | : ; [ ] $ % { }** are not supported in the RID or SID used in the C37.111-2013 filenames, and the relay will automatically remove them.

Table 15.13 EVENTS Directory Files (for Event 10001)

File	Usage
HISTORY.TXT	History file; read-only
CHISTORY.TXT	Compressed ASCII history file; read-only
C4_10001.TXT	4-samples/cycle Compressed ASCII event report; read-only
C8_10001.TXT[a]	8-samples/cycle Compressed ASCII event report; read-only
E4_10001.TXT	4-samples/cycle event report; read-only
E8_10001.TXT[b]	8-samples/cycle event report; read-only
HR_10001.CFG	Sample/second C37.111-1999 COMTRADE configuration file; read-only
HR_10001.DAT	Sample/second C37.111-1999 COMTRADE binary data file; read-only
HR_10001.HDR	Sample/second C37.111-1999 COMTRADE header file; read-only
yymmdd,hhMMssmmm,0T,aaaaa,bbbbb,ccccc,pq,nnnnn.CFG[c]	Sample/Second C37.111-2013 COMTRADE configuration file, read-only
yymmdd,hhMMssmmm,0T,aaaaa,bbbbb,ccccc,pq,nnnnn.DAT	Sample/Second C37.111-2013 data file, read-only
yymmdd,hhMMssmmm,0T,aaaaa,bbbbb,ccccc,pq,nnnnn.HDR	Sample/Second C37.111-2013 COMTRADE header file, read-only

[a] In the SEL-487B, this is replaced with C1210001.TXT, which provides a 12-samples/cycle Compressed ASCII event report.
[b] In the SEL-487B, this is replaced with E1210001.TXT, which provides a 12-samples/cycle event report.
[c] See the filename descriptions in Figure 15.12 for an explanation of the variable names used in the C37.111-2013 COMTRADE format.

Synchrophasors Directory

Table 15.14 shows an example SYNCHROPHASORS directory. Synchrophasor data recording is enabled when synchrophasors are enabled and EPMDR := Y. The filename includes a time stamp based on the first data frame in the file. The data in the file conforms to the IEEE C37.118 data format.

Table 15.14 SYNCHROPHASORS Directory File Sample

File	Description
080528,160910,0,ONA,1,ABC.PMU	080528 = date 160910 = time 0 = GMT (no time offset) ONA = Last three letter (spaces removed) of the PMSTN setting 1 = PMID setting ABC = CONAM setting (company name) PMU = file name extension indicating synchrophasor recording file

Upgrade Directory

Table 15.15 shows the file contents of the UPGRADE directory. The UPGRADE directory is only available via FTP at Access Level 2 and above on relays that support Ethernet firmware upgrades. The directory is not available if the Port 5 setting EETHFWU := N. The RELAY.ZDS and SELBOOT.ZDS are write-only files, whereas the ERR.TXT is a read-only file.

NOTE: The UPGRADE directory is not available via FTP if FTPANM := Y.

Table 15.15 UPGRADE Directory File Sample

File	Description
ERR.TXT	Digitally signed firmware upgrade error file, read-only
RELAY.ZDS	Digitally signed firmware upgrade file, write-only
SELBOOT.ZDS	SELBOOT firmware digitally signed upgrade file, write-only

Batch File Access

You can access files as a batch by using the supported wildcard characters ***** or **?**. Use ***** to match any sequence of characters and **?** to match any single character.

FTP and MMS Wildcard Usage

Table 15.16 shows examples using supported wildcards. Note that these wildcards may be appended to a directory path (e.g., /specified_directory/*.txt).

Table 15.16 FTP and MMS Wildcard Usage Examples

Usage	Description	Example	Note
**xyz*	Lists all files and/or subdirectories, within a specified directory, whose names (including extension) end with *xyz*.	/*.TXT	List all files with the .TXT extension
*abc**	Lists all files and/or subdirectories, within a specified directory, whose names begin with *abc*.	/SETTINGS/SET*	List all settings files that start with SET
mno	Lists all files and/or subdirectories, within a specified directory, whose names contain *mno*.	/EVENTS/*_100*	List all events that contain _100 in the ID number
abc?.xyz[a]	Lists all files, within a specified directory, whose names begin with *abc* and whose names (including extension) end with *xyz* and have any one single character following the letter *c*.	/EVENTS/C?_10007.CEV	Retrieves both the filtered and raw compressed event reports pertaining to the unique event number 10007

[a] Only available for FTP.

Ymodem Wildcard Usage

NOTE: Ymodem protocol only supports wildcard file retrieval operations for event files.

NOTE: Wildcards cannot be used in the last five digits of the file name when retrieving event reports.

Event, report, synchrophasor, and settings files can be accessed as a batch by using wildcards.

Table 15.17 Ymodem Wildcard Usage Examples

Usage	Description	Example	Note
**xyz*	Selects all files whose names (including extension) end with *xyz*.	FILE DIR EVENTS *.CFG	Lists all COMTRADE.CFG files
*abc**	Selects all files whose names begin with *abc*.	FILE READ EVENTS HR_10007*	Retrieves all of the three files for the COMTRADE event 10007 (HR_10007.CFG, HR_10007.DAT, and HR_10007.HDR)
mno	Selects all files whose names contain *mno*.	FILE READ EVENTS *10007*	Retrieves all event files pertaining to the unique event number 10007 (including both the filtered and raw compressed event reports and all three comtrade files)
abc?.xyz	Selects all files whose names begin with *abc* and whose names (including extension) end with *xyz* and have any one single character following the letter c.	FILE DIR SETTINGS SET_D?.TXT	Lists all of the DNP settings files (SET_D1.TXT–SET_D5.TXT)

Software Protocol Selections

The relay supports the protocols and command sets shown in *Table 15.18*.

NOTE: Not all SEL-400 series relays support MBGA and MBGB protocol.

NOTE: Not all SEL-400 series relays support synchrophasors (the PMU protocol choice).

NOTE: Not all SEL-400 series relays support RTD communications with the SEL-2600A.

Table 15.18 Supported Serial Command Sets

PROTO Setting Value	Command Set	Description
SEL	SEL ASCII	Commands and responses
SEL	SEL Compressed ASCII	Commands and comma-delimited responses
SEL	SEL Fast Meter	Binary meter and digital element commands and responses
SEL	SEL Fast Operate	Binary operation commands
SEL	SEL Fast Message	Fast Message database access, binary SER commands and responses
MBA, MBB, MBGA, or MBGB	SEL MIRRORED BITS communications	Binary high-speed control commands
PMU	Phasor Measurement Unit	Binary Synchrophasor Protocol, as selected by Port Setting PMUMODE and Global Setting MFRMT (see *Section 18: Synchrophasors*).
RTD	SEL Fast Message protocol for resistance temperature detector (RTD) data	As many as 12 analog temperature readings from the SEL-2600A.
DNP	DNP3 Level 2 Outstation	Binary commands and responses (see *Section 16: DNP3 Communication*).

Virtual Serial Ports

Actual serial ports are described in *Serial Port Hardware Protocol on page 15.4*. In addition to actual serial ports, the relay supports several virtual serial ports. A virtual serial port does the following:

- Transmits and receives characters through a different mechanism than the physical serial port
- "Encapsulates" characters in virtual terminal messages of a different protocol
- Simulates an actual serial port with setting PROTO := SEL
- May have restrictions imposed by the protocol that encapsulates the virtual serial data

You can set the relay to use virtual serial ports encapsulated in SEL MIRRORED BITS communications links, DNP3 links, and through Telnet over Ethernet.

SEL Protocol

This section describes the command sets that are active when the port setting PROTO := SEL. You can also access these protocols through virtual serial ports that simulate ports with PROTO := SEL.

SEL ASCII Commands

SEL originally designed the SEL ASCII commands for communication between the relay and a human operator via a keyboard and monitor or a printing terminal. A computer with a serial port can also use the SEL ASCII protocol to communicate with the relay, collect data, and issue commands.

The ASCII character set specifies numeric codes that represent printing characters and control characters. The complete ASCII command set is shown in *Section 14: ASCII Command Reference*. *Table 15.19* shows the subset of the ASCII control characters used in this section.

Table 15.19 Selected ASCII Control Characters

Decimal Code	Name	Usage	Keystroke(s)
13	CR	Carriage return	**<Enter>** or **<RETURN>** or **<Ctrl+M>**
10	LF	Line feed	**<Ctrl+J>**
02	STX	Start of transmission	**<Ctrl+B>**
03	ETX	End of transmission	**<Ctrl+C>**
24	CAN	Cancel	**<Ctrl+X>**
17	XON	Flow control on	**<Ctrl+Q>**
19	XOFF	Flow control off	**<Ctrl+S>**

The **<Enter>** key on standard keyboards sends the ASCII character CR for a carriage return. This manual instructs you to press the **<Enter>** key after commands to send the proper ASCII code to the relay. A correctly formatted command transmitted to the relay consists of the command, including optional parameters,

followed by either a CR character (carriage return) or CR and LF characters (carriage return and line feed). The following line contains this information in the format this manual uses to describe user input:

<command> <Enter> or <command> <Enter> <CR>

You may truncate commands to the first three characters. For example, **EVENT 1 <Enter>** is equivalent to **EVE 1 <Enter>**. You may use upper- and lowercase characters without distinction, except in passwords.

In response to a command, the relay may respond with an additional dialog line or message. The relay transmits dialog lines in the following format:

```
<DIALOG LINE ><CR><LF>
```

The relay transmits messages in the following format:

```
<STX><MESSAGE LINE 1><CR><LF>
<MESSAGE LINE 2><CR><LF>
…
<LAST MESSAGE LINE><CR><LF>< ETX>
```

Each message begins with the start-of-transmission character, STX, and ends with the end-of-transmission character, ETX. Each line of the message ends with a carriage return, CR, and line feed, LF.

Send the CAN character to the relay to abort a transmission in progress. For example, if you request a long report and want to terminate transmission of this report, depress the **<Ctrl>** and **<X>** keys (**<Ctrl+X>**) to terminate the report.

SEL Compressed ASCII Commands

The relay supports a subset of SEL ASCII commands identified as Compressed ASCII commands. Each of these commands results in a comma-delimited message that includes a checksum field. Most spreadsheet and database programs can directly import comma-delimited files. Devices with embedded processors connected to the relay can execute software to parse and interpret comma-delimited messages without expending the customization and maintenance labor needed to interpret nondelimited messages. The relay calculates a checksum for each line by numerically summing all of the bytes that precede the checksum field in the message. The program that uses the data can detect transmission errors in the message by summing the characters of the received message and comparing this sum to the received checksum.

Most commands are available only in SEL ASCII format. Selected commands have versions in both standard SEL ASCII and Compressed ASCII formats. Compressed ASCII reports generally have fewer characters than conventional SEL ASCII reports, because the compressed reports reduce blanks, tabs, and other white space between data fields to a single comma.

Compressed ASCII Message Format

Each message begins with the start-of-transmission character, STX, and ends with the end-of-transmission character, ETX:

```
<STX><MESSAGE LINE 1><CR><LF>
<MESSAGE LINE 2><CR><LF>
...
<LAST MESSAGE LINE><CR><LF><ETX>
```

Each line in the message consists of one or more data fields, a checksum field, and a CRLF. Commas separate adjacent fields. Each field is either a number or a string. Number fields contain base-10 numbers that use the ASCII characters 0–9, plus (+), minus (-), and period (.). String fields begin and end with quote marks and contain standard ASCII characters. Hexadecimal numbers are contained in string fields.

The checksum consists of four ASCII characters that are the hexadecimal representation of the two-byte binary checksum. The checksum value is the sum of the first byte on a line (first byte following <STX>, <CR>, or <CR><LF>) through the comma preceding the checksum.

If you request data with a Compressed ASCII command and these data are not available, (in the case of an empty history buffer or invalid event request), the relay responds with the following Compressed ASCII format message:

```
<STX>"No Data Available","0668"<CR><ETX>
```

where:

No Data Available is a text string field.

0668 is the checksum field, which is a hexadecimal number represented by a character string.

Table 15.20 lists the typical Compressed ASCII commands and contents of the command responses. The Compressed ASCII commands are described in *Section 14: ASCII Command Reference*.

Table 15.20 Typical Compressed ASCII Commands

Command	Response	Access Level
BNAME	ASCII names of Fast Meter status bits	0
CASCII	Configuration data of all Compressed ASCII commands available at access levels > 0	0
CBREAKER	Circuit breaker data	1
CEVENT	Event report	1
CHISTORY	List of events	1
CPR	Displays the first 20 rows of the profile report, with the oldest row at the bottom and the latest row at the top	
CSER	Sequential Events Recorder report	1
CSTATUS	Self-diagnostic status	1
CSUMMARY	Summary of an event report	1
DNAME	ASCII names of digital I/O reported in Fast Meter	0
ID	Relay identification	0
SNS	ASCII names for SER data reported in Fast Meter	0

CASCII Configuration Message for Compressed ASCII Commands

The CASCII message provides a block of data for each of the Compressed ASCII commands supported by an SEL device. The block of data for each command provides message description information to allow automatic data extraction. The relay arranges items in the Compressed ASCII configuration message in a predefined order. For the purpose of improving products and services, SEL sometimes changes the items and item order. The information presented below explains the message and serves as a guide to the items in Compressed ASCII configuration messages.

NOTE: Compressed ASCII is self-describing and may vary with the firmware version of your relay. Before you program a master device to send and parse Compressed ASCII commands and responses, you should perform a **CASCII** command on your relay or contact SEL for more detailed information.

A Compressed ASCII command can require multiple header and data configuration lines. The general format of a Compressed ASCII configuration message is the following:

```
<STX>"CAS",n,"yyyy"<CR><LF>
"COMMAND 1",ll,"yyyy"<CR><LF>
"#H","xxxxx","xxxxx",......,"xxxxx","yyyy"<CR><LF>
"#D","ddd","ddd","ddd","ddd",......,"ddd","yyyy"<CR><LF>
.
.
.
"COMMAND n",ll,"yyyy"<CR><LF>
"#H","xxxxx","xxxxx",......,"xxxxx","yyyy"<CR><LF>
"#D","ddd","ddd","ddd","ddd",......,"ddd","yyyy"<CR><LF><ETX>
```

Definitions for the items and fields in a Compressed ASCII configuration message are the following:

- `n` is the number of Compressed ASCII command descriptions to follow.
- `COMMAND` is the ASCII name for the Compressed ASCII command that the requesting device (terminal or external software) sends. The naming convention for the Compressed ASCII commands is a C character preceding the typical command. For example, **CSTATUS**, abbreviated to **CST**, is the Compressed ASCII **STATUS** command.
- `#H` identifies a header line to precede one or more data lines; the # character represents the number of subsequent ASCII names. For example, 21H identifies a header line with 21 ASCII labels.
- `xxxxx` is an ASCII name for corresponding data on following data lines. Maximum ASCII name width is ten characters.
- `#D` identifies a data format line; the # character represents the maximum number of data lines in command response.
- `ddd` identifies a format field containing one of the following type designators:
  - I—Integer data
  - F—Floating-point data
  - *z*S—String of maximum *z* characters (for example, enter 10S for a 10-character string)
- *yyyy* is the 4-byte hex ASCII representation of the checksum. Every checksum is followed by a new line indication (<CR><LF>).

Software Flow Control

Software handshaking is a form of flow control that two serial devices use to prevent input buffer overflow and loss of characters. The relay uses XON and XOFF control characters to implement software flow control for ASCII commands.

The relay transmits the XOFF character when the input buffer is more than 75 percent full. The connected device should monitor the data it receives for the XOFF character to prevent relay input buffer overflow. The external device should suspend transmission at the end of a message in progress when it receives the XOFF character. When the relay has processed the input buffer so that the buffer is less than 25 percent full, the relay transmits an XON character. The external device should resume normal transmission after receiving the XON character.

The relay also uses XON/XOFF flow control to delay data transmission to avoid overflow of the input buffer in a connected device. When the relay receives an XOFF character during transmission, it pauses transmission at the end of the

message in progress. If there is no message in progress when the relay receives the XOFF character, it blocks transmission of any subsequent message. Normal transmission resumes after the relay receives an XON character.

Automatic Messages

If you enable automatic messages, **AUTO = Y**, the relay issues a message any time the relay turns on, asserts a self-test, changes to another settings group, or triggers an event. For virtual ports, the relay issues automatic messages only if the connection is active. Automatic messages contain the following information:

- Power-up: When you turn on the relay, the message provides the terminal ID and the present date and time.
- Self-test failure: When the relay detects an internal failure, the automatic message is the same as the relay response to the **STATUS** command.
- Group switch: Whenever a settings group change occurs, the message contains the relay ID, terminal ID, present date and time, and the selected settings group.
- Events: When the relay triggers an event, the automatic message is the same as the relay response to the **SUMMARY** command.

Time-Out

Use the TIMEOUT setting to set the idle time for each port. Idle time is the period when no ASCII characters are transmitted and received (interleaved Fast Messages do not affect the idle time). When the idle time exceeds the TIMEOUT setting, the following takes place:

- The access level changes to Access Level 0.
- The front-panel targets reset to TAR 0 if the port had previously remapped the targets.
- Virtual connections are disconnected.
- The software flow control state changes to XON.

When set to OFF, the port never times out.

Interleaved ASCII and Binary Messages

SEL relays have two separate data streams that share the same physical serial port. Human data communications with the relay consist of ASCII character commands and reports that you view using a terminal or terminal emulation package. The binary data streams can interrupt the ASCII data stream to obtain information; the ASCII data stream continues after the interruption. This mechanism uses a single communications channel for ASCII communication (transmission of an event report, for example) interleaved with short bursts of binary data to support fast acquisition of metering data. The device connected to the other end of the link requires software that uses the separate data streams to exploit this feature. However, you do not need a device to interleave data streams to use the binary or ASCII commands. Note that XON, XOFF, and CAN operations operate on only the ASCII data stream.

An example of using these interleaved data streams is when the relay communicates with an SEL communications processor. The communications processor performs autoconfiguration by using a single data stream and SEL Compressed

ASCII and binary messages. In subsequent operations, the communications processor uses the binary data stream for Fast Meter, Fast Operate, and Fast SER messages to populate a local database and to perform SCADA operations. At the same time, you can use the ASCII data stream for commands and responses.

SEL Fast Meter, Fast Operate, Fast SER Messages, and Fast Message Data Access

NOTE: For the list of available bits to Fast Meter, see DNAME X on page 14.31.

SEL Fast Meter is a binary message that you solicit with binary commands. Fast Operate is a binary message for control. The relay can also send unsolicited Fast SER messages and unsolicited synchrophasor messages automatically. If the relay is connected to an SEL communications processor, these messages provide the mechanism that the communications processor uses for SCADA or DCS functions that occur simultaneously with ASCII interaction.

This section summarizes the binary commands and messages and includes our recommendation for using Fast Commands and Compressed ASCII configuration information to communicate with the relay. You need this information to develop or specify the software an external device uses to communicate using Fast Messages with the relay. To support this type of development, you will also need to contact SEL for Fast Message protocol details.

Table 15.21 lists the two-byte Fast Commands and the actions the relay takes in response to each command.

NOTE: Not all SEL-400 series relays support demand metering and the corresponding fast commands.

Table 15.21 Fast Commands and Response Descriptions

Command (Hex)	Name	Response Description
A5B9h	Status acknowledge message	Clears Fast Meter status byte and sends current status.
A5C0h	Relay Fast Meter definition block	Defines available Fast Meter messages and general relay configuration information.
A5C1h	Fast Meter configuration block	Defines contents of Fast Meter data message.
A5C2h	Demand Fast Meter configuration block	Defines contents of demand Fast Meter data message.
A5C3h	Peak demand Fast Meter configuration block	Defines contents of peak demand Fast Meter data message.
A5CEh	Fast Operate configuration block	Defines available circuit breaker, remote bits, and associated commands.
A5D1h	Fast Meter data message	Defines present values of analog and digital data.
A5D2h	Demand Fast Meter data message	Defines values of most recently completed demand period.
A5D3h	Peak demand Fast Meter data message	Defines values for peak demands as of end of most recently completed demand periods.

Fast Operate commands use one of the two-byte command types shown in *Table 15.22*. Each Fast Operate command also includes additional bytes that specify a remote bit or circuit breaker bit.

Table 15.22 Fast Operate Command Types

Command (Hex)	Name	Description
A5E0h	Fast Operate command for remote bits	Sends command code that will change the state of a remote bit, if setting FASTOP :=Y for this port.
A5E3h	Fast Operate command for circuit breaker bits	Sends command code that will change the state of a circuit breaker control bit, if setting FASTOP :=Y for this port.

The Fast Operate messages transfer control commands through the binary data stream. You must enable Fast Operate messages for a port before the relay accepts these messages on that port. In the port settings, when the protocol is set to SEL, the FASTOP setting is visible. Set FASTOP :=Y to enable Fast Operate commands or to N to disable Fast Operate commands.

General Fast Messages have a two-byte identifier (A546h) and a function code. Fast SER messages are general Fast Messages that transport Sequential Event Recorder report information. The Fast SER messages include function codes to accomplish different tasks. *Table 15.23* lists the Fast SER function codes and the actions the relay takes in response to each command.

Table 15.23 Fast Message Command Function Codes Used With Fast Messages (A546 Message) and Relay Response Descriptions

Function Code (Hex)	Function	Relay Action
00h	Fast Message definition block request	Relay transmits Fast Message definition request acknowledge (Function Code 80).
01h	Enable unsolicited transfers	Relay transmits Fast SER command acknowledged message (Function Code 81) and sets relay element bit FSERx. Relay will transmit subsequent SER events (Unsolicited SER broadcast, Function Code 18).
02h	Disable unsolicited transfers	Relay sends Fast SER command acknowledged message (Function Code 82) and clears relay element bit FSERx. Relay will not transmit subsequent SER messages.
05h	Ping—determine channel is operable	Relay aborts unsolicited message in progress and transmits ping acknowledge message (Function Code 85).
98h	Fast SER Message acknowledge	Relay completes dialog processing for unsolicited message sequence.
30h	Device description request	Relay sends summary of data blocks available (Function Code B0h).
31h	Data format request	Relay sends description of requested data block, including data labels and types (Function Code B1h).
33h	Bit label request	Relay sends set of bit labels for specific data item (Function Code B3h).
10h	Data request	Relay responds with set of requested data (Function Code 90h).

The SEL Fast Message Synchrophasor Protocol is described in *Section 18: Synchrophasors*.

Recommended Use of Relay Self-Description Messages for Automatic Configuration

Compressed ASCII and Fast Message commands provide information to allow an external computer-based device to adapt to the special messages for each relay. The SEL communications processors use the self-description messages to configure a database and name the elements in the database.

Table 15.24 lists commands and command usage in the recommended order of execution for automatic configuration.

Table 15.24 Commands in Recommended Sequence for Automatic Configuration

Command ASCII or hexadecimal (h suffix)	Response	Usage
ID	Relay identification	ID and FID
A5C0h	Relay Fast Meter definition block	Defines available Fast Meter messages and general relay configuration information
A5C1h, A5C2h, A5C3h	Fast Meter configuration blocks	Defines contents of Fast Meter data messages
BNAME	Binary names	ASCII names of status bits
DNAME	Digital I/O name	ASCII names of digital I/O points
SNS	SER names	ASCII names for SER data points
CASCII	Compressed ASCII configuration block	Configuration data for Compressed ASCII commands with access levels > 0
A5CEh	Fast Operate configuration block	Defines available circuit breaker and remote bits, and associated commands, if setting FASTOP :=Y for this port

SEL MIRRORED BITS Communication

With SEL-patented MIRRORED BITS communications protocol, protective relays and other devices can directly exchange information quickly, securely, and with minimal cost. Use MIRRORED BITS communications for remote control, remote sensing, or communications-assisted protection schemes such as permissive overreaching transfer trip (POTT) and directional comparison blocking (DCB).

SEL products support several variations of MIRRORED BITS communications protocols. Through port settings, you can set the relay for compatible operation with SEL-300 series relays, the SEL-2505 or SEL-2506 Remote I/O Modules, and the SEL-2100 Protection Logic Processors. These devices use MIRRORED BITS communications to exchange the states of eight logic bits. You can also use settings to select extensions of the MIRRORED BITS communications protocols, available only in SEL-400 series relays, to exchange analog values, synchronize clocks, and engage in virtual terminal dialogs. *Table 15.25* summarizes MIRRORED BITS communications features.

Table 15.25 MIRRORED BITS Communications Features (Sheet 1 of 2)

Feature	Compatibility
Transmit and receive logic bits	SEL-300 series relays, SEL-2505, SEL-2506, SEL-2100, SEL-400 series relays
Transmit and receive analog values	SEL-400 series relays
Synchronize time	SEL-400 series relays

Table 15.25 MIRRORED BITS Communications Features (Sheet 2 of 2)

Feature	Compatibility
Send and receive virtual serial port characters	SEL-400 series relays
Support synchronous communications channel	SEL-400 series relays

Communications Channels and Logical Data Channels

The relay supports two MIRRORED BITS communications channels, designated A and B. Use the port setting PROTO to assign one of the MIRRORED BITS communications channels to a serial port: PROTO := MBA or MBGA for MIRRORED BITS communications Channel A or PROTO := MBB or MBGB for MIRRORED BITS communications Channel B.

Transmitted bits include TMB1A–TMB8A and TMB1B–TMB8B. The last letter (A or B) designates with which channel the bits are associated. These bits are controlled by SELOGIC control equations. Received bits include RMB1A–RMB8A and RMB1B–RMB8B. You can use received bits as arguments in SELOGIC control equations. The channel status bits are ROKA, RBADA, CBADA, LBOKA, ROKB, RBADB, CBADB, LBOKB, DOKA, ANOKA, DOKB, and ANOKB. You can also use these bits as arguments in SELOGIC control equations. Use the **COM** command for additional channel status information.

Within each MIRRORED BITS communications message for a given channel (A or B), there are eight logical data channels (1–8). In operation compatible with other SEL products, you can use the eight logical data channels for TMB1–TMB8. If you use fewer than eight transmit bits, Data Channel 8 is reserved to support data framing and time synchronization features. You can assign the eight logical data channels as follows:

- Logic bits: Setting MBNUM controls the number of channels used for logic bits, TMB1–TMB8, inclusive.
  - If you set MBNUM to 8, then you cannot use channels for any of the following features.
  - If you set MBNUM to less than 8, you can use the remaining channels (as many as eight total) for the features listed below.
- Message and time synchronization: If MBNUM is less than 8, the relay dedicates a logical data channel to message framing and time synchronization. This feature is enabled by the MBTIME setting.
- Analog channels: Setting MBNUMAN controls the number of analog channels. It is not guaranteed that multiple analog quantities will come from the same relay sampling interval.
  - If MBNUM := 8, all channels are used for logic bits and MBNUMAN is forced to 0.
  - If MBNUM := 7, seven channels are used for logic bits and one channel is used for message and time synchronization.
  - If MBNUM is less than 7, you can use the remaining channels for analog channels by setting the desired number of channels in MBNUMAN (1 to 7 – MBNUM).

  Note: Analog quantities are converted to Integer values for transmission via MIRRORED BITS. Because of this, they will lose any fractional value they may have had. To maintain a fixed resolution, multiply the analog quantity by a set value before transmission, and divide by the same quantity upon reception. To maintain accuracy, add 0.5 to the analog quantity after any scaling.

- Virtual terminal sessions: Setting MBNUMVT controls the number of additional channels available for the virtual terminal session.
  - If MBNUMVT := OFF, the relay does not dedicate any additional channels to the virtual terminal session.
  - If there are spare channels (7 – MBNUM – MBNUMAN > 0), you can use MBNUMVT to dedicate these additional channels to the virtual terminal session.
  - With MBNUM = 7 or less and MBNUMVT = 0, virtual terminal is still possible because the relay uses the eighth element for time synchronization and virtual terminal.

  The virtual terminal session uses channels differently than other data exchange mechanisms. There can be only one active virtual terminal session across a MIRRORED BITS link. One channel, included in the synchronization data, is always dedicated to this virtual terminal session. If you assign additional channels to the virtual terminal session (set MBNUMVT > 0), you will improve the performance of the virtual terminal session. The relay uses the additional channels to exchange data more quickly.

Operation

MBG Protocol

The MBG protocol selection allows the user to move the MIRRORED BITS Transmit equations to the Group settings for more flexibility in bus transfer schemes. Using MBG will allow the MIRRORED BITS settings to transfer with a Group Switch when it occurs.

NOTE: The MBG protocol option is only available in some SEL-400 series relays.

To enable the MBG protocol, set the Port setting PROTO := MBGA to enable Channel A MIRRORED BITS, or PROTO := MBGB for Channel B MIRRORED BITS. Next, the protocol will need to be enabled in the Group settings.

Under Group settings, enable the MBG protocol for Channel A by setting EMBA := Y. When this setting is enabled, the transmit equation settings TX_IDA, RX_IDA, and TMB*n*A will be available in the Group settings and will be hidden from the Port settings.

The MBG protocol can also be enabled for Channel B by setting EMBB := Y. When this setting is enabled, the transmit equation settings TX_IDB, RX_IDB, and TMB*n*B will be available in the Group settings and will be hidden from the Port settings.

MB8

While the relay does not have a setting for the MB8 protocol implemented in some SEL products, you can configure the relay to communicate with devices set to MB8A or MB8B (such as the SEL-351S or SEL-2505). Set the protocol setting PROTO to MBA or MBB. Set the STOPBIT setting to 2. Set all other settings to match those in the other device.

Message Transmission

The relay transmits a MIRRORED BITS communications message as fast as it can for the configured data rate. At 9600 bps, this is approximately one message every 1/4-cycle. At 19200 bps, it is approximately every 1/8-cycle. At 38400 bps, it is approximately two every 1/8-cycle. However, if pacing is enabled, it slows to

one message every 3 ms at 19200 and 38400 bps (see *Table 15.28*). Each message contains the most recent values of the transmit bits. If you enabled any of the extended features through the settings, note that the relay transmits a portion of the extended data in each message.

If you have specified virtual terminal data channels for this port, the designated data channels are normally idle. If you use the **PORT** command to open a virtual terminal session for this port and type characters, the relay transmits these characters through the virtual terminal logical data channels.

Message Reception Overview

When the devices are synchronized and the MIRRORED BITS communications channel is in a normal state, the relay decodes and checks each received message. If the message is valid, the relay performs the following operations:

- Sends each received logic bit (RMB*n*) to the corresponding pickup and dropout security counters, that in turn set or clear the RMB*nc* relay element bits.
- Accumulates the analog data, and every 18th message, updates the received analog quantities.
- Accumulates the virtual terminal information, and every 18th message, makes the received character or characters available to the virtual terminal.

NOTE: c represents the MIRRORED BITS channel (A or B), n represents the MIRRORED BITS data channel data number (1–8).

Message Decoding and Integrity Checks

The relay provides indication of the status of each MIRRORED BITS communications channel, with element bits ROKA and ROKB. During normal operation, the relay sets the ROK*c* bit. The relay clears the bit upon detecting any of the following conditions:

- Parity, framing, or overrun errors
- Receive data redundancy error
- Receive message identification error
- No message received in the time three messages have been sent

The relay will assert ROK*c* only after successful synchronization as described below and two consecutive messages pass all of the data checks described above. After ROK*c* is reasserted, received data may be delayed while passing through the security counters described below.

While ROK*c* is not set, the relay does not transfer new RMB data to the pickup-dropout security counters described below. Instead, the relay sends one of the user-definable default values to the security counter inputs. For each RMB*n*, specify the default value with setting RMB*n*FL, as follows:

- 1
- 0
- P (to use last valid value)

Individual pickup and dropout security counters supervise the movement of each received data bit into the corresponding RMB*n* element. You can set each pickup/dropout security counter from 1 to 8. A setting of 1 causes a security counter to pass every occurrence, while a setting of 8 causes a counter to wait for eight consecutive occurrences in the received data before updating the data bits. The pickup and dropout security count settings are separate. Control the security count settings with the settings RMB*n*PU and RMB*n*DO.

A pickup/dropout security counter operates identically to a pickup/dropout timer, except that the counter uses units of counted received messages instead of time. An SEL relay communicating with another SEL relay typically sends and receives MIRRORED BITS communications messages eight times per power system cycle. Therefore, a security counter set to two counts will delay a bit by approximately 1/4 of a power system cycle. Reference *Table 15.28* for the message rates based on the settings. You must consider the impact of the security counter settings in the receiving device to determine the channel timing performance.

Channel Synchronization

When an SEL relay detects a communications error, it deasserts ROKA or ROKB. The relay transmits an attention message until it receives an attention message that includes a match to the TX_ID setting value. If the attention message is successful, the relay has properly synchronized and data transmission will resume. If the attention message is not successful, the relay will repeat the attention message until it is successful.

Loopback Testing

Use the **LOOP** command to verify the communications channel. In this mode, the relay expects the transmitted data to be looped back to the relay to test the data transmissions, including communications data. At the remote end, jumper the send and receive communications channels to complete the path for the test. While in loopback mode, ROK*c* is deasserted, and LBOK*c* asserts and deasserts based on the received data checks.

Channel Monitoring

Based on the results of data checks (described above), the relay collects information regarding the 255 most recent communications errors. Each record contains at least the following fields:

- Dropout Time/Date
- Pickup Time/Date
- Time elapsed during dropout
- Reason for dropout

Use the **COM** command to generate a long or summary report of the communications errors.

NOTE: Combine error conditions including RBADA, RBADB, CBADA, and CBADB with other alarm conditions by using SELOGIC control equations. You can use these alarm conditions to monitor and report a communications channel failure.

There is a single record for each outage, but an outage can evolve. For example, the initial cause could be a data disagreement, but framing errors can extend the outage. If the channel is presently down, the COMM record will only show the initial cause, but the COMM summary will display the present cause of failure.

When the duration of an outage on Channel A or B exceeds a user-definable threshold, the relay will assert a user-accessible flag, RBADA or RBADB. When channel unavailability exceeds a user-definable threshold for Channel A or B, the relay asserts a user-accessible flag, CBADA or CBADB.

MIRRORED BITS Communications Protocol for the Pulsar 9600-BPS Modem

NOTE: The MBT9600 modem requires +5 Vdc from pin 1 of the DB 9 connector. A rear serial port can supply this voltage if its jumper is set. See Serial Port Jumpers in the product-specific instruction manual for more information.

NOTE: You must consider the idle time in the calculations of data transfer latency through a Pulsar MBT modem system.

To use a Pulsar MBT modem, set setting MBT := Y. Setting MBT := Y hides setting SPEED and forces it to 9600, and hides setting RTSCTS and forces it to a value of N. The relay also injects a delay (idle time) of 3 ms between messages.

The relay sets RTS to a negative voltage at the EIA-232 connector to signify that MIRRORED BITS communications matches this specification.

Settings

The port settings associated with MIRRORED BITS communications are shown in *Table 15.26* and *Table 15.27*.

Set PROTO := MBA or MBGA to enable the MIRRORED BITS communications protocol Channel A on this port. Set PROTO := MBB or MBGB to enable the MIRRORED BITS communications protocol Channel B on this port.

Table 15.26 General Port Settings Used With MIRRORED BITS Communications

Name	Description	Range	Default
PROTO	Protocol	None, SEL, DNP, MBA, MBB, MBGA, MBGB, RTD, PMU	SEL
MBT	Enable Pulsar 9600 modem	Y, N	N
SPEED	Data speed. Hidden and set to 9600 if MBT := Y	300, 600, 1200, 2400, 4800, 9600, 19200, 38400, SYNC	9600
STOPBIT	Stop bits. Hidden and set to 1 if MBT := Y	1, 2	1

Setting SPEED := SYNC (available only on the rear-panel serial ports for which PROTO := MBA, MBB, MBGA, or MBGB) places the serial port in synchronous (or externally clocked) mode. The serial port hardware will synchronize transmit and receive data (TX/RX) to a clock signal applied to the Pin 8 input at any effective data rate as high as 64000. This setting choice will suit certain synchronous communications networks.

The relay uses the RBADPU setting to determine how long a channel error must persist before the relay asserts RBADA or RBADB. The relay deasserts RBADA and RBADB when it no longer detects a channel error. RBADA and RBADB update immediately in the MIRRORED BITS protocol but may take several milliseconds to update for SELOGIC control equations. It is recommended to use RBADA and RBADB in SELOGIC control equations for monitoring purposes only.

The relay uses the CBADPU setting to determine when to assert CBADA and CBADB. If the short-term channel downtime ratio exceeds CBADPU, the relay asserts the appropriate CBAD bit.

The TXMODE setting provides compatibility with SEL devices that are not SEL-400 series relays. The relay can send messages more quickly than the SEL-300 series relays and other SEL devices can process these messages. This could lead to loss of data and a failure to communicate properly. When you set TXMODE to P, the relay sends new MIRRORED BITS messages every 3 ms even if the selected data speed (SPEED setting) would allow more frequent messages.

As a function of the settings for SPEED, TXMODE, and MBT, the message transmission periods are shown in *Table 15.28*.

Table 15.27 MIRRORED BITS Communications Protocol Settings

Name	Description	Range
TX_ID	MIRRORED BITS communications ID of this device	1–4
RX_ID	MIRRORED BITS communications ID of device connected to this port	1–4 (must be different than TX_ID)
RBADPU	Outage duration to set RBAD	1–10000 seconds
CBADPU	Channel unavailability to set CBAD	1–100000 parts per million
TXMODE	Transmission mode[a]	N (normal), P (paced)
MBNUM	Number of MIRRORED BITS communications data channels used for logic bits	0–8
RMB1FL[b]	RMB1 channel fail state	0, 1, P
RMB1PU[b]	RMB1 pickup message count	1–8
RMB1DO[b]	RMB1 dropout message count	1–8
• • •	• • •	
RMB8FL[b]	RMB8 channel fail state	0, 1, P
RMB8PU[b]	RMB8 pickup message count	1–8
RMB8DO[b]	RMB8 dropout message count	1–8
MBTIME	MIRRORED BITS time synchronize enable	Y, N
MBNUMAN	Number of analog data channels (hidden and set to 0 if MBNUM := 7 or 8)	0–*n*, *n* = 7–MBNUM
MBANA1[c]	Selection for analog Channel 1	Analog quantity label
MBANA2[c]	Selection for analog Channel 2	Analog quantity label
MBANA3[c]	Selection for analog Channel 3	Analog quantity label
MBANA4[c]	Selection for analog Channel 4	Analog quantity label
MBANA5[c]	Selection for analog Channel 5	Analog quantity label
MBANA6[c]	Selection for analog Channel 6	Analog quantity label
MBANA7[c]	Selection for analog Channel 7	Analog quantity label
MBNUMVT	Number of virtual terminal channels	OFF, 0–*n*, *n* = 7–MBNUM–MBNUMAN

[a] Must be P for connections to devices that are not SEL-400 series relays.
[b] Hidden based on MBNUM setting.
[c] Hidden based on MBNUMAN setting.

Table 15.28 MIRRORED BITS Communications Message Transmission Period

Speed in Bits per Second	TXMODE := NORMAL MBT := N	TXMODE := PACED MBT := N	MBT :=Y
38400	1.0 ms	3.0 ms	N/A
19200	2.0 ms	3.0 ms	N/A
9600	4.0 ms	4.0 ms	7.0 ms
4800	8.0 ms	8.0 ms	N/A

Set the RX_ID of the local relay to match the TX_ID of the remote relay. In a three-terminal case, Relay X transmits to Relay Y, Relay Y transmits to Relay Z, and Relay Z transmits to Relay X. *Table 15.29* lists the MIRRORED BITS communications ID settings for Relays X, Y, and Z.

Table 15.29 MIRRORED BITS Communications ID Settings for Three-Terminal Application

Relay	TX_ID	RX_ID
X	1	3
Y	2	1
Z	3	2

SEL Distributed Port Switch Protocol (LMD)

The relay does not have built-in LMD protocol, but you can connect the relay to an SEL-2885 EIA-232 to EIA-485 Transciever and connect the SEL-2885 to an EIA-485 multidrop network. See the *SEL-2885 EIA-232 to EIA-485 Transceiver* product flyer for more information on the settings, configuration, and application of the SEL-2885. Application Guide AG94-03 provides additional details for applying this protocol and is available at selinc.com.

SEL-2600A RTD Module Operation

The SEL-2600A RTD Module Protocol (RTD) enables communication with an SEL-2600A via an SEL-2800 (EIA-232 to Fiber-Optic) Transceiver.

NOTE: Not all SEL-400 series relays support communication with SEL-2600A RTD Modules.

Figure 15.10 SEL-2600A RTD Module and the Relay

This protocol supports data acquisition of as many as 12 temperature channels and places the results directly into predefined analog quantities (RTD01–RTD12) inside the relay for use in freeform SELOGIC applications. For more information on the SEL-2600A or SEL-2800, contact your local technical service center, the SEL factory, or visit the SEL website at selinc.com for a copy of the SEL-2600A and SEL-2800 product fliers.

Initialization

Perform the following steps to prepare the relay for communicating with an SEL-2600A RTD module:

Step 1. Set the desired port to RTD protocol.

Step 2. Set the port setting RTDNUM to the number of RTDs attached to the SEL-2600A.

Step 3. Set the RTD type settings (RTD*nn*TY) to the appropriate RTD type.

Step 4. Connect the SEL-2600A RTD Module to the port via the SEL-2800 (EIA-232 to Fiber-Optic) Transceiver.

Operation

The SEL-2600A RTD module sends all temperature measurements to the relay every 0.5 seconds. The relay places the received temperature measurements into analog quantities RTD01–RTD12 for use in freeform SELOGIC applications. The data range is from –50 to +250 °C.

NOTE: When a channel status bit is not asserted, the data in the respective analog quantity is the last valid temperature, not the current temperature.

If the relay stops receiving valid analog quantities from a certain channel, the temperature stored in the relay freezes at the last received value. Fifteen status bits help supervise decisions based on temperature measurements. *Table 15.30* describes how to interpret the status bits.

Table 15.30 RTD Status Bits

RTD Status Bit	Description
RTDFL	Asserts if the SEL-2600A experiences an internal problem.
RTDCOMF	Asserts if the relay does not receive a valid measurement from the SEL-2600A for 1.25 seconds.
RTD01ST–RTD12ST	Assert when an RTD is attached to a channel and the SEL-2600A is able to read RTD.
RTDIN	SEL-2600 input status bit. Asserts when the SEL-2600 is healthy and the received data indicates the assertion of the input.

NOTE: In some SEL-400 series relays, you must use **MET RTD** instead of **MET T**.

To view the temperature measurements received from the SEL-2600A, issue the **MET T** command, as depicted in *Figure 15.11*.

```
=>>MET T <Enter>
Relay 1                                    Date: 03/17/2023  Time: 13:42:13.220
Station A                                  Serial Number: 1230769999
RTD Input Temperature Data (deg. C)
RTD  1 = -48

RTD  2 = Channel Failure
RTD  3 =   0
RTD  4 =  24
RTD  5 = Channel Not Used
RTD  6 =  72
RTD  7 = Channel Failure
RTD  8 = 120

RTD  9 = Channel Not Used
RTD 10 = 168
RTD 11 = 192
RTD 12 = 216
```

Figure 15.11 MET T Command Response

The **MET T** command displays the following messages:

- `Channel Failure`: This message is displayed for each channel whose channel status bit is not asserted.
- `Channel Not Used`: This message is displayed for each channel whose channel type is set to NA.

When there is a status problem with the SEL-2600A RTD module, the **MET T** command will respond with an informational message, as shown in *Figure 15.12*.

```
=>>MET T
SEL-2600 Failure
```

Figure 15.12 MET T Command Response for Status Problem

The four possible messages for status problems, with their interpretation, are indicated in *Table 15.31*.

Table 15.31 MET T Command Status Messages

Message	Interpretation
SEL-2600 Failure	RTDFL status bit asserted
Communication Failure	RTDCOMF status bit asserted
No data available	Port Protocol not set to RTD
Channel Failure	RTD*xx*ST status bit deasserted

Direct Networking Example

This example demonstrates direct networking to the relay through use of the Ethernet card. *Figure 15.13* shows the Ethernet network topology. This examples uses an SEL-421, but the same concepts apply to any SEL-400 series relay.

Figure 15.13 Example Direct Networking Topology

Application

The Ethernet network is used primarily for an engineering connection to the devices in the substation either across the WAN or from the local computer. The engineer can use FTP to collect settings, oscillography, and other file data directly from the SEL-421 Relays. The engineer can also use Telnet to establish a terminal connection to the SEL-421 Relays or through the SEL-3530 to one of the serial IEDs to configure these devices or obtain diagnostic information. The SEL-3530 provides IRIG-B time synchronization to all the IEDs via a serial connection.

Settings

This example focuses on the relay labeled Line 1 shown in *Figure 15.13*. Port 5 settings for the SEL-421 configure the Ethernet card. Port 5 settings for this example are shown in *Table 15.32*.

Table 15.32 SEL-421 Port 5 Direct Networking Settings

Setting Name	Setting	Description
BUSMODE[a]	INDEPEND	Bus operating mode
EINTF[a]	CD	Enable interface
IPADDR	10.201.0.112/16	IP network address
DEFRTR	10.201.0.1	Default router
ETCPKA	N	Disable TCP keep-alive functionality
KAIDLE	10	Length of time to wait with no detected activity before sending a keep-alive packet (must be greater than or equal to KAINTV)
KAINTV	1	Length of time to wait between sending keep-alive packets after receiving no response for the prior keep-alive packet (must be less than or equal to KAIDLE)
KACNT	6	Maximum number of keep-alive packets to send
NETPORT	C	Primary network port selected to `PORT 5C`
NETCSPD[b]	A	Automatically detect network speed on `PORT C`
FTPSERV	Y[c]	Enabled FTP server
FTPCBAN	FTP SERVER:	FTP connect banner
FTPIDLE	5	FTP connection time-out in minutes
FTPANMS	N	Anonymous login disabled so that passwords are required for all FTP users
FTPAUSR	“”	Host user from which anonymous FTP client inherits access rights—not used in this application
ETELNET	Y[c]	Enable Telnet server
TCBAN	HOST TERMINAL SERVER:	Host Telnet connect banner
TPORT	23	Host Telnet TCP/IP port
TIDLE	5	Telnet connection time-out in minutes

[a] Five-port Ethernet card only.
[b] Not applicable for fiber ports.
[c] Set to CD when using the five-port Ethernet card.

FTP Session

Figure 15.14 is a screen capture of an FTP session with the relay. The FTP client used for this example is included with the Windows operating system and accessible through a command prompt window. The operator connects to the relay, moves to the SETTINGS directory, and collects the Port 5 settings. *Figure 15.14* shows a portion of the Port 5 settings in the SET_P5.TXT file.

```
C:\>ftp 10.201.0.112 <Enter>
Connected to 10.201.0.112.
220 FTP SERVER:
User (10.201.0.112:(none)): 2AC
331 User name okay, need password.
Password:
230 User logged in, proceed.
ftp> ls
200 PORT Command okay.
150 File status okay; about to open data connection.
CFG.TXT
CFG.XML
EVENTS
REPORTS
SETTINGS
SWCFG.ZIP

SYNCHROPHASORS
226 Closing data connection.
ftp: 72 bytes received in 0.00Seconds 72.00Kbytes/sec.
ftp> cd SETTINGS
250 CWD  requested file action okay, completed.
ftp> ls
200 PORT Command okay.
150 File status okay; about to open data connection.
BAY_SCREEN.TXT
ERR.TXT

SET_A1.TXT
SET_A10.TXT
SET_A2.TXT
SET_A3.TXT
SET_A4.TXT
SET_A5.TXT
SET_A6.TXT
SET_A7.TXT
SET_A8.TXT
SET_A9.TXT
SET_ALL.TXT

SET_B1.TXT
SET_D1.TXT
SET_D2.TXT
SET_D3.TXT
SET_D4.TXT
SET_D5.TXT
SET_F1.TXT
SET_G1.TXT
SET_L1.TXT
SET_L2.TXT
SET_L3.TXT
SET_L4.TXT
SET_L5.TXT
SET_L6.TXT

SET_N1.TXT
SET_O1.TXT
SET_P1.TXT
SET_P2.TXT
SET_P3.TXT
SET_P5.TXT
SET_PF.TXT
SET_R1.TXT
SET_S1.TXT
SET_S2.TXT
SET_S3.TXT
SET_S4.TXT
SET_S5.TXT
SET_S6.TXT
SET_SM.TXT
SET_T1.TXT

UPGRADE_RPT.TXT
226 Closing data connection.
ftp: 536 bytes received in 0.01Seconds 53.60Kbytes/sec.
ftp> get SET_P5.TXT
200 PORT Command okay.
150 File status okay; about to open data connection.
226 Closing data connection.
ftp: 3853 bytes received in 0.01Seconds 428.11Kbytes/sec.
ftp> quit
221 Goodbye.

C:\>
```

Figure 15.14 Example FTP Session

```
[INFO]
RELAYTYPE=SEL
FID=SEL-421-X045-V0-Z001001-D20010106
BFID=SLBT-CFS-X000
PARTNO=SEL-400H1234
[IOBOARDS]
[COMCARDS]
, SEL-2701-X061-V0-Z000000-D20010117, SLBT-2701-X021-V0-Z000000-D20010109, 1
[P5]

"TIMEOUT",5
"AUTO",Y
"FASTOP",N
"TERTIM1",1
"TERSTRN","\005"
"TERTIM2",0

"IPADDR","10.201.0.112"
"SUBNETM","255.255.0.0"
"DEFRTR","10.201.0.1"
"NETPORT","C"
"FAILOVR","N"

"FTIME",5
"NETCSPD","A"
"NETDSPD","A"
"FTPSERV","Y"

"FTPCBAN","FTP SERVER:"
"FTPIDLE",5
"FTPANMS","N"
"FTPAUSR","ACC"

"T1CBAN","HOST TERMINAL SERVER:"
"T1INIT","N"
"T1RECV","Y"
"T1PNUM",23

"T2CBAN","CARD TERMINAL SERVER:"
"T2RECV","Y"
"T2PNUM",1024
"TIDLE",5
Remaining settings not shown
```

Figure 15.15 Partial Contents of SET_P5.TXT

Telnet Session

This section contains screen captures of a Telnet session with the Line 1 SEL-421. The Telnet application is included with the Windows operating system. *Figure 15.16* shows the login dialog box and the entries required to connect to the SEL-421.

Figure 15.16 Telnet Connection Dialog Box

Figure 15.17 is a screen capture of a Telnet session with the relay. The operator connects to the relay, and displays the Port 5 settings. Only a portion of the Port 5 settings are shown.

```
TERMINAL SERVER:
=ACC <Enter>

Password: ?OTTER <Enter>

Relay 1                                     Date: 03/17/2023  Time: 01:17:08.142
Station A                                   Serial Number: 1230769999

Level 1

=>2AC <Enter>

Password: ?TAIL <Enter>

Relay 1                                     Date: 03/17/2023  Time: 01:17:23.082
Station A                                   Serial Number: 1230769999

Level 2

=>>SHO P 5 <Enter>
Port 5

Protocol Selection

EPORT   := Y        EPAC    := N        MAXACC  := C

SEL Protocol Settings

AUTO    := Y        FASTOP  := N        TERTIM1 := 1
TERSTRN := "\005"
TERTIM2 := 0

Fast Message Read Data Access

FMRENAB := Y        FMRLCL  := N        FMRMTR  := Y        FMRDMND := Y
FMRTAR  := Y        FMRHIS  := N        FMRBRKR := N        FMRSTAT := N
FMRANA  := Y

IP Configuration

IPADDR  := 10.201.0.112/16
DEFRTR  := "10.201.0.1"
ETCPKA  := Y        KAIDLE  := 10       KAINTV  := 1        KACNT   := 6
NETMODE := FIXED    NETPORT := C        NETASPD := AUTO     NETBSPD := AUTO
NETCSPD := AUTO     NETDSPD := AUTO

FTP Configuration

FTPSERV := N

HTTP Server Configuration

EHTTP   := N

Telnet Configuration

ETELNET := Y
TCBAN   := "TERMINAL SERVER:"
TPORT   := 23       TIDLE   := 15

DNP Configuration

EDNP    := 0

Phasor Measurement Configuration

EPMIP   := N

SNTP Protocol Selection

ESNTP   := OFF

PTP Settings

EPTP    := N
=>>QUI <Enter>
```

Figure 15.17 Example Telnet Session

This page intentionally left blank

SECTION 16

DNP3 Communication

The relay provides a DNP3-2009 Level 2 outstation interface for direct network connections to the relay. This section covers the following topics:

- *Introduction to DNP3 on page 16.1*
- *DNP3 in the Relay on page 16.7*
- *DNP3 Documentation on page 16.12*
- *DNP3 Serial Application Example on page 16.26*
- *DNP3 LAN/WAN Application Example on page 16.31*

Introduction to DNP3

A SCADA manufacturer-developed DNP3 from the lower layers of IEC 60870-5. Originally designed for use in telecontrol applications, version 3 of the protocol has also become popular for local substation data collection. DNP3 has been standardized as IEEE 1815.

Rather than wiring individual input and output points from the station RTU to the station IEDs, many stations use DNP3 to convey measurement and control data over a single serial or Ethernet cable to the RTU. The RTU then forwards data to the offsite master station. By using a data communications protocol rather than hard wiring, designers have reduced installation, commissioning, and maintenance costs while increasing remote control and monitoring flexibility.

The DNP User's Group maintains and publishes DNP3 standards in cooperation with IEEE. See the DNP User's Group website (www.dnp.org) for more information on DNP3 standards, implementers of DNP3, and tools for working with DNP3.

DNP3 Specifications

DNP3 is a feature-rich protocol with many ways to accomplish tasks. The *Interoperability* section of IEEE 1815 defines four levels of subsets to help improve interoperability. The levels are listed in *Table 16.1*.

Table 16.1 DNP3 Implementation Levels

Level	Description	Equipment Types
1	Simple: limited communications requirements	Meters, simple IEDs
2	Moderately complex: monitoring and metering devices and multifunction devices that contain more data	Protective relays, RTUs
3	Sophisticated: devices with great amounts of data or complex communications requirements	Large RTUs, SCADA masters
4	Enhanced: additional data types and functionality for more complex requirements	Large RTUs, SCADA masters

Each level is a proper superset of the next lower-numbered level. A higher level device can act as a master to a lower level device, but can only use the data types and functions implemented in the lower level device. For example, a typical SCADA master is a Level 3 device and can use Level 2 (or lower) functions to poll a Level 2 (or lower) device by using only the data types and functions that the lower-level device uses. A lower-level device can also poll a higher-level device, but the lower level device can only access the features and data available to its level.

Data Handling

Objects

DNP3 uses a system of data references called object types, commonly referred to as objects. Each subset level specification requires a minimum implementation of objects and also recommends several optional objects. DNP3 objects are specifications for the type of data the object carries. An object can include a single value or more complex data. Some objects serve as shorthand references for collections of data or even all data within the DNP3 device.

Each instance of the object includes an index that makes it unique. For example, each binary status point (Object 1) has an index. If there are 16 binary status points, these points are Object 1, Index 0 through Object 1, Index 15. Note that index numbers are 0-based.

Each object also includes multiple versions called variations. For example, Object 1 has three variations: 0, 1, and 2. Variation 0 is used to request Object 1 data from a DNP3 device by using its default variation. Variation 1 is used to specify binary input values only and Variation 2 is used to specify binary input values with status information.

Each DNP3 device has both a list of objects and a map of object indices. The list of objects defines the available objects, variations, and qualifier codes. The map defines the indices for objects that have multiple instances and what data or control points correspond with each index.

A master initiates all DNP3 message exchanges except unsolicited data. DNP3 terminology describes all points from the perspective of the master. Binary points for control that move from the master to the outstation are called binary outputs, while binary status points within the outstation are called binary inputs.

Function Codes

Each DNP3 message includes a function code. Each object has a limited set of function codes that a master may use to manipulate the object. The object listing for the device shows the permitted function codes for each type of object. The most common DNP3 function codes are listed in *Table 16.2*.

Table 16.2 Selected DNP3 Function Codes

Function Code	Function	Description
1	Read	Request data from the outstation
2	Write	Send data to the outstation
3	Select	First part of a select-before-execute operate
4	Execute	Second part of a select-before-execute operate
5	Direct operate	One-step operation with acknowledgment
6	Direct operate, no ack.	One-step operation with no acknowledgment

Qualifier Codes and Ranges

DNP3 masters use qualifier codes and ranges to make requests for specific objects by index. Qualifier codes specify the style of range, and the range specifies the indices of the objects of interest. DNP3 masters use qualifier codes to compose the shortest, most concise message possible when requesting points from a DNP3 remote device.

For example, the qualifier code 01 specifies that the request for points will include a start address and a stop address. Each of these two addresses uses two bytes. An example request using qualifier code 01 might have the four-hexadecimal byte range field, 00h 04h 00h 10h, that specifies points in the range 4–16.

Access Methods

DNP3 has many features that help it obtain maximum possible message efficiency. DNP3 Masters send requests with the least number of bytes by using special objects, variations, and qualifiers that reduce the message size. Other features eliminate the continual exchange of static (unchanging) data values. These features optimize use of bandwidth and maximize performance over a connection of any speed.

DNP3 event data collection eliminates the need to use bandwidth to transmit values that have not changed. Event data are time-stamped records that show when observed measurements changed. For binary points, the outstation device logs changes from logical 1 to logical 0 and from logical 0 to logical 1. For analog points, the remote device logs changes that exceed a deadband. DNP3 outstation devices collect event data in a buffer that either the master can request or the device can send to the master without a request message. Data sent from the outstation to the master without a polling request are called unsolicited data.

DNP3 data fit into one of four event classes: 0, 1, 2, or 3. Class 0 is reserved for reading the present value (static data). Classes 1, 2, and 3 are event data classes. The meaning of Classes 1 to 3 is arbitrary and defined by the application at hand. With remotes that contain great amounts of data or in large systems, the three event classes provide a framework for prioritizing different types of data. For example, you can poll once a minute for Class 1 data, once an hour for Class 2 data, and once a day for Class 3 data.

Class 0 polling is also known as static polling, or simple polling of the present value of data points within the outstation. By combining event data polls, unsolicited messaging, and static polling, you can operate your system in one of the four access methods shown in *Table 16.3*.

The access methods listed in *Table 16.3* are in order of increasing communications efficiency. With various tradeoffs, each method is less demanding of communications bandwidth than the previous one. For example, unsolicited report-by-exception consumes less communications bandwidth because of the elimination of polling messages from the master required by polled report-by-exception. You must also consider overall system size and the volume of data communication expected to properly evaluate which access method provides optimum performance for your application.

Table 16.3 DNP3 Access Methods

Access Method	Description
Polled static	Master polls for present value (Class 0) data only.
Polled report-by-exception	Master polls frequently for event data and occasionally for Class 0 data.
Unsolicited report-by-exception	Remote devices send unsolicited event data to the master, and the master occasionally polls for Class 0 data.
Quiescent	Master never polls and relies on unsolicited reports only.

Binary Control Operations

DNP3 masters use the Object 12 control relay output block to perform binary control operations. The control relay output block has both a trip/close selection and a code selection. The trip/close selection allows a single index to operate two related control points, such as trip and close or raise and lower. Trip/close pair operation is not recommended for new DNP3 devices, but is often included for interoperability with older DNP3 master implementations.

The control relay output block code selection specifies either a latch or pulse operation on the point. In many cases, DNP3 outstations have only a limited subset of the possible combinations of the code field. Sometimes, DNP3 outstations assign special operation characteristics to the latch and pulse selections.

Conformance Testing

In addition to the protocol specifications, the DNP User's Group has approved conformance testing requirements for all levels of outstation devices. Some implementers perform their own conformance specification testing, while some contract with independent companies to perform conformance testing.

Conformance testing does not always guarantee that a master and remote will be fully interoperable (work together properly for all implemented features). Conformance testing does help to standardize the testing procedure and move the DNP3 implementers toward a higher level of interoperability.

DNP3 Serial Network Issues

You can build a DNP3 network by using either a multidrop or star topology. Each DNP3 network has one or more DNP3 masters and DNP3 outstations. *Figure 16.1* shows the DNP3 multidrop network topology.

Figure 16.1 DNP3 Multidrop Network Topology

Figure 16.2 shows the DNP3 star network topology.

Figure 16.2 DNP3 Star Network Topology

DNP3 multidrop networks that are used within substations often use an EIA-485 physical layer. The multidrop network is vulnerable to the failure of a single transmitter. If any one transmitter fails in a state that disrupts signals on the network, the network will fail. The DNP3 star network topology eliminates the network transmitters and other single points of failure related to the physical medium.

If you are planning either a DNP3 star or multidrop network topology, you should consider the benefits of including an SEL communications processor such as the SEL-2032 or SEL-3530 RTAC in your design. A network with a communications processor is shown in *Figure 16.3*. A DNP3 network that includes a communications processor has a lower data latency and shorter scan time than comparable networks through two primary mechanisms. First, the communications processor collects data from all remotes in parallel rather than one-by-one. Second, the master can collect all data with one message and response, drastically reducing message overhead.

Figure 16.3 DNP3 Network With Communications Processor

In the communications processor DNP3 network, you can also collect data from devices that do not support the DNP3 protocol. SEL communications processors can collect data and present it to the master as DNP3 data regardless of the protocol between the SEL communications processor and the remote device.

Data Link Layer Operation

DNP3 employs a three-layer version of the seven-layer OSI (open systems interconnect) model called the enhanced performance architecture. The layer definition helps to categorize functions and duties of various software components that make up the protocol. The middle layer, the data link layer, includes several functions for error checking and media access control.

A feature called data link confirmation is a mechanism that provides positive confirmation of message receipt by the receiving DNP3 device. While this feature helps you recognize a failed device or failed communications link quickly, it also adds significant overhead to the DNP3 conversation. Consider for your individual application whether you require this link integrity function at the expense of overall system speed and performance.

The DNP3 specification recommends against using data link confirmations because these processes can add to traffic in situations where communications are marginal. The increased traffic will reduce connection throughput further, possibly preventing the system from operating properly.

Network Medium Contention

When more than one device requires access to a single network medium, you must provide a mechanism to resolve the resulting network medium contention. For example, unsolicited reporting results in network medium contention if you do not design your network as a star topology of point-to-point connections or use carrier detection on a multidrop network.

To avoid collisions among devices trying to send messages, DNP3 includes a collision avoidance feature. Before sending a message, a DNP3 device listens for a carrier signal to verify that no other node is transmitting data. The device transmits if there is no carrier or waits for a random time before rechecking for a carrier signal. However, if two nodes both detect a lack of carrier at the same instant, these two nodes could begin simultaneous transmission of data and cause a data collision. If your network allows for spontaneous data transmission including unsolicited event data transmissions, you also must use application confirmation to provide a retry mechanism for messages lost as a result of data collisions.

DNP3 LAN/WAN Considerations

The main process for carrying DNP3 over an Ethernet network (LAN/WAN) involves encapsulating the DNP3 data link layer data frames within the transport layer frames of the IP suite. This allows the IP stack to deliver the DNP3 data link layer frames to the destination in place of the original DNP3 physical layer. The DNP User's Group Technical Committee has recommended the following guidelines for carrying DNP3 over a network:

- DNP3 shall use the IP suite to transport messages over a LAN/WAN
- Ethernet is the recommended physical link, though others may be used
- TCP must be used for WANs
- TCP is strongly recommended for LANs
- UDP may be used for highly reliable single segment LANs
- UDP is necessary if broadcast messages are required
- The DNP3 protocol stack shall be retained in full
- Link layer confirmations shall be disabled

The Technical Committee has registered a standard port number, 20000, for DNP3 with the Internet Assigned Numbers Authority (IANA). This port is used for either TCP or UDP.

The Committee recommends the selection of TCP or UDP protocol as per the guidelines in *Table 16.4*.

Table 16.4 TCP/UDP Selection Guidelines

Use in the case of...	TCP	UDP
Most situations	X	
Non-broadcast or multicast	X	
Mesh Topology WAN	X	
Broadcast		X
Multicast		X
High-reliability single-segment LAN		X
Pay-per-byte, non-mesh WAN, for example, Cellular Digital Packet Data (CDPD)		X
Low-priority data, for example, data monitor or configuration information		X

DNP3 in the Relay

The relay is a DNP3-2009 Level 2 outstation device. The relay DNP3 interface has the capabilities summarized in *Table 16.5*.

Table 16.5 Relay DNP3 Feature Summary

Feature	Application
DNP3 event data reporting	More efficient polling through event collection or unsolicited data
Time-tagged events	Time-stamped SER data
Control output relay blocks	Operator-initiated control
Write analog set point	Change the active protection settings group
Time synchronization	Set the relay time from the master station or automatically request time synchronization from the master
Custom mapping	Increase communications efficiency by organizing data and reducing available data to what you need for your application
Modem support	Reduce the cost of the communications channel by either master dialing to relay or relay dialing to master
Analog deadband settings per session	Deadbands may be set to different values per session depending on desired application
Virtual Terminal	Provides engineering access for configuration, diagnostics, and other tasks over the existing DNP3 connection
TEST DB2 command	Test DNP3 protocol interface without disturbing protection
Support for Object 0 Device Attributes	Provides Device Attributes (Device ID, Number of binary, analog and counter points, Manufacturer information, etc.) for the device specific to the current connected DNP3 session in use
XML DNP3 Device Profile Document	The DNP3 Device Profile document contains the complete information on DNP3 Protocol support in the relay. This information is available in XML format.

Data Access

You can use any of the data access methods listed in *Table 16.6*. *Table 16.6* also lists the relay DNP3 settings. You must configure the DNP3 master for the data access method you select.

NOTE: Because unsolicited messaging only operates properly in some situations, for maximum performance and minimum risk of configuration problems, SEL recommends the polled report-by-exception access method.

Table 16.6 DNP3 Access Methods

Access Method	Master Polling	Relay Settings
Polled static	Class 0	Set ECLASSB, ECLASSC, ECLASSA, ECLASSV to OFF, UNSOL to N.
Polled report-by-exception	Class 0 occasionally, Class 1, 2, 3 frequently	Set ECLASSB, ECLASSC, ECLASSA, ECLASSV to the desired event class, UNSOL to N.
Unsolicited report-by-exception	Class 0 occasionally, optional Class 1, 2, 3 less frequently, mainly relies on unsolicited messages	Set ECLASSB, ECLASSC, ECLASSA, ECLASSV to the desired event class, set UNSOL to Y and PUNSOL to Y or N.
Quiescent	Class 0, 1, 2, 3 never, relies completely on unsolicited messages	Set ECLASSB, ECLASSC, ECLASSA, ECLASSV to the desired event class, set UNSOL and PUNSOL to Y.

In both the unsolicited report-by-exception and quiescent polling methods shown in *Table 16.6*, you must make a selection for the PUNSOL setting. This setting enables or disables unsolicited data reporting when you turn the relay on. If your master can send the DNP3 message to enable unsolicited reporting from the relay, you should set PUNSOL to No.

NOTE: The DNP3 LAN/WAN settings have names similar to the serial port settings above, but include the session number n as a suffix ranging from 1 to 6 (for example, CLASSB1, UNSOL1, PUNSOL1). All settings with the same numerical suffix comprise the complete DNP3 LAN/WAN session configuration.

While automatic unsolicited data transmission on power-up is convenient, problems can result if your master is not prepared to start receiving data immediately when you turn on the relay. If the master does not acknowledge the unsolicited data with an application confirm, the relay will resend the data until it is acknowledged. On a large system, or in systems where the processing power of the master is limited, you may have problems when several outstations simultaneously begin sending data and waiting for acknowledgment messages.

Collision Avoidance

If your application requires unsolicited reporting from multiple devices on a single (serial) network medium, you must select a half-duplex medium or a medium that supports carrier detection to avoid data collisions. EIA-485 two-wire networks are half-duplex. EIA-485 four-wire networks do not provide carrier detection.

The relay uses application confirmation messages to guarantee delivery of unsolicited event data before erasing the local event data buffer. Data collisions are typically resolved when messages are repeated until confirmed.

The relay pauses for a random delay between the settings MAXDLY and MINDLY when it detects a carrier through data on the receive line or the CTS pin. If you use the settings of 0.10 seconds for MAXDLY and 0.05 seconds for MINDLY, the relay will insert a random delay of 50 to 100 ms (milliseconds) between the end of carrier detection and the start of data transmission.

Transmission Control

If you use a media transceiver (for example, EIA-232 to EIA-485) or a radio system for your serial DNP3 network, you may need to adjust data transmission properties. Use the PREDLY and POSTDLY settings to provide a delay between RTS signal control and data transmission. For example, an EIA-485 transceiver typically requires 10–20 ms to change from receive to transmit. If you set the predelay to 30 ms, you will avoid data loss resulting from data transmission beginning at the same time as RTS signal assertion.

Event Data

DNP3 event data objects contain change-of-state and time-stamp information that the relay collects and stores in a buffer. You can configure the relay to either report the data without a polling request from the master (unsolicited data) or hold the data until the master requests it with an event poll message.

With the event class settings ECLASSB, ECLASSC, ECLASSA, and ECLASSV you can set the event class for binary, counter, analog, and virtual terminal information. You can use the classes as a simple priority system for collecting event data. The relay does not treat data of different classes differently with respect to unsolicited messages, but the relay does allow the master to perform independent class polls.

NOTE: Most RTUs that act as substation DNP3 masters perform an event poll that collects event data of all classes simultaneously. Confirm that the polling configuration of your master allows independent polling for each class before implementing separate classes in the relay.

For event data collection you must also consider and enter appropriate settings for deadband and scaling operation on analog points shown in *DNP3 Settings—Custom Maps on page 12.19*. You can either set and use default deadband and scaling according to data type or use a custom data map to select deadbands on a point-by-point basis. See *Configurable Data Mapping on page 16.23* for a discussion of how to set scaling and deadband operation on a point-by-point basis.

The serial port settings ANADBA, ANADBV, and ANADBM (ANADBA*n*, ANADBV*n*, and ANADBM*n* for Ethernet port settings on session *n*) control default deadband operation for the specified data type. Because DNP3 Objects 30 and 32 use integer data by default, you can use scaling to send digits after the decimal point and avoid truncating to a simple integer value.

With no scaling, the value of 12.632 would be sent as 12. With a scaling setting of 1, the value transmitted is 126. With a scaling setting of 3, the value transmitted is 12632. You must make certain that the maximum value does not exceed 32767 if you are polling the default 16-bit variations for Objects 30 and 32, but you can send some decimal values by using this technique. You must also configure the master to perform the appropriate division on the incoming value to display it properly.

Set the default analog value scaling with the DECPLA, DECPLV, and DECPLM settings (DECPLA*n*, DECPLV*n*, and DECPLM*n* for Ethernet port settings on session *n*). Application of event reporting deadbands occurs after scaling in the DECPLA, DECPLV, and DECPLM. For example, if you set DECPLA to 2 and ANADBA to 10, a measured current of 10.14 amperes would be scaled to the value 1014 and would have to increase to more than 1024 or decrease to less than 1004 (a deadband of 0.2 amperes) for the relay to report a new event value.

The relay uses the NUMEVE and AGEEVE settings (NUMEVE*n* and AGEEVE*n* Ethernet port settings for session *n*) to decide when to send unsolicited data to the master. The relay sends an unsolicited report when the total number of events accumulated in the event buffer reaches NUMEVE. The relay also sends an unsolicited report if the age of the oldest event in the buffer exceeds AGEEVE. The relay has the buffer capacities listed in *Table 16.7*.

Table 16.7 Relay Event Buffer Capacity

Type	Maximum Number of Events
Binary	1024
Analog	One event per analog input in the DNP3 Map
Counters	One event per counter input in the DNP3 Map
Virtual Terminal Objects	5

Binary Controls

The relay provides more than one way to control individual points within the relay. The relay maps incoming control points either to remote bits within the relay or to internal command bits that cause circuit breaker operations.

NOTE: The port setting DNPCL (or DNPCLn for DNP3 LAN/WAN session n) must be set to Y to enable binary controls for the DNP3 session. Binary Output Status requests (Object 10, Variation 2) and Class 0 requests will have no Binary Outputs in the response unless DNPCL := Y.

A DNP3 technical bulletin (*Control Relay Output Block Minimum Implementation 9701-002*) recommends that you use one point per Object 12, control block output relay. You can use this method to perform pulse on, latch on, and latch off operations on selected remote bits.

If your master does not support the single-point-per-index messages or single-operation database points, you can use the trip/close operation or use the code field in the DNP3 message to specify operation of the points shown in *Control Point Operation on page 16.20*.

Time Synchronization

The accuracy of DNP3 time synchronization is insufficient for most protection and oscillography needs. DNP3 time synchronization provides backup time synchronization in the event the relay loses primary synchronization through the IRIG-B TIME input or some other high-accuracy source.

Enable time synchronization with the TIMERQ setting (TIMERQ*n* for DNP3 LAN/WAN Session *n*) and use Object 50, Variation 1, and Object 52, Variation 2 (Object 50, Variation 3 for DNP3 LAN/WAN), to set the time via a DNP3 master.

TIMERQ can be set in one of three ways:

- A numeric setting of 1–32767 minutes specifies the rate at which the relay shall request a time synchronization.
- A setting of M disables the relay from requesting a time synchronization, but still allows the relay to accept and apply time synchronization messages from the master.
- A setting of I disables the relay from requesting a time synchronization, and sets the relay to ignore time synchronization messages from the master.

Effective January 1, 2008, the DNP3 standard requires that DNP3 time correspond to Coordinated Universal Time (UTC). To help ease into the transition to this standard, you can use the DNPSRC Global setting to determine whether the relay will use local or UTC time for DNP3.

When requesting time synchronization with DNPSRC := UTC, the relay will treat incoming DNP3 time-set messages as UTC time. All DNP3 event timestamps (binary input changes with time, analog input changes with time, etc.) will be in UTC time.

When requesting time synchronization with DNPSRC := LOCAL, the relay will treat incoming time set by the DNP3 master as local time. All DNP3 event timestamps will be in local time.

When setting the time with local time, there is an ambiguity during the last hour of daylight-saving time (DST) and to resolve this ambiguity, if the relay accepts a Time Set request in this hour, it will assume the time is in DST.

Modem Support

The relay DNP3 implementation includes modem support. Your DNP3 master can dial-in to the relay and establish a DNP3 connection. The relay can automatically dial out and deliver unsolicited DNP3 event data. When the relay dials out, it waits for the CONNECT message from the local modem and for assertion of the relay CTS line before continuing the DNP3 transaction. This requires a connection from the modem DCD to the relay CTS line.

NOTE: Contact SEL for information on serial cable configurations and requirements for connecting your relay to other devices.

NOTE: RTS/CTS hardware flow control is not available for a DNP3 modem connection. You must set the port data speed slower than the effective data rate of the modem.

Either connect the modem to a computer and configure it before connecting it to the relay, or program the appropriate modem setup string in the modem startup string setting MSTR. Use the PH_NUM1 setting to set the phone number that you want the relay to dial. The relay will automatically send the ATDT modem dial command and then the contents of the PH_NUM1 setting when dialing the modem. PH_NUM1 is a text setting that must conform to the AT modem command set dialing string standard. Use a comma (,) for a pause of four seconds. You may need to include a nine to reach an outside line or a one if the number requires long distance access. You can also insert other special codes your telephone service provider designates for block call waiting and other telephone line features.

The relay supports backup dial-out to a second phone number. If PH_NUM2 is set, the RETRY1 setting is used to configure the number of times the relay tries to dial PH_NUM1 before dialing PH_NUM2. Similarly, the RETRY2 setting configures the number of times the relay tries to dial PH_NUM2 before trying PH_NUM1. MDTIME sets the length of time from initiating the call to declaring it failed because of no connection, and MDRET sets the time between dial-out attempts.

DNP3 Settings

DNP3 configuration involves both Global (SET G) and Port (SET P) settings. The Global settings govern behavior for all DNP3 sessions, serial or LAN/WAN. The Port settings apply to specific DNP3 sessions only.

There are two Global settings that directly configure DNP3. These settings, EVELOCK and DNPSRC, define the behavior of Fault Summary event retrieval and the DNP3 session time base. See *Reading Relay Event Data on page 16.21* for more information on EVELOCK. The DNPSRC setting can be either LOCAL or UTC (default). See *Time Synchronization on page 16.10* for more information on the DNPSRC setting.

The DNP3 protocol settings are shown in *Table 12.9* and *Table 12.23*. The DNP3 protocol settings are in the port settings for the port that you select for the DNP3 protocol. You can use DNP3 on any of the serial ports (**PORT F** and **PORT 1**–**PORT 3**) or Ethernet port (**PORT 5**), but you can only enable DNP3 on one serial port at a time. You may enable as many as six DNP3 sessions over Ethernet, independent of the number of serial DNP3 sessions enabled.

Warm Start and Cold Start

The DNP3 function codes for warm start and cold start reset the relay serial port or DNP3 Ethernet session. These function codes do not interrupt protection processes within the relay.

Testing

NOTE: The **TEST DB2** command will override the state of all instances of the forced bit or value for all active protocols. This includes DNP3 serial and LAN/WAN and IEC 61850 GOOSE and Manufacturing Message Specification (MMS). Before using the command, take precautions to ensure against unintended operations from inadvertent messages sent as the result of a **TEST DB2** override, for example, a bit used to trip a breaker on a remote relay via IEC 61850 GOOSE.

Use the **TEST DB2** command to test the data mapping from the relay to your DNP3 master. You can use the **TEST DB2** command to force DNP3 values by object type and label. Although the relay reports forced values to the DNP3 host, these values do not affect protection processing within the relay. The **TEST DB2** command operates by object type and label, so it works equally well with custom mapping and the default DNP3 maps. See *TEST DB2 on page 14.66* for more information.

When you are using the **TEST DB2** command to test DNP3 operation, the Relay Word bit TESTDB2 will be asserted to indicate that test mode is active. The DNP3 status bit will also show forced status for any object variations that include status.

DNP3 Documentation

Object List

Table 16.8 lists the objects and variations with supported function codes and qualifier codes available in the relay. The list of supported objects conforms to the format laid out in the DNP3 specifications and includes both supported and unsupported objects. Those that are supported include the function and qualifier codes. The objects that are not supported are shown without any corresponding function and qualifier codes.

Table 16.8 Relay DNP3 Object List (Sheet 1 of 6)

Obj.	Var.	Description	Request[a]		Response[a]	
			Funct. Codes	Qual. Codes	Funct. Codes	Qual. Codes
0	211	Device attributes—User-specific sets of attributes	1	0	129	0, 17
0	212	Device attributes—Master data set prototypes	1	0	129	0, 17
0	213	Device attributes—Outstation data set prototypes	1	0	129	0, 17
0	214	Device attributes—Master data sets	1	0	129	0, 17
0	215	Device attributes—Outstation data sets	1	0	129	0, 17
0	216	Device attributes—Max. binary outputs per request	1	0	129	0, 17
0	219	Device attributes—Support for analog output events	1	0	129	0, 17
0	220	Device attributes—Max. analog output index	1	0	129	0, 17
0	221	Device attributes—Number of analog outputs	1	0	129	0, 17
0	222	Device attributes—Support for binary output events	1	0	129	0, 17
0	223	Device attributes—Max. binary output index	1	0	129	0, 17
0	224	Device attributes—Number of binary outputs	1	0	129	0, 17
0	225	Device attributes—Support for frozen counter events	1	0	129	0, 17
0	226	Device attributes—Support for frozen counters	1	0	129	0, 17
0	227	Device attributes—support for counter events	1	0	129	0, 17
0	228	Device attributes—Max. counter index	1	0	129	0, 17
0	229	Device attributes—Number of counters	1	0	129	0, 17
0	230	Device attributes—Support for frozen analog inputs	1	0	129	0, 17
0	231	Device attributes—Support for analog input events	1	0	129	0, 17

Table 16.8 Relay DNP3 Object List (Sheet 2 of 6)

Obj.	Var.	Description	Request[a]		Response[a]	
			Funct. Codes	Qual. Codes	Funct. Codes	Qual. Codes
0	232	Device attributes—Max. analog input index	1	0	129	0, 17
0	233	Device attributes—Number of analog inputs	1	0	129	0, 17
0	234	Device attributes—Support for double-bit events	1	0	129	0, 17
0	235	Device attributes—Max. double-bit binary index	1	0	129	0, 17
0	236	Device attributes—Number of double-bit binaries	1	0	129	0, 17
0	237	Device attributes—Support for binary input events	1	0	129	0, 17
0	238	Device attributes—Max. binary input index	1	0	129	0, 17
0	239	Device Attributes—Number of binary inputs	1	0	129	0, 17
0	240	Device attributes—Max. transmit fragment size	1	0	129	0, 17
0	241	Device attributes—Max. receive fragment size	1	0	129	0, 17
0	242	Device attributes—Device manufacturer's software version	1	0	129	0, 17
0	243	Device attributes—Device manufacturer's hardware version	1	0	129	0, 17
0	245	Device attributes—User-assigned location name	1	0	129	0, 17
0	246	Device attributes—User-assigned ID code/number	1	0	129	0, 17
0	247	Device attributes—User-assigned device name	1	0	129	0, 17
0	248	Device attributes—Device serial number	1	0	129	0, 17
0	249	Device attributes—DNP3 subset and conformance	1	0	129	0, 17
0	250	Device attributes—Device manufacturer's product name and model	1	0	129	0, 17
0	252	Device attributes—Device manufacturer's name	1	0	129	0, 17
0	254	Device attributes—Non-specific all attributes request	1	0, 6	129	0, 17
0	255	Device attributes—List of attribute variations	1	0, 6	129	0, 17
1	0	Binary input—All variations	1	0, 1, 6, 7, 8, 17, 28		
1	1	Binary input	1	0, 1, 6, 7, 8, 17, 28	129	0, 1, 17, 28
1	2[a]	Binary input with status	1	0, 1, 6, 7, 8, 17, 28	129	0, 1, 17, 28
2	0	Binary input change—All variations	1	6, 7, 8		
2	1	Binary input change without time	1	6, 7, 8	129	17, 28
2	2	Binary input change with time	1	6, 7, 8	129, 130	17, 28
2	3	Binary input change with relative time	1	6, 7, 8	129	17, 28
10	0	Binary output—All variations	1	0, 1, 6, 7, 8		
10	1	Binary output				
10	2[a]	Binary output status	1	0, 1, 6, 7, 8	129	0, 1
12	0	Control block—All variations				
12	1	Control relay output block	3, 4, 5, 6	17, 28	129	echo of request
12	2	Pattern control block	3, 4, 5, 6	7	129	echo of request
12	3	Pattern mask	3, 4, 5, 6	0, 1	129	echo of request

Table 16.8 Relay DNP3 Object List (Sheet 3 of 6)

Obj.	Var.	Description	Request[a]		Response[a]	
			Funct. Codes	Qual. Codes	Funct. Codes	Qual. Codes
20	0	Binary counter—All variations	1, 7, 8, 9, 10	0, 1, 6, 7, 8, 17, 28		
20	1	32-Bit binary counter	1, 7, 8, 9, 10	0, 1, 6, 7, 8, 17, 28		
20	2	16-Bit binary counter	1, 7, 8, 9, 10	0, 1, 6, 7, 8, 17, 28		
20	3	32-Bit delta counter				
20	4	16-Bit delta counter				
20	5	32-Bit binary counter without flag	1, 7, 8, 9, 10	0, 1, 6, 7, 8, 17, 28	129	0, 1, 17, 28
20	6[a]	16-Bit binary counter without flag	1, 7, 8, 9, 10	0, 1, 6, 7, 8, 17, 28	129	0, 1, 17, 28
20	7	32-Bit delta counter without flag				
20	8	16-Bit delta counter without flag				
21	0	Frozen counter—All variations				
21	1	32-Bit frozen counter				
21	2	16-Bit frozen counter				
21	3	32-Bit frozen delta counter				
21	4	16-Bit frozen delta counter				
21	5	32-Bit frozen counter with time of freeze				
21	6	16-Bit frozen counter with time of freeze				
21	7	32-Bit frozen delta counter with time of freeze				
21	8	16-Bit frozen delta counter with time of freeze				
21	9	32-Bit frozen counter without flag				
21	10	16-Bit frozen counter without flag				
21	11	32-Bit frozen delta counter without flag				
21	12	16-Bit frozen delta counter without flag				
22	0	Counter change event—All variations	1	6, 7, 8		
22	1	32-Bit counter change event without time	1	6, 7, 8	129	17, 28
22	2[a]	16-Bit counter change event without time	1	6, 7, 8	129, 130	17, 28
22	3	32-Bit delta counter change event without time				
22	4	16-Bit delta counter change event without time				
22	5	32-Bit counter change event with time	1	6, 7, 8	129	17, 28
22	6	16-Bit counter change event with time	1	6, 7, 8	129	17, 28
22	7	32-Bit delta counter change event with time				
22	8	16-Bit delta counter change event with time				
23	0	Frozen counter event—All variations				
23	1	32-Bit frozen counter event without time				
23	2	16-Bit frozen counter event without time				
23	3	32-Bit frozen delta counter event without time				
23	4	16-Bit frozen delta counter event without time				

Table 16.8 Relay DNP3 Object List (Sheet 4 of 6)

Obj.	Var.	Description	Request[a]		Response[a]	
			Funct. Codes	Qual. Codes	Funct. Codes	Qual. Codes
23	5	32-Bit frozen counter event with time				
23	6	16-Bit frozen counter event with time				
23	7	32-Bit frozen delta counter event with time				
23	8	16-Bit frozen delta counter event with time				
30	0	Analog input—All variations	1	0, 1, 6, 7, 8, 17, 28		
30	1[b]	32-Bit analog input with flag	1	0, 1, 6, 7, 8, 17, 28	129	0, 1, 17, 28
30	2[b]	16-Bit analog input with flag	1	0, 1, 6, 7, 8, 17, 28	129, 130	0, 1, 17, 28
30	3[b]	32-Bit analog input without flag	1	0, 1, 6, 7, 8, 17, 28	129	0, 1, 17, 28
30	4[b]	16-Bit analog input without flag	1	0, 1, 6, 7, 8, 17, 28	129	0, 1, 17, 28
30	5[b]	Single-precision floating-point analog input with flag	1	0, 1, 6, 7, 8, 17, 28	129	0, 1, 17, 28
30	6[b]	Double-precision floating-point analog input with flag	1	0, 1, 6, 7, 8, 17, 28	129	0, 1, 17, 28
31	0	Frozen analog input—All variations				
31	1	32-Bit frozen analog input				
31	2	16-Bit frozen analog input				
31	3	32-Bit frozen analog input with time of freeze				
31	4	16-Bit frozen analog input with time of freeze				
31	5	32-Bit frozen analog input without flag				
31	6	16-Bit frozen analog input without flag				
32	0	Analog change event—All variations	1	6, 7, 8		
32	1[b]	32-Bit analog change event without time	1	6, 7, 8	129	17, 28
32	2[b]	16-Bit analog change event without time	1	6, 7, 8	129, 130	17, 28
32	3	32-Bit analog change event with time	1	6, 7, 8	129	17, 28
32	4	16-Bit analog change event with time	1	6, 7, 8	129	17, 28
32	5[b]	Single-precision floating-point analog change event without time	1	6, 7, 8	129	17, 18
32	6[b]	Double-precision floating-point analog change event without time	1	6, 7, 8	129	17, 18
32	7[b]	Single-precision floating-point analog change event with time	1	6, 7, 8	129	17, 28
32	8[b]	Double-precision floating-point analog change event with time	1	6, 7, 8	129	17, 28
33	0	Frozen analog event—All variations				
33	1	32-Bit frozen analog event without time				
33	2	16-Bit frozen analog event without time				
33	3	32-Bit frozen analog event with time				
33	4	16-Bit frozen analog event with time				

Table 16.8 Relay DNP3 Object List (Sheet 5 of 6)

Obj.	Var.	Description	Request[a]		Response[a]	
			Funct. Codes	Qual. Codes	Funct. Codes	Qual. Codes
34	0	Analog input deadband—All variations	1	0, 1, 6, 7, 8, 17, 28		
34	1	16-Bit analog input deadband	1, 2	0, 1, 6, 7, 8, 17, 28	129	0, 1, 17, 28
34	2[a]	32-Bit analog input deadband	1, 2	0, 1, 6, 7, 8, 17, 28	129	0, 1, 17, 28
34	3	Single-precision floating-point analog input deadband	1, 2	0, 1, 6, 7, 8, 17, 28	129	0, 1, 17, 28
40	0	Analog output status—All variations	1	0, 1, 6, 7, 8		
40	1	32-Bit analog output status	1	0, 1, 6, 7, 8	129	0, 1, 17, 28
40	2[a]	16-Bit analog output status	1	0, 1, 6, 7, 8	129	0, 1, 17, 28
40	3	Single-precision floating-point analog output status	1	0, 1, 6, 7, 8	129	0, 1, 17, 28
40	4	Double-precision floating-point analog output status	1	0, 1, 6, 7, 8	129	0, 1, 17, 28
41	0	Analog output block—All variations				
41	1	32-Bit analog output block	3, 4, 5, 6	17, 28	129	echo of request
41	2	16-Bit analog output block	3, 4, 5, 6	17, 28	129	echo of request
41	3	Single-precision floating-point analog output block	3, 4, 5, 6	17, 28	129	echo of request
41	4	Double-precision floating-point analog output block	3, 4, 5, 6	17, 28	129	echo of request
50	0	Time and date—All variations				
50	1	Time and date	1, 2	7, 8 index = 0	129	07, quantity = 1
50	2	Time and date with interval				
50	3	Time and date at last recorded time	2	7 quantity = 1	129	
51	0	Time and date CTO—All variations				
51	1	Time and date CTO			129	07, quantity = 1
51	2	Unsynchronized time and date CTO			129	07, quantity = 1
52	0	Time delay—All variations				
52	1	Time delay, coarse				
52	2	Time delay, fine			129	07, quantity = 1
60	0	All classes of data	1, 20, 21, 22	6, 7, 8		
60	1	Class 0 data	1, 22	6, 7, 8		
60	2	Class 1 data	1, 20, 21, 22	6, 7, 8		
60	3	Class 2 data	1, 20, 21, 22	6, 7, 8		
60	4	Class 3 data	1, 20, 21, 22	6, 7, 8		
70	1	File identifier				
80	1	Internal indications	2	0, 1 index = 4, 7		

Table 16.8 Relay DNP3 Object List (Sheet 6 of 6)

Obj.	Var.	Description	Request[a]		Response[a]	
			Funct. Codes	Qual. Codes	Funct. Codes	Qual. Codes
81	1	Storage object				
82	1	Device profile				
83	1	Private registration object				
83	2	Private registration object descriptor				
90	1	Application identifier				
100	1	Short floating point				
100	2	Long floating point				
100	3	Extended floating point				
101	1	Small packed binary—Coded decimal				
101	2	Medium packed binary—Coded decimal				
101	3	Large packed binary—Coded decimal				
112	All	Virtual terminal output block	2	6		
113	All	Virtual terminal event data	1	6	129, 130	17, 28
N/A		No object required for the following function codes: 13 cold start 14 warm start 23 delay measurement	13, 14, 23			

[a] Default variation.
[b] Setting AIVAR determines default variation.

Device Profile

The DNP3 Device Profile document, available as a download from the SEL website, contains the standard device profile information for the relay. This information is also available in XML format. Please refer to this document for complete information on DNP3 Protocol support in the relay.

Reference Data Map

Table 16.9 shows the common portions of the relay DNP3 reference data map. See *Section 10: Communications Interfaces* in the product-specific instruction manual for a complete DNP3 reference map for that relay. You can use the default map or the custom DNP3 mapping functions of the relay to include only the points required by your application.

The entire Relay Word bit table (see *Section 11: Relay Word Bits* in the product-specific instruction manual) is part of the DNP3 reference map. You may include any label in the Relay Word bit table as part of a DNP3 custom map.

The relay scales analog values by the indicated settings or fixed scaling. Analog inputs for event (fault) summary reporting use a default scale factor of 1 and deadband of ANADBM. Per-point scaling and deadband settings specified in a custom DNP3 map will override defaults.

Table 16.9 Relay DNP3 Reference Data Map (Sheet 1 of 2)

Object	Label	Description
Binary Inputs		
01, 02	RLYDIS	Relay disabled
01, 02	STFAIL	Relay diagnostic failure
01, 02	STWARN	Relay diagnostic warning
01, 02	STSET	Settings change or relay restart
01, 02	UNRDEV	New relay event available
01, 02	NUNREV	An unread event exists, newer than the event in the event summary AIs
01, 02	LDATPFW	Leading true power factor A-Phase, Terminal W (1 if leading, 0 if lagging or zero)
01, 02	LDBTPFW	Leading true power factor B-Phase, Terminal W (1 if leading, 0 if lagging or zero)
01, 02	LDCTPFW	Leading true power factor C-Phase, Terminal W (1 if leading, 0 if lagging or zero)
01, 02	LD3TPFW	Leading true power factor three-phase, Terminal W (1 if leading, 0 if lagging or zero)
01, 02	Relay Word	Relay Word bit label
Binary Outputs		
10, 12	RB01–RB*nn*	Remote bits RB01–RB*nn*[a]
10, 12	RB01:RB02 RB03:RB04 RB05:RB06 • • • RB*mm*:RB*nn*	Remote bit pairs RB01–RB*nn*[a]
10, 12	OC*m*	Pulse open Circuit Breaker *m* command[b]
10, 12	CC*m*	Pulse close Circuit Breaker *m* command[b]
10, 12	OC*m*:CC*m*	Open/close pair for Circuit Breaker *m*[b]
10, 12	89OC01–89OC*dd*	Open Disconnect Switch Control 1–*dd*[c]
10, 12	89CC01–89CC*dd*	Close Disconnect Switch Control 1–*dd*[c]
10, 12	89OC01:89CC01 89OC02:89CC02 89OC03:89CC03 • • • 89OC*dd*:89CC*dd*	Open/close Disconnect Switch Control Pair 1–*dd*[c]
10, 12	RST_DEM	Reset demands[d]
10, 12	RST_PDM	Reset demand peaks[d]
10, 12	RST_ENE	Reset energies[d]
10, 12	RSTMML	Reset min/max metering data for the line[d]
10, 12	RSTMMB*m*	Reset min/max metering data for Circuit Breaker *m*[d]
10, 12	RST_BK*m*	Reset Breaker *m* monitor data[d]
10, 12	RST_BAT	Reset battery monitor data[d]
10, 12	RST_79C	Reset recloser shot counter[d]
10, 12	RSTFLOC	Reset fault location data[d]
10, 12	RSTTRGT	Reset front-panel targets[d]

Table 16.9 Relay DNP3 Reference Data Map (Sheet 2 of 2)

Object	Label	Description
10, 12	RSTDNPE	Reset (clear) DNP3 event summary AIs[d]
10, 12	NXTEVE	Load next fault event into DNP3 event summary AIs
Binary Counters		
20, 22	ACTGRP	Active settings group
NOTE: Additional binary counters are relay-specific. See the relay instruction manual to see what counter objects are available.		
Analog Inputs		
NOTE: The analog inputs available is relay dependent. See the relay instruction manual to determine what analog inputs are available.		
Analog Outputs		
40, 41	ACTGRP0	Active settings group
40, 41	TECORR[e]	Time-error preload value
40, 41	RA001–RA256	Remote analogs

[a] The number of remote bits available, nn, depends on the specific relay. See the relay instruction manual to see how many are available.
[b] The number of breakers to control and their designations, m, depends on the specific relay. See the relay instruction manual to determine which breakers are available.
[c] The number of disconnect controls, dd, available depends on the relay. See the relay instruction manual to determine how many disconnects are supported. Not all SEL-400 series relays support disconnect controls.
[d] Not all SEL-400 series relays support all of these resets. See the relay instruction manual to see which specific controls are available.
[e] In milliseconds, −30000 ≤ time ≤ 30000. When writing to this value, the Relay Word bit PLDTE asserts for approximately 1.5 cycles.

Device Attributes (Object 0)

Table 16.8 includes the supported Object 0 device attributes and variations. In response to Object 0 requests, the relay will send attributes that apply to that particular DNP3 session. Because the relay supports custom DNP3 maps, these values will likely be different for each session.

The relay uses its internal settings for the following variations:

- Variation 245—SID Global setting
- Variation 246—DNPID port setting
- Variation 247—RID Global setting

Binary Inputs

Binary inputs (Objects 1 and 2) are supported as defined by *Table 16.8*. The default variation for both static and event inputs is 2. Only the Read function code (1) is allowed with these objects. The relay will respond to an Object 2, Variation 3 request, but the response will contain no data.

The relay scans binary inputs approximately twice per second to generate DNP3 change events. When time is reported with these event objects, it is the time at which the scanner observed the bit change. This may be significantly delayed from when the original source changed and should not be used for sequence-of-events determination. Binary inputs registered with SER are derived from the SER process and carry the time stamp of actual occurrence. Some additional binary inputs are available to DNP3, most without SER time stamps. For example, RLYDIS is derived from the relay status variable, STWARN and STFAIL are derived from the diagnostic task data, and UNRDEV and NUNREV are derived from the event queue. Another binary input, STSET, is derived from the SER and carries the time stamp of actual occurrence.

Binary Outputs

Binary output status (Object 10, Variation 2) is supported as defined by *Table 16.8*. Static reads of points RB01–RB*nn*, OC*m*, CC*m*, 89OC01–89OC*dd*, and 89CC01–89CC*dd* respond with the online bit set and the state of the requested bit. Reads from control-only binary output points (such as the data reset controls RSTTRGT and RSTDNPE) respond with the online bit set and a state of 0.

The relay supports control relay output block objects (Object 12, Variation 1). The control relays correspond to the remote bits and other functions as shown above. Each DNP3 control message contains a trip/close code (TRIP, CLOSE, or NUL) and an operation type (PULSE ON, LATCH ON, LATCH OFF, or NUL). The trip/close code works with the operation type to produce set, clear, and pulse operations.

Control operations differ slightly for single-point controls compared to paired outputs. Paired outputs correspond to the complementary two-output model, and single-point controls follow the complementary latch or activation model. In the complementary two-output model, paired points only support close or trip operations, which, when issued, will pulse on the first or second point in the pair, respectively. Latch commands and pulse operations without a trip code are not supported. An operation in progress may be canceled by issuing a NUL trip/close code with a NUL operation type. Single output points support both pulse and latch operations. See *Control Point Operation on page 16.20* for details on control operations.

The status field is used exactly as defined. All other fields are ignored. A pulse operation is asserted for a single processing interval. You should exercise caution if sending multiple remote bit pulses in a single message (i.e., point count > 1), because this may result in some of the pulse commands being ignored and the return of an already active status message. The relay will only honor the first ten points in an Object 12, Variation 1 request. Any additional points in the request will return the DNP3 status code `TOO_MANY_OBJS`.

The relay also supports pattern control blocks (Object 12, Variations 2 and 3) to control multiple binary output points. Variation 2 defines the control type (trip/close, set/clear, or pulse) and the range of points to operate. Variation 3 provides a pattern mask that indicates which points in that range should be operated. Object 12, Variations 2 and 3 define the entire control command: the DNP3 master must send both for a successful control. For example, the DNP3 master sends an Object 12, Variation 2 message to request a trip of the range of indices 0–7. The DNP3 master then sends an Object 12, Variation 3 message with a hexadecimal value of “BB” as the pattern mask (converted to binary notation: 10111011). Read right to left in increasing bit order, the pattern block control command will result in a TRIP of indexes 0, 1, 3 to 5, and 7.

Control Point Operation

Use the trip and close, latch on/off and pulse on operations with Object 12 control relay output block command messages to operate the binary output points. See *Section 10: Communications Interfaces* in the product-specific instruction manual for a complete table of object 12 controls available in that relay. Pulse operations provide a pulse with duration of one protection processing interval. Cancel an operation in progress by issuing a NUL trip/close code with a NUL operation type.

Analog Inputs

Analog inputs (Objects 30 and 32) are supported as defined by *Table 16.8*. The default variation for both static and event inputs is defined by the AIVAR (AIVAR*n* for DNP3 LAN/WAN session *n*) setting. Only the Read function code (1) is allowed with these objects.

NOTE: Sequence current quantities are forced to 0 if the value is below 0.5 percent of I_{NOM}.

Unless otherwise indicated, analog values are reported in primary units. Voltage magnitudes below 0.10 volts secondary and current magnitudes below 0.5 percent of I_{NOM} are forced to 0, as are their corresponding angles. Default scaling is indicated in the product-specific instruction manual, but default scaling can be overridden by per-point scaling in a custom DNP3 map. The DECPLA, DECPLV, and DECPLM settings are the default scaling factors (in powers of 10) for current magnitudes, voltage magnitudes, and miscellaneous magnitudes, respectively. See *Configurable Data Mapping on page 16.23* for more information.

Default deadbands are also indicated in the product-specific instruction manual and may be overridden by per-point deadband configuration. In general, the ANADBA, ANADBV, and ANADBM settings are the default deadbands for current magnitudes, voltage magnitudes, and miscellaneous magnitudes, respectively. Deadbands are applied after any custom or default scaling factors. Events are generated when values exceed deadbands.

Reading Relay Event Data

The relay provides protective relay event history information in one of two modes: single-event or multiple-event access. Each DNP3 session begins in the mode specified by Port setting EVEMOD*n* (where *n* = 1–6 for Ethernet sessions and not present for serial sessions). The selected mode is entered when the relay is first enabled, when there is a DNP3 settings change, a DNP3 map change, or an SER settings change. When EVEMOD*n* = SINGLE, the relay powers up in single-event mode. When EVEMOD*n* = MULTI, the relay powers up in multiple-event mode. A DNP3 session will switch to multiple-event mode if the session DNP3 master sends a control to the NXTEVE binary output control point. The DNP3 session will revert to the default mode after a power cycle or relay restart.

When a relay event occurs, (TRIP asserts, ER asserts, or TRI asserts) whose fault location is in the range of MINDIST to MAXDIST, the data shall be made available to DNP3. If MINDIST is set to OFF, then there is no minimum. Similarly, if MAXDIST is set to OFF, there is no maximum.

In either mode, DNP3 events for all event summary analog inputs will be generated if any of them change beyond their deadband value after scaling (usually whenever a new relay event occurs and is loaded into the event summary analog inputs). Events are detected approximately twice a second by the scanning process.

The specific fault data available and its encoding is relay-specific. See *Section 10: Communications Interfaces* in the product-specific instruction manual for information on the relay reports fault data.

Single-Event Mode

Single-event mode provides the most recent tripping event. When a relay event occurs and FLOC is in range of MINDIST and MAXDIST, these data regions are copied to the DNP3 fault summary analog inputs, generating appropriate DNP3 events. The relay shall then ignore any subsequent events for EVELOCK (Global setting) time. When the EVELOCK setting is zero, single-event mode effectively acts as a zero-buffer FIFO queue. In this mode, relay events are presented to gen-

erate DNP3 events for the fault summary analog inputs as they occur. Fault summary analog inputs shall be reset to 0 on a rising edge of RSTDNPE (Global SELOGIC equation result). The relay element EVELOCK shall be set when a relay event is triggered and reset when EVELOCK time expires.

Multiple-Event Mode

Relay multiple-event summary data can be read in two ways: first in, first out (FIFO); or last in, first out (LIFO).

See *FIFO on page 16.22* and *LIFO on page 16.22* below for procedures to retrieve relay events that occur when FLOC is in range of MINDIST and MAXDIST. Event retrieval as shown below is a manual monitor, control, and poll process. A DNP3 master can collect relay event summaries by using event data rather than the static data polling described below. For best results, the master must control the NXTEVE binary output no faster than once every two seconds to load a new event into the event summary analog inputs. If the NXTEVE binary output is controlled at a faster rate, some DNP3 events may not be recognized and processed by the DNP3 event scanner.

FIFO

Multiple-event FIFO mode shall be initiated if the DNP3 session master operates the NXTEVE (next event) control. The master should monitor the UNRDEV binary input point, which will be asserted when there is an unread relay event summary. The NUNREV bit will also be asserted as long as there remain any unread events newer than the currently loaded event summary. To read the oldest unread relay event summary, the master should send a close, latch on, or pulse on control to the NXTEVE binary output point. This will load the relay event summary analogs with information from the oldest relay event summary, discarding the values from the previous load.

After reading the analogs, the master should again check the UNRDEV binary input point, which will be on if there is another unread relay event summary. The master should continue this process until the UNRDEV binary input point deasserts. If the master attempts to load values by controlling the NXTEVE output point when the UNRDEV binary input point is deasserted, the relay event type analog (FTYPE) will be loaded with zero. With the FIFO method, the relay event summaries will always be collected in chronological order.

LIFO

Multiple-event LIFO mode event summary retrieval is similar to FIFO retrieval, with the following difference: to read the newest unread relay event summary, the master should send a latch off control to the NXTEVE binary output point. As with FIFO retrieval, the master should monitor the UNRDEV binary input to determine if there are any unread events. Users must be aware of one caveat with LIFO retrieval: if an event occurs while in the process of reading the newest event(s) event collection will no longer continue in reverse chronological order. The next event read will be the newest event, and will proceed with the next newest, but any events that have already been read shall be skipped. The NUNREV bit will be asserted if this happens, signifying that the currently loaded event summary is no longer the newest event.

Analog Outputs

Analog outputs (Objects 40 and 41) are supported as defined by *Table 16.8*. The default variation for both static and event inputs is Variation 2. If an invalid value is written, the relay will ignore the value without generating an error.

The relay will only honor the first ten points in a request. Any additional points in the request will be ignored without generating an error.

Counters

Counters (Object 20 and 22) are supported as defined by *Table 16.8*. The default variation for Object 20 is Variation 6, and Variation 2 is the default for Object 22. Counters shall only support the Read function code (1). A Read of Object 21 will receive a Null response. The default deadband is 0, which may be overridden by a per-point deadband in a custom map. Scaling for counters is always 1.

Default Data Map

See *Section 10: Communications Interfaces* in the product-specific instruction manual to see the relay default map. If the default maps are not appropriate, you can also use the custom DNP3 mapping commands **SET D *n*** and **SHOW D *n***, where *n* is the map number, to edit or create the map required for your application.

Configurable Data Mapping

One of the most powerful features of the relay DNP3 implementation is the ability to remap DNP3 data and, for analog and counter inputs, specify per-point scaling and deadbands. Remapping is the process of selecting data from the default or reference map and organizing it into a data set optimized for your application. The relay uses point labels rather than point indexes in a reference map to streamline the remapping process. This enables you to quickly create a custom map without having to search for point indexes in a large reference map.

You may use any of the five available DNP3 maps to exchange data with any DNP3 master. Each map is initially populated with default data points, as described in the Default DNP3 Map. You may remap the points in a default map to create a custom map with as many as:

- 400 binary inputs
- 160 binary outputs
- 20 counters
- 200 analog inputs
- 100 analog outputs

Use the settings Class D to access the relay DNP3 map settings shown in *DNP3 Settings—Custom Maps on page 12.19*. There are five DNP3 maps available to customize, or leave as default.

The mapping settings are entered in a line-based freeform format. An example of these settings is shown in *Figure 16.4*. You can program a custom scaling and deadband for each point where indicated. If you do not specify a custom scaling or deadband, the relay will use the default for the type of value you are mapping. For example, if you enter the label 3P_F in Row 1 of the custom analog map with

no other parameters, the power in MW will be available as Objects 30 and 32, Index 0 and the relay will use the default scaling DECPLM and default deadband of ANADBM.

You can use the **SHOW D *x*** command to view the DNP3 data map settings, where *x* is the DNP3 map number from 1 to 5. See *Figure 16.4* for an example display of Map 1.

```
=>>SHO D 1 <Enter>
DNP 1

DNP Object Default Map Enables

MINDIST := OFF      MAXDIST := OFF


Binary Input Map
(Binary Input Label)

1: EN_RLY
2: TRIPLED
.
.
.
13: RBO4
14: RBO5
15: RBO6


Binary Output Map
(Binary Output Label)

1: RBO1
2: RBO2
.
.
.
5: RBO5
6: RBO6


Counter Map
(Counter Label, Deadband)

1: ACTGRP

Analog Input Map
(Analog Input Label, Scale Factor, Deadband)

1: IAWFMC
2: IAWFAC
.
.
.
15: 3SWFC
16: VDC1


Analog Output Map
(Analog Output Label)

1: ACTGRP
```

Figure 16.4 Sample Response to SHO D Command

You can use the **SET D *x*** command (where *x* is the map number), to edit or create custom DNP3 data maps. You can also use QuickSet, which is recommended for this purpose.

See the Reference Map to determine the available choices for each object type.

For binary inputs, a value of 0 or 1 may be used instead of a label; this will cause the relay to report that value for that point. Similarly, for counters and analog inputs, a value of 0 may be used instead of a label, which will cause the relay to report 0 for that point. A NOOP can be used as a placeholder for binary or analog outputs-control of a point with this label does not change any relay values nor respond with an error message. Duplicate point labels are not allowed within a map, except for the values 0 or 1 or NOOP.

You can customize the DNP3 analog input map with per-point scaling and deadband settings. Class scaling (DECPLA*n*, DECPLV*n*, and DECPLM*n*) and deadband settings (ANADBA*n*, ANADBV*n*, and ANADBM*n*) are applied to indices that do not have per-point entries. Per-point scaling overrides any class scaling and deadband settings. Unlike per-point scaling, class-level scaling is specified by an integer in the range 0–3 (inclusive), which indicates the number of decimal place shifts. In other words, you should select 0 to multiply by 1, 1 for 10, 2 for 100, or 3 for 1000.

NOTE: The settings above contain the DNP3 LAN/WAN session suffix n. This suffix is not present in serial port DNP3 settings.

Scaling factors allow you to overcome the limitations imposed, by default, of the integer nature of Objects 30 and 32. For example, DNP3, by default, truncates a value of 11.4 A to 11 A. You may use scaling to include decimal point values by multiplying by a power of 10. For example, if you use 10 as a scaling factor, 11.4 A will be transmitted as 114. You must divide the value by 10 in the master to see the original value including one decimal place.

You can also use scaling to avoid overflowing the 16-bit maximum integer value of 32767. For example, if you have a value that can reach 157834, you cannot send it using DNP3 16-bit analog object variations. You could use a scaling factor of 0.1 so that the maximum value reported is 15783. You can then multiply the value by 10 in the master to see a value of 157830. You will lose some precision as the last digit is dropped in the scaling process, but you can transmit the scaled value by using the default variations for DNP3 Objects 30 and 32.

If your DNP3 master has the capability to request floating-point analog input variations, the relay will support them. These floating-point variations, 5 and 6 for Object 30 and 5–8 for Object 32, allow the transmission of 16- or 32-bit floating-point values to DNP3 masters. When used, these variations eliminate the need for scaling and maintain the resolution of the relay analog values. Note that this support is greater than DNP3 Level 4 functionality, so you must confirm that your DNP3 master can work with these variations before you consider using floating-point analog variations.

The following example describes how to create a custom DNP3 map by point type. The example demonstrates the **SET D** command for analog inputs. Alternatively, you can use the QuickSet software to simplify custom data map creation. The example uses quantities available in the SEL-411L, but similar operations can be performed on any SEL-400 series relay.

Consider a case where you want to set the analog input points in a map as shown in *Table 16.10*.

Table 16.10 Sample Custom DNP3 Analog Input Map

Point Index	Description	Label	Scaling	Deadband
0	Fundamental IA magnitude	LIAFM	Default	Default
1	Fundamental IB magnitude	LIBFM	Default	Default
2	Fundamental IC magnitude	LICFM	Default	Default
3	Fundamental IC magnitude	LIAFM	Default	Default
4	Fundamental three-phase power	3P_F	5	Default
5	Fundamental A-Phase magnitude	VAFM	Default	Default
6	Fundamental A-Phase angle	VAFA	1	15
7	Frequency	FREQ	0.01	1

To set these points as part of custom map 1, you can use the **SET D 1 TERSE** command as shown in *Figure 16.5*.

```
=>>SET D 1 TERSE <Enter>
DNP 1

DNP Object Default Map Enables


Min Fault Location to Capture (OFF,-10000 - 10000)   MINDIST := OFF    ?
Max Fault Location to Capture (OFF,-10000 - 10000)   MAXDIST := OFF    ?

Analog Input Map
(Analog Input Label, Scale Factor, Deadband)
1:
? LIBFM <Enter>
2:
? LICFM <Enter>
3:
? LIAFM <Enter>
4:
? 3P_F,5 <Enter>

5:
? VAFM <Enter>
6:
? VAFA,1,15 <Enter>
7:
? FREQ,.01,1 <Enter>
8:
? END
Save settings (Y,N) ?Y <Enter>
Saving Settings, Please Wait...........
Settings Saved
```

Figure 16.5 Sample Custom DNP3 Analog Input Map Settings

DNP3 Serial Application Example

Application

This example uses an SEL-421 connected to an RTU over an EIA-485 network. The RTU collects basic metering information from the relay and other devices. The network for this example is shown in *Figure 16.6*.

Figure 16.6 DNP3 Application Network Diagram

The metering and status data that the RTU collects from the relay are listed in *Table 16.11*.

Table 16.11 DNP3 Application Example Data Map

Label	Object	Custom Map Index	Description
EN	1, 2	0	Relay enabled
TRIPLED	1, 2	1	Circuit Breaker tripped
IN101	1, 2	2	Relay Discrete Input 1
IN102	1, 2	3	Relay Discrete Input 2
IN103	1, 2	4	Relay Discrete Input 3
IN104	1, 2	5	Relay Discrete Input 4
SALARM	1, 2	6	Relay software alarm
HALARM	1, 2	7	Relay hardware alarm
TESTDB2	1, 2	8	Test mode enabled
RB01	10, 12	0	Remote Bit 1
RB02	10, 12	1	Remote Bit 2
RB03	10, 12	2	Remote Bit 3
RB04	10, 12	3	Remote Bit 4
RB05	10, 12	4	Remote Bit 5
RB06	10, 12	5	Remote Bit 6
OC1:CC1	10, 12	6	Circuit Breaker 1 trip/close pair
LIAFM	30, 32	0	IA magnitude
LIAFA	30, 32	1	IA angle
LIBFM[a]	30, 32	2	IB magnitude
LIBFA[b]	30, 32	3	IB angle
LICFM[a]	30, 32	4	IC magnitude
LICFA[b]	30, 32	5	IC angle
VAFM[c]	30, 32	6	VAY magnitude
VAFA[b]	30, 32	7	VAY angle
VBFM[c]	30, 32	8	VBY magnitude
VBFA[b]	30, 32	9	VBY angle
VCFM[c]	30, 32	10	VCY magnitude
VCFA[b]	30, 32	11	VCY angle
3P_F[d]	30, 32	12	Three-phase real power in MW
3Q_F[d]	30, 32	13	Three-phase reactive power in MVAR
DC1[e]	30, 32	14	DC1 voltage multiplied by 100
ACTGRP	40	0	Active settings group

[a] Assume the largest expected current is 2000 A and scale the analog value by a factor of 10 to provide a resolution of 0.1 A and a maximum current of 3276.7 A. Report change events on a change of 5 A.

[b] Angles are scaled to 1/100 of a degree. Report change events on a change of 2 degrees.

[c] For a nominal voltage of 230 kV, scale the analog value by a factor of 100 to provide a resolution of 10 V and a maximum value of 327.67 kV. Report 1 kV for change event reporting.

[d] For a maximum load of 800 MW (or 800 mVar), scale the power by a factor of 40 to provide a resolution of 0.025 MW and a maximum value of 819.175 MW. Report 1 MW for change event reporting.

[e] VDC1 is scaled by a factor of 1/100 of a volt. Report change events on a change of 2 V.

Settings

Figure 16.7 shows how to enter the new map into the relay. Use the **SET D** command and enter N at the prompts shown in *Figure 16.7* to allow changes to the existing maps. Press **<Enter>** at the empty line prompt to advance to the next map. For example, press **<Enter>** at line 10 of the Binary Input Map to advance to the Binary Output Map. If the prompt contains an entry, you can enter the greater-than symbol (>) and press **<Enter>** to advance to the next step.

```
=>>SET D 1 TERSE <Enter>
DNP 1

DNP Object Default Map Enables

Min Fault Location to Capture (OFF,-10000 - 10000)   MINDIST := OFF    ? <Enter>
Max Fault Location to Capture (OFF,-10000 - 10000)   MAXDIST := OFF    ? <Enter>


Binary Input Map
(Binary Input Label)

1: RLYDIS
?  DELETE 100 <Enter>
1:
?  EN <Enter>
2:
?  TRIPLED <Enter>
3:
?  IN101 <Enter>
4:
?  IN102 <Enter>
5:
?  IN103 <Enter>
6:
?  IN104 <Enter>
7:
?  SALARM <Enter>
8:
?  HALARM <Enter>
9:
?  TESTDB2 <Enter>
10:
? <Enter>


Binary Output Map
(Binary Output Label)

1: RB01
?  DELETE 100 <Enter>
1:
?  RB01 <Enter>
2:
?  RB02 <Enter>
3:
?  RB03 <Enter>
4:
?  RB04 <Enter>
5:
?  RB05 <Enter>
6:
?  RB06 <Enter>
7:
?  OC1:CC1 <Enter>
8:
? <Enter>


Counter Map
(Counter Label, Deadband)

1: ACTGRP
?
2: BKR1OPA
? DELETE 100 <Enter>
2:
? <Enter>
```

Figure 16.7 SEL-421 Example DNP Map Settings

```
Analog Input Map
(Analog Input Label, Scale Factor, Deadband)

1: LIAFM
?  <Enter>
2: LIAFA
?  LIAFA,1,200 <Enter>
3: LIBFM
? <Enter>
4: LIBFA
?  LIBFA,1,200 <Enter>
5: LICFM
? <Enter>
6: LICFA
?  LICFA,1,200 <Enter>
7: B1IAFM
?  VAFM <Enter>
8: B1IAFA
?  VAFA,1,200 <Enter>
9: B1IBFM
?  VBFM <Enter>
10: B1IBFA
?  VBFA,1,200 <Enter>
11: B1ICFM
?  VCFM <Enter>
12: B1ICFA
?  VCFA,1,200 <Enter>
13: B2IAFM
?  3P_F,40,40 <Enter>
14: B2IAFA
?  3Q_F,40,40 <Enter>
15: B2IBFM
?  DC1,,200 <Enter>
16: B2IBFA
?  DELETE 200 <Enter>
16:
? <Enter>


Analog Output Map
(Analog Output Label)

1: ACTGRP
? <Enter>
2:
? <Enter>

Save settings (Y,N)  ?Y <Enter>
Saving Settings, Please Wait...........
Settings Saved
=>>
```

Figure 16.7 SEL-421 Example DNP Map Settings (Continued)

Table 16.12 lists the settings for **PORT 3** for this example. The physical connection between the relay and the DNP3 master is an EIA-485 network. An SEL-2884 interface converter on the relay **PORT 3** provides conversion from EIA-232 to EIA-485. Unsolicited reporting has been disabled because the network is wired as a four-wire connection and does not provide carrier detection or the opportunity to monitor for data traffic on the network.

Table 16.12 SEL-421 PORT 3 Example Settings (Sheet 1 of 2)

Setting Name	Setting	Description
EPORT	Y	Enable port
EPAC	N	Enable port access control
MAXACC	2	Maximum access level for virtual terminal sessions
PROTO	DNP	DNP3 protocol
SPEED	9600	Data speed
PARITY	N	No parity bit
STOPBIT	1	1 stop bit
TIMEOUT	5	Time out virtual terminal session after 5 minutes
TERTIM1	1	Check for termination after 1 second idle time

Table 16.12 SEL-421 PORT 3 Example Settings (Sheet 2 of 2)

Setting Name	Setting	Description
TERSTRN	"\005"	Virtual terminal termination string
TERTIM2	0	No delay before accepting termination string
DNPADR	101	DNP3 address = 101
DNPID	"RELAY1-DNP"	DNP ID for Object 0 self-description
DNPMAP	1	Use DNP3 Map 1
ECLASSB	1	Event Class 1 for binary event data
ECLASSC	1	Event Class 1 for counter event data
ECLASSA	1	Event Class 1 for analog event data
ECLASSV	OFF	Disable virtual terminal event data (this feature is not supported by the DNP3 master)
TIMERQ	I	Ignore time-set request because IRIG-B is used for time synchronization
DECPLA	1	Scale current, multiplying by 10 to send amperes and tenths of an ampere. The relay would report a value of 10.4 as 104, which would remain unscaled at the master.
DECPLV	2	Scale voltage, multiplying by 100 to send kilovolts, tenths, and hundredths of a kilovolt
DECPLM	2	Scale miscellaneous analog data, multiplying by 100 to send whole numbers and hundredths. The relay would report a value of 5.25 as 525, which would remain unscaled at the master.
STIMEO	10.0	10 second select before operate time-out
DRETRY	OFF	Turn off data link retries
MINDLY	0.05	Minimum delay from DCD to TX
MAXDLY	0.10	Maximum delay from DCD to TX
PREDLY	0.025	Settle time from RTS on to TX to allow EIA-485 transceiver to switch to transmit mode
PSTDLY	0.00	Settle time from TX to RTS off—not required in this application
DNPCL	Y	Enable controls for DNP3
AIVAR	2	Default AI variation
ANADBA	50	Analog reporting deadband for currents, 5 A based on DECPLA scaling factor
ANADBV	100	Analog reporting deadband for voltages, 1 kV based on DECPLV scaling factor
ANADBM	100	Miscellaneous analog value deadband, based on DECPLM scaling factor
ETIMEO	10	Event Message Confirm Time-Out, 10 seconds
UNSOL	N	Unsolicited reporting disabled (data retrieval method is polled report-by-exception)
MODEM	N	No modem connected to port

In this example, the polling method employed by the RTU DNP3 master is polled report-by-exception. The master device normally polls for events only. Once every 25 event polls, the master polls for Class 0 data (status of all points). This polling method allows the master to collect data efficiently from the IEDs by not continuously polling and receiving data that are not changing.

DNP3 LAN/WAN Application Example

Application

This example uses an SEL-487E connected to an RTU over an Ethernet (TCP) network. The RTU collects basic metering information from the relay. The network for this example is shown in *Figure 16.8*.

Figure 16.8 DNP3 LAN/WAN Application Example Ethernet Network

The polling method employed by the RTU DNP3 master is polled report-by-exception, so it normally only does event polls. Once every 25 event polls, the master polls for Class 0 data (status of all points). This polling method allows the master to collect data efficiently from the IEDs by only polling and receiving data that has changed.

The RTU, which will act as the DNP3 master to the SEL-487E outstation, has an IP address of 192.9.0.3 and a DNP3 address of 12. The SEL-487E should be assigned an IP address of 192.9.0.2, default router of 192.9.0.1, and DNP3 address of 101.

All event data (analog, binary, counter) should be assigned to CLASS 1. All Binary Inputs should have SOE-quality time stamps.

The desired DNP3 data map is shown in *Table 16.13*.

Table 16.13 DNP3 Application Example Data Map (Sheet 1 of 2)

Label	Object	Custom Map Index	Description
EN	1, 2	0	Relay enabled
TRIPLED	1, 2	1	Circuit Breaker tripped
IN101	1, 2	2	Relay Discrete Input 1
IN102	1, 2	3	Relay Discrete Input 2
IN103	1, 2	4	Relay Discrete Input 3
IN104	1, 2	5	Relay Discrete Input 4
SALARM	1, 2	6	Relay software alarm
HALARM	1, 2	7	Relay hardware alarm
TESTDB2	1, 2	8	Test mode enabled
RB01	10, 12	0	Remote Bit 1
RB02	10, 12	1	Remote Bit 2
RB03	10, 12	2	Remote Bit 3
RB04	10, 12	3	Remote Bit 4

Table 16.13 DNP3 Application Example Data Map (Sheet 2 of 2)

Label	Object	Custom Map Index	Description
RB05	10, 12	4	Remote Bit 5
RB06	10, 12	5	Remote Bit 6
OCS:CCS	10, 12	6	Circuit Breaker S trip/close pair
IASFMC	30, 32	0	A-Phase Current magnitude
IASFAC	30, 32	1	A-Phase Current angle
IBSFMC[a]	30, 32	2	B-Phase Current magnitude
IBSFAC[b]	30, 32	3	B-Phase Current angle
ICSFMC[a]	30, 32	4	C-Phase Current magnitude
ICSFAC[b]	30, 32	5	C-Phase Current angle
VAVFMC	30, 32	6	VA Phase Voltage magnitude, Terminal V
VAVFAC[b]	30, 32	7	VA Phase Voltage angle, Terminal V
VBVFMC[c]	30, 32	8	VB Phase Voltage magnitude, Terminal V
VBVFAC[b]	30, 32	9	VB Phase Voltage angle, Terminal V
VCVFMC[c]	30, 32	10	VC Phase Voltage magnitude, Terminal V
VCVFAC[b]	30, 32	11	VC Phase Voltage angle, Terminal V
VDC[d]	30, 32	12	VDC voltage multiplied by 100
ACTGRP	40	0	Active settings group

[a] Assume the largest expected current is 2000 A, scale the analog value by a factor of 10 to provide a resolution of 0.1 A and a maximum current of 3276.7 A. Report change events on a change of 5 A.
[b] Angles are scaled to 1/100 of a degree. Report change events on a change of 2 degrees.
[c] For a nominal voltage of 230 kV, scale the analog value by a factor of 100 to provide a resolution of 10 V and a maximum value of 327.67 kV. Report 1 kV for change event reporting.
[d] VDC1 is scaled by a factor of 1/100 of a volt. Report change events on a change of 2 V.

Settings

Use SEL Grid Configurator to enter the DNP3 protocol settings and new data map into the relay.

Table 16.14 DNP3 LAN/WAN Application Example Protocol Settings (Sheet 1 of 2)

Setting Name	Setting	Description
EPORT	Y	Enable Ethernet port
IPADDR	192.9.0.2/16	Relay IP address and network in classless inter-domain routing (CIDR) notation
DEFRTR	192.9.0.1	Default router
EDNP	1	Enable DNP3 LAN/WAN Session 1
DNPADR	101	DNP3 address for relay is 101
DNPPNUM	20000[a]	DNP3 port number for TCP
DNPID	RELAY1DNP	DNP3 ID for Object 0 self-description
DNPIP1	192.9.0.3	DNP3 Master (RTU) IP address
DNPTR1	TCP	Use TCP transport
DNPMAP1	1	Use DNP3 Map 1 for DNP3 LAN/WAN Session 1
CLASSB1	1	Binary event data = Class 1
CLASSC1	1	Counter event data = Class 1

Table 16.14 DNP3 LAN/WAN Application Example Protocol Settings (Sheet 2 of 2)

Setting Name	Setting	Description
CLASSA1	1	Analog event data = Class 1
TIMERQ1	1	Ignore time synchronization requests from DNP3 Master
DECPLA1	2	Scale analog current data, multiplying by 10 to send whole numbers and tenths. The relay would report a value of 5.25 as 525, which would remain unscaled at the master. (10^2 = 100)
DECPLV1	2	Scale analog voltage data, multiplying by 10 to send whole numbers and tenths. The relay would report a value of 5.25 as 525, which would remain unscaled at the master. (10^2 = 100)
DECPLM1	2	Scale analog miscellaneous data, multiplying by 10 to send whole numbers and tenths. The relay would report a value of 5.25 as 525, which would remain unscaled at the master. (10^2 = 100)
STIMEO1	1.0[a]	1.0 second to select before operate time-out
DNPINA1	120[a]	Wait 120 seconds to send inactive heartbeat
DNPCL1	Y	Allow DNP3 controls for this session
AIVAR1	2	Default AI variation
ANADBA1	200	Analog deadband counts, set to 2 engineering units, based on DECPLA scaling factor
ANADBV1	200	Analog deadband counts, set to 2 engineering units, based on DECPLV scaling factor
ANADBM1	200	Analog deadband counts, set to 2 engineering units, based on DECPLM scaling factor
ETIMEO1	2[a]	Event message confirm time-out (2 s)
UNSOL1	N	Disable unsolicited reporting for Master 1

[a] Default value.

To meet the requirement for SOE-quality time stamps, enter all binary inputs into the SER report. See *Figure 16.9* for a screenshot of the process.

Figure 16.9 Add Binary Inputs to SER Point List

This page intentionally left blank

SECTION 17

IEC 61850 Communication

The relay supports the following features using Ethernet and IEC 61850.

- **SCADA**—Connect as many as seven simultaneous IEC 61850 Manufacturing Message Specification (MMS) client sessions. The relay also supports as many as seven buffered and seven unbuffered report control blocks. See *Table 17.34* for logical node mapping that enables SCADA control (including Setting Group Switch) via a MMS browser. Controls support the Direct Normal Security and Enhanced Security (Direct or Select Before Operate) control models.
- **Peer-to-Peer Real-Time Status and Control**—Use GOOSE with as many as 128 incoming (receive) and 8 outgoing (transmit) messages. Virtual Bits (VB001–VB256) and remote analogs (RA001–RA256) can be mapped from incoming GOOSE messages. Remote analog outputs (RAO01–RAO64) provide peer-to-peer real-time analog data transmission.
- **Sampled Values—**Use Sampled Values (SV) to replace the traditional copper wiring between instrument transformers and the relay. Connect an SEL SV publisher to CTs and VTs to publish SV. Use SV subscribers to subscribe to these SV messages. SEL-400 series SV products are compliant to the UCA 61850 9-2LE guidelines. In accordance with the guideline, each publication includes one application service data unit (ASDU), with four current and four voltage channels. Supported publication rates are 4.8 kHz for a 60 Hz power system and 4 kHz for a 50 Hz power system. SEL SV publishers support as many as seven SV streams. SEL SV subscribers support subscribing to as many as seven streams.
- **Configuration**—Use File Transfer Protocol (FTP) client software or ACSELERATOR Architect SEL-5032 Software to transfer the Substation Configuration Language (SCL) Configured IED Description (CID) file to the relay. SEL-400 series SV products also support SV configuration via **PORT 5** settings.
- **Commissioning and Troubleshooting**—Use software such as MMS Object Explorer and AX-S4 MMS from Sisco, Inc., to browse the relay logical nodes and verify functionality.

NOTE: The CID file contains only the necessary data for the required data sets, reports, GOOSE/SV publications, subscriptions, and supervisions. This helps prevent a CID file from exceeding its allocated memory. Refer to Section 10: Testing, Troubleshooting, and Maintenance for more information.

NOTE: Not all SEL-400 series relays support SV publication or subscription.

NOTE: The relay ships with a default CID file installed, which supports basic IEC 61850 functionality. A new CID file should be loaded if a change in the relay configuration is required. If an invalid CID file is transferred, the relay will reject the file and revert to the previous valid CID file.

This section presents the information you need to use the IEC 61850 features of the relay.

- *Introduction to IEC 61850 on page 17.2*
- *IEC 61850 Operation on page 17.3*
- *IEC 61850 Configuration on page 17.47*
- *Logical Nodes on page 17.53*
- *Protocol Implementation Conformance Statement on page 17.84*
- *ACSI Conformance Statements on page 17.89*

Introduction to IEC 61850

In the early 1990s, the Electric Power Research Institute (EPRI) and the Institute of Electrical and Electronics Engineers, Inc. (IEEE) began to define a Utility Communications Architecture (UCA). They initially focused on inter-control center and substation-to-control center communications and produced the Inter-Control Center Communications Protocol (ICCP) specification. This specification, later adopted by the IEC as 60870-6 TASE.2, became the standard protocol for real-time exchange of data between databases.

In 1994, EPRI and IEEE began work on UCA 2.0 for Field Devices (simply referred to as UCA2). In 1997, they combined efforts with Technical Committee 57 of the IEC to create a common international standard. Their joint efforts created the current IEC 61850 standard.

The IEC 61850 standard, a superset of UCA2, contains most of the UCA2 specification, plus additional functionality. The standard describes client/server and peer-to-peer communications, substation design and configuration, testing, and project standards.

The IEC 61850 standard consists of the parts listed in *Table 17.1*. The original parts were first published between 2001 and 2004 and are often referred to as IEC 61850 Edition 1 (Ed1). Selected parts of these standards were updated in 2011 and tagged as Edition 2 (Ed2). The current edition, Edition 2, Amendment 1 (Ed2.1), was published in 2020. Refer to the product-specific manual to identify edition compliance.

It is possible and even likely that an installation will have a mixture of devices that conform to different editions. The standard generally supports backward compatibility, i.e., Ed2 devices can send and receive messages to and from Ed1 devices. However, there are important considerations to be made when adding Ed2 or Ed2.1 devices to an existing Ed1 system. Refer to *Potential Client and Automation Application Issues With Ed2 and Ed2.1 Upgrades on page 17.94* for more information.

Table 17.1 IEC 61850 Document Set (Sheet 1 of 2)

IEC 61850 Sections	Definitions
IEC 61850-1	Introduction and overview
IEC 61850-2	Glossary
IEC 61850-3	General requirements
IEC 61850-4	System and project management
IEC 61850-5	Communication requirements
IEC 61850-6	Configuration description language for substation IEDs
IEC 61850-7-1	Basic communication structure for substations and feeder equipment—Principles and models
IEC 61850-7-2	Basic communication structure for substations and feeder equipment—Abstract communication service interface (ACSI)
IEC 61850-7-3	Basic communication structure for substations and feeder equipment—Common data classes (CDCs)
IEC 61850-7-4	Basic communication structure for substations and feeder equipment—Compatible logical node (LN) classes and data classes
IEC 61850-8-1	SCSM—Mapping to Manufacturing Messaging Specification (MMS) (ISO/IEC 9506-1 and ISO/IEC 9506-2 over ISO/IEC 8802-3)

Table 17.1 IEC 61850 Document Set (Sheet 2 of 2)

IEC 61850 Sections	Definitions
IEC 61850-9-1	SCSM—Sampled values over serial multidrop point-to-point link
IEC 61850-9-2	SCSM—Sampled values over ISO/IEC 8802-3
IEC 61850-10	Conformance testing

The IEC 61850 document set, available directly from IEC at www.iec.ch, contains information necessary for successful implementation of this protocol. SEL strongly recommends that anyone involved with the design, installation, configuration, or maintenance of IEC 61850 systems be familiar with the appropriate sections of this standard.

IEC 61850 Operation

IEC 61850 and Ethernet networking model options are available when ordering a new relay and may also be available as field upgrades to relays equipped with the Ethernet card. In addition to IEC 61850, the Ethernet card provides support protocols and data exchange, including FTP and Telnet, to SEL devices. Access the relay PORT 5 settings to configure all of the Ethernet settings, including the IEC 61850 network settings.

The relay supports IEC 61850 services, including transport of logical node objects, over TCP/IP. The relay can coordinate a maximum of seven concurrent IEC 61850 MMS sessions.

Object Models

The IEC 61850 standard relies heavily on the Abstract Communication Service Interface (ACSI) models to define a set of services and the responses to those services. In terms of network behavior, abstract modeling enables all IEDs to act identically. These abstract models are used to create objects (data items) and services that exist independently of any underlying protocols. These objects are in conformance with the CDC specification IEC 61850-7-3, which describes the type and structure of each element within a logical node. CDCs for status, measurements, controllable analogs and statuses, and settings all have unique CDC attributes. Each CDC attribute belongs to a set of functional constraints that groups the attributes into specific categories such as status (ST) and description (DC). Functional constraints, CDCs, and CDC attributes are used as building blocks for defining logical nodes. *Table 17.2* shows the CDCs supported in SEL-400 series relays.

Table 17.2 Relay Common Data Classes (Sheet 1 of 2)

CDC Name	Description
Status Information	
SPS	Single point status
DPS	Double point status
INS	Integer status
ENS	Enumerated status
ACT	Protection activation information
ACD	Directional protection activation information

Table 17.2 Relay Common Data Classes (Sheet 2 of 2)

CDC Name	Description
BCR	Binary counter reading
VSS	Visible string status
Measurand Information	
MV	Measured value
CMV	Complex measured value
SAV	Sampled value
WYE	Phase-to-ground/neutral-related measured values of a three-phase system.
DEL	Phase-to-phase-related measured values of a three-phase system
SEQ	Sequence
Status Settings	
SPG	Single point setting
ING	Integer status setting
ENG	Enumerated status setting
ORG	Object reference setting
TSG	Time setting group
CUG	Currency setting group
VSG	Visible string setting
Analog Settings	
ASG	Analog setting
CURVE	Setting curve
Description Information	
DPL	Device name plate
LPL	Logical node name plate
Controls	
SPC	Controllable single point
DPC	Controllable double point
ENC	Controllable enumerated status
INC	Controllable integer status
BSC	Binary controlled step position information
ISC	Integer controlled step position information
APC	Controllable analog process value
BAC	Binary controlled analog process value

The standard describes elements of the power system that use semantic representations. A physical device contains one or more logical devices that contain many logical nodes. A logical node represents a group of data (controls, status, measurements, etc.) associated with a particular function. For example, the MMXU logical node (polyphase measurement unit) contains nonrevenue grade measurement data and other points associated with three-phase metering. Each IED may contain many functions such as protection, metering, and control. Multiple logical nodes represent the functions in multifunction devices.

IEC 61850 devices are capable of self-description. Clients can request descriptions of the data available in an IEC 61850 server. Simply run an MMS browser to query devices on an IEC 61850 network and discover what data are available. Self-description also shows extensions to both standard and custom data models. Instead of having to look up data in a profile stored in its database, an IEC 61850 client can query an IEC 61850 device and receive a description of all logical devices, logical nodes, and available data.

Unlike other SCADA protocols that present data as a list of addresses or indices, IEC 61850 presents data with descriptors in a composite notation made up of components. *Table 17.3* shows how the A-Phase current magnitude expressed as MMXUAphsA$cVal.mag.f is broken down into its component parts.

Table 17.3 Example IEC 61850 Descriptor Components

Component		Description
MMXU	Logical Node	Polyphase measurement unit
A	Data Object	Phase-to-ground amperes
PhsA	Subdata Object	A-Phase
cVal	Data Attribute	Complex value
mag	Subdata Attribute	Magnitude
f	Data type	Float32

Functional Naming

NOTE: Functional naming is not supported by all MMS clients and GOOSE subscribers. Verify support for this feature before configuring functional names in a publishing IED. Earlier SEL-400 series relays firmware that do not support functional naming can subscribe to GOOSE and SV publications from IEDs that use functional naming.

Substation design typically starts with a one-line diagram and progresses down to the assignment of functions to IEDs. In this top-down approach, the functions are identified and named independently from the IEDs to which they are assigned. Because a logical device is a grouping of logical nodes that perform a certain high-level function at a substation, the associated name often indicates the assigned function. The functional naming feature allows users to name a logical device based on the function it provides independent of the name of the IED to which the function is assigned. The alternative is product naming, which prepends the IED name to the logical device instance to create the logical device name. The functional name is used on the communications interface for all references to data in the logical device.

SEL-400 series relays support functional naming of logical devices. You can add functional names in Architect for supported Ed2 relays. To enable it in Architect, navigate to **Edit > Project Settings** and select the **Enable functional name editing on Server Model tab of supporting IEDs** check box, as shown in *Figure 17.1*.

Figure 17.1 Enabling Functional Naming in Architect

To provide functional names to the logical devices, navigate to the Server Model tab for the IED. Because data sets and control blocks are in the CFG logical device, any functional name given to the CFG logical device instance is used in data set references, control block references, and published GOOSE messages, as shown in *Figure 17.2*. The IED Server Model also allows the user to change the default logical node prefix and instance values.

Figure 17.2 Configure Functional Naming in Architect

Data Mapping

Device data are mapped to IEC 61850 LN according to rules defined by SEL. Refer to IEC 61850-5:2013(E) and IEC 61850-7-4:2010(E) for the mandatory content and usage of these LNs. The relay logical nodes are grouped under Logical Devices for organization based on function. See *Table 17.4* for descriptions of the logical devices in a relay. See *Logical Nodes on page 17.53* for a description of the LNs that make up these logical devices.

Table 17.4 Relay Logical Devices

Logical Device	Description
CFG	Configuration elements—data sets and report control blocks
PRO	Protection elements—protection functions and breaker control
MET	Metering or Measurement elements—currents, voltages, power, etc.
CON	Control elements—remote bits
ANN	Annunciator elements—alarms, status values
MU[a]	Merging unit elements—voltage and current channels

[a] This only applies to merging units.

Architect Flexible Server Model (FSM)

Architect provides an interface to build custom ICD files for Ed2.1 devices that have ICD files ClassFileVersion 010 or later. SEL devices have a default ICD file available in Architect, but you may need to add IEC 61850 optional objects to the default logical nodes or add additional logical nodes based on your application.

You may need to customize the SCL server model of a device to model functions configured in SELOGIC control equations, and then make them available through MMS or GOOSE. Various functions, such as automatic tap changer control, gas alarm for GIS, etc., can be configured in SELOGIC programming but require specific customization to implement in IEC 61850.

For example, the SIML logical node models insulation medium supervision (liquid). Transformers or tap changers use oil as an insulator, and sensors or measuring devices can be wired to relay contact inputs. Because the connection of these sensors to a device are application-specific, they are not included in the default ICD file. The FSM provides an interface to add and customize the SIML logical node.

Begin by adding a device to the Project Editor in Architect and selecting an existing ICD file (ClassFileVersion 010 or later). Select the **Server Model** tab to view the logical devices, logical nodes, and data objects that exist in the default ICD file. Although logical nodes can be added to an existing logical device, SEL recommends adding a new logical device for custom logical nodes. If SEL releases new logical nodes or features in the future, the merge operation between default and custom files is less prone to the inadvertent removal of the custom logical nodes.

The default ICD file in this example contains five logical devices: CFG, PRO, MET, CON, and ANN. To add a logical device, select the **+ Add LDevice** button in the logical device pane. Provide an instance name for the new logical device. The new logical device is named XFMR, as shown in *Figure 17.3*.

Figure 17.3 Server Model View in Architect

Every logical device contains an LLN0 or common logical node that provides common information. To add another logical node, either right-click in the logical node pane or select the **+ Add LN button**. This opens a pop-up window that contains a list of logical nodes that are present in the Architect Library. There may be more than one variant of each logical node, where each variant may have different data objects included. In this case, only one SIML logical node is added to this file (see *Figure 17.4*).

Figure 17.4 Add a Logical Node From the Architect Library

Once the logical node is added to the logical device, select the logical node, which will display the data objects available in the data object pane (see *Figure 17.5*). Add the TmpAlm and GasInsAlm objects by selecting the box to the left of the attribute name. Each object conforms to a particular CDC defined for that object in the IEC 61850 standard. In this example, both TmpAlm and GasInsAlm are single point status (SPS) data objects. *Table 17.2* lists the CDCs supported by the SEL-400 series relays.

Figure 17.5 Add Data Objects to a Logical Node

Each object contains a list of attributes. TmpAlm, when expanded, lists the associated attributes. In this example, the temperature alarm is wired to Input 6 on I/O Card 2, which is represented by Relay Word bit IN206. The association between the TmpAlm.stVal (status value) and IN206 must be made by entering the Relay Word bit name after the db prompt in the RWB/AQ column, as shown in *Figure 17.6*.

Figure 17.6 Associate a Data Attribute's Value to a Relay Variable

If desired, other logical nodes can be added to the new XFMR logical device. Save the configuration of the project and device. The new logical node objects and attributes are available to add to data sets that may be sent in a GOOSE message or added to a report, as shown in *Figure 17.7*.

Figure 17.7 Data Set Mapping From an FSM Created Attribute

MMS

MMS provides services for the application-layer transfer of real-time data within a substation LAN. MMS was developed as a network-independent data exchange protocol for industrial networks in the 1980s and standardized as ISO 9506.

In theory, you can map IEC 61850 to any protocol. However, it can become unwieldy and quite complicated to map objects and services to a protocol that only provides access to simple data points via registers or index numbers. MMS supports complex named objects and flexible services that enable mapping to IEC 61850 in a straightforward manner. This was why the UCA users group used MMS for UCA from the start and why IEC chose to keep it for IEC 61850. MMS associations are discussed within IEC61850-8-1, Clause 10 of the Ed1 standard.

If MMS authentication is enabled, the device will authenticate each MMS association by requiring the client to provide the password authentication parameter with a value that is equal to the Access Level 2 password of the relay.

- ➤ If the correct password authentication parameter value is not received, the device will return a not authenticated error code. If a user attempts to log in to the relay with three consecutive invalid login attempts within a 1-minute period, the relay will disable login requests for 30 seconds and pulse the SALARM and BADPASS Relay Word bits.
- ➤ If the correct password authentication parameter value is received, the device will provide a successful association response. The device will allow access to all supported MMS services for that association.

Control

IEC 61850 Controls

An IEC 61850 server may allow a client to manipulate data related to its outputs, external devices, or internal functions. This is accomplished by the IEC 61850 control model, which provides services to execute control commands. The control models are defined in IEC 61850-7-2 and the mapping to the MMS application protocol is defined in IEC 61850-8-1. The former describes control functionality while the latter maps the IEC 61850 control primitives to MMS.

The SEL-400 series relays support four different control models for all controllable CDCs defined in IEC 61850-7-3:

- Status only
- Direct with Normal Security
- Direct with Enhanced Security
- SBO with Enhanced Security

One control model must be selected during the initial IED configuration in Architect and be applied throughout the CID file. This control model applies to all controls in the IED. For CID files created from an ICD file with ClassFileVersion 010 or later, Architect allows modifying the control model on a per-control basis if a different control model is required other than the one selected during initial IED configuration.

Firmware that supports Ed2.1 and ClassFileVersion 010 or later supports pulsing the SPC and DPC control models as defined in IEC 61850-7-3 by configuring pulseConfig attributes cmdQual, onDur, offDur, and numPls.

Direct Control Models

The direct control models provide the simplest means to initiate actions on the server. In these models, the client issues a control request via MMS and the server validates the request. Once validated, the server attempts to act upon the request. Note that if multiple clients try to perform control actions, the server does nothing to prevent the simultaneous control actions.

SBO Control Model

The SBO control model supports the SelectWithValue Service and can be used to prevent multiple clients from performing simultaneous control actions. In this mode, a client has to “reserve” the control object by sending a “select” control command. Once an object is selected, only the client that made the selection is allowed to perform control actions on it. If that client does not send a valid operate request for the object by the time the select time-out runs out, the object becomes available for selection again. The relay supports as many as ten pending control object selections at any time.

NOTE: When an IED is configured with the SBO with Enhanced Security control model, the sboTimeout attribute of the controllable CDCs in the CID file is set to ten seconds. This time-out is not configurable via Architect.

The attribute stSeld (selected status) of the controllable CDC is set to TRUE when a client successfully selects the control object. The attribute is reset to FALSE when either the control (operate) command is successfully executed, an error occurs, or no operate command is received within the select time-out period. The stSeld attribute may trigger a report just like any data attribute with trigger option.

Security in Control Models

"Security" in the control model context refers to additional supervision of the status value by the control object. The enhanced security models report additional error information on failed operations to the requesting client unlike the models with normal security. Enhanced security control models provide a command termination report indicating if the control actually reached the new state as commanded within a configurable time-out period.

NOTE: The maximum time required for a control operation to be completed should be less than the configured time-out period to avoid erroneous command termination reports indicating failure.

The time-out period between the execution of a control and the generation of a command termination report indicating failure has a default value of 1 s and is configurable via the CID file. This time out is not configurable via Architect.

Optional Control Configurations

The SEL-400 series relays that support Ed2.1 and ClassFileVersion 010 or later support the pulse configuration option specified in Clause 6.7 of IEC 61850-7-3. For relays that do not support Ed2.1, some control logical nodes are available that pulse the control for one processing interval.

Controls that can be configured for pulse operations, such as the SPCSO data objects in the RBGGIO logical nodes, contain a pulseConfig constructed data attribute type.

The cmdQual data attribute of an SPC control defines whether the control will be persistent or pulsed. For DPC, only the pulse operation is supported.

- If cmdQual = pulse (0), the control object pulses according to the onDur, offDur and numPls attributes. The control object pulses for one processing interval when cmdQual = pulse, onDur = 0, offDur = 0, and numPls = 1.

  Figure 17.8 shows an example of how onDur, offDur, and numPls are used when the control is pulsed.

Figure 17.8 Pulse Behavior in Control Operations

- If cmdQual = persistent (1), the control object sets when the command writes TRUE and clears when it writes FALSE.
- cmdQual = persistent-feedback (2) is not supported.

Use Architect to configure a control to pulse by selecting a controllable data object (such as a remote bit), selecting the Control Configuration tab, and setting the pulseConfig.cmdQual to pulse (see *Figure 17.9*). Setting pulseConfig.cmdQual allows changes to the onDur, offDur, and numPls attributes.

Figure 17.9 Configure Pulse Control Attributes

Control Interlocking

The IEC 61850 standards make provision for control object interlocking, and the IEC 61850-7-4 standard explains how this is performed using the CILO logical node. The CILO logical node has two data objects, namely Enable Open (EnaOpn) and Enable Close (EnaCls), for each breaker or disconnect control object.

NOTE: The IEC 61850 CILO interlocking function does not affect controls sent by any other protocols or local front-panel operations.

The SEL-400 series relays use control interlocking to supervise the open and close control commands from MMS clients. The relay accomplishes this by checking each CSWI logical node control object against an associated CILO logical node data object. When the associated CILO logical node EnaCls and EnaOpn data objects are not asserted, the relay blocks the control operation and sends the AddCause "Blocked-by-interlocking" to the MMS client.

Table 17.5 defines how control interlocking is implemented in the CILO logical node.

Table 17.5 CILO Logical Node EnaOpn and EnaCls Equations

CILO LN Data Object	Data Source	Data Source Equation
EnaCls	BKENC*n*[a]	NOT SCBK*n*BC[a]
EnaOpn	BKENO*n*[a]	NOT SCBK*n*BO[a]
EnaCls	89ENC*mm*[b]	NOT (89CBL*mm* OR 89OPE*mm*)[b]
EnaOpn	89ENO*mm*[b]	NOT (89OBL*mm* OR 89CLS*mm*)[b]

[a] n = Breaker terminal.
[b] mm = Disconnect switch number.

SCBK*n*BO and SCBK*n*BC are SELOGIC control equations. Program these equations in the Protection SELOGIC setting (SET L) to block breaker operation. Program the 89CBL*mm* and 89OBL*mm* SELOGIC control equations in the Bay settings (SET B) to block disconnect operation.

Figure 17.10 CSWI Logical Node Direct Operate Command Request

Figure 17.10 shows how the relay responds to CSWI logical node command requests from MMS Clients when IEC 61850 control interlocking is applied. The SBO control model performs the same check when the select control command is received and again when the operate control is received.

Local/Remote Control Authority

Control commands at a substation originate from one of three levels: remote (network control center), station, or bay. Under certain operational conditions (e.g., during maintenance), you may need to block control commands from one or more of these levels. The local/remote control feature allows you to enable or disable control authority at any of the three levels. The level at which a control command originates is determined by the value of the origin.orCat (originator category) attribute in the command. *Table 17.6* describes the different orCat values defined in IEC 61850-7-2.

Table 17.6 Originator Categories

Originator Category	Value
not-supported	0
bay-control	1
station-control	2
remote-control	3
automatic-bay	4
automatic-station	5
automatic-remote	6
maintenance	7
process	8

The SEL-400 series relays support the local/remote control feature defined in IEC 61850-7-4. The feature is supported at the IED level and the logical node level with identical and configurable attributes in the LLN0 logical node in each logical device and in CSWI logical nodes. *Table 17.7* describes the attributes and their data sources in various logical nodes.

Table 17.7 Control Authority Attributes

Logical Node	Attribute	Data Source	Description
LLN0	Loc.stVal	LOC	Control authority of the IED at local (bay) level
	LocKey.stVal	NOOP	Physical key or toggle switch indication for switching IED in local mode
	LocSta.stVal	LOCSTA	Control authority of the IED at station level
	MltLev.setVal	MLTLEV	Multi-level control authority
CSWI	Loc.stVal	LOC	Control authority of the switch controller at local (bay) level
	LocKey.stVal	NOOP	Physical key or toggle switch indication for switching switch controller LN in local mode
	LocSta.stVal	LOCSTA	Control authority of the switch controller at station level
XCBR/XSWI	Loc.stVal	LOCAL	Switchgear local/remote status
	LocKey.stVal	NOOP	Physical key or toggle switch indication for switchgear local mode

You can control the Relay Word bits LOC, LOCAL, LOCSTA, and MLTLEV through SELOGIC control equations. LOCSTA is set to True when the SELOGIC control equation SC850LS asserts and is set to False when SC850LS deasserts. LOCSTA can also be controlled through MMS, but if LOCSTA is set to True through SELOGIC control equations, it cannot be set to False through MMS. The LocKey data objects are set to NOOP by default as a placeholder. The data source of the LocKey data object can be changed depending on application requirements.

The IED-level local/remote behavior can be changed using the following methods:

- The value of the LOC Relay Word bit is changed through a SELOGIC control equation.
- If the system is equipped with a physical key or a toggle switch for controlling the local/remote status of the entire IED, the data source of CFG.LLN0.LocKey.stVal can be configured to indicate the binary input to which the physical key is wired.

Similarly, the switchgear local/remote behavior can be changed using the following methods:

- The value of the LOCAL Relay Word bit is changed through a SELOGIC control equation. Asserting the LOCAL Relay Word bit changes the XCBR and XSWI logical nodes to local mode. This blocks all control commands to the associated CSWI logical nodes.
- If a switchgear has a physical local/remote control switch, the data source of XCBR.LocKey.stVal can be configured to indicate the binary input to which the physical key is wired.

The MLTLEV SELOGIC control equation allows you to define whether multiple levels of control authority are allowed. If MLTLEV is FALSE, only one level of control authority is allowed to control the switchgear, as shown in *Table 17.8*.

Table 17.8 Control Authority Settings–MLTLEV Set to FALSE[a] (Sheet 1 of 2)

Switchgear Local/ Remote Behavior	Local Control Behavior	Control Authority at Station Level	orCat Value		
XCBR.Loc XSWI.Loc	CSWI.Loc	CSWI.LocSta	Bay (1 or 4)	Station (2 or 5)	Remote (3 or 6)
T	X	X	NA	NA	NA
F	T	X	AA	NA	NA

Table 17.8 Control Authority Settings–MLTLEV Set to FALSE[a] (Sheet 2 of 2)

Switchgear Local/ Remote Behavior	Local Control Behavior	Control Authority at Station Level	orCat Value		
XCBR.Loc XSWI.Loc	CSWI.Loc	CSWI.LocSta	Bay (1 or 4)	Station (2 or 5)	Remote (3 or 6)
F	F	T	NA	AA	NA
F	F	F	NA	NA	AA

[a] T = True (asserted)
F = False (deasserted)
X = Do not care (True or False)
AA = Command is allowed
NA = Command is not allowed

If MLTLEV is TRUE, multiple levels of control authority are allowed to control the switchgear, as shown in *Table 17.9*.

Table 17.9 Control Authority Settings–MLTLEV Set to TRUE[a]

Switchgear Local/ Remote Behavior	Local Control Behavior	Control Authority at Station Level	orCat Value		
XCBR.Loc XSWI.Loc	CSWI.Loc	CSWI.LocSta	Bay (1 or 4)	Station (2 or 5)	Remote (3 or 6)
T	X	X	NA	NA	NA
F	T	X	AA	NA	NA
F	F	T	AA	AA	NA
F	F	F	AA	AA	AA

[a] T = True (asserted)
F = False (deasserted)
X = Do not care (True or False)
AA = Command is allowed
NA = Command is not allowed

Control Requests

IEC 61850 control services are implemented by reading and writing to pseudo-variables in the relay in response to MMS requests. Similar to how client requests are generated and mapped to MMS read or write service requests, server actions are also mapped to internal commands, read and write actions, and MMS information report messages. In the case of an unsuccessful control request, the relay sends the appropriate response PDU indicating that there was a problem and an MMS information report that contains more detailed information about the problem that occurred.

When writing controls, the client must select and write the entire Oper, SBOw or Cancel structure to the relay. See *Figure 17.11* for the attributes of the CON logical device and the ST and CO functional constraints (FC) of LN RBGGIO1 used for control of RB01 through RB08.

Figure 17.11 MMS Client View of the CON Logical Device

Control Error Messages

If a control request results in an error condition, the relay responds with an AddCause value in an MMS information report. See Clause 20.5.2.9 of IEC 61850-7-2 for additional information on the AddCause values.

The SEL-400 series relays support the AddCause values in *Table 17.10* as part of the LastApplError information report.

Table 17.10 AddCause Descriptions

AddCause Enumeration	AddCause Description	Error Condition
0	Unknown	No other AddCause value defined within this section applies
2	Blocked-by-switching-hierarchy	Logical node is set to local mode, i.e., Loc.stVal = true
3	Select-failed	Originator category not allowed to issue control commands or SelectWithValue operation fails
4	Invalid-position	For controls with enhanced security, an AddCause of “Invalid-position” (4) will be sent if the control status changes to an unexpected value. If no control status change is detected after the operate time-out period, an AddCause of “Time-limit-over” (16) will be sent.
5	Position-reached	Control status is already at the desired state
6	Parameter-change-in-execution	Control object is already selected by the client, and 1. Logical node is set to local mode i.e., Loc.stVal = true, or 2. Originator category not allowed to issue control commands
8	Blocked-by-mode	Mode of logical device or node is not ON
10	Block-by-interlocking	Selection of switch device failed due to interlock check
12	Command-already-in-execution	Execution of a previous control is not completed
13	Blocked-by-health	Health of logical device or node is not OK
16	Time-limit-over	CommandTermination gives a negative response. (The control failed to reach its intended state prior to time-out.)
18	Object-not-selected	Cancel operation fails
20	No-access-authority	Control action is blocked due to lack of access authority

Any AddCause value not specified above is not supported. Control CDC data attributes that are associated with unsupported AddCause values and are not part of a control structure will be accepted but ignored. For example, the attribute CmdBlk.stVal, which is associated with the AddCause value "blocked-by-command" and is not part of a SBOw, Oper, or Cancel structure, will be ignored.

Group Switch Via MMS

The group switch feature in IEC 61850 is primarily a convenience feature for users so that they can institute a settings group switch from an IEC 61850 client without having to revert to the command line or some other tool. However, this has great potential for integration with IEC 61850 SCADA systems that would be able to control setting groups through IEC 61850 MMS.

The IEC 61850 specification outlines a method for switching the current settings group to another preconfigured settings group. The setting group control block, or SGCB, contains the SettingControl element that enables settings group control. The SEL-400 series relays require the minimum versions of the firmware and ICD files to enable the SGCB. Refer to Appendix A in the product-specific manuals for supported firmware and ICD versions. In the IEC 61850 standard, SGCB class includes an attribute for the active settings group, or ActSG, as a read/write attribute. The ActSG is a read-only attribute in SEL-400 series relays. Adding the ActSG attribute with a value to the SettingControl element of the ICD file results in the relay ignoring the value and continuing to use the existing active settings group when the ICD file is downloaded.

When the IEC 61850 functions of the relay are enabled, the selectActiveSG service allows an MMS client to request that the relay change the active setting group. The MMS client can request a group switch by writing a valid setting group number to ActSG. The relay updates the ActSG value under the following conditions:

- The value written to ActSG is valid and not the current active group
- There is no group switch in progress
- The setting of the active group was successful.

Note that if the value written to ActSG is the same as the current group, the relay will not attempt to switch settings groups. Refer to *Multiple Setting Groups on page 12.4* for more information on Group settings.

Service Tracking

The IEC 61850 standard defines many services to be provided by an IED (server). These services include control services, reporting services, logging services, and group switch control services. IEC 61850 Ed2 defines the service tracking feature to allow these services to be reported or logged, whether they succeed or fail.

SEL-400 series relays support the service tracking feature for control commands, report control block edits, and group switch selection. You can report these services.

Tracking of these services is enabled by data objects in the service tracking logical node LTRK. *Table 17.11* lists the service tracking data objects. Their data attributes mirror those in the service request or in the control block that was the target of the service request.

Table 17.11 Service Tracking Data Objects

Data Object	CDC	Description
SpcTrk	CTS	Tracks control service requests targeted at a controllable single-point object
DpcTrk	CTS	Tracks control service requests targeted at a controllable double-point object
EncTrk	CTS	Tracks control service requests targeted at a controllable enumerated status object
UrcbTrk	UTS	Tracks unbuffered report control block edits
BrcbTrk	BTS	Tracks buffered report control block edits
SgcbTrk	STS	Tracks active settings group selection

Refer to *Table 17.28* for information regarding the available attributes in each tracking data object.

Each tracking data object includes the data attributes objRef, serviceType, and errorCode. The attribute objRef provides the reference to the control object or control block instance that was the target of the service request. The attribute serviceType provides an enumerated value for the specific service requested or executed. *Table 17.12* defines the service type enumerations.

Table 17.12 IEC 61850 Service Type Enumeration

Service Type	Service Name	Description
16	SelectActiveSG	Active settings group switch request
24	SetBRCBValues	Write request on one or more of the following buffered report control block attributes: RptID, RptEna, OptFlds, BufTm, TrgOps, IntgPd, PurgeBuf, EntryID, or GI
26	SetURCBValues	Write request on one or more of the following unbuffered report control block attributes: RptID, RptEna, OptFlds, BufTm, TrgOps, IntgPd, Resv, or GI
44	SelectWithValue	Select control request
45	Cancel	Cancel control request
46	Operate	Operate control request
47	CommandTermination	Control processing completed on a control object configured with enhanced security control model
54	InternalChange	Report control block has been automatically disabled, i.e., RptEna is set to False after a loss of association with the client

The attribute errorCode provides the error code that indicates whether the service was successful or unsuccessful. The codes are listed in *Table 17.13* together with the corresponding ACSI errors.

Table 17.13 IEC 61850 ACSI Service Error (Sheet 1 of 2)

Error Code	ACSI Error
0	no-error
1	instance-not-available
3	access-violation
5	parameter-value-inappropriate
6	parameter-value-inconsistent
7	class-not-supported
8	instance-locked-by-other-client
10	type-conflict

Table 17.13 IEC 61850 ACSI Service Error (Sheet 2 of 2)

Error Code	ACSI Error
11	failed-due-to-communications-constraint
12	failed-due-to-server-constraint

When creating data sets to track the services through information reporting, it is important to include the tracking data objects as a whole object (FCD—functionally constrained data), and not as individual data attributes (FCDA—functional constrained data attribute). Only the objRef attribute has a trigger option (dupd—data update) and can trigger a report. The dupd trigger option must also be enabled in the report control block that is reporting changes in the tracking data objects.

File Services

The Ethernet file system allows reading or writing data as files. The file system supports FTP and MMS file transfer. The file system provides:

- A means for the device to transfer data as files.
- A hierarchal file structure for the device data.

The relay supports MMS file transfer with or without authentication. Note that the MMS File Transfer service will still be supported even if the relay contains an invalid CID file. The service is intended to support:

- Settings file download and upload
- CID file download and upload
- Event report retrieval

MMS File Services are enabled or disabled via the PORT 5 settings, EMMSFS. Permissions for the Access Level 2 apply to MMS File Services requests. All files and directories that are available at the Access Level 2 via any supported file transfer mechanism (FTP, file read/write, etc.) are also available for transfer via MMS File Services.

SCL Files

Substation Configuration Language (SCL) is an XML-based configuration language used to support the exchange of database configuration data between different tools, which may come from different manufacturers. There are four types of SCL files:

- IED Capability Description (.ICD) file
- System Specification Description (.SSD) file
- Substation Configuration Description (.SCD) file
- Configured IED Description (.CID) file

The ICD file describes the capabilities of an IED, including information on LN and GOOSE support. The SSD file describes the single-line diagram of the substation and the required LNs. The SCD file contains information on all IEDs, communications configuration data, and a substation description. The CID file, of which there may be several, describes a single instantiated IED within the project and includes address information.

Reports

IEC 61850 provides two classes of reporting services, unbuffered and buffered, that a client can use to receive event data from a server. The unbuffered report service provides event data on a best-effort basis only while the client is connected. In contrast, the buffered report service keeps an internal buffer of events, which ensures that clients can receive a sequence of events even after reconnecting following a lost connection. The relay supports unbuffered and buffered report control blocks in the report model as defined in IEC 61850-8-1:2020.

IEC 61850 servers can deliver the same event data to multiple clients. IEC 61850 Ed1 proposed two different approaches that a server could use to accomplish this: association-based (non-indexed) reports and indexed reports. As of Ed2.1, SEL-400 series relays support both methods. The relay supports as many as 14 report control blocks (7 each of unbuffered and buffered reports). Reports can be either configured as association-based reports or indexed reports. Configuring a mix of association-based reports and indexed reports is not allowed, and such a configuration will be rejected by the IED. SEL devices with ClassFileVersion 009 or earlier support only association-based reports. Devices that are ClassFileVersion 010 or later support association-based reports as well as indexed reports.

ICD files with ClassFileVersion 009 or earlier only support dynamic report reservations. Writing to ResvTms of the buffered report control block (BRCB) or Resv of the unbuffered report control block (URCB) causes the client to dynamically obtain a reservation. ICD files with ClassFileVersion 010 support both preconfigured report reservations and dynamic reservations.

Reports are serviced at a 2 Hz rate. The client can set the IntgPd to any value with a resolution of 1 ms. However, the integrity report is only sent when the period has been detected as having expired. The report service rate of 2 Hz results in a report being sent within 500 ms of expiration of the IntgPd. The new IntgPd begins at the time that the current report is serviced.

When you are configuring unbuffered and buffered reports that contain only analog values, a data change report only is triggered when there is a change in the magnitude value in excess of the deadband setting. When you are configuring unbuffered and buffered reports that contain a combination of digital and analog values, any digital value change triggers a data change report, which contains the current value of the analogs contained in the report at the time of the trigger.

Unbuffered Reports

By using Architect, you can define if the URCB should be association-based or indexed. You can allocate data within each report data set to present different data attributes for each report. For unbuffered reports, connected clients may edit the report parameters shown in *Table 17.14*.

Table 17.14 Unbuffered Report Control Block Client Access (Sheet 1 of 2)

RCB Attribute	User Changeable (Report Disabled)[a]	User Changeable (Report Enabled)	Default Values
RptID	YES		URep01–URep07
RptEna	YES	YES	FALSE

Table 17.14 Unbuffered Report Control Block Client Access (Sheet 2 of 2)

RCB Attribute	User Changeable (Report Disabled)[a]	User Changeable (Report Enabled)	Default Values
Resv	YES		Association-based reports: Resv = FALSE for all URCB instances if none is preconfigured for any client Resv = TRUE for all URCB instances if one or more are preconfigured for a client Indexed reports: Resv = FALSE for the specific URCB instance if it is not preconfigured for any client Resv = TRUE for the specific URCB instance if it is preconfigured for a client
OptFlds	YES		seqNum
			timeStamp
			dataSet
			reasonCode
BufTm	YES		250
TrgOps	YES		dchg
			qchg
			period
IntgPd	YES		0
GI		YES[b]	FALSE
Owner			If the ReportControl has a single preconfigured client and its IP address can be found in the SCL, the IP address of the client is used as the default value for Owner; otherwise, the default value is NULL.

[a] The report must be actively reserved by setting Resv to 1 before the attribute values can be changed.
[b] Exhibits a pulse behavior. Write a one to issue the command. Once command is accepted will return to zero. Always read as zero.

Resv indicates the report reservation for unbuffered reports. Clients must actively reserve the URCB by setting Resv to 1 before the report can be enabled. This is applicable to preconfigured SCL clients as well. A successful write to Resv results in the Owner attribute being updated to the IP address of the client that performed the write operation. When the MMS client disables the URCB by setting RptEna to FALSE and actively unreserves it by setting Resv to 0, the report is immediately available for write operations.

Association-Based (Non-Indexed) URCBs

In association-based URCBs, the relay provides a unique URCB instance for each client association. Each client sees a different instance, although all instances have the same URCB name. This results in multiple client associations for that URCB. Once enabled, each client has independent access to an instance of that URCB. The server automatically ensures that a URCB instance is available to each client. SEL first offered association-based URCB support in the IEC 61850 Ed1 release of the relay.

The relay supports 7 association-based URCBs and 7 simultaneous clients, resulting in a total of 49 URCB instances, because each client views a different instance.

For example, if an association-based URCB is named UrcbA, seven clients can get independent access to UrcbA.

Indexed URCBs

In indexed URCBs, the server provides multiple URCB instances with all instances visible to all clients. Because all clients can see all instances, each instance must have a unique name. The report name is appended with a two-digit number *nn*, where *nn* ranges from 01 to the maximum number of instances supported for that control block. This allows a client to view all instances of a report control block, unlike association-based reports, where each client can only view the instance to which it is connected. Clients can reserve an instance by using the URCB Resv attribute. To prevent conflicts between clients, Ed2 introduced the concept of pre-configured reservations.

The relay added support for as many as 49 indexed URCB instances as a part of the IEC 61850 Ed2.1 release of the relay.

Each report control block has seven instances available to connect to when a URCB is configured as indexed. For example, if UrcbA is configured as indexed, a client can connect to any of the instances named UrcbA*xx*, where *xx* = 01–07.

Buffered Reports

By using Architect, you can define if the BRCB should be association-based or indexed. You can allocate data within each report data set to present different data attributes for each report. For buffered reports, connected clients can edit the report parameters shown in *Table 17.15*.

Table 17.15 Buffered Report Control Block Client Access (Sheet 1 of 2)

RCB Attribute	User Changeable (Report Disabled)[a]	User Changeable (Report Enabled)	Default Values
RptID	YES		BRep01–BRep07
RptEna	YES	YES	FALSE
OptFlds	YES		seqNum
			timeStamp
			dataSet
			reasonCode
			entryID
BufTm	YES		500
TrgOps	YES		dchg
			qchg
			period
IntgPd	YES		0
GI	YES[b, c]	YES[a]	0
PurgeBuf	YES[b]		FALSE
EntryId	YES		0

Table 17.15 Buffered Report Control Block Client Access (Sheet 2 of 2)

RCB Attribute	User Changeable (Report Disabled)[a]	User Changeable (Report Enabled)	Default Values
ResvTms	YES		–1 if the BRCB instance is preconfigured for a specific client in the SCL 0 if the BRCB instance is not reserved 60 if the report has been reserved with a write value of 0
Owner			NULL if the BRCB instance is not preconfigured or the IP address of the client in the SCL if it is preconfigured or dynamically assigned

[a] The report must be actively reserved by setting ResvTms > 0 before the attribute values can be changed.
[b] Exhibits a pulse behavior. Write a one to issue the command. Once command is accepted will return to zero. Always read as zero.
[c] When disabled, a GI will be processed and the report buffered if a buffer has been previously established. Buffered reports begin buffering at startup.

ResvTms indicates the report reservation time for buffered reports. Clients must actively reserve the BRCB by setting ResvTms to a value greater than 0 before the report can be enabled. This is applicable to preconfigured SCL clients as well. A successful write to ResvTms results in the Owner attribute being updated to the IP address of the client that performed the write operation. When the MMS client disables the BRCB by setting RptEna to FALSE and actively unreserves it by setting ResvTms to 0, the report is immediately available for write operations. After the ResvTms duration elapses, ResvTms reverts to 0 for dynamic associations, indicating the control block is available to other clients.

Association-Based (Non-Indexed) BRCBs

When a BRCB is configured as association-based or non-indexed, only one client can enable the BRCB at a time, which results in a client association for that BRCB. Once enabled, the associated client has exclusive access to the BRCB until the connection is closed or the BRCB is unreserved. Once enabled by a client, all unassociated clients have read-only access to the BRCB. SEL first offered association-based BRCB support in the IEC 61850 Ed1 release of the relay. For example, if an association-based BRCB is named BrcbA, a client can connect to the report with name BrcbA.

Indexed BRCBs

In indexed BRCBs, the server provides multiple BRCB instances with all instances visible to all clients. The report name is appended with a two-digit number *nn*, where *nn* ranges from 01 to the maximum number of instances supported for that control block. This allows a client to view all instances of a report control block. Clients can reserve an instance by using the BRCB ResvTms attribute.

The relay supports seven indexed BRCB instances as part of the IEC 61850 Ed2.1 release of the relay.

Only one instance of the report control block is available to connect to when a BRCB is configured as indexed. For example, if BrcbA is configured as indexed in Architect, a client connects to the report with name BrcbA01.

Data Sets

IEC 61850 data sets are lists of references to DataObject attributes for the purpose of efficient observation and transmission of data. Use Architect to configure data sets to be used to transfer data via GOOSE messages, SV messages, or MMS reports.

- GOOSE: You can create data sets for outgoing GOOSE transmission.
- SV: Predefined data sets are provided. Each data set includes three phase currents and the neutral current as well as three phase voltages and the neutral voltage.
- Reports: You can create data sets that are linked to buffered and unbuffered reports.

Deadband

Analog values of the MV, CMV, APC, and BAC CDCs defined in IEC 61850-7-3 have associated deadbands that determine when the analog values should be updated. The MV and CMV analog objects contain attributes that reflect the instantaneous value of the magnitude (instMag) and the value of the magnitude (mag), which is updated based on the deadband calculation.

Deadband calculations in Ed1 and Ed2 use a percent multiplier and the maximum range. The percent multiplier, a number between 0 and 100,000, is multiplied by 0.001 percent to determine the percentage of the maximum range to use as a deadband. Architect handles these calculations in the background, enabling users to configure the deadbands using nominal values. *Figure 17.12* displays the view from the Deadband tab in Architect for both Ed1 and Ed2 implementations.

Figure 17.12 Deadband Configuration View for Ed1 and Ed2

Ed2.1 introduced deadband-related attributes, dbRef, dbAngRef, zeroDb, and zeroDbRef to explicitly expose the deadband behavior. The attribute dbRef may have a value of 0, which means the value db is used as the percentage of the last transmitted value in units of 0.001 percent. If the dbRef value is less than 0, it means db represents the percentage of dbRef in units of 0.001 percent and is appropriate for values with constant or small-changing values, for example frequency. The zeroDb attribute is the configuration parameter used to calculate the range around zero where the deadbanded value mag is forced to zero. The value of zeroDb represents the percentage of zeroDbRef in units of 0.001 percent.

For ICD files with ClassFileVersion 010 or higher, use Architect to view and configure the deadbands for analog values. The configuration values for the parameters shown in *Figure 17.13* are editable, and Architect displays the resulting deadband value.

Figure 17.13 Deadband Configuration View for Ed2.1

Supplemental Software Support

Examine the data structure and values of the supported IEC 61850 LNs with an MMS browser such as MMS Object Explorer and AX-S4 61850 from Sisco, Inc.

The settings needed to browse the relay with an MMS browser are shown below.

OSI-PSEL (Presentation Selector)	00000001
OSI-SSEL (Session Selector)	0001
OSI-TSEL (Transport Selector)	0001

Time Stamps and Quality

In addition to the various data values, the two attributes quality and t (time stamp) are available at any time. The time stamp is determined when data or quality change is detected. A change in the quality attribute can also be used to issue an internal event.

The time stamp is applied to all data and quality attributes (Boolean, Bstrings, analogs, etc.) in the same fashion when a data or quality change is detected. However, there is a difference in how the change is detected between the different attribute types. For points in a data set that are also listed in the SER, the change is detected by the SER process. For all other Booleans or Bstrings, the change is detected via the scanner, which compares the last state against the previous state to detect the change. For analogs, the scanner looks at the amount of change relative to the deadband configured for the point to indicate a change and apply the time stamp. In all cases, these time stamps are used for the reporting model.

LN data attributes listed in the SER will have SER time stamps of 1 ms accuracy for data change events. All other LN data attributes are scanned on a 1/2-second interval for data change and have 1/2-second time-stamp accuracy.

The relay uses GOOSE quality attributes to indicate the quality of the data in its transmitted GOOSE messages. Under normal conditions, all attributes are zero, indicating good quality data. *Figure 17.14* shows the GOOSE quality attributes available to devices that subscribe to GOOSE messages from relay data sets that contain them. Internal status indicators provide the information necessary for the device to set these attributes. For example, if the device becomes disabled, as shown via status indications (e.g., an internal self-test failure), the relay will set the Validity attribute to INVALID and the Failure attribute to TRUE. Note that the relay does not set any of the other quality attributes. These attributes will always indicate FALSE (0). See the Architect online help for additional information on GOOSE quality attributes.

Figure 17.14 GOOSE Quality Attributes

GOOSE

The Generic Object Oriented Substation Event (GOOSE) object within IEC 61850 is for high-speed control messaging. IEC 61850 GOOSE automatically broadcasts messages containing status, controls, and measured values onto the network for use by other devices. IEC 61850 GOOSE sends the message several times, increasing the likelihood that other devices receive the messages.

IEC 61850 GOOSE objects can quickly and conveniently transfer status, controls, and measured values between peers on an IEC 61850 network. Configure SEL devices to respond to GOOSE messages from other network devices with Architect. Also, configure outgoing GOOSE messages for SEL devices in Architect. See the Architect online help for more information.

Each IEC 61850 GOOSE sender includes a text identification string (GOOSE Control Block Reference) in each outgoing message and an Ethernet multicast group address. Devices that receive GOOSE messages use the text identification and multicast group to identify and filter incoming GOOSE messages.

Virtual bits (VB001–VB256) are control inputs that you can map to values from incoming GOOSE messages by using the Architect software. See the VB*nnn* bits in *Table 17.28*, *Table 17.29*, and *Table 17.30* for details on which logical nodes and names are used for these bits. This information can be useful when searching through device data with MMS browsers. If you intend to use any relay virtual bits for controls, you must create SELOGIC control equations to define these operations. The relay is capable of receiving and sending analog values via peer-to-peer GOOSE messages. Remote analogs (RA001–RA256) are analog inputs that you can map to values from incoming GOOSE messages. Remote analog outputs (RAO01–RAO64) can be used to transmit analog values via GOOSE messages. You must create SELOGIC control equations to assign internal relay values to RAO points to transmit them via GOOSE.

GOOSE Processing

SEL devices support GOOSE processing as defined by IEC 61850-7-1:2011(E), IEC 61850-7-2:2010(E), and IEC 61850-8-1:2011(E) via the installed Ethernet port.

Outgoing GOOSE messages are processed in accordance with the following constraints.

- The user can define as many as eight data sets for outgoing GOOSE messages consisting of any data attribute (DA) from any logical node. A single DA can be mapped to one or more outgoing GOOSE data sets, or one or more times within the same outgoing GOOSE data set. A user can also map a single GOOSE data set to multiple GOOSE control blocks. The number of unique Boolean variables is limited to a combined total of 512 digital bits across all eight outgoing messages.
- High-speed GOOSE messaging (as defined under GOOSE Performance) is available for GOOSE messages that contain either all Boolean data or a combination of Boolean data and remote analog output (RAO01–RAO64) data.
- The relay will transmit all configured GOOSE immediately upon successful initialization. If a GOOSE message is not retriggered, then following the initial transmission, the relay shall retransmit that GOOSE message based on the Min. Time and Max. Time configured for that GOOSE message. The first transmission shall occur immediately upon triggering of an element within the GOOSE data set. The second transmission shall occur Min. Time later. The third shall occur Min. Time after the second. The fourth shall occur twice Min. Time after the third. All subsequent transmissions shall occur at the Max. Time interval. For example, a message with a Min. Time of 4 ms and Max. Time of 1000 ms, will be transmitted upon triggering, then retransmitted at intervals of 4 ms, 4 ms, 8 ms, and then at 1000 ms indefinitely or until another change triggers a new GOOSE message (see IEC 61850-8-1, Sec. 18.1).
- Each outgoing GOOSE message includes communications parameters (VLAN, priority, and multicast address) and is transmitted entirely in a single network frame.
- The relay maintains the configuration of outgoing GOOSE messages through a power cycle and device reset.

Incoming GOOSE messages are processed in accordance with the following constraints.

- The user can configure the relay to subscribe to as many as 128 incoming GOOSE messages.
- Control bits in the relay get data from incoming GOOSE messages which are mapped to virtual bits (VB*nnn*). Virtual bits are volatile and are reset to zero when a new CID file is loaded, the device is restarted, or they are overwritten by data from a subscribed GOOSE message.
- The relay recognizes incoming GOOSE messages as valid based on the following content:
  - Source Broadcast MAC Address
  - Data Set Reference*
  - Application ID*
  - GOOSE Control Reference*

NOTE: Options marked with * are configurable via tools such as Architect. The relay, by default, checks against this parameter.

Any GOOSE message that fails these checks shall be rejected. You can find the default quality check in the quality mask in Architect. See Figure 17.24 for an example.

- Configuration Revision*
- Needs Commissioning*
- Quality Test*

- Every received and validated GOOSE message that indicates a data change, by an incremented status number, is evaluated as follows:
  - Data within the received GOOSE data set that are mapped to host data bits are identified.
  - Mapped bits are compared against a local version of the available host data bits.
  - If the state of the received bits is different than the local version:
    - Update the local version with the new state for that bit.
    - Pass the new state for the bit to the relay.
- Rejection of all DA contained in an incoming GOOSE message, based on the presence of the following error indications created by inspection of the received GOOSE message:
  - Configuration Mismatch: The configuration number of the incoming GOOSE message changes.
  - Needs Commissioning: This Boolean parameter of the incoming GOOSE message is true.
  - Decode Error: The format of the incoming GOOSE messageis not as configured.
- Reject DAs with quality indicating test if the subscriber is On or On-blocked mode.
- Upon a transition of Mod/Beh, the received GOOSE messages are evaluated to determine if the message will be processed according to IEC 61850-7-4 Appendix A.
- The relay discards incoming GOOSE under the following conditions:
  - After a permanent (latching) self-test failure
  - When EGSE is set to No

Link-layer priority tagging and virtual LAN is supported as described in Annex C of IEC 61850-8-1:2011.

GOOSE Performance

For outgoing high-speed data (as identified under GOOSE Processing), transmission of GOOSE begins within 2 ms of transition of digital data within the relay. Note that you can include RAO points in outgoing GOOSE for high-speed transmission. Only the transition of a digital point will trigger the transmission within 2 ms. For all other data contained in outgoing GOOSE, transmission of GOOSE begins within 500 ms of transition of data within the relay. For incoming GOOSE data with an included change of state, the corresponding mapped virtual bit states update within two processing intervals.

Sampled Values

NOTE: Not all SEL-400 series products support SV.

IEC 61850 9-2, also known as Sampled Values (SV), describes a service that brings digital samples of analog signals from the substation yard to the control house. Multiple components are essential to successful implementation of such a

service. SV publishers, also known as merging units, locally sample and convert analog signals to digital time-stamped samples. They then publish these samples with minimum delays via an Ethernet connection. Ethernet connections are established between SV publishers and SV subscribers for transmitting SV samples and GOOSE messages. This network is also called the process bus network. The information exchange between the SV publisher and the SV-subscribing relays is based on a publisher/subscriber mechanism that is similar to GOOSE messaging. The SV subscribing relay receives the time-stamped SV messages and checks the timeliness of the samples. Messages are buffered and then used by the relays.

To promote interoperability and fast deployment of SV, UCA International Users Group released "Implementation Guideline for Digital Interface to Instrument Transformers Using IEC 61850-9-2" and described a subset of IEC 61850-9-2, also known as UCA 61850 9-2LE or simply 9-2LE. The SEL-400 series SV products are compliant with the 9-2LE guideline, also known as the 9-2LE profile in this manual.

You can configure the SEL-400 series SV products via Architect or by using **PORT 5** settings. See *IEC 61850 Configuration on page 17.47* for more information on SV product configuration.

SV Processing

SV Publication

An SV publisher is an interface to the non-conventional instrument transformers (NCIT) and traditional instrument transformers. When an SV publisher is connected to a traditional instrument transformer, it is also called a standalone merging unit. The SV publisher samples the analog data at 8 kHz and downsamples to 4.8 kHz/4.0 kHz when the nominal frequency is 60 Hz/50 Hz. A time stamp representation, known as smpCnt, is encoded with each published SV message. Given the sampling rate and the need to maintain the time coherence of samples from multiple merging units, merging units must be time-synchronized to high-accuracy time source. See *Section 11: Time and Date Management* for time-synchronization methods. The difference between the time encoded by the smpCnt in an SV message and the time that the message is published at the Ethernet interface is the merging unit processing delay. This delay and the transmitting delay over a process bus network is the total network delay. See *SV Network Delays on page 17.33* for more about network delay.

SV Data Set

NOTE: SV publications are not supported for measurements that use delta-connected CTs or PTs. Any SV stream that includes data from a delta-connected CT or PT is marked as questionable/inaccurate.

SEL SV publishers can transmit multiple SV data streams. Each SV message includes four currents and four voltages. For example, the SEL-401 Protection, Automation, and Control Merging Unit has inputs for 12 analog measurements (6 currents and 6 voltages). This means that the merging unit function requires at least two streams to send all available voltage/current inputs. Merging units support as many as seven output streams, allowing unmatched flexibility with measurement channel assignment and precise routing of duplicate streams.

Primary/Secondary Scale Factor

The analog measurements inside SV messages represent the primary side of the instrument transformer. When connecting a standalone merging unit to a conventional transformer, a scale factor should be applied such that the measured sec-

ondary quantity is scaled to primary values. SEL recommends matching the transformer ratios between SV publishers and subscribers to ensure consistent pickup settings when protection elements are enabled in both.

Time Synchronization

SmpCnt is a representation of the time stamp, which is encoded in each SV message. If SV messages from multiple merging units are used for an application, the smpCnt from these merging units must represent the same time instance to correctly align the data. High-accuracy time synchronization is critical. SEL-400 series relays can be synchronized with high-quality IRIG-B or high-quality Precision Time Protocol (PTP). The quality of smpCnt at the time the sample was taken is indicated by the SmpSynch value included in each SV message. When a merging unit is not time synchronized to any time source, its sample time error is unknown. Without time synchronization, the relay sets the smpSynch to 0. When the merging unit is synchronized to a high-quality local time source (TLOCAL = 1), the smpSynch is set to 1. When the merging unit is synchronized to a high-quality global time source (TGLOBAL = 1), the smpSynch is set to 2. TLOCAL and TGLOBAL are indicators of the time-synchronization source. See *Section 11: Time and Date Management* for information about TLOCAL and TGLOBAL. During the synchronization process to a time source, SEL merging units may set the quality attribute validity as questionable and detailQual attribute as inaccurate in the SV message.

SEL merging units use the information in *Table 17.16* and *Table 17.17* to determine the quality of sample timing and the smpSynch values. See *Table 17.16* and *Table 17.17* for smpSynch values.

When high-quality IRIG-B is the current time source (CUR_SRC = BNC_IRIG or CUR_SRC = SER_IRIG):

Table 17.16 Mechanism of Determining smpSynch Values With an IRIG-B Time Source

Time Synchronization Status	smpSynch Value
TGLOBAL = 1	2
TLOCAL = 1	1
TGLOBAL = 0 TLOCAL = 0	0

When high-quality PTP is the current time source (CUR_SRC = PTP):

Table 17.17 Mechanism of Determining smpSynch Values With a PTP Time Source

Profile	MU Sync State	smpSynch Value
IEEE C37.238, IEC 61850-9-3, or Default Profile	TGLOBAL = 1	2
IEEE C37.238	TLOCAL = 1	GMID[a]
IEC 61850-9-3 or Default Profile	TLOCAL = 1	1
IEEE C37.238, IEC 61850-9-3, or Default Profile	TGLOBAL = 0 TLOCAL = 0	0

[a] Grand Master ID

SV Subscription

An SEL SV relay can receive one or more SV streams from one or more merging units. SEL SV relays only support receiving 9-2LE-compliant SV messages. Once messages are received, samples are buffered to ensure that samples used to calculate protection elements are from the same time. The SV message attribute, smpCnt, is used to check and align samples. SV messages can be published at different frequencies based on the nominal frequency. The SEL SV relay nominal frequency setting must match the merging unit nominal frequency.

Primary/Secondary Scale Factor

SV messages provide current and voltage measurements in terms of the primary side of the instrument transformers. SEL SV relay protection calculations are based on traditional secondary quantities. Thus, the received digital samples must be scaled to the secondary properly. For example, if the SV stream comes from a merging unit that is connected to a 1200/5 CT, the SEL SV relay CT ratio settings should be 240.

Current Summation

NOTE: Use caution when externally summing CT currents for differential protection. Because the resulting restraint current can be lower than expected, this can have implications for protection security.

To provide a similar function to sum currents by connecting copper wires together, SEL-400 series relays provide current summation via SV subscriptions. You can map as many as three SV current channels (UCA 9-2LE-compliant) to the same SV subscriber analog channel. You can enable this function by clearing **Hide current summation rows** in Architect in the **SV Receive** tab.

Example 17.1 Current Summation Via SV Subscription

In this example, a transmission line connects to a line reactor. The line current is the sum of the two breaker currents minus the reactor current. Merging unit Bay1MU #1 current transformer logical nodes TCTR1 and TCTR2 are both mapped to Terminal W on the SEL-421-7 Protection, Automation, and Control System With Sampled Values. SEL-421-7 Current Channel IAW has current measurements summed from Bay1MU #1...TCTR1.Amp.instMag.i and Bay1MU #1...TCTR2.Amp.instMag.i. The reactor current published from Bay1MU #2 is mapped to Terminal X on the SEL-421-7. The Terminal W and Terminal X currents are then combined by setting LINEI := COMB in Global settings.

Example 17.1 Current Summation Via SV Subscription (Continued)

Figure 17.15 Example Current Summation

The corresponding configuration is shown in *Figure 17.16*.

Figure 17.16 Example Current-Summation Configuration

SV Network Delays

The SV merging unit and process bus network act as the data acquisition system for an SV relay. There are time delays introduced by DSS. The delays of an SV stream include the merging unit processing delay and the process bus network delay. The sum of these is called the network delay. SEL SV relays measure and report this network delay. The measured network delay for each SV subscription

is stored as an analog quantity and reported via the **COM SV** ASCII command. See *Section 9: ASCII Command Reference* in the product-specific instruction manual for more detailed information.

SEL SV relays account for a network delay by buffering SV samples. The buffer length is controlled by the CH_DLY setting. Set the CH_DLY setting to the following value:

$$\text{CH_DLY} = \text{MAX}(\text{SVND}mm) + (\text{N} + 1) \bullet (\text{Sample Period})$$

Equation 17.1

where:

MAX(SVND*mm*) is the maximum network delay out of all received streams

N is the number of lost packets you want the relay to ride through by interpolating data

N = 3 is a good choice for typical applications because it allows the relay to ride through a loss of three packets. The allowable range for N is 1–3. The CH_DLY setting is specified in milliseconds (ms), and the SVND*mm* value is reported in milliseconds (ms), both in the **COM SV** command response and as a user-accessible analog quantity. Convert the last part of the channel delay equation to milliseconds by treating a sample period as 0.2083 ms for a 60 Hz system, or 0.25 ms for a 50 Hz system.

SEL SV relays wait to start resampling until samples arrive for the configured CH_DLY. This design also provides a consistent delay (CH_DLY) to protection and control operations, which overcomes the non-deterministic delays caused by the Ethernet process bus network.

If SV messages of the first SV subscription, which is listed first in the **COM SV** command response, are delayed by more than CH_DLY, they are considered lost. If less than three consecutive messages are delayed or missing, the SEL SV relay interpolates for these delayed or lost messages. If more than three samples are delayed or missing, the SEL relay ASCII command **COM SV** reports `SV STREAM LOST` for this scenario.

The protection and control operation times are delayed by the configured CH_DLY. Use caution when setting the relay coordination times to account for this added delay.

Coupled Clocks Mode

The SV relay operates in coupled clocks mode when both it and the merging unit configured as the time reference are synchronized to either a high-quality global time source or the same high-quality local time source. The relay evaluates its operation in this mode by using the local smpSynch and the smpSynch value from the first subscribed SV stream. The SVCC Relay Word bit asserts when the relay is operating in coupled clocks mode and can calculate the network delay for incoming SV streams. These delays are stored in analog quantities SVND*mm*, where *mm* is the subscription number, and are also reported in the **COM SV** command response.

Freewheeling Mode

When the relay is not operating in coupled clocks mode, it operates in freewheeling mode. In this mode, only the data from the reference stream are used; all other SV streams are discarded. The SVCC Relay Word bit remains deasserted in this mode and the network delay statistics are not reported.

Subscription Reference Stream

SEL SV relays store the smpSynch of each subscribed SV stream in analog quantities SV*mm*SNC, where *mm* is the subscription number. If a CID file is used, the first subscription stream in the CID file is used as the smpSynch reference. If the **PORT 5** SV setting is used, the subscription with the subscribed MAC address set by SVRADR1 is the first subscription and is used as the smpSynch reference. In coupled clocks mode, any subsequent streams that do not have the same smpSynch as the time reference are discarded. If the relay stops receiving data for the first subscription stream, the last smpSynch value received from the first subscription stream continues to remain as the time reference. If the smpSynch value of the first subscription stream is zero, only the first subscription stream is accepted.

Station Bus and Process Bus (Four-Port Ethernet Card)

NOTE: The MERGED BUSMODE is not recommended for long-term operations, as the large amount of process bus traffic can adversely affect station bus functions when the buses are combined.

The SEL SV publishers and subscribers allow flexible station bus and process bus configurations when using the four-port Ethernet card. If BUSMODE := INDEPEND, station bus traffic (typically MMS and GOOSE) will only be transmitted out on the station bus ports, and process bus traffic (typically SV and GOOSE) will only be transmitted on process bus ports. If BUSMODE := MERGED, all communications use **PORT 5A** and **PORT 5B**, with process bus and station bus traffic merged on the same physical network, and the process bus ports are disabled. The designation of station bus and process bus is controlled by NETPORT settings. The station bus port is the same as the primary port, as specified by NETPORT settings. If NETPORT := A or NETPORT := B, then **PORT 5A** and **PORT 5B** are used for station bus communication and **PORT 5C** and **PORT 5D** are used for process bus communication. If NETPORT := C or NETPORT := D, then **PORT 5C** and **PORT 5D** are used for station bus communication and **PORT 5A** and **PORT 5B** are used for process bus communication. IEEE 1588-based time synchronization is only available on **PORT 5A** and **PORT 5B** when using the four-port Ethernet card. If you want PTP time synchronization on the process bus, use **PORT 5A** and **PORT 5B** for process-bus communications. *Figure 17.17* shows some common network configurations, including the NETPORT and BUSMODE settings used.

Figure 17.17 shows an independent bus mode network schematic with PTP time synchronization on the process bus. In this schematic, the merging unit has settings BUSMODE := INDEPEND and NETPORT := C.

Figure 17.17 Independent Bus Mode With PTP Time Synchronization on the Process Bus

Figure 17.18 shows an independent bus mode network schematic with PTP time synchronization on the station bus. In this schematic, the merging unit has settings BUSMODE := INDEPEND and NETPORT := A.

Figure 17.18 Independent Bus Mode With PTP Time Synchronization on the Station Bus

Figure 17.19 shows an independent bus mode network schematic with local IRIG time source. In this schematic, the merging unit has settings BUSMODE := INDEPEND and NETPORT := A.

Figure 17.19 Independent Bus Mode With IRIG Time Synchronization

Figure 17.20 shows a merged bus mode network schematic with PTP time synchronization. Process bus and station bus traffic are all processed in PORT A. In this schematic, the merging unit has settings BUSMODE := MERGED and NETPORT := A.

Figure 17.20 Merged Bus Mode With PTP Time Synchronization

Station Bus and Process Bus (Five-Port Ethernet Card)

When using the five-port Ethernet card, the station bus and process bus designations are fixed. If BUSMODE := INDEPEND, the process bus is assigned to PORT 5A and PORT 5B, and the station bus is assigned to PORT 5C and PORT 5D. If

BUSMODE := MERGED, traffic is processed on **PORT 5A** and **PORT 5B**, and **PORT 5C** and **PORT 5D** are disabled. The engineering access port (**PORT 5E**) is not associated with the BUSMODE setting; therefore, its designation and functionality remain the same. The card uses three source MAC addresses. The first MAC address is applied to the process bus. The second MAC address is applied to the station bus. The third MAC address is applied to the engineering access port. IEEE 1588-based time synchronization is available on either the process bus or station bus when using the five-port Ethernet card.

IEC 61850 Messaging (Four-Port Ethernet Card)

The SEL-400 series relays publish and subscribe GOOSE messages on both the station bus and the process bus ports when using the four-port Ethernet card. GOOSE subscription error out of sequence may be reported if GOOSE messages from station bus and process bus are not isolated properly via network management. For example, *Figure 17.21* shows an SEL merging unit publishing two GOOSE messages from the station bus and process bus. Without proper GOOSE messages routing on the Ethernet switch, the SV relay receives GOOSE messages #1 and #2 from the process bus and the station bus, and out-of-sequence error is reported for GOOSE messages #1 and #2 subscriptions. Proper management and segregation of GOOSE messages from the station bus and the process resolves this. For example, if GOOSE message #1 is designed for the process bus only, engineers can configure the station bus Ethernet switch to only forward GOOSE message #2 and the process bus Ethernet switch to only forward GOOSE message #1 via VLAN management.

SEL recommends using an SEL software-defined network (SDN) Ethernet switch to engineer each Ethernet traffic flow. Engineers can plan the network path for process bus GOOSE messages to flow through the process bus SDN switch only and discard the station bus GOOSE messages.

Figure 17.21 Use Ethernet Switch to Engineer Network Path for GOOSE Messages

IEC 61850 Messaging (Five-Port Ethernet Card)

To configure IEC 61850 messaging in the five-port Ethernet card, download a ClassFileVersion 007 CID file to the relay. This file provides multiple access points to differentiate between the process bus, station bus, and engineering access networks, as well as to define which services are available on those networks. Use Architect to configure communications for each network. For example, to publish a GOOSE message on process bus **PORT 5A** and **PORT 5B**, select interface **P1** in the address dropdown menu in the GOOSE transmit editor, as shown in *Figure 17.22*.

Figure 17.22 GOOSE Transmit Interface Selection (Five-Port Ethernet Card)

The five-port Ethernet card supports two levels of GOOSE message VLAN prioritization: high and low. GOOSE messages with VLAN tags priorities from 0–3 are processed as low priority. GOOSE messages with VLAN priorities tags from 4–7 are processed as high priority. GOOSE messages without VLAN tags are processed as low priority.

IEC 61850 Simulation Mode

NOTE: SV simulation is only applicable in IEDs with SV subscription capability.

The SEL-400 series relays (including the SEL-401) can be configured to operate in simulation mode. In this mode, the SEL-400 series relays continue to process normal SV or GOOSE messages until a simulated SV or GOOSE message is received for a subscription. Once a simulated SV or GOOSE message is received, only simulated SV or GOOSE messages are processed for that subscription. Simulated mode only terminates when LPHDSIM is returned to FALSE. When the relay is not in simulation mode, only normal SV or GOOSE messages are processed for all subscriptions.

A user can place the SEL-400 series relays in IEC 61850 simulation mode by setting LPHDSIM (CFG.DevIDLPHD1.Sim.stVal) to true via MMS messaging.

Alternatively, you can use SELOGIC variable SC850SM to set LPHDSIM. The rising edge of SC850SM sets LPHDSIM, and the falling edge of SC850SM clears LPHDSIM. When you use SC850SM to enter simulation mode, the relay rejects MMS attempts to enter or exit simulation mode until SC850SM deasserts.

IEC 61850 Mode/Behavior

NOTE: IEC 61850 Mode/Behavior is only available in IEDs with IEC 61850 Ed2 support.

The IEC 61850-7-4:2010 standard defines behaviors of different modes to facilitate testing. SEL-400 series relays support the following modes:

- On
- Blocked
- Test
- Test/Blocked
- Off

IEC 61850 Behavior is jointly determined by the logical device mode and its logical node mode according to the IEC 61850 standard. For SEL-400 series relays, the selected IEC 61850 Mode/Behavior applies to the entire IED, including all its logical devices and all logical nodes. The behavior of the IED is always the same as the selected mode.

Table 17.18 describes the available services based on the mode/behavior of the IED.

Table 17.18 IEC 61850 Services Available Based on Mode/Behavior

Mode	MMS	GOOSE Publication and Subscription	SV Publication and Subscription
On	Available	Available	Available
Blocked	Available	Available	Available
Test	Available	Available	Available
Test/Blocked	Available	Available	Available
Off	No services[a]	Publication[b]	Publication[b]

[a] All MMS control requests to change the mode with Test = false will be processed.
[b] GOOSE and SV publication in mode Off are disabled if EOFFMTX = N.

The analog quantity I850MOD is an enumerated number that corresponds to mode and behavior, as shown in *Table 17.19*.

Table 17.19 Analog Quantity I850MOD Status Based on the Selected IEC 61850 Mode/Behavior

I850MOD	IEC 61850 Mode/Behavior
1	On
2	Blocked
3	Test
4	Test/Blocked
5	Off
0	Not Supported

Mode/Behavior Control

Enable Mode/Behavior Control

IEC 61850 Mode/Behavior, by default, is disabled on SEL-400 series relays. To enable IEC 61850 Mode/Behavior, you must set PORT 5 setting E61850 to **Y**. To enable IEC 61850 Mode/Behavior control, you must set port setting E850MBC to **Y** and the CID file setting controllableModeSupported to **True**. You can set the controllableModeSupported setting by selecting **Enable control of IEC 61850 Mode/Behavior** when adding an IED into an Architect project, as shown in *Figure 17.23*.

Figure 17.23 Set controllableModeSupported = True

Enhanced Secure Mode Control

Relay setting E850MBC and CID file setting controllableModeSupported provide security to prevent accidental switching into an unplanned IEC 61850 Mode/Behavior during normal operations. For example, following IED testing, a technician can disable unplanned switching of IEC 61850 Mode/Behavior by setting E850MBC to N after switching the relay back to On mode.

Change Mode Via MMS or SELOGIC

If IEC 61850 Mode/Behavior is set as controllable, you can control the IEC 61850 Mode/Behavior via MMS writes to the LLN0 logical node mode data object (Mod.Oper.ctlVal) in logical device CFG. Note that Mod.Oper.ctlVal in other logical devices does not accept MMS writes.

Write Values to Mod.Oper.ctlVal in Logical Device CFG	Selected IEC 61850 Mode/Behavior
1	On
2	Blocked
3	Test
4	Test/Blocked
5	Off

You can also control IEC 61850 Mode/Behavior through use of the **SET L** command with protection SELOGIC variables SC850TM and SC850BM on the left side of protection logic equations. These variables are the SELOGIC controls for the Test mode and the Blocked mode, respectively.

NOTE: The variables SC850TM and SC850BM are not protection settings.

SC850TM	SC850BM	Selected IEC 61850 Mode/Behavior
0	0	See Note[a]
1	0	Test
0	1	Blocked
1	1	Test/Blocked
See Note[b]	See Note[b]	Off

[a] **Note:** The SELOGIC controls have higher priority than MMS clients in controlling the Test mode and Blocked mode. When SC850TM and SC850BM both evaluate to 0 (false), IEC 61850 Mode/Behavior control is available to MMS clients. If either SC850TM or SC850BM evaluates to 1 (true), SELOGIC determines the IEC 61850 Mode/Behavior of the IED regardless of MMS control values.

[b] **Note:** You cannot control Off mode by using SC850TM and SC850BM. When an MMS client causes the IED to be in Off mode, the SELOGIC controls are disabled and SC850TM and SC850BM are not evaluated.

Example 17.2 Change Mode Via SELOGIC

In this example, pushbuttons PB1 and PB2 control SC850TM. Pushbuttons PB3 and PB4 control SC850BM. If you press PB1, the relay enters Test mode. If you press PB3, the relay transitions from Test mode into Test/Blocked mode. Press PB2 and PB4 to reset Test mode and Blocked mode, respectively.

Example 17.2 Change Mode Via SELOGIC (Continued)

```
=>>SHO L
Protection 1

1: PLT01S := PB1
2: PLT01R := PB2
3: SC850TM := PLT01
4: PLT02S := PB3
5: PLT02R := PB4
6: SC850BM := PLT02
```

You can read the current IEC 61850 Mode/Behavior through an MMS client or by using the **STA A** commands.

Mode Indications on HMI

If the Mode/Behavior is Test, Blocked, or Test/Blocked, the relay toggles the **ENABLED** LED on the front panel approximately every half a second to alarm users that the relay is not in On mode. When the relay is placed in Off mode, the relay is disabled and the relay **ENABLED** LED is solid red.

Incoming Messages Processing

IEC 61850 incoming data processing is jointly determined by quality validity, test, and operatorBlocked. SEL-400 series relays, by default, check if the quality operatorBlocked = False; if not, the relays treat the messages as invalid. You can disable the default check by changing the quality mask of GOOSE subscriptions. *Figure 17.24* illustrates the default quality check for GOOSE subscription on SEL-400 series relays.

Figure 17.24 Default Quality Check on GOOSE Subscription if Quality Is Present

Relay Operation for Different IEC 61850 Modes/Behaviors

Refer to *Section 10: Testing, Troubleshooting, and Maintenance* for information on how to use the various modes in testing.

Mode: On

In On mode, the relay operates as normal; it reports IEC 61850 Mode/Behavior status as On and processes all inputs and outputs as normal. If the quality of the subscribed SV messages satisfies *Table 14.46*, the relay processes the received SV messages as valid. If the quality of the subscribed GOOSE messages satisfies the GOOSE processing (see *GOOSE Processing on page 17.28*), the relay processes the received GOOSE messages as valid.

NOTE: An IEC 61850 IED determines the processing of GOOSE messages based on the received quality of the GOOSE data and its current mode. If a GOOSE message does not contain quality information, the relay always processes it as valid. To use the IEC 61850 Mode/Behavior, SEL recommends including quality attributes in GOOSE messages.

Table 17.20 IEC 61850 Incoming Message Handling in On Mode

IEC 61850 Messages	Incoming Message With Quality Test Bit Set to False (0)	Incoming Message With Quality Test Bit Set to True (1)
MMS	Processed	Processed as invalid
GOOSE	Processed	Processed as invalid
SV[a]	Processed	Processed as invalid

[a] IEC SV subscribers only.

Table 17.21 IEC 61850 Outgoing Message Handling in On Mode

IEC 61850 Messages	Outgoing Message Quality Test Bit Status
MMS	False
GOOSE	False
SV[a]	False

[a] IEC SV publishers only.

Figure 17.25 illustrates the mode/behavior.

Figure 17.25 Relay Operations in On Mode

Mode: Blocked

The relay operates in Blocked mode similarly to how it operates in On mode, except that it does not operate any physical contact outputs in this mode. It does continue to operate control bits such as remote bits and output contact bits.

NOTE: In Blocked mode, the physical output contacts are frozen in the state they were in prior to entering Blocked mode.

Figure 17.26 Relay Operations in Blocked Mode

Mode: Test

In Test mode, the relay processes valid incoming test signals or normal messages and operates physical contact outputs if triggered. In this mode/behavior, outgoing MMS, GOOSE, and SV messages have the quality test bit set to True if the quality test bit is present. If the quality of the subscribed SV messages satisfies *Table 14.46* (regardless of whether the quality test bit is set to True or False), the relay processes the received SV messages as valid. If the quality of the subscribed GOOSE messages satisfies the user-defined quality type definition (regardless of whether the quality test bit is set to True or False—see *GOOSE Processing on page 17.28*), the relay processes the received GOOSE messages as valid.

NOTE: An IEC 61850 IED determines the processing of GOOSE messages based on the received quality of the GOOSE data and its current mode. If a GOOSE message does not contain quality information, the relay always processes it as valid. To use the IEC 61850 Mode/Behavior, SEL recommends including quality attributes in GOOSE messages.

Table 17.22 IEC 61850 Incoming Message Handling in Test Mode

IEC 61850 Messages	Incoming Message With Quality Test Bit Set to False (0)	Incoming Message With Quality Test Bit Set to True (1)
MMS	Not Processed	Processed
GOOSE	Processed	Processed
SV[a]	Processed	Processed

[a] IEC SV subscribers only.

Table 17.23 IEC 61850 Outgoing Message Handling in Test Mode

IEC 61850 Messages	Outgoing Message Quality Test Bit Status
MMS	True
GOOSE	True
SV[a]	True

[a] IEC SV publishers only.

Figure 17.27 illustrates the mode/behavior.

Figure 17.27 Relay Operations in Test Mode

Mode: Test/Blocked

In Test/Blocked mode (see *Section 10: Testing, Troubleshooting, and Maintenance* for more information), the relay processes valid incoming test signals or normal messages but blocks any physical contact outputs from operating. In this mode/behavior, outgoing MMS, GOOSE, and SV messages have the quality test bit set to True if the quality test bit is present. If the quality of the subscribed SV messages satisfies *Table 14.46* (regardless of whether the quality test bit is set to True or False), the relay processes the received SV messages as valid. If the quality of the subscribed GOOSE messages satisfies the user-defined quality type definition (regardless of whether the quality test bit is set to True or False—see *GOOSE Processing on page 17.28*), the relay processes the received GOOSE messages as valid.

NOTE: An IEC 61850 IED determines the processing of GOOSE messages based on the received quality of the GOOSE data and its current mode. If a GOOSE message does not contain quality information, the relay always processes it as valid. To use the IEC 61850 Mode/Behavior, SEL recommends including quality attributes in GOOSE messages.

Figure 17.28 illustrates the mode/behavior.

Figure 17.28 Relay Operations in Test/Blocked Mode

Mode: Off

In Off mode, the relay no longer processes incoming GOOSE and SV messages. The relay processes MMS control requests to change the IEC 61850 Mode/Behavior if the quality Test bit is set to False. The relay is in a disabled state, and it no longer trips any physical contact outputs.

In this mode, the relay is in a disabled state. Relay Word bit EN is set to False. The device processes MMS control requests to change the active mode of IEC 61850 Mode/Behavior if the quality Test bit of the control is set to False.

If EOFFMTX is set to True, the relay continues to transmit SV messages and GOOSE messages with the quality test bit set to False (0), the validity set to Invalid (01), and the quality failure bit set to True if the quality is present in the messages. If EOFFMTX is set to False, the relay does not transmit GOOSE or SV messages in this mode. The relay also does not process any incoming GOOSE and SV messages.

Table 17.24 IEC 61850 Incoming Message Handling in Off Mode

IEC 61850 Messages	Incoming Message With Quality Test Bit Set to False (0)	Incoming Message With Quality Test Bit Set to True (1)
MMS	Relay Only Processes Messages to Control the Mode	Not Processed
GOOSE	Not Processed	Not Processed
SV	Not Processed	Not Processed

Table 17.25 IEC 61850 Outgoing Message Handling in Off Mode

IEC 61850 Messages	Outgoing Message Quality Validity Bit
MMS	Invalid
GOOSE	Invalid
SV	Invalid

Figure 17.29 illustrates the IEC 61850 Mode/Behavior.

Figure 17.29 Relay Operations in Off Mode

Relay Output Contact Behavior Following a Power Cycle

The behavior of the relay output contacts vary based on the IEC 61850 mode in which the relay existed prior to the power cycle. The behavior for all contact outputs at relay loss of power is to de-energize the contact outputs (open for normally open and close for normally closed). Upon restoring power, the relay re-establishes the IEC 61850 mode prior to loss of power, and if the IEC 61850 mode was Blocked or Test/Blocked, the relay will not operate the output contacts based on the SELOGIC control equations, even if the outputs were energized prior to the power cycle. *Table 17.26* describes all scenarios.

Table 17.26 Output Contact Behavior for IEC 61850 Modes Following a Power Cycle

IEC 61850 Mode Prior to Power Cycle	Output Contact State Prior to Power Cycle	Output Contact State During Power Off	Output Contact State Following the Power Cycle
ON	0	0	0
BLOCKED	0	0	0
TEST	0	0	0
TEST/BLOCKED	0	0	0
OFF	0	0	0
ON	1	0	1
BLOCKED	1	0	0
TEST	1	0	1
TEST/BLOCKED	1	0	0
OFF	1	0	0

SEL TEST SV Mode

The SEL SV subscriber and the SEL SV publisher both support TEST SV mode. This mode is designed to validate SV communications during testing.

SEL SV Subscriber

When the **TEST SV** command is executed on an SEL SV subscriber, it sets the Relay Word bit SVSTST to TRUE. In this mode, the relay accepts either TEST SV data (test bit of the quality attribute is TRUE) or normal SV data (test bit of the quality attribute is FALSE). If the relay receives TEST SV data, the warning code `QUALITY(TEST)` is used to indicate the subscription status. While in TEST SV mode, the relay processes the SV stream and exercises all associated protection logic.

If the SEL SV subscriber is not in TEST SV mode, SVSTST is set to FALSE and the relay only accepts SV data with a valid quality. If TEST SV data are received, messages are discarded and error code `INVALID QUAL` is used to indicate the subscription status.

SEL SV Publisher

When the **TEST SV** command is executed on the SEL-401, SEL-421-7, or SEL-451-6 SV publishers, it sets the Relay Word bit SVPTST to TRUE. In this mode, the relay generates test signals on all configured SV streams. The test bit in the quality attribute is TRUE for all published SV messages. The published signals are scaled from secondary values (Magnitude in *Table 17.27*) to primary values in accordance with the CT and PT ratio setting as follows:

- CTRW is used for both IW and IX scaling.
- PTRY is used for both VY and VZ scaling.

Table 17.27 Secondary Quantities for the SEL SV Publishers

IEC	SEL	Magnitude (RMS)		Angle (Degrees)	
		5 A[a]	1 A[a]	ABC Rotation	ACB Rotation
I1	IA	5	1	0	0
I2	IB	5	1	–120	120
I3	IC	5	1	120	–120
I4	IN	0[b]	0[b]	0[b]	0[b]
V1	VA	67	67	0	0
V2	VB	67	67	–120	120
V3	VC	67	67	120	–120
V4	VN	0[b]	0[b]	0[b]	0[b]

[a] 1 A or 5 A nominal current.
[b] The neutral channel is the sum of the waveforms for A-, B-, and C-Phase

Refer to *Section 14: ASCII Command Reference* for more information about the **TEST SV** command.

IEC 61850 Configuration

Settings

Table 12.18 lists the IEC 61850 settings. *Table 12.19* lists the Mode/Behavior settings. These settings are only available if your device includes the optional IEC 61850 protocol.

Architect

NOTE: Not all SEL-400 series relays support SV.

NOTE: Other manufacturers' ICD and CID files must have IEC 61850 outgoing GOOSE messages with Application IDs (APPIDs) of exactly four characters and VLAN IDs of exactly three characters so that the relay can successfully subscribe to them. If you attempt to configure a relay to subscribe to a GOOSE message that does not meet this criteria, the relay will reject the CID file upon download. Edit other manufacturers' ICD and CID files prior to importing them into Architect by adding leading zeros to the APPID and VLAN ID of outgoing GOOSE messages, as necessary.

NOTE: Use unique VLAN tags when publishing 87L, GOOSE, and SV messages to avoid mixing process bus traffic with station bus traffic. However, the VLAN IDs of subscribed GOOSE messages can be the same as outgoing 87L or SV VLAN IDs.

The Architect software enables protection and integration engineers to design and commission IEC 61850 substations containing SEL IEDs.

Engineers can use Architect to perform the following configuration tasks:

- Organize and configure all SEL IEDs in a substation project.
- Configure incoming and outgoing GOOSE messages.
- Configure SV publication and subscription, if supported.
- Edit and create GOOSE and SV data sets.
- Read non-SEL IED Capability Description (ICD) and CID files and determine the available IEC 61850 messaging options.
- Use or edit preconfigured data sets for reports.
- Load device settings as part of IEC 61850 CID files into SEL IEDs.
- Generate ICD files that will provide SEL IED descriptions to other manufacturers' tools so they can use SEL GOOSE messages and reporting features.

Architect provides a GUI for engineers to select, edit, and create IEC 61850 GOOSE messages important for substation protection, coordination, and control schemes. Typically, the engineer first places icons representing IEDs in a substation container, then edits the outgoing GOOSE messages or creates new ones for each IED. The engineer may also select incoming GOOSE messages for each

IED to receive from any other IEDs in the domain. Architect has the capability to read other manufacturers' ICD and CID files, enabling the engineer to map the data seamlessly into SEL IED logic. See the Architect help for more information.

Architect also provides a GUI for engineers to configure SV publications and SV subscriptions when the IED supports SV. The process is similar to that described for GOOSE, except that SEL SV devices can either publish or subscribe to SV, but not both. The engineer edits or creates SV publication data sets to configure the SEL SV publisher(s). Architect then displays the available SV publications in the project, using any SV publications defined in the project, including those from imported CID files from other manufacturers' SV publishers. The engineer then configures subscriptions by mapping the published data to the available analog channels in the SEL SV subscriber.

The following example includes configurations via the Architect software. The software supports IEC 61850 MMS, GOOSE, and SV configurations. This example shows how to use the software to configure two SV publications on an SEL-401 and the SV subscriptions on an SEL-421-7.

Example 17.3 SV Application

Step 1. Open Architect.

Step 2. Insert the SEL-401 ICD and the SEL-421-7 SV Subscriber ICD in the project tree.

Figure 17.30 Add ICD to Project Tree

Example 17.3 SV Application (Continued)

Step 3. Create an SV Publication for the SEL-401. Configure SVID, MAC address, APP ID, and VLAN information as desired. Select an SV data set to associate it with the SV publication.

Figure 17.31 Configure an SV Publication

Example 17.3 SV Application (Continued)

Step 4. To view the content of the data set, select the **...** icon next to the data set.

Figure 17.32 Example SV Publication Data Set

Example 17.3 SV Application (Continued)

Step 5. Select the SEL-421 and select the **SV Receive** tab to configure the SV subscriptions as shown in *Figure 17.33*.

Figure 17.33 Configure SV Subscription

Step 6. Right-click the IED, and choose to send the CID file. Ensure that the FTP function is enabled on the IEDs before sending CID files.

Figure 17.34 Send SEL-401 CID File

Example 17.3 SV Application (Continued)

Figure 17.35 Send SEL-421-7 CID File

Step 7. Issue the **COM SV** command on the merging unit and the relay to verify successful publication and subscription.

```
=>>COM SV <Enter>

IEC 61850 Mode/Behavior: On

SEL TEST SV Mode: Off

SV Publication Information

 MultiCastAddr   Ptag:Vlan AppID  smpSynch
_____________________________________________________________________
A0401_006_ICD_ExampleCFG/LLN0$MS$MSVCB01
 01-0C-CD-04-00-11  4:1    4001      0
 SV ID: 4001
 Data Set: A0401_006_ICD_ExampleCFG/LLN0$PhsMeas1
```

Figure 17.36 SEL-401 Publication Status

```
=>>COM SV <Enter>

IEC 61850 Mode/Behavior: On

SEL TEST SV Mode: Off

SIMULATED Mode: Off

SV Subscription Status

 MultiCastAddr   Ptag:Vlan AppID  smpSynch    Code          Network Delay (ms)
_____________________________________________________________________
A0401_006_ICD_ExampleCFG/LLN0$MS$MSVCB01
 01-0C-CD-04-00-11  4:1    4001      1
 SV ID: 4001
 Data Set: A0401_006_ICD_ExampleCFG/LLN0$PhsMeas1
```

Figure 17.37 SEL-421-7 SV Subscription Status

SV Configuration

The SEL-400 series relays support SV configuration via Architect or **PORT 5** settings via ACSELERATOR QuickSet SEL-5030 Software, terminal window, or front-panel HMI. **PORT 5** SV settings take precedence over any SV configuration via CID files. If SVTXEN > 0 or SVRXEN > 0, **PORT 5** SV configuration is used.

SV Communication Status

SEL SV publishers support as many as seven SV publications. The SEL SV publishers indicate the publication status by using Relay Word bits SVP*nn*OK (*nn*= 01 to 07). If a publication is configured, the corresponding SVP*nn*OK Relay Word bit asserts. The **COM SV** command provides a detailed report on the configured SV publications.

SEL SV subscribers support as many as seven SV subscriptions. The SEL SV subscriber monitors each incoming SV stream and, when queried with the **COM SV** command, reports errors or warnings if detected. For example, if the relay has not received four or more consecutive SV messages, **COM SV** reports the error code `SV STREAM LOST`. If the received SV messages include more than one application service data unit (ASDU), the error code `ASDU ERROR` is reported to indicate that the SEL-400 only supports one ASDU. Warning codes include `CH DLY EXCEEDED`, `INTERPOLATED`, `SIMULATED`, etc. For example, if the measured network delay of any subscribed SV stream exceeded the CH_DLY when the relay is in coupled clock mode. If SV subscriptions experience an error, the corresponding subscription status, SVS*nn*OK (*nn* = 01–07), deasserts.

Refer to *Section 14: ASCII Command Reference* for more information about the **COM SV** command.

SEL ICD File Versions

Architect version 1.1.69.0 and higher supports multiple ICD file versions for each IED in a project. Because relays with different firmware may require different CID file versions, this allows users to manage the CID files of all IEDs within a single project.

Ensure that you work with the appropriate version of Architect relative to your current configuration, existing project files, and ultimate goals. If you desire the best available IEC 61850 functionality for your SEL relay, obtain the latest version of Architect and select the appropriate ICD version(s) for your needs. Architect generates CID files from ICD files so the ICD file version Architect uses also determines the CID file version generated.

Architect comes with several versions of relay ICD files. ICD file descriptions in Architect indicate the minimum firmware versions required to use that particular file. Unless otherwise indicated, ICD files will work with firmware higher than the firmware in the description. but not with lower firmware versions.

See *Appendix A: Firmware, ICD File, and Manual Versions* in the product-specific instruction manual for a list of ICD versions and corresponding firmware versions.

Logical Nodes

Each logical device (LD) has a set of common data objects at the top-level LN0. These represent the current state of the device, as well as some informational data. These data objects are: Mod (Mode), Beh (Behavior), Health, and NamPlt. See the following for brief descriptions of each object.

Mode

In the SEL-400 series relays, the top-level LN0 within each LD includes the following enumerations for **Mod stVal**:

Mod stVal Enumeration	Description
1	On
2	Blocked
3	Test
4	Test/Blocked
5	Off
0	IEC 61850 Mode/Behavior disabled

The top-level logical node of each LD also includes the following Mod attributes:

- **Mod.q** represents quality.
- **Mod.t** represents time stamps.
- **Mod.stVal** represents the current mode/behavior.

You can control IEC 61850 Mode/Behavior via LLN0COMod$Oper in your CFG logical device.

Behavior

SEL-400 series relay LNs include the following enumerations for **Beh stVal**:

Beh stVal Enumeration	Description
1	On
2	Blocked
3	Test
4	Test/Blocked
5	Off
0	IEC 61850 Mode/Behavior disabled

Logical nodes also include the following Beh attributes:

Beh q and **Beh t** per the Time Stamps and Quality section.

Health

The SEL-400 series relay includes at the top-level LN0 within each LD the following enumerations for **Health stVal**:

Health stVal Enumeration	Health stVal Value	Description
1	Ok	EN Relay Word bit = 1
3	Alarm	EN Relay Word bit = 0

The top-level logical node of each LD also includes the following Health attributes:

Health q and **Health t** per the Time Stamps and Quality section.

NamPlt

The top-level LN0 of each LD includes the following NamPlt attributes:

- NamPlt.vendor has a string value set to SEL.
- NamPlt.swRev contains the relay FID string value.
- NamPlt.d contains the LD description.

LPHD

The LPHD logical node in the CFG logical device contains information about the physical device, such as the physical device nameplate information. SEL extended this logical node to include an object that provides an identifier for the version of the IEC 61850 component firmware in the device. This object, LPHD.SelLibID, contains a checksum derived from the IEC 61850 library version and is the same value across different devices with the same underlying code. This value is also available in the LIB61850ID field of the ID command.

Common Logical Nodes

NOTE: With the introduction of the Flexible Server Model (FSM) in Architect for ICD files ClassFileVersion 010 or later, use FSM as the primary reference to view and edit the mapping between IEC 61850 data attributes and relay variables. The LN tables provided in this section serve as general guidelines.

Table 17.28–Table 17.31 list the logical nodes (LNs) supported in all SEL-400 series relays. See the respective product-specific instruction manuals to see which additional logical nodes are available in that relay.

Table 17.28 shows the LNs associated with the Logical Node CFG.

Table 17.28 Logical Device: CFG (Configuration) (Sheet 1 of 8)

Logical Node	Attribute	Data Source	Comment
Functional Constraint = CO			
LLN0	LocSta.Oper.ctlVal	SC850LS	SELOGIC control for control authority at station level
LLN0	Mod.Oper.ctlVal	I60MOD[a]	IEC 61850 mode/behavior control
DevIDLPHD1	Sim.Oper.ctlVal	LPHDSIM	IEC 61850 logical node for physical device simulation
EALCCH1	RsStat.Oper.ctlVal	EARST[b, c]	Reset engineering access statistics
GOLCCH2	RsStat.Oper.ctlVal	GORST[b]	Reset statistics for GOOSE traffic
IPLCCH1	RsStat.Oper.ctlVal	IPRST[b]	Reset statistics for general IP traffic (excluding GOOSE, SV, and 87L traffic).
LGOS*n*[d]	RsStat.Oper.ctlVal	GRST*n*[e]	Reset GOOSE statistics for Message *n*
LSVS*n*[f]	RsStat.Oper.ctlVal	SRST*n*[e]	Reset SV statistics for SV Stream *n*
PBLCCH1	RsStat.Oper.ctlVal	PBRST[b, c]	Reset process bus statistics
SBLCCH1	RsStat.Oper.ctlVal	SBRST[b, c]	Reset station bus statistics
Functional Constraint = DC			
LLN0	NamPlt.swRev	VERFID	Relay FID string
DevIDLPHD1	PhyNam.hwRev	HWREV[g]	Hardware version of the relay main board
DevIDLPHD1	PhyNam.model	PARNUM	Relay part number string
DevIDLPHD1	PhyNam.serNum	SERNUM	Relay serial number string
DevIDLPHD1	SelLibId.val	–[b]	Checksum derived from the IEC 61850 library version
Functional Constraint = ST			
LLN0	Mod.stVal	I60MOD[a]	IEC 61850 mode/behavior status
LLN0	Health.stVal	EN?3:1[h]	Relay enabled

Table 17.28 Logical Device: CFG (Configuration) (Sheet 2 of 8)

Logical Node	Attribute	Data Source	Comment
LLN0	Loc.stVal	LOC	Control authority at local (bay) level
LLN0	LocSta.stVal	LOCSTA	Control authority at station level
LLN0	LocKey.stVal	NOOP	
DevIDLPHD1	Sim.stVal	LPHDSIM	IEC 61850 logical node for physical device simulation
DevIDLPHD1	PhyHealth.stVal	EN?3:1[h]	Relay enabled
EALCCH1	ChLiv.stVal	EACH[b, c]	Status of engineering access channel
EALCCH1	RxCnt.actVal	EARX[b, c]	Number of non-SV, non-GOOSE frames received on the engineering access channel
EALCCH1	TxCnt.actVal	EATX[b, c]	Number of frames transmitted on the engineering access channel
EALCCH1	RsStat.stVal	EARST[b, c]	Status of engineering access statistics reset
GOLCCH2	ChLiv.stVal	GOCH[b]	Status of primary GOOSE channel
GOLCCH2	RedChLiv.stVal	GORCH[b]	Status of redundant GOOSE channel
GOLCCH2	RxCnt.actVal	GORX[b]	Number of frames received over the primary GOOSE channel
GOLCCH2	RedRxCnt.actVal	GORRX[b]	Number of frames received over the redundant GOOSE channel
GOLCCH2	TxCnt.actVal	GOTX[b]	Number of frames transmitted on both primary and redundant GOOSE channels
GOLCCH2	FerCh.stValj	GOFER[b]	Frame error rate on the primary GOOSE channel
GOLCCH2	RedFerCh.stValj	GORFER[b]	Frame error rate on the redundant GOOSE channel
GOLCCH2	RsStat.stVal	GORST[b]	Status of statistics reset for GOOSE traffic
IPLCCH1	ChLiv.stVal	IPCH[b]	Status of primary IP channel
IPLCCH1	RedChLiv.stVal	IPRCH[b]	Status of redundant IP channel
IPLCCH1	RxCnt.actVal	IPRX[b]	Number of frames received over the primary IP channel
IPLCCH1	RedRxCnt.actVal	IPRRX[b]	Number of frames received over the redundant IP channel
IPLCCH1	TxCnt.actVal	IPTX[b]	Number of frames transmitted on both primary and redundant IP channels
IPLCCH1	FerCh.stVal	IPFER[b]	Frame error rate on the primary IP channel
IPLCCH1	RedFerCh.stValj	IPRFER[b]	Frame error rate on the redundant IP channel
IPLCCH1	RsStat.stVal	IPRST[b]	Status of statistics reset for general IP traffic (excludes GOOSE, SV, and 87L traffic)
LGOS*n*[d]	NdsCom.stVal	GNCM*n*[e]	Subscription needs commissioning for GOOSE Message *n*. True if ConfRevNum does not match RxConfRevNum
LGOS*n*[d]	St.stVal	GST*n*[e]	Status of the subscription (True = active, False = not active) for GOOSE Message *n*
LGOS*n*[d]	SimSt.stVal	GSIM*n*[e]	Status showing that simulation messages are received and accepted for GOOSE Message *n*
LGOS*n*[d]	LastStNum.stVal	GLST*n*[e]	Last state number received (StNum) for GOOSE Message *n*
LGOS*n*[d]	LastSqNum.stVal	GLSQ*n*[e]	Last sequence number received (SqNum) for GOOSE Message *n*
LGOS*n*[d]	LastTal.stVal	GTAL*n*[e]	Last time-allowed-to-live received (TTL) for GOOSE Message *n*
LGOS*n*[d]	ConfRevNum.stVal	–	Expected configuration revision number for GOOSE Message *n*
LGOS*n*[d]	RxConfRevNum.stVal	GCNF*n*[e]	Received configuration revision number for GOOSE Message *n*
LGOS*n*[d]	ErrSt.stVal	GERR*n*[e]	Error status of the subscription for GOOSE Message *n*
LGOS*n*[d]	OosCnt.stVal	GOOS*n*[e]	Number of out-of-sequence (OOS) errors for GOOSE Message *n*
LGOS*n*[d]	TalCnt.stVal	GTLC*n*[e]	Number of time-allowed-to-live violations for GOOSE Message *n*
LGOS*n*[d]	DecErrCnt.stVal	GDER*n*[e]	Number of messages that failed decoding for GOOSE Message *n*

Table 17.28 Logical Device: CFG (Configuration) (Sheet 3 of 8)

Logical Node	Attribute	Data Source	Comment
LGOS*n*[d]	BufOvflCnt.stVal	GBFO*n*[e]	Number of messages lost because of buffer overflow for GOOSE Message *n*
LGOS*n*[d]	MsgLosCnt.stVal	GMSL*n*[e]	Number of messages lost due to OOS errors (estimated) for GOOSE Message *n*
LGOS*n*[d]	MaxMsgLos.stVal	GMXM*n*[e]	Maximum number of sequential messages lost because of OOS error (estimated) for GOOSE Message *n*
LGOS*n*[d]	InvQualCnt.stVal	GIDQ*n*[e]	Number of mapped incoming GOOSE data with invalid quality for GOOSE Message *n*
LGOS*n*[d]	RsStat.stVal	GRST*n*[e]	Status of statistics reset for GOOSE messages
LSVS*n*[f]	NdsCom.stVal	SNCM*n*[e]	Subscription needs commissioning for SV Stream *n*. True if ConfRevNum does not match RxConfRevNum
LSVS*n*[f]	St.stVal	SST*n*[e]	Status of the subscription (True = active, False = not active) for SV Stream *n*
LSVS*n*[f]	SimSt.stVal	SSIM*n*[e]	Status showing that simulation messages are received and accepted for SV Stream *n*
LSVS*n*[f]	ConfRevNum.stVal	–[i]	Expected configuration revision number for SV Stream *n*
LSVS*n*[f]	RxConfRevNum.stVal	SCNF*n*[e]	Received configuration revision number for SV Stream *n*
LSVS*n*[f]	SmpSynch.stVal,	SSMP*n*[e]	Synchronization state for SV Stream *n*
LSVS*n*[f]	ErrSt.stVal	SERR*n*[e]	Error status of the subscription for SV Stream *n*
LSVS*n*[f]	OosCnt.stVal	SOOS*n*[e]	Number of OOS errors for SV Stream *n*
LSVS*n*[f]	DscdCnt.stVal	SDIS*n*[e]	Number of messages that were discarded for SV Stream *n*
LSVS*n*[f]	IntpCnt.stVal	SINT*n*[e]	Number of messages interpolated for SV Stream *n*
LSVS*n*[f]	RsStat.stVal	SRST*n*[e]	Status of statistics reset for SV Stream *n*
LTIM	TmDT.stVal	TMDT[b]	Indicates daylight-saving time is currently in effect at the IED location
LTMS	TmAcc.stVal	TSACC[b]	Number of significant bits in the FractionOfSecond (an attribute of TimeStamp) 20: 1 ms accuracy (2–20) 10: 1 ms accuracy (2–10) 7: 10 ms accuracy (2–7) 31: Unknown accuracy
LTMS	TmSrc.stVal	TSSRC[b]	Time-source identity If TmSrcTyp is PTP: For ICD files with ClassFileVersion 010 or later, TmSrc indicates the grandmaster clock identity according to IEC/IEEE 61855:2021 For ICD files with ClassFile version earlier than 010, TmSrc indicates the timeSource enumeration according to IEEE 1588-2008 If TmSrcTyp is SNTP, TmSrc indicates the IP address of the SNTP server For all other values of TmSrcTyp, TmSrc is set to “NA”
LTMS	TmSrcTyp.stVal	TSTYPE[b]	Type of the clock source as defined by Relay Word bits TSNTP, TPTP, and TIRIG 1: Unknown 2: SNTP 3: PTP 4: IRIG-B

Table 17.28 Logical Device: CFG (Configuration) (Sheet 4 of 8)

Logical Node	Attribute	Data Source	Comment
LTMS	TmSyn.stVal	TSSYN[b]	Traceability of the reference time to which the IED is synchronized 2: GlobalAreaClock—Time synchronized to a clock that is traceable to a global reference, or TmSrcTyp is SNTP 1: LocalAreaClock—Time synchronized to a local area clock that is not traceable to a global reference 0: InternalClock—Not synchronized to an external clock source
LTMS	TmSynLkd.stVal	TSSYNLK[b]	Status of clock synchronization: 1: Locked 2: Unlocked for 0–10 seconds 3: Unlocked for 10–100 seconds 4: Unlocked for 100–1000 seconds 5: Unlocked for more than 1000 seconds
PBLCCH1	ChLiv.stVal	PBCH[b, c]	Status of process bus primary channel
PBLCCH1	RedChLiv.stVal	PBRCH[b, c]	Status of process bus redundant channel
PBLCCH1	RxCnt.actVal	PBRX[b, c]	Number of non-SV, non-GOOSE frames received on the process bus primary channel
PBLCCH1	RedRxCnt.actVal	PBRRX[b, c]	Number of non-SV, non-GOOSE frames received on the process bus redundant channel
PBLCCH1	RxCntGo.actVal	PBRXGO[b, c]	Number of GOOSE frames received on the process bus primary channel
PBLCCH1	RedRxCntGo.actVal	PBRRXGO[b, c]	Number of GOOSE frames received on the process bus redundant channel
PBLCCH1	RxCntSv.actVal	PBRXSV[b, c]	Number of SV frames received on the process bus primary channel
PBLCCH1	RedRxCntSv.actVal	PBRRXSV[b, c]	Number of SV frames received on the process bus redundant channel
PBLCCH1	TxCnt.actVal	PBTX[b, c]	Number of frames transmitted on both process bus channels
PBLCCH1	FerCh.stVal	PBFER[b, c]	Number of non-SV, non-GOOSE PRP frames missed on the process bus primary channel over the last 1000 processed PRP frames
PBLCCH1	RedFerCh.stVal	PBRFER[b, c]	Number of non-SV, non-GOOSE PRP frames missed on the process bus redundant channel over the last 1000 processed PRP frames
PBLCCH1	FerChGo.stVal	PBFRGO[b, c]	Number of GOOSE PRP frames missed on the process bus primary channel over the last 1000 processed PRP frames
PBLCCH1	RedFerChGo.stVal	PBRFRGO[b, c]	Number of GOOSE PRP frames missed on the process bus redundant channel over the last 1000 processed PRP frames
PBLCCH1	FerChSv.stVal	PBFRSV[b, c]	Number of SV PRP frames missed on the process bus primary channel over the last second
PBLCCH1	RedFerChSv.stVal	PBRFRSV[b, c]	Number of SV PRP frames missed on the process bus redundant channel over the last second
PBLCCH1	RsStat.stVal	PBRST[b, c]	Status of process bus statistics reset
SBLCCH1	ChLiv.stVal	SBCH[b, c]	Status of station bus primary channel
SBLCCH1	RedChLiv.stVal	SBRCH[b, c]	Status of station bus redundant channel
SBLCCH1	RxCnt.actVal	SBRX[b, c]	Number of non-SV, non-GOOSE frames received on the station bus primary channel
SBLCCH1	RedRxCnt.actVal	SBRRX[b, c]	Number of non-SV, non-GOOSE frames received on the station bus redundant channel
SBLCCH1	RxCntGo.actVal	SBRXGO[b, c]	Number of GOOSE frames received on the station bus primary channel
SBLCCH1	RedRxCntGo.actVal	SBRRXGO[b, c]	Number of GOOSE frames received on the station bus redundant channel
SBLCCH1	TxCnt.actVal	SBTX[b, c]	Number of frames transmitted on both station bus channels
SBLCCH1	FerCh.stVal	SBFER[b, c]	Number of non-SV, non-GOOSE PRP frames missed on the station bus primary channel over the last 1000 processed PRP frames

Table 17.28 Logical Device: CFG (Configuration) (Sheet 5 of 8)

Logical Node	Attribute	Data Source	Comment
SBLCCH1	RedFerCh.stVal	SBRFER[b, c]	Number of non-SV, non-GOOSE PRP frames missed on the station bus redundant channel over the last 1000 processed PRP frames
SBLCCH1	FerChGo.stVal	SBFRGO[b, c]	Number of GOOSE PRP frames missed on the station bus primary channel over the last 1000 processed PRP frames
SBLCCH1	RedFerChGo.stVal	SBRFRGO[b, c]	Number of GOOSE PRP frames missed on the station bus redundant channel over the last 1000 processed PRP frames
SBLCCH1	RsStat.stVal	SBRST[b, c]	Status of station bus statistics reset
Functional Constraint = MX			
LGOS*n*[d]	TotDwnTm.instMag.f	GDWT*n*[e]	Total downtime in seconds for GOOSE Message *n*
LGOS*n*[d]	MaxDwnTm.instMag.f	GMXD*n*[e]	Maximum continuous downtime in seconds for GOOSE Message *n*
LSVS*n*[f]	NetwDly.instMag.f	SNET*n*[e]	Network delay in milliseconds for SV Stream *n*
LSVS*n*[f]	TotDwnTm.instMag.f	SDWT*n*[e]	Total downtime in seconds for SV Stream *n*
LSVS*n*[f]	MaxDwnTm.instMag.f	SMXD*n*[e]	Maximum continuous downtime in seconds for SV Stream *n*
LTMS	TmTosPer.instMag.f	TSPER[b]	Duration, in milliseconds, between two consecutive top-of-second points on the synchronized time; TmTosPer is set to 0 for time sources other than high-accuracy PTP or IRIG-B
Functional Constraint = SP			
LLN0	MltLev.setVal	MLTLEV	Multi-level mode of control authority
EALCCH1	ApNam.setVal	–[c, i]	Access point name for the engineering access channel
GOLCCH2	NetMod.setVal	NETMODE	PORT 5 network operating mode setting (1: Fixed, 2: Failover, 3: Switched, 4: PRP, 5: IsolatedIP)
IPLCCH1	NetMod.setVal	NETMODE	PORT 5 network operating mode setting (1: Fixed, 2: Failover, 3: Switched, 4: PRP, 5: IsolatedIP).
LGOS*n*[d]	GoCBRef.setSrcRef	–[i]	Configured GOOSE control block reference for GOOSE Message *n*
LGOS*n*[d]	DatSet.setSrcRef	–[i]	Configured data set reference for GOOSE Message *n*
LGOS*n*[d]	GoID.setVal	–[i]	Configured ID for GOOSE Message *n*
LGOS*n*[d]	Addr.setVal	–[i]	Configured multicast MAC address for GOOSE Message *n*
LGOS*n*[d]	VlanID.setVal	–[i]	Configured VLAN ID for GOOSE Message *n*
LGOS*n*[d]	VlanPri.setVal	–[i]	Configured VLAN priority for GOOSE Message *n*
LGOS*n*[d]	AppID.setVal	–[i]	Configured APPID for GOOSE Message *n*
LSVS*n*[f]	SvCBRef.setSrcRef	–[i]	Configured SV control block reference for SV Stream *n*
LSVS*n*[f]	DatSet.setSrcRef	–[i]	Configured data set reference for SV Stream *n*
LSVS*n*[f]	SvID.setVal	–[i]	Configured SV ID for SV Stream *n*
LSVS*n*[f]	Addr.setVal	–[i]	Configured multicast MAC address for SV Stream *n*
LSVS*n*[f]	VlanID.setVal	–[i]	Configured VLAN ID for SV Stream *n*
LSVS*n*[f]	VlanPri.setVal	–[i]	Configured VLAN priority for SV Stream *n*
LSVS*n*[f]	AppID.setVal	–[i]	Configured APPID for SV Stream *n*
LTIM	TmOfsTmm.setVal	TMOFFS[b]	Offset of local time from UTC in minutes
LTIM	TmUseDT.setVal	TMUSEDT[b]	Set to True if daylight-saving time is enabled
LTIM	TmChgDT.setTm	TMCHGDT[b]	Local time of next change to daylight-saving time
LTIM	TmChgST.setTm	TMCHGST[b]	Local time of next change to standard time
PBLCCH1	ApNam.setVal	–[c, i]	Access point name for the process bus
PBLCCH1	NetModP.setVal	NETMODP[c]	PORT 5 network operating mode setting for the process bus (1: Fixed, 2: Failover, 3: PRP)

Table 17.28 Logical Device: CFG (Configuration) (Sheet 6 of 8)

Logical Node	Attribute	Data Source	Comment
PBLCCH1	BusMode.setVal	BUSMODE[c]	PORT 5 bus operating mode setting (1: Independent, 2: Merged)
PBLCCH1	NetPorP.setVal	NETPORP[c]	PORT 5 primary network port setting for the process bus (1: A, 2: B)
SBLCCH1	ApNam.setVal	_[c, i]	Access point name for the station bus
SBLCCH1	NetMode.setVal	NETMODE[c]	PORT 5 network operating mode setting for the station bus (1: Fixed, 2: Failover, 3: PRP)
SBLCCH1	BusMode.setVal	BUSMODE[c]	PORT 5 bus operating mode setting (1: Independent, 2: Merged)
SBLCCH1	NetPort.setVal	NETPORT[c]	PORT 5 primary network port setting for the station bus (1: C, 2: D)
Functional Constraint = SR			
LTRK1	SpcTrk.objRef	_[j]	ACSI reference to the SPC object targeted in the request
LTRK1	SpcTrk.serviceType	_[j, k]	Type of service requested or executed
LTRK1	SpcTrk.errorCode	_[j, l]	ACSI service error status
LTRK1	SpcTrk.ctlVal	_[j]	Control value in the request
LTRK1	SpcTrk.ctlNum	_[j]	Control number in the request
LTRK1	SpcTrk.origin.orCat	_[j]	Originator category value in the request
LTRK1	SpcTrk.origin.orIdent	_[j]	Originator identity value in the request
LTRK1	SpcTrk.T	_[j]	Time-stamp value in the request
LTRK1	SpcTrk.Test	_[j]	Test value in the request
LTRK1	SpcTrk.Check	_[j]	Check condition value in the request
LTRK1	SpcTrk.respAddCause	_[j]	AddCause value returned in the response
LTRK1	DpcTrk.objRef	_[j]	ACSI reference of the DPC object targeted in the request
LTRK1	DpcTrk.serviceType	_[j, k]	Type of service requested or executed
LTRK1	DpcTrk.errorCode	_[j, l]	ACSI service error status
LTRK1	DpcTrk.ctlVal	_[j]	Control value in the request
LTRK1	DpcTrk.ctlNum	_[j]	Control number in the request
LTRK1	DpcTrk.origin.orCat	_[j]	Originator category value in the request
LTRK1	DpcTrk.origin.orIdent	_[j]	Originator identity value in the request
LTRK1	DpcTrk.T	_[j]	Time-stamp value in the request
LTRK1	DpcTrk.Test	_[j]	Test value in the request
LTRK1	DpcTrk.Check	_[j]	Check condition value in the request
LTRK1	DpcTrk.respAddCause	_[j]	AddCause value returned in the response
LTRK1	EncTrk.objRef	_[j]	ACSI reference of the ENC object targeted in the request
LTRK1	EncTrk.serviceType	_[j, k]	Type of service requested or executed
LTRK1	EncTrk.errorCode	_[j, l]	ACSI service error status
LTRK1	EncTrk.ctlVal	_[j]	Control value in the request
LTRK1	EncTrk.ctlNum	_[j]	Control number in the request
LTRK1	EncTrk.origin.orCat	_[j]	Originator category value in the request
LTRK1	EncTrk.origin.orIdent	_[j]	Originator identity value in the request
LTRK1	EncTrk.T	_[j]	Time-stamp value in the request
LTRK1	EncTrk.Test	_[j]	Test value in the request
LTRK1	EncTrk.Check	_[j]	Check condition value in the request
LTRK1	EncTrk.respAddCause	_[j]	AddCause value returned in the response

Table 17.28 Logical Device: CFG (Configuration) (Sheet 7 of 8)

Logical Node	Attribute	Data Source	Comment
LTRK1	BrcbTrk.objRef	_[j]	ACSI reference of the BRCB object targeted in the request
LTRK1	BrcbTrk.serviceType	_[j, k]	Type of service requested or executed
LTRK1	BrcbTrk.errorCode	_[j, l]	ACSI service error status
LTRK1	BrcbTrk.rptID	_[j]	RptID attribute value in the request or target BRCB object
LTRK1	BrcbTrk.rptEna	_[j]	RptEna attribute value in the request or target BRCB object
LTRK1	BrcbTrk.datSet	_[j]	DatSet attribute value in the target BRCB object
LTRK1	BrcbTrk.confRev	_[j]	ConfRev attribute value in the target BRCB object
LTRK1	BrcbTrk.optFlds	_[j]	OptFlds attribute value in the request or target BRCB object
LTRK1	BrcbTrk.bufTm	_[j]	BufTm attribute value in the request or target BRCB object
LTRK1	BrcbTrk.sqNum	_[j]	SqNum attribute value in the target BRCB object
LTRK1	BrcbTrk.trgOps	_[j]	TrgOps attribute value in the request or target BRCB object
LTRK1	BrcbTrk.intgPd	_[j]	IntgPd attribute value in the request or target BRCB object
LTRK1	BrcbTrk.gi	_[j]	GI attribute value in the request or target BRCB object
LTRK1	BrcbTrk.purgeBuf	_[j]	PurgeBuf attribute value in the request or target BRCB object
LTRK1	BrcbTrk.entryID	_[j]	EntryID attribute value in the request or target BRCB object
LTRK1	BrcbTrk.timeOfEntry	_[j]	TimeOfEntry attribute value in the target BRCB object
LTRK1	UrcbTrk.objRef	_[j]	ACSI reference of the URCB object targeted in the request
LTRK1	UrcbTrk.serviceType	_[j, k]	Type of service requested or executed
LTRK1	UrcbTrk.errorCode	_[j, l]	ACSI service error status
LTRK1	UrcbTrk.rptID	_[j]	RptID attribute value in the request or target URCB object
LTRK1	UrcbTrk.rptEna	_[j]	RptEna attribute value in the request or target URCB object
LTRK1	UrcbTrk.resv	_[j]	Resv attribute value in the request or target URCB object
LTRK1	UrcbTrk.datSet	_[j]	DatSet attribute value in the target URCB object
LTRK1	UrcbTrk.confRev	_[j]	ConfRev attribute value in the target URCB object
LTRK1	UrcbTrk.optFlds	_[j]	OptFlds attribute value in the request or target URCB object
LTRK1	UrcbTrk.bufTm	_[j]	BufTm attribute value in the request or target URCB object
LTRK1	UrcbTrk.sqNum	_[j]	SqNum attribute value in the target URCB object
LTRK1	UrcbTrk.trgOps	_[j]	TrgOps attribute value in the request or target URCB object
LTRK1	UrcbTrk.intgPd	_[j]	IntgPd attribute value in the request or target URCB object
LTRK1	UrcbTrk.gi	_[j]	GI attribute value in the request or target URCB object
LTRK1	SgcbTrk.objRef	_[j]	ACSI reference of the SGCB object targeted in the request
LTRK1	SgcbTrk.serviceType	_[j, k]	Type of service requested (SelectActiveSG)
LTRK1	SgcbTrk.errorCode	_[j, l]	ACSI service error status
LTRK1	SgcbTrk.numOfSG	_[j]	NumOfSG attribute value in the target SGCB object
LTRK1	SgcbTrk.actSG	_[j]	ActSG attribute value in the request
LTRK1	SgcbTrk.editSG	_[j]	EditSG attribute value in the target SGCB object (0)

Table 17.28 Logical Device: CFG (Configuration) (Sheet 8 of 8)

Logical Node	Attribute	Data Source	Comment
LTRK1	SgcbTrk.cnfEdit	_[j]	CnfEdit attribute value in the target SGCB object (FALSE)
LTRK1	SgcbTrk.lActTm	_[j]	LActTm attribute value in the target SGCB object after the activation of the settings group via MMS or non-MMS means

[a] I60MOD is an internal data source derived from the I850MOD analog quantity and is not available to the user.
[b] Internal data source and not available to the user.
[c] Only applicable when using the five-port Ethernet card.
[d] Where n = 1–64, corresponding to the first 64 GOOSE message subscriptions.
[e] Internal data source not available to the user. See COM SV on page 14.18 and GOOSE on page 14.38 for more information.
[f] Where n = 1–7, corresponding to each of the seven possible SV subscriptions.
[g] HWREV is an internal data source and is not available to the user.
[h] If enabled, value = 1. If disabled, value = 3.
[i] Data source defined in the IEC 61850 Configured IED Description (CID) file.
[j] The value depends on the ACSI service type requested, the target object, and the error status.
[k] Refer to Table 17.12 IEC 61850 service type enumeration.
[l] Refer to Table 17.13 IEC 61850 ACSI service error.

Table 17.29 shows the LNs associated with control elements, defined as Logical Device CON.

NOTE: For logical node PRBGGIO, writing TRUE to either operSet or operClear pulses the remote bit.

Table 17.29 Logical Device: CON (Remote Control) (Sheet 1 of 6)

Logical Node	Attribute	Data Source	Comment
Functional Constraint = CO			
RB1GGIO1[a]	SPCSO01.Oper.ctlVal	RB01	Remote Bit 1
RB1GGIO1[a]	SPCSO02.Oper.ctlVal	RB02	Remote Bit 2
RB1GGIO1[a]	SPCSO03.Oper.ctlVal	RB03	Remote Bit 3
RB1GGIO1[a]	SPCSO04.Oper.ctlVal	RB04	Remote Bit 4
RB1GGIO1[a]	SPCSO05.Oper.ctlVal	RB05	Remote Bit 5
RB1GGIO1[a]	SPCSO06.Oper.ctlVal	RB06	Remote Bit 6
RB1GGIO1[a]	SPCSO07.Oper.ctlVal	RB07	Remote Bit 7
RB1GGIO1[a]	SPCSO08.Oper.ctlVal	RB08	Remote Bit 8
RB2GGIO1[a]	SPCSO09.Oper.ctlVal	RB09	Remote Bit 9
RB2GGIO1[a]	SPCSO10.Oper.ctlVal	RB10	Remote Bit 10
RB2GGIO1[a]	SPCSO11.Oper.ctlVal	RB11	Remote Bit 11
RB2GGIO1[a]	SPCSO12.Oper.ctlVal	RB12	Remote Bit 12
RB2GGIO1[a]	SPCSO13.Oper.ctlVal	RB13	Remote Bit 13
RB2GGIO1[a]	SPCSO14.Oper.ctlVal	RB14	Remote Bit 14
RB2GGIO1[a]	SPCSO15.Oper.ctlVal	RB15	Remote Bit 15
RB2GGIO1[a]	SPCSO16.Oper.ctlVal	RB16	Remote Bit 16
RB3GGIO1[a]	SPCSO17.Oper.ctlVal	RB17	Remote Bit 17
RB3GGIO1[a]	SPCSO18.Oper.ctlVal	RB18	Remote Bit 18
RB3GGIO1[a]	SPCSO19.Oper.ctlVal	RB19	Remote Bit 19
RB3GGIO1[a]	SPCSO20.Oper.ctlVal	RB20	Remote Bit 20
RB3GGIO1[a]	SPCSO21.Oper.ctlVal	RB21	Remote Bit 21
RB3GGIO1[a]	SPCSO22.Oper.ctlVal	RB22	Remote Bit 22
RB3GGIO1[a]	SPCSO23.Oper.ctlVal	RB23	Remote Bit 23
RB3GGIO1[a]	SPCSO24.Oper.ctlVal	RB24	Remote Bit 24

Table 17.29 Logical Device: CON (Remote Control) (Sheet 2 of 6)

Logical Node	Attribute	Data Source	Comment
RB4GGIO1[a]	SPCSO25.Oper.ctlVal	RB25	Remote Bit 25
RB4GGIO1[a]	SPCSO26.Oper.ctlVal	RB26	Remote Bit 26
RB4GGIO1[a]	SPCSO27.Oper.ctlVal	RB27	Remote Bit 27
RB4GGIO1[a]	SPCSO28.Oper.ctlVal	RB28	Remote Bit 28
RB4GGIO1[a]	SPCSO29.Oper.ctlVal	RB29	Remote Bit 29
RB4GGIO1[a]	SPCSO30.Oper.ctlVal	RB30	Remote Bit 30
RB4GGIO1[a]	SPCSO31.Oper.ctlVal	RB31	Remote Bit 31
RB4GGIO1[a]	SPCSO32.Oper.ctlVal	RB32	Remote Bit 32
RB5GGIO1	SPCSO33.Oper.ctlVal	RB33	Remote Bit 33
RB5GGIO1	SPCSO34.Oper.ctlVal	RB34	Remote Bit 34
RB5GGIO1	SPCSO35.Oper.ctlVal	RB35	Remote Bit 35
RB5GGIO1	SPCSO36.Oper.ctlVal	RB36	Remote Bit 36
RB5GGIO1	SPCSO37.Oper.ctlVal	RB37	Remote Bit 37
RB5GGIO1	SPCSO38.Oper.ctlVal	RB38	Remote Bit 38
RB5GGIO1	SPCSO39.Oper.ctlVal	RB39	Remote Bit 39
RB5GGIO1	SPCSO40.Oper.ctlVal	RB40	Remote Bit 40
RB6GGIO1	SPCSO41.Oper.ctlVal	RB41	Remote Bit 41
RB6GGIO1	SPCSO42.Oper.ctlVal	RB42	Remote Bit 42
RB6GGIO1	SPCSO43.Oper.ctlVal	RB43	Remote Bit 43
RB6GGIO1	SPCSO44.Oper.ctlVal	RB44	Remote Bit 44
RB6GGIO1	SPCSO45.Oper.ctlVal	RB45	Remote Bit 45
RB6GGIO1	SPCSO46.Oper.ctlVal	RB46	Remote Bit 46
RB6GGIO1	SPCSO47.Oper.ctlVal	RB47	Remote Bit 47
RB6GGIO1	SPCSO48.Oper.ctlVal	RB48	Remote Bit 48
RB7GGIO1	SPCSO49.Oper.ctlVal	RB49	Remote Bit 49
RB7GGIO1	SPCSO50.Oper.ctlVal	RB50	Remote Bit 50
RB7GGIO1	SPCSO51.Oper.ctlVal	RB51	Remote Bit 51
RB7GGIO1	SPCSO52.Oper.ctlVal	RB52	Remote Bit 52
RB7GGIO1	SPCSO53.Oper.ctlVal	RB53	Remote Bit 53
RB7GGIO1	SPCSO54.Oper.ctlVal	RB54	Remote Bit 54
RB7GGIO1	SPCSO55.Oper.ctlVal	RB55	Remote Bit 55
RB7GGIO1	SPCSO56.Oper.ctlVal	RB56	Remote Bit 56
RB8GGIO1	SPCSO57.Oper.ctlVal	RB57	Remote Bit 57
RB8GGIO1	SPCSO58.Oper.ctlVal	RB58	Remote Bit 58
RB8GGIO1	SPCSO59.Oper.ctlVal	RB59	Remote Bit 59
RB8GGIO1	SPCSO60.Oper.ctlVal	RB60	Remote Bit 60
RB8GGIO1	SPCSO61.Oper.ctlVal	RB61	Remote Bit 61
RB8GGIO1	SPCSO62.Oper.ctlVal	RB62	Remote Bit 62
RB8GGIO1	SPCSO63.Oper.ctlVal	RB63	Remote Bit 63
RB8GGIO1	SPCSO64.Oper.ctlVal	RB64	Remote Bit 64
RB9GGIO1[b]	SPCSO65.Oper.ctlVal	RB65	Remote Bit 65

Table 17.29 Logical Device: CON (Remote Control) (Sheet 3 of 6)

Logical Node	Attribute	Data Source	Comment
RB9GGIO1[b]	SPCSO66.Oper.ctlVal	RB66	Remote Bit 66
RB9GGIO1[b]	SPCSO67.Oper.ctlVal	RB67	Remote Bit 67
RB9GGIO1[b]	SPCSO68.Oper.ctlVal	RB68	Remote Bit 68
RB9GGIO1[b]	SPCSO69.Oper.ctlVal	RB69	Remote Bit 69
RB9GGIO1[b]	SPCSO70.Oper.ctlVal	RB70	Remote Bit 70
RB9GGIO1[b]	SPCSO71.Oper.ctlVal	RB71	Remote Bit 71
RB9GGIO1[b]	SPCSO72.Oper.ctlVal	RB72	Remote Bit 72
RB10GGIO1[b]	SPCSO73.Oper.ctlVal	RB73	Remote Bit 73
RB10GGIO1[b]	SPCSO74.Oper.ctlVal	RB74	Remote Bit 74
RB10GGIO1[b]	SPCSO75.Oper.ctlVal	RB75	Remote Bit 75
RB10GGIO1[b]	SPCSO76.Oper.ctlVal	RB76	Remote Bit 76
RB10GGIO1[b]	SPCSO77.Oper.ctlVal	RB77	Remote Bit 77
RB10GGIO1[b]	SPCSO78.Oper.ctlVal	RB78	Remote Bit 78
RB10GGIO1[b]	SPCSO79.Oper.ctlVal	RB79	Remote Bit 79
RB10GGIO1[b]	SPCSO80.Oper.ctlVal	RB80	Remote Bit 80
RB11GGIO1[b]	SPCSO81.Oper.ctlVal	RB81	Remote Bit 81
RB11GGIO1[b]	SPCSO82.Oper.ctlVal	RB82	Remote Bit 82
RB11GGIO1[b]	SPCSO83.Oper.ctlVal	RB83	Remote Bit 83
RB11GGIO1[b]	SPCSO84.Oper.ctlVal	RB84	Remote Bit 84
RB11GGIO1[b]	SPCSO85.Oper.ctlVal	RB85	Remote Bit 85
RB11GGIO1[b]	SPCSO86.Oper.ctlVal	RB86	Remote Bit 86
RB11GGIO1[b]	SPCSO87.Oper.ctlVal	RB87	Remote Bit 87
RB11GGIO1[b]	SPCSO88.Oper.ctlVal	RB88	Remote Bit 88
RB12GGIO1[b]	SPCSO89.Oper.ctlVal	RB89	Remote Bit 89
RB12GGIO1[b]	SPCSO90.Oper.ctlVal	RB90	Remote Bit 90
RB12GGIO1[b]	SPCSO91.Oper.ctlVal	RB91	Remote Bit 91
RB12GGIO1[b]	SPCSO92.Oper.ctlVal	RB92	Remote Bit 92
RB12GGIO1[b]	SPCSO93.Oper.ctlVal	RB93	Remote Bit 93
RB12GGIO1[b]	SPCSO94.Oper.ctlVal	RB94	Remote Bit 94
RB12GGIO1[b]	SPCSO95.Oper.ctlVal	RB95	Remote Bit 95
RB12GGIO1[b]	SPCSO96.Oper.ctlVal	RB96	Remote Bit 96
Functional Constraint = DC			
CTRLLPHD1	PhyNam.model	PARNUM	Relay part number string
CTRLLPHD1	PhyNam.hwRev	HWREV[c]	Hardware version of the relay main board
CTRLLPHD1	PhyNam.serNum	SERNUM	Relay serial number
LLN0	NamPlt.swRev	VERFID	Relay FID string
Functional Constraint = ST			
CTRLLPHD1	PhyHealth.stVal	EN?3:1[d]	Relay enabled
LLN0	Mod.stVal	I60MOD[e]	IEC 61850 mode/behavior status
LLN0	Loc.stVal	LOC	Control authority at local (bay) level

Table 17.29 Logical Device: CON (Remote Control) (Sheet 4 of 6)

Logical Node	Attribute	Data Source	Comment
LLN0	LocSta.stVal	LOCSTA	Control authority at station level
LLN0	LocKey.stVal	NOOP	
RB1GGIO1	SPCSO01.stVal	RB01	Remote Bit 1
RB1GGIO1	SPCSO02.stVal	RB02	Remote Bit 2
RB1GGIO1	SPCSO03.stVal	RB03	Remote Bit 3
RB1GGIO1	SPCSO04.stVal	RB04	Remote Bit 4
RB1GGIO1	SPCSO05.stVal	RB05	Remote Bit 5
RB1GGIO1	SPCSO06.stVal	RB06	Remote Bit 6
RB1GGIO1	SPCSO07.stVal	RB07	Remote Bit 7
RB1GGIO1	SPCSO08.stVal	RB08	Remote Bit 8
RB2GGIO1	SPCSO09.stVal	RB09	Remote Bit 9
RB2GGIO1	SPCSO10.stVal	RB10	Remote Bit 10
RB2GGIO1	SPCSO11.stVal	RB11	Remote Bit 11
RB2GGIO1	SPCSO12.stVal	RB12	Remote Bit 12
RB2GGIO1	SPCSO13.stVal	RB13	Remote Bit 13
RB2GGIO1	SPCSO14.stVal	RB14	Remote Bit 14
RB2GGIO1	SPCSO15.stVal	RB15	Remote Bit 15
RB2GGIO1	SPCSO16.stVal	RB16	Remote Bit 16
RB3GGIO1	SPCSO17.stVal	RB17	Remote Bit 17
RB3GGIO1	SPCSO18.stVal	RB18	Remote Bit 18
RB3GGIO1	SPCSO19.stVal	RB19	Remote Bit 19
RB3GGIO1	SPCSO20.stVal	RB20	Remote Bit 20
RB3GGIO1	SPCSO21.stVal	RB21	Remote Bit 21
RB3GGIO1	SPCSO22.stVal	RB22	Remote Bit 22
RB3GGIO1	SPCSO23.stVal	RB23	Remote Bit 23
RB3GGIO1	SPCSO24.stVal	RB24	Remote Bit 24
RB4GGIO1	SPCSO25.stVal	RB25	Remote Bit 25
RB4GGIO1	SPCSO26.stVal	RB26	Remote Bit 26
RB4GGIO1	SPCSO27.stVal	RB27	Remote Bit 27
RB4GGIO1	SPCSO28.stVal	RB28	Remote Bit 28
RB4GGIO1	SPCSO29.stVal	RB29	Remote Bit 29
RB4GGIO1	SPCSO30.stVal	RB30	Remote Bit 30
RB4GGIO1	SPCSO31.stVal	RB31	Remote Bit 31
RB4GGIO1	SPCSO32.stVal	RB32	Remote Bit 32
RB5GGIO1	SPCSO33.stVal	RB33	Remote Bit 33
RB5GGIO1	SPCSO34.stVal	RB34	Remote Bit 34
RB5GGIO1	SPCSO35.stVal	RB35	Remote Bit 35
RB5GGIO1	SPCSO36.stVal	RB36	Remote Bit 36
RB5GGIO1	SPCSO37.stVal	RB37	Remote Bit 37
RB5GGIO1	SPCSO38.stVal	RB38	Remote Bit 38
RB5GGIO1	SPCSO39.stVal	RB39	Remote Bit 39

Table 17.29 Logical Device: CON (Remote Control) (Sheet 5 of 6)

Logical Node	Attribute	Data Source	Comment
RB5GGIO1	SPCSO40.stVal	RB40	Remote Bit 40
RB6GGIO1	SPCSO41.stVal	RB41	Remote Bit 41
RB6GGIO1	SPCSO42.stVal	RB42	Remote Bit 42
RB6GGIO1	SPCSO43.stVal	RB43	Remote Bit 43
RB6GGIO1	SPCSO44.stVal	RB44	Remote Bit 44
RB6GGIO1	SPCSO45.stVal	RB45	Remote Bit 45
RB6GGIO1	SPCSO46.stVal	RB46	Remote Bit 46
RB6GGIO1	SPCSO47.stVal	RB47	Remote Bit 47
RB6GGIO1	SPCSO48.stVal	RB48	Remote Bit 48
RB7GGIO1	SPCSO49.stVal	RB49	Remote Bit 49
RB7GGIO1	SPCSO50.stVal	RB50	Remote Bit 50
RB7GGIO1	SPCSO51.stVal	RB51	Remote Bit 51
RB7GGIO1	SPCSO52.stVal	RB52	Remote Bit 52
RB7GGIO1	SPCSO53.stVal	RB53	Remote Bit 53
RB7GGIO1	SPCSO54.stVal	RB54	Remote Bit 54
RB7GGIO1	SPCSO55.stVal	RB55	Remote Bit 55
RB7GGIO1	SPCSO56.stVal	RB56	Remote Bit 56
RB8GGIO1	SPCSO57.stVal	RB57	Remote Bit 57
RB8GGIO1	SPCSO58.stVal	RB58	Remote Bit 58
RB8GGIO1	SPCSO59.stVal	RB59	Remote Bit 59
RB8GGIO1	SPCSO60.stVal	RB60	Remote Bit 60
RB8GGIO1	SPCSO61.stVal	RB61	Remote Bit 61
RB8GGIO1	SPCSO62.stVal	RB62	Remote Bit 62
RB8GGIO1	SPCSO63.stVal	RB63	Remote Bit 63
RB8GGIO1	SPCSO64.stVal	RB64	Remote Bit 64
RB9GGIO1[b]	SPCSO65.stVal	RB65	Remote Bit 65
RB9GGIO1[b]	SPCSO66.stVal	RB66	Remote Bit 66
RB9GGIO1[b]	SPCSO67.stVal	RB67	Remote Bit 67
RB9GGIO1[b]	SPCSO68.stVal	RB68	Remote Bit 68
RB9GGIO1[b]	SPCSO69.stVal	RB69	Remote Bit 69
RB9GGIO1[b]	SPCSO70.stVal	RB70	Remote Bit 70
RB9GGIO1[b]	SPCSO71.stVal	RB71	Remote Bit 71
RB9GGIO1[b]	SPCSO72.stVal	RB72	Remote Bit 72
RB10GGIO1[b]	SPCSO73.stVal	RB73	Remote Bit 73
RB10GGIO1[b]	SPCSO74.stVal	RB74	Remote Bit 74
RB10GGIO1[b]	SPCSO75.stVal	RB75	Remote Bit 75
RB10GGIO1[b]	SPCSO76.stVal	RB76	Remote Bit 76
RB10GGIO1[b]	SPCSO77.stVal	RB77	Remote Bit 77
RB10GGIO1[b]	SPCSO78.stVal	RB78	Remote Bit 78
RB10GGIO1[b]	SPCSO79.stVal	RB79	Remote Bit 79
RB10GGIO1[b]	SPCSO80.stVal	RB80	Remote Bit 80

Table 17.29 Logical Device: CON (Remote Control) (Sheet 6 of 6)

Logical Node	Attribute	Data Source	Comment
RB11GGIO1[b]	SPCSO81.stVal	RB81	Remote Bit 81
RB11GGIO1[b]	SPCSO82.stVal	RB82	Remote Bit 82
RB11GGIO1[b]	SPCSO83.stVal	RB83	Remote Bit 83
RB11GGIO1[b]	SPCSO84.stVal	RB84	Remote Bit 84
RB11GGIO1[b]	SPCSO85.stVal	RB85	Remote Bit 85
RB11GGIO1[b]	SPCSO86.stVal	RB86	Remote Bit 86
RB11GGIO1[b]	SPCSO87.stVal	RB87	Remote Bit 87
RB12GGIO1[b]	SPCSO88.stVal	RB88	Remote Bit 88
RB12GGIO1[b]	SPCSO89.stVal	RB89	Remote Bit 89
RB12GGIO1[b]	SPCSO90.stVal	RB90	Remote Bit 90
RB12GGIO1[b]	SPCSO91.stVal	RB91	Remote Bit 91
RB12GGIO1[b]	SPCSO92.stVal	RB92	Remote Bit 92
RB12GGIO1[b]	SPCSO93.stVal	RB93	Remote Bit 93
RB12GGIO1[b]	SPCSO94.stVal	RB94	Remote Bit 94
RB12GGIO1[b]	SPCSO95.stVal	RB95	Remote Bit 95
RB12GGIO1[b]	SPCSO96.stVal	RB96	Remote Bit 96
Functional Constraint = SP			
LLN0	GrRef.setSrcRef	@CFG	Functional name

[a] The SEL-487V supports only RBGGIO1–RBGGIO4 and PRBGGIO1–PRBGGIO4.
[b] Only the SEL-487B and SEL-487E support RBGGIO9–RBGGIO12 and PRBGGIO9–PRBGGIO12.
[c] HWREV is an internal data source and is not available to the user.
[d] If enabled, value = 1. If disabled, value = 3.
[e] I60MOD is an internal data source derived from the I850MOD analog quantity and is not available to the user.

Table 17.30 shows the LNs associated with the annunciation element, defined as Logical Device ANN.

Table 17.30 Logical Device: ANN (Annunciation) (Sheet 1 of 17)

Logical Node	Attribute	Data Source	Comment
Functional Constraint = CO			
ETH1GGIO1	SPCSO01.Oper.ctlVal	ETHRST[a, b]	Reset Ethernet card statistics
Functional Constraint = DC			
STALPHD1	PhyNam.model	PARNUM	Relay part number string
STALPHD1	PhyNam.hwRev	HWREV[c]	Hardware version of the relay main board
STALPHD1	PhyNam.serNum	SERNUM	Relay serial number
LLN0	NamPlt.swRev	VERFID	Relay FID string
Functional Constraint = MX			
ACN1GGIO1	AnIn001.instMag.f	ACN01CV	Automation SELOGIC Counter 01 current value
ACN1GGIO1	AnIn002.instMag.f	ACN02CV	Automation SELOGIC Counter 02 current value
ACN1GGIO1	AnIn003.instMag.f	ACN03CV	Automation SELOGIC Counter 03 current value
• • •			

Table 17.30 Logical Device: ANN (Annunciation) (Sheet 2 of 17)

Logical Node	Attribute	Data Source	Comment
ACN1GGIO1	AnIn014.instMag.f	ACN14CV	Automation SELOGIC Counter 14 current value
ACN1GGIO1	AnIn015.instMag.f	ACN15CV	Automation SELOGIC Counter 15 current value
ACN1GGIO1	AnIn016.instMag.f	ACN16CV	Automation SELOGIC Counter 16 current value
AMV1GGIO1	AnIn001.instMag.f	AMV001	Automation SELOGIC Math Variable 001
AMV1GGIO1	AnIn002.instMag.f	AMV002	Automation SELOGIC Math Variable 002
AMV1GGIO1	AnIn003.instMag.f	AMV003	Automation SELOGIC Math Variable 003
• • •			
AMV1GGIO1	AnIn030.instMag.f	AMV030	Automation SELOGIC Math Variable 030
AMV1GGIO1	AnIn031.instMag.f	AMV031	Automation SELOGIC Math Variable 031
AMV1GGIO1	AnIn032.instMag.f	AMV032	Automation SELOGIC Math Variable 032
AMV2GGIO1	AnIn001.instMag.f	AMV033	Automation SELOGIC Math Variable 033
AMV2GGIO1	AnIn002.instMag.f	AMV034	Automation SELOGIC Math Variable 034
AMV2GGIO1	AnIn003.instMag.f	AMV035	Automation SELOGIC Math Variable 035
• • •			
AMV2GGIO1	AnIn030.instMag.f	AMV062	Automation SELOGIC Math Variable 062
AMV2GGIO1	AnIn031.instMag.f	AMV063	Automation SELOGIC Math Variable 063
AMV2GGIO1	AnIn032.instMag.f	AMV064	Automation SELOGIC Math Variable 064
AMV3GGIO1	AnIn001.instMag.f	AMV065	Automation SELOGIC Math Variable 065
AMV3GGIO1	AnIn002.instMag.f	AMV066	Automation SELOGIC Math Variable 066
AMV3GGIO1	AnIn003.instMag.f	AMV067	Automation SELOGIC Math Variable 067
• • •			
AMV3GGIO1	AnIn030.instMag.f	AMV094	Automation SELOGIC Math Variable 094
AMV3GGIO1	AnIn031.instMag.f	AMV095	Automation SELOGIC Math Variable 095
AMV3GGIO1	AnIn032.instMag.f	AMV096	Automation SELOGIC Math Variable 096
AMV4GGIO1	AnIn001.instMag.f	AMV097	Automation SELOGIC Math Variable 097
AMV4GGIO1	AnIn002.instMag.f	AMV098	Automation SELOGIC Math Variable 098
AMV4GGIO1	AnIn003.instMag.f	AMV099	Automation SELOGIC Math Variable 099
• • •			
AMV4GGIO1	AnIn030.instMag.f	AMV126	Automation SELOGIC Math Variable 126
AMV4GGIO1	AnIn031.instMag.f	AMV127	Automation SELOGIC Math Variable 127
AMV4GGIO1	AnIn032.instMag.f	AMV128	Automation SELOGIC Math Variable 128
ETH2GGIO1	AnIn01.instMag.f	P5ARXP[a, b]	SFP transceiver receive power info (dBm) on PORT 5A
ETH2GGIO1	AnIn02.instMag.f	P5BRXP[a, b]	SFP transceiver receive power info (dBm) on PORT 5B
ETH2GGIO1	AnIn03.instMag.f	P5CRXP[a, b]	SFP transceiver receive power info (dBm) on PORT 5C
ETH2GGIO1	AnIn04.instMag.f	P5DRXP[a, b]	SFP transceiver receive power info (dBm) on PORT 5D

Table 17.30 Logical Device: ANN (Annunciation) (Sheet 3 of 17)

Logical Node	Attribute	Data Source	Comment
ETH2GGIO1	AnIn05.instMag.f	P5ERXP[a, b]	SFP transceiver receive power info (dBm) on PORT 5E
ETH2GGIO1	AnIn06.instMag.f	P5ATXP[a, b]	SFP transceiver transmit power info (dBm) on PORT 5A
ETH2GGIO1	AnIn07.instMag.f	P5BTXP[a, b]	SFP transceiver transmit power info (dBm) on PORT 5B
ETH2GGIO1	AnIn08.instMag.f	P5CTXP[a, b]	SFP transceiver transmit power info (dBm) on PORT 5C
ETH2GGIO1	AnIn09.instMag.f	P5DTXP[a, b]	SFP transceiver transmit power info (dBm) on PORT 5D
ETH2GGIO1	AnIn10.instMag.f	P5ETXP[a, b]	SFP transceiver transmit power info (dBm) on PORT 5E
ETH2GGIO1	AnIn11.instMag.f	P5ATMP[a, b]	SFP transceiver temperature info (°C) on PORT 5A
ETH2GGIO1	AnIn12.instMag.f	P5BTMP[a, b]	SFP transceiver temperature info (°C) on PORT 5B
ETH2GGIO1	AnIn13.instMag.f	P5CTMP[a, b]	SFP transceiver temperature info (°C) on PORT 5C
ETH2GGIO1	AnIn14.instMag.f	P5DTMP[a, b]	SFP transceiver temperature info (°C) on PORT 5D
ETH2GGIO1	AnIn15.instMag.f	P5ETMP[a, b]	SFP transceiver temperature info (°C) on PORT 5E
PCNGGIO1	AnIn001.instMag.f	PCN01CV	Protection SELOGIC Counter 01 current value
PCN1GGIO1	AnIn002.instMag.f	PCN02CV	Protection SELOGIC Counter 02 current value
PCN1GGIO1	AnIn003.instMag.f	PCN03CV	Protection SELOGIC Counter 03 current value
• • •			
PCN1GGIO1	AnIn014.instMag.f	PCN14CV	Protection SELOGIC Counter 14 current value
PCN1GGIO1	AnIn015.instMag.f	PCN15CV	Protection SELOGIC Counter 15 current value
PCN1GGIO1	AnIn016.instMag.f	PCN16CV	Protection SELOGIC Counter 16 current value
PMV1GGIO1	AnIn01.instMag.f	PMV01	Protection SELOGIC Math Variable 01
PMV1GGIO1	AnIn02.instMag.f	PMV02	Protection SELOGIC Math Variable 02
PMV1GGIO1	AnIn03.instMag.f	PMV03	Protection SELOGIC Math Variable 03
• • •			
PMV1GGIO1	AnIn30.instMag.f	PMV30	Protection SELOGIC Math Variable 30
PMV1GGIO1	AnIn31.instMag.f	PMV31	Protection SELOGIC Math Variable 31
PMV1GGIO1	AnIn32.instMag.f	PMV32	Protection SELOGIC Math Variable 32
PMV2GGIO1	AnIn01.instMag.f	PMV33	Protection SELOGIC Math Variable 33
PMV2GGIO1	AnIn02.instMag.f	PMV34	Protection SELOGIC Math Variable 34
PMV2GGIO1	AnIn03.instMag.f	PMV35	Protection SELOGIC Math Variable 35
• • •			
PMV2GGIO1	AnIn30.instMag.f	PMV62	Protection SELOGIC Math Variable 62
PMV2GGIO1	AnIn31.instMag.f	PMV63	Protection SELOGIC Math Variable 63
PMV2GGIO1	AnIn32.instMag.f	PMV64	Protection SELOGIC Math Variable 64
RAI1GGIO1	AnIn01.instMag.f	RA001	Remote Analog Input 001
RAI1GGIO1	AnIn02.instMag.f	RA002	Remote Analog Input 002
RAI1GGIO1	AnIn03.instMag.f	RA003	Remote Analog Input 003

Table 17.30 Logical Device: ANN (Annunciation) (Sheet 4 of 17)

Logical Node	Attribute	Data Source	Comment
• • •			
RAI1GGIO1	AnIn30.instMag.f	RA030	Remote Analog Input 030
RAI1GGIO1	AnIn31.instMag.f	RA031	Remote Analog Input 031
RAI1GGIO1	AnIn32.instMag.f	RA032	Remote Analog Input 032
RAI2GGIO1	AnIn01.instMag.f	RA033	Remote Analog Input 033
RAI2GGIO1	AnIn02.instMag.f	RA034	Remote Analog Input 034
RAI2GGIO1	AnIn03.instMag.f	RA035	Remote Analog Input 035
• • •			
RAI2GGIO1	AnIn30.instMag.f	RA062	Remote Analog Input 062
RAI2GGIO1	AnIn31.instMag.f	RA063	Remote Analog Input 063
RAI2GGIO1	AnIn32.instMag.f	RA064	Remote Analog Input 064
RAI3GGIO1	AnIn01.instMag.f	RA065	Remote Analog Input 065
RAI3GGIO1	AnIn02.instMag.f	RA066	Remote Analog Input 066
RAI3GGIO1	AnIn03.instMag.f	RA067	Remote Analog Input 067
• • •			
RAI3GGIO1	AnIn30.instMag.f	RA094	Remote Analog Input 094
RAI3GGIO1	AnIn31.instMag.f	RA095	Remote Analog Input 095
RAI3GGIO1	AnIn32.instMag.f	RA096	Remote Analog Input 096
RAI4GGIO1	AnIn01.instMag.f	RA097	Remote Analog Input 097
RAI4GGIO1	AnIn02.instMag.f	RA098	Remote Analog Input 098
RAI4GGIO1	AnIn03.instMag.f	RA099	Remote Analog Input 099
• • •			
RAI4GGIO1	AnIn30.instMag.f	RA126	Remote Analog Input 126
RAI4GGIO1	AnIn31.instMag.f	RA127	Remote Analog Input 127
RAI4GGIO1	AnIn32.instMag.f	RA128	Remote Analog Input 128
RAI5GGIO1	AnIn01.instMag.f	RA129	Remote Analog Input 129
RAI5GGIO1	AnIn02.instMag.f	RA130	Remote Analog Input 130
RAI5GGIO1	AnIn03.instMag.f	RA131	Remote Analog Input 131
• • •			
RAI5GGIO1	AnIn30.instMag.f	RA158	Remote Analog Input 158
RAI5GGIO1	AnIn31.instMag.f	RA159	Remote Analog Input 159
RAI5GGIO1	AnIn32.instMag.f	RA160	Remote Analog Input 160
RAI6GGIO1	AnIn01.instMag.f	RA161	Remote Analog Input 161

Table 17.30 Logical Device: ANN (Annunciation) (Sheet 5 of 17)

Logical Node	Attribute	Data Source	Comment
RAI6GGIO1	AnIn02.instMag.f	RA162	Remote Analog Input 162
RAI6GGIO1	AnIn03.instMag.f	RA163	Remote Analog Input 163
• • •			
RAI6GGIO1	AnIn30.instMag.f	RA190	Remote Analog Input 190
RAI6GGIO1	AnIn31.instMag.f	RA191	Remote Analog Input 191
RAI6GGIO1	AnIn32.instMag.f	RA192	Remote Analog Input 192
RAI7GGIO1	AnIn01.instMag.f	RA193	Remote Analog Input 193
RAI7GGIO1	AnIn02.instMag.f	RA194	Remote Analog Input 194
RAI7GGIO1	AnIn03.instMag.f	RA195	Remote Analog Input 195
• • •			
RAI7GGIO1	AnIn30.instMag.f	RA222	Remote Analog Input 222
RAI7GGIO1	AnIn31.instMag.f	RA223	Remote Analog Input 223
RAI7GGIO1	AnIn32.instMag.f	RA224	Remote Analog Input 224
RAI8GGIO1	AnIn01.instMag.f	RA225	Remote Analog Input 225
RAI8GGIO1	AnIn02.instMag.f	RA226	Remote Analog Input 226
RAI8GGIO1	AnIn03.instMag.f	RA227	Remote Analog Input 227
• • •			
RAI8GGIO1	AnIn30.instMag.f	RA254	Remote Analog Input 254
RAI8GGIO1	AnIn31.instMag.f	RA255	Remote Analog Input 255
RAI8GGIO1	AnIn32.instMag.f	RA256	Remote Analog Input 256
RAO1GGIO1	AnIn01.instMag.f	RAO01	Remote Analog Output 01
RAO1GGIO1	AnIn02.instMag.f	RAO02	Remote Analog Output 02
RAO1GGIO1	AnIn03.instMag.f	RAO03	Remote Analog Output 03
• • •			
RAO1GGIO1	AnIn30.instMag.f	RAO30	Remote Analog Output 30
RAO1GGIO1	AnIn31.instMag.f	RAO31	Remote Analog Output 31
RAO1GGIO1	AnIn32.instMag.f	RAO32	Remote Analog Output 32
RAO2GGIO1	AnIn01.instMag.f	RAO33	Remote Analog Output 33
RAO2GGIO1	AnIn02.instMag.f	RAO34	Remote Analog Output 34
RAO2GGIO1	AnIn03.instMag.f	RAO35	Remote Analog Output 35
• • •			
RAO2GGIO1	AnIn30.instMag.f	RAO62	Remote Analog Output 62

Table 17.30 Logical Device: ANN (Annunciation) (Sheet 6 of 17)

Logical Node	Attribute	Data Source	Comment
RAO2GGIO1	AnIn31.instMag.f	RAO63	Remote Analog Output 63
RAO2GGIO1	AnIn32.instMag.f	RAO64	Remote Analog Output 64
Functional Constraint = ST			
STALPHD1	PhyHealth.stVal	EN?3:1[d]	Relay enabled
LLN0	Mod.stVal	I60MOD[e]	IEC 61850 mode/behavior status
LLN0	Loc.stVal	LOC	Control authority at local (bay) level
LLN0	LocSta.stVal	LOCSTA	Control authority at station level
LLN0	LocKey.stVal	NOOP	
ALMGGIO1	Ind01.stVal	SALARM	Software alarm
ALMGGIO1	Ind02.stVal	HALARM	Hardware alarm
ALMGGIO1	Ind03.stVal	BADPASS	Invalid password attempt alarm
ALMGGIO1	Ind04.stVal	SETCHG	Pulsed alarm for settings changes
ALMGGIO1	Ind05.stVal	GRPSW	Pulsed alarm for group switches
ALMGGIO1	Ind06.stVal	ACCESS	A user is logged in at Access Level B or higher
ALMGGIO1	Ind07.stVal	PASSDIS	Asserts to indicate password disable jumper is installed
ALMGGIO1	Ind08.stVal	BRKENAB	Asserts to indicate breaker control enable jumper is installed
ALT1GGIO1	Ind01.stVal	ALT01	Automation Latch 1
ALT1GGIO1	Ind02.stVal	ALT02	Automation Latch 2
ALT1GGIO1	Ind03.stVal	ALT03	Automation Latch 3
• • •			
ALT1GGIO1	Ind30.stVal	ALT30	Automation Latch 30
ALT1GGIO1	Ind31.stVal	ALT31	Automation Latch 31
ALT1GGIO1	Ind32.stVal	ALT32	Automation Latch 32
ASV1GGIO1	Ind01.stVal	ASV001	Automation SELOGIC Variable 1
ASV1GGIO1	Ind02.stVal	ASV002	Automation SELOGIC Variable 2
ASV1GGIO1	Ind03.stVal	ASV003	Automation SELOGIC Variable 3
• • •			
ASV1GGIO1	Ind30.stVal	ASV030	Automation SELOGIC Variable 30
ASV1GGIO1	Ind31.stVal	ASV031	Automation SELOGIC Variable 31
ASV1GGIO1	Ind32.stVal	ASV032	Automation SELOGIC Variable 32
ASV2GGIO1	Ind01.stVal	ASV033	Automation SELOGIC Variable 33
ASV2GGIO1	Ind02.stVal	ASV034	Automation SELOGIC Variable 34
ASV2GGIO1	Ind03.stVal	ASV035	Automation SELOGIC Variable 35
• • •			
ASV2GGIO1	Ind30.stVal	ASV062	Automation SELOGIC Variable 62
ASV2GGIO1	Ind31.stVal	ASV063	Automation SELOGIC Variable 63

Table 17.30 Logical Device: ANN (Annunciation) (Sheet 7 of 17)

Logical Node	Attribute	Data Source	Comment
ASV2GGIO1	Ind32.stVal	ASV064	Automation SELOGIC Variable 64
ASV3GGIO1	Ind01.stVal	ASV065	Automation SELOGIC Variable 65
ASV3GGIO1	Ind02.stVal	ASV066	Automation SELOGIC Variable 66
ASV3GGIO1	Ind03.stVal	ASV067	Automation SELOGIC Variable 67
• • •			
ASV3GGIO1	Ind30.stVal	ASV094	Automation SELOGIC Variable 94
ASV3GGIO1	Ind31.stVal	ASV095	Automation SELOGIC Variable 95
ASV3GGIO1	Ind32.stVal	ASV096	Automation SELOGIC Variable 96
ASV4GGIO1	Ind01.stVal	ASV097	Automation SELOGIC Variable 97
ASV4GGIO1	Ind02.stVal	ASV098	Automation SELOGIC Variable 98
ASV4GGIO1	Ind03.stVal	ASV099	Automation SELOGIC Variable 99
• • •			
ASV4GGIO1	Ind30.stVal	ASV126	Automation SELOGIC Variable 126
ASV4GGIO1	Ind31.stVal	ASV127	Automation SELOGIC Variable 127
ASV4GGIO1	Ind32.stVal	ASV128	Automation SELOGIC Variable 128
ETH1GGIO1	Ind01.stVal	P5ASEL	PORT 5A active/inactive
ETH1GGIO1	Ind02.stVal	LINK5A	Link status of PORT 5A connection
ETH1GGIO1	Ind03.stVal	P5BSEL	PORT 5B active/inactive
ETH1GGIO1	Ind04.stVal	LINK5B	Link status of PORT 5B connection
ETH1GGIO1	Ind05.stVal	P5CSEL	PORT 5C active/inactive
ETH1GGIO1	Ind06.stVal	LINK5C	Link status of PORT 5C connection
ETH1GGIO1	Ind07.stVal	P5DSEL	PORT 5D active/inactive
ETH1GGIO1	Ind08.stVal	LINK5D	Link status of PORT 5D connection
ETH1GGIO1	Ind09.stVal	LNKFAIL	Link status of the active station bus port
ETH1GGIO1	Ind10.stVal	LNKFL2[f]	Link status of the active process bus port
ETH1GGIO1	Ind11.stVal	P5ESEL[b]	PORT 5E active/inactive
ETH1GGIO1	Ind12.stVal	LINK5E[b]	Link status of the PORT 5E connection
ETH2GGIO1	CntVal01.actVal	P5ATPTX[a, b]	Total number of packets transmitted on PORT 5A
ETH2GGIO1	CntVal02.actVal	P5BTPTX[a, b]	Total number of packets transmitted on PORT 5B
ETH2GGIO1	CntVal03.actVal	P5CTPTX[a, b]	Total number of packets transmitted on PORT 5C
ETH2GGIO1	CntVal04.actVal	P5DTPTX[a, b]	Total number of packets transmitted on PORT 5D
ETH2GGIO1	CntVal05.actVal	P5ETPTX[a, b]	Total number of packets transmitted on PORT 5E
ETH2GGIO1	CntVal06.actVal	P5ATPRX[a, b]	Total number of packets received on PORT 5A
ETH2GGIO1	CntVal07.actVal	P5BTPRX[a, b]	Total number of packets received on PORT 5B
ETH2GGIO1	CntVal08.actVal	P5CTPRX[a, b]	Total number of packets received on PORT 5C
ETH2GGIO1	CntVal09.actVal	P5DTPRX[a, b]	Total number of packets received on PORT 5D
ETH2GGIO1	CntVal10.actVal	P5ETPRX[a, b]	Total number of packets received on PORT 5E
ETH2GGIO1	CntVal11.actVal	P5ATPDI[a, b]	Total number of packets discarded on PORT 5A

Table 17.30 Logical Device: ANN (Annunciation) (Sheet 8 of 17)

Logical Node	Attribute	Data Source	Comment
ETH2GGIO1	CntVal12.actVal	P5BTPDI[a, b]	Total number of packets discarded on PORT 5B
ETH2GGIO1	CntVal13.actVal	P5CTPDI[a, b]	Total number of packets discarded on PORT 5C
ETH2GGIO1	CntVal14.actVal	P5DTPDI[a, b]	Total number of packets discarded on PORT 5D
ETH2GGIO1	CntVal15.actVal	P5ETPDI[a, b]	Total number of packets discarded on PORT 5E
ETH2GGIO1	CntVal16.actVal	P5ATEPR[a, b]	Total number of erroneous packets received on PORT 5A
ETH2GGIO1	CntVal17.actVal	P5BTEPR[a, b]	Total number of erroneous packets received on PORT 5B
ETH2GGIO1	CntVal18.actVal	P5CTEPR[a, b]	Total number of erroneous packets received on PORT 5C
ETH2GGIO1	CntVal19.actVal	P5DTEPR[a, b]	Total number of erroneous packets received on PORT 5D
ETH2GGIO1	CntVal20.actVal	P5ETEPR[a, b]	Total number of erroneous packets received on PORT 5E
ETH2GGIO1	SPCSO01.stVal	ETHRST[a, b]	Status of Ethernet card statistics reset
HSRGGIO1	Ind01.stVal	HSRAOK[b]	HSR Port 5A status
HSRGGIO1	Ind02.stVal	HSRBOK[b]	HSR Port 5B status
HSRGGIO1	Ind03.stVal	HSRCOK[b]	HSR Port 5C status
HSRGGIO1	Ind04.stVal	HSRDOK[b]	HSR Port 5D status
HSRGGIO1	AnIn01.instMag.f	HSRSRTP[b]	Round-trip time for HSR supervision frames on process bus
HSRGGIO1	AnIn02.instMag.f	HSRSRTS[b]	Round-trip time for HSR supervision frames on station bus
IN1XGGIO1	Ind01.stVal	IN101	Main Board Input 1
IN1XGGIO1	Ind02.stVal	IN102	Main Board Input 2
IN1XGGIO1	Ind03.stVal	IN103	Main Board Input 3
IN1XGGIO1	Ind04.stVal	IN104	Main Board Input 4
IN1XGGIO1	Ind05.stVal	IN105	Main Board Input 5
IN1XGGIO1	Ind06.stVal	IN106	Main Board Input 6
IN1XGGIO1	Ind07.stVal	IN107	Main Board Input 7
IN2XGGIO1	Ind01.stVal	IN201	First Optional I/O Board Input 1 (if installed)
IN2XGGIO1	Ind02.stVal	IN202	First Optional I/O Board Input 2 (if installed)
IN2XGGIO1	Ind03.stVal	IN203	First Optional I/O Board Input 3 (if installed)
• • •			
IN2XGGIO1	Ind22.stVal	IN222	First Optional I/O Board Input 22 (if installed)
IN2XGGIO1	Ind23.stVal	IN223	First Optional I/O Board Input 23 (if installed)
IN2XGGIO1	Ind24.stVal	IN224	First Optional I/O Board Input 24 (if installed)
IN3XGGIO1	Ind01.stVal	IN301	Second Optional I/O Board Input 1 (if installed)
IN3XGGIO1	Ind02.stVal	IN302	Second Optional I/O Board Input 2 (if installed)
IN3XGGIO1	Ind03.stVal	IN303	Second Optional I/O Board Input 3 (if installed)
• • •			
IN3XGGIO1	Ind22.stVal	IN322	Second Optional I/O Board Input 22 (if installed)
IN3XGGIO1	Ind23.stVal	IN323	Second Optional I/O Board Input 23 (if installed)
IN3XGGIO1	Ind24.stVal	IN324	Second Optional I/O Board Input 24 (if installed)
IN4XGGIO1[g]	Ind01.stVal	IN401	Third Optional I/O Board Input 1 (if installed)

Table 17.30 Logical Device: ANN (Annunciation) (Sheet 9 of 17)

Logical Node	Attribute	Data Source	Comment
IN4XGGIO1[g]	Ind02.stVal	IN402	Third Optional I/O Board Input 2 (if installed)
IN4XGGIO1[g]	Ind03.stVal	IN403	Third Optional I/O Board Input 3 (if installed)
• • •			
IN4XGGIO1[g]	Ind22.stVal	IN422	Third Optional I/O Board Input 22 (if installed)
IN4XGGIO1[g]	Ind23.stVal	IN423	Third Optional I/O Board Input 23 (if installed)
IN4XGGIO1[g]	Ind24.stVal	IN424	Third Optional I/O Board Input 24 (if installed)
IN5XGGIO1[h]	Ind01.stVal	IN501	Fourth Optional I/O Board Input 01 (if installed)
IN5XGGIO1[h]	Ind02.stVal	IN502	Fourth Optional I/O Board Input 02 (if installed)
IN5XGGIO1[h]	Ind03.stVal	IN503	Fourth Optional I/O Board Input 03 (if installed)
• • •			
IN5XGGIO1[h]	Ind22.stVal	IN522	Fourth Optional I/O Board Input 22 (if installed)
IN5XGGIO1[h]	Ind23.stVal	IN523	Fourth Optional I/O Board Input 23 (if installed)
IN5XGGIO1[h]	Ind24.stVal	IN524	Fourth Optional I/O Board Input 24 (if installed)
LB1XGGIO1[i]	Ind01.stVal	LB01	Local Bit 1
LB1XGGIO1[i]	Ind02.stVal	LB02	Local Bit 2
LB1XGGIO1[i]	Ind03.stVal	LB03	Local Bit 3
• • •			
LB1XGGIO1[i]	Ind30.stVal	LB30	Local Bit 30
LB1XGGIO1[i]	Ind31.stVal	LB31	Local Bit 31
LB1XGGIO1[i]	Ind32.stVal	LB32	Local Bit 32
LB2XGGIO1[i]	Ind01.stVal	LB33	Local Bit 33
LB2XGGIO1[i]	Ind02.stVal	LB34	Local Bit 34
LB2XGGIO1[i]	Ind03.stVal	LB35	Local Bit 35
• • •			
LB2XGGIO1[i]	Ind30.stVal	LB62	Local Bit 62
LB2XGGIO1[i]	Ind31.stVal	LB63	Local Bit 63
LB2XGGIO1[i]	Ind32.stVal	LB64	Local Bit 64
LB3XGGIO1[i]	Ind01.stVal	LB65	Local Bit 65
LB3XGGIO1[i]	Ind02.stVal	LB66	Local Bit 66
LB3XGGIO1[i]	Ind03.stVal	LB67	Local Bit 67
• • •			
LB3XGGIO1[i]	Ind30.stVal	LB94	Local Bit 94
LB3XGGIO1[i]	Ind31.stVal	LB95	Local Bit 95

Table 17.30 Logical Device: ANN (Annunciation) (Sheet 10 of 17)

Logical Node	Attribute	Data Source	Comment
LB3XGGIO1[i]	Ind32.stVal	LB96	Local Bit 96
MBOKGGIO1	Ind01.stVal	ROKA	Normal MIRRORED BITS communications Channel A status while not in loop-back mode
MBOKGGIO1	Ind02.stVal	RBADA	Outage too long on MIRRORED BITS communications Channel A
MBOKGGIO1	Ind03.stVal	CBADA	Unavailability threshold exceeded for MIRRORED BITS communications Channel A
MBOKGGIO1	Ind04.stVal	LBOKA	Normal MIRRORED BITS communications Channel A status while in loopback mode
MBOKGGIO1	Ind05.stVal	ANOKA	Analog transfer OK on MIRRORED BITS communications Channel A
MBOKGGIO1	Ind06.stVal	DOKA	Normal MIRRORED BITS communications Channel A status
MBOKGGIO1	Ind07.stVal	ROKB	Normal MIRRORED BITS communications Channel B status while not in loop-back mode
MBOKGGIO1	Ind08.stVal	RBADB	Outage too long on MIRRORED BITS communications Channel B
MBOKGGIO1	Ind09.stVal	CBADB	Unavailability threshold exceeded for MIRRORED BITS communications Channel B
MBOKGGIO1	Ind10.stVal	LBOKB	Normal MIRRORED BITS communications Channel B status while in loopback mode
MBOKGGIO1	Ind11.stVal	ANOKB	Analog transfer OK on MIRRORED BITS communications Channel B
MBOKGGIO1	Ind12.stVal	DOKB	Normal MIRRORED BITS communications Channel B status
OUT1GGIO1[j]	Ind01.stVal	OUT101	Main Board Output 1
OUT1GGIO1[j]	Ind02.stVal	OUT102	Main Board Output 2
OUT1GGIO1[j]	Ind03.stVal	OUT103	Main Board Output 3
OUT1GGIO1[j]	Ind04.stVal	OUT104	Main Board Output 4
OUT1GGIO1[j]	Ind05.stVal	OUT105	Main Board Output 5
OUT1GGIO1[j]	Ind06.stVal	OUT106	Main Board Output 6
OUT1GGIO1[j]	Ind07.stVal	OUT107	Main Board Output 7
OUT1GGIO1[j]	Ind08.stVal	OUT108	Main Board Output 8
OUT2GGIO1	Ind01.stVal	OUT201	First Optional I/O Board Output 1
OUT2GGIO1	Ind02.stVal	OUT202	First Optional I/O Board Output 2
OUT2GGIO1	Ind03.stVal	OUT203	First Optional I/O Board Output 3
• • •			
OUT2GGIO1	Ind14.stVal	OUT214	First Optional I/O Board Output 14
OUT2GGIO1	Ind15.stVal	OUT215	First Optional I/O Board Output 15
OUT2GGIO1	Ind16.stVal	OUT216	First Optional I/O Board Output 16
OUT3GGIO1	Ind01.stVal	OUT301	Second Optional I/O Board Output 1
OUT3GGIO1	Ind02.stVal	OUT302	Second Optional I/O Board Output 2
OUT3GGIO1	Ind03.stVal	OUT303	Second Optional I/O Board Output 3
• • •			
OUT3GGIO1	Ind14.stVal	OUT314	Second Optional I/O Board Output 14
OUT3GGIO1	Ind15.stVal	OUT315	Second Optional I/O Board Output 15

Table 17.30 Logical Device: ANN (Annunciation) (Sheet 11 of 17)

Logical Node	Attribute	Data Source	Comment
OUT3GGIO1	Ind16.stVal	OUT316	Second Optional I/O Board Output 16
OUT4GGIO1[i]	Ind01.stVal	OUT401	Third Optional I/O Board Output 1
OUT4GGIO1[i]	Ind02.stVal	OUT402	Third Optional I/O Board Output 2
OUT4GGIO1[i]	Ind03.stVal	OUT403	Third Optional I/O Board Output 3
• • •			
OUT4GGIO1[i]	Ind14.stVal	OUT414	Third Optional I/O Board Output 14
OUT4GGIO1[i]	Ind15.stVal	OUT415	Third Optional I/O Board Output 15
OUT4GGIO1[i]	Ind16.stVal	OUT416	Third Optional I/O Board Output 16
OUT5GGIO1[h]	Ind01.stVal	OUT501	Fourth Optional I/O Board Output 1
OUT5GGIO1[h]	Ind02.stVal	OUT502	Fourth Optional I/O Board Output 2
OUT5GGIO1[h]	Ind03.stVal	OUT503	Fourth Optional I/O Board Output 3
• • •			
OUT5GGIO1[h]	Ind14.stVal	OUT514	Fourth Optional I/O Board Output 14
OUT5GGIO1[h]	Ind15.stVal	OUT515	Fourth Optional I/O Board Output 15
OUT5GGIO1[h]	Ind16.stVal	OUT516	Fourth Optional I/O Board Output 16
OUT3SGGIO1	Ind01.stVal	OUT301S	TiDL mapped OUT301 contact status
OUT3SGGIO1	Ind02.stVal	OUT302S	TiDL mapped OUT302 contact status
OUT3SGGIO1	Ind03.stVal	OUT303S	TiDL mapped OUT303 contact status
• • •			
OUT3SGGIO1	Ind14.stVal	OUT314S	TiDL mapped OUT314 contact status
OUT3SGGIO1	Ind15.stVal	OUT315S	TiDL mapped OUT315 contact status
OUT3SGGIO1	Ind16stVal	OUT316S	TiDL mapped OUT316 contact status
OUT4SGGIO1	Ind01stVal	OUT401S	TiDL mapped OUT401 contact status
OUT4SGGIO1	Ind02.stVal	OUT402S	TiDL mapped OUT402 contact status
OUT4SGGIO1	Ind03.stVal	OUT403S	TiDL mapped OUT403 contact status
• • •			
OUT4SGGIO1	Ind14.stVal	OUT414S	TiDL mapped OUT414 contact status
OUT4SGGIO1	Ind15.stVal	OUT415S	TiDL mapped OUT415 contact status
OUT4SGGIO1	Ind16stVal	OUT416S	TiDL mapped OUT416 contact status
OUT5SGGIO1	Ind01stVal	OUT501S	TiDL mapped OUT501 contact status
OUT5SGGIO1	Ind02.stVal	OUT502S	TiDL mapped OUT502 contact status
OUT5SGGIO1	Ind03.stVal	OUT503S	TiDL mapped OUT503 contact status
• • •			

Table 17.30 Logical Device: ANN (Annunciation) (Sheet 12 of 17)

Logical Node	Attribute	Data Source	Comment
OUT5SGGIO1	Ind14.stVal	OUT514S	TiDL mapped OUT514 contact status
OUT5SGGIO1	Ind15.stVal	OUT515S	TiDL mapped OUT515 contact status
OUT5SGGIO1	Ind16stVal	OUT516S	TiDL mapped OUT516 contact status
PBLEDGGIO1	Ind01.stVal	PB1_LED	Pushbutton 1 LED
PBLEDGGIO1	Ind02.stVal	PB2_LED	Pushbutton 2 LED
PBLEDGGIO1	Ind03.stVal	PB3_LED	Pushbutton 3 LED
PBLEDGGIO1	Ind04.stVal	PB4_LED	Pushbutton 4 LED
PBLEDGGIO1	Ind05.stVal	PB5_LED	Pushbutton 5 LED
PBLEDGGIO1	Ind06.stVal	PB6_LED	Pushbutton 6 LED
PBLEDGGIO1	Ind07.stVal	PB7_LED	Pushbutton 7 LED
PBLEDGGIO1	Ind08.stVal	PB8_LED	Pushbutton 8 LED
PBLEDGGIO1	Ind09.stVal	PB9_LED	Pushbutton 9 LED
PBLEDGGIO1	Ind10.stVal	PB10LED	Pushbutton 10 LED
PBLEDGGIO1	Ind11.stVal	PB11LED	Pushbutton 11 LED
PBLEDGGIO1	Ind12.stVal	PB12LED	Pushbutton 12 LED
PLT1GGIO1	Ind01.stVal	PLT01	Protection Latch 1
PLT1GGIO1	Ind02.stVal	PLT02	Protection Latch 2
PLT1GGIO1	Ind03.stVal	PLT03	Protection Latch 3
• • •			
PLT1GGIO1	Ind30.stVal	PLT30	Protection Latch 30
PLT1GGIO1	Ind31.stVal	PLT31	Protection Latch 31
PLT1GGIO1	Ind32.stVal	PLT32	Protection Latch 32
PRPGGIO1	Ind01.stVal	PRPAGOK[b]	PRP PORT 5A GOOSE status
PRPGGIO1	Ind02.stVal	PRPBGOK[b]	PRP PORT 5B GOOSE status
PRPGGIO1	Ind03.stVal	PRPCGOK[b]	PRP PORT 5C GOOSE status
PRPGGIO1	Ind04.stVal	PRPDGOK[b]	PRP PORT 5D GOOSE status
PRPGGIO1	Ind05.stVal	PRPASOK[b]	PRP PORT 5A SV status
PRPGGIO1	Ind06.stVal	PRPBSOK[b]	PRP PORT 5B SV status
PSV1GGIO1	Ind01.stVal	PSV01	Protection SELOGIC Variable 1
PSV1GGIO1	Ind02.stVal	PSV02	Protection SELOGIC Variable 2
PSV1GGIO1	Ind03.stVal	PSV03	Protection SELOGIC Variable 3
• • •			
PSV1GGIO1	Ind30.stVal	PSV30	Protection SELOGIC Variable 30
PSV1GGIO1	Ind31.stVal	PSV31	Protection SELOGIC Variable 31
PSV1GGIO1	Ind32.stVal	PSV32	Protection SELOGIC Variable 32
PSV2GGIO1	Ind01.stVal	PSV33	Protection SELOGIC Variable 33
PSV2GGIO1	Ind02.stVal	PSV34	Protection SELOGIC Variable 34
PSV2GGIO1	Ind03.stVal	PSV35	Protection SELOGIC Variable 35

Table 17.30 Logical Device: ANN (Annunciation) (Sheet 13 of 17)

Logical Node	Attribute	Data Source	Comment
• • •			
PSV2GGIO1	Ind30.stVal	PSV62	Protection SELOGIC Variable 62
PSV2GGIO1	Ind31.stVal	PSV63	Protection SELOGIC Variable 63
PSV2GGIO1	Ind32.stVal	PSV64	Protection SELOGIC Variable 64
RMBAGGIO1	Ind01.stVal	RMB1A	Channel A Receive Mirrored Bit 1
RMBAGGIO1	Ind02.stVal	RMB2A	Channel A Receive Mirrored Bit 2
RMBAGGIO1	Ind03.stVal	RMB3A	Channel A Receive Mirrored Bit 3
RMBAGGIO1	Ind04.stVal	RMB4A	Channel A Receive Mirrored Bit 4
RMBAGGIO1	Ind05.stVal	RMB5A	Channel A Receive Mirrored Bit 5
RMBAGGIO1	Ind06.stVal	RMB6A	Channel A Receive Mirrored Bit 6
RMBAGGIO1	Ind07.stVal	RMB7A	Channel A Receive Mirrored Bit 7
RMBAGGIO1	Ind08.stVal	RMB8A	Channel A Receive Mirrored Bit 8
RMBBGGIO1	Ind01.stVal	RMB1B	Channel B Receive Mirrored Bit 1
RMBBGGIO1	Ind02.stVal	RMB2B	Channel B Receive Mirrored Bit 2
RMBBGGIO1	Ind03.stVal	RMB3B	Channel B Receive Mirrored Bit 3
RMBBGGIO1	Ind04.stVal	RMB4B	Channel B Receive Mirrored Bit 4
RMBBGGIO1	Ind05.stVal	RMB5B	Channel B Receive Mirrored Bit 5
RMBBGGIO1	Ind06.stVal	RMB6B	Channel B Receive Mirrored Bit 6
RMBBGGIO1	Ind07.stVal	RMB7B	Channel B Receive Mirrored Bit 7
RMBBGGIO1	Ind08.stVal	RMB8B	Channel B Receive Mirrored Bit 8
RTCAGGIO1	Ind01.stVal	RTCAD01	RTC Remote Data Bits, Channel A, Bit 1
RTCAGGIO1	Ind02.stVal	RTCAD02	RTC Remote Data Bits, Channel A, Bit 2
RTCAGGIO1	Ind03.stVal	RTCAD03	RTC Remote Data Bits, Channel A, Bit 3
• • •			
RTCAGGIO1	Ind14.stVal	RTCAD14	RTC Remote Data Bits, Channel A, Bit 14
RTCAGGIO1	Ind15.stVal	RTCAD15	RTC Remote Data Bits, Channel A, Bit 15
RTCAGGIO1	Ind16.stVal	RTCAD16	RTC Remote Data Bits, Channel A, Bit 16
RTCBGGIO1	Ind01.stVal	RTCBD01	RTC Remote Data Bits, Channel B, Bit 1
RTCBGGIO1	Ind02.stVal	RTCBD02	RTC Remote Data Bits, Channel B, Bit 2
RTCBGGIO1	Ind03.stVal	RTCBD03	RTC Remote Data Bits, Channel B, Bit 3
• • •			
RTCBGGIO1	Ind14.stVal	RTCBD14	RTC Remote Data Bits, Channel B, Bit 14
RTCBGGIO1	Ind15.stVal	RTCBD15	RTC Remote Data Bits, Channel B, Bit 15
RTCBGGIO1	Ind16.stVal	RTCBD16	RTC Remote Data Bits, Channel B, Bit 16
RTDHGGIO1	Ind01.stVal	RTD01ST	RTD Status for Channel 1
RTDHGGIO1	Ind02.stVal	RTD02ST	RTD Status for Channel 2

Table 17.30 Logical Device: ANN (Annunciation) (Sheet 14 of 17)

Logical Node	Attribute	Data Source	Comment
RTDHGGIO1	Ind03.stVal	RTD03ST	RTD Status for Channel 3
RTDHGGIO1	Ind04.stVal	RTD04ST	RTD Status for Channel 4
RTDHGGIO1	Ind05.stVal	RTD05ST	RTD Status for Channel 5
RTDHGGIO1	Ind06.stVal	RTD06ST	RTD Status for Channel 6
RTDHGGIO1	Ind07.stVal	RTD07ST	RTD Status for Channel 7
RTDHGGIO1	Ind08.stVal	RTD08ST	RTD Status for Channel 8
RTDHGGIO1	Ind09.stVal	RTD09ST	RTD Status for Channel 9
RTDHGGIO1	Ind10.stVal	RTD10ST	RTD Status for Channel 10
RTDHGGIO1	Ind11.stVal	RTD11ST	RTD Status for Channel 11
RTDHGGIO1	Ind12.stVal	RTD12ST	RTD Status for Channel 12
SG1XGGIO1	Ind01.stVal	SG1	Settings Group 1 active
SG1XGGIO1	Ind02.stVal	SG2	Settings Group 2 active
SG1XGGIO1	Ind03.stVal	SG3	Settings Group 3 active
SG1XGGIO1	Ind04.stVal	SG4	Settings Group 4 active
SG1XGGIO1	Ind05.stVal	SG5	Settings Group 5 active
SG1XGGIO1	Ind06.stVal	SG6	Settings Group 6 active
SG1XGGIO1	Ind07.stVal	CHSG	Settings group change
SG1XGGIO1	Ind08.stVal	GRPSW	Pulsed alarm for group switches
TLEDGGIO1	Ind01.stVal	EN	Relay enabled
TLEDGGIO1	Ind02.stVal	TRIPLED	Trip LED
TLEDGGIO1	Ind03.stVal	TLED_1	Target LED 1
TLEDGGIO1	Ind04.stVal	TLED_2	Target LED 2
TLEDGGIO1	Ind05.stVal	TLED_3	Target LED 3
TLEDGGIO1	Ind06.stVal	TLED_4	Target LED 4
TLEDGGIO1	Ind07.stVal	TLED_5	Target LED 5
TLEDGGIO1	Ind08.stVal	TLED_6	Target LED 6
TLEDGGIO1	Ind09.stVal	TLED_7	Target LED 7
TLEDGGIO1	Ind10.stVal	TLED_8	Target LED 8
TLEDGGIO1	Ind11.stVal	TLED_9	Target LED 9
TLEDGGIO1	Ind12.stVal	TLED_10	Target LED 10
TLEDGGIO1	Ind13.stVal	TLED_11	Target LED 11
TLEDGGIO1	Ind14.stVal	TLED_12	Target LED 12
TLEDGGIO1	Ind15.stVal	TLED_13	Target LED 13
TLEDGGIO1	Ind16.stVal	TLED_14	Target LED 14
TLEDGGIO1	Ind17.stVal	TLED_15	Target LED 15
TLEDGGIO1	Ind18.stVal	TLED_16	Target LED 16
TLEDGGIO1	Ind19.stVal	TLED_17	Target LED 17
TLEDGGIO1	Ind20.stVal	TLED_18	Target LED 18
TLEDGGIO1	Ind21.stVal	TLED_19	Target LED 19
TLEDGGIO1	Ind22.stVal	TLED_20	Target LED 20
TLEDGGIO1	Ind23.stVal	TLED_21	Target LED 21

Table 17.30 Logical Device: ANN (Annunciation) (Sheet 15 of 17)

Logical Node	Attribute	Data Source	Comment
TLEDGGIO1	Ind24.stVal	TLED_22	Target LED 22
TLEDGGIO1	Ind25.stVal	TLED_23	Target LED 23
TLEDGGIO1	Ind26.stVal	TLED_24	Target LED 24
TMBAGGIO1	Ind01.stVal	TMB1A	Channel A Transmit Mirrored Bit 1
TMBAGGIO1	Ind02.stVal	TMB2A	Channel A Transmit Mirrored Bit 2
TMBAGGIO1	Ind03.stVal	TMB3A	Channel A Transmit Mirrored Bit 3
TMBAGGIO1	Ind04.stVal	TMB4A	Channel A Transmit Mirrored Bit 4
TMBAGGIO1	Ind05.stVal	TMB5A	Channel A Transmit Mirrored Bit 5
TMBAGGIO1	Ind06.stVal	TMB6A	Channel A Transmit Mirrored Bit 6
TMBAGGIO1	Ind07.stVal	TMB7A	Channel A Transmit Mirrored Bit 7
TMBAGGIO1	Ind08.stVal	TMB8A	Channel A Transmit Mirrored Bit 8
TMBBGGIO1	Ind01.stVal	TMB1B	Channel B Transmit Mirrored Bit 1
TMBBGGIO1	Ind02.stVal	TMB2B	Channel B Transmit Mirrored Bit 2
TMBBGGIO1	Ind03.stVal	TMB3B	Channel B Transmit Mirrored Bit 3
TMBBGGIO1	Ind04.stVal	TMB4B	Channel B Transmit Mirrored Bit 4
TMBBGGIO1	Ind05.stVal	TMB5B	Channel B Transmit Mirrored Bit 5
TMBBGGIO1	Ind06.stVal	TMB6B	Channel B Transmit Mirrored Bit 6
TMBBGGIO1	Ind07.stVal	TMB7B	Channel B Transmit Mirrored Bit 7
TMBBGGIO1	Ind08.stVal	TMB8B	Channel B Transmit Mirrored Bit 8
TPORTGGIO1	Ind01.stVal	TDLCMSD	TiDL active topology commissioned
TPORTGGIO1	Ind02.stVal	TIDLALM	TiDL alarm
TPORTGGIO1	Ind03.stVal	P6AMAP	PORT 6A mapped
TPORTGGIO1	Ind04.stVal	P6AOK	PORT 6A OK
TPORTGGIO1	Ind05.stVal	P6BMAP	PORT 6B mapped
TPORTGGIO1	Ind06.stVal	P6BOK	PORT 6BOK
TPORTGGIO1	Ind07.stVal	P6CMAP	PORT 6C mapped
TPORTGGIO1	Ind08.stVal	P6COK	PORT 6C OK
TPORTGGIO1	Ind09.stVal	P6DMAP	PORT 6D mapped
TPORTGGIO1	Ind10.stVal	P6DOK	PORT 6D OK
TPORTGGIO1	Ind11.stVal	P6EMAP	PORT 6E mapped
TPORTGGIO1	Ind12.stVal	P6EOK	PORT 6E OK
TPORTGGIO1	Ind13.stVal	P6FMAP	PORT 6F mapped
TPORTGGIO1	Ind14.stVal	P6FOK	PORT 6F OK
VB1XGGIO1	Ind01.stVal	VB001	Virtual Bit 001
VB1XGGIO1	Ind02.stVal	VB002	Virtual Bit 002
VB1XGGIO1	Ind03.stVal	VB003	Virtual Bit 003
• • •			
VB1XGGIO1	Ind30.stVal	VB030	Virtual Bit 030
VB1XGGIO1	Ind31.stVal	VB031	Virtual Bit 031

Table 17.30 Logical Device: ANN (Annunciation) (Sheet 16 of 17)

Logical Node	Attribute	Data Source	Comment
VB1XGGIO1	Ind32.stVal	VB032	Virtual Bit 032
VB2XGGIO1	Ind01.stVal	VB033	Virtual Bit 033
VB2XGGIO1	Ind02.stVal	VB034	Virtual Bit 034
VB2XGGIO1	Ind03.stVal	VB035	Virtual Bit 035
• • •			
VB2XGGIO1	Ind30.stVal	VB062	Virtual Bit 062
VB2XGGIO1	Ind31.stVal	VB063	Virtual Bit 063
VB2XGGIO1	Ind32.stVal	VB064	Virtual Bit 064
VB3XGGIO1	Ind01.stVal	VB065	Virtual Bit 065
VB3XGGIO1	Ind02.stVal	VB066	Virtual Bit 066
VB3XGGIO1	Ind03.stVal	VB067	Virtual Bit 067
• • •			
VB3XGGIO1	Ind30.stVal	VB094	Virtual Bit 094
VB3XGGIO1	Ind31.stVal	VB095	Virtual Bit 095
VB3XGGIO1	Ind32.stVal	VB096	Virtual Bit 096
VB4XGGIO1	Ind01.stVal	VB097	Virtual Bit 097
VB4XGGIO1	Ind02.stVal	VB098	Virtual Bit 098
VB4XGGIO1	Ind03.stVal	VB099	Virtual Bit 099
• • •			
VB4XGGIO1	Ind30.stVal	VB126	Virtual Bit 126
VB4XGGIO1	Ind31.stVal	VB127	Virtual Bit 127
VB4XGGIO1	Ind32.stVal	VB128	Virtual Bit 128
VB5XGGIO1	Ind01.stVal	VB129	Virtual Bit 129
VB5XGGIO1	Ind02.stVal	VB130	Virtual Bit 130
VB5XGGIO1	Ind03.stVal	VB131	Virtual Bit 131
• • •			
VB5XGGIO1	Ind30.stVal	VB158	Virtual Bit 158
VB5XGGIO1	Ind31.stVal	VB159	Virtual Bit 159
VB5XGGIO1	Ind32.stVal	VB160	Virtual Bit 160
VB6XGGIO1	Ind01.stVal	VB161	Virtual Bit 161
VB6XGGIO1	Ind02.stVal	VB162	Virtual Bit 162
VB6XGGIO1	Ind03.stVal	VB163	Virtual Bit 163
• • •			

Table 17.30 Logical Device: ANN (Annunciation) (Sheet 17 of 17)

Logical Node	Attribute	Data Source	Comment
VB6XGGIO1	Ind31.stVal	VB191	Virtual Bit 191
VB6XGGIO1	Ind32.stVal	VB192	Virtual Bit 192
VB7XGGIO1	Ind01.stVal	VB193	Virtual Bit 193
VB7XGGIO1	Ind02.stVal	VB194	Virtual Bit 194
VB7XGGIO1	Ind03.stVal	VB195	Virtual Bit 195
• • •			
VB7XGGIO1	Ind30.stVal	VB222	Virtual Bit 222
VB7XGGIO1	Ind31.stVal	VB223	Virtual Bit 223
VB7XGGIO1	Ind32.stVal	VB224	Virtual Bit 224
VB8XGGIO1	Ind01.stVal	VB225	Virtual Bit 225
VB8XGGIO1	Ind02.stVal	VB226	Virtual Bit 226
VB8XGGIO1	Ind03.stVal	VB227	Virtual Bit 227
• • •			
VB8XGGIO1	Ind30.stVal	VB254	Virtual Bit 254
VB8XGGIO1	Ind31.stVal	VB255	Virtual Bit 255
VB8XGGIO1	Ind32.stVal	VB256	Virtual Bit 256

[a] Internal data source and not available to the user.
[b] Only applicable when using the five-port Ethernet card.
[c] HWREV is an internal data source and is not available to the user.
[d] If enabled, value = 1. If disabled, value = 3.
[e] I60MOD is an internal data source derived from the I850MOD analog quantity and is not available to the user.
[f] Only applicable to SEL-400 series relays with SV support and the SEL-411L with 87L over Ethernet.
[g] Not all SEL-400 series relays support a third interface board.
[h] Not all SEL-400 series relays support four interface boards.
[i] Not supported in the SEL-487V.
[j] Not all SEL-400 series relays support main board outputs.

SEL Nameplate Data

The CID file contains information that describes the physical device attributes according to IEC 61850 standards. The LN0 logical node of each logical device contains the Nameplate DOI (instantiated data object) with the following data.

Table 17.31 SEL Nameplate Data

Data Attribute	Value
vendor	“SEL”
swRev	Contents of FID string from **ID** command
d	Description of LD
configRev	Always 0
1dNs	IEC 61850-7-4:2007A

Protocol Implementation Conformance Statement

Table 17.32 and *Table 17.33* are as shown in the IEC 61850 standard, Part 8-1, Section 24. Because the standard explicitly dictates which services and functions must be implemented to achieve conformance, only the optional services and functions are listed.

Table 17.32 PICS for A-Profile Support

Profile		Client	Server	Value/Comment
A1	Client/Server		Y	
A2	GOOSE/GSE management	Y	Y	Only GOOSE, not GSSE management
A3	GSSE			
A4	Time Sync	Y		

Table 17.33 PICS for T-Profile Support

Profile		Client	Server	Value/Comment
T1	TCP/IP		Y	
T2	OSI			
T3	GOOSE/GSE	Y	Y	Only GOOSE, not GSSE
T4	GSSE			
T5	Time Sync	Y		

Refer to the *ACSI Conformance Statements on page 17.89* for information on the supported services.

MMS Conformance

The MMS stack provides the basis for many IEC 61850 protocol services. *Table 17.34* defines the service support requirement and restrictions of the MMS services that support Conformance Building Block (CBB) in the SEL-400 series devices. Generally, only those services whose implementation is not mandatory are shown in Server-CR (Conformance Requirement). Refer to the IEC 61850 standard Part 8-1 for more information.

Table 17.34 MMS Service Supported Conformance (Sheet 1 of 3)

MMS Service Supported CBB	Client-CR Supported	Server-CR Supported
status		Y
getNameList		Y
identify		Y
rename		
read		Y
write		Y
getVariableAccessAttributes		Y
defineNamedVariable		
defineScatteredAccess		
getScatteredAccessAttributes		

Table 17.34 MMS Service Supported Conformance (Sheet 2 of 3)

MMS Service Supported CBB	Client-CR Supported	Server-CR Supported
deleteVariableAccess		
defineNamedVariableList		
getNamedVariableListAttributes		Y
deleteNamedVariableList		
defineNamedType		
getNamedTypeAttributes		
deleteNamedType		
input		
output		
takeControl		
relinquishControl		
defineSemaphore		
deleteSemaphore		
reportPoolSemaphoreStatus		
reportSemaphoreStatus		
initiateDownloadSequence		
downloadSegment		
terminateDownloadSequence		
initiateUploadSequence		
uploadSegment		
terminateUploadSequence		
requestDomainDownload		
requestDomainUpload		
loadDomainContent		
storeDomainContent		
deleteDomain		
getDomainAttributes		Y
createProgramInvocation		
deleteProgramInvocation		
start		
stop		
resume		
reset		
kill		
getProgramInvocationAttributes		
obtainFile		Y
defineEventCondition		
deleteEventCondition		
getEventConditionAttributes		
reportEventConditionStatus		

Table 17.34 MMS Service Supported Conformance (Sheet 3 of 3)

MMS Service Supported CBB	Client-CR Supported	Server-CR Supported
alterEventConditionMonitoring		
triggerEvent		
defineEventAction		
deleteEventAction		
alterEventEnrollment		
reportEventEnrollmentStatus		
getEventEnrollmentAttributes		
acknowledgeEventNotification		
getAlarmSummary		
getAlarmEnrollmentSummary		
readJournal		
writeJournal		
initializeJournal		
reportJournalStatus		
createJournal		
deleteJournal		
fileOpen		Y
fileRead		Y
fileClose		Y
fileRename		
fileDelete		Y
fileDirectory		Y
unsolicitedStatus		
informationReport		Y
eventNotification		
attachToEventCondition		
attachToSemaphore		
conclude		Y
cancel		Y
getDataExchangeAttributes		
exchangeData		
defineAccessControlList		
getAccessControlListAttributes		
reportAccessControlledObjects		
deleteAccessControlList		
alterAccessControl		
reconfigureProgramInvocation		

Table 17.35 lists specific settings for the MMS parameter conformance building block (CBB).

Table 17.35 MMS Parameter CBB

MMS Parameter CBB	Client-CR Supported	Server-CR Supported
STR1		Y
STR2		Y
VNAM		Y
VADR		Y
VALT		Y
TPY		Y
VLIS		Y
CEI		

The following variable access conformance statements are listed in the order specified in the IEC 61850 standard, Part 8-1. Generally, only those services whose implementation is not mandatory are shown. Refer to the IEC 61850 standard Part 8-1 for more information.

Table 17.36 AlternateAccessSelection Conformance Statement

AlternateAccessSelection	Client-CR Supported	Server-CR Supported
accessSelection		Y
component		Y
index		
indexRange		
allElements		
alternateAccess		Y
selectAccess		Y
component		Y
index		
indexRange		
allElements		

Table 17.37 VariableAccessSpecification Conformance Statement

VariableAccessSpecification	Client-CR Supported	Server-CR Supported
listOfVariable		Y
variableSpecification		Y
alternateAccess		Y
variableListName		Y

Table 17.38 VariableSpecification Conformance Statement

VariableSpecification	Client-CR Supported	Server-CR Supported
name		Y
address		
variableDescription		
scatteredAccessDescription		
invalidated		

Table 17.39 Read Conformance Statement

Read	Client-CR Supported	Server-CR Supported
Request		
specificationWithResult		
variableAccessSpecification		
Response		
variableAccessSpecification		Y
listOfAccessResult		Y

Table 17.40 GetVariableAccessAttributes Conformance Statement

GetVariableAccessAttributes	Client-CR Supported	Server-CR Supported
Request		
name		
address		
Response		
mmsDeletable		
address		
typeSpecification		

Table 17.41 DefineNamedVariableList Conformance Statement

DefineVariableAccessAttributes	Client-CR Supported	Server-CR Supported
Request		
variableListName		
listOfVariable		
variableSpecification		
alternateAccess		
Response		

Table 17.42 GetNamedVariableListAttributes Conformance Statement (Sheet 1 of 2)

GetNamedVariableListAttributes	Client-CR Supported	Server-CR Supported
Request		
ObjectName		

Table 17.42 GetNamedVariableListAttributes Conformance Statement (Sheet 2 of 2)

GetNamedVariableListAttributes	Client-CR Supported	Server-CR Supported
Response		
mmsDeletable		Y
listOfVariable		Y
variableSpecification		Y
alternateAccess		Y

Table 17.43 DeleteNamedVariableList Conformance Statement

DeleteNamedVariableList	Client-CR Supported	Server-CR Supported
Request		
Scope		
listOfVariableListName		
domainName		
Response		
numberMatched		
numberDeleted		
DeleteNamedVariableList-Error		

GOOSE Services Conformance Statement

Table 17.44 GOOSE Conformance

	Subscriber	Publisher	Value/Comment
GOOSE Services	Y	Y	
SendGOOSEMessage		Y	
GetGoReference			
GetGOOSEElementNumber			
GetGoCBValues		Y	
SetGoCBValues			
GSENotSupported			
GOOSE Control Block (GoCB)		Y	

ACSI Conformance Statements

Table 17.45 Basic Conformance Statement (Sheet 1 of 2)

Services		Client/ Subscriber[a]	Server/ Publisher[a]	Value/ Comments[a]
Client-Server Roles				
B11	Server side (of TWO-PARTY-APPLICATION-ASSOCIATION)		Y	
B12	Client side (of TWO-PARTY-APPLICATION-ASSOCIATION)			

Table 17.45 Basic Conformance Statement (Sheet 2 of 2)

Services		Client/ Subscriber[a]	Server/ Publisher[a]	Value/ Comments[a]
SCSMs Supported				
B21	SCSM: IEC 6185-8-1 used		Y	
B22	SCSM: IEC 6185-9-1 used			Deprecated in Ed2
B23	SCSM: IEC 6185-9-2 used	Y[b]	Y[c]	
B24	SCSM: other			
Generic Substation Event (GSE) Model				
B31	Publisher side		Y	
B32	Subscriber side	Y		
Transmission of Sampled Value Model (SVC)				
B41	Publisher side		Y[c]	
B42	Subscriber side	Y[b]		

[a] Y = supported
N or blank = not supported
[b] Only applicable for SV Subscriber devices
[c] Only applicable for SV Publisher devices

Table 17.46 ACSI Models Conformance Statement (Sheet 1 of 2)

		Client/Subscriber[a]	Server/Publisher[a]	Value/Comments
If Server Side (B11) and/or Client Side (B12) Supported				
M1	Logical device		Y	
M2	Logical node		Y	
M3	Data		Y	
M4	Data set		Y	
M5	Substitution			
M6	Setting group control		Y	
Reporting				
M7	Buffered report control		Y	
M7–1	sequence-number		Y	
M7–2	report-time-stamp		Y	
M7–3	reason-for-inclusion		Y	
M7–4	data-set-name		Y	
M7–5	data-reference		Y	
M7–6	buffer-overflow		Y	
M7–7	entryID		Y	
M7–8	BufTim		Y	
M7–9	IntgPd		Y	
M7–10	GI		Y	
M7–11	conf-revision		Y	
M8	Unbuffered report control		Y	
M8–1	sequence-number		Y	
M8–2	report-time-stamp		Y	

Table 17.46 ACSI Models Conformance Statement (Sheet 2 of 2)

		Client/Subscriber[a]	Server/Publisher[a]	Value/Comments
M8–3	reason-for-inclusion		Y	
M8–4	data-set-name		Y	
M8–5	data-reference		Y	
M8–6	BufTim		Y	
M8–7	IntgPd		Y	
M8–8	GI		Y	
M8–9	conf-revision		Y	
	Logging			
M9	Log control			
M9–1	IntgPd			
M10	Log			
M11	Control		Y	
M17	File transfer		Y	
M18	Application association		Y	
M19	GOOSE control block		Y	
M20	Sampled Value control block		Y[b]	
If GSE (B31/32) Is Supported				
M12	GOOSE		Y	
M13	GSSE			Deprecated in Ed2
If SVC (B41/42) Is Supported				
M14	Multicast SVC		Y[b]	
M15	Unicast SVC			
For All IEDs				
M16	Time		Y	Time source with required accuracy shall be available. Only the time master is an SNTP (Mode 4 response) time server. All other client/server devices require SNTP (Mode 3 request) clients.

[a] Y = supported
N or blank = not supported
[b] SV publisher only

Table 17.47 ACSI Service Conformance Statement (Sheet 1 of 4)

Services			AA: TP/MC	Client (C)	Server (S)	Comments
Server						
S1	1, 2	GetServerDirectory (LOGICAL-DEVICE)	TP		Y	
Application Association						
S2	1, 2	Associate			Y	
S3	1, 2	Abort			Y	
S4	1, 2	Release			Y	
Logical Device						
S5	1, 2	GetLogicalDeviceDirectory	TP		Y	

Table 17.47 ACSI Service Conformance Statement (Sheet 2 of 4)

Services			AA: TP/MC	Client (C)	Server (S)	Comments
Logical Node						
S6	1, 2	GetLogicalNodeDirectory	TP		Y	
S7	1, 2	GetAllDataValues	TP		Y	
Data						
S8	1, 2	GetDataValues	TP		Y	
S9	1, 2	SetDataValues	TP			
S10	1, 2	GetDataDirectory	TP		Y	
S11	1, 2	GetDataDefinition	TP		Y	
Data Set						
S12	1, 2	GetDataSetValues	TP		Y	
S13	1, 2	SetDataSetValues	TP			
S14	1, 2	CreateDataSet	TP			
S15	1, 2	DeleteDataSet	TP			
S16	1, 2	GetDataSetDirectory	TP		Y	
Substitution						
S17	1	SetDataValues	TP			
Setting Group Control						
S18	1, 2	SelectActiveSG	TP		Y	
S19	1, 2	SelectEditSG	TP			
S20	1, 2	SetEditSGValues	TP			
S21	1, 2	ConfirmEditSGValues	TP			
S22	1, 2	GetEditSGValues	TP			
S23	1, 2	GetSGCBValues	TP		Y	
Reporting						
Buffered Report Control Block (BRCB)						
S24	1, 2	Report	TP		Y	
S24–1	1, 2	data-change (dchg)			Y	
S24–2	1, 2	quality-change (qchg)			Y	
S24–3	1, 2	data-update (dupd)			Y	
S25	1, 2	GetBRCBValues	TP		Y	
S26	1, 2	SetBRCBValues	TP		Y	
Unbuffered Report Control Block (URCB)						
S27	1, 2	Report	TP		Y	
S27–1	1, 2	data-change (dchg)			Y	
S27–2	1, 2	quality-change (qchg)			Y	
S27–3	1, 2	data-update (dup)			Y	
S28	1, 2	GetURCBValues	TP		Y	
S29	1, 2	SetURCBValues	TP		Y	

Table 17.47 ACSI Service Conformance Statement (Sheet 3 of 4)

Services			AA: TP/MC	Client (C)	Server (S)	Comments
Logging						
Log Control Block						
S30	1, 2	GetLCBValues	TP			
S31	1, 2	SetLCBValues	TP			
Log						
S32	1, 2	QueryLogByTime	TP			
S33	1, 2	QueryLogAfter	TP			
S34	1, 2	GetLogStatusValues	TP			
Generic Substation Event Model (GSE)						
GOOSE						
S35	1, 2	SendGOOSEMessage	MC		Y	
GOOSE-CONTROL-BLOCK						
S36	1, 2	GetGoReference	TP			
S37	1, 2	GetGOOSEElementNumber	TP			
S38	1, 2	GetGoCBValues	TP		Y	
S39	1, 2	SetGoCBValues	TP			
GSSE						
S40	1	SendGSSEMessage	MC			Deprecated in Ed2
GSSE-CONTROL-BLOCK						
S41	1	GetReference	TP			Deprecated in Ed2
S42	1	GetGSSEElementNumber	TP			Deprecated in Ed2
S43	1	GetGsCBValues	TP			Deprecated in Ed2
S44	1	SetGsCBValues	TP			Deprecated in Ed2
Transmission of Sampled Value Model (SVC)						
Multicast SV						
S45	1, 2	SendMSVMessage	MC		Y[a]	
Multicast Sampled Value Control Block						
S46	1, 2	GetMSVCBValues	TP		Y[a]	
S47	1, 2	SetMSVCBValues	TP			
Unicast SV						
S48	1, 2	SendUSVMessage	TP			
Unicast Sampled Value Control Block						
S49	1, 2	GetUSVCBValues	TP			
S50	1, 2	SetUSVCBValues	TP			
Control						
S51	1, 2	Select				
S52	1, 2	SelectWithValue	TP		Y	
S53	1, 2	Cancel	TP		Y	
S54	1, 2	Operate	TP		Y	
S55	1, 2	CommandTermination	TP		Y	
S56	1, 2	TimeActivatedOperate	TP			

Table 17.47 ACSI Service Conformance Statement (Sheet 4 of 4)

Services			AA: TP/MC	Client (C)	Server (S)	Comments
File Transfer						
S57	1, 2	GetFile	TP		Y	
S58	1, 2	SetFile	TP		Y	
S59	1, 2	DeleteFile	TP			
S60	1, 2	GetFileAttributeValues	TP		Y	
S61	1, 2	GetServerDirectory (FILE SYSTEM)	TP		Y	
Time						
T1	1, 2	Time resolution of internal clock			20	Nearest negative power of 2^{-n} in seconds (number 0 . . . 24)
T2	1, 2	Time accuracy of internal clock			IRIG-B T5 PTP T5 SNTP T1	TL (ms) (low-accuracy), T3 < 7) (only Ed. 2) T0 (ms) (≤ 10 ms), 7 ≤ T3 < 10 T1 (µs) (≤ 1 ms), 10 ≤ T3 < 13 T2 (µs) (≤ 100 µS), 13 ≤ T3 < 15 T3 (µs) (≤ 25 µS), 15 ≤ T3 < 18 T4 (µs) (≤ 25 µS), 15 ≤ T3 < 18 T5 (µs) (≤ 1 µS), T3 ≥ 20
T3	1, 2	Supported TimeStamp resolution			IRIGB 18 PTP 18 SNTP 7	Nearest negative power of 2^{-n} in seconds (number 0 . . . 24)

[a] SV publisher only

Potential Client and Automation Application Issues With Ed2 and Ed2.1 Upgrades

The following are issues that IEC 61850 Ed1-based client or automation applications may experience with IEC 61850 Ed2 and Ed2.1 ICD and firmware changes. However, such issues may be resolved by reconfiguring the client or automation application or worked around by restoring the Ed1 (CID) configuration. None of these should prevent a client application from dynamically discovering the data in the IED as long as the application adheres to the specification of the standard. Note that upgrading to Ed2 or Ed2.1 firmware will not break existing Ed1 configurations (CID files) in the field, nor require loading a new version of the CID file.

Unexpected Error Messages

Some MMS and control errors have been changed in Ed2. Hence, the firmware now issues only the Ed2-compliant errors. Clients or automation applications that rely on the Ed1-compliant errors will not function correctly. You can resolve this by reconfiguring the client or automation application to accept Ed2-compliant errors.

Missing or Unknown Data Objects and Attributes

Ed2 has changed some data object and attribute names, as well as the data types of some attributes. Ed2 also prohibits the use of proprietary CDCs. See *Common Logical Nodes on page 17.55* and the logical nodes tables in each product-specific manual to determine the Ed2 names. This may cause the failure of clients or automation applications that rely on the Ed1 names. A workaround is to use the Ed1 version of the CID file, if available, to configure the IED. You can also resolve this by reconfiguring the client or automation application to accept the Ed2 names.

Unable to Find Operate Time-Out

A proprietary method was used to specify the operate time-out of control objects in the CID files. A client or automation application that relies on this proprietary method will fail to find the operate time-out in the CID file. A workaround is to use the Ed1 CID file to configure the IED. You can also resolve this by reconfiguring the client or automation application to accept the Ed2 control object operate time-outs.

Unexpected Control Block Data Attribute Type

The string type data attributes in control blocks (RptID, DatSet, etc.) have been changed from a maximum length of 65 to 129 characters, i.e., VisString65 to VisString129. Some clients and automation applications might see this as an error when the type is reported in the MMS GetVariableAccessAttributes response. You can resolve this by reconfiguring the client or automation application or enabling the Ed1 server compatibility mode in the relay (see *Backward Compatibility With Ed1 Devices on page 17.97*).

Unexpected Reports

Ed2 requires report buffering to start when the device is turned on, unlike in the Ed1 implementation where report buffering started after the first report enable. If a client or automation application relies on the Ed1 behavior, it might fail or indicate an error if the IED sends buffered reports immediately after the first enable. You can resolve this by reconfiguring the client or automation application.

Failure to Reselect a Control Object Before the Time-Out

In Ed1, if a client reselected a control object before the select-before-operate time-out expired, the reselection would succeed and cause the selected time-out to restart. According to Ed2, this reselection is supposed to fail. Ed1-based clients or automation applications that rely on successful reselection might operate incorrectly. You can resolve this by reconfiguring the client or automation application.

Test Control Commands Fail Immediately

In Ed1, if the test attribute was set in a control command structure, the relay would accept the command but perform no action on the target control object. With enhanced control models, the IED would eventually report an operate time-out error after the operate time-out expired. However, in Ed2, any such test commands will fail immediately with an error indicating that the command is blocked

because the IED is not in the appropriate mode. Clients or automation applications that depend on the Ed1 behavior might fail. You can resolve this by reconfiguring the client or automation application.

No Reports

Ed2 specifies that no reports are to be generated for a deadbanded attribute if the deadband is set to 0. Previously in Ed1, a deadband of 0 would cause the relay to generate reports for any change in the instantaneous value. Ed1-based clients or automation applications might not operate correctly because of the lack of reports. You can resolve this by reconfiguring the client or automation application.

Known Interoperability Issues Between Ed2.1 and Ed2

For unbuffered and buffered reporting, the client reserves the RCB first before changing the configuration and enabling it. Otherwise, if not reserved, the server refuses the configuration and enable request. SEL recommends that you update each client system to Ed2.1 when an Ed2.1 server device is used.

Changes to Data Modeling in Ed2.1

Some logical nodes and data objects have been extended and updated in Ed2.1. The logical nodes and objects present in the default ICD files for SEL devices may have changed for Ed2.1. A table of objects included in the default ICD files is included in the product-specific instruction manual. Optional objects and attributes not included in the default ICD files may not be listed.

The name space for data modeling in Ed2.1 has been changed from IEC 61850-7-4:2007A to IEC 61850-7-4:2007B.

Changes Related to Communication Services in Ed2.1

The changes for communication services in Ed2.1 include:

- Setting Group
  - SGCB.LActTm updates when the active setting group has changed via non-IEC 61850 means or if a setting has changed in the active setting group.
- Unbuffered Reporting
  - Clients must always set Resv = TRUE, even when the URCB is preassigned, before the report can be enabled.
  - When a URCB instance is preassigned to a specific client, Resv = TRUE.
- Buffered Reporting
  - Clients must always set ResvTms to a value greater than 0, even when the BRCB is preassigned, before the report can be enabled.
  - Servers will refuse configuration and RptEna = T if the client did not reserve a report.
- LTMS.TmSrc Data Object
  - When the type of clock source is PTP, the LTMS.TmSrc data object outputs the grandmaster PTP clock identity according to IEC/IEEE 61588:2021.

Backward Compatibility With Ed1 Devices

In some cases, updating Ed1 client applications or server devices in an existing IEC 61850 system may not be feasible. While Ed2 or Ed2.1 devices are generally backward compatible, it might be preferable to use an Ed1 ICD file in a device that supports Ed2 or Ed2.1. Architect provides a selection option to allow an Ed2.1 device to communicate with an Ed1 client.

Ed1 subscriber devices cannot interpret the simulation bit or Mode/Behavior in a GOOSE or Sampled Values data message, which could lead to a misoperation. Therefore, caution and thorough testing are essential in mixed edition systems.

This page intentionally left blank

SECTION 18

Synchrophasors

Most SEL-400 series relays can be configured to function as a phasor measurement unit (PMU).

This section covers:

- *Synchrophasor Measurement on page 18.3*
- *Settings for Synchrophasors on page 18.6*
- *Synchrophasor Quantities on page 18.18*
- *View Synchrophasors by Using the MET PM Command on page 18.21*
- *IEEE C37.118 Synchrophasor Protocol on page 18.23*
- *SEL Fast Message Synchrophasor Protocol on page 18.29*
- *Control Capabilities on page 18.33*
- *PMU Recording Capabilities on page 18.42*

Introduction

The word synchrophasor is derived from two words: synchronized phasor. Synchrophasor measurement refers to the concept of providing measurements taken on a synchronized schedule in multiple locations. A high-accuracy clock, commonly a Global Positioning System (GPS) receiver such as the SEL-2488 Satellite-Synchronized Network Clock, makes synchrophasor measurement possible.

The availability of an accurate time reference over a large geographic area allows multiple devices, such as a number of relays, to synchronize the gathering of power system data. The accurate clock allows precise event report triggering and other offline analysis functions.

The Global settings class contains the synchrophasor settings, including the choice of Synchrophasor Protocol and the synchrophasor data set the relay will transmit. The Port settings class selects which port(s) are configured for Synchrophasor Protocol use.

The high-accuracy timekeeping function generates status Relay Word bits and time-quality information that is important for synchrophasor measurement.

When synchrophasor measurement is enabled, the relay creates the synchrophasor data set at a rate of either 50 or 60 times per second, depending on the nominal system frequency (Global setting NFREQ). This data set, including time-of-sample, is available in analog quantities in the relay (see Synchrophasor Analog Quantities). You can view synchrophasor data over the relay ASCII terminal interface (see *View Synchrophasors by Using the MET PM Command on page 18.21*).

The value of synchrophasor data increases greatly when the data can be shared over a communications network in real time. Two Synchrophasor Protocols are available in the relay that allow for a centralized device to collect data efficiently from several PMUs. Some possible uses of a system-wide synchrophasor system include the following:

- Power system state measurement
- Wide-area network protection and control schemes
- Small-signal analysis
- Power system disturbance analysis

NOTE: The SEL-3555 RTAC with the SVP library has replaced the SEL-3378, which is no longer in production, but you can still use the SEL-3378 in the examples in this section.

The SEL-3555 Real-Time Automation Controller (RTAC) is a real-time synchrophasor programmable logic controller. Use the SEL-3555 to collect synchrophasor messages from relays and PMUs. The SEL-3555 time-aligns incoming messages and processes these messages with an internal logic engine. Additionally, the SEL-3555 can send calculated or derived data to devices such as other synchrophasor vector processors (SVPs), phasor data concentrators (PDCs), and monitoring systems.

In any installation, the relay can use only one of the synchrophasor message formats, SEL Fast Message Synchrophasor, or IEEE C37.118, as selected by Global setting MFRMT. The chosen format is available on multiple serial ports when port setting(s) PROTO := PMU. IEEE C37.118 is available over Ethernet when the **PORT 5** setting EPMIP is enabled.

NOTE: Relays that support IEEE C37.118.1-2011 do not support SEL Fast Message Synchophasor protocol.

With either the SEL Fast Message or IEEE C37.118 synchrophasor format, the relay can receive control operation commands over the same channel used for synchrophasor data transmission. These commands are SEL Fast Operate messages, which are described in *SEL Fast Meter, Fast Operate, Fast SER Messages, and Fast Message Data Access on page 15.34*.

After enabling the data recording function with the Global EPMDR settings, record synchrophasor data using the PMTRIG setting. When PMTRIG asserts, the relay records IEEE synchrophasor data in binary format for the duration specified with the PMLER setting. The relay stores these files in the synchrophasor subdirectory in the relay.

You can configure the relay to receive IEEE C37.118 protocol synchrophasor data. The relay receives the data over a serial connection and stores these data in Analog Quantities. Time-alignment is automatic. Use the local phasor data and as many as two remote sets of phasor data in SELOGIC equations.

Functionality in IEEE C37.118.1-2011-Compliant Synchrophasors

When compared to IEEE C37.118-2005, IEEE C37.118.1 has several differences, some of which are described below.

NOTE: All references to IEEE C37.118.1 in this document are references to IEEE C37.118.1-2011, as amended by IEEE C37.118.1a-2014.

Performance Classes. IEEE C37.118.1 introduced two performance classes: P class and M class. P class (protection) is for applications that require a faster response and less filtering. M class (measurement) is for applications that require more accuracy and do not require minimal reporting delay.

Specified Latency. IEEE C37.118.1 introduced message latency requirements. In this context, message latency is defined as the time interval between when an event occurs on the power system to the time that it is reported in data.

Dynamic Performance. IEEE C37.118.1 introduced dynamic performance requirements, whereas the 2005 standard only specified performance when the power system was in steady state.

Rate-of-Change of Frequency (ROCOF). IEEE C37.118.1 introduced requirements on the responsiveness of ROCOF beyond that of the 2005 standard. One effect of these changes is to make ROCOF more sensitive to noise, so care should be taken before applying the ROCOF value to a control scheme.

Synchrophasor Measurement

The PMU uses the signal processing shown in *Figure 18.1* to measure the synchrophasors. The input signal passes through a traditional anti-aliasing low-pass filter (LPF). This filter has a cutoff frequency of 250 Hz. The PMU decimates this 8 kHz filtered data by eight and then processes the resulting data at 1 kHz.

NOTE: This section describes IEEE C37.118-2005-compliant devices.

The PMU then modulates the 1 kHz data with two sinusoids, each 90 degrees apart to produce real and imaginary components of the synchrophasor. The modulating sinusoids are synchronized to absolute time to provide an absolute time reference for the synchrophasor. Also an angular compensation factor compensates for the phase shift introduced by the PMU hardware and software.

The modulated data are filtered using low-pass filters. The filter coefficients are based on NFREQ, PMAPP, and MRATE. The filtered data provides good attenuation for harmonics and interharmonics. For PMAPP = F and N the attenuation is 20 dB. For PMAPP = 1 the attenuation is 40 dB.

Relays with DSS technology adjust synchrophasors automatically by the channel delay associated with the DSS technology used. This allows for comparing synchrophasor measurements gathered from traditional, non-DSS relays.

Figure 18.1 Synchrophasor Processing Block Diagram

Figure 18.2 shows the magnitude frequency response of the synchronized phasor measurement for PMAPP = F, N, and 1 for MRATE = 60.

Figure 18.2 Magnitude Frequency Response

After low-pass filtering, the data are decimated to the nominal power system frequency (NFREQ).

If frequency-based phasor compensation is enabled (PHCOMP = Y), the relay calculates a compensation factor based on the measured synchrophasor frequency (FREQPM) and filter configuration (based on NFREQ, MRATE, and PMAPP). The PMU then corrects the measured synchrophasors by this factor.

Using the V*m*COMP and I*n*COMP settings, the PMU compensates the voltage and current synchrophasors for any externally introduced phase angle errors. The PMU adds the user-entered phase angle to the phase angle of the measured synchrophasor.

The PMU converts the synchrophasor data to primary units by multiplying them with the respective PT or CT ratios. Note that the resulting data Vk*m*SF and Ik*n*SF is in complex form (A + jB). The PMU calculates the positive-sequence synchrophasor with the three-phase synchrophasors.

The PMU then converts all synchrophasor data to polar and rectangular quantities. The data are available as analog quantities as well as for the synchrophasor data frames. The synchrophasor data are updated at the nominal power system frequency.

Accuracy

For devices that comply to IEEE C37.118.1, refer to the IEEE standard.

For synchrophasors that comply to the 2005 standard, the following phasor measurement accuracy is valid when frequency-based phasor compensation is enabled (Global setting PHCOMP := Y), and when the phasor measurement application setting is in the narrow bandwidth mode (Global setting PMAPP := N).

NOTE: When the PMU is in the fast response mode (Global setting PMAPP := F), the TVE is within specified limits only when the out of band interfering signals influence quantity is not included.

TVE (total vector error) ≤1% for one or more of the following influence quantities.

- For PMAPP = N Signal Frequency Range: ±5 Hz of nominal (50 or 60 Hz)
- For PMAPP = 1 Signal Frequency Range: ±2 Hz of 60 Hz
- Voltage Magnitude Range: 30 V–150 V
- Current Magnitude Range: (0.1–2) • I_{NOM}, (I_{NOM} = 1 A or 5 A)
- Phase Angle Range: –179.99° to 180°
- Harmonic distortion ≤10 percent (any harmonic)
- Out of band interfering signals ≤10 percent

The out-of-band interfering signal frequency (f_i) must satisfy:

$$| f_i - NFREQ | > MRATE/2,$$

where NFREQ is nominal system frequency and MRATE is the message rate, as defined in IEEE C37.118.

It is important to note that the synchrophasors can only be correlated when the PMU is in HIRIG or HPTP timekeeping mode, which can be verified by monitoring the TSOK Relay Word bit. When TSOK = logical 1, the PMU timekeeping is synchronized to the high-accuracy IRIG-B signal or Precision Time Protocol (PTP) time source, and the synchrophasor data are precisely time-stamped. See *Section 11: Time and Date Management* for details.

PMU Data Block Status

In a PMU data frame, each data block is headed by a two-byte STAT field. This field indicates the status of the PMU data block. Bit 15 of the STAT field indicates the validity of data. SEL-400 series relays assert bit 15 of the STAT when synchrophasor test mode indicator PMTEST asserts or SVBK_EX asserts in SEL-400 series Sampled Values (SV) subscribers.

For SV-subscribing relays, configure Global setting SVBLK to assert on errors encountered in SV data acquisition. For example, set SVBLK := IAWBK OR IBWBK OR ICWBK. In this example, if SV data for any Terminal W current is lost, SVBK_EX asserts, which then asserts bit 15 in the STAT field, indicating current data have errors and, therefore, synchrophasor data are invalid.

For an explanation of other bits in the STAT field, refer to the IEEE C37.118 standard.

Synchrophasor Frequency

The PMU calculates frequency deviation and rate-of-change of frequency from the synchrophasor positive-sequence voltage angle (V1*n*PMA, where *n* = PMFRQST) as follows.

NOTE: Applies to IEEE C37.118-2005-compliant devices.

First, the PMU calculates the frequency deviation from nominal using the following formula.

$$f_k = \frac{(\theta_k - \theta_{k-1})}{\Delta t \bullet 360}$$

Equation 18.1

Where θ_k is the V1*n*PMA and θ_{k-1} is V1*n*PMA calculated 1 cycle previously. Δt is the time difference between the angle calculations (*k* increments once a nominal power system cycle).

Next, the PMU averages the frequency deviation as shown in *Equation 18.2* and *Equation 18.3*.

If the frequency application is smooth (PMFRQA = S)

$$favg_k = \frac{\left(\sum_{n=0}^{9} f_k - n\right) - f_{max1} - f_{max2} - f_{min1} - f_{min2}}{6}$$

Equation 18.2

If the frequency application is fast (PMFRQA = F)

$$favg_k = \frac{\left(\sum_{n=0}^{3} f_k - n\right) - f_{max} - f_{min}}{2}$$

Equation 18.3

The PMU then calculates rate-of-change of frequency, *df/dt* from the averaged frequencies deviations (*Equation 18.4*).

$$df/dt_k = \frac{(favg_k - favg_{k-1})}{\Delta t}$$

Equation 18.4

If the frequency value is equal to or within ±20 Hz and V1*n*MPM/PTR*n* (secondary) is larger than 0.1 • VNOM*n* then:

$FREQPM_k = favg_k + NFREQ$	<analog>
$DFDTPM_k = df/dt_k$	<analog>
After six consecutive cycles	
$FROKPM_k = 1$	<digital>

If the frequency value exceeds ±20 Hz or the V1*n*MPM/PTR*n* (secondary) is below 0.1 • VNOM*n* then:

$FREQPM_k = FREQPM_{k-1}$	<analog>
$DFDTPM_k = 0$	<analog>
$FROKPM_k = 0$	<digital>

The frequency and rate-of-change of frequency are available as analog quantities as well as for the synchrophasor data frames. The data are updated at the nominal power system frequency.

Table 18.1 Synchrophasor Analog Quantities Frequency

Name	Description	Units
FREQPM	Measured system frequency	Hz
DFDTPM	Rate-of-change of frequency	Hz/s

Settings for Synchrophasors

Each SEL-400 series relay supports a variety of current and voltage terminals. See the product-specific instruction manuals for specific settings based on the synchrophasor standard supported and to see which terminals are available to synchrophasors. Synchrophasors are primarily configured through the Global settings. There are also a few port settings necessary to enable synchrophasor communications.

Global Settings

The Global enable setting EPMU must be set to Y before the remaining synchrophasor settings are available. The PMU is disabled when EPMU := N.

Table 18.2 Global Settings for Configuring the PMU

Setting	Setting Prompt
EPMU	Synchronized Phasor Measurement (Y, N)
MFRMT[a]	Message Format (C37.118, FM)
MRATE[a]	Messages per Second (1, 2, 4, 5, 10, 12, 15, 20, 30, 60)[b]
PMAPP[a]	PMU Application (F, N, 1)
MRATE*n*[c]	Messages per Second (1, 2, 4, 5, 10, 12, 15, 20, 30, 60)[b]
PMAPP*n*[c]	PMU Application (P, M)
PMLEGCY[a]	Synchrophasor Legacy Settings (Y, N, N1[d])
NUMPHDC	Number of Data Configurations (1–5)
PMSTN*q*[e]	Station Name (16 characters)
PMID*q*[e]	PMU Hardware ID (1–65534)
PHDV*q*[e]	Phasor Data Set, Voltages (V1, PH, ALL)
PHDI*q*[e]	Phasor Data Set, Currents (I1, PH, ALL)
PHNR*q*[e]	Phasor Num. Representation (I = Integer, F = Float)
PHFMT*q*[e]	Phasor Format (R = Rectangular, P = Polar)
FNR*q*[e]	Freq. Num. Representation (I = Integer, F = Float)
TREA[1–4]	Trigger Reason Bit [1–4] (SELOGIC Equation)
PMTRIG	Trigger (SELOGIC Equation)
PMTEST	PMU in Test Mode (SELOGIC Equation)
V*k*COMP[f]	Comp. Angle Terminal *k* (–179.99° to 180°)
I*n*COMP[g]	Comp. Angle Terminal *n* (–179.99° to 180°)
PMFRQST	PMU Primary Frequency Source Terminal
PMFRQA[a]	PMU Frequency Application (F, S)
PHCOMP[a]	Freq. Based Phasor Compensation (Y, N)

[a] Not used in IEEE C37.118-2011-compliant devices.
[b] If NFREQ = 50 then the range is 1, 2, 5, 10, 25, 50.
[c] Only used in IEEE C37.118-2011-compliant devices.
[d] PMLEGCY option of N1 only applies to the SEL-487E.
[e] q = 1–NUMPHDC.
[f] k = voltage terminal.
[g] n = current terminal.

Descriptions for some of the settings in *Table 18.2* are as follows.

MFRMT

Selects the message format for synchrophasor data.

SEL recommends the use of MFRMT := C37.118 for any new PMU applications because of increased setting flexibility and the expected availability of software for synchrophasor processors. The PMU still includes the MFRMT := FM setting choice to maintain compatibility in any systems presently using SEL Fast Message synchrophasors.

MRATE

Selects the message rate in messages per second for synchrophasor data.

Choose the MRATE setting that suits the needs of your PMU application. The PMU supports as many as 60 messages per second if NFREQ = 60 and as many as 50 messages per second if NFREQ = 50.

MRATEn

Selects the message rate in messages per second for synchrophasor data per data configuration 1–5. MRATE*n* must be set to the same value across all data configurations that share the same filter type. The filter type is determined by the PMAPP*n* setting.

PMAPP

Selects the type of digital filters used in the synchrophasor measurement.

- The Narrow Bandwidth setting (N) represents filters with a cutoff frequency approximately 1/4 of MRATE. The response in the frequency domain is narrower, and response in the time domain is slower. This method results in synchrophasor data that are free of aliasing signals and well suited for post-disturbance analysis.
- The Fast Response setting (F) represents filters with a higher cutoff frequency. The response in the frequency domain is wider and the response in the time domain is faster. This method results in synchrophasor data that can be used in synchrophasor applications requiring more speed in tracing system parameters.
- The Filter One setting (1) represents filters that have a response much narrower than the narrow bandwidth filters. This method has a better step response with overshoot within 7.5 percent. This filter is available only for MRATE = 60.

PMAPPn

Selects the type of digital filters used in the synchrophasor measurement per data configuration 1–5. The filter that you select is applied to all configured data streams.

IEEE C37.118.1-2011 defines two performance classes: P (protection) and M (meter). P class measurements has faster response times and lower message latency. M class measurements are more accurate but have a slower response time and higher message latency.

For more information on the filtering classes, refer to the IEEE C37.118 standard.

PMLEGCY

This setting is provided for supporting legacy synchrophasor settings. Set this to N to access the latest features. See *Legacy Settings on page 18.15* to see a description of the legacy settings. The remainder of this section describes the non-legacy settings. Relays that support IEEE C37.118.1-2011 do not contain this setting.

NUMPHDC

Enables as many as five unique synchrophasor data configurations.

The four serial ports (**PORT 1**, **PORT 2**, **PORT 3**, and **PORT F**) and two Ethernet sessions (TCP/UDP Sessions 1 and 2) can be mapped to any of these five data configurations. In other words each port can be configured to send unique synchrophasor data streams.

PMSTNq and PMIDq

Defines the station name and number of the PMU for data configuration *q*.

The PMSTN*q* setting is an ASCII string with as many as 16 characters. The PMID*q* setting is a numeric value. Use your utility or synchrophasor data concentrator naming convention to determine these settings. PMSTN*q* allows all printable characters.

Phasors Included in the Data q

Terminal Name, Relay Word Bit, Alternative Terminal Name

Specify the terminal for Synchrophasor measurement and transmission in the synchrophasor data stream *q*.

This is a freeform setting category for enabling the terminals for synchrophasor measurement and transmission. This freeform setting has three arguments. Specify the terminal name (any one of the valid terminals for the relay) for the first argument. Specify any Relay Word bit for the second argument. Specify the alternative terminal name (any one of the valid terminals for the relay) for the third argument.

The second and third arguments are optional unless switching between terminals is required. Whenever the Relay Word bit in the second argument is asserted the terminal synchrophasor data are replaced by the alternative terminal data.

PHDVq

Selects the type of voltages to be included in the synchrophasor data stream *q*.

This setting affects the synchrophasor data packet size.

- PHDV*q* := V1, sends only positive-sequence voltage synchrophasors of selected terminals.
- PHDV*q* := PH, sends only phase voltage synchrophasors of selected terminals.
- PHDV*q* := ALL, sends phase and positive-sequence voltage synchrophasors of selected terminals.

PHDIq

Selects the type of currents to be included in the synchrophasor data stream q.

This setting affects the synchrophasor data packet size.

- PHDI*q* := I1, sends only positive-sequence current synchrophasors of selected terminals.
- PHDI*q* := PH, sends only phase current synchrophasors of selected terminals.
- PHDI*q* := ALL, sends phase and positive-sequence current synchrophasors of selected terminals.

PHNRq

Selects the numeric representation, integer (I) or floating-point (F), of voltage and current phasor data in the synchrophasor data stream *q*. This setting affects the synchrophasor data packet size.

- PHNR*q* := I sends each voltage and/or current synchrophasor as 2 two-byte integer values. The PMU uses ((7 • I_{NOM} • CT Ratio) / 32768) • 100000)) for the current phasor scaling factor and uses ((150 • PTR) / 32768) • 100000)) for the voltage phasor scaling factor. I_{NOM} is 1 A or 5 A.
- PHNR*q* := F sends each voltage and/or current synchrophasor as 2 four-byte floating-point values.

PHFMTq

Selects the phasor representation of voltage and current phasor data in the synchrophasor data stream q.

- PHFMT*q* := R (rectangular) sends each voltage and/or current synchrophasor as a pair of signed real and imaginary values.
- PHFMT*q* := P (polar) sends each voltage and/or current synchrophasor as a magnitude and angle pair. The angle is in radians when PHNR*q* := F, and in radians • 10^4 when PHNR*q* := I. The range is $-\pi < \text{angle} \leq \pi$.

In both the rectangular and polar representations, the values are scaled in root mean square (rms) units. For example, a synchrophasor with a magnitude of 1.0 at an angle of –30 degrees will have a real component of 0.866, and an imaginary component of –0.500.

FNRq

Selects the numeric representation, integer (I) or floating-point (F), of the two frequency values in the synchrophasor data stream *q*.

This setting affects the synchrophasor data packet size.

- FNR*q* := I sends the frequency data as a difference from nominal frequency, NFREQ, with the following formula.

  (FREQPM – NFREQ) • 1000,

  represented as a signed, two-byte value. See *Synchrophasor Frequency on page 18.5* for details.
- FNR*q* := I also sends the rate-of-change-of-frequency data with scaling.

  DFDTPM • 100,

  represented as a signed, two-byte value. See *Synchrophasor Frequency on page 18.5* for details.
- FNR*q* := F sends the measured frequency data and rate-of-change of frequency as two four-byte, floating-point values.

Phasor Aliases in Data Configuration q

Phasor Name, Alias Name

This is a freeform setting category with two arguments. Specify the phasor name and a 16 character descriptive name to be included in the synchrophasor data stream *q*. If a phasor is not assigned a descriptive name, it will be described using the phasor name.

Analog Quantities in Data Configuration q

Analog Quantity Name, Alias Name

This is a freeform setting category with two arguments. Specify the analog quantity name and an optional 16 character descriptive name to be included in the synchrophasor data stream *q*. See *Section 12: Analog Quantities* in the product-specific instruction manual for a list of analog quantities that the PMU supports. The PMU can be configured for as many as 16 unique analog quantities for each data configuration *q*. The analog quantities are floating-point values, so each analog quantity the PMU includes will take four bytes.

Digitals in Data Configuration q

Relay Word Bit Name, Alias Name

This is a freeform setting category with two arguments. Specify the Relay Word bit name and an optional 16 character descriptive name that you need to include in the synchrophasor data stream *q*. See the Relay Word Bits section of the relay-specific instruction manual for a list of Relay Word bits that the PMU supports. You can configure the PMU for as many as 64 unique digitals for each data configuration.

TREA1, TREA2, TREA3, TREA4, and PMTRIG

Defines the programmable trigger bits as allowed by IEEE C37.118.

Each of the four Trigger Reason settings, TREA1–TREA4, and the PMU Trigger setting, PMTRIG, are SELOGIC control equations. The PMU evaluates these equations and places the results in Relay Word bits with the same names: TREA1–TREA4 and PMTRIG.

NOTE: Select PMTRIG trigger conditions to assert PMTRIG no more frequently than once every four hours if EPMDR = Y (i.e., synchrophasor recording is enabled).

The Trigger Reason equations represent the Trigger Reason bits in the STAT field of the data packet. After the Trigger Reason bits are set to convey a message, the PMTRIG Equation should be asserted long enough to allow the synchrophasor processor to read the TREA1–TREA4 fields. To calculate how long PMTRIG should remain asserted (in seconds), divide 1 by the MRATE Global settings value. For example, if MRATE = 60, PMTRIG should be asserted at least 17 ms. If MRATE = 1, PMTRIG should be asserted at least 1 second.

The IEEE C37.118 standard defines the first 8 of 16 binary combinations of these trigger reason bits (Bits 0–3).

The remaining eight binary combinations are available for user definition.

The PMU does not automatically set the TREA1–TREA4 or PMTRIG Relay Word bits—these bits must be programmed.

These bits may be used to send various messages at a low bandwidth via the synchrophasor message stream. Digital Status Words may also be used to send binary information directly, without the need to manage the coding of the trigger reason messages in SELOGIC.

Use these Trigger Reason bits if your synchrophasor system design requires these bits. The PMU synchrophasor processing and protocol transmission are not affected by the status of these bits.

PMTEST

Program this SELOGIC setting to force the PMU to test mode. The SELOGIC evaluation of this setting, PMTEST is mapped to the data valid bit (i.e., bit 15) in the STAT field.

VkCOMP

The V*k*COMP (*k* = voltage terminals) setting allows correction for any steady-state voltage phase errors (from the PTs or wiring characteristics). See *Synchrophasor Measurement on page 18.3* for details on this setting.

InCOMP

The I*n*COMP (*n* = current terminals) settings allow correction for any steady-state phase errors (from the CTs or wiring characteristics). See *Synchrophasor Measurement on page 18.3* for details on these settings.

PMFRQST

Selects the voltage terminal that will be the primary source of the system frequency for the PMU calculations. For example, if PMFRQST = Z, then the Z PT terminal is the source for frequency estimation.

PMFRQA

Selects the PMU frequency application. A setting of S sets a smooth frequency application. A setting of F selects a fast frequency application.

NOTE: Does not apply to newer synchrophasors.

The frequency application is used in the calculation of the rate-of-change of frequency for a given analog signal. A smooth frequency application setting (PMFRQA = S) uses 9 cycles of data for the rate-of-change calculation. A fast frequency application setting (PMFRQA = F) uses 3 cycles of data for the rate-of-change calculation.

The fast frequency application will detect rapid changes in frequency faster, but will also contain more low-level oscillations. The slow frequency application will provide a rate-of-change profile that is smoother, but slower to respond to rapid frequency fluctuations.

PHCOMP

Enables or disables frequency-based compensation for synchrophasors.

NOTE: Does not apply to newer synchrophasors.

For most applications, set PHCOMP := Y to activate the algorithm that compensates for the magnitude and angle errors of synchrophasors for frequencies that are off nominal.

For PMAPP = F or N, the PMU only compensates if the estimated frequency is ±5 Hz of nominal frequency. For PMAPP = 1 the PMU compensates if the frequency is ±2 Hz of nominal frequency.

Serial Port Settings

The port settings found in *Table 18.3* are used for configuring synchrophasor data transmission over a serial port.

Table 18.3 Serial PORT 1, PORT 2, PORT 3, PORT F Settings for Synchrophasors

Setting	Description
PROTO	Protocol (SEL, DNP, MBA, MBB, PMU[a])
SPEED	Data Speed (300–57600)
STOPBIT	Stop Bits (1, 2)
RTSCTS	Enable Hardware Handshaking (Y, N)
FASTOP	Enable Fast Operate Messages (Y, N)
PMUMODE	PMU Mode (CLIENTA, CLIENTB, SERVER)
PMODC	PMU Output Data Configuration (1–5)

[a] The specific protocol choices available depends on the relay.

Descriptions for some of the settings in *Table 18.3* are as follows.

PROTO

Setting this to PMU enables synchrophasor data transmission on the specific serial port. Once set to PMU that specific serial port cannot be used for accessing settings or issuing any ASCII commands.

If PROTO := PMU and MFRMT := C37.118, then the serial port will only respond to IEEE C37.118 commands.

- Stop synchrophasor data
- Start synchrophasor data
- Send header data
- Send Configuration 1 data
- Send Configuration 2 data
- Process extended frame data

NOTE: Relays that support IEEE C37.118.1-2011 do not support SEL Fast Message Synchrophasor protocol.

If PROTO := PMU or SEL and MFRMT := FM, then the serial port will only respond to SEL Fast Message synchrophasor commands.

SPEED

Select the data rate (300–57600) for synchrophasor data transmission on the specific serial port. This setting affects the synchrophasor data packet size. See *Communications Bandwidth on page 18.24* for detailed information.

PMUMODE

Set PMUMODE := SERVER if the serial port is intended to send synchrophasor data. Client applications are described in *Real-Time Control on page 18.36*.

PMODC

NOTE: If PMODC is set to a number that exceeds the setting for NUMPHDC, the port sends the data for the first PMU configuration.

Select the data configuration (1-NUMPHDC) for synchrophasor data transmission on the specific serial port. This setting affects the synchrophasor data packet size. See *Communications Bandwidth on page 18.24* for detailed information. Through the use of this setting each serial port can be configured to stream unique synchrophasor data.

EPMU := N Supersedes Synchrophasor Port Settings

The PROTO := PMU settings choice can be made even when Global setting EPMU := N. However, in this situation, the serial port will not respond to any commands or requests. Either enable synchrophasors by setting EPMU to Y, or change the port PROTO setting to SEL.

If you use a computer terminal session or ACSELERATOR QuickSet SEL-5030 Software connected to a serial port, and then set that same serial port PROTO setting to PMU, you will lose the ability to communicate with the relay through ASCII commands or virtual file interface commands. If this happens, either connect via another serial port (that has PROTO := SEL) or use the front-panel `HMI SET/SHOW` screen to change the disabled port PROTO setting back to SEL.

Ethernet Port Settings

The settings found in *Table 12.24* and *Table 12.32* are used for configuring synchrophasor data transmission over an Ethernet port. Descriptions for some of the settings are as follows.

EPMIP

This setting enables synchrophasor data transmission over Ethernet. Enabling EPMIP when Global setting EPMU := N results in the relay ignoring any incoming synchrophasor requests regardless of whether the Ethernet port settings are correct or not.

PMOTS[2]

Selects the PMU Output transport scheme for session 1 and 2, respectively.

- PMOTS[2] := TCP establishes a single, persistent TCP socket for transmitting and receiving synchrophasor messages (both commands and data), as illustrated in *Figure 18.3*.

Figure 18.3 TCP Connection

- PMOTS[2] := UDP_T establishes two socket connections. A nonpersistent TCP connection is used for receiving synchrophasor command messages as well as synchrophasor configuration and header response messages. A persistent UDP connection is used to transmit synchrophasor data messages. *Figure 18.4* depicts the UDP_T connection.
- PMOTS[2] := UDP_U uses the same connection scheme as the UDP_T except the synchrophasor configuration and header response messages are sent over the UDP connection, as shown in *Figure 18.4*.

Figure 18.4 UDP_T and UDP_U Connections

➤ PMOTS[2] := UDP_S establishes a single persistent UDP socket to transmit synchrophasor messages. Synchrophasor data are transmitted whenever new data are read. With this communications scheme, the relay sends a "Synchrophasor Configuration Response 2" once every minute, as shown in *Figure 18.5*.

Figure 18.5 UDP_S Connection

PMODC[2]

NOTE: If PMODC is set to a number that exceeds the setting for NUMPHDC, the port sends the data for the first PMU configuration.

Select the data configuration (1-NUMPHDC) for synchrophasor data transmission on the specific session 1 and 2. Using this setting, each Ethernet session can be configured to stream unique synchrophasor data.

PMOIPA[2]

Defines the PMU Output Client IP address for session 1 and 2, respectively.

PMOTCP[2]

Defines the TCP/IP (Local) port number for session 1 and 2, respectively. These port numbers must all be unique.

PMOUDP[2]

Defines the UDP/IP (Remote) port number for session 1 and 2, respectively.

Legacy Settings

The PMU provides the following legacy synchrophasor settings that can be enabled by setting PMLEGCY = Y.

PMSTN and PMID

Defines the name and number of the PMU. The PMSTN setting is an ASCII string with as many as 16 characters. The PMID setting is a numeric value (1–65534). Use your utility or synchrophasor data concentrator naming convention to determine these settings.

PHVOLT and PHDATAV

PHDATAV and PHVOLT select which voltage synchrophasors to include in the data packet. If MFRMT = FM, the only options available are V1 and ALL.

- PHDATAV := V1 will transmit only positive-sequence voltage,V1
- PHDATAV = PH will transmit phase voltages only (VA, VB, VC)
- PHDATAV := ALL will transmit V1, VA, VB, and VC
- PHDATAV := NA will not transmit any voltages

PHVOLT selects the voltage sources for the synchrophasor data selected by PHDATAV.

Use the PHVOLT setting to select any combination of available voltage terminals.

PHCURR and PHDATAI

PHDATAI and PHCURR select which current synchrophasors to include in the data packet.

- PHDATAI := I1 will transmit only positive-sequence current, I1
- PHDATAI := PH transmits phase currents (IA, IB, IC)
- PHDATAI := ALL will transmit I1, IA, IB, and IC
- PHDATAI := NA will not transmit any currents

PHCURR selects the source current(s) for the synchrophasor data selected by PHDATAI.

Use the PHCURR setting to select any combination of available current terminals. If MFRMT = FM, only a single terminal can be selected.

PHNR

Selects the numerical representation of voltage and current phasor data in the synchrophasor data stream. If MFRMT = FM, this setting is forced to F, a floating-point value.

PHFMT

Selects the phasor representation of voltage and current phasor data in the synchrophasor data stream. If MFRMT = FM, this setting is forced to P, for polar phasor format. This setting is hidden if PHDATAV and PHDATAI = NA.

FNR

Selects the numeric representation of the two frequency values in the synchrophasor data stream. If MFRMT = FM, this setting is forced to F, a floating-point value.

NUMANA

Selects the number of user-definable analog values to be included in the synchrophasor data stream.

- Setting NUMANA := 0 sends no user-definable analog values.
- Setting NUMANA := 1–16 sends the user-definable analog values, as listed in *Table 18.4*.

The format of the user-defined analog data is always floating point, and each value occupies four bytes. If MFRMT = FM, this setting is forced to 0 and the relay does not send any user-definable analog values.

Table 18.4 User-Defined Analog Values Selected by NUMANA Setting

NUMANA Setting	Analog Quantities Sent	Total Number of Bytes Used for Analog Values
0	None	0
1	PMV64	4
2	Above, plus PMV63	8
3	Above, plus PMV62	12
4	Above, plus PMV61	16
5	Above, plus PMV60	20
6	Above, plus PMV59	24
7	Above, plus PMV58	28
8	Above, plus PMV57	32
9	Above, plus PMV56	36
10	Above, plus PMV55	40
11	Above, plus PMV54	44
12	Above, plus PMV53	48
13	Above, plus PMV52	52
14	Above, plus PMV51	56
15	Above, plus PMV50	60
16	Above, plus PMV49	64

NUMDSW

Selects the number of user-definable digital status words to be included in the synchrophasor data stream.

Setting NUMDSW := 0 sends no user-definable binary status words.

Setting NUMDSW := 1, 2, 3, or 4 sends the user-definable binary status words, as listed in *Table 18.5*. If MFRMT = FM, this is forced to 1.

Table 18.5 User-Defined Digital Status Words Selected by the NUMDSW Setting (Sheet 1 of 2)

NUMDSW Setting	Digital Status Words Sent	Total Number of Bytes Used for Digital Values
0	None	0
1	[PSV64, PSV63 … PSV49]	2

Table 18.5 User-Defined Digital Status Words Selected by the NUMDSW Setting (Sheet 2 of 2)

NUMDSW Setting	Digital Status Words Sent	Total Number of Bytes Used for Digital Values
2	[PSV64, PSV63 … PSV49] [PSV48, PSV47 … PSV33]	4
3	[PSV64,PSV63 … PSV49] [PSV48,PSV47 … PSV33] [PSV32,PSV31 … PSV17]	6
4	[PSV64,PSV63 … PSV49] [PSV48,PSV47 … PSV33] [PSV32,PSV31 … PSV17] [PSV16,PSV15 … PSV01]	8

Synchrophasor Quantities

Relay Word Bits

This section describes the Relay Word bits that are related to synchrophasor measurement.

The Synchrophasor Trigger Relay Word bits in *Table 18.6* follow the state of the SELOGIC control equations of the same name. These Relay Word bits are included in the IEEE C37.118 synchrophasor data frame STAT field. See *Table 18.6* for standard definitions for these settings.

Table 18.6 Synchrophasor Trigger Relay Word Bits

Name	Description
PMTRIG	Trigger (SELOGIC control equation)
TREA4	Trigger Reason Bit 4 (SELOGIC control equation)
TREA3	Trigger Reason Bit 3 (SELOGIC control equation)
TREA2	Trigger Reason Bit 2 (SELOGIC control equation)
TREA1	Trigger Reason Bit 1 (SELOGIC control equation)

The Time-Synchronization Relay Word bits in *Table 18.7* indicate the present status of the high-accuracy timekeeping function of the relay.

Table 18.7 Time-Synchronization Relay Word Bits

Name	Description
TIRIG	Asserts while relay time is based on IRIG-B time source.
PTP	Synchronized to a PTP source.
TPTP	The active relay time source is PTP.
TSOK	Time synchronization OK. Asserts while time is based on high-accuracy IRIG-B or PTP time source (HIRIG or HPTP mode) of sufficient accuracy for synchrophasor measurement.
PTPSYNC	Asserts while the relay is synchronized to a high-quality PTP time source.
PMDOK	Phasor measurement data OK. Asserts when the relay is enabled and synchrophasors are enabled (Global setting EPMU := Y).

When using the relay as a synchrophasor client, the Relay Word bits in *Table 18.8* indicate the state of the synchronization.

Table 18.8 Synchrophasor Client Status Bits for Real-Time Control

Name	Description
RTCENA	Asserts for one processing interval when a valid message is received on Channel A.
RTCENB	Asserts for one processing interval when a valid message is received on Channel B.
RTCROKA	Asserts for one processing interval when data are aligned for Channel A. Use this bit to condition usage of the Channel A data.
RTCROKB	Asserts for one processing interval when data are aligned for Channel B. Use this bit to condition usage of the Channel B data.
RTCROK	Asserts for one processing interval when data for all enabled channels are aligned. Use this bit to condition general usage of the aligned synchrophasor data.
RTCDLYA	This bit is asserted when the last received valid message on Channel A is older than MRTCDLY.
RTCDLYB	This bit is asserted when the last received valid message on Channel B is older than MRTCDLY.
RTCSEQA	This bit is asserted when the processed received message on Channel A is the expected next-in-sequence. It is deasserted if it is not. The deassertion implies that one or more packets of information were lost. Use this bit to condition usage of channel A data in applications where sequential data are required.
RTCSEQB	This bit is asserted when the processed received message on Channel B is the expected next-in-sequence. It is deasserted if it is not. The deassertion implies that one or more packets of information were lost. Use this bit to condition usage of channel B data in applications where sequential data are required.
RTCCFGA	Indicates Channel A is successfully configured.
RTCCFGB	Indicates Channel B is successfully configured.

When received, synchrophasor messages contain digital data. These data are stored in the Remote Synchrophasor Relay Word bits in *Table 18.9*.

Table 18.9 Remote Synchrophasor Data Bits for Real-Time Control

Name	Description
RTCAD01–RTCAD16	First 16 digitals received in synchrophasor message on Channel A. Only valid when RTCROKA is asserted.
RTCBD01–RTCBD16	First 16 digitals received in synchrophasor message on Channel B. Only valid when RTCROKB is asserted.

Analog Quantities

The synchrophasor measurements in *Table 18.10* are available whenever Global setting EPMU := Y. When EPMU := N, these analog quantities are set to 0.0000.

NOTE: Sampled Values-subscribing relays experience a communication delay in their analog data. Time-stamping of synchrophasor data is adjusted by the **PORT 5** channel delay setting CH_DLY.

It is important to note that the synchrophasors are only valid when the relay is in HIRIG or HPTP timekeeping mode, which can be verified by monitoring the TSOK Relay Word bit. When TSOK = logical 1, the relay timekeeping is synchronized to the high-accuracy IRIG-B signal or PTP time source, and the synchrophasor data are precisely time-stamped.

Table 18.10 Synchrophasor Analog Quantities

Name	Description	Units
Frequency		
FREQPM	Measured system frequency[a]	Hz
DFDTPM	Rate-of-change of frequency, df/dt[a]	Hz/s
Synchrophasor Measurements		
Vk*m*PMM, Vk*m*PMA, Vk*m*PMR, Vk*m*PMI[b, c]	Phase k synchrophasor voltage (M-magnitude, A-Angle, R-Real, I-Imaginary) Terminal *m*	kV Primary, degrees, kV Primary, kV Primary
V1*m*PMM, V1*m*PMA, V1*m*PMR, V1*m*PMI	Positive-sequence synchrophasor voltage (M-magnitude, A-Angle, R-Real, I-Imaginary) Terminal *m*	kV Primary, degrees, kV Primary, kV Primary
Ik*n*PMM, Ik*n*PMA, Ik*n*PMR, Ik*n*PMI[d]	Phase k synchrophasor current (M-magnitude, A-Angle, R-Real, I-Imaginary) Terminal *n*	A Primary, degrees, A Primary, A Primary
I1*n*PMM, I1*n*PMA, I1*n*PMR, I1*n*PMI	Positive-sequence synchrophasor current (M-magnitude, A-Angle, R-Real, I-Imaginary) Terminal *n*	A Primary, degrees, A Primary, A Primary
SODPM	Second of the day of the PM data	s
FOSPM	Fraction of the second of the PM data	s

[a] Measured value if the voltages are valid and EMPU = Y, otherwise FREQPM = nominal frequency setting NFREQ, and DFDT is zero.
[b] k = A, B, or C.
[c] m = voltage terminal.
[d] n = current terminal.

When using the relay for synchrophasor acquisition, the delayed and aligned analog quantities listed in *Table 18.11* are available. Be aware that these quantities are only valid when RTCROK is asserted and only for the enabled channels. The specific channel quantities are also valid whenever their respective RTCROK*c* Relay Word bit is set.

Table 18.11 Synchrophasor Aligned Analog Quantities for Real-Time Control (Sheet 1 of 2)

Name	Description	Units
RTCAP01–RTCAP32	Remote phasor pairs for Channel A. Only those channels provided by the remote are valid to use. Use the **RTC** command to confirm interpretation of these quantities.	
RTCBP01–RTCBP32	Remote phasor pairs for Channel B. Only those channels provided by the remote are valid to use. Use the **RTC** command to confirm interpretation of these quantities.	
RTCAA01–RTCAA08	Remote analogs for Channel A. Only those channels provided by the remote are valid to use. Use the **RTC** command to confirm interpretation of these quantities.	
RTCBA01–RTCBA08	Remote analogs for Channel B. Only those channels provided by the remote are valid to use. Use the **RTC** command to confirm interpretation of these quantities.	
RTCFA	Remote frequency for Channel A.	Hz
RTCFB	Remote frequency for Channel B.	Hz
RTCDFA	Remote frequency rate-of-change for Channel A.	Hz/s
RTCDFB	Remote frequency rate-of-change for Channel B.	Hz/s
Vk*m*PMMD, Vk*m*PMAD, Vk*m*PMRD, Vk*m*PMID[a, b]	Aligned phase k synchrophasor voltage (M-magnitude, A-Angle, R-Real, I-Imaginary) Terminal *m*.	kV Primary, degrees, kV Primary, kV Primary

Table 18.11 Synchrophasor Aligned Analog Quantities for Real-Time Control (Sheet 2 of 2)

Name	Description	Units
V1*m*PMMD, V1*m*PMAD, V1*m*PMRD, V1*m*PMID[b]	Aligned positive-sequence synchrophasor voltage (M-magnitude, A-Angle, R-Real, I-Imaginary) Terminal *m*.	kV Primary, degrees, kV Primary, kV Primary
Ik*n*PMMD, Ik*n*PMAD, Ik*n*PMRD, Ik*n*PMID[a, c]	Aligned phase *k* synchrophasor current (M-magnitude, A-Angle, R-Real, I-Imaginary) Terminal *n*.	A Primary, degrees, A Primary, A Primary
I1*n*PMMD, I1*n*PMAD, I1*n*PMRD, I1*n*PMID[c]	Aligned positive-sequence synchrophasor current (M-magnitude, A-Angle, R-Real, I-Imaginary) Terminal *n*.	A Primary, degrees, A Primary, A Primary
SODPMD	Second-of-day for all aligned data.	Seconds
FOSPMD	Fraction-of-second for all aligned data.	Seconds
FREQPMD	Aligned local system frequency.	Hz
DFDTPMD	Aligned local rate-of-change of frequency.	Hz/s

[a] k = A, B, or C.
[b] m = voltage terminal.
[c] n = current terminal.

View Synchrophasors by Using the MET PM Command

The **MET PM** serial port ASCII command may be used to view the PMU synchrophasor measurements. See *METER on page 14.47* for general information on the **MET** command.

The **MET PM** command can be used as follows:

- As a test tool, to verify connections, phase rotation, and scaling.
- As an analytical tool, to capture synchrophasor data at an exact time, to compare it with similar data captured in other phasor measurement unit(s) at the same time.
- As a method of periodically gathering synchrophasor data through a communications processor.

Figure 18.6 shows a sample **MET PM** command response. The synchrophasor data are also available via the **HMI > Synchrophasor Metering** menu in QuickSet, and has a similar format to *Figure 18.6*.

The **MET PM** command can work even when no serial or Ethernet ports are configured for sending synchrophasor data.

The **MET PM** command will only operate when the relay is in the HIRIG timekeeping mode, as indicated by Relay Word bit TSOK = logical 1.

The **MET PM** command shows if there is a serial port configuration error. If any of the SPCER*p* bits assert, then the command displays `Y`. Otherwise, it displays `N`.

The **MET PM** command checks for assertion of the PMTEST bit to show whether the PMU is in a test mode. If the bit is asserted then the command displays `Y`. Otherwise, it displays `N`.

The **MET PM** time command can be used to direct the PMU to display the synchrophasor for an exact specified time, in 24-hour format. For example, entering the command **MET PM 14:14:12** will result in a response similar to *Figure 18.6* occurring just after 14:14:12, with the time stamp 14:14:12.000000.

If you are not connected to the PMU when the **MET PM** time command issues its timed response, you can use the **MET PM HIS** command to view this response. This permits you to issue MET PM time to multiple PMUs at a certain point in time and then go back later to see the results from all the PMUs at that point in time.

See *MET PM on page 14.49* for complete command options, and error messages.

```
=>>MET PM <Enter>
Relay 1                                    Date: 04/20/2015 Time: 22:02:12.000
Station A                                  Serial Number: 1152490016

Time Quality   Maximum time synchronization error:  0.000 (ms)  TSOK = 1
Serial Port Configuration Error: N                    PMU in TEST MODE = N

Synchrophasors
                    VV Phase Voltages             Pos. Sequence Voltage
                 VA        VB        VC                 V1
MAG (kV)        127.266   126.972   127.148            127.128
ANG (DEG)        73.542   -46.400  -166.103             73.677

                    VZ Phase Voltages             Pos. Sequence Voltage
                 VA        VB        VC                 V1
MAG (kV)         76.383    76.103    76.277             76.254
ANG (DEG)        73.623   -46.319  -166.175             73.707

                    IS Phase Currents          IS Pos. Sequence Current
                 IA        IB        IC                 I1S
MAG (A)         221.707   221.851   221.661            221.740
ANG (DEG)        57.667   -62.223   177.875             57.767

                    T Phase Currents          IT Pos. Sequence Current
                 IA        IB        IC                 I1T
MAG (A)         440.487   441.507   440.698            440.897
ANG (DEG)      -122.055   118.057    -1.933           -121.983

                    I IU Phase Currents          IU Pos. Sequence Current
                 IA        IB        IC                 I1U
 I1U
MAG (A)           0.000     0.000     0.000              0.000
ANG (DEG)         0.000     0.000     0.000              0.000

                    IW Phase Currents          IW Pos. Sequence Current
                 IA        IB        IC                 I1W
MAG (A)           0.000     0.000     0.000              0.000
ANG (DEG)         0.000     0.000     0.000              0.000

                    IX Phase Currents          IX Pos. Sequence Current
                 IA        IB        IC                 I1X
MAG (A)           0.000     0.000     0.000              0.000
ANG (DEG)         0.000     0.000     0.000              0.000

                    IY Phase Currents          IY Pos. Sequence Current
                 IA        IB        IC                 I1Y
MAG (A)           0.000     0.000     0.000              0.000
ANG (DEG)         0.000     0.000     0.000              0.000
```

Figure 18.6 Sample SEL-487E MET PM Command Response

```
FREQ (Hz) 59.990          Frequency Tracking = Y
Rate-of-change of FREQ (Hz/s)    0.00


Digitals
PSV08  PSV07  PSV06  PSV05  PSV04  PSV03  PSV02  PSV01
  0      0      0      0      0      0      0      0
PSV16  PSV15  PSV14  PSV13  PSV12  PSV11  PSV10  PSV09
  0      0      0      0      0      0      0      0
PSV24  PSV23  PSV22  PSV21  PSV20  PSV19  PSV18  PSV17
  0      0      0      0      0      0      0      0
PSV32  PSV31  PSV30  PSV29  PSV28  PSV27  PSV26  PSV25
  0      0      0      0      0      0      0      0
PSV40  PSV39  PSV38  PSV37  PSV36  PSV35  PSV34  PSV33
  0      0      0      0      0      0      0      0
PSV48  PSV47  PSV46  PSV45  PSV44  PSV43  PSV42  PSV41
  0      0      0      0      0      0      0      0
PSV56  PSV55  PSV54  PSV53  PSV52  PSV51  PSV50  PSV49
  0      0      0      0      0      0      0      0
PSV64  PSV63  PSV62  PSV61  PSV60  PSV59  PSV58  PSV57
  0      0      0      0      0      0      0      0


Analogs
PMV49      0.000  PMV50      0.000  PMV51      0.000  PMV52      0.000
PMV53      0.000  PMV54      0.000  PMV55      0.000  PMV56      0.000
PMV57      0.000  PMV58      0.000  PMV59      0.000  PMV60      0.000
PMV61      0.000  PMV62      0.000  PMV63      0.000  PMV64      0.000
=>>
```

Figure 18.6 Sample SEL-487E MET PM Command Response (Continued)

IEEE C37.118 Synchrophasor Protocol

The relay complies with IEEE C37.118, Standard for Synchrophasor Measurements for Power Systems, when Global setting MFRMT := C37.118. The protocol is available on Serial Ports 1, 2, 3, and F by setting the corresponding Port setting PROTO := PMU. The protocol is available over Ethernet when EPMIP is enabled.

This section does not cover the details of the protocol, but highlights some of the important features and options that are available.

Settings Affect Message Contents

The relay allows several options for transmitting synchrophasor data. These are controlled by Global settings described in Settings for Synchrophasors. You can select how often to transmit the synchrophasor messages (MRATE), which synchrophasors to transmit, which numeric representation to use, and which coordinate system to use.

The relay automatically includes the frequency and rate-of-change of frequency in the synchrophasor messages. Global setting FNR*q* selects the numeric format to use for these two quantities.

The relay can include as many as sixteen user-programmable analog values in the synchrophasor message and 0, 16, 32, 48, or 64 digital status values.

The relay always includes the results of four synchrophasor trigger reason SELOGIC equations TREA1, TREA2, TREA3, and TREA4, and the trigger SELOGIC control equation result PMTRIG, in the synchrophasor message.

Communications Bandwidth

A PMU that is configured to transmit a single synchrophasor (positive-sequence voltage, for example) at a message rate of once per second places little burden on the communications channel. As more synchrophasors, analog values, or digital status words are added, or if the message rate is increased, some communications channel restrictions come into play.

If the SPEED setting on any serial port set with PROTO := PMU is insufficient for the PMU Global settings, the relay or QuickSet will display an error message and fail to save settings until the error is corrected.

The IEEE C37.118 synchrophasor message format always includes 16 bytes for the message header and terminal ID, time information, and status bits. The selection of synchrophasor data, numeric format, programmable analog, and programmable digital data will add to the byte requirements. *Table 18.12* can be used to calculate the number of bytes in a synchrophasor message.

Table 18.12 Size of a IEEE C37.118 Synchrophasor Message

Item	Possible number of quantities	Bytes per quantity	Minimum number of bytes	Maximum number of bytes
Fixed			18	18
Synchrophasors[a]	0, 1, 2…32	4 (PHNR := I) 8 (PHNR := F)	0	256
Frequency	2 (fixed)	2 (FNR := I) 4 (FNR := F)	4	8
Analog Values	0 – 16	4	0	64
Digital Status Words	0 – 4	2	0	8
Total (Minimum and Maximum)			22	354

[a] Some SEL relays have a smaller number of possible synchrophasors.

Table 18.13 lists the bps settings available on any relay serial port (setting SPEED), and the maximum message size that can fit within the port bandwidth. Blank entries indicate bandwidths of less than 20 bytes.

Table 18.13 Serial Port Bandwidth for Synchrophasors (in Bytes) (Sheet 1 of 2)

Global Setting MRATE	Maximum Message Size								
	300	600	1200	2400	4800	9600	19200	38400	57600
1	21	42	85	170	340	680	1360	2720	4080
2		21	42	85	170	340	680	1360	2040
4 (60 Hz only)			21	42	85	170	340	680	1020
5				34	68	136	272	544	816
10					34	68	136	272	408
12 (60 Hz only)					28	56	113	226	340
15 (60 Hz only)					21	45	90	181	272
20 (60 Hz only)						34	68	136	204
25 (50 Hz only)						27	54	108	163

Table 18.13 Serial Port Bandwidth for Synchrophasors (in Bytes) (Sheet 2 of 2)

Global Setting MRATE	Maximum Message Size								
30 (60 Hz only)						22	45	90	136
50 (50 Hz only)							27	54	81
60 (60 Hz only)							22	45	68

Referring to *Table 18.12* and *Table 18.13*, it is clear that the lower SPEED settings are very restrictive.

The smallest practical synchrophasor message would be comprised of one synchrophasor and one digital status word, and this message would consume between 26 and 34 bytes, depending on the numeric format settings. This type of message could be sent at any message rate (MRATE) when SPEED := 38400 or 57600, as fast as MRATE := 50 or 30 when SPEED := 19200, and as fast as MRATE := 25 or 20 when SPEED := 9600.

Another example application has messages comprised of eight synchrophasors, one digital status word, and two analog values. This type of message would consume between 62 and 98 bytes, depending on the numeric format settings. The 62-byte version, using integer numeric representation, could be sent at any message rate (MRATE) when SPEED := 57600. The 98-byte version, using floating-point numeric representation, could be sent at as fast as MRATE := 30 when SPEED := 57600, as fast as MRATE := 25 when SPEED := 38400, and as fast as MRATE := 12 when SPEED := 19200.

Protocol Operation

The relay will only transmit synchrophasor messages over serial ports that have setting PROTO := PMU. The connected device will typically be a synchrophasor processor. The synchrophasor processor controls the PMU functions of the relay, with IEEE C37.118 commands, including commands to start and stop synchrophasor data transmission, and commands to request a configuration block from the relay, so the synchrophasor processor can automatically build a database structure.

Transmit Mode Control

The relay will not begin transmitting synchrophasors until an enable message is received from the synchrophasor processor. The relay will stop synchrophasor transmission when the appropriate command is received from the synchrophasor processor. The relay can also indicate when a configuration change occurs, so the synchrophasor processor can request a new configuration block and keep its database up-to-date.

The relay will only respond to configuration block request messages when it is in the nontransmitting mode.

Independent Ports

Each serial port with the PROTO := PMU setting is independently configured and enabled for synchrophasor and Fast Operate commands. For example, if there are two serial ports set to PROTO := PMU, the status of one port has no effect on the other port. One port might be commanded to start transmitting synchrophasor messages, while the other port is idle, responding to a configuration block or Fast Operate request, or transmitting synchrophasors. The ports are not

required to have the same SPEED setting, although the slowest SPEED setting on a PROTO := PMU port will affect the maximum Global MRATE setting that can be used.

Ethernet Operation

IEEE C37.118 Synchrophasors may be used over Ethernet if an Ethernet card is installed in the relay. Four transport methods are supported: UDP_U, UDP_S, UDP_T, and TCP.

UDP_U, UDP_S, UDP_T

UDP stands for User Datagram Protocol and is a network protocol used for the Internet. UDP uses a simple transmission model without implicit handshaking interchanges for guaranteeing reliability, ordering, or data integrity. As such, UDP minimizes additional overhead needed to send messages. Time-sensitive applications often use UDP because dropping packets is preferable to waiting for delayed packets, which may not be an option in a real-time system. UDP_S is a version of UDP that only sends data; no reverse messaging is used, thus providing streaming data in one direction only. UDP_T uses a TCP socket to command and configure PMU measurements, and then uses a UDP socket for sending data out. UDP_U is the same as UDP_T except that the synchrophasor configuration and header response messages are sent over UDP instead of TCP. A user may choose to use UDP to minimize the additional overhead bits added and thus minimize the communications bandwidth needed to send PMU information out of a substation. UDP_S uses the least amount of overhead (and provides some additional security as the PMU or PDC using this method is only sending data and ignores any messages coming in).

TCP

TCP stands for Transmission Control Protocol and is a connection-oriented protocol, which means that it requires handshaking to set up end-to-end communications. Once a connection is set up, user data may be sent bi-directionally over the connection. TCP manages message acknowledgment, retransmission, and timeouts. With TCP, there are no lost data; the server will request the lost portion to be resent. Additionally, TCP ensures that the messages are received in the order sent. TCP provides the most robust connection, but it also adds additional overhead bits to any message data.

PMU Setting Example

A power utility is upgrading the line protection on its 230 kV system to use the SEL-421 relay as main protection. The grid operator also wants the utility to install PMUs in each 230 kV substation to collect data for a new remedial action scheme, and to eventually replace their present state estimation system.

The PMU data collection requirements call for the following data, collected at 10 messages per second:

- Frequency
- Positive-sequence voltage from the bus in each substation
- Three-phase and positive-sequence current for each line terminal
- Indication when the line breaker is open
- Indication when the voltage or frequency information is unusable

- Ambient temperature (one reading per station)
- Station battery voltage
- No relay control from the PMU communications port, for the initial stage of the project

The utility is able to meet the grid operator requirements with the relay, an SEL-2600A RTD Module, an SEL-2407 Satellite-Synchronized Clock, and an SEL-3555 in each substation.

This example will cover the PMU settings in one of the relays.

Some system details:

- The nominal frequency is 60 Hz.
- The line is protected by a breaker-and-a-half scheme.
- The station ambient temperature is collected by an SEL-2600A, Channel RTD01.
- The line PTs and wiring have a phase error of 4.20 degrees (lagging) at 60 Hz.
- The Breaker 1 CTs and wiring have a phase error of 3.50 degrees (lagging) at 60 Hz.
- The Breaker 2 CTs and wiring have a phase error of 5.50 degrees (lagging) at 60 Hz.
- The synchrophasor data will be using **PORT 3**, and the maximum bps allowed is 19200.
- The system designer specified floating-point numeric representation for the synchrophasor data, and rectangular coordinates.
- The system designer specified integer numeric representation for the frequency data.
- The system designer specified fast synchrophasor response, because the data are being used for system monitoring.

The protection settings and resistance temperature detector (RTD) serial port settings will not be shown.

Determining Settings

The protection engineer performs a bandwidth check, using *Table 18.12*, and determines the required message size. The system requirements, in order of appearance in *Table 18.12*, are as follows.

- 5 Synchrophasors, in floating-point representation
- Integer representation for the frequency data
- 2 analog values
- 3 digital status bits, which require one status word

The message size is 16 + 5 • 8 + 2 • 2 + 2 • 4 + 1 • 2 = 70 bytes. Using *Table 18.13*, the engineer verifies that the port bps of 19200 is adequate for the message, at 10 messages per second.

Protection Math Variables PMV64 and PMV63 will be used to transmit the RTD01 ambient temperature data and the station battery voltage DC1, respectively.

The Protection SELOGIC Variables PSV64, PSV63, and PSV62 will be used to transmit the breaker status, loss-of-potential alarm, and frequency measurement status, respectively.

The PORT 3 FASTOP setting will be set to N, to disable any control attempts from the PMU port.

Make the Global settings as shown in *Table 18.14*.

Table 18.14 Example Synchrophasor Global Settings (Sheet 1 of 2)

Setting	Description	Value
NFREQ	Nominal System Frequency (50, 60 Hz)	60
NUMBK	Number of Breakers in Scheme (1, 2)	2
EPMU	Enable Synchronized Phasor Measurement (Y, N)	Y
MFRMT	Message Format (IEEE C37.118, FM)	C37.118
MRATE	Messages per Second (1, 2, 4, 5, 10, 12, 15, 20, 30, 60)	10
PMAPP	PMU Application (F = Fast Response, N = Narrow Bandwidth, 1 = Extra Narrow[a])	F
PMLEGCY	Synchrophasor Legacy Settings	N
NUMPHDC	Number of Phasor Data Configurations	1
PMFRQA	PMU Frequency Application (F = Fast, S = Slow)	S
PHCOMP	Frequency-Based Phasor Compensation (Y, N)	Y
PMSTN	Station Name (16 characters)	SAMPLE1
PMID	PMU Hardware ID (1–65534)	14
PHVI111	Phasor 1 (S, W, X, Y, Z)	Y
PHVT112	Phasor 2 (S, W, X, Y, Z)	W
PHVI113	Phasor 3 (S, W, X, Y, Z)	X
PHDV1	Phasor Data Set, Voltages (I1, PH, ALL)	V1
VYCOMP	Voltage Angle Compensation Factor (–179.99 to 180 degrees)	4.20
PHDI1	Phasor Data Set, Currents (I1, PH, ALL)	ALL
IWCOMP	IW Angle Compensation Factor (–179.99 to 180 degrees)	3.50
IXCOMP	IX Angle Compensation Factor (–179.99 to 180 degrees)	5.50
PHNR1	Phasor Numeric Representation (I = Integer, F = Floating point)	F
PHFMT1	Phasor Format (R = Rectangular coordinates, P = Polar coordinates)	R
FNR1	Frequency Numeric Representation (I = Integer, F = Float)	I
PMAQ11	Any Analog Quantity or alias	RTD01
PMAA11	Alias Name for the analog quantity	AmbientTemp
PMAQ12	Any Analog Quantity or alias	DC1
PMAA12	Alias Name for the analog quantity	StationBattery
PMDG11	Any Relay Word bit or alias	PSV64
PMDA11	Alias Name of Relay Word bit	LineBKStatus
PMDG12	Any Relay Word bit or alias	LOP
TREA1	Trigger Reason Bit 1 (SELOGIC Equation)	NA
TREA2	Trigger Reason Bit 2 (SELOGIC Equation)	NA
TREA3	Trigger Reason Bit 3 (SELOGIC Equation)	NA
TREA4	Trigger Reason Bit 4 (SELOGIC Equation)	NA

Table 18.14 Example Synchrophasor Global Settings (Sheet 2 of 2)

Setting	Description	Value
PMTRIG	Trigger (SELOGIC Equation)	NA
EPMDR	Enable PMU Data Recording	N
PMTEST	PMU Test Mode Equation (SELOGIC Equation)	NA

[a] Option 1 is available only if MRATE = 60.

The line breaker status must be created with protection SELOGIC variables. Make the Protection Freeform logic settings in *Table 18.15* in all six settings groups.

Table 18.15 Example Synchrophasor Protection Freeform Logic Settings

Setting	Value
PSV64	NOT (3PO OR SPO) # Line breaker status

Make the *Table 18.16* settings for serial PORT 3, using the **SET P 3** command.

Table 18.16 Example Synchrophasor Port Settings

Setting	Description	Value
PROTO	Protocol (SEL, DNP, MBA, MBB, MBGA, MBGB, RTD, PMU)	PMU
SPEED	Data Speed (300 to 57600)	19200
STOPBIT	Stop Bits (1, 2 bits)	1
RTSCTS	Enable Hardware Handshaking (Y, N)	N
FASTOP	Enable Fast Operate Messages (Y, N)	N
PMU MODE	PMU Mode (CLIENTA, CLIENTB, SERVER)	SERVER
PMODC	PMU Output Data Configuration	1

SEL Fast Message Synchrophasor Protocol

NOTE: Relays that support IEEE C37.118.1-2011 do not support SEL Fast Message Synchrophasor protocol.

SEL Fast Message Unsolicited Write (synchrophasor) messages are general Fast Messages (A546h) that transport measured synchrophasor information. The relay can send unsolicited write messages as fast as every 50 ms on a 60 Hz system, and 100 ms on a 50 Hz system. When MFRMT = FM, set PMLEGCY = Y to use Global settings PHDATAV, PHDATAI, PHVOLT, and PHCURR to select the voltage and current data to include in the Fast Message. Not all messages are supported at all data speeds. If the selected data rate is not sufficient for the given message length, the relay responds with an error message.

Table 18.17 lists the Synchrophasor Fast Message Write function codes and the actions the relay takes in response to each command.

Table 18.17 Fast Message Command Function Codes for Synchrophasor Fast Write

Function Code (Hex)	Function	Relay Action
00h	Fast Message definition block request	Relay transmits Fast Message definition request acknowledge (Function Code 80)
01h	Enable unsolicited transfer	Relay transmits Fast Message command acknowledged message (Function Code 81). Relay transmits Synchrophasor Measured Quantities (function to enable: Unsolicited Write broadcast, Function Code 20)
02h	Disable unsolicited transfer	Relay sends Fast Message command acknowledge message (Function Code 82) and discontinues transferring unsolicited synchrophasor messages (function to disable: Unsolicited Write broadcast, Function Code 20)
05h	Ping: determine if channel is operable	Relay aborts unsolicited message in progress and transmits ping acknowledge message (Function Code 85)

See the SEL application guide "Using SEL-421 Relay Synchrophasors in Basic Applications" (AG2002-08) for more information on the SEL Fast Message Synchrophasor Protocol.

Fast Message Synchrophasor Settings

The settings for SEL Fast Message synchrophasors are listed in *Table 18.18*. Many of these settings are identical to the settings for the IEEE C37.118 format (see *Settings for Synchrophasors on page 18.6*).

Table 18.18 PMU Settings in the Relay for SEL Fast Message Protocol (in Global Settings)

Setting	Description
EPMU	Enable Synchronized Phasor Measurement (Y, N)
MFRMT	Message Format (C37.118, FM)[a]
PMAPP	PMU Application (F = Fast Response, N = Narrow Bandwidth, 1 = Extra Narrow[b])
PMLEGCY[c]	Synchrophasor Legacy Settings (Y, N)
PHCOMP	Frequency-Based Phasor Compensation (Y, N)
PMID	PMU Hardware ID (0–4294967295)
PHVOLT	Include Voltage Terminal
PHDATAV	Phasor Data Set, Voltages (V1, ALL)
V*k*COMP[d]	V*k* Voltage Angle Compensation Factor (–179.99 to +180 degrees)
PHCURR[e]	Current Source
PHDATAI[f]	Phasor Data Set, Currents (ALL, NA)
I*n*COMP[g]	In Angle Compensation Factor (–179.99 to +180 degrees)

[a] C37.118 = IEEE Std C37.118. FM := SEL Fast Message. Set MFRMT := FM to enter the Fast Message settings.
[b] Option 1 is not available when MFRMT = FM.
[c] PMLEGCY must be set to Y to access the data configuration settings shown in this table.
[d] k = voltage terminal.
[e] Setting hidden when PHDATAI := NA.
[f] When PHDATAV:= V1, this setting is forced to NA and cannot be changed.
[g] n = current terminal.

Certain settings in *Table 18.18* are hidden, depending on the status of other settings. For example, if PHDATAI := NA, the PHCURR setting is hidden to limit the number of settings for your synchrophasor application.

The SEL Fast Message Synchrophasor Protocol always includes the frequency information in floating-point representation, and 14 user-programmable SELOGIC variables PSV49–PSV64. There are no user-programmable analog quantities in the SEL Fast Message Synchrophasor Protocol.

Communications Bandwidth

A PMU that is configured to transmit a single synchrophasor (positive-sequence voltage, for example) at a message period of one second places little burden on the communications channel. As more synchrophasors are added, or if the message rate is increased, some communications channel restrictions come into play.

In the SEL Fast Message Synchrophasor Protocol, the master device determines the message period (the time among successive synchrophasor message timestamps) in the enable request. If the relay can support the requested message period on that serial port, the relay acknowledges the request (if an acknowledge was requested) and commences synchrophasor data transmission. If the relay cannot support the requested message period, the relay responds with a response code indicating bad data (if an acknowledge was requested).

The SPEED setting on any serial port set with PROTO := PMU should be set as high as possible, to allow for the largest number of possible message period requests to be successful.

The relay Fast Message synchrophasor format always includes 32 bytes for the message header and terminal ID, time information, frequency, and status bits. The selection of synchrophasor data will add to the byte requirements. *Table 18.19* can be used to calculate the number of bytes in a synchrophasor message.

Table 18.19 Size of an SEL Fast Message Synchrophasor Message

Item	Possible Number of Quantities	Bytes per Quantity	Minimum Number of Bytes	Median Number of Bytes	Maximum Number of Bytes
Fixed			32	32	32
Synchrophasors	1, 4, or 8	8	8	32	64
Total (Minimum, Median, and Maximum)			40	64	96

Table 18.20 lists the bps settings available on any relay serial port (setting SPEED), and the maximum message size that can fit within the port bandwidth. Blank entries indicate bandwidths of less than 40 bytes.

Table 18.20 Serial Port Bandwidth for Synchrophasors (in Bytes)

Requested Message Period (ms)	Equivalent Message Rate (messages per second)	Port Setting SPEED								
		300	600	1200	2400	4800	9600	19200	38400	57600
1000	1		41	83	166	333	666	1332	2665	3998
500	2			41	83	166	333	666	1332	1999
250 (60 Hz only)	4				41	83	166	333	666	999
200	5					66	133	266	533	799
100	10						66	133	266	399
50 (60 Hz only)	20							66	133	199

Referring to *Table 18.19* and *Table 18.20*, it is clear that the lower SPEED settings are very restrictive.

Some observations from *Table 18.20* follow.

- A serial port set with SPEED := 38400 or 57600 can handle any size message at any data rate.
- A serial port set with SPEED := 19200 can handle a single-synchrophasor or four-synchrophasor message at any data rate, and any size message as fast as 10 messages per second.
- A serial port set with SPEED := 9600 can handle a single-synchrophasor message at any data rate, a four-synchrophasor message at as fast as 10 messages per second, and any size message at as fast as 5 messages per second.
- A serial port set with SPEED := 300 cannot be used for Fast Message synchrophasors.

Protocol Operation

The relay will only transmit synchrophasor messages over serial ports that have setting PROTO := PMU. The connected device will typically be a synchrophasor processor. The synchrophasor processor controls the PMU functions of the relay, with SEL Fast Message commands, including commands to start and stop synchrophasor data transmission, and commands to request a configuration block from the relay, so the synchrophasor processor determine the correct configuration for storing the synchrophasor data.

Transmit Mode Control

The relay will not begin transmitting synchrophasors until an enable message is received from the synchrophasor processor. The relay will stop synchrophasor transmission on a particular serial port when the disable command is received from the synchrophasor processor, or when the relay settings for that port are changed. The relay will stop synchrophasor transmission on all serial ports when any Global or Group settings change is made.

The relay will respond to configuration block request messages regardless of the present transmit status, waiting only as long as it takes for any partially sent messages to be completely transmitted.

The relay will respond to a ping request immediately upon receipt, terminating any partially sent messages.

Independent Ports

Each serial port with the PROTO := PMU setting is independently configured and enabled for synchrophasor and Fast Operate commands. For example, if there are two serial ports set to PROTO := PMU, the status of one port has no effect on the other port. One port might be commanded to start transmitting synchrophasor messages, while the other port is idle, responding to a configuration block or Fast Operate request, or transmitting synchrophasors. The ports are not required to have the same SPEED setting, although the SPEED setting on each PROTO := PMU port will affect the minimum synchrophasor message data period that can be used on that port.

Control Capabilities

Serial Port Fast Operate Operation

The PMU can be configured to process SEL Fast Operate commands received on serial ports that have the Port setting PROTO := PMU, when the Port setting FASTOP := Y, and Global Settings EPMU := Y and PMAPP := F.

This functionality can allow a remote device (client) to initiate control actions in a serially connected PMU without the need for a separate communications interface. The client should enable Fast Operate Transmit on the serial port connected to the PMU. This can be accomplished with Global Setting EPMU := Y, Port Settings PROTO := PMU, FASTOP := Y, and PMUMODE set to either CLIENTA or CLIENTB.

The client can request a Fast Operate Configuration Block when the relay is in the nontransmitting mode, and the relay will respond with a message, which includes codes that define the circuit breaker and remote bit control points that are available via Fast Operate commands.

Once the control points are identified, the Fast Operate Output (FOP) Control Bits can be assigned to SELOGIC equations in the client's SELOGIC freeform protection logic settings. FOP Control Bits take the form FOP*p_n*, where *p* is the serial port (F, 1, 2, or 3) and *n* is the bit number from 01–32. The bit number can correspond to a circuit breaker or remote bit control in the local relay, identified in the Fast Operate Configuration Block.

A change to any FOP*p_n* value will cause the client to transmit a Fast Operate remote bit control message on `PORT p`. If the FOP control bit asserts, the message will contain the opcode to set the corresponding control bit in the PMU. If it deasserts, the message will contain the opcode to clear the control bit. The remote device will send a Fast Operate message no later than 20 ms after it detects a change in the FOP bit.

The PMU will process Fast Operate requests regardless of whether synchrophasors are being transmitted, as long as serial port setting FASTOP := Y and PMUMODE is set to SERVER. When FASTOP := N, the relay will ignore Fast Operate commands. Use the FASTOP := N option to lock out any control actions from that serial port if required by your company operating practices.

SEL Fast Operate commands are discussed in *SEL Fast Meter, Fast Operate, Fast SER Messages, and Fast Message Data Access on page 15.34*.

The PMU can also process the Fast Operate commands embedded in the extended frame of the IEEE C37.118 command frame. This way you can accomplish both synchrophasor measurement and control by using the same IEEE C37.118 protocol on both serial and Ethernet interfaces. This way is also independent of the FASTOP setting.

Ethernet Fast Operate Operation

Fast Operate commands can be issued from a host device to control the function of remote bits and breaker operation in the relay. When coupled with synchrophasor measurements, Fast Operate commands can provide control to system events.

The implementation using the extended frame in the IEEE C37.118 synchrophasor packet makes it possible to send Fast Operate commands and synchrophasor data over the same Ethernet session. The Fast Operate command is embedded in

the extended frame of the IEEE C37.118 command frame. See the following example for configuration and setup of the IEEE C37.118 extended frame implementation.

Example 18.1 Synchrophasor Control Application

Refer to *Table 18.14* for an example of a PMU communications network with an SVP collecting and analyzing synchrophasor data in the network, based on a programmed power flow and voltage regulation scheme. Each of the depicted PMU/IEDs are connected to a load, feeder line, or generation facility streaming synchrophasors to the SVP.

Figure 18.7 Synchrophasor Control Application

Should you need to change the relay protection scheme because of system configuration or to shed bus load to maintain voltage quality, you can program your SVP to send control commands to the relay according to an algorithm. You can set a remote bit in the relay to change the Group settings for an alternative protection scheme or send a **PULSE** command to the circuit breaker to disconnect load from the system.

To set the relay for such a control scenario, first configure synchrophasors for the IEEE C37.118 protocol. *Figure 18.8* depicts one way to configure synchrophasors for transport. In this SEL-487E example, all of the S- and T-terminal phase currents and Z-terminal voltages, along with the positive-sequence values, are transmitted in polar floating-point format at a message rate of 60 messages per second. The filter settings are configured for a fast response with phase compensation.

```
Synchronized Phasor Configuration Settings

MFRMT   := C37.118  MRATE   := 60       PMAPP   := 1        PMLEGCY := N
NUMPHDC := 1


Synchrophasor Data Configuration 1

PMSTN1  := "PMU Control"
PMID1   := 1



Phasors Included in the Data 1

Terminal Name, Relay Word Bit, Alternate Terminal Name

1: Z
2: S
3: T



PHDV1   := ALL      PHDI1   := ALL      PHNR1   := F        PHFMT1  := P
FNR1    := F

Phasor Aliases in Data Configuration 1
 (Phasor Name, Alias Name)

Synchrophasor Analog Quantities in Data Configuration 1
 (Analog Quantity Name, Alias Name)


Synchrophasor Digitals in Data Configuration 1
 (Digital Name, Alias Name)

TREA1   := NA
TREA2   := NA
TREA3   := NA
TREA4   := NA
PMTRIG  := NA
PMTEST  := NA
VZCOMP  := 0.00     ISCOMP  := 0.00     ITCOMP  := 0.00     PMFRQA  := S
PHCOMP  := Y


Synchronized Phasor Recorder Settings

EPMDR   := N

Synchronized Phasor Real Time Control Settings

RTCRATE := 2        MRTCDLY := 500
```

Figure 18.8 PMU Global Settings

Next, configure the Ethernet port to transmit synchrophasor data and accept Fast Operate commands. To enable an Ethernet port to accept Fast Operate commands, simply set FASTOP := Y.

```
SEL Protocol Settings

AUTO    := Y        FASTOP  := Y        TERTIM1 := 1
TERSTRN := "\005"
TERTIM2 := 0
```

Figure 18.9 Enabling Fast Operate Messages on PORT 5

Using the C37.118 extended frame option to transport Fast Operate commands it is necessary to setup only one TCP/UDP session (see *Figure 18.10*).

```
Phasor Measurement Configuration

EPMIP   := Y        PMOTS1  := UDP_T
PMOIPA1 := "192.168.1.3"
PMOTCP1 := 4712     PMOUDP1 := 4713     PMOTS2  := OFF
```

Figure 18.10 Ethernet PORT 5 Settings for Communications Using C37.118 Extended Fame

The relay is now ready to start transmitting synchrophasors and receive Fast Operate commands from the SVP.

Real-Time Control

The PMU can be configured to process IEEE C37.118 synchrophasor data received from two remote PMUs over serial ports. The PMU processes the remote PMU data, time-aligns them with the local data, and makes them available as analogs and digitals. Use the local synchrophasor analogs and as many as two remote sets of synchrophasor analogs in SELOGIC equations to do real-time control (RTC) applications.

Table 18.21 shows the serial port settings that need to be configured for RTC applications.

Table 18.21 Serial Port Settings for RTC

Setting	Description	Default
PMUMODE[a]	PMU Mode (CLIENTA, CLIENTB, SERVER)	SERVER
RTCID[b]	Remote PMU Hardware ID (1–65534)	1
PMODC[c]	PMU Output Data Configuration (1–5)	1

[a] Set PROTO := PMU to enable (on this port) the Synchrophasor Protocol selected by Global setting MFRMT.
[b] Setting hidden when PMUMODE := SERVER.
[c] Only available when PMUMODE := SERVER.

Descriptions for the settings in *Table 18.21* are as follows.

PMUMODE

Selects whether the port is operating as a synchrophasor server (source of data) or a client (consumer of data). When the port is intended to be a source of synchrophasor data, set this setting to SERVER. The Global setting MFRMT determines the format of the transmitted data. When using the port to receive synchrophasor data from another device, set this setting to either CLIENTA or CLIENTB. Only two ports may be configured as client ports and they must be uniquely configured for Channel A or Channel B. When a port is configured to receive synchrophasor data, the port will only receive data that uses the IEEE C37.118 format, regardless of the MFRMT setting.

RTCID

Expected synchrophasor ID from remote relay.

When the PMU is operating as a synchrophasor client (PMUMODE set to CLIENTA or CLIENTB), it will only accept incoming messages that contain this ID. Make sure this ID matches the ID configured in the remote relay.

PMODC

Select the data configuration set to be sent out from that port. This setting is only available when the PMUMODE=SERVER.

Table 18.22 shows the Global settings that need to be configured for RTC applications.

NOTE: The maximum channel delay is available in the **COM RTC** command.

Table 18.22 Global Settings for RTC

Setting	Description	Default
RTCRATE	Remote Messages per Second (1, 2, 5, 10, or 50 when NFREQ := 50) (1, 2, 4, 5, 10, 12, 15, 20, 30, or 60 when NFREQ := 60)	2
MRTCDLY	Maximum RTC Synchrophasor Packet Delay (20–1000 ms)	500

Descriptions for the settings in *Table 18.22* are as follows.

RTCRATE

Rate at which to expect messages from the remote synchrophasor device.

When the PMU is operating as a synchrophasor client (PMUMODE set to CLIENTA or CLIENTB), the relay will only accept incoming messages at this rate. Make sure the remote synchrophasor source(s) is configured to send messages at this same rate.

MRTCDLY

Selects the maximum acceptable delay for received synchrophasor messages.

When the PMU is operating as a synchrophasor client (PMUMODE set to CLIENTA or CLIENTB), the relay only accepts incoming messages that are not older than allowed by this setting. When determining an appropriate value for this setting, consider the channel delay, the transfer time at the selected baud rate, plus add some margin for internal delays in both the remote and local relay.

When you use the PMU for synchrophasor acquisition, the delayed and aligned analog quantities specific to that relay are available. Be aware that these quantities are only valid when RTCROK is asserted and only for the enabled channels. The specific channel quantities are also valid whenever their respective RTCROK*p* Relay Word bit is set (see *Table 18.10*).

When using the relay as a synchrophasor client, the Relay Word bits in *Table 18.23* indicate the state of the synchronization.

Table 18.23 Synchrophasor Client Status Bits

Name	Description
RTCEN*p*[a]	Asserts for one processing interval when a valid message is received on Channel *p*.
RTCROK*p*[a]	Asserts for one processing interval when data are aligned for Channel p. Use this bit to condition usage of the Channel *p* data.
RTCROK	Asserts for one processing interval when data for all enabled channels are aligned. Use this bit to condition general usage of the aligned synchrophasor data.
RTCDLY*p*[a]	This bit is asserted when the last received valid message on Channel *p* is older than MRTCDLY.
RTCSEQ*p*[a]	This bit is asserted when the processed received message on Channel *p* is the expected next-in-sequence. It is deasserted if it is not. The deassertion implies that one or more packets of information were lost. Use this bit to condition usage of Channel *p* data in applications where sequential data are required.
RTCCFG*p*[a]	Indicates Channel *p* is successfully configured.

[a] p = A or B.

When received, synchrophasor messages contain digital data. These data are stored in the Remote Synchrophasor Relay Word bits in *Figure 18.24*.

Table 18.24 Remote Synchrophasor Data Bits

Name	Description
RTC*p*D[16][a]	First 16 digitals received in synchrophasor message on Channel *p*. Only valid when RTCROK*p* is asserted.

[a] p = A or B.

Set MRTCDLY for the maximum expected communications channel delay in milliseconds. Any data arriving later than this time are rejected. The RTCDLY*p* Relay Word bit indicates this condition. Use the MRTCDLY to constrain the maximum longest operating time of the system. Set the RTCRATE to the rate of synchrophasor data being sent by remote relay. This is the MRATE setting on the remote relay.

Several Relay Word bits are useful for monitoring system status. Add RTCCFG*p* and RTCDLY*p* to the SER.

The RTCCFG*p* Relay Word bit is asserted after the two relays have communicated configuration data successfully. RTCCFG*p* deassertion indicates that the system has changed, perhaps because of a setting change in one of the relays.

If the RTCCFG*p* Relay Word bit indicates a new configuration, you can issue the **RTC** command to ensure that the data being received have not changed. The **RTC** command displays a description of the synchrophasor data being received. Use this command to ensure that the remote value that you chose for the SELOGIC equation is the correct value to compare with the local synchrophasor value.

The RTCDLYA bit asserts when synchrophasor data have not been received on Channel A within the window you set with the local MRTCDLY setting (100 ms in this example). If the RTCDLYA asserts, consider three options. First, the MRTCDLY setting can be increased. However, the MRTCDLY setting is your way of guaranteeing operation within a certain time. Increasing MRTCDLY allows for communications channels with longer transmission delay, but at the cost of increasing the maximum time of operation. A second option is to improve the communications channel so that it operates within the required MRTCDLY setting time. A final option is available if the assertion of MRTCDLY results from a temporary communications channel disruption. In this case, putting RTCDLYA in the SER provides warning.

The **COM RTC** command also provides information for monitoring system status. *Figure 18.11* shows a **COM RTC** command response. Use the maximum packet delay field to monitor the communications channel delay. This information can help you choose an appropriate value for the MRTCDLY setting.

```
Summary for RTC channel A
Port:              2
ID:                8
Present Status:    Receiving
Max Packet Delay:  50 msec
Message Rate:      60 msgs/sec

Summary for RTC channel B
Port:              1
ID:                9
Present Status:    Receiving
Max Packet Delay:  40 msec
Message Rate:      60 msgs/sec
```

Figure 18.11 Example COM RTC Command Response

Real-Time Control Example

Figure 18.12 shows an application example using SEL-411L relays. In this example, Area 2 supplies power to Area 1 and Area 3. An important contingency is loss of both Link 1 and Link 2. In such a case, the generators in Area 2 accelerate. Alternative paths between Area 2 and Area 1 can also become stressed beyond their design limits. A simple solution is to measure the phase angle between Area 1 and Area 2. When the angle exceeds a predetermined limit, control the generation to avoid exceeding system limits.

Figure 18.12 Real-Time Control Application

Figure 18.13 shows the SELOGIC for the relay controlling the generator (called the local relay in this example). Lines 1 and 2 store phasor data into PMV53 and PMV54 so they can be viewed through use of the **MET PMV** command. Line 3 computes the angle difference between the local and remote relays. RTCAP02 is the remote V1Y angle. Lines 4–10 unwrap the phase angle when the difference exceeds ±180 degrees.

RTCROKA pulses true whenever a good synchrophasor message is received. For purposes of this example, we need it to hold true until the next message is received. To achieve this, lines 11–13 implement a timer to extend this bit by 1.75 cycles. A message is expected every 1 cycle; the additional 0.75 cycles covers any jitter that may occur in the rate or message receipt. Line 14 calculates a qualification signal consisting of the local and remote quality indicators. RTCROKA is the local indicator that has been extended as PCT01. RTCAD16 is the remote quality indicator. *Figure 18.14* shows its construction at the remote relay.

Line 15 computes absolute value of the angle. Line 16 checks the angle against the reference value. In this case, the reference value is 10 degrees.

The final result, PSV03, asserts when the relay receives a synchrophasor message with an angle difference exceeding 10 degrees.

```
Protection 1
1: PMV53 := V1YPMAD
2: PMV54 := RTCAP02
3: PMV55 := V1YPMAD - RTCAP02
4: PSV01 := PMV55 >= 180.000000
5: PMV01 := -180.000000
6: PSV02 := PMV55 <= PMV01
7: PMV01 := PMV55 + 360.000000

8: PMV02 := PMV55 - 360.000000
9: PMV55 :=NOT PSV01*PMV55+PSV01*PMV02
10: PMV55 :=NOT PSV02*PMV55+PSV02*PMV01
11: PCT01PU := 0.000000
12: PCT01DO := 1.750000
13: PCT01N := R_TRIG RTCROKA
14: PSV01 := PCT01Q AND RTCAD16
15: PMV56 := ABS(PMV55)
16: PSV03 :=(PMV56 > 10.000000) AND PSV01
```

Figure 18.13 Local Relay SELOGIC Settings

Figure 18.14 shows the SELOGIC settings for the remote relay. Set PSV64 to indicate that the sending data are correct. These data are sent with the synchrophasor data in the IEEE C37.118 data packet and are received by the local relay as RTCAD16. The RTCAD16 qualification on line 11 of the local relay (see *Figure 18.13*) contains this remote data quality indicator. A local relay quality indicator also qualifies line 11.

```
1: PSV64 := TSOK AND PMDOK
```

Figure 18.14 Remote Relay SELOGIC Settings

Set the remote relay Global settings according to *Figure 18.15*. Set the number of digitals (NUMDSW) to one. In this case, the relay sends SELOGIC values PSV49–PSV64 in the IEEE C37.118 data packet. This is how the remote TSOK AND PMDOK qualification maps to the local RTCAD16 Relay Word bit. Set the PMU application (PMAPP) to fast, because this is a protection application. Therefore, you must choose a filter for faster response. Also set the synchrophasor enable Global setting to yes (EPMU = Y). The MRTCDLY and RTCRATE settings are set but not used by the remote relay.

```
Synchronized Phasor Measurement Settings

MFRMT   := C37.118  MRATE   := 60       PMAPP   := F        PHCOMP  := Y
PMSTN   := "REMOTE RTC"
PMID    := 8
PHDATAV := V1       VCOMP   := 0.00     PHDATAI := NA       IWCOMP  := 0.00
IXCOMP  := 0.00     PHNR    := F        PHFMT   := P        FNR     := F
NUMANA  := 0        NUMDSW  := 1

TREA1   := NA
TREA2   := NA
TREA3   := NA
TREA4   := NA
PMTRIG  := NA
MRTCDLY := 100
RTCRATE := 60

Time and Date Management

IRIGC   := C37.118
```

Figure 18.15 Remote Relay Global Settings

Set the local relay Global settings according to *Figure 18.16*. It is important for synchrophasors to be enabled (EPMU = Y), the application to be fast (PMAPP = F), the compensation settings to be set correctly (VYCOMP, VZCOMP, IWCOMP, and IXCOMP), and for IRIGC = C37.118.

Set MRTCDLY for the maximum expected communications channel delay in milliseconds. Any data arriving later than this time are rejected. The RTCDLYA Relay Word bit indicates this condition. Use the MRTCDLY to constrain the

maximum longest operating time of the system. Set the RTCRATE to the rate of synchrophasor data being sent by remote relay. This is the MRATE setting on the remote relay.

The other Global settings are not relevant to this application.

```
Synchronized Phasor Measurement Settings

MFRMT   := C37.118  MRATE   := 60       PMAPP   := F        PHCOMP  := Y
PMSTN   := "LOCAL RTC"
PMID    := 4
PHDATAV := V1       VCOMP   := 0.00     PHDATAI := NA       IWCOMP  := 0.00
IXCOMP  := 0.00     PHNR    := F        PHFMT   := P        FNR     := F
NUMANA  := 0        NUMDSW  := 0

TREA1   := NA
TREA2   := NA
TREA3   := NA
TREA4   := NA
PMTRIG  := NA
MRTCDLY := 100
RTCRATE := 60

Time and Date Management

IRIGC   := C37.118
```

Figure 18.16 Local Relay Global Settings

Set the port settings for the port that sends the synchrophasor data on the remote relay, according to *Figure 18.17*.

```
Protocol Selection

PROTO   := PMU

Communications Settings

SPEED   := 57600    STOPBIT := 1        RTSCTS  := N


SEL Protocol Settings

FASTOP  := N

PMUMODE := SERVER
```

Figure 18.17 Remote Relay Port Settings

Set the port settings for the port that receives the synchrophasor data on the local relay, according to *Figure 18.18*. Notice that the RTCID setting must match the PMID setting of the remote relay.

```
Protocol Selection

PROTO   := PMU

Communications Settings

SPEED   := 57600    STOPBIT := 1        RTSCTS  := N


SEL Protocol Settings

FASTOP  := N

PMUMODE := CLIENTA
RTCID   := 8
```

Figure 18.18 Local Relay Port Settings

Several Relay Word bits are useful for monitoring system status. Add RTCCFGA and RTCDLYA to the SER.

The RTCCFGA Relay Word bit is asserted after the two relays have communicated configuration data successfully. RTCCFGA deassertion indicates that the system has changed, perhaps because of a setting change in one of the relays.

If the RTCCFGA Relay Word bit indicates a new configuration, you can issue the **RTC** command to ensure that the data being received have not changed. The **RTC** command displays a description of the synchrophasor data being received. Use this command to ensure that the remote value that you chose for the SELOGIC equation (for example, RTCAP02 in *Figure 18.13*) is the correct value to compare with the local synchrophasor value.

The RTCDLYA bit asserts when synchrophasor data have not been received within the window you set with the local MRTCDLY setting (100 ms in this example). If the RTCDLYA asserts, consider three options. First, the MRTCDLY setting can be increased. However, the MRTCDLY setting is your way of guaranteeing operation within a certain time. Increasing MRTCDLY allows for communications channels with longer transmission delay, but at the cost of increasing the maximum time of operation. A second option is to improve the communications channel so that it operates within the required MRTCDLY setting time. A final option is available if the assertion of RTCDLY results from a temporary communications channel disruption. In this case, putting RTCDLYA in the SER provides warning.

The **COM RTC** command also provides information for monitoring system status. *Figure 18.19* shows a **COM RTC** command response. Use the maximum packet delay field to monitor the communications channel delay. This information can help you choose an appropriate value for the MRTCDLY setting.

```
Summary for RTC channel A
Port:              2
ID:                8
Present Status:    Receiving
Max Packet Delay:  50 msec
Message Rate:      60 msgs/sec

Summary for RTC channel B
Port:              1
ID:                9
Present Status:    Receiving
Max Packet Delay:  40 msec
Message Rate:      60 msgs/sec
```

Figure 18.19 Example COM RTC Command Response

PMU Recording Capabilities

The PMU can be configured to record synchrophasor data by setting EPMDR := Y. Select one of the data configuration q you want to record using SPMDR setting where q = 1–NUMPHDC. Create a recording trigger using PMTRIG SELOGIC setting. On the rising edge of PMTRIG, the PMU starts recording synchrophasor data. The duration and the pretrigger duration of the recording are user-settable.

NOTE: Select PMTRIG trigger conditions to assert PMTRIG only once during a four-hour period if EPMDR = Y (i.e., synchrophasor recording is enabled).

The PMU stores these files in the SYNCHROPHASOR subdirectory with .PMU extension. Use FILE READ or File Transfer Protocol (FTP) to retrieve these stored data files. The file is in binary format and IEEE C37.118 data format compliant.

The file starts with a Configuration 2 frame followed by the data frames as shown below.

<Configuration 2 Frame>

<Data Frame 1>

<Data Frame 2>

.

.

.

<Data Frame *t*>

<Data Frame *t*+1>

.

.

.

<Data Frame *n*>

where:

t = the number of pretrigger data frames, and is equal to PMPRE • MRATE.

n = the total number of data frames, and is equal to PMLER • MRATE.

<Data Frame *t*+1> is the first data frames with Bit 11 in the STAT field (PMTRIG) asserted.

The recorded file has the following file naming convention.

yymmdd,hhmmss,0,aaa,bbb,ccc.PMU

where,

yymmdd, hhmmss = the UTC time stamp of the first data frame in the file with bit 11 (PMTRIG) asserted

aaa = the last three characters of the PMSTN*q* setting (after removing characters " / \ < > * | : ; [ ] $ % { } and the spaces)

bbb = the last three characters of the PMID*q*

ccc = the last three characters of the CONAM setting (after removing the spaces)

Additional PMTRIG assertions are ignored during recording.

Table 18.25 shows the setting name, description, and default value to help configure the data recording.

Table 18.25 PMU Recording Settings

Setting	Description
EPMDR[a]	Enable PMU Data Recording (Y, N)
SPMDR[b]	Select Data Configuration for PMU Recording (1–NUMPHDC)
CONAM[c]	Company Name (1–5 characters)
PMLER[b]	Length of PMU Triggered Data (2–120 s)
PMPRE[b]	Length of PMU Pretriggered Data (1–20 s)

[a] This setting is forced to N if MFRMT = FM.
[b] This setting is hidden if EPMRD = N.
[c] Global Setting.

Descriptions for the settings in *Table 18.25* are as follows.

EPMDR

Use the EPMDR setting to enable synchrophasor data recording. This setting is hidden when EPMU := N. When EPMDR = Y, phasor measurement data recording will begin on the rising edge of PMTRIG. Any subsequent PMTRIG assertions

during the allotted recording period (PMLER) will not result in another PMU data recording being started. The relay will store synchrophasor measurement data as a IEEE C37.118 binary format file that can be retrieved from the relay by using FTP. Synchrophasor data are recorded into a file with extension *.PMU.

SPMDR

The SPMDR setting provides a means for selecting any one of the enabled data configuration 1–NUMPHDC for synchrophasor data recording.

PMLER

PMLER sets the total length of the synchrophasor data recording, in seconds. The PMLER time includes the PMPRE time. For example, if PMLER is set for 30 seconds of PMU recorded data, and PMPRE is set for 10 seconds of pretrigger data, the final recording will contain 10 seconds of pretrigger data and 20 seconds of triggered data for a total report time of 30 seconds.

PMPRE

The PMPRE setting sets the length of the pretrigger data within the synchrophasor data recording. The PMPRE data begins at the PMTRIG point of the recording, and extends back in time (previous time to the trigger event) for the designated amount of time.

SECTION 19

Digital Secondary Systems

Some SEL-400 series relays can receive analog and binary inputs from a digital secondary system (DSS). DSS technology uses merging units to measure currents and voltages and perform substation control operations. This technology provides flexible solutions, reduces the cost of copper, and improves overall safety in the substation.

Refer to *Table 19.1* to select your DSS of interest.

Table 19.1 SEL DSS Technologies

DSS Technology	Supported Relays	SEL Supported Merging Units	Supported Features			Page Link
			Selective Protection Disabling	Multiple Point-to-Point Direct Connections	Custom Topologies	
TiDL (T-Protocol)	SEL-411L-2 SEL-421-7 SEL-451-6 SEL-487B-2 SEL-487E-5	SEL-TMU	Yes	Yes	Yes	*TiDL (T-Protocol) on page 19.1*
TiDL[a] (EtherCAT)	SEL-421-4, -5 SEL-451-5 SEL-487B-1 SEL-487E-3, -4	SEL-2240 Axion Nodes	No	No	No	*TiDL (EtherCAT) on page 19.17*
Sampled Values (IEC 61850-9-2LE)	SEL-411L-2 SEL-421-7 SEL-451-6 SEL-487B-2 SEL-487E-5	SEL-401 SEL-421-7 SEL-451-6 Other IEC 61850-9-2LE-Compliant Publishers	Yes	No	Yes	*IEC 61850-9-2 Sampled Values (SV) on page 19.23*

[a] TiDL (EtherCAT) technology is no longer offered.

Time-Domain Link (TiDL)

TiDL (T-Protocol)

The TiDL (T-Protocol) relays identified in *Table 19.1* receive analog and binary input data from connected SEL-TMUs. A TiDL system communicates over direct fiber-optic connections between relays and SEL-TMUs.

Designing and implementing a TiDL system uses the following the general process.

- Design a TiDL system from one-line diagram
- Configure a TiDL system in SEL Grid Configurator
- Connect and commission the TiDL system
- Operate the TiDL system

For an example configured TiDL substation and a guide for setting up your first TiDL system, see the *SEL-400 Series TiDL QuickStart Guide* available on selinc.com. For detailed information on the SEL-TMU, refer to the *SEL TiDL Merging Unit Instruction Manual*.

Figure 19.1 highlights a high-level SEL TiDL substation.

Figure 19.1 TiDL High-Level Substation Overview

Some of the benefits of a TiDL system include:

- No external time source required for relay and merging unit synchronization
- SEL TiDL relays and SEL-TMUs communicate via a nonroutable protocol that does not offer interactive remote user access. These features minimize security complexity and the associated compliance costs in a DSS.
- Simplified system configuration through SEL Grid Configurator software:
  - Custom topology configuration
  - Commissioning through SEL Grid Configurator
  - Commissioning report providing the present system level overview.

SEL TiDL relays can communicate with as many as eight SEL-TMUs. An SEL-TMU can then communicate with as many as four SEL TiDL relays.

A SEL TiDL system has a fixed channel delay of 1 millisecond. See *Section 1: Specifications* in the product-specific manual to see the link budget specifications of the TiDL (T-Protocol) communications ports.

When configuring a TiDL system in SEL Grid Configurator (see *TiDL Mapping on page 19.4*), create the SEL-TMUs by SEL-TMU type (either 4CT/4PT or 8CT), then map to the appropriate relay TiDL ports according to your TiDL substation requirements. When a commissioning attempt occurs (see *Commissioning TiDL Systems on page 19.14*), the relay checks that the SEL-TMU type physically connected to each relay TiDL port matches your configuration. If all connected SEL-TMUs match the expected SEL-TMU type, the relay successfully commissions that system and creates a correlation lock between each commissioned relay TiDL port and its unique SEL-TMU that was connected during the commissioning process. Once commissioned, each relay TiDL port will only accept incoming data from the unique SEL-TMU it commissioned. This provides additional security to a DSS. Should an SEL-TMU need to be replaced, see *Replacing SEL-TMUs on page 19.17*.

Selective Protection Disabling

See *Section 5: Protection Functions* of the product-specific instruction manual for channel status bits and the role they play in providing selective protection disabling in cases where analog data are lost.

Important Selective Protection Disabling Considerations

When an SEL-TMU is connected to multiple TiDL relays, the following situations can result in a momentary communication loss with the shared relays:

- Modifying the TiDL I/O map.
- Decommissioning a connected relay on an active SEL-TMU port.
- Initiating an SEL-TMU firmware upgrade to a connected relay.

Implement selective protection disabling in the other connected relays to avoid an adverse impact on relay protection functions.

TiDL Binary Input and Output Behavior

When a relay is commissioned, 300-, 400-, and 500-level I/O are mapped from SEL-TMUs.

Binary inputs are user-settable with default settings that make the binary inputs behave as level-sensitive inputs. The default settings for input and dropout thresholds are modified by the nominal voltage of the I/O board local to the relay. See *TiDL Binary Input Settings on page 19.10* for additional information on binary input settings. If the relay loses communications with the SEL-TMU, the relay binary inputs mapped to that SEL-TMU will remain at their last known value until communications are restored.

Because binary outputs on an SEL-TMU can be shared among the connected TiDL relays, each TiDL relay maps the status of the SEL-TMU binary outputs to local output status bits local to each relay (OUT*xxx*S). For example, if a relay has the SEL-TMU binary output OUT01 mapped to OUT301 locally, the OUT301S Relay Word bit indicates the state of OUT01 to the local relay. See *Binary Outputs* of the *SEL-TMU Instruction Manual* for a description of output behavior during a loss of communications with the SEL-TMU.

Binary inputs and outputs do not have to map to the same I/O in each connected relay. For example, OUT01 on the SEL-TMU could map to OUT301 of the SEL TiDL relay connected to SEL-TMU **PORT 1**, OUT307 of the SEL TiDL relay connected to SEL-TMU **PORT 2**, OUT405 of the SEL TiDL relay connected to SEL-TMU **PORT 3**, and OUT503 of the SEL TiDL relay connected to SEL-TMU

PORT 4. In such a case, the output control equation for OUT01 can be considered as $OUT01_{TMU} := OUT301_{Relay\ 1} + OUT307_{Relay\ 2} + OUT405_{Relay\ 3} + OUT503_{Relay\ 4}$.

Decommissioned Relay I/O Statuses

When a TiDL relay is decommissioned, all I/O Relay Word bit statuses revert to their default deasserted state.

TiDL Mapping

When configuring your TiDL I/O mapping, first add devices to your SEL Grid Configurator workspace according to your TiDL substation requirements. *Figure 19.2* shows the process for adding a device to a folder or just to the overall workspace. All TiDL devices added to a SEL Grid Configurator workspace are available for mapping purposes, not just those co-located within the same folder.

Figure 19.2 Adding a Device to the SEL Grid Configurator Workspace

Repeat the steps in *Figure 19.2* to add all remaining devices in your TiDL substation. Next, enable the TiDL I/O Map (Port 6) of the relay you are currently configuring in SEL Grid Configurator, as shown in *Figure 19.3*.

Figure 19.3 Navigating to the TiDL I/O Map Workspace

Next, configure your TiDL relay and SEL-TMU port mapping by following the process shown in *Figure 19.4*.

NOTE: You can use all SEL-TMUs in the SEL Grid Configurator workspace to create a topology mapping.

Figure 19.4 Configure Port Mapping

Proceed to configuring your I/O mapping. You can only use I/O from the SEL-TMUs configured as mapped to your relay from *Figure 19.4* when configuring your relay I/O mapping. *Figure 19.5* shows the process for configuring I/O mapping.

Note: Only SEL-TMU devices that have been mapped to a relay port (see ①) appear in the list of SEL-TMU devices from which you can map I/O.

① See Figure 19.4.

Figure 19.5 Configure I/O Mapping

SEL TiDL Relay Nominal Secondary Current

NOTE: In the SEL-451-6 R401 firmware, the **CFG CTNOM** command defaults all relay settings, which will also decommission the relay's TiDL mapping. SEL Grid Configurator can only configure the nominal secondary current of the SEL-451-6 in firmware versions R402 and newer.

The SEL-400 devices accept 1A or 5A CTs. Configure an SEL TiDL relay via SEL Grid Configurator (see *Figure 19.11*) or the **CFG CTNOM** command to set the nominal secondary current for its mapped CT inputs. The SEL TiDL relays follow the same makeup of nominal CT inputs as their corresponding traditional relay version. This means that for SEL TiDL relays, with the exception of the SEL-487E-5, all CT terminals share the same nominal secondary. The SEL-487E-5 provides options for modifying the nominal secondary on a per-terminal basis.

By default, the relay assumes 5A nominal secondaries.

When the **CFG CTNOM** command is issued by either SEL Grid Configurator or through an ASCII terminal and only if the nominal secondary is changed (i.e., changing from 5A nominal to 1A nominal, or 1A nominal to 5A nominal), Global and Group settings are forced to default, then the relay restarts.

When you are adding a device to the SEL Grid Configurator System Explorer, select the applicable secondary current options for the device. *Figure 19.6(a)* shows options for an SEL-451-6 and *Figure 19.6(b)* shows options for a SEL-487E-5. From the selected secondary current options, SEL Grid Configurator creates a device with defaults and settings ranges based on the nominal secondary currents.

(a) (b)

Figure 19.6 Configure Device Nominal Secondary Current Configuration

To see the configured nominal secondary current of a device in SEL Grid Configurator, see the SEL Grid Configurator settings of SECINC (in relays other than the SEL-487E-5) or CURSTU and CURXYZ (in the SEL-487E-5).

Reading Settings in SEL Grid Configurator

When reading settings from a device in SEL Grid Configurator, you can do one of the following:

- Read settings to a device that already exists in the SEL Grid Configurator workspace
- Add a device to the SEL Grid Configurator workspace by using the retrieved settings

For the first case, if you read settings for a device that already exists in the SEL Grid Configurator workspace, the following can occur:

- The configuration in SEL Grid Configurator matches the relay configuration and settings are automatically loaded.
- A discrepancy exists between SEL Grid Configurator and the relay. In this case, SEL Grid Configurator alerts and asks the user what the nominal secondary current configuration should be.

For the second case, if you add a device to SEL Grid Configurator by using the retrieved settings, SEL Grid Configurator creates a device with a nominal secondary current configuration that matches the relay configuration in your project.

Modifying Previously Configured Nominal Secondary Current

If a device in SEL Grid Configurator requires updating the nominal secondary current, follow the process outlined in *Figure 19.7*.

Figure 19.7 Modifying Nominal Secondary Current Configuration

TiDL Binary Input Settings

The SEL TiDL relay binary inputs that are mapped from SEL-TMUs behave as user-settable inputs. Pickup and dropout levels are also set independently per relay. This means that an SEL-TMU binary input that is shared among multiple relays does not require the same pickup and dropout thresholds configured in each relay; they can be set differently. Although you can set shared inputs independently, SEL typically recommends to set settings for shared inputs consistently among the connected relays.

By default, all binary inputs have settings determined by the additional I/O board in slot Position B of the local relay. All virtual I/O default to the threshold levels similar to the level-sensitive board through the GINP setting. If the mapped binary inputs all share the same pickup, dropout, etc. settings but are different from the default, change the GINP, GINDF, etc. settings and leave EICIS := N. However, if the mapped binary inputs require different settings on a per input basis, follow the process outlined in *Figure 19.4*.

You can send binary input settings to a relay prior to, during, or any time following a TiDL relay commissioning without needing to re-commission your TiDL relay.

Figure 19.8 Binary Input Settings Flow Diagram

SEL Grid Configurator Aliasing

SEL Grid Configurator provides an option of aliasing the SEL-TMU I/O. Through aliasing the SEL-TMU I/O, you can make the mapping configuration more intuitive. *Figure 19.9* shows the steps for aliasing SEL-TMU I/O.

Figure 19.9 Creating Aliases for SEL-TMU I/O

Once the alias is created, it appears in the TMU I/O Selection dialog box. The original I/O name appears in parentheses following the alias name.

Figure 19.10 Aliases Shown in TMU I/O Selection Dialog Box

Commissioning TiDL Systems

NOTE: To decommission a TiDL system use the **R_S** command, send a TiDL channel map without selecting **Commission**, or send an empty TiDL channel map.

Figure 19.11 shows the process for commissioning a TiDL system. Each TiDL system (a TiDL relay and the connected SEL-TMU TiDL ports) is commissioned independently with no impact to other relays and SEL-TMUs already in service (outside of shared SEL-TMU outputs that you can now control through the newly commissioned relay).

① See Figure 19.6; ② See Figure 19.7

Figure 19.11 SEL TiDL Relay Commissioning

Following a commissioning attempt, the result is provided, as shown in *Figure 19.12*. For successful attempts, you can generate a commissioning report that includes a record of the relay and SEL-TMUs commissioned. For failed attempts, SEL Grid Configurator displays error messages that indicate the reason why the commissioning attempt failed. In addition to the provided commissioning report, following any commissioning attempt, a SER entry is recorded to indicate a commissioning attempt and the result (successful, unsuccessful, etc.).

Figure 19.12 TiDL Commissioning Report

TiDL System Troubleshooting

Use the **STA T** command (see *STA T on page 14.62*) to view the current operational status of your TiDL system.

For commissioned SEL-TMUs, the **STA T** command indicates OK for an SEL-TMU device that is communicating and properly commissioned or an error if the corresponding SEL-TMU is not communicating with the relay. Check the fiber connection between the relay and SEL-TMU. Use the **VEC** command (see *VECTOR on page 14.73*) to obtain relevant SEL-TMU diagnostics, then contact SEL technical support.

Ports that are not mapped according to the configured topology are indicated as Not Mapped in the **STA T** command response.

Replacing SEL-TMUs

Anytime a commissioned SEL-TMU is replaced, each TiDL system that uses the SEL-TMU in mapping must be recommissioned by following the process outlined in *Figure 19.11*.

TiDL (EtherCAT)

NOTE: TiDL (EtherCAT) technology is no longer offered. It is recommended to use TiDL (T-Protocol).

The TiDL (EtherCAT) relays identified in *Table 19.1* can receive analog and binary inputs from the SEL-2240 Axion. The Axion provides the analog and binary data over an IEC 61158 EtherCAT, TiDL network. This technology provides very low and deterministic latency over point-to-point architecture. Point-to-point architecture eliminates the need for time synchronization between the Axion nodes and the relay. In addition, it eliminates the complex communications network often associated with DSS and simplifies the programming and installation process.

SEL-400 series relays with TiDL can receive as many as eight fiber links from as many as eight Axion nodes. Not all nodes have to supply analog data—some can supply digital input and output (I/O) only. The firmware will recognize and validate the connected Axion modules and determine if they match a predefined supported topology. The supported topologies are balanced between copper reduction and the number of required Axion nodes. Refer to *Section 2: Installation* in the product-specific instruction manuals to review the supported TiDL topologies.

Figure 19.13 Sample TiDL System Topology

SEL-400 series relays that support TiDL are only available in a 4U chassis. These relays support an I/O board on the relay, and, when applicable, main board I/O. These I/Os will be mapped to the 100- and 200-level inputs and outputs. Axion modules provide additional I/O by using the internal digital Relay Word bits for the 300, 400, and 500 levels of the relays. Note that when the relay part number supports TiDL, all output settings for I/O are available. Correctly set these outputs for what is installed because all output settings will be available but all may not be physically installed in your system.

Relay Word bits IO300OK, IO400OK, and IO500OK indicate the status of installed I/O boards in standard relays or whether an Axion module is commissioned. These bits can also identify whether a board is installed or when an Axion I/O module fails.

Figure 19.14 Rear Panel of Relays With TiDL

TiDL applications use the SEL-2240 Axion, which is a fully integrated analog and digital I/O control solution suitable for DSS. An Axion node consists of a 10-slot, 4-slot, or dual 4-slot chassis that is configurable to contain a power module and combinations of CT/PT, digital input (DI), or digital output (DO) modules.

Figure 19.15 Axion Chassis

Each chassis requires a SEL-2243 Power Coupler (see *Figure 19.16*). This module supplies power to the rest of the node and transmits the data to the relay through fiber-optic communication. See the *SEL-2240 Axion Instruction Manual* for more information.

Figure 19.16 SEL-2243 Power Coupler

The SEL-2244-2 Digital Input Module (see *Figure 19.17*) consists of 24 optoisolated inputs that are not polarity-dependent. These inputs can be configured to respond to ac or dc control signals. The TiDL system maps as many as 72 DI points to the relay. For more information on DI mapping, refer to *Section 2: Installation* in the product-specific instruction manuals.

Figure 19.17 SEL-2244-2 Digital Input Module

The SEL-2244-5 Fast High-Current Digital Output Module (see *Figure 19.18*) consists of ten fast, high-current output contacts. The TiDL system can map as many as 48 DO points to the relay. For more information on DO mapping, refer to *Section 2: PC Software*.

Figure 19.18 SEL-2244-5 Fast High-Current Digital Output Module

The SEL-2245-42 AC Analog Input Module (see *Figure 19.19*) provides protection-class ac analog input (CT/PT) and can accept three voltage and three current inputs. The module samples at 24 kHz and is 1 A or 5 A software-selectable. Depending on the supported fixed topology, multiple CT/PT input modules can function in each node. Some topologies only support one CT/PT module per node. See the supported topologies in *Section 2: Installation* in the product-specific instruction manual for more information.

Figure 19.19 SEL-2245-42 AC Analog Input Module

A simple commissioning process identifies the connected TiDL system and verifies it matches one of the supported relay topologies. Once the commissioning process is complete, the topology is stored in memory. At each additional relay startup, the firmware validates that the connected modules match those of the stored configuration. It recognizes if any CT/PT modules within the node have changed.

Secondary injection testing takes place at each Axion node. Test sources are required to inject voltages and current to the Axion node to verify correct installation and mapping. Monitoring of the voltages and currents will remain in the control house at the relay location.

TiDL (EtherCAT) Settings

NOTE: The relay must be configured using the **CFG CTNOM n** command before the settings are transferred to the relay to avoid erasing the transferred settings. The commands used to set the nominal current in the relay will default all settings after the commands are issued. Changing the SECINC, CURSTU, or CURWXY settings in QuickSet will not change the rest of the settings in QuickSet back to default but will provide an error if any of the current settings are now out of range. In addition, when the relay is connected to QuickSet, the software reads the configuration of the relay and appropriately updates this setting automatically; however, this setting must work offline and develop settings when not connected to the relay.

In TiDL (EtherCAT) relays, there are configurable settings that are specific to those applications in QuickSet. These settings are needed to help configure QuickSet and control attributes such as setting ranges, defaults, and functionality. These settings are not part of the actual relay firmware, and therefore are not sent to the relay at the time the settings transfer. SECINC is one of these configurable settings. SECINC determines the nominal current input for the connected Axion units. In the relay, the user issues an ASCII command, **CFG CTNOM *n***, to set the relay firmware to the correct nominal current being received from the TiDL Axion units. Once the command has been used to set the nominal current value from the Axion units, use QuickSet to set SECINC (see *Figure 19.20*) to that same nominal value to adjust all QuickSet setting ranges to the appropriate scales.

Figure 19.20 SECINC Setting

Some relays, such as the SEL-487E, have multiple setting combinations. The QuickSet settings for the SEL-487E, CURSTU and CURWXY, are shown in *Figure 19.21*. and are used instead of SECINC. For more information on the settings options, review the **CFG CTNOM** command operation in *Section 2: Installation* of the product-specific instruction manual.

Figure 19.21 SEL-487E Nominal Current Selection

If at the time the relay settings are transferred, the QuickSet settings SECINC, CURSTU, or CURWXY do not match the nominal current set in the relay by the **CFG CTNOM** command, the settings transfer is rejected and an error message is displayed.

For relays that do not support DSS, the SECINC setting is grayed out in QuickSet (see *Figure 19.22*). Settings CURSTU and CURWXY are also grayed out in the SEL-487E.

Figure 19.22 SECINC Disabled

IEC 61850-9-2 Sampled Values (SV)

Some SEL-400 series relays are available with the capability to either publish or subscribe to analogs in accordance with the UCA International Users Group's "Implementation Guideline for Digital Interface to Instrument Transformers Using IEC 61850-9-2," The 9-2LE guideline is a subset of IEC 61850-9-2 and specifies, among other things, logical devices, data set contents, sampling rates, the time-synchronization method, and the message format. The 9-2LE guideline clarified ambiguities in the 9-2 standard, improving interoperability between SV devices from different manufacturers.

Architecture

9-2LE uses OSI Layer 2 multicast messages on standard Ethernet network architecture. Merging units sample analog values, convert them to digital signals, and then publish them over the Ethernet network. Two key components of SV messages (besides the current and voltage data) are the destination MAC address and the application ID, or APPID. Relays, meters, DFRs, and other devices on the network can selectively subscribe to the SV streams they need for their application based on these attributes. Because SV streams only carry current and voltage measurements, to accommodate digital input and output data or controls, IEC 61850 GOOSE must also be configured on the network. This network, which carries data essential for the first level of basic substation processes, is known as the process bus. Another network commonly associated with IEC 61850 is known as the station bus, which carries station-level communications such as SCADA.

The process bus allows a single merging unit to share its data with multiple devices and for a single device to receive data from multiple merging units. To align these data, 9-2LE requires time synchronization for all devices. This can also be accomplished over either the process bus or the station bus network via IEEE 1588 or Precision Time Protocol (PTP). Alternatively, SEL SV devices can be synchronized via IRIG-B. Because of the bandwidth requirements and message types that can be present on the process bus, optimal SV performance requires a well-engineered process bus and station bus network.

Figure 19.23 Example SV Network

Refer to *Section 17: IEC 61850 Communication* for information on process bus and station bus designations for the four-port and five-port Ethernet cards.

Benefits of a 9-2LE SV System

Some of the benefits of a 9-2LE SV system include:

- Set the relay as you would conventional SEL-400 series relays through use of QuickSet or SEL Grid Configurator and ACSELERATOR Architect SEL-5032 Software.
- Decrease costs through copper reduction and data sharing.
- Increase safety in the substation by removing high-energy cables from the control house. This also eliminates the concern of an open circuited CT when a relay is removed from service.

SV Publication

SV Publication Capability

Some SEL-400 series relays are available with the capability for SV publication. Enabling SV publication through settings—**PORT 5** setting SVTXEN > 0 or via Configured IED Description (CID) file—enables the merging unit functionality of the device. The SV publication capability of each SEL SV publishing devices is identical, so throughout this section, SEL devices with SV publication enabled are referred to as SV publishers.

The SV publisher digitizes the data from its voltage and current inputs, records its current state of time synchronization, scales these values to primary units by using the CT and PT ratio settings, and then transmits these values in accordance with the 9-2LE guideline. SEL SV publishers support the “MSVCB01” model of the multicast SV control block described in the guideline, which includes a single application service data unit (ASDU). The transmission rate is 80 samples per

nominal frequency cycle. If the nominal frequency setting of the SV publisher NFREQ = 50 Hz or 60 Hz, the SV transmission rate is 4000 or 4800 samples per second, respectively.

The SV publisher can publish as many as seven SV streams simultaneously. SV publication is independent of the protection elements, so protection functionality remains secure even when the SV publisher is publishing the maximum number of SV streams.

Because multiple SV streams may be received by a single subscriber, all streams usually require time-alignment to a time source with an accuracy of <1 µs. SV messages indicate the synchronization state of the SV publisher at the time the sample was taken. This value, smpSynch in the SV message, will be 0, 1, or 2, to indicate whether the merging unit was synchronized with a global time source (2), a local time source (1), or an internal clock (0). If the SV publisher is synchronized with an IEEE 1588 PTP time source that uses the PTP Power Profile (C37.238), the smpSynch value is equal to the ID of the grandmaster clock, usually a value between 5 and 254. The subscriber can also operate in the local time mode with a single time source accuracy of >1 µs.

Though SV messages do not contain an actual time stamp, they do include a value, smpcnt (sample count), that the publisher increments for each message that it transmits, which represents the time at which the sample was taken. For every SV message that the SV publisher transmits, smpcnt increments until it reaches a value of 4799 on a 60 Hz system, or 3999 on a 50 Hz system. At the top of the second, smpcnt resets to 0. Smpcnt can be used to calculate the time stamp of the message in relation to the most recent top of a second by multiplying it by the transmission interval (208.33 µs for a 60 Hz system or 250 µs for a 50 Hz system). For example, a message with smpcnt=699 on a 50 Hz system was taken 699 • 250 µs = 174.75 ms after the top of the second.

SV Publisher Configuration

Architect provides support for the configuration of the SEL SV publisher via a GUI. This interface provides the most flexible configuration of SV publications, including the creation of customized SV data sets. This mechanism is very similar to the configuration of GOOSE publications. For more information, see *IEC 61850 Configuration on page 17.47*.

Figure 19.24 Example Architect SV Publication Configuration

Architect includes ICD files for the SEL-401, SEL-421-7, and SEL-451-6 SV publishers. ICD files of SV publishers contain default SV data sets, which contain combinations of the current and voltage terminals available on the publisher, i.e., W and Y, W and Z, X and Y, or X and Z. You can choose to publish any of these preconfigured data sets or create and publish a custom data set that conforms to the 9-2LE guideline. This feature is useful if you need the SV publisher to send anything other than all phases (A, B, C, and neutral) of a current or voltage terminal in an SV stream.

SV publications may also be configured via **PORT 5** settings through QuickSet or an ASCII terminal window. You can use **PORT 5** settings to quickly configure SV streams that do not require much customization. All phases (A, B, C, and neutral) of a current or voltage terminal must be mapped to an SV stream, and each stream must contain at least one set of voltage or current terminal phase quantities.

SV Publisher Startup

When initially turned on, the SV publisher **ENABLED** LED illuminates as soon as protection functionality is enabled, typically within 10 seconds, but there can be an additional delay of approximately 6 seconds before the initial SV publication is transmitted. Once the SV publisher has begun transmitting SV streams, they can be temporarily disabled for the following conditions:

- **PORT 5** settings are modified
- A new CID file configuration is enabled
- Power is cycled

SV publications stop if the SV publisher is disabled (EN Relay Word bit = False), the **PORT 5** setting EPORT is set to “N”, or the processor fails. SV publications will not resume unless the disabling condition is addressed.

SV Publisher Diagnostics and Testing

Once SV publication is configured and enabled, new commands are available to verify configuration, diagnose and troubleshoot SV communications, and aid in commissioning and testing: **COM SV** and **TEST SV**.

The **COM SV** command displays information about the SV streams that the unit is configured to publish. The data includes the SV destination MAC address, Application ID, message name, data set name, VLAN ID, and priority if the SV publisher is configured via CID file. If the publisher is configured via PORT 5 settings, the data set name remains blank because it is not used in PORT 5 settings, and therefore unavailable. For more information on the **COM SV** command, see *Section 9: ASCII Command Reference* in the product-specific manual.

The **TEST SV** command places the SV publisher into TEST SV mode. In this mode, it replaces the current and voltage data of all SV configured streams with predefined signals for a period of 15 minutes. Also, the SV publisher asserts the test bit in the quality attribute of each current and voltage to identify it as test data. Note that the SV publisher remains in normal mode, and does not enter IEC 61850 Test mode. This does not affect metering or protection functions on the SV publisher. The **COM SV** command indicates whether the SV publisher is in TEST SV mode by displaying the information at the top of the response. Refer to the **TEST SV** command description in *Section 9: ASCII Command Reference* in the product-specific manual for more information.

SV Subscriber

SV Subscriber Functionality

SEL SV subscribers do not have current or voltage input terminals like conventional relays. SV subscribers also do not have internal instrument transformers. Conventional relays are typically ordered from the factory with either 1 A or 5 A nominal CTs, which provide the full range of measured values for the current input terminals. Before or during installation, SEL SV SV subscribers must be configured with the same nominal current value of the merging unit for proper operation. The ASCII command **CFG CTNOM *n***, where *n* is 1 or 5, must be used to configure the SV subscriber with the nominal current value of the subscribed merging unit. Refer to the *Section 9: ASCII Command Reference in the SEL-421-7 Instruction Manual* for more information on the **CFG CTNOM** command.

Five-port Ethernet card ordering option depicted.

i7158c

Figure 19.25 SEL-421-7 SV Subscriber, 4U Rear Panel

SV Subscribers, such as the SEL-421-7 SV Subscriber, must be configured to subscribe to 9-2LE-compliant SV streams to enable any protection functions. When configured via **PORT 5** settings, all phases (A, B, and C) of a current or voltage terminal must come from an SV stream, and terminals cannot be mapped more than once. When configured using Architect, as many as three streams can be summed and mapped to a single terminal. The SEL-411L-2, SEL-421-7, and SEL-451-6 SV Subscribers can receive as many as four streams when configured through **PORT 5** settings, and the SEL-487E-5 and SEL-487B-2 SV Subscribers can receive as many as seven streams when configured through **PORT 5** settings. All SV subscribers can receive as many as seven streams when configured through use of a CID file.

Once SV subscriptions are configured and are being received, the SV subscriber provides a suite of protection functionality. Refer to the specific product instruction manual for a list of available protection functions.

Note that IEC 61850-9-2LE only covers the publication and subscription of analog data. To communicate digital input and output data or controls, IEC 61850 GOOSE must be configured and optimized on either the process bus or the station bus.

SV Subscriber Configuration

Architect provides support for the configuration of the SEL SV subscriber via a GUI. This interface provides the most flexible configuration of SV publications, including the creation of customized SV data sets. This mechanism is very similar to the configuration of GOOSE publications. For more detailed information, see *IEC 61850 Configuration on page 17.47*.

Figure 19.26 Example Architect SV Subscription Configuration

When configuring the SV subscriber, SV subscriptions are accomplished in the same manner as GOOSE subscriptions. Simply drag a published current into an appropriate current slot, or a published voltage into a voltage slot in the SV subscriber **SV Receive** tab. Note that even though a publisher may have a neutral current or voltage value in its publication, the SEL subscriber does not have a neutral current or voltage slot to map it into. Finally, configure the time reference of the subscriber (which selects the device whose smpSynch value all other subscribed messages must match) by selecting the device name from the dropdown list labeled **Time Reference**. See *Subscription Reference Stream on page 17.35*

for more information about the reference stream. Architect also allows as many as three received current streams to be summed and mapped to a single relay current terminal.

SV subscriptions may also be configured via PORT 5 settings through QuickSet or an ASCII terminal window. PORT 5 settings can be used to quickly configure SV subscriptions that do not require much customization. All phases (A, B, C) of a current or voltage terminal must be mapped to an SV subscription. Please note that regardless of the configuration method, you cannot map a current or voltage phase value into more than one subscriber slot.

SV Subscriber Startup

When initially turned on, the SV subscriber ENABLED LED illuminates as soon as protection functionality is enabled, which can take as long as 17 seconds but will typically be within 10 seconds. Once the SV subscriber has begun accepting SV streams, SV processing can be temporarily disabled for the following conditions:

- PORT 5 settings are modified
- A new CID file configuration is enabled
- Power is cycled

SV subscriptions are disabled if the SV subscriber is disabled (EN Relay Word bit = False), the PORT 5 setting EPORT is set to "N", or the processor fails. SV subscriptions do not resume unless the disabling condition is addressed. When SV subscriptions are disabled, so is the primary means of data acquisition for the relay. Take care to recognize when such a condition occurs, generate appropriate warnings or alarms, and resolve any issues.

SV Subscriber Diagnostics and Testing

Once SV subscriptions are configured and enabled, new commands are available to verify configuration, diagnose and troubleshoot SV communications, and aid in commissioning and testing: **COM SV** and **TEST SV**.

The **COM SV** command displays information about the SV streams to which the unit has been configured to subscribe. The data includes the SV destination MAC address, Application ID, message name, data set name, VLAN ID, and priority if the information is available. If information is not available, the field remains blank. The **COM SV** command also provides statistics for individual subscribed SV streams and any error conditions that are currently present or were present during the previous 30 seconds. For more information on the **COM SV** command, see *Section 9: ASCII Command Reference* in the product-specific manual.

See *Table 14.45* for detailed explanations of the information provided in the **COM SV** command.

If any subscribed SV streams are lost, the SV subscriber can still be able to provide some subset of metering and protection functionality, depending on what data are in the missing stream(s). For example, consider an SV subscriber that has two active subscriptions with the first one providing one set of terminal currents and voltages, and the other providing another set of currents. If the second subscription is lost, the SV subscriber can still provide metering data and some degree of overcurrent and LOP protection with the data available from the first stream. Refer to the product-specific instruction manual for available protection features.

NOTE: TEST SV is an SEL proprietary mode. For the IEC 61850-compliant modes, see IEC 61850 Simulation Mode on page 17.38 and IEC 61850 Mode/Behavior on page 17.38.

The **TEST SV** command places the SV subscriber into SEL's TEST SV mode. In this mode, it accepts any subscribed messages with or without the test bit of the quality attribute set. The data that the SV subscriber receives while in TEST SV mode are processed as valid data, so take care to ensure that outputs are blocked to prevent any undesired operations. The **MET** command reflects the received data as actual data, even with the test bit asserted. The **COM SV** command indicates whether the SV subscriber is in TEST SV mode by displaying the information at the top of the response. Refer to the TEST SV command description in *Section 9: ASCII Command Reference* of the product-specific manual for more information.

The health of the incoming SV subscription data channels can be monitored with the SV subscription Relay Word bits SVSALM, SVS*mm*OK, and SVCC, and the SVND*mm* (where *mm* is the SV stream number 01–07) analog quantities. The SVS*mm*OK Relay Word bits are asserted when subscription *mm* is configured and data conforming with the 9-2LE guideline is being actively received from it. The SVCC (SV coupled clocks mode) Relay Word bit is asserted when the SV subscriber is synchronized with the same smpSynch value as the subscription reference stream. The SVND*mm* analog quantities indicate the measured channel delay of each subscription and are compared with the PORT 5 CH_DLY setting to generate an alarm condition as described in the following.

The SVSALM Relay Word bit is a general purpose alarm that will assert for the following conditions:

- The SV subscriber has lost sync with the device providing its reference stream
- One or more subscribed SV streams network delays exceed the CH_DLY setting
- One or more subscribed SV streams are no longer being received (lost)
- One or more subscribed SV streams have a subscription status SVS*mm*OK bit that is not set.

The SV subscriber also provides analog channel status Relay Word bits, which are useful for supervising protection based on the state of SV communications for each current and voltage channel. These bits include *nnn*OK and *nnn*BK bits, where *nnn* is the product-specific current or voltage channel that can potentially be mapped to data from an incoming SV stream, for example, IAW, IBW, ICW, VAY, VBY, VCY, etc. in the SEL-421-7 SV Subscriber. The *nnn*OK bits asserts for all data channels that are mapped to a subscribed SV stream and have data actively being received from it. The *nnn*BK bits are the inverse of the *nnn*OK bits.

See *Section 5: Protection Functions* of the product-specific manual for more information on SV status logic.

APPENDIX A

Manual Versions

The date code at the bottom of each page of this manual reflects the creation or revision date.

Table A.1 lists the firmware versions, revision descriptions, and corresponding instruction manual date codes.

Table A.1 Instruction Manual Revision History (Sheet 1 of 11)

Date Code	Summary of Revisions
20250214	**General** ➤ Removed references to the product literature DVD and firmware CD. **Section 2** ➤ Updated *Table 2.1: SEL Software*. **Section 9** ➤ Added note to *ERAQc (Analog Quantities)*. **Section 12** ➤ Added note to *Active Setting Group Changes.* ➤ Updated *Table 12.27: Protocol Selection (Five-Port Ethernet Card)*. **Section 13** ➤ Updated *Table 13.2: First Execution Bit Operation on Startup* and *Table 13.25: SEL-400 Series SELOGIC Control Equation Programming Summary*. **Section 17** ➤ Updated *Introduction to IEC 61850* and *IEC 61850 Operation*. ➤ Added *LPHD*. ➤ Updated *Table 17.28: Logical Device: CFG (Configuration), Table 17.29 Logical Device: CON (Remote Control),* and *Table 17.30: Logical Device: ANN (Annunciation)*. ➤ Added *Potential Client and Automation Application Issues With Edition 2 and 2.1 Upgrades* and *Backward Compatibility With Edition 1 Devices*. **Appendix B** ➤ Updated *Important Considerations*.
20241211	**Section 15** ➤ Updated *Figure 15.2: Example 4U Rear-Panel Layout in Relay With Bay Cards*.
20241022	**Section 1** ➤ Updated *Common Features.* **Section 7** ➤ Updated *Energy Metering.* **Section 10** ➤ Added note to *TEST SV Command* and *Example 10.4: Checking Data Acquisition With the TEST SV Command.* ➤ Updated *Figure 10.8: MET Command Response.* **Section 12** ➤ Updated *Table 12.14: IP/Network Configuration* and *Table 12.28: IP/Network Configuration, Table 12.51: Event Reporting.* **Section 13** ➤ Updated *Table 13.10: Conditioning Timer Parameters.*

Table A.1 Instruction Manual Revision History (Sheet 2 of 11)

Date Code	Summary of Revisions
	Section 14 ➤ Added *COM HSR*. ➤ Updated *COM PRP*. ➤ Added note to *TEST SV*. ➤ Updated *Table 14.148: SV Output Values During TEST SV Mode*. **Section 15** ➤ Updated *Table 15.1: Relay Communications Protocols* and *Table 15.4: Ethernet Protocol Options*. ➤ Updated *Network Connection by Using PRP Operating Mode* and *Redundant Ethernet Ports (Five-Port Ethernet Card)*. **Section 17** ➤ Updated *Coupled Clocks Mode*. ➤ Added *Freewheeling Mode*. ➤ Updated *Subscription Reference Stream*. ➤ Added note to *SV Data Set*. ➤ Updated *Table 17.27: Logical Device: CON (Remote Control)* and *Table 17.28: Logical Device: ANN (Annunciation)*. **Section 19** ➤ Updated *TiDL Binary Input and Output Behavior*.
20240710	**Section 2** ➤ Updated *Table 2.1: SEL Software*. **Appendix B** ➤ Updated *Table B.1: SEL-400 Series Relays Supporting Ethernet Firmware Upgrades*.
20240509	**Section 9** ➤ Updated *Figure 9.1: Input Processing* and *Figure 9.2: Input Processing of SEL-400 Series Relays Supporting DSS Technology*. **Section 10** ➤ Updated *Table 10.7: Secondary Quantities for the SEL-401, SEL-421-7, and SEL-451-6 SV Publishers*. **Section 11** ➤ Updated *Time Source Selection*. ➤ Updated *Figure 11.3: TLOCAL and TGLOBAL Logic*. **Section 17** ➤ Updated *SEL SV Publisher* and *IEC 61850 Configuration*. ➤ Updated *Table 17.28: Logical Device: ANN (Annunciation)*. **Section 19** ➤ Updated *Table 19.1: SEL DSS Technologies*. ➤ Updated *Architecture* and *SV Publisher Configuration*.
20240229	**Section 9** ➤ Updated *Figure 9.1: Input Processing*. **Section 11** ➤ Updated *Time Source Selection*. ➤ Updated *Figure 11.3: TLOCAL and TGLOBAL Logic*.
20231219	**Section 13** ➤ Updated *Conditioning Timers* and *Sequencing Timers*.
20231207	**Section 8** ➤ Updated *Circuit Breaker Inactivity Time Elapsed*. **Section 11** ➤ Updated *PTP Over PRP Networks*.

Table A.1 Instruction Manual Revision History (Sheet 3 of 11)

Date Code	Summary of Revisions
	Section 12 ➤ Updated *Table 12.49: SER Chatter Criteria* and *Table 12.51: Event Reporting*. **Section 14** ➤ Updated *Table 14.37: COM PTP Command* and *Table 14.129: STA T SEL-TMU Error Messages and User Action*. **Section 17** ➤ Updated *Reports*. ➤ Updated *Table 17.30: PICS for A-Profile Support* and *Table 17.31: PICS for T-Profile Support*. ➤ Updated *MMS Conformance*. ➤ Updated *Table 17.43: Basic Conformance Statement, Table 17.44: ACSI Models Conformance Statement,* and *Table 17.45: ACSI Service Conformance Statement*. **Section 18** ➤ Updated *Introduction*. **Section 19** ➤ Updated *Table 19.1: SEL DSS Technologies*. ➤ Updated *SV Subscriber Functionality*. **Appendix B** ➤ Updated *A Set PORT 5 Settings MAXACC, EETHFWU, and EPAC* under *Method 4: Using FTP*. ➤ Updated *Time-Domain Link (TiDL) Centrally Controlled Firmware Upgrade (For Relays Supporting T-Protocol)*. **Appendix C** ➤ Added note under *Physical Ports*. ➤ Updated *Table C.1: IP Port Numbers*.
20230830	**Section 3** ➤ Updated *Figure 3.8: Relay Status, Figure 3.9: Relay Status, Figure 3.28: Terminal Screen MET Metering Quantities*, and *Figure 3.36: Sample HIS Command Output in the Terminal*. **Section 10** ➤ Updated *Figure 10.6: Enter TEST SV Mode in the Relay, Figure 10.8: MET Command Response*, and *Figure 10.10: Relay Status From a STATUS A Command on a Terminal*. **Section 11** ➤ Updated *Figure 11.4: Sample TIM Q Command Response*. **Section 14** ➤ Updated *Figure 14.1: Sample COM PRP Command Response, Figure 14.2: Sample COM PTP Command Response, Figure 14.8: Sample ETH Command Response for the Two-Port Ethernet Card, Figure 14.9: Sample ETH Command Response for the Five-Port Ethernet Card, Figure 14.17: Sample TIME Q Command Response With IRIG*, and *Figure 14.18: Sample Time Q Command Response With PTP*. **Section 15** ➤ Updated *Figure 15.11: MET T Command Response* and *Figure 15.17: Example Telnet Session*.
20230317	**Section 1** ➤ Updated *Parallel Redundancy Protocol (PRP)* in *Common Features*. **Section 3** ➤ Updated *Making an Ethernet Telnet Connection*, *Making an Ethernet Web Server (HTTP) Connection*, *Communications Ports Access Levels*, and *Viewing SER Records*. ➤ Updated *Figure 3.8: Relay Status, Figure 3.9: Relay Status, Figure 3.11: Checking Relay Status From the Front-Panel LCD, Figure 3.28: Terminal Screen MET Metering Quantities,* and *Figure 3.36: Sample HIS Command Output in the Terminal*. **Section 4** ➤ Updated *Figure 4.39: Sample Status Warning and Trip EVENT SUMMARY Screens*. **Section 6** ➤ Added note to *Autoreclose Logic Diagrams*.

Table A.1 Instruction Manual Revision History (Sheet 4 of 11)

Date Code	Summary of Revisions
	Section 8 ➤ Added note to *Breaker History*. ➤ Updated *Figure 8.10: Breaker History Report*. **Section 9** ➤ Updated *Settings Section of the Event Report*. **Section 10** ➤ Updated *Figure 10.6: Enter TEST SV Mode in the Relay* and *Figure 10.8: MET Command Response*. ➤ Updated *Status*. ➤ Updated *Figure 10.11: Example Compressed ASCII Status Message*. ➤ Updated *Table 10.10: Troubleshooting for Relay Self-Test Warnings and Failures*. **Section 11** ➤ Updated *PTP Timekeeping* and *Time Quality Indications*. **Section 14** ➤ Added *COM PRP*. ➤ Updated *Figure 14.1: Sample COM PRP Command Response, Figure 14.2: Sample COM PTP Command Response,* and *Figure 14.8: Sample ETH Command Response for the Two-Port Ethernet Card*. ➤ Added *Figure 14.9: Sample ETH Command Response for the Five-Port Ethernet Card*. ➤ Updated *Figure 14.13: Sample ID Command Response From Ethernet Card, Figure 14.17: Sample TIME Q Command Response With IRIG, Figure 14.18: Sample Time Q Command Response With PTP*, and *Figure 14.19: Sample VER Command Response*. **Section 15** ➤ Updated *Figure 15.9: Example PRP Network Using SEL-400 Series Relays With Five-Port Ethernet Cards, Figure 15.11: MET T Command Response*, and *Figure 15.17: Example Telnet Session*. **Section 17** ➤ Updated *Figure 17.6 GOOSE Quality Attributes*. ➤ Updated *Station Bus and Process Bus (Four-Port Ethernet Card)*. ➤ Added *Station Bus and Process Bus (Five-Port Ethernet Card)*. ➤ Updated *IEC 61850 Messaging (Four-Port Ethernet Card)*. ➤ Added *IEC 61850 Messaging (Five-Port Ethernet Card)*. ➤ Updated *IEC 61850 Configuration*. ➤ Updated *Table 17.26: Logical Device: CFG (Configuration)* and *Table 17.28: Logical Device: ANN (Annunciation).* **Section 19** ➤ Updated *IEC 61850-9-2 Sampled Values (SV)*. **Appendix B** ➤ Added *Important Considerations for the Five-Port Ethernet Card* and *Resolving Communications Card Firmware Mismatch*.
20230112	**Section 2** ➤ Updated *Table 2.1: SEL Software.* **Section 17** ➤ Updated *Table 17.27: Logical Device: CFG (Configuration), Table 17.28: Logical Device: CON (Remote Control), Table 17.29: Logical Device: ANN (Annunciation), Table 17.45: ACSI Models Conformance Statement,* and *Table 17.46: ACSI Service Conformance Statement*. **Appendix B** ➤ Updated *Important Considerations, Ethernet Firmware Upgrades, Relay Firmware Upgrade Procedure,* and *Verify IEC 61850 Operation (Optional)*. ➤ Added *Return Relay to Service*. ➤ Removed *TiDL Firmware Upgrade (For TiDL [EtherCAT] Relays Only*).
20220928	**Section 7** ➤ Updated *Table 7.2: Instantaneous Metering Accuracy—Voltages, Currents, and Frequency*.

Table A.1 Instruction Manual Revision History (Sheet 5 of 11)

Date Code	Summary of Revisions
	Section 14 ➤ Added note for the **PULSE** command. **Section 18** ➤ Updated to IEC/IEEE 60255-118-1:2018 (IEEE Std C37.118 2011, 2014a).
20220523	**Section 7** ➤ Updated *Table 7.2: Instantaneous Metering Accuracy—Voltages, Currents, and Frequency*. **Section 9** ➤ Updated *Data Processing*. **Section 10** ➤ Updated *Example 10.4: Checking Data Acquisition With the TEST SV Command.* ➤ Updated *Relay Self-Tests*. ➤ Updated *Table 10.9: Troubleshooting Procedures*. **Section 11** ➤ Updated *IRIG-B Timekeeping*, *PTP Timekeeping,* and *Time Quality Indications*. **Section 12** ➤ Updated *Table 12.10: FTP Configuration*, *Table 12.12: Telnet Configuration*, and *Table 12.25: PTP Settings*. **Section 13** ➤ Updated *Table 13.9: Conditioning Timer Quantities* and *Table 13.25: SEL-400 Series SELOGIC Control Equation Programming Summary*. **Section 14** ➤ Updated *Table 14.40: Accessible Information for Each SV Publication*. **Section 15** ➤ Updated *Table 15.4: Ethernet Card Network Configuration Settings* and *Table 15.7: FTP Settings*. ➤ Updated *Precision Time Protocol (PTP), Channel Monitoring,* and *Settings*. **Section 17** ➤ Updated *Local/Remote Control Authority*, *Reports*, *SV Network Delays,* and *Change Mode Via MMS or SELOGIC*. ➤ Updated *Table 17.27: Logical Device: CFG (Configuration)*. **Section 19** ➤ Updated *Table 19.1: SEL DSS Technologies*. ➤ Updated *Time-Domain Link (TiDL)* and *IEC 61850-9-2 Sampled Values (SV)*. **Appendix B** ➤ Updated *Upgrade* and *Resolving Model Mismatch*. **Appendix C** ➤ Updated *Physical Ports* and *T-Protocol Ports*. **Glossary** ➤ Updated definitions for *Axion, Digital Secondary System (DSS), SEL-TMU, Selective Protection Disabling,* and *Time-Domain Link (TiDL)*.
20210817	**Section 17** ➤ Added *Control Interlocking* under *IEC 61850 Operation*.
20210701	**Section 2** ➤ Updated *Table 2.1: SEL Software*. ➤ Updated *SEL Grid Configurator Software*. **Section 5** ➤ Updated *Bay Control Screens*. **Section 9** ➤ Updated *Triggering Data Captures and Event Reports*.

Table A.1 Instruction Manual Revision History (Sheet 6 of 11)

Date Code	Summary of Revisions
	Section 11 ➤ Updated *Time Triggering the Relay*. Section 16 ➤ Updated *Figure 16.9 Add Binary Inputs to SER Point List*. Section 19 ➤ Updated *Table 19.1: SEL DSS Technologies*. ➤ Updated *Time-Domain Link (TiDL)*. Appendix B ➤ Updated *Table B.1: SEL-400 Series Relays Supporting Ethernet Firmware Upgrades*.
20210514	Section 2 ➤ Updated *Table 2.1: SEL Software.* Section 3 ➤ Added *Communications Ports Access Control*. Section 12 ➤ Updated *Table 12.5: Protocol Selection.* Section 15 ➤ Updated *Figure 15.14: Example Telnet Session*. Section 16 ➤ Updated *Table 16.12: SEL-421 Port 3 Example Settings*. Section 17 ➤ Updated *Table 17.27: Logical Device: CON (Remote Control)*. Section 19 ➤ Updated *Table 19.1: SEL DSS Technologies*. Appendix B ➤ Updated *Table B.1: SEL-400 Series Relays Supporting Ethernet Firmware Upgrades.* ➤ Updated *Set Port 5 Settings MAXACC, EETHFWU, and EPAC* and *Set Port 5 Settings MAXACC, EETHFWU, and EPAC*. Appendix C ➤ Updated *Local Accounts*.
20210326	Section 6 ➤ Updated *Figure 6.11: One Circuit Breaker Single-Pole Cycle State (79CY1), Figure 6.12: One Circuit Breaker Three-Pole Cycle State (79CY3), Figure 6.13: Two Circuit Breakers Single-Pole Cycle State (79CY1) When E79 := Y, Figure 6.14: Two Circuit Breakers Single-Pole Cycle State (79CY1) When E79 := Y1, Figure 6.15: Two Circuit Breakers Three-Pole Cycle State (79CY3) When E79 := Y,* and *Figure 6.16: Two Circuit Breakers Three-Pole Cycle State (79CY3) When E79 := Y1*. Section 19 ➤ Updated *Table 19.1: SEL DSS Technologies*. Appendix B ➤ Updated *Table B.1: SEL-400 Series Relays Supporting Ethernet Firmware Upgrades*.
20210209	Section 2 ➤ Updated *Table 2.1: SEL Software.* Section 14 ➤ Updated *CFG CTNOM*. Section 19 ➤ Updated *Time-Domain Link (TiDL)*. ➤ Updated *Table 19.1: SEL DSS Technologies*. Appendix B ➤ Updated *Table B.1: SEL-400 Series Relays Supporting Ethernet Firmware Upgrades* and *Table B.3: Firmware Upgrade Scenarios and Available Methods*.

Table A.1 Instruction Manual Revision History (Sheet 7 of 11)

Date Code	Summary of Revisions
20201204	**Preface** ➤ Updated *Manual Overview*. ➤ Updated *Safety Marks*. **Section 2** ➤ Added *Table 2.1: SEL Software*. **Section 3** ➤ Updated *Figure 3.37: Sample Event Oscillogram*. **Section 5** ➤ Updated *Remote Bits*. ➤ Updated *Analog Display*. **Section 6** ➤ Updated *Figure 6.19 Voltage Check Element Logic (EISYNC := N)* and *Figure 6.20 Voltage Check Element Logic (EISYNC := Y)*. **Section 10** ➤ Updated *Table 10.9: Troubleshooting Procedures*. **Section 11** ➤ Added note to *CFG CTNOM*. ➤ Updated *CFG NFREQ* and *STA T*. ➤ Added note to *TEST FM*. **Section 12** ➤ Added *TiDL (Port 6)*. **Section 14** ➤ Added *STA T* and added information to *VEC*. **Section 15** ➤ Added note to *SEL Fast Meter, Fast Operate, Fast SER Messages, and Fast Message Data Access*. **Section 17** ➤ Added *IEC 61850 Simulation Mode*. ➤ Updated *GOOSE Performance*. ➤ Updated *Table 17.27 Logical Device: ANN (Annunciation)*. **Section 18** ➤ Updated section to include the impact of DSS channel delay. **Section 19** ➤ Added *Table 19.1: SEL DSS Technologies*. ➤ Added *TiDL (T-Protocol)*. **Appendix B** ➤ Added *TiDL Centrally Controlled Firmware Upgrade*. ➤ Updated *Table B.3 Firmware Upgrade Scenarios and Available Methods*. ➤ Updated *Time-Domain Link (TiDL) Centrally Controlled Firmware Upgrade (For Relays Supporting T-Protocol)* and *TiDL Firmware Upgrade (For TiDL [EtherCAT] Relays Only)*. **Appendix C** ➤ Added *T-Protocol Ports*. ➤ Updated to include references for in-service relay firmware verification. **Glossary** ➤ Updated for DSS and TiDL.
20201009	**Section 17** ➤ Added *Relay Output Contact Behavior Following a Power Cycle*.
20200520	**Section 13** ➤ Updated text to include Automation SELOGIC conditioning timers.

Table A.1 Instruction Manual Revision History (Sheet 8 of 11)

Date Code	Summary of Revisions
20200424	**Section 18** ➤ Updated *Control Capabilities*.
20200401	**Section 2** ➤ Added *SEL Grid Configurator Software*. **Section 4** ➤ Updated *Figure 4.15: Enter Password Screen*. **Section 5** ➤ Updated for SEL-400G. **Section 9** ➤ Updated for SEL-400G. ➤ Removed *Table 9.1: Report Settings*. **Section 14** ➤ Updated for SEL-400G. **Section 18** ➤ Updated for SEL-400G.
20200229	**Section 4** ➤ Updated *Figure 4.15: Enter Password Screen*. ➤ Added *Figure 4.16: Invalid Password Screen*. **Section 5** ➤ Updated *Figure 5.1: Disconnect Switch Close Logic* and *Figure 5.2: Disconnect Switch OPEN Logic*. **Section 6** ➤ Updated text and figures to include new EISYNC setting. **Section 10** ➤ Updated *Table 10.9: Troubleshooting Procedures*. **Section 11** ➤ Updated text in *PTP Over PRP Networks*. **Section 12** ➤ Updated notes for *Table 12.25: PTP Settings*. **Section 14** ➤ Updated *Figure 14.7: Sample ETH Command Response*. ➤ Updated *Table 14.43: Warning and Error Codes for SV Subscriptions* and *Table 14.77: Accessible GOOSE IED Information*. ➤ Added *Table 14.78: Warning and Error Codes for GOOSE Subscriptions*. **Section 15** ➤ Added text regarding wildcard usage ➤ Added *Table 15.19: FTP and MMS Wildcard Usage Examples* and *Table 15.20: Ymodem Wildcard Usage Examples*. **Section 16** ➤ Updated *Figure 16.4: Sample Response to SHO D Command*, *Figure 16.5: Sample Custom DNP3 Analog Input Map Settings*, *Figure 16.6: DNP3 Application Network Diagram*, and *Figure 16.8: DNP3 LAN/WAN Application Example Ethernet Network*. **Section 17** ➤ Updated text and figures in *IEC 61850 Configuration*. ➤ Updated *Table 17.20: Logical Device: CFG (Configuration)* and *Table 17.21: Logical Device: ANN (Annunciation)*. **Section 18** ➤ Updated *Equation 18.4*. **Appendix B** ➤ Added text and tables for *Upgrading With Digitally Signed Firmware Upgrade Files*.

Table A.1 Instruction Manual Revision History (Sheet 9 of 11)

Date Code	Summary of Revisions
20191210	**Section 14** ➤ Added margin note regarding the SEL-487E in *CLOSE n*.
20181115	**Section 15** ➤ Updated margin note in *Precision Time Protocol (PTP)*.
20180910	**Section 10** ➤ Added *IEC 61850 Mode/Behavior and Simulation Mode* in *Testing Features and Tools*. ➤ Added *IEC 61850 Testing* in *Test Methods*. ➤ Updated *Table 10.7: Alarm Relay Word Bits*. **Section 12** ➤ Updated *Table 12.9: IP Configuration*, *Table 12.11: HTTP Server Configuration*, and *Table 12.12: Telnet Configuration*. ➤ Added *Table 12.14: IEC 61850 Mode/Behavior Configuration*. ➤ Updated *Table 12.15: Sampled Value Receiver Configuration* and *Table 12.16: Sampled Value Transmitter Configuration*. ➤ Added *Table 12.17: Sampled Value Channel Delay Settings*. **Section 14** ➤ Updated *COM SV* in *Command Description*. ➤ Updated *Figure 14.3: GOOSE Command Response*. ➤ Updated *STA A*, *TEST DB2*, and *TEST DB2 OFF* in *Command Description*. ➤ Updated *TEST SV* in *Command Description*. **Section 17** ➤ Updated *GOOSE Processing* in *IEC 61850.* ➤ Updated *Primary/Secondary Scale Factor* in *Sampled Values*. ➤ Added *Current Summation* in *Sampled Values*. ➤ Updated *Figure 17.6: Independent Bus Mode With PTP Time Synchronization on the Process Bus*, *Figure 17.7: Independent Bus Mode With PTP Time Synchronization on the Station Bus*, and *Figure 17.8: Merged Bus Mode With PTP Time Synchronization*. ➤ Updated *GOOSE and SV Messaging* in *Sampled Values*. ➤ Updated *IEC 61850 Simulation Mode*. ➤ Added *IEC 61850 Mode/Behavior*. ➤ Updated *Table 17.17: IEC 61850 Settings*. ➤ Updated *Figure 17.18: Add ICD to Project Tree*. ➤ Updated *Mode*, *Behavior*, and *Health* under *Logical Nodes*. ➤ Updated *Table 17.18: Logical Device: CFG (Configuration)*. ➤ Updated *Table 17.35: Basic Conformance Statement* and *Table 17.37: ACSI Service Conformance Statement*. **Section 18** ➤ Updated *Table 18.26: PMU Recording Settings*. ➤ Updated *CONAM* in *PMU Recording Capabilities*.
20180630	**Section 5** ➤ Added *Rack Type Breaker Mosaics* and *Status-Only Disconnects* to *Bay Control Front-Panel Operations*. ➤ Added 89CTL*m* to *Disconnect Logic*. ➤ Added 89CTL01 and 52*m*RACK, 52*m*TEST to *Disconnect Assignments*. ➤ Added *Disconnect Front-Panel Control Enable* to *Disconnect Information*.
20180329	**Section 3** ➤ Updated *Reading Oscillograms, Event Reports, and SER.* **Section 4** ➤ Added information on setting combinations to *Front-Panel Menus and Screens*. **Section 9** ➤ Updated *Oscillography* and *Event Reports, Event Summaries, and Event Histories*. **Section 11** ➤ Added information to *Events Directory* in *Virtual File Interface*.

Table A.1 Instruction Manual Revision History (Sheet 10 of 11)

Date Code	Summary of Revisions
20171006	**Section 16** ➤ Updated *Table 16.8: Relay DNP3 Object List*. **Section 17** ➤ Updated for IEC 61850 configuration. **Appendix B** ➤ Updated to help preserve IEC 61850 configuration during a firmware upgrade.
20170714	**Section 2** ➤ Updated *Table 2.2: QuickSet HMI Tree View Functions*. ➤ Updated *Figure 2.20: Retrieving an Event History* and *Figure 2.22: Sample Event Oscillogram*. **Section 9** ➤ Updated *Figure 9.1: Input Processing* to include Sampled Values data acquisition. ➤ Added *Figure 9.2: Input Processing of SEL-400 Series Relays With SV Remote Data Acquisition*. ➤ Updated *Generating Raw Data Oscillograms*, and added *Figure 9.7: An Overcurrent Application Via Remote Data Acquisition* through *Figure 9.9: Filtered Event Reports From SEL-401 and SEL-421*. **Section 10** ➤ Added Sequence of Events Recorder to *Table 10.6: Troubleshooting Procedures*. ➤ Added *Table 10.7: Troubleshooting for Relay Self-Test Warnings and Failures.* **Section 11** ➤ Added *PTP Over PRP Networks*. ➤ Added *Global Time Source vs Local Time Source*. **Section 12** ➤ Added a footnote to *Table 12.5: Protocol Selection* for the EPORT setting. ➤ Added *Table 12.14: SV Receiver Configuration* and *Table 12.15: SV Transmitter Configuration*. ➤ Added a footnote to *Table 12.23: PTP Settings* for setting PTPPRO. ➤ Removed note that PTP is not supported in PRP mode. **Section 14** ➤ Added references to IEC Sampled Values. ➤ Added a note that the CFG NFREQ command is not available in IEC Sampled Values relays. ➤ Updated *Figure 14.2: Sample ETH Command Response*. ➤ Updated *Figure 14.11: Sample VER Command Response*. **Section 15** ➤ Updated *Figure 15.6: Using Internal Ethernet Switch to Add Networked Devices*. **Section 16** ➤ Updated *Table 16.8: Relay DNP Object List*. **Section 17** ➤ Added text for IEC Sampled Values. ➤ Updated *Table 17.3: Relay Logical Devices*. ➤ Added *Sampled Values*. ➤ Added *Simulation Mode*. ➤ Added *Example 17.1: SV Application*. ➤ Updated *Table 17.27: Basic Conformance Statement.* ➤ Updated *Table 17.28: ACSI Models Conformance Statement*. ➤ Updated *Table 17.29: ACSI Service Conformance Statement*. **Section 18** ➤ Added a note regarding Sampled Values-subscribing relays. **Section 19** ➤ Added *IEC 61850-9-2 Sampled Values (SV).*

Table A.1 Instruction Manual Revision History (Sheet 11 of 11)

Date Code	Summary of Revisions
	Appendix C ➤ Updated text for LNKFAIL and LNKFL2. Glossary ➤ Added terms for IEC Sampled Values, Parallel Redundancy Protocol, and real-time control.
20170428	Section 19 ➤ Updated *Figure 19.4: SEL-2243 Power Coupler*.
20170326	Section 15 ➤ Updated Ethernet Communications for information on MMS inactivity. Appendix B ➤ Updated *TiDL Firmware Upgrade*.
20161215	Preface ➤ Updated to describe the new section, *Section19: Remote Data Acquisition*. Section 1 ➤ Updated to introduce TiDL technology. Section 3 ➤ Added information on TiDL system input and output handling. Section 7 ➤ Added information about leading and lagging power factor Relay Word bits. Section 9 ➤ Described the impact of the ERDIG setting on event report handling. ➤ Added a note about SER storage limitations. Section 10 ➤ Added information on TiDL system commissioning. ➤ Described additional diagnostics. ➤ Described module replacement in Axion nodes for the TiDL system. Section 11 ➤ Improved the description of the TSOK Relay Word bit. Section 12 ➤ Added the ERDIG report setting. Section 14 ➤ Added **CFG CTNOM** and **CFG NFREQ** commands. ➤ Clarified the **TEST DB2 A** operation. Section 15 ➤ Updated SNTP accuracy. Section 18 ➤ Updated typographical information in *Figure 18.5: UDP_S Connection*. Section 19 ➤ Added as a new section. Appendix B ➤ Updated to describe firmware upgrades to the TiDL system. Appendix C ➤ Updated to describe cybersecurity aspects of EtherCAT ports. Glossary ➤ Added terms related to TiDL systems.
20160518	➤ Initial version.

This page intentionally left blank

APPENDIX B

Firmware Upgrade Instructions

These instructions guide you through the process of upgrading the firmware in the device. Note that these instructions are only intended for upgrading firmware from an older revision to a newer revision. Downgrading firmware—going from a newer to an older revision—should not be attempted. It will result in the loss of relay calibration, MAC addresses, and other device configuration information. Contact SEL if you need to downgrade the firmware in a relay.

The firmware upgrade will be either a standard release or a point release. A standard release adds new functionality to the firmware beyond the specifications of the existing version. A point release is reserved for modifying firmware functionality to conform to the specifications of the existing version.

A standard release is identified by a change in the R-number of the device firmware identification (FID) string.

Existing firmware:

FID=SEL-411L-**R100**-V0-Z001001-Dxxxxxxxx, or

FID=SEL-411L-1-**R100**-V0-Z001001-Dxxxxxxxx

Standard release firmware:

FID=SEL-411L-**R101**-V0-Z001001-Dxxxxxxxx, or

FID=SEL-411L-1-**R101**-V0-Z001001-Dxxxxxxxx

A point release is identified by a change in the V-number of the device FID string.

Existing firmware:

FID=SEL-411L-R100-**V0**-Z001001-Dxxxxxxxx, or

FID=SEL-411L-1-R100-**V0**-Z001001-Dxxxxxxxx

Point release firmware:

FID=SEL-411L-R100-**V1**-Z001001-Dxxxxxxxx, or

FID=SEL-411L-1-R100-**V1**-Z001001-Dxxxxxxxx

Required Equipment

You will need the following items before beginning the firmware upgrade process:

- Personal computer (PC)
- Terminal emulation software that supports Xmodem/CRC or Ymodem protocol (if upgrading over a serial port connection)
- SEL-C234A cable, SEL-C662 USB to EIA-232, or equivalent (if upgrading over a serial port connection).
- A relay with Telnet-enabled Ethernet ports, a Telnet connection, and a Telnet user interface that supports Ymodem file transfer (if performing an upgrade over Ethernet).
- A relay with HTTP-enabled Ethernet ports and an HTTP Ethernet connection (if upgrading via a web browser). This is the most user-friendly method to complete an upgrade.
- A relay with FTP-enabled Ethernet ports and an FTP Ethernet connection (if upgrading over FTP) and an FTP user interface that supports FTP file transfer.
- .z19, .s19, or .zds firmware upgrade file (.z19 requires SELBOOT R205 or a newer R2*xx* SELBOOT version; .zds requires SELBOOT R300 or newer)
- SELBOOT firmware upgrade file (if necessary; based on the existing SELBOOT revision of the relay)
- Relay Firmware Upgrade Instructions

Optional Equipment

These items help you manage relay settings and understand procedures in the relay upgrade process:

- ACSELERATOR QuickSet SEL-5030 Software (also contains a firmware upload tool that helps to automate this process over a serial-port connection)
- ACSELERATOR Architect SEL-5032 Software (manages IEC 61850 GOOSE, Manufacturing Message Specification [MMS], and SV Configured IED Description [CID] files)
- SEL-5037 Grid Configurator Software (for relays supported by SEL Grid Configurator)
- Appropriate SEL-400 series relay manual

Important Considerations

If upgrading an SEL-451-5, SEL-421-4, or SEL-421-5 from firmware revision R309 or earlier to firmware revision R311 and later, upgrade to R310 before upgrading to R311 and later. Similarly, if upgrading an SEL-487V-0 or SEL-487V-1 from firmware revision R107 or earlier to firmware revision R109 and later, upgrade to R108 before upgrading to R109 and later. Failure to do so will result in the reset of relay settings back to factory defaults.

In some unusual cases, such as loss of relay power during the firmware file transfer process, it is possible for data, including relay settings and the IEC 61850 CID file to be lost. Before beginning the firmware upgrade process, save relay settings (including the IEC 61850 CID file, if applicable), as indicated in *C Save Settings and Other Data on page B.12*.

Important Considerations for the Five-Port Ethernet Card

If installing a five-port Ethernet card for the first time, perform the conversion in this order:

Step 1. Install the required boot firmware (SELBOOT). Refer to Appendix A of the relay-specific instruction manual for compatible SELBOOT versions.

Step 2. Install the required relay firmware. Refer to Appendix A of the relay-specific instruction manual for compatible firmware versions.

Step 3. Follow the *Removing and Installing SEL-400 Series Relay Ethernet Cards* instruction sheet included with your conversion kit.

Upgrading With Digitally Signed Firmware Upgrade Files

NOTE: R2xx SELBOOT versions only support serial-port firmware upgrades with .s19 or .z19 firmware upgrade files. R3xx SELBOOT versions only support .zds digitally signed firmware upgrade files over a serial or Ethernet connection.

The firmware versions identified in *Table B.1* support .zds firmware upgrade files, which can be used to upgrade the relay over a serial or Ethernet connection. The .zds firmware upgrade files can only be sent to relays running SELBOOT R300 or newer.

To prepare relays to accept digitally signed Ethernet firmware upgrades, perform the following:

1. Upgrade SELBOOT to R300 or newer over a serial connection with a .s19 SELBOOT upgrade file.
2. Upgrade relay firmware to a relay version identified in *Table B.1* over a serial connection with a .zds firmware upgrade file.

Once the relay has a firmware version identified in *Table B.1* installed, you can upgrade the relay over an Ethernet connection to any new firmware version above the initial firmware version outlined in the table.

NOTE: Relay firmware versions identified in Table B.1 require SELBOOT R300 or newer because only .zds firmware upgrade files are provided. Firmware .s19 and .z19 upgrade files are not created for these firmware versions.

Table B.1 SEL-400 Series Relays Supporting Ethernet Firmware Upgrades

SEL Relay	Firmware Versions Supporting Ethernet Firmware Upgrades
SEL-400G	All released firmware versions
SEL-401	R407 and newer
SEL-411L-A, -B	All released firmware versions
SEL-411L-0, -1	R126 and newer
SEL-411L-2	All released firmware versions
SEL-421-4, -5	R327 and newer
SEL-421-7	R407 and newer
SEL-451-A	All released firmware versions
SEL-451-5	R324 and newer
SEL-451-6	R401 and newer
SEL-487B-1	R315 and newer
SEL-487B-2	R401 and newer
SEL-487E-3, -4	R318 and newer
SEL-487E-5	R401 and newer

Digitally signed firmware-upgrade files are compressed to reduce file-transfer times and are digitally signed by SEL through use of a secure hash algorithm. The signature ensures that the file has been provided by SEL and that the contents have not been altered. Once uploaded to the relay, the signature of the firmware file is verified with a public key that is stored on the relay. If the relay cannot verify the signature, the file is rejected.

The name of the digitally signed firmware file is of the form r*nnn*-vy4*xx*.zds or s*nnn*-vy4*xx*, where r*nnn* is the standard-release relay firmware identifier, s*nnn* is the standard-release SELBOOT firmware identifier, v*y* is the point-release identifier, and 4*xx* identifies the SEL-400 series relay. Differentiation between relay model variants is handled by the standard-release firmware identifier. See the list (at the beginning of this section) of firmware versions that support digitally signed firmware upgrades to find the standard-release firmware variants of the same relay model.

Ethernet Firmware Upgrades

NOTE: The relay pulses the SALARM bit and writes an entry to the relay SER log whenever a firmware upgrade is attempted over Ethernet. Monitoring this bit and reviewing the SER log can help identify possible unauthorized firmware upgrade attempts.

For relays that support firmware upgrades over Ethernet, you can send the .zds firmware upgrade files via FTP or HTTP protocols to a relay running SELBOOT version R300 or newer and a relay firmware version identified in *Table B.1*. FTP and HTTP are plaintext protocols and do not inherently support message encryption (of relay passwords, etc.). Because of this, SEL strongly recommends using between the relay and your network a security gateway that provides encrypted communications along with SEL SDN technology to harden your network cybersecurity.

Relay Firmware Upgrade Procedure

NOTE: The .z19 files are compressed versions of the .s19 files. These will load into the relay much faster than the .s19 files, but you must have relay SELBOOT version R205 or a newer R2xx SELBOOT version to use these files. Both the .z19 and .s19 files can only be used to upgrade relay firmware over a serial-port connection and can only be sent to a relay with SELBOOT that does not support digitally signed firmware upgrades.

NOTE: The .zds files are digitally signed upgrade files. These upgrade files provide the fastest way to upgrade firmware on a relay, but the relay must be running SELBOOT version R300 or newer to use these files.

NOTE: When you are upgrading relay firmware over a serial connection, SEL strongly recommends that you upgrade firmware at the location of the relay and with a direct connection from the PC to one of the relay serial ports. Do not load firmware from a remote location; problems can arise that you will not be able to address from a distance. When upgrading at the substation, do not attempt to load the firmware into the relay through an SEL communications processor.

The upgrade kit you received contains the firmware needed to upgrade the SEL-400 series relays. The kit may also contain firmware needed to upgrade the SELBOOT program. See *Table B.2* to identify which firmware files you received in the upgrade kit.

Table B.2 Firmware Upgrade Files

Product	File Name[a]	File Type
SEL-400 series relays SELBOOT	s*nnn*4*xx*.s19, s*nnn*-vy4*xx*.s19, or s3*nn*-vy4*xx*.zds	SEL-400 series SELBOOT firmware
SEL-400 series relays (prior to firmware releases identified in *Table B.1*)	r*nnn*4*xx*.s19 or r*nnn*4*xx*.z19	SEL-400 series relay firmware
SEL-400 series relays after SEL started offering point releases (prior to firmware releases identified in *Table B.1*)	r*nnn*-vy4*xx*.s19 or r*nnn*-vy4*xx*.z19	SEL-400 series relay firmware
SEL-400 series relays with SELBOOT versions supporting .zds upgrade files	r*nnn*-vy4*xx*.zds	SEL-400 series relay firmware digitally signed upgrade file

[a] nnn in the file name will always represent the device firmware revision number.
y represents that point release version number.
4xx represents the product name.

The firmware upgrade can be performed in one of four ways. Methods 1 and 2 are provided for upgrading over a serial connection. Methods 3 and 4 are provided for upgrading over an Ethernet connection. When upgrading over a serial connection, you can upgrade using .s19, .z19, or .zds files depending on the SELBOOT firmware the relay is running. When upgrading over an Ethernet connection, you can only upgrade using a .zds file and the relay must currently be running a SELBOOT firmware version that supports digitally signed upgrade files and a relay firmware version that supports Ethernet firmware upgrades (see *Table B.1*).

- Method 1: Use the Firmware Loader provided within QuickSet. The Firmware Loader automates the firmware upgrade process and is the preferred method. The Firmware Loader can be used to upgrade only relay firmware (r*nnn*4*xx* files or r*nnn*-vy4*xx*). If upgrading SELBOOT (s*nnn*4*xx* or s*nnn*-vy4*xx*) firmware is required, use Method 2.
- Method 2: Connect to the relay in a terminal session and upgrade the firmware by using the steps documented in *Method 2: Using a Terminal Emulator on page B.11*.
- Method 3: Connect to the relay over an Ethernet web browser and use the steps documented in *Method 3: Using a Web Browser on page B.17*.
- Method 4: Connect to the relay over an Ethernet FTP connection and use the steps documented in *Method 4: Using FTP on page B.20*.

NOTE: Relays supported only by SEL Grid Configurator (e.g., TiDL relays, etc.) should only use Methods 2–4.

Determine Which Upgrade Method to Use

Table B.3 helps you determine which firmware upgrade method you would like to use based on your upgrade scenario. From the links provided in *Table B.3*, you can use the link to easily move ahead to the method of your choosing. For help in identifying which scenario you fall under, see *Identify Firmware Versions on the Relay on page B.6*.

Table B.3 Firmware Upgrade Scenarios and Available Methods (Sheet 1 of 2)

Upgrade Scenario	Available Methods
Upgrading SELBOOT firmware from an R2*xx* SELBOOT version to a newer R2*xx* SELBOOT version	Upgrade with a .s19 SELBOOT upgrade file via *Method 2: Using a Terminal Emulator on page B.11*
Upgrading SELBOOT firmware from an R2*xx* SELBOOT version to an R3*xx* SELBOOT version	Upgrade with a .s19 SELBOOT upgrade file via *Method 2: Using a Terminal Emulator on page B.11*
Upgrading SELBOOT firmware from an R3*xx* SELBOOT version to a newer R3*xx* SELBOOT version on a relay running a relay firmware version prior to one identified in *Table B.1*.	Upgrade with a .zds SELBOOT upgrade file via *Method 2: Using a Terminal Emulator on page B.11*
Upgrading SELBOOT firmware from an R3*xx* SELBOOT version to a newer R3*xx* SELBOOT version on a relay running relay firmware identified in *Table B.1*.	Upgrade with a .zds SELBOOT upgrade file via one of the following: *Method 2: Using a Terminal Emulator on page B.11* *Method 3: Using a Web Browser on page B.17* (Using a web browser is the most user-friendly option) *Method 4: Using FTP on page B.20*

Table B.3 Firmware Upgrade Scenarios and Available Methods (Sheet 2 of 2)

Upgrade Scenario	Available Methods
Upgrading relay firmware on a relay running any R2*xx* SELBOOT version	Upgrade with a .s19 or .z19 relay firmware upgrade file via one of the following: *Method 1: Using QuickSet Firmware Loader on page B.6* *Method 2: Using a Terminal Emulator on page B.11*
Upgrading relay firmware on a relay currently running an R3*xx* SELBOOT version and a relay firmware version prior to a version identified in *Table B.1*.	Upgrade with a .zds SELBOOT upgrade file via one of the following: *Method 1: Using QuickSet Firmware Loader on page B.6* *Method 2: Using a Terminal Emulator on page B.11*
Upgrading relay firmware on a relay currently running an R3*xx* SELBOOT version and a relay firmware version identified in *Table B.1*.	Upgrade with a .zds relay firmware upgrade file via one of the following: *Method 1: Using QuickSet Firmware Loader on page B.6* *Method 2: Using a Terminal Emulator on page B.11* *Method 3: Using a Web Browser on page B.17* (Using a web browser is the most user-friendly option) *Method 4: Using FTP on page B.20*

NOTE: Relays supported only by SEL Grid Configurator (e.g., TiDL relays, etc.) should only use Methods 2–4.

Identify Firmware Versions on the Relay

To determine the SELBOOT and relay firmware versions the relay is currently running, do the following:

Step 1. Establish a serial or Telnet terminal session between the relay and a personal computer.

Step 2. In the relay terminal line, type **ID <Enter>**.

The relay responds with the following:

```
"FID=SEL-4xx-x-Rxxx-V0-Zxxxxxx-Dxxxxxxxx","xxxx"
"BFID=SLBT-4XX-Rxxx-V0-Zxxxxxx-Dxxxxxxx","xxxxx"
"CID=xxx","xxxx"
"DEVID=xxxxxxx","xxxx"
"DEVCODE=xx","xxxx"
"PARTNO=xxxxxxxxxxxxxx","xxxx"
"SERIALNO=xxxxxxxxxx","xxxx"
"CONFIG=xxxxxxxx","xxxx"
"SPECIAL=xxxxx","xxxx"
```

Step 3. Locate the relay firmware identification (FID) string and the Boot firmware identification (BFID) string.

Step 4. See *Table B.3* for upgrade methods available based on the firmware versions currently operating on the relay.

Method 1: Using QuickSet Firmware Loader

To use the QuickSet Firmware Loader, you must have QuickSet. See *Section 2: PC Software* for instructions on how to obtain and install the software. Once the software is installed, perform the firmware upgrade as follows.

A Obtain Firmware File

NOTE: The Firmware Loader can be used to load only relay firmware (rnnn4xx or rnnn-vy4xx) on relays supported by QuickSet. This method cannot be used to upgrade firmware on relays only supported by SEL Grid Configurator.

Contact SEL customer service for the firmware file. The file name is of the form r*nnn*4*xx* or r*nnn*-v*y*4*xx*, where r*nnn* is the firmware revision number, v*y* indicates the point release number, and 4*xx* indicates the relay type. The firmware file name extensions are .s19, .z19, and .zds. Copy the firmware file to an easily accessible location on the PC.

Firmware is designed to be used with specific relays. A list of relay serial numbers is provided as part of the firmware upgrade package. The firmware provided is for use with the listed relays only. Attempts to upgrade relays not listed might not be successful and can result in relay failure.

B Remove Relay From Service

Step 1. If the relay is in use, follow your company practices for removing a relay from service. Typically, these practices include disabling input and output control functions.

Step 2. Apply power to the relay.

Step 3. Connect a communications cable and determine the port speed.

If using the EIA-232 front port to upgrade firmware, determine the port speed as follows:

a. From the relay front panel, press the **ENT** pushbutton.

b. Use the arrow pushbuttons to navigate to `SET/SHOW`.

c. Press the **ENT** pushbutton.

d. Use the arrow pushbuttons to navigate to `PORT`.

e. Press the **ENT** pushbutton.

f. Use the arrow pushbuttons to navigate to the relay serial port you plan to use (usually the front port, **PORT F**).

g. Press the **ENT** pushbutton.

h. Use the arrow pushbuttons to navigate to **Communication Settings**.

i. Press the **ENT** pushbutton to view the selected port communications settings. Write down the value for each setting.

j. Once the port settings have been recorded, press the **ESC** pushbutton four times to return to the `MAIN MENU`.

k. Connect an SEL-C234A EIA-232 serial cable, SEL-C662 USB to EIA-232 converter, or equivalent communications cable to the relay serial port and to the PC.

C Establish Communications With the Relay

NOTE: Once serial port communication is established, it is recommended to set the SELBOOT Max Baud setting to the highest possible port speed available (typically 115200 bps). This will reduce the time needed to read settings and events from the relay.

Use the **Communications > Parameters** menu of QuickSet to establish a connection using the communications settings determined in *Step 3* under *B Remove Relay From Service on page B.7*. See *Section 2: PC Software* for additional information.

D Save Settings and Other Data

It is possible for data to be lost during the firmware upgrade process. Follow the steps in this section carefully to ensure that important data are saved.

Step 1. For SEL-400 series relays with optional IEC 61850 protocol configured, follow the steps in section *Verify IEC 61850 Operation (Optional) on page B.22* to save the CID file and send it back to the relay after the firmware upgrade.

Step 2. Select **Tools > Firmware Loader** and follow the onscreen prompts.

Step 3. In the Step 1 of 4 window of the Firmware Loader (as shown in *Figure B.1*), select the ellipsis button and browse to the location of the firmware file. Select the file and select **Open**.

Figure B.1 Prepare the Device (Step 1 of 4)

Step 4. Select the **Save calibration settings** check box in the Step 1 of 4 window of the Firmware Loader. These factory settings are required for proper operation of the relay and must be reentered in the unlikely event they are erased during the firmware upgrade process. The Firmware Loader saves the settings in a text file on the PC.

Step 5. Select the **Save device settings** check box if you do not have a copy of the relay settings. It is possible for relay settings to be lost during the upgrade process.

Step 6. Select the **Save events** check box if there are any event reports that have not been previously saved. The event history is cleared during the upgrade process.

Step 7. Select **Next**.

The Firmware Loader reads the calibration settings and saves them in a text file on the PC. Make note of the file name and the location.

If **Save device settings** was selected, the Firmware Loader reads all of the settings from the relay. The software may ask if you want to merge the settings read from the relay with existing design templates on the PC. Select **No, do not merge settings with Design Template**. The Firmware Loader will suggest a name for the settings, but the suggested name can be modified as desired.

If **Save events** was selected, the **Event History** window will open to allow the events to be saved. See *Section 2: PC Software* for more information.

Step 8. If you use the Breaker Wear Monitor, select the **Terminal** button in the lower left portion of the Firmware Loader to open the terminal window. From the Access Level 1 prompt, issue the **BRE** command and record the internal and external trip counters, internal and external trip currents for each phase, and breaker wear percentages for each phase.

Step 9. Enable Terminal Logging capture (see *Section 2: PC Software*) and issue the following commands to save stored data. It is possible for these data to be lost during the firmware upgrade process.

a. **MET E**—accumulated energy metering

b. **MET D**—demand and peak demand

c. **MET M**—maximum/minimum metering

d. **COMM A** and **COMM B**—MIRRORED BITS communications logs

e. **PROFILE**—Load Profile

f. **SER**—Sequential Events Records

E Start SELBOOT

In the Step 2 of 4 window of the Firmware Loader, select **Next** to disable the relay and enter SELBOOT (see *Figure B.2*).

Figure B.2 Load Firmware (Step 2 of 4)

F Maximize Port Data Rate

This step is performed automatically by the software.

G Upload New Relay Firmware

This step is performed automatically by the software. The software will erase the existing firmware and start the file transfer to upload the new firmware. Upload progress will be shown in the **Transfer Status** window. The entire firmware upload process can take longer than 10 minutes to complete.

When the firmware upload is complete, the relay will restart. The Firmware Loader automatically reestablishes communications and issues an **STA** command to the relay.

In cases where the relay does not restart within two minutes of the firmware upload completion (as indicated by the PC application), and no error messages appear on the relay HMI, turn the relay off and back on again. The firmware loader application should then resume. Answer **Yes** if the Firmware Loader prompts you to continue.

H Verify Relay Self-Tests

The Step 3 of 4 window of the Firmware Loader will indicate that it is checking the device status and when the check is complete (see *Figure B.3*).

The software will notify you if any problems are detected. You can view the relay status by opening the terminal using the Terminal button in the lower left portion of the Firmware Loader. If status failures are shown, open the terminal and see *Troubleshooting on page B.24*.

Select **Next** to go to the completion step.

Figure B.3 Load Firmware (Step 3 of 4)

I Verify Relay Settings

If there are no failures, the relay will enable. In the Step 4 of 4 window (see *Figure B.4*), the Firmware Loader will give you the option to compare the device settings. If any differences are found, the software will provide the opportunity to restore the settings.

Figure B.4 Verify Device Settings (Step 4 of 4)

Method 2: Using a Terminal Emulator

These instructions assume you have a working knowledge of your PC terminal emulation software. In particular, you must be able to modify the serial communications parameters (data speed, data bits, parity, and similar parameters), disable any hardware or software flow control in the computer terminal emulation software, select a transfer protocol (1K Xmodem, for example), and transfer files (send and receive binary files).

The programs (firmware) that run in the SEL-400 series relays reside in Flash memory. To load new firmware versions, follow these instructions. The SEL-400 series relays have two programs that you may need to upgrade: the regular, or "executable" program and the SELBOOT program.

A Obtain Firmware File

Contact SEL customer service for the firmware file. For relay firmware, the file name is of the form r*nnn*4*xx* or r*nnn*-v*y*4*xx*, where r*nnn* is the firmware revision number, v*y* indicates the point release number, and 4*xx* indicates the relay type. For SELBOOT firmware, the file name is of the form s*nnn*4xx or s*nnn*-v*y*4xx, where s*nnn* is the SELBOOT revision number and 4xx indicates that the SELBOOT version is for SEL-400 series relays. The firmware file name extensions are .s19, .z19, and .zds. Copy the firmware file to an easily accessible location on the PC.

Firmware is designed to be used with specific relays. A list of relay serial numbers is provided as part of the firmware upgrade package. The firmware provided is for use with the listed relays only. Attempts to upgrade relays not listed might not be successful and can result in relay failure.

B Prepare the Relay

If the relay is in service, follow your company practices for removing a relay from service. Typically, these practices include disabling input and output control functions.

C Save Settings and Other Data

It is possible for data to be lost during the firmware upgrade process. Follow the steps in this section carefully to ensure that important data are saved.

Enter Access Level 2

NOTE: Once serial port communication is established, it is recommended to set the port SPEED setting to the highest possible port speed available (typically 57600 bps in Access Level 2). This will reduce the time needed to read settings and events from the relay.

Step 1. Using the communications terminal, at Access Level 0, type **ACC <Enter>**.

Step 2. Type the Access Level 1 password and press **<Enter>**.

You will see the Access Level 1 => prompt.

Step 3. Type **2AC <Enter>**, and then type the correct password to go to Access Level 2.

You will see the Access Level 2 =>> prompt.

For more information, see *Making an EIA-232 Serial Port Connection on page 3.4*.

Backup Relay Settings

The relay preserves the settings and passwords during the firmware upgrade process. However, if relay power is interrupted during the firmware upgrade process, the relay can lose the settings. Make a copy of the original relay settings in case you need to reenter settings.

NOTE: In addition to all of the normal settings classes, log in to Access Level C and save the SET_CM.TXT file.

Use one of the following methods to backup relay settings.

- If you have not already saved copies of the relay settings, use QuickSet to read and save the relay settings.

  See *Create and Manage Relay Settings on page 2.21*.

- Alternatively, you can use the terminal to download all the relay settings.

  See the **FILE READ** command under *FILE on page 14.37*.

  For file retrieval procedures see *Reading Oscillograms, Event Reports, and SER on page 3.46*.

- If you have IEC 61850 configurations and you have not already saved copies of the CID file, use Architect to read and save the CID file. See *Verify IEC 61850 Operation (Optional) on page B.22* for details.

D Start SELBOOT

Step 1. Establish/confirm binary transfer terminal communication.

Use a terminal program that supports 1K Xmodem transfer protocol to communicate with the relay.

Step 2. Prepare to control the relay at Access Level 2. If the relay is not already at Access Level 2, use the procedure in *Enter Access Level 2 on page B.12*.

Step 3. Start the relay SELBOOT program.

a. Type **L_D <Enter>**.

If running a R2*xx* SELBOOT version, the relay responds with the following message:

```
Disable relay to send or receive firmware (Y/N)?
```

If running a R3*xx* SELBOOT version, the relay responds with the following message:

```
Disable relay and transition to SELBoot (Y/N)?
```

b. Type **Y <Enter>**.

The relay responds with the following message:

```
Are you sure (Y/N)?
```

c. Type **Y <Enter>**.

The relay responds with the following message:

```
Relay Disabled
```

Step 4. Wait for the SELBOOT program to load.

The front-panel LCD screen displays the SELBOOT R*yyy* firmware number (e.g., `SELBOOT R209`). R*yyy* is the SELBOOT revision number and is a different revision number from the relay firmware revision number. The LCD also displays the present relay firmware (e.g., `SEL-451-5-R324`), and `INITIALIZING`.

When finished loading the SELBOOT program, the relay responds to the terminal with the SELBOOT !> prompt; the LCD shows the SELBOOT and relay firmware revision numbers.

Step 5. Press **<Enter>** to confirm that the relay is in SELBOOT; you will see another SELBOOT !> prompt.

Establish a High-Speed Serial Connection

Step 1. At the SELBOOT prompt, type **BAU 115200 <Enter>** (see *Figure B.7*).

Step 2. Set your terminal program for a data speed of 115200 bps.

Step 3. Press **<Enter>** to check for the SELBOOT !> prompt indicating that serial communication at 115200 bps is successful.

E Upload New SELBOOT Firmware to the Relay

NOTE: Loading the incorrect SELBOOT firmware to the relay may cause the relay to malfunction, requiring factory repair.

Upgrading SELBOOT firmware in SEL-400 series relays is typically not required as part of a normal relay firmware upgrade process. However, core functions of the relay are occasionally enhanced, and the SELBOOT firmware must be upgraded to enable the enhanced functions. If a SELBOOT upgrade for the relay is not indicated in your upgrade kit, skip this step and continue on to *F Upload New Relay Firmware on page B.14*. See *Table B.2* for file names.

NOTE: Do not cycle power to the relay during the SELBOOT firmware upgrade process. Doing so may cause the relay to malfunction, requiring factory repair.

To begin the relay SELBOOT upgrade, start at the SELBOOT !> prompt.

Step 1. Type **REC BOOT** command at the SELBOOT prompt, and answer **Y** when prompted to erase the existing SELBOOT firmware.

If the relay is running a R2*xx* SELBOOT version, the relay responds with:

```
!>REC BOOT <Enter>
Caution! -  This command erases the SELboot firmware.
Are you sure you want to erase the existing firmware? (Y/N)
```

If the relay is running a R3*xx* SELBOOT version, the relay responds with:

```
!>REC BOOT <Enter>
Caution! This command erases the SELBoot firmware.
Do not interrupt power during SELboot upload
or the device may require factory reprogramming.

Are you sure you want to erase the existing firmware (Y/N)?
```

Step 2. The relay will prompt you to begin the file transfer. Press any key to begin the file transfer to the relay.

Step 3. Select Xmodem as your file transfer method, then point the sending software tool to the relay SELBOOT file (s*nnn*4xx.s19, s*nnn*-v*y*4xx.s19 or s3*nn*-v*y*4xx.zds) that is to be uploaded to the relay.

Upon successful negotiation of the new SELBOOT firmware file, the old SELBOOT software will be erased, and the new SELBOOT firmware will be written to the Flash memory of the relay. The relay will then automatically restart using the new SELBOOT firmware.

```
Erasing old SELboot

Writing new SELboot to flash

Press any key to begin transfer, then start transfer at the PCC
Restarting SELboot
```

Step 4. Once the relay has restarted, revert back to *Table B.3* and determine your relay firmware upgrade method.

F Upload New Relay Firmware

If you are only upgrading SELBOOT, you can skip this step and continue to *G Return Serial Data Speed to Nominal Operating Speed and Exit SELBOOT on page B.15*.

Step 1. From the SELBOOT !> prompt, type **REC <Enter>**.

If running a R2*xx* SELBOOT version, the relay responds with the prompt shown in *Figure B.5*.

```
!>BAU 115200 <Enter>
!><Enter>


!>REC <Enter>
Caution! - This command erases the device firmware.
If you erase the firmware, new firmware must be loaded into the device
before it can be put back into service.
Are you sure you want to erase the existing firmware? (Y/N) Y <Enter>
Erasing


Erase successful
Press any key to begin transfer, then start transfer at the PCCC <Enter>
```

Figure B.5 Transferring New Firmware

If running a R3*xx* SELBOOT version, the relay responds with the prompt shown in *Figure B.6*.

```
!>REC <Enter>
Caution! This command erases the firmware.
If you erase the firmware then new firmware
must be loaded before returning the IED to service.

Are you sure you want to erase the existing firmware (Y/N)?
Press any key to begin transfer and then start transfer at the terminal.
```

Figure B.6 Transferring New Firmware

Step 2. When prompted with `Are you sure you want to erase the existing firmware? (Y/N)`, type **Y <Enter>**.

The relay responds, `Erasing`, and erases the existing firmware. The front-panel LCD shows `ERASING MEMORY`.

When finished erasing, the relay responds, `Erase successful`, and prompts you to press any key to begin transferring the new firmware. The front-panel LCD shows only the SELBOOT program revision number.

Step 3. Press **<Enter>** to begin uploading the new firmware.

Step 4. Start the **Transfer** or **Send** process in your terminal emulation program.

Use 1K Xmodem for fast transfer of the new firmware to the relay.

Step 5. Point the terminal program to the location of the new firmware file (the file that ends in .s19, .z19, and .zds).

NOTE: The relay displays one or more "C" characters while waiting for your PC terminal emulation program to send the new firmware. If you do not start the transfer quickly (within about 18 seconds), the relay times out and responds `Remote system is not responding`. If this happens, begin again at F Upload New Relay Firmware on page B.14.

Step 6. Begin the file transfer.

The typical transfer time at 115200 bps with 1K Xmodem is 10 to 20 minutes. The LCD screen shows `SELBOOT Ryyy LOADING CODE` while the relay loads the new firmware.

Step 7. Wait for firmware load completion.

If the relay responds with the message `Transfer failed — Model mismatch`, please refer to *Troubleshooting on page B.24*.

When finished loading the new firmware, the relay responds, `Transfer completed successfully` and displays the SELBOOT !> prompt. The LCD screen displays `SELBOOT Ryyy SEL-4xx-Rnnn`, where *yyy* is the SELBOOT revision number, 4*xx* is the particular model of the SEL-400 series relay being upgraded, and *nnn* is the firmware revision number of the relay, e.g., R100 SEL-421-R105.

G Return Serial Data Speed to Nominal Operating Speed and Exit SELBOOT

Step 1. Type **<Enter>** to confirm relay communication.

The terminal displays the SELBOOT !> prompt.

Step 2. Type **BAU 9600 <Enter>** to reduce the data speed to your nominal serial communications speed (9600 bps in this example).

Step 3. Set your terminal emulation program to match the nominal data speed.

Step 4. Type **<Enter>** to confirm that you have reestablished communication with the relay.

The relay responds with the SELBOOT !> prompt.

Step 5. Type **EXI <Enter>** to exit the SELBOOT program.

After a slight delay, the relay responds with the following message:

```
CAUTION: Initial relay restart. DO NOT cycle power during
this time. Please wait 3 minutes for restart completion.
```

Step 6. Following the expected relay restart time from *Step 5*, proceed to *H Verify Relay Self-Tests on page B.16*.

H Verify Relay Self-Tests

Step 1. Press **<Enter>** and confirm that the Access Level 0 = prompt appears on your terminal screen.

Step 2. Remove input power to the relay.

a. Allow at least 10 seconds during the removal of relay power to ensure that the power supply has shut down.

b. Reapply input power to the relay.

c. Wait 10 minutes after startup of the relay to allow the relay to detect any hardware changes made during the upgrade process.

Step 3. Enter Access Level 1 using the **ACC** command and Access Level 1 password.

Step 4. Enter Access Level 2 using the **2AC** command and Access Level 2 password.

Step 5. Type **VER <Enter>** to confirm the new firmware.

Step 6. Match the firmware revision number with the FID number on the screen.

Step 7. Type **STA <Enter>** to check the relay status and accept new hardware changes if needed.

Step 8. Verify that all relay self-test parameters are within tolerance. (The relay compares the settings before and after the upgrade process and displays an upgrade warning if settings are dissimilar. You can find details in the upgrade report file.)

Step 9. View the front-panel **ENABLED** LED and confirm that the LED is illuminated.

Unless there is a serious problem, the **ENABLED** LED illuminates without any intervention, and the relay retains all settings.

If the relay does not enable within five minutes of the `Initial relay restart` message, contact your Technical Service Center or the SEL factory for assistance (see *Technical Support on page B.26*).

I Verify Relay Settings

Step 1. Prepare to control the relay at Access Level 2; use the procedure in *Enter Access Level 2 on page B.12*.

Step 2. Type **VER <Enter>** to confirm the new firmware.

Step 3. Match the firmware revision number with the FID number on the screen.

Step 4. Use one of the following methods to review your settings.

- ➢ Use the QuickSet **Read** menu.

  If the settings do not match the settings that you recorded in *Backup Relay Settings on page B.12*, use QuickSet to restore relay settings.

- ➢ Type **SHOW <Enter>**.

  You can reissue the settings with the **SET** commands (see *Section 9: ASCII Command Reference* of the product-specific instruction manual for information on the **SHOW** and **SET** commands).

Step 5. Type **STA <Enter>** to check relay status.

Step 6. Verify that all relay self-test parameters are within tolerance.

Method 3: Using a Web Browser

NOTE: The relay pulses the SALARM bit and writes an entry to the relay SER log whenever a firmware upgrade is attempted over Ethernet. Monitoring this bit and reviewing the SER log can help identify possible unauthorized firmware upgrade attempts.

To upgrade firmware through use of the web browser, the HTTP server must be enabled for the Ethernet ports. SEL recommends enabling Telnet in case you need to perform any ASCII terminal commands (inputting settings, etc.).

Never use the web browser to downgrade firmware on a relay.

A Set PORT 5 Settings MAXACC, EETHFWU, and EPAC

To upgrade relay firmware by using the web browser, the PORT 5 settings MAXACC and EETHFWU must be set to 2 or C, and Y, respectively. In the web browser login page, Access Level 2 is provided as a user-selectable login access level. If EETHFWU is set to N, upgrading firmware over an Ethernet connection is disabled. If EPAC = Y, ensure Relay Word bit E2AC is asserted to allow Level 2 access.

B Obtain Firmware File

Contact SEL customer service for the firmware file. For relay firmware, the file name is of the form r*nnn*4*xx* or r*nnn*-v*y*4*xx*, where r*nnn* indicates the firmware revision number, v*y* indicates the point-release number, and 4*xx* indicates the relay type. For SELBOOT firmware, the file name is of the form s*nnn*-v*y*4xx, where s*nnn* is the SELBOOT revision number, and 4xx indicates that the SELBOOT version is for SEL-400 series relays. The firmware file name extensions are .s19, .z19, and .zds. Only the .zds file can be used when using the web browser. Copy the .zds digitally signed firmware upgrade file to an easily accessible location on the PC.

Firmware is designed to be used with specific relays. A list of relay serial numbers is provided as part of the firmware upgrade package. The firmware provided is for use with the listed relays only. Attempts to upgrade relays not listed might not be successful and can result in relay failure.

C Remove Relay From Service

Step 1. If the relay is in use, follow your company practices for removing a relay from service. Typically, these include changing settings, or disconnecting external voltage sources or output contact wiring, to disable relay control functions.

Step 2. Apply power to the relay.

D Read IEC 61850 CID File Through Architect

Step 1. Establish an FTP connection between the relay and your computer in Architect.

Step 2. Download the CID file by using the IP address of the relay.

E Prepare the Relay (Save Relay Settings and Other Data)

Create a Telnet connection in QuickSet or SEL Grid Configurator (for relays supported by SEL Grid Configurator) and read both settings and event reports stored on the relay. If you prefer using FTP to pull settings and reports, and FTP is enabled on the Ethernet ports, see *E Establish Communications With the Relay and Read Settings on page B.21* for pulling events and reports over FTP.

F Establish a Web Browser Connection With the Relay

Step 1. Establish communication between your personal computer and the relay through a web browser (HTTP) connection. See *HTTP (Hypertext Transfer Protocol) Server on page 15.20* for more information.

G Upload New Firmware

NOTE: Access level passwords are not encrypted in any way by the Web Server when logging in.

Step 1. To upload new firmware, log in to Access Level 2 of the web server. Select **2AC** from the Access Level dropdown box. Enter the respective Access Level 1 and 2 passwords and select the **Login** button.

Step 2. Once logged in verify communication with the correct relay by checking the Relay Identifier (RID setting) and Substation Identifier (SID setting) next to the SEL icon in the upper left corner of the web browser page. Choose **System > Firmware Upgrade** from the left pane, which brings up the page shown in *Figure B.7*. This page also displays feedback from the previous firmware upgrades. If the prior firmware upgrade was successful, the page displays **Previous firmware upgrade successful. Date:** ***mm/dd/yy*** **Time:** ***hh:mm:ss***. If the prior firmware upgrade failed, the page displays **Previous firmware upgrade failed. Date:** ***mm/dd/yy*** **Time:** ***hh:mm:ss***, with an error message below. If no prior firmware upgrade has occurred (which is the case for a new unit from the factory), the page displays, **Previous firmware upgrade information is unavailable.**

Figure B.7 Firmware Upload File Selection Page

Step 3. To search for your firmware file, select the **Browse** button. The format of this file must be .zds. If upgrading relay firmware, the name of the file sent can be either r*nnn*-vy4*xx*.zds or RELAY.ZDS. If upgrading SELBOOT firmware, the name of the file can be s3*nn*-vy4*xx*.zds or SELBOOT.ZDS.

NOTE: The relay automatically disables during the firmware upgrade process then enables following a successful upgrade.

Step 4. To submit, select **Upload File**. Once the upload has started, it cannot be canceled. During the upload process the relay remains enabled and continues normal operation.

Step 5. Once the firmware file is transferred to the device, the relay disables and attempts to restart using the new firmware.

Step 6. When the firmware upload process is complete, the message shown in *Figure B.8* is displayed by the web server. The HTTP session closes after the upload is complete and the firmware upgrade takes place. The message displayed indicates how long the firmware upgrade process will take. The relay automatically enables after a successful firmware upgrade.

Figure B.8 Firmware Upgrade Confirmation

H Verify Firmware

Step 1. Re-establish an HTTP connection with the relay after the displayed expected upgrade time or monitor the link status with the relay and then re-establish a connection when the relay reports as online.

Step 2. Select **System > Device Features** from the left pane and verify the relay FID or BFID matches the firmware to which you expected to upgrade.

I Check Web Browser Upgrade Messages

After the firmware upgrade is completed and once you have logged back into Access Level 1 of the web server, you can check the relay self-tests by selecting **Relay Status > Self Tests** in the left pane. The following table provides messages displayed in the web browser and the message meaning.

Table B.4 Ethernet Firmware Upgrade User Messages (Sheet 1 of 2)

User Message	Relay Condition
Previous upgrade information is not available.	No previous firmware upgrade using a .zds file has occurred
Previous upgrade successful.	The previous firmware upgrade with a .zds file was successful.

Table B.4 Ethernet Firmware Upgrade User Messages (Sheet 2 of 2)

User Message	Relay Condition
Previous upgrade failed.	A previous attempt to upgrade firmware failed. Contact SEL Support if this occurs.
The file upload was successful. The device is restarting and the connection with the web server is closing to complete the firmware upgrade process. You should be able to log back into the web server within about 5 minutes.	The relay successfully received and validated the .zds file and will now load the firmware and automatically restart and enable the new firmware.
Invalid upgrade file.	The .zds file was not successfully received or validated by the relay.
Model mismatch.	The .zds file is for firmware for a different SEL-400 series relays model.
Settings modification in progress on another interface.	Settings within the relay are currently being modified through another connection.
Upgrade in progress on another interface.	A firmware upgrade is currently being performed through another connection.

J Verify Relay Settings

To verify the settings are correct for your relay, choose **Show Settings** in the left pane. Verify that these match the settings saved earlier (see *G Upload New Firmware on page B.18*). Note that calibration settings are not viewable via the web server, a terminal connection is needed to verify these settings. If the settings do not match, reenter the settings saved earlier.

Method 4: Using FTP

NOTE: The relay pulses the SALARM bit and writes an entry to the relay SER log whenever a firmware upgrade is attempted over Ethernet. Monitoring this bit and reviewing the SER log can help identify possible unauthorized firmware upgrade attempts.

To upgrade firmware through use of FTP, FTP must be enabled for the Ethernet ports. SEL recommends enabling Telnet in case you need to perform any ASCII terminal commands (inputting settings, etc.). SEL recommends a software interface on your PC because it can help you visualize and simplify the file-transfer process. Become familiar with the FTP interface of your choosing prior to attempting a firmware upgrade over FTP.

Never use FTP to downgrade firmware on a relay.

A Set PORT 5 Settings MAXACC, EETHFWU, and EPAC

To upgrade firmware by using FTP, the **PORT 5** settings MAXACC and EETHFWU must be set to 2 or C, and Y, respectively. If EETHFWU is set to N, upgrading firmware over an Ethernet connection is disabled. If EPAC = Y, ensure Relay Word bit E2AC is asserted to allow Level 2 access. Also, if FTP anonymous logins are enabled (FTPANMS := Y), the **UPGRADE** directory is hidden from FTP and Ethernet upgrades over FTP are not allowed.

B Obtain Firmware File and Rename File for FTP File Transfer

Contact SEL customer service for the firmware file. For relay firmware, the file name is of the form r*nnn*-v*y*4*xx*, where r*nnn* indicates the firmware revision number, v*y* indicates the point-release number, and 4*xx* indicates the relay type. For SELBOOT firmware, the file name is of the form s*nnn*4xx, where s*nnn* is the SELBOOT revision number and 4xx indicates that the SELBOOT version is for SEL-400

series relays. The firmware file name extensions are .s19, .z19, and .zds. Only the .zds file can be used when using FTP. Copy the .zds digitally signed firmware upgrade file to an easily accessible location on the PC.

Firmware is designed to be used with specific relays. A list of relay serial numbers is provided as part of the firmware upgrade package. The firmware provided is for use with the listed relays only. Attempts to upgrade relays not listed might not be successful and can result in relay failure.

If upgrading relay firmware, rename the provided r*nnn*-v*y*4*xx*.zds firmware upgrade file to RELAY.ZDS by right-clicking the file on your PC and selecting **Rename**. Based on FTP file transfer and relay directories, the relay must receive the file as the name RELAY.ZDS.

If upgrading SELBOOT firmware, rename the provided s3*nn*-v*y*4*xx*.zds SELBOOT upgrade file to SELBOOT.ZDS by right-clicking the file on your PC and selecting **Rename**. Because of the FTP file transfer and relay directories, the relay must receive the SELBOOT upgrade file as the name SELBOOT.ZDS.

C Remove Relay From Service

Step 1. If the relay is in use, follow your company practices for removing relays from service. Typically, these include changing settings or disconnecting external voltage sources or output contact wiring to disable relay functions.

Step 2. Apply power to the relay.

D Read IEC 61850 CID File Through Architect

Step 1. Establish an FTP connection between the relay and your computer in Architect.

Step 2. Download the CID file by using the IP address of the relay.

E Establish Communications With the Relay and Read Settings

Step 1. Establish an FTP connection between your personal computer and relay in the FTP software interface of your choosing. The username is 2AC and the password is your Access Level 2 password. FTP is used on Port 21 of the relay, so ensure in the connections window the IP address of your relay you are upgrading is correct and the FTP port is assigned to 21.

Step 2. In the FTP user interface, in the relay file list, navigate to the **SETTINGS** folder.

Step 3. Download all .TXT files stored in this folder from the relay. Note that the **SEL_ALL.TXT** file is a read-only file and cannot be sent back to the relay.

Step 4. In the relay file list menu, navigate back to the main root folder, then navigate to the **REPORTS** folder. Download all .TXT files stored in this folder from the relay.

Step 5. In the relay file list menu, navigate back to the main root folder, then navigate to the **EVENTS** folder. Download all events of interest.

F Send Firmware

Step 1. With the FTP connection established in *E Establish Communications With the Relay and Read Settings on page B.21*, in your FTP software interface, point to the renamed relay RELAY.ZDS file if upgrading relay firmware, or the renamed SELBOOT SELBOOT.ZDS upgrade file if upgrading SELBOOT firmware on your PC. On the relay side, navigate to the **UPGRADE** folder and open it.

Step 2. Send the renamed RELAY.ZDS or SELBOOT.ZDS file to the **UPGRADE** file directory folder of the relay. Select **Yes** to the overwrite question, if prompted.

NOTE: The relay automatically disables during the firmware upgrade process then enables following a successful upgrade.

Once the file is loaded to the relay, the relay verifies the file and then accepts the file if the file is verified by the keying algorithm. If the relay accepts the file, the previous firmware is removed and the new firmware is installed. It is important to note that once the relay successfully loads the new firmware, it automatically restarts and enables the firmware. During this process, you will lose the FTP connection, and you must re-establish the FTP connection if required to perform *Step 3* after approximately five minutes. The relay automatically enables after a successful firmware upgrade.

Step 3. During this upgrade process, you will lose the FTP connection, and you must re-establish the FTP connection after approximately five minutes or when the link status with the relay shows the relay online. Re-establish the FTP connection, then navigate to the relay **UPGRADE** directory and read the error file ERR.TXT. Open the .txt file on your PC and review for any error messages. If the firmware upgraded properly, no errors occurred during the upgrade process and the file is empty. If messages are contained within the file, see *Table B.4* for the error message and what the error means.

G Verify Firmware

Step 1. Establish a Telnet connection with the relay after the displayed expected upgrade time or monitor the link status with the relay and then establish a connection when the relay reports as online.

Step 2. Issue the **ID** command and verify the relay FID or BFID matches the firmware to which you expected to upgrade.

H Verify Relay Settings

Step 1. Establish the same FTP connection as identified in *E Establish Communications With the Relay and Read Settings on page B.21*.

Step 2. Navigate to the relay root directory, then the relay **SETTINGS** directory.

Step 3. Read the **UPGRADE_RPT.TXT** file from the relay. Open the .TXT file on your PC and see if there are any unexpected settings changes. Contact SEL Support (selinc.com/support/) at any time for further assistance.

Verify IEC 61850 Operation (Optional)

The SEL-400 series relays with optional IEC 61850 protocol require the presence of one valid CID file to enable the protocol. You should only transfer a CID file to the relay if you want to implement a change in the IEC 61850 configuration or restore the relay CID file after a firmware upgrade in which the CID file is

removed. If you transfer an invalid CID file, the relay will disable the IEC 61850 protocol because it no longer has a valid configuration. To restart IEC 61850 protocol operation, you must transfer a valid CID file to the relay.

NOTE: The five-port Ethernet card uses a ClassFileVersion 007 or higher CID file for IEC 61850 configuration. Use Architect to create a CID file for the five-port Ethernet card.

Perform the following steps to verify that the IEC 61850 protocol is still operational and if not, re-enable it. This procedure assumes that IEC 61850 was operational with a valid CID file immediately before initiating the firmware upgrade. If the IEC 61850 protocol was not configured prior to the upgrade, skip to *Return Relay to Service on page B.24*. Refer to the *Section 17: IEC 61850 Communication* for help with IEC 61850 configuration.

Step 1. Issue the **STA**, **ID**, and **GOO** commands.

Step 2. Verify that there are no error messages regarding IEC 61850 or CID file parsing.

If the responses to the **STA**, **ID**, or **GOO** commands contain IEC 61850 or CID error messages, continue with the following steps to re-enable the IEC 61850 protocol. Otherwise, skip to *Method 2: Using a Terminal Emulator on page B.11*.

If the IEC 61850 protocol has been disabled because of an upgrade-induced CID file incompatibility, you can use Architect to create and send a compatible CID file to the relay.

Step 3. In the Telnet session, issue the **STA**, **ID**, and **GOO** commands.

Step 4. Verify that no IEC 61850 error messages are in the **STA** or **ID** command responses.

Step 5. Verify the GOOSE transmitted and received messages are as expected.

Relays being upgraded from firmware that did not support a local-time UTC offset setting (UTCOFF) to firmware that does support the UTCOFF setting may show incorrect time stamps in Demand Metering and Breaker Monitor report data that was recorded by the relay prior to the firmware upgrade.

The time stamps shown for the Demand Metering and Breaker Monitor data recorded prior to the firmware upgrade will show UTC time plus an eight-hour local time offset, along with any applicable daylight-saving time adjustment.

This only affects time stamps recorded and stored by the relay prior to the firmware upgrade. All time stamps in Demand Metering and Breaker Monitoring following the firmware upgrade will be UTC time with the local time offset setting (UTCOFF) and daylight-saving time applied.

No other reports (Event History, Event Summary, SER, etc.) are affected.

Time-Domain Link (TiDL) Centrally Controlled Firmware Upgrade (For Relays Supporting T-Protocol)

The SEL-TMUs will be selectively upgraded through connected relays.

Relays that share common SEL-TMUs can be upgraded independently without affecting other devices (relays and SEL-TMUs) in the TiDL system. When an SEL-TMU is being upgraded, the relays connected to this SEL-TMU detects a loss in communication and implements selective protection disabling. See *Selective Protection Disabling on page 19.3* for details.

Return Relay to Service

NOTE: Converting to the five-port Ethernet card introduces a third MAC address. Follow your company networking guidelines to update your Ethernet switch configurations to integrate the five-port Ethernet card into your network.

Step 1. Open a terminal window.

Step 2. Use the **ACC** command with the associated password to enter Access Level 1.

Step 3. Issue the **ID** command and compare the firmware revision (R*nnn* or R*nnn*-V*y*) displayed in the FID string against the number from the firmware envelope label. If the numbers match, proceed to *Step 5*.

Step 4. For a mismatch between a displayed FID and the firmware envelope label, re-attempt the upgrade or contact SEL for assistance.

Step 5. If you use the Breaker Wear Monitor, type **BRE <Enter>** to check the data to see if the relay retained breaker wear data through the upgrade procedure. If the relay did not retain these data, use the **BRE W** command to reload the percent contact wear values recorded in *D Save Settings and Other Data on page B.7*.

Step 6. Apply current and voltage signals to the relay.

Step 7. Type **MET <Enter>** or use the QuickSet HMI to verify that the current and voltage signals are correct.

Step 8. Use the **TRI** and **EVE/CEV** commands or **Tools > Events > Get Events** menu in QuickSet to verify that the magnitudes of the current and voltage signals you applied to the relay match those displayed in the event report. If these values do not match, check the relay settings and wiring.

Step 9. Autoconfigure the SEL communications processor port if you have an SEL communications processor connected to the relay. This step re-establishes automatic data collection between the SEL communications processor and the relay. Failure to perform this step can result in automatic data collection failure when cycling communications processor power.

Follow your company procedures for returning a relay to service.

Troubleshooting

Resolving Model Mismatch

When uploading a new firmware file to the relay, SELBOOT checks the relay model number (for example, 451, 421, 487) to ensure that the firmware being loaded into the relay is correct for the relay model. If the relay responds with `Transfer failed — Model mismatch` when a firmware upload is attempted, it is because the relay model number does not match. This may be because the firmware file is not correct, or the relay model number stored in the relay memory was corrupted by an interruption of the file upload.

To remedy this problem, first ensure you are sending the correct file to the relay. *Table B.2* shows the file names used for the firmware files. Verify that the model number in the firmware file matches the model of the relay and then reattempt the upload. If the upload fails again or if SELBOOT is inaccessible, contact SEL for assistance.

Resolving Communications Card Firmware Mismatch

The `COMM CARD FIRMWARE MISMATCH` error indicates that the five-port Ethernet card is installed, but either the relay firmware or SELBOOT is not compatible with the Ethernet card. To resolve the error, verify SELBOOT R302 or later is installed and load any relay firmware that supports the five-port Ethernet card. Refer to Appendix A of the relay-specific instruction manual for compatible firmware versions. If supported firmware is already loaded, reload the firmware. If the error persists, contact SEL for assistance.

Resolving Status Failure Message Response to STA Command

If a status failure message is returned in response to the **STA** command, perform the following steps.

Step 1. Use the **ACC** and **2AC** commands with the associated passwords to enter Access Level 2.

Step 2. Type **STA C <Enter>**. Answer **Y <Enter>** to the `Reboot the relay and clear status` prompt. The relay will respond with `Rebooting the relay`. Wait for about 30 seconds, then press **<Enter>** until you see the Access Level 0 = prompt.

Step 3. Use the **ACC** command with the associated password to enter Access Level 1.

Step 4. Type **STA <Enter>**.

If there are no fail messages and you are using Method 1, select **Next** in Step 3 of 4 of the Firmware Loader and go to *I Verify Relay Settings on page B.16*.

If there are no fail messages and you are using Method 2, go to *I Verify Relay Settings on page B.16*.

If there are fail messages, continue with *Step 5*.

NOTE: Step 7 causes the loss of settings and other important data. Be sure to retain relay settings and other data downloaded from the relay at the start of the firmware upgrade process. Relay calibration level settings will not be lost.

Step 5. Use the **2AC** command with the associated password to enter Access Level 2.

Step 6. Use the **CAL** command and type the corresponding password to enter Access Level C.

Step 7. Type **R_S <Enter>** to restore factory-default settings in the relay.

The relay asks whether to restore default settings. If the relay does not accept the **R_S** command, contact SEL for assistance.

Step 8. Type **Y <Enter>**.

The relay can take as long as two minutes to restore default settings. The relay then reinitializes, and the **ENABLED** LED illuminates. This LED is labeled either **EN** or **ENABLED**, depending on the relay model.

Step 9. Press **<Enter>** to check for the Access Level 0 = prompt indicating that serial communication is successful.

Step 10. Use the **ACC** and **2AC** commands and type the corresponding passwords to reenter Access Level 2.

Step 11. Use the **CAL** command and type the corresponding password to enter the relay Calibration settings level.

Step 12. Type **SHO C <Enter>** to verify the relay calibration settings.

If using Method 1 and the settings do not match the settings contained in the text file you recorded in *C Save Settings and Other Data on page B.12*, contact SEL for assistance.

If using Method 2 and the settings do not match the settings contained in the text file you recorded in *B Prepare the Relay on page B.11*, contact SEL for assistance.

Step 13. Use the **PAS *n*** (*n* = 0, 1, 2, B, P, A, O, C) command to set the relay passwords.

Step 14. Restore the relay settings.

Step 15. If any failure status messages still appear on the relay display, see the Testing and Troubleshooting section in your relay instruction manual or contact SEL for assistance.

Technical Support

We appreciate your interest in SEL products and services. If you have questions or comments, please contact us at:

Schweitzer Engineering Laboratories, Inc.
2350 NE Hopkins Court
Pullman, WA 99163-5603 U.S.A.
Tel: +1.509.338.3838
Fax: +1.509.332.7990
Internet: selinc.com/support
Email: info@selinc.com

APPENDIX C

Cybersecurity Features

The SEL-400 series relays have a number of security features to assist users with meeting their cybersecurity design requirements.

Ports and Services

Physical Ports

NOTE: Connect SEL devices only to trusted networks.

The SEL-400 series relays include four serial ports and an Ethernet communications card with as many as five ports. Each physical serial port and Ethernet port can be individually disabled using the EPORT setting. By default, all of the ports are enabled.

SEL recommends that unused communications ports be disabled.

SEL-400 series relays with a TiDL configuration also have eight ports. These are always enabled, but they have a very limited functionality, as described below.

IP Ports

When using Ethernet, there are a number of possible IP ports available within the relay. Many of these IP port numbers are configurable. All IP ports can be disabled and are disabled by default. *Table C.1* describes each of these.

Table C.1 IP Port Numbers

IP Port Default	Port Selection Setting	Network Protocol	Default Port State	Port Enable Setting	Purpose
21	--	TCP	Disabled	FTPSERV	FTP protocol access for file transfer of settings and reports
23	TPORT	TCP	Disabled	ETELNET	Telnet access for general engineering terminal access
80	HTTPPOR	TCP	Disabled	EHTTP	Web server access to read various relay information
102	--	TCP	Disabled	E61850	IEC 61850 Manufacturing Message Specification (MMS) for SCADA functionality
123	SNTPPOR	UDP	Disabled	ESNTP	SNTP time synchronization
319/320	--	UDP	Disabled	EPTP	Precision Time Protocol (PTP) time synchronization
4712/ 4713	PMOTCP1/ PMOUDP1	TCP/UDP	Disabled	PMOTS1	Synchrophasor data output, session 1
4722/ 4713	PMOTCP2/ PMOUDP2	TCP/UDP	Disabled	PMOTS2	Synchrophasor data output, session 2
20000	DNPPNUM	TCP/UDP	Disabled	EDNP	DNP3 for SCADA functionality

Note that IP traffic is only supported on station bus ports, so process bus ports have no open IP ports. See *Ethernet Communications on page 15.6* for more information on these settings.

Segregating Ethernet Ports

NOTE: Isolated IP mode is not available when using the five-port Ethernet card. Configure a ClassFileVersion 007 or higher CID file for the five-port Ethernet card to define which ports publish GOOSE traffic.

In some operating modes, the enabled Ethernet ports support both IP traffic and layer 2 protocols (i.e., IEC 61850 GOOSE). If NETMODE = ISOLATEIP, then one port only permits GOOSE traffic. This allows this port to be routed outside of a security perimeter while retaining the ability to perform basic monitoring and control. See *Redundant Ethernet Ports (Two- or Four-Port Ethernet Card) on page 15.10* for more information on this mode.

T-Protocol Ports

SEL-400 series relays with a TiDL configuration that supports T-Protocol have eight TiDL communications ports. These ports communicate with SEL-TMUs. The ports are used exclusively for exchanging analog and digital data with SEL-TMUs; they will not recognize any other types of communications.

Once the system is configured and commissioned, the relay only communicates with the associated SEL-TMUs that were commissioned during the relay commissioning process. Any other traffic on these ports is ignored.

EtherCAT Ports

SEL-400 series relays with a TiDL configuration that supports EtherCAT have eight EtherCAT ports. These communicate with Axion nodes. The ports are used exclusively for exchanging analog and digital data with Axions; they will not recognize any other types of communication.

Once the system is configured and commissioned, the relay will only communicate with recognized Axions. Any other traffic on these ports will be ignored. After commissioning, the loss of communications to any configured Axion or Axion module will cause the relay to disable.

Authentication and Authorization Controls

Local Accounts

SEL-400 series relays support eight levels of access, as described in the *Access Levels and Passwords on page 3.7*. Refer to this section to learn how each level is accessed and what the default passwords are. It is good security practice to change the default passwords of each access level and to use a unique password for each level.

Relays have the capability to limit the level of access on a port basis. The maximum access level setting may be used on each port to restrict these authorization levels. This permits you to operate under the principle of “least privilege,” restricting ports to the levels needed for the functions performed on those ports. In addition, you can use the EPAC setting on each port to restrict read or write access as defined by the Global SELOGIC equations EACC and E2AC.

Each relay supports strong passwords of as many as 12 characters including any printable character, allowing users to select complex passwords if they so choose. SEL recommends that passwords contain a minimum of eight characters containing at least one of each of the following: lowercase letter, uppercase letter, number, and special character.

Authentication Failures

When three successive login attempts fail as a result of an incorrect password entry, the relay locks out login attempts on that port for 30 seconds. It also pulses the BADPASS Relay Word bit.

Malware Protection Features

Firmware Hash Verification

SEL provides firmware hashes as an additional tool to verify the integrity of SEL firmware upgrade files. This helps ensure that the firmware received from the factory is complete and unaltered prior to sending the firmware to the SEL device. Verify that the firmware file in your possession is a known good SEL firmware release by comparing the calculated hash value of the firmware in your possession with the hash value provided at selinc.com/products/firmware/.

Operating System/Firmware

SEL-400 series relays are embedded devices that do not allow additional software to be installed. SEL-400 series relays include a self-test that continually checks running code against the known good baseline version of code in nonvolatile memory. This process is outlined in more detail in the document titled *The SEL Process for Mitigating Malware Risk to Embedded Devices* located at selinc.com/mitigating_malware/.

SEL-400 series relays run in an embedded environment for which there is no commercial anti-virus software available.

Software/Firmware Verification

SEL-400 series relays have the ability to install firmware updates in the field. Authenticity and integrity of firmware updates can be verified by using the Firmware Hash page at selinc.com/products/firmware/.

See **Firmware Verification** available at selinc.com/products/firmware for information that can help verify that currently installed firmware on an SEL relay is complete and unaltered.

Logging Features

Internal Log Storage

The Sequential Event Recorder (SER) log is a useful tool for capturing a variety of relay events. In addition to capturing state changes of user selected Relay Word bits, it captures all startups, settings changes, and group switches. See *Sequential Events Recorder (SER) on page 9.28* for more information about SER.

Alarm Reporting

The relay provides the following Relay Word bits that are useful for monitoring relay access:

- BADPASS—Pulses for one second if a user enters three successive bad passwords.
- ACCESS—Set while any user is logged into Access Level B or higher.
- ACCESSP—Pulses for one second whenever a user gains access to an Access Level of B or higher.
- PASSDIS—Set if the password disable jumper is installed.
- BRKENAB—Set if the breaker control enable jumper is installed.
- LINK5A, LINK5B, LINK5C, LINK5D, LINK5E—Set while the link is active on the respective Ethernet port. Loss-of-link can be an indication that an Ethernet cable has been disconnected.

NOTE: The relay can take as long as 6 ms to detect and report the loss of link on an active port (assert LNKFAIL or LNKFL2).

- LNKFAIL—Set if link is lost on any active station bus port. For relays with only two Ethernet ports, LNKFAIL asserts if link is lost on either port.
- LNKFL2—Set if link is lost on the active process bus port (Ethernet 87L ports or Sampled Values (SV) ports in devices with those capabilities). Once detected, the loss of the active port on the process bus causes immediate failover if the backup port has a good data link. If this is the case, failover may occur too quickly for the SER scanner to register the assertion and deassertion of LNKFL2.

These bits can be mapped for SCADA monitoring via DNP3, IEC 61850, or SEL Fast Message. They can also be added to the SER log for later analysis and assigned to output contacts for alarm purposes.

Physical Access Security

Physical security of cybersecurity assets is a common concern. Typically, relays are installed within a control enclosure that provides physical security. Other times, they are installed in boxes within the switch yard. The relay provides some tools that may be useful to help manage physical security, especially when the unit is installed in the switch yard.

You can monitor physical ingress by wiring a door sensor to one of the relay contact inputs. This input can then be mapped for SCADA monitoring or added to the SER log so that you can detect when physical access to the relay occurs.

It is also possible to wire an electronic latch to a relay contact output. You could then map this input for SCADA control.

Configuration Control Support

Product Version Information

The SEL-400 series relay firmware revision number (FID) provides the current firmware version/patch level. The FID can be obtained using the **STATUS** command.

Settings Version Information

All settings changes are logged to the SER log. Analysis of this log will let you determine if any unauthorized settings changes occurred.

The relay also stores a hash code for each settings class in the CFG.txt file. After configuring the device, you can read the CFG.txt file and store it for future reference. You can then periodically read this file from the relay and compare it to the stored reference. If any of the hash codes have changed, then you know that a settings class has been modified.

Backup and Restore

SEL-400 series relays support the export and import of settings and configuration by using ACSELERATOR QuickSet SEL-5030 Software and ACSELERATOR Architect SEL-5032 Software. Settings can also be imported and exported as files by using any file transfer mechanism.

Decommissioning

NOTE: Do not do this when sending in the relay for service at the factory. SEL needs to be able to see how the relay was configured to properly diagnose any problems.

It is often desirable to erase the settings from the relay when it is removed from service. You can completely erase all the configuration settings from the relay by using the following procedure.

Step 1. Go to Access Level C.

Step 2. Execute the **R_S** command to restore the device to factory-default settings.

Step 3. Allow the relay to restart.

Step 4. Go to Access Level C.

Step 5. Execute the **R_S** command again to set the backup copy of settings to factory default.

Step 6. Allow the relay to restart.

Once this procedure is complete, all internal instances of all user settings and passwords will be erased.

Vulnerability Notification Process

Security Vulnerability Process

SEL provides security disclosure alerts to customers, and SEL instruction manuals document all releases. SEL security vulnerability disclosures are described in *The SEL Process for Disclosing Security Vulnerabilities* located at selinc.com.

Emailed Security Notification

You can sign up to receive email notifications when SEL releases security vulnerability notices and service bulletins at selinc.com/support/security-notifications/.

This page intentionally left blank

Glossary

a Contact A breaker auxiliary contact (ANSI Standard Device Number 52A) that closes when the breaker is closed and opens when the breaker is open.

a Output A relay control output that closes when the output relay asserts.

b Contact A breaker auxiliary contact (ANSI Standard Device Number 52B) that opens when the breaker is closed and closes when the breaker is open.

b Output A relay control output that opens when the output relay asserts.

c Contact A breaker auxiliary contact that can be set to serve either as an a contact or as a b contact.

c Output An output with both an a output and b output sharing a common post.

3U, 4U, 5U, 6U, 7U, 9U The designation of the vertical height of a device in rack units. One rack unit, U, is approximately 1.75 in or 44.45 mm.

A Abbreviation for amps or amperes—a unit of electrical current flow.

ABS Operator An operator in math SELOGIC control equations that provides absolute value.

AC Ripple The peak-to-peak ac component of a signal or waveform. In the station dc battery system, monitoring ac ripple provides an indication of whether the substation battery charger has failed.

Acceptance Testing Testing that confirms that the relay meets published critical performance specifications and requirements of the intended application. Such testing involves testing protection elements and logic functions when qualifying a relay model for use on the utility system.

Access Level A relay command level with a specified set of relay information and commands. Except for Access Level 0, you must have the correct password to enter an access level.

Access Level 0 The least secure and most limited access level. No password protects this level. From this level, you must enter a password to go to a higher level.

Access Level 1 A relay command level you use to monitor (view) relay information. The default access level for the relay front panel.

Access Level 2 The most secure access level where you have total relay functionality and control of all settings types.

Access Level A A relay command level you use to access all Access Level 1 and Access Level B (Breaker) functions plus Automation, Alias, Global, Front Panel, Report, Port, and DNP3 settings.

Access Level B A relay command level you use for Access Level 1 functions plus circuit breaker control and data.

Access Level O A relay command level you use to access all Access Level 1 and Access Level B (Breaker) functions plus Output, Alias, Global, Front Panel, Report, Port, and DNP3 settings.

Access Level P
A relay command level you use to access all Access Level 1 and Access Level B (Breaker) functions plus Protection, SELOGIC, Alias, Global, Group, Breaker Monitor, Front Panel, Report, Port, and DNP3 settings.

ACSELERATOR Architect SEL-5032 Software
Architect is an add-on to the QuickSet Suite that uses the IEC 61850 Substation Configuration Language to configure SEL IEDs.

ACSELERATOR QuickSet SEL-5030 Software
A Windows-based program that simplifies settings and provides analysis support.

ACSI
Abstract Communications Service Interface for the IEC 61850 protocol. Defines a set of objects, a set of services to manipulate and access those objects, and a base set of data types for describing objects.

Active Settings Group
The settings group that the relay is presently using from among six settings groups available in the relay.

ADC
Analog to Digital Converter. A device that converts analog signals into digital signals.

Admittance
The reciprocal of impedance, I/V.

Advanced Settings
Settings for customizing protection functions; these settings are hidden unless you set EADVS := Y and EGADVS := Y.

Alias
An alternative name assigned to Relay Word bits, analog quantities, default terminals, and bus-zone names.

Analog Quantities
Variables represented by such fluctuating measurable quantities as temperature, frequency, current, and voltage.

AND Operator
Logical AND. An operator in Boolean SELOGIC control equations that requires fulfillment of conditions on both sides of the operator before the equation is true.

ANSI Standard Device Numbers
A list of standard numbers used to represent electrical protection and control relays. The standard device numbers used in this instruction manual include the following:

21 Distance element
24 Volts/Hertz Element
25 Synchronism-check element
27 Undervoltage Element
32 Directional Elements
49 Thermal Element
50 Overcurrent Element
51 Inverse-Time Overcurrent Element
52 AC Circuit Breaker
59 Overvoltage Element
67 Definite-Time Overcurrent
79 Recloser
86 Breaker Failure Lockout
89 Disconnect

These numbers are frequently used within a suffix letter to further designate their application. The suffix letters used in this instruction manual include the following:

- P Phase Element
- G Residual/Ground Element
- N Neutral/Ground Element
- Q Negative-Sequence (3I2) Element

Anti-Aliasing Filter A low-pass filter that blocks frequencies too high for the given sampling rate to accurately reproduce.

Apparent Power, S Complex power expressed in units of volt-amperes (VA), kilovolt-amperes (kVA), or megavolt-amperes (MVA). Accounts for both real (P) and reactive (Q) power dissipated in a circuit: S = P + jQ. This is power at the fundamental frequency only; no harmonics are included in this quantity.

Arcing Resistance The resistance in the arc resulting from a power line fault.

ASCII Abbreviation for American Standard Code for Information Interchange. Defines a standard set of text characters. The relay uses ASCII text characters to communicate using front-panel and rear-panel EIA-232 serial ports on the relay and through virtual serial ports.

ASCII Terminal A terminal without built-in logic or local processing capability that can only send and receive information.

Assert To activate. To fulfill the logic or electrical requirements needed to operate a device. To set a logic condition to the true state (logical 1) of that condition. To apply a closed contact to a relay input. To close a normally open output contact. To open a normally closed output contact.

AT Modem Command Set Dialing String Standard The command language standard that Hayes Microcomputer Products, Inc. developed to control autodial modems from an ASCII terminal (usually EIA-232 connected) or a PC containing software allowing emulation of such a terminal.

Autoconfiguration The ability to determine relay type, model number, metering capability, port ID, data rate, passwords, relay elements, and other information that an IED (an SEL-2020/2030 communications processor) needs to automatically communicate with relays.

Automatic Messages Messages including status failure and status warning messages that the relay generates at the serial ports and displays automatically on the front-panel LCD.

Automatic Reclose Automatic closing of a circuit breaker after a breaker trip by a protective relay.

Automation Variables Variables that you include in automation SELOGIC control equations.

Autoreclose-Drive-to-Lockout A logical condition that drives the autoreclose function out of service with respect to a specific circuit breaker.

Autotransformer A transformer with at least two common windings.

AX-S4 MMS “Access for MMS” is an IEC 61850, UCA2, and MMS client application produced by SISCO, Inc., for real-time data integration in Microsoft Windows-based systems supporting OPC and DDE. Included with AX-S4 MMS is the interactive MMS Object Explorer for browser-like access to IEC 61850/UCA2 and MMS device objects.

Axion Another term for the SEL-2240. The Axion is an integrated, modular input/output and control solution suited for utility and industrial applications. In TiDL (EtherCAT) systems, it is used for data acquisition and control.

Bandpass Filter A filter that passes frequencies within a certain range and blocks all frequencies outside this range.

Bay Primary plant including disconnects, circuit breaker, CTs, PTs, power transformer, etc.

Bay Control Front-panel control (open and close) of the transformer circuit breakers and disconnects (isolators).

Best Choice Ground Directional Element Logic An SEL logic that determines the directional element that the relay uses for ground faults.

Bit Label The identifier for a particular bit.

Bit Value Logical 0 or logical 1.

Block Trip Extension Continuing the blocking signal at the receiving relay by delaying the dropout of Relay Word bit BT.

Blocking Signal Extension The blocking signal for the DCB (directional comparison blocking) trip scheme is extended by a time delay on dropout timer to prevent unwanted tripping following current reversals.

Bolted Fault A fault with essentially zero impedance or resistance between the shorted conductors.

Boolean Logic Statements Statements consisting of variables that behave according to Boolean logic operators such as AND, NOT, and OR.

Breaker Auxiliary Contact An electrical contact associated with a circuit breaker that opens or closes to indicate the breaker position. A Form A breaker auxiliary contact (ANSI Standard Device Number 52A) closes when the breaker is closed and opens when the breaker is open. A Form B breaker auxiliary contact (ANSI Standard Device Number 52B) opens when the breaker is closed and closes when the breaker is open.

Breaker-and-a-half Configuration A switching station arrangement of three circuit breakers per two circuits; the two circuits share one of the circuit breakers.

Breaker Differential Differential zone of protection configured exclusively across the tie breaker; the breaker differential protects only the area between the two tie-breaker CTs.

Buffered Report IEC 61850 IEDs can issue buffered reports of internal events (caused by trigger options data-change, quality-change, and data-update). These event reports can be sent immediately or buffered (to some practical limit) for transmission, such that values of data are not lost because of transport flow control constraints or loss of connection. Buffered reporting provides Sequence-of-Events (SOE) functionality.

Busbar Electrical junction of two or more primary circuits. For a single busbar, there could be multiple bus-zones; there can be more bus-zones than busbars, but not more busbars than bus-zones.

Bus Coupler (see also Tie Breaker) Equipment with at least a CT and circuit breaker, connecting two busbars when the circuit breaker is closed. Disconnects of other terminals at the station (feeders, lines, etc.) are normally arranged in parallel with the bus coupler. Closing two or more disconnects of the other terminals bypasses the bus coupler, forming a connection without a circuit breaker between two or more busbars.

Busbar Protection Element Each busbar protection elements comprise a differential element, a directional element, and a fault detection logic.

Bus Sectionalizer (see also Buscoupler) Equipment with at least a CT and circuit breaker, connecting two busbars when the circuit breaker is closed.

Bus-Zone-to-Bus-Zone Connection Variable SELOGIC variable stating the conditions when the relay merges two zones to form a single protection zone.

Bus-Zone (see also Protection Zone) Area of protection formed by a minimum of two terminals.

C37.118 IEEE C37.118, Standard for Synchrophasor Measurements for Power Systems.

C37.238 IEEE C37.238, Standard Profile for Use of IEEE 1588 Precision Time Protocol in Power System Applications.

Capacitor Bank Assembly of a number of capacitor units.

Capacitor Element Device consisting of two electrodes separated by a dielectric.

Capacitor Unit Assembly of a number of capacitor elements.

Category A collection of similar relay settings.

CCVT Capacitively coupled voltage transformer that uses a capacitive voltage divider to reduce transmission voltage to a level safe for metering and relaying devices. See CVT.

Checksum A method for checking the accuracy of data transmission involving summation of a group of digits and comparison of this sum to a previously calculated value.

Check Zone Protection zone formed by two or more terminals where the differential calculation is independent of the status of the disconnect auxiliary contacts.

CID Checksum identification of the firmware.

CID File IEC 61850 Configured IED Description file. XML file that contains the configuration for a specific IED.

Circuit Breaker Failure Logic This logic within the relay detects and warns of failure or incomplete operation of a circuit breaker in clearing a fault or in performing a trip or close sequence.

Circuit Breaker History Report A concise circuit breaker event history that contains as many as 128 events. This breaker history report includes circuit breaker mechanical operation times, electrical operation times, interrupted currents, and dc battery monitor voltages.

Circuit Breaker Report A full report of breaker parameters for the most recent operation. These parameters include interrupted currents, number of operations, and mechanical and electrical operating times among many parameters.

Class The first level of the relay settings structure including Global, Group, Breaker Monitor, Port, Report, Front Panel, DNP3 settings, Protection SELOGIC control equations, Automation SELOGIC control equations, and Output SELOGIC control equations.

Cold Start Turning a system on without carryover of previous system activities.

Combined Winding Mathematical combination (in the SEL-451) of currents from two separate sets of CT on the same voltage level, typical of breaker-and-a-half busbar configurations.

Commissioning Testing Testing that serves to validate all system ac and dc connections and confirm that the relay, auxiliary equipment, and SCADA interface all function as intended with your settings. Perform such testing when installing a new protection system.

Common Class Components Composite data objects that contain instances of UCA standard data types.

Common Data Class IEC 61850 grouping of data objects that model substation functions. Common Data Classes include Status information, Measured information, Controllable status, Controllable analog, Status settings, Analog settings, and Description information.

Common Inputs Relay control inputs that share a common terminal.

Common Time Delay Both ground and phase distance protection follow a common time delay on pickup.

Common Zone Timing Both ground and phase distance protection follow a common time delay on pickup.

Communications Protocol A language for communication between devices.

Communications-Assisted Tripping Circuit breaker tripping resulting from the transmission of a control signal over a communications medium.

Comparison Boolean SELOGIC control equation operation that compares two numerical values. Compares floating-point values such as currents, total counts, and other measured and calculated quantities.

Computer Terminal Emulation Software Software such as Microsoft HyperTerminal or ProComm Plus that can be used to send and receive ASCII text messages and files via a computer serial port.

COMTRADE Abbreviation for Common Format for Transient Data Exchange. The relay supports the IEEE Std C37.111–1999 and C37.111-2013, Common Format for Transient Data Exchange (COMTRADE) for Power Systems.

Conditioning Timers Timers for conditioning Boolean values. Conditioning timers either stretch incoming pulses or allow you to require that an input take a state for a certain period before reacting to the new state.

Contact Input See Control Input.

Contact Output See Control Output.

Control Input Relay inputs for monitoring the state of external circuits. Connect auxiliary relay and circuit breaker contacts to the control inputs.

Control Output Relay outputs that affect the state of other equipment. Connect control outputs to circuit breaker trip and close coils, breaker failure auxiliary relays, communications-assisted tripping circuits, and SCADA systems.

Coordination Timer A timer that delays an overreaching element so that a downstream device has time to operate.

COS Operator Operator in math SELOGIC control equations that provides the cosine function.

Counter Variable or device such as a register or storage location that either records or represents the number of times an event occurs.

Cross-Country Fault A cross-country fault consists of simultaneous separate single phase-to-ground faults on parallel lines.

CT Current transformer.

CT Subsidence Current Subsidence current appears as a small exponentially decaying dc current with a long time constant. This current results from the energy trapped in the CT magnetizing branch after the circuit breaker opens to clear a fault or interrupt load.

CTR Current transformer ratio.

Current Compensation Adjustment of the current signals to nullify any standing unbalance current.

Current Reversal Guard Logic Under this logic, the relay does not key the transmitter and ignores reception of a permissive signal from the remote terminal when a reverse-looking element detects an external fault.

Current Transformer Saturation The point of maximum current input to a CT; any change of input beyond the saturation point fails to produce any appreciable change in output.

CVT Capacitive voltage transformer that uses a capacitive voltage divider to reduce transmission voltage to a level safe for metering and relaying devices. See CCVT.

CVT Transient Blocking Logic that prevents transient errors on capacitive voltage transformers from causing false operation of Zone 1 mho elements.

CVT Transient Detection Logic Logic that detects transient errors on capacitive voltage transformers.

Data Attribute In the IEC 61850 protocol, the name, format, range of possible values, and representation of values being communicated.

Data Bit A single unit of information that can assume a value of either logical 0 or logical 1 and can convey control, address, information, or frame check sequence data.

Data Class In the IEC 61850 protocol, an aggregation of classes or data attributes.

Data Label The identifier for a particular data item.

Data Object In the IEC 61850 protocol, part of a logical node representing specific information (status or measurement, for example). From an object-oriented point of view, a data object is an instance of a data class.

DC Offset A dc component of fault current that results from the physical phenomenon preventing an instantaneous change of current in an inductive circuit.

DCB (Directional Comparison Blocking) A communications-assisted protection scheme. A fault occurring behind a sending relay causes the sending relay to transmit a blocking signal to a remote relay; the blocking signal interrupts the tripping circuit of the remote relay and prevents tripping of the protected line.

DCE Devices Data communications equipment devices (modems).

DCUB (Directional Comparison Unblocking) A communications-assisted tripping scheme with logic added to a POTT scheme that allows high-speed tripping of overreaching elements for a brief time during a loss of channel. The logic then blocks trip permission until the communications channel guard returns for a set time.

Deadband The range of variation an analog quantity can traverse before causing a response.

Deassert To deactivate. To remove the logic or electrical requirements needed to operate a device. To clear a logic condition to its false state (logical 0). To open the circuit or open the contacts across a relay input. To open a normally open output contact. To close a normally closed output contact.

Debounce Time The time that masks the period when relay contacts continue to move after closing; debounce time covers this indeterminate state.

Default Data Map The default map of objects and indices that the relay uses in DNP3 protocol.

Delta A phase-to-phase series connection of circuit elements, particularly voltage transformers or loads.

Demand Meter A measuring function that calculates a rolling average or thermal average of instantaneous measurements over time.

Differential Element The differential element calculates current differences across a zone of protection.

Digital Secondary System (DSS) A protection system that uses merging units to perform signal gathering and control.

Direct Tripping Local or remote protection elements provide tripping without any additional supervision.

Directional Element The directional element determines the direction of power flow at a point in the power system.

Directional Start A blocking signal provided by reverse reaching elements to a remote terminal used in DCB communications-assisted tripping schemes. If the fault is internal (on the protected line), the directional start elements do not see the fault and do not send a blocking signal. If the fault is external (not on the protected line), the directional start elements start sending the block signal.

Directional Supervision The relay uses directional elements to determine whether protective elements operate based on the direction of a fault relative to the relay.

Disabling Time Delay A DCUB scheme timer (UBDURD) that prevents high-speed tripping following a loss-of-channel condition.

Disconnect (Isolator) Mechanical switch that isolates primary equipment such as circuit breakers from the electrical system.

Distance Calculation Smoothness A relay algorithm that determines whether the distance-to-fault calculation varies significantly or is constant.

Distance Protection Zone The area of a power system where a fault or other application-specific abnormal condition should cause operation of a protective relay.

DMTC Period The time of the demand meter time constant in demand metering.

DNP (Distributed Network Protocol) Manufacturer-developed, hardware-independent communications protocol.

Dropout Time The time measured from the removal of an input signal until the output signal deasserts. You can set the time, in the case of a logic variable timer, or the dropout time can be a result of the characteristics of an element algorithm, as in the case of an overcurrent element dropout time.

DTE Devices Data terminal equipment (computers, terminals, printers, relays, etc.).

DTT (Direct Transfer Trip) A communications-assisted tripping scheme. A relay at one end of a line sends a tripping signal to the relay at the opposite end of the line.

Dumb Terminal See ASCII terminal.

DUTT (Direct Underreaching Transfer Trip) A communications-assisted tripping scheme. Detection of a Zone 1 fault at either end of a line causes tripping of the local circuit breaker as well as simultaneous transmission of a tripping signal to the relay at the opposite end of the line. The scheme is said to be underreaching because the Zone 1 relays at both ends of the line reach only 80 percent (typically) of the entire line length.

Dynamic Zone Selection The process by which the currents from the CTs are assigned to or removed from the differential calculations as a function of the Boolean value (logical 0 or logical 1) of a particular SELOGIC equation.

ECB (EtherCAT Communications Board) A circuit board mounted within the relay that has eight EtherCAT fiber connections for creating a TiDL (EtherCAT) system.

Echo The action of a local relay returning (echoing) the remote terminal permissive signal to the remote terminal when the local breaker is open or a weak infeed condition exists.

Echo Block Time Delay A time delay that blocks the echo logic after dropout of local permissive elements.

Echo Duration Time Delay A time delay that limits the duration of the echoed permissive signal.

ECTT (Echo Conversion to Trip) An element that allows a weak terminal, after satisfaction of specific conditions, to trip by converting an echoed permissive signal to a trip signal.

EEPROM Electrically Erasable Programmable Read-Only Memory. Nonvolatile memory where relay settings, event reports, SER records, and other nonvolatile data are stored.

EHV Extra high voltage. Voltages greater than 230 kV.

EIA-232 Electrical definition for point-to-point serial data communications interfaces, based on the standard EIA/TIA-232. Formerly known as RS-232.

EIA-485 Electrical standard for multidrop serial data communications interfaces, based on the standard EIA/TIA-485. Formerly known as RS-485.

Electrical Operating Time Time between trip or close initiation and an open-phase status change.

Electromechanical Reset Setting of the relay to match the reset characteristics of an electromechanical overcurrent relay.

End-Zone Fault A fault at the farthest end of a zone that a relay is required to protect.

Energy Metering Energy metering provides a look at imported power, exported power, and net usage over time; measured in MWh (megawatt-hours).

Equalize Mode A procedure where substation batteries are overcharged intentionally for a preselected time to bring all cells to a uniform output.

ESD (Electrostatic Discharge) The sudden transfer of charge between objects at different potentials caused by direct contact or induced by an electrostatic field.

EtherCAT (Ethernet for Control Automation Technology) An Ethernet-based network protocol for high-speed control networks that require real-time performance and ease of network configuration.

Ethernet A network physical and data link layer defined by IEEE 802.2 and IEEE 802.3.

Event History A quick look at recent relay activity that includes a standard report header; event number, date, time, and type; fault location; maximum fault phase current; active group at the trigger instant; and targets.

Event Report A text-based collection of data stored by the relay in response to a triggering condition, such as a fault or ASCII TRI command. The data show relay measurements before and after the trigger, in addition to the states of protection elements, relay inputs, and relay outputs each processing interval. After an electrical system fault, use event reports to analyze relay and system performance.

Event Summary A shortened version of stored event reports. An event summary includes items such as event date and time, event type, fault location, time source, recloser shot counter, pre-fault and fault voltages, currents, and sequence current, and MIRRORED BITS communications channel status (if enabled).

The relay sends an event report summary (if automessaging is enabled) to the relay serial port a few seconds after an event.

External Fuse Fuse external to a capacitor unit (usually mounted on the unit).

EXP Operator Math SELOGIC control equation operator that provides exponentiation.

F_TRIG Falling-edge trigger. Boolean SELOGIC control equation operator that triggers an operation upon logic detection of a falling edge.

Fail-Safe Refers to an output that is open during normal relay operation and closed when relay power is removed or if the relay fails. Configure alarm outputs for fail-safe operation.

Falling Edge Transition from logical 1 to logical 0.

Fast Hybrid Control Output A control output similar to, but faster than, the hybrid control output. The fast hybrid output uses an insulated-gate bipolar junction transistor (IGBT) to

interrupt (break) high inductive dc currents and to very rapidly make and hold the current until a metallic contact operates, at which time the IGBT turns off and the metallic contact holds the current. Unlike the hybrid control output, this output is not polarity-sensitive—reversed polarity causes no misoperations.

Fast Meter SEL binary serial port command used to collect metering data with SEL relays.

Fast Operate SEL binary serial port command used to perform control with SEL relays.

Fast Message SEL binary serial port protocol used for Fast SER, Fast Message Synchrophasors, and resistance temperature detector (RTD) communications.

Fault Detection Logic Logic that distinguishes between internal and external faults.

Fault-Type Identification Selection Logic the relay uses to identify balanced and unbalanced faults (FIDS).

FID Relay firmware identification string. Lists the relay model, firmware version and date code, and other information that uniquely identifies the firmware installed in a particular relay.

Firmware The nonvolatile program stored in the relay that defines relay operation.

Flash Memory A type of nonvolatile relay memory used for storing large blocks of nonvolatile data.

Flashover A disruptive discharge over the surface of a solid dielectric in a gas or liquid.

Float High The highest charging voltage supplied by a battery charger.

Float Low The lowest charging voltage supplied by a battery charger.

Free-Form Logic Custom logic creation and execution order.

Free-Form SELOGIC Control Equations Free-form relay programming that includes mathematical operations, custom logic execution order, extended relay customization, and automated operation.

FTP File Transfer Protocol.

Function In IEC 61850, task(s) performed by the substation automation system, i.e., by application functions. Generally, functions exchange data with other functions. Details are dependent on the functions involved.

Functions are performed by IEDs (physical devices). A function may be split into parts residing in different IEDs but communicating with each other (distributed function) and with parts of other functions. These communicating parts are called logical nodes.

Function Code A code that defines how you manipulate an object in DNP3 protocol.

Functional Component Portion of a UCA GOMSFE brick dedicated to a particular function including status, control, and descriptive tags.

Fundamental Frequency The component of the measured electrical signal with a frequency equal to the normal electrical system frequency, usually 50 Hz or 60 Hz. Generally used to differentiate between the normal system frequency and any harmonic frequencies present.

Fundamental Power Power calculated with components of the measured electrical signal with a frequency equal to the normal electrical system frequency, usually 50 Hz or 60 Hz.

Fuse Device that opens the circuit in which it is connected to provide overcurrent protection.

Fuseless Capacitor Bank A capacitor bank without internal or external fuses.

Global Settings General settings including those for relay and station identifiers, number of breakers, date format, phase rotation, nominal system frequency, enables, station dc monitoring, control inputs, settings group selection, data reset controls, frequency tracking, time and date management, and current and voltage source selection.

GOMSFE Generic Object Model for Substation and Feeder Equipment; a system for presenting and exchanging IED data.

GOOSE IEC 61850 Generic Object Oriented Substation Event. GOOSE objects can quickly and conveniently transfer status, controls, and measured values among peers on an IEC 61850 network.

GPS Global Positioning System. Source of position and high-accuracy time information.

Ground Directional Element Priority The order the relay uses to select directional elements to provide ground directional decisions (relay setting ORDER).

Ground Distance Element A mho or quadrilateral distance element the relay uses to detect faults involving ground along a transmission line.

Ground Fault Loop Impedance The impedance in a fault-caused electric circuit connecting two or more points through ground conduction paths.

Ground Overcurrent Elements Elements that operate by comparing a residual-ground calculation of the three-phase inputs with the residual overcurrent threshold setting. The relay asserts ground overcurrent elements when a relay residual current calculation exceeds ground current setting thresholds.

Ground Quadrilateral Distance Protection Ground distance protection consisting of a four-sided characteristic on an R-X diagram.

Ground Return Resistance Fault resistance that can consist of ground path resistance typically in tower footing resistance and tree resistance.

Grounded Capacitor Bank Capacitor bank with a solid connection to ground.

Guard-Present Delay A timer that determines the minimum time before the relay reinstates permissive tripping following a loss-of-channel condition in the DCUB communications-assisted tripping scheme (relay setting GARD1D).

GUI Graphical user interface.

Harmonics Frequencies that are multiples of the frequency of the power system; 100 Hz is the second harmonic of a 50 Hz power system.

Harmonic Restraint Method by which harmonics are used to desensitize differential elements, thereby avoiding misoperations during inrush conditions.

Harmonic Blocking Method by which harmonics are used to block differential elements thereby avoiding misoperations during inrush conditions.

Hexadecimal Address A register address consisting of a numeral with an “h” suffix or a “0x” prefix.

High-Resolution Data Capture Reporting of 3 kHz low-pass analog filtered data from the power system at each event trigger or trip at high-sample rates of 8000 samples/second, 4000 samples/second, 2000 samples/second, and 1000 samples/second.

High-Speed, High-Current Interrupting Control Output A control output similar to, but faster than, the hybrid control output. The high-speed, high-current interrupting output uses an insulated-gate bipolar junction transistor (IGBT) to interrupt (break) high inductive dc currents and to very rapidly make and hold the current until a metallic contact operates, at which time the IGBT turns off and the metallic contact holds the current. Unlike the hybrid control output, this output is not polarity-sensitive—reversed polarity causes no misoperations.

HMI Human-machine interface.

Homogeneous System A power system with nearly the same angle (less than $\angle 5°$ difference) for the impedance angles of the local source, the protected line, and the remote source.

HSR High-Availability Seamless Redundancy Protocol, as defined in IEC 62439-3 for network redundancy and seamless failover.

HV High voltage. System voltage greater than or equal to 100 kV and less than 230 kV.

Hybrid Control Output Contacts that use an insulated-gate bipolar junction transistor (IGBT) in parallel with a mechanical contact to interrupt (break) high inductive dc currents. The contacts can carry continuous current, while eliminating the need for heat sinking and providing security against voltage transients. These contacts are polarity-dependent and cannot be used to switch ac control signals.

IA, IB, IC Measured A-Phase, B-Phase, and C-Phase currents.

ICD File IEC 61850 IED Capability Description file. XML file that describes IED capabilities, including information on logical node and GOOSE support.

IEC 61850 Internationally standardized method of communications and integration conceived with the goal of supporting systems of multivendor IEDs networked together to perform protection, monitoring, automation, metering, and control.

IEC 61850-9-2 IEC 61850 standard that defines mapping of Sampled Values data onto ISO 8802-3.

IED Intelligent electronic device.

IEEE Institute of Electrical and Electronics Engineers, Inc.

IG Residual current, calculated from the sum of the phase currents. In normal, balanced operation, this current is very small or zero.

IGBT Insulated-gate bipolar junction transistor.

Inboard CT (bushing CT) Current transformer physically positioned in such a way that the CT is bypassed when the feeder is on transfer.

Independent Zone Timing The provision of separate zone timers for phase and ground distance elements.

Infinite Bus A constant-voltage bus.

Input Conditioning The establishment of debounce time and assertion level.

Instance A subdivision of a relay settings class. Group settings have several subdivisions (Group 1–Group 6), while the Global settings class has one instance.

Instantaneous Meter Type of meter data presented by the relay that includes the present values measured at the relay ac inputs. The word "Instantaneous" is used to differentiate these values from the measurements presented by the demand, thermal, energy, and other meter types.

Internal Fuse Fuse inside a capacitor unit.

IP Address An identifier for a computer or device on a TCP/IP network. Networks using the TCP/IP protocol route messages based on the IP address of the destination. The format of an IP address is a 32-bit numeric address written as four numbers separated by periods. Each number can be zero to 255. For example, 1.160.10.240 could be an IP address.

IRIG-B A time-code input that the relay can use to set the internal relay clock.

ISO 8802-3 Defines Ethernet for local area and metropolitan area networks.

Jitter Time, amplitude, frequency, or phase-related abrupt, spurious variations in duration, magnitude, or frequency.

L/R Circuit inductive/resistive ratio.

LAN Local Area Network. A network of IEDs interconnected in a relatively small area, such as a room, building, or group of buildings.

Latch Bits Nonvolatile storage locations for binary information.

LED Light-emitting diode. Used as indicators on the relay front panel.

Left-Side Value LVALUE. Result storage location of a SELOGIC control equation.

Line Impedance The phasor sum of resistance and reactance in the form of positive-sequence, negative-sequence, and zero-sequence impedances of the protected line.

LMD SEL distributed port switch protocol.

LN Operator Math SELOGIC control equation operator that provides natural logarithm.

Load Encroachment The load-encroachment feature allows setting of phase overcurrent elements and phase distance elements independent of load levels.

Local Bits The Relay Word bit outputs of local control switches that you access through the front panel of the relay. Local control switches replace traditional panel-mounted control switches.

Lockout Relay An auxiliary relay that prevents operation of associated devices until it is reset either electrically or by hand.

Logical 0 A false logic condition, dropped out element, or deasserted control input or control output.

Logical 1 A true logic condition, picked up element, or asserted control input or control output.

Logical Node In IEC 61850, the smallest part of a function that exchanges data. A logical node (LN) is an object defined by its data and methods. Each logical node represents a group of data (controls, status, measurements, etc.) associated with a particular function.

Loss of Channel Loss of guard and no permissive signal from communications gear in a DCUB (directional comparison unblocking scheme) for either two or three terminal lines.

Loss of Guard No guard signal from communications gear.

Loss of Potential Loss of one or more phase voltage inputs to the relay secondary inputs.

Low-Level Test Interface An interface that provides a means for interrupting the connection between the relay input transformers and the input processing module and allows inserting reduced-scale test quantities for relay testing.

MAC Address The Media Access Control (hardware) address of a device connected to a shared network medium, most often used with Ethernet networks.

Maintenance Testing Testing that confirms that the relay is measuring ac quantities accurately and verifies correct functioning of auxiliary equipment, scheme logic, and protection elements.

Math Operations Calculations for automation or extended protection functions.

Math Operators Operators that you use in the construction of math SELOGIC control equations to manipulate numerical values and provide a numerical base-10 result.

Maximum Dropout Time The maximum time interval following a change of input conditions between the deassertion of the input and the deassertion of the output.

Maximum/Minimum Meter Type of meter data presented by the relay that includes a record of the maximum and minimum of each value, along with the date and time that each maximum and minimum occurred.

Mechanical Operating Time Time between trip initiation or close initiation and the change in status of an associated circuit breaker auxiliary 52A normally open contacts.

Merging Unit A device that converts analog signals to digital signals and transmits them as IEC 61850-9-2 data.

Mho Characteristic A directional distance relay characteristic that plots a circle for the basic relay operation characteristic on an R-X diagram.

MIRRORED BITS Communications Patented relay-to-relay communications technique that sends internal logic status, encoded in a digital message, from one relay to the other. Eliminates the need for some communications hardware.

MMS Manufacturing messaging specification, a data exchange protocol used by UCA.

MOD Motor-operated disconnect.

Model Model of device (or component of a device) including the data, control access, and other features in UCA protocol.

Motor Running Time The circuit breaker motor running time. Depending on your particular circuit breaker, you can use the motor running time to monitor the charge time of the circuit breaker springs or the running time of the compressor motor.

MOV Metal-oxide varistor.

MVA Mega Volt-Ampere. Typical unit for expressing the capacity of a power transformer, e.g., 100MVA.

Negation Operator A SELOGIC control equation math operator that changes the sign of the argument. The argument of the negation operation is multiplied by –1.

Negative-Sequence A configuration of three-phase currents and voltages. The currents and voltages have equal magnitude and a phase displacement of 120°, and have clockwise phase rotation with current and voltage maxima that occur differently from that for positive-sequence configuration. If positive-sequence maxima occur as ABC, negative-sequence maxima occur as ACB.

Negative-Sequence Current Supervision Pickup An element allowed to operate only when a negative-sequence current exceeds a threshold.

Negative-Sequence Directional Element An element that provides directivity by the sign, plus or minus, of the measured negative-sequence impedance.

Negative-Sequence Impedance Impedance of a device or circuit that results in current flow with a balanced negative-sequence set of voltage sources.

Negative-Sequence Overcurrent Elements Elements that operate by comparing a negative-sequence calculation of the three-phase secondary inputs with negative-sequence overcurrent setting thresholds. The relay asserts these elements when a relay negative-sequence calculation exceeds negative-sequence current setting thresholds.

Negative-Sequence Voltage-Polarized Directional Element These directional elements are 32QG and 32Q. 32QG supervises the ground distance elements and residual directional-overcurrent elements; 32Q supervises the phase distance elements.

NEMA National Electrical Manufacturers' Association.

Neutral Impedance An impedance from neutral to ground on a device such as a generator or transformer.

No Current/Residual Current Circuit Breaker Failure Protection Logic Logic for detecting and initiating circuit breaker failure protection with a logic transition, or when a weak source drives the fault or a high-resistance ground fault occurs.

Nondirectional Start A blocking signal provided by nondirectional-overcurrent elements to a remote terminal used in DCB communications-assisted tripping schemes. The nondirectional start elements start sending the block signal.

Nonhomogeneous System A power system with a large angle difference (>5° difference) for the impedance angles of the local source, the protected line, and the remote source.

Nonvolatile Memory Relay memory that persists over time to maintain the contained data even when the relay is de-energized.

NOT Operator A logical operator that produces the inverse value.

Operate Current Differential current (vector sum) between current(s) that enter a point, and current(s) that leave that point.

OR Operator Logical OR. A Boolean SELOGIC control equation operator that compares two Boolean values and yields either a logical 1 if either compared Boolean value is logical 1 or a logical 0 if both compared Boolean values are logical 0.

OSI Open Systems Interconnect. A model for describing communications protocols. Also an ISO suite of protocols designed to this model.

Out-of-Step Blocking Blocks the operation of phase distance elements during power swings.

Out-of-Step Tripping Trips the circuit breaker(s) during power swings.

Outboard CT Current transformer physically positioned in such a way that the CT remains in circuit when the feeder is on transfer.

Over/Underpower Elements Elements that calculate the forward and reverse power flow and compare the result against settable thresholds.

Over/Undervoltage Elements Elements that calculate the system voltage and compare the result against settable thresholds.

Over/Underfrequency Elements Elements that calculate the power system frequency and compare the result against settable thresholds.

Overlap Configuration Configuration of the tie-breaker protection whereby the area between the tie-breaker CTs are part of two bus-zones, i.e., a fault between the tie-breaker CTs is common to two bus-zones.

Override Values Test values you enter in Fast Meter, DNP3, and communications card database storage.

Parentheses Operator Math operator. Use paired parentheses to control the execution of operations in a SELOGIC control equation.

PC Personal computer.

Peak Demand Metering Maximum demand and a time stamp for phase currents, negative-sequence and zero-sequence currents, and powers. The relay stores peak demand values and the date and time these occurred to nonvolatile storage once per day, overwriting the previously stored value if the new value is larger. Should the relay lose control power, the relay restores the peak demand information saved at 23:50 hours on the previous day.

Phase Distance Element A mho distance element the relay uses to detect phase-to-phase and three-phase faults at a set reach along a transmission line.

Phase Overcurrent Element Elements that operate by comparing the phase current applied to the secondary current inputs with the phase overcurrent setting. The relay asserts these elements when any combination of the phase currents exceeds phase current setting thresholds.

Phase Rotation The sequence of voltage or current phasors in a multiphase electrical system. In an ABC phase rotation system, the B-Phase voltage lags the A-Phase voltage by 120°, and the C-Phase voltage lags B-Phase voltage by 120°. In an ACB phase rotation system, the C-Phase voltage lags the A-Phase voltage by 120°, and the B-Phase voltage lags the C-Phase voltage by 120°.

Phase Selection Ability of the relay to determine the faulted phase or phases.

Pickup Time The time measured from the application of an input signal until the output signal asserts. You can set the time, as in the case of a logic variable timer, or the pickup time can be a result of the characteristics of an element algorithm, as in the case of an overcurrent element pickup time.

Pinout The definition or assignment of each electrical connection at an interface. Typically refers to a cable, connector, or jumper.

PMU Phasor measurement unit. A device that measures and publishes synchrophasor data.

Polarizing Memory A circuit that provides a polarizing source for a period after the polarizing quantity has changed or gone to zero.

Pole Discrepancy A difference in the open/closed status of circuit breaker poles. The relay continuously monitors the status of each circuit breaker pole to detect open or close conditions among the three poles.

Pole-Open Logic Logic that determines the conditions that the relay uses to indicate an open circuit breaker pole.

Pole Scatter Deviation in operating time between pairs of circuit breaker poles.

Port Settings Communications port settings such as Data Bits, Speed, and Stop Bits.

Positive-Sequence A configuration of three-phase currents and voltages. The currents and voltages have equal magnitude and a phase displacement of 120°. With conventional rotation in the counter-clockwise direction, the positive-sequence current and voltage maxima occur in ABC order.

Positive-Sequence Current Restraint Factor, a2 This factor compensates for highly unbalanced systems with many untransposed lines and helps prevent misoperation during CT saturation. The a2 factor is the ratio of the magnitude of negative-sequence current to the magnitude of positive-sequence current (I2/I1).

Positive-Sequence Current Supervision Pickup An element that operates only when a positive-sequence current exceeds a threshold.

Positive-Sequence Impedance Impedance of a device or circuit that results in current flow with a balanced positive-sequence set of voltage sources.

POTT (Permissive Overreaching Transfer Trip) A communications-assisted line protection scheme. At least two overreaching protective relays must receive a permissive signal from the other terminal(s) before all relays trip and isolate the protected line.

Power Factor The cosine of the angle by which phase current lags or leads phase voltage in an ac electrical circuit. Power factor equals 1.0 for power flowing to a pure resistive load.

PPS Pulse per second from a GPS receiver. Previous relays had a TIME 1k PPS input.

Primitive Name The predefined name of a quantity within the relay.

Process Bus Network bus for IED communication at the bay level.

Protection and Automation Separation Segregation of protection and automation processing and settings.

Protection Settings Group Individual scheme settings for as many as six different schemes (or instances).

Protection-Disabled State Suspension of relay protection element and trip/close logic processing and de-energization of all control outputs.

Protection Zone (also see Bus-Zone) Area of protection formed by a minimum of one bus-zone. A protection zone can include more than one bus-zone. For example, merging two bus-zones results in a single protection zone. When no bus-zones are merged, a protection zone and a bus-zone have the same meanings.

PRP Parallel Redundancy Protocol, as defined in IEC 62439-3 for network redundancy and seamless failover.

PT Potential transformer. Also referred to as a voltage transformer or VT.

PTP Precision Time Protocol, as defined in IEEE 1588 for high-accuracy clock synchronization.

PTR Potential transformer ratio.

Quadrilateral Characteristic A distance relay characteristic on an R-X diagram consisting of a directional measurement, reactance measurement, and two resistive measurements.

Qualifier Code Specifies type of range for DNP3 objects. With the help of qualifier codes, DNP3 master devices can compose the shortest, most concise messages.

R_TRIG Rising-edge trigger. Boolean SELOGIC control equation operator that triggers an operation upon logic detection of a rising edge.

RAM Random Access Memory. Volatile memory where the relay stores intermediate calculation results, Relay Word bits, and other data.

Reactance Reach The reach of a distance element in the reactive (X) direction in the R-X plane.

Real Power Power that produces actual work. The portion of apparent power that is real, not imaginary.

Reclose The act of automatically closing breaker contacts after a protective relay trip has opened the circuit breaker contacts and interrupted current through the breaker.

Relay Word Bit A single relay element or logic result. A Relay Word bit can equal either logical 1 or logical 0. Logical 1 represents a true logic condition, picked up element, or asserted control input or control output. Logical 0 represents a false logic condition, dropped out element, or deasserted control input or control output. Use Relay Word bits in SELOGIC control equations.

Remapping The process of selecting data from the default map and configuring new indices to form a smaller data set optimized to your application.

Remote Bit A Relay Word bit with a state that is controlled by serial port commands, including the **CONTROL** command, a binary Fast Operate command, DNP3 binary output operation, or a UCA control operation.

Report Settings Event report and Sequential Events Recorder (SER) settings.

Residual Current The sum of the measured phase currents. In normal, balanced operation, this current is very small or zero.

Residual Directional Overcurrent Element A residual overcurrent element allowed to operate in only the forward or reverse direction.

Residual Overcurrent Protection Overcurrent protection that operates at conditions exceeding a threshold of system unbalance ($3I_0 = I_A + I_B + I_C$).

Resistance Blinder An operate boundary in the resistive direction of a ground quadrilateral distance element.

Resistive Reach The reach of a distance element in the resistive (R) direction in the R-X plane.

Restraint Current Sum of the absolute values of current(s) entering a point, and leaving that point. Used as basis to calculate the reference (setting) value for differential elements.

Restricted Earth Fault Differential element that augments the phase differential element by providing sensitive protection against ground faults close to the neutral of a grounded-wye transformer. The element compares the phase angle of zero-sequence quantities from the transformer neutral with zero-sequence quantities from as many as five line CTs.

Retrip A subsequent act of attempting to open the contacts of a circuit breaker after the failure of an initial attempt to open these contacts.

Reverse Fault A fault operation behind a relay terminal.

Rising Edge Transition from logical 0 to logical 1, or the beginning of an operation.

RMS Root-mean-square. This is the effective value of the current and voltage measured by the relay, accounting for the fundamental frequency and higher-order harmonics in the signal.

Rolling Demand A sliding time-window arithmetic average in demand metering.

RTC Real-Time Control. A method for exchanging synchrophasor control data.

RTD Resistance Temperature Detector.

RTU Remote Terminal Unit.

RXD Received data.

SCADA Supervisory control and data acquisition.

SCD File IEC 61850 Substation Configuration Description file. XML file that contains information on all IEDs within a substation, communications configuration data, and a substation description.

SCL IEC 61850 Substation Configuration Language. An XML-based configuration language that supports the exchange of database configuration data among different software tools that can be from different manufacturers. There are four types of SCL files used within IEC 61850: CID, ICD, SCD, and SSD.

SDN Software-defined networking.

SEL-TMU A merging unit used in TiDL (T-Protocol) systems.

Selective Protection Disabling A feature that allows for selectively disabling protection elements that are impacted by a loss of DSS data and allow non-impacted protection functions to remain operational.

Self-Description A feature of GOMSFE in the UCA2 protocol. A master device can request a description of all of the GOMSFE models and data within the IED.

Self-Test A function that verifies the correct operation of a critical device subsystem and indicates detection of an out-of-tolerance condition. The relay has self-tests that validate the relay power supply, microprocessor, memory, and other critical systems.

SELOGIC Control Equation A relay setting that allows you to control a relay function (such as a control output) using a logical combination of relay element outputs and fixed logic outputs.

SELOGIC Expression Builder A rules-based editor within the QuickSet software program for programming SELOGIC control equations.

SELOGIC Math Variables Math calculation result storage locations.

Sequencing Timers Timers designed for sequencing automated operations.

Sequential Events Recorder A relay function that stores a record of the date and time of each assertion and deassertion of every Relay Word bit in a list that you set in the relay. A Sequential Events Recorder (SER) provides a useful way to determine the order and timing of events of a relay operation.

SER Sequential Events Recorder or the relay serial port command to request a report of the latest 1000 sequential events.

Series-Compensated Line A power line on which the addition of series capacitance compensates for excessive inductive line impedance.

Settle/Settling Time Time required for an input signal to result in an unvarying output signal within a specified range.

SFP Small form-factor pluggable transceiver module.

Shot Counter A counter that records the number of times a recloser attempts to close a circuit breaker.

Shunt Admittance The admittance resulting from the presence of a device in parallel across other devices or apparatus that diverts some current away from these devices or apparatus.

Shunt Capacitance The capacitance between a network connection and any existing ground.

Shunt Current The current that a parallel-connected high-resistance or high-impedance device diverts away from devices or apparatus.

SIN Operator Operator in math SELOGIC control equations that provides the sine function.

Single-CT Application Tie breaker with only one CT available for busbar protection.

Single-Pole Trip A circuit breaker trip operation that occurs when one pole of the three poles of a circuit breaker opens independently of the other poles.

Single Relay Application (Bus Protection) Stations with as many as 21 per-phase CTs require only one SEL-487B. Stations with more than 21 and as many as 54 per-phase CTs require three SEL-487B relays.

SIR Source-to-line impedance ratio.

SNTP Simple Network Time Protocol. A network protocol for time synchronization.

SOTF (Switch-Onto-Fault Protection Logic) Logic that provides tripping if a circuit breaker closes into a zero-voltage bolted fault, such as would happen if protective grounds remained on the line following maintenance.

Source Impedance The impedance of an energy source at the input terminals of a device or network.

SQRT Operator Math SELOGIC control equation operator that provides square root.

SSD File IEC 61850 System Specification Description file. XML file that describes the single-line diagram of the substation and the required logical nodes.

Stable Power Swing A change in the electrical angle between power systems. A control action can return the angular separation between systems to less than the critical angle.

Station Bus Network bus for IED communication between the bay and station levels.

Status Failure A severe out-of-tolerance internal operating condition. The relay issues a status failure message and enters a protection-disabled state.

Status Warning Out-of-tolerance internal operating conditions that do not compromise relay protection, yet are beyond expected limits. The relay issues a status warning message and continues to operate.

Strong Password A mix of valid password characters in a six-character combination that does not spell common words in any portion of the password. Valid password characters are numbers, upper- and lowercase alphabetic characters, “.” (period), and “-” (hyphen).

Subnet Mask The subnet mask divides the local node IP address into two parts, a network number and a node address on that network. A subnet mask is four bytes of information and is expressed in the same format as an IP address.

Subsidence Current See CT subsidence current.

SV Sampled Values, as defined in Part 9-2 of IEC 61850.

SV Channel A single-phase voltage or current transmitted as an integer value containing its magnitude and phase angle.

SV Stream Multicast packets containing a fixed data set transmitted periodically. In the case of 9-2LE, SV streams contain four currents and four voltages and are transmitted at a rate of 80 samples per cycle.

Synch Reference A phasor the relay uses as a polarizing quantity for synchronism-check calculations.

Synchronism-Check Verification by the relay that system components operate within a preset frequency difference and within a preset phase angle displacement between voltages.

Synchronized Phasor A phasor calculated from data samples using an absolute time signal as the reference for the sampling process. The phasors from remote sites have a defined common phase relationship. Also known as Synchrophasor.

TAP Full-load secondary current that the relay uses to convert ampere values to dimensionless per-unit values.

TAP Tappings on some power transformer windings, used for voltage/reactive power flow control.

TAP (Point) Point in each phase that divides the capacitor bank into two parts.

TCB A circuit board mounted within the relay that has eight T-Protocol fiber-optic connections for creating a TiDL system.

Telnet An IP for exchanging terminal data that connects a computer to a network server and allows control of that server and communication with other servers on the network.

Terminal-to-Bus-Zone Connection Variable SELOGIC variable stating the conditions when the relay considers the current input from a particular terminal in the differential calculations of a particular bus-zone.

Terminal Emulation Software Software that can be used to send and receive ASCII text messages and files via a computer serial port.

Thermal Demand Thermal demand is a continuous exponentially increasing or decreasing accumulation of metered quantities (used in demand metering).

Thermal Withstand Capability The capability of equipment to withstand a predetermined temperature value for a specified time.

Three-Phase Fault A fault involving all three phases of a three-phase power system.

Three-Pole Trip A circuit breaker operation that occurs when the circuit breaker opens all three poles at the same time.

Three-Relay Application Stations with more than 21 and as many as 54 per-phase CTs require three SEL-487B relays. Stations with as many as 21 per-phase CTs require only one SEL-487B.

Tie Breaker See Bus Coupler and Bus Sectionalizer.

Time Delay on Pickup The time interval between initiation of a signal at one point and detection of the same signal at another point.

Time Dial A control that governs the time scale of the time-overcurrent characteristic of a relay. Use the time-dial setting to vary relay operating time.

Time-Delayed Tripping Tripping that occurs after expiration of a predetermined time.

Time-Domain Link (TiDL) A technology that uses TiDL merging units to provide CT and PT inputs that are communicated to the relay by using direct fiber-optic connections.

Time Error A measurement of how much time an ac powered clock would be ahead or behind a reference clock, as determined from system frequency measurements.

Time-Overcurrent Element An element that operates according to an inverse relationship between input current and time, with higher current causing faster relay operation.

Time Quality An indication from a GPS clock receiver that specifies the maximum error in the time information. Defined in IEEE C37.118.

Torque Control A method of using one relay element to supervise the operation of another.

Total Clearing Time The time interval from the beginning of a fault condition to final interruption of the circuit.

Tower Footing Resistance The resistance between true ground and the grounding system of a tower.

Transformer Impedance The resistive and reactive parameters of a transformer looking in to the transformer primary or secondary windings. Use industry accepted open-circuit and short-circuit tests to determine these transformer equivalent circuit parameters.

Tree Resistance Resistance resulting from a tree in contact with a power line.

TVE Total Vector Error. A measurement of accuracy for phasor quantities that combines magnitude and angle errors into one quantity. Defined in IEEE C37.118.

TXD Transmitted data.

UCA2 Utility Communications Architecture. A network-independent protocol suite that serves as an interface for individual IEDs.

UCA 61850-9-2LE Guideline for implementation of IEC 61850-9-2 created by the UCAIug to facilitate interoperability. The guideline can be considered a subset, or profile, of the IEC 61850-9-2 standard, which defines requirements for certain parts of the standard, including data mode implementation, data set descriptions, time synchronization, transfer rates, and sampling rates. Also referred to as 9-2LE.

UCAIug Utility Communications Architecture International Users Group.

Unbalanced Current Element Element that calculates the percentage difference between the three phase currents.

Unbalanced Fault All faults that do not include all three phases of a system.

Unbuffered Report IEC 61850 IEDs can issue immediate unbuffered reports of internal events (caused by trigger options data-change, quality-change, and data-update) on a "best efforts" basis. If no association exists, or if the transport data flow is not fast enough to support it, events may be lost.

Unconditional Tripping Protection element tripping that occurs apart from conditions such as those involving communication, switch-onto-fault logic, etc.

Ungrounded Capacitor Bank Capacitor bank with no intentional connection to ground. (A bank with a PT connected between the bank's neutral point and ground is considered ungrounded.)

Unstable Power Swing A change in the electrical angle between power systems for which a control action cannot return the angular separation between systems to an angle less than the critical angle.

Untransposed Line A transmission line with phase conductors that are not regularly transposed. The result is an unbalance in the mutual impedances between phases.

User ST Region in GOOSE for user-specified applications.

VA, VB, VC Measured A-Phase-to-neutral, B-Phase-to-neutral, and C-Phase-to-neutral voltages.

VAB, VBC, VCA Measured or calculated phase-to-phase voltages.

VG Residual voltage calculated from the sum of the three phase-to-neutral voltages, if connected.

Virtual Terminal Connection A mechanism that uses a virtual serial port to provide the equivalent functions of a dedicated serial port and a terminal.

Volatile Storage A storage device that cannot retain data following removal of relay power.

Voltage Compensation Adjustment of the voltage signals to nullify any standing unbalance voltage.

VT Voltage transformer. Also referred to as a potential transformer or PT.

Warm Start The reset of a running system without removing and restoring power.

Weak Infeed Logic Logic that permits rapid tripping for internal faults when a line terminal has insufficient fault current to operate protective elements.

Winding Transformer winding, synonymous with “terminal.”

Wye A phase-to-neutral connection of circuit elements, particularly voltage transformers or loads. To form a wye connection using transformers, connect the nonpolarity side of each of three voltage transformer secondaries in common (the neutral), and take phase-to-neutral voltages from each of the remaining three leads. When properly phased, these leads represent the A-Phase-, B-Phase-, and C-Phase-to-neutral voltages. This connection is frequently called ‘four-wire wye,’ alluding to the three phase leads plus the neutral lead.

XML Extensible Markup Language. This specification developed by the W3C (World Wide Web Consortium) is a pared-down version of SGML designed especially for web documents. It allows designers to create their own customized tags, enabling the definition, transmission, validation, and interpretation of data among applications and organizations.

Zero-Sequence A configuration of three-phase currents and voltages with currents and voltages that occur simultaneously, are always in phase, and have equal magnitude ($3I_0 = I_A + I_B + I_C$).

Zero-Sequence Compensation Factor A factor based on the zero-sequence and positive-sequence impedance of a line that modifies a ground distance element to have the same reach as a phase distance element.

Zero-Sequence Impedance Impedance of a device or circuit resulting in current flow when a single voltage source is applied to all phases.

Zero-Sequence Mutual Coupling Zero-sequence current in an unbalanced circuit in close proximity to a second circuit induces voltage into the second circuit. When not controlled by protection system design and relay settings, this situation can cause improper operation of relays in both systems.

Zero-Sequence Overcurrent Element Overcurrent protection that operates at conditions exceeding a threshold of system unbalance.

Zero-Sequence Voltage-Polarized Directional Element
An element that provides directionality by the sign, plus or minus, of the measured zero-sequence impedance.

Z-Number
That portion of the relay FID string that identifies the proper QuickSet software relay driver version and HMI driver version when creating or editing relay settings files.

Zone Time Delay
Time delay associated with the forward or reverse step distance and zone protection.