

Test BC-HLR-31

"Ao detectar um erro, o módulo B/C deve fazer um log com estado onde erro aconteceu e o motivo para Auditoria"

Procedimento realizado

1. O B/C deve estar ligado, em modo de manutenção
2. O GSE deve estar logado, conectado no wifi do B/C e o operador deve ter escolhido uma imagem para envio clicando em transferir
3. Deve-se abrir o monitor serial e verificar o log dos erros e motivos:
Erro Validação do PN - Compatibilidade: enviar software pelo GSE com PN não incluso na lista do B/C

Resultados obtidos

Log de erro ao testar compatibilidade de PN de software

The screenshot shows a software window with the following components:

- Logs:** A large text area displaying a log of events. The log starts with "I (17116) auth: Iniciando handshake de autenticação" and continues through various TFTP and ARINC messages related to file transfers.
- Imagen:** A section with a label "Imagen:" and a button "Nenhuma imagem selecionada".
- Progresso:** A progress bar at the bottom of the main log area.
- Buttons:** At the bottom right are three buttons: "Transferir" (Transfer), "Selecionar Imagem" (Select Image), and "Sair" (Exit).