

Test GSE-HLR-15

" Autenticação e Autorização para Acesso ao Sistema

O sistema deve permitir acesso ao software do GSE somente após o operador ser autenticado e autorizado; caso contrário, o sistema deve negar o acesso ao sistema.."

Procedimento realizado

1. Após abrir o software, tentou-se acessar o ambiente restrito de uploading com senhas e usuários diversos incorretos

Resultados obtidos

O software bloqueou corretamente a entrada

The screenshot shows a software application window for Embraer GSE-HLR-15. At the top is a blue header bar with the Embraer logo on the left and standard window controls (minimize, maximize, close) on the right. Below the header is a large blue Embraer logo. The main area contains a login form with two text input fields: the first is labeled 'operador' and the second is a password field represented by a series of dots. Below the inputs, a red error message reads 'Usuário ou senha inválidos.' (User or password invalid). At the bottom is a large blue rectangular button with the word 'Entrar' (Enter) in white text.