# 目录

| 1 | 概述     | 2                           |
|---|--------|-----------------------------|
|   | 1.1    | http 请求格式 (URL)             |
|   | 1.2    | TCP/UDP 请求格式 (socket)2      |
| 2 | API Co | mmand Reference3            |
|   | 2.1    | /cgi-bin/device_status.cgi3 |
|   | 2.2    | /cgi-bin/viewOperate.cgi4   |
|   | 2.3    | /cgi-bin/motion.cgi5        |
|   | 2.4    | /cgi-bin/network.cgi6       |
|   | 2.5    | /cgi-bin/sdcard.cgi         |
|   | 2.6    | /cgi-bin/device_info.cgi8   |
|   | 2.7    | /cgi-bin/deviceCtrl.cgi8    |

#### 1 概述

#### 1.1 http 请求格式 (URL)

```
Format:
http://<camera host>/<CGI-URL>?<CMD_ID>=<command>&<parameter>=<value>

Example: http://192.168.2.12:80/cgi-bin/device_status.cgi?CMD_ID=setCameraPowerStatus& VALUES =on

Response:
    {
        "CMD_ID":"setCameraPowerStatus",
        "CODE":"0",
        "MSG":"",
        "VALUES":"on"
    }
        й明: CMD_ID : 为请求的命令;
        CODE : 0表示成功,其他表示失败;
        MSG : 失败返回的描述,如:不支持这个命令;
        VALUES : 请求设置成功的值;
```

#### 1.2 TCP/UDP 请求格式 (socket)

```
DataType:
json

Request:
{"CMD_ID":"setCameraPowerStatus"," VALUES ":"on/off"}

Response:
{
    "CMD_ID":"setCameraPowerStatus",
    "CODE":"0",
    "MSG":"",
    "VALUES":"on"
}

数据格式说明:

4 bytes(type) | 4bytes(date length) | data
```

type 为数据类型,类型为 int,1 表示 data 为 json 的数据格式; 2 表示 data 为 audio 数据; date length 为 int 类型,表示后面携带的数据的长度; data 为传输携带的数据。

## 2 API Command Reference

#### 2.1 /cgi-bin/device\_status.cgi

Get or Set Device Status and Information

Request method: GET/POST/SOCKET

| command                 | parameter | value                | response   | description                            |
|-------------------------|-----------|----------------------|--|--|
| set Camera Power Status | VALUES    | on or off            | {     "CMD_ID":"setCameraPowerStatus",     "CODE":"0",     "MSG":"",     "VALUES":"" }               | Setting Camera Power on or off         |
| getCameraPowerStatus    | none      | none                 | {     "CMD_ID":"getCameraPowerStatus",     "CODE":"0",     "MSG":"",     "VALUES":"on/off" }         |  |
| setPowerLedStatus       | VALUES    | enable or<br>disable | {     "CMD_ID":"setPowerLedStatus",     "CODE":"0",     "MSG":"",     "VALUES":"" }                  | Setting Power Led Status               |
| getPowerLedStatus       | none      | none                 | {     "CMD_ID":"getPowerLedStatus",     "CODE":"0",     "MSG":"",     "VALUES":"enable/disable" }    |  |
| setMicStatus            | VALUES    | enable or<br>disable | {     "CMD_ID":"setMicStatus",     "CODE":"0",     "MSG":"",     "VALUES":"" }                       | Setting Mic Status                     |
| getMicStatus            | none      | none                 | {     "CMD_ID":"getMicStatus",     "CODE":"0",     "MSG":"",     "VALUES":"enable/disable" }         |  |
| setInfraredLedStatus    | VALUES    | enable or<br>disable | {     "CMD_ID":"setInfraredLedStatus",     "CODE":"0",     "MSG":"",     "VALUES":"" }               | Setting Infrared Lamp mode             |
| getInfraredLedStatus    | none      | none                 | {     "CMD_ID":"getInfraredLedStatus",     "CODE":"0",     "MSG":"",     "VALUES":"enable/disable" } |  |
| getFirewareVersion      | none      | none                 | {     "CMD_ID":"getFirewareVersion",     "CODE":"0",     "MSG":"",     "VALUES":" v3.0.0.0" }        | Get Device Current Fireware<br>Version |

| setFirewareUpgrade | VALUES | downloadUrl | {     "CMD_ID":" setFirewareUpgrade ",     "CODE":"0",     "MSG":"",     "VALUES":" " } | downloadUrl 为 APP 通过 OTA 服务器查询到的最新固件下载地址 |
|--------------------|--------|-------------|---|--|
|--------------------|--------|-------------|---|--|

## 2.2 /cgi-bin/viewOperate.cgi

Get or Set camera stream parameter

Request method: GET/POST/SOCKET

| command         | parameter | value                | response  | description   |
|-----------------|-----------|----------------------|---|---|
| setflipVertical | VALUES    | enable or<br>disable | {     "CMD_ID":"setflipVertical",     "CODE":"0",     "MSG":"",     "VALUES":"" }               | Mirror flip Vertical                                  |
| getflipVertical | none      | none                 | {     "CMD_ID":"getflipVertical",     "CODE":"0",     "MSG":"",     "VALUES":"enable/disable" } |   |
| setResolution   | VALUES    | H,M,L                | {     "CMD_ID":"setResolution",     "CODE":"0",     "MSG":"",     "VALUES":"" }                 | H 高清: 1920*1080P<br>M 标清: 1080*720P<br>L 普通: 640*480P |
| getResolution   | none      | none                 | {     "CMD_ID":"getResolution",     "CODE":"0",     "MSG":"",     "VALUES":"H/M/L"              |   |

## 2.3 /cgi-bin/motion.cgi

Get or Set motion parameter

Request method: GET/POST/SOCKET

| command              | parameter | value                | response  | description   |
|----------------------|-----------|----------------------|---|---|
| setMotion            | VALUES    | enable or<br>disable | {     "CMD_ID":"setMotion",     "CODE":"0",     "MSG":"",     "VALUES":"" }                 | Set motion detect status                                    |
| getMotion            | none      | none                 | {     "CMD_ID":"getMotion",     "CODE":"0",     "MSG":"",     "VALUES":"enable/disable" }   | Get motion detect status                                    |
| setMotionSensitivity | VALUES    | L,M,H                | {     "CMD_ID":"setMotionSensitivity",     "CODE":"0",     "MSG":"",     "VALUES":"" }      | 高、中、低三个灵敏度  |
| getMotionSensitivity | none      | none                 | {     "CMD_ID":"getMotionSensitivity",     "CODE":"0",     "MSG":"",     "VALUES":"L/M/H" } |   |
| set Motion Frequence | VALUES    | L,M,H                | {     "CMD_ID":"setMotionFrequence",     "CODE":"0",     "MSG":"",     "VALUES":"" }        | Setting motion frequence<br>level                           |
| getMotionFrequence   | none      | none                 | {     "CMD_ID":"getMotionFrequence",     "CODE":"0",     "MSG":"",     "VALUES":"L/M/H" }   |   |
| setMotionTime        | VALUES    | 0:24                 | {     "CMD_ID":"setMotionTime",     "CODE":"0",     "MSG":"",     "VALUES":"" }             | 0:24表示设置为0到24小时,<br>12:12表示12时这个小时,<br>12:15表示12时到15时这个时间段。 |
| getMotionTime        | none      | none                 | {     "CMD_ID":"getMotionTime",     "CODE":"0",     "MSG":"",     "VALUES":"0:24" }         |   |

## 2.4 /cgi-bin/network.cgi

#### Get network information

Request method: GET/POST/SOCKET

| command           | parameter | value | response  | description                     |
|-------------------|-----------|-------|---|---------------------------------|
| get Wireless Info | none      | none  | {  "CMD_ID":"getWirelessInfo",  "CODE":"0",  "MSG":"",  "VALUES":{  "ssid":"WIFIAP",  "IPv4":"192.168.1.5",  "macaddr":"AA:BB:CC:DD:EE:FF"  } | 获取设备网络信息,如果其中某个值不存在,则返回值<br>填空。 |

## 2.5 /cgi-bin/sdcard.cgi

Get sdcard status and sdcard operation

Request method: GET/POST/SOCKET

| Reque           | est method: GET/POS | r/socket   |  |   |
|-----------------|---------------------|--|--|---|
| command         | parameter           | value  | response   | description   |
| getSDCardStatus | none                | none   | {     "CMD_ID":"getSDCardStatus",     "CODE":"0",     "MSG":"",     "VALUES":{         "status":"mount/unmount",         "totalsize":"16GB",         "available":"5GB"     } } | status 表示状态;<br>totalsize 表示总共大<br>小;available 表示可<br>用大小。                      |
| formatting      | none                | none   | {  "CMD_ID":"formatting",  "CODE":"0",  "MSG":"",  "VALUES":"" }   | Format sdcard   |
| stopSDCard      | none                | none   | {     "CMD_ID":"stopSDCard",     "CODE":"0",     "MSG":"",     "VALUES":"" }   | UnMount sdcard  |
| mountSDCard     | none                | none   | {     "CMD_ID":"mountSDCard",     "CODE":"0",     "MSG":"",     "VALUES":"" }  | Mount sdcard  |
|                 | orderBy             |  | {  "CMD_ID":"getFileList",   | 排序,<br>time/name/size   |
|                 | start               |  | "CODE":"0",<br>"MSG":"",   | 返回分页的起始索<br>引   |
| getFileList     | count               | 1、 http 请求:  http://ip:port//url?orderBy=time&  start=1&count=100; 2、 socket 请求:  {"orderBy":"time","start":1,"count  ":100} | "VALUES": [  | 分页每一页返回的数量。举例,文件夹数量为 50,如果需要分两页返回,第一页:start=1,count=25<br>第二页,start=26,count=25 |

## 2.6 /cgi-bin/device\_info.cgi

Get all device information

Request method: GET/POST/SOCKET

| command       | parameter | value | response  | description |
|---------------|-----------|-------|---|-------------|
| getDeviceInfo | none      | none  | {     "CMD_ID":" getDeviceInfo ",     "CODE":"0",     "MSG":"",     "VALUES":{         "powerStatus":"enable/disable", //设置状态灯开关         "flipVertical":"enable/disable", //极衰克风         "infraredLedStatus":"enable/disable", //核效红外灯         "motion":"enable/disable", //移动侦测         "motionFrequence":"L/M/H", //报警灵敏度         "motionFrequence":"L/M/H", //报警频率         "motionTime":"0:24", //报警时间         "resolution":"H/M/L", //解析度         "firewareVersion":"v3.0.0.0", //设备当前固件版本号         "SDCardStatus":{ //SDCard 状态         "status":"mount/unmount",         "totalsize":"16GB",         "available":"5GB"         },         "wirelessInfo":{ //wifi 信息         "ssid":"WIFIAP",         "IPv4":"192.168.1.5",         "macaddr":"AA:BB:CC:DD:EE:FF"         }     } } | 统一获取设备相关信息  |

## 2.7 /cgi-bin/deviceCtrl.cgi

| command    | parameter | value | response                | description                     |
|------------|-----------|-------|-------------------------|---------------------------------|
| move_up    | none      | none  | {                       | Control device move up step     |
|            |           |       | "CMD_ID":"move_up ",    |                                 |
|            |           |       | "CODE":"0",             |                                 |
|            |           |       | "MSG":"",               |                                 |
|            |           |       | "VALUES":""             |                                 |
|            |           |       | }                       |                                 |
| move_down  | none      | none  | {                       | Control device move down step   |
|            |           |       | "CMD_ID":"move_down ",  |                                 |
|            |           |       | "CODE":"0",             |                                 |
|            |           |       | "MSG":"",               |                                 |
|            |           |       | "VALUES":""             |                                 |
|            |           |       | }                       |                                 |
| move_left  | none      | none  | {                       | Control device move left step   |
|            |           |       | "CMD_ID":"move_left ",  |                                 |
|            |           |       | "CODE":"0",             |                                 |
|            |           |       | "MSG":"",               |                                 |
|            |           |       | "VALUES":""             |                                 |
|            |           |       | }                       |                                 |
| move_right | none      | none  | {                       | Control device move rights step |
|            |           |       | "CMD_ID":"move_right ", |                                 |
|            |           |       | "CODE":"0",             |                                 |
|            |           |       | "MSG":"",               |                                 |
|            |           |       | "VALUES":""             |                                 |
|            |           |       | }                       |                                 |