

System Test of Airflow

Scope This Job Instruction (JI) describes the process for System Test of Airflow, both the 8-10 min test, and the 2-4 min test This Job Instruction elaborates parts of ref QXXXXXX	Process Overview <table border="1"><thead><tr><th>Process Step</th><th>Page</th></tr></thead><tbody><tr><td>1. Perform System Test of Airflow (8-10 min)</td><td>3</td></tr><tr><td>2. Perform System Test of Airflow (2-4 min)</td><td>4</td></tr></tbody></table>	Process Step	Page	1. Perform System Test of Airflow (8-10 min)	3	2. Perform System Test of Airflow (2-4 min)	4
Process Step	Page						
1. Perform System Test of Airflow (8-10 min)	3						
2. Perform System Test of Airflow (2-4 min)	4						
Applies to This Job Instruction applies to: - Employees demoing the pipe system Materials - Pipe system - Spare part box - Pump	Symbols These symbols will be found in the JI when increased focus is important. Require-ments 						

Perform System Test of Airflow (8-10 min)

Symbol	What (Important steps)	How (Key points)	Why (Reasons)
	1. Prepare	1. Place the pump on the table 2. Ensure valve "V555" is open 3. Ensure valve "V803" is closed 4. Ensure "Blow-Out" valve is closed	1. So it is ready to be used 2. To ensure the airflow valve has access to system 1 3. To ensure system 1 and 2 are separated 4. To ensure the air stays within the system for an accurate test result
	2. Fill 1st Airflow system with air	1. Dismantle the 2 caps from air valve 1 (the air valve closest to you) 2. Attach the pump by using the "P" connection. Raise the handle of the pump to mount it in place 3. Pump air into the system until pressure gauge 1 shows [3 bars] 4. Remove the pump 5. Place the 2 caps back on air valve 1 6. Close valve "V555"	1. So we can attach the pump 2. Because this is the connection that fits the valve 3. Because this is the required test value 4. Because you are done using it 5. To protect the air valve 6. To ensure there are no leaks within air valve 1
	3. Fill 2nd Airflow system with air	1. Take an air valve 2 from the spare part box 2. Mount air valve 2 onto the pipe system by screwing it in place 3. Remove the black cap from air valve 2 4. Attach the pump by using the "P" connection. Raise the handle of the pump to mount it in place 5. Pump air into the system until pressure gauge 2 shows [4 bars] 6. Remove the pump 7. Place the black cap back onto air valve 2 8. Open valve "V803"	1. So you are ready to mount it 2. To be able to use air valve 2 3. To be able to attach the pump 4. Because this is the connection that fits the valve 5. Because this is the required test value 6. Because you are done using it 7. To protect the valve 8. To open up between system 1 and 2
	4. Execute system test of Airflow	1. Open the "Blow- Out" valve and listen for the whistle noise 2. Open valve "V555"	1. To successfully complete the test 2. To empty air-system completely

1.2

Perform System Test of Airflow (2-4 min)

Symbol	What (Important steps)	How (Key points)	Why (Reasons)
	1. Prepare	1. Place the pump on the table 2. Ensure valve "V803" is closed 3. Ensure "Blow-Out" valve is closed	1. So it is ready to be used 2. To ensure system 1 and 2 are separated 3. To ensure the air stays within the system for an accurate test result
	2. Fill 2nd Airflow system with air	1. Remove the black cap from air valve 2 2. Attach the pump by using the "P" connection. Raise the handle of the pump to mount it in place 3. Pump air into the system until pressure gauge 2 shows [3 bars] 4. Remove the pump 5. Place the black cap back onto air valve 2 6. Open valve "V803"	1. To be able to attach the pump 2. Because this is the connection that fits the valve 3. Because this is the required test value 4. Because you are done using it 5. To protect the valve 6. To open up between system 1 and 2
	3. Execute system test of Airflow	1. Open the "Blow-Out" valve and listen for the whistle noise	1. To successfully complete the test

1.1