

SPPL

SAVEMA THERMAL TRANSFER PROGRAMMING LANGUAGE (Revision-11)



Markalama ve Kodlama Makinaları San.Tic. Ltd. Sti.

Fevzi Cakmak Mah. Ahmet Petekci Cad. No :5L/1

Karatay / KONYA / TURKIYE

Tel : +90 332 239 2339

Fax : +90 332 239 2319

Web: www.savema.com.tr

Document Version : Rev.11 © Copyright 2022 by SAVEMA TTO

Revision Notes

The following changes have been made to this document.

- 1- SPLAMQ(Append Multi Queue Datas) command is added. That command provides to add dynamic data to more than one queue. (Page 77)
- 2- SPLGMQ(Get Multi Queue Capacity) command is added. That command returns item count of specified queues. (Page 79)
- 3- SPLCMQ(Clear Multi Queue Datas) command is added. That command deletes datas in specified queues. (Page 80)
- 4- SPMCLV (Change Logo Value) command is added. That command provides to change logo remotely.(Page 83)

Note: Controller software version must be minimum v3.18 to use above changes.

CONTENTS

1. General Rules for SPPL	6
1.1. Command Structure	6
1.2. Command List	6
2. Configuration Commands	12
2.1. Set/Get System Date&Time and Time Offset	12
2.2. Set/Get Network Configuration	13
2.3. Set Get RS-232 Configuration	14
2.4. Set/Get Print Speed(Intermittent).....	15
2.5. Set/Get Print Delay Value	16
2.6. Set/Get Darkness(Contrast) Value	17
2.7. Set/Get Print Rotation.....	17
2.8. Set/Get Horizontal Position	18
2.9. Set/Get Vertical Position	19
2.10. Set/Get Mirroring Option	19
2.11. Set/Get RibbonSave Mode	20
2.12. Set/Get Internal Contact Mode(Continuous only)	21
2.13. Set/Get Trigger Contact Mode(Continuous only).....	22
2.14. Set/Get All Settings	23
2.15. Set/Get System Parameters	25
2.16. Set/Get All System Parameters	26
2.17. Set/Get One Additional Settings.....	27
2.18. Set/Get All Additional Settings.....	27
2.19. Set /Get System Language	28
2.20. Set/Get Administrator Password	30
2.21. Return to Factory Settings	30
2.22. Set/Get Print Request Message	31
3. Label Designing Commands	32
3.1. Create Template Datas and Template Structure	32
3.1.1. General Template Datas	33
3.1.2. General Object Datas	35
3.1.3. Objects(Content)	35
3.1.3.1. Date	35
3.1.3.2. Time	38
3.1.3.3. Text	40

3.1.3.4.	RichText.....	41
3.1.3.5.	Counter	42
3.1.3.6.	Logo(Image).....	45
3.1.3.7.	Shape.....	46
3.1.3.8.	Shift Code	47
3.1.3.9.	Barcode	49
3.1.3.10.	2D Barcode	56
3.1.3.11.	Database.....	65
3.1.3.12.	Table.....	66
3.1.4.	Font	68
3.2.	Load Template File from Printer	70
3.3.	Get Active Template	70
3.4.	Get Stored Templates	70
3.5.	Create Database File	71
3.6.	Get Stored Data Files	72
3.7.	Delete Template File	72
3.8.	Delete All Templates.....	72
3.9.	Delete Data File	73
3.10.	Delete All Data Files.....	73
3.11.	Clear Data Buffer.....	74
3.12.	Load Font File.....	74
3.13.	Get Font Files.....	75
3.14.	Delete Font File.	75
3.15.	Get Field Names.....	75
3.16.	Get Field Value.....	76
3.17.	Append Queue Datas	77
3.18.	Append Multi Queue Datas	77
3.19.	Get Queue Capacity	78
3.20.	Get Multi Queue Capacity	79
3.21.	Clear Queue Datas	79
3.22.	Clear Multi Queue Datas	80

4. Modification Commands81

4.1.	Changing Text Value	81
4.2.	Changing Barcode Value	82
4.3.	Changing 2D Barcode Value	82
4.4.	Changing Counter Value	83
4.5.	Changing Logo	83

4.6.	Changing Selected Values...	84
5.	Print Commands	86
5.1.	Start Print	86
5.2.	Set/Get Print Count for Limited print	86
5.3.	Stop Print	87
5.4.	One Test Print.....	87
5.5.	Status of Printer.....	88
6.	General Commands	89
6.1.	Send User Message to Printer	89
6.2.	General Response Command From Printer	89
6.3.	Get Total Print Count	90
6.4.	Get Current Print Count	90
6.5.	Get Firmware Version	90
6.6.	Get Remaining Ribbon(From Cassette models)	91
6.7.	Get Serial Number of Printer	91
6.8.	Set Lock Interface	91
6.9.	Get Lock Interface	92
7.	Traverse Commands.....	93
7.1.	Set/Get Pack Size.....	93
7.2.	Set/Get Print Count.....	94
7.3.	Set/Get Print Position.....	94
7.4.	Set/Get Pack Distance.....	95
7.5.	Set/Get Printing Area.....	96
7.6.	Set/Get All Traverse Parameters.....	96
8.	System Parameters Explanation	98
8.1.	32x40I, 32x50I, 53x40I and 53x50I Parameters.....	98
8.2.	32x70I, 53x70I, 53x125I, 107x75I and 107x125I Parameters.....	100
8.3.	32C Parameters	102
8.4.	32C with Cassette, 53C and 107C Parameters Explanation	104
8.5.	32TR, 53TR and 107TR Parameters Explanation	106
9.	Warnings	108
9.1.	Command Limitations.....	109
9.2.	Command Operating Conditions	110

1.General Rules for SPPL

SPPL is programming language for controlling Savema Thermal Transfer printer over Ethernet/RS-232 communication.

1.1 SPPL Command Structure

SPPL commands have some rules which is shown in below;

- SPPL commands starts with ~ character and ends with ^ character.(ie ~SPPSAP^)
- SPPL commands separates with | character for more than one commands. (ie ~SPPSLQ{1000}| SPPSAP^). This character only have to be used for separate commands.
- SPPL command parameters defines between { and } characters.
- (ie. ~ SPPSLQ {1000}^)
- Set and Change Commands parameters separates with > character. (ie. ~SPCSSC{115200>None>8>1}^)

Get Commands parameters separates with < characters. (ie.

~ SPGRES{ SPCGSC:115200<None<8<1}^)

Modification commands and Create Data File command parameters separates with ~gt~ text. (ie. ~SPMCSV{text1~gt~Savema}^)

- SPPL command letters are created according to some rules.
 - o SP means Savema Printer
 - o 3rd character indicates Command type. Command types with letters are;
 - C : Configuration Commands
 - L : Label Commands
 - M : Modification Commands
 - P : Print Commands
 - G : General Commands
 - o Last 3 characters are abbreviation of Command Name

Forexample; SPCSNC command letters are separating like below;

- o SP is Savema Printer
- o C is Configuration Command type
- o SNC is Set Network Configuration

1.2 Command List

SPPL commands separates according to using type. There are 5 types of command groups in SPPL.

- **Configuration Commands**
- **Label Designing Commands**
- **Modification Commands**

- **Print Commands**
- **General Commands**
- **Traverse Commands**

Note : Some commands doesn't supported by all printers. If so, printer sends FAIL message when getting incompatible command. Please see part 9.1) Command Limitations .

Note : Data transfer time changes according to communication type and speed. If data is big, transfer time increases.

All of commands are listed in below as a table format

SAVEMA PRINTER PROGRAMMING LANGUAGE COMMAND LIST			
Command	Explanation	Usage	Example
CONFIGURATION COMMANDS			
SPCSDT	Set System Date&Time and Time Offset	~SPCSDT{DD>MM>YYYY>HH>mm>SS>OO}^	~SPCSDT{25>01>2015>11>36>00>00}^
SPCGDT	Get System Date&Time and Time Offset	~SPCGDT^	~SPCGDT^
SPCSNC	Set Network Configuration	~SPCSNC{IP Address>Subnet Mask>Gateway>Port number}^	~SPCSNC{192.168.1.123>255.255.255.0>192.168.1.1>9100}^
SPCGNC	Get Network Configuration	~SPCGNC^	~SPCGNC^
SPCSSC	Set RS-232 Configuration	~SPCSSC{Baud Rate> Parity> Data Bits> Stop Bits}^	~SPCSSC{115200>None>8>1}^
SPCGSC	Get RS-232 Configuration	~SPCGSC^	~SPCGSC^
SPCSPS	Set Print Speed (Intermittent)	~SPCSPS{Print Speed}^	~SPCSPS{200}^
SPCGPS	Get Print Speed (Intermittent)	~SPCGPS^	~SPCGPS^
SPCSPD	Set Print Delay value	~SPCSPD{Print Delay}^	~SPCSPD{10}^
SPCGPD	Get Print Delay value	~SPCGPD^	~SPCGPD^
SPCSDV	Set Darkness(Contrast) Value	~SPCSDV{Contrast}^	~SPCSDV{100}^
SPCGDV	Get Darkness(Contrast) Value	~SPCGDV^	~SPCGDV^
SPCSPR	Set Print Rotation	~SPCSPR{Print Rotation}^	~SPCSPR{180}^
SPCGPR	Get Print Rotation	~SPCGPR^	~SPCGPR^
SPCSHP	Set Horizontal Position	~SPCSHP{Horizontal Position Value}^	~SPCSHP{0}^
SPCGHP	Get Horizontal Position	~SPCGHP^	~SPCGHP^
SPCSV	Set Vertical Position	Will be used in then future	
SPCGVP	Get Vertical Position	Will be used in then future	
SPCSMO	Set Mirroring Option	~SPCSMO{Mirroring Option}^	~SPCSMO{0}^
SPCGMO	Get Mirroring Option	~SPCGMO^	~SPCGMO^
SPCSRS	Set RibbonSave Mode	~SPCSRS{Direction>Column No>Shifting length }^	~SPCSRS{0>2>4}^
SPCGRS	Get RibbonSave Mode	~SPCGRS^	~SPCGRS^

SPCSIC	Set Internal Contact Mode (Continuous only)	~SPCSIC{Internal Contact Mode State>Package length }^	~SPCSIC{1>100}^
SPCGIC	Get Internal Contact Mode (Continuous only)	~SPCGIC^	~SPCGIC^
SPCSTC	Set Trigger Contact Mode (Continuous only)	~SPCSTC{Trigger Contact Mode State>Print Count>Package length }^	~SPCSTC{1>3>100}^
SPCGTC	Get Trigger Contact Mode (Continuous only)	~SPCGTC^	~SPCGTC^
SPCSAS	Set All Settings	~SPCSAS{Print Speed>Print Delay>Darkness Value>RibbonSave Mode Direction>RibbonSave Mode Column No>RibbonSave Mode Package Length>Internal Contact Mode State>Internal Contact Mode Package Length>Trigger Contact Mode State>Trigger Contact Mode Print Count>Trigger Contact Mode Package Length}^	~SPCSAS{300>2>100>0>1>0>0>30>1>3>60 }^
SPCGAS	Get All Settings	~SPCGAS^	~SPCGAS^
SPCSSP	Set System Parameter	~SPCSSP{Parameter No> Parameter value}^	~SPCSSP{1>25}^
SPCGSP	Get System Parameter	~SPCGSP{Parameter No }^	~SPCGSP{1}^
SPCSPA	Set All System Parameters	~SPCSPA{P1>P2>P3,P4>P5>P6>P7>P8>P9>P10>P11>P12>P13>P14>P15>P16>P17>P18>P19>P20}^ P means Parameter	~SPCSPA{25>27>300>200>31>77>0>24>25>0>12>65>0>5>0>23>0>4>0>0>400}^
SPCGPA	Get All System Parameters	~SPCGPA^	~SPCGPA^
SPCSSL	Set System Language	~SPCSSL{System Language Code }^	~SPCSSL{02}^
SPCGSL	Get System Language	~SPCGSL^	~SPCGSL^
SPCSAP	Set Administrator Password	~SPCSAP{System Password}^	~SPCSAP{123456}^
SPCGAP	Get Administrator Password	~SPCGAP^	~SPCGAP^
SPCSFS	Return to Factory Settings	~SPCSFS^	~SPCSFS^
SPCSPM	Set Print Request Message	~SPCSPM{Print Request Active Passive>Print Message}^	~SPCSPM{0>OK}^
SPCGPM	Get Print Request Message	~SPCGPM^	~SPCGPM^
LABEL DESIGNING COMMANDS			

SPLTDS	Create Template Datas and Template Structure	~SPLTDS{Template Datas}^	~SPLTDS{<Template> <General> <MachineType>53x70I</MachineType> <Name>temp1_53.ronx</Name> <Width>640</Width> <Height>480</Height> </General> <Object> <ObjectType>Text</ObjectType> <Name>text1</Name> <X>10</X> <Y>63</Y> <W>105</W> <H>33</H> <Rotate>180</Rotate> <Content> <Data>savema Printer</Data> <Source>Internal</Source> <MagnificationRatio>100</MagnificationRatio> </Content> <Name>Arial</Name> <Size>15</Size> <Style>Bold,Italic</Style> </Object> </Template>}^
SPLLTF	Load Template from Printer	~SPLLTF{Template File Name}^	~SPLLTF{temp1_53.ronx}^
SPLGAT	Get Active Template	~SPLGAT^	~SPLGAT^
SPLGST	Get Stored Templates	~SPLGST^	~SPLGST^
SPLGSD	Get Stored Data Files	~SPLGSD^	~SPLGSD^
SPLCDF	Create Data File	~SPLCDF{Data File Name~gt~File Content}^	~SPLCDF{sample.csv~gt~abc bce cde}^
SPLDTF	Delete Template	~SPLDTF{Template File Name}^	~SPLDTF{temp1_53.ronx}^
SPLDTA	Delete All Template	~SPLDTA^	~SPLDTA^
SPLDDF	Delete Data File	~SPLDDF{Data File Name}^	~SPLDDF{datafile1.csv}^
SPLDDA	Delete All Data File	~SPLDDA^	~SPLDDA^
SPLCDB	Clear Data Buffer	~SPLCDB^	~SPLCDB^
SPLGFN	Get Field Names	~SPLGFN{Template File Name}^	~SPLGFN{temp1_53.rox}^
SPLGFV	Get Field Value	~SPLGFN{ Field Name}^	~SPLGFN{BatchNo}^
SPLAQD	Append Queue Datas	~SPLAQD{Field Name~gt~Datas}^	~SPLAQD{TextCSV~gt~AB001 AB002}^
SPLAMQ	Append Multi Queue Datas	~SPLAMQ{Field Name1~gt~Datas1~gt~ Field Name2~gt~Datas2~gt~ Field Name3~gt~Datas3~gt~.....}^	~SPLAMQ{PRDNAME~gt~PR01 PR02~ PR03~gt~BATCH NO~gt~A01B A02B A03B}^
SPLGQC	Get Queue Capacity	~SPLGQC{Field Name}^	~SPLGQC{TextCSV}^
SPLGMQ	Get Multi Queue Capacity	~SPLGMQ{Field Name1~gt~Field Name2~gt~....}^	~SPLGMQ{PRDNAME~gt~ BATCH NO}^
SPLCQD	Clear Queue Datas	~SPLCQD{Field Name}^	~SPLCQD{TextCSV}^

SPLCMQ	Clear Multi Queue Datas	~SPLCMQ{ Field Name1~gt~Field Name2~gt~....}^	~SPLCMQ{PRDNAME~gt~ BATCH NO}^
MODIFICATION COMMANDS			
SPMCTV	Changing Text Value	~SPMCTV{Name of Object~gt~Text Value}^	~SPMCTV{brand_txt~gt~SAVEMA}^
SPMCBV	Changing Barcode Value	~SPMCBV{Name of Object ~gt~Barcode Value}^	~SPMCBV{barcodeno~gt~8691234567890}^
SPMC2D	Changing 2D Barcode Value	~SPMC2D{ Name of Object ~gt~Barcode Value}^	~SPMC2D{qrcodeno~gt~savema12345}^
SPMCCV	Changing Counter Value	~SPMCCV{Name of Object ~gt~Counter Value}^	~SPMCCV{counter1~gt~000055}^
SPMCLV	Changing Logo Value	~SPMCLV{Name of Object ~gt~Base64 data}^	~SPMCLV{productlogo~gt~/9j/4....Q==}^
SPMCSV	Changing Selected Values	~SPMCSV{Name of Object~gt~Text Value~gt~Name of Object~gt~Text Value}^	~SPMCSV{ brand_txt~gt~SAVEMA~gt~qrcodeno~gt~savema12345}^
PRINT COMMANDS			
SPPSAP	Start Automatically Print	~SPPSAP^	~SPPSAP^
SPPSLQ	Set Print Count for Limited print	~SPPSLQ{Print Quantity}^	~SPPSLQ{1000}^
SPPGLQ	Get Print Count for Limited print	~SPCGLQ^	~SPPGLQ^
SPPSTP	Stop Print	~SPPSTP^	~SPPSTP^
SPPOTP	One Test Print	~SPPOTP^	~SPPOTP^
SPPSTA	Status of Printer	~SPPSTA^	~SPPSTA^
GENERAL COMMANDS			
SPGSUM	Send User Message to Printer	~SPGSUM{User Message}^	~SPGSUM{Package finished. Please stop printer}^
SPGRES	General Response Command From Printer	~SPGRES{Response}^	~SPGRES{950225}^
SPGGTP	Get Total Print Count	~SPGGTP^	~SPGGTP^
SPGGFW	Get Firmware Version	~SPGGFV^	~SPGGFV^
SPGGRR	Get Remaining Ribbon(From Cassette models)	~SPGGRR^	~SPGGRR^
SPGGSN	Get Serial Number of Printer	~SPGGSN^	~SPGGSN^
SPGGCP	Get Current Print Count	~SPGGCP^	~SPGGCP^
SPGSLI	Set Lock Interface	~SPGSLI{Lock/Unlock}^	~SPGSLI{1}^
SPGGLI	Get Lock Interface	~SPGGLI^	~SPGGLI^
TRAVERSE COMMANDS			
SPTSPS	Set Pack Size	~SPTSPS{Pack Size(mm)}^	~SPTSPS{60}^
SPTGPS	Get Pack Size	~ SPTGPS^	~SPTGPS^
SPTSPC	Set Print Count	~ SPTSPC{Print Count}^	~SPTSPC{5}^
SPTGPC	Get Print Count	~SPTGPC^	~SPTGPC^
SPTSPP	Set Print Position	~SPTSPP{Print position(mm)}^	~SPTSPP{10}^
SPTGPP	Get Print osition	~SPTGPP^	~SPTGPP^
SPTSPD	Set Pack Distance From Beginning	~SPTSPD{Pack distance(mm)}^	~SPTSPD{50}^
SPTGPD	Get Pack istance From Beginning	~ SPTGPD^	~SPTGPD^

SPTSPA	Set Printing Area	~ SPTSPA{Printing Area}^	~SPTSPA{400}^
SPTGPA	Get Printing Area	~SPTGPA^	~SPTGPA^
SPTSTP	Set All Traverse Parameters	~SPTSTP{Pack Size>Print Count>Print Position>Pack Distance>Printing Area}^	~SPTSTP{60>5>10>50>400}^
SPTGTP	Get All Traverse Parameters	~SPTGTP^	~SPTGTP^

Table-1) Command List