

Hydraulic Pump H1-2 Maintenance SOP

Asset ID: PUMP-H1-2

Department: Mechanical Maintenance

Maintenance Schedule:

- Inspect every 30 days.
- Replace hydraulic oil every 6 months.
- Check inlet and outlet pressure.
- Verify motor alignment.

Safety Instructions:

1. Disconnect power before servicing.
2. Wear safety gloves and goggles.
3. Release system pressure before opening the pump.

Replacement Procedure:

1. Shut down the system.
2. Isolate the hydraulic line.
3. Remove the damaged pump.
4. Install the replacement pump.
5. Tighten all mounting bolts.
6. Reconnect hydraulic lines.
7. Restore power.
8. Perform a leak test.

Vendor:

ABC Industrial Systems

Revision: 1.2