TEKGROAML Display Support

Complete Buyer FAQ

English edition

Latest guides

https://github.com/tekgroaml/tekgroaml-display-support

Click the address above to visit our GitHub home page.

Connection checks • Windows • Product FAQs • Dual-screen demos

Document date: 2026-11-08
Source snapshot: 6d86428

This English buyer edition collects the home-page introduction, Windows guide, and product troubleshooting steps. Detailed experiment records and evidence remain linked online. No new hardware testing is implied.

Contents

TEKGROAML Display Support 3

Windows: quick checks for picture and touch 5

2.1-inch 480×480 single-screen touchscreen 7

2.1-inch dual-screen kit, 480×480 per screen, non-touch 8

2.8-inch 480×480 single-screen touchscreen 10

2.8-inch dual-screen kit, 480×480 per screen, non-touch 11

2.8-inch 480×480, touch status unconfirmed 13

3.4-inch 800×800 touchscreen 15

4.0-inch 720×720 touchscreen 17

6.2-inch 360×960 cut-panel touchscreen 19

6.2-inch 360×960 cut panel, non-touch 21

Same-content and different-content dual screens: uses and driver-board logic 23

TEKGROAML Display Support

Download the complete English FAQ: PDF - English edition. Includes the home-page introduction, Windows checks, product FAQs and dual-screen examples, with a clickable GitHub home link on the cover.

Find your screen by size - resolution - touch capability in the product FAQ directory. Each current product has a separate English FAQ and Chinese FAQ with reciprocal language links. Updated 2026-11-08.

Start with the symptom you can observe: no picture or flicker, touch missing or inaccurate, or part of the image missing. Open your product below for steps to try. Technical data is available at the end of each FAQ.

Before changing settings

• Black or flickering after moving a cable? Leave it still and wait about 10-15 seconds. If it does not recover, unplug and firmly reconnect HDMI and USB power; try another cable if movement keeps causing it.

• No touch, or touch on another screen? For a touch model, plug its USB power/touch data cable into the same computer that sends the picture, not just a charger. Check each screen's HDMI and USB as a pair. A charging-only cable cannot carry touch.

• Using Windows? Start with the Windows picture and touch steps. The Raspberry Pi commands in this repository do not run on Windows.

Product options: the current dual-screen kits are non-touch. The 2.1-inch and 2.8-inch single-screen ranges include touch models. Both single-screen touch models are confirmed 480×480; model-specific acceptance is still pending. The older 2.8-inch black-screen pair has not been matched to a confirmed touch/non-touch SKU.

Product	English FAQ
2.1-inch 480×480 single-screen touchscreen	English
2.1-inch dual-screen, 480×480 each, non-touch	English
2.8-inch 480×480 single-screen touchscreen	English
2.8-inch dual-screen, 480×480 each, non-touch	English
2.8-inch 480×480 historical test pair (exact variant pending)	English
3.4-inch 800×800 touchscreen	English
4.0-inch 720×720 touchscreen	English
6.2-inch 360×960 cut-panel touchscreen	English
6.2-inch 360×960 cut panel, non-touch	English

Dual-screen uses and picture distribution

For these one-HDMI kits, same content repeats the full picture on both panels; different content uses a left/right picture prepared by the app, with one part on each panel. Copying suits repeated information and symmetry; splitting suits instruments and primary/secondary dashboards. “Mirroring” here preserves reading orientation rather than reversing text.

Round/square use cases, board-flow diagrams and demo entrypoints. One HDMI kit may correctly appear as one monitor. Hardware-copy single-picture input and SBS double-width input are not interchangeable.

Non-touch dual-screen records with size unconfirmed

Choose shape and same/different content: round SBS, square SBS, round hardware-copy and square hardware-copy kits. Added issues cover one dark panel, demos stopping after a swap, mixing 480×480 and 960×480 inputs, and apps rejecting observed ~62.811/~71.295Hz rates.

These are provisional connection records, not identified new SKUs. They stay outside the inch-sorted table and are not assigned to the 2.8-inch product. Windows and Pi steps are separate. Refresh compatibility changed app acceptance only, not screen timings.

Non-touch dual-screen kit list

Sizes are still being matched to the kits; all four configurations below are non-touch.

Kit	FAQ
Round dual-screen / same content / non-touch	English
Round dual-screen / different content / non-touch	English
Square dual-screen / same content / non-touch	English
Square dual-screen / different content / non-touch	English

Prefer to let AI help?

If you use GPT or Claude, download this guide, the matching display tools and any demo you want to try. Then tell your AI what you want: make a wish, and let AI help with the steps. With access to the project files and your computer or Raspberry Pi, a capable AI assistant can help inspect settings, run tests and set up a supported demo.

- Product guides and FAQs
- Display configuration and test tools
- Round-screen Home Assistant kiosk demo

For example, tell it:

Please read these repositories first. I have a [size/resolution/touch option] screen connected to [Windows / Raspberry Pi]. I want to [fix the picture / test touch / run a demo]. Check the connections and supported options first, then help me step by step. Keep a way to restore settings when making changes.

Tell the AI your screen model, how HDMI and USB are connected, and what you see. If it can only chat, it can guide you through the steps; running commands requires a tool-enabled assistant with access you grant. Physical connection or hardware faults may still need hands-on checks or our support. Raspberry Pi scripts are not Windows programs.

The product pages cover no picture/flicker, touch issues and cut-panel compensation, including verified results and unresolved cases. EDID input modes are separated from physical visible resolution. Unknown specifications are marked rather than inferred from controller names.

- Shared procedures and all tested scenarios
- General touchscreen customer FAQ
- Display tools and installation

The cut-panel workaround is currently application-level; it does not claim whole-desktop or boot-time compensation. Historical product/package links are retained under the product directory. Documentation can be downloaded independently of the tools repository.

Open the current online page

Windows: quick checks for picture and touch

Start here before installing drivers or running scripts. These are things to try in Windows 10/11; menu names can vary. A successful Raspberry Pi test does not guarantee the same result on Windows.

The screen goes black or flickers when I touch a cable

1. Keep the cables still and wait about 10-15 seconds.

2. If the picture does not return, unplug and firmly reconnect HDMI and USB power. Check the computer end too.

3. Try another cable. Test one screen at a time and use the screen's specified power connection.

If a slight movement repeatedly causes the problem, replace the cable first. It is not a reason to start changing display firmware.

A two-panel kit appears as one display, or cannot show separate content

One logical display can be normal for two panels driven by one HDMI board. A hardware-copy board sends one picture to both; an SBS board sends half a double-width picture to each. Windows Duplicate/Extend changes host outputs, not the board's internal mapping.

1. Check the product instructions for same/different content and whether one or two HDMI cables are used.

2. Select only an actually offered input matching the board. Do not force 960×480 onto a 480×480 board. A normal full-screen window does not guarantee two complete SBS panel views.

3. For one dark panel, wait, reconnect HDMI/USB power and compare cables and rated supplies first. A complete screenshot does not prove both panels received the signal.

Provisional dual-screen records contain Pi-side evidence, not a Windows driver or completed Windows acceptance. Approximately 71.295Hz is a particular advertised input, not a universal target. Do not force Windows rates to pass a Pi demo check.

It still has no picture, flickers, or looks the wrong size

1. Right-click the desktop → Display settings → Identify. Select the small screen.

2. Choose the resolution listed for your product, if Windows offers it. Do not copy another screen's settings.

3. For separate screens, choose Extend these displays. Duplicate mode can limit the available picture sizes.

4. Open Advanced display, select the same screen, and try 60Hz only if it is offered. If unavailable or worse, return to the previous setting. Confirm a change only when the picture looks correct; Windows normally offers a brief chance to keep or revert display changes.

5. If the whole screen is visible but text is too large, adjust Scale. Scale changes text/app size; it does not restore pixels cut off by the screen hardware.

If Windows cannot detect the screen, recheck power and HDMI and try a known-good port/cable or another computer. If detected but still black, contact us with a photo and the selected resolution/refresh rate.

The picture works, but touch does nothing

The touch model's supplied USB power/touch cable also carries touch data. Connect it to the same computer that sends the HDMI picture, not only to a wall charger. Use a USB data cable, not a charging-only cable. A non-touch model will not respond to finger taps.

Try another USB port directly on the computer, temporarily bypass a hub, and reconnect USB. Open Device Manager → Human Interface Devices and look for a touchscreen entry such as HID-compliant touch screen. If disabled, enable it. If missing or showing a warning, try the data cable/port first, then ask support before installing a third-party driver. Do not disable unrelated input devices.

Touch controls the other screen

1. Check that both cables from each screen go to the intended computer. Test one screen and its USB touch cable at a time.

2. Reconnect both. Use Identify in Display settings to confirm which display is which.

3. Search Start for Calibrate the screen for pen or touch input. In Tablet PC Settings, choose Setup (Touch input if asked).

4. Follow the prompt: touch the requested screen. If the prompt appears on a non-touch screen, press Enter to move it to the next screen. Finish and test both screens.

Try Setup before calibration; it assigns the touch input to a display. Availability depends on Windows and the controller. If the option is absent or both still act on one screen, send us a photo of the cable connections and a Device Manager screenshot. The Raspberry Pi USB-mapping script does not configure Windows.

Touch is on the right screen, but the point misses my finger

First confirm the display resolution, orientation and touch-screen assignment above. If a previous Windows calibration was applied, use Reset in Tablet PC Settings if available, then test again. On a normal rectangular touchscreen, Calibrate may help if offered. A round panel may hide the calibration corners; do not complete a calibration by guessing invisible points.

For the 6.2-inch cut panel, fix the visible picture area before attempting calibration. A calibration alone cannot reveal missing picture content. See the cut-panel product FAQ.

A side of the 6.2-inch picture is missing

The measured touch sample displays only part of the incoming picture. The Raspberry Pi application workaround is documented, but a whole-desktop Windows workaround has not been validated. Do not expect a different resolution, 60Hz or Windows touch calibration alone to fix the missing area. Send a full-screen photo and a screenshot of Advanced display so support can check your sample.

Do I need the scripts?

The screen-config, screen-test and Python cut-panel demo in these support pages are for Raspberry Pi OS with the documented desktop setup. They are not Windows programs. Windows users should start with the steps above and contact support if the problem remains.

Choose your product · Support home

Open the current online page

2.1-inch 480×480 single-screen touchscreen

The seller confirmed that the 2.1-inch single-screen range has a touch model. Check the touch option and resolution on your order. The seller confirmed a 480×480 resolution. Model-specific touch acceptance is still pending; resolution confirmation alone is not a completed test. This is separate from the non-touch dual-screen kits.

The screen goes black or flickers after moving a cable

Wait about 10-15 seconds without moving the cables. If the picture does not return, reconnect HDMI and USB power firmly at both ends. Try another cable if it happens repeatedly, and follow the product's power requirements.

Touch does nothing

Connect the USB power/touch data cable to the same computer or Pi sending the HDMI picture. A wall charger or charging-only cable cannot carry touch input to the host.

Touch operates another screen

Test this screen with its HDMI and USB cable first. If it still reaches another display on Windows, follow the Windows touch setup steps. These checks are general guidance, not a completed product-specific acceptance test.

Optional Raspberry Pi steps

Install the display tools and log into the graphical desktop first. These commands do not run on Windows. Use connector 2 instead of 1 if connected there:

```
screen-config list
screen-config modes --port 1
```

Share the listed resolution, a product-label photo and any remaining symptom with support. No specific timing override or calibration is confirmed for this entry; do not apply another product's profile.

Product directory

Open the current online page

2.1-inch dual-screen kit, 480×480 per screen, non-touch

The seller confirmed this 2.1-inch dual-screen option has two 480×480 panels and no touch. Check your order for round/square shape and same/different-content options. These options use different layouts; their exact mapping to the earlier test boards has not been established.

One or both screens stay black or flicker after a cable is moved

Wait about 10-15 seconds, then firmly reconnect HDMI and USB power if the picture does not return. Test with known-good cables and the specified supply. Do not reseat internal panel ribbons while powered. Send a photo showing both screens and the board label if it still fails.

Windows shows one display number, but there are two panels

This can be normal when one driver board feeds both panels from one HDMI cable. 480×480 is each panel's resolution. A same-content board can receive one 480×480 picture; a side-by-side different-content board can receive a combined 960×480 picture. Check the actual modes offered for your board; do not force one input for every kit.

Tapping either screen does nothing

This kit is non-touch. USB power does not add touch support. The 2.1-inch single-screen range also has touch models, sold as a separate option.

Which applications suit same or different content?

For these one-HDMI kits, same content repeats the full picture on both panels; different content uses a left/right picture prepared by the app, with one part on each panel. “Mirroring” here duplicates the picture in the same reading orientation; it does not reverse text horizontally.

Content / shape	Applications	Two-panel arrangement
Same / round	Music visualization, RGB ambience, desktop clock	Identical spectrum/light/time for symmetry or opposite viewers
Same / square	Retail offers, meeting-room status, parcel pickup	The same product/room/parcel information on both sides of a counter
Different / round	Flight, automotive instruments, PC monitoring	Left attitude/right airspeed; speed/engine; CPU/GPU
Different / square	Smart home, PC case, industrial equipment	Left environment/right energy; CPU/cooling; pump/trends

Choose the shape and option on your order. This table does not mean every combination is sold or physically tested at this size. Existing Pi showcases use simulated data; the music demo is silent. Real prices, calendars, shipments, weather and device data are not connected automatically.

Each showcase introduces brand/use case for 3s, then runs effects for 10s; three chapters loop in 39s. Same-content introductions/effects match on both panels. Different-content introductions show brand/use case on separate panels, followed by different effects. See use cases and board diagrams for the full explanation and script entrypoints.

Which demo should I use?

Choose the matching shape and same/different-content layout. These links describe earlier connection tests, not proof that every shape/layout has been tested at this size:

- Round / same content
- Round / different content

• Square / same content

• Square / different content

Start with the Windows checks when using a PC. Raspberry Pi commands in the linked demo pages are not Windows programs. No size-specific timing correction, universal 60Hz setting or touch calibration is claimed here.

How does the board distribute one picture to two panels?

“Driver” here means the hardware board and its firmware driving both panels, not a Windows driver you must install.

• Different-content board (SBS): the host/app prepares one combined left-A/right-B image. The board sends the left half to panel 1 and the right half to panel 2. For two 480×480 panels, a matching input example is 960×480. The app lays out both views beforehand; the board does not redesign an ordinary page into two complete interfaces.

• Same-content board (hardware clone): the host supplies complete A, and the board copies it to both panels. Each shows complete A in the normal reading orientation. Example input: 480×480, without a horizontal flip.

• SBS software duplication: the app prepares [A | A] in a double-width image, then the SBS board splits it. Both panels match, but still require double-width input rather than the single input used by a hardware-copy board.

One HDMI kit may occupy one OS monitor entry. Windows Duplicate/Extend controls host outputs, not the board's internal mapping. Use board documentation and actually offered modes; do not force all kits to 960×480 or 60Hz. Software duplication does not mean a copy board can be converted to different content.

Picture-flow diagrams, use cases and Pi commands. These explanations do not replace per-size, board or batch acceptance.

Confirmed information and remaining details

Seller-confirmed: 2.1 inches per panel, two panels, 480×480 per panel, non-touch. Pending: order/SKU, board revision, shape/layout assignment and per-size physical acceptance. Observed refresh rates belong to the linked connection records; they are not new recommended product specifications.

Product index

Open the current online page

2.8-inch 480×480 single-screen touchscreen

The seller confirmed that the 2.8-inch single-screen range has a touch model. Check the touch option and resolution on your order. The seller confirmed a 480×480 resolution. Model-specific touch acceptance is still pending; resolution confirmation alone is not a completed test. This is separate from the non-touch dual-screen kits.

The screen goes black or flickers after moving a cable

Wait about 10-15 seconds without moving the cables. If the picture does not return, reconnect HDMI and USB power firmly at both ends. Try another cable if it happens repeatedly, and follow the product's power requirements.

Touch does nothing

Connect the USB power/touch data cable to the same computer or Pi sending the HDMI picture. A wall charger or charging-only cable cannot carry touch input to the host.

Touch operates another screen

Test this screen with its HDMI and USB cable first. If it still reaches another display on Windows, follow the Windows touch setup steps. These checks are general guidance, not a completed product-specific acceptance test.

Optional Raspberry Pi steps

Install the display tools and log into the graphical desktop first. These commands do not run on Windows. Use connector 2 instead of 1 if connected there:

```
screen-config list
screen-config modes --port 1
```

Share the listed resolution, a product-label photo and any remaining symptom with support. No specific timing override or calibration is confirmed for this entry; do not apply another product's profile.

Product directory

Open the current online page

2.8-inch dual-screen kit, 480×480 per screen, non-touch

The seller confirmed this 2.8-inch dual-screen option has two 480×480 panels and no touch. Check your order for round/square shape and same/different-content options. These options use different layouts; their exact mapping to the earlier test boards has not been established.

One or both screens stay black or flicker after a cable is moved

Wait about 10-15 seconds, then firmly reconnect HDMI and USB power if the picture does not return. Test with known-good cables and the specified supply. Do not reseat internal panel ribbons while powered. Send a photo showing both screens and the board label if it still fails.

Windows shows one display number, but there are two panels

This can be normal when one driver board feeds both panels from one HDMI cable. 480×480 is each panel's resolution. A same-content board can receive one 480×480 picture; a side-by-side different-content board can receive a combined 960×480 picture. Check the actual modes offered for your board; do not force one input for every kit.

Tapping either screen does nothing

This kit is non-touch. USB power does not add touch support. The 2.8-inch single-screen range also has touch models, sold as a separate option.

Which applications suit same or different content?

For these one-HDMI kits, same content repeats the full picture on both panels; different content uses a left/right picture prepared by the app, with one part on each panel. “Mirroring” here duplicates the picture in the same reading orientation; it does not reverse text horizontally.

Content / shape	Applications	Two-panel arrangement
Same / round	Music visualization, RGB ambience, desktop clock	Identical spectrum/light/time for symmetry or opposite viewers
Same / square	Retail offers, meeting-room status, parcel pickup	The same product/room/parcel information on both sides of a counter
Different / round	Flight, automotive instruments, PC monitoring	Left attitude/right airspeed; speed/engine; CPU/GPU
Different / square	Smart home, PC case, industrial equipment	Left environment/right energy; CPU/cooling; pump/trends

Choose the shape and option on your order. This table does not mean every combination is sold or physically tested at this size. Existing Pi showcases use simulated data; the music demo is silent. Real prices, calendars, shipments, weather and device data are not connected automatically.

Each showcase introduces brand/use case for 3s, then runs effects for 10s; three chapters loop in 39s. Same-content introductions/effects match on both panels. Different-content introductions show brand/use case on separate panels, followed by different effects. See use cases and board diagrams for the full explanation and script entrypoints.

Which demo should I use?

Choose the matching shape and same/different-content layout. These links describe earlier connection tests, not proof that every shape/layout has been tested at this size:

- Round / same content
- Round / different content

• Square / same content

• Square / different content

Start with the Windows checks when using a PC. Raspberry Pi commands in the linked demo pages are not Windows programs. No size-specific timing correction, universal 60Hz setting or touch calibration is claimed here.

How does the board distribute one picture to two panels?

“Driver” here means the hardware board and its firmware driving both panels, not a Windows driver you must install.

• Different-content board (SBS): the host/app prepares one combined left-A/right-B image. The board sends the left half to panel 1 and the right half to panel 2. For two 480×480 panels, a matching input example is 960×480. The app lays out both views beforehand; the board does not redesign an ordinary page into two complete interfaces.

• Same-content board (hardware clone): the host supplies complete A, and the board copies it to both panels. Each shows complete A in the normal reading orientation. Example input: 480×480, without a horizontal flip.

• SBS software duplication: the app prepares [A | A] in a double-width image, then the SBS board splits it. Both panels match, but still require double-width input rather than the single input used by a hardware-copy board.

One HDMI kit may occupy one OS monitor entry. Windows Duplicate/Extend controls host outputs, not the board's internal mapping. Use board documentation and actually offered modes; do not force all kits to 960×480 or 60Hz. Software duplication does not mean a copy board can be converted to different content.

Picture-flow diagrams, use cases and Pi commands. These explanations do not replace per-size, board or batch acceptance.

Confirmed information and remaining details

Seller-confirmed: 2.8 inches per panel, two panels, 480×480 per panel, non-touch. Pending: order/SKU, board revision, shape/layout assignment and per-size physical acceptance. Observed refresh rates belong to the linked connection records; they are not new recommended product specifications.

Product index

Open the current online page

2.8-inch 480×480, touch status unconfirmed

Product option update: the 2.8-inch single-screen range has a touch model. This page retains an older black-screen pair whose exact SKU has not been matched; it does not mean the product range lacks touch. The current non-touch dual-screen kits are documented separately.

Please check the size, resolution and touch option on your order. Start with the simple checks below; no commands are needed.

The screen goes black or flickers after a cable is moved

• Leave the cables still and wait about 10-15 seconds for the picture to return.

• If it stays black, unplug and firmly reconnect HDMI and the USB power connection. Check both ends.

• Try another cable and test one screen at a time. Use the power supply specified for your screen.

If this happens every time a cable moves, try replacing that cable. If the screen never lights up, follow the same connection checks first.

Touch does nothing or controls another screen

• Connect the screen's USB power/touch cable to the same computer that is sending the picture. A wall charger can power the screen but cannot send your touches to the computer.

• Use a USB data cable. A charging-only cable may light the screen without making touch work.

• With two screens, check each screen's HDMI and USB cable as a pair. Try one screen with its USB cable first, then reconnect the other.

Check your order first: touch was not confirmed for the samples in this entry. A non-touch version will not respond to a finger.

What can I try in Windows?

Right-click the desktop and open Display settings. Select this screen, use its listed resolution and choose Extend these displays if you want separate screens. For flicker, open Advanced display and try 60Hz only if it is available for that screen.

If touch still goes to the wrong screen, search Windows for Calibrate the screen for pen or touch input. Open it, choose Setup, and follow the prompts to identify the touchscreen. Check the USB connection first.

Windows steps with more detail. The commands in the optional Raspberry Pi section below do not run on Windows.

Still black after these checks?

Please send a photo of the wiring, tell us whether the backlight or power light is on, and include your computer model. The black-screen issue for the tested pair is not yet resolved; we cannot promise a settings change will fix it.

Optional: Raspberry Pi instructions

Commands below run on the Raspberry Pi after installing the display tools. Use version 2.3.2+ for rectangular touch tests. Examples select connector 1 (HDMI-A-1, board HDMI0); replace 1 with 2 for connector 2 (board HDMI1). Run screen tests as the desktop user, without sudo.

The screen stays black after HDMI and power are connected

1. Leave only one screen connected. Check the rated supply, the power indicator and whether the backlight glows.

2. Power down the screen, reseat HDMI, then power it back on. Compare a known-good cable and another host.

3. Inspect what the Pi detects:

```
screen-config list
 screen-config modes --port 1
```

4. Only if screen information is readable and 480×480 at about 60Hz is listed, try:

```
screen-config set --port 1 --mode 480x480@60
 screen-test white --screen 1
 screen-test pattern --screen 1
```

These are troubleshooting steps, not a confirmed cure. One tested screen was already outputting 480×480 at 60Hz and still appeared black. If it remains black, send a photo of the connections and indicators, supply details and the command output to support. Do not use the 720-square or 6.2-strip profile.

The command shows “Remote I/O error”

The Pi could not read the display information on the tested connection, even though HDMI was detected. Recheck screen power, HDMI seating and cables. screen-config auto depends on that read and cannot repair the physical link. A reported 1024×768 fallback is not your panel's resolution. Contact support if the error persists after cable/power checks.

The screen displays a picture, but finger taps do nothing

Confirm your order is for the touch version, then check the USB data connection. If it has touch, follow the touch checklist. A non-touch version will not react to a finger. No calibration or cut-panel offset has been verified for these samples.

Open the current online page

3.4-inch 800×800 touchscreen

Please check the size, resolution and touch option on your order. Start with the simple checks below; no commands are needed.

The screen goes black or flickers after a cable is moved

• Leave the cables still and wait about 10-15 seconds for the picture to return.

• If it stays black, unplug and firmly reconnect HDMI and the USB power connection. Check both ends.

• Try another cable and test one screen at a time. Use the power supply specified for your screen.

If this happens every time a cable moves, try replacing that cable. If the screen never lights up, follow the same connection checks first.

Touch does nothing or controls another screen

• Connect the screen's USB power/touch cable to the same computer that is sending the picture. A wall charger can power the screen but cannot send your touches to the computer.

• Use a USB data cable. A charging-only cable may light the screen without making touch work.

• With two screens, check each screen's HDMI and USB cable as a pair. Try one screen with its USB cable first, then reconnect the other.

What can I try in Windows?

Right-click the desktop and open Display settings. Select this screen, use its listed resolution and choose Extend these displays if you want separate screens. For flicker, open Advanced display and try 60Hz only if it is available for that screen.

If touch still goes to the wrong screen, search Windows for Calibrate the screen for pen or touch input. Open it, choose Setup, and follow the prompts to identify the touchscreen. Check the USB connection first.

Windows steps with more detail. The commands in the optional Raspberry Pi section below do not run on Windows.

Still not working?

Please send a photo or short video, your computer model, and how HDMI and USB are connected. Raspberry Pi users can try the product-specific steps below after the basic checks.

Optional: Raspberry Pi instructions

Commands below run on the Raspberry Pi after installing the display tools. Use version 2.3.2+ for rectangular touch tests. Examples select connector 1 (HDMI-A-1, board HDMI0); replace 1 with 2 for connector 2 (board HDMI1). Run screen tests as the desktop user, without sudo.

After connecting the round screen, there is no picture or the picture looks wrong

This can happen when an output still uses the mode selected for a previously connected screen.

1. Check power and HDMI, then inspect the screen's available modes:

```
screen-config list
 screen-config modes --port 1
```

2. Only if 800×800 at approximately 60Hz is listed, select it and display the test:

```
screen-config set --port 1 --mode 800x800@60
 screen-test pattern --screen 1
```

3. If the physical picture is stable, save that selection:

```
screen-config set --port 1 --mode 800x800@60 --save
```

The sample displayed a stable picture after selecting 800×800 at 60Hz. If the mode is missing, send screen-config list and screen-config modes --port 1 to support; do not use the square-screen or strip-screen repair profile. These commands do not provide an automatic rollback.

Touch does not work or controls the other display

Connect the USB data cable, then run:

```
screen-test touch --screen 1 --shape round
```

Tap the five numbered circles, then slide. If touches appear on another screen, identify each USB touch cable and follow the pairing procedure. This procedure corrected the dual-touch problem in the tested setup.

The test screenshot has corners that are not visible on the screen

A round panel cannot show the four corners of a square 800×800 screenshot. Keep application buttons inside the visible circle and use --shape round for touch testing. A missing part of the circle or clipped center content is a different problem: send a photo to support. Do not apply the strip panel's 60-column offset.

The test window disappears after reconnecting

```
screen-test stop
screen-test touch --screen 1 --shape round
```

Open the current online page

4.0-inch 720×720 touchscreen

Please check the size, resolution and touch option on your order. Start with the simple checks below; no commands are needed.

The screen goes black or flickers after a cable is moved

• Leave the cables still and wait about 10-15 seconds for the picture to return.

• If it stays black, unplug and firmly reconnect HDMI and the USB power connection. Check both ends.

• Try another cable and test one screen at a time. Use the power supply specified for your screen.

If this happens every time a cable moves, try replacing that cable. If the screen never lights up, follow the same connection checks first.

Touch does nothing or controls another screen

• Connect the screen's USB power/touch cable to the same computer that is sending the picture. A wall charger can power the screen but cannot send your touches to the computer.

• Use a USB data cable. A charging-only cable may light the screen without making touch work.

• With two screens, check each screen's HDMI and USB cable as a pair. Try one screen with its USB cable first, then reconnect the other.

What can I try in Windows?

Right-click the desktop and open Display settings. Select this screen, use its listed resolution and choose Extend these displays if you want separate screens. For flicker, open Advanced display and try 60Hz only if it is available for that screen.

If touch still goes to the wrong screen, search Windows for Calibrate the screen for pen or touch input. Open it, choose Setup, and follow the prompts to identify the touchscreen. Check the USB connection first.

Windows steps with more detail. The commands in the optional Raspberry Pi section below do not run on Windows.

Still not working?

Please send a photo or short video, your computer model, and how HDMI and USB are connected. Raspberry Pi users can try the product-specific steps below after the basic checks.

Optional: Raspberry Pi instructions

Commands below run on the Raspberry Pi after installing the display tools. Use version 2.3.2+ for rectangular touch tests. Examples select connector 1 (HDMI-A-1, board HDMI0); replace 1 with 2 for connector 2 (board HDMI1). Run screen tests as the desktop user, without sudo.

The screen stays black or the picture flickers

What you may see: the display is powered and HDMI is connected, but there is no picture, or the picture appears and flickers.

1. Check the screen's rated power supply and HDMI cable; test one screen first.

2. Inspect the detected screen, then try the matching compatibility profile:

```
screen-config list
 screen-config apply --port 1 --profile 4.0inch-720x720-60hz-wks-lontium-semi
 screen-test pattern --screen 1
```

Save open desktop files first: applying the profile may restart the desktop. This command has no automatic timeout rollback. If the tool says the screen does not match, stop and contact support rather than force it.

3. Check that the picture is stable and all four edges are visible. If it passes, save:

```
screen-config apply --port 1 --profile 4.0inch-720x720-60hz-wks-lontium-semi --save
```

This timing correction worked on the tested sample. If you need to undo it and the screen information can be read, run screen-config auto --port 1 --save; the original symptom may return.

Touch does nothing, operates the other screen, or misses buttons

1. Connect a USB data cable to the touch socket; HDMI alone does not carry touch.

2. Open the target test:

```
screen-test touch --screen 1 --shape rect
```

3. Tap all five targets and slide a finger. Targets should turn green and the trail should follow the finger on the same screen.

4. If another screen responds, use the USB/HDMI pairing steps. Different screen models can report the same controller name.

If the trail is on the correct screen but remains offset, contact support with a photo and screen-config list; do not apply the 6.2-inch cut-panel correction to this square screen.

The test image disappears after changing cables

Restart the test window:

```
screen-test stop
screen-test pattern --screen 1
```

If the desktop is also absent, check screen power/connection and that the graphical desktop is logged in.

Open the current online page

6.2-inch 360×960 cut-panel touchscreen

Please check the size, resolution and touch option on your order. Start with the simple checks below; no commands are needed.

The screen goes black or flickers after a cable is moved

• Leave the cables still and wait about 10-15 seconds for the picture to return.

• If it stays black, unplug and firmly reconnect HDMI and the USB power connection. Check both ends.

• Try another cable and test one screen at a time. Use the power supply specified for your screen.

If this happens every time a cable moves, try replacing that cable. If the screen never lights up, follow the same connection checks first.

Touch does nothing or controls another screen

• Connect the screen's USB power/touch cable to the same computer that is sending the picture. A wall charger can power the screen but cannot send your touches to the computer.

• Use a USB data cable. A charging-only cable may light the screen without making touch work.

• With two screens, check each screen's HDMI and USB cable as a pair. Try one screen with its USB cable first, then reconnect the other.

What can I try in Windows?

Right-click the desktop and open Display settings. Select this screen, use its listed resolution and choose Extend these displays if you want separate screens. For flicker, open Advanced display and try 60Hz only if it is available for that screen.

If touch still goes to the wrong screen, search Windows for Calibrate the screen for pen or touch input. Open it, choose Setup, and follow the prompts to identify the touchscreen. Check the USB connection first.

Windows steps with more detail. The commands in the optional Raspberry Pi section below do not run on Windows.

The left side is cut off, or left-side touches miss buttons

This cut-glass sample needs a special picture layout. Changing Windows resolution alone has not been shown to fix it. Please send us a photo showing all four screen edges.

On Raspberry Pi, we confirmed a workaround inside a test app: the full picture became visible and touch lined up. It does not automatically fix Windows, the whole desktop or every app. The optional Raspberry Pi section below explains how to try it.

Optional: Raspberry Pi instructions

Commands below run on the Raspberry Pi after installing the display tools. Use version 2.3.2+ for rectangular touch tests. Examples select connector 1 (HDMI-A-1, board HDMI0); replace 1 with 2 for connector 2 (board HDMI1). Run screen tests as the desktop user, without sudo.

The left side is missing: text, buttons or targets are cut off

What you may see: right-side content looks complete, but the left border and left-side buttons are missing. Changing resolution alone may not help.

Try the included compensated test application:

1. Install display tools 2.3.2+ and download this support repository. Close any older temporary test window first.

2. From the support repository root, inspect the connected screen:

```
screen-config list
 screen-test stop
```

3. If the selected output is already 420×960, normal rotation, scale 1, run:

```
python3 product-support/6.2inch-360x960-touch/scripts/6.2inch-360x960-touch-window-demo.py --screen 1
```

4. Check that all four white borders and all five numbered circles are visible. Tap and slide to check touch alignment. Press Ctrl+C in the launching terminal to close the demo.

A prior temporary application using this method showed complete content and accurate touch on the sample. The included program reproduces that method and has had a launch/screenshot check; its new five-point UI still needs its own physical acceptance check. If the command rejects your output mode or the borders remain clipped, send a photo and screen-config list to support. Do not save an unverified profile or guess a new resolution.

Scope: compensation is inside this application only. The ordinary desktop, browser and stock screen-test are not automatically compensated. Applications intended for this screen need the same visible-area layout.

Buttons on the right are close, but left-side touches land too far left

First check that touch reaches this physical screen rather than another one; use the pairing guide if necessary. Then use the compensated demo above: it corrects the visible content and touch position together.

Tap the center and all four corner targets. A target should turn green and the white touch mark should follow your finger. If the input has already been calibrated elsewhere, do not apply the correction twice. Ordinary screen-test touch --shape rect changes target layout but does not include this cut-panel correction.

The picture flickers, even though content is visible

1. Check rated screen power and cables first.

2. If support confirms this sample matches the known touch-strip profile, try the timing correction below. Save desktop work first: applying it may restart the desktop, and it has no timed rollback.

```
screen-config apply --port 1 --profile 6.2inch-420x960-60hz-ltm-zl480 --confirm-profile
 screen-test pattern --screen 1
```

3. Inspect stability separately from image completeness. A 60Hz test improved flicker on an earlier touch sample, but it did not fix the missing left edge.

The successful cut-window and touch test used approximately 51.85Hz. The combined 60Hz-plus-compensation configuration still needs physical verification. Do not add --save on the strength of a stable picture alone.

Open the current online page

6.2-inch 360×960 cut panel, non-touch

Please check the size, resolution and touch option on your order. Start with the simple checks below; no commands are needed.

The screen goes black or flickers after a cable is moved

• Leave the cables still and wait about 10-15 seconds for the picture to return.

• If it stays black, unplug and firmly reconnect HDMI and the USB power connection. Check both ends.

• Try another cable and test one screen at a time. Use the power supply specified for your screen.

If this happens every time a cable moves, try replacing that cable. If the screen never lights up, follow the same connection checks first.

Tapping the screen does nothing

This is the non-touch version, so that is expected. If a second touchscreen controls this screen, check that the other screen's HDMI and USB cables go to the same computer, then set its touch screen in Windows as described below.

What can I try in Windows?

Right-click the desktop and open Display settings. Select this screen, use its listed resolution and choose Extend these displays if you want separate screens. For flicker, open Advanced display and try 60Hz only if it is available for that screen.

Windows steps with more detail. The commands in the optional Raspberry Pi section below do not run on Windows.

The screen keeps getting brighter and darker, or an edge is missing

Please send us a short video and your power connection details. The tested non-touch sample still had this issue after a 60Hz trial; we do not have a confirmed software fix for it. The touch version’s cut-screen workaround has not been confirmed for this version.

Optional: Raspberry Pi instructions

Commands below run on the Raspberry Pi after installing the display tools. Use version 2.3.2+ for rectangular touch tests. Examples select connector 1 (HDMI-A-1, board HDMI0); replace 1 with 2 for connector 2 (board HDMI1). Run screen tests as the desktop user, without sudo.

Brightness repeatedly gets lighter and darker

What you may see: the picture stays in place, but the backlight or overall brightness pulses.

1. Test one screen with its rated supply. Compare a known-good power cable and suitable independent supply, following the product's power specification.

2. Check and compare the HDMI cable and a known-good host.

3. Display white and a grid so changes are easier to observe:

```
screen-config list
 screen-test white --screen 1
 screen-test pattern --screen 1
```

If it persists, send support a short video, supply details and screen-config list. A 60Hz timing test did not solve this sample, so there is no verified profile to recommend. Do not apply the touch-model profile just because the screen name matches.

The left edge is missing or the image is cropped

Use screen-test pattern --screen 1 and photograph all four screen edges. The touch version required a special visible-area layout, but its exact offset has not been measured or confirmed for this non-touch version. Contact support to measure your sample before adopting that layout.

Touch targets appear, but tapping does nothing

This is expected: the non-touch version has no touch input. Use color and geometry tests instead:

```
screen-test cycle --screen 1 --interval 5
screen-test pattern --screen 1
```

If another attached touchscreen controls this screen, follow the mixed-screen pairing procedure; map that touchscreen only to its own display.

The picture disappears after reconnecting

```
screen-test stop
screen-test pattern --screen 1
```

If it remains black, check power, backlight and screen detection before trying timing changes. Report any Remote I/O error to support with the connection details.

Open the current online page

Same-content and different-content dual screens: uses and driver-board logic

For kits with one HDMI cable feeding a board connected to two panels. Check your order for same/different content and round/square shape. The current 2.1-inch and 2.8-inch kits each have two 480×480 non-touch panels. Exact shape/board assignments to earlier samples still need confirmation.

What should the two screens show?

Choose	Visible result	Suitable uses
Same content	Both show the same complete picture, such as one promotion on both sides	Opposite viewers, repeated information, symmetrical decoration
Different content	Each shows a different part of one complete input canvas, such as instruments on the left and status on the right	Multiple metrics, primary/secondary information, coordinated dashboards

For these one-HDMI kits, same content repeats the full picture on both panels; different content uses a left/right picture prepared by the app, with one part on each panel. Here, “mirroring” means duplicating the picture in the same reading orientation, not horizontally reversing the text.

Which applications fit each choice?

These Raspberry Pi demos are implemented use cases, not proof that every size, shape or board has passed physical tests. The table does not establish that every configuration is sold for each size; check your order.

Content / shape	Application	What the panels show
Same / round	Music visualization	Identical colored spectra, sample track information and beat halos
Same / round	RGB ambience	Identical flowing rings and breathing effects on both sides of a desk or speakers
Same / round	Desktop clock	Identical time and sample weather for viewers on opposite sides
Same / square	Retail promotions	Identical products, sample prices and offer copy
Same / square	Meeting-room status	Identical availability/occupancy and demo countdown
Same / square	Parcel pickup	Identical sample shipment status and collection reference
Different / round	Flight instruments	Left attitude/heading; right airspeed/altitude
Different / round	Automotive instruments	Left speed/RPM/gear; right engine/fuel/voltage
Different / round	PC case	Left CPU/RAM; right GPU/cooling
Different / square	Smart home	Left environment/lighting; right solar/household power

Content / shape	Application	What the panels show
Different / square	PC case	Left CPU/RAM/trends; right GPU/temperature/fans
Different / square	Industrial equipment	Left pump/pressure/flow; right trends/equipment status

Product showcases use simulated data. The music demo neither captures nor plays sound. Weather, prices, calendars and shipments do not connect to real services automatically. Flight, vehicle and industrial pages do not establish real-device connection or control. Actual data integration requires the appropriate software and source separately.

Why does each different-content panel show half a picture?

If one ordinary page fills a double-width canvas, splitting it gives each panel only part of that page. This can be the expected board behavior rather than missing pixels.

1. Confirm the product option and board input, not only the OS display number.

2. Prepare two complete views in the host application: one on the left, one on the right.

3. For two 480×480 panels, a supported side-by-side board can receive one 960×480 canvas: left 480×480 to panel 1, right 480×480 to panel 2. Use the actual board documentation and offered modes.

4. Check that each panel's borders and text are complete. Round layouts must keep important content inside the visible circle.

The board distributes pixels; it does not open two applications or redesign an ordinary page into two complete interfaces. If it still looks wrong, check cables/power and provide a photo of both panels, the host screenshot and the current input mode.

Does same content also need two halves?

A hardware-copy board needs one complete picture, then duplicates it to both panels. For example, one 480×480 input can repeat on two 480×480 panels. Do not force 960×480 merely because there are two panels.

An SBS board can also show the same content through software: the application repeats the complete picture in both halves of a double-width canvas, and the board splits it normally. Software duplication still uses the SBS double-width input; hardware copying uses a single-picture input. Supported modes depend on the board. This does not imply interchangeable boards or a firmware conversion.

Can Windows Duplicate/Extend switch the board mode?

One HDMI kit may correctly appear as one logical monitor. Windows Duplicate/Extend controls host outputs, not how this board splits or duplicates its input internally.

Start with Windows Display settings and the modes actually offered by the board. SBS requires a matching two-region layout; a hardware-copy board requires its matching single picture. Pi demo scripts do not run on Windows and do not establish Windows physical acceptance for these kits.

Optional: run a three-use-case showcase on the Pi

Install the complete dual-display app repository, v0.10.2 or a later compatible release. Follow its README for dependencies and signal requirements. Tested environment: Pi 4B, Bookworm Desktop 64-bit, labwc/Wayland. Use SSH as the ordinary user who owns the logged-in graphical desktop, without sudo.

Family	Script	Sequence
Same / round	./demos/same/round/demo	Music → RGB ambience → clock
Same / square	./demos/same/square/demo	Retail → room status → pickup

Family	Script	Sequence
Different / round	./demos/different/round/demo	Flight → automotive → PC case
Different / square	./demos/different/square/demo	Home → PC case → pump

Each chapter introduces the brand/use case for 3s, then runs the effect for 10s; 39s loop. Same-content introductions and effects are identical. Different-content introductions show brand/icon on the left and use-case/metrics on the right; effects show different information.

Example for a confirmed square hardware-copy board, from the complete app directory:

```
cd ~/apps/lvgl-embedded-gui-demos
./app --version
./app stop --port 1
./demos/same/square/demo check --port 1 --size 480
./demos/same/square/demo start --port 1 --size 480
```

Stop targets this project only; use another tool's own normal stop command if it occupies the output. Before upgrading, stop the old version using its existing code, then update the complete project rather than overwriting running files.

Same-content scripts default to --signal clone for hardware copying. For an actual SBS board supporting double-width input, add --signal sbs to both check/start. Do not change to another board's geometry or rate merely to pass validation. Specific recorded rates and evidence are in the connection records; 480×480 per panel does not establish a universal 60Hz or other tested rate.

Public port 1/2 = Linux HDMI-A-1/2 = Pi 4 board HDMI0/1. This identifies the host connector, not the board's left/right panels. Change to --port 2 if wired to connector 2.

Inspect or stop later:

```
./demos/same/square/demo status --port 1
./demos/same/square/demo stop --port 1
```

These app commands do not change timings, EDID, screen firmware or system mirroring, and do not restart the desktop. No timed rollback is provided. If check fails, verify the board/mode; failure does not create a missing mode. start runs in the background after SSH exits while the desktop stays logged in. Normal stop closes this project's window. Disconnecting/changing boards can end the app; reconnect stably and check/start again rather than assuming automatic recovery.

Open the current online page