TEKGROAML Display Support

Complete Buyer FAQ
显示屏买家FAQ总册

English first • 简体中文在后

Latest guides / 最新文档

https://github.com/tekgroaml/tekgroaml-display-support

Click the address above to visit our GitHub home page.
点击以上地址即可进入GitHub首页，查找最新FAQ和工具。

Connection checks • Windows • Product FAQs • Dual-screen demos
接线检查、Windows操作、各产品处理步骤、双屏演示说明

Document date / 文档日期: 2026-11-08
Source snapshot / 来源版本: 52aaabe

This buyer edition collects the home-page introduction, Windows guide, and product troubleshooting steps. Detailed experiment records and evidence remain linked online. No new hardware testing is implied.
本册收录首页说明、Windows指南和各产品排查步骤。详细试验记录及证据通过链接在线查看；不表示进行了新的硬件验收。

Contents / 目录

TEKGROAML Display Support 3

Windows: quick checks for picture and touch 5

2.1-inch 480×480 single-screen touchscreen 7

2.1-inch dual-screen kit, 480×480 per screen, non-touch 8

2.8-inch 480×480 single-screen touchscreen 10

2.8-inch dual-screen kit, 480×480 per screen, non-touch 11

2.8-inch 480×480, touch status unconfirmed 13

3.4-inch 800×800 touchscreen 15

4.0-inch 720×720 touchscreen 17

6.2-inch 360×960 cut-panel touchscreen 19

6.2-inch 360×960 cut panel, non-touch 21

Same-content and different-content dual screens: uses and driver-board logic 23

TEKGROAML 显示屏支持中心 26

Windows：画面和触摸先这样检查 28

2.1英寸480×480单屏触摸款 30

2.1英寸双屏套装，每屏480×480，非触摸 31

2.8英寸480×480单屏触摸款 33

2.8英寸双屏套装，每屏480×480，非触摸 34

2.8英寸480×480，触摸属性待确认 36

3.4英寸800×800触摸屏 38

4.0英寸720×720触摸屏 40

6.2英寸360×960切割触摸屏 42

6.2英寸360×960切割非触摸屏 44

双屏同显与异显：用途、画面准备和驱动板原理 46

TEKGROAML Display Support

Find your screen by size - resolution - touch capability in the product FAQ directory. Each current product has a separate English FAQ and Chinese FAQ with reciprocal language links. Updated 2026-11-08.

Start with the symptom you can observe: no picture or flicker, touch missing or inaccurate, or part of the image missing. Open your product below for steps to try. Technical data is available at the end of each FAQ.

Before changing settings

• Black or flickering after moving a cable? Leave it still and wait about 10-15 seconds. If it does not recover, unplug and firmly reconnect HDMI and USB power; try another cable if movement keeps causing it.

• No touch, or touch on another screen? For a touch model, plug its USB power/touch data cable into the same computer that sends the picture, not just a charger. Check each screen's HDMI and USB as a pair. A charging-only cable cannot carry touch.

• Using Windows? Start with the Windows picture and touch steps. The Raspberry Pi commands in this repository do not run on Windows.

Product options: the current dual-screen kits are non-touch. The 2.1-inch and 2.8-inch single-screen ranges include touch models. Both single-screen touch models are confirmed 480×480; model-specific acceptance is still pending. The older 2.8-inch black-screen pair has not been matched to a confirmed touch/non-touch SKU.

Product	English FAQ	中文FAQ
2.1-inch 480×480 single-screen touchscreen	English	中文
2.1-inch dual-screen, 480×480 each, non-touch	English	中文
2.8-inch 480×480 single-screen touchscreen	English	中文
2.8-inch dual-screen, 480×480 each, non-touch	English	中文
2.8-inch 480×480 historical test pair (exact variant pending)	English	中文
3.4-inch 800×800 touchscreen	English	中文
4.0-inch 720×720 touchscreen	English	中文
6.2-inch 360×960 cut-panel touchscreen	English	中文
6.2-inch 360×960 cut panel, non-touch	English	中文

Dual-screen uses and picture distribution

For these one-HDMI kits, same content repeats the full picture on both panels; different content uses a left/right picture prepared by the app, with one part on each panel. Copying suits repeated information and symmetry; splitting suits instruments and primary/secondary dashboards. “Mirroring” here preserves reading orientation rather than reversing text.

Round/square use cases, board-flow diagrams and demo entrypoints. One HDMI kit may correctly appear as one monitor. Hardware-copy single-picture input and SBS double-width input are not interchangeable.

Non-touch dual-screen records with size unconfirmed

Choose shape and same/different content: round SBS, square SBS, round hardware-copy and square hardware-copy kits. Added issues cover one dark panel, demos stopping after a swap, mixing 480×480 and 960×480 inputs, and apps rejecting observed ~62.811/~71.295Hz rates.

These are provisional connection records, not identified new SKUs. They stay outside the inch-sorted table and are not assigned to the 2.8-inch product. Windows and Pi steps are separate. Refresh compatibility changed app acceptance

only, not screen timings.

Non-touch dual-screen kit list

Sizes are still being matched to the kits; all four configurations below are non-touch.

Kit	FAQ	
Round dual-screen / same content / non-touch	English	中文
Round dual-screen / different content / non-touch	English	中文
Square dual-screen / same content / non-touch	English	中文
Square dual-screen / different content / non-touch	English	中文

Prefer to let AI help?

If you use GPT or Claude, download this guide, the matching display tools and any demo you want to try. Then tell your AI what you want: make a wish, and let AI help with the steps. With access to the project files and your computer or Raspberry Pi, a capable AI assistant can help inspect settings, run tests and set up a supported demo.

- Product guides and FAQs
- Display configuration and test tools
- Round-screen Home Assistant kiosk demo

For example, tell it:

Please read these repositories first. I have a [size/resolution/touch option] screen connected to [Windows / Raspberry Pi]. I want to [fix the picture / test touch / run a demo]. Check the connections and supported options first, then help me step by step. Keep a way to restore settings when making changes.

Tell the AI your screen model, how HDMI and USB are connected, and what you see. If it can only chat, it can guide you through the steps; running commands requires a tool-enabled assistant with access you grant. Physical connection or hardware faults may still need hands-on checks or our support. Raspberry Pi scripts are not Windows programs.

The product pages cover no picture/flicker, touch issues and cut-panel compensation, including verified results and unresolved cases. EDID input modes are separated from physical visible resolution. Unknown specifications are marked rather than inferred from controller names.

- Shared procedures and all tested scenarios
- General touchscreen customer FAQ
- Display tools and installation

The cut-panel workaround is currently application-level; it does not claim whole-desktop or boot-time compensation. Historical product/package links are retained under the product directory. Documentation can be downloaded independently of the tools repository.

Open the current online page

Windows: quick checks for picture and touch

Start here before installing drivers or running scripts. These are things to try in Windows 10/11; menu names can vary. A successful Raspberry Pi test does not guarantee the same result on Windows.

The screen goes black or flickers when I touch a cable

1. Keep the cables still and wait about 10-15 seconds.

2. If the picture does not return, unplug and firmly reconnect HDMI and USB power. Check the computer end too.

3. Try another cable. Test one screen at a time and use the screen's specified power connection.

If a slight movement repeatedly causes the problem, replace the cable first. It is not a reason to start changing display firmware.

A two-panel kit appears as one display, or cannot show separate content

One logical display can be normal for two panels driven by one HDMI board. A hardware-copy board sends one picture to both; an SBS board sends half a double-width picture to each. Windows Duplicate/Extend changes host outputs, not the board's internal mapping.

1. Check the product instructions for same/different content and whether one or two HDMI cables are used.

2. Select only an actually offered input matching the board. Do not force 960×480 onto a 480×480 board. A normal full-screen window does not guarantee two complete SBS panel views.

3. For one dark panel, wait, reconnect HDMI/USB power and compare cables and rated supplies first. A complete screenshot does not prove both panels received the signal.

Provisional dual-screen records contain Pi-side evidence, not a Windows driver or completed Windows acceptance. Approximately 71.295Hz is a particular advertised input, not a universal target. Do not force Windows rates to pass a Pi demo check.

It still has no picture, flickers, or looks the wrong size

1. Right-click the desktop → Display settings → Identify. Select the small screen.

2. Choose the resolution listed for your product, if Windows offers it. Do not copy another screen's settings.

3. For separate screens, choose Extend these displays. Duplicate mode can limit the available picture sizes.

4. Open Advanced display, select the same screen, and try 60Hz only if it is offered. If unavailable or worse, return to the previous setting. Confirm a change only when the picture looks correct; Windows normally offers a brief chance to keep or revert display changes.

5. If the whole screen is visible but text is too large, adjust Scale. Scale changes text/app size; it does not restore pixels cut off by the screen hardware.

If Windows cannot detect the screen, recheck power and HDMI and try a known-good port/cable or another computer. If detected but still black, contact us with a photo and the selected resolution/refresh rate.

The picture works, but touch does nothing

The touch model's supplied USB power/touch cable also carries touch data. Connect it to the same computer that sends the HDMI picture, not only to a wall charger. Use a USB data cable, not a charging-only cable. A non-touch model will not respond to finger taps.

Try another USB port directly on the computer, temporarily bypass a hub, and reconnect USB. Open Device Manager → Human Interface Devices and look for a touchscreen entry such as HID-compliant touch screen. If disabled, enable it. If missing or showing a warning, try the data cable/port first, then ask support before installing a third-party driver. Do not disable unrelated input devices.

Touch controls the other screen

1. Check that both cables from each screen go to the intended computer. Test one screen and its USB touch cable at a time.

2. Reconnect both. Use Identify in Display settings to confirm which display is which.

3. Search Start for Calibrate the screen for pen or touch input. In Tablet PC Settings, choose Setup (Touch input if asked).

4. Follow the prompt: touch the requested screen. If the prompt appears on a non-touch screen, press Enter to move it to the next screen. Finish and test both screens.

Try Setup before calibration; it assigns the touch input to a display. Availability depends on Windows and the controller. If the option is absent or both still act on one screen, send us a photo of the cable connections and a Device Manager screenshot. The Raspberry Pi USB-mapping script does not configure Windows.

Touch is on the right screen, but the point misses my finger

First confirm the display resolution, orientation and touch-screen assignment above. If a previous Windows calibration was applied, use Reset in Tablet PC Settings if available, then test again. On a normal rectangular touchscreen, Calibrate may help if offered. A round panel may hide the calibration corners; do not complete a calibration by guessing invisible points.

For the 6.2-inch cut panel, fix the visible picture area before attempting calibration. A calibration alone cannot reveal missing picture content. See the cut-panel product FAQ.

A side of the 6.2-inch picture is missing

The measured touch sample displays only part of the incoming picture. The Raspberry Pi application workaround is documented, but a whole-desktop Windows workaround has not been validated. Do not expect a different resolution, 60Hz or Windows touch calibration alone to fix the missing area. Send a full-screen photo and a screenshot of Advanced display so support can check your sample.

Do I need the scripts?

The screen-config, screen-test and Python cut-panel demo in these support pages are for Raspberry Pi OS with the documented desktop setup. They are not Windows programs. Windows users should start with the steps above and contact support if the problem remains.

Choose your product · Support home

Open the current online page

2.1-inch 480×480 single-screen touchscreen

The seller confirmed that the 2.1-inch single-screen range has a touch model. Check the touch option and resolution on your order. The seller confirmed a 480×480 resolution. Model-specific touch acceptance is still pending; resolution confirmation alone is not a completed test. This is separate from the non-touch dual-screen kits.

The screen goes black or flickers after moving a cable

Wait about 10-15 seconds without moving the cables. If the picture does not return, reconnect HDMI and USB power firmly at both ends. Try another cable if it happens repeatedly, and follow the product's power requirements.

Touch does nothing

Connect the USB power/touch data cable to the same computer or Pi sending the HDMI picture. A wall charger or charging-only cable cannot carry touch input to the host.

Touch operates another screen

Test this screen with its HDMI and USB cable first. If it still reaches another display on Windows, follow the Windows touch setup steps. These checks are general guidance, not a completed product-specific acceptance test.

Optional Raspberry Pi steps

Install the display tools and log into the graphical desktop first. These commands do not run on Windows. Use connector 2 instead of 1 if connected there:

```
screen-config list
screen-config modes --port 1
```

Share the listed resolution, a product-label photo and any remaining symptom with support. No specific timing override or calibration is confirmed for this entry; do not apply another product's profile.

Product directory

Open the current online page

2.1-inch dual-screen kit, 480×480 per screen, non-touch

The seller confirmed this 2.1-inch dual-screen option has two 480×480 panels and no touch. Check your order for round/square shape and same/different-content options. These options use different layouts; their exact mapping to the earlier test boards has not been established.

One or both screens stay black or flicker after a cable is moved

Wait about 10-15 seconds, then firmly reconnect HDMI and USB power if the picture does not return. Test with known-good cables and the specified supply. Do not reseat internal panel ribbons while powered. Send a photo showing both screens and the board label if it still fails.

Windows shows one display number, but there are two panels

This can be normal when one driver board feeds both panels from one HDMI cable. 480×480 is each panel's resolution. A same-content board can receive one 480×480 picture; a side-by-side different-content board can receive a combined 960×480 picture. Check the actual modes offered for your board; do not force one input for every kit.

Tapping either screen does nothing

This kit is non-touch. USB power does not add touch support. The 2.1-inch single-screen range also has touch models, sold as a separate option.

Which applications suit same or different content?

For these one-HDMI kits, same content repeats the full picture on both panels; different content uses a left/right picture prepared by the app, with one part on each panel. “Mirroring” here duplicates the picture in the same reading orientation; it does not reverse text horizontally.

Content / shape	Applications	Two-panel arrangement
Same / round	Music visualization, RGB ambience, desktop clock	Identical spectrum/light/time for symmetry or opposite viewers
Same / square	Retail offers, meeting-room status, parcel pickup	The same product/room/parcel information on both sides of a counter
Different / round	Flight, automotive instruments, PC monitoring	Left attitude/right airspeed; speed/engine; CPU/GPU
Different / square	Smart home, PC case, industrial equipment	Left environment/right energy; CPU/cooling; pump/trends

Choose the shape and option on your order. This table does not mean every combination is sold or physically tested at this size. Existing Pi showcases use simulated data; the music demo is silent. Real prices, calendars, shipments, weather and device data are not connected automatically.

Each showcase introduces brand/use case for 3s, then runs effects for 10s; three chapters loop in 39s. Same-content introductions/effects match on both panels. Different-content introductions show brand/use case on separate panels, followed by different effects. See use cases and board diagrams for the full explanation and script entrypoints.

Which demo should I use?

Choose the matching shape and same/different-content layout. These links describe earlier connection tests, not proof that every shape/layout has been tested at this size:

- Round / same content
- Round / different content

• Square / same content

• Square / different content

Start with the Windows checks when using a PC. Raspberry Pi commands in the linked demo pages are not Windows programs. No size-specific timing correction, universal 60Hz setting or touch calibration is claimed here.

How does the board distribute one picture to two panels?

“Driver” here means the hardware board and its firmware driving both panels, not a Windows driver you must install.

• Different-content board (SBS): the host/app prepares one combined left-A/right-B image. The board sends the left half to panel 1 and the right half to panel 2. For two 480×480 panels, a matching input example is 960×480. The app lays out both views beforehand; the board does not redesign an ordinary page into two complete interfaces.

• Same-content board (hardware clone): the host supplies complete A, and the board copies it to both panels. Each shows complete A in the normal reading orientation. Example input: 480×480, without a horizontal flip.

• SBS software duplication: the app prepares [A | A] in a double-width image, then the SBS board splits it. Both panels match, but still require double-width input rather than the single input used by a hardware-copy board.

One HDMI kit may occupy one OS monitor entry. Windows Duplicate/Extend controls host outputs, not the board's internal mapping. Use board documentation and actually offered modes; do not force all kits to 960×480 or 60Hz. Software duplication does not mean a copy board can be converted to different content.

Picture-flow diagrams, use cases and Pi commands. These explanations do not replace per-size, board or batch acceptance.

Confirmed information and remaining details

Seller-confirmed: 2.1 inches per panel, two panels, 480×480 per panel, non-touch. Pending: order/SKU, board revision, shape/layout assignment and per-size physical acceptance. Observed refresh rates belong to the linked connection records; they are not new recommended product specifications.

Product index

Open the current online page

2.8-inch 480×480 single-screen touchscreen

The seller confirmed that the 2.8-inch single-screen range has a touch model. Check the touch option and resolution on your order. The seller confirmed a 480×480 resolution. Model-specific touch acceptance is still pending; resolution confirmation alone is not a completed test. This is separate from the non-touch dual-screen kits.

The screen goes black or flickers after moving a cable

Wait about 10-15 seconds without moving the cables. If the picture does not return, reconnect HDMI and USB power firmly at both ends. Try another cable if it happens repeatedly, and follow the product's power requirements.

Touch does nothing

Connect the USB power/touch data cable to the same computer or Pi sending the HDMI picture. A wall charger or charging-only cable cannot carry touch input to the host.

Touch operates another screen

Test this screen with its HDMI and USB cable first. If it still reaches another display on Windows, follow the Windows touch setup steps. These checks are general guidance, not a completed product-specific acceptance test.

Optional Raspberry Pi steps

Install the display tools and log into the graphical desktop first. These commands do not run on Windows. Use connector 2 instead of 1 if connected there:

```
screen-config list
screen-config modes --port 1
```

Share the listed resolution, a product-label photo and any remaining symptom with support. No specific timing override or calibration is confirmed for this entry; do not apply another product's profile.

Product directory

Open the current online page

2.8-inch dual-screen kit, 480×480 per screen, non-touch

The seller confirmed this 2.8-inch dual-screen option has two 480×480 panels and no touch. Check your order for round/square shape and same/different-content options. These options use different layouts; their exact mapping to the earlier test boards has not been established.

One or both screens stay black or flicker after a cable is moved

Wait about 10-15 seconds, then firmly reconnect HDMI and USB power if the picture does not return. Test with known-good cables and the specified supply. Do not reseat internal panel ribbons while powered. Send a photo showing both screens and the board label if it still fails.

Windows shows one display number, but there are two panels

This can be normal when one driver board feeds both panels from one HDMI cable. 480×480 is each panel's resolution. A same-content board can receive one 480×480 picture; a side-by-side different-content board can receive a combined 960×480 picture. Check the actual modes offered for your board; do not force one input for every kit.

Tapping either screen does nothing

This kit is non-touch. USB power does not add touch support. The 2.8-inch single-screen range also has touch models, sold as a separate option.

Which applications suit same or different content?

For these one-HDMI kits, same content repeats the full picture on both panels; different content uses a left/right picture prepared by the app, with one part on each panel. “Mirroring” here duplicates the picture in the same reading orientation; it does not reverse text horizontally.

Content / shape	Applications	Two-panel arrangement
Same / round	Music visualization, RGB ambience, desktop clock	Identical spectrum/light/time for symmetry or opposite viewers
Same / square	Retail offers, meeting-room status, parcel pickup	The same product/room/parcel information on both sides of a counter
Different / round	Flight, automotive instruments, PC monitoring	Left attitude/right airspeed; speed/engine; CPU/GPU
Different / square	Smart home, PC case, industrial equipment	Left environment/right energy; CPU/cooling; pump/trends

Choose the shape and option on your order. This table does not mean every combination is sold or physically tested at this size. Existing Pi showcases use simulated data; the music demo is silent. Real prices, calendars, shipments, weather and device data are not connected automatically.

Each showcase introduces brand/use case for 3s, then runs effects for 10s; three chapters loop in 39s. Same-content introductions/effects match on both panels. Different-content introductions show brand/use case on separate panels, followed by different effects. See use cases and board diagrams for the full explanation and script entrypoints.

Which demo should I use?

Choose the matching shape and same/different-content layout. These links describe earlier connection tests, not proof that every shape/layout has been tested at this size:

- Round / same content
- Round / different content

• Square / same content

• Square / different content

Start with the Windows checks when using a PC. Raspberry Pi commands in the linked demo pages are not Windows programs. No size-specific timing correction, universal 60Hz setting or touch calibration is claimed here.

How does the board distribute one picture to two panels?

“Driver” here means the hardware board and its firmware driving both panels, not a Windows driver you must install.

• Different-content board (SBS): the host/app prepares one combined left-A/right-B image. The board sends the left half to panel 1 and the right half to panel 2. For two 480×480 panels, a matching input example is 960×480. The app lays out both views beforehand; the board does not redesign an ordinary page into two complete interfaces.

• Same-content board (hardware clone): the host supplies complete A, and the board copies it to both panels. Each shows complete A in the normal reading orientation. Example input: 480×480, without a horizontal flip.

• SBS software duplication: the app prepares [A | A] in a double-width image, then the SBS board splits it. Both panels match, but still require double-width input rather than the single input used by a hardware-copy board.

One HDMI kit may occupy one OS monitor entry. Windows Duplicate/Extend controls host outputs, not the board's internal mapping. Use board documentation and actually offered modes; do not force all kits to 960×480 or 60Hz. Software duplication does not mean a copy board can be converted to different content.

Picture-flow diagrams, use cases and Pi commands. These explanations do not replace per-size, board or batch acceptance.

Confirmed information and remaining details

Seller-confirmed: 2.8 inches per panel, two panels, 480×480 per panel, non-touch. Pending: order/SKU, board revision, shape/layout assignment and per-size physical acceptance. Observed refresh rates belong to the linked connection records; they are not new recommended product specifications.

Product index

Open the current online page

2.8-inch 480×480, touch status unconfirmed

Product option update: the 2.8-inch single-screen range has a touch model. This page retains an older black-screen pair whose exact SKU has not been matched; it does not mean the product range lacks touch. The current non-touch dual-screen kits are documented separately.

Please check the size, resolution and touch option on your order. Start with the simple checks below; no commands are needed.

The screen goes black or flickers after a cable is moved

• Leave the cables still and wait about 10-15 seconds for the picture to return.

• If it stays black, unplug and firmly reconnect HDMI and the USB power connection. Check both ends.

• Try another cable and test one screen at a time. Use the power supply specified for your screen.

If this happens every time a cable moves, try replacing that cable. If the screen never lights up, follow the same connection checks first.

Touch does nothing or controls another screen

• Connect the screen's USB power/touch cable to the same computer that is sending the picture. A wall charger can power the screen but cannot send your touches to the computer.

• Use a USB data cable. A charging-only cable may light the screen without making touch work.

• With two screens, check each screen's HDMI and USB cable as a pair. Try one screen with its USB cable first, then reconnect the other.

Check your order first: touch was not confirmed for the samples in this entry. A non-touch version will not respond to a finger.

What can I try in Windows?

Right-click the desktop and open Display settings. Select this screen, use its listed resolution and choose Extend these displays if you want separate screens. For flicker, open Advanced display and try 60Hz only if it is available for that screen.

If touch still goes to the wrong screen, search Windows for Calibrate the screen for pen or touch input. Open it, choose Setup, and follow the prompts to identify the touchscreen. Check the USB connection first.

Windows steps with more detail. The commands in the optional Raspberry Pi section below do not run on Windows.

Still black after these checks?

Please send a photo of the wiring, tell us whether the backlight or power light is on, and include your computer model. The black-screen issue for the tested pair is not yet resolved; we cannot promise a settings change will fix it.

Optional: Raspberry Pi instructions

Commands below run on the Raspberry Pi after installing the display tools. Use version 2.3.2+ for rectangular touch tests. Examples select connector 1 (HDMI-A-1, board HDMI0); replace 1 with 2 for connector 2 (board HDMI1). Run screen tests as the desktop user, without sudo.

The screen stays black after HDMI and power are connected

1. Leave only one screen connected. Check the rated supply, the power indicator and whether the backlight glows.

2. Power down the screen, reseat HDMI, then power it back on. Compare a known-good cable and another host.

3. Inspect what the Pi detects:

```
screen-config list
 screen-config modes --port 1
```

4. Only if screen information is readable and 480×480 at about 60Hz is listed, try:

```
screen-config set --port 1 --mode 480x480@60
 screen-test white --screen 1
 screen-test pattern --screen 1
```

These are troubleshooting steps, not a confirmed cure. One tested screen was already outputting 480×480 at 60Hz and still appeared black. If it remains black, send a photo of the connections and indicators, supply details and the command output to support. Do not use the 720-square or 6.2-strip profile.

The command shows “Remote I/O error”

The Pi could not read the display information on the tested connection, even though HDMI was detected. Recheck screen power, HDMI seating and cables. screen-config auto depends on that read and cannot repair the physical link. A reported 1024×768 fallback is not your panel's resolution. Contact support if the error persists after cable/power checks.

The screen displays a picture, but finger taps do nothing

Confirm your order is for the touch version, then check the USB data connection. If it has touch, follow the touch checklist. A non-touch version will not react to a finger. No calibration or cut-panel offset has been verified for these samples.

Open the current online page

3.4-inch 800×800 touchscreen

Please check the size, resolution and touch option on your order. Start with the simple checks below; no commands are needed.

The screen goes black or flickers after a cable is moved

• Leave the cables still and wait about 10-15 seconds for the picture to return.

• If it stays black, unplug and firmly reconnect HDMI and the USB power connection. Check both ends.

• Try another cable and test one screen at a time. Use the power supply specified for your screen.

If this happens every time a cable moves, try replacing that cable. If the screen never lights up, follow the same connection checks first.

Touch does nothing or controls another screen

• Connect the screen's USB power/touch cable to the same computer that is sending the picture. A wall charger can power the screen but cannot send your touches to the computer.

• Use a USB data cable. A charging-only cable may light the screen without making touch work.

• With two screens, check each screen's HDMI and USB cable as a pair. Try one screen with its USB cable first, then reconnect the other.

What can I try in Windows?

Right-click the desktop and open Display settings. Select this screen, use its listed resolution and choose Extend these displays if you want separate screens. For flicker, open Advanced display and try 60Hz only if it is available for that screen.

If touch still goes to the wrong screen, search Windows for Calibrate the screen for pen or touch input. Open it, choose Setup, and follow the prompts to identify the touchscreen. Check the USB connection first.

Windows steps with more detail. The commands in the optional Raspberry Pi section below do not run on Windows.

Still not working?

Please send a photo or short video, your computer model, and how HDMI and USB are connected. Raspberry Pi users can try the product-specific steps below after the basic checks.

Optional: Raspberry Pi instructions

Commands below run on the Raspberry Pi after installing the display tools. Use version 2.3.2+ for rectangular touch tests. Examples select connector 1 (HDMI-A-1, board HDMI0); replace 1 with 2 for connector 2 (board HDMI1). Run screen tests as the desktop user, without sudo.

After connecting the round screen, there is no picture or the picture looks wrong

This can happen when an output still uses the mode selected for a previously connected screen.

1. Check power and HDMI, then inspect the screen's available modes:

```
screen-config list
 screen-config modes --port 1
```

2. Only if 800×800 at approximately 60Hz is listed, select it and display the test:

```
screen-config set --port 1 --mode 800x800@60
 screen-test pattern --screen 1
```

3. If the physical picture is stable, save that selection:

```
screen-config set --port 1 --mode 800x800@60 --save
```

The sample displayed a stable picture after selecting 800×800 at 60Hz. If the mode is missing, send screen-config list and screen-config modes --port 1 to support; do not use the square-screen or strip-screen repair profile. These commands do not provide an automatic rollback.

Touch does not work or controls the other display

Connect the USB data cable, then run:

```
screen-test touch --screen 1 --shape round
```

Tap the five numbered circles, then slide. If touches appear on another screen, identify each USB touch cable and follow the pairing procedure. This procedure corrected the dual-touch problem in the tested setup.

The test screenshot has corners that are not visible on the screen

A round panel cannot show the four corners of a square 800×800 screenshot. Keep application buttons inside the visible circle and use --shape round for touch testing. A missing part of the circle or clipped center content is a different problem: send a photo to support. Do not apply the strip panel's 60-column offset.

The test window disappears after reconnecting

```
screen-test stop
screen-test touch --screen 1 --shape round
```

Open the current online page

4.0-inch 720×720 touchscreen

Please check the size, resolution and touch option on your order. Start with the simple checks below; no commands are needed.

The screen goes black or flickers after a cable is moved

• Leave the cables still and wait about 10-15 seconds for the picture to return.

• If it stays black, unplug and firmly reconnect HDMI and the USB power connection. Check both ends.

• Try another cable and test one screen at a time. Use the power supply specified for your screen.

If this happens every time a cable moves, try replacing that cable. If the screen never lights up, follow the same connection checks first.

Touch does nothing or controls another screen

• Connect the screen's USB power/touch cable to the same computer that is sending the picture. A wall charger can power the screen but cannot send your touches to the computer.

• Use a USB data cable. A charging-only cable may light the screen without making touch work.

• With two screens, check each screen's HDMI and USB cable as a pair. Try one screen with its USB cable first, then reconnect the other.

What can I try in Windows?

Right-click the desktop and open Display settings. Select this screen, use its listed resolution and choose Extend these displays if you want separate screens. For flicker, open Advanced display and try 60Hz only if it is available for that screen.

If touch still goes to the wrong screen, search Windows for Calibrate the screen for pen or touch input. Open it, choose Setup, and follow the prompts to identify the touchscreen. Check the USB connection first.

Windows steps with more detail. The commands in the optional Raspberry Pi section below do not run on Windows.

Still not working?

Please send a photo or short video, your computer model, and how HDMI and USB are connected. Raspberry Pi users can try the product-specific steps below after the basic checks.

Optional: Raspberry Pi instructions

Commands below run on the Raspberry Pi after installing the display tools. Use version 2.3.2+ for rectangular touch tests. Examples select connector 1 (HDMI-A-1, board HDMI0); replace 1 with 2 for connector 2 (board HDMI1). Run screen tests as the desktop user, without sudo.

The screen stays black or the picture flickers

What you may see: the display is powered and HDMI is connected, but there is no picture, or the picture appears and flickers.

1. Check the screen's rated power supply and HDMI cable; test one screen first.

2. Inspect the detected screen, then try the matching compatibility profile:

```
screen-config list
 screen-config apply --port 1 --profile 4.0inch-720x720-60hz-wks-lontium-semi
 screen-test pattern --screen 1
```

Save open desktop files first: applying the profile may restart the desktop. This command has no automatic timeout rollback. If the tool says the screen does not match, stop and contact support rather than force it.

3. Check that the picture is stable and all four edges are visible. If it passes, save:

```
screen-config apply --port 1 --profile 4.0inch-720x720-60hz-wks-lontium-semi --save
```

This timing correction worked on the tested sample. If you need to undo it and the screen information can be read, run screen-config auto --port 1 --save; the original symptom may return.

Touch does nothing, operates the other screen, or misses buttons

1. Connect a USB data cable to the touch socket; HDMI alone does not carry touch.

2. Open the target test:

```
screen-test touch --screen 1 --shape rect
```

3. Tap all five targets and slide a finger. Targets should turn green and the trail should follow the finger on the same screen.

4. If another screen responds, use the USB/HDMI pairing steps. Different screen models can report the same controller name.

If the trail is on the correct screen but remains offset, contact support with a photo and screen-config list; do not apply the 6.2-inch cut-panel correction to this square screen.

The test image disappears after changing cables

Restart the test window:

```
screen-test stop
screen-test pattern --screen 1
```

If the desktop is also absent, check screen power/connection and that the graphical desktop is logged in.

Open the current online page

6.2-inch 360×960 cut-panel touchscreen

Please check the size, resolution and touch option on your order. Start with the simple checks below; no commands are needed.

The screen goes black or flickers after a cable is moved

• Leave the cables still and wait about 10-15 seconds for the picture to return.

• If it stays black, unplug and firmly reconnect HDMI and the USB power connection. Check both ends.

• Try another cable and test one screen at a time. Use the power supply specified for your screen.

If this happens every time a cable moves, try replacing that cable. If the screen never lights up, follow the same connection checks first.

Touch does nothing or controls another screen

• Connect the screen's USB power/touch cable to the same computer that is sending the picture. A wall charger can power the screen but cannot send your touches to the computer.

• Use a USB data cable. A charging-only cable may light the screen without making touch work.

• With two screens, check each screen's HDMI and USB cable as a pair. Try one screen with its USB cable first, then reconnect the other.

What can I try in Windows?

Right-click the desktop and open Display settings. Select this screen, use its listed resolution and choose Extend these displays if you want separate screens. For flicker, open Advanced display and try 60Hz only if it is available for that screen.

If touch still goes to the wrong screen, search Windows for Calibrate the screen for pen or touch input. Open it, choose Setup, and follow the prompts to identify the touchscreen. Check the USB connection first.

Windows steps with more detail. The commands in the optional Raspberry Pi section below do not run on Windows.

The left side is cut off, or left-side touches miss buttons

This cut-glass sample needs a special picture layout. Changing Windows resolution alone has not been shown to fix it. Please send us a photo showing all four screen edges.

On Raspberry Pi, we confirmed a workaround inside a test app: the full picture became visible and touch lined up. It does not automatically fix Windows, the whole desktop or every app. The optional Raspberry Pi section below explains how to try it.

Optional: Raspberry Pi instructions

Commands below run on the Raspberry Pi after installing the display tools. Use version 2.3.2+ for rectangular touch tests. Examples select connector 1 (HDMI-A-1, board HDMI0); replace 1 with 2 for connector 2 (board HDMI1). Run screen tests as the desktop user, without sudo.

The left side is missing: text, buttons or targets are cut off

What you may see: right-side content looks complete, but the left border and left-side buttons are missing. Changing resolution alone may not help.

Try the included compensated test application:

1. Install display tools 2.3.2+ and download this support repository. Close any older temporary test window first.

2. From the support repository root, inspect the connected screen:

```
screen-config list
 screen-test stop
```

3. If the selected output is already 420×960, normal rotation, scale 1, run:

```
python3 product-support/6.2inch-360x960-touch/scripts/6.2inch-360x960-touch-window-demo.py --screen 1
```

4. Check that all four white borders and all five numbered circles are visible. Tap and slide to check touch alignment. Press Ctrl+C in the launching terminal to close the demo.

A prior temporary application using this method showed complete content and accurate touch on the sample. The included program reproduces that method and has had a launch/screenshot check; its new five-point UI still needs its own physical acceptance check. If the command rejects your output mode or the borders remain clipped, send a photo and screen-config list to support. Do not save an unverified profile or guess a new resolution.

Scope: compensation is inside this application only. The ordinary desktop, browser and stock screen-test are not automatically compensated. Applications intended for this screen need the same visible-area layout.

Buttons on the right are close, but left-side touches land too far left

First check that touch reaches this physical screen rather than another one; use the pairing guide if necessary. Then use the compensated demo above: it corrects the visible content and touch position together.

Tap the center and all four corner targets. A target should turn green and the white touch mark should follow your finger. If the input has already been calibrated elsewhere, do not apply the correction twice. Ordinary screen-test touch --shape rect changes target layout but does not include this cut-panel correction.

The picture flickers, even though content is visible

1. Check rated screen power and cables first.

2. If support confirms this sample matches the known touch-strip profile, try the timing correction below. Save desktop work first: applying it may restart the desktop, and it has no timed rollback.

```
screen-config apply --port 1 --profile 6.2inch-420x960-60hz-ltm-zl480 --confirm-profile
 screen-test pattern --screen 1
```

3. Inspect stability separately from image completeness. A 60Hz test improved flicker on an earlier touch sample, but it did not fix the missing left edge.

The successful cut-window and touch test used approximately 51.85Hz. The combined 60Hz-plus-compensation configuration still needs physical verification. Do not add --save on the strength of a stable picture alone.

Open the current online page

6.2-inch 360×960 cut panel, non-touch

Please check the size, resolution and touch option on your order. Start with the simple checks below; no commands are needed.

The screen goes black or flickers after a cable is moved

• Leave the cables still and wait about 10-15 seconds for the picture to return.

• If it stays black, unplug and firmly reconnect HDMI and the USB power connection. Check both ends.

• Try another cable and test one screen at a time. Use the power supply specified for your screen.

If this happens every time a cable moves, try replacing that cable. If the screen never lights up, follow the same connection checks first.

Tapping the screen does nothing

This is the non-touch version, so that is expected. If a second touchscreen controls this screen, check that the other screen's HDMI and USB cables go to the same computer, then set its touch screen in Windows as described below.

What can I try in Windows?

Right-click the desktop and open Display settings. Select this screen, use its listed resolution and choose Extend these displays if you want separate screens. For flicker, open Advanced display and try 60Hz only if it is available for that screen.

Windows steps with more detail. The commands in the optional Raspberry Pi section below do not run on Windows.

The screen keeps getting brighter and darker, or an edge is missing

Please send us a short video and your power connection details. The tested non-touch sample still had this issue after a 60Hz trial; we do not have a confirmed software fix for it. The touch version’s cut-screen workaround has not been confirmed for this version.

Optional: Raspberry Pi instructions

Commands below run on the Raspberry Pi after installing the display tools. Use version 2.3.2+ for rectangular touch tests. Examples select connector 1 (HDMI-A-1, board HDMI0); replace 1 with 2 for connector 2 (board HDMI1). Run screen tests as the desktop user, without sudo.

Brightness repeatedly gets lighter and darker

What you may see: the picture stays in place, but the backlight or overall brightness pulses.

1. Test one screen with its rated supply. Compare a known-good power cable and suitable independent supply, following the product's power specification.

2. Check and compare the HDMI cable and a known-good host.

3. Display white and a grid so changes are easier to observe:

```
screen-config list
 screen-test white --screen 1
 screen-test pattern --screen 1
```

If it persists, send support a short video, supply details and screen-config list. A 60Hz timing test did not solve this sample, so there is no verified profile to recommend. Do not apply the touch-model profile just because the screen name matches.

The left edge is missing or the image is cropped

Use screen-test pattern --screen 1 and photograph all four screen edges. The touch version required a special visible-area layout, but its exact offset has not been measured or confirmed for this non-touch version. Contact support to measure your sample before adopting that layout.

Touch targets appear, but tapping does nothing

This is expected: the non-touch version has no touch input. Use color and geometry tests instead:

```
screen-test cycle --screen 1 --interval 5
screen-test pattern --screen 1
```

If another attached touchscreen controls this screen, follow the mixed-screen pairing procedure; map that touchscreen only to its own display.

The picture disappears after reconnecting

```
screen-test stop
screen-test pattern --screen 1
```

If it remains black, check power, backlight and screen detection before trying timing changes. Report any Remote I/O error to support with the connection details.

Open the current online page

Same-content and different-content dual screens: uses and driver-board logic

For kits with one HDMI cable feeding a board connected to two panels. Check your order for same/different content and round/square shape. The current 2.1-inch and 2.8-inch kits each have two 480×480 non-touch panels. Exact shape/board assignments to earlier samples still need confirmation.

What should the two screens show?

Choose	Visible result	Suitable uses
Same content	Both show the same complete picture, such as one promotion on both sides	Opposite viewers, repeated information, symmetrical decoration
Different content	Each shows a different part of one complete input canvas, such as instruments on the left and status on the right	Multiple metrics, primary/secondary information, coordinated dashboards

For these one-HDMI kits, same content repeats the full picture on both panels; different content uses a left/right picture prepared by the app, with one part on each panel. Here, “mirroring” means duplicating the picture in the same reading orientation, not horizontally reversing the text.

Which applications fit each choice?

These Raspberry Pi demos are implemented use cases, not proof that every size, shape or board has passed physical tests. The table does not establish that every configuration is sold for each size; check your order.

Content / shape	Application	What the panels show
Same / round	Music visualization	Identical colored spectra, sample track information and beat halos
Same / round	RGB ambience	Identical flowing rings and breathing effects on both sides of a desk or speakers
Same / round	Desktop clock	Identical time and sample weather for viewers on opposite sides
Same / square	Retail promotions	Identical products, sample prices and offer copy
Same / square	Meeting-room status	Identical availability/occupancy and demo countdown
Same / square	Parcel pickup	Identical sample shipment status and collection reference
Different / round	Flight instruments	Left attitude/heading; right airspeed/altitude
Different / round	Automotive instruments	Left speed/RPM/gear; right engine/fuel/voltage
Different / round	PC case	Left CPU/RAM; right GPU/cooling
Different / square	Smart home	Left environment/lighting; right solar/household power

Content / shape	Application	What the panels show
Different / square	PC case	Left CPU/RAM/trends; right GPU/temperature/fans
Different / square	Industrial equipment	Left pump/pressure/flow; right trends/equipment status

Product showcases use simulated data. The music demo neither captures nor plays sound. Weather, prices, calendars and shipments do not connect to real services automatically. Flight, vehicle and industrial pages do not establish real-device connection or control. Actual data integration requires the appropriate software and source separately.

Why does each different-content panel show half a picture?

If one ordinary page fills a double-width canvas, splitting it gives each panel only part of that page. This can be the expected board behavior rather than missing pixels.

1. Confirm the product option and board input, not only the OS display number.

2. Prepare two complete views in the host application: one on the left, one on the right.

3. For two 480×480 panels, a supported side-by-side board can receive one 960×480 canvas: left 480×480 to panel 1, right 480×480 to panel 2. Use the actual board documentation and offered modes.

4. Check that each panel's borders and text are complete. Round layouts must keep important content inside the visible circle.

The board distributes pixels; it does not open two applications or redesign an ordinary page into two complete interfaces. If it still looks wrong, check cables/power and provide a photo of both panels, the host screenshot and the current input mode.

Does same content also need two halves?

A hardware-copy board needs one complete picture, then duplicates it to both panels. For example, one 480×480 input can repeat on two 480×480 panels. Do not force 960×480 merely because there are two panels.

An SBS board can also show the same content through software: the application repeats the complete picture in both halves of a double-width canvas, and the board splits it normally. Software duplication still uses the SBS double-width input; hardware copying uses a single-picture input. Supported modes depend on the board. This does not imply interchangeable boards or a firmware conversion.

Can Windows Duplicate/Extend switch the board mode?

One HDMI kit may correctly appear as one logical monitor. Windows Duplicate/Extend controls host outputs, not how this board splits or duplicates its input internally.

Start with Windows Display settings and the modes actually offered by the board. SBS requires a matching two-region layout; a hardware-copy board requires its matching single picture. Pi demo scripts do not run on Windows and do not establish Windows physical acceptance for these kits.

Optional: run a three-use-case showcase on the Pi

Install the complete dual-display app repository, v0.10.2 or a later compatible release. Follow its README for dependencies and signal requirements. Tested environment: Pi 4B, Bookworm Desktop 64-bit, labwc/Wayland. Use SSH as the ordinary user who owns the logged-in graphical desktop, without sudo.

Family	Script	Sequence
Same / round	./demos/same/round/demo	Music → RGB ambience → clock
Same / square	./demos/same/square/demo	Retail → room status → pickup

Family	Script	Sequence
Different / round	./demos/different/round/demo	Flight → automotive → PC case
Different / square	./demos/different/square/demo	Home → PC case → pump

Each chapter introduces the brand/use case for 3s, then runs the effect for 10s; 39s loop. Same-content introductions and effects are identical. Different-content introductions show brand/icon on the left and use-case/metrics on the right; effects show different information.

Example for a confirmed square hardware-copy board, from the complete app directory:

```
cd ~/apps/lvgl-embedded-gui-demos
./app --version
./app stop --port 1
./demos/same/square/demo check --port 1 --size 480
./demos/same/square/demo start --port 1 --size 480
```

Stop targets this project only; use another tool's own normal stop command if it occupies the output. Before upgrading, stop the old version using its existing code, then update the complete project rather than overwriting running files.

Same-content scripts default to --signal clone for hardware copying. For an actual SBS board supporting double-width input, add --signal sbs to both check/start. Do not change to another board's geometry or rate merely to pass validation. Specific recorded rates and evidence are in the connection records; 480×480 per panel does not establish a universal 60Hz or other tested rate.

Public port 1/2 = Linux HDMI-A-1/2 = Pi 4 board HDMI0/1. This identifies the host connector, not the board's left/right panels. Change to --port 2 if wired to connector 2.

Inspect or stop later:

```
./demos/same/square/demo status --port 1
./demos/same/square/demo stop --port 1
```

These app commands do not change timings, EDID, screen firmware or system mirroring, and do not restart the desktop. No timed rollback is provided. If check fails, verify the board/mode; failure does not create a missing mode. start runs in the background after SSH exits while the desktop stays logged in. Normal stop closes this project's window. Disconnecting/changing boards can end the app; reconnect stably and check/start again rather than assuming automatic recovery.

Open the current online page

TEKGROAML 显示屏支持中心

按尺寸 - 分辨率 - 是否触摸进入产品FAQ目录。每款独立提供英文、中文，互有语言切换链接；默认入口英文。更新：2026-11-08。

先从你看到的现象开始：黑屏或闪烁、触摸没反应或不准、画面显示不完整。进入对应产品后先看处理步骤，详细参数在各FAQ末尾。

先别急着改设置

• 碰线后黑屏或闪烁？先别动线，等约10～15秒；没恢复就拔下HDMI和USB供电线重新插紧。每次碰线都发生，优先换线。

• 触摸没反应，或跑到另一屏？触摸款的USB供电 / 触摸数据线要插到正在输出画面的同一台电脑或树莓派上，不是只插充电头。每块屏的HDMI与USB成组核对，纯充电线不能传触摸。

• 用Windows？先看Windows画面及触摸操作，本仓库的树莓派命令不能在Windows运行。

产品选项已确认：当前双屏套装都不带触摸；2.1英寸和2.8英寸单屏系列均有触摸型号。这两种单屏触摸款均已确认480×480；专属实体验收仍待完成。此前2.8英寸黑屏双屏记录尚未与具体触摸 / 非触摸SKU对应。

产品	中文FAQ	English FAQ
2.1英寸480×480单屏触摸款	中文	English
2.1英寸双屏，每屏480×480，非触摸	中文	English
2.8英寸480×480单屏触摸款	中文	English
2.8英寸双屏，每屏480×480，非触摸	中文	English
2.8英寸480×480历史双屏记录（具体款式待核对）	中文	English
3.4英寸800×800触摸屏	中文	English
4.0英寸720×720触摸屏	中文	English
6.2英寸360×960切割触摸屏	中文	English
6.2英寸360×960切割非触摸屏	中文	English

双屏同显与异显：场景和画面分配

本系列一根HDMI带两屏：同显时两屏重复完整画面；异显时应用先准备左右两页，再分别显示到两屏。 同显适合重复信息 / 对称装饰，异显适合仪表 / 主辅看板。这里“镜像”表示正常方向的画面复制，不是文字左右翻转。

查看圆形 / 方形应用场景、驱动板流向图与演示入口。一根HDMI在系统里只显示一个编号可以是正常的；同显板的单幅输入与SBS板的双宽输入不能直接混用。

非触摸双屏套装（尺寸待核对）

按形状与同显 / 异显查看：圆形异显、方形异显、圆形同显、方形同显。新增问题包括只有一块显示、换屏后演示停止、480×480与960×480输入混用，以及应用未接受实际上报的约62.811 / 71.295Hz。

这些是待核对的连接样本，不是已确认的新SKU，不插入上方按英寸升序的产品表，也不归到2.8英寸款。Windows与树莓派分别说明；刷新率兼容更新只改变应用接受范围，没有改屏幕时序。

非触摸双屏套装列表

各套装尺寸仍待对应，以下四种配置均已确认不带触摸。

套装	FAQ	
圆形双屏 / 同显 / 非触摸	中文	English

套装	FAQ	
圆形双屏 / 异显 / 非触摸	中文	English
方形双屏 / 同显 / 非触摸	中文	English
方形双屏 / 异显 / 非触摸	中文	English

会用 GPT 或 Claude？让 AI 帮你一起搞定

把这份文档、配套测试工具，以及想体验的场景仓库下载下来，交给你常用的 AI。接下来，把你想做的事告诉它，向 AI“许愿”就好。如果 AI 能读取项目并操作你的电脑或树莓派，它就可以帮你检查设置、执行测试、部署支持的演示场景。

- 产品文档与FAQ
- 屏幕配置与测试工具
- 圆屏 Home Assistant 场景演示

可以直接这样说：

请先阅读这些仓库。我有一块[尺寸 / 分辨率 / 是否触摸]屏幕，连接的是[Windows电脑 / 树莓派]。我想[修好显示 / 测试触摸 / 运行某个演示]。请先检查接线和支持范围，再一步步帮我完成；修改设置时保留恢复方法。

告诉它屏幕型号、HDMI和USB怎么接，以及现在看到的现象。普通聊天AI可以指导你操作；直接执行命令需要使用带操作工具的AI，并由你提供访问权限。接线或硬件故障仍可能需要你动手检查，或联系我们协助。树莓派脚本不能直接在Windows运行。

各产品包含黑屏 / 闪烁、触摸问题及切割屏补偿三类内容，并区分已验证与未解决问题。输入分辨率与物理可见区域分开记录，未知规格不通过控制器名称推断。

- 通用流程与全部测试场景
- 通用客户触摸FAQ
- 配套程序与安装

切割屏目前是应用内补偿，未宣称整个桌面或开机自动补偿。历史产品及配置包链接保留在产品目录中，文档可独立下载。

打开此页的最新在线文档

Windows：画面和触摸先这样检查

先做这些检查，不用一上来安装驱动或运行脚本。适用于Windows 10 / 11的常见操作，菜单名称可能略有不同。树莓派测试成功，不代表Windows也已验证通过。

碰一下线，屏幕就黑了或闪了

1. 先别动线，等约10～15秒。

2. 没恢复，就拔下HDMI和USB供电线重新插紧，电脑端也检查。

3. 换线试试，先只接一块屏，供电按商品要求连接。

如果轻碰就反复发生，优先换线，不要先改屏幕固件。

双屏套装只显示一个编号，或不能分别显示

一根HDMI连接的双面板驱动板，系统只看到一个逻辑显示器可能是正常的：硬件同显板把一张图送到两个面板，SBS板把双宽图分到左右。Windows“复制 / 扩展”改变的是主机输出，不能改变板内分配方式。

1. 先按商品说明确认同显还是异显，核对一根还是两根HDMI。

2. 只选择本板实际提供且与资料匹配的输入；不能把单幅480×480板强制改成960×480，也不能用普通应用全屏就保证SBS两区各有完整内容。

3. 只有一块亮时，先等待、重插HDMI / USB供电，再对照线材与额定电源；系统截图完整不证明两个面板都收到信号。

待确认双屏样本包含Pi侧记录，不是Windows驱动或该套装已完成Windows验收。约71.295Hz是特定连接的上报记录，不是通用目标。不要为通过Pi演示检查强制改变Windows刷新率。

还是没画面、闪烁，或显示大小不对

1. 桌面右键→显示设置→标识，选中小屏幕。

2. 如果列表支持，选择与商品对应的分辨率，不照搬另一块屏的设置。

3. 双屏想分别显示时选扩展这些显示器；复制模式可能限制可选分辨率。

4. 进入高级显示，仍选这块屏，仅在列表支持时尝试60Hz。没有该选项或效果更差就恢复原设置。只有画面正常时才确认保留；Windows通常会短暂询问保留还是还原。

5. 四边完整但字太大时，可调整缩放。它只改变文字和软件大小，不能找回被屏幕硬件截掉的像素。

Windows完全检测不到屏幕时，先查供电和HDMI，再换已知正常的接口、线或电脑。能检测但仍黑屏时，提供照片和已选分辨率 / 刷新率联系支持。

有画面，但手指点了没反应

触摸款随附的USB供电 / 触摸线也传输触摸数据，必须接到正在通过HDMI输出画面的同一台电脑，不能只插充电头。用能传数据的USB线，纯充电线不行。非触摸款不会响应手指。

换电脑上的USB口，暂时绕过集线器，重新插接USB。打开设备管理器→人体学输入设备，查看是否有类似符合HID标准的触摸屏。若被禁用，可启用；若没有或带警告，先换数据线和接口，再联系支持，不先安装来路不明的驱动，也不禁用其他输入设备。

点小屏，却在另一块屏上操作

1. 核对每块屏的两根线是否接到正确主机，先逐块连接HDMI和USB测试。

2. 接回双屏，在显示设置中点标识确认编号。

3. 开始菜单搜索校准笔和触控输入的屏幕，在Tablet PC设置中点设置（Setup）；如有询问，选触摸输入。

4. 按提示触摸对应屏幕。提示出现在非触摸屏时，按Enter移到下一屏，完成后分别测试。

先做Setup，它用于指定触摸对应哪块屏，不是直接校准。不同Windows和控制器可用选项可能不同。如果没有此项，或仍控制同一屏，请提供接线照片及设备管理器截图。树莓派USB映射脚本不能配置Windows。

响应在本屏，但触点和手指对不上

先确认上面的分辨率、方向和触摸对应屏幕。如果以前做过Windows校准，可在Tablet PC设置中用重置（Reset）（如可用）后再试。普通矩形触摸屏可尝试校准（Calibrate）；圆屏可能看不到角落校准点，不要凭猜测点击隐藏位置。

6.2英寸切割屏先处理画面可见区域，再考虑校准；校准本身不能恢复被截掉的内容。见切割屏产品FAQ。

6.2英寸屏幕左边内容不全

已测触摸样机只显示输入画面的一部分。文档里的树莓派应用补偿已验证过，但尚未验证Windows整个桌面的修复方案。不保证改分辨率、60Hz或做触摸校准就能恢复。请发完整屏幕照片及高级显示截图，由支持核对实物。

我需要运行脚本吗？

本支持文档里的screen-config、screen-test和Python切割屏演示，适用于树莓派及文档指定的图形桌面环境，不是Windows软件。Windows先按上面步骤处理，未恢复再联系支持。

选择产品 · 支持首页

打开此页的最新在线文档

2.1英寸480×480单屏触摸款

卖家已确认2.1英寸单屏系列有触摸型号。请核对订单的触摸选项和分辨率，卖家已确认分辨率为480×480，专属触摸验收仍待完成；规格确认不代表测试已通过。本款与非触摸双屏套装分开说明。

碰线后黑屏或闪烁

先不动线，等约10～15秒。没恢复就重新插紧HDMI和USB供电线，两端都检查；反复发生优先换线，供电按商品要求。

点击没反应

USB供电 / 触摸数据线要接到正在输出HDMI画面的同一台电脑或树莓派。只插充电头、使用纯充电线，都不能把触摸传给主机。

点击却控制了另一块屏

先只接本屏及其HDMI、USB线测试。Windows仍串屏时按Windows触摸设置操作。这些是通用检查，不代表本型号已经完成触摸验收。

可选：树莓派检查

先安装显示工具并登录图形桌面。命令不适用于Windows，接接口2时替换数字：

```
screen-config list
screen-config modes --port 1
```

将模式结果、商品标签照片和现象提供给支持。本条目没有已确认的专用时序或校准参数，不套用其他型号的修复档。

产品目录

打开此页的最新在线文档

2.1英寸双屏套装，每屏480×480，非触摸

卖家已确认本2.1英寸双屏选项为两块480×480屏幕，均不带触摸。圆形 / 方形、同显 / 异显请按订单核对，各选项布局不同；与此前测试板卡的具体对应尚未建立。

碰线后只有一块亮，或两块都黑 / 闪烁

先等约10～15秒，没恢复再插紧HDMI和USB供电线。对照已知良好的线及额定电源，不带电重新插接内部排线。仍异常时，提供两块屏及板卡标签照片。

Windows只显示一个编号，但实际有两块屏

一块驱动板通过一根HDMI带两块屏时，可能就是这样。480×480是每块屏的分辨率：同显板可接收一路480×480画面，左右异显板可接收两区合起来的960×480画面。以当前板卡实际提供的模式为准，不对所有套装强制同一种输入。

手指点击没反应

本双屏不带触摸，USB供电不会增加触摸功能。2.1英寸单屏系列另有触摸型号，是不同选项。

同显和异显分别适合什么应用？

本系列一根HDMI带两屏：同显时两屏重复完整画面；异显时应用先准备左右两页，再分别显示到两屏。 同显的“镜像”表示重复同一画面，文字方向相同，不是左右翻转。

显示关系 / 形状	应用例子	两屏内容
同显 / 圆形	音乐律动、RGB氛围、桌面信息钟	两屏相同频谱 / 光环 / 时间，适合对称装饰、对向观看
同显 / 方形	门店促销、会议室状态、物流取件	两屏重复同一商品 / 房间 / 包裹信息，适合柜台两侧
异显 / 圆形	飞行、汽车仪表、PC机箱监控	左姿态右空速；左车速右发动机；左CPU右GPU
异显 / 方形	智能家居、PC机箱、工业设备	左环境右能源；左CPU右散热；左泵站右趋势

按订单的形状和显示选项选择，不表示上表每种组合都已在本尺寸完成测试或全部在售。现有树莓派演示使用模拟数据，音乐演示无声，不自动连接真实价格、日历、物流、天气或设备。

现有脚本每组先介绍品牌与场景3秒，再展示效果10秒，三组共39秒。同显介绍 / 效果均两屏相同；异显介绍左品牌 / 右用途，效果两屏不同。用途与驱动板图解有完整说明和脚本入口。

应该选哪个演示？

按形状及同显 / 异显选择。以下是此前连接记录，不代表每种形状和布局都已在本尺寸完成测试：

- 圆形同显
- 圆形异显
- 方形同显
- 方形异显

电脑用户先看Windows操作，链接中的树莓派命令不适用于Windows。本页不宣称已有本尺寸专用时序修复、所有套装统一60Hz或触摸校准。

驱动板怎样把一张图送到两块屏？

这里“驱动”指连接两面板的硬件驱动板及其固件，不是要求另装Windows驱动。

• 异显板（左右分区 / SBS）：主机 / 应用先准备一张含左页A、右页B的合成画面，板子把左半送屏1、右半送屏2。每屏480×480时，匹配的输入示例为960×480。两页内容由应用预先排好，板子不会自动把普通页面排成两个完整界面。

• 同显板（硬件复制 / clone）：主机提供一张完整A，板子复制给两块屏，各屏都是完整A。输入示例为480×480，画面正常阅读，不做水平翻转。

• SBS软件同显：应用把A重复成[A | A]的双宽画面，再由SBS板拆分，两屏也会相同；仍需双宽输入，不能当作单幅输入板来设置。

一根HDMI在系统里可以只占一个显示器编号。Windows“复制 / 扩展”针对主机输出，不自动切换驱动板内部逻辑。实际输入和硬件模式切换能力以板卡资料 / 系统提供模式为准，不强制所有套装960×480或60Hz；软件同显不表示同显板可改成异显板。

查看画面流向图、场景说明与Pi命令。这些说明不代替逐尺寸、板卡与批次验收。

已确认与待补充

卖家确认：每屏2.1英寸、两块屏、每屏480×480、非触摸。待补充：SKU、板卡修订、形状和布局归属，以及逐尺寸实体验收。历史刷新率属于连接记录，不直接作为本产品新的推荐规格。

产品目录

打开此页的最新在线文档

2.8英寸480×480单屏触摸款

卖家已确认2.8英寸单屏系列有触摸型号。请核对订单的触摸选项和分辨率，卖家已确认分辨率为480×480，专属触摸验收仍待完成；规格确认不代表测试已通过。本款与非触摸双屏套装分开说明。

碰线后黑屏或闪烁

先不动线，等约10～15秒。没恢复就重新插紧HDMI和USB供电线，两端都检查；反复发生优先换线，供电按商品要求。

点击没反应

USB供电 / 触摸数据线要接到正在输出HDMI画面的同一台电脑或树莓派。只插充电头、使用纯充电线，都不能把触摸传给主机。

点击却控制了另一块屏

先只接本屏及其HDMI、USB线测试。Windows仍串屏时按Windows触摸设置操作。这些是通用检查，不代表本型号已经完成触摸验收。

可选：树莓派检查

先安装显示工具并登录图形桌面。命令不适用于Windows，接接口2时替换数字：

```
screen-config list
screen-config modes --port 1
```

将模式结果、商品标签照片和现象提供给支持。本条目没有已确认的专用时序或校准参数，不套用其他型号的修复档。

产品目录

打开此页的最新在线文档

2.8英寸双屏套装，每屏480×480，非触摸

卖家已确认本2.8英寸双屏选项为两块480×480屏幕，均不带触摸。圆形 / 方形、同显 / 异显请按订单核对，各选项布局不同；与此前测试板卡的具体对应尚未建立。

碰线后只有一块亮，或两块都黑 / 闪烁

先等约10～15秒，没恢复再插紧HDMI和USB供电线。对照已知良好的线及额定电源，不带电重新插接内部排线。仍异常时，提供两块屏及板卡标签照片。

Windows只显示一个编号，但实际有两块屏

一块驱动板通过一根HDMI带两块屏时，可能就是这样。480×480是每块屏的分辨率：同显板可接收一路480×480画面，左右异显板可接收两区合起来的960×480画面。以当前板卡实际提供的模式为准，不对所有套装强制同一种输入。

手指点击没反应

本双屏不带触摸，USB供电不会增加触摸功能。2.8英寸单屏系列另有触摸型号，是不同选项。

同显和异显分别适合什么应用？

本系列一根HDMI带两屏：同显时两屏重复完整画面；异显时应用先准备左右两页，再分别显示到两屏。 同显的“镜像”表示重复同一画面，文字方向相同，不是左右翻转。

显示关系 / 形状	应用例子	两屏内容
同显 / 圆形	音乐律动、RGB氛围、桌面信息钟	两屏相同频谱 / 光环 / 时间，适合对称装饰、对向观看
同显 / 方形	门店促销、会议室状态、物流取件	两屏重复同一商品 / 房间 / 包裹信息，适合柜台两侧
异显 / 圆形	飞行、汽车仪表、PC机箱监控	左姿态右空速；左车速右发动机；左CPU右GPU
异显 / 方形	智能家居、PC机箱、工业设备	左环境右能源；左CPU右散热；左泵站右趋势

按订单的形状和显示选项选择，不表示上表每种组合都已在本尺寸完成测试或全部在售。现有树莓派演示使用模拟数据，音乐演示无声，不自动连接真实价格、日历、物流、天气或设备。

现有脚本每组先介绍品牌与场景3秒，再展示效果10秒，三组共39秒。同显介绍 / 效果均两屏相同；异显介绍左品牌 / 右用途，效果两屏不同。用途与驱动板图解有完整说明和脚本入口。

应该选哪个演示？

按形状及同显 / 异显选择。以下是此前连接记录，不代表每种形状和布局都已在本尺寸完成测试：

- 圆形同显
- 圆形异显
- 方形同显
- 方形异显

电脑用户先看Windows操作，链接中的树莓派命令不适用于Windows。本页不宣称已有本尺寸专用时序修复、所有套装统一60Hz或触摸校准。

驱动板怎样把一张图送到两块屏？

这里“驱动”指连接两面板的硬件驱动板及其固件，不是要求另装Windows驱动。

• 异显板（左右分区 / SBS）：主机 / 应用先准备一张含左页A、右页B的合成画面，板子把左半送屏1、右半送屏2。每屏480×480时，匹配的输入示例为960×480。两页内容由应用预先排好，板子不会自动把普通页面排成两个完整界面。

• 同显板（硬件复制 / clone）：主机提供一张完整A，板子复制给两块屏，各屏都是完整A。输入示例为480×480，画面正常阅读，不做水平翻转。

• SBS软件同显：应用把A重复成[A | A]的双宽画面，再由SBS板拆分，两屏也会相同；仍需双宽输入，不能当作单幅输入板来设置。

一根HDMI在系统里可以只占一个显示器编号。Windows“复制 / 扩展”针对主机输出，不自动切换驱动板内部逻辑。实际输入和硬件模式切换能力以板卡资料 / 系统提供模式为准，不强制所有套装960×480或60Hz；软件同显不表示同显板可改成异显板。

查看画面流向图、场景说明与Pi命令。这些说明不代替逐尺寸、板卡与批次验收。

已确认与待补充

卖家确认：每屏2.8英寸、两块屏、每屏480×480、非触摸。待补充：SKU、板卡修订、形状和布局归属，以及逐尺寸实体验收。历史刷新率属于连接记录，不直接作为本产品新的推荐规格。

产品目录

打开此页的最新在线文档

2.8英寸480×480，触摸属性待确认

产品选项补充：2.8英寸单屏系列有触摸型号。本页保留的是此前未核对具体SKU的双屏黑屏记录，不表示该系列没有触摸款；当前非触摸双屏套装另行记录。

先核对订单上的尺寸、分辨率和触摸选项。优先做下面的接线检查，不用先运行脚本。

碰到连接线后，突然黑屏或闪烁

• 先不要动线，等约10～15秒，看画面是否恢复。

• 还没恢复，就拔下HDMI和USB供电线，重新插紧，两端都检查一下。

• 换一根线试试，先只接一块屏幕。供电按商品要求连接。

如果每次碰线都会发生，优先换线。一直不亮时，也先从这些接线检查开始。

触摸没反应，或点这块屏却响应到另一块

• 先看屏幕的USB供电 / 触摸线有没有插到正在输出画面的那台电脑或树莓派上。只插充电头，屏幕可能会亮，但触摸传不到主机。

• 用能传数据的USB线。只能充电的线可能让屏幕亮起来，却不能触摸。

• 双屏时，把每块屏幕的HDMI和USB线成组核对。先只接一块及其USB线，确认后再接另一块。

请先核对订单是否带触摸；本条目样机的触摸选项尚未确认，非触摸版不会响应手指。

Windows电脑可以先试什么？

桌面右键打开显示设置，选中这块屏幕，选择列表中的对应分辨率。双屏想分别显示时选扩展这些显示器。如果闪烁，进入高级显示，仅在列表支持时尝试60Hz。

触摸仍跑到另一屏时，在Windows中搜索校准笔和触控输入的屏幕，打开后选设置（Setup），按提示指定触摸屏。先确认USB线接对，再做这一步。

Windows详细操作。后面的树莓派命令不能在Windows中运行。

做完还是黑屏？

请发接线照片，说明背光或电源灯是否亮、使用什么电脑。已测双屏黑屏问题尚未解决，不能保证改设置就能修好。

可选：树莓派操作

以下命令在安装显示工具后的树莓派中执行，矩形触摸测试需2.3.2+。示例为接口1（HDMI-A-1，板上HDMI0），接口2（板上HDMI1）替换数字。测试命令使用桌面用户，不加sudo。

HDMI和电源都接了，但屏幕一直黑

1. 先只接一块，检查额定电源、电源指示灯及背光是否发亮。

2. 屏幕断电后重新插紧HDMI，再供电；对照已知良好的线及另一台主机。

3. 查看树莓派识别结果：

```
screen-config list
 screen-config modes --port 1
```

4. 仅当屏幕信息可读且存在约60Hz的480×480时，尝试：

```
screen-config set --port 1 --mode 480x480@60
 screen-test white --screen 1
 screen-test pattern --screen 1
```

以上是排查步骤，不是已确认修复。已测一块即使输出480×480、60Hz仍黑。若未恢复，提供接线及指示灯照片、电源信息和命令结果联系支持，不套用720方屏或6.2长条档。

执行命令出现“Remote I/O error”

测试连接上，树莓派虽然检测到HDMI，却无法读取显示信息。重新检查屏幕供电、HDMI接触及线材。screen-config auto依赖该读取，无法修复物理链路；回退显示1024×768不代表面板就是这个分辨率。换线及供电检查后仍报错，请联系支持。

能显示，但手指点击没反应

先确认订单是触摸版，再查USB数据连接。带触摸时按触摸检查流程处理；非触摸版不会响应手指。本次样机没有已验证校准或切割偏移参数。

打开此页的最新在线文档

3.4英寸800×800触摸屏

先核对订单上的尺寸、分辨率和触摸选项。优先做下面的接线检查，不用先运行脚本。

碰到连接线后，突然黑屏或闪烁

• 先不要动线，等约10～15秒，看画面是否恢复。

• 还没恢复，就拔下HDMI和USB供电线，重新插紧，两端都检查一下。

• 换一根线试试，先只接一块屏幕。供电按商品要求连接。

如果每次碰线都会发生，优先换线。一直不亮时，也先从这些接线检查开始。

触摸没反应，或点这块屏却响应到另一块

• 先看屏幕的USB供电 / 触摸线有没有插到正在输出画面的那台电脑或树莓派上。只插充电头，屏幕可能会亮，但触摸传不到主机。

• 用能传数据的USB线。只能充电的线可能让屏幕亮起来，却不能触摸。

• 双屏时，把每块屏幕的HDMI和USB线成组核对。先只接一块及其USB线，确认后再接另一块。

Windows电脑可以先试什么？

桌面右键打开显示设置，选中这块屏幕，选择列表中的对应分辨率。双屏想分别显示时选扩展这些显示器。如果闪烁，进入高级显示，仅在列表支持时尝试60Hz。

触摸仍跑到另一屏时，在Windows中搜索校准笔和触控输入的屏幕，打开后选设置（Setup），按提示指定触摸屏。先确认USB线接对，再做这一步。

Windows详细操作。后面的树莓派命令不能在Windows中运行。

还是不正常？

请发照片或短视频，说明电脑型号以及HDMI、USB怎么接。树莓派用户完成基本检查后，再按下面的产品专属步骤尝试。

可选：树莓派操作

以下命令在安装显示工具后的树莓派中执行，矩形触摸测试需2.3.2+。示例为接口1（HDMI-A-1，板上HDMI0），接口2（板上HDMI1）替换数字。测试命令使用桌面用户，不加sudo。

换上圆屏后没画面，或画面显示不对

换屏后，接口可能仍沿用上一块屏幕的模式。

1. 检查供电和HDMI，再查看可用模式：

```
screen-config list
 screen-config modes --port 1
```

2. 仅当列表存在约60Hz的800×800时，选择该模式并打开测试：

```
screen-config set --port 1 --mode 800x800@60
 screen-test pattern --screen 1
```

3. 实体画面稳定后保存：

```
screen-config set --port 1 --mode 800x800@60 --save
```

样机选择800×800、60Hz后画面稳定。若没有该模式，向支持提供上述list和modes结果，不套用方屏或长条屏档；这些命令没有自动恢复倒计时。

触摸无反应，或另一块屏幕在响应

接上USB数据线后执行：

```
screen-test touch --screen 1 --shape round
```

点击五个编号圆点并滑动。若响应跑到另一块屏幕，逐根识别USB触摸线并按配对流程操作；已测环境中双触摸问题由此解决。

截图里的四角在屏幕上看不到

圆形玻璃不能显示800×800方形截图的四角。应用按钮应放在可见圆内，触摸测试选择--shape round。如果圆形本身缺了一部分或中心内容被截，拍照联系支持；不要套用长条屏的60列偏移。

重新插线后测试窗口消失

```
screen-test stop
screen-test touch --screen 1 --shape round
```

打开此页的最新在线文档

4.0英寸720×720触摸屏

先核对订单上的尺寸、分辨率和触摸选项。优先做下面的接线检查，不用先运行脚本。

碰到连接线后，突然黑屏或闪烁

• 先不要动线，等约10～15秒，看画面是否恢复。

• 还没恢复，就拔下HDMI和USB供电线，重新插紧，两端都检查一下。

• 换一根线试试，先只接一块屏幕。供电按商品要求连接。

如果每次碰线都会发生，优先换线。一直不亮时，也先从这些接线检查开始。

触摸没反应，或点这块屏却响应到另一块

• 先看屏幕的USB供电 / 触摸线有没有插到正在输出画面的那台电脑或树莓派上。只插充电头，屏幕可能会亮，但触摸传不到主机。

• 用能传数据的USB线。只能充电的线可能让屏幕亮起来，却不能触摸。

• 双屏时，把每块屏幕的HDMI和USB线成组核对。先只接一块及其USB线，确认后再接另一块。

Windows电脑可以先试什么？

桌面右键打开显示设置，选中这块屏幕，选择列表中的对应分辨率。双屏想分别显示时选扩展这些显示器。如果闪烁，进入高级显示，仅在列表支持时尝试60Hz。

触摸仍跑到另一屏时，在Windows中搜索校准笔和触控输入的屏幕，打开后选设置（Setup），按提示指定触摸屏。先确认USB线接对，再做这一步。

Windows详细操作。后面的树莓派命令不能在Windows中运行。

还是不正常？

请发照片或短视频，说明电脑型号以及HDMI、USB怎么接。树莓派用户完成基本检查后，再按下面的产品专属步骤尝试。

可选：树莓派操作

以下命令在安装显示工具后的树莓派中执行，矩形触摸测试需2.3.2+。示例为接口1（HDMI-A-1，板上HDMI0），接口2（板上HDMI1）替换数字。测试命令使用桌面用户，不加sudo。

通电后黑屏，或画面一直闪烁

可能看到的现象：电源和HDMI已经连接，但没有画面；或有画面但持续闪烁。

1. 检查屏幕额定供电及HDMI线，先只连接一块屏幕。

2. 查看识别结果，再临时应用对应兼容配置：

```
screen-config list
 screen-config apply --port 1 --profile 4.0inch-720x720-60hz-wks-lontium-semi
 screen-test pattern --screen 1
```

先保存桌面文件，配置可能重启桌面，命令没有自动倒计时恢复。如果提示产品不匹配，请停止并联系支持，不强制套用。

3. 检查画面是否稳定、四边是否完整，通过后再保存：

```
screen-config apply --port 1 --profile 4.0inch-720x720-60hz-wks-lontium-semi --save
```

该时序方案已在样机通过。需撤回且屏幕信息能正常读取时，执行screen-config auto --port 1 --save；撤回后原症状可能返回。

点击无反应、控制了另一块屏，或点不到按钮

1. 用USB数据线连接触摸口，HDMI本身没有触摸数据。

2. 打开靶点测试：

```
screen-test touch --screen 1 --shape rect
```

3. 点击五个靶点并滑动；命中应变绿，轨迹应在同一块屏上跟随手指。

4. 若另一块屏响应，按USB与HDMI配对流程重新确认。不同型号也可能上报相同控制器名称。

本屏响应但仍偏移时，提供照片及screen-config list结果联系支持；本款方屏不使用6.2切割屏的偏移补偿。

换线后测试图案不见了

重启测试窗口：

```
screen-test stop
screen-test pattern --screen 1
```

如果连桌面也看不到，继续检查供电、连接，以及是否已登录图形桌面。

打开此页的最新在线文档

6.2英寸360×960切割触摸屏

先核对订单上的尺寸、分辨率和触摸选项。优先做下面的接线检查，不用先运行脚本。

碰到连接线后，突然黑屏或闪烁

• 先不要动线，等约10～15秒，看画面是否恢复。

• 还没恢复，就拔下HDMI和USB供电线，重新插紧，两端都检查一下。

• 换一根线试试，先只接一块屏幕。供电按商品要求连接。

如果每次碰线都会发生，优先换线。一直不亮时，也先从这些接线检查开始。

触摸没反应，或点这块屏却响应到另一块

• 先看屏幕的USB供电 / 触摸线有没有插到正在输出画面的那台电脑或树莓派上。只插充电头，屏幕可能会亮，但触摸传不到主机。

• 用能传数据的USB线。只能充电的线可能让屏幕亮起来，却不能触摸。

• 双屏时，把每块屏幕的HDMI和USB线成组核对。先只接一块及其USB线，确认后再接另一块。

Windows电脑可以先试什么？

桌面右键打开显示设置，选中这块屏幕，选择列表中的对应分辨率。双屏想分别显示时选扩展这些显示器。如果闪烁，进入高级显示，仅在列表支持时尝试60Hz。

触摸仍跑到另一屏时，在Windows中搜索校准笔和触控输入的屏幕，打开后选设置（Setup），按提示指定触摸屏。先确认USB线接对，再做这一步。

Windows详细操作。后面的树莓派命令不能在Windows中运行。

左边内容缺了一部分，或越往左点击越不准

这块切割玻璃样机需要专门安排画面位置，尚未证明只改Windows分辨率能解决。请先拍一张四边都能看清的照片发给我们。

树莓派上已在测试应用内确认：补偿后画面完整、触摸对齐。但它不会自动修复Windows、整个桌面或所有软件。想尝试时，再展开下面的树莓派步骤。

可选：树莓派操作

以下命令在安装显示工具后的树莓派中执行，矩形触摸测试需2.3.2+。示例为接口1（HDMI-A-1，板上HDMI0），接口2（板上HDMI1）替换数字。测试命令使用桌面用户，不加sudo。

左边内容显示不全，文字、按钮或靶点被截掉

可能看到的现象：右边正常，左侧边框和按钮缺失，单纯修改分辨率也没解决。

可先试随文提供的补偿测试应用：

1. 安装显示工具2.3.2+并下载本支持仓库，先关闭旧临时测试窗口。

2. 在支持仓库根目录查看当前屏幕：

```
screen-config list
 screen-test stop
```

3. 所选输出已经是420×960、无旋转、缩放1时执行：

```
python3 product-support/6.2inch-360x960-touch/scripts/6.2inch-360x960-touch-window-demo.py --screen 1
```

4. 检查四边白框和五个编号圆点是否完整，再点击、滑动确认触摸。启动终端按Ctrl+C退出。

此前采用同一方法的临时应用已由用户确认内容完整、触摸精准；随文程序复现该方法，已检查启动和截图，新五点界面仍需单独实体验收。若程序提示输出模式不符，或边缘仍被截，请提供照片与screen-config list结果，不保存未经验证配置，

也不继续猜分辨率。

适用范围：只在这个应用内补偿，普通桌面、浏览器及标准screen-test不会自动修正。实际应用也需要采用相同的可见区布局。

右侧按钮接近正确，越往左点击越偏左

先确认触摸响应在当前实体屏；若跑到另一屏，先按配对指南处理。随后运行上面的补偿演示，它同时调整显示窗口与触摸位置。

点击中心及四角，命中应变绿，白色触点应跟随手指。已在其他地方校准过的输入不能重复补偿。普通screen-test touch --shape rect只换靶点布局，没有切割屏补偿。

能显示，但画面仍然闪烁

1. 先检查屏幕额定供电和线材。

2. 支持确认该样机匹配已知触摸长条屏配置后，可临时试下面的时序修复。先保存桌面文件，配置可能重启桌面，没有倒计时恢复。

```
screen-config apply --port 1 --profile 6.2inch-420x960-60hz-ltm-zl480 --confirm-profile
 screen-test pattern --screen 1
```

3. 稳定性与完整性分开检查。早期触摸样机60Hz后闪烁改善，但并未修复左侧缺边。

可见区与触摸成功试验使用约51.85Hz；60Hz与补偿组合仍需实体确认。不能只因画面稳定就加--save。

打开此页的最新在线文档

6.2英寸360×960切割非触摸屏

先核对订单上的尺寸、分辨率和触摸选项。优先做下面的接线检查，不用先运行脚本。

碰到连接线后，突然黑屏或闪烁

• 先不要动线，等约10～15秒，看画面是否恢复。

• 还没恢复，就拔下HDMI和USB供电线，重新插紧，两端都检查一下。

• 换一根线试试，先只接一块屏幕。供电按商品要求连接。

如果每次碰线都会发生，优先换线。一直不亮时，也先从这些接线检查开始。

手指点击没有反应

本款不带触摸，这是正常的。如果另一块触摸屏反而控制本屏，先核对另一块屏的HDMI和USB是否接在同一台主机，再按下面的Windows方法指定触摸屏。

Windows电脑可以先试什么？

桌面右键打开显示设置，选中这块屏幕，选择列表中的对应分辨率。双屏想分别显示时选扩展这些显示器。如果闪烁，进入高级显示，仅在列表支持时尝试60Hz。

Windows详细操作。后面的树莓派命令不能在Windows中运行。

亮度一直一明一暗，或画面缺边

请发一段短视频，并说明怎么供电。这块非触摸样机调到60Hz后仍有问题，目前没有已确认的软件修复；触摸款切割补偿也未在本款确认。

可选：树莓派操作

以下命令在安装显示工具后的树莓派中执行，矩形触摸测试需2.3.2+。示例为接口1（HDMI-A-1，板上HDMI0），接口2（板上HDMI1）替换数字。测试命令使用桌面用户，不加sudo。

画面位置不动，但亮度反复一明一暗

可能看到的现象：内容在原位置，但背光或整体亮度持续变化。

1. 先单屏测试，按产品额定要求供电，对照已知良好的供电线及合适的独立电源。

2. 对照HDMI线和已知正常主机。

3. 打开白色及网格，便于观察：

```
screen-config list
 screen-test white --screen 1
 screen-test pattern --screen 1
```

仍异常时，提供短视频、电源信息与screen-config list联系支持。此样机60Hz试验未解决，暂没有已验证的推荐配置；不因名称相同就套用触摸款档。

左边缺失，或画面被裁掉

执行screen-test pattern --screen 1并拍清四边。触摸版曾需要可见区布局补偿，但其偏移量尚未在本非触摸版测量确认。先联系支持测量本样机，再决定补偿参数。

有触摸靶点，但手指点击没反应

这是正常现象：非触摸款没有触摸输入。改用颜色及几何测试：

```
screen-test cycle --screen 1 --interval 5
screen-test pattern --screen 1
```

如果另一块触摸屏反而控制本屏，按混合双屏配对流程将该触摸控制器仅绑定所属输出。

重新连接后测试图不见了

```
screen-test stop
screen-test pattern --screen 1
```

仍黑屏时先查供电、背光及连接识别，再考虑时序；若出现Remote I/O error，提供连接信息联系支持。

打开此页的最新在线文档

双屏同显与异显：用途、画面准备和驱动板原理

适用于一根HDMI连接驱动板、再连接两块屏幕的双屏套装。先核对订单选择的是同显还是异显、圆形还是方形。当前2.1英寸和2.8英寸双屏均为每屏480×480、非触摸；具体形状 / 板卡与历史样机的对应关系仍需核对。

想让两块屏显示什么？

选择	两屏实际效果	适合的用途
同显	两屏显示同一张完整画面，例如两边都显示同一条促销信息	对向观看、两侧重复信息、对称装饰
异显	两屏分别显示一张完整输入画布的不同部分，例如左仪表、右状态	多指标仪表、主信息与辅助信息、两页联动看板

本系列一根HDMI带两屏：同显时两屏重复完整画面；异显时应用先准备左右两页，再分别显示到两屏。 这里“镜像同显”指复制相同内容、保持正常阅读方向，不是把一块屏的文字左右翻转。

可以展示哪些应用场景？

以下是已经实现的树莓派演示内容，帮助选择产品用途。不是每个尺寸、形状、板卡都已完成实物验证，也不表示本页列出的配置全部作为商品选项出售；按订单选择匹配项。

显示关系 / 形状	应用场景	两屏内容
同显 / 圆形	音乐律动	两屏相同的彩色频谱、示例曲目信息和节拍光环
同显 / 圆形	RGB氛围	两屏相同的流动色环与呼吸效果，适合音箱 / 桌面两侧
同显 / 圆形	桌面信息钟	两屏相同的时间与示例天气，适合对向观看
同显 / 方形	门店促销	两屏相同的商品、示例价格和优惠文案
同显 / 方形	会议室状态	两屏相同的空闲 / 占用状态与演示倒计时
同显 / 方形	物流取件	两屏相同的示例包裹状态与取件参考码
异显 / 圆形	飞行仪表	左姿态 / 航向，右空速 / 高度
异显 / 圆形	汽车仪表	左车速 / 转速 / 挡位，右发动机 / 油量 / 电压
异显 / 圆形	PC机箱	左CPU / 内存，右GPU / 散热
异显 / 方形	智能家居	左室内环境 / 灯光，右光伏 / 家庭用电
异显 / 方形	PC机箱	左CPU / 内存 / 趋势，右GPU / 温度 / 风扇
异显 / 方形	工业设备	左泵站 / 压力 / 流量，右趋势 / 设备状态

这些产品展示使用模拟数据。音乐演示不采集或播放声音，天气 / 价格 / 日历 / 物流也不自动连接真实服务；汽车、飞行和工业页面不代表已接入或控制真实设备。真实数据接入需要对应软件和数据源另外实现。

为什么异显看到的是半张图？

如果原本把一张普通完整页面铺在双宽画布上，驱动板拆开后，每个面板就只显示其中一部分。这符合异显板的分区逻辑，不一定是缺边故障。

1. 先确认订单及驱动板输入要求，不仅看系统的显示器编号。

2. 异显要在电脑 / 应用端准备好左右两区：左边完整设计一页，右边完整设计另一页。

3. 以本系列每屏480×480举例，支持左右分区的板通常使用一张960×480画布；左480×480给屏1，右480×480给屏2。实际输入仍以该板资料和系统提供模式为准。

4. 检查两屏各自的边框和文字是否完整；圆形内容要放在可见圆内。

驱动板负责分配像素，不会自动打开两个应用，也不会把普通程序重新排版成两个完整页面。仍异常时，先检查接线、供电，再提供两屏照片、主机画面截图和当前输入模式。

同显是不是也要把一张图分成两半？

硬件同显板不需要用户准备两套页面：主机给一张完整画面，板子把这张画面复制给两块屏。例如480×480单幅输入可以给两块480×480屏重复显示；不要仅因有两个面板就强制设置960×480。

SBS异显板也可以用软件做出同显：应用先把同一幅画面分别放到双宽画布的左右区，再由板子正常拆分。这种软件同显仍使用SBS的双宽输入，与硬件同显板的单幅输入不同。 能否这样用要看板卡支持的模式，不代表两种板可以任意互换或刷固件转换。

Windows里选“复制 / 扩展”能直接切换吗？

一根HDMI只作为一个逻辑显示器被系统识别，可以是正常现象。Windows“复制 / 扩展”针对的是主机的多个输出，不负责改变这块驱动板内部的分图 / 复制方式。

先用Windows显示设置查看该板实际提供的分辨率。SBS需要支持左右分区的画面布局；同显板需要与其匹配的单幅画面。这里的树莓派演示脚本不能在Windows运行，也不代表该套装已完成Windows实体验收。

可选：在树莓派运行三场景演示

安装完整双屏应用仓库，使用v0.10.2或后续兼容版，按其README确认依赖和输入。测试环境为Pi4B、Bookworm Desktop 64位、labwc/Wayland。以已登录图形桌面的同一普通用户在SSH运行，不加sudo。

类型	脚本	三场景顺序
圆形同显	./demos/same/round/demo	音乐→RGB氛围→信息钟
方形同显	./demos/same/square/demo	门店→会议室→取件
圆形异显	./demos/different/round/demo	飞行→汽车→PC机箱
方形异显	./demos/different/square/demo	家居→PC机箱→泵站

每组先介绍品牌与场景3秒，再演示10秒，共39秒循环。同显介绍与效果两屏相同；异显介绍左屏品牌 / 图标、右屏用途 / 指标，效果各显不同内容。

例如，确认是方形硬件同显板后，在完整应用根目录执行：

```
cd ~/apps/lvgl-embedded-gui-demos
./app --version
./app stop --port 1
./demos/same/square/demo check --port 1 --size 480
./demos/same/square/demo start --port 1 --size 480
```

停止命令只针对本项目；若其他工具占口，先用其自身的正常stop命令。升级前要先用旧版本停止，再更新完整项目，不能覆盖运行中的程序。

同显脚本默认--signal clone，对应硬件复制；若实际为支持双宽输入的SBS板，check/start都显式加--signal sbs。不要为了通过检查而改成另一块板的分辨率或刷新率。四类连接的具体速率和证据见连接记录，不能从每屏480×480推断通用60Hz

或某个已测速率适用。

公共端口1/2=Linux HDMI-A-1/2=Pi4板标HDMI0/1，指主机HDMI接口，不是驱动板的左 / 右面板。示例为接口1，接口2接线时改为--port 2。

检查或稍后停止：

```
./demos/same/square/demo status --port 1
./demos/same/square/demo stop --port 1
```

这些应用命令不修改时序、EDID、屏幕固件或系统镜像设置，不重启桌面、无定时回退。check不匹配时先核对板卡和模式；失败不会创建缺失模式。start后台运行，SSH退出后继续，前提是桌面保持登录；正常stop关闭本项目窗口。拔线 / 换板可能使程序退出，重新连接稳定后再check/start，不能假设自动恢复。

打开此页的最新在线文档