Test1

Getting started · built Nov 2, 2026

Getting started

Install the driver and prove the controller answers before anything else.

Work through this page at the machine, not at a desk. It takes about ten minutes and ends with a controller that answers, which is the state every other page assumes.

> **NOTE**
>
> Work at the controller, not at a desk: the driver install needs the machine plugged in, and the last step asks the hardware a question rather than the software.

Install the driver

The driver ships inside the Temco installer. Run it as an administrator, then plug the controller in. Windows shows a new port under **Ports (COM & LPT)** — the number beside it is the one you will point at in the next step.

Point the port

Open the tool, choose the port the controller appeared on, and press **Connect**. A controller that has never been commissioned answers on its own address; one that has been on a network answers on the address it was given.

If nothing answers, try the other ports in the list before assuming the controller is faulty: a USB adapter usually takes the port beside its own.

Check the answer

Ask for the controller's identity. A good answer names the model, the firmware and how long the machine has been running:

```text
Test1  firmware 1.0  uptime 0d 00:07:12
```

That line is enough to prove three things: the loop is powered, the driver is talking to it, and the firmware in front of you is the firmware this documentation was written for.

Where next

- Ports and wiring — what each terminal is for
- Writing a program — the first thing a machine needs to do
- Alarms — when the machine says something is wrong