# ON-ALARM

| | |
|---|---|
| Purpose: | To redirect program execution if there was an alarm. |
| Format: | ON-ALARM line |
| Description: | line is the line number |
| Example: | 10 DALARM FIRE = 1 , 10 , THERE IS A FIRE |
| 20 ON-ALARM 100 | |
| 30 REM CONTINUES HERE IF NO ALARM | |
| 40 END | |
| 100 | REM SPECIAL FIRE PROCEDURES |
| 110 STOP BOILER1 : STOP BOILER2 | |
| Note: | This branch happens only once when the alarm is generated. |