PRINT, PRINT-AT

PRINT (T3000 only)

Purpose: To print strings on a printer

Format: PRINT string [;]

Description: string is the string to be printed

If a semi colon is included at the end of the PRINT statement no CR/LF (Carriage return / Line feed) will be done, otherwise a CR/LF is done.

Example:

10 IF+ FIRE THEN GOSUB 100

20 END

100 REM FIRE INSTRUCTIONS

110 PRINT “THE FOLLOWING PROCEDURE SHOULD NOW BE

CARRIED OUT:"

120 PRINT “1. ..... etc.”

130 RETURN

Note: The PRINT-AT statement must be used before using PRINT.

Keywords recognized in PRINT statement:

- DATE prints the date and time
- TIME prints the date and time
- USER-A prints the name of user logged on at port A (local)
- USER-B prints the name of user logged on at port A (remote)
- BEEP causes the printer to beep

- POINT/LOCAL VARIABLE VALUES

prints values from -999,999.9 to 999,999.9

Remember to use the print statement in conjunction with the PRINT- AT statement to specify which panel to print at. If you do not use the PRINT-AT statement, it will not print.

Be careful when the IF+, IF-, and INTER VAL statements are used with PRINT. Make sure that the same item is not printed repeatedly.

Examples: 10 PRINT-AT 2 , 5 10 PRINT-AT 2 , 5

20 IF+ USER-A THEN PRINT USER-A ; “HAS SIGNED ON AT PORT A ON” ; DATE

30 IF+ VALUE > MAXIMUM THEN GOSUB 100

40 IF INTERVAL(01:00) THEN PRINT “BUILDING LOW IS: ; L : ” TIME:" ; TIME

50 END

100 PRINT “VALUE IS” ; VALUE ; “ AT ” ; DATE ; BEEP ; BEEP ; BEEP ; BEEP

110 PRINT “MESSAGE”

120 PRINT “MESSAGE”

130 RETURN

PRINT-AT [TBD]

Purpose: To select which panel(s) will receive the print message(s).

Format:	PRINT-AT panel [panel panel] or PRINT-AT ALL
Examples:	10 PRINT-AT ALL
20	PRINT “THIS IS PRINTED AT ALL PANELS IN SYSTEM.”
30	PRINT-AT 2
40	PRINT “THIS IS PRINTED AT PANEL 2 ONLY.”
50	PRINT-AT 1 3
60	PRINT “THIS IS PRINTED AT PANELS 1 AND 3.”
70	PRINT-AT 1 5 8
80	PRINT “THIS IS PRINTED AT PANELS 1, 5 AND 8.”
Note:	Commas are not needed to separate panel numbers