T3000

DISABLE · built Nov 12, 2026

DISABLE

Purpose:	To set the value of a variable to 0 (i.e. off).	
Format:	DISABLE variable	
Example:	10	DISABLE OUT1
20	DISABLE A	
30	DISABLE VAR1	
40	DISABLE PRG10	