ON-ALARM

Purpose:	To redirect program execution if there was an alarm.
Format:	ON-ALARM line
Description:	line is the line number
Example:	10 DALARM FIRE = 1 , 10 , THERE IS A FIRE
20 ON-ALARM 100	
30 REM CONTINUES HERE IF NO ALARM	
40 END	
100	REM SPECIAL FIRE PROCEDURES
110 STOP BOILER1 : STOP BOILER2	
Note:	This branch happens only once when the alarm is generated.