REMOTE-GET, REMOTE-SET

Purpose:	To get a value from another system.
Format:	REMOTE-GET a = remote point

Description: a is the variable that will assume the value of the remote point remote point is the point in the remote system

Example:	100	PHONE 555-1234
110	REMOTE-GET A = 3-IN5	
120 HANGUP		
130 ALARM A >24 , 2 , REMOTE SITE TOO HOT		

REMOTE-SET	(T3000 only)
Purpose:	To set a value in another system.

Format:	REMOTE-SET remote point = x	
Description	x is the variable that the remote point is to be set to	
remote point is the point in the remote system		
Example:	10	REM START A REMOTE OUTPUT
20	PHONE 555-1234	
30	A = 1	
40	REMOTE-SET 2-OUT4 = A	
50 HANGUP		