T3000

T3000 · built Nov 12, 2026

T3000

The T3000 front end: the controller, its hardware, the software, Control Basic, and the examples that tie them together.

Contents

- T3000 Manual
- Introduction
  - System Description
  - General Overview
  - System Highlights
  - Control Concepts
  - Software
  - Overview
  - Menus and Work Area
  - System Requirements
  - Keyboard and Mouse
  - Open Source Project
  - T3 Controller Hardware
  - T3 Controller
  - Hardware Architecture
  - Communications Ports
  - Wireless
    - Expansion Modules
    - T3-8o
    - T3-22i
    - T3-PT12
    - PWM
  - Installing and connecting
  - Installing T3000 Software

- Hardware Details
- Misc
- Troubleshooting Ethernet Connections
- Installing T3000 Software
- Menu Items and Tree
- PRG Files
- System Tree
  - Building Database
  - T3000 Remote Connection
- 6 Control
  - 6.1 Graphic Screens
  - 6.1.1 Insert Point
  - 6.1.2 Edit Point
- 6.2 Programs
  - Inputs
  - Menu
  - Pulse Counting
  - Custom Digital Ranges
    - Range Setting
    - Select Range Number window
- 6.4 Outputs
- 6.5 Variables
  - 6.6 PID Loops
  - PID Loops Introduction
    - PID Loop Work Screen
    - PID LOOP MATH DISCUSSION
    - PID Loops Introduction
  - PID Loop Math Discussion
- 6.7 Schedules
- 6.8 Holidays
- 6.9 Trend Logs
- 6.10 ALARM LOG

- Panel Configuration
- 8 Control Basic Programming

- 9 Programming a controller
  - Control Basic Programming
    - Numbers, Time and Date Handling
    - Logical Operators
    - Expressions
    - Variables
  - List of Statements
  - ABS
  - ALARM, ALARM-AT
  - AVG
  - CALL
  - CLEAR
  - CLOSE
  - DALARM
  - Declare
  - DISABLE
  - DOM, DOW, DOY
  - ENABLE
  - END
  - FOR
  - GOSUB
  - GOTO
  - HANGUP
  - IF
  - IF+ , IF-
  - INT
  - INTERVAL
  - LN, LN-1
  - LET
  - MAX, MIN
  - NEXT
  - ON
  - ON-ALARM
  - ON- ERROR
  - OPEN
    - PIDProp, PIDInt, PIDDeriv

        - PID LOOP MATH DISCUSSION
        - PID Loops Introduction
    - PHONE
    - POWER-LOSS
    - PRINT, PRINT-AT
    - REM
    - REMOTE-GET, REMOTE-SET
    - RETURN
    - RUN-MACRO
    - SCANS
    - SET-PRINTER
    - SQR
    - START, STOP
    - STATUS
    - TBL
    - TIME-ON, TIME-OFF
    - TIME
    - UNACK
    - USER[X]
    - WAIT
    - WR-ON / WR-OFF
    - ErrorMessages
- Port Forwarding
- Network&Remote points support
- T3000 Release History
- DEMO PROGRAM
    - FIRMWARE UPDATE, SINGLE DEVICE
    - FIRMWARE UPDATES: BATCH LOADING
- 14 How to use subnet
- Expansion Inputs & Outputs
- License Agreement
- Bacnet Integration
- IP SETTINGS
- Offline Mode