TEMCO LEARN

TStat8

OFF Mode · built Nov 12, 2026

OFF Mode



Heating/Cooling Stage




Set the number of stages of heating and cooling.

Modes Setting



You can set the number of modes at the tab, two modes have been selected here with the default names as Off and Auto.

OFFSelecting



You can rename them by editing the names at the tab.Next we'll edit the Off table by selecting the radio button. The grid shown represents the outputs when the stat is in the off mode.

Heat2

Heat2
Off
Off
Off
Off
Off
Closed
Closed

The center column represents the coasting mode, everything is off there as well.

Various Outputs State

Heat2	Heat1	Coast	Cool1	Cool2
Off	Off	Off	Off	Off
Off	Off	Off	Off	Off
Off	Off	Off	Off	Off
Off	Off	Off	Off	Off
Off	Off	Off	Off	Off
Closed	Closed	Closed	Closed	Closed
Closed	Closed	Closed	Closed	Closed

Each row is one output and the columns represent the outputs in each of the stages of heating and cooling. In this example, everything is off for all 2 stages of heat and two cool.