ALARM, ALARM-AT

ALARM

Purpose: To generate alarms based on user defined conditions and includes automatic hysterisis to reduce multiple triggers from the same event.

Format: ALARM x > y , z , string

ALARM x < y , z , string

Description: x > y and x < y are the alarm conditions

z is the alarm hysterisis, once the alarm is triggered the condition must swing back by this amount before another event is triggered.

string is the alarm message with a length of up to 69 characters.

Example: 10 ALARM SAT > SETPOINT + 5 , 2 , SUPPLY AIR TEMP IS TOO HIGH

In this example, the alarm is triggered when the supply air is 5 degrees above setpoint. Another alarm will not be triggered till the alarm resets itself by swinging thru 3 Degrees again (5 - 2 = 3 degrees) over setpoint.

ALARM- AT

Purpose:	Selects which panel(s) will receive the alarms.
Format:	ALARM-AT panel1 panel2 ...] or ALARM-AT ALL
Example:	10 ALARM-AT ALL
20REM ALARMS WILL GO TO ALL PANELS.	
30ALARM-AT 2 8	
40REM ALARMS WILL GO TO PANELS 2 AND 8 ONLY	