UNACK

Purpose:	To determine if there are any unacknowledged alarms in the system. The function returns 1 if there are alarms that are still on and that have not been acknowledged, otherwise it will return 0.
Format:	UNACK
Example:	10 IF UNACK THEN START ALRM-OUT ELSE STOP ALRM-OUT