

User Manual v1.0: Polaris ICE Air Situation Display (ASD) v2.6.72.1

Table of Contents

1. Introduction
 - 1.1. Definitions and Acronyms
 - 1.2. Document History
2. UI Overview
 - 2.1. Header
3. User Setup
 - 3.1. User Login & Logout
 - 3.2. Basic Navigation Features
 - 3.3. Setup Map Layer Display
 - 3.4. Setup Picture in Picture (PIP)
 - 3.5. Reset CWP to Default Settings
 - 3.6. Toggle MSA
4. Flight states overview
 - 4.1. Lifecycle State
 - 4.2. Control State
 - 4.3. Coordination State
 - 4.4. Track Representation of Flight States
5. Inbound, Sector and Departure Procedures
 - 5.1. Sector List Overview
 - 5.2. Inbound List Overview
 - 5.3. Departures List Overview
 - 5.4. Lost List
 - 5.5. Sending Manual Departure Messages
 - 5.6. Assume Inbound Track
 - 5.7. Transfer Flight Control
 - 5.8. SSR Discrepancy
 - 5.9. SSR Code Allocation
 - 5.10. Clearances
6. Track Management
 - 6.1. Track History
 - 6.2. Track Label Customisation
 - 6.3. Track Label Marks
 - 6.4. Extended Track Label
 - 6.5. Filtering Tracks
 - 6.6. Filter by Field
 - 6.7. SPI Signal Indication (Squawk Ident)
 - 6.8. Flight Plan Track
 - 6.9. Correlation Procedures
 - 6.10. Call sign Menu procedures
 - 6.11. Manual Coordination
 - 6.12. Manually activate next internal sector
 - 6.13. Transferring to any sector
7. Assigning Clearances
 - 7.1. CFL (Cleared Flight Level)
 - 7.2. XFL (Exit Flight Level)
 - 7.3. Assigned Heading
 - 7.4. Cleared Waypoint

- 7.5. ASP (Assigned Speed)
- 7.6. ARC (Assigned Rate of Climb)
- 7.7. SID
- 7.8. STAR
- 7.9. RWY
- 7.10. APP
- 8. Approach Sequencing
 - 8.1. Assigning an approach Sequence Numbers from the Track Label
 - 8.2. Assigning an approach Sequence Numbers from the flight list
 - 8.3. Manual Sequencing Menu
- 9. Graphical Route Editing
 - 9.1. Visibility
 - 9.2. Updating the route
 - 9.3. Suggested rejoin for selected flight
- 10. System Flight Record Editing
 - 10.1. Viewing System Flight Records
 - 10.2. Finding System Flight Records
 - 10.3. Editing System Flight Records
 - 10.4. Create New Flight Record
 - 10.5. Additional Dialogs
 - 10.6. Terminating System Flight Records
 - 10.7. Moving SFR Editor
 - 10.8. Closing SFR Editor
- 11. Creating Abbreviated Flight Plans
 - 11.1. Editing & Converting Abbreviated Flight Plans
 - 11.2. Moving Correlation To Full Flight Plan
- 12. Holding
 - 12.1. Initiation of Holding
- 13. CWP Messaging
 - 13.1. Supervisor CWP Messaging
 - 13.2. Draft messages
 - 13.3. Expiration time of CWP Messages
- 14. Measurement Tools
 - 14.1. QDM
 - 14.2. Surveillance Separation Tool
 - 14.3. Flight Plan Separation Tool
- 15. Adjusting Speed Vector Length
 - 15.1. Speed Vector Track display
- 16. Environmental Data and Aerodrome Tasks
 - 16.1. Environmental Data Tasks
 - 16.2. Aerodrome Tasks
- 17. Alerts and Warnings Procedures
 - 17.1. Equipment Warnings
 - 17.2. Correlation Warnings
 - 17.3. Clearance Warnings
 - 17.4. Distress Procedures
 - 17.5. ATCO Failed Commands
 - 17.6. Covering Data
 - 17.7. Safety Nets

18. Check Sensor Status

18.1. Using the Sensor Status Window

19. Checking Subsystem Status

19.1. Using the Subsystem Status Window

19.2. Total dataloss

19.3. Check MLAT Status

20. Supervisor Functions

20.1. Manage Allocations

20.2. Safety net allocation

20.3. Manage Sectorisation

20.4. Manage Safety Nets

20.5. Manage Airspaces

20.6. Manage Aerodromes

20.7. Manage ATC units

Appendix A: Drone Traffic

Appendix B: User Defined Map

B.1. Color Group Buttons

B.2. Moving Tool

B.3. Free Hand Tool

B.4. Circle Drawing Tool

B.5. Line Drawing Tool

B.6. Text Tool

B.7. Icon Tool

B.8. Save UDM

B.9. Display, Edit, Delete and Export Saved UDM

Appendix C: CWP Customisation for End Users

C.1. Daylight Mode

C.2. Screenshot Button

C.3. Home Button

C.4. Test Audio

C.5. Change Font Sizes

C.6. Marks and freetext in Flight Lists

C.7. Customize Flight List Appearance

C.8. Change Surveillance Source

C.9. Show/Hide Map Scale

C.10. Cleaning Mode

Appendix D: Version Information

21. Interactive Playback

21.1. Selecting Workstation and Time

21.2. Playback Controls

Appendix E: Polaris Air Situation Display (ASD) v2.6.72.1

E.1. Introduction

E.2. Technical Features

E.3. Choose monitor

E.4. User Permissions

E.5. Disable Ground Targets

E.6. Map Layer Configuration

E.7. Runway Menu Maps Configuration

E.8. Color Configuration

- E.9. SNS alert configuration
- E.10. UDM configuration
- E.11. Keyboard shortcut configuration
- E.12. SFR Editor Configuration
- E.13. Radio Callsign Editing
- E.14. Schemas