Restoring the X,Y or Z Key

To restore the X,Y, Z key, first insert the correct key into the lock and turn the key.

Turn the releasing switch handle to LOCKED

Tell the signaller that the key has been returned

and then close the cabinet.

For the latest up to date rules, procedures, forms and videos, please refer to the RailSafe website railsafe.org.au

We hope that this video has been helpful, if there is any feedback please email it to NRU@transport.nsw.gov.au