Protocol Document：

PS. “The hardware” in the following description can be models: DC-101, DC-300, or DC-016RW

I、Command of setting hardware’s action (GetDescriptor)

1. When a PC tries to control the hardware, you need to use String (Example: wValue=09h) in GetDescriptor to the hardware side, and the value of wIndex are the commands that PC send to the hardware.
2. The hardware always response commands from a PC passively, so only when a PC gives a command, the hardware response a string to PC side to show status or value of hardware.
3. The hardware receives commands first and then response “status string” to PC side, status strings are following 4 words:
   A. Status string “ACK” => Command is accepted by the hardware.
   B. Status string “Busy” => The hardware is busy, this command cannot be executed, PC needs to wait for a while to send the command again.
   C. Status string ”ERROR” => The hardware has an error and not working, PC can send “RESET” command to do troubleshooting or recovering.
   D. Status string “numbers” => When a PC sends a command to retrieve the machine’s unique number or slot number in the hardware, the hardware responses a number.

II、Command => **wIndex**：

1. Retrieve model number of the hardware: wIndex = 09h
   The hardware responses a string.
   A. Responding string “123456789” means DC-101 or DC-300, capacity is 150 CDs
   B. Responding string “DC016RW” means DC-016RW, capacity is 100 CDs.
   C. Other strings are for future expansion

2. Retrieve the unique number of the hardware: wIndex = 0Ah
   The Hardware responses a number, it is the unique number of the hardware.

3. Reset the hardware: wIndex = 0Bh
   The hardware responses “Status string” to the PC.

4. Move a slot to the door: wIndex = 0Ch
   A. You need to send 2 commands, PC sends wIndex = 0Ch and then wait for the hardware responses status string “ACK”, PC then sends a slot number, wIndex = slot number, and then the hardware responses string “ACK” which means the commands are complete and executable.
   B. If the hardware does not response “ACK”, it means that the command that you just sent cannot be accepted.

5. Door closing: wIndex = 0Eh
   The hardware response status string.

6. Digital LED display lights up: wIndex = 0Fh
   The hardware response status string.

7. Digital LED display becomes OFF: wIndex = 10h
   The hardware response status string.

8. Read the hardware status: wIndex = 11h
   The hardware response status string.
   A. Status string “ACK” => Command is accepted by the hardware.
   B. Status string “Busy” => The hardware is busy, this command cannot be executed, PC needs to wait for a while to send the command again.
   C. Status string ”ERROR” => The hardware has error, it’s not working, PC can send “RESET” command to do troubleshooting or recovering.
9. Retrieve the slot number that has a CD in the DVD drive: wIndex = 12h
   The hardware (DC-016RW only) response a number (1~100), Zero (0) means no disc in the DVD drive.

10. Move a CD in the slot into the DVD drive: wIndex = 13h
    A. You need to send 2 commands, PC sends wIndex = 13h and then wait for the hardware responses status string “ACK”, PC then sends the slot number, wIndex = slot number, and then the hardware responses string “ACK” which means the commands are complete and executable.
    B. If the hardware does not response “ACK”, it means that the command that you just sent cannot be accepted.

11. Eject a CD in the DVD drive: wIndex = 14h
    The hardware response status string.