
## VN7050ASTR



Pin 8: VCC battery connection

Pins 6 & 7: OUTPUT Power outputs


Pin 3: GND Ground

Pin 1: INPUT (GPIO) Switch control 3.3 or 5V

Pin 4: MultiSense Analog current sense

Pin 2: SEn Multisense enable

## STMPS2141MTR



Pin 1: GND Ground

Pins 2 & 3: IN 2.7-5.5V switch input

Pin 4: EN (GPIO) switch enable

Pin 5: FAULT Fault indicator (low)

Pins 6, 7 & 8: OUT Power switch output