

Fleetly Pro - Customer User Manual

Welcome to Fleetly Pro, your premium GPS tracking and fleet management solution. This guide will walk you through the core features of your new dashboard.

1. Accessing Your Dashboard

To access your vehicles:

1. Navigate to the login page (e.g., <http://your-domain.com>).
2. Enter your secure **Username** and **Password** provided by your administrator.
3. Click **Access Dashboard**.

If your subscription has expired, you will see a lock screen. Please contact your Admin to recharge your account.

2. The Interactive Map

When you log in, you will be greeted by the live tracking map.

- **Filter Bar (Bottom):** Quickly filter your view between **ALL** vehicles, **ACTIVE** (currently driving), and **IDLE** (parked/stopped).
- **Map Layers (Top Right):** Click the layer icon to toggle between:
 - **Standard View**
 - **Dark Mode** (High contrast, ideal for night monitoring)
 - **Satellite View**

3. Vehicle 360 Details Panel

To see in-depth information about a specific vehicle, simply click its card in the left sidebar, or click its marker directly on the map.

A sleek panel will slide out from the right, displaying:

- **Live Speedometer:** A gauge that animates in real-time as your vehicle's speed changes.
- **Odometer:** Total distance traveled by the vehicle.
- **Ignition Status:** Whether the engine is currently ON or OFF.
- **Internal Battery:** The percentage of backup power remaining in the tracker itself (e.g., if the main vehicle battery is disconnected).
- **GPS Lock:** Displays the quality of the satellite connection (e.g., "3D Fix") and the number of satellites connected.
- **Live Coordinates:** The exact Latitude and Longitude of the vehicle.

4. Adding a New Tracker

If you have purchased a new hardware tracker, you must link it to your account before it appears on your map.

1. Click the **+ Add Tracker** button in the left sidebar.
2. Enter the **15-digit IMEI number** printed on the back of your physical tracker.
3. Click **Link Tracker**.
4. This sends a request to your Administrator. Once approved, the vehicle will instantly appear on your dashboard!

5. Understanding Telemetry Metrics

- **3D Fix:** This means your tracker is connected to 4 or more satellites in space, providing a highly accurate location.
- **No Fix:** The tracker cannot see the sky (e.g., parked in an underground garage) and is using its last known location.
- **Battery Percentage:** This shows the backup battery of the tracker. If it drops below 20%, the icon will turn red, indicating that the main vehicle battery may have been disconnected or is failing to charge the device.

Thank you for choosing Fleetly GPS. For further support, please contact your system administrator.