

Clap Parameter Guide

Parameter reference — Thee Coast Machine

1. Internal Structure

Pink noise → **bandpass** + **Style burst train**. Switches between Single, TR-707 (×2) and TR-909 (×3) styles.

Element	Role	Sonic character
Pink noise	Soft base material (low-tilted noise)	Soft "pa"
Bandpass filter	Shaped by FREQ + Q	Tone of the instrument
Style burst	Switches Single / 707 (×2) / 909 (×3)	"papa" / "papapa"
Decay envelope	Determines the ringing time	Tight vs. rich

2. Parameter Reference

FREQ (500 — 3000 Hz)

Center frequency of bandpass.

- **500–800 Hz**: dark (Dub, Lo-Fi)
- **800–1200 Hz**: standard 808
- **1200–1800 Hz**: bright (TR-909, House)
- **1800–3000 Hz**: sharp (EDM)

Tip: Avoid the Snare body band (~200–500 Hz).

Q (1 — 8)

Bandpass sharpness.

- **1–1.5**: broad, natural
- **1.5–3**: standard
- **3–5**: pinned
- **5–8**: too sharp

Tip: Sweet spot 1.2–2.0.

DECAY (0.03 — 0.4 sec)

Length of the clap.

- **0.03–0.08**: tight, tick
- **0.08–0.15**: standard

- **0.15–0.25:** long, rich
- **0.25–0.4:** reverberant

Tip: STYLE × DECAY interact.

STYLE (0 — 1 (3 stages))

Burst pattern.

- **0.00–0.33: Single** — classic
- **0.34–0.66: 707** — 2 bursts, 22 ms
- **0.67–1.00: 909** — 3 bursts, 13 ms

Tip: Slow tracks: Single. Techno: 707 / 909.

3. Character Presets

Goal	FREQ	Q	DECAY	STYLE
TR-808 (warm single)	1200	1.5	0.16	0.0 (Single)
TR-909 (bright triple)	1100	1.6	0.18	1.0 (909)
TR-707 (double)	1300	1.7	0.15	0.5 (707)
Deep House	1300	1.4	0.18	0.5 (707)
Acid (sharp)	1500	2.5	0.10	0.0 (Single)
Dub (long, spacious)	1100	1.5	0.30	0.0 (Single)
Modern Tech House	1400	1.8	0.12	0.5 (707)
Footwork	1400	2.0	0.10	0.0 (Single)
Industrial	1600	3.5	0.13	1.0 (909)

4. Tuning Order

#	Do this	Why
Step 1	Choose STYLE	Single or burst?
Step 2	Set FREQ for brightness	Where vs. the Snare?
Step 3	Set DECAY (length)	Tight or rich?
Step 4	Use Q to sharpen	Broad or pinned?
Step 5	PAN to place it	Offset to coexist with snare

5. Troubleshooting

Symptom	Cause & fix
Clashes with Snare	Pan by ± 0.2 –0.3, or separate FREQ by 200–300 Hz.
Doesn't sound like a clap	Keep Q in 1.2–1.8. Try STYLE 707/909.
Thin, weak presence	Switch to STYLE 909, or raise ClapVol.
Flammy bursts	Shorten DECAY (0.08–0.12), raise Q.
Boingy tone	Lower both FREQ and Q.

※ Clap and Snare often share the backbeat. Split by PAN or stack by FREQ for a thick layered backbeat.