

Slat transmission — inspections**Slat actuation and transmission**

Scheduled maintenance requirements

Object code	DMC-A350X-A-27-81-00-00A-310A-A	Issue	005-00 (revised)
Issue date	2026-06-09	Language	en-GB
Responsible partner	AIRBUS S.A.S. (U8025)	Originator	AIRBUS S.A.S. — Maintenance Programme Engineering (U8025)
Security	01 — Unclassified	Quality assurance	First verification (tabtop)
Applicability	A350X-900 and A350X-1000, all aircraft		

Slat transmission — inspections

TASK No.	DESCRIPTION	THRESHOLD	INTERVAL	ZONE / MHR
271811-01	General visual inspection of the slat transmission shafts and couplings Examine the transmission for corrosion, for damaged couplings and for security of the support bearings between rib 1 and rib 14. (Ref. DMC-A350X-A-27-81-00-00A-200A-A)	7200 FH	3600 FH	571 / 1.5
271811-02	Detailed inspection of the wing tip brake attachment Examine the wing tip brake attachment lugs for cracks with the transmission in the retracted position.	24 MO	24 MO	573 / 2.0
271811-03	Operational check of the asymmetry detection Do the asymmetry detection test and make sure that the wing tip brakes engage inside the permitted time.	12 MO	12 MO	192 / 0.8

Slat actuation — servicing tasks

TASK No.	DESCRIPTION	THRESHOLD	INTERVAL	ZONE / MHR
271811-51	Lubrication of the transmission support bearings Apply grease to the eleven support bearings of each wing through the lubrication nipples.	4000 FH	4000 FH	571 / 3.0
271811-52	Functional check of the feedback position pick-off units Measure the drift of the position signal against the rigging position and record the value in the maintenance record.	10000 FC	5000 FC	192 / 1.2

NOTE: The thresholds are counted from the date of manufacture of the aircraft. An operator that has an approved reliability programme may escalate the intervals by up to 10 percent with the agreement of the national authority.