

1WAVE

Pg 1 **Saw / Square**
CHOMPI + Turn: Pulse Width

Pg 2 **Pattern Length**
CHOMPI + Turn: Tuning ±1 st

2ENV MOD

Turn **Env Mod**: how far the filter sweeps

CHOMPI + Turn: Accent Level

As on a 303: little below 12 o'clock, a lot above.

3DECAY

Turn **Decay**: the sweep's length

CHOMPI + Turn: Slide Time

4EFFECTS

Pg 1 **Delay Mix** · **CHOMPI**: synced time
Push + turn: free time, with a tape swoop

Pg 2 **Tape Feedback** · **CHOMPI**: tone

Pg 3 **Chorus** → **Flanger** · **CHOMPI**: width

Pg 4 **Bit Crush** · **CHOMPI**: rate

5FILTER

Turn **Cutoff**

CHOMPI: Resonance

Press **Tap Tempo**

Its two lights flash the eighth notes, left and right.

6VOLUME

Pg 1 **Volume** · **CHOMPI**: drive

Pg 2 **Tempo** · **CHOMPI**: swing

Pg 3 **Mix** drums ↔ bass · **CHOMPI**: effects balance

Pg 4 **Compressor** · **CHOMPI**: kick sidechain

Press a knob: next page · **CHOMPI + Press**: reset that page · **CHOMPI + Push 2 s**: reset every page (knobs 1–3) · Knobs **accelerate**: click slowly for fine steps, spin for the whole range.

Step Mode

toggle up

build the pattern one step at a time

DOWNUP

ACCENTSLIDE

TIE

VIEW

TRANSPOSE

COPY

PATTERN

CLEAR

1

2

3

4

5

6

7

8/9

10

11

12

13

14

15

16

Step key

select a step; again: on / off. Middle C is step 8 or 9

CHOMPI + any key

set the selected step's note (the keybed is a keyboard)

DOWN ... TIE

a page: step keys toggle octave down / up, accent, slide, tie

TRANSPOSE

keys set the transpose. Leave: tap a key twice, or hold 2 s

PATTERN

the bass's pattern page: **A**, or **B** with CHOMPI held. Running, a pick waits for the bar; again: now

PATTERN held + key

on the page: **both** bass and drums there, together at the bar

PATTERN held 2 s

write protect, while stopped: play freely, nothing saves

Pattern key held 2 s

export every pattern as MIDI to `/X0X/MIDI`

COPY + step key

copy the pattern there · **+ PATTERN**: to its other side, A ⇌ B

CLEAR

tap: the selected step · hold 1 s: the pattern

LOOP

switch to the **drums** · **CHOMPI + LOOP**: mute / unmute the bass

Live Mode

toggle down

play, record, arpeggiate

OCT -OCT +

ACCENTSLIDE

TIE

QUANTIZE

TRANSPOSE

ARP PATT

ARP OCT -ARP OCT +

Keys

play; overlapping notes **slide**. Top-row functions: with CHOMPI held

LOOP

record on / off · hold 2 s: clear the pattern

Recording, running

notes go in, held notes tie. CHOMPI + accent / slide / tie: on the step playing

Recording, stopped

note entry: each note fills the next step. CHOMPI + the blinking step: a rest on / off · CHOMPI + white key 1–3: grid 1/16, 1/8, 1/4 · hold 2 s: for good

QUANTIZE

arpeggiator on / off · **CHOMPI + LOOP**: latch

CHOMPI + PLAY

octaves below / above (0–2); up, down, up-down, random, as played

ARP OCTPATT

keys transpose the pattern (or the arp); tap a key twice to leave

TRANSPOSE

switch to the **drums** (in either mode)

PATTERNS & THE CARD

16 patterns, **A** and **B** sides; each holds a bassline **and** a drum part, and the two sides can play **different patterns**

Edits save to `/X0X` by themselves, unless write-protected

Import: `3B.mid` into `/X0X/IMPORT`, then power on (drums: channel 10)

BASS & DRUMS

Both always play: **LOOP** (step mode) or **CHOMPI tapped twice** picks which you edit

CHOMPI + LOOP (step mode): mute the side you're on

Volume Pg 3: **mix** · **CHOMPI**: **effects balance** · Pg 4: **compressor** · **CHOMPI**: each kick ducks the rest

LIGHTS

Steps red; accent bright, tie dim · **patterns A / B**, **magenta / orange** protected

CHOMPI and **LOOP** purple on the bass, amber on the drums; LOOP blinks if muted

PLAY green while running · **LOOP** red while recording

x0x · github.com/theotherson/chompi-x0x · a community firmware for CHOMPI

Not an official CHOMPI Club release

1

VOICE & LFO

Pg 1

Level · **CHOMPI**: pan

Pg 2

Accent Level · **CHOMPI**: drum part length

Pg 3

LFO Shape · **CHOMPI**: rate, 4 bars ... 1/32

Pg 4

LFO Target, this voice · **CHOMPI**: depth

One LFO, in time; each voice picks what it moves (below).

2

ATTACK

Pg 1

Attack: click / snap
CHOMPI + Turn: Tuning ±24 st

Pg 2

Kit Filter: low-pass left, high-pass right, off in the middle
CHOMPI + Turn: Resonance

3

DECAY

Pg 1

Decay
CHOMPI + Turn: Feedback FM, grit to glitch

Pg 2

Filter Envelope: each hit sweeps the kit filter
CHOMPI + Turn: its Decay

4

EFFECTS

Pg 1

Reverb Send · **CHOMPI**: size

Pg 2

Delay Send · **CHOMPI**: delay time

Pg 3

Bit Crush · **CHOMPI**: rate

Hold

+ a voice key: that voice in / out of the reverb & delay

5

TEMPO

Turn

Tempo

CHOMPI: Swing

Press

Tap Tempo

6

VOLUME

Pg 1

Volume · **CHOMPI**: drum distortion

Pg 3

Mix drums ↔ bass · **CHOMPI**: effects balance

Pg 4

Compressor · **CHOMPI**: kick sidechain

No tempo page on this side: the purple knob has it.

Voice pages light in the **voice's colour**. The kit filter, its envelope, the effects and the volume knob act on **all** the drums · **CHOMPI + Push 2 s**: reset every page of knobs 1–3.

Step Mode

toggle up

program each voice on its page

BD

SD

LT / HT

CY

CH / OH

VIEW

COPY

PATTERN

CLEAR

1

2

3

4

5

6

7

8/9

10

11

12

13

14

15

16

Voice key

that voice's page; the toms' and hats' keys alternate (again: the other)

Step key

the voice's hit on / off; others' hits dim, accented ones tinted blue

ACCENT

the accent page · **hold 2 s**: unmute every voice

CHOMPI + voice

mute / unmute (it blinks)

Voice held 2 s

solo: the rest muted; bring them back with CHOMPI. Again when it's the only one: all back

PATTERN

the **drums**' pattern page (lit: slots with drum parts) · **held + key**: both sides

COPY + step key

copy the **drum part** there (its bassline kept) · **+ PATTERN**: A ⇌ B

CLEAR

tap: this voice's hits (or the accents) · hold 1 s: the whole drum part

LOOP

switch to the **bass** · **CHOMPI + LOOP**: mute / unmute the drums

Live Mode

toggle down

every voice its own key

BD

SD

LT

HT

CY

OH

ROLL

QUANTIZE

ERASE

C

D

E

F

G

A

B

C

D

E

F

G

A

B

C

Voice keys

play, and record. Mute and solo as in step mode

Bottom row

the last voice **pitched**, C major an octave either way; recorded at that pitch

LOOP

record on / off · hold 2 s: clear the drum part · **CHOMPI + LOOP**: accent your hits

QUANTIZE

tap: on / off (off keeps your timing) · held + key 1–3: grid 1/16, 1/8, 1/4

ROLL

held + voice keys: they repeat in time · held + key 1–5: 1/8, 1/8T, 1/16, 1/16T, 1/32

ERASE

held + voice keys while it runs: their hits wiped as they pass

CHOMPI, tapped twice

switch to the **bass**

LFO TARGETS · KNOB 1, PG 4

1

off

2

level: dips it, as far as silent

3

pan: swings it either side

4

tuning: an octave either way

5

filter: its own low-pass, swept down from open

6

feedback FM: adds grit

7

decay: longer or shorter, hit by hit

Shapes: off, triangle, ramp up, ramp down, sample & hold; from the top of the bar on PLAY

SOUND

A

drum part in every pattern, with its **own length** (polymeters) and its own pattern

Accent: up to 3× as loud · a closed hat chokes the open one

A

plate reverb; the delay is the bass's, so the echoes line up

MIDI channel 10, GM notes: BD 36 · SD 38 · LT 45 · HT 50 · CY 49 · OH 46 · CH 42

LIGHTS

Voice keys in their colours; the selected one bright; each flashes as it plays

Muted: blinks slowly · **whole kit back**: all flash white

Accent blue · **roll** green · **erase** red, with the voices it's erasing

CHOMPI amber on this side; it flashes on the beat