

1WAVE

Pg 1

Saw / Square

CHOMPI + Turn:

Pulse Width

Pg 2

Pattern Length

CHOMPI + Turn:

Tuning ±1 st

2ENV MOD

Turn

Env Mod

how far the filter sweeps

CHOMPI + Turn:

Accent Level

As on a 303: little below 12 o'clock, a lot above.

3DECAY

Turn

Decay

the sweep's length

CHOMPI + Turn:

Slide Time

4EFFECTS

Pg 1

Delay Mix

CHOMPI:

sync'd time

Push + turn: free time, with a tape swoop

Pg 2

Tape Feedback

CHOMPI:

tone

Pg 3

Chorus → Flanger

CHOMPI:

width

Pg 4

Bit Crush

CHOMPI:

rate

5FILTER

Turn

Cutoff

CHOMPI:

Resonance

Press

Tap Tempo

Its two lights flash the eighth notes, left and right.

6VOLUME

Pg 1

Volume

CHOMPI:

drive

Pg 2

Tempo

CHOMPI:

swing

Pg 3

Mix drums ↔ bass

CHOMPI:

effects balance

Pg 4

Compressor

CHOMPI:

kick sidechain

Press a knob: next page · **CHOMPI + Press**: reset that page · **CHOMPI + Push 2 s**: reset every page (knobs 1–3) · Knobs **accelerate**: click slowly for fine steps, spin for the whole range.

Step Mode

toggle up

build the pattern one step at a time

DOWN

UP

ACCENT

SLIDE

TIE

VIEW

TRANSPOSE

COPY

PATTERN

CLEAR

1

2

3

4

5

6

7

8/9

10

11

12

13

14

15

16

Step key

select a step; again: on / off. Middle C is step 8 or 9

CHOMPI + any key

set the selected step's note (the keybed is a keyboard)

DOWN ... TIE

a page: step keys toggle octave down / up, accent, slide, tie

TRANSPOSE

keys set the transpose. Leave: tap a key twice, or hold 2 s

PATTERN

the bass's pattern page: **A**, or **B** with CHOMPI held. Running, a pick waits for the bar; again: now

PATTERN held + key

on the page: **both** bass and drums there, together at the bar

PATTERN held 2 s

write protect, while stopped: play freely, nothing saves

Pattern key held 2 s

export every pattern as MIDI to `/X0X/MIDI`

COPY + step key

copy the pattern there · **+ PATTERN**: to its other side, A ⇌ B

CLEAR

tap: the selected step · hold 1 s: the pattern

LOOP

switch to the **drums** · **CHOMPI + LOOP**: mute / unmute the bass

Live Mode

toggle down

play, record, arpeggiate

OCT -

OCT +

ACCENT

SLIDE

TIE

QUANTIZE

TRANSPOSE

ARP PATT

ARP OCT -

ARP OCT +

Keys

play; overlapping notes **slide**. Top-row functions: with CHOMPI held

LOOP

record on / off · hold 2 s: clear the pattern

Recording, running

notes go in, held notes tie. CHOMPI + accent / slide / tie: on the step playing

Recording, stopped

note entry: each note fills the next step. CHOMPI + the blinking step: a rest

QUANTIZE

on / off · CHOMPI + white key 1–3: grid 1/16, 1/8, 1/4 · hold 2 s: for good

CHOMPI + PLAY

arpeggiator on / off · **CHOMPI + LOOP**: latch

ARP OCT PATT

octaves below / above (0–2); up, down, up-down, random, as played

TRANSPOSE

keys transpose the pattern (or the arp); tap a key twice to leave

CHOMPI, tapped twice

switch to the **drums** (in either mode)

PATTERNS & THE CARD

16 patterns, **A** and **B** sides; each holds a bassline **and** a drum part, and the two sides can play **different patterns**

Edits save to `/X0X` by themselves, unless write-protected

Import: `3B.mid` into `/X0X/IMPORT`, then power on (drums: channel 10)

BASS & DRUMS

Both always play: **LOOP** (step mode) or **CHOMPI tapped twice** picks which you edit

CHOMPI + LOOP (step mode): mute the side you're on

Volume Pg 3: **mix** · **CHOMPI**: **effects balance** · Pg 4: **compressor** · **CHOMPI**: each kick ducks the rest

LIGHTS

Steps red; accent bright, tie dim · **patterns A / B**, **magenta / orange** protected

CHOMPI and **LOOP** purple on the bass, amber on the drums; LOOP blinks if muted

PLAY green while running · **LOOP** red while recording

x0x · github.com/theotherson/chompi-x0x · a community firmware for CHOMPI

Not an official CHOMPI Club release

1 VOICE & LFO

Pg 1 🔴 **Level** · **CHOMPI**: pan

Pg 2 🔵 **Accent Level** · **CHOMPI**: drum part length

Pg 3 🟢 **LFO Speed**, 4 bars ... 1/32 · **CHOMPI**: shape

Pg 4 🟡 **LFO Depth**, this voice · **CHOMPI**: target

One LFO, in time; each voice picks what it moves (below).

2 ATTACK

Pg 1 🔴 **Attack**: click / snap
CHOMPI + Turn: Tuning ±24 st

Pg 2 ⬜ **Kit Filter**: low-pass left, high-pass right, off in the middle

3 DECAY

Pg 1 🔴 **Decay**
CHOMPI + Turn: Feedback FM, grit to glitch

Pg 2 🟡 **Filter Envelope**: each hit sweeps the kit filter
CHOMPI + Turn: its Decay

4 EFFECTS

Pg 1 🔵 **Reverb Send** · **CHOMPI**: size

Pg 2 🟢 **Delay Send** · **CHOMPI**: delay time

Pg 3 🟢 **Bit Crush** · **CHOMPI**: rate

Hold ⬜ **+ a voice key**: that voice in / out of the reverb & delay

5 TEMPO

Turn 🟡 **Tempo**

🟡 **CHOMPI**: Swing

Press ⬜ **Tap Tempo**

6 VOLUME

Pg 1 ⬜ **Volume** · **CHOMPI**: drum distortion

Pg 3 🟡 **Mix** drums ↔ bass · **CHOMPI**: effects balance

Pg 4 🟢 **Compressor** · **CHOMPI**: kick sidechain

No tempo page on this side: the purple knob has it.

Voice pages light in the **voice's colour**. The kit filter, its envelope, the effects and the volume knob act on **all** the drums · **CHOMPI + Push 2 s**: reset every page of knobs 1–3.

Step Mode toggle up program each voice on its page

BD

SD

LT / HT

CY

CH / OH

VIEW

COPY

PATTERN

CLEAR

1

2

3

4

5

6

7

8/9

10

11

12

13

14

15

16

Voice key

Step key

ACCENT

CHOMPI + voice

Voice held 2 s

PATTERN

COPY + step key

CLEAR

LOOP

that voice's page; the toms' and hats' keys alternate (again: the other)

the voice's hit on / off; others' hits dim, accented ones tinted blue

the accent page · **hold 2 s**: unmute every voice

mute / unmute (it blinks)

solo: the rest muted; bring them back with CHOMPI. Again when it's the only one: all back

the **drums**' pattern page (lit: slots with drum parts) · **held + key**: both sides

copy the **drum part** there (its bassline kept) · **+ PATTERN**: A ⇌ B

tap: this voice's hits (or the accents) · hold 1 s: the whole drum part

switch to the **bass** · **CHOMPI + LOOP**: mute / unmute the drums

Live Mode toggle down every voice its own key

BD

SD

LT

HT

CY

OH

ROLL

QUANTIZE

ERASE

C

D

E

F

G

A

B

C

D

E

F

G

A

B

C

Voice keys

Bottom row

LOOP

QUANTIZE

ROLL

ERASE

CHOMPI, tapped twice

play, and record. Mute and solo as in step mode

the last voice **pitched**, C major an octave either way; recorded at that pitch

record on / off · hold 2 s: clear the drum part · **CHOMPI + LOOP**: accent your hits

tap: on / off (off keeps your timing) · held + key 1–3: grid 1/16, 1/8, 1/4

held + voice keys: they repeat in time · held + key 1–5: 1/8, 1/8T, 1/16, 1/16T, 1/32

held + voice keys while it runs: their hits wiped as they pass

switch to the **bass**

LFO TARGETS · CHOMPI + KNOB 1, PG 4

1 off · 2 level: dips it, as far as silent · 3 pan: swings it either side

4 tuning: an octave either way · 5 filter: its own low-pass, swept down from open

6 feedback FM: adds grit · 7 decay: longer or shorter, hit by hit

Shapes: off, triangle, ramp up, ramp down, sample & hold; from the top of the bar on PLAY

SOUND

A drum part in every pattern, with its **own length** (polymeters) and its own pattern

Accent: up to 3× as loud · a closed hat chokes the open one

A plate reverb; the delay is the bass's, so the echoes line up

MIDI channel 10, GM notes: BD 36 · SD 38 · LT 45 · HT 50 · CY 49 · OH 46 · CH 42

LIGHTS

🔴 **Voice keys** in their colours; the selected one bright; each flashes as it plays

⬜ **Muted**: blinks slowly · **whole kit back**: all flash white

🔵 **Accent blue** · 🟢 **roll green** · 🔴 **erase red**, with the voices it's erasing

🟡 **CHOMPI** amber on this side; it flashes on the beat

x0x · github.com/theotherson/chompi-x0x · a community firmware for CHOMPI

Not an official CHOMPI Club release