






Serial RS232, IDC-10 to IDC-10















BUZZER +5V ∱ LS1 BUZZER Q17 2N3904 R68 W 1K ⊸JBUZZ GND LCD 4x20 CHAR DS1 0.1uF||C51 D€ -₽8 VSS 1
VDD 2
VO 3
RS 4
R/W 5
6 7
DD 7
DD 9
DD 11
DS 12
D6 13
D7 14
LED+ 15
LED- 16 — disp_contr — disp_regsel — disp_rw — disp_op_ena -DISP_DB0
-DISP_DB1
-DISP_DB2
-DISP_DB3 -dDISP_BACKL LEFT S1E UP RIGHT DOWN **PUSH BUTTONS** UP S1B RIGHT S1C 10 05 SW_NAVI DOWN S1D 10 06 SW_NAVI - □PBROW_DRV0 - □PBROW_DRV1 BIG-RIGHT BIG-LEFT PUSH SV_PUSH PUSH S1A 10 03 SW_NAVI SW_PUSH —DPBCOL_SENO —DPBCOL_SEN1 —DPBCOL_SEN2 —DPBCOL_SEN3 PS/2 ₹89% \$4.7k . \$R99 \$4.7k --◇PS2_DAT --◇PS2_CLK MINIDIN6 J18





CONFIGURATION CONTROLLER

