

Troubleshooting: Device does not power on

1. Ensure the power cable is firmly connected to the AC outlet.
2. Check that the outlet is providing power by testing with another device.
3. Hold the power button for 10 seconds to perform a hard reset.
4. If the LED indicator is red, the internal battery may be depleted.
5. Connect the charger for at least 30 minutes before retrying.

Troubleshooting: Wi-Fi connectivity issue

1. Verify the router is broadcasting on 2.4 GHz.
2. Reset network settings from Settings > Network > Reset.
3. Move the device within 10 meters of the router.

Error Codes

E01: Overheating. Turn off and wait 15 minutes to cool.

E02: Firmware corruption. Reflash via USB recovery mode.

E03: Sensor calibration required. Access Settings > Calibrate.

E04: Low battery. Charge the device.

Maintenance

Clean the exterior with a dry microfiber cloth. Do not use solvents.

Store between -10 C and 40 C. Keep away from direct sunlight.