

BrewMaster Pro X500

Programmable Espresso & Drip Coffee Machine
USER MANUAL & QUICK REFERENCE GUIDE

Model: BM-X500-B / BM-X500-S

Document Version: 3.2 | Revision Date: March 2026

Manufactured by: Aurelia Home Appliances Pvt. Ltd.

Please read this manual carefully before first use and retain it for future reference.

Table of Contents

1. Safety Information	3
2. Package Contents & Product Overview	3
3. Control Panel & Display Icons	4
4. Installation & First-Time Setup	5
5. Operating Instructions	5
6. Brewing Modes Explained	6
7. Cleaning & Descaling	7
8. Maintenance Schedule	8
9. Troubleshooting Guide	8
10. Technical Specifications	9
11. Warranty Information	9
12. Frequently Asked Questions (FAQ)	10

1. Safety Information

Read all instructions before operating the BrewMaster Pro X500. Failure to follow these safety guidelines may result in fire, electric shock, burns, or personal injury.

- Do not immerse the power cord, plug, or main unit in water or any other liquid.
- Place the machine on a stable, heat-resistant, level surface away from the edge of the counter.
- Do not operate the appliance if the power cord or plug is damaged, or after the appliance malfunctions.
- Always allow the machine to cool before cleaning or moving it.
- The steam wand and portafilter become extremely hot during use. Use the provided handle and avoid direct skin contact.
- Unplug the unit when not in use for extended periods and before cleaning.
- This appliance is not intended for use by children or persons with reduced physical, sensory, or mental capabilities without supervision.
- Do not use accessories or attachments not recommended by Aurelia Home Appliances, as this may cause injury.
- Never operate the machine without water in the reservoir; running dry can permanently damage the internal pump.

2. Package Contents & Product Overview

Thank you for purchasing the BrewMaster Pro X500. Please verify that the following items are included in your package:

- 1 x BrewMaster Pro X500 main unit
- 1 x Removable 1.8L water reservoir
- 1 x Stainless steel portafilter with single and double shot baskets
- 1 x Milk frothing pitcher (500ml)
- 1 x Cleaning brush and descaling spoon
- 1 x Water filter cartridge
- 1 x Quick start guide and this user manual

Product Overview

The X500 combines a 15-bar Italian pump system with a programmable drip brewing mode, allowing you to prepare espresso, americano, and traditional filter coffee from a single unit. It features a 2.4-inch LCD touch display, five saved user profiles, and an automatic descaling reminder system.

Key Features

- Dual brewing system: 15-bar espresso pump and 950W drip mode
- PID temperature control for consistent extraction ($\pm 1^{\circ}\text{C}$ accuracy)
- Programmable auto-start timer (up to 24 hours in advance)
- Integrated conical burr grinder with 18 grind settings
- Automatic milk frother with 4 texture presets
- Removable drip tray and used-puck container for easy cleaning
- Energy-saving auto-off after 30 minutes of inactivity

3. Control Panel & Display Icons

The control panel is located on the front of the unit above the cup tray. Below is a description of each icon and button.

Icon / Button	Function
Power (■)	Turns the machine on/standby. Hold 3 seconds for full shutdown.
Mode Dial	Rotate to select: Espresso, Americano, Drip, Manual, Clean.
Grind Adjust (+/-)	Increases or decreases grind coarseness in 18 steps.
Cup Size	Cycles between Single (30ml), Double (60ml), Long (110ml).
Milk Froth Button	Activates auto-frothing cycle; press again to stop early.
Timer Icon	Enters programmable auto-brew scheduling menu.
Descale Light (red)	Illuminates when 300 brew cycles have been reached.
Water Drop Icon	Flashes when the reservoir is empty or not seated correctly.
Filter Reset	Hold 5 seconds after replacing the water filter cartridge.

4. Installation & First-Time Setup

- Remove all packaging materials and protective film from the exterior.
- Wash the water reservoir, portafilter, and milk pitcher in warm soapy water before first use.
- Insert the water filter cartridge into the reservoir slot and soak it in water for 5 minutes before installing.
- Fill the reservoir with fresh, cold water up to the MAX line and reinsert it firmly.
- Plug the unit into a grounded 220–240V outlet (or 110–120V for North American models).
- Before brewing your first coffee, run two cycles with water only (no coffee grounds) to rinse the internal lines.

5. Operating Instructions

Brewing Espresso

- Fill the hopper with whole coffee beans, or use the bypass doser for pre-ground coffee.
- Select the Espresso mode using the Mode Dial.
- Choose your cup size (Single, Double, or Long).
- Lock the portafilter into the group head by turning it firmly to the right.
- Press the brew button once to begin extraction; the machine will stop automatically at the selected volume.

Brewing Drip Coffee

- Switch the Mode Dial to Drip.
- Add a paper or reusable filter to the brew basket and add ground coffee (1 tbsp per 180ml recommended).
- Fill the reservoir to your desired number of cups (up to 12).
- Press Start, or use the Timer icon to schedule a future brew time.

6. Brewing Modes Explained

Mode	Water Temp	Pressure	Typical Use
Espresso	92–96°C	15 bar	Single/double shots, base for milk drinks
Americano	88–92°C	15 bar + dilution	Espresso shot diluted with hot water
Drip	94–98°C	Gravity fed	Traditional filter coffee, 2–12 cups
Manual	User set	User set	Advanced users adjusting time/pressure
Clean	Ambient/Hot rinse	Low	Automated rinse and descale cycle

Choosing a Grind Setting

Grind coarseness directly affects extraction time and flavor. As a general guide:

- Settings 1–5 (Fine): Best for espresso; produces a slower, more concentrated extraction.
- Settings 6–12 (Medium): Suitable for Americano and pour-over style brewing.
- Settings 13–18 (Coarse): Best for drip mode and French-press style grounds.

Milk Frothing Presets

- Preset 1 – Cold Foam: For iced beverages, no heating applied.
- Preset 2 – Latte Texture: Micro-foam, heated to 55°C.
- Preset 3 – Cappuccino Texture: Denser foam, heated to 60°C.
- Preset 4 – Hot Chocolate Mode: Heats milk to 65°C without frothing.

7. Cleaning & Descaling

Daily Cleaning

- Empty and rinse the drip tray and used-puck container after each use.
- Wipe the steam wand with a damp cloth immediately after frothing milk to prevent residue buildup.
- Remove and rinse the portafilter and brew basket under warm water.

Weekly Cleaning

- Run the 'Clean' mode cycle using only water to flush the internal brew group.
- Wash the milk pitcher and frothing wand attachment with warm soapy water.
- Wipe down the water reservoir and check for mineral buildup.

Descaling Procedure (Every 300 Cycles or 3 Months)

When the red Descale Light illuminates, follow these steps:

- Empty the water reservoir completely.
- Mix the provided descaling solution (or food-grade citric acid) with water according to the ratio printed on the packet.
- Pour the solution into the reservoir and select 'Clean' mode, then choose the Descale sub-option.
- Allow the full cycle to complete; this takes approximately 20 minutes and includes an automatic rinse phase.
- Run two additional cycles with clean water only to remove any residual descaling solution.
- Replace the water filter cartridge if it has been in use for more than 2 months.

8. Maintenance Schedule

Task	Frequency
Empty drip tray & puck container	After every use
Clean steam wand	After every milk use
Rinse portafilter & basket	Daily
Wipe exterior & reservoir	Weekly
Replace water filter cartridge	Every 2 months
Full descaling cycle	Every 300 brews / 3 months
Replace burr grinder (if worn)	Every 2–3 years of regular use

9. Troubleshooting Guide

Problem	Possible Cause	Solution
Machine won't power on	Not plugged in / outlet issue	Check power cord and outlet; try a different socket
No water flow during brew	Reservoir empty or airlock	Refill reservoir; run Clean cycle to prime the pump
Coffee tastes weak	Grind too coarse or under-dosed	Use a finer grind setting or increase coffee dose
Coffee tastes bitter/burnt	Grind too fine or over-extraction	Use a coarser grind; reduce brew volume
Steam wand not frothing	Wand clogged with dried milk	Soak nozzle in warm water; clear with cleaning pin
Red descale light won't turn off	Filter reset not performed	Hold Filter Reset button for 5 seconds after descaling
Portafilter leaks during brew	Worn gasket or misalignment	Realign portafilter; replace group head gasket if worn
Grinder makes loud grinding noise	Foreign object or dry beans	Power off, clear hopper, inspect burrs for debris

10. Technical Specifications

Specification	Detail
Model Number	BM-X500-B / BM-X500-S
Power Rating	1350W (Boiler) / 950W (Drip element)
Voltage	220–240V ~ 50/60Hz (also available 110–120V)
Pump Pressure	15 bar
Water Reservoir Capacity	1.8 Liters
Bean Hopper Capacity	250 grams
Milk Pitcher Capacity	500 ml
Dimensions (W x D x H)	28cm x 38cm x 40cm
Weight	8.6 kg
Display	2.4-inch color touch LCD
Auto Shut-off	30 minutes of inactivity
Warranty Period	2 years limited (see Section 11)

11. Warranty Information

Aurelia Home Appliances Pvt. Ltd. warrants the BrewMaster Pro X500 against defects in materials and workmanship for a period of 2 years from the date of original purchase, subject to the conditions below.

- Warranty covers the pump, heating element, control board, and display under normal household use.
- Warranty does NOT cover damage caused by descaling neglect, use of non-filtered hard water, or unauthorized repairs.
- The portafilter gasket, water filter cartridge, and burr grinder blades are considered consumable parts and are covered for 6 months only.
- Proof of purchase is required for any warranty claim. Contact authorized service centers listed on the Aurelia website.
- This warranty is void if the appliance has been used commercially rather than for personal household use.

12. Frequently Asked Questions (FAQ)

Q: Can I use pre-ground coffee instead of whole beans?

A: Yes. Use the bypass doser chute located next to the bean hopper to add pre-ground coffee directly, bypassing the internal grinder.

Q: Why does my espresso shot take longer than 30 seconds?

A: This usually indicates a grind that is too fine or an over-filled basket. Try a coarser grind setting or reduce the coffee dose slightly.

Q: Is it safe to leave water in the reservoir overnight?

A: Yes, but for best taste, Aurelia recommends emptying and refilling with fresh water every 24–48 hours, especially in hard water areas.

Q: Can I use the milk frother with plant-based milk?

A: Yes, oat and soy milk work well with the frother. Almond milk may produce less foam due to lower protein content.

Q: What do I do if the descale light comes on but I already descaled?

A: You must manually reset the counter by holding the Filter Reset button for 5 seconds after the descaling cycle completes.

Q: How many user profiles can I save?

A: The X500 supports 5 individual profiles, each storing preferred cup size, grind setting, and milk texture preference.

Q: Can I brew directly into a travel mug?

A: Yes, the drip tray can be lowered or removed entirely to accommodate mugs up to 15cm in height.

Q: What should I do if the machine shows an 'E02' error code?

A: E02 indicates a temperature sensor fault. Power off the unit for 10 minutes and restart. If the error persists, contact an authorized service center.