

- (5) Failure or damage caused by failure to follow the instructions.
- (6) Failure or damage caused by disassembling, repairing or refitting products without authorization of the manufacturer or non-professional personnel. Failure caused by using control series not approved by our factory or matched by our factory.
- (7) Consumables - Our factory reserves the right of final interpretation of this warranty clause.

USER MANUAL



Six-eye swing laser

Thank's for choosing our product,please carefully read this manual and operate it obey the specification in order to make sure you can correctly and safety install,operate and maintain it;We will not take any responsibility for the damage and body injury which are caused by the abnormal operation.



Product Notes:

- 1. In order to ensure the service life of the product, the product should not be placed in a wet or leaky place, not to mention.
- 1 can work in an environment with temperature over 60 degrees
- 2. Do not place the product in a place that is easy to loosen or shake.
- 3. In order to avoid the danger of electric shock, the maintenance request of this product helps professional maintenance.
- 4. When the bulb is used, the change of power supply voltage should not exceed (+10%). If the voltage is too high, the life of the bulb will be shortened. If the voltage is too low, the light color of the bulb will be affected.
- 5. After power failure, it takes 5-10 minutes for the lamp to be fully cooled before it can be re-energized.
- 6. To ensure the normal use of this product, please read the instructions carefully.

Product and Functional Effect Introduction:

·Using those that meet the international standards for using laser generators
Semiconductor laser generator, laser source has long service life and high stability.
Operation is very simple, humanized design, dimming without flicker, jitter and so on.
It can be used in photography, photography, television and other places where lighting requirements are strict.
Classic effects: three-dimensional laser effects such as beam network, vast sea of clouds, 10,000 Zhang light, amplification and reduction, space-time tunnel, etc.Menu function:

Installation instructions for lamps:

The lamp can be placed horizontally, hanging diagonally and upside down, and you must pay attention to the installation method when hanging diagonally and upside down.
Fixing installation of lamps and lanterns: Before positioning the lamps and lanterns, ensure the stability of the installation site. When reversing the hanging installation, make sure that the lamps do not fall down on the support frame, and use safety ropes to pass through the support frame and the lamp handle. Carry out auxiliary hanging; to ensure safety. Prevent the lamp from falling and sliding. When the lamp is installed and debugged, pedestrians are prohibited from passing underneath. Regularly check whether the safety rope is worn and the hook screw is loose. If the hanging installation is unstable, the lamp will be caused The manufacturer does not bear any responsibility for all the consequences of the fall.

safety warning!

208---219	Effect17	220---231	Effect18
232---243	Effect19	244---255	Effect20

- 21 laser self-propelled speed: 0-255 speed from slow to fast
- 22. Motor Self-running: 0-15 No Function 16-45 Self-propelled Effect 1 (X Controlled) 46-75 Self-propelled Effect 2 (X Controlled) 76-105 Self-propelled Effect 3 (X Controlled) 106-135 Self-propelled Effect 4 (X Controllable) 136-165 Self-propelled Effect 5 (X Controllable) 166-195 Self-propelled Effect 6 (X Controlled) 196-225 self-propelled effect 7 (X uncontrollable) 226-255 voice control (226--240X controllable, 241-255x uncontrollable)
- 23. Self-walking speed: Self-walking is fast and slow
- 24. Reset: 0-127 has no function, 128-255 whole machine reset (value stays for 5 seconds)

Motor trim function operation:

Press the MENU key " MENU" to ENTER the menu, press the " Enter" key for at least 3 seconds, the menu interface displays " PAN OFFERS ET" (X - axis motor fine tuning), press the " OK" key to adjust the motor position within the value - 127 - 127, and then press the " OK" key to save the fine tuning value you set.

Maintenance:

- 1. Eliminate the artificial laying of dust, dirt and fume into the lamp body as far as possible, and keep the laser performer clean as possible in the environment.
- 2. Please use professional glass cleaner regularly every month and wash the mirror with flannel cloth to ensure maximum laser brightness output and prolong the service life of the light source.

Warranty Notes

Warranty Period: This product is guaranteed for one year from the date of purchase.
Warranty clauses:
1. Faults arising from the normal use of the product during the warranty period may be repaired free of charge by presenting the warranty card and purchase ticket (photocopy) according to the content of the warranty clause.
2. During the warranty period, the following conditions will be implemented to provide paid maintenance services.
(1) Failure to produce a valid warranty card.
(2) There are omissions, alterations and no sales names on the warranty card.
(3) Faults and damages caused by irresistibility.
(4) Faults and damages caused in transportation and handling.

- 56-80 self-propelled effect 1 (XY uncontrollable)
- 81-105 self-propelled Effect 2 (XY uncontrollable)
- 106-130 self-propelled effect 3 (XY uncontrollable)
- 131 - 155 self-propelled effect 4 (XY uncontrollable)
- 156-180 self-propelled effect 5 (XY uncontrollable)
- 181-205 voice control (XY uncontrollable)
- 206 - 230 self-propelled effect 6 (XY uncontrollable)
- 231 - 255 voice control (XY uncontrollable)

19. Self-propelled Speed: Self-propelled Speed and Acoustic Sensitivity

24CH:

- 1. X-axis motor stroke: 0-255 0-360 positioning
- 2. Fine adjustment of X axis: 0-255
- 3.X-axis motor speed: 0-255 speed from fast to slow
- 4.Y1 axis motor stroke: 0-255 0-106.8 positioning
- 5. Stroke of 5.Y2 Axis Motor: 0-255 0-106.8 Positioning
- 6. Motor stroke of 6.Y3 shaft: 0-255 0-106.8 positioning
- 7. Travel of 7.Y4 Axis Motor: 0-255 0-106.8 Positioning
- 8. Travel of 8.Y5 Axis Motor: 0-255 0-106.8 Positioning
- 9. Travel of 9.Y6 Axis Motor: 0-255 0-106.8 Positioning
- 10. Travel of Y1-Y6 Axis Motor: 0 No Function 1-255 0-106.8 Positioning 11.Y axis motor speed: 0-255 speed from fast to slow
- 12. Main switch: 0-127 off and 128-255 on
- 13. stroboscopic: 0-9 no stroboscopic 10-255 stroboscopic speed from slow to fast
- 14. Laser 1: 0-127 Off 128-255 On
- 15. Laser 2: 0-127 off 128-255 on
- 16. Laser 3: 0-127 Off 128-255 On
- 17. Laser 4: 0-127 off 128-255 on
- 18. Laser 5: 0-127 Off 128-255 Illumination
- 19. laser 6: 0-127 off 128-255 on
- 20. Laser Self-propelled: 0-15 No Function

16---27	Effect1	28---39	Effect2
40---51	Effect3	52---63	Effect4
64---75	Effect5	76---87	Effect6
88---99	Effect7	100---111	Effect8
112---123	Effect9	124---135	Effect10
136---147	Effect11	148---159	Effect12
160---171	Effect13	172---183	Effect14
184---195	Effect15	196---207	Effect16

In order to ensure that you use the lamp safely and correctly, please read the following safety tips carefully before use to avoid unnecessary failures and injuries.

- 1.Non-professionals, do not disassemble the lamps and the accessories in the lamps without authorization.
2. AC power supply: Check whether the local power supply meets the product's rated voltage requirements.
3. This lamp is designed according to the type of electric shock protection. The lamp must be connected to a fully grounded power supply system, and the ground wire of the lamp must be connected to the ground wire of the power supply system. Do not use a power cord with a damaged insulation layer, and do not The power cord is connected to other wires.
4. When the lamp is installed and positioned, the minimum distance between any point on the surface of the lamp and any combustible and explosive objects is 10 meters, and the distance from the irradiated object is 2.5 meters. Please do not install the lamp directly on the surface of burnable materials.
5. The ambient temperature of the lamp: (-10 degrees + 40 degrees), the maximum temperature of the surface of the lamp is 80 degrees, and the lamp should be kept away from liquid substances and humid environments.
- 6.Before using the lamp, make sure that the lamp is well grounded, and do not install and remove any parts of the lamp with power.
- 7.When installing the lamp, the fixing screws must be tightened, with safety cables, and regular inspections.
8. It is recommended that the continuous working time of the lamp should not exceed 10 hours, and the interval between continuous starting of the lamp should not be less than 10 minutes. Otherwise, the lamp will not be triggered normally due to the overheating protection of the lamp.
- 9.During use, if the lamp is abnormal, stop using the lamp in time.
- 10.When the bulb reaches the rated service life, it should be replaced in time, otherwise there will be a dangerous accident of bubble explosion.
- 11.The rotating parts of the lamp and the pasted accessories must be checked regularly, and if there is looseness, the shaking should be reinforced in time to prevent accidents.
- 12.The lamp adopts strong wind cooling, which is easy to accumulate dust. It must be cleaned once a month, especially the heat dissipation vent, otherwise it will be blocked by the accumulation of dust, resulting in poor heat dissipation and abnormalities in the lamp.

Menu functions:

DMX Address	A001 - A512 address code
Channel Mode	11CH,19CH,24CH Channel selection
Show Mode	SOUND AUTO, Effect Selection
Slave Mode	MASTER, SLAVE, Selection of main and auxiliary aircraft
Black Out	YES, NO standby mode
Sound State	ON, OFF Voice control switch
Sound Sense	Sound control sensitivity (0 off, 100 mostsensitive)
Pan Inverse	YES, NO Horizontal Reverse
Tilt1 Inverse	YES, NO Vertical reverse
Tilt2 Inverse	YES, NO Vertical reverse
Tilt3 Inverse	YES, NO Vertical reverse
Tilt4 Inverse	YES, NO Vertical reverse
Tilt5 Inverse	YES, NO Vertical reverse
Tilt6 Inverse	YES, NO Vertical reverse
Back Light	ON, OFF Backlight switch
Auto Test	automatic testing
Fixture Time	0----9999 Time of machine use
Firmware Version	V104 Software Version Number
Defaults	YES, NO Restore factory settings
System Reset	YES, NO Reset of the whole machine

DMX channel function

11CH:

- 1. X-axis motor stroke: 0 - - 2550 - - 360 positioning
- 2. X-axis motor speed: 0-255 speed from fast to slow
- 3. Y1-Y6 axis motor stroke: 0 No function 1-255 0-106.8 positioning
- 4. Y axis motor speed: 0-255 speed from fast to slow
- 5. Main switch: 0-127 off and 128-255 on
- 6. stroboscopic: 0-9 no stroboscopic 10-255 stroboscopic speed from slow to fast
- 7 Laser Self-propelled: 0-15 No Function

16---27	Effect1	28---39	Effect2
40---51	Effect3	52---63	Effect4
64---75	Effect5	76---87	Effect6
88---99	Effect7	100---111	Effect8
112---123	Effect9	124---135	Effect10

136---147	Effect11	148---159	Effect12
160---171	Effect13	172---183	Effect14
184---195	Effect15	196---207	Effect16
208---219	Effect17	220---231	Effect18
232---243	Effect19	244---255	Effect20

- 8. Laser self-propelled speed: 0-255 speed from slow to fast
- 9. Motor Self-running: 0-15 No Function
 - 16-45 Self-propelled Effect 1 (X Controlled)
 - 46-75 Self-propelled Effect 2 (X Controlled)
 - 76-105 Self-propelled Effect 3 (X Controlled)
 - 106-135 Self-propelled Effect 4 (X Controllable)
 - 136-165 Self-propelled Effect 5 (X Controllable)
 - 166-195 Self-propelled Effect 6 (X Controlled)
 - 196-225 self-propelled effect 7 (X uncontrollable)
 - 226-255 voice control (226--240X controllable, 241-255x uncontrollable)
- 10. Self-walking speed: Self-walking is fast and slow
- 11. 11. Reset: 0-127 has no function, 128-255 whole machine reset (value stays for 5 seconds)

19CH:

- 1. X-axis motor stroke: 0 - - 2550 - - 360 positioning
- 2. X-axis motor speed: 0-255 speed from fast to slow
- 3.Y1 Axis Motor Travel: 0-2550 Degree-360 Degree Positioning
- 4.Y2 Axis Motor Travel: 0-2550 degree-360 degree Positioning
- 5.Y3 Axis Motor Travel: 0-2550 degree-360 degree Positioning
- 6.Y4 Axis Motor Travel: 0-2550 degree-360 degree Positioning
- 7.Y5 Axis Motor Travel: 0-2550 degree-360 degree Positioning
- 8.Y6 Axis Motor Travel: 0-2550 degree-360 degree Positioning
- 9.Y-axis motor speed: 0-255 speed from fast to slow
- 10. Master switch: 0-127 shut-off 128-255 turn-on
- 11. stroboscopic: 0-9 stroboscopic-free 10-255 stroboscopic speed from slow to fast
- 12. Laser 1:0-127 turn off 128-255 turn on
- 13. Laser 2:0-127 turn off 128-255 turn on
- 14. Laser 3:0-127 turn off 128-255 turn on
- 15. Laser 4:0-127 turn off 128-255 turn on
- 16. Laser 5:0-127 turn off 128-255 turn on
- 17. Laser 6:0-127 turn off 128-255 turn on
- 18. Walk by yourself: 0-55 is nonfunctional