Frequency and channel frequency table:

Band	CH1	CH2	CH3	CH4	CH5	CH6	CH7	CH8
Band-A	5865	5845	5825	5805	5785	5765	5745	5725
Band-b	5733	5752	5771	5790	5809	5828	5847	5866
Band-E	5705	5685	5665	5645	5885	5905	5925	5945
Band-F	5740	5760	5780	5800	5820	5840	5860	5880
Band-r	5658	5695	5732	5769	5806	5843	5880	5917
Band-U	5325	5348	5366	5384	5402	5420	5438	5456
Band-o	5474	5492	5510	5528	5546	5564	5582	5600
Band-L	5333	5373	5413	5453	5493	5533	5573	5613
Band-H	5653	5693	5733	5773	5813	5853	5893	5933

www.eachine.com

EACHINE

EACHINE ATX03

Super Mini 5.8GHz 72CH FPV Transmitter

0/25mW/50mW/200mW adjustable

Product Instruction Manual

EACHINE

Antenna

Button

LED display

3.2-5.5V
GND
5V OUT
CAM GND
Audio
Video

Super Mini 5.8GHz 72CH FPV Transmitter

Specification and Parameters:
- Output power: 0/25mW/50mW/200mW adjustable
  (Set output power on 0, to avoid frequency interference)
- Input voltage: 3.2–5.5V
- 5V camera supply,570mA(MAX)------25mW
  5V camera supply,450mA(MAX)------50mW
  5V camera supply,360mA(MAX)------200mW
- Video system: NTSC/PAL
- Audio input level: 1Vp-p(1KHZ)
- Audio input impedance: 10KΩ
- Antenna dimensions: 55mm X 5mm diameter
- Antenna: IPEX
- Frequency: 5.8GHz 9 bands 72 channels,
           with Raceband: 5325-5945 MHZ
- Size: 21.43*15.20mm(L*W)
- Weight: 3.5g

Operation Instruction:
1. Powering on the vtx, blue LED display 0, indicating the vtx is powered on, but it is in off status without any transmission.
2. Short-press the button to change channel (CH), digital display will change synchronously. Digital display changes cyclically from 1 to 8.
3. Long-press the button for 2 seconds until digital display flicker. Then short-press the button to change the frequency band (FR), digital display will change synchronously. Digital display changes cyclically from A、b、E、F、r、U、o、L、H.
4. Long-press the button for 5 second until digital display flicker. Then short-press the button to change the power, 25mW/50mW/200mW (one hyphen stands for 25mW, two hyphens stand for 50mW, and three hyphens stand for 200mW).
5. 5 seconds after setting, CH, FR and power will flicker alternately.

Notice: The vtx has memory for settings. To change the settings, please repeat steps as above.

尺寸：80*98mm
材料：128g双铜