

▲ By The Way...

You can get around this limit by re-initializing part of your hard drive in HFS (Macintosh) format. (You can't reformat the whole drive for HFS; System 6 must start up from a ProDOS partition.) However, access to HFS partitions is slower than access to ProDOS partitions, and HFS partitions are inaccessible to older (ProDOS 8) programs like AppleWorks. Our suggestion is to stick to ProDOS unless you're swapping the drive between a IIGS and a Macintosh.

HFS
HARD
DRIVE

Most hard drives can't be "ejected," so the "Eject" and "Put Away" menu options have little effect on them. But some hard drives do have cartridges that can be ejected—45 megabyte drives based on the SyQuest mechanism are the most popular. Ejecting a cartridge manually (using the controls on the drive) ejects it temporarily; the Finder displays a dimmed hard drive icon like other ejected disk icons. (You can use this feature to copy information from one cartridge to another—it's cumbersome but it works.) To eject a cartridge permanently, drag the dimmed icon to the Trash (or do a "Put Away"). If there's more than one partition on the cartridge, you'll need to drag *all* the icons to the Trash.

CD-ROM (Compact Disc) drives behave similarly to cartridge drives. However, many CD-ROMs have both Macintosh (HFS) and High Sierra partitions in addition to the usual ProDOS partitions. (High Sierra is a universal format designed to allow CD-ROM discs to be used on many different models of computers.) All these types of partitions will appear on your desktop. As with cartridge drives, the Finder considers the disk temporarily ejected when you remove the CD-ROM. Drag the dimmed partitions to the Trash to permanently eject them.

Working With Network Volumes

If you're on an AppleShare network, you'll probably have shared disks (or network volumes) on your Finder desktop. The process of telling the IIGS which network volumes you want to use is called logging on to the AppleShare file server, or mounting the network volumes. It's accomplished from the AppleShare control panel.

To unmount a network volume, just drag it to the trash, or Eject it or do a Put Away. (Eject and Put Away have identical effects on network volumes.)

Note!

Since all AppleShare servers are Macintosh computers, network volumes follow the same naming rules as Macintosh disks. Disk names can be up to 27 characters in length and can contain any character but colons; file and folder names also cannot contain colons and can be up to 31 characters long.