CHECKING THE OIL LEVEL OF THE Engine

Make sure the engine oil nival is! between the "1" (low) and "F*Wleno) of the sale of the () while the motorcycle is in position. vertical tion.

(a) CAUTION:

Mo never get the motor cyclist up and running when the engine oil level is below "L" (low) mark in the inspection window.

Never exceed the "F" mark (lena) and the nivol de ací.