[Switch Interlocking. Bracket — [Apropid operation, Side 'on or

## TO START THE ENGINE

- (1) Make sure the fuel tap is in the "ON" position and the switch engine stop in the "RUN" position.
- (2). I insert the lave on the switch turn it on and put it in the "ON" position.
- (3). Put the transmission to a standstill