

INTERRUPTOR DEL MOTOR DE ARRANQUE ELECTRICO 3

El motor de arranque empezará a girar cuando presione este interruptor.

bring Migrad

START "ENGINE" SWITCH ELECTRICY Y)

The starter will start spinning when pre- use this switch, $31\,$