When the engine is hot:

- (1). Opening the throttle handle enters $1/8\ 1/4$ back.
- (2). Press the starter switch Electric.

NOTE; The operation of the strangulation system carburetor is not necessary when the engine be hot